


NetVanta T1/FT1 + DSX-1 Network Interface Module (NIM) P/N 1202863L1



SPECIFICATIONS

Operating Modes	Frame Relay, Multilink Frame Relay, PPP, Multilink PPP, HDLC
T1/FT1 Interface	Supported Standards: AT&T TR 62411, AT&T TR 54016, Bellcore TR 194, ANSI T1.403 Line Rate: 1.544 Mbps \pm 75 bps Line Code: AMI or B8ZS Framing: D4 (SF) or ESF FT1 Line Rate: DS0 channelized (multiples of 56/64 kbps) Input Signal: 0 to -36 dB (DS1) Line Build-Out: 0, -7.5, -15, -22.5 dB (long); 0 to 655 ft (short) Connector: RJ-48C DS0 Assignment: Programmable
DSX-1 Interface	Supported Standards: ANSI T1.102 Line Rate: 1.544 Mbps DSX Receiver Input Range: -10 dBdsx to +6 dBdsx Capacity: 1 to 24 DS0s Line Codes: AMI, B8ZS DSX-1 Interface to PBX Framing: D4 (SF) or ESF Line Length: 0 to 655 ft and -7.5 dB Connector: RJ-48C
Clock Source	Network, Internal, and through
Diagnostics	Test Pattern Generation and Detection: QRSS, 511, all ones, all zeros Network loopbacks (local and remote); responds to both inband and FDL loop codes (T1 interface only) Alarm generation and detection Network and user sets of performance data (15 minutes and 24 hours)
Compliance	FCC Part 15 Class A, EN 55022 Class A ACTA/FCC Part 68, IC CS-03 UL/CUL 60950
Physical	Dimensions: 2.75-inch W x 4.25-inch D Operating Temperature: 0°C to 50°C Storage Temperature: -20°C to 70°C Relative Humidity: Up to 95 percent, noncondensing

INSTALLATION INSTRUCTIONS

1. Remove the power from the unit.
2. Slide the option module into the option slot until the module is firmly seated against the chassis.
3. Secure the pins at both edges of the module.
4. Connect the cables to the associated device(s).
5. Complete installation of the base unit.
6. Restore power to the unit.



NetVanta modules should be installed only in NetVanta Series products.

WAN-T1 NETWORK (RJ-48C) CONNECTION PINOUTS

Pin	Name	Description
1	R1	Receive data from the network - Ring 1
2	T1	Transmit data from the network - Tip 1
3	—	Unused
4	R	Transmit data toward the network - Ring
5	T	Transmit data toward the network - Tip
6-8	—	Unused

DSX-1 (RJ-48C) CONNECTION PINOUTS

Pin	Name	Description
1	R	Transmit data toward the DTE - Ring
2	T	Transmit data toward the DTE - Tip
3	—	Unused
4	R1	Receive data from the DTE - Ring 1
5	T1	Receive data from the DTE - Tip 1
6-8	—	Unused



*An optional Dial Backup Interface Module (DIM) is required for dial backup applications.
For a description of the DBU pinouts, refer to the Quick Start Guide included with your DIM shipment.*



***Important:** For additional details on product features, specifications, installation, and safety, refer to the appropriate Hardware Installation Guide on the ADTRAN OS System Documentation CD shipped with the base unit and available online at www.adtran.com.*

T1/FT1 + DSX-1 NIM COMMANDS

clock source [internal | line* | through]

Configures the source timing used for the interface. Use the no form of this command to return to the default value.

internal	Configures the unit to provide clocking using the internal oscillator.
line*	Configures the unit to recover clocking from the T1 circuit.
through	Configures the unit to recover clocking from the circuit connected to the DSX-1 interface.

coding [ami | b8zs*]

Configures the line coding for a T1 physical interface. This setting must match the line coding supplied on the circuit by the service provider.

ami	Configures the line coding for alternate mark inversion (AMI).
b8zs*	Configures the line coding for bipolar eight zero substitution (B8ZS).

fdl [ansi* | at | none]

Configures the format for the facility data link (FDL) channel on the T1 circuit. Use the no form of this command to return to the default value.

ansi*	Configures the FDL for ANSI T1.403 standard.
at	Configures the FDL for AT&T TR 54010 standard.
none	Disables FDL on this circuit.

framing [d4 | esf*]

Configures the framing format for the T1 interface. This parameter should match the framing format supplied by your network provider. Use the no form of this command to return to the default value.

d4	Specifies D4 superframe (SF) format.
esf*	Specifies extended superframe (ESF) format.

lbo [long <-22.5, -15, -7.5, 0> | short <0 to 655>]

Configures the line build out (LBO) for the T1 interface. Use the no form of this command to return to the default value.

long <-22.5, -15, -7.5, 0>	Configures the LBO (in dB) for T1 interfaces with cable lengths greater than 655 feet. Choices are -22.5, -15, -7.5, and 0 dB.
short <0 to 655>	Configures the LBO (in feet) for T1 interfaces with cable lengths less than 655 feet. Range is 0 to 655 feet.

loopback network [line | payload]

Initiates a loopback on the interface toward the network. Use the no form of this command to deactivate the loopback.

line	Initiates a metallic loopback of the physical T1 network interface.
payload	Initiates a loopback of the T1 framer (CSU portion) of the T1 network interface.

loopback remote line [fd | inband]

Sends a loopback code to the remote unit to initiate a line loopback. Use the no form of this command to send a loopdown code to the remote unit to deactivate the loopback.

fd	Uses the facility data link (FDL) to initiate a full 1.544 Mbps physical (metallic) loopback of the signal received by the remote unit from the network (T1 interface only).
-----------	--

inband	Uses the inband channel to initiate a full 1.544 Mbps physical (metallic) loopback of the signal received from the network.
---------------	---

loopback remote payload

Sends a loopback code to the remote unit to initiate a payload loopback. A payload loopback is a 1.538 Mbps loopback of the payload data received from the network maintaining bit-sequence integrity for the information bits by synchronizing (regenerating) the timing. Use the no form of this command to send a loopdown code to the remote unit to deactivate the loopback.

remote-alarm [ra]

Selects the alarm signaling type to be sent when a loss of frame is detected on the T1 receive signal. Use the no form of this command to disable all transmitted alarms.

ra	Specifies sending a remote alarm indication (RAI) in response to a loss of frame. Also prevents a received RAI from causing a change in interface operational status.
-----------	---

remote-loopback

Configures the interface to respond to loopbacks initiated by a remote unit (or service provider). Use the no form of this command to disable this feature.

show test-pattern

Displays results from test patterns inserted using the test-pattern command.

signaling-mode [message-oriented | none | robbed-bit*]

Configures the signaling type (robbed-bit for voice or clear channel for data) for the DSOs mapped to the DSX-1 port.

message-oriented	Specifies clear channel signaling on Channel 24 only. Use this signaling type with OSIG installations.
none	Specifies clear channel signaling on all 24 DSOs. Use this signaling type with data-only or PRI DSX-1 installations.
robbed-bit*	Specifies robbed bit signaling on all DSOs. Use this signaling type for voice-only DSX-1 applications.

snmp trap link-status

Controls the Simple Network Management Protocol (SNMP) variable linkUpDownTrapEnable (RFC2583) to enable (or disable) the interface to send SNMP traps when there is an interface status change. Use the no form of this command to disable this trap.

tdm-group <group number> timeslot <1-24> speed [56 | 64*]

Creates a group of contiguous DSOs on this interface to be used during the cross-connected process.

<group number>	Identifies the created TDM group (valid range: 1 to 255).
timeslots <1-24>	Specifies the DSOs to be used in the TDM group. This can be entered as a single number representing one of the 24 T1 channel timeslots or as a contiguous group of DSOs. (For example, 1-10 specifies the first 10 channels of the T1.)

speed [56 64*]	Optional. Specifies the individual DSO rate on the T1 and DSX-1 interfaces to be 56 kbps or 64 kbps. The default speed is 64 kbps.
-------------------------	--

test-pattern [clear | insert | ones | p511 | qrs | zeros]

Activates the built-in pattern generator and begin sending the specified test pattern. Can be used to verify a data path when used in conjunction with an active loopback. Use the no form of this command to cease pattern generation.

clear	Clears the test pattern error count.
insert	Inserts an error into the currently active test pattern. Display the injected error result using the show test-pattern command.
ones	Generates a test pattern of continuous ones.
p511	Generates a test pattern of repeating ones and zeros.
qrs	Generates a test pattern of random ones and zeros.
zeros	Generates a test pattern of continuous zeros.

* Indicates default values.