



TOTAL ACCESS 600 SERIES System Manual

4200641L1	Total Access 604, T1 TDM
4200641L2	Total Access 604, T1 ATM
4200644L1	Total Access 604, ADSL
4200642L1	Total Access 604, SDSL
4200643L1	Total Access 604, SHDSL
4200681L1	Total Access 608, T1 TDM
4200681L2	Total Access 608, T1 ATM
4200684L1	Total Access 608, ADSL
4200682L1	Total Access 608, SDSL
4200683L1	Total Access 608, SHDSL
4200612L1#TDM	Total Access 612, T1 TDM
4200612L2#TDM	Total Access 612, T1 TDM with Echo Cancellation, ADPCM Module
4200612L1#ATM	Total Access 612, T1 ATM
4200612L2	Total Access 612, SDSL
4200612L3	Total Access 612, SHDSL
4200616L1#TDM	Total Access 616, T1 TDM
4200616L2#TDM	Total Access 616, T1 TDM with Echo Cancellation, ADPCM Module
4200616L1#ATM	Total Access 616, T1 ATM
4200616L2	Total Access 616, SDSL
4200616L3	Total Access 616, SHDSL
4200624L1#TDM	Total Access 624, T1 TDM
4200624L2#TDM	Total Access 624, T1 TDM with Echo Cancellation, ADPCM Module
4200624L1#ATM	Total Access 624, T1 ATM
4200624L2	Total Access 624, SDSL
4200624L3	Total Access 624, SHDSL

Trademarks

Any brand names and product names included in this manual are trademarks, registered trademarks, or trade names of their respective holders.

To the Holder of the Manual

The contents of this manual are current as of the date of publication. ADTRAN reserves the right to change the contents without prior notice.

In no event will ADTRAN be liable for any special, incidental, or consequential damages or for commercial losses even if ADTRAN has been advised thereof as a result of issue of this publication.



901 Explorer Boulevard
P.O. Box 140000
Huntsville, AL 35814-4000
Phone: (256) 963-8000

©2002 ADTRAN, Inc.
All Rights Reserved.
Printed in U.S.A.

About this Manual

This manual provides a complete description of the Total Access 600 Series system and system software. The purpose of this manual is to provide the technician, system administrator, and manager with general and specific information related to the planning, installation, operation, and maintenance of the Total Access 600 Series. This manual is arranged so that needed information can be quickly and easily found. The following is an overview of the contents.

Section 1	System Description	15
	Provides managers with a system overview, features and benefits, and a list of resource modules supported.	
Section 2	Engineering Guidelines	23
	Provides equipment dimensions, power requirements, front panel design, rear panel design, LEDs, and at-a-glance specifications.	
Section 3	Network Turnup Procedure	39
	Provides shipment contents list, grounding instructions, mounting options, and specifics of supplying power to the unit.	
Section 4	User Interface Guides (UIG)	45
	Provides detailed definitions, ranges, and default values for all ATM and TDM menu options.	
Section 5	Detail Level Procedures.	355
	Provides instructions on how to perform basic unit functions such as: Connection Log-in Adding/removing telnet users and changing passwords Setting IP parameters and verifying LAN communication Telnet Firmware upgrade Saving and loading config files	
Section 6	ADTRAN Utilities	413
	Provides instructions for configuring and using the ADTRAN Utilities software programs including Telnet, VT100, and TFTP.	
Section 7	MIB	423
	Provides the MIB compilation order and the MIBs, Traps, and MIB Variables supported by the unit.	

Revision History

This is the first issue of this manual.



In this manual, unit refers to the Total Access 604, 608, 612, 616, and 624. If a statement only applies to a particular unit, the unit will be specified by number.



Notes provide additional useful information.



Cautions signify information that could prevent service interruption.



Warnings provide information that could prevent damage to the equipment or endangerment to human life.

Safety Instructions

When using your telephone equipment, please follow these basic safety precautions to reduce the risk of fire, electrical shock, or personal injury:

1. Do not use this product near water, such as a bathtub, wash bowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.
2. Avoid using a telephone (other than a cordless-type) during an electrical storm. There is a remote risk of shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord, power supply, and/or batteries indicated in the manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for special disposal instructions.

Save These Important Safety Instructions

FCC regulations require that the following information be provided in this manual:

1. This equipment complies with Part 68 of FCC rules. On the back of the equipment housing is a label showing the FCC registration number and ringer equivalence number (REN). If requested, provide this information to the telephone company.
2. If this equipment causes harm to the telephone network, the telephone company may temporarily discontinue service. If possible, advance notification is given; otherwise, notification is given as soon as possible. The telephone company will advise the customer of the right to file a complaint with the FCC.
3. The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper operation of this equipment. Advance notification and the opportunity to maintain uninterrupted service are given.
4. If experiencing difficulty with this equipment, please contact ADTRAN for repair and warranty information. The telephone company may require this equipment to be disconnected from the network until the problem is corrected or it is certain the equipment is not malfunctioning.
5. This unit contains no user-serviceable parts.
6. An FCC compliant telephone cord with a modular plug is provided with this equipment. This equipment is designed to be connected to the telephone network or premises wiring using an FCC compatible modular jack, which is Part 68 compliant.
7. The following information may be required when applying to the local telephone company for leased line facilities.

Product	Reg. Number	Service Type	REN/SOC	FIC	USOC
TA 600 Series T1 Products	HDCUSA-44556-DE-N	1.544 Mbps - SF 1.544 Mbps - SF and B8ZS 1.544 Mbps - ESF 1.544 Mbps - ESF and B8ZS	6.0N	04DU9-BN 04DU9-DN 04DU9-1KN 04DU9-1SN	RJ-48 C
		Analog Loop Start/ Ground Start Service	0.1B/9.0F	02LS2 02GS2	RJ-11C
TA 600 Series SDSL & SHDSL Products	HDCUSA-44560-OT-N	Analog Loop Start/Ground Start Service	0.1B/9.0F	02LS2 02GS2	RJ-11C
TA 600 Series ADSL Products	US: HDCDL02B4200644L1	Analog Loop Start/Ground Start Service	0.1B/9.0F	02LS2 02GS2	RJ-11C
		ADSL Service	0.2B/9.0F	02LS2	

8. The REN is useful in determining the quantity of devices you may connect to your telephone line and still have all of those devices ring when your number is called. In most areas, the sum of the RENs of all devices should not exceed five. To be certain of the number of devices you may connect to your line as determined by the REN, call your telephone company to determine the maximum REN for your calling area.
9. This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs. Contact your state public utility commission or corporation commission for information.

Affidavit Requirements for Connection to Digital Services

- An affidavit is required to be given to the telephone company whenever digital terminal equipment without encoded analog content and billing protection is used to transmit digital signals containing encoded analog content which are intended for eventual conversion into voiceband analog signals and transmitted on the network.
- The affidavit shall affirm that either no encoded analog content or billing information is being transmitted or that the output of the device meets Part 68 encoded analog content or billing protection specifications.
- End user/customer will be responsible for filing an affidavit with the local exchange carrier when connecting unprotected customer premise equipment (CPE) to 1.544 Mbps or subrate digital services.

Until such time as subrate digital terminal equipment is registered for voice applications, the affidavit requirement for subrate services is waived.

**Affidavit for Connection of Customer Premises Equipment
to 1.544 Mbps and/or Subrate Digital Services**

For the work to be performed in the certified territory of _____ (telco name)

State of _____

County of _____

I, _____ (name), _____ (business address),
_____ (telephone number) being duly sworn, state:

I have responsibility for the operation and maintenance of the terminal equipment to be connected to 1.544 Mbps and/or _____ subrate digital services. The terminal equipment to be connected complies with Part 68 of the FCC rules except for the encoded analog content and billing protection specifications. With respect to encoded analog content and billing protection:

- ☐ I attest that all operations associated with the establishment, maintenance, and adjustment of the digital CPE with respect to analog content and encoded billing protection information continuously complies with Part 68 of the FCC Rules and Regulations.
- ☐ The digital CPE does not transmit digital signals containing encoded analog content or billing information which is intended to be decoded within the telecommunications network.
- ☐ The encoded analog content and billing protection is factory set and is not under the control of the customer.

I attest that the operator(s)/maintainer(s) of the digital CPE responsible for the establishment, maintenance, and adjustment of the encoded analog content and billing information has (have) been trained to perform these functions by successfully having completed one of the following (check appropriate blocks):

- ☐ A. A training course provided by the manufacturer/grantee of the equipment used to encode analog signals; or
- ☐ B. A training course provided by the customer or authorized representative, using training materials and instructions provided by the manufacturer/grantee of the equipment used to encode analog signals; or
- ☐ C. An independent training course (e.g., trade school or technical institution) recognized by the manufacturer/grantee of the equipment used to encode analog signals; or
- ☐ D. In lieu of the preceding training requirements, the operator(s)/maintainer(s) is (are) under the control of a supervisor trained in accordance with _____ (circle one) above.

I agree to provide _____ (telco's name) with proper documentation to demonstrate compliance with the information as provided in the preceding paragraph, if so requested.

Signature

Title

Date

Transcribed and sworn to before me

This _____ day of _____, _____

Notary Public

My commission expires:

Federal Communications Commission Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio frequencies. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



Shielded cables must be used with this unit to ensure compliance with Class A FCC limits.

WARNING

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada Compliance Information

Notice: The Industry Canada label applied to the product (identified by the Industry Canada logo or the “IC:” in front of the certification/registration number) signifies that the Industry Canada technical specifications were met.

Notice: The Ringer Equivalence Number (REN) for this terminal equipment is supplied in the documentation or on the product labeling/markings. The REN assigned to each terminal device indicates the maximum number of terminals that can be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices should not exceed five (5).

Canadian Emissions Requirements

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled “Digital Apparatus,” ICES-003 of the Department of Communications.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Class A prescrites dans la norme sur le matériel brouilleur: “Appareils Numériques,” NMB-003 édictée par le ministre des Communications.

Warranty and Customer Service

ADTRAN will repair and return this product within ten years from the date of shipment if it does not meet its published specifications or fails while in service. For detailed warranty, repair, and return information refer to the ADTRAN Equipment Warranty and Repair and Return Policy Procedure.

Return Material Authorization (RMA) is required prior to returning equipment to ADTRAN.

For service, RMA requests, or further information, contact one of the numbers listed at the end of this section.

LIMITED PRODUCT WARRANTY

ADTRAN warrants that for ten years from the date of shipment to Customer, all products manufactured by ADTRAN will be free from defects in materials and workmanship. ADTRAN also warrants that products will conform to the applicable specifications and drawings for such products, as contained in the Product Manual or in ADTRAN's internal specifications and drawings for such products (which may or may not be reflected in the Product Manual). This warranty only applies if Customer gives ADTRAN written notice of defects during the warranty period. Upon such notice, ADTRAN will, at its option, either repair or replace the defective item. If ADTRAN is unable, in a reasonable time, to repair or replace any equipment to a condition as warranted, Customer is entitled to a full refund of the purchase price upon return of the equipment to ADTRAN. This warranty applies only to the original purchaser and is not transferable without ADTRAN's express written permission. This warranty becomes null and void if Customer modifies or alters the equipment in any way, other than as specifically authorized by ADTRAN.

EXCEPT FOR THE LIMITED WARRANTY DESCRIBED ABOVE, THE FOREGOING CONSTITUTES THE SOLE AND EXCLUSIVE REMEDY OF THE CUSTOMER AND THE EXCLUSIVE LIABILITY OF ADTRAN AND IS IN LIEU OF ANY AND ALL OTHER WARRANTIES (EXPRESSED OR IMPLIED). ADTRAN SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES, INCLUDING (WITHOUT LIMITATION), ALL WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THIS EXCLUSION MAY NOT APPLY TO CUSTOMER.

In no event will ADTRAN or its suppliers be liable to the Customer for any incidental, special, punitive, exemplary or consequential damages experienced by either the Customer or a third party (including, but not limited to, loss of data or information, loss of profits, or loss of use). ADTRAN is not liable for damages for any cause whatsoever (whether based in contract, tort, or otherwise) in excess of the amount paid for the item. Some states do not allow the limitation or exclusion of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to the Customer.

Customer Service, Product Support Information, and Training

ADTRAN will repair and return this product if within ten years from the date of shipment the product does not meet its published specification or the product fails while in service.

A return material authorization (RMA) is required prior to returning equipment to ADTRAN. For service, RMA requests, training, or more information, use the contact information given below.

Repair and Return

If you determine that a repair is needed, please contact our Customer and Product Service (CAPS) department to have an RMA number issued. CAPS should also be contacted to obtain information regarding equipment currently in house or possible fees associated with repair.

CAPS Department (256) 963-8722

Identify the RMA number clearly on the package (below address), and return to the following address:

ADTRAN Customer and Product Service
901 Explorer Blvd. (East Tower)
Huntsville, Alabama 35806

RMA # _____

Pre-Sales Inquiries and Applications Support

Your reseller should serve as the first point of contact for support. If additional pre-sales support is needed, the ADTRAN Support web site provides a variety of support services such as a searchable knowledge base, latest product documentation, application briefs, case studies, and a link to submit a question to an Applications Engineer. All of this, and more, is available at:

<http://support.adtran.com>

When needed, further pre-sales assistance is available by calling our Applications Engineering Department.

Applications Engineering (800) 615-1176

Post-Sale Support

Your reseller should serve as the first point of contact for support. If additional support is needed, the ADTRAN Support web site provides a variety of support services such as a searchable knowledge base, updated firmware releases, latest product documentation, service request ticket generation and trouble-shooting tools. All of this, and more, is available at:

<http://support.adtran.com>

When needed, further post-sales assistance is available by calling our Technical Support Center. Please have your unit serial number available when you call.

Technical Support (888) 4ADTRAN

Installation and Maintenance Support

The ADTRAN Custom Extended Services (ACES) program offers multiple types and levels of installation and maintenance services which allow you to choose the kind of assistance you need. This support is available at:

<http://www.adtran.com/aces>

For questions, call the ACES Help Desk.

ACES Help Desk (888) 874-ACES (2237)

Training

The Enterprise Network (EN) Technical Training Department offers training on our most popular products. These courses include overviews on product features and functions while covering applications of ADTRAN's product lines. ADTRAN provides a variety of training options, including customized training and courses taught at our facilities or at your site. For more information about training, please contact your Territory Manager or the Enterprise Training Coordinator.

Training Phone	(800) 615-1176, ext. 7500
Training Fax	(256) 963-6700
Training Email	training@adtran.com

SYSTEM DESCRIPTION

CONTENTS

System Overview	17
Features and Benefits	17
Configuration and Management	17
Firmware Upgradeable	18
Network Interface	18
ATM Support	18
Frame Relay Support	18
Analog Ports	18
Routing Capability	18
Security	19
V.35 DTE Interface	19
Integrated Components	19
Testing	19
IAD Systems	20
T1	20
ADSL	20
SDSL	20
SHDSL	20
Resource Modules	21

1. SYSTEM OVERVIEW

The products of the Total Access 600 Series are Integrated Access Devices (IAD) designed for cost-effective deployment of voice and data services at the customer premises. The Total Access 600 Series benefits integrated communications providers (such as CLECs, ILECs, and ISPs) who require a customer premises device with integrated voice and data functions, and provides a viable migration path from TDM to packet-based technology. These IADs support applications such as VoDSL and VoATM.

The Total Access 600 Series features remote management, built-in IP router, and life-line voice backup. An optional battery backup is also available for many of the models. The units include a Nx56/64 V.35 interface, 10/100BaseT interface, FXS ports, and network interfaces (T1, ADSL, SDSL, and SHDSL). The last two digits of the product name indicate the number of on-board FXS ports. The Total Access 604 contains four FXS ports, the Total Access 608 contains eight FXS ports, etc. The units can provision, test, and provide status for any of the voice and data interfaces. All connections are made via the rear panel.

This line of IADs includes both the ATM and TDM versions of the Total Access 604/608/612/616/624. Until now, the Total Access TDM units have been running firmware version A.03.XX. Recently, A.04.XX has been released to support the TDM Total Access IADs. The development of A.04.XX code is a significant step in the evolution of the Total Access product line, as it allows all Total Access family members to share the same base code. This means that features and fixes are more easily implemented and are propagated across the product line. The TDM User Interface Guide section of this manual represents the A.04 firmware. There are two possible upgrade paths: (1) Upgrading from A.03 to A.04 directly (2) Upgrading from A.03 to A.03.90 (Transition Build) to A.04.



Upgrading from A.03 to A.03.90 (Transition Build) to A.04 will save the unit's configuration. Upgrading from A.03 to A.04 directly (or from A.04 to A.03 directly) will erase the unit's configuration. See DLP-016, A.03 to A.04 Firmware Upgrade for more details.



Units manufactured after October 2002 will not be compatible with some older versions of Total Access 612, 616, and 624 software. Refer to the following information if an older version of software is to be loaded into the unit. For TDM applications, please use software revision A.03.58 or later. For ATM applications, software revision D.01.30 or later is required. Using incompatible software will cause the unit to malfunction. For more information or technical assistance, please call ADTRAN Technical Support at 888-4ADTRAN. Please have the unit serial number available when contacting Technical Support.

2. FEATURES AND BENEFITS

Below is a list of unit features and benefits. Some features are model-dependent.

Configuration and Management

- VT100 Emulation via the Craft port
- Telnet
- SNMP
- Support for VoDSL gateway management systems and firmware download

Firmware Upgradeable

- TFTP download
- XMODEM via Craft port

Network Interface

- T1
- ADSL
- SDSL
- SHDSL

ATM Support

- AAL2 (voice), AAL5 (data, voice)
- 6 PVCs (1 voice, 5 data)
- RFC 1483 (multiprotocol over ATM)
- PPPoA (RFC 2364)
- QoS Support: VBR-rt (voice), UBR (data)
- L.610 F5 OAM loopback
- G.165/G.168 echo cancellation, 8 ms echo tail
- Voice Codes: PCM (G.711), 32k ADPCM (G.726)
- Idle channel suppression

Frame Relay Support

- Copper Mountain CE fragmentation support
- FRF.5 and FRF.8 support (V.35)

Analog Ports

- Analog FXS ports per TR-57, 50-Pin Amp (number of ports is unit dependent)
- Supports popular CLASS™ features
- Modes: FXS Loop Start, FXS Ground Start, TR08 Single, TR08 UVG, DP0, Tandem (E&M)
- Assured Dialtone™ Lifeline POTS port
- Unbalanced ringing, 5 REN per port not to exceed 35 REN (Total Access 612/616/624)
- Balanced ringing, 3.75 REN per port not to exceed 15 REN (Total Access 604/608)
- Fixed 88 Vrms ringer (Total access 612/616/624)
- Programmable ring voltage from 45 Vrms-62 Vrms (Total Access 604/608)
- Distance up to 1000 feet

Routing Capability

- Ethernet: 10/100BaseT (RJ-45)

- IEEE 802.3 and 802.1D (MAC Bridging)
- IP Support: TCP, RIP V1, RIP V2, UDP, ICMP, ARP, UDP Relay, SYSLOG
- PPP Support: LCP, IPCP, BCP
- DHCP Server to LAN, DHCP from network (NAT)
- Copper Mountain Compatible

Security

- PAP, CHAP, EAP, and Radius
- NAT with multi-point to single-point
- Future support of NAT multi-point to multi-point
- PAT with DHCP
- Filtering (Pattern, IP, Bridge)
- Password protection

V.35 DTE Interface

- Data Rate: Nx56 or Nx64 kbps (N=1 to 24)
- Electrical and Mechanical: CCITT V.35, 34-pin
- Frame Relay (FRF.5, FRF.8 capable)

Integrated Components

- IP router
- Life-line voice backup
- Network connection
- 10/100 BaseT connection
- V.35 Nx56/64 DTE interface
- Craft port

Testing

- Local/Remote Loopbacks
- Payloads
- FXS Tests

3. IAD SYSTEMS

The units support a variety of WAN technologies. The units are listed below in categories based on these technologies.

T1

- P/N 4200641L1 Total Access 604 T1 TDM
- P/N 4200641L2 Total Access 604 T1 ATM
- P/N 4200681L1 Total Access 608 T1 TDM
- P/N 4200681L2 Total Access 608 T1 ATM
- P/N 4200612L1#TDM Total Access 612 T1 TDM
- P/N 4200612L1#ATM Total Access 612 T1 ATM
- P/N 4200612L2#TDM Total Access 612 T1 TDM with Echo Cancellation, ADPCM Module
- P/N 4200616L1#TDM Total Access 616 T1 TDM
- P/N 4200616L1#ATM Total Access 616 T1 ATM
- P/N 4200616L2#TDM Total Access 616 T1 TDM with Echo Cancellation, ADPCM Module
- P/N 4200624L1#TDM Total Access 624 T1 TDM
- P/N 4200624L1#ATM Total Access 624 T1 ATM
- P/N 4200624L2#TDM Total Access 624 T1 TDM with Echo Cancellation, ADPCM Module

ADSL

- P/N 4200644L1 Total Access 604 ADSL
- P/N 4200684L1 Total Access 608 ADSL

SDSL

- P/N 4200642L1 Total Access 604 SDSL
- P/N 4200682L1 Total Access 608 SDSL
- P/N 4200612L2 Total Access 612 SDSL
- P/N 4200616L2 Total Access 616 SDSL
- P/N 4200624L2 Total Access 624 SDSL

SHDSL

- P/N 4200643L1 Total Access 604 SHDSL
- P/N 4200683L1 Total Access 608 SHDSL
- P/N 4200612L3 Total Access 612 SHDSL
- P/N 4200616L3 Total Access 616 SHDSL
- P/N 4200624L3 Total Access 624 SHDSL

4. RESOURCE MODULES

Echo Cancellor with ADPCM

The Echo Canceller Module provides G.165/G.168 echo cancellation for voice over ATM applications and is available with Adaptive Differential Pulse Code Modulation (ADPCM). ADPCM is a speech coding method which uses fewer bits than traditional Pulse Code Modulation (PCM), allowing the user to get more analog voice calls on less bandwidth. Echo cancellation and ADPCM resources are built into all Total Access 604/608 units and the third generation Total Access 612/616/624 units (P/N 1203612L1, 1203616L1, and 1203624L1). The Total Access 612/616/624 T1 TDM units (P/N 4200612L1#TDM, 4200616L1#TDM, and 4200624L1#TDM) may be upgraded to include echo cancellation via three methods:

1. The upgrade package may be purchased from ADTRAN. This package includes EC/ADPCM (P/N 1200613L1) and the ADTRAN installation and test. If this package is ordered, the customer must send their TDM 612/616/624 unit back to ADTRAN. Once received the EC/ADPCM module is installed along with the latest VoATM firmware. The upgraded unit is then tested and returned to the customer. Please call ADTRAN CAPs department at 800-9-ADTRAN extension 7722 for this service.
2. An EC/ADPCM module may be purchased separately and installed by the customer. The latest VoATM firmware may be obtained from the ADTRAN website (<http://www.ADTRAN.com>) and loaded into the unit by the customer. For more detailed instructions, refer to DLP-015 *TDM to ATM Upgrade*.
3. For customers who plan to initially operate a TDM application, but eventually upgrade to an ATM application, a Total Access 612/616/624 unit may be purchased with the EC/ADPCM card installed (P/N 4200612L2#TDM, 4200616L2#TDM, 4200642L2#TDM). When the circuit is converted to ATM, the ATM firmware must be obtained from the ADTRAN website (<http://www.ADTRAN.com>) and loaded into the unit by the customer. For more detailed instructions, refer to DLP-015 *TDM to ATM Upgrade*.

ENGINEERING GUIDELINES

CONTENTS

Equipment Dimensions	25
Total Access 604/608	25
Total Access 612/616/624	25
Power Requirements	25
AC Power	25
Reviewing the Front Panel Design	26
Total Access 604/608	26
Total Access 612/616/624	26
Front Panel LEDs	27
Reviewing the Rear Panel Design	30
Voice Connection	31
Life Line Connection	32
NTWK Connection	32
Craft Port	34
10/100BaseT Connection	35
V.35 Connection	35
Battery Backup Connection	36
AC Power Connection	36
DB-9 to RJ Adapter	36
At-A-Glance Specifications	37

FIGURES

Figure 1.	Total Access 604/608 Front Panel	26
Figure 2.	Total Access 612/616/624 Front Panel	26
Figure 3.	Total Access 604/608 Rear Panel	30
Figure 4.	Total Access 612/616/624 Rear Panel	30
Figure 5.	Voice Connector Pin Assignments	31

TABLES

Table 1.	AC Power Requirements	25
Table 2.	Total Access 604/608 TDM Front Panel LEDs	27
Table 3.	Total Access 612/616/624 TDM Front Panel LEDs	28
Table 4.	Total Access 604/608/612/616/624 ATM Front Panel LEDs	29
Table 5.	LIFE LINE Connection Pinout	32
Table 6.	T1 NTWK Connection Pinout	32
Table 7.	ADSL Network Connection Pinout	33
Table 8.	SDSL Network Connection Point	33
Table 9.	SHDSL Network Connection Pinout	33
Table 10.	CRAFT Pinout	34
Table 11.	10/100BaseT Pinout	35
Table 12.	V.35 Interface Pinout	35
Table 13.	DB-9 to RJ Adapter Pinout	36
Table 14.	Specifications	37

1. EQUIPMENT DIMENSIONS

Total Access 604/608

The Total Access 604/608 units measure 11.25" W, 7.5" D, and 2" H and come equipped for table top or wall mount use.

Total Access 612/616/624

The Total Access 612/616/624 units measure 17" W, 8.5" D, and 1.75" H and come equipped for table top or wall mount use. They can also be mounted in a 19" or 23" rack with the purchase of mounting brackets (P/N1200627L1 - 19" and P/N1200627 L2- 23").

2. POWER REQUIREMENTS

AC Power

The units vary in their maximum power consumption and current draw. See Table 1 for details.

Table 1. AC Power Requirements

Product	Maximum Power Consumption	Maximum Current Draw
Total Access 604	90-125 VAC 60 Hz	300 mA
Total Access 608	90-125 VAC 60 Hz	300 mA
Total Access 612	90-120 VAC 60 Hz	1.3 A
Total Access 616	90-120 VAC 60 Hz	1.3 A
Total Access 624	90-120 VAC 60 Hz	1.3 A

3. REVIEWING THE FRONT PANEL DESIGN

Total Access 604/608

The front panels of the Total Access 604/608 units are identical. Figure 1 shows the Total Access 608 as a representative of both models. Table 2 on page 27 and Table 4 on page 29 describe the LEDs and their functions.




Figure 1. Total Access 604/608 Front Panel

Total Access 612/616/624

The front panels of the Total Access 612/616/624 units are identical. Figure 2 shows the Total Access 612 as a representative of all three models. Table 3 on page 28 and Table 4 on page 29 describe the LEDs and their functions.




Figure 2. Total Access 612/616/624 Front Panel

Front Panel LEDs

The front panel provides eight status LEDs to monitor operation and activity. The LED functionality varies based on product and software load (TDM vs ATM). The following tables provide LED activity explanations for the various combinations.

Table 2. Total Access 604/608 TDM Front Panel LEDs

For these LEDs...	This color light...	Indicates that...
TX/RX	Off	There is no data traffic on the LAN.
	Green (blinking)	There is data traffic on the LAN.
LINK	Off	The physical link is down, there is no Ethernet connection.
	Green (solid)	There is link integrity on the LAN (physical link is up).
V.35 RX	Off	No data traffic is being received on the V.35.
	Green (blinking)	Data is being received on the V.35.
V.35 TX	Off	No data traffic is being transmitted on the V.35.
	Green (blinking)	Data is being transmitted on the V.35.
DATA	Red (solid)	The T1 is in red alarm or T1 sync loss has occurred.
	Yellow (solid)	The T1 is in test.
	Green (solid)	Layer 2 is up.
VOICE	Off	The T1 is down.
	Green (blinking)	The phone is off hook.
	Green (solid)	The T1 is up and the phone is on hook.
BATT	Off	AC has failed and no battery.
	Green (solid)	AC is operational and battery is good.
	Red/Green (alternating)	AC is operational and battery is bad.
	Amber (solid)	AC has failed and the battery is good.
	Red/Amber (alternating)	AC has failed and the battery is bad.
PWR NET	Green (solid)	Layer 1 is up.
	Green (blinking)	Layer 1 is not up.

Table 3. Total Access 612/616/624 TDM Front Panel LEDs

For these LEDs...	This color light...	Indicates that...
TX/RX	Off	There is no data traffic on the LAN.
	Green (blinking)	There is data traffic on the LAN.
LINK	Off	The physical link is down, there is no Ethernet connection.
	Green (solid)	There is link integrity on the LAN (physical link is up).
V.35 RX	Off	No data traffic is being received on the V.35.
	Green (blinking)	Data is being received on the V.35.
V.35 TX	Off	No data traffic is being transmitted on the V.35.
	Green (blinking)	Data is being transmitted on the V.35.
DATA	Red (solid)	The T1 is in red alarm or T1 sync loss has occurred.
	Yellow (solid)	The T1 is in test.
	Green (solid)	Layer 2 is up.
VOICE	Red (solid)	The T1 is down.
	Green (blinking)	The phone is off hook.
	Green (solid)	The T1 is up and the phone is on hook.
BATT	Off	AC has failed and no battery.
	Green (solid)	AC is operational and battery is good.
	Red/Green (alternating)	AC is operational and battery is bad.
	Amber (solid)	AC has failed and the battery is good.
	Red/Amber (alternating)	AC has failed and the battery is bad.
PWR NET	Green (solid)	Layer 1 is up.
	Green (blinking)	Layer 1 is not up.



The only difference in the 604/608 TDM LEDs and the 612/616/624 TDM LEDs is in the Voice LED. For the 604/608, the Voice LED is off if the T1 is down. For the 612/616/624, the Voice LED is solid red if the T1 is down.

Table 4. Total Access 604/608/612/616/624 ATM Front Panel LEDs



For these LEDs...	This color light...	Indicates that...
TX/RX	Off	There is no data traffic on the LAN.
	Green (blinking)	There is data traffic on the LAN.
LINK	Off	The physical link is down, there is no Ethernet connection.
	Green (solid)	There is link integrity on the LAN (physical link is up).
V.35 RX	Off	No data traffic is being received on the V.35.
	Green (blinking)	Data is being received on the V.35.
V.35 TX	Off	No data traffic is being transmitted on the V.35.
	Green (blinking)	Data is being transmitted on the V.35.
DATA	Red (solid)	Layer 2 is not up.
	Green (solid)	Layer 2 is up.
VOICE	Red (solid)	The T1 is down.
	Green (blinking)	The phone is off hook.
VOICE (if Gateway is Jetstream)	Red (solid)	Gateway link is down.
	Green (solid)	Gateway link is up.
VOICE (if Gateway is Coppercom or LES-CAS)	Red (solid)	Layer 2 is down.
	Green (solid)	Layer 2 is up.
VOICE (if Gateway is Tollbridge)	Red (solid)	Gateway status is inactive.
	Green (solid)	Gateway status is active.
VOICE (if no Gateway)	Yellow (blinking)	The phone is off hook.
	Off	The phone is on hook.

Table 4. Total Access 604/608/612/616/624 ATM Front Panel LEDs (Continued)

For these LEDs...	This color light...	Indicates that...
BATT	Off	AC has failed and no battery.
	Green (solid)	AC is operational and battery is good.
	Red/Green (alternating)	AC is operational and battery is bad.
	Amber (solid)	AC has failed and the battery is good.
	Red/Amber (alternating)	AC has failed and the battery is bad.
PWR NET	Green (solid)	Layer 1 is up.
	Green (blinking slowly)	Unit was unable to train -- Layer 1 is down.
	Green (blinking rapidly)	Layer 1 is training (SDSL and SHDSL only).

4. REVIEWING THE REAR PANEL DESIGN

The Total Access 600 Series rear panel contains the same 8 ports regardless of the model. Figure 3 shows the Total Access 604/608 rear panel and Figure 4 shows the Total Access 612/616/624 rear panel. The sections following the figures provide detailed information about each port's functionality and pinouts.

**Figure 3. Total Access 604/608 Rear Panel****Figure 4. Total Access 612/616/624 Rear Panel**

Voice Connection

A single 50-pin female amphenol connector provides the interconnect wiring for the analog circuits. Figure 5 on page 31 shows the pinouts for the **Voice** connector.

Connector type 50-pin female amphenol




Figure 5. Voice Connector Pin Assignments

Life Line Connection

The **LIFE LINE** connector provides assured voice for port 1. If the unit loses power or goes into alarm, the network voice service is inhibited and the on-board relay opens. The first port of the voice connector is provided with analog voice from the **LIFE LINE** connection. A regular POTS line needs to be plugged into the Life Line port. Table 5 shows the **LIFE LINE** Connection pinout.

Connector type 8-pin modular

Table 5. LIFE LINE Connection Pinout

PIN	DESCRIPTION
1-2	Not used
3	Life Line ring
4	Life Line tip
5-6	Not used

NTWK Connection

The **NTWK** connection pinout is unit-dependent. The possibilities are T1, ADSL, SDSL, and SHDSL. Table 6 through Table 9 show the pinouts for these network connections.

Connector type RJ-48C

Table 6. T1 NTWK Connection Pinout

PIN	NAME		DESCRIPTION
1	R1	RXDATA-RING	Receive data from the network
2	T1	RXDATA-TIP	Receive data from the network
3	—	UNUSED	—
4	R	TXDATA-RING	Transmit data toward the network
5	T	TXDATA-TIP	Transmit data toward the network
6, 7, 8	—	UNUSED	—

Table 7. ADSL Network Connection Pinout

PIN	NAME	DESCRIPTION
1	Network Rx Ring	Receive data from the network
2	Network Rx Tip	Receive data from the network
3	—	—
4	Network Tx Ring	Transmit data toward the network
5	Network Tx Tip	Transmit data toward the network
6-8	—	—

Table 8. SDSL Network Connection Point

PIN	NAME	DESCRIPTION
1	Network Rx Ring	Receive data from the network
2	Network Rx Tip	Receive data from the network
3	—	—
4	Network Tx Ring	Transmit data toward the network
5	Network Tx Tip	Transmit data toward the network
6-8	—	—

Table 9. SHDSL Network Connection Pinout

PIN	NAME	DESCRIPTION
1	Network Rx Ring	Receive data from the network
2	Network Rx Tip	Receive data from the network
3	—	—
4	Network Tx Ring	Transmit data toward the network
5	Network Tx Tip	Transmit data toward the network
6-8	—	—

Craft Port

The **CRAFT** port connects to a computer or modem. The **CRAFT** port input provides the following functions:

- Accepts input from a PC or a modem for controlling the unit.
- Operates at 300, 1200, 2400, 4800, 9600, 19200, 38400, 57600, and 115200 bps.
- Acts as input for either VT 100 or PC control.
- Acts as an interface for flash memory software downloads using XMODEM.

The **CRAFT** connection follows, and Table 10 shows the pinout.

Connector type RJ-48C

Table 10. CRAFT Pinout

PIN	NAME	DESCRIPTION
1	GND	Ground - connected to unit chassis
2	RTS	Request to send - flow control
3	RXDATA	Data received by the unit.
4	DTR	Data terminal ready
5	TXDATA	Data transmitted by the unit.
6	CD	Carrier detect
7	UNUSED	—
8	CTS	Clear to send - flow control

10/100BaseT Connection

The **10/100BaseT** port (RJ-48C) provides a 10/100BaseT Ethernet LAN connection, which is used for IP Routing, TFTP, SNMP, and Telnet connections. The **10/100BaseT** connection follows, and Table 11 shows the pinout.

Connector type RJ-48C

Table 11. 10/100BaseT Pinout

PIN	NAME	DESCRIPTION
1	TX1	Transmit Positive
2	TX2	Transmit Negative
3	RX1	Receive Positive
4, 5	UNUSED	—
6	RX2	Receive Negative
7, 8	UNUSED	—

V.35 Connection

The DTE interface is compliant with ITU Recommendation V.35 through a standard 34-pin Winchester connector. The **V.35** connection follows, and Table 12 shows the pinout.

Connector type 34-pin Winchester

Table 12. V.35 Interface Pinout

PIN	CCITT	DESCRIPTION
A	101	Protective ground (PG)
B	102	Signal ground (SG)
C	105	Request to send (RTS) from DTE
D	106	Clear to send (CTS) to DTE
E	107	Data set ready (DSR) to DTE
F	109	Received line signal detector (DCD) to DTE
H	—	Data terminal ready (DTR) from DTE
J	—	Ring indicator (RI)
R	104	Received data (RD-A) to DTE
T	104	Received data (RD-B) to DTE
V	115	RX clock (RC-A) to DTE
X	115	RX clock (RC-B) to DTE

Table 12. V.35 Interface Pinout (Continued)

PIN	CCITT	DESCRIPTION
P	103	Transmitted data (TD-A) from DTE
S	103	Transmitted data (TD-B) from DTE
Y	114	TX clock (TC-A) to DTE
AA	114	TX clock (TC-B) to DTE
U	113	External TX clock (ETC-A) from DTE
W	113	External TX clock (ETC-B) from DTE
NN	—	Test mode (TM) to DTE

Battery Backup Connection

An optional battery backup system is available for the Total Access 604/608 (P/N 1200641L1) and the Total Access 612/616/624 (P/N 1175044L1, 1175044L2, or 1175044L4). Refer to the documentation available for your specific battery backup unit.

AC Power Connection

Each unit includes an auto ranging 90-250 VAC, 50/60 Hz power supply with a 3-prong removable cable. Connect the power supply to a standard 120 VAC, 60 Hz electrical outlet for proper operation.

5. DB-9 TO RJ ADAPTER

The DB-9 to RJ adapter is used to connect a PC or VT100 terminal to the **CRAFT** port. This adapter does not ship with the unit. A customer can obtain a free adapter (P/N 3196ADPT001) by contacting ADTRAN Technical Support or can order the adapter with the unit. Customers can also build their own adapters by purchasing unassembled adapter kits through companies like Black Box and Datacomm Warehouse. The adapter pinout is shown in Table 13.

Table 13. DB-9 to RJ Adapter Pinout

DB-9	RJ-45	DESCRIPTION
2	5	TX Data
3	3	RX Data
5	1	GND
Note: All other pins are unused.		

6. AT-A-GLANCE SPECIFICATIONS

Table 14 lists the unit specifications.

Table 14. Specifications

Application	Feature	Specification
T1 Network Interface		
	Physical Interface	RJ-48C
	Line Rate	1.544 Mbps +/- 75 bps
	Framing	D4 (SF)/ESF AT&T 54016 ANSI T1.403
	Line Code	AMI/B8ZS
ADSL Network Interface (ITU G.992.1)		
	Throughput	Up to 8 Mbps downstream/ Up to 1 Mbps upstream
	Interoperability	Interoperate with G.992.1 compliant DSLAMs
G.SHDSL Network Interface (ITU G.991.2)		
	Line Rate	192 kbps to 2.3 Mbps
SDSL Network Interface (2B1Q Conexant-based)		
	Line Rate	160 kbps to 2.3 Mbps
	Training	Conexant Autobaud capable
ATM Support		
	Voice Codes	PCM (G.711) 32K ADPCM (G.726)
	PVC Capability	6 PVCs (1 voice, 5 data)
	Echo Cancellation	G.165/G.168 Echo Cancellation, 8 ms echo tail
	QoS Support	VBR-rt (voice) UBR (data)
	Specifications	AAL2 (voice) AAL5 (data, voice) RFC 1483 (multiprotocol over ATM) RFC 2364 (PPPoA)
Frame Relay Support		
	Specifications	FRF.5 FRF.8

Table 14. Specifications (Continued)

Application	Feature	Specification
Analog Ports		
	Number of FXS Ports	4 ports for Total Access 604 8 ports for Total Access 608 12 ports for Total Access 612 16 ports for Total Access 616 24 ports for Total Access 624
	Modes	FXS Loop Start FXS Ground Start TR08 Single TR08 UVG DP0 Tandem (E&M)
	Ringing	Unbalanced ringing, 5 REN per port not to exceed 35 REN (Total Access 612/616/624) Balanced ringing, 3.75 REN per port not to exceed 15 REN (Total Access 604/608)
	Ring Voltage	Fixed 88 Vrms ringer (Total Access 612/616/624) Programmable ring voltage from 45 Vrms-62 Vrms (Total Access 604/608)
Routing (Ethernet)		
	Specifications	IEEE 802.3
	IP Support	TCP, RIP V1, RIP V2, UDP, ICMP, ARP, UDP Relay, SYSLOG
	PPP Support	LCP, IPCP, BCP
	DHCP	DHCP Server to LAN DHCP from network (NAT)
Management		
	Craft Interface	EIA 232, Physical RJ-48C
	Ethernet 10/100BaseT Interface	SNMP V1 support <ul style="list-style-type: none"> • 604/608 ATM units running D.01.36 firmware or previous • 612/616/624 ATM units running D.01.30 firmware or previous SNMP V2 support <ul style="list-style-type: none"> • TDM units running A.04 firmware or later Full menu-driven Telnet access Software download via TFTP Support for VoDSL gateway management systems and firmware download

NETWORK TURNUP PROCEDURE

CONTENTS

Introduction	41
Tools Required	41
Unpack and Inspect the System	41
Contents of ADTRAN Shipment	41
Grounding Instructions	42
AC Power	42
DC Power (Optional Battery Backup)	42
Supplying Power to the Unit	42
AC Powered Systems	42
DC Powered Systems	43
Mounting Options	44
Total Access 604/608	44
Total Access 612/616/624	44

1. INTRODUCTION

This section discusses the unit installation process.

2. TOOLS REQUIRED

The tools required for unit installation are:

- Screws (customer-provided for wallmount installation)
- Screwdriver (for wall or rackmount installation)

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



During installation, power should be the last connection made.



Electronic modules can be damaged by static electrical discharge. Before handling modules, wear an antistatic discharge wrist strap to prevent damage to electrical components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

3. UNPACK AND INSPECT THE SYSTEM

Each unit is shipped in its own cardboard shipping carton. Open each carton carefully and avoid deep penetration into the carton with sharp objects.

After unpacking the unit, inspect it for possible shipping damage. If the equipment has been damaged in transit, immediately file a claim with the carrier, then contact ADTRAN Customer Service (see *Customer Service, Product Support Information, and Training* in the front of this manual).

Contents of ADTRAN Shipment

Your ADTRAN shipment of the unit (regardless of product or software load -- ATM vs TDM) includes the following items:

- Mounting Instructions (P/N 61200680L1-19B)
- CD (P/N 3253052@A)
- Cable Tie (P/N 3292032)
- Silver Satin Cable (P/N 3127004)
- Four Rubber Feet (P/N 3270BF003)
- Power Cord (P/N 3127009)

- The Total Access 600 Series base unit (Total Access 604, Total Access 608, Total Access 612, Total Access 616, Total Access 624). The units come with installed wallmount brackets.

4. GROUNDING INSTRUCTIONS

The following provides grounding instruction information from the Underwriters' Laboratory UL 60950 Standard for Safety of Information Technology Equipment Including Electrical Business Equipment, with revisions dated March 15, 2002.

AC Power

The attachment-plug receptacles in the vicinity of the product or system are all to be of a grounding type, and the equipment grounding conductors serving these receptacles are to be connected to earth ground at the service equipment.

DC Power (Optional Battery Backup)

The Total Access units are not DC powered. However, an optional DC battery backup system is available for the Total Access 604/608 (P/N 1200641L1) and the Total Access 612/616/624 (P/N 1175044L1, 1175044L2, or 1175044L4).

A supplementary equipment grounding conductor shall be installed between the product or system and ground that is in addition to the equipment grounding conductor in the power supply cord.

The supplementary equipment grounding conductor shall not be smaller in size than the ungrounded branch-circuit supply conductors. The supplementary equipment grounding conductor shall be connected to the product at the terminal provided, and shall be connected to ground in a manner that will retain the ground connection when the product is unplugged from the receptacle. The connection to ground of the supplementary equipment grounding conductor shall be in compliance with the rules for terminating bonding jumpers at Part K or Article 250 of the National Electrical Code, ANSI/NFPA 70. Termination of the supplementary equipment grounding conductor is permitted to be made to building steel, to a metal electrical raceway system, or to any grounded item that is permanently and reliably connected to the electrical service equipment ground.

The supplemental grounding conductor shall be connected to the equipment using a number 8 ring terminal and should be fastened to the grounding lug provided on the rear panel of the equipment. The ring terminal should be installed using the appropriate crimping tool (AMP P/N 59250 T-EAD Crimping Tool or equivalent.)

5. SUPPLYING POWER TO THE UNIT

AC Powered Systems

The AC powered unit comes equipped with a detachable power cord with a 3-prong plug for connecting to a grounded power receptacle. As shipped, the unit is set to factory default conditions. After installing the chassis, the unit is ready for power-up. To power-up the unit, ensure that the unit is properly connected to an appropriate power source.



- *This unit shall be installed in accordance with Article 400 and 364.8 of the NEC NFPA 70 when installed outside of a Restricted Access Location (i.e., central office, behind a locked door, service personnel only area).*
- *Power to the unit's AC system must be from a grounded 90-130 VAC, 50/60 Hz source.*
- *The power receptacle uses double-pole, neutral fusing.*
- *Maximum recommended ambient operating temperature is 45 °C.*

DC Powered Systems

An optional battery backup system is available for the Total Access 604/608 (P/N 1200641L1) and the Total Access 612/616/624 (P/N 1175044L1, 1175044L2, or 1175044L4). Refer to the documentation available for your specific battery backup unit.



- *The backup system shall be installed in accordance with Article 400 and 364.8 of the NEC NFPA 70 when installed outside of a Restricted Access Location (i.e., central office, behind a locked door, service personnel only area).*
- *Power to the backup system must be from a grounded 90-130 VAC, 50/60 Hz source which is electrically isolated from the AC source.*
- *The power receptacle for the backup system uses double-pole, neutral fusing.*
- *Maximum recommended ambient operating temperature is 45 °C.*

6. MOUNTING OPTIONS

Total Access 604/608

- The Total Access 604/608 units come equipped for table top or wallmount use. The units come with installed wallmount brackets.

WARNING

If wallmounted, the Total Access 604/608 units must be mounted with the LEDs pointing down or sideways as shown in the mounting instructions (61200624L1-19A).

Total Access 612/616/624

- The Total Access 612/616/624 units come equipped for table top or wallmount use. The units come with installed wallmount brackets. The units can also be mounted in a 19" or 23" rack with the purchase of mounting brackets (P/N 1200627L1 for the 19" rack and P/N 1200627L2 for the 23" rack).

WARNING

If wallmounted, the Total Access 612/616/624 units must be mounted with the LEDs pointing down or sideways as shown in the mounting instructions (61200624L1-19A).

NOTE

If rack mounted, the installed wallmount brackets must first be removed.

SECTION 4.0 USER INTERFACE GUIDES (UIG)

The UIG section of this system manual provides detailed definitions, ranges, and default values for all menu items. Due to the inherent differences associated with the various physical interfaces and software loads, it was necessary to create separate UIGs for each combination of these parameters. The commons UIG provides terminal navigation information and defines any parameter which appears regardless of physical interface or software load. The UIGs contained in this section are shown below.

Section 4.1	Commons User Interface Guide	47
Section 4.2	T1 TDM User Interface Guide	55
Section 4.3	T1 ATM User Interface Guide	151
Section 4.4	ADSL ATM User Interface Guide	199
Section 4.5	SDSL ATM User Interface Guide	251
Section 4.6	SHDSL ATM User Interface Guide	299
Section 4.7	FXS User Interface Guide	345

SECTION 4.1 COMMONS USER INTERFACE GUIDE

This section covers all the common features and attributes for all models in the Total Access 600 Series of products (regardless of physical interface or software load). It contains information about VT100 control and navigation, and system control. It is designed for use by network administrators and others who will configure and provision the system.

SECTION INDEX

Navigating the Terminal Menu	49
Terminal Menu Window	49
Navigating using the Keyboard Keys	51
Terminal Menu and System Control	53
Selecting the Appropriate Menu	53
Telnet Security Levels	53

FIGURES

Figure 1.	Top-Level Terminal Menu Window	49
Figure 2.	Alternate Window View	50

TABLES

Table 1. Telnet Password Security Levels	50
--	----

1. NAVIGATING THE TERMINAL MENU

Terminal Menu Window

The unit uses a multi-level menu structure that contains both menu items and data fields. All menu items and data fields display in the terminal menu window (see Figure 1), through which you have complete control of the unit.



NOTE

All figures in this section will be representative of the Total Access 624 unit.




Figure 1. Top-Level Terminal Menu Window

Menu Path

The first line of the terminal menu window (the menu path) shows the session's current position (path) in the menu structure. For example, Figure 1 shows the top-level menu with the cursor on the System Info submenu; therefore, the menu path reads **TA 624 IAD/System Info**.

Window Panes

When you first start a terminal menu session, the terminal menu window is divided into left and right panes. The left pane shows the list of available submenus, while the right pane shows the contents of the currently selected submenu.

You can view the terminal windows in two ways: with fields and submenus displaying horizontally across the right pane, or with fields and submenus displaying vertically down the right pane. Viewing submenus vertically rather than horizontally allows you to see information at a glance rather than scrolling horizontally across the window. To change the view, move your cursor to an index number and press <Enter>. Figure 2 shows this alternate view. Fields and submenu names may vary slightly in this view.




Figure 2. Alternate Window View

Window Pane Navigation

Use the following chart to assist you in moving between and within the two window panes.

To do this...	Press this key...
Move from left pane to right pane	Tab, Enter, or Right arrow
Move from right pane to left pane	Tab, Escape, Left arrow, or Backspace
Move within each pane	Up/Down or Left/Right arrows

Right Window Pane Notation

The right window pane shows the contents of the currently selected menu. These contents can include both submenu items and data fields. Some submenus contain additional submenus and some data fields contain additional data fields. The following chart explains the notation used to identify these additional items.

This notation...	Means that...
[+]	More items are available when selected
<+>	An action is to be taken, such as activating a test
Highlighted menu item	You can enter data in this field
Underlined field	The field contains read-only information

Additional Terminal Menu Window Features

- Tool Tip - provides a brief description of the currently selected mode
- Network Status - displays network status information, Up or Down
- Slot Status - displays type of module installed in each slot. No entry will appear for slots not containing a module.
- Extended Help - displays information about selected commands (CTRL+A)
- Navigation Help - lists characters used for navigating the terminal menu and session management (CTRL+Z)
- System Time - displays current time

Navigating using the Keyboard Keys

You can use various keystrokes to move through the terminal menu, to manage a terminal menu session, and to configure the system. Press <CTRL+Z> to activate a pop-up screen listing the navigation keystrokes.

Moving Through the Menus

To do this...	Press this key...
Return to the home screen	H
Jump between two menu items Press <J> while the cursor is located on a menu item, and you jump back to the main screen. Go to another menu item, press <J>, and you jump back to the screen that was displayed the first time you pressed <J>. Press <J> anytime you want to jump between these items.	J
Select items	Arrows
Edit a selected menu item	Enter
Cancel an edit	Escape
Close pop-up help screen	Escape
Move between the left and right panes	Tab Arrows
Move to the top of a screen	A
Move to the bottom of a screen	Z
Ascend one menu level	Backspace
Jump to terminal mode (only supported in T1 TDM code)	Ctrl + T
Jump to NAT menu (only supported in T1 TDM code)	Ctrl + N
Return to Login prompt (CRAFT Port connection only)	Ctrl + L
Return to Login prompt (CRAFT Port connection only)	Ctrl + S

Session Management Keystrokes

To do this...	Press this key...
Log out of a session (Telnet Connection)	CTRL+L
Refresh the screen To save time, only the portion of the screen that has changed is refreshed. This option should only be necessary if the display picks up incorrect characters.	CTRL+R

Configuration Keystrokes

To do this...	Press this key...
Restore factory default settings. This setting restores the factory defaults based on the location of the cursor.	F
Copy selected items to the clipboard. The amount of information you can copy depends on the cursor location when you press <C>: If the cursor is over an editable field, only that item is copied. If the cursor is over the index number of a list, then all of the items in the row of the list are copied. For example, if the cursor is over the DS0 field in the EDIT/VIEW MAP screen, all of the information associated with the DS0 is copied.	C
Paste the item stored in the clipboard, if the information is compatible. You must confirm all pastes - except those to a single editable field.	P
Increment the value of certain types of fields by one when you paste information into those fields.	>
Decrement the value of certain types of fields by one when you paste information into those fields.	<
Insert a new list item. For example, add a new item to the TELNET USER LIST connection list by pressing <I> while the cursor is over the index number.	I
Delete a list item. For example, delete an item from the TELNET USER LIST connection list by pressing <D> while the index number is active.	D

2. TERMINAL MENU AND SYSTEM CONTROL

Selecting the Appropriate Menu

The terminal menu is the access point to all other operations. Each terminal menu item has several functions and submenus that identify and provide access to specific operations and parameters. Use the chart below to help select the appropriate terminal menu.

To do this...	Go to this menu...
Review and monitor general system information	SYSTEM INFO
Set up the management, syslog, and network time	SYSTEM CONFIG
Upgrade firmware, do config transfers, ping, traceroute, reset unit, and access terminal mode	SYSTEM UTILITY
Configure and monitor the T1, ethernet, V.35, and FXS interfaces	INTERFACES
Configure and monitor the L2 protocol for the T1 and ethernet interfaces	L2 PROTOCOL
Configure and monitor bridging parameters	BRIDGE
Define, configure, and monitor all router functions	ROUTER
Configure the filter defines and Radius server	SECURITY
Configure and apply DS0 maps	DS0 MAPS

Telnet Security Levels

To edit terminal menu items via Telnet, you must have a password and the appropriate security level. Table 1 describes the security levels.

Table 1. Telnet Password Security Levels

Security Level	Description
Full	The user has all access to view and configure all menus (same as logging in to the Craft port)
Support	The user has access to view SYSTEM INFO . The user has privileges to view and change everything under the SYSTEM CONFIG menu except for the Craft port settings, telnet access lists, and the SNMP management communities. The user has full access to the SYSTEM UTILITY menu, including the ability to upgrade firmware and reset the unit. The user has full access to the INTERFACES , L2 PROTOCOL , BRIDGE , ROUTER , and DS0 menus. The user does not have the ability to set RADIUS SERVER settings under the SECURITY menu.
Config	The same privileges as support, except that the user does not have privileges to download firmware or configuration from the SYSTEM UTILITY menu. The user additionally does not have the privilege to reset the unit remotely, or enter the terminal menu.

Table 1. Telnet Password Security Levels (Continued)

Security Level	Description
Router	The user has view only privileges of SYSTEM INFO . There is no access to the SYSTEM CONFIG menu. The user has PING and TRACEROUTE access from the SYSTEM UTILITY menu. The user is limited to ethernet configuration and status from the INTERFACES menu. The user has full access to the BRIDGE and ROUTER menus. Access is limited to filters only from the SECURITY menu.
Voice	The user has read privileges of the SYSTEM INFO menu. The user has access to the PING and TRACEROUTE utilities from the SYSTEM UTILITIES menu. The user has full access to the FXS module from the INTERFACES menu.
Status	The user has read access of all menus except for the following: SYSTEM CONFIG/CRAFT PORT , SYSTEM CONFIG/TELNET ACCESS , SYSTEM CONFIG/SNMP MANAGEMENT , and SECURITY/ RADIUS SERVER . The user does not have access to UPGRADE FIRMWARE , UPGRADE CONFIG , PING , or TRACEROUTE menus. The user cannot reset the unit or enter terminal mode.

SECTION 4.2 T1 TDM USER INTERFACE GUIDE

The T1 TDM User Interface Guide is designed for use by network administrators and others who will configure and provision the system. This section provides details unique to the T1 TDM IADs. It contains an overview, application details, configuration information, and menu descriptions. It is recommended that you review Section 4.1, *Commons User Interface Guide* in addition to this section.

SECTION INDEX

T1 TDM Overview	59
T1 TDM Application	59
Configuration	60
System Info	60
System Info > System Name	60
System Info > System Location	60
System Info > System Contact	61
System Info > Unit Name	61
System Info > CLEI Code	61
System Info > Part Number	61
System Info > Serial Number	61
System Info > Firmware Revision	61
System Info > Bootcode Revision	61
System Info > System Uptime	61
System Info > Date/Time	61
System Config	62
System Config > Management	62
System Config > Syslog	68
System Config > Network Time	73
System Utility	75
System Utility > Upgrade Firmware	75
System Utility > Config Transfer	76
System Utility > System Utilization	77
System Utility > Ping	78
System Utility > Traceroute	79
System Utility > Reset Unit	79
System Utility > Terminal Mode	79
Interfaces	80
Interfaces (T1[0])	80
Interfaces (T1[0]) > Config	80
Interfaces (T1[0]) > Status	81
Interfaces (T1[0]) > Test	83
Interfaces (ETH[1])	84
Interfaces (ETH[1]) > Config	84
Interfaces (ETH[1]) > Status	84

Interfaces (V35[2])	85
Interfaces (V35[2]) > Config	85
Interfaces (V35[2]) > Status	85
Interfaces (FXS)	86
Interfaces (FXS) > Config	86
Interfaces (FXS) > Status	88
Interfaces (FXS) > Test	89
L2 Protocol	90
L2 Protocol (T1[0])	90
L2 Protocol (T1[0]) > Protocol	90
L2 Protocol (T1[0] - PPP)	91
L2 Protocol (T1[0] - PPP) > Config	91
L2 Protocol (T1[0] - PPP) > Status	93
L2 Protocol (T1[0] - FRE)	94
L2 Protocol (T1[0] - FRE) > Config	94
L2 Protocol (T1[0] - FRE) > Status	96
L2 Protocol (T1[0] - Auto)	99
L2 Protocol (T1[0] - Auto) > Status	99
L2 Protocol (ETH[1])	100
L2 Protocol (ETH[1]) > Protocol	100
L2 Protocol (ETH[1]) > Config	100
L2 Protocol (ETH[1]) > Status	100
Bridge	102
Bridge > Config	102
Bridge > Status	103
Router	104
Router > Config	104
Router > Status	116
Security	126
Security > Filters	126
Security > Radius Server	135
DS0 Maps	137
DS0 Maps > Active Map	137
DS0 Maps > Apply Template to Map 1	137
DS0 Maps > Edit/View Map 1	137
DS0 Maps > Apply Template to Map 2	138
Appendix A. Configuring the Unit for Routing	140
Appendix B. Configuring the Unit for Bridging	146
Appendix C. Configuring the Unit for Voice Applications	148

FIGURES

Figure 1.	Typical Total Access TDM Application	59
Figure 2.	System Info Menu	60
Figure 3.	System Config Menu	62
Figure 4.	System Utility Menu	75
Figure 5.	Interfaces menus	80
Figure 6.	L2 Protocol Menu	90
Figure 7.	Bridge Menu	102
Figure 8.	Router Menu	104
Figure 9.	Security Menu	126
Figure 10.	DS0 Maps Menu	137

TABLES

Table 1.	Instructions for Changing Passwords	63
Table 2.	Telnet Security Levels	65

1. T1 TDM OVERVIEW

Time Division Multiplexing (TDM) is the technology used to transmit several voice, data, and/or video signals at the same time over one communications path. This path is shared by fixed timeslots that transport multiple media. The Total Access 600 Series is a complete solution IAD for Voice and Data applications. The unit includes a network interface, V.35 interface, 10/100BaseT interface, FXS ports, life-line voice backup, built-in IP router, and an optional battery backup for added security. The unit can provision, test, and provide status for any of the voice and data interfaces.

2. T1 TDM APPLICATION

The unit connects to the network to provide both voice and high speed data from a single platform. The most common T1 TDM application includes simultaneous support for the following:

- Router connection via the V.35 or Network interface
- LAN connection via a 10/100BaseT interface
- 4 POTS connections via FXS interfaces for the Total Access 604
- 8 POTS connections via FXS interfaces for the Total Access 608
- 12 POTS connections via FXS interfaces for the Total Access 612
- 16 POTS connections via FXS interfaces for the Total Access 616
- 24 POTS connections via FXS interfaces for the Total Access 624

Figure 1 shows a typical T1 TDM application.




Figure 1. Typical Total Access TDM Application

3. CONFIGURATION

SYSTEM INFO

The **SYSTEM INFO** menu provides basic information about the unit as well as data fields for editing information. Figure 2 displays the submenus that are available when you select this menu item.



All figures in this section will be representative of the Total Access 624 unit. Firmware revision will reflect A.04.01 for released revisions of software.




Figure 2. System Info Menu

SYSTEM INFO > SYSTEM NAME

Provides a user-configurable text string for the name of the unit. This name can help you distinguish between different installations. You can enter up to 31 alpha-numeric characters in this field, including spaces and special characters (such as an underscore). This name will appear on the top line of all screens. The factory default is to have no entry in the system name field.

SYSTEM INFO > SYSTEM LOCATION

Provides a user-configurable text string for the location of the unit. This field is to help you keep track of the actual physical location of the unit. You can enter up to 31 alphanumeric characters in this field, including spaces and special characters (such as an underscore). The factory default is to have no entry in the system location field.

SYSTEM INFO > SYSTEM CONTACT

Provides a user-configurable text string for a contact name. You can use this field to enter the name, phone number, or E-mail address of a person responsible for the unit. You can enter up to 31 alpha-numeric characters in this field, including spaces and special characters (such as an underscore). The factory default is to have no entry in the system contact field

SYSTEM INFO > UNIT NAME

Product-specific name for the unit.

SYSTEM INFO > CLEI CODE

The CLEI code for the unit.

SYSTEM INFO > PART NUMBER

ADTRAN part number for the unit.

SYSTEM INFO > SERIAL NUMBER

The serial number field will reflect serial number located on bottom of the unit's chassis.

SYSTEM INFO > FIRMWARE REVISION

Displays the current firmware revision level of the unit.

SYSTEM INFO > BOOTCODE REVISION

Displays the bootcode revision.

SYSTEM INFO > SYSTEM UPTIME

Displays the length of time since the last reboot of the unit.



Each time you reset the system, this value resets to 0 days, 0 hours, 0 min. and 0 secs.

SYSTEM INFO > DATE/TIME

Displays the current date and time, including seconds. This field can be edited. Enter the time in 24-hour format (such as 23:00:00 for 11:00 pm). Enter the date in mm-dd-yyyy format (for example, 10-30-1998).

SYSTEM CONFIG

Set up the unit's operational configuration from the **SYSTEM CONFIG** menu. Figure 3 shows the items included in this menu.




Figure 3. System Config Menu

SYSTEM CONFIG > MANAGEMENT

Set up the **CRAFT PORT**, **TELNET ACCESS**, **SNMP MANAGEMENT**, and **FDL MANAGEMENT** from this menu.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT

Set up the **CRAFT PORT** parameters from this menu.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > PASSWORD PROTECT

The unit's VT 100 **CRAFT** port can be accessed via an RJ 48 connector located on the rear of the unit.

When **PASSWORD PROTECT** is set to **No**, the **CRAFT** port is not password protected. When **YES** (def), the unit will prompt for a password upon startup.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > PASSWORD

This is the text string that is used for comparison when password protecting the **CRAFT** port. By default, no password is entered. You can enter up to 30 characters in this field. Table 1 provides instructions for changing the password.



*The security level for the **CRAFT** port is always set to **FULL**. This gives full access to all menus.*



Passwords are case-sensitive and can contain up to 30 alphanumeric characters (including spaces and special characters).

Table 1. Instructions for Changing Passwords

Step	Action
1	Select the PASSWORD field—a new PASSWORD field displays.
2	Type the new password in the ENTER field.
3	Type the new password again in the CONFIRM field.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > BAUD RATE

This is the asynchronous rate that the **CRAFT** port will run. The possible values are **300, 1200, 2400, 4800, 9600, 19200, 38400, 57600, and 115200**. The default value is **9600**.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > DATA BITS

This is the asynchronous bit rate that the **CRAFT** port will run. The possible values are **7** or **8** (def) bits.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > PARITY

This is the asynchronous parity that the **CRAFT** port will run. The possible values are **NONE** (def), **ODD**, or **EVEN**.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > STOP BITS

This is the number of stop bits used for the **CRAFT** port. The possible values are **1** (def), **1.5** or **2**.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS

Activate the Telnet access and set up the various telnet parameters from this menu.



The ATM D.01.XX firmware supports one telnet session active at a time. The TDM A.03.XX firmware supports one telnet session active at a time. The TDM A.04 firmware supports five simultaneous telnet sessions.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS > ACCESS

Sets **ACCESS** to **ON** or **OFF**. The factory default value for this parameter is **ON**.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS > AUTHEN METHOD

Set up the telnet authentication method from this menu. The choices are **PASSWORD**, **RADIUS**, **PASSWORD/RADIUS**, and **RADIUS/PASSWORD**. **PASSWORD/RADIUS** indicates that the unit will try Password Authentication first and if that fails, it will try Radius Authentication. **RADIUS/PASSWORD** indicates that the unit will try Radius authentication first and if that fails, it will try Password authentication. The default is **PASSWORD**.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS > USER LIST

Add telnet users and control the telnet access conditions through this menu.

#

Display the index number of the telnet users. Up to four users can be configured for access to the unit. Each user can be assigned a security level and idle time.

NAME

The name is a text string of the user name for this session. You can enter up to 15 characters in this field. The factory default is no entry in the **NAME** field.

PASSWORD

When the authenticating method is password, or password radius, this text string is used for the password. You can enter up to 30 characters in this field. The factory default is no entry in this field.

IDLE TIME (MINS)

This sets the amount of time in minutes you can be idle before you are automatically logged off. The factory default is **10 MINUTES**. The range is 1-255 minutes.

LEVEL

This is the security level granted to the user. Table 2 gives a brief description of each level. The factory default is **FULL**.

Table 2. Telnet Security Levels

Security Level	Description
Full	The user has all access to view and configure all menus (same as logging in to the CRAFT port)
Support	The user has read only access to view the SYSTEM INFO menu. The user has privileges to view and change everything under the SYSTEM CONFIG menu except for the CRAFT port settings, telnet access lists, and the SNMP management communities. The user has full access to the SYSTEM UTILITY menu, including the ability to upgrade firmware and reset the unit. The user has full access to the INTERFACES , L2 PROTOCOL , BRIDGE , ROUTER , and DS0 menus. The user does not have the ability to set RADIUS SERVER settings under the SECURITY menu.
Config	The same privileges as support, except that the user does not have privileges to download firmware or configuration from the SYSTEM UTILITY menu. The user additionally does not have the privilege to reset the unit remotely, or enter the terminal menu.
Router	The user has read only privileges for the SYSTEM INFO menu. There is no access to the SYSTEM CONFIG menu. The user has PING and TRACEROUTE access from the SYSTEM UTILITY menu. The user is limited to ethernet configuration and status from the INTERFACES menu. The user has full access to the BRIDGE and ROUTER menus. Access is limited to filters only from the SECURITY menu.
Voice	The user has read only privileges for the SYSTEM INFO menu. The user has access to the PING and TRACEROUTE utilities from the SYSTEM UTILITIES menu. The user has full access to the FXS module from the INTERFACES menu.
Status	The user has read access of all menus except for the following: SYSTEM CONFIG/CRAFT PORT , SYSTEM CONFIG/TELNET ACCESS , SYSTEM CONFIG/SNMP MANAGEMENT , and SECURITY/ RADIUS SERVER . The user does not have access to UPGRADE FIRMWARE , UPGRADE CONFIG , PING , or TRACEROUTE menus. The user cannot reset the unit or enter terminal mode.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS > IP ACCESS LIST

Set up the list of allowed telnet managers.

NETWORK ADDRESS AND MASK

Enter a network address and subnet mask from which telnet access to the unit is allowed. When a remote unit requests telnet access to the unit, if the access list is empty or the remote's IP address matches a list entry, remote access is granted. A subnet mask of 0.0.0.0 will allow any host telnet access, regardless of the network address. A network address of 0.0.0.0 with corresponding netmask 255.255.255.255 will not allow any host telnet access.

The factory default is **0.0.0.0**. for both parameters, which will allow all users telnet IP access.

SYSTEM CONFIG > MANAGEMENT > SNMP MANAGEMENT

Active the SNMP management and configure the SNMP communities and traps from this menu.

SYSTEM CONFIG > MANAGEMENT > SNMP MANAGEMENT > ACCESS

When set to **OFF**, SNMP access is denied. When set to **ON**, the unit will respond to SNMP managers based on the configuration. The factory default is **ON**.

SYSTEM CONFIG > MANAGEMENT > SNMP MANAGEMENT > COMMUNITIES

Set up the SNMP communities parameters from this menu.

#

Displays the index number of the SNMP Communities.

This list is used to set up to 8 SNMP communities that the unit will allow.

NAME

This is the text string used to identify the SNMP community. The factory default is no entry in the name parameter.

PRIVILEGE

The access for this manager can be assigned three levels. The factory default is **NONE**.

NONE	No access is allowed for this community or manager.
GET	Manager can only read items.
GET/SET	Manager can read and set items.

MANAGER IP

This may be used in conjunction with the Netmask field to define a range of manager IPs. A netmask of 255.255.255.255 defines a single IP as the manager host IP. The default value is **0.0.0.0**.

NETMASK

The mask is used to determine which bits of the **MANAGER IP** are significant. A "0" bit means "don't care." A "1" bit means that the corresponding address bits in the incoming SNMP packet must match the address bit in the defined **MANAGER IP**. The netmask of 255.255.255.255 defines a single IP as the manager host IP. The default value is **0.0.0.0**.

SYSTEM CONFIG > MANAGEMENT > SNMP MANAGEMENT > TRAPS

Sets up the trap manager name and IP from this menu.

#

Displays the index number in the SNMP traps table.

This list allows up to 20 managers to be listed to receive traps.

MANAGER NAME is the text string describing the name of the entry. It is intended for easy reference and has no bearing on the SNMP trap function. You can enter up to 31 characters in this field. The factory default is no entry in the manager name field.

MANAGER IP

This is the IP address of the manager that is to receive the traps. The factory default is **0.0.0.0**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT

Enables the FDL management and configures mode and IP addresses from this menu.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > MODE

This enables the FDL (only in ESF mode) to be used for management. Learning mode can also be enabled so the unit can "learn" its IP configuration to be used for its FDL management. Once it learns this information from, for example a Total Access 4303, the configuration items populate. The factory default is **ON**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > LINK IP ADDRESS

This is the local IP address used for FDL management. The FDL uses a separate IP network for communication, distinct from the customer data that is configured under the **ROUTER** menus. The factory default is **0.0.0.0**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > IP NETMASK

This is the subnet mask defining the IP network used for FDL management. The factory default is **0.0.0.0**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > FAR-END IP ADDRESS

This is the far-end IP address used for the FDL management. The FDL is a separate IP network from the customer data that is configured under the **ROUTER** menus. The factory default is **0.0.0.0**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > LEARN ADDRESS

When set to **ON**, the destination address on each received packet is assumed to be the FDL interface address. A 255.255.255.252 netmask is used, which determines the far-side address as well (since there can be only two addresses on a subnet with that netmask). When set to **OFF**, the user must input the IP address assigned to the FDL interface. Default is **ON**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > ACCEPT ALL SNMP

When set to **ON**, SNMP gets/sets received over the FDL link are always accepted regardless of the community table. When set to **OFF**, the community table is searched for valid manager IP addresses and the SNMP traffic is rejected if a match is not found. Default is **ON**.

SYSTEM CONFIG > SYSLOG

Configure the unit Syslog client for use with a Syslog server (supplied with ADTRAN Utilities or available on most Unix platforms) from this menu.



For additional information, reference RFC3164: The BSD Syslog Protocol.

SYSTEM CONFIG > SYSLOG > SYSLOG IP

IP address of the syslog daemon to which log message should be sent. The values must be dotted decimal notation.

SYSTEM CONFIG > SYSLOG > SYSLOG FORMAT

The **SYSLOG FORMAT** is the format of log messages. "**ADTRAN**" uses a format that is compatible with Adtran Utilities and forces the Syslog Facility to LOCAL0. **UNIX** uses the traditional Unix format and reports at the configured facility level.



Adtran Utilities may malfunction if messages are received in the Unix format.

SYSTEM CONFIG > SYSLOG > SYSLOG FACILITY

The choices are: **LOCAL0**, **LOCAL1**, **LOCAL2**, **LOCAL3**, **LOCAL4**, **LOCAL5**, **LOCAL6**, **LOCAL7**. **SYSLOG FACILITY** is the facility level for all messages forwarded from the unit to the syslog server. This allows all messages received from the IAD to be filtered by facility level. See RFC3164: The BSD Syslog Protocol..



*This does not have to correspond to the facility level shown in the terminal mode option.
See SYSLOG Facility using Terminal Mode*

The remaining Syslog parameters have the following level choices:

FATAL (Highest priority)
ALERT
CRITICAL
ERROR
WARNING
NOTICE
INFO
DEBUG (Lowest priority)

Every log message generated by the IAD has a reporting level priority. If the message priority is lower than the configured priority for the destination log, the message is not forwarded to the syslog daemon. See RFC3164: The BSD Syslog Protocol. The lower the log level, the more messages that will be generated. Setting reporting levels to DEBUG may negatively affect the performance of the IAD, including causing the IAD to reset.



ADTRAN recommends using DEBUG for only short periods of time for debug purposes only.

SYSLOG using Terminal Mode

Another option for configuring syslog is using the terminal mode command **log dump <logname>**. The logname must be all CAPS and be one of the following names:

FATAL
ALERT
CRITICAL
ERROR
WARNING
NOTICE
INFO
DEBUG

The command will dump all messages for the indicated log (**ALL LEVEL** shows all log messages) stored in the internal log buffer to the command line display.

SYSTEM CONFIG > SYSLOG > ALL LEVEL

This entry allows setting the default reporting level for all log entries. If **ALL LEVEL** is a lower priority than the individual log entry level, **ALL LEVEL** overrides the individual log reporting level.

SYSTEM CONFIG > SYSLOG > KERNEL LEVEL

Minimum required level for sending KERNEL log messages.

SYSTEM CONFIG > SYSLOG > DHCP LEVEL

Minimum required level for sending DHCP log messages.

SYSTEM CONFIG > SYSLOG > NTP LEVEL

Minimum required level for sending NTP log messages.

SYSTEM CONFIG > SYSLOG > TFTP LEVEL

Minimum required level for sending TFTP log messages.

SYSTEM CONFIG > SYSLOG > TELNET LEVEL

Minimum required level for sending TELNET log messages.

SYSTEM CONFIG > SYSLOG > IP LEVEL

Minimum required level for sending IP log messages.

SYSTEM CONFIG > SYSLOG > PPP LEVEL

Minimum required level for sending PPP log messages.

SYSTEM CONFIG > SYSLOG > NAT LEVEL

Minimum required level for sending NAT log messages.

SYSTEM CONFIG > SYSLOG > ARP LEVEL

Minimum required level for sending ARP log messages.

SYSTEM CONFIG > SYSLOG > UDP LEVEL

Minimum required level for sending UDP log messages.

SYSTEM CONFIG > SYSLOG > NETWRITE LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > TCP LEVEL

Minimum required level for sending TCP log messages.

SYSTEM CONFIG > SYSLOG > COMPSYS LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > CONSOLE LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > CFGXFER LEVEL

Minimum required level for sending configuration transfer log messages.

SYSTEM CONFIG > SYSLOG > ROUTER LEVEL

Minimum required level for sending router log messages.

SYSTEM CONFIG > SYSLOG > NONVOL LEVEL

Minimum required level for sending nonvolatile memory log messages.

SYSTEM CONFIG > SYSLOG > NOKIA LEVEL

Minimum required level for sending log messages about communication with the Nokia DSLAM. Messages are only generated for products with an SDSL WAN interface.

SYSTEM CONFIG > SYSLOG > AUTOBAUD LEVEL

Minimum required level for sending log messages about communication with the Lucent Stinger DSLAM. Messages are only generated for products with an SDSL WAN interface.

SYSTEM CONFIG > SYSLOG > TOLLBRG LEVEL

Minimum required level for sending log messages about communication with the Tollbridge Voice Gateway. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > CMCP LEVEL

Minimum required level for sending log messages about communication with the CopperMountain DSLAM. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > SDSL LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > L1 LEVEL

Minimum required level for sending log messages about WAN physical or Layer 1 connection.

SYSTEM CONFIG > SYSLOG > ETH LEVEL

Minimum required level for sending log messages about Ethernet physical connection.

SYSTEM CONFIG > SYSLOG > ICMP LEVEL

Minimum required level for sending ICMP log messages.

SYSTEM CONFIG > SYSLOG > CONFIG LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > DSO LEVEL

Minimum required level for sending log messages about DSO mapping.

SYSTEM CONFIG > SYSLOG > SELFTEST LEVEL

Minimum required level for sending log messages about selftest.

SYSTEM CONFIG > SYSLOG > VOICE LEVEL

Minimum required level for sending log messages about AAL2 voices services.
Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > JETSTREAM LEVEL

Minimum required level for sending log messages about communication with the JetStream Voice Gateway. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > POTS LEVEL

Minimum required level for sending log messages about POTS line cards and services.

SYSTEM CONFIG > SYSLOG > LESCAS LEVEL

Minimum required level for sending messages about communication with LESCAS compatible Voice Gateways. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > ATM LEVEL

Minimum required level for sending ATM log messages. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > COPPERCOM LEVEL

Minimum required level for sending log messages about communication with the CopperCom Voice Gateway. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > VOFR LEVEL

Minimum required level for sending voice-over-frame-relay log messages about communication with the CopperMountain DSLAM. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > XMODEM LEVEL

Minimum required level for sending XMODEM log messages for firmware and configuration transfers.

SYSTEM CONFIG > SYSLOG > EMWEB LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > FRELAY LEVEL

Minimum required level for sending frame relay log messages.

SYSTEM CONFIG > SYSLOG > BRIDGE LEVEL

Minimum required level for sending bridge mode log messages.

SYSTEM CONFIG > SYSLOG > MAINT LEVEL

Minimum required level for sending **CRAFT** port log messages.

SYSTEM CONFIG > SYSLOG > HDLC LEVEL

Minimum required level for sending low level HDLC log messages.

SYSTEM CONFIG > SYSLOG > VOATM LEVEL

Minimum required level for sending Voice-over-ATM log messages.

SYSTEM CONFIG > SYSLOG > PPPOA LEVEL

Minimum required level for sending PPP-over-ATM log messages.

SYSTEM CONFIG > SYSLOG > FDL LEVEL

Minimum required level for sending FDL log messages.

SYSTEM CONFIG > NETWORK TIME

Activate the network time and configure the server type, time zone and various other network time parameters from this menu.

SYSTEM CONFIG > NETWORK TIME > SERVER TYPE

The unit time can be entered manually from the **SYSTEM INFO** menu, or the unit can receive time from an NTP/SNTP server. The **NETWORK TIME** menu includes all parameters relating to how the unit communicates with the time server.

The server type defines the port on which the unit will listen to receive timing information from the time server. The choices are **NT TIME** and **SNTP**. When set to **NT TIME**, the unit will receive time from an NT server running SNTP software on its TIME port. When set to **SNTP**, the unit will receive time directly from an SNTP server. The factory default is **SNTP**.

SYSTEM CONFIG > NETWORK TIME > ACTIVE

This network timing feature can be turned on and off. It determines whether the unit will request and receive time from a time server. The factory default is **No**.

SYSTEM CONFIG > NETWORK TIME > TIME ZONE

All time zones are based off of Greenwich Mean Time (GMT). The choices are listed below

- **GMT**
- **GMT -5 (EASTERN)**
- **GMT -6 (CENTRAL)**
- **GMT -7 (MOUNTAIN)**
- **GMT -8 (PACIFIC)**
- **GMT -9 (ALASKA)**
- **GMT -10 (HAWAII)**

The factory default is **GMT-6 (CENTRAL)**.

SYSTEM CONFIG > NETWORK TIME > ADJUST FOR DAYLIGHT SAVING

Since some areas of the world use Daylight Savings Time, the unit is designed to adjust the time on the first Sunday in April and the last Sunday in October accordingly if this option is turned on. The factory default is **YES**.

SYSTEM CONFIG > NETWORK TIME > HOST ADDRESS

This is the IP address of the time server that the unit will request and receive time from. The factory default is no entry in the host address field.

SYSTEM CONFIG > NETWORK TIME > REFRESH

This is the interval of time between each request the unit sends out to the time server. A smaller refresh time guarantees that the unit receives the correct time from the server and corrects possible errors more quickly. This may be more taxing on the machine. A range of refresh times is available for the user to decide which is best for their unit. Choices include **5 MINS, 10 MINS, 15 MINS, 20 MINS, 25 MINS, 30 MINS, 35 MINS, 40 MINS, 45 MINS, 50 MINS, 55 MINS, and 60 MINS**. The factory default is **60 MINS**.

SYSTEM CONFIG > NETWORK TIME > STATUS

This displays the current status of the time negotiation process. If an error is displayed, check all connections and configurations to try to resolve the problem.

SYSTEM UTILITY

Use the **SYSTEM UTILITY** menu to view and set the system parameters shown in Figure 4.




Figure 4. System Utility Menu

SYSTEM UTILITY > UPGRADE FIRMWARE

Select the firmware upgrade method and perform upgrade from this menu.

SYSTEM UTILITY > UPGRADE FIRMWARE > TRANSFER METHOD

The customer can update firmware when unit enhancements are released.

The two methods for upgrading are **XMODEM** and **TFTP**. (See the DLP section of this manual for more information.) **TFTP** requires a TFTP server running on the network. The unit starts a TFTP client function which gets the upgrade code from the TFTP server. Selecting **XMODEM** will load the upgrade code through the **CRAFT** port using any PC terminal emulator with XMODEM capability. The factory default is **TFTP**.

SYSTEM UTILITY > UPGRADE FIRMWARE > TFTP SERVER ADDRESS

This is required when the transfer method is TFTP. It is the IP address or domain name (if DNS is configured) of the TFTP server. The factory default is no entry in the TFTP server address field.

SYSTEM UTILITY > UPGRADE FIRMWARE > TFTP SERVER FILENAME

This is required when the transfer method is TFTP. It is the case-sensitive file name which contains the upgrade code. The factory default is no entry in the TFTP server filename field.

SYSTEM UTILITY > UPGRADE FIRMWARE > TRANSFER STATUS

This appears when TFTP is used. It displays the status of the transfer as it happens. Any error or success message will be displayed here.

SYSTEM UTILITY > UPGRADE FIRMWARE > START TRANSFER

This activator is used when the configurable items in this menu are complete. This will initiate the transfer for either TFTP or XMODEM upgrades.



Before using Start Transfer, the unit should have a valid IP address, subnet mask, and default gateway (if required). See DLP-004, Setting Ethernet IP Parameters for more information.

SYSTEM UTILITY > UPGRADE FIRMWARE > ABORT TRANSFER

Use this activator to cancel any TFTP transfer in progress.

SYSTEM UTILITY > CONFIG TRANSFER

Select the config transfer method and perform the transfer from this menu.

SYSTEM UTILITY > CONFIG TRANSFER > TRANSFER METHOD

Sends a file containing the unit configuration to a PC connected to the **CRAFT** port using XMODEM protocol or to a file on a TFTP server using the TFTP protocol.

CONFIG TRANSFER also lets you save the unit configuration as a backup file, so you can use the same configuration with multiple units. In addition, **CONFIG TRANSFER** can retrieve a configuration file from a TFTP server.

To support these transfers, ADTRAN delivers a TFTP program with the unit called TFTP Server. You can configure any PC running Microsoft Windows with this software, and store a configuration file.



Before using Start Transfer, the unit should have a valid IP address, subnet mask, and default gateway (if required). See DLP-004, Setting Ethernet IP Parameters for more information.

Only one configuration transfer session (upload or download) can be active at a time. **XMODEM** and **TFTP** are supported.

SYSTEM UTILITY > CONFIG TRANSFER > TFTP SERVER IP ADDRESS

Specifies the IP address of the TFTP server. Get this number from your system administrator. If using the ADTRAN Utilities TFTP server, this number appears in the TFTP server status window. The factory default value is **0.0.0.0**.

SYSTEM UTILITY > CONFIG TRANSFER > TFTP SERVER FILENAME

Defines the name of the configuration file that you transfer to or retrieve from the TFTP server. The default name is **ta_iad.cfg**, but you can edit this name.

SYSTEM UTILITY > CONFIG TRANSFER > CURRENT TRANSFER STATUS

Indicates the current status of the update.

SYSTEM UTILITY > CONFIG TRANSFER > PREVIOUS TRANSFER STATUS

Indicates the status of the previous update.

SYSTEM UTILITY > CONFIG TRANSFER > LOAD AND USE CONFIG

Retrieves the configuration file specified in the **TFTP SERVER FILENAME** field from the server. To start this command, enter **Y** to begin or enter **N** to cancel.



If you execute this command, the unit retrieves the configuration file, reboots, then restarts using the new configuration.

SYSTEM UTILITY > CONFIG TRANSFER > SAVE CONFIG REMOTELY

Saves the configuration file specified in **TFTP SERVER FILENAME** to the server identified in **TFTP SERVER IP ADDRESS**. To start this command, enter **Y** to begin or enter **N** to cancel.



*Before using this command, you must have identified a valid TFTP server in **TFTP SERVER IP ADDRESS**.*

SYSTEM UTILITY > SYSTEM UTILIZATION

View the CPU Utilization stats from this menu.

SYSTEM UTILITY > SYSTEM UTILIZATION > PERFORMANCE

Clear the System Utilization stats and view the total and current CPU utilization stats from this menu.

SYSTEM UTILITY > SYSTEM UTILIZATION > PERFORMANCE > TOTAL AVG CPU UTILIZATION

TOTAL AVG CPU UTILIZATION is a running total of CPU utilization since the last reset.

SYSTEM UTILITY > SYSTEM UTILIZATION > PERFORMANCE > CURRENT AVG CPU UTILIZATION

CURRENT AVG CPU UTILIZATION is the running total of CPU utilization since the last clear.

SYSTEM UTILITY > SYSTEM UTILIZATION > PERFORMANCE > CLEAR STATS

This activator will clear all the system utilization performance stats.

SYSTEM UTILITY > PING

Activate the ping test and define the ping packet characteristics from this menu.

SYSTEM UTILITY > PING > START/STOP

Activator to start and cancel a ping test.



Only one ping session can be active at a time.

SYSTEM UTILITY > PING > HOST ADDRESS

IP address or domain name (if DNS is configured) of device to receive the ping. The factory default is no entry in the host address field.

SYSTEM UTILITY > PING > SOURCE ADDRESS

Selects whether the ping packet should use the **INTERFACE** address or the **NAPT** (if that interface uses NAT) as the source address of the ping packet. This is the address that is used for ICMP requests. **INTERFACE** means it will use the IP address associated with the WAN for outgoing packets and the Ethernet IP address for ICMP requests made on the LAN. **NAPT ADDRESS** will replace the WAN IP address with the NAPT address for outgoing ICMP requests. Default is **INTERFACE**.

SYSTEM UTILITY > PING > SIZE (40-1500)

Total size of the ping to send. Range is 40 to 1500 bytes. The default is **64**.

SYSTEM UTILITY > PING > # OF PACKETS

Total packets to send every 2 seconds. Setting this to **0** allows the client to ping continuously. The default is **5**.

SYSTEM UTILITY > PING > # TRANSMITS

Total packets sent (read only).

SYSTEM UTILITY > PING > # RECEIVES

Total packets received (read only).

SYSTEM UTILITY > PING > % LOSS

Percentage loss based on ping returned from host (read only).

SYSTEM UTILITY > TRACEROUTE

Utility program used to trace a data path to a final destination.

SYSTEM UTILITY > TRACEROUTE > TRACE TARGET

Specifies the IP address of the remote system to trace the routes to.

SYSTEM UTILITY > TRACEROUTE > MAXIMUM HOPS

Specifies the maximum number of router exchanges allowed when traveling to the final destination (specified using the **TRACE TARGET** field) Range is **1** to **30**. Default is **30**.

SYSTEM UTILITY > TRACEROUTE > TIMEOUT (IN SECS)

Specifies the maximum delay (in milliseconds) given to a host (along a path to the final destination) to respond to the probe datagram sent before considering the packet a failure.

SYSTEM UTILITY > TRACEROUTE > RETRIES

Specifies the number of times the probe datagram is sent to each host (along the path to the final destination).

SYSTEM UTILITY > TRACEROUTE > BEGIN TRACEROUTE

Activator to begin the traceroute process by sending a probe datagram with a Time To Live (TTL) value of 1.

SYSTEM UTILITY > RESET UNIT

Selecting this activator will power reset the unit.

SYSTEM UTILITY > TERMINAL MODE

The terminal mode gives the user a command-line prompt. From this prompt, you can:

- Perform a reset with the command "reset"
- Perform a factory restore with the command "factory_reset"
- Configure the unit. The unit has the ability to download a text file which contains the configuration of the entire unit. This configuration may then be altered in a text editor, and then uploaded to a unit. (See DLP-013, *Saving and Loading Text Configuration Using the Terminal Command Line* for further assistance.)
- Debug and troubleshoot. This function would be carried out with the assistance of ADTRAN Technical Support.
- Start and stop the fail-safe timer for the auto-config feature (See DLP-014, *Unit Installation Using the Auto-Config Feature* for details.)

INTERFACES

Use the **INTERFACES** menu to view and configure parameters for the **T1**, **ETHERNET**, **V.35**, and **FXS** interfaces as shown in figure 5.




Figure 5. Interfaces menus

INTERFACES (T1[0])

View the T1 interface status and configure T1 parameters from this menu.



The 0 in T1[0] represents a physical port. The T1 physical port is always 0.

INTERFACES (T1[0]) > CONFIG

Configures the various T1 parameters and enable/disable loopbacks from this menu.

INTERFACES (T1[0]) > CONFIG > TIMING MODE

Choices are **NETWORK** and **INTERNAL**. Select **NETWORK** when the unit will receive timing from the network. Select **INTERNAL** when the unit will generate the timing. Default is **NETWORK**.

INTERFACES (T1[0]) > CONFIG > FORMAT

This sets the frame format for the T1 interface. The setting must match the frame format of the circuit to which the interface is connected. Choices are **ESF**, **SF**, **SLC96 ALARM-16**, and **SLC96 ALARM-13**. Extended Superframe (**ESF**) provides a non-disruptive means of full-time monitoring on the facility datalink (FDL). Default is **ESF**.



***SF** is equivalent to the D4 frame format.*

INTERFACES (T1[0]) > CONFIG > LINE CODE

This sets the line code for the T1 interface. The setting must match the line code of the circuit to which the interface is connected. Choices are **B8ZS** (bipolar with 8-zero substitution) and **AMI** (alternate mark inversion). Default is **B8ZS**.

INTERFACES (T1[0]) > CONFIG > EQUALIZATION

Select the line build out for the T1 interface. These are attenuation settings. 0 dB is the strongest signal and the other settings make the T1 transmit signal weaker. The setting of this field depends on whether the circuit is provisioned for DS1 by the telephone company. The choices are **0 dB**, **-7.5 dB**, **-15 dB**, **-22 dB**. Default is **0 dB**.

INTERFACES (T1[0]) > CONFIG > CSU LPBK

Choices are **ENABLE**, **DISABLE**, and **DISABLE ALL**. Default is **ENABLE**. This allows the unit to either respond or not respond to CSU loop up commands.

INTERFACES (T1[0]) > STATUS

Displays the T1 status including performance data and alarm histories.

INTERFACES (T1[0]) > STATUS > PERFORMANCE

Displays the T1 performance data.

INTERFACES (T1[0]) > STATUS > PERFORMANCE > TIME FRAME

Choices are **CURRENT**, **15 MIN**, and **24 HR**. Default is **CURRENT**. The performance fields -- either **CURRENT**, **15 MIN**, or **24 HR** -- provide status on key performance measures as specified in ANSI T1.403 and AT&T TR 54016 for each of the T1 ports. When **CURRENT** is chosen, the performance data for the current 15 minute window is shown.

INTERFACES (T1[0]) > STATUS > PERFORMANCE > CLEAR

Clears information for the selected port. Press <Enter> when the cursor is over this field to clear the data.

INTERFACES (T1[0]) > STATUS > PERFORMANCE > ES

ES (Errored Second) - For ESF mode, an errored second is defined as a second with one or more Path Code Violations (PCVs), or one or more Out of Frame (OOF) defects, or one or more Controlled Slip events, or a detected AIS (blue alarm) defect. For D4 (SF) mode, the presence of Bipolar Violations (BPVs) also triggers an errored second.

INTERFACES (T1[0]) > STATUS > PERFORMANCE > SES

SES (Severely Errored Second) - For ESF mode, an **SES** is a second with 320 or more PCVs, or one or more OOF defects, or a detected AIS defect. For D4 (SF) mode, an **SES** is a second with one or more Framing Error events, or an OOF defect, or at least 1544 Line Code Violations or more.

INTERFACES (T1[0]) > STATUS > PERFORMANCE > SEF

SEF (Severely Errored Frame) - An **SEF** condition occurs when 2 out of 6 consecutive frame bits are in error.

INTERFACES (T1[0]) > STATUS > PERFORMANCE > FS

FS (Frame Slip) - A frame slip is defined as one or more frame bit errors in a one-second interval.

INTERFACES (T1[0]) > STATUS > PERFORMANCE > LCV

LCV (Line Code Violation) - A Line Code Violation is defined as a Bipolar Violation (BPV), not including the B8ZS code word if B8ZS is employed. The number displayed is **LCV** events, which is defined as one or more BPVs in a one-second interval.

INTERFACES (T1[0]) > STATUS > PERFORMANCE > SLP

SLP (Slip Error Event) - This occurs when a received frame is either repeated or deleted. A **SLP** error indicates a timing problem.

INTERFACES (T1[0]) > STATUS > PERFORMANCE > UAS

UAS (Unavailable Seconds) - When 10 consecutive **SES** have been logged, the unit is declared in an unavailable state, the 10 **SES** are cleared, and the Unavailable Seconds count begins to increment starting with 10. The unavailable state is cleared when 10 consecutive non-SES seconds have occurred.

INTERFACES (T1[0]) > STATUS > ALARMS

Displays current alarms and alarm history for T1 interface.

INTERFACES (T1[0]) > STATUS > ALARMS > CURRENT ALARMS

Displays the current alarms on the T1 interface. An asterisk in a field indicates that an alarm is active.

LOS	Loss of Signal. No signal detected on port interface.
RED	Not able to frame data received on the port. Alternately referred to as Out of Frame (OOF).
YELLOW	Remote alarm indicator (RAI) being received on port.
BLUE	Receiving unframed all ones from the port alarm indicator signal (AIS).

INTERFACES (T1[0]) > STATUS > ALARMS > ALARM HISTORY

Displays the alarm history for the T1 interface. An asterisk in a field indicates that an alarm has occurred on the T1 interface since the last clear history.

LOS	Loss of Signal. No signal detected on port interface.
RED	Not able to frame data received on the port. Alternately referred to as Out of Frame (OOF).
YELLOW	Remote alarm indicator (RAI) being received on port.
BLUE	Receiving unframed all ones from the port alarm indicator signal (AIS).

INTERFACES (T1[0]) > STATUS > ALARMS > CLEAR HISTORY

Selecting this activator will clear the Alarm History for the T1 interface.

INTERFACES (T1[0]) > TEST

These options are used to initiate local and remote loopback tests and display the test status.

INTERFACES (T1[0]) > TEST > LOC LB

Loopback of the local unit. Choices are **NONE**, **LINE**, and **PAYLOAD**. **LINE** Loopback loops all of the received data back toward the network. The transmitted data is the identical line code that was received, including any bipolar violations. **PAYLOAD** Loopback is similar to line loopback except that the framing is extracted from the received data and then regenerated for the transmitted data. **NONE** disables the loopback test. Default is **NONE**.

INTERFACES (T1[0]) > TEST > REM LB

Loopback of remote unit. Choices are **NONE**, **LINE**, and **PAYLOAD**. **LINE** Loopback loops all of the received data back toward the network. The transmitted data is the identical line code that was received, including any bipolar violations. **PAYLOAD** Loopback is similar to line loopback except that the framing is extracted from the received data and then regenerated for the transmitted data. **NONE** disables the loopback test. Default is **NONE**.

INTERFACES (T1[0]) > TEST > TEST STATUS

Indicates whether a test is in progress.

INTERFACES (ETH[1])

View the Ethernet interface status and configure the Ethernet parameters from this menu.



The 1 in ETH[1] represents a physical port. The Ethernet physical port is always 1.

INTERFACES (ETH[1]) > CONFIG

Enable the **AUTONEGOTIATION** and configure the Ethernet rate from this menu.

INTERFACES (ETH[1]) > CONFIG > AUTONEGOTIATION

If set to **ON**, **AUTONEGOTIATION** automatically detects 10 or 100 Mb Ethernet and negotiates the duplex setting. **ON** is the default setting.

INTERFACES (ETH[1]) > CONFIG > DATA RATE

*(This option is only available if **AUTONEGOTIATION** is set to **OFF**.)* Data rate sets the speed of the Ethernet interface. Choices are **10BASET** and **100BASET**. The default value is **10BASET**.

INTERFACES (ETH[1]) > CONFIG > DUPLEX TYPE

*(This option is only available if **AUTONEGOTIATION** is set to **OFF**.)* Duplex type configures the Ethernet interface for **FULL DUPLEX** or **HALF DUPLEX**. **FULL DUPLEX** allows the Ethernet interface to send and receive simultaneously. **HALF DUPLEX** allows the Ethernet interface to either send or receive at any given moment, but not simultaneously. The default is **HALF DUPLEX**.



*If the **DATA RATE** is set to **10BASET** or **100BASET** the **DUPLEX TYPE** must be configured as **FULL DUPLEX** or **HALF DUPLEX**.*

INTERFACES (ETH[1]) > STATUS

Displays the **MAC ADDRESS**, **DATA LINK**, **DATA RATE** and **DUPLEX TYPE**.

INTERFACES (ETH[1]) > STATUS > MAC ADDRESS

This is a read-only field which displays the unique MAC address programmed at ADTRAN.

INTERFACES (ETH[1]) > STATUS > DATA LINK

Displays the status of the data link as up or down. This is a read only field.

INTERFACES (ETH[1]) > STATUS > DATA RATE

Displays the data rate present on the Ethernet interface. The possibilities are **10BASET**, **100BASET**, and **N/A**. **N/A** indicates the **AUTONEGOTIATION** is set to **ON** and there is no Ethernet connection. This is read only field.

INTERFACES (ETH[1]) > STATUS > DUPLEX TYPE

Displays the duplex type present on the Ethernet interface. The possibilities are **FULL DUPLEX** and **HALF DUPLEX**. This is a read only field.

INTERFACES (V35[2])

View the V.35 interface status and configure the V.35 parameters from this menu.



The 2 in V35[2] represents a physical port. The V.35 physical port is always 2.

INTERFACES (V35[2]) > CONFIG

Configure the DTE leads from this menu.

INTERFACES (V35[2]) > CONFIG > CTS

Sets the control characteristic of the clear-to-send lead. Choices are **NORMAL** (follows RTS) or **FORCE ON**. Default is **NORMAL**.

INTERFACES (V35[2]) > CONFIG > DCD

Sets the control characteristic of the carrier detect lead. Choices are **NORMAL** (follows valid signal on the network interface) or **FORCE ON**. Default is **NORMAL**.

INTERFACES (V35[2]) > CONFIG > DSR

Sets the control characteristic of the data set ready lead. Choices are **NORMAL** (follows DTR) or **FORCE ON**. Default is **NORMAL**.

INTERFACES (V35[2]) > STATUS

View the status of the DTE leads from this menu.

INTERFACES (V35[2]) > STATUS > RTS

View the status of Request to Send (RTS) lead. Possibilities are **OFF** or **ON**. This is a read only field.

INTERFACES (V35[2]) > STATUS > DTR

View the status of the Data Terminal Read (DTR) lead. Possibilities are **OFF** and **ON**. This is a read only field.

INTERFACES (FXS)

View the FXS interface status and configure the FXS parameters from this menu.

INTERFACES (FXS) > CONFIG

Configure the FXS mode, line impedance and Tandem parameters from this menu.

INTERFACES (FXS) > CONFIG > PORT

Indicates the port on which the FXS is installed.

INTERFACES (FXS) > CONFIG > MODE

Choices are given below. Default is **LOOP START**.



This mode needs to be set based on how the network is set up and how each port is being used. Each port does not need to be set to the same mode.

LOOP START	Sets the port to use FXS loop start signaling on the T-span and loop start supervision on the analog 2-wire interface.
GROUND START	Sets the port to use FXS ground start signaling on the T-span and ground start supervision on the analog 2-wire interface.
TR08 SINGLE	Sets the port to use Single Party Channel Unit signaling on the T-span (as defined by TR-TSY-000008) and loop start supervision on the analog 2-wire interface.
TR08 UVG	Sets the port to use Universal Voice Grade signaling on the T-span (as defined by TR-TSY-000008) and either loop start or ground start supervision on the analog 2-wire interface.
DPO	Sets the port to use Dial Pulse signaling to originate dialed numbers.
TANDEM (E&M)	Sets the port to use E&M signaling on the T-span and either loop start or ground start supervision on the analog 2-wire interface. See the Tandem submenus for more information.

INTERFACES (FXS) > CONFIG > Tx (dB)

Sets the TX direction level points. This signal will change the volume of the voice. TX (dB) is the signal that is transmitted out the T1, with 0 dB being the strongest. If the volume is too loud across the T1, this number should be increased. A higher number indicates more attenuation which equals lower volume. The value entered must be less than 10 dB. Default is **6.0 dB**.

INTERFACES (FXS) > CONFIG > Rx (dB)

Sets the RX direction level points. This signal will change the volume of the voice. A higher number indicates more attenuation which equals lower volume. The value entered must be less than 10 dB. Default is **3.0 dB**. 0.0 dB is the maximum signal.

INTERFACES (FXS) > CONFIG > SVC MODE

Indicates whether the module is **IN SERVICE** or **OUT OF SVC**. This does not indicate whether the port has been mapped. For proper operation, the port must be mapped using the **DS0 MAPS** menu. Default is **IN SERVICE**.

INTERFACES (FXS) > CONFIG > LINE Z

Sets the line impedance. Choices are **600 OHMS**, **900 OHMS**, **600 OHMS + 2.16 μ F**, **900 OHMS + 2.16 μ F**, and **AUTO**. The line impedance of each port is based on the size of the network. Default is **600 OHMS**.

INTERFACES (FXS) > CONFIG > MSG IND

This is better referred to as On-Hook Message Waiting. When this is set to **ENABLE**, talk path is always open, even in On-Hook conditions, in order for these FXS message tones to pass through. Default is **DISABLE**. Enabling on-hook message waiting will allow message lamp usage but will cause a lower on-hook voltage. Disabling this feature will allow higher on-hook voltage but will not allow on-hook messaging other than caller ID.

INTERFACES (FXS) > CONFIG > TANDEM

Set the port to use E&M signaling on the T-Span and either loop start or ground start supervision on the analog 2-wire interface. To access submenus for this item, use the arrow keys to scroll to the **TANDEM** column for the corresponding module, and then press <Enter>.

INTERFACES (FXS) > CONFIG > TANDEM > CONVERSION MODE

Sets the port to either **LOOP START** or **GROUND START** mode. Default is **LOOP START**.

INTERFACES (FXS) > CONFIG > TANDEM > SUPERVISION

Sets the supervision method used to either **IMMEDIATE** or **WINK**. Default is **IMMEDIATE**.

INTERFACES (FXS) > CONFIG > TANDEM > DIAL TONE

(This option is only available for the Total Access 612/616/624.)

Used to enable or disable the on-board dial tone generation. Dial Tone is supplied for 5 sec, then it drops. It cannot be broken when dialing digits. Default is **DISABLE**.

INTERFACES (FXS) > CONFIG > TANDEM > RING BACK TONE

(This option is only available for the Total Access 612/616/624.)

Used to enable or disable the option of generating ring back tone towards the T-span. Default is **DISABLE**.

INTERFACES (FXS) > CONFIG > TANDEM > ANSWER SUPERVISION

Causes the polarity of tip and ring to be reversed when the far-end answers. Can be enabled or disabled. Default is **DISABLE**.

INTERFACES (FXS) > CONFIG > TANDEM > DNIS OPTIONS

This parameter is used in conjunction with DNIS Delay. Choices are **DISABLE**, **ENABLE**, and **ENABLE W/ NO ANSWER WINK**. Default is **DISABLE**.

INTERFACES (FXS) > CONFIG > TANDEM > DNIS DELAY

Sets the amount of time the voice module waits after it receives a wink before forwarding a DNIS digit if the **DNIS OPTION** is set to Enable. Choices are **0.5 SEC**, **1.0 SEC**, **1.5 SEC**, **2.0 SEC**, **2.5 SEC**, **3.0 SEC**, and **5.0 SEC**. Default is **3.0 SEC**.

INTERFACES (FXS) > CONFIG > TANDEM > FWD DISC DELAY

In Tandem mode, **FWD DISC DELAY** defines the delay between the time the forward disconnect is received and the actual battery removal/reversal. Choices are **250 MSEC**, **500 MSEC**, **750 MSEC**, **1 SEC**, and **2 SEC**. Default is **1 SEC**.

INTERFACES (FXS) > CONFIG > TANDEM > FWD DISC BATTERY

In Tandem mode, selects whether battery is to be removed or reversed during forward disconnect. Choices are **REMOVE** and **REVERSE**. Default is **REMOVE**.

INTERFACES (FXS) > STATUS

Displays the status of the FXS signal bits.

INTERFACES (FXS) > STATUS > PORT

Displays the port number.

INTERFACES (FXS) > STATUS > TA SIG

This parameter displays the status of the Transmit A signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXS) > STATUS > TB SIG

This parameter displays the status of the Transmit B signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXS) > STATUS > RA SIG

This parameter displays the status of the Receive A signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXS) > STATUS > RB SIG

This parameter displays the status of the Receive B signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXS) > TEST

Activate tests and monitor test status on a per port basis from this menu.

INTERFACES (FXS) > TEST > PORT

Displays the port number.

INTERFACES (FXS) > TEST > TEST

Choices are given below. Default is **NONE**.

NONE	Indicates that no test is currently active.
DIGITAL NETWORK LPBK	Used to loop back DS0 data coming from the network for each channel. Received data is latched in on the appropriate receive time slot on the receive bus. This data is then placed on the transmit bus in the unit's transmit time slot.
NETWORK ON HOOK TEST	Used to test signaling sent to the network by the unit. On-hook signaling is sent to the network. The customer loop is forced on-hook while this test is active.
NETWORK OFF HOOK TEST	Used to test signaling sent to the network by the unit. Off-hook signaling is sent to the network. The customer loop is forced on-hook while this test is active.
1 KHZ TONE-NEAR END	For Near End, the 2-wire side sends out a 1 kHz tone to verify talk path.
1 KHZ TONE-FAR END	For Far End, the tone side is sent out across the Network and can be heard if monitoring on the T1 as well as off of the Far End 2-wire side. This verifies talk path.
CUSTOMER RING TEST	The customer ring test will activate the unit's ring relay in a 2-on /4-off cadence, providing ringing to the customer loop.

INTERFACES (FXS) > TEST > TEST STATUS

This option indicates whether a test is in progress.

L2 PROTOCOL

Use the L2 protocol menu to select the L2 protocol, configure the protocol specific parameters and view the status as shown in Figure 6.




Figure 6. L2 Protocol Menu

L2 PROTOCOL (T1[0])

Configure the L2 protocol and view the status parameters from this menu.



The 0 in T1[0] represents a physical port. The T1 physical port is always 0.

L2 PROTOCOL (T1[0]) > PROTOCOL

Configure the L2 protocol mode. Choices are **PPP**, **FRE**, and **AUTO**. The default is **AUTO**. Selecting **AUTO** enables the Auto-config feature. Reference *DLP-014, Unit Installation Using the Auto-Config Feature*, for more information.

L2 PROTOCOL (T1[0]) > PROTOCOL > PPP

Point-to-Point Protocol (PPP) is an 8-bit serial protocol which allows a PC to connect as a TCP/IP host to a network through an asynchronous port. PPP is used for connection from a PC to an Internet Service Provider (ISP) for Internet access. PPP works over synchronous and asynchronous circuits.

Router-to-router and host-to-network connections can be made via PPP. PPP includes error detection while Serial Line Internet Protocol (SLIP) and other protocols do not.

L2 PROTOCOL (T1[0]) > PROTOCOL > FRE

Frame Relay is a switched data link layer protocol that handles multiple virtual circuits using High-Level Data Link Control (HDLC) encapsulation. Frame Relay uses statistical multiplexing as opposed to time-division-multiplexing to multiplex many logical connections over a single physical link. It contains a cyclic redundancy check (CRC) for detecting bad data, but leaves the error correction algorithms to be performed by the higher protocol layers. Similarly, Frame Relay uses simple congestion notification. This notification in turn can alert higher-layer protocols to exercise flow control. These characteristics allow Frame Relay to provide a more flexible and efficient use of bandwidth.

L2 PROTOCOL (T1[0]) > PROTOCOL > AUTO

Setting the **L2 PROTOCOL** to **AUTO** allows the unit to automatically detect the **L2 PROTOCOL** from the network.



*The **L2 PROTOCOL** must be set to **AUTO** in order to use the Auto-config feature. Reference DLP-12 Unit Installation Using the Auto-Config Feature, for more information.*

L2 PROTOCOL (T1[0] - PPP)

Configure the **L2 PROTOCOL** parameters and view the status of the T1 interface using PPP protocol from this menu.

L2 PROTOCOL (T1[0] - PPP) > CONFIG

Configure the **L2 PROTOCOL** parameters for the T1 interface using PPP protocol.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > MODE

Select the **L2 PROTOCOL** mode. Choices are **ROUTE IP**, **BRIDGE ALL**, and **ROUTE IP/BRIDGE OTHER**. The Default is **ROUTE IP**.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > AUTHENTICATION

The authentication menu contains the required parameters for the authentication of the PPP peer and for being authenticated by the PPP peer. Authentication is applied between the unit and the PPP peer as described in the **AUTHENTICATION** submenus.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > AUTHENTICATION > Tx METHOD

This parameter specifies how the unit is to be authenticated by the PPP peer. There are four possible selections. Default is **NONE**.

NONE	The connection will not allow the PPP peer to authenticate it.
PAP, CHAP, OR EAP	The unit will ask for EAP during the first PPP LCP negotiation and allow the PPP peer to negotiate down to CHAP or PAP .
CHAP OR EAP	The unit will ask for EAP during the first PPP LCP negotiation and allow the PPP peer to negotiate down to CHAP but not PAP .
EAP ONLY	The unit will only allow EAP to be negotiated. If the PPP peer is not capable of doing EAP , then the connection will not succeed.
PAP ONLY	The unit will only allow PAP to be negotiated. If the PPP peer is not capable of doing PAP , then the connection will not succeed.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > AUTHENTICATION > Tx USERNAME

*(This option is not available when the **TX METHOD** is set to **NONE**.)*

This is the username that is used when being authenticated by the PPP peer. You can enter up to 31 characters in this field. Default is no entry in the **TX USERNAME** field.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > AUTHENTICATION > Tx PASSWORD

*(This option is not available when the **TX METHOD** is set to **NONE**.)*

This is the password or secret that is used when being authenticated by the PPP peer. You can enter up to 30 characters in this field. Default is no password.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > AUTHENTICATION > Rx METHOD

This parameter specifies how the unit is to be authenticated by the PPP peer. There are four possible selections. Default is **NONE**.

NONE	The connection will not allow the PPP peer to authenticate it.
PAP, CHAP, OR EAP	The unit will ask for EAP during the first PPP LCP negotiation and allow the PPP peer to negotiate down to CHAP or PAP .
CHAP OR EAP	The unit will ask for EAP during the first PPP LCP negotiation and allow the PPP peer to negotiate down to CHAP but not PAP .
EAP	The unit will only allow EAP to be negotiated. If the PPP peer is not capable of doing EAP , then the connection will not succeed.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > AUTHENTICATION > RX USERNAME

*(This option is not available when the **RX METHOD** is set to none.)*

This is the username used to authenticate the PPP peer. You can enter up to 31 characters in this field. Default is no entry in the **RX USERNAME** field.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > AUTHENTICATION > RX PASSWORD

*(This option is not available when the **RX METHOD** is set to none.)*

This is the password or secret that is used to authenticate the PPP peer. You can enter up to 30 characters in this field. Default is no password.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > PPP

Configure the PPP specific parameters such as **MAX CONFIG**, **MAX TIMER**, **MAX FAILURE**, and **FORCE PEER IP ADDRESS** from this menu.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > PPP > MAX CONFIG

This value is the number of unanswered configuration-requests that should be transmitted before resetting PPP negotiations. The possible values are **5**, **10**, **15** and **20** (default).

L2 PROTOCOL (T1[0] - PPP) > CONFIG > PPP > MAX TIMER (SEC)

This value is the number of seconds to wait between unanswered configuration-requests. The possible values are **1 SEC**, **2 SECS**, **3 SECS (DEFAULT)**, **5 SECS** and **10 SECS**.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > PPP > MAX FAILURE

Due to the nature of PPP, configuration options may not be agreed upon between two PPP peers. This value is the number of configuration-naks that should occur before an option is configuration-rejected. The possible values are **5 (DEFAULT)**, **10**, **15** and **20**.

L2 PROTOCOL (T1[0] - PPP) > CONFIG > PPP > FORCE PEER IP ADDRESS

This option forces the PPP to negotiate the IP address entered instead of allowing the other an address to be assigned by the remote end.

L2 PROTOCOL (T1[0] - PPP) > STATUS

View the **L2 PROTOCOL** status for the T1 interface using the PPP protocol.

L2 PROTOCOL (T1[0] - PPP) > STATUS > LCP

Link Control Protocol. Reflects LCP layer active.

L2 PROTOCOL (T1[0] - PPP) > STATUS > BCP

Shows UP if PPP Bridge Control Protocol has negotiated successfully.

L2 PROTOCOL (T1[0] - PPP) > STATUS > IPCP

Shows UP if PPP IP Control Protocol has negotiated successfully.

L2 PROTOCOL (T1[0] - PPP) > STATUS > UP TIME

Displays how long the PPP session has been connected.

L2 PROTOCOL (T1[0] - PPP) > STATUS > Tx PKTS

Number of packets transmitted.

L2 PROTOCOL (T1[0] - PPP) > STATUS > Rx PKTS

Number of packets received.

L2 PROTOCOL (T1[0] - PPP) > STATUS > Tx BYTES

Number of bytes transmitted.

L2 PROTOCOL (T1[0] - PPP) > STATUS > Rx BYTES

Number of bytes received.

L2 PROTOCOL (T1[0] - PPP) > STATUS > CLEAR STATS

Selecting this activator will clear the PPP stats.

L2 PROTOCOL (T1[0] - FRE)

Configure the **L2 PROTOCOL** parameters and view the status of the T1 interface using Frame Relay protocol from this menu.

L2 PROTOCOL (T1[0] - FRE) > CONFIG

Configure the **L2 PROTOCOL** parameters for the T1 interface using the Frame Relay protocol.

L2 PROTOCOL (T1[0] - FRE) > CONFIG > MAINTENANCE PROTOCOL

The Frame Relay maintenance protocol is used on the WAN port. The maintenance protocol is used to send link status and virtual circuit information between Frame Relay switches and other devices (such as routers) that communicate with them. Possible choices are as follows:

- | | |
|------------------------|---|
| ANNEX D (ANSI) | This is ANSI standard ANSI T1.617-D and is the most commonly used in the United States. |
| ANNEX A (Q933A) | This is the CCITT European standard, ITU-T Q.933-A. |
| LMI | This was developed by a vendor consortium and is also known as the “Consortium” management interface specification. It is still used by some carriers in the United States. |

STATIC (No Sig) This should be selected when there is no Frame Relay switch in the circuit. The DLCIs are assigned in the DLCI Mapping and must be the same for the device it will communicate with.

The default value is **ANNEX D (ANSI)**.

L2 PROTOCOL (T1[0] - FRE) > CONFIG > POLLING FREQUENCY (5-30)

This parameter is the interval that the unit polls the Frame Relay switch using the maintenance protocol selected. The unit is required to poll the Frame Relay switch periodically to determine whether the link is active. The value is in seconds and ranges from **5 TO 30** seconds with a default of **10 SECONDS**.

L2 PROTOCOL (T1[0] - FRE) > CONFIG > DLCI MAPPING

This menu allows each DLCI to be mapped to a particular Frame Relay maintenance protocol. Each protocol parameter can be individually configured for each DLCI. By factory default, the DLCI map is empty.

When empty and a maintenance protocol other than static is used, the unit will poll the switch to determine which DLCIs are active. These active DLCIs will attempt to determine the IP addresses on the other end of the virtual circuit using Inverse ARP (IARP). If there is a response, the network learned will be added to the router tables and the virtual circuit will be treated as an unnumbered interface. Bridge connections are made using bridge group 1. When more than one DLCI mapping is listed, the unit will try to match the DLCIs learned from the Frame Relay switch with the DLCI values in the map. If there is a match, the protocols specified in the map are used. However, if an active DLCI is not in the list, it looks for an entry that has 0 in the DLCI field. This entry is considered the default entry to use when no match occurs. If this default entry is not present, the unit falls back to using IARP to determine the protocols to use with that particular virtual circuit. If a static maintenance protocol is used, at least one DLCI mapping must be specified.



*To insert a new profile, press the **I** key when over the **Num** column. A new inserted profile will always be set up with the default parameters. To copy parameters from an old profile to this newly inserted profile, use the copy (**C**) and paste (**P**) keys. Entire configuration trees can be copied with this method.*



*To delete an unused profile, use the **D** key when the cursor is over the number in the **Num** column. Once deleted, the profile is gone permanently.*

L2 PROTOCOL (T1[0] - FRE) > CONFIG > DLCI MAPPING > NUM

Displays the index number in the DLCI mapping table.

L2 PROTOCOL (T1[0] - FRE) > CONFIG > DLCI MAPPING > ACTIVE

When this parameter is set to **YES** (def), the mapping is used to determine the protocols used. If set to **No**, the unit will ignore the virtual circuit with this DLCI.

L2 PROTOCOL (T1[0] - FRE) > CONFIG > DLCI MAPPING > INTERFACE

Shows the user the physical and logical port associated with each DLCI. This is a read-only field.

L2 PROTOCOL (T1[0] - FRE) > CONFIG > DLCI MAPPING > DLCI

The Data Link Connection Identifier (DLCI) number identifies the virtual circuit being configured.

L2 PROTOCOL (T1[0] - FRE) > CONFIG > DLCI MAPPING > MODE

The mode identifies how the data will be forwarded. The choices are;

ROUTE IP	All IP data for this DLCI will be routed
BRIDGE ALL	All data for this DLCI will be bridged
ROUTE IP/BRIDGE OTHER	All IP data will be routed. All other data will be bridged.

The default is **ROUTE IP**.

L2 PROTOCOL (T1[0] - FRE) > CONFIG > BECN TIMEOUT (MSEC)

This value is expressed in milliseconds and represents the amount of time the unit will stop transmitting over a PVC which received a packet with the BECN bit set. Range is 50-5000 msec, the default is **50 SECONDS**.

L2 PROTOCOL (T1[0] - FRE) > STATUS

View the L2 protocol status for the T1 interface using the Frame Relay protocol.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT

View the Frame Relay statistics on the WAN port.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > PORT INDEX

Integer used for identifying DLCIs on an interface. A single DLCI will always be port index 0. Subsequent DLCIs will have incrementing port indices.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > SIGNAL STATE

Displays “up” when the unit is communicating with the Frame Relay switch; otherwise displays “down”.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > TX FRAMES

Total frames transmitted out the WAN port.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > RX FRAMES

Total frames received on the WAN port.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > TX BYTES

Total bytes transmitted out the WAN port

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > RX BYTES

Total bytes received on the WAN port

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > FULL STATUS TX FRAMES

Number of full status frames transmitted out the WAN port.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > FULL STATUS RX FRAMES

Number of full status frames received on the WAN port.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > LINK INTEGRITY STATUS TX FRAMES

Number of Link-Integrity (LI) only Frames transmitted out the WAN port.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > LINK INTEGRITY STATUS RX FRAMES

Number of LI only Frames received on the WAN port.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > DROP UNKNOWN DLCI

Number of frames received that were not associated with any known PVC.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > DROP INVALID DLCI

Number of frames received that had illegal DLCIs.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PORT > CLEAR STATS

Selecting this activator will clear the port Frame Relay Statistics.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC'S

View the Frame Relay status on a per PVC basis.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC'S > DLCI

The DLCI number identifies the virtual circuit being monitored.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC's > STATE

The state of the virtual circuit:

INACTIVE	The circuit exists but has been deactivated by the Frame Relay switch.
EXISTS	The circuit exists at this point and should be activated soon.
ACTIVE	The circuit is fully active.
OFF	The circuit has been turned off by the DLCI mapping active selection.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC's > Tx FRAMES

Number of Frame Relay packets that have been transmitted via this DLCI.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC's > Rx FRAMES

Number of Frame Relay packets that have been received via this DLCI.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC's > Tx BYTES

Number of Frame Relay bytes that have been transmitted via this DLCI.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC's > Rx BYTES

Number of Frame Relay bytes that have been received via this DLCI.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC's > DE COUNT

Number of packets received on this DLCI with the Discharge Eligible (DE) bit set.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC's > CR COUNT

Number of packets received on this DLCI with the command response (CR) bit set.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC's > BECN COUNT

Number of packets received on this DLCI with the Backward Explicit Congestion Notification (BECN) bit set.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC's > FECN COUNT

Number of packets received on this DLCI with the Forward Explicit Congestion Notification (FECN) bit set.

L2 PROTOCOL (T1[0] - FRE) > STATUS > PVC's > UNKNOWN FRAME RX

Number of frames that have been received that the unit does not know where to route.

L2 PROTOCOL (T1[0] - AUTO)

View the status of the T1 interface with the **L2 PROTOCOL** set to **AUTO** (using Auto-config feature). Reference *DLP-014, Unit Installation Using the Auto-Config Feature* for further details.

L2 PROTOCOL (T1[0] - AUTO) > STATUS

View the status of the auto detect function and traffic flow for the T1 interface with a L2 protocol set to auto.

L2 PROTOCOL (T1[0] - AUTO) > STATUS > STATE

This field represents the state of the auto detect/configuration function. The possible states are:

OFF	The T1 interface is down so the auto detect/configuration process is currently idle.
DETECTING L2 PROTOCOL	The T1 interface is up and waiting for the first control/signaling packet.
CONFIRMING FR	The T1 interface is up and one FR signaling packet has been received.
CONFIRMED FR	The T1 interface is up and two FR signaling packets have been received. It takes two consecutive control/signaling packets of the same type to confirm the detected protocol.
CONFIRMING PPP	The T1 interface is up and one PPP control packet has been received.
CONFIRMED PPP	The T1 interface is up and two PPP control packets have been received. It takes two consecutive control/signaling packets of the same type to confirm the detected protocol.

L2 PROTOCOL (T1[0] - AUTO) > STATUS > Tx PKTS

Number of packets transmitted out of the WAN port.

L2 PROTOCOL (T1[0] - AUTO) > STATUS > Rx PKTS

Number of packets received on the WAN port.

L2 PROTOCOL (T1[0] - AUTO) > STATUS > Tx BYTES

Number of bytes transmitted out of the WAN port.

L2 PROTOCOL (T1[0] - AUTO) > STATUS > Rx BYTES

Number of bytes received out the WAN port.

L2 PROTOCOL (T1[0] - AUTO) > STATUS > CLEAR STATS

Selecting this activator will clear the statistics.

L2 PROTOCOL (ETH[1])

Configure the **L2 PROTOCOL** parameters and view the status of the Ethernet interface from this menu.



The 1 in ETH[1] represents a physical port. The Ethernet physical port is always 1.

L2 PROTOCOL (ETH[1]) > PROTOCOL

Displays the L2 protocol for the **10/100BASET** Ethernet port. Currently only 802.3 is supported.

L2 PROTOCOL (ETH[1]) > CONFIG

Configure the mode for this **10/100BASET** Ethernet port from this menu.

L2 PROTOCOL (ETH[1]) > CONFIG > MODE

The mode identifies how the data will be forwarded. The choices are;

- | | |
|------------------------------|---|
| ROUTE IP | All IP data will be routed |
| BRIDGE ALL | All data will be bridged |
| ROUTE IP/BRIDGE OTHER | All IP data will be routed. All other data will be bridged. |

The default is **ROUTE IP**.

L2 PROTOCOL (ETH[1]) > STATUS

View the L2 protocol statistics for the 10/100BaseT Ethernet port from this menu.

L2 PROTOCOL (ETH[1]) > STATUS > TX PACKETS

Total number of packets transmitted out the Ethernet port.

L2 PROTOCOL (ETH[1]) > STATUS > RX PACKETS

Total number of packets received from the Ethernet port.

L2 PROTOCOL (ETH[1]) > STATUS > TX ERRORS

Total number of transmit errors encountered on Ethernet port.

L2 PROTOCOL (ETH[1]) > STATUS > SINGLE COLLISIONS

Total number of single collisions before successful transmission.

L2 PROTOCOL (ETH[1]) > STATUS > MULTIPLE COLLISIONS

Total number of multiple collisions before successful transmission.

L2 PROTOCOL (ETH[1]) > STATUS > EXCESSIVE COLLISIONS

Total number of collisions that resulted in packet being dropped.

L2 PROTOCOL (ETH[1]) > STATUS > DEFERRED TRANSMISSIONS

Total number of packets deferred due to collisions.

L2 PROTOCOL (ETH[1]) > STATUS > CARRIER SENSE ERRORS

Total number of carrier sense errors encountered (no link integrity).

L2 PROTOCOL (ETH[1]) > STATUS > RX ERRORS

Number of packets received in error and dropped.

L2 PROTOCOL (ETH[1]) > STATUS > CRCs

Number of packets detected with CRC errors.

L2 PROTOCOL (ETH[1]) > STATUS > RX COLLISIONS

Number of collisions which occurred during reception.

L2 PROTOCOL (ETH[1]) > STATUS > NON-ALIGNED

The **NON-ALIGNED** parameter is set when the number of bits received is not divisible by 8.

L2 PROTOCOL (ETH[1]) > STATUS > CLEAR COUNTS

Selecting this activator clears all the Ethernet stats.

BRIDGE

Configure the bridge parameters and view bridging statistics from this menu as shown in Figure 7.




Figure 7. Bridge Menu

BRIDGE > CONFIG

Configure the interfaces and bridge table parameters from this menu.

BRIDGE > CONFIG > INTERFACES (T1[0])

Configure the T1 interface bridging parameters from this menu.



The T1[0] interface will not appear as a bridge interface entry if the mode is set to route IP.

BRIDGE > CONFIG > INTERFACES (T1[0]) > SUB-INTERFACE

The T1 sub-interface is PPP [0.0] if the **L2 PROTOCOL** is set for **PPP**. The [0.0] represents the T1 physical and logical ports respectively. This is a read-only field. The T1 sub-interface is **FRE [0.X]** if the **L2 PROTOCOL** is set for **FRAME RELAY**. The [0.X] represents the T1 physical and logical ports respectively. The T1 physical port is always 0. The X represents the Frame Relay logical port and will be a number between 0-9 corresponding to the interface number under **L2 PROTOCOL > CONFIG > DLCI MAPPING**. This is a read-only field.

BRIDGE > CONFIG > INTERFACES (ETH[1])

Configure the Ethernet Bridging parameters from this menu.



The ETH[1] interface will not appear as a bridge interface entry if the mode is set to route IP.

BRIDGE > CONFIG > INTERFACES (ETH[1]) > SUB-INTERFACE

The Ethernet sub-interface is 802.3[1.0]. The [1.0] represents the Ethernet physical and logical ports, where 1 is the physical port and 0 is the logical port assigned to the Ethernet interface. This is a read-only field.

BRIDGE > CONFIG > BRIDGE TABLE

Configure the bridge table parameters from this menu.

BRIDGE > CONFIG > BRIDGE TABLE > BRIDGE TABLE AGING (0-65535)

BRIDGE TABLE AGING is how soon an entry ages out of the Bridge table (in minutes). Default is 5.

BRIDGE > STATUS

View the bridging statistics from this menu.

BRIDGE > STATUS > BRIDGE TABLE

View the bridge table status from this menu.

BRIDGE > STATUS > BRIDGE TABLE > MAC ADDRESS

Ethernet address for device learned. This is a read only field.

BRIDGE > STATUS > BRIDGE TABLE > LOCATION

Location indicates if it is LAN or WAN. This is a read-only field.

BRIDGE > STATUS > BRIDGE TABLE > TTL

Time to Live (TTL) is the number of seconds until the address is removed from the table. This is a read only field.

ROUTER

Configure the router parameters and view routing statistics from this menu as shown in Figure 8.




Figure 8. Router Menu

ROUTER > CONFIG

Configure the interfaces, routes, DHCP Server, and UDP Relay options from this menu.

ROUTER > CONFIG > INTERFACES

Configure the layer 3 options for the Ethernet and T1 interfaces from this menu.

ROUTER > CONFIG > INTERFACES (ETH[1])

Configure the layer 3 options for the Ethernet parameters from this menu.



The 1 in ETH[1] represents a physical port. The Ethernet physical port will always be 1.



The Ethernet port will always appear in the Router > Config > Interfaces table regardless of the L2 protocol mode setting.

ROUTER > CONFIG > INTERFACES (ETH[1]) > SUB-INTERFACE

The Ethernet sub-interface is 802.3[1.0]. The [1.0] represents the Ethernet physical and logical ports, where 1 is the physical port and 0 is the logical port assigned to the Ethernet interface. This is a read-only field.

ROUTER > CONFIG > INTERFACES (ETH[1])> SETUP

Configure the Ethernet addressing, RIP, and Proxy ARP from this menu.

PRIMARY IP

This is used to setup the IP addresses for the LAN on the unit.

IP ADDRESS

The IP address assigned to the unit's Ethernet port is set here. This address must be unique within the network. Default is **10.0.0.1**.

SUBNET MASK

This is the IP network mask that is to be applied to the unit's Ethernet port. Default is **255.255.255.0**.

RIP

Use this menu to enable RIP on the LAN interface.

VERSION

Enables or disables RIP and specifies the RIP protocol. Choices are; **OFF** (which disables RIP), **V1** (RIP Version 1) or **V2** (RIP Version 2). The default is **OFF**.

METHOD

Specifies the way the RIP protocol sends out its advertisements. The following options are available:

SPLIT HORIZON (DEF) Only routes not learned from this circuit are advertised.

POISON REVERSE All routes are advertised, but the routes learned from this port are "poisoned" with an infinite metric.

DIRECTION

Allows the direction at which RIP advertisements are sent and received to be specified.

TX AND RX (DEF)	RIP advertisements are periodically transmitted and are listened to on this port.
TX ONLY	RIP advertisements are periodically transmitted but are not listened to on this port.
RX ONLY	RIP advertisements are listened to on this port, but are not transmitted on this port.

V2 SECRET

Enter the secret used by RIP version 2 here.

PROXY ARP

This feature allows the network portion of a group of addresses to be shared among several physical network segments. The ARP protocol provides a way for devices to create a mapping between physical addresses and logical IP addresses. Proxy ARP makes use of this mapping feature by instructing a router to answer ARP requests as a "proxy" for the IP addresses behind one of its ports. The device which sent the ARP request will then correctly assume that it can reach the requested IP address by sending packets to the physical address that was returned. This technique effectively hides the fact that a network has been (further) subnetted. If this option is set to **YES**, when an ARP request is received on the Ethernet port the address is looked up in the IP routing table. If the forwarding port is not on the Ethernet port and the route is not the default route, the unit will answer the request with its own hardware address. Default is **No**.

SECONDARY IP

This allows the unit to specify additional IP addresses and networks on its Ethernet. The maximum number of entries is 5.

NUM

Displays the index number in the secondary IP list.

IP ADDRESS

This is the second IP address the unit will respond to on the Ethernet. Default is **0.0.0.0**.

SUBNET MASK

This is the mask for the network. Default is **255.255.255.255**.

ROUTER > CONFIG > INTERFACES (T1[0])

Configure the T1 interface parameters from this menu.



The 0 in T1[0] represents a physical port. The T1 physical port will always be 0.



*The T1 interface will not appear in the **ROUTER > CONFIG > INTERFACES** table if the **L2 PROTOCOL MODE** is set for **BRIDGE ALL**. The T1 interface will not appear if a DLCI is not entered in the **DLCI MAPPING** table (**L2 PROTOCOL (T1[0]-FRE) > CONFIG > DLCI MAPPING**) when the **L2 PROTOCOL** is set to **Frame Relay (FRE)**.*

ROUTER > CONFIG > INTERFACES (T1[0])> SUB-INTERFACE

The T1 sub-interface is PPP [0.0] if the L2 protocol is set for **PPP**. The [0.0] represents the T1 physical and logical ports respectively. This is a read-only field.

The T1 sub-interface is FRE [0.X] if the L2 protocol is set for **FRAME RELAY**. The [0.X] represents the T1 physical and logical ports respectively. The T1 physical port is always 0. The X represents the Frame Relay logical port and will be a number between 0-9 corresponding to the interface number under **L2 PROTOCOL > CONFIG > DLCI MAPPING**. This is a read-only field.

ROUTER > CONFIG > INTERFACES (T1[0]) > SET-UP

Configure the addressing, address mode, MTU, NAT, and RIP parameters from this menu.

ACTIVE

This option allows this DLCI to be assumed as active (set to **YES**) and begin transmitting data packets. If set to No, the interface will not be put in the route table and will not be seen by other devices on the network. This can be set to **NO** if waiting on future turnup from Frame Relay provider. Default is set to **YES**.

DLCI

*(This option is only available when the **L2 PROTOCOL** is set to **FRAME RELAY**.)* This DLCI is the number associated with the virtual circuit on the T1 interface. This number corresponds to the DLCI number in the **L2 PROTOCOL > CONFIG > DLCI MAPPING** Table.

ADDRESS MODE

This option determines how the WAN interface receives its IP address. **USER SPECIFIED** is the normal mode of operation.

- The choices are **USER SPECIFIED** (default) and **IPCP ASSIGNED** if the **L2 PROTOCOL** is set to **PPP**.
- The choices are **USER SPECIFIED** (default), **IARP**, and **DHCP CLIENT** if the **L2 PROTOCOL** is set to **FRAME RELAY**. **IARP** can be used to learn the far end IP address.
- If using the Auto-config option and the **L2 PROTOCOL** is **PPP**, the default is **IPCP ASSIGNED**. This means the unit will learn its IP address from a router on the WAN during IPCP negotiation. It is the same mechanism used by the auto detection algorithm.
- If using the Auto-config option and the **L2 PROTOCOL** is **FRAME RELAY**, the default is **DHCP CLIENT**. This means a DHCP Server from the service provider will issue this unit an IP address using DHCP.
- If the Auto-config option is not used, the **USER SPECIFIED** option for both **PPP** and **FRAME RELAY** allows the IP addresses to be statically programmed into the unit.

LOCAL IP ADDRESS

(This option is only applicable in User Specified address mode.) For **PPP**, this IP address is the local WAN IP address and can be statically assigned if using numbered interfaces. For **FRAME RELAY**, this is the numbered IP associated with this DLCI interface. This address is used by the unit to respond to Inverse ARP requests. If this IP address is left as **0.0.0.0**, the link is treated as unnumbered and the unit responds to the Inverse ARP with its Ethernet IP address. Default is **0.0.0.0**.

IP NETMASK

(This option is not available for FRAME RELAY DHCP CLIENT ADDRESS MODE.) For Frame Relay, the IP netmask which is applied to the **FAR-END IP ADDRESS** and **LOCAL IP ADDRESS** is specified here. Default is **0.0.0.0**. For the PPP protocol, this network mask is applied to the **FAR-END IP ADDRESS** for determining the PPP peer's network. If left as 0.0.0.0, a standard network mask is used. Default is **0.0.0.0**.

FAR-END IP ADDRESS

(This option is not available for FRAME RELAY DHCP CLIENT ADDRESS MODE, FRAME RELAY IARP ADDRESS MODE or PPP IPCP ASSIGNED ADDRESS MODE.) For Frame Relay, this is the IP address of the device on the other end of the virtual circuit. When this DLCI becomes active, the unit will add a route in the IP routing table. Default is **0.0.0.0**. For the PPP protocol, the PPP peer's IP address or network can be set here, if known. Leaving this at **0.0.0.0** means that the unit will determine the PPP peer's IP and network (if unnumbered) using the PPP IPCP. Default is **0.0.0.0**.

MTU

*(This option is not available if the **L2 PROTOCOL** is set to **PPP**.)* The Maximum Transmission Unit (MTU) is the largest possible data unit that can be transmitted. The range is 64 to 1500. The default is 1500.

NAT

The unit can perform Network Address Translation (NAT). This feature is most widely used when connecting to the Internet. The Ethernet network can consist of private network numbers. When this profile is enabled, all IP addresses on the Ethernet side are translated into the one real IP address. Multiple stations on the Ethernet side can access the Internet simultaneously.

PORT TRANSLATION

By enabling port translation, IP packets are modified as they pass through this interface. During transmission, private addresses are translated into a single public (NAPT) IP address. Incoming packets are translated from the public to private address based on the protocol port numbers. Default is **DISABLED**. When disabled, the unit will route across the connection normally.

PUBLIC IP ADDRESS MODE

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* The port translation requires at least a single real IP address for translating. This value can use the IP assigned to the interface (or assigned via layer 2 protocol like PPP), obtained using DHCP client, or statically specified on this menu. If the address cannot be learned, then it must be specified in order for the translation to work. Choices are **INTERFACE**, **SPECIFIED**, and **DHCP CLIENT**. Default is **INTERFACE**.

PUBLIC IP ADDRESS

*(This option is only available when **NAT PORT TRANSLATION** is enabled and the **PUBLIC IP ADDRESS MODE** is set to **SPECIFIED**.)* This is the specified address used as the NAT address. Default is **0.0.0.0**.

TRANSLATE BODY OF UNMAPPED PORTS

If this option is set to **DISABLED**, the user must add an entry in the translation table for every port which needs to be translated. If set to enabled, every port will be translated. The default is **DISABLED** which is sufficient for most circuits.

TRANSLATION TABLE

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* Add translation entries to specify port address translations or to setup 1:1 translations.

PUBLIC ADDRESS MODE

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* The public IP address used for this translation entry can be the NAPT IP address assigned to the link or can be specified. You specify an address to direct packets with certain protocols to different servers. Choices are **NAPT ADDR** and **SPECIFIED**. Default is **NAPT ADDR**.

PUBLIC ADDRESS

*(This option is only available when **NAT PORT TRANSLATION** is enabled and the **PUBLIC ADDRESS MODE** is set to **SPECIFIED**.)* Default is **0.0.0.0**.

PROTOCOL MODE

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* The upper layer protocol that is to be monitored for translation. For **TCP** and **UDP**, a port number must also be specified. Choices are **TCP**; **UDP**; **ICMP**; **ANY (TCP, UDP, or ICMP)**; **ALL**; **SPECIFIED**; and **NONE**. Default is **NONE**.

PROTOCOL

*(This option is only available when **NAT PORT TRANSLATION** is enabled and **PROTOCOL MODE** is set to **SPECIFIED**.)* Default is **0** (decimal).

PROTOCOL TYPE

*(This option is only available when **NAT PORT TRANSLATION** is enabled and **PROTOCOL MODE** is set to **SPECIFIED**.)* For well known protocols, this status will populate with the protocol. This is a read-only field.

PUBLIC TYPE MODE

*(This option is only available when **NAT PORT TRANSLATION** is enabled and **PROTOCOL MODE** is set to either **TCP** or **UDP**.)* The public destination port associated with this entry can be specified to add more control over certain types of traffic. Choices are **SPECIFIED** and **ANY PORT**. The default, **ANY PORT**, covers all port types.

PUBLIC PORT

*(This option is only available when **NAT PORT TRANSLATION** is enabled and **PUBLIC PORT MODE** is set to **SPECIFIED**.)* However, it will not be available if **PROTOCOL MODE** is set to **ICMP**; **ANY (TCP, UDP, or ICMP)**; **ALL**; **SPECIFIED**; or **NONE**. Default is **0** (decimal).

PUBLIC PORT TYPE

*(This option is only available when **NAT PORT TRANSLATION** is enabled and **PUBLIC PORT MODE** is set to **SPECIFIED**.)* However, it will not be available if **PROTOCOL MODE** is set to **ICMP**; **ANY (TCP, UDP, or ICMP)**; **ALL**; **SPECIFIED**; or **NONE**. Read-only.

PRIVATE ADDRESS MODE

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* The private IP address can be specified to steer certain protocols and ports to specific servers in the private network. Likewise, internal hosts can be steered to certain servers on the public network. A new request from the public network matching this entry's public parameters will be dropped if this mode is set to **ANY INTERNAL**. Choices are **SPECIFIED** and **ANY INTERNAL**. Default is **ANY INTERNAL**.

PRIVATE ADDRESS

*(This option is only available when **NAT PORT TRANSLATION** is enabled and **PRIVATE ADDRESS MODE** is set to **SPECIFIED**.)* Default is **0.0.0.0**.

PRIVATE PORT MODE

*(This option is only available when **NAT PORT TRANSLATION** is enabled. However, it will not be available if **PROTOCOL MODE** is set to **ICMP; ANY (TCP, UDP, or ICMP); ALL; SPECIFIED; or NONE**.)* The private destination port associated with this entry can be specified to add more control over certain types of traffic. Leave as Any Port to cover all port types. Choices are **ANY PORT** and **SPECIFIED**. Default is **ANY PORT**.

PRIVATE PORT

*(This option is only available when **NAT PORT TRANSLATION** is enabled and **PRIVATE PORT MODE** is set to **SPECIFIED**. However, it will not be available if **PROTOCOL MODE** is set to **ICMP; ANY (TCP, UDP, or ICMP); ALL; SPECIFIED; or NONE**. Default is **0** (decimal).)*

TRANSLATE BODY

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* When set to **YES**, the application payload in the packet is scanned for occurrences of the private/public IP address in binary or ASCII form. Set this to **No** (default) for applications where this will cause problems.

NAT VIEW

Shows the protocols that are actively being translated.

ENTRY

Indicates the entry number in the NAT View Table.

PRIV ADDR

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* This shows the private address of the host that the entry is used for.

PUB ADDR

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* This shows the public address this entry is using for its NAT.

SERV ADDR

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* This is the destination of the packet.

PROTO

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* This shows the protocol used (**TCP, UDP, ICMP**, etc.).

PRIV PORT

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* This is the private port used for the entry.

SPOOF PORT

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* If the same private port is already used in the table, it will spoof a different port for the entry.

SERVER PORT

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* This port is used on the public side.

TIME

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* This is the time since the entry was last used.

IN CNT

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* This is the number of packets that came in.

OUT CNT

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* This is the number of packets sent out.

NAPT ADDRESS

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* Represents the public address that is being used as the NAPT address. Read-only.

ENTRY COUNT

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* The number of entries in the NAT table. Maximum is 1500.

ENTRY OVERFLOW COUNT

*(This option is only available when **NAT PORT TRANSLATION** is enabled.)* A count of the dropped entries due to entry count being 1500 or greater; i.e., the NAT table is full.

RIP

Routing Information Protocol (RIP) is based on the shortest path (hops) between two IP addresses on a network. Each router maintains and broadcasts a routing table of known addresses/routes.

VERSION

The RIP protocol can be specified per DLCI. The possible selections are **OFF** (default) (meaning no RIP packets are listened to or sent), **V1** (RIP version 1) or **V2** (which is RIP version 2).

METHOD

This specifies the way the RIP protocol sends out its advertisements.

NONE (DEF)	All routes in the router table are advertised out this virtual circuit with no modification of the metrics.
SPLIT HORIZON	Only routes not learned from this particular virtual circuit are advertised.
POISON REVERSE	All routes are advertised, but the routes learned from this port are “poisoned” with an infinite metric.

DIRECTION

This parameter specifies the direction at which RIP advertisements are sent and listened.

TX AND RX (DEF)	RIP advertisements are periodically transmitted and are listened to on this virtual circuit.
TX ONLY	RIP advertisements are periodically transmitted but are not listened to on this virtual circuit.
RX ONLY	RIP is not transmitted on this virtual circuit but they are listened to.

V2 SECRET

Enter the secret used by RIP version 2 here.

ROUTER > CONFIG > ROUTES

Configures the default gateway and static routes from this menu.

ROUTER > CONFIG > ROUTES > DEFAULT GATEWAY

The default gateway is used by the unit to send IP packets whose destination address is not found in the route table. Default is **0.0.0.0**. This is a default gateway for the entire unit, not just for the Ethernet port.

ROUTER > CONFIG > ROUTES > STATIC ROUTES

Use this menu to enter static routes to other networks.

NUM

Displays the index number in the static route table.

ACTIVE

Adds this static route entry to the IP routing table when set to **YES** and removes it (if it was previously added) if set to **NO**. Default is **NO**.

IP ADDRESS

The IP address of the host or network address of the device being routed to. Default is **0.0.0.0**.

SUBNET MASK

Determines the bits in the previous IP address that are used. If this is to be a host route, it must be set to all ones (255.255.255.255). Default is **0.0.0.0**.

GATEWAY

The IP address of the router to receive the forwarded IP packet. Default is **0.0.0.0**.

HOPS

The number of router hops required to get to the network or host. Maximum distance is 16 hops. Default is **1**.

PRIVATE

When set to **NO**, the unit will advertise this static route using RIP. Setting to **YES** means that the route is kept private. Default is **NO**.

ROUTER > CONFIG > DHCP SERVER

Use this menu to set up the DHCP server.

ROUTER > CONFIG > DHCP SERVER > DHCP MODE

When set to **ON**, the unit acts as a DHCP server and will dynamically assign IP, network mask, default gateway, and DNS addresses to any device which transmits a broadcast DHCP request. The addresses assigned are based on the unit's own IP address and will be within the same network. Default is **OFF**.

ROUTER > CONFIG > DHCP SERVER > DHCP RENEWAL TIME (HOURS)

The number of hours that the DHCP server should allow the device to keep its previous IP assignment, before it is required to send a new DHCP request. The default is **0 HOURS** which represents an infinite lease.

ROUTER > CONFIG > DHCP SERVER > DOMAIN NAME

Text string used to represent the domain name used by the unit.

ROUTER > CONFIG > DHCP SERVER > PRIMARY DNS

First server to which domain name requests are sent.

ROUTER > CONFIG > DHCP SERVER > SECONDARY DNS

Server used as a backup, in case the primary address does not respond to the request.

ROUTER > CONFIG > DHCP SERVER > PRIMARY NBNS/WINS

Primary address of the NBNS/WINS server.

ROUTER > CONFIG > DHCP SERVER > SECONDARY NBNS/WINS

Secondary address of the NBNS/WINS server.

ROUTER > CONFIG > UDP RELAY

This menu configures the unit to act as a UDP relay agent for applications requiring a response from UDP hosts that are not on the same network segment as their clients.

ROUTER > CONFIG > UDP RELAY > MODE

When this option is set to **ON**, the unit will act as a relay agent. Default is **OFF**.

ROUTER > CONFIG > UDP RELAY > UDP RELAY LIST

Up to four relay destination servers can be specified in this list.

#

Indicates the entry number in the UDP Relay List table.

RELAY ADDRESS

This is the IP address of the server that will receive the relay packet. Default is **0.0.0.0**.

UDP PORT TYPE

The choices are **STANDARD** (def) and **SPECIFIED**. The following standard UDP protocols are relayed when set: DHCP, TFTP, DNS, NTP (Network Time Protocol, port 123), NBNS (NetBios Name Server, port 137), NBDG (NetBIOS Datagram, port 138), and BootP. When **SPECIFIED** is set, the UDP port (1 to 65535) can be specified in the UDP Port columns (up to three per server).

UDP PORT 1, 2, 3

Used for specifying UDP ports to be relayed. These fields only apply when **UDP PORT TYPE** is set to **SPECIFIED**. Default is 0.

ROUTER > STATUS

View the **IP ROUTES**, **IP STATS**, and **ARP CACHE** statistics from this menu.

ROUTER > STATUS > IP ROUTES

This lists the contents of the unit's IP route table.

ROUTER > STATUS > IP ROUTES > IP ADDRESS

Network or host destination address.

ROUTER > STATUS > IP ROUTES > NETMASK

Network mask applied to the destination address.

ROUTER > STATUS > IP ROUTES > GATEWAY

Host or router to receive this packet.

ROUTER > STATUS > IP ROUTES > PORT

Port gateway is located on:

LOCAL	sent directly to the unit's router
ETH0	The unit's ethernet port
WAN0	The unit's first PPP bundle
FR 0 . . . FR 9	The unit is connected up to 10 DLCIs

ROUTER > STATUS > IP ROUTES > USE

Number of times the unit has referenced the route.

ROUTER > STATUS > IP ROUTES > FLAGS

Important tags associated with this route entry

H	route is a host route
G	route is a gateway route
S	Static route, or learned via IPCP, IARP, DHCP
R1	learned from RIP Version 1
R2	learned from RIP Version 2
I	route learned from an ICMP redirect
C	directly connected interface
P	route is private and is not advertised with RIP
T	route is to a triggered port (updates only when table changes)
U	learned by unknown method

ROUTER > STATUS > IP ROUTES > HOPS

Number of routers that must go through to get to destination. Ranges from 0-15 or 16 for infinite (can't get there from here).

ROUTER > STATUS > IP ROUTES > TTL

Seconds until address is removed from table. Value of 999 means route is static.

ROUTER > STATUS > IP STATS

This section describes the following **STATISTICS** submenus (and see the tables on the pages following):

- IP
- ICMP
- TCP
- UDP

All of these statistics are taken from the MIB-II variables in RFC 1156. To clear the accumulated statistics, press the Enter key on **CLEAR COUNTS**.

ROUTER > STATUS > IP STATS > IP

View the IP statistics from this menu.

DEFAULT TTL

The default value inserted into the Time-To-Live field of the IP header of datagrams originated at this unit, whenever a TTL value is not supplied by the transport layer protocol.

IP DATAGRAMS RECEIVED

The total number of input datagrams received from interfaces, including those received in error.

BAD HEADER PACKETS

The number of input datagrams discarded due to errors in their IP headers, including bad check sums, version number mismatch, other format errors, time-to-live exceeded, errors discovered in processing their IP options, etc.

BAD IP ADDRESSES

The number of input datagrams discarded because the IP address in their IP header's destination field was not a valid address to be received at this unit. This count includes invalid addresses (e.g., 0.0.0.0) and addresses of unsupported Classes (e.g., Class E). For entities which are not IP Gateways and therefore do not forward datagrams, this counter includes datagrams discarded because the destination address was not a local address.

TOTAL FORWARDED DATAGRAMS

The number of input datagrams for which this unit was not their final IP destination, as a result of which an attempt was made to find a route to forward them to that final destination. In entities which do not act as IP Gateways, this counter will include only those packets which were Source-Routed via this unit, and the Source-Route option processing was successful.

BAD PROTOCOL DISCARDS

The number of locally-addressed datagrams received successfully but discarded because of an unknown or unsupported protocol.

DATAGRAMS DISCARDED

The number of input IP datagrams for which no problems were encountered to prevent their continued processing, but which were discarded (e.g., for lack of buffer space). Note that this counter does not include any datagrams discarded while awaiting re-assembly.

SENT DATAGRAMS TO UPPER LAYERS

The total number of input datagrams successfully delivered to IP user-protocols (including ICMP).

IP DATAGRAMS SENT

IP packets from the unit's IP stack.

ERRORFREE DISCARDS

The number of output IP datagrams for which no problem was encountered to prevent their transmission to their destination, but which were discarded (e.g., for lack of buffer space). Note that this counter would include datagrams counted in **TOTAL FORWARDED DATAGRAMS** if any such packets met this (discretionary) discard criterion.

ROUTELESS DISCARDS

The number of IP datagrams discarded because no route could be found to transmit them to their destination. Note that this counter includes any packets counted in **TOTAL FORWARDED DATAGRAMS** which meet this “no-route” criterion. Note also that this includes any datagrams which a host cannot route because all of its default gateways are down.

IP REASSEMBLY TIMEOUT

The maximum number of seconds which received fragments are held while they are awaiting reassembly at this unit.

DISASSEMBLED FRAGMENTS

The number of IP fragments received which needed to be reassembled at this unit.

IP DATAGRAMS REASSEMBLED

The number of IP datagrams successfully reassembled.

IP REASSEMBLY FAILURES

The number of failures detected by the IP reassembly algorithm (for whatever reason: timed out, errors, etc.). Note that this is not necessarily a count of discarded IP fragments since some algorithms (notably RFC 815s) can lose track of the number of fragments by combining them as they are received.

SUCCESSFUL FRAGMENTS

The number of IP datagrams that have been successfully fragmented at this unit.

FAILED FRAGMENTS

The number of IP datagrams that have been discarded because they needed to be fragmented at this unit but could not be, e.g., because their “Don't Fragment” flag was set.

TOTAL IP FRAGMENTS

The number of IP datagram fragments that have been generated as a result of fragmentation at this unit.

DISCARDED ROUTING ENTRIES

A packet the unit couldn't route.

CLEAR COUNTS

Setting this activator will clear the IP Statistics.

ROUTER > STATUS > IP STATS > ICMP**ICMP MESSAGES RECEIVED**

The total number of ICMP messages which the unit received. Note that this counter includes all those counted by **ICMP SPECIFIC ERRORS**.

ICMP SPECIFIC ERRORS

The number of ICMP messages which the unit received but determined as having errors (bad ICMP checksums, bad length, etc.)

ICMP DEST. UNREACHABLE MSGS RCVD

The number of ICMP Destination Unreachable messages received.

ICMP TIMEOUTS RECEIVED

The number of ICMP Time Exceeded messages received.

ICMP PARAMETER PROBLEM MSGS RCVD

The number of ICMP Parameter Problem messages received.

ICMP SOURCE QUENCH MSGS RCVD

The number of ICMP Source Quench messages received.

ICMP REDIRECTED MESSAGES RCVD

The number of ICMP Redirect messages received.

ICMP ECHO REQUEST MSGS RCVD

The number of ICMP Echo (request) messages received.

ICMP ECHO REPLY MSGS RCVD

The number of ICMP Echo Reply messages received.

ICMP TIMESTAMP REQUEST MSGS RCVD

The number of ICMP Timestamp (request) messages received.

ICMP TIMESTAMP REPLY MSGS RCVD

The number of ICMP Timestamp Reply messages received.

ICMP ADDRESS MASK REQUEST MSGS RCVD

The number of ICMP Address Mask Request messages received.

ICMP ADDRESS MASK REPLY MSGS RCVD

The number of ICMP Address Mask Reply messages received.

ICMP MESSAGES SENT

The total number of ICMP messages which this unit attempted to send. Note that this counter includes all those counted by **ICMP PACKET ERRORS**.

ICMP PACKET ERRORS

The number of ICMP messages which this unit did not send due to problems discovered within ICMP such as a lack of buffers. This value should not include errors discovered outside the ICMP layer such as the inability of IP to route the resultant datagram. In some implementations there may be no types of error which contribute to this counter's value.

ICMP DEST. UNREACHABLE MSGS SENT

The number of ICMP Destination Unreachable messages sent.

ICMP TIME EXCEEDED MSGS SENT

The number of ICMP Time Exceeded messages sent.

ICMP PARAMETER PROBLEM MSGS SENT

The number of ICMP Parameter Problem messages sent.

ICMP SOURCE QUENCH MSGS SENT

The number of ICMP Source Quench messages sent.

ICMP REDIRECT MSGS SENT

The number of ICMP Redirect messages sent.

ICMP ECHO REQUEST MSGS SENT

The number of ICMP Echo (request) messages sent.

ICMP ECHO REPLY MSGS SENT

The number of ICMP Echo Reply messages sent.

ICMP TIMESTAMP REQUEST MSGS SENT

The number of ICMP Timestamp (request) messages sent.

ICMP TIMESTAMP REPLY MSGS SENT

The number of ICMP Timestamp Reply messages sent.

ICMP ADDR MASK REQUEST MSGS SENT

The number of ICMP Address Mask Request messages sent.

ICMP ADDR MASK REPLY MSGS SENT

The number of ICMP Address Mask Reply messages sent.

CLEAR COUNTS

Selecting this activator will clear the ICMP statistics.

ROUTER > STATUS > IP STATS > UDP

View the UDP statistics from this menu

UDP DATAGRAMS RECEIVED

The total number of UDP datagrams delivered to UDP users.

NO APPLICATION AT DEST. PORT

The total number of received UDP datagrams for which there was no application at the destination port.

UDP BAD PACKETS

The number of received UDP datagrams that could not be delivered for reasons other than the lack of an application at the destination port.

UDP DATAGRAMS SENT

The total number of UDP datagrams sent from this unit.

CLEAR COUNTS

Selecting this activator will clear the UDP statistics.

ROUTER > STATUS > IP STATS > UDP TABLE

View the UDP table statistics from this menu.

LOCAL IP ADDRESS

The destination IP address of the packet

PORT

The destination UDP port of the packet.

ROUTER > STATUS > IP STATS > TCP

View the TCP statistics from this menu.

RETRANSMISSION TIMEOUT ALGORITHM

The algorithm used to determine the timeout value used for retransmitting unacknowledged octets.

MIN RETRANSMISSION TIMEOUT (MS)

The minimum value permitted by a TCP implementation for the retransmission timeout, measured in milliseconds. More refined semantics for objects of this type depend upon the algorithm used to determine the retransmission timeout. In particular, when the timeout algorithm is rsre(3), an object of this type has the semantics of the LBOUND quantity described in RFC 793.

MAX RETRANSMISSION TIMEOUT (MS)

The maximum value permitted by a TCP implementation for the retransmission timeout, measured in milliseconds. More refined semantics for objects of this type depend upon the algorithm used to determine the retransmission timeout. In particular, when the timeout algorithm is rsre(3), an object of this type has the semantics of the UBOUND quantity described in RFC 793.

MAX TCP CONNECTIONS

The limit on the total number of TCP connections the unit can support. In entities where the maximum number of connections is dynamic, this object should contain the value -1.

ACTIVE TCP CONNECTIONS

The number of times TCP connections have made a direct transition to the SYN-SENT state from the CLOSED state.

TCP PASSIVE CONNECTIONS

The number of times TCP connections have made a direct transition to the SYN-RCVD state from the LISTEN state.

TCP FAILED ATTEMPTS

The number of times TCP connections have made a direct transition to the CLOSED state from either the SYN-SENT state or the SYN-RCVD state, plus the number of times TCP connections have made a direct transition to the LISTEN state from the SYN-RCVD state.

TOTAL TCP RESETS

The number of times TCP connections have made a direct transition to the CLOSED state from either the ESTABLISHED state or the CLOSE-WAIT state.

TCP CURRENT CONNECTIONS

The number of TCP connections for which the current state is either ESTABLISHED or CLOSE-WAIT.

TCP SEGMENTS RECEIVED

The total number of segments received, including those received in error. This count includes segments received on currently established connections.

TCP SEGMENTS SENT

The total number of segments sent, including those on current connections but excluding those containing only retransmitted octets.

TOTAL TCP RETRANSMITS

The total number of segments retransmitted - that is, the number of TCP segments transmitted containing one or more previously transmitted octets.

CLEAR COUNTS

Selecting this activator will clear the TCP statistics.

ROUTER > STATUS > IP STATS > TCP CONNS

View the TCP Conns Statistics from this menu. This table shows the different states of each TCP connection.

STATE

The possible states are **FREE**, **CLOSED**, **LISTEN**, **SYNC SENT**, **SYNC RECEIVED**, **ESTABLISHED**, **FINWAIT1**, **FINWAIT2**, **CLOSEWAIT**, **LASTACK**, **CLOSING**, and **TIMEWAIT**.

LOCAL IP ADDRESS

Local IP address of the TCP connection.

LOCAL PORT

Local port of the TCP connection.

REMOTE IP ADDRESS

Remote IP address of the TCP connection.

REMOTE PORT

Remote port of the TPC connection.

ROUTER > STATUS > IP STATS > ARP CACHE

This lists the contents of the units's ARP table. All resolved cache entries time out after 20 minutes. Unresolved entries time out in 3 minutes. The ARP cache can be cleared by pressing "f" while on the menu or by pressing "d" on the individual number for that entry.

IP ADDRESS

IP address used for resolving MAC address.

MAC ADDRESS

Ethernet address resolved (0=no resolution).

TIME

Minutes since entry was first entered.

SECURITY

Configure the **SECURITY FILTERS** and **RADIUS SERVER** parameters from this menu as shown in Figure 9.




Figure 9. Security Menu

SECURITY > FILTERS

Configure the filter characteristics from this menu.

SECURITY > FILTERS > FILTER DEFINES

The unit can filter packets based on certain parameters within the packet. The method used by the unit allows the highest flexibility for defining filters and assigning them to a PVC or PPP link. The filters are set up in two steps: (1) defining the filter types, and (2) applying them to a list under the PVC or PPP configuration. This menu is used to define the individual filter defines based on packet type.



The Filter Defines option works for Frame Relay and PPP.

SECURITY > FILTERS > FILTER DEFINES > MAC FILTER DEFINES

The MAC filter is applied to bridge packets only. Bridge packets which are forwarded by the bridge functionality of the unit are defined here. Up to 32 MAC defines can be specified.

NUM

Indicates the entry number in the MAC Filter Defines table.

NAME

Identifies the filter entry. Default is no entry in name field.

SRC ADDR

48-bit MAC source address used for comparison. Values are in hexadecimal format. Default is **00:00:00:00:00:00**.

SRC MASK

Bits in the MAC source address which are compared. Values are in hexadecimal format. Default is **00:00:00:00:00:00**.

DEST ADDR

48-bit MAC destination address used for comparison. Values are in hexadecimal format. Default is **00:00:00:00:00:00**.

DEST MASK

Bits in the MAC destination address used for comparison. Values are in hexadecimal format. Default is **00:00:00:00:00:00**.

TYPE

16-bit type field used for comparison. Values are in hexadecimal format. Default is **00:00**.

TYPE MASK

Bits in the type field used for comparison. Values are in hexadecimal format. Default is **00:00**.

SECURITY > FILTERS > FILTER DEFINES > PATTERN FILTER DEFINES

The pattern filter is applied to bridge packets only. That is any packet which is forwarded by the bridge functionality of the unit. Up to 32 pattern defines can be specified.

NUM

Indicates the entry number in the Pattern Filter Defines table.

NAME

Identifies the filter entry. Default is no entry in name field.

OFFSET

Offset from beginning of packet of where to start the pattern comparison. Default is **0**.

PATTERN

64 bits used for comparison. Values are in hexadecimal format. Default is **00:00:00:00:00:00:00:00**.

MASK

Bits in the pattern to be compared. Values are in hexadecimal format. Default is **00:00:00:00:00:00:00:00**.

SECURITY > FILTERS > FILTER DEFINES > IP FILTER DEFINES

The IP filter defines apply to any IP packet, whether it is routed or bridged. Up to 32 IP defines can be specified.

NUM

Indicates the entry number in the IP Filter Defines table.

NAME

Identifies the filter entry. Default is no entry in name field.

SRC ADDR

IP address compared to the source address. Value is in dotted decimal format. Default is **0.0.0.0**.

SRC MASK

Bits which are used in the source comparison. Value is in dotted decimal format. Default is **0.0.0.0**.

DEST ADDR

IP address compared to the destination address. Value is in dotted decimal format. Default is **0.0.0.0**.

DEST MASK

Bits which are used in the destination comparison. Value is in dotted decimal format. Default is **0.0.0.0**.

SRC PORT

IP source port number used for comparison. Value is in decimal format. Range: **0 TO 65535**. Default is **0**.

SRC PORT COMP

Type of comparison that is performed. Default is **NONE**.

= means ports equal to

not = means port not equal to

> means port greater than

< means port less than

None - means the source port is not compared

DEST PORT

IP destination port number used for comparison. Value is in decimal format. Range: **0 TO 65535**. Default is **0**.

DEST PORT COMP

Type of comparison that is performed. Default is **NONE**.

= means ports equal to

not = means port not equal to

> means port greater than

< means port less than

None - means the source port is not compared

PROTO PORT

Protocol used for comparison. Value is in decimal format. Range: **0 TO 255**. Default is **0**.

PROTO PORT COMP

Type of comparison that is performed. Default is **NONE**.

= means ports equal to

not = means port not equal to

> means port greater than

< means port less than

None - means the source port is not compared

TCP ESTAB

Yes - only when TCP established

No - only when TCP not established

Ignore - ignore TCP flags (default)

SECURITY > FILTERS > INTERFACES

The unit can block packets in and out of an interface by use of the filters. They are set up in two steps: 1) define the types of packets that would be of interest in the **SECURITY > FILTERS > FILTER DEFINES** menu, and 2) set up the filter type and combination of defines that will cause a packet block.

SECURITY > FILTERS > INTERFACES (T1[0])

Define the filters for the T1 interfaces from this menu.



*The T1 interface will only appear in the **SECURITY > FILTERS > INTERFACE** list if the **L2 PROTOCOL** is set to **FRAME RELAY** or **PPP**.*

SECURITY > FILTERS > INTERFACES (T1[0]) > SUB-INTERFACE

If the **L2 PROTOCOL** is **FRAME RELAY**, the **SUB-INTERFACE** will be **FRE [0.X]**, where the [0.X] represents the T1 physical and logical ports respectively. The T1 physical port is always zero. The X represents the Frame Relay logical port and will always be a number 0-9 corresponding to the interface number under **L2 PROTOCOL > CONFIG > DLCI MAPPING**. This is a read-only field.

If the **L2 PROTOCOL** is **PPP**, the **SUB-INTERFACE** is **PPP [0.0]**. The [0.0] represents the T1 physical and logical ports respectively. This is a read-only field.

SECURITY > FILTERS > INTERFACES (T1[0]) > SET-UP

Enable the T1 interface filtering and define filters from this menu.

IN FROM VC

The packets which come into the unit can be filtered in three ways:

DISABLE (DEF)	Turns off packet input filtering. No incoming packets are blocked.
BLOCK ALL	All incoming packets from the WAN are blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > IN EXCEPTIONS list.
FORWARD ALL	All incoming packets from the WAN are not blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > IN EXCEPTIONS list.

IN EXCEPTIONS

This is a list of up to 32 filter entries which can be combined using the operations field. The operations are performed in the order they appear on the list.

#

Indicates the entry number in the In Exceptions table.

ACTIVE

Turns this entry active when set to **YES**. Default is **NO**.

TYPE

Selects the filter define list to reference (default is **MAC**):

MAC	from the SECURITY/FILTERS/FILTER DEFINES/MAC FILTER DEFINES list.
PATTERN	from the SECURITY/FILTERS/FILTER DEFINES/PATTERN FILTER DEFINES list.
IP	from the SECURITY/FILTERS/FILTER DEFINES/IP FILTER DEFINES list.

FILTER LIST NAME

Selects between filters defined in the list. Default is no entry in filter list name.

NEXT OPER

The next operation to use to combine with the next filter in the list (default is **END**):

END	the last filter to combination.
AND	logically AND this filter with the next filter in the list.
OR	logically OR this filter with the next filter in the list.

OUT TO VC

The packets which come from the unit to the WAN can be filtered in three ways:

DISABLE (DEF)	Turns off packet output filtering. No outgoing packets are blocked.
BLOCK ALL	All outgoing packets to the WAN are blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > OUT EXCEPTIONS list.
FORWARD ALL	All outgoing packets to the WAN are not blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > OUT EXCEPTIONS list.

OUT EXCEPTIONS

This is a list of up to 32 filter entries which can be combined using the operations field. The operations are performed in the order they appear on the list.

#

Indicates the entry number in the In Exceptions table.

ACTIVE

Turns this entry active when set to **YES**. Default is **No**.

TYPE

Selects the filter define list to reference (default is **MAC**):

MAC	from the SECURITY > FILTERS > FILTER DEFINES > MAC FILTER DEFINES list.
PATTERN	from the SECURITY > FILTERS > FILTER DEFINES > PATTERN FILTER DEFINES list.
IP	from the SECURITY > FILTERS > FILTER DEFINES > IP FILTER DEFINES list.

FILTER LIST NAME

Selects between filters defined in the list. Default is no entry in filter list name.

NEXT OPER

The next operation to use to combine with the next filter in the list (default is **END**):

END	The last filter to combination.
AND	logically AND this filter with the next filter in the list.
OR	logically OR this filter with the next filter in the list.

SECURITY > FILTERS > INTERFACES (ETH[1])

Define the filters for the Ethernet interface from this menu.

SECURITY > FILTERS > INTERFACES (ETH[1]) > SUB-INTERFACE

The Ethernet sub-interface is 802.3[1.0]. This is a read-only field.

SECURITY > FILTERS > INTERFACES (ETH[1]) > SET-UP

Enable the Ethernet interface filtering and define filters from this menu.

IN FROM VC

The packets which come into the unit can be filtered in three ways:

DISABLE (DEF)	Turns off packet input filtering. No incoming packets are blocked.
BLOCK ALL	All incoming packets from the WAN are blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > IN EXCEPTIONS list.
FORWARD ALL	All incoming packets from the WAN are not blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > IN EXCEPTIONS list.

IN EXCEPTIONS

This is a list of up to 32 filter entries which can be combined using the operations field. The operations are performed in the order they appear on the list.

#

Indicates the entry number in the In Exceptions table.

ACTIVE

Turns this entry active when set to **Yes**. Default is **No**.

TYPE

Selects the filter define list to reference (default is **MAC**):

MAC	from the SECURITY > FILTERS > FILTER DEFINES > MAC FILTER DEFINES list.
PATTERN	from the SECURITY > FILTERS > FILTER DEFINES > PATTERN FILTER DEFINES list.
IP	from the SECURITY > FILTERS > FILTER DEFINES > IP FILTER DEFINES list.

FILTER LIST NAME

Selects between filters defined in the list. Default is no entry in filter list name.

NEXT OPER

The next operation to use to combine with the next filter in the list (default is **END**):

END	the last filter to combination.
AND	logically AND this filter with the next filter in the list.
OR	logically OR this filter with the next filter in the list.

OUT TO VC

The packets which come from the unit to the WAN can be filtered in three ways:

DISABLE (DEF)	Turns off packet output filtering. No outgoing packets are blocked.
BLOCK ALL	All outgoing packets to the WAN are blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > OUT EXCEPTIONS list.
FORWARD ALL	All outgoing packets to the WAN are not blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > OUT EXCEPTIONS list.

OUT EXCEPTIONS

This is a list of up to 32 filter entries which can be combined using the operations field. The operations are performed in the order they appear on the list.

#

Indicates the entry number in the In Exceptions table.

ACTIVE

Turns this entry active when set to **Yes**. Default is **No**.

TYPE

Selects the filter define list to reference (default is **MAC**):

MAC	from the SECURITY > FILTERS > FILTER DEFINES > MAC FILTER DEFINES list.
PATTERN	from the SECURITY > FILTERS > FILTER DEFINES > PATTERN FILTER DEFINES list.
IP	from the SECURITY > FILTERS > FILTER DEFINES > IP FILTER DEFINES list.

FILTER LIST NAME

Selects between filters defined in the list. Default is no entry in filter list name.

NEXT OPER

The next operation to use to combine with the next filter in the list (default is **END**):

END	the last filter to combination.
AND	logically AND this filter with the next filter in the list.
OR	logically OR this filter with the next filter in the list.

SECURITY > RADIUS SERVER

The parameters for the **RADIUS SERVER** are configured in this menu.



Telnet radius is only available in A.04 firmware or later.

SECURITY > RADIUS SERVER > SERVER 1

This is the IP address of the first **RADIUS SERVER** that the unit should attempt to communicate with when authenticating a telnet session. Default is **0.0.0.0**.

SECURITY > RADIUS SERVER > SERVER 2

This is the IP address of the second **RADIUS SERVER** that the unit should attempt to communicate with when the primary server does not respond. Default is **0.0.0.0**.

SECURITY > RADIUS SERVER > SERVER 3

This is the IP address of the third **RADIUS SERVER** that the unit should attempt to communicate with when authenticating a telnet session. Default is **0.0.0.0**.

SECURITY > RADIUS SERVER > UDP PORT

This is the UDP port that the unit should use when communicating with the **RADIUS SERVER**. The default is **1812**, which is the commonly used port.

SECURITY > RADIUS SERVER > SECRET

The **RADIUS SERVER** and unit share this text string. It is used by the **RADIUS SERVER** to authenticate the unit, the RADIUS client. The factory default is not to use a secret.

SECURITY > RADIUS SERVER > RETRY COUNT (1-10)

This is the number of times the unit should send a request packet to the **RADIUS SERVER** without a response before giving up. If the number of attempts to communicate with the primary server is equal to the retry count, the second server (if defined) is tried. If the second server does not respond within the retry count the third server (if defined) is tried. If the third server does not respond within the retry count, the Telnet session is not authenticated and is dropped. The default is **5**.

DS0 MAPS

The **DS0 MAPS** menu allows you to map data and voice ports to the network T1 time slots. You may edit either of the two maps at any time. If you make changes to the current map, only those DS0s that have changed will be updated (unchanged DS0s will not be affected). The DS0 menu is shown in Figure 10.




Figure 10. DS0 Maps Menu.

DS0 MAPS > ACTIVE MAP

Activates one of the two dedicated maps (**MAP 1** or **MAP 2**). Default is **MAP 1**.

DS0 MAPS > APPLY TEMPLATE TO MAP 1

Choices are **CURRENT MAP 1**, **CURRENT MAP 2**, **D4 MAP**, **D1D MAP**, and **CLEAR MAP**. Default is **CURRENT MAP 1**. **D4 MAP** automaps the voice port in a 1-to-1 configuration. **D1D MAP** maps voice ports in an SLC-96 configuration. **CLEAR MAP** clears the entire map.

DS0 MAPS > EDIT/VIEW MAP 1

Define map 1. The map allows the user to assign services and ports to individual DS0s 1-24.



*In the default configuration for TDM A.04.XX firmware, DS0 24 is mapped to the router at 64K on **MAP 1**.*

DS0 MAPS > EDIT/VIEW MAP 1 > DS0

Displays the network T1 time slot to be assigned.

DS0 MAPS > EDIT/VIEW MAP 1 > SERVICE

When you select this option, a list of all of the slots and the modules will display. The first option is **OPEN**, which unassigns the slot if selected. For modules, the slot number and name are shown. For example, **FXS** indicates that an FXS card is installed. Use **TA IAD** to map network timeslots to the **V.35** port or to the router. Pick the appropriate **SERVICE** and press <Enter>. Default is **OPEN**.

DS0 MAPS > EDIT/VIEW MAP 1 > PORT

When you select this option, a list of ports appears. Pick the appropriate port, and press <Enter>. The selection list shows only the remaining ports available to be assigned. It may be necessary to unassign a port in order to reassign it elsewhere.

Once a **SERVICE** is assigned, the choices are module-dependent. For the **FXS**, the port choices are **UNASSIGNED**, and **PORTS 1-24**. For the **TA IAD**, the port choices are **UNASSIGNED**, **ROUTER 64K**, **ROUTER 56K**, **V.35 64K**, and **V.35 56K**. Default is **N/A**.

DS0 MAPS > EDIT/VIEW MAP 1 > RBS

Robbed Bit Signaling. Default is **N/A**. Once a service and port are assigned, this will automatically change to **ON** or **OFF**. The unit will automatically assign **OFF** where **RBS** is not an option. **ON** preserves the signaling bits between the connections. **OFF** ignores the signaling bits. For the **FXS**, **RBS** defaults to **ON**. The **RBS** parameter remains at **N/A** for the **TA IAD**, because **RBS** is not applicable to data connections.

DS0 MAPS > APPLY TEMPLATE TO MAP 2

Choices are **CURRENT MAP 1**, **CURRENT MAP 2**, **D4 MAP**, **D1D MAP**, and **CLEAR MAP**. Default is **CURRENT MAP 2**. **D4 MAP** automaps the voice port in a 1-to-1 configuration. **D1D MAP** maps voice ports in an SLC-96 configuration. **CLEAR MAP** clears the entire map.

DS0 MAPS > EDIT/VIEW MAP 2

Define map 2. The map allows the user to assign services and ports to individual DS0s 1-24.

DS0 MAPS > EDIT/VIEW MAP 2 > DS0

Displays the network T1 time slot to be assigned.

DS0 MAPS > EDIT/VIEW MAP 2 > SERVICE

When you select this option, a list of all of the slots and the modules will display. The first option is **OPEN**, which unassigns the slot if selected. For modules, the slot number and name are shown. For example, **FXS** indicates that an FXS card is installed. Use **TA IAD** to map network timeslots to the V.35 port or to the router. Pick the appropriate **SERVICE** and press <Enter>. Default is **OPEN**.

DS0 MAPS > EDIT/VIEW MAP 2 > PORT

When you select this option, a list of ports appears. Pick the appropriate port and press <Enter>. The selection list shows only the remaining ports available to be assigned. It may be necessary to unassign a port in order to reassign it elsewhere.

Once a **SERVICE** is assigned, the choices are module-dependent. For the **FXS**, the port choices are **UNASSIGNED**, and **PORTS 1-24**. For the **TA IAD**, the port choices are **UNASSIGNED**, **ROUTER 64K**, **ROUTER 56K**, **V.35 64K**, and **V.35 56K**. Default is **N/A**.

DS0 MAPS > EDIT/VIEW MAP 2 > RBS


Robbed Bit Signaling. Default is **N/A**. Once a service and port are assigned, this will automatically change to **ON** or **OFF**. The unit will automatically assign **OFF** where **RBS** is not an option. **ON** preserves the signaling bits between the connections. **OFF** ignores the signaling bits. For the **FXS**, **RBS** defaults to **ON**. The **RBS** parameter remains at **N/A** for the **TA IAD** because **RBS** is not applicable to data communications.

Appendix A. Configuring the Unit for Routing

Initial Setup

Before the unit can be configured for routing, the DS0s must be mapped.

DS0 Mapping

DS0 Mapping Instructions	
Step	Action
1.	From the Main menu, select DS0 MAPS .
2.	<p>Verify that the ACTIVE MAP is set to either MAP 1 or MAP 2. This is the map that is actively running on the unit. The unit has the ability to store two maps.</p> <ul style="list-style-type: none"> To edit the current map, press ENTER on EDIT/VIEW MAP 1 to view the map. (If Map 1 is the Active Map) To edit the standby map, press ENTER on EDIT/VIEW MAP 2 to view the map. (If Map 2 is the Active Map)
 NOTE	<i>The T1 line entering the unit is broken up into 24 DS0s or channels. At least one DS0 needs to be mapped to the router in order to use the unit for routing purposes.</i>
3.	Scroll down to the DS0 that will be mapped. (Any DS0 can be mapped to the router.)
4.	Set the SERVICE for the DS0 that you are mapping to TA IAD .
5.	Set the PORT of the DS0 that you are mapping to ROUTER 64K or ROUTER 56K .
6.	Map all the DS0s as desired, and exit this menu by pressing the left arrow button. Your changes will automatically save when exiting the map.
7.	Make sure the ACTIVE MAP is set to the correct map (the map you want running) before exiting the DS0 MAPS menu.

Setting up Routing Options

The unit can support IP routing and bridging. These procedures are described on the pages that follow.

IP Routing

After completing the DS0 mapping, there are three remaining steps required for the unit to be used for IP Routing: (1) Ethernet Interface Configuration, (2) T1 Interface Configuration, and (3) Default Gateway Configuration. All of these procedures are described in the pages that follow.


Router Ethernet Interface Setup


Router Ethernet Interface Setup Instructions	
Step	Action
1	From the Main Menu, select ROUTER , select CONFIG , select INTERFACES and then select ETH [1] SETUP and press ENTER .
2	Press Enter on the PRIMARY IP [+] option to enter primary ethernet configuration.
3	Set the IP ADDRESS of the Ethernet port.
4	Set the SUBNET MASK of the Ethernet port.
5	RIP on the Ethernet is disabled by default. If RIP needs to be enabled, press Enter on RIP [+] .
6	Press ENTER on VERSION and select V1 or V2 to activate RIP .
7	Press the down arrow and select the appropriate RIP METHOD , DIRECTION , and V2 SECRET (where applicable).
8	Press the left arrow key to return to the Ethernet menu showing PRIMARY IP and SECONDARY IPS .
9	If the unit needs additional secondary IP addresses, press Enter on SECONDARY IPS [+] . The unit supports up to 5 additional LAN segments. Enter each additional secondary IP address and subnet mask. Press "I" to insert additional entries.

Router T1 Interface Setup

Before configuring the Router T1 Interface, choose **L2 PROTOCOL** and select **PPP**, **FRE**, or **AUTO**. Setup instructions for the **PPP** and **FRE** are described on the following pages. For information on setting the **L2 PROTOCOL** to **AUTO**, reference DLP-014, *Unit Installation Using the Auto-Config Feature*.

Router T1 Interface Setup Instructions when L2 Protocol = PPP	
Step	Action
1	From the Main Menu, select L2 PROTOCOL and press ENTER .
2	Set the T1 [0] interface protocol to PPP .
3	Press Enter on the CONFIG [+] option. Verify mode is Route IP.
4	Press Enter on the AUTHENTICATION [+] option if you wish to change options related to how the link is established. Default is Tx METHOD = NONE and RX METHOD = NONE . If TX METHOD and RX METHOD are set to any option other than NONE , TX/RX USERNAME and PASSWORD options will appear.
5	Left arrow back to the main menu.
6	<p>Select router, select CONFIG, select INTERFACES, and select T1 [0] SETUP. Enter WAN information:</p> <ul style="list-style-type: none"> • Far-End IP Address The far-end WAN IP address from the unit. • IP Netmask The subnet mask for this WAN link • Local IP Address The local WAN IP address for the unit. <p>The other config items can be left at the defaults.</p>
7	For NAT configuration, please see the IP Routing with NAT section of this appendix.

Router T1 Interface Setup Instruction when L2 Protocol = Frame Relay (FRE) (required if the unit is to be used for Frame Relay IP Routing on the WAN interface)	
Step	Action
1	From the Main Menu, select L2 PROTOCOL and press ENTER .
2	Set the T1 [0] interface protocol to FRE .
3	Press Enter on the CONFIG [+] option.
4	Set the MAINTENANCE PROTOCOL to ANNEX D (ANSI), ANNEX A (q 933a), LMI , OR STATIC (no sig).
 NOTE	<i>The MAINTENANCE PROTOCOL should be set based on the Frame Relay switch.</i>
5	Down arrow and press Enter on DLCI MAPPING [+] . Right arrow one time to create an entry.
6	Set ACTIVE to YES .
7	Set DLCI to the DLCI number.
8	Set mode to ROUTE IP .
9	Left arrow back to the main menu. Select ROUTER , select CONFIG , select INTERFACES , and select T1 [0] SETUP . Set ACTIVE to YES .
10	Set ADDRESS MODE to USER SPECIFIED and enter a FAR-END IP ADDRESS . This will force the unit to not use IARP.
11	Enter the IP Netmask.
12	Enter the local IP address for the unit. The other config items can be left at the default values.
13	For NAT configuration, please see the IP Routing with NAT section of this appendix.

Router T1 Interface Setup Instructions - IP Routing with NAT																					
Step	Action																				
1	The NAT menu is found under Router >Config >Interfaces (T1 [0]) > Setup . The NAT menu can be easily accessed by pressing <Ctrl><N> .																				
 NOTE	<i>The T1 interface will not appear if a DLCI is not entered in the DLCI mapping table (L2 Protocol T1[0]-FRE > Config > DLCI mapping) when the L2 protocol is set to Frame Relay (FRE).</i>																				
2	From the NAT menu, set PORT TRANSLATION to ENABLED . (This will enable translation and populate the corresponding NAT menu options.)																				
3	<p>Set PUBLIC IP ADDRESS MODE to either INTERFACE or SPECIFIED.</p> <ul style="list-style-type: none"> INTERFACE is the default and will use the WAN IP address for the NAPT address. SPECIFIED allows you to enter another public address for private addresses to be translated into. <p>For basic NAT, this is all of the configuration that needs to be done. For specific port translations or 1:1 mapping, you can enter TRANSLATION TABLE [+].</p>																				
4	From the TRANSLATION TABLE menu, create a new entry by using the right arrow to enter the table.																				
5	<p>Create specific NAT translations based on your application.</p> <table border="0"> <tr> <td>PUBLIC ADDRESS MODE</td><td>NAPT ADDR (Address) or SPECIFIED. Choice of using the NAPT address or specifying a different public address to be used for this translation.</td></tr> <tr> <td>PUBLIC ADDRESS MODE</td><td>NAPT ADDR (Address) or SPECIFIED. Choice of using the NAPT address or specifying a different public address to be used for this translation.</td></tr> <tr> <td>PROTOCOL</td><td>Protocol for this translation.</td></tr> <tr> <td>PUBLIC PORT MODE</td><td>SPECIFIED or ANY PORT. Choosing SPECIFIED brings up the PUBLIC PORT and PUBLIC PORT TYPE (read-only) settings.</td></tr> <tr> <td>PUBLIC PORT</td><td>Numeric Public Port number to be translated (i.e., 23, 80).</td></tr> <tr> <td>PUBLIC PORT TYPE</td><td>Read-only port type chosen by the user setting of the PUBLIC PORT option.</td></tr> <tr> <td>PRIVATE ADDRESS MODE</td><td>SPECIFIED or ANY INTERNAL. Choosing SPECIFIED brings up the PRIVATE ADDRESS option.</td></tr> <tr> <td>PRIVATE PORT MODE</td><td>SPECIFIED or ANY PORT. Choosing SPECIFIED brings up the PRIVATE PORT option.</td></tr> <tr> <td>PRIVATE PORT</td><td>Numeric Private Port number to be translated to (i.e. 23, 80).</td></tr> <tr> <td>TRANSLATE BODY</td><td>YES or NO. If set to YES, this will translate the body of the data packet and replace the private address with the NAPT address. Default is No, which is used for most applications.</td></tr> </table>	PUBLIC ADDRESS MODE	NAPT ADDR (Address) or SPECIFIED . Choice of using the NAPT address or specifying a different public address to be used for this translation.	PUBLIC ADDRESS MODE	NAPT ADDR (Address) or SPECIFIED . Choice of using the NAPT address or specifying a different public address to be used for this translation.	PROTOCOL	Protocol for this translation.	PUBLIC PORT MODE	SPECIFIED or ANY PORT . Choosing SPECIFIED brings up the PUBLIC PORT and PUBLIC PORT TYPE (read-only) settings.	PUBLIC PORT	Numeric Public Port number to be translated (i.e., 23, 80).	PUBLIC PORT TYPE	Read-only port type chosen by the user setting of the PUBLIC PORT option.	PRIVATE ADDRESS MODE	SPECIFIED or ANY INTERNAL . Choosing SPECIFIED brings up the PRIVATE ADDRESS option.	PRIVATE PORT MODE	SPECIFIED or ANY PORT . Choosing SPECIFIED brings up the PRIVATE PORT option.	PRIVATE PORT	Numeric Private Port number to be translated to (i.e. 23, 80).	TRANSLATE BODY	YES or NO . If set to YES , this will translate the body of the data packet and replace the private address with the NAPT address. Default is No , which is used for most applications.
PUBLIC ADDRESS MODE	NAPT ADDR (Address) or SPECIFIED . Choice of using the NAPT address or specifying a different public address to be used for this translation.																				
PUBLIC ADDRESS MODE	NAPT ADDR (Address) or SPECIFIED . Choice of using the NAPT address or specifying a different public address to be used for this translation.																				
PROTOCOL	Protocol for this translation.																				
PUBLIC PORT MODE	SPECIFIED or ANY PORT . Choosing SPECIFIED brings up the PUBLIC PORT and PUBLIC PORT TYPE (read-only) settings.																				
PUBLIC PORT	Numeric Public Port number to be translated (i.e., 23, 80).																				
PUBLIC PORT TYPE	Read-only port type chosen by the user setting of the PUBLIC PORT option.																				
PRIVATE ADDRESS MODE	SPECIFIED or ANY INTERNAL . Choosing SPECIFIED brings up the PRIVATE ADDRESS option.																				
PRIVATE PORT MODE	SPECIFIED or ANY PORT . Choosing SPECIFIED brings up the PRIVATE PORT option.																				
PRIVATE PORT	Numeric Private Port number to be translated to (i.e. 23, 80).																				
TRANSLATE BODY	YES or NO . If set to YES , this will translate the body of the data packet and replace the private address with the NAPT address. Default is No , which is used for most applications.																				

Default Gateway Setup

In A.04 TDM code, the default gateway is for the entire unit, not just for the Ethernet Port.

Default Gateway Setup Instructions	
1	From the Main Menu, select ROUTER , select CONFIG , and select ROUTES .
2	Press Enter on the DEFAULT GATEWAY and set the corresponding IP address for the DEFAULT GATEWAY .

Appendix B. Configuring the Unit for Bridging

Initial Setup

Before the unit can be configured for bridging, DS0s must be mapped. Reference the DS0 Mapping section in Section 4.2 Appendix A.


Setting up Bridging Options

If the unit will be used for bridging, continue with the steps below.

Bridging

Bridging is supported by the PPP and Frame Relay protocols. The following procedures described the bridging configuration for those two protocols.

PPP Bridging Setup Instructions	
1	From the Main Menu, select L2 PROTOCOL (T1[0])>PROTOCOL and select PPP .
2	Select CONFIG and press enter. Then select MODE and select BRIDGE ALL .
3	Use the left arrow to return to the Main Menu and select BRIDGE .
4	The user may confirm that Bridging is activated by selecting CONFIG and pressing enter. If the T1[0] interface appears in the list, the Bridging is active on the WAN link.
5	The time (in minutes) it takes an entry to age out of the Bridge table may be set by down arrowing to BRIDGE TABLE and then using the right arrow to select BRIDGE TABLE AGING .


Frame Relay Bridging Setup Instructions	
1	From the Main Menu, select L2 PROTOCOL (T1[0])>PROTOCOL and select FRE .
2	Select CONFIG and press enter.
3	Set the MAINTENANCE PROTOCOL TO ANNEX D (ANSI), ANNEX A (q933a), LMI , or STATIC (NO SIG) .
 NOTE	<i>The MAINTENANCE PROTOCOL should be set based on the Frame Relay switch.</i>
4	Select DLCI MAPPING and press enter. Then select MODE and select BRIDGE ALL for all DLCIs which will use bridging.
5	Use the left arrow to return to the Main Menu and select BRIDGE .

Frame Relay Bridging Setup Instructions (Continued)	
6	The user may confirm that Bridging is activated by selecting CONFIG and pressing enter. If the T1[0] interface appears in the list, the Bridging is active on the WAN link.
7	The time (in minutes) it takes an entry to age out of the Bridge table may be set by down arrowing to BRIDGE TABLE and then using the right arrow to select BRIDGE TABLE AGING .


Appendix C. Configuring the Unit for Voice Applications


To set the unit up for voice applications, follow the steps below.

Mapping the DS0s



DS0 Mapping Instructions	
Step	Action
1	From the MAIN menu, select DS0 MAPS .
2	<p>Verify that the ACTIVE MAP is set to either MAP 1 or MAP 2. This is the map that is actively running on the unit. The unit has the ability to store two maps.</p> <ul style="list-style-type: none"> To edit the current map, press Enter on EDIT/VIEW MAP 1 [+] to view the map. (If Map 1 is the Active Map) To edit the standby map, press Enter on EDIT/VIEW MAP 2 [+] to view the map. (If Map 2 is the Active Map)
 NOTE	<i>The T1 line entering the unit is broken up into 24 DS0s or channels. You must map each voice port you want to use.</i>
3	Scroll down to the DS0 that will be mapped.
4	Set the SERVICE for the DS0 that you are mapping to FXS .
5	Set the PORT of the DS0 that you are mapping. The port number entered must match the voice port the DS0 is being mapped to. RBS (robbed bit signaling) will automatically turn on when a port number has been selected.
6	Map all the DS0s as desired, and exit this menu by pressing the left arrow key. Your changes will save automatically upon exiting the map.
7	Make sure the ACTIVE MAP is set to the map definition you want implemented before exiting the DS0 MAPS menu.

Setting up the T1 Interface

T1 Interface Setup Instructions	
Step	Action
1	From the Main Menu, select INTERFACES .
2	Select T1[0] CONFIG [+] and press ENTER .
3	Right arrow to select FORMAT and choose ESF , SF , or SLC96 .
 NOTE	<i>This format must match the format used by the other units in the network.</i>
4	Set the LINE CODE to B8ZS or AMI .

T1 Interface Setup Instructions (Continued)	
 NOTE	<i>This line code must match the line code used by the other units in the network.</i>
5	Set the EQUALIZATION or line build out in the lines based on the size of the network.
6	Set the CSU LPBK option to ENABLE , DISABLE or DISABLE ALL based on whether looping to this unit from another unit will be allowed.

Setting up the FXS Voice Ports

FXS Voice Ports Setup Instructions	
Step	Action
1	From the Main Menu, select INTERFACES .
2	Select FXS CONFIG [+] and press ENTER .
3	Set the MODE of each port to LOOP START , GROUND START , TANDEM (E&M) , TR08 SINGLE , TR08 UVG , or DP0 .
 NOTE	<i>This mode needs to be set based on how the network is set up and how each port is being used. Each port does not need to be set to the same mode. If the mode is set to TANDEM (E&M), be sure to set the TANDEM options as described in Steps 9 and following.</i>
4	Set the Tx (dB) or transmit direction level points of each port. Default is recommended.
5	Set the Rx (dB) or receive direction level points of each port. Default is recommended.
6	Set the SVC MODE of each port to either IN SERVICE or OUT OF SVC .
7	Set the LINE Z , or line impedance, of each port based on the size of the network. Default is recommended.
8	Set the MSG IND to disable or enable. When set to enable, talk path is always open, even in on-hook conditions, in order for FXS message tones to pass through. Disabling this feature will allow higher on-hook voltage but will not allow on-hook messaging other than caller ID.
9	Press Enter on the TANDEM [+] option to view the TANDEM options if the port mode is set to TANDEM (E&M) .
10	Set the CONVERSION MODE of the port to either LOOP START or GROUND START .
11	Set the SUPERVISION of the port to either IMMEDIATE or WINK .
 NOTE	<i>Be sure to set the TANDEM options for each port set to TANDEM E&M.</i>

SECTION 4.3 T1 ATM USER INTERFACE GUIDE

The T1 ATM User Interface Guide is designed for use by network administrators and others who will configure and provision the system. This section provides details unique to the T1 ATM IADs. It contains an overview, application details, configuration information, and menu descriptions. It is recommended that you review *Section 1, Commons User Interface Guide* in addition to this section.

CONTENTS

Total Access 600 Overview	153
Analog Lifeline.	153
Firmware Updates.	153
Voice Over ATM Overview	154
Voice Over ATM Application	154
Configuring the Total Access 600	155
System Info.	155
System Config.	157
System Utility	160
Configuring WAN Settings	163
Configuring the Router – Configuration.	167
Configuring the Router – Status	180
Configuring the Router – Logs	181
Configuring Voice Support – Config	183
Configuring Voice Support – Status	184
Managing the Modules – Modules	185
Managing the Modules – V.35 Setup	188
Appendix A. Voice Gateway Quick Start Procedure (Voice Turn up)	191
Appendix B. RFC1483 Quick Start (IP Routing)	193
Appendix C. RFC1483 Quick Start (IP Routing with NAT)	195
Appendix D. RFC1483 Quick Start (Bridging)	196
Appendix E. Routing in HDIA Mode	197

FIGURES

Figure 1. Total Access 600 Rear Panel.	153
Figure 2. Voice over ATM	154
Figure 3. System Information Menu	155
Figure 4. System Configuration Menu.	157
Figure 5. System Utility Menu	160
Figure 6. WAN Menu.	163
Figure 7. ATM Config Menu	164
Figure 8. ATM Stats Menu	165
Figure 9. Router/Configuration Menu	167
Figure 10. Global Menu.	167
Figure 11. Ethernet Menu	172
Figure 12. WAN Menu.	174

Figure 13.	Router/Status Menu	180
Figure 14.	Router/Logs Menu	181
Figure 15.	Voice/Config Menu	183
Figure 16.	Voice/Status Menu	184
Figure 17.	Modules Menu	185
Figure 18.	V.35 Setup Menu	188
Figure 19.	Application Diagram	191
Figure 20.	Application Diagram	193
Figure 21.	Routing with Copper Mountain	198

1. TOTAL ACCESS 600 OVERVIEW

The Total Access 600 is a complete solution Integrated Access Device (IAD) for Voice over ATM (VoATM) applications. The unit includes a modular network interface, Nx64 V.35 interface, 10/100BaseT interface, FXS ports, life-line voice backup, and an optional battery back-up for added security. The Total Access 600 can provision, test, and provide status for any of the voice and data interfaces. All connections are made via the rear panel. In addition to a built-in IP router, the Total Access 600 contains an echo canceller and ADPCM compression modules necessary for VoATM applications.

Analog Lifeline

The **LIFE LINE** connector on the rear panel (see Figure 1) provides assured voice for port 1. When a connection to the Voice Gateway is not possible due to loss of power or some other reason, an on-board relay opens and the first port of the voice connector is provided with analog voice from the analog lifeline connection.



For the analog lifeline feature to work, the user must subscribe to an analog voice line and it must be connected via the lifeline connector.




Figure 1. Total Access 600 Rear Panel

Firmware Updates

Firmware can be updated by using XMODEM transfer protocol via the unit's **CRAFT** port (see Figure 1) or by using TFTP from a network server. (See DLP-007, *Upgrading the Firmware Using XMODEM* and DLP-008, *Upgrading the Firmware Using TFTP*.)

The terminal menu is the access point to all other operations. Each terminal menu item has several functions and submenus that identify and provide access to specific operations and parameters. These menu selections are described later in this User Interface Guide.



See Section 1, Commons User Interface Guide for instructions about navigating the terminal menus..



*See Section 2, Engineering Guidelines, for the **CRAFT** port connection pin-out.*

2. VOICE OVER ATM OVERVIEW

Voice over ATM (VoATM) is the technology used to transmit voice conversations over a data network using Asynchronous Transfer Mode (ATM). There are several potential benefits to moving voice over a data network using ATM. First, the small, fixed-length cells require lower processing overhead. Second, these small, fixed-length cells allow higher transmission speeds than traditional packet switching methods.

ATM allocates bandwidth on demand, making it suitable for high-speed connection of voice, data, and video services. Conventional networks carry data in a synchronous manner. Because empty slots are circulating even when the link is not needed, network capacity is wasted. ATM automatically adjusts the network capacity to meet the system needs.

3. VOICE OVER ATM APPLICATION

The echo canceller is used in ATM voice applications that require G.165 echo cancellation. The Total Access 600 also contains an integrated ADPCM encoder/decoder for voice compression.

Figure 2 shows a typical VoATM application. The Total Access 600 connects to the ATM Network to provide both voice and high speed data from a single platform.




Figure 2. Voice over ATM



Refer to the next section, Configuring the Total Access 600, for general configuration instructions. Refer to the appendices at the end of this section for information on using the Total Access 600 in specific applications:

- *Appendix A. Voice Gateway Quick Start Procedure (Voice Turn up) on page 191.*
- *Appendix B. RFC1483 Quick Start (IP Routing) on page 193.*
- *Appendix C. RFC1483 Quick Start (IP Routing with NAT) on page 195.*
- *Appendix D. RFC1483 Quick Start (Bridging) on page 196.*

4. CONFIGURING THE TOTAL ACCESS 600

System Info

The **SYSTEM INFO** menu provides basic information about the unit and contains data fields for editing information. Figure 3 displays the submenus available when you select this menu item.




Figure 3. System Information Menu

>System Name

Provides a user-configurable text string for the name of the Total Access 600. This name can help you distinguish between different installations. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar). This name will appear on the top line of all screens.

>System Location

Provides a user-configurable text string for the location of the Total Access 600. This field is to help you keep track of the actual physical location of the unit. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar).

>System Contact

Provides a user-configurable text string for a contact name. You can use this field to enter the name, phone number, or email address of a person responsible for the Total Access 600 system. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar).

>Unit Name

Product-specific name for the product assembly.

>CLEI Code

CLEI code for the product assembly.

> Part Number

ADTRAN part number for the product assembly.

>Serial Number

Serial number of the product assembly.

>Firmware Revision

Displays the current firmware revision level of the controller.

>Bootcode Revision

Displays the bootcode revision.

>System Uptime

Displays the length of time since the Total Access 600 system reboot.

>Date/Time

Displays the current date and time, including seconds. This field can be edited. Enter the time in 24-hour format (such as 23:00:00 for 11:00 pm). Enter the date in mm-dd-yyyy format (for example, 10-30-1998).



Each time you reset the system, this value resets to 0 days, 0 hours, 0 min and 0 secs.

System Config

Set up the Total Access 600 operational configuration from the **SYSTEM CONFIG** menu. Figure 4 shows the items included in this menu.




Figure 4. System Configuration Menu

>Network Timing Mode

Selects the timing source for the entire system. Network is the only timing option available.

Network

The system's clock is recovered from the network (WAN interface).

>Telnet Access

Sets Telnet access to **ON** or **OFF**.

>Telnet User List

Up to four users can be configured for access to the Total Access 600. Each user can be assigned a security level and time out.

Name

A text string of the user name for this session.

Authen Method

The user can be authenticated in two ways:

- | | |
|-----------------|--|
| PASSWORD | The Password field is used to authenticate the user. |
| RADIUS | The Radius client is used for authenticating the user. |

Password

When the authenticating method is **PASSWORD**, this text string is used for the password.

Idle Time (1-255)

This sets the amount of time you can be idle before you are automatically logged off.

Level

This is the security level granted to the user.

>Maint Port Menu

The Total Access 600's VT 100 **CRAFT** port can be accessed via an RJ-48 located on the rear panel. The setup for these ports is under this menu.

Password Protect

When set to **No**, the maintenance port is not password protected. When **YES** (def), the Total Access 600 will prompt for a password upon startup.

Password

This is the text string that is used for comparison when password protecting the maintenance port. By default, no password is entered.



*If you forget your password, type **CHALLENGE** in all capital letters. Call technical support and have the displayed **CHALLENGE** code ready.*



The security level for the maintenance port is always set to 0. This gives full access to all menus.



Passwords are case-sensitive.

Instructions for Changing Passwords	
Step	Action
1.	Select the PASSWORD field—a new PASSWORD field displays.
2.	Type the new password in the ENTER field.
3.	Type the new password again in the CONFIRM field.
	<i>The password can contain up to 12 alphanumeric characters. You can also use spaces and special characters in the password.</i>

Baud Rate

This is the asynchronous rate that the maintenance port will run. The possible values are 300, 1200, 2400, 4800, 9600 (def), 19200, 38400, 57600, and 115200.

Data Bits

This is the asynchronous bit rate that the maintenance port will run. The possible values are 7 or 8 (def) bits.

Parity

This is the asynchronous parity that the maintenance port will run. The possible values are **NONE** (def), **ODD**, or **EVEN**.

Stop Bits

This is the stop bit used for the maintenance port. The possible values are 1 (def), 1.5 or 2.

>Network Time

The Total Access 600 unit time can be entered manually from the **SYSTEM INFO** menu, or the unit can receive time from an NTP/SNTP server. The **NETWORK TIME** menu includes all parameters relating to how the unit communicates with the time server.

Server Type

The server type defines which port the Total Access 600 will listen on to receive timing information from the time server.

NT Time

The Total Access 600 will receive time from an NT server running SNTP software on its TIME port.

SNTP

The Total Access 600 will receive time directly from an SNTP server.

Active

This network timing feature can be turned on and off. It determines whether the unit will request and receive time from a time server.

Time Zone

There are several time zones available for the time to be displayed in. All time zones are based off of Greenwich Mean Time (GMT).

Adjust for Daylight Saving

Since some areas of the world use Daylight Savings Time, the Total Access 600 is designed to adjust the time on the first Sunday in April and the last Sunday in October accordingly if this option is turned on.

Host Address

This is the IP address of the time server that the Total Access 600 will request and receive time from.

Refresh

This is the interval of time between each request the Total Access 600 sends out to the time server. A smaller refresh time guarantees that the unit receives the correct time from the server and corrects possible errors more quickly, but it is more taxing on the machine. A range of refresh times is available for the user to decide which is best for their unit.

Status

This displays the current status of the time negotiation process. If an error is displayed, check all connections and configurations to try to resolve the problem.

System Utility

Use the **SYSTEM UTILITY** menu to view and set the system parameters shown in Figure 5.



Figure 5. System Utility Menu

>Upgrade Firmware

Updates firmware when Total Access 600 enhancements are released. Two transfer methods are available for use in updating the Total Access 600 system controller.

Transfer Method

The two methods for upgrading are **XMODEM** and **TFTP**. (See DLP-007, *Upgrading the Firmware Using XMODEM* and DLP-008, *Upgrading the Firmware Using TFTP* for more information.) **TFTP** requires a TFTP server running somewhere on the network. The Total Access 600 starts a TFTP client function which gets the upgrade code from the TFTP server. Selecting **XMODEM** will load the upgrade code through the **CRAFT** port using any PC terminal emulator with xmodem capability.

TFTP Server Address

This is required when the transfer method is TFTP. It is the IP address or domain name (if DNS is configured) of the TFTP server.

TFTP Server Filename

This is required when the transfer method is TFTP. It is the case-sensitive file name which contains the upgrade code.

Transfer Status

This appears when TFTP is used. It displays the status of the transfer as it happens. Any error or success message will be displayed here.

Start Transfer

This activator is used when the configurable items in this menu are complete.



*Before using **START TRANSFER**, the Total Access 600 should have a valid IP address, subnet mask, and default gateway (if required).*

Abort Transfer

Use this activator to cancel any TFTP transfer in progress.

>Config Transfer

Used only with TFTP transfers. Sends a file containing the Total Access 600 configuration to a file on a TFTP server using the TFTP protocol. **CONFIG TRANSFER** also lets you save the Total Access 600 configuration as a backup file, so you can use the same configuration with multiple Total Access 600 units. In addition, **CONFIG TRANSFER** can retrieve a configuration file from a TFTP server.

To support these transfers, ADTRAN delivers a TFTP program with the Total Access 600 called *TFTP Server*. You can configure any PC running Microsoft Windows with this software, and store a configuration file. See *DLP-008, Upgrading the Firmware Using TFTP* for details on how to use *TFTP Server*.



*Before using **CONFIG TRANSFER**, the Total Access 600 should have a valid IP address, subnet mask, and default gateway (if required).*

Only one configuration transfer session (upload or download) can be active at a time.

Transfer Method

Displays the method used to transfer the configuration file to or from a server. Currently, you must use TFTP.

Transfer Type

Only **BINARY** transfers are currently supported.

TFTP Server IP Address

Specifies the IP address of the TFTP server. Get this number from your system administrator.

TFTP Server Filename

Defines the name of the configuration file that you transfer to or retrieve from the TFTP server. The default name is **Total Access 600.cfg**, but you can edit this name.

Current Transfer Status

Indicates the current status of the update.

Previous Transfer Status

Indicates the status of the previous update.

Load and Use Config

Retrieves the configuration file specified in the **TFTP SERVER FILENAME** field from the server. To start this command, enter **Y** to begin or enter **N** to cancel.



If you execute this command, the Total Access 600 retrieves the configuration file, reboots, then restarts using the new configuration.

Save Config Remotely

Saves the configuration file specified in **TFTP SERVER FILENAME** to the server identified in **TFTP SERVER IP ADDRESS**. To start this command, enter **Y** to begin or enter **N** to cancel.



*Before using this command, you must have identified a valid TFTP server in **TFTP SERVER IP ADDRESS**.*

>Ping

Allows you to send pings (ICMP requests) to hosts. The following items are under this menu:



Only one ping session can be active at a time.

Start/Stop

Activator to start and cancel a ping test.

Host Address

IP address or domain name (if DNS is configured) of device to receive the ping.

Size (40-1500)

Total size of the ping to send. Range is 40 (64 is def) to 1500 bytes.

of Packets

Total packets to send every 2 seconds. Setting this to **0** allows the client to ping continuously.

Transmits

Total packets sent (read only).

Receives

Total packets received (read only).

%Loss

Percentage loss based on ping returned from host (read only).

Configuring WAN Settings

>DSLAM Type

Set this to the type of DSLAM the Total Access 600 will be connecting to.

>Layer One Interface

This is the physical layer protocol used to connect the DSLAM to the Total Access 600.

>Layer Two Protocol

This is the data link layer protocol used to connect the DSLAM to the Total Access 600.



If the DSLAM Type is CopperMountain, refer to Appendix E. Routing in HDIA Mode on page 197 for information.

>ATM Config

Use the **WAN** menu (Figure 6) to access the **ATM CONFIG** menu.




Figure 6. WAN Menu

Use the **ATM CONFIG** menu (Figure 7) to set the parameters listed below the figure.



Figure 7. ATM Config Menu

Idle Cells

The **IDLE CELLS** format must be configured for either **ATM FORUM** or **ITU**. Configuring this setting incorrectly for a particular circuit will cause poor performance at the ATM layer.



This setting must match the configuration setting of the ATM switch or DSLAM at the other end of the circuit.

Data Scrambling

DATA SCRAMBLING can be **ENABLED** or **DISABLED** for cell traffic. Configuring this setting incorrectly for a particular circuit will cause poor performance at the ATM layer.



This setting must match the configuration setting of the ATM switch or DSLAM at the other end of the circuit.

>ATM Stats

Use the **WAN** menu (Figure 6 on page 163) to access the **ATM STATS** menu (Figure 8) and view the parameters listed below the figure.

TA 608 TAD/MAZ/AM Stats		
ATM Config	AP: TxCells	0
ATM Stats	AP: RxCells	0
	AP: RxOAMCells	0
	AP: ReceiveCellsDiscarded	0
	AP: ReceiveCellErrors	0
	AP: Sync	Inactive
	AP: OutOfCellDelineation	0
	AAL5: TransmitFrames	0
	AAL5: ReceiveFrames	0
	AAL5: TransmitDiscardedFrames	0
	AAL5: ReceiveErrors	0
	AAL5: ReceiveDiscardedFrames	0
	AAL5: NoAtmFrames	0
	AAL5: NoDataPackets	0
	Clear Stats	<+>
MODE: T1 TAD		
NET: down		
^Z=help 0:37		

Figure 8. ATM Stats Menu

AP: Tx Cells

This is the number of cells transmitted.

AP: Rx Cells

This is the number of cells received.

AP: Rx OAM Cells

This is the number of OAM cells received

AP: Receive Cells Discarded

This is the number of cells received and discarded. An incrementing count in this field could indicate a configuration problem with the ATM layer.

AP: Receive Cell Errors

This is the number of cells received with an HEC error.

AP: Sync

This indicates cell delineation at the ATM layer.

AP: Out Of Cell Delineation

This indicates loss of cell delineation at the ATM layer.

AAL5: Transmit Frames

This is the number of AAL5 frames transmitted.

AAL5: Receive Frames

This is the number of AAL5 frames received.

AAL5: Transmit Discarded Frames

This is the number of AAL5 frames discarded.

AAL5: Receive Errors

This is the number of AAL5 errors received.

AAL5: Receive Discarded Frames

This is the number of AAL5 frames discarded.

AAL5: No ATM Frames

This is for internal use only.

AAL5: No Data Packets

This is for internal use only.

DBG: DEBUG

This is for internal use only.

Clear Stats

This is used to clear the counters on this menu screen.

Configuring the Router – Configuration

Use the **ROUTER/CONFIGURATION** menu (Figure 9) to access the **GLOBAL**, **ETHERNET**, and **WAN** menus.



Figure 9. Router/Configuration Menu

>Global

Use the **GLOBAL** menu (Figure 10) to set up general router functions.




Figure 10. Global Menu

IP

This is used for general IP configuration.

Mode

This item controls how the 600 handles IP routes. When this option is set to **ON** (def), the 600 will advertise and listen to routes from other IP routers. If **OFF**, the route table is still used, but only static routes are used for routing IP packets and only the Ethernet port is used. IP packets can be sent over the WAN, but only when bridged.

Static Routes

Use this menu to enter static routes to other networks.

ACTIVE	Adds this static route entry to the IP routing table when set to YES (def) and removes it (if it was previously added) if set to No .
IP ADDRESS	The IP address of the host or network address of the device being routed to.
SUBNET MASK	Determines the bits in the previous IP address that are used. <i>If this is to be a host route, it must be set to all ones (255.255.255.255).</i>
GATEWAY	The IP address of the router to receive the forwarded IP packet.
HOPS	The number of router hops required to get to the network or host. Maximum distance is 15 hops.
PRIVATE	When set to No , the Total Access 600 will advertise this static route using RIP. Setting to YES means that the route is kept private.

DHCP Server

DHCP MODE	When set to ON , the Total Access 600 acts as a DHCP server and will dynamically assign IP, network mask, default gateway, and DNS addresses to any device which transmits a broadcast DHCP request. The addresses assigned are based on the Total Access 600's own IP address and will be within the same network.
DHCP RENEWAL TIME	The number of hours that the DHCP server should allow the device before it is required to send a new DHCP request. The default is 15 hours, and 0 represents an infinite lease.

Domain Names

Enter the 600's domain name and the primary and secondary DNS servers in this menu.

DOMAIN NAME	Text string used to represent the domain name used by the Total Access 600.
PRIMARY DNS	First server to which domain name requests are sent.
SECONDARY DNS	Server used as a backup, in case the primary address does not respond to the request.
PRIMARY NBNS/WINS	Server to which NT domain name requests are sent.
SECONDARY NBNS/WINS	Server used when there is no response from the primary server.

UDP Relay

This menu configures the 600 to act as a UDP relay agent for applications requiring a response from UDP hosts that are not on the same network segment as their clients.

Mode

When this option is set to **ON** (def), the Total Access 600 will act as a relay agent.

UDP Relay List

Up to four relay destination servers can be specified in this list.

RELAY ADDRESS	This is the IP address of the server that will receive the relay packet.
UDP PORT TYPE	
STANDARD (def)	The following standard UDP protocols are relayed when set: DHCP, TFTP, DNS, NTP (Network Time Protocol, port 123, NBNS (NetBios Name Server, port 137), NBDG (NetBIOS Datagram, port 138), and BootP.
SPECIFIED	When set, the UDP port (1 to 65535) can be specified in the UDP Port columns (up to three per server).
UDP PORT 1, 2, 3	Used for specifying UDP ports to be relayed. These fields only apply when UDP PORT TYPE is set to SPECIFIED .

Bridge

The **BRIDGE** menu is used to set up the bridge parameters for the 600. The bridging function runs at the Media Access Control (MAC) level which allows any protocol packets that run over Ethernet to be forwarded. Bridging can run concurrently with IP. However, when IP routing is active, IP packets (which include ARP packets) are not bridged.

Mode

This is used to enable the bridge function.

Address Table

The 600 automatically maintains a table of MAC addresses detected and associates those addresses with the LAN or WAN port from which they were received.

AGING	The maximum time an idle MAC address remains in the table before being removed. The value is in minutes.
FORWARD POLICY	When this parameter is set to UNKNOWN (def), any bridge packet with a destination MAC address that is not in the bridge table is forwarded to all other ports. When set to KNOWN , the packet with the unknown destination MAC address is dropped and is not forwarded.

Security

Filter Defines

The Total Access 600 can filter packets based on certain parameters within the packet. The method used by the Total Access 600 allows the highest flexibility for defining filters and assigning them to a PVC. The filters are set up in two steps: (1) defining the packet types, and (2) adding them to a list under the PVC. This menu is used to define the individual filter defines based on packet type.

Filter Defines /MAC Filter Defines

The MAC filter is applied to bridge packets only. Bridge packets which are forwarded by the bridge functionality of the Total Access 600 are defined here. Up to 32 MAC defines can be specified.

NAME	Identifies the filter entry.
SRC ADDR	48-bit MAC source address used for comparison. (hexadecimal format)
SRC MASK	Bits in the MAC source address which are compared. (hexadecimal format)
DEST ADDR	48-bit MAC destination address used for comparison. (hexadecimal format)
DEST MASK	Bits in the MAC destination address used for comparison. (hexadecimal format)
MAC TYPE	16-bit MAC type field used for comparison. (hexadecimal format)
TYPE MSK	Bits in the MAC type field used for comparison. (hexadecimal format)

Filter Defines /Pattern Filter Defines

The pattern filter is applied to bridge packets only. That is any packet which is forwarded by the bridge functionality of the Total Access 600. Up to 32 pattern defines can be specified.

NAME	Identifies the filter entry.
OFFSET	Offset from beginning of packet of where to start the pattern comparison.
PATTERN	64 bits used for comparison. (hexadecimal format)
MASK	Bits in the pattern to be compared. (hexadecimal format)

Filter Defines /IP Filter Defines

The IP filter defines apply to any IP packet, whether it is routed or bridged. Up to 32 IP defines can be specified.

NAME	Identifies the filter entry.
IP SRC	IP address compared to the source address. (dotted decimal format)

SRC MASK	Bits which are used in the source comparison. (dotted decimal format)
IP DEST	IP address compared to the destination address. (dotted decimal format)
DEST MASK	Bits which are used in the destination comparison. (dotted decimal format)
SRC PORT	IP source port number used for comparison Range: 0 to 65535. (decimal format)
SRC PORT CMPR	Type of comparison that is performed. = means ports equal to not = means port not equal to > means port greater than < means port less than None - means the source port is not compared
DST PORT	IP destination port number used for comparison Range: 0 to 65535. (decimal format)
DST PORT CMPR	Type of comparison that is performed = means ports equal to not = means port not equal to > means port greater than < means port less than None - means the destination port is not compared
PROTO	Protocol used for comparison. Range: 0 to 255. (decimal format)
PROTO CMPR	Type of comparison that is performed = means protocols equal to not = means protocols not equal to > means protocols greater than < means protocols less than None means the protocol is not compared
TCP EST	Yes - only when TCP established

No - only when TCP not established

Ignore - ignore TCP flags

>Ethernet

Use the **ETHERNET** menu (Figure 11) to configure the Ethernet port on the 600.



Figure 11. Ethernet Menu

IP

This is used to set up the IP addresses for the LAN on the 600

IP Address

The IP address assigned to the 600's Ethernet port is set here. This address must be unique within the network.

Subnet Mask

This is the IP network mask that is to be applied to the 600's Ethernet port.

Default Gateway

The default gateway is used by the 600 to send IP packets whose destination address is not found in the route table.

RIP

Use this menu to enable RIP on the LAN interface.

MODE	Enables or disables RIP.
PROTOCOL	Specifies the RIP protocol. Choices are V1 (def) (which is RIP version 1) or V2 (RIP version 2).
METHOD	Specifies the way the RIP protocol sends out its advertisements. Choices are given below.
NONE	All routes in the router table are advertised with no modification of the metrics.
SPLIT HORIZON (def)	Only routes not learned from this circuit are advertised.
POISON REVERSE	All routes are advertised, but the routes learned from this port are "poisoned" with an infinite metric.
DIRECTION	Allows the direction at which RIP advertisements are sent and listened to be specified.
TX AND RX (def)	RIP advertisements are periodically transmitted and are listened to on this port.
TX ONLY	RIP advertisements are periodically transmitted but are not listened to on this port.
RX ONLY	RIP advertisements are not transmitted on this port, but are listened.
V2 SECRET	Enter the secret used by RIP version 2 here.

Proxy ARP

This feature allows the network portion of a group of addresses to be shared among several physical network segments. The ARP protocol provides a way for devices to create a mapping between physical addresses and logical IP addresses. Proxy ARP makes use of this mapping feature by instructing a router to answer ARP requests as a "proxy" for the IP addresses behind one of its ports. The device which sent the ARP request will then correctly assume that it can reach the requested IP address by sending packets to the physical address that was returned. This technique effectively hides the fact that a network has been (further) subnetted. If this option is set to **YES**, when an ARP request is received on the Ethernet port the address is looked up in the IP routing table. If the forwarding port is not on the Ethernet port and the route is not the default route, the 600 will answer the request with its own hardware address.

MAC Address

This is a read-only MAC address programmed at ADTRAN.

>WAN

Use the **WAN** menu (Figure 12) to configure WAN settings on the 600.



Figure 12. WAN Menu

L2 Protocol

Displays the current L2 protocol - ATM (Read Only).

ATM

Use the ATM menu to setup Data PVCs for the router.

Description

This is the text description for the PVC.

VPI

ATM virtual port identifier.

VCI

This is the ATM virtual channel identifier.

PCR

Peak Cell Rate. Limits transmitted cells.

QOS

Quality of Service. Indicates this PVC's traffic class.

Protocol

This is the protocol supported on the PVC.

RFC1483 IP

Use this selection to support IP on this PVC. (These settings only take effect when RFC1483 is the selected protocol.)

Active

This selection enables IP on this PVC.

Far - End IP Address

This is the address of the NEXT hop router on this interface.

IP netmask

This is the network mask used for this interface.

Local IP Address

This is the IP address for this PVC.

NAT

Use this menu to set up and use Network Address Translation on this interface.

NETWORK ADDRESS PORT TRANSLATION	By enabling port translation, IP packets are modified as they pass through this interface. During transmission, private addresses are translated into a single public (NAPT) IP address. Incoming packets are translated from the public to private address based on the protocol port numbers. Once enabled, you must set up NAT for use.
PUBLIC IP ADDRESS MODE	The port translation requires at least a single real IP address for translating. This value can use the IP assigned to the interface (or assigned via layer 2 protocol like PPP), obtained using DHCP client, or statically specified on this menu. If the address cannot be learned, then it must be specified in order for the translation to work.
TRANSLATION TABLE	Add translation entries to "fine tune" special protocols or specify private addresses.
PUBLIC ADDRESS MODE	The public IP address used for this translation entry can be the NAPT IP address assigned to the link or can be specified. You specify an address to direct packets with certain protocols to different servers.
PROTOCOL	The upper layer protocol that is to be monitored for translation. For TCP and UDP, a port number must also be specified.
PUBLIC PORT MODE	The public destination port associated with this entry can be specified to add more control over certain types of traffic. The default, ANY PORT , covers all port types.
PRIVATE ADDRESS MODE	The private IP address can be specified to steer certain protocols and ports to specific servers in the private network. Likewise, internal hosts can be steered to certain servers on the public network. A new request from the public network matching this entry's public parameters will be dropped if this mode is set to ANY INTERNAL .

PRIVATE PORT MODE	The private destination port associated with this entry can be specified to add more control over certain types of traffic. Leave as ANY PORT to cover all port types.
TRANSLATE BODY	By default, the application payload in the packet is scanned for occurrences of the private/public IP address in binary or ASCII form. Set this to No for applications where this will cause problems.
NAT VIEW	Shows the protocols that are actively being translated.
NAPT ADDRESS	Represents the public address that is being used as the NAPT address.
ENTRY COUNT	The number of entries in the NAT table.
ENTRY OVERFLOW COUNT	A count of the dropped entries due to low memory.

RIP

Use this menu to enable RIP on the WAN interface. (See *RIP* on page 173 for description of options.)

RFC 1484 Bridge

This is used to enable bridge mode on this PVC. (These settings only take effect when RFC1483 is the selected protocol.)

PPPoATM

The Total Access 600 uses the PPPoATM profile to specify the profile used when connected using PPP.

Authentication

The authentication menu contains the required parameters for the authentication of the PPP peer and for being authenticated by the PPP peer. Authentication is applied between the Total Access 600 and the PPP peer as follows:

TX Method

This parameter specifies how the Total Access 600 is to be authenticated by the PPP peer. There are four possible selections.

NONE (def)	The connection will not allow the PPP peer to authenticate it.
PAP, CHAP, OR EAP	The connection can be authenticated using PAP, CHAP or EAP.
CHAP OR EAP	The connection can be authenticated using CHAP or EAP only.
EAP	The connection will only allow authentication by the peer using EAP.

TX Username

This is the username that is used when being authenticated by the PPP peer.

TX Password

This is the password or secret that is used when being authenticated by the PPP peer.

RX Username

This is the username used to authenticate the PPP peer.

RX Password

This is the password or secret that is used to authenticate the PPP peer.

IP

The IP menu contains the parameters for exchanging IP data with the PPP peer.

Mode

Setting to **ON** (def) will permit this connection profile to negotiate PPP IPCP with the PPP peer for exchanging of IP packets.

Local IP

This is the IP address that is assigned to the PPP link when using numbered links. Leaving this as 0.0.0.0 means the Total Access 600 will determine its IP address using PPP IPCP. If the far end router does not assign an IP address, the PPP link is left unnumbered.

Netmask

This network mask is applied to the IP/Local IP address for determining the PPP peer's network. If left as 0.0.0.0, a standard network mask is used.

Remote IP

The PPP peer's IP address or network can be set here, if known. Leaving this at 0.0.0.0 means that the Total Access 600 will determine the PPP peer's IP and network using the PPP IPCP.

NAT

The Total Access 600 can perform Network Address Translation. This feature is most widely used when connecting to the Internet. The Ethernet network can consist of private network numbers. When this profile is connected, all IP addresses on the Ethernet side are translated into the one real IP address negotiated with the PPP peer (ISP). Multiple stations on the Ethernet side can access the Internet simultaneously. Setting this option to **ON** will cause the Total Access 600 to perform NAT. In the **OFF** (def) position, the unit will route across the connection normally.

Route

The IP parameters are configured in this menu. Usually the Total Access 600 will automatically discover the PPP peer's networks using PPP IPCP and/or RIP.

- **Route/Static Route**

Selecting yes will add a static route to the remote peer to the route table.

- **Route/Private**

Selecting yes will prevent this route from being advertised.

- **Route/Hops (1-16)**

This value is the metric or number of hops that RIP will use in advertising the static route. The range is 1 to 16, where 1 is the default. The value 16 is considered an infinite distance (poisoned route).

- **Route/Force IP**

When set to **YES**, the Total Access 600 will force the PPP peer to use the IP address in the **LOCAL IP** for this profile as its WAN IP address. Normally this is set in the **No** (def) position.

RIP

The RIP parameters can be adjusted from their defaults under this menu.

- **Mode**

The Total Access 600 performs RIP over the WAN connection when this is set to **ON** (def).

- **Protocol**

The Total Access 600 performs version 1, **V1** (def), or version 2, **V2**, of RIP on this WAN connection.

- **Method**

SPLIT HORIZON	Only routes not learned on the WAN connection are advertised.
POISON REVERSE (def)	All routes are advertised, including routes learned from the WAN connection. These routes are poisoned.
NONE	All routes are advertised, including routes learned from the WAN connection. No attempt is made to poison these routes.

- **Direction**

Tx AND Rx (def)	RIP advertisements are transmitted and listened to on the WAN connection.
Tx ONLY	RIP advertisements are transmitted and not listened to.
Rx ONLY	RIP advertisements are listened to but not transmitted.

- **Triggered**

When set to **YES**, only IP RIP updates are sent when the routing table has changed and learned routes are not "aged." When set to **No** (def), updates are sent periodically.

- **Retain**

When this Connection List entry is disconnected and this parameter is set to **YES**, all routes learned from this WAN connection are retained and their routing interface is set to idle.

PPP

The Total Access 600 supports the IETF standards for the Point-to-Point Protocol. The PPP state machine running in the Total Access 600 can be fine-tuned to support many applications that can be employed. The configurable items under this menu can be changed from their default values for special cases.

VJ Compression

When this item is set to **ON**, the Total Access 600 will perform TCP/IP header compression known as Van Jacobson compression to the PPP peer.

Max Config

This value is the number of unanswered configuration-requests that should be transmitted before giving up on a call. The possible values are 5, 10 (def), 15 and 20.

Max Timer

This value is the number of seconds to wait between unanswered configuration requests. The possible values are 1 sec, 2 secs (def), 3 secs, 5 secs and 10 secs.

Max Failure

Due to the nature of PPP, configuration options may not be agreed upon between two PPP peers. This value is the number of configuration-naks that should occur before an option is configuration-rejected. This allows a connection to succeed that might otherwise fail. The possible values are 5 (def), 10, 15 and 20.

Encapsulation

This is the PPP encapsulation. (LLC or VC-Mux)

Filters

The Total Access 600 can block packets in and out of a WAN port by use of the filters. They are set up in two steps: 1) define the types of packets that would be of interest in the **CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES** menu, and 2) set up the filter type and combination of defines that will cause a packet block.

WAN-TO-LAN (In)

The packets which come into the Total Access 600 can be filtered in three ways:

DISABLED (def)	Turns off packet input filtering. No incoming packets are blocked.
BLOCK ALL	All incoming packets from the WAN are blocked except as defined in the FILTERS/IN EXCEPTIONS list.
FORWARD ALL	All incoming packets from the WAN are not blocked except as defined in the FILTERS/IN EXCEPTIONS list.

In Exceptions

This is a list of up to 32 filter entries which can be combined using the operations field. The operations are performed in the order they appear on the list.

ACTIVE	Turns this entry active when set to ON .
TYPE	Selects the filter define list to reference:
MAC	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/MAC FILTER DEFINES list.
PATTERN	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/PATTERN FILTER DEFINES list.
IP	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/IP FILTER DEFINES list.
IPX	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/IPX FILTER DEFINES list.
FILTER LIST NAME	Selects between filters defined in the list.
NEXT OPER	The next operation to use to combine with the next filter in the list:
END	the last filter to combination.

AND	logically AND this filter with the next filter in the list.
OR	logically OR this filter with the next filter in the list.

LAN-TO-WAN (Out)

The packets which come out toward the WAN from the TA600 can be filtered in three ways:

DISABLED (def)	Turns off packet input filtering. No outgoing packets are blocked.
BLOCK ALL	All outgoing packets to the WAN are blocked except as defined in the FILTERS/OUT EXCEPTIONS list.
FORWARD ALL	All outgoing packets to the WAN are not blocked except as defined in the FILTERS/OUT EXCEPTIONS list.

Out Exceptions

This is a list of up to 32 filter entries. The setup is exactly the same as the **FILTERS/IN EXCEPTIONS** list.

Configuring the Router – Status

Use the **ROUTER/STATUS** menu to view and set the parameters shown in Figure 13. The **ROUTER/STATUS** screens give the user useful information for debugging the current routes in the 600.




Figure 13. Router/Status Menu

>Session

This menu maintains statistics about the active ATM PVCs.

>ARP cache

This is a listing of the currently connected Ethernet port on the LAN.

>Bridge Table

This shows the detected MAC addresses and the interface to which they are associated.

>IP Routes

This shows the current routes in the 600 and their use.

>LAN Stats

This shows traffic over the LAN interface.

>IP Stats

This shows IP traffic through the 600.

Configuring the Router – Logs

The Logs menu (Figure 14) contains logs displaying important information about the running condition of the Total Access 600. The logs can be set to capture diagnostics of error conditions only by way of a log level. The levels are divided up as follows:

- level 0 - Fatal event (causes reset)
- level 1 - Critical event
- level 2 - Error event
- level 3 - Warning event
- level 4 - Notify event
- level 5 - Informational event
- level 6 - Debugging event




Figure 14. Router/Logs Menu

Sys log Host

Set this to the IP address or domain name (if DNS configured) of the sys log host device. All log events are sent to this device.

PPP Log

Information pertaining to the PPP negotiation and authentication is logged in the PPP log.

Connection Log

Information pertaining to the call placement and answering is logged in the Connection log.

Network Log

Information pertaining to routing protocols is placed in this log.
Each log (PPP log, Connection log, and Network log) contains the following elements.

Active

When set to **YES** (def), PPP events below or equal the log level are logged into the log.

Wrap

When set to **YES** (def), new PPP events will overwrite old PPP events when the log is full. All logging will stop when the log is full and set to **No**.

Level

In order to log events, they must be at or below this level. Range is 0 to 6. The default is 3.

View

This menu displays the log list. The fields are as follows:

DATE/TIME	Date and time event occurred.
LEVEL	Level associated with this event (0-6).
MESSAGE	Text message for this event. If message is too long to fit on the line, another event appears below it continuing the message.

Clear

This clears the log when activated.

Configuring Voice Support – Config

Use the **VOICE/CONFIG** menu to view and set the parameters shown in Figure 15.



TA 608	TAD/Voice/Config		
Config	Call Control	Jetstream	
Status	VPI	0	
	VCI	39	
MODE: T1 TAD			
		NET: down	
		^Z=help	0:46

Figure 15. Voice/Config Menu

>Call Control

The **CALL CONTROL** setting is used to configure the correct Voice Gateway protocol for voice signaling control between the Total Access 600 and the configured Gateway. The **CALL CONTROL** setting must be configured correctly before the voice circuits will work correctly. The Total Access 600 supports Jetstream, Tollbridge, and CopperCom Voice Gateways.

>VPI

The **VPI** setting is used to configure the Total Access 600 virtual path setting used to communicate with the configured Voice Gateway.

>VCI

The **VCI** setting is used to configure the Total Access 600 virtual circuit setting used to communicate with the configured Voice Gateway.

Configuring Voice Support – Status

Use the **VOICE/STATUS** menu to view and set the parameters shown in Figure 16.




Figure 16. Voice/Status Menu

>Gateway Stats

The **GATEWAY STATS** menu shows the current state of the communication link between the Total Access 600 and the Voice Gateway. The Gateway Link is indicated as **UP** or **DOWN**. A count of management messages is indicated along with the number of active calls in progress.

>PVC Stats

The **PVC STATS** menu shows the current state of the virtual circuit used between the Voice Gateway and the Total Access 600 IAD for voice signaling and voice payload delivery.

>POTS Stats

The **POTS STATS** menu shows real-time indication status of each voice port on the Total Access 600. From this menu, on a per port basis, the user can determine which ports are active/inactive. Several statistics at this menu are used only for internal ADTRAN development. Task, Inserts, and Drops indicators are for internal use only.

>Clear Stats

The **CLEAR STATS** menu can be used to clear the counters used for Voice Status menus.

Managing the Modules – Modules

Use the **MODULES** menu to view and set the parameters shown in Figure 17. The Total Access 600 contains four fixed modules: The WAN/Network interface, FXS, Echo Cancellor/ADPCM module, and the V.35 interface. The **MODULES** table allows management of the on-board modules in the Total Access 600.

The table contains **MENU**, **ALARM**, **TEST**, and **STATUS** indicators/menus customized for each module.

TA 608 IAD/Modules/Modules						
Modules	Slot	Type	Menu	Alarm	Test	Status
0.35 Setup	0	NET (T1)	[+]	[+]	[+]	[+]
	1	FXS	[+]	[n/a]	[+]	[+]
	2	EC/ADPCM	[+]	-	-	-

MODE: T1 IAD	NET: down
Access module menus	*Z=help 0:51

Figure 17. Modules Menu

>NET (T1)

Menu

Format

Sets the frame format for the T1 interface. The setting must match the frame format of the circuit to which the interface is connected. Choices are **ESF** (extended superframe), **SF** (superframe), or **SLC96**.



SF is equivalent to the D4 frame format.

Line Code

Sets the line code for the T1 interface. The setting must match the line code of the circuit to which the interface is connected. Choices are **B8ZS** (bipolar with 8-zero substitution) or **AMI** (alternate mark inversion).

Equalization

Sets the line build-out for the T1 interface. The setting of this field depends on whether the circuit is provisioned for DS1 by the telephone company. Choices are 0dB, -7.5dB, -15dB, -22dB, 266FT, 399FT, 533FT, and 655 FT.

CSU Lpbk

Enables or disables far-end commanded loopbacks via the FDL channel.

Test

These options are used to initiate local and remote loopback tests and display the test status.

Loc LB

(Local Loopback) Causes loopback on near-end port.

None

No test/stop test.

Line

Metallic loopback

Payload

Payload loopback framing and clocking are regenerated.

Remote LB

(Remote Loopback) Sends a loopback code to a remote CSU.

None

No test/stop test.

Line

Metallic loopback

Payload

Payload loopback framing and clocking are regenerated.

Test Status

Indicates whether a test is underway.

Alarm**Loss of Signal (LOS)**

No signal detected on port interface.

Red Alarm (RED)

Not able to frame data received on the port. Alternately referred to as Out of Frame (OOF).

Yellow Alarm (YELLOW)

Remote alarm indicator (RAI) being received on port.

Blue Alarm (BLUE)

Receiving unframed all ones from the port alarm indicator signal (AIS).

Status

Displays T1 performance data.

Time Frame

In the Time Frame menu, three options are available: **CURRENT** , **15 MIN** and **24 HR**. The performance data for the given window is stored.

CLR

Clears information for the selected port. Press **ENTER** when the cursor is over this field to clear the data.

ES

Errored Seconds. An ES is a second with one or more error events or one or more Out Of Frame events or one or more Controlled Slips.

SES

Severely Errored Seconds. An SES is a second with 320 or more error events or one or more OutOfFrame events.

SEF

Severely Errored Frames.

FS

Frame Sync Errors.

LCV

Line Code Violations.

SLP

Slip Error Events.

UAS

Unavailable Seconds

>FXS

Refer to the Section 4.7, FXS User Interface Guide.

>EC/ADPCM

Refer to the Section 4.7, FXS User Interface Guide.

Managing the Modules – V.35 Setup

Use the **V.35 SETUP** menu to view and set the parameters shown in Figure 18.




Figure 18. V.35 Setup Menu

CHANNEL RATE and **EIA** settings are supported via this menu option. For all typical applications, these settings are left in their default states.

>ATM/FR IWF

This menu contains the setup and status for the ATM/Frame Relay interworking functions.

Mode

The **MODE** setting configures the V.35 port for FRF5 or FRF8 operation, depending upon the application being supported.

FRF5

This is also known as Network Interworking. Use this mode for Frame Relay over ATM.

FRF8

This is also known as Service Interworking. In this mode, the Total Access 600 performs a translation between Frame Relay and ATM protocols.

Configuration

The **CONFIGURATION** menu is used to support the configuration of Frame-to-ATM interworking, signaling formats, timeout values, and PVC settings.

The following settings are used for FRF5.

LAN FR MAINT PROTOCOL	Frame Relay maintenance or signaling protocol between local V.35 port and the attached DTE port, support ANSI Annex A, CCITT Q933 Annex D, CISCO LMI or Static (no signaling).
LAN FR POLL TIMEOUT T392 (5-30)	T392 for signaling protocol, typical value 15. No meaning if Maint Protocol is Static.
FRN PORT CONFIG	Logical Frame Relay ports over ATM. Up to 4 ports are supported with each port supporting up to 4 DLCI mappings. Go to NUM field. Typing "i" or "I" will insert another entry, and typing "d" or "D" will delete one entry.
NAME	To identify your port.
ATM VPI	Specifies the virtual path over which this logical port is running.
ATM VCI	Specifies the virtual circuit over which this logical port is running.
DE MAP	Frame Relay to ATM DE mapping; default value (Frn Only, ATM 0) suggested.
CLPI MAP	ATM to Frame Relay CLPI map; default value (Frn Only) suggested.
D/C	Set D/C field in the header to 0 or 1.
HEADER	Header format; only 2 bytes supported now.
MAINT PROTOCOL	Maintenance or signaling protocol over this logical Frame Relay port. Support Annex A, Annex D, CISCO LMI or Static.
MUX MODE	Many DLCIs or one DLCI mapping over this port.
DLCI MAP	Actual DLCI mappings.
LAN DLCI	The DLCI configured over local V.35 Frame Relay port.
NET DLCI	The DLCI configured over the WAN side logical Frame Relay port.
ACTIVE	Always active, not configurable.

The following settings are used for FRF8.

LAN FR MAINT PROTOCOL	Frame Relay maintenance or signaling protocol between local V.35 port and the attached DTE port, support ANSI Annex A, CCITT Q933 Annex D, CISCO LMI or Static (no signaling).
LAN FR POLL TIMEOUT T392 (5-30)	T392 for signaling protocol, typical value 15. No meaning if Maint Protocol is Static.
FR/ATM PVC MAPPING	Up to 4 mappings are supported.
FR DLCI	Frame Relay DLCI on V.35 port.
ATM VPI	Specifies the virtual path to which DLCI is mapped.
ATM VCI	Specifies the virtual circuit to which DLCI is mapped.
TRANSLATE	Translate or transparent mode between Frame Relay frames and ATM cells.
DE MAP	Map Frame Relay DE bit to ATM CLPI bit, Always 0, Always 1 or Convert each other.
FECN MAP	Map Frame Relay FECN bit to ATM EFCI bit, Always 0, Always 1 or Convert each other.

Appendix A. Voice Gateway Quick Start Procedure (Voice Turn up)

A typical VoATM application (see Figure 19) uses a Total Access 600 connected to an ATM network. For voice applications, a Voice Gateway is needed to interface with the PSTN. Jetstream, Tollbridge, and CopperCom are popular Gateway types.




Figure 19. Application Diagram

To configure a Total Access 600 for use with the Voice Gateway, you need to know the VPI and VCI to be used on the ATM network to access the Gateway from this Total Access 600. You also need to know the format for Idle Cells and whether Data Scrambling is used on this ATM network. The following procedure will help you navigate the Total Access 600 menus for configuring the necessary elements for VoATM with the Voice Gateway.

Voice Turn Up	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. (Here you set up the ATM network.)
2.	Select the ATM CONFIG menu.
3.	Enter the IDLE CELLS format for your network.
4.	Set DATA SCRAMBLING appropriately for your network.
5.	Back all the way out to the top level Total Access 600 menu, and then select the VOICE menu. (From this menu, the appropriate Voice information for working with the Voice Gateway is entered.)
6.	<p>Select CONFIG, and from the CONFIG menu, enter the Gateway type under CALL CONTROL and enter the VPI and VCI values for communicating with that Gateway.</p> <p>CALL CONTROL should be set to the Gateway type and the VPI and VCI values should be set appropriately for your network.</p>
7.	<p>To verify correct setup, use the STATUS menu (under the VOICE menu) to look at the current status of the voice connection.</p> <p>Under STATUS, you can view the GATEWAY STATS and information about the voice PVC along with information about the POTs ports available on the Gateway.</p> <p>The GATEWAY STATS menu should show the Gateway Link is up (if everything is configured correctly).</p> <p>A visual inspection of the VOICE LED on the front panel will also yield the status. Green = up. Red = Down.</p>

Appendix B. RFC1483 Quick Start (IP Routing)

The Total Access 600 allows for complete integration of voice and data delivery from one compact platform (see Figure 20). Once you have completed the voice turn up procedure from the previous example, adding data to the circuit requires some additional setup.




Figure 20. Application Diagram

To configure a Total Access 600 for IP routing, you need to know the VPI and VCI values for the data circuit on your network. You also need the IP address of the next hop router in the circuit.

The table on the next page shows how to configure the Total Access 600 for IP Routing.

IP Routing	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. (Here you set up the ATM network.)
2.	Select the ATM CONFIG menu.
3.	Enter the IDLE CELLS format for your network.
4.	Set DATA SCRAMBLING appropriately for your network.
5.	Back all the way out to the top level Total Access 600 menu, and then select the ROUTER menu.

IP Routing	
6.	Select CONFIGURATION . From the CONFIGURATION menu, you will set up addresses for your LAN and WAN. For basic IP routing, use all the default values from the GLOBAL menu.
7.	From the ETHERNET menu, enter the IP menu to enter your LAN configuration.
8.	Enter your LAN IP ADDRESS , SUBNET MASK , and DEFAULT GATEWAY information. For this example, the IP ADDRESS is 192.168.1.2, the SUBNET MASK is 255.255.255.0, and the DEFAULT GATEWAY is 10.25.4.10.
9.	Arrow back to the main ROUTER CONFIGURATION menu, and select the WAN menu and then the ATM menu. (Here you will enter your data PVC information.)
10.	Create a new PVC by entering the menu. Enter your VPI and VCI values.
11.	From the RFC1483 IP menu, enter your LAN information. For this example, the FAR END IP ADDRESS is 10.25.4.9, the IP NETMASK is 255.255.255.252, and the LOCAL IP ADDRESS is 10.25.4.10.
12.	Arrow back to the top level Total Access 600 menu to activate your changes.

Appendix C. RFC1483 Quick Start (IP Routing with NAT)

To illustrate the use of NAT, consider the example from *Appendix B. RFC1483 Quick Start (IP Routing)* on page 193. To set up a single public address that will be used to access the public network, you will use the **NAT** menu on the **WAN/ATM/RFC1483 IP** menu.

IP Routing with NAT	
Step	Action
1.	From the NAT menu, set NETWORK ADDRESS PORT TRANSLATION to ENABLED . (This will enable translation and allow you to enter the NAT options.)
2.	Set PUBLIC IP ADDRESS MODE to SPECIFIED so you can enter your public address. During transmission, private addresses are translated into this public (NAPT) address.
3.	You will also need to set up the Translation Table to do translation on the body of the packets for certain protocols, such as FTP, to work correctly.
4.	From the TRANSLATION TABLE menu, create a new entry by arrowing into the table.
5.	For PUBLIC ADDRESS MODE , select NAPT ADDRESS to use the previously specified public address.
6.	For PROTOCOL , select TCP .
7.	Make sure that TRANSLATE BODY is set to YES .

Appendix D. RFC1483 Quick Start (Bridging)

The Total Access 600 allows for complete integration of voice and data delivery from one compact platform. Once you have completed the voice turn up procedure from the previous example, adding data to the circuit requires some additional setup.

To configure a Total Access 600 for Bridging, you need to know the VPI and VCI values for the data circuit on your network.

Bridging	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. (Here you set up the ATM network.)
2.	Select the ATM CONFIG menu.
3.	Enter the IDLE CELLS format for your network.
4.	Set DATA SCRAMBLING appropriately for your network.
5.	Back all the way out to the top level Total Access 600 menu, and then select the ROUTER menu.
6.	Enter the CONFIGURATION menu. From this menu, you will set up addresses for your LAN and WAN. For basic IP routing, use all the default values from the GLOBAL menu.
7.	From the ETHERNET menu, enter the IP menu to enter your LAN configuration.
8.	Enter your LAN IP ADDRESS and SUBNET MASK . For this example, the IP ADDRESS is 192.168.1.2 and the SUBNET MASK is 255.255.255.0. This is not required, but will allow Telnet configuration and TFTP upgrades from the LAN.
9.	Arrow back to the main ROUTER CONFIGURATION menu, and select the WAN menu and then the ATM menu. (Here you will enter your data PVC information.)
10.	Create a new PVC by entering the menu. Enter your VPI and VCI values.
11.	Disable IP on the RFC1483 IP menu and enable Bridging on the RFC1483 BRIDGE menu. (This enables the Total Access 600 as a bridge.)
12.	Arrow back to the top level Total Access 600 menu to activate your changes. All packets that come in on the Ethernet will be forwarded on the WAN.

Appendix E. Routing in HDIA Mode

The Total Access 600 allows for complete integration of voice and data delivery from one compact platform. The CopperMountain DSLAM uses Frame Relay instead of ATM as their Layer 2 protocol. Once you have completed the Layer 1 configuration from the previous examples, you must configure the Layer 2 protocol. Refer to Figure 21 on page 198 as you complete the steps below.

Frame Relay Setup	
Step	Action
1.	From the IAD/WAN/FRAME RELAY CONFIG menu, select MAINTENANCE PROTOCOL . Set MAINTENANCE PROTOCOL to STATIC .
2.	From the IAD/WAN/FRAME RELAY CONFIG menu, select DLCI MAPPING .
3.	On the DLCI MAPPING menu, DLCI 528 should be selected. Right arrow to the IP MAP menu.
4.	On the IP MAP menu, set up the following: Set ACTIVE to YES W/BRIDGE ENCAPSULATION . Set ADDRESS MODE to either USER SPECIFIED or DHCP CLIENT . If DHCP CLIENT is selected, the link addresses will be learned through DHCP (skip to Step 5). Set FAR-END IP ADDRESS to the next hop router on the ATM interface connected to the Copper Mountain for this DSL line (10.100.2.145 in Figure 21). Set IP NETMASK appropriately for this interface. Set LOCAL IP ADDRESS to the Copper Mountain IP address for this line (10.100.2.148 in Figure 21).
5.	On the NAT menu, set up the following: Set NETWORK ADDRESS PORTTRANSLATION to ENABLED . Set PUBLIC IP ADDRESS MODE to SPECIFIED . Set PUBLIC IP ADDRESS the same as LOCAL IP ADDRESS above. From the TRANSLATION TABLE , set up the following (create entries so that the appropriate protocols are translated): Right arrow to create an entry. Keep the defaults to enable TCP translation. Press I over the 1 in the first entry to create entry 2. Change the Protocol to ICMP for this entry. Continue creating entries as appropriate for each application.
6.	Arrow back (left arrow) to the IAD/WAN/FRAME RELAY CONFIG/DLCI MAPPING menu.
7.	From the BRIDGE MAP menu, set ACTIVE to NO .

Frame Relay Setup	
8.	Arrow back to the IAD/ROUTER menu. Select CONFIGURATION .
9.	<p>On the GLOBAL menu, set up the following:</p> <p>Select IP.</p> <p>Set MODE to ON.</p> <p>Select DHCP SERVER.</p> <p>Set DHCP MODE to ON.</p> <p>From DOMAIN NAMES, set up the following:</p> <p>Set PRIMARY DNS appropriately (172.22.48.47 in Figure 21).</p> <p>Set SECONDARY DNS appropriately (172.22.48.1 in Figure 21).</p> <p>Select BRIDGE.</p> <p>Set MODE to OFF.</p>
10.	<p>Arrow back to the ETHERNET menu, and set up the following:</p> <p>Select IP.</p> <p>Set IP ADDRESS appropriately for your LAN (10.0.0.1 in Figure 21).</p> <p>Set SUBNET MASK appropriately.</p> <p>Set DEFAULT GATEWAY to the ATM router connected to the Copper Mountain (10.100.2.145 in Figure 21).</p>




Figure 21. Routing with Copper Mountain

SECTION 4.4 ADSL ATM USER INTERFACE GUIDE

The ADSL ATM User Interface Guide is designed for use by network administrators and others who will configure and provision the system. This section provides details unique to the ADSL ATM IADs. It contains an overview, application details, configuration information, and menu descriptions. It is recommended that you review *Section 4.1, Commons User Interface Guide* in addition to this section.

CONTENTS

Total Access 600 Overview	205
Analog Lifeline.	205
Firmware Updates.	205
Voice Over DSL Overview	206
Voice Over ATM Overview	206
Voice Over DSL Application	206
Configuring the Total Access 600	208
System Info.	208
System Name	208
System Location	208
System Contact	208
Unit Name	208
CLEI Code	208
Part Number	208
Serial Number	209
Firmware Revision	209
Bootcode Revision	209
System Uptime	209
Date/Time	209
System Config.	210
Network Timing Mode	210
Network	210
Telnet Access	210
Telnet User List	210
Name.	210
Authen Method	210
Password.	210
Idle Time (1-255)	210
Level	211
Maint Port Menu	211
Password Protect	211
Password.	211
Baud Rate	212
Data Bits	212
Parity	212
Stop Bits	212
Network Time	212
Server Type.	212
NT Time	212

SNTP	212
Active	212
Time Zone	212
Adjust for Daylight Saving	212
Host Address	212
Refresh	212
Status	213
System Utility	213
Upgrade Firmware	213
Transfer Method	213
TFTP Server Address	213
TFTP Server Filename	213
Transfer Status	213
Start Transfer	214
Abort Transfer	214
Config Transfer	214
Transfer Method	214
Transfer Type	214
TFTP Server IP Address	214
TFTP Server Filename	214
Current Transfer Status	215
Previous Transfer Status	215
Load and Use Config	215
Save Config Remotely	215
Ping	215
Start/Stop	215
Host Address	215
Size (40-1500)	215
# of Packets	215
# Transmits	215
# Receives	215
%Loss	216
Configuring WAN Settings	216
DSLAM Type	216
Layer One Interface	216
Layer Two Protocol	216
ATM Config	216
Idle Cells	217
Data Scrambling	217
ATM Stats	217
AP: Tx Cells	218
AP: Rx Cells	218
AP: Rx OAM Cells	218
AP: Receive Cells Discarded	218
AP: Receive Cell Errors	218
AP: Sync	218
AP: Out Of Cell Delineation	218
AAL5: Transmit Frames	218
AAL5: Receive Frames	218
AAL5: Transmit Discarded Frames	218
AAL5: Receive Errors	218

AAL5: Receive Discarded Frames	219
AAL5: No ATM Frames	219
AAL5: No Data Packets	219
Clear Stats	219
Configuring the Router – Configuration	220
Global	220
IP	220
Mode	220
Static Routes	220
DHCP Server	221
Domain Names	221
UDP Relay	222
Mode	222
UDP Relay List	222
Bridge	222
Mode	222
Address Table	222
Security	223
Filter Defines	223
Filter Defines /MAC Filter Defines	223
Filter Defines /Pattern Filter Defines	223
Filter Defines /IP Filter Defines	223
Ethernet	225
IP	225
IP Address	225
Subnet Mask	225
Default Gateway	225
RIP	226
Proxy ARP	226
MAC Address	226
WAN	227
L2 Protocol	227
ATM	227
Description	227
VPI	227
VCI	227
PCR (Peak Cell Rate)	227
QOS (Quality of Service)	227
Protocol	227
RFC1483 IP	228
Active	228
Far - End IP Address	228
IP netmask	228
Local IP Address	228
NAT	228
RIP	229
RFC 1483 Bridge	229
PPPoATM	229
Authentication	229
TX Method	229
TX Username	230

TX Password	230
RX Username	230
RX Password	230
IP	230
Mode	230
Local IP	230
Netmask	230
Remote IP	230
NAT	230
Route	230
RIP	231
PPP	231
VJ Compression	231
Max Config	232
Max Timer	232
Max Failure	232
Encapsulation	232
Filters	232
WAN-TO-LAN (In)	232
In Exceptions	232
LAN-TO-WAN (Out)	233
Out Exceptions	233
Configuring the Router – Status	233
Session	234
ARP cache	234
Bridge Table	234
IP Routes	234
LAN Stats	234
IP Stats	234
Configuring the Router – Logs	234
Sys log Host	235
PPP Log	235
Connection Log	235
Network Log	235
Active	236
Wrap	236
Level	236
View	236
Clear	236
Configuring Voice Support – Config	237
Call Control	237
VPI	237
VCI	237
Configuring Voice Support – Status	238
Gateway Stats	238
PVC Stats	238
POTS Stats	238
Clear Stats	238
Managing the Modules – Modules	239
NET (ADSL)	239
Menu	239

Tx Atten	239
Retrain	239
Status	239
Rx Rate	239
Tx Rate	239
Rx Latency	239
Tx Latency	239
Standard	239
SNR (dB)	240
FXS	240
EC/ADPCM	240
Managing the Modules – V.35 Setup	241
ATM/FR IWF	241
Mode	241
FRF5	241
FRF8	241
Configuration	241
Appendix A. Voice Gateway Quick Start Procedure (Voice Turn up)	244
Voice Turn Up	245
Appendix B. RFC1483 Quick Start (IP Routing)	246
IP Routing	246
Appendix C. RFC1483 Quick Start (IP Routing with NAT)	248
IP Routing with NAT	248
Appendix D. RFC1483 Quick Start (Bridging)	249
Bridging	249

FIGURES

Figure 1. Total Access 600 Rear Panel	205
Figure 2. Voice over DSL	207
Figure 3. System Information Menu	208
Figure 4. System Configuration Menu	210
Figure 5. System Utility Menu	213
Figure 6. WAN Menu	216
Figure 7. ATM Config Menu	217
Figure 8. ATM Stats Menu	218
Figure 9. Router/Configuration Menu	220
Figure 10. Global Menu	220
Figure 11. Ethernet Menu	225
Figure 12. WAN Menu	227
Figure 13. Router/Status Menu	233
Figure 14. Router/Logs Menu	234
Figure 15. Voice/Config Menu	237
Figure 16. Voice/Status Menu	238
Figure 17. Modules Menu	239
Figure 18. V.35 Setup Menu	241
Figure 19. Application Diagram	244

Figure 20. Application Diagram..... 246

5. TOTAL ACCESS 600 OVERVIEW

The Total Access® 600 is a complete solution Integrated Access Device (IAD) for Voice over ATM (VoATM) applications. The unit includes a modular network interface, Nx64 V.35 interface, 10/100BaseT interface, FXS ports, life-line voice backup, and an optional battery back-up for added security. The Total Access 600 can provision, test, and provide status for any of the voice and data interfaces. All connections are made via the rear panel. In addition to a built-in IP router, the Total Access 600 contains an echo canceller and ADPCM compression modules necessary for VoATM applications.

Analog Lifeline

The **LIFE LINE** connector on the rear panel (see Figure 1) provides assured voice for port 1. When a connection to the Voice Gateway is not possible due to loss of power or some other reason, an on-board relay opens and the first port of the voice connector is provided with analog voice from the analog lifeline connection.



For the analog lifeline feature to work, the user must subscribe to an analog voice line and it must be connected via the lifeline connector.




Figure 22. Total Access 600 Rear Panel

Firmware Updates

Firmware can be updated by using XMODEM transfer protocol via the unit's **CRAFT** port (see Figure 1) or by using TFTP from a network server. (See DLP-007 Upgrading the Firmware Using XMODEM and DLP-008 Upgrading the Firmware Using TFTP.)

The terminal menu is the access point to all other operations. Each terminal menu item has several functions and submenus that identify and provide access to specific operations and parameters. These menu selections are described later in this User Interface Guide.



See Section 4.1, Commons User Interface Guide for instructions about using the terminal menus.



See the Engineering Guidelines section for the CRAFT port connection pin-out..

6. VOICE OVER DSL OVERVIEW

Voice over DSL (VoDSL) refers to providing toll quality voice access to the Public Switched Telephone Network (PSTN) over twisted copper pair using DSL. Data can be combined with multiple voice lines over a single medium via DSL, thus yielding many advantages over traditional TDM technologies.

Traditional TDM technologies are limited by statically allocating bandwidth. DSL overcomes this by providing a large bandwidth and utilizing other technologies, such as ATM, to dynamically assign bandwidth as it is needed. Because of this, the user is able to add voice and data connections over a DSL line with flexibility and ease.

7. VOICE OVER ATM OVERVIEW


Voice over ATM is the technology used to transmit voice conversations over a data network using Asynchronous Transfer Mode (ATM). There are several potential benefits to moving voice over a data network using ATM. First, the small, fixed-length cells require lower processing overhead. Second, these small, fixed-length cells allow higher transmission speeds than traditional packet switching methods.

ATM allocates bandwidth on demand, making it suitable for high-speed connection of voice, data, and video services. Conventional networks carry data in a synchronous manner. Because empty slots are circulating even when the link is not needed, network capacity is wasted. ATM automatically adjusts the network capacity to meet the system needs.

8. VOICE OVER DSL APPLICATION

The Total Access 600 connects to a DSLAM via DSL and ATM. The Total Access 600 has a built in echo canceller that provides G.165 echo cancellation. The module can automatically detect ADPCM and enable it as needed.

Figure 23 shows a typical VoDSL application. The Total Access 600 connects to the ATM network, via a DSLAM, to provide both voice and high speed data from a single platform.

**Figure 23. Voice over DSL**

9. CONFIGURING THE TOTAL ACCESS 600

System Info

The **SYSTEM INFO** menu provides basic information about the unit and contains data fields for editing information. Figure 24 displays the submenus available when you select this menu item.




Figure 24. System Information Menu

>System Name

Provides a user-configurable text string for the name of the Total Access 600. This name can help you distinguish between different installations. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar). This name will appear on the top line of all screens.

>System Location

Provides a user-configurable text string for the location of the Total Access 600. This field is to help you keep track of the actual physical location of the unit. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar).

>System Contact

Provides a user-configurable text string for a contact name. You can use this field to enter the name, phone number, or E-mail address of a person responsible for the Total Access 600 system. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar).

>Unit Name

Product-specific name for the product assembly.

>CLEI Code

CLEI code for the product assembly.

>Part Number

ADTRAN part number for the product assembly.

>Serial Number

Serial number of the product assembly.

>Firmware Revision

Displays the current firmware revision level of the controller.

>Bootcode Revision

Displays the bootcode revision.

>System Uptime

Displays the length of time since the Total Access 600 system reboot.

>Date/Time

Displays the current date and time, including seconds. This field can be edited. Enter the time in 24-hour format (such as 23:00:00 for 11:00 pm). Enter the date in mm-dd-yyyy format (for example, 10-30-2001).

**NOTE**

Each time you reset the system, this value resets to 0 days, 0 hours, 0 min and 0 secs.

System Config

Set up the Total Access 600 operational configuration from the **SYSTEM CONFIG** menu. Figure 25 shows the items included in this menu.




Figure 25. System Configuration Menu

>Network Timing Mode

Selects the timing source for the entire system. Network is the only timing option available.

Network

The system's clock is recovered from the network (WAN interface).

>Telnet Access

Sets Telnet access to **ON** or **OFF**.

>Telnet User List

Up to four users can be configured for access to the Total Access 600. Each user can be assigned a security level and time out.

Name

A text string of the user name for this session.

Authen Method

The user can be authenticated in two ways:

- | | |
|-----------------|--|
| PASSWORD | The Password field is used to authenticate the user. |
| RADIUS | The Radius client is used for authenticating the user. |

Password

When the authenticating method is **PASSWORD**, this text string is used for the password.

Idle Time (1-255)

This sets the amount of time you can be idle before you are automatically logged off.

Level

This is the security level granted to the user.

>Maint Port Menu

The Total Access 600's VT 100 **CRAFT** port can be accessed via an RJ-48 located on the rear panel. The setup for these ports is under this menu.

Password Protect

When set to **No**, the maintenance port is not password protected. When **Yes** (def), the Total Access 600 will prompt for a password upon startup.

Password

This is the text string that is used for comparison when password protecting the maintenance port. By default, no password is entered.




If you forget your password, type CHALLENGE in all capital letters. Call technical support and have the displayed CHALLENGE code ready.



The security level for the maintenance port is always set to 0. This gives full access to all menus.



Passwords are case-sensitive.

Instructions for Changing Passwords	
Step	Action
1.	Select the PASSWORD field—a new PASSWORD field displays.
2.	Type the new password in the ENTER field.
3.	Type the new password again in the CONFIRM field.
	<i>The password can contain up to 12 alphanumeric characters. You can also use spaces and special characters in the password.</i>

Baud Rate

This is the asynchronous rate that the maintenance port will run. The possible values are 300, 1200, 2400, 4800, 9600 (def), 19200, 38400, 57600, and 115200.

Data Bits

This is the asynchronous bit rate that the maintenance port will run. The possible values are 7 or 8 (def) bits.

Parity

This is the asynchronous parity that the maintenance port will run. The possible values are **NONE** (def), **Odd**, or **EVEN**.

Stop Bits

This is the stop bit used for the maintenance port. The possible values are 1 (def), 1.5 or 2.

>Network Time

The Total Access 600 unit time can be entered manually from the **SYSTEM INFO** menu, or the unit can receive time from an NTP/SNTP server. The **NETWORK TIME** menu includes all parameters relating to how the unit communicates with the time server.

Server Type

The server type defines which port the Total Access 600 will listen on to receive timing information from the time server.

NT Time

The Total Access 600 will receive time from an NT server running SNTP software on its TIME port.

SNTP

The Total Access 600 will receive time directly from an SNTP server.

Active

This network timing feature can be turned on and off. It determines whether the unit will request and receive time from a time server.

Time Zone

There are several time zones available for the time to be displayed in. All time zones are based off of Greenwich Mean Time (GMT).

Adjust for Daylight Saving

Since some areas of the world use Daylight Savings Time, the Total Access 600 is designed to adjust the time on the first Sunday in April and the last Sunday in October accordingly if this option is turned on.

Host Address

This is the IP address of the time server that the Total Access 600 will request and receive time from.

Refresh

This is the interval of time between each request the Total Access 600 sends out to the time server. A smaller refresh time guarantees that the unit receives the correct time from the server and corrects possible errors more quickly, but it is more taxing on the machine. A range of refresh times is available (user configurable).

Status

This displays the current status of the time negotiation process. If an error is displayed, check all connections and configurations to try to resolve the problem.

System Utility

Use the **SYSTEM UTILITY** menu to view and set the system parameters shown in Figure 26.




Figure 26. System Utility Menu

>Upgrade Firmware

Updates firmware when Total Access 600 enhancements are released. Two transfer methods are available for use in updating the Total Access 600 system controller.

Transfer Method

The two methods for upgrading are **XMODEM** and **TFTP**. (See DLP-007, *Upgrading the Firmware Using XMODEM* and DLP-008, *Upgrading the Firmware Using TFTP*.) **TFTP** requires a TFTP server running somewhere on the network. The Total Access 600 starts a TFTP client function which gets the upgrade code from the TFTP server. Selecting **XMODEM** will load the upgrade code through the **CRAFT** port using any PC terminal emulator with xmodem capability.

TFTP Server Address

This is required when the transfer method is TFTP. It is the IP address or domain name (if DNS is configured) of the TFTP server.

TFTP Server Filename

This is required when the transfer method is TFTP. It is the case-sensitive file name which contains the upgrade code.

Transfer Status

This appears when TFTP is used. It displays the status of the transfer as it happens. Any error or success message will be displayed here.

Start Transfer

This activator is used when the configurable items in this menu are complete.



*Before using **START TRANSFER**, the Total Access 600 should have a valid IP address, subnet mask, and default gateway (if required).*

Abort Transfer

Use this activator to cancel any TFTP transfer in progress.

>Config Transfer

Sends a file containing the Total Access 600 configuration to a PC connected to the **CRAFT** port using XMODEM protocol or to a file on a TFTP server using the TFTP protocol. See DLP-007, *Upgrading the Firmware Using XMODEM* and DLP-008, *Upgrading the Firmware Using TFTP* for details.

CONFIG TRANSFER also lets you save the Total Access 600 configuration as a backup file, so you can use the same configuration with multiple Total Access 600 units. In addition, **CONFIG TRANSFER** can retrieve a configuration file from a TFTP server.

To support these transfers, ADTRAN delivers a TFTP program with the Total Access 600 called *TFTP Server*. You can configure any PC running Microsoft Windows with this software, and store a configuration file.



*Before using **CONFIG TRANSFER**, the Total Access 600 should have a valid IP address, subnet mask, and default gateway (if required).*

Only one configuration transfer session (upload or download) can be active at a time.

Transfer Method

Displays the method used to transfer the configuration file to or from a server. XMODEM and TFTP are supported.

Transfer Type

Only **BINARY** transfers are currently supported.

TFTP Server IP Address

Specifies the IP address of the TFTP server. Get this number from your system administrator.

TFTP Server Filename

Defines the name of the configuration file that you transfer to or retrieve from the TFTP server. The default name is **ta600.cfg**, but you can edit this name.

Current Transfer Status

Indicates the current status of the update.

Previous Transfer Status

Indicates the status of the previous update.

Load and Use Config

Retrieves the configuration file specified in the **TFTP SERVER FILENAME** field from the server. To start this command, enter **Y** to begin or enter **N** to cancel.



If you execute this command, the Total Access 600 retrieves the configuration file, reboots, then restarts using the new configuration.

Save Config Remotely

Saves the configuration file specified in **TFTP SERVER FILENAME** to the server identified in **TFTP SERVER IP ADDRESS**. To start this command, enter **Y** to begin or enter **N** to cancel.



*Before using this command, you must have identified a valid TFTP server in **TFTP SERVER IP ADDRESS**.*

>Ping

Allows you to send pings (ICMP requests) to hosts. The following items are under this menu:



Only one ping session can be active at a time.

Start/Stop

Activator to start and cancel a ping test.

Host Address

IP address or domain name (if DNS is configured) of device to receive the ping.

Size (40-1500)

Total size of the ping to send. Range is 40 to 1500 bytes. 64 is default.

of Packets

Total packets to send every 2 seconds. Setting this to **0** allows the client to ping continuously.

Transmits

Total packets sent (read only).

Receives

Total packets received (read only).

%Loss

Percentage loss based on ping returned from host (read only).

Configuring WAN Settings**>DSLAM Type**

Set this to the type of DSLAM the Total Access 600 will be connecting to.

>Layer One Interface

This is the physical layer protocol used to connect the DSLAM to the Total Access 600.

>Layer Two Protocol

This is the data link layer protocol used to connect the DSLAM to the Total Access 600.

>ATM Config

Use the **WAN** menu (Figure 27) to access the **ATM CONFIG** menu.




Figure 27. WAN Menu

Use the **ATM CONFIG** menu (Figure 28) to set the parameters listed below the figure.



Figure 28. ATM Config Menu

Idle Cells

The **IDLE CELLS** format must be configured for either **ATM FORUM** or **ITU**. Configuring this setting incorrectly for a particular circuit will cause poor performance at the ATM layer.



This setting must match the configuration setting of the ATM switch or DSLAM at the other end of the circuit.

Data Scrambling

DATA SCRAMBLING can be **ENABLED** or **DISABLED** for cell traffic. Configuring this setting incorrectly for a particular circuit will cause poor performance.



This setting must match the configuration setting of the ATM switch or DSLAM at the other end of the circuit.

>ATM Stats

Use the **WAN** menu (Figure 27 on page 216) to access the **ATM STATS** menu (Figure 29 on page 218) and view the parameters listed below the figure.

TA 600 TAB/MAN/ATM Stats		
ATM Config	AP: TxCells	0
ATM Stats	AP: RxCells	0
	AP: RxOAMCells	0
	AP: ReceiveCellsDiscarded	0
	AP: ReceiveCellErrors	0
	AP: Sync	Inactive
	AP: OutOfCellDelineation	0
	AAL5: TransmitFrames	0
	AAL5: ReceiveFrames	0
	AAL5: TransmitDiscardedFrames	0
	AAL5: ReceiveErrors	0
	AAL5: ReceiveDiscardedFrames	0
	AAL5: NoAtmFrames	0
	AAL5: NoDataPackets	0
	Clear Stats	<+>
MODE: ADSL TAB		
NE1: down		
*Z=help 0:02		

Figure 29. ATM Stats Menu

AP: Tx Cells

This is the number of cells transmitted.

AP: Rx Cells

This is the number of cells received.

AP: Rx OAM Cells

This is the number of OAM cells received

AP: Receive Cells Discarded

This is the number of cells received and discarded. An incrementing count in this field could indicate a configuration problem with the ATM layer.

AP: Receive Cell Errors

This is the number of cells received with an HEC error.

AP: Sync

This indicates cell delineation at the ATM layer.

AP: Out Of Cell Delineation

This indicates loss of cell delineation at the ATM layer.

AAL5: Transmit Frames

This is the number of AAL5 frames transmitted.

AAL5: Receive Frames

This is the number of AAL5 frames received.

AAL5: Transmit Discarded Frames

This is the number of AAL5 frames discarded.

AAL5: Receive Errors

This is the number of AAL5 errors received.

AAL5: Receive Discarded Frames

This is the number of AAL5 frames discarded.

AAL5: No ATM Frames

This is for internal use only.

AAL5: No Data Packets

This is for internal use only.

Clear Stats

This is used to clear the counters on this menu screen.

Configuring the Router – Configuration

Use the **ROUTER/CONFIGURATION** menu (Figure 30) to access the **GLOBAL**, **ETHERNET**, and **WAN** menus.




Figure 30. Router/Configuration Menu

>Global

Use the **GLOBAL** menu (Figure 31) to set up general router functions.




Figure 31. Global Menu

IP

This is used for general IP configuration.

Mode

This item controls how the Total Access 600 handles IP routes. When this option is set to **ON** (def), the Total Access 600 will advertise and listen to routes from other IP routers. If **OFF**, the route table is still used, but only static routes are used for routing IP packets and only the Ethernet port is used. IP packets can be sent over the WAN, but only when bridged.

Static Routes

Use this menu to enter static routes to other networks.

ACTIVE	Adds this static route entry to the IP routing table when set to YES and removes it (if it was previously added) if set to No (def).
IP ADDRESS	The IP address of the host or network address of the device being routed to.
SUBNET MASK	Determines the bits in the previous IP address that are used. <i>If this is to be a host route, it must be set to all ones (255.255.255.255).</i>
GATEWAY	The IP address of the router to receive the forwarded IP packet.
HOPS	The number of router hops required to get to the network or host. Maximum distance is 15 hops.
PRIVATE	When set to No , the Total Access 600 will advertise this static route using RIP. Setting to YES means that the route is kept private.

DHCP Server

DHCP MODE	When set to ON , the Total Access 600 acts as a DHCP server and will dynamically assign IP, network mask, default gateway, and DNS addresses to any device which transmits a broadcast DHCP request. The addresses assigned are based on the Total Access 600's own IP address and will be within the same network.
DHCP RENEWAL TIME	The number of hours that the DHCP server should allow the device before it is required to send a new DHCP request. The default is 15 hours, and 0 represents an infinite lease.

Domain Names

Enter the Total Access 600's domain name and the primary and secondary DNS servers in this menu.

DOMAIN NAME	Text string used to represent the domain name used by the Total Access 600.
PRIMARY DNS	First server to which domain name requests are sent.
SECONDARY DNS	Server used as a backup, in case the primary address does not respond to the request.
PRIMARY NBNS/WINS	Server to which NT domain name requests are sent.
SECONDARY NBNS/WINS	Server used when there is no response from the primary server.

UDP Relay

This menu configures the Total Access 600 to act as a UDP relay agent for applications requiring a response from UDP hosts that are not on the same network segment as their clients.

Mode

When this option is set to **ON**, the Total Access 600 will act as a relay agent.

UDP Relay List

Up to four relay destination servers can be specified in this list.

RELAY ADDRESS	This is the IP address of the server that will receive the relay packet.
UDP PORT TYPE	
STANDARD (def)	The following standard UDP protocols are relayed when set: DHCP, TFTP, DNS, NTP (Network Time Protocol, port 123, NBNS (NetBios Name Server, port 137), NBDG (NetBIOS Datagram, port 138), and BootP.
SPECIFIED	When set, the UDP port (1 to 65535) can be specified in the UDP Port columns (up to three per server).
UDP PORT 1, 2, 3	Used for specifying UDP ports to be relayed. These fields only apply when UDP PORT TYPE is set to SPECIFIED .

Bridge

The **BRIDGE** menu is used to set up the bridge parameters for the Total Access 600. The bridging function runs at the Media Access Control (MAC) level which allows any protocol packets that run over Ethernet to be forwarded. Bridging can run concurrently with IP. However, when IP routing is active, IP packets (which include ARP packets) are not bridged.

Mode

This is used to enable the bridge function.

Address Table

The Total Access 600 automatically maintains a table of MAC addresses detected and associates those addresses with the LAN or WAN port from which they were received.

AGING	The maximum time an idle MAC address remains in the table before being removed. The value is in minutes.
FORWARD POLICY	When this parameter is set to UNKNOWN (def), any bridge packet with a destination MAC address that is not in the bridge table is forwarded to all other ports. When set to KNOWN , the packet with the unknown destination MAC address is dropped and is not forwarded.

Security

Filter Defines

The Total Access 600 can filter packets based on certain parameters within the packet. The method used by the Total Access 600 allows the highest flexibility for defining filters and assigning them to a PVC. The filters are set up in two steps: (1) defining the packet types, and (2) adding them to a list under the PVC. This menu is used to define the individual filter defines based on packet type.

Filter Defines /MAC Filter Defines

The MAC filter is applied to bridge packets only. Bridge packets which are forwarded by the bridge functionality of the Total Access 600 are defined here. Up to 32 MAC defines can be specified.

NAME	Identifies the filter entry.
SRC ADDR	48-bit MAC source address used for comparison. (hexadecimal format)
SRC MASK	Bits in the MAC source address which are compared. (hexadecimal format)
DEST ADDR	48-bit MAC destination address used for comparison. (hexadecimal format)
DEST MASK	Bits in the MAC destination address used for comparison. (hexadecimal format)
MAC TYPE	16-bit MAC type field used for comparison. (hexadecimal format)
TYPE MSK	Bits in the MAC type field used for comparison. (hexadecimal format)

Filter Defines /Pattern Filter Defines

The pattern filter is applied to bridge packets only. That is any packet which is forwarded by the bridge functionality of the Total Access 600. Up to 32 pattern defines can be specified.

NAME	Identifies the filter entry.
OFFSET	Offset from beginning of packet of where to start the pattern comparison.
PATTERN	64 bits used for comparison. (hexadecimal format)
MASK	Bits in the pattern to be compared. (hexadecimal format)

Filter Defines /IP Filter Defines

The IP filter defines apply to any IP packet, whether it is routed or bridged. Up to 32 IP defines can be specified.

NAME	Identifies the filter entry.
IP SRC	IP address compared to the source address. (dotted decimal format)

SRC MASK	Bits which are used in the source comparison. (dotted decimal format)
IP DEST	IP address compared to the destination address. (dotted decimal format)
DEST MASK	Bits which are used in the destination comparison. (dotted decimal format)
SRC PORT	IP source port number used for comparison Range: 0 to 65535. (decimal format)
SRC PORT CMPR	Type of comparison that is performed. = means ports equal to not = means port not equal to > means port greater than < means port less than None - means the source port is not compared
DST PORT	IP destination port number used for comparison Range: 0 to 65535. (decimal format)
DST PORT CMPR	Type of comparison that is performed = means ports equal to not = means port not equal to > means port greater than < means port less than None - means the destination port is not compared
PROTO	Protocol used for comparison. Range: 0 to 255. (decimal format)
PROTO CMPR	Type of comparison that is performed = means protocols equal to not = means protocols not equal to > means protocols greater than < means protocols less than None means the protocol is not compared
TCP EST	Yes - only when TCP established

No - only when TCP not established

Ignore - ignore TCP flags

>Ethernet

Use the **ETHERNET** menu (Figure 32) to configure the Ethernet port on the Total Access 600.



Figure 32. Ethernet Menu

IP

This is used to set up the IP addresses for the LAN on the Total Access 600.

IP Address

The IP address assigned to the Total Access 600's Ethernet port is set here. This address must be unique within the network.

Subnet Mask

This is the IP network mask that is to be applied to the Total Access 600's Ethernet port.

Default Gateway

The default gateway is used by the Total Access 600 to send IP packets whose destination address is not found in the route table.

RIP

Use this menu to enable RIP on the LAN interface.

MODE	Enables or disables RIP.
PROTOCOL	Specifies the RIP protocol. Choices are V1 (def) (which is RIP version 1) or V2 (RIP version 2).
METHOD	Specifies the way the RIP protocol sends out its advertisements. Choices are given below.
NONE	All routes in the router table are advertised with no modification of the metrics.
SPLIT HORIZON	Only routes not learned from this circuit are advertised.
POISON REVERSE (def)	All routes are advertised, but the routes learned from this port are "poisoned" with an infinite metric.
DIRECTION	Allows the direction at which RIP advertisements are sent and listened to be specified.
TX AND RX (def)	RIP advertisements are periodically transmitted and are listened to on this port.
TX ONLY	RIP advertisements are periodically transmitted but are not listened to on this port.
RX ONLY	RIP advertisements are not transmitted on this port, but are listened.
V2 SECRET	Enter the secret used by RIP version 2 here.

Proxy ARP

This feature allows the network portion of a group of addresses to be shared among several physical network segments. The ARP protocol provides a way for devices to create a mapping between physical addresses and logical IP addresses. Proxy ARP makes use of this mapping feature by instructing a router to answer ARP requests as a "proxy" for the IP addresses behind one of its ports. The device which sent the ARP request will then correctly assume that it can reach the requested IP address by sending packets to the physical address that was returned. This technique effectively hides the fact that a network has been (further) subnetted. If this option is set to **YES**, when an ARP request is received on the Ethernet port the address is looked up in the IP routing table. If the forwarding port is not on the Ethernet port and the route is not the default route, the Total Access 600 will answer the request with its own hardware address.

MAC Address

This is a read-only MAC address programmed at ADTRAN.

>WAN

Use the **WAN** menu (Figure 33) to configure WAN settings on the Total Access 600.




Figure 33. WAN Menu

L2 Protocol

Displays the current L2 protocol - ATM (Read Only).

ATM

Use the ATM menu to setup Data PVCs for the router.

Description

This is the text description for the PVC.

VPI

ATM virtual port identifier.

VCI

This is the ATM virtual channel identifier.

PCR (Peak Cell Rate)

Limits transmitted cells.

QOS (Quality of Service)

Indicates this PVC's traffic class.

Protocol

This is the protocol supported on the PVC.

RFC1483 IP

Use this selection to support IP on this PVC. (These settings only take effect when RFC 1483 is the selected protocol.)

Active

This selection enables IP on this PVC.

Far - End IP Address

This is the address of the NEXT hop router on this interface.

IP netmask

This is the network mask used for this interface.

Local IP Address

This is the IP address for this PVC.

NAT

Use this menu to set up and use Network Address Translation on this interface.

NETWORK ADDRESS PORT TRANSLATION	By enabling port translation, IP packets are modified as they pass through this interface. During transmission, private addresses are translated into a single public (NAPT) IP address. Incoming packets are translated from the public to private address based on the protocol port numbers. Once enabled, you must set up NAT for use.
PUBLIC IP ADDRESS MODE	The port translation requires at least a single real IP address for translating. This value can use the IP assigned to the interface (or assigned via layer 2 protocol like PPP), obtained using DHCP client, or statically specified on this menu. If the address cannot be learned, then it must be specified in order for the translation to work.
TRANSLATION TABLE	Add translation entries to "fine tune" special protocols or specify private addresses.
PUBLIC ADDRESS MODE	The public IP address used for this translation entry can be the NAPT IP address assigned to the link or can be specified. You specify an address to direct packets with certain protocols to different servers.
PROTOCOL	The upper layer protocol that is to be monitored for translation. For TCP and UDP, a port number must also be specified.
PUBLIC PORT MODE	The public destination port associated with this entry can be specified to add more control over certain types of traffic. The default, ANY PORT , covers all port types.

PRIVATE ADDRESS MODE	The private IP address can be specified to steer certain protocols and ports to specific servers in the private network. Likewise, internal hosts can be steered to certain servers on the public network. A new request from the public network matching this entry's public parameters will be dropped if this mode is set to ANY INTERNAL .
PRIVATE PORT MODE	The private destination port associated with this entry can be specified to add more control over certain types of traffic. Leave as ANY PORT to cover all port types.
TRANSLATE BODY	By default, the application payload in the packet is scanned for occurrences of the private/public IP address in binary or ASCII form. Set this to No for applications where this will cause problems.
NAT VIEW	Shows the protocols that are actively being translated.
NAPT ADDRESS	Represents the public address that is being used as the NAPT address.
ENTRY COUNT	The number of entries in the NAT table.
ENTRY OVERFLOW COUNT	A count of the dropped entries due to low memory.

RIP

Use this menu to enable RIP on the WAN interface. (See *RIP* on page 226 for description of options.)

RFC 1483 Bridge

This is used to enable bridge mode on this PVC.

PPPoATM

The Total Access 600 uses the PPPoATM profile to specify the profile used when connected using PPP.

Authentication

The authentication menu contains the required parameters for the authentication of the PPP peer and for being authenticated by the PPP peer. Authentication is applied between the Total Access 600 and the PPP peer as follows:

TX Method

This parameter specifies how the Total Access 600 is to be authenticated by the PPP peer. There are four possible selections.

NONE (def)	The connection will not allow the PPP peer to authenticate it.
PAP, CHAP, OR EAP	The connection can be authenticated using PAP, CHAP or EAP.
CHAP OR EAP	The connection can be authenticated using CHAP or EAP only.
EAP	The connection will only allow authentication by the peer using EAP.

TX Username

This is the username that is used when being authenticated by the PPP peer.

TX Password

This is the password or secret that is used when being authenticated by the PPP peer.

RX Username

This is the username used to authenticate the PPP peer.

RX Password

This is the password or secret that is used to authenticate the PPP peer.

IP

The IP menu contains the parameters for exchanging IP data with the PPP peer.

Mode

Setting to **ON** (def) will permit this connection profile to negotiate PPP IPCP with the PPP peer for exchanging of IP packets.

Local IP

This is the IP address that is assigned to the PPP link when using numbered links. Leaving this as 0.0.0.0 means the Total Access 600 will determine its IP address using PPP IPCP. If the far end router does not assign an IP address, the PPP link is left unnumbered.

Netmask

This network mask is applied to the IP/Local IP address for determining the PPP peer's network. If left as 0.0.0.0, a standard network mask is used.

Remote IP

The PPP peer's IP address or network can be set here, if known. Leaving this at 0.0.0.0 means that the Total Access 600 will determine the PPP peer's IP and network using the PPP IPCP.

NAT

The Total Access 600 can perform Network Address Translation. This feature is most widely used when connecting to the Internet. The Ethernet network can consist of private network numbers. When this profile is connected, all IP addresses on the Ethernet side are translated into the one real IP address negotiated with the PPP peer (ISP). Multiple stations on the Ethernet side can access the Internet simultaneously. Setting this option to **ON** will cause the Total Access 600 to perform NAT. In the **OFF** (def) position, the unit will route across the connection normally.

Route

The IP parameters are configured in this menu. Usually the Total Access 600 will automatically discover the PPP peer's networks using PPP IPCP and/or RIP.

- **Route/Static Route**

Selecting yes will add a static route to the remote peer to the route table.

- **Route/Private**

Selecting yes will prevent this route from being advertised.

- **Route/Hops (1-16)**

This value is the metric or number of hops that RIP will use in advertising the static route. The range is 1 to 16, where 1 is the default. The value 16 is considered an infinite distance (poisoned route).

- **Route/Force IP**

When set to **YES**, the Total Access 600 will force the PPP peer to use the IP address in the **LOCAL IP** for this profile as its WAN IP address. Normally this is set in the **No** (def) position.

RIP

The RIP parameters can be adjusted from their defaults under this menu.

- **Mode**

The Total Access 600 performs RIP over the WAN connection when this is set to **ON** (def).

- **Protocol**

The Total Access 600 performs version 1, **V1** (def), or version 2, **V2**, of RIP on this WAN connection.

- **Method**

SPLIT HORIZON	Only routes not learned on the WAN connection are advertised.
POISON REVERSE (def)	All routes are advertised, including routes learned from the WAN connection. These routes are poisoned.
NONE	All routes are advertised, including routes learned from the WAN connection. No attempt is made to poison these routes.

- **Direction**

TX AND RX (def)	RIP advertisements are transmitted and listened to on the WAN connection.
TX ONLY	RIP advertisements are transmitted and not listened to.
RX ONLY	RIP advertisements are listened to but not transmitted.

- **Triggered**

When set to **YES**, only IP RIP updates are sent when the routing table has changed and learned routes are not "aged." When set to **No** (def), updates are sent periodically.

- **Retain**

When this Connection List entry is disconnected and this parameter is set to **YES**, all routes learned from this WAN connection are retained and their routing interface is set to idle.

PPP

The Total Access 600 supports the IETF standards for the Point-to-Point Protocol. The PPP state machine running in the Total Access 600 can be fine-tuned to support many applications that can be employed. The configurable items under this menu can be changed from their default values for special cases.

VJ Compression

When this item is set to **ON**, the Total Access 600 will perform TCP/IP header compression known as Van Jacobson compression to the PPP peer.

Max Config

This value is the number of unanswered configuration requests that should be transmitted before giving up on a call. The possible values are 5, 10 (def), 15 and 20.

Max Timer

This value is the number of seconds to wait between unanswered configuration requests. The possible values are 1 sec, 2 secs (def), 3 secs, 5 secs and 10 secs.

Max Failure

Due to the nature of PPP, configuration options may not be agreed upon between two PPP peers. This value is the number of configuration-naks that should occur before an option is configuration-rejected. This allows a connection to succeed that might otherwise fail. The possible values are 5 (def), 10, 15 and 20.

Encapsulation

This is the PPP encapsulation. (LLC or VC-Mux)

Filters

The Total Access 600 can block packets in and out of a WAN port by use of the filters. They are set up in two steps: 1) define the types of packets that would be of interest in the **CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES** menu, and 2) set up the filter type and combination of defines that will cause a packet block.

WAN-TO-LAN (In)

The packets which come into the Total Access 600 can be filtered in three ways:

DISABLED (def)	Turns off packet input filtering. No incoming packets are blocked.
BLOCK ALL	All incoming packets from the WAN are blocked except as defined in the FILTERS/IN EXCEPTIONS list.
FORWARD ALL	All incoming packets from the WAN are not blocked except as defined in the FILTERS/IN EXCEPTIONS list.

In Exceptions

This is a list of up to 32 filter entries which can be combined using the operations field. The operations are performed in the order they appear on the list.

ACTIVE	Turns this entry active when set to ON .
TYPE	Selects the filter define list to reference:
MAC	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/MAC FILTER DEFINES list.
PATTERN	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/PATTERN FILTER DEFINES list.
IP	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/IP FILTER DEFINES list.

IPX	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/IPX FILTER DEFINES list.
FILTER LIST NAME	Selects between filters defined in the list.
NEXT OPER	The next operation to use to combine with the next filter in the list:
END	the last filter to combination.
AND	logically AND this filter with the next filter in the list.
OR	logically OR this filter with the next filter in the list.

LAN-TO-WAN (Out)

The packets which come out toward the WAN from the TA600 can be filtered in three ways:

DISABLED (def)	Turns off packet input filtering. No outgoing packets are blocked.
BLOCK ALL	All outgoing packets to the WAN are blocked except as defined in the FILTERS/OUT EXCEPTIONS list.
FORWARD ALL	All outgoing packets to the WAN are not blocked except as defined in the FILTERS/OUT EXCEPTIONS list.

Out Exceptions

This is a list of up to 32 filter entries. The setup is exactly the same as the **FILTERS/IN EXCEPTIONS** list.

Configuring the Router – Status

Use the **ROUTER/STATUS** menu to view and set the parameters shown in Figure 34. The **ROUTER/STATUS** screens give the user useful information for debugging the current routes in the Total Access 600.



Figure 34. Router/Status Menu

>Session

This menu maintains statistics about the active ATM PVCs.

>ARP cache

This is a listing of the currently connected Ethernet port on the LAN.

>Bridge Table

This shows the detected MAC addresses and the interface to which they are associated.

>IP Routes

This shows the current routes in the Total Access 600 and their use.

>LAN Stats

This shows traffic over the LAN interface.

>IP Stats

This shows IP traffic through the Total Access 600.

Configuring the Router – Logs

The Logs menu (Figure 35) contains logs displaying important information about the running condition of the Total Access 600. The logs can be set to capture diagnostics of error conditions only by way of a log level. The levels are divided up as follows:

- level 0 - Fatal event (causes reset)
- level 1 - Critical event
- level 2 - Error event
- level 3 - Warning event
- level 4 - Notify event
- level 5 - Informational event
- level 6 - Debugging event




Figure 35. Router/Logs Menu

Sys log Host

Set this to the IP address or domain name (if DNS configured) of the sys log host device. All log events are sent to this device.

PPP Log

Information pertaining to the PPP negotiation and authentication is logged in the PPP log.

Connection Log

Information pertaining to the call placement and answering is logged in the Connection log.

Network Log

Information pertaining to routing protocols is placed in this log.

Each log (PPP log, Connection log, and Network log) contains the following elements.

Active

When set to **YES** (def), PPP events below or equal the log level are logged into the log.

Wrap

When set to **YES** (def), new PPP events will overwrite old PPP events when the log is full. All logging will stop when the log is full and set to **No**.

Level

In order to log events, they must be at or below this level. Range is 0 to 6. The default is 3.

View

This menu displays the log list. The fields are as follows:


DATE/TIME	Date and time event occurred.
LEVEL	Level associated with this event (0-6).
MESSAGE	Text message for this event. If message is too long to fit on the line, another event appears below it continuing the message.

Clear

This clears the log when activated.

Configuring Voice Support – Config

Use the **VOICE/CONFIG** menu to view and set the parameters shown in Figure 36.



TA 608 TA07/Voice/Config		
Config	Call Control	None
Status	VPI	0
	VCI	39

MODE: ADSL TA0	NE1: down
	^Z=help U:10

Figure 36. Voice/Config Menu

>Call Control

The **CALL CONTROL** setting is used to configure the correct Voice Gateway protocol for voice signaling control between the Total Access 600 and the configured Gateway. The **CALL CONTROL** setting must be configured correctly before the voice circuits will work correctly. The Total Access 600 supports Jetstream, Tollbridge, and CopperCom Voice Gateways.

>VPI

The **VPI** setting is used to configure the Total Access 600 virtual path setting used to communicate with the configured Voice Gateway.

>VCI

The **VCI** setting is used to configure the Total Access 600 virtual circuit setting used to communicate with the configured Voice Gateway.

Configuring Voice Support – Status

Use the **VOICE/STATUS** menu to view and set the parameters shown in Figure 37.




Figure 37. Voice/Status Menu

>Gateway Stats

The **GATEWAY STATS** menu shows the current state of the communication link between the Total Access 600 and the Voice Gateway. The Gateway Link is indicated as **UP** or **DOWN**. A count of management messages is indicated along with the number of active calls in progress.

>PVC Stats

The **PVC STATS** menu shows the current state of the virtual circuit used between the Voice Gateway and the Total Access 600 IAD for voice signaling and voice payload delivery.

>POTS Stats

The **POTS STATS** menu shows real-time indication status of each voice port on the Total Access 600. From this menu, on a per port basis, the user can determine which ports are active/inactive. Several statistics at this menu are used only for internal ADTRAN development. Task, Inserts, and Drops indicators are for internal use only.

>Clear Stats

The **CLEAR STATS** menu can be used to clear the counters used for Voice Status menus.

Managing the Modules – Modules

Use the **MODULES** menu to view and set the parameters shown in Figure 38. The Total Access 600 contains four fixed modules: The WAN/Network interface, FXS, Echo Cancellor/ADPCM module, and the V.35 interface. The **MODULES** table allows management of the on-board modules in the Total Access 600.

The table contains **MENU**, **ALARM**, **TEST**, and **STATUS** indicators/menus customized for each module.

TA 608 IAD/Modules/Modules						
Modules	Slot	Type	Menu	Alarm	Test	Status
0.35 Setup	0	NET (ADSL)	[+]	[n/a]	[n/a]	[+]
	1	FXS	[+]	[n/a]	[+]	[+]
	2	EC/ADPCM	[+]	-	-	-

MOD: ADSL IAD	Net: down
Access module menus	^Z=help 0:14

Figure 38. Modules Menu

>NET (ADSL)

Menu

Tx Atten

Used to select transmit attenuation level.

Retrain

Causes the unit to retrain.

Status

Rx Rate

Downstream data rate.

Tx Rate

Upstream data rate.

Rx Latency

Fast or interleaved.

Tx Latency

Fast or interleaved.

Standard

ITU G.922.1 (G.DMT), ANSI T1.413, or ITU G.922.2 (G.lite).

SNR (dB)

Signal-to-noise ratio.

>FXS

Refer to Section 4.7, *FXS User Interface Guide*.

>EC/ADPCM

Refer to Section 4.7, *FXS User Interface Guide*.

Managing the Modules – V.35 Setup

Use the **V.35 SETUP** menu to view and set the parameters shown in Figure 39.




Figure 39. V.35 Setup Menu

CHANNEL RATE and **EIA** settings are supported via this menu option. For all typical applications, these settings are left in their default states.

>ATM/FR IWF

This menu contains the setup and status for the ATM/Frame Relay interworking functions.

Mode

The **MODE** setting configures the V.35 port for FRF5 or FRF8 operation, depending upon the application being supported.

FRF5

This is also known as Network Interworking. Use this mode for Frame Relay over ATM.

FRF8

This is also known as Service Interworking. In this mode, the Total Access 600 performs a translation between Frame Relay and ATM protocols.

Configuration

The **CONFIGURATION** menu is used to support the configuration of Frame-to-ATM interworking, signaling formats, timeout values, and PVC settings.

The following settings are used for FRF5.

LAN FR MAINT PROTOCOL	Frame Relay maintenance or signaling protocol between local V.35 port and the attached DTE port, support ANSI Annex A, CCITT Q933 Annex D, CISCO LMI or Static (no signaling).
LAN FR POLL TIMEOUT T392 (5-30)	T392 for signaling protocol, typical value 15. No meaning if Maint Protocol is Static.
FRN PORT CONFIG	Logical Frame Relay ports over ATM. Up to 4 ports are supported with each port supporting up to 4 DLCI mappings. Go to NUM field. Typing "i" or "I" will insert another entry, and typing "d" or "D" will delete one entry.
NAME	To identify your port.
ATM VPI	Specifies the virtual path over which this logical port is running.
ATM VCI	Specifies the virtual circuit over which this logical port is running.
DE MAP	Frame Relay to ATM DE mapping; default value (Frn Only, ATM 0) suggested.
CLPI MAP	ATM to Frame Relay CLPI map; default value (Frn Only) suggested.
D/C	Set D/C field in the header to 0 or 1.
HEADER	Header format; only 2 bytes supported now.
MAINT PROTOCOL	Maintenance or signaling protocol over this logical Frame Relay port. Support Annex A, Annex D, CISCO LMI or Static.
MUX MODE	Many DLCIs or one DLCI mapping over this port.
DLCI MAP	Actual DLCI mappings.
LAN DLCI	The DLCI configured over local V.35 Frame Relay port.
NET DLCI	The DLCI configured over the WAN side logical Frame Relay port.
ACTIVE	Always active, not configurable.

The following settings are used for FRF8.

LAN FR MAINT PROTOCOL	Frame Relay maintenance or signaling protocol between local V.35 port and the attached DTE port, support ANSI Annex A, CCITT Q933 Annex D, CISCO LMI or Static (no signaling).
LAN FR POLL TIMEOUT T392 (5-30)	T392 for signaling protocol, typical value 15. No meaning if Maint Protocol is Static.
FR/ATM PVC MAPPING	Up to 4 mappings are supported.
FR DLCI	Frame Relay DLCI on V.35 port.
ATM VPI	Specifies the virtual path to which DLCI is mapped.
ATM VCI	Specifies the virtual circuit to which DLCI is mapped.
TRANSLATE	Translate or transparent mode between Frame Relay frames and ATM cells.
DE MAP	Map Frame Relay DE bit to ATM CLPI bit, Always 0, Always 1 or Convert each other.
FECN MAP	Map Frame Relay FECN bit to ATM EFCI bit, Always 0, Always 1 or Convert each other.

Appendix A. Voice Gateway Quick Start Procedure (Voice Turn up)

A typical VoATM application (see Figure 40) uses a Total Access 600 connected to an ATM network. For voice applications, a Voice Gateway is needed to interface with the PSTN. Jetstream, Tollbridge, and CopperCom are popular Gateway types.




Figure 40. Application Diagram

To configure a Total Access 600 for use with the Voice Gateway, you need to know the VPI and VCI to be used on the ATM network. You also need to know the format for Idle Cells and whether Data Scrambling is used on this ATM network. The following procedure will help you navigate the Total Access 600 menus for configuring the necessary elements for VoATM with the Voice Gateway.

Voice Turn Up	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. Select DSLAM TYPE and select the name of the DSLAM type you are using. (At this point you need to back out of the menu to save the changes. The unit will need to reboot if it was not previously configured for this DSLAM type.)
2.	Select DSL RATE CONFIG (BIT RATE) and change the setting to match that in your DSLAM. (If this field is read-only, allow a few seconds for autobaud to expire and the field will change to writeable.)
3.	Select WAN , and then select the ATM CONFIG menu.
4.	Enter the IDLE CELLS format for your network.
5.	Set DATA SCRAMBLING appropriately for your network.
6.	Back all the way out to the top level Total Access 600 menu, and then select the VOICE menu. (From this menu, the appropriate Voice information for working with the Voice Gateway is entered.)
7.	Select CONFIG , and from the CONFIG menu, enter the Gateway type under CALL CONTROL and enter the VPI and VCI values for communicating with that Gateway. CALL CONTROL should be set to the Gateway type, and the VPI and VCI values should be set appropriately for your network.
8.	To verify correct setup, use the STATUS menu (under the VOICE menu) to look at the current status of the voice connection. Under STATUS , you can view the GATEWAY STATS and information about the voice PVC along with information about the POTs ports available on the Gateway. The GATEWAY STATS menu should show the Gateway Link is up (if everything is configured correctly). A visual inspection of the VOICE LED on the front panel will also yield the status. Green = Up. Red = Down.

Appendix B. RFC1483 Quick Start (IP Routing)

The Total Access 600 allows for complete integration of voice and data delivery from one compact platform (see Figure 41). Once you have completed the voice turn up procedure from the previous example, adding data to the circuit requires some additional setup.




Figure 41. Application Diagram

To configure a Total Access 600 for IP routing, you need to know the VPI and VCI values for the data circuit on your network. You also need the IP address of the next hop router in the circuit.

The table on the next page shows how to configure the Total Access 600 for IP Routing.

..

IP Routing	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. (Here you set up the ATM network.)
2.	Select the ATM CONFIG menu.
3.	Enter the IDLE CELLS format for your network.
4.	Set DATA SCRAMBLING appropriately for your network.
5.	Back all the way out to the top level Total Access 600 menu, and then select the ROUTER menu.

IP Routing	
6.	Select CONFIGURATION . From the CONFIGURATION menu, you will set up addresses for your LAN and WAN. For basic IP routing, use all the default values from the GLOBAL menu.
7.	From the ETHERNET menu, enter the IP menu to enter your LAN configuration.
8.	Enter your LAN IP ADDRESS , SUBNET MASK , and DEFAULT GATEWAY information. For this example, the IP ADDRESS is 192.168.1.2, the SUBNET MASK is 255.255.255.0, and the DEFAULT GATEWAY is 10.25.4.10.
9.	Arrow back to the main ROUTER CONFIGURATION menu, and select the WAN menu and then the ATM menu. (Here you will enter your data PVC information.)
10.	Create a new PVC by entering the menu. Enter your VPI and VCI values.
11.	From the RFC1483 IP menu, enter your LAN information. For this example, the FAR END IP ADDRESS is 10.25.4.9, the IP NETMASK is 255.255.255.252, and the LOCAL IP ADDRESS is 10.25.4.10.
12.	Arrow back to the top level Total Access 600 menu to activate your changes.

Appendix C. RFC1483 Quick Start (IP Routing with NAT)

To illustrate the use of NAT, consider the example from Appendix B. To set up a single public address that will be used to access the public network, you will use the **NAT** menu on the **WAN/ATM/RFC1483 IP** menu.

IP Routing with NAT	
Step	Action
1.	From the NAT menu, set NETWORK ADDRESS PORT TRANSLATION to ENABLED . (This will enable translation and allow you to enter the NAT options.)
2.	Set PUBLIC IP ADDRESS MODE to SPECIFIED so you can enter your public address. During transmission, private addresses are translated into this public (NAPT) address.
3.	You will also need to set up the Translation Table to do translation on the body of the packets for certain protocols, such as FTP, to work correctly.
4.	From the TRANSLATION TABLE menu, create a new entry by arrowing into the table.
5.	For PUBLIC ADDRESS MODE , select NAPT ADDRESS to use the previously specified public address.
6.	For PROTOCOL , select TCP .
7.	Make sure that TRANSLATE BODY is set to YES .

Appendix D. RFC1483 Quick Start (Bridging)

The Total Access 600 allows for complete integration of voice and data delivery from one compact platform. Once you have completed the voice turn up procedure from the previous example, adding data to the circuit requires some additional setup.

To configure a Total Access 600 for Bridging, you need to know the VPI and VCI values for the data circuit on your network.

Bridging	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. (Here you set up the ATM network.)
2.	Select the ATM CONFIG menu.
3.	Enter the IDLE CELLS format for your network.
4.	Set DATA SCRAMBLING appropriately for your network.
5.	Back all the way out to the top level Total Access 600 menu, and then select the ROUTER menu.
6.	Enter the CONFIGURATION menu. From this menu, you will set up addresses for your LAN and WAN. For basic IP routing, use all the default values from the GLOBAL menu.
7.	From the ETHERNET menu, enter the IP menu to enter your LAN configuration.
8.	Enter your LAN IP ADDRESS and SUBNET MASK . For this example, the IP ADDRESS is 192.168.1.2 and the SUBNET MASK is 255.255.255.0. This is not required, but will allow Telnet configuration and TFTP upgrades from the LAN.
9.	Arrow back to the main ROUTER CONFIGURATION menu, and select the WAN menu and then the ATM menu. (Here you will enter your data PVC information.)
10.	Create a new PVC by entering the menu. Enter your VPI and VCI values.
11.	Disable IP on the RFC1483 IP menu and enable Bridging on the RFC1483 BRIDGE menu. (This enables the Total Access 600 as a bridge.)
12.	Arrow back to the top level Total Access 600 menu to activate your changes. All packets that come in on the Ethernet will be forwarded on the WAN.

SECTION 4.5 SDSL ATM USER INTERFACE GUIDE

The SDSL ATM User Interface Guide is designed for use by network administrators and others who will configure and provision the system. This section provides details unique to the SDSL ATM IADs. It contains an overview, application details, configuration information, and menu descriptions. It is recommended that you review Section 4.1, Commons User Interface Guide in addition to this section.

CONTENTS

Total Access 600 Overview	253
Analog Lifeline.	253
Firmware Updates.	253
Voice Over DSL Overview	254
Voice Over ATM Overview	254
Voice Over DSL Application	254
Configuring the Total Access 600	256
System Info.	256
System Config.	258
System Utility	261
Configuring WAN Settings	264
Configuring the Router – Configuration.	268
Configuring the Router – Status	281
Configuring the Router – Logs	282
Configuring Voice Support – Config	284
Configuring Voice Support – Status	285
Managing the Modules – Modules	286
Managing the Modules – V.35 Setup	287
Appendix A. Voice Gateway Quick Start Procedure (Voice Turn up)	290
Appendix B. RFC1483 Quick Start (IP Routing)	292
Appendix C. RFC1483 Quick Start (IP Routing with NAT)	294
Appendix D. RFC1483 Quick Start (Bridging)	295
Appendix E. Routing in HDIA Mode	296

FIGURES

Figure 1. Total Access 600 Rear Panel.	253
Figure 2. Voice over DSL	255
Figure 3. System Information Menu	256
Figure 4. System Configuration Menu.	258
Figure 5. System Utility Menu	261
Figure 6. WAN Menu.	264
Figure 7. ATM Config Menu	265
Figure 8. ATM Stats Menu	266
Figure 9. Router/Configuration Menu	268

Figure 10.	Global Menu	268
Figure 11.	Ethernet Menu	273
Figure 12.	WAN Menu	275
Figure 13.	Router/Status Menu	281
Figure 14.	Router/Logs Menu	282
Figure 15.	Voice/Config Menu	284
Figure 16.	Voice/Status Menu	285
Figure 17.	Modules Menu	286
Figure 18.	V.35 Setup Menu	287
Figure 19.	Application Diagram	290
Figure 20.	Application Diagram	292
Figure 21.	Routing with Copper Mountain	297

1. TOTAL ACCESS 600 OVERVIEW

The Total Access 600 is a complete solution Integrated Access Device (IAD) for Voice over ATM (VoATM) applications. The unit includes a modular network interface, Nx64 V.35 interface, 10/100BaseT interface, FXS ports, life-line voice backup, and an optional battery back-up for added security. The Total Access 600 can provision, test, and provide status for any of the voice and data interfaces. All connections are made via the rear panel. In addition to a built-in IP router, the Total Access 600 contains an echo canceller and ADPCM compression modules necessary for VoATM applications.

Analog Lifeline

The **LIFE LINE** connector on the rear panel (see Figure 1) provides assured voice for port 1. When a connection to the Voice Gateway is not possible due to loss of power or some other reason, an on-board relay opens and the first port of the voice connector is provided with analog voice from the analog lifeline connection.



For the analog lifeline feature to work, the user must subscribe to an analog voice line and it must be connected via the lifeline connector.




Figure 1. Total Access 600 Rear Panel

Firmware Updates

Firmware can be updated by using XMODEM transfer protocol via the unit's **CRAFT** port (see Figure 1) or by using TFTP from a network server. (See *DLP-007, Upgrading the Firmware Using XMODEM* and *DLP-008, Upgrading the Firmware Using TFTP*.)

The terminal menu is the access point to all other operations. Each terminal menu item has several functions and submenus that identify and provide access to specific operations and parameters. These menu selections are described later in this User Interface Guide.



See Section 1, Commons User Interface Guide for instructions about navigating the terminal menus.



*See Section 2, Engineering Guidelines for the **CRAFT** port connection pin-out.*

2. VOICE OVER DSL OVERVIEW

Voice over DSL (VoDSL) refers to providing toll quality voice access to the Public Switched Telephone Network (PSTN) over twisted copper pair using DSL. Data can be combined with multiple voice lines over a single medium via DSL, thus yielding many advantages over traditional TDM technologies.

Traditional TDM technologies are limited by statically allocating bandwidth. DSL overcomes this by providing a large bandwidth and utilizing other technologies, such as ATM, to dynamically assign bandwidth as it is needed. Because of this, the user is able to add voice and data connections over a DSL line with flexibility and ease.

3. VOICE OVER ATM OVERVIEW


Voice over ATM is the technology used to transmit voice conversations over a data network using Asynchronous Transfer Mode (ATM). There are several potential benefits to moving voice over a data network using ATM. First, the small, fixed-length cells require lower processing overhead. Second, these small, fixed-length cells allow higher transmission speeds than traditional packet switching methods.

ATM allocates bandwidth on demand, making it suitable for high-speed connection of voice, data, and video services. Conventional networks carry data in a synchronous manner. Because empty slots are circulating even when the link is not needed, network capacity is wasted. ATM automatically adjusts the network capacity to meet the system needs.

4. VOICE OVER DSL APPLICATION

The Total Access 600 connects to a DSLAM via DSL and ATM. The Total Access 600 has a built in echo canceller that provides G.165 echo cancellation. The module can automatically detect ADPCM and enable it as needed.

Figure 2 shows a typical VoDSL application. The Total Access 600 connects to the ATM network, via a DSLAM, to provide both voice and high speed data from a single platform.

**Figure 2. Voice over DSL**

5. CONFIGURING THE TOTAL ACCESS 600

System Info

The **SYSTEM INFO** menu provides basic information about the unit and contains data fields for editing information. Figure 3 displays the submenus available when you select this menu item.




Figure 3. System Information Menu

>System Name

Provides a user-configurable text string for the name of the Total Access 600. This name can help you distinguish between different installations. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar). This name will appear on the top line of all screens.

>System Location

Provides a user-configurable text string for the location of the Total Access 600. This field is to help you keep track of the actual physical location of the unit. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar).

>System Contact

Provides a user-configurable text string for a contact name. You can use this field to enter the name, phone number, or email address of a person responsible for the Total Access 600 system. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar).

>Unit Name

Product-specific name for the product assembly.

>CLEI Code

CLEI code for the product assembly.

>Part Number

ADTRAN part number for the product assembly.

>Serial Number

Serial number of the product assembly.

>Firmware Revision

Displays the current firmware revision level of the controller.

>Bootcode Revision

Displays the bootcode revision.

>System Uptime

Displays the length of time since the Total Access 600 system reboot.

>Date/Time

Displays the current date and time, including seconds. This field can be edited. Enter the time in 24-hour format (such as 23:00:00 for 11:00 pm). Enter the date in mm-dd-yyyy format (for example, 10-30-1998).

**NOTE**

Each time you reset the system, this value resets to 0 days, 0 hours, 0 min and 0 secs.

System Config

Set up the Total Access 600 operational configuration from the **SYSTEM CONFIG** menu. Figure 4 shows the items included in this menu.




Figure 4. System Configuration Menu

>Network Timing Mode

Selects the timing source for the entire system. Network is the only timing option available.

Network

The system's clock is recovered from the network (WAN interface).

>Telnet Access

Sets Telnet access to **ON** or **OFF**.

>Telnet User List

Up to four users can be configured for access to the Total Access 600. Each user can be assigned a security level and time out.

Name

A text string of the user name for this session.

Authen Method

The user can be authenticated in two ways:

- | | |
|-----------------|--|
| PASSWORD | The Password field is used to authenticate the user. |
| RADIUS | The Radius client is used for authenticating the user. |

Password

When the authenticating method is **PASSWORD**, this text string is used for the password.

Idle Time (1-255)

This sets the amount of time you can be idle before you are automatically logged off.

Level

This is the security level granted to the user.

>Maint Port Menu

The Total Access 600's VT 100 **CRAFT** port can be accessed via an RJ-48 located on the rear panel. The setup for these ports is under this menu.

Password Protect

When set to **No**, the maintenance port is not password protected. When **Yes** (def), the Total Access 600 will prompt for a password upon startup.

Password

This is the text string that is used for comparison when password protecting the maintenance port. By default, no password is entered.



*If you forget your password, type **CHALLENGE** in all capital letters. Call technical support and have the displayed **CHALLENGE** code ready.*



The security level for the maintenance port is always set to 0. This gives full access to all menus.



Passwords are case-sensitive.

Instructions for Changing Passwords	
Step	Action
1.	Select the PASSWORD field—a new PASSWORD field displays.
2.	Type the new password in the ENTER field.
3.	Type the new password again in the CONFIRM field.
	<i>The password can contain up to 12 alphanumeric characters. You can also use spaces and special characters in the password.</i>

Baud Rate

This is the asynchronous rate that the maintenance port will run. The possible values are 300, 1200, 2400, 4800, 9600 (def), 19200, 38400, 57600, and 115200.

Data Bits

This is the asynchronous bit rate that the maintenance port will run. The possible values are 7 or 8 (def) bits.

Parity

This is the asynchronous parity that the maintenance port will run. The possible values are **NONE** (def), **Odd**, or **EVEN**.

Stop Bits

This is the stop bit used for the maintenance port. The possible values are 1 (def), 1.5 or 2.

>Network Time

The Total Access 600 unit time can be entered manually from the **SYSTEM INFO** menu, or the unit can receive time from an NTP/SNTP server. The **NETWORK TIME** menu includes all parameters relating to how the unit communicates with the time server.

Server Type

The server type defines which port the Total Access 600 will listen on to receive timing information from the time server.

NT Time

The Total Access 600 will receive time from an NT server running SNTP software on its TIME port.

SNTP

The Total Access 600 will receive time directly from an SNTP server.

Active

This network timing feature can be turned on and off. It determines whether the unit will request and receive time from a time server.

Time Zone

There are several time zones available for the time to be displayed in. All time zones are based off of Greenwich Mean Time (GMT).

Adjust for Daylight Saving

Since some areas of the world use Daylight Savings Time, the Total Access 600 is designed to adjust the time on the first Sunday in April and the last Sunday in October accordingly if this option is turned on.

Host Address

This is the IP address of the time server that the Total Access 600 will request and receive time from.

Refresh

This is the interval of time between each request the Total Access 600 sends out to the time server. A smaller refresh time guarantees that the unit receives the correct time from the server and corrects possible errors more quickly, but it is more taxing on the machine. A range of refresh times is available for the user to decide which is best for their unit.

Status

This displays the current status of the time negotiation process. If an error is displayed, check all connections and configurations to try to resolve the problem.

System Utility

Use the **SYSTEM UTILITY** menu to view and set the system parameters shown in Figure 5.




Figure 5. System Utility Menu

>Upgrade Firmware

Updates firmware when Total Access 600 enhancements are released. Two transfer methods are available for use in updating the Total Access 600 system controller.

Transfer Method

The two methods for upgrading are **XMODEM** and **TFTP**. (See *DLP-007, Upgrading the Firmware Using XMODEM* and *DLP-008, Upgrading the Firmware Using TFTP* for more information.) **TFTP** requires a TFTP server running somewhere on the network. The Total Access 600 starts a TFTP client function which gets the upgrade code from the TFTP server. Selecting **XMODEM** will load the upgrade code through the **CRAFT** port using any PC terminal emulator with xmodem capability.

TFTP Server Address

This is required when the transfer method is TFTP. It is the IP address or domain name (if DNS is configured) of the TFTP server.

TFTP Server Filename

This is required when the transfer method is TFTP. It is the case-sensitive file name which contains the upgrade code.

Transfer Status

This appears when TFTP is used. It displays the status of the transfer as it happens. Any error or success message will be displayed here.

Start Transfer

This activator is used when the configurable items in this menu are complete.



*Before using **START TRANSFER**, the Total Access 600 should have a valid IP address, subnet mask, and default gateway (if required).*

Abort Transfer

Use this activator to cancel any TFTP transfer in progress.

>Config Transfer

Sends a file containing the Total Access 600 configuration to a PC connected to the **CRAFT** port using XMODEM protocol or to a file on a TFTP server using the TFTP protocol. See *DLP-007, Upgrading the Firmware Using XMODEM* and *DLP-008, Upgrading the Firmware Using TFTP* for details.

CONFIG TRANSFER also lets you save the Total Access 600 configuration as a backup file, so you can use the same configuration with multiple Total Access 600 units. In addition, **CONFIG TRANSFER** can retrieve a configuration file from a TFTP server.

To support these transfers, ADTRAN delivers a TFTP program with the Total Access 600 called *TFTP Server*. You can configure any PC running Microsoft Windows with this software, and store a configuration file.



*Before using **CONFIG TRANSFER**, the Total Access 600 should have a valid IP address, subnet mask, and default gateway (if required).*

Only one configuration transfer session (upload or download) can be active at a time.

Transfer Method

Displays the method used to transfer the configuration file to or from a server. XMODEM and TFTP are supported.

Transfer Type

Only **BINARY** transfers are currently supported.

TFTP Server IP Address

Specifies the IP address of the TFTP server. Get this number from your system administrator.

TFTP Server Filename

Defines the name of the configuration file that you transfer to or retrieve from the TFTP server. The default name is **ta600.cfg**, but you can edit this name.

Current Transfer Status

Indicates the current status of the update.

Previous Transfer Status

Indicates the status of the previous update.

Load and Use Config

Retrieves the configuration file specified in the **TFTP SERVER FILENAME** field from the server. To start this command, enter **Y** to begin or enter **N** to cancel.



If you execute this command, the Total Access 600 retrieves the configuration file, reboots, then restarts using the new configuration.

Save Config Remotely

Saves the configuration file specified in **TFTP SERVER FILENAME** to the server identified in **TFTP SERVER IP ADDRESS**. To start this command, enter **Y** to begin or enter **N** to cancel.



*Before using this command, you must have identified a valid TFTP server in **TFTP SERVER IP ADDRESS**.*

>Ping

Allows you to send pings (ICMP requests) to hosts. The following items are under this menu:



Only one ping session can be active at a time.

Start/Stop

Activator to start and cancel a ping test.

Host Address

IP address or domain name (if DNS is configured) of device to receive the ping.

Size (40-1500)

Total size of the ping to send. Range is 40 (64 is def) to 1500 bytes.

of Packets

Total packets to send every 2 seconds. Setting this to **0** allows the client to ping continuously.

Transmits

Total packets sent (read only).

Receives

Total packets received (read only).

%Loss

Percentage loss based on ping returned from host (read only).

Configuring WAN Settings

>DSLAM Type

Set this to the type of DSLAM the Total Access 600 will be connecting to.

>Layer One Interface

This is the physical layer protocol used to connect the DSLAM to the Total Access 600.

>Layer Two Protocol

This is the data link layer protocol used to connect the DSLAM to the Total Access 600.



If the DSLAM Type is CopperMountain, refer to Appendix E. Routing in HDIA Mode for further information.

>ATM Config

Use the **WAN** menu (Figure 6) to access the **ATM CONFIG** menu.




Figure 6. WAN Menu

Use the **ATM CONFIG** menu (Figure 7) to set the parameters listed below the figure.



Figure 7. ATM Config Menu

Idle Cells

The **IDLE CELLS** format must be configured for either **ATM FORUM** or **ITU**. Configuring this setting incorrectly for a particular circuit will cause poor performance at the ATM layer.



This setting must match the configuration setting of the ATM switch or DSLAM at the other end of the circuit.

Data Scrambling

DATA SCRAMBLING can be **ENABLED** or **DISABLED** for cell traffic. Configuring this setting incorrectly for a particular circuit will cause poor performance.



This setting must match the configuration setting of the ATM switch or DSLAM at the other end of the circuit.

>ATM Stats

Use the **WAN** menu (Figure 6 on page 264) to access the **ATM STATS** menu (Figure 8) and view the parameters listed below the figure.

TA 608 TAD/MAIN/ATM Stats		
ATM Config	AP: TxCells	0
ATM Stats	AP: RxCells	0
	AP: RxOAMCells	0
	AP: ReceiveCellsDiscarded	0
	AP: ReceiveCellErrors	0
	AP: Sync	Inactive
	AP: OutOfCellDelineation	0
	AAL5: TransmitFrames	0
	AAL5: ReceiveFrames	0
	AAL5: TransmitDiscardedFrames	0
	AAL5: ReceiveErrors	0
	AAL5: ReceiveDiscardedFrames	0
	AAL5: NoAtmFrames	0
	AAL5: NoDataPackets	0
	Clear Stats	<+>
MODE: SDSL TAD		
NET: down		
^Z=help 0:17		

Figure 8. ATM Stats Menu

AP: Tx Cells

This is the number of cells transmitted.

AP: Rx Cells

This is the number of cells received.

AP: Rx OAM Cells

This is the number of OAM cells received

AP: Receive Cells Discarded

This is the number of cells received and discarded. An incrementing count in this field could indicate a configuration problem with the ATM layer.

AP: Receive Cell Errors

This is the number of cells received with an HEC error.

AP: Sync

This indicates cell delineation at the ATM layer.

AP: Out Of Cell Delineation

This indicates loss of cell delineation at the ATM layer.

AAL5: Transmit Frames

This is the number of AAL5 frames transmitted.

AAL5: Receive Frames

This is the number of AAL5 frames received.

AAL5: Transmit Discarded Frames

This is the number of AAL5 frames discarded.

AAL5: Receive Errors

This is the number of AAL5 errors received.

AAL5: Receive Discarded Frames

This is the number of AAL5 frames discarded.

AAL5: No ATM Frames

This is for internal use only.

AAL5: No Data Packets

This is for internal use only.

Clear Stats

This is used to clear the counters on this menu screen.

>DSL Rate Config

This is the bit rate the SDSL link has trained to.

Configuring the Router – Configuration

Use the **ROUTER/CONFIGURATION** menu (Figure 9) to access the **GLOBAL**, **ETHERNET**, and **WAN** menus.




Figure 9. Router/Configuration Menu

>Global

Use the **GLOBAL** menu (Figure 10) to set up general router functions.



Figure 10. Global Menu

IP

This is used for general IP configuration.

Mode

This item controls how the Total Access 600 handles IP routes. When this option is set to **ON** (def), the Total Access 600 will advertise and listen to routes from other IP routers. If **OFF**, the route table is still used, but only static routes are used for routing IP packets and only the Ethernet port is used. IP packets can be sent over the WAN, but only when bridged.

Static Routes

Use this menu to enter static routes to other networks.

ACTIVE	Adds this static route entry to the IP routing table when set to YES and removes it (if it was previously added) if set to No (def).
IP ADDRESS	The IP address of the host or network address of the device being routed to.
SUBNET MASK	Determines the bits in the previous IP address that are used. <i>If this is to be a host route, it must be set to all ones (255.255.255.255).</i>
GATEWAY	The IP address of the router to receive the forwarded IP packet.
HOPS	The number of router hops required to get to the network or host. Maximum distance is 15 hops.
PRIVATE	When set to No , the Total Access 600 will advertise this static route using RIP. Setting to YES means that the route is kept private.

DHCP Server

DHCP MODE	When set to ON , the Total Access 600 acts as a DHCP server and will dynamically assign IP, network mask, default gateway, and DNS addresses to any device which transmits a broadcast DHCP request. The addresses assigned are based on the Total Access 600's own IP address and will be within the same network.
DHCP RENEWAL TIME	The number of hours that the DHCP server should allow the device before it is required to send a new DHCP request. The default is 15 hours, and 0 represents an infinite lease.

Domain Names

Enter the Total Access 600's domain name and the primary and secondary DNS servers in this menu.

DOMAIN NAME	Text string used to represent the domain name used by the Total Access 600.
PRIMARY DNS	First server to which domain name requests are sent.
SECONDARY DNS	Server used as a backup, in case the primary address does not respond to the request.
PRIMARY NBNS/WINS	Server to which NT domain name requests are sent.
SECONDARY NBNS/WINS	Server used when there is no response from the primary server.

UDP Relay

This menu configures the Total Access 600 to act as a UDP relay agent for applications requiring a response from UDP hosts that are not on the same network segment as their clients.

Mode

When this option is set to **ON**, the Total Access 600 will act as a relay agent.

UDP Relay List

Up to four relay destination servers can be specified in this list.

RELAY ADDRESS	This is the IP address of the server that will receive the relay packet.
UDP PORT TYPE	
STANDARD (def)	The following standard UDP protocols are relayed when set: DHCP, TFTP, DNS, NTP (Network Time Protocol, port 123, NBNS (NetBios Name Server, port 137), NBDG (NetBIOS Datagram, port 138), and BootP.
SPECIFIED	When set, the UDP port (1 to 65535) can be specified in the UDP Port columns (up to three per server).
UDP PORT 1, 2, 3	Used for specifying UDP ports to be relayed. These fields only apply when UDP PORT TYPE is set to SPECIFIED .

Bridge

The **BRIDGE** menu is used to set up the bridge parameters for the Total Access 600. The bridging function runs at the Media Access Control (MAC) level which allows any protocol packets that run over Ethernet to be forwarded. Bridging can run concurrently with IP. However, when IP routing is active, IP packets (which include ARP packets) are not bridged.

Mode

This is used to enable the bridge function.

Address Table

The Total Access 600 automatically maintains a table of MAC addresses detected and associates those addresses with the LAN or WAN port from which they were received.

AGING	The maximum time an idle MAC address remains in the table before being removed. The value is in minutes.
FORWARD POLICY	When this parameter is set to UNKNOWN (def), any bridge packet with a destination MAC address that is not in the bridge table is forwarded to all other ports. When set to KNOWN , the packet with the unknown destination MAC address is dropped and is not forwarded.

Security

Filter Defines

The Total Access 600 can filter packets based on certain parameters within the packet. The method used by the Total Access 600 allows the highest flexibility for defining filters and assigning them to a PVC. The filters are set up in two steps: (1) defining the packet types, and (2) adding them to a list under the PVC. This menu is used to define the individual filter defines based on packet type.

Filter Defines /MAC Filter Defines

The MAC filter is applied to bridge packets only. Bridge packets which are forwarded by the bridge functionality of the Total Access 600 are defined here. Up to 32 MAC defines can be specified.

NAME	Identifies the filter entry.
SRC ADDR	48-bit MAC source address used for comparison. (hexadecimal format)
SRC MASK	Bits in the MAC source address which are compared. (hexadecimal format)
DEST ADDR	48-bit MAC destination address used for comparison. (hexadecimal format)
DEST MASK	Bits in the MAC destination address used for comparison. (hexadecimal format)
MAC TYPE	16-bit MAC type field used for comparison. (hexadecimal format)
TYPE MSK	Bits in the MAC type field used for comparison. (hexadecimal format)

Filter Defines /Pattern Filter Defines

The pattern filter is applied to bridge packets only. That is any packet which is forwarded by the bridge functionality of the Total Access 600. Up to 32 pattern defines can be specified.

NAME	Identifies the filter entry.
OFFSET	Offset from beginning of packet of where to start the pattern comparison.
PATTERN	64 bits used for comparison. (hexadecimal format)
MASK	Bits in the pattern to be compared. (hexadecimal format)

Filter Defines /IP Filter Defines

The IP filter defines apply to any IP packet, whether it is routed or bridged. Up to 32 IP defines can be specified.

NAME	Identifies the filter entry.
IP SRC	IP address compared to the source address. (dotted decimal format)

SRC MASK	Bits which are used in the source comparison. (dotted decimal format)
IP DEST	IP address compared to the destination address. (dotted decimal format)
DEST MASK	Bits which are used in the destination comparison. (dotted decimal format)
SRC PORT	IP source port number used for comparison Range: 0 to 65535. (decimal format)
SRC PORT CMPR	Type of comparison that is performed. = means ports equal to not = means port not equal to > means port greater than < means port less than None - means the source port is not compared
DST PORT	IP destination port number used for comparison Range: 0 to 65535. (decimal format)
DST PORT CMPR	Type of comparison that is performed = means ports equal to not = means port not equal to > means port greater than < means port less than None - means the destination port is not compared
PROTO	Protocol used for comparison. Range: 0 to 255. (decimal format)
PROTO CMPR	Type of comparison that is performed = means protocols equal to not = means protocols not equal to > means protocols greater than < means protocols less than None means the protocol is not compared
TCP EST	Yes - only when TCP established

No - only when TCP not established

Ignore - ignore TCP flags

>Ethernet

Use the **ETHERNET** menu (Figure 11) to configure the Ethernet port on the Total Access 600.



Figure 11. Ethernet Menu

IP

This is used to set up the IP addresses for the LAN on the Total Access 600.

IP Address

The IP address assigned to the Total Access 600's Ethernet port is set here. This address must be unique within the network.

Subnet Mask

This is the IP network mask that is to be applied to the Total Access 600's Ethernet port.

Default Gateway

The default gateway is used by the Total Access 600 to send IP packets whose destination address is not found in the route table.

RIP

Use this menu to enable RIP on the LAN interface.

MODE	Enables or disables RIP.
PROTOCOL	Specifies the RIP protocol. Choices are V1 (def) (which is RIP version 1) or V2 (RIP version 2).
METHOD	Specifies the way the RIP protocol sends out its advertisements. Choices are given below.
NONE	All routes in the router table are advertised with no modification of the metrics.
SPLIT HORIZON	Only routes not learned from this circuit are advertised.
POISON REVERSE (def)	All routes are advertised, but the routes learned from this port are "poisoned" with an infinite metric.
DIRECTION	Allows the direction at which RIP advertisements are sent and listened to be specified.
TX AND RX (def)	RIP advertisements are periodically transmitted and are listened to on this port.
TX ONLY	RIP advertisements are periodically transmitted but are not listened to on this port.
RX ONLY	RIP advertisements are not transmitted on this port, but are listened.
V2 SECRET	Enter the secret used by RIP version 2 here.

Proxy ARP

This feature allows the network portion of a group of addresses to be shared among several physical network segments. The ARP protocol provides a way for devices to create a mapping between physical addresses and logical IP addresses. Proxy ARP makes use of this mapping feature by instructing a router to answer ARP requests as a "proxy" for the IP addresses behind one of its ports. The device which sent the ARP request will then correctly assume that it can reach the requested IP address by sending packets to the physical address that was returned. This technique effectively hides the fact that a network has been (further) subnetted. If this option is set to **YES**, when an ARP request is received on the Ethernet port the address is looked up in the IP routing table. If the forwarding port is not on the Ethernet port and the route is not the default route, the Total Access 600 will answer the request with its own hardware address.

MAC Address

This is a read-only MAC address programmed at ADTRAN.

>WAN

Use the **WAN** menu (Figure 12) to configure WAN settings on the Total Access 600.



Figure 12. WAN Menu

L2 Protocol

Displays the current L2 protocol - ATM (Read Only).

ATM

Use the ATM menu to setup Data PVCs for the router.

Description

This is the text description for the PVC.

VPI

ATM virtual port identifier.

VCI

This is the ATM virtual channel identifier.

PCR

Peak Cell Rate. Limits transmitted cells.

QOS

Quality of Service. Indicates this PVC's traffic class.

Protocol

This is the protocol supported on the PVC.

RFC1483 IP

Use this selection to support IP on this PVC. (These settings only take effect when RFC1483 is the selected protocol.)

Active

This selection enables IP on this PVC.

Far - End IP Address

This is the address of the NEXT hop router on this interface.

IP netmask

This is the network mask used for this interface.

Local IP Address

This is the IP address for this PVC.

NAT

Use this menu to set up and use Network Address Translation on this interface.

NETWORK ADDRESS PORT TRANSLATION	By enabling port translation, IP packets are modified as they pass through this interface. During transmission, private addresses are translated into a single public (NAPT) IP address. Incoming packets are translated from the public to private address based on the protocol port numbers. Once enabled, you must set up NAT for use.
PUBLIC IP ADDRESS MODE	The port translation requires at least a single real IP address for translating. This value can use the IP assigned to the interface (or assigned via layer 2 protocol like PPP), obtained using DHCP client, or statically specified on this menu. If the address cannot be learned, then it must be specified in order for the translation to work.
TRANSLATION TABLE	Add translation entries to "fine tune" special protocols or specify private addresses.
PUBLIC ADDRESS MODE	The public IP address used for this translation entry can be the NAPT IP address assigned to the link or can be specified. You specify an address to direct packets with certain protocols to different servers.
PROTOCOL	The upper layer protocol that is to be monitored for translation. For TCP and UDP, a port number must also be specified.
PUBLIC PORT MODE	The public destination port associated with this entry can be specified to add more control over certain types of traffic. The default, ANY PORT , covers all port types.
PRIVATE ADDRESS MODE	The private IP address can be specified to steer certain protocols and ports to specific servers in the private network. Likewise, internal hosts can be steered to certain servers on the public network. A new request from the public network matching this entry's public parameters will be dropped if this mode is set to ANY INTERNAL .

PRIVATE PORT MODE	The private destination port associated with this entry can be specified to add more control over certain types of traffic. Leave as ANY PORT to cover all port types.
TRANSLATE BODY	By default, the application payload in the packet is scanned for occurrences of the private/public IP address in binary or ASCII form. Set this to No for applications where this will cause problems.
NAT VIEW	Shows the protocols that are actively being translated.
NAPT ADDRESS	Represents the public address that is being used as the NAPT address.
ENTRY COUNT	The number of entries in the NAT table.
ENTRY OVERFLOW COUNT	A count of the dropped entries due to low memory.

RIP

Use this menu to enable RIP on the WAN interface. (See *RIP* on page 274 for description of options.)

RFC 1483 Bridge

This is used to enable bridge mode on this PVC. (These settings only take effect when RFC1483 is the selected protocol.)

PPPoATM

The Total Access 600 uses the PPPoATM profile to specify the profile used when connected using PPP.

Authentication

The authentication menu contains the required parameters for the authentication of the PPP peer and for being authenticated by the PPP peer. Authentication is applied between the Total Access 600 and the PPP peer as follows:

TX Method

This parameter specifies how the Total Access 600 is to be authenticated by the PPP peer. There are four possible selections.

NONE (def)	The connection will not allow the PPP peer to authenticate it.
PAP, CHAP, OR EAP	The connection can be authenticated using PAP, CHAP or EAP.
CHAP OR EAP	The connection can be authenticated using CHAP or EAP only.
EAP	The connection will only allow authentication by the peer using EAP.

TX Username

This is the username that is used when being authenticated by the PPP peer.

TX Password

This is the password or secret that is used when being authenticated by the PPP peer.

RX Username

This is the username used to authenticate the PPP peer.

RX Password

This is the password or secret that is used to authenticate the PPP peer.

IP

The IP menu contains the parameters for exchanging IP data with the PPP peer.

Mode

Setting to **ON** (def) will permit this connection profile to negotiate PPP IPCP with the PPP peer for exchanging of IP packets.

Local IP

This is the IP address that is assigned to the PPP link when using numbered links. Leaving this as 0.0.0.0 means the Total Access 600 will determine its IP address using PPP IPCP. If the far end router does not assign an IP address, the PPP link is left unnumbered.

Netmask

This network mask is applied to the IP/Local IP address for determining the PPP peer's network. If left as 0.0.0.0, a standard network mask is used.

Remote IP

The PPP peer's IP address or network can be set here, if known. Leaving this at 0.0.0.0 means that the Total Access 600 will determine the PPP peer's IP and network using the PPP IPCP.

NAT

The Total Access 600 can perform Network Address Translation. This feature is most widely used when connecting to the Internet. The Ethernet network can consist of private network numbers. When this profile is connected, all IP addresses on the Ethernet side are translated into the one real IP address negotiated with the PPP peer (ISP). Multiple stations on the Ethernet side can access the Internet simultaneously. Setting this option to **ON** will cause the Total Access 600 to perform NAT. In the **OFF** (def) position, the unit will route across the connection normally.

Route

The IP parameters are configured in this menu. Usually the Total Access 600 will automatically discover the PPP peer's networks using PPP IPCP and/or RIP.

- **Route/Static Route**

Selecting yes will add a static route to the remote peer to the route table.

- **Route/Private**

Selecting yes will prevent this route from being advertised.

- **Route/Hops (1-16)**

This value is the metric or number of hops that RIP will use in advertising the static route. The range is 1 to 16, where 1 is the default. The value 16 is considered an infinite distance (poisoned route).

- **Route/Force IP**

When set to **YES**, the Total Access 600 will force the PPP peer to use the IP address in the **LOCAL IP** for this profile as its WAN IP address. Normally this is set in the **No** (def) position.

RIP

The RIP parameters can be adjusted from their defaults under this menu.

- **Mode**

The Total Access 600 performs RIP over the WAN connection when this is set to **ON** (def).

- **Protocol**

The Total Access 600 performs version 1, **V1** (def), or version 2, **V2**, of RIP on this WAN connection.

- **Method**

SPLIT HORIZON	Only routes not learned on the WAN connection are advertised.
POISON REVERSE (def)	All routes are advertised, including routes learned from the WAN connection. These routes are poisoned.
NONE	All routes are advertised, including routes learned from the WAN connection. No attempt is made to poison these routes.

- **Direction**

TX AND RX (def)	RIP advertisements are transmitted and listened to on the WAN connection.
TX ONLY	RIP advertisements are transmitted and not listened to.
RX ONLY	RIP advertisements are listened to but not transmitted.

- **Triggered**

When set to **YES**, only IP RIP updates are sent when the routing table has changed and learned routes are not "aged." When set to **No** (def), updates are sent periodically.

- **Retain**

When this Connection List entry is disconnected and this parameter is set to **YES**, all routes learned from this WAN connection are retained and their routing interface is set to idle.

PPP

The Total Access 600 supports the IETF standards for the Point-to-Point Protocol. The PPP state machine running in the Total Access 600 can be fine-tuned to support many applications that can be employed. The configurable items under this menu can be changed from their default values for special cases.

VJ Compression

When this item is set to **ON**, the Total Access 600 will perform TCP/IP header compression known as Van Jacobson compression to the PPP peer.

Max Config

This value is the number of unanswered configuration-requests that should be transmitted before giving up on a call. The possible values are 5, 10 (def), 15 and 20.

Max Timer

This value is the number of seconds to wait between unanswered configuration requests. The possible values are 1 sec, 2 secs (def), 3 secs, 5 secs and 10 secs.

Max Failure

Due to the nature of PPP, configuration options may not be agreed upon between two PPP peers. This value is the number of configuration-naks that should occur before an option is configuration-rejected. This allows a connection to succeed that might otherwise fail. The possible values are 5 (def), 10, 15 and 20.

Encapsulation

This is the PPP encapsulation. (LLC or VC-Mux)

Filters

The Total Access 600 can block packets in and out of a WAN port by use of the filters. They are set up in two steps: 1) define the types of packets that would be of interest in the **CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES** menu, and 2) set up the filter type and combination of defines that will cause a packet block.

WAN-TO-LAN (In)

The packets which come into the Total Access 600 can be filtered in three ways:

DISABLED (def)	Turns off packet input filtering. No incoming packets are blocked.
BLOCK ALL	All incoming packets from the WAN are blocked except as defined in the FILTERS/IN EXCEPTIONS list.
FORWARD ALL	All incoming packets from the WAN are not blocked except as defined in the FILTERS/IN EXCEPTIONS list.

In Exceptions

This is a list of up to 32 filter entries which can be combined using the operations field. The operations are performed in the order they appear on the list.

ACTIVE	Turns this entry active when set to ON .
TYPE	Selects the filter define list to reference:
MAC	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/MAC FILTER DEFINES list.
PATTERN	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/PATTERN FILTER DEFINES list.
IP	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/IP FILTER DEFINES list.
IPX	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/IPX FILTER DEFINES list.
FILTER LIST NAME	Selects between filters defined in the list.
NEXT OPER	The next operation to use to combine with the next filter in the list:

END	the last filter to combination.
AND	logically AND this filter with the next filter in the list.
OR	logically OR this filter with the next filter in the list.

LAN-TO-WAN (Out)

The packets which come out toward the WAN from the TA600 can be filtered in three ways:

DISABLED (def)	Turns off packet input filtering. No outgoing packets are blocked.
BLOCK ALL	All outgoing packets to the WAN are blocked except as defined in the FILTERS/OUT EXCEPTIONS list.
FORWARD ALL	All outgoing packets to the WAN are not blocked except as defined in the FILTERS/OUT EXCEPTIONS list.

Out Exceptions

This is a list of up to 32 filter entries. The setup is exactly the same as the **FILTERS/IN EXCEPTIONS** list.

Configuring the Router – Status

Use the **ROUTER/STATUS** menu to view and set the parameters shown in Figure 13. The **ROUTER/STATUS** screens give the user useful information for debugging the current routes in the Total Access 600.




Figure 13. Router/Status Menu

>Session

This menu maintains statistics about the active ATM PVCs.

>ARP cache

This is a listing of the currently connected Ethernet port on the LAN.

>Bridge Table

This shows the detected MAC addresses and the interface to which they are associated.

>IP Routes

This shows the current routes in the Total Access 600 and their use.

>LAN Stats

This shows traffic over the LAN interface.

>IP Stats

This shows IP traffic through the Total Access 600.

Configuring the Router – Logs

The Logs menu (Figure 14) contains logs displaying important information about the running condition of the Total Access 600. The logs can be set to capture diagnostics of error conditions only by way of a log level. The levels are divided up as follows:

- level 0 - Fatal event (causes reset)
- level 1 - Critical event
- level 2 - Error event
- level 3 - Warning event
- level 4 - Notify event
- level 5 - Informational event
- level 6 - Debugging event



Figure 14. Router/Logs Menu

Sys log Host

Set this to the IP address or domain name (if DNS configured) of the sys log host device. All log events are sent to this device.

PPP Log

Information pertaining to the PPP negotiation and authentication is logged in the PPP log.

Connection Log

Information pertaining to the call placement and answering is logged in the Connection log.

Network Log

Information pertaining to routing protocols is placed in this log.

Each log (PPP log, Connection log, and Network log) contains the following elements.

Active

When set to **YES** (def), PPP events below or equal the log level are logged into the log.

Wrap

When set to **YES** (def), new PPP events will overwrite old PPP events when the log is full. All logging will stop when the log is full and set to **No**.

Level

In order to log events, they must be at or below this level. Range is 0 to 6. The default is 3.

View

This menu displays the log list. The fields are as follows:

DATE/TIME	Date and time event occurred.
LEVEL	Level associated with this event (0-6).
MESSAGE	Text message for this event. If message is too long to fit on the line, another event appears below it continuing the message.

Clear

This clears the log when activated.

Configuring Voice Support – Config

Use the **VOICE/CONFIG** menu to view and set the parameters shown in Figure 15.

TA 608	IAD/Voice/Config		
Config	Call Control	Jetstream	
Status	VPI	0	
	VCI	39	
MODE: SDSL IAD			
NE1: down			
^Z=help 0:26			

Figure 15. Voice/Config Menu

>Call Control

The **CALL CONTROL** setting is used to configure the correct Voice Gateway protocol for voice signaling control between the Total Access 600 and the configured Gateway. The **CALL CONTROL** setting must be configured correctly before the voice circuits will work correctly. The Total Access 600 supports Jetstream, Tollbridge, and CopperCom Voice Gateways.

>VPI

The **VPI** setting is used to configure the Total Access 600 virtual path setting used to communicate with the configured Voice Gateway.

>VCI

The **VCI** setting is used to configure the Total Access 600 virtual circuit setting used to communicate with the configured Voice Gateway.

Configuring Voice Support – Status

Use the **VOICE/STATUS** menu to view and set the parameters shown in Figure 16.




Figure 16. Voice/Status Menu

>Gateway Stats

The **GATEWAY STATS** menu shows the current state of the communication link between the Total Access 600 and the Voice Gateway. The Gateway Link is indicated as **UP** or **DOWN**. A count of management messages is indicated along with the number of active calls in progress.

>PVC Stats

The **PVC STATS** menu shows the current state of the virtual circuit used between the Voice Gateway and the Total Access 600 IAD for voice signaling and voice payload delivery.

>POTS Stats

The **POTS STATS** menu shows real-time indication status of each voice port on the Total Access 600. From this menu, on a per port basis, the user can determine which ports are active/inactive. Several statistics at this menu are used only for internal ADTRAN development. Task, Inserts, and Drops indicators are for internal use only.

>Clear Stats

The **CLEAR STATS** menu can be used to clear the counters used for Voice Status menus.

Managing the Modules – Modules

Use the **MODULES** menu to view and set the parameters shown in Figure 17. The Total Access 600 contains four fixed modules: The WAN/Network interface, FXS, Echo Cancellor/ADPCM module, and the V.35 interface. The **MODULES** table allows management of the on-board modules in the Total Access 600.

The table contains **MENU**, **ALARM**, **TEST**, and **STATUS** indicators/menus customized for each module.

TA 608 IAD/Modules/Modules						
Modules	Slt	Type	Menu	Alarm	Test	Status
0.35 Setup	0	NET (SDSL)	[n/a]	[n/a]	[+]	[n/a]
	1	FXS	[+]	[n/a]	[+]	[+]
	2	EC/ADPCM	[+]	-	-	-

MODE: SDSL IAD	NET: down
Access module menus	^Z=help 0:29

Figure 17. Modules Menu

>NET (SDSL)

Test

These tests are meant for debug purposes only. A reboot may be required to return the Total Access 600 to normal operation.

Network Loopback

Sets the network interface in loopback mode.

Send/Check 2047

Sends and checks a 2047 BERT pattern over the network interface (assuming LTU in loopback). Results of the test can be found in Test Results.

Send/Check ALT

Sends and checks an alternating pattern over the network interface (assuming LTU in loopback). Results of the test can be found in Test Results.

>FXS

Refer to *Section 7, FXS User Interface Guide*.

>EC/ADPCM

Refer to *Section 7, FXS User Interface Guide*.

Managing the Modules – V.35 Setup

Use the **V.35 SETUP** menu to view and set the parameters shown in Figure 18.




Figure 18. V.35 Setup Menu

CHANNEL RATE and **EIA** settings are supported via this menu option. For all typical applications, these settings are left in their default states.

>ATM/FR IWF

This menu contains the setup and status for the ATM/Frame Relay interworking functions.

Mode

The **MODE** setting configures the V.35 port for FRF5 or FRF8 operation, depending upon the application being supported.

FRF5

This is also known as Network Interworking. Use this mode for Frame Relay over ATM.

FRF8

This is also known as Service Interworking. In this mode, the Total Access 600 performs a translation between Frame Relay and ATM protocols.

Configuration

The **CONFIGURATION** menu is used to support the configuration of Frame-to-ATM interworking, signaling formats, timeout values, and PVC settings.

The following settings are used for FRF5.

LAN FR MAINT PROTOCOL	Frame Relay maintenance or signaling protocol between local V.35 port and the attached DTE port, support ANSI Annex A, CCITT Q933 Annex D, CISCO LMI or Static (no signaling).
LAN FR POLL TIMEOUT T392 (5-30)	T392 for signaling protocol, typical value 15. No meaning if Maint Protocol is Static.
FRN PORT CONFIG	Logical Frame Relay ports over ATM. Up to 4 ports are supported with each port supporting up to 4 DLCI mappings. Go to NUM field. Typing "i" or "I" will insert another entry, and typing "d" or "D" will delete one entry.
NAME	To identify your port.
ATM VPI	Specifies the virtual path over which this logical port is running.
ATM VCI	Specifies the virtual circuit over which this logical port is running.
DE MAP	Frame Relay to ATM DE mapping; default value (Frn Only, ATM 0) suggested.
CLPI MAP	ATM to Frame Relay CLPI map; default value (Frn Only) suggested.
D/C	Set D/C field in the header to 0 or 1.
HEADER	Header format; only 2 bytes supported now.
MAINT PROTOCOL	Maintenance or signaling protocol over this logical Frame Relay port. Support Annex A, Annex D, CISCO LMI or Static.
MUX MODE	Many DLCIs or one DLCI mapping over this port.
DLCI MAP	Actual DLCI mappings.
LAN DLCI	The DLCI configured over local V.35 Frame Relay port.
NET DLCI	The DLCI configured over the WAN side logical Frame Relay port.
ACTIVE	Always active, not configurable.

The following settings are used for FRF8.

LAN FR MAINT PROTOCOL	Frame Relay maintenance or signaling protocol between local V.35 port and the attached DTE port, support ANSI Annex A, CCITT Q933 Annex D, CISCO LMI or Static (no signaling).
LAN FR POLL TIMEOUT T392 (5-30)	T392 for signaling protocol, typical value 15. No meaning if Maint Protocol is Static.
FR/ATM PVC MAPPING	Up to 4 mappings are supported.
FR DLCI	Frame Relay DLCI on V.35 port.
ATM VPI	Specifies the virtual path to which DLCI is mapped.
ATM VCI	Specifies the virtual circuit to which DLCI is mapped.
TRANSLATE	Translate or transparent mode between Frame Relay frames and ATM cells.
DE MAP	Map Frame Relay DE bit to ATM CLPI bit, Always 0, Always 1 or Convert each other.
FECN MAP	Map Frame Relay FECN bit to ATM EFCI bit, Always 0, Always 1 or Convert each other.

Appendix A. Voice Gateway Quick Start Procedure (Voice Turn up)

A typical VoATM application (see Figure 19) uses a Total Access 600 connected to an ATM network. For voice applications, a Voice Gateway is needed to interface with the PSTN. Jetstream, Tollbridge, and CopperCom are popular Gateway types.




Figure 19. Application Diagram

To configure a Total Access 600 for use with the Voice Gateway, you need to know the VPI and VCI to be used on the ATM network. You also need to know the format for Idle Cells and whether Data Scrambling is used on this ATM network. The following procedure will help you navigate the Total Access 600 menus for configuring the necessary elements for VoATM with the Voice Gateway.

Voice Turn Up	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. Select DSLAM TYPE and select the name of the DSLAM type you are using. (At this point you need to back out of the menu to save the changes. The unit will need to reboot if it was not previously configured for this DSLAM type.)
2.	Select DSL RATE CONFIG (BIT RATE) and change the setting to match that in your DSLAM. (If this field is read-only, allow a few seconds for autobaud to expire and the field will change to writeable.)
3.	Select WAN , and then select the ATM CONFIG menu.
4.	Enter the IDLE CELLS format for your network.
5.	Set DATA SCRAMBLING appropriately for your network.
6.	Back all the way out to the top level Total Access 600 menu, and then select the VOICE menu. (From this menu, the appropriate Voice information for working with the Voice Gateway is entered.)
7.	Select CONFIG , and from the CONFIG menu, enter the Gateway type under CALL CONTROL and enter the VPI and VCI values for communicating with that Gateway. CALL CONTROL should be set to the Gateway type, and the VPI and VCI values should be set appropriately for your network.
8.	To verify correct setup, use the STATUS menu (under the VOICE menu) to look at the current status of the voice connection. Under STATUS , you can view the GATEWAY STATS and information about the voice PVC along with information about the POTs ports available on the Gateway. The GATEWAY STATS menu should show the Gateway Link is up (if everything is configured correctly). A visual inspection of the VOICE LED on the front panel will also yield the status. Green = Up. Red = Down.

Appendix B. RFC1483 Quick Start (IP Routing)

The Total Access 600 allows for complete integration of voice and data delivery from one compact platform (see Figure 20). Once you have completed the voice turn up procedure from the previous example, adding data to the circuit requires some additional setup.




Figure 20. Application Diagram

To configure a Total Access 600 for IP routing, you need to know the VPI and VCI values for the data circuit on your network. You also need the IP address of the next hop router in the circuit.

The table on the next page shows how to configure the Total Access 600 for IP Routing.

..

IP Routing	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. (Here you set up the ATM network.)
2.	Select the ATM CONFIG menu.
3.	Enter the IDLE CELLS format for your network.
4.	Set DATA SCRAMBLING appropriately for your network.
5.	Back all the way out to the top level Total Access 600 menu, and then select the ROUTER menu.

IP Routing	
6.	Select CONFIGURATION . From the CONFIGURATION menu, you will set up addresses for your LAN and WAN. For basic IP routing, use all the default values from the GLOBAL menu.
7.	From the ETHERNET menu, enter the IP menu to enter your LAN configuration.
8.	Enter your LAN IP ADDRESS , SUBNET MASK , and DEFAULT GATEWAY information. For this example, the IP ADDRESS is 192.168.1.2, the SUBNET MASK is 255.255.255.0, and the DEFAULT GATEWAY is 10.25.4.10.
9.	Arrow back to the main ROUTER CONFIGURATION menu, and select the WAN menu and then the ATM menu. (Here you will enter your data PVC information.)
10.	Create a new PVC by entering the menu. Enter your VPI and VCI values.
11.	From the RFC1483 IP menu, enter your LAN information. For this example, the FAR END IP ADDRESS is 10.25.4.9, the IP NETMASK is 255.255.255.252, and the LOCAL IP ADDRESS is 10.25.4.10.
12.	Arrow back to the top level Total Access 600 menu to activate your changes.

Appendix C. RFC1483 Quick Start (IP Routing with NAT)

To illustrate the use of NAT, consider the example from Appendix B. To set up a single public address that will be used to access the public network, you will use the **NAT** menu on the **WAN/ATM/RFC1483 IP** menu.

IP Routing with NAT	
Step	Action
1.	From the NAT menu, set NETWORK ADDRESS PORT TRANSLATION to ENABLED . (This will enable translation and allow you to enter the NAT options.)
2.	Set PUBLIC IP ADDRESS MODE to SPECIFIED so you can enter your public address. During transmission, private addresses are translated into this public (NAPT) address.
3.	You will also need to set up the Translation Table to do translation on the body of the packets for certain protocols, such as FTP, to work correctly.
4.	From the TRANSLATION TABLE menu, create a new entry by arrowing into the table.
5.	For PUBLIC ADDRESS MODE , select NAPT ADDRESS to use the previously specified public address.
6.	For PROTOCOL , select TCP .
7.	Make sure that TRANSLATE BODY is set to YES .

Appendix D. RFC1483 Quick Start (Bridging)

The Total Access 600 allows for complete integration of voice and data delivery from one compact platform. Once you have completed the voice turn up procedure from the previous example, adding data to the circuit requires some additional setup.

To configure a Total Access 600 for Bridging, you need to know the VPI and VCI values for the data circuit on your network.

Bridging	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. (Here you set up the ATM network.)
2.	Select the ATM CONFIG menu.
3.	Enter the IDLE CELLS format for your network.
4.	Set DATA SCRAMBLING appropriately for your network.
5.	Back all the way out to the top level Total Access 600 menu, and then select the ROUTER menu.
6.	Enter the CONFIGURATION menu. From this menu, you will set up addresses for your LAN and WAN. For basic IP routing, use all the default values from the GLOBAL menu.
7.	From the ETHERNET menu, enter the IP menu to enter your LAN configuration.
8.	Enter your LAN IP ADDRESS and SUBNET MASK . For this example, the IP ADDRESS is 192.168.1.2 and the SUBNET MASK is 255.255.255.0. This is not required, but will allow Telnet configuration and TFTP upgrades from the LAN.
9.	Arrow back to the main ROUTER CONFIGURATION menu, and select the WAN menu and then the ATM menu. (Here you will enter your data PVC information.)
10.	Create a new PVC by entering the menu. Enter your VPI and VCI values.
11.	Disable IP on the RFC1483 IP menu and enable Bridging on the RFC1483 BRIDGE menu. (This enables the Total Access 600 as a bridge.)
12.	Arrow back to the top level Total Access 600 menu to activate your changes. All packets that come in on the Ethernet will be forwarded on the WAN.

Appendix E. Routing in HDIA Mode

The Total Access 600 allows for complete integration of voice and data delivery from one compact platform. The CopperMountain DSLAM uses Frame Relay instead of ATM as their Layer 2 protocol. Once you have completed the Layer 1 configuration from the previous examples, you must configure the Layer 2 protocol. Refer to Figure 21 on page 297 as you complete the steps below.

Frame Relay Setup	
Step	Action
1.	From the IAD/WAN/FRAME RELAY CONFIG menu, select MAINTENANCE PROTOCOL . Set MAINTENANCE PROTOCOL to STATIC .
2.	From the IAD/WAN/FRAME RELAY CONFIG menu, select DLCI MAPPING .
3.	On the DLCI MAPPING menu, DLCI 528 should be selected. Right arrow to the IP MAP menu.
4.	On the IP MAP menu, set up the following: Set ACTIVE to YES W/BRIDGE ENCAPSULATION . Set ADDRESS MODE to either USER SPECIFIED or DHCP CLIENT . If DHCP CLIENT is selected, the link addresses will be learned through DHCP (skip to Step 5). Set FAR-END IP ADDRESS to the next hop router on the ATM interface connected to the Copper Mountain for this DSL line (10.100.2.145 in Figure 21). Set IP NETMASK appropriately for this interface. Set LOCAL IP ADDRESS to the Copper Mountain IP address for this line (10.100.2.148 in Figure 21).
5.	On the NAT menu, set up the following: Set NETWORK ADDRESS PORTTRANSLATION to ENABLED . Set PUBLIC IP ADDRESS MODE to SPECIFIED . Set PUBLIC IP ADDRESS the same as LOCAL IP ADDRESS above. From the TRANSLATION TABLE , set up the following (create entries so that the appropriate protocols are translated): Right arrow to create an entry. Keep the defaults to enable TCP translation. Press I over the 1 in the first entry to create entry 2. Change the Protocol to ICMP for this entry. Continue creating entries as appropriate for each application.
6.	Arrow back (left arrow) to the IAD/WAN/FRAME RELAY CONFIG/DLCI MAPPING menu.
7.	From the BRIDGE MAP menu, set ACTIVE to NO .

Frame Relay Setup	
8.	Arrow back to the IAD/ROUTER menu. Select CONFIGURATION .
9.	<p>On the GLOBAL menu, set up the following:</p> <p>Select IP.</p> <p>Set MODE to ON.</p> <p>Select DHCP SERVER.</p> <p>Set DHCP MODE to ON.</p> <p>From DOMAIN NAMES, set up the following:</p> <p>Set PRIMARY DNS appropriately (172.22.48.47 in Figure 21).</p> <p>Set SECONDARY DNS appropriately (172.22.48.1 in Figure 21).</p> <p>Select BRIDGE.</p> <p>Set MODE to OFF.</p>
10.	<p>Arrow back to the ETHERNET menu, and set up the following:</p> <p>Select IP.</p> <p>Set IP ADDRESS appropriately for your LAN (10.0.0.1 in Figure 21).</p> <p>Set SUBNET MASK appropriately.</p> <p>Set DEFAULT GATEWAY to the ATM router connected to the Copper Mountain (10.100.2.145 in Figure 21).</p>




Figure 21. Routing with Copper Mountain

SECTION 4.6 SHDSL ATM USER INTERFACE GUIDE

The SHDSL ATM User Interface Guide is designed for use by network administrators and others who will configure and provision the system. This section provides details unique to the SHDSL ATM IADs. It contains an overview, application details, configuration information, and menu descriptions. It is recommended that you review *Section 4.1, Commons User Interface Guide* in addition to this section.

CONTENTS

Total Access 600 Overview	301
Analog Lifeline.	301
Firmware Updates.	301
Voice Over DSL Overview	302
Voice Over ATM Overview	302
Voice Over DSL Application	302
Configuring the Total Access 600	304
System Info.	304
System Config.	306
System Utility	309
Configuring WAN Settings	312
Configuring the Router – Configuration.	316
Configuring the Router – Status	329
Configuring the Router – Logs	330
Configuring Voice Support – Config	332
Configuring Voice Support – Status	333
Managing the Modules – Modules	334
Managing the Modules – V.35 Setup	336
Appendix A. Voice Gateway Quick Start Procedure (Voice Turn up)	339
Appendix B. RFC1483 Quick Start (IP Routing)	341
Appendix C. RFC1483 Quick Start (IP Routing with NAT)	343
Appendix D. RFC1483 Quick Start (Bridging)	344

FIGURES

Figure 1. Total Access 600 Rear Panel.	301
Figure 2. Voice over DSL	303
Figure 3. System Information Menu	304
Figure 4. System Configuration Menu.	306
Figure 5. System Utility Menu	309
Figure 6. WAN Menu.	312
Figure 7. ATM Config Menu	313
Figure 8. ATM Stats Menu	314
Figure 9. Router/Configuration Menu	316
Figure 10. Global Menu.	316
Figure 11. Ethernet Menu	321

Figure 12.	WAN Menu	323
Figure 13.	Router/Status Menu	329
Figure 14.	Router/Logs Menu	330
Figure 15.	Voice/Config Menu	332
Figure 16.	Voice/Status Menu	333
Figure 17.	Modules Menu	334
Figure 18.	V.35 Setup Menu	336
Figure 19.	Application Diagram	339
Figure 20.	Application Diagram	341

1. TOTAL ACCESS 600 OVERVIEW

The Total Access® 600 is a complete solution Integrated Access Device (IAD) for Voice over ATM (VoATM) applications. The unit includes a modular network interface, Nx64 V.35 interface, 10/100BaseT interface, FXS ports, life-line voice backup, and an optional battery back-up for added security. The Total Access 600 can provision, test, and provide status for any of the voice and data interfaces. All connections are made via the rear panel. In addition to a built-in IP router, the Total Access 600 contains an echo canceller and ADPCM compression modules necessary for VoATM applications.

Analog Lifeline

The **LIFE LINE** connector on the rear panel (see Figure 1) provides assured voice for port 1. When a connection to the Voice Gateway is not possible due to loss of power or some other reason, an on-board relay opens and the first port of the voice connector is provided with analog voice from the analog lifeline connection.



For the analog lifeline feature to work, the user must subscribe to an analog voice line and it must be connected via the lifeline connector.




Figure 1. Total Access 600 Rear Panel

Firmware Updates

Firmware can be updated by using XMODEM transfer protocol via the unit's **CRAFT** port (see Figure 1) or by using TFTP from a network server. (See *DLP-007, Upgrading the Firmware Using XMODEM* and *DLP-008, Upgrading the Firmware Using TFTP*.)

The terminal menu is the access point to all other operations. Each terminal menu item has several functions and submenus that identify and provide access to specific operations and parameters. These menu selections are described later in this User Interface Guide.



See Section 4.1, Commons User Interface Guide for instructions about navigating the terminal menus.



*See Section 2.2, Engineering Guidelines for the **CRAFT** port connection pin-out.*

2. VOICE OVER DSL OVERVIEW

Voice over DSL (VoDSL) refers to providing toll quality voice access to the Public Switched Telephone Network (PSTN) over twisted copper pair using DSL. Data can be combined with multiple voice lines over a single medium via DSL, thus yielding many advantages over traditional TDM technologies.

Traditional TDM technologies are limited by statically allocating bandwidth. DSL overcomes this by providing a large bandwidth and utilizing other technologies, such as ATM, to dynamically assign bandwidth as it is needed. Because of this, the user is able to add voice and data connections over a DSL line with flexibility and ease.

3. VOICE OVER ATM OVERVIEW


Voice over ATM is the technology used to transmit voice conversations over a data network using Asynchronous Transfer Mode (ATM). There are several potential benefits to moving voice over a data network using ATM. First, the small, fixed-length cells require lower processing overhead. Second, these small, fixed-length cells allow higher transmission speeds than traditional packet switching methods.

ATM allocates bandwidth on demand, making it suitable for high-speed connection of voice, data, and video services. Conventional networks carry data in a synchronous manner. Because empty slots are circulating even when the link is not needed, network capacity is wasted. ATM automatically adjusts the network capacity to meet the system needs.

4. VOICE OVER DSL APPLICATION

The Total Access 600 connects to a DSLAM via DSL and ATM. The Total Access 600 has a built in echo canceller that provides G.165 echo cancellation. The module can automatically detect ADPCM and enable it as needed.

Figure 2 shows a typical VoDSL application. The Total Access 600 connects to the ATM network, via a DSLAM, to provide both voice and high speed data from a single platform.

**Figure 2. Voice over DSL**

5. CONFIGURING THE TOTAL ACCESS 600

System Info

The **SYSTEM INFO** menu provides basic information about the unit and contains data fields for editing information. Figure 3 displays the submenus available when you select this menu item.




Figure 3. System Information Menu

>System Name

Provides a user-configurable text string for the name of the Total Access 600. This name can help you distinguish between different installations. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar). This name will appear on the top line of all screens.

>System Location

Provides a user-configurable text string for the location of the Total Access 600. This field is to help you keep track of the actual physical location of the unit. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar).

>System Contact

Provides a user-configurable text string for a contact name. You can use this field to enter the name, phone number, or E-mail address of a person responsible for the Total Access 600 system. You can enter up to 31 characters in this field, including spaces and special characters (such as an underbar).

>Unit Name

Product-specific name for the product assembly.

>CLEI Code

CLEI code for the product assembly.

>Part Number

ADTRAN part number for the product assembly.

>Serial Number

Serial number of the product assembly.

>Firmware Revision

Displays the current firmware revision level of the controller.

>Bootcode Revision

Displays the bootcode revision.

>System Uptime

Displays the length of time since the Total Access 600 system reboot.

>Date/Time

Displays the current date and time, including seconds. This field can be edited. Enter the time in 24-hour format (such as 23:00:00 for 11:00 pm). Enter the date in mm-dd-yyyy format (for example, 10-30-1998).

**NOTE**

Each time you reset the system, this value resets to 0 days, 0 hours, 0 min and 0 secs.

System Config

Set up the Total Access 600 operational configuration from the **SYSTEM CONFIG** menu. Figure 4 shows the items included in this menu.




Figure 4. System Configuration Menu

>Network Timing Mode

Selects the timing source for the entire system. Network is the only timing option available.

Network

The system's clock is recovered from the network (WAN interface).

>Telnet Access

Sets Telnet access to **ON** or **OFF**.

>Telnet User List

Up to four users can be configured for access to the Total Access 600. Each user can be assigned a security level and time out.

Name

A text string of the user name for this session.

Authen Method

The user can be authenticated in two ways:

- PASSWORD** The Password field is used to authenticate the user.
- RADIUS** The Radius client is used for authenticating the user.

Password

When the authenticating method is **PASSWORD**, this text string is used for the password.

Idle Time (1-255)

This sets the amount of time you can be idle before you are automatically logged off.

Level

This is the security level granted to the user.

>Maint Port Menu

The Total Access 600's VT 100 **CRAFT** port can be accessed via an RJ-48 located on the rear panel. The setup for these ports is under this menu.

Password Protect

When set to **No**, the maintenance port is not password protected. When **Yes** (def), the Total Access 600 will prompt for a password upon startup.

Password

This is the text string that is used for comparison when password protecting the maintenance port. By default, no password is entered.



If you forget your password, type CHALLENGE in all capital letters. Call technical support and have the displayed CHALLENGE code ready.



The security level for the maintenance port is always set to 0. This gives full access to all menus.



Passwords are case-sensitive.

Instructions for Changing Passwords	
Step	Action
1.	Select the PASSWORD field—a new PASSWORD field displays.
2.	Type the new password in the ENTER field.
3.	Type the new password again in the CONFIRM field.
	<i>The password can contain up to 12 alphanumeric characters. You can also use spaces and special characters in the password.</i>

Baud Rate

This is the asynchronous rate that the maintenance port will run. The possible values are 300, 1200, 2400, 4800, 9600 (def), 19200, 38400, 57600, and 115200.

Data Bits

This is the asynchronous bit rate that the maintenance port will run. The possible values are 7 or 8 (def) bits.

Parity

This is the asynchronous parity that the maintenance port will run. The possible values are **NONE** (def), **Odd**, or **EVEN**.

Stop Bits

This is the stop bit used for the maintenance port. The possible values are 1 (def), 1.5 or 2.

>Network Time

The Total Access 600 unit time can be entered manually from the **SYSTEM INFO** menu, or the unit can receive time from an NTP/SNTP server. The **NETWORK TIME** menu includes all parameters relating to how the unit communicates with the time server.

Server Type

The server type defines which port the Total Access 600 will listen on to receive timing information from the time server.

NT Time

The Total Access 600 will receive time from an NT server running SNTP software on its TIME port.

SNTP

The Total Access 600 will receive time directly from an SNTP server.

Active

This network timing feature can be turned on and off. It determines whether the unit will request and receive time from a time server.

Time Zone

There are several time zones available for the time to be displayed in. All time zones are based off of Greenwich Mean Time (GMT).

Adjust for Daylight Saving

Since some areas of the world use Daylight Savings Time, the Total Access 600 is designed to adjust the time on the first Sunday in April and the last Sunday in October accordingly if this option is turned on.

Host Address

This is the IP address of the time server that the Total Access 600 will request and receive time from.

Refresh

This is the interval of time between each request the Total Access 600 sends out to the time server. A smaller refresh time guarantees that the unit receives the correct time from the server and corrects possible errors more quickly, but it is more taxing on the machine. A range of refresh times is available for the user to decide which is best for their unit.

Status

This displays the current status of the time negotiation process. If an error is displayed, check all connections and configurations to try to resolve the problem.

System Utility

Use the **SYSTEM UTILITY** menu to view and set the system parameters shown in Figure 5.



Figure 5. System Utility Menu

>Upgrade Firmware

Updates firmware when Total Access 600 enhancements are released. Two transfer methods are available for use in updating the Total Access 600 system controller.

Transfer Method

The two methods for upgrading are **XMODEM** and **TFTP**. (See *DLP-007, Upgrading the Firmware Using XMODEM* and *DLP-008, Upgrading the Firmware Using TFTP* for more information.) **TFTP** requires a TFTP server running somewhere on the network. The Total Access 600 starts a TFTP client function which gets the upgrade code from the TFTP server. Selecting **XMODEM** will load the upgrade code through the **CRAFT** port using any PC terminal emulator with xmodem capability.

TFTP Server Address

This is required when the transfer method is TFTP. It is the IP address or domain name (if DNS is configured) of the TFTP server.

TFTP Server Filename

This is required when the transfer method is TFTP. It is the case-sensitive file name which contains the upgrade code.

Transfer Status

This appears when TFTP is used. It displays the status of the transfer as it happens. Any error or success message will be displayed here.

Start Transfer

This activator is used when the configurable items in this menu are complete.



*Before using **START TRANSFER**, the Total Access 600 should have a valid IP address, subnet mask, and default gateway (if required).*

Abort Transfer

Use this activator to cancel any TFTP transfer in progress.

>Config Transfer

Sends a file containing the Total Access 600 configuration to a PC connected to the **CRAFT** port using XMODEM protocol or to a file on a TFTP server using the TFTP protocol. See *DLP-007, Upgrading the Firmware Using XMODEM* and *DLP-008, Upgrading the Firmware Using TFTP* for details.

CONFIG TRANSFER also lets you save the Total Access 600 configuration as a backup file, so you can use the same configuration with multiple Total Access 600 units. In addition, **CONFIG TRANSFER** can retrieve a configuration file from a TFTP server.

To support these transfers, ADTRAN delivers a TFTP program with the Total Access 600 called *TFTP Server*. You can configure any PC running Microsoft Windows with this software, and store a configuration file.



*Before using **CONFIG TRANSFER**, the Total Access 600 should have a valid IP address, subnet mask, and default gateway (if required).*

Only one configuration transfer session (upload or download) can be active at a time.

Transfer Method

Displays the method used to transfer the configuration file to or from a server. XMODEM and TFTP are supported.

Transfer Type

Only **BINARY** transfers are currently supported.

TFTP Server IP Address

Specifies the IP address of the TFTP server. Get this number from your system administrator.

TFTP Server Filename

Defines the name of the configuration file that you transfer to or retrieve from the TFTP server. The default name is **ta600.cfg**, but you can edit this name.

Current Transfer Status

Indicates the current status of the update.

Previous Transfer Status

Indicates the status of the previous update.

Load and Use Config

Retrieves the configuration file specified in the **TFTP SERVER FILENAME** field from the server. To start this command, enter **Y** to begin or enter **N** to cancel.



If you execute this command, the Total Access 600 retrieves the configuration file, reboots, then restarts using the new configuration.

Save Config Remotely

Saves the configuration file specified in **TFTP SERVER FILENAME** to the server identified in **TFTP SERVER IP ADDRESS**. To start this command, enter **Y** to begin or enter **N** to cancel.



*Before using this command, you must have identified a valid TFTP server in **TFTP SERVER IP ADDRESS**.*

>Ping

Allows you to send pings (ICMP requests) to hosts. The following items are under this menu:



Only one ping session can be active at a time.

Start/Stop

Activator to start and cancel a ping test.

Host Address

IP address or domain name (if DNS is configured) of device to receive the ping.

Size (40-1500)

Total size of the ping to send. Range is 40 to 1500 bytes. 64 is default.

of Packets

Total packets to send every 2 seconds. Setting this to **0** allows the client to ping continuously.

Transmits

Total packets sent (read only).

Receives

Total packets received (read only).

%Loss

Percentage loss based on ping returned from host (read only).

Configuring WAN Settings**>DSLAM Type**

Set this to the type of DSLAM the Total Access 600 will be connecting to.

>Layer One Interface

This is the physical layer protocol used to connect the DSLAM to the Total Access 600.

>Layer Two Protocol

This is the data link layer protocol used to connect the DSLAM to the Total Access 600.

>ATM Config

Use the **WAN** menu (Figure 6) to access the **ATM CONFIG** menu.




Figure 6. WAN Menu

Use the **ATM CONFIG** menu (Figure 7) to set the parameters listed below the figure.



Figure 7. ATM Config Menu

Idle Cells

The **IDLE CELLS** format must be configured for either **ATM FORUM** or **ITU**. Configuring this setting incorrectly for a particular circuit will cause poor performance at the ATM layer.



This setting must match the configuration setting of the ATM switch or DSLAM at the other end of the circuit.

Data Scrambling

DATA SCRAMBLING can be **ENABLED** or **DISABLED** for cell traffic. Configuring this setting incorrectly for a particular circuit will cause poor performance.



This setting must match the configuration setting of the ATM switch or DSLAM at the other end of the circuit.

>ATM Stats

Use the **WAN** menu (Figure 6 on page 312) to access the **ATM STATS** menu (Figure 8) and view the parameters listed below the figure.

TA 608 TAD/MAN/ATM Stats		
ATM Config	AP: TxCells	0
ATM Stats	AP: RxCells	0
	AP: RxOAMCells	0
	AP: ReceiveCellsDiscarded	0
	AP: ReceiveCellErrors	0
	AP: Sync	Inactive
	AP: OutOfCellDelineation	0
	AAL5: TransmitFrames	0
	AAL5: ReceiveFrames	0
	AAL5: TransmitDiscardedFrames	0
	AAL5: ReceiveErrors	0
	AAL5: ReceiveDiscardedFrames	0
	AAL5: NoAtmFrames	0
	AAL5: NoDataPackets	0
	Clear Stats	<+>
MODE: SHDSL TAD		
Net: down ^Z=help 0:10		

Figure 8. ATM Stats Menu

AP: Tx Cells

This is the number of cells transmitted.

AP: Rx Cells

This is the number of cells received.

AP: Rx OAM Cells

This is the number of OAM cells received

AP: Receive Cells Discarded

This is the number of cells received and discarded. An incrementing count in this field could indicate a configuration problem with the ATM layer.

AP: Receive Cell Errors

This is the number of cells received with an HEC error.

AP: Sync

This indicates cell delineation at the ATM layer.

AP: Out Of Cell Delineation

This indicates loss of cell delineation at the ATM layer.

AAL5: Transmit Frames

This is the number of AAL5 frames transmitted.

AAL5: Receive Frames

This is the number of AAL5 frames received.

AAL5: Transmit Discarded Frames

This is the number of AAL5 frames discarded.

AAL5: Receive Errors

This is the number of AAL5 errors received.

AAL5: Receive Discarded Frames

This is the number of AAL5 frames discarded.

AAL5: No ATM Frames

This is for internal use only.

AAL5: No Data Packets

This is for internal use only.

Clear Stats

This is used to clear the counters on this menu screen.

Configuring the Router – Configuration

Use the **ROUTER/CONFIGURATION** menu (Figure 9) to access the **GLOBAL**, **ETHERNET**, and **WAN** menus.




Figure 9. Router/Configuration Menu

>Global

Use the **GLOBAL** menu (Figure 10) to set up general router functions.




Figure 10. Global Menu

IP

This is used for general IP configuration.

Mode

This item controls how the Total Access 600 handles IP routes. When this option is set to **ON** (def), the Total Access 600 will advertise and listen to routes from other IP routers. If **OFF**, the route table is still used, but only static routes are used for routing IP packets and only the Ethernet port is used. IP packets can be sent over the WAN, but only when bridged.

Static Routes

Use this menu to enter static routes to other networks.

ACTIVE	Adds this static route entry to the IP routing table when set to YES and removes it (if it was previously added) if set to No (def).
IP ADDRESS	The IP address of the host or network address of the device being routed to.
SUBNET MASK	Determines the bits in the previous IP address that are used. <i>If this is to be a host route, it must be set to all ones (255.255.255.255).</i>
GATEWAY	The IP address of the router to receive the forwarded IP packet.
HOPS	The number of router hops required to get to the network or host. Maximum distance is 15 hops.
PRIVATE	When set to No , the Total Access 600 will advertise this static route using RIP. Setting to YES means that the route is kept private.

DHCP Server

DHCP MODE	When set to ON , the Total Access 600 acts as a DHCP server and will dynamically assign IP, network mask, default gateway, and DNS addresses to any device which transmits a broadcast DHCP request. The addresses assigned are based on the Total Access 600's own IP address and will be within the same network.
DHCP RENEWAL TIME	The number of hours that the DHCP server should allow the device before it is required to send a new DHCP request. The default is 15 hours, and 0 represents an infinite lease.

Domain Names

Enter the Total Access 600's domain name and the primary and secondary DNS servers in this menu.

DOMAIN NAME	Text string used to represent the domain name used by the Total Access 600.
PRIMARY DNS	First server to which domain name requests are sent.
SECONDARY DNS	Server used as a backup, in case the primary address does not respond to the request.
PRIMARY NBNS/WINS	Server to which NT domain name requests are sent.
SECONDARY NBNS/WINS	Server used when there is no response from the primary server.

UDP Relay

This menu configures the Total Access 600 to act as a UDP relay agent for applications requiring a response from UDP hosts that are not on the same network segment as their clients.

Mode

When this option is set to **ON**, the Total Access 600 will act as a relay agent.

UDP Relay List

Up to four relay destination servers can be specified in this list.

RELAY ADDRESS	This is the IP address of the server that will receive the relay packet.
UDP PORT TYPE	
STANDARD (def)	The following standard UDP protocols are relayed when set: DHCP, TFTP, DNS, NTP (Network Time Protocol, port 123, NBNS (NetBios Name Server, port 137), NBDG (NetBIOS Datagram, port 138), and BootP.
SPECIFIED	When set, the UDP port (1 to 65535) can be specified in the UDP Port columns (up to three per server).
UDP PORT 1, 2, 3	Used for specifying UDP ports to be relayed. These fields only apply when UDP PORT TYPE is set to SPECIFIED .

Bridge

The **BRIDGE** menu is used to set up the bridge parameters for the Total Access 600. The bridging function runs at the Media Access Control (MAC) level which allows any protocol packets that run over Ethernet to be forwarded. Bridging can run concurrently with IP. However, when IP routing is active, IP packets (which include ARP packets) are not bridged.

Mode

This is used to enable the bridge function.

Address Table

The Total Access 600 automatically maintains a table of MAC addresses detected and associates those addresses with the LAN or WAN port from which they were received.

AGING	The maximum time an idle MAC address remains in the table before being removed. The value is in minutes.
FORWARD POLICY	When this parameter is set to UNKNOWN (def), any bridge packet with a destination MAC address that is not in the bridge table is forwarded to all other ports. When set to KNOWN , the packet with the unknown destination MAC address is dropped and is not forwarded.

Security

Filter Defines

The Total Access 600 can filter packets based on certain parameters within the packet. The method used by the Total Access 600 allows the highest flexibility for defining filters and assigning them to a PVC. The filters are set up in two steps: (1) defining the packet types, and (2) adding them to a list under the PVC. This menu is used to define the individual filter defines based on packet type.

Filter Defines /MAC Filter Defines

The MAC filter is applied to bridge packets only. Bridge packets which are forwarded by the bridge functionality of the Total Access 600 are defined here. Up to 32 MAC defines can be specified.

NAME	Identifies the filter entry.
SRC ADDR	48-bit MAC source address used for comparison. (hexadecimal format)
SRC MASK	Bits in the MAC source address which are compared. (hexadecimal format)
DEST ADDR	48-bit MAC destination address used for comparison. (hexadecimal format)
DEST MASK	Bits in the MAC destination address used for comparison. (hexadecimal format)
MAC TYPE	16-bit MAC type field used for comparison. (hexadecimal format)
TYPE MSK	Bits in the MAC type field used for comparison. (hexadecimal format)

Filter Defines /Pattern Filter Defines

The pattern filter is applied to bridge packets only. That is any packet which is forwarded by the bridge functionality of the Total Access 600. Up to 32 pattern defines can be specified.

NAME	Identifies the filter entry.
OFFSET	Offset from beginning of packet of where to start the pattern comparison.
PATTERN	64 bits used for comparison. (hexadecimal format)
MASK	Bits in the pattern to be compared. (hexadecimal format)

Filter Defines /IP Filter Defines

The IP filter defines apply to any IP packet, whether it is routed or bridged. Up to 32 IP defines can be specified.

NAME	Identifies the filter entry.
IP SRC	IP address compared to the source address. (dotted decimal format)

SRC MASK	Bits which are used in the source comparison. (dotted decimal format)
IP DEST	IP address compared to the destination address. (dotted decimal format)
DEST MASK	Bits which are used in the destination comparison. (dotted decimal format)
SRC PORT	IP source port number used for comparison Range: 0 to 65535. (decimal format)
SRC PORT CMPR	Type of comparison that is performed. = means ports equal to not = means port not equal to > means port greater than < means port less than None - means the source port is not compared
DST PORT	IP destination port number used for comparison Range: 0 to 65535. (decimal format)
DST PORT CMPR	Type of comparison that is performed = means ports equal to not = means port not equal to > means port greater than < means port less than None - means the destination port is not compared
PROTO	Protocol used for comparison. Range: 0 to 255. (decimal format)
PROTO CMPR	Type of comparison that is performed = means protocols equal to not = means protocols not equal to > means protocols greater than < means protocols less than None means the protocol is not compared
TCP EST	Yes - only when TCP established

No - only when TCP not established

Ignore - ignore TCP flags

>Ethernet

Use the **ETHERNET** menu (Figure 11) to configure the Ethernet port on the Total Access 600.




Figure 11. Ethernet Menu

IP

This is used to set up the IP addresses for the LAN on the Total Access 600.

IP Address

The IP address assigned to the Total Access 600's Ethernet port is set here. This address must be unique within the network.

Subnet Mask

This is the IP network mask that is to be applied to the Total Access 600's Ethernet port.

Default Gateway

The default gateway is used by the Total Access 600 to send IP packets whose destination address is not found in the route table.

RIP

Use this menu to enable RIP on the LAN interface.

MODE	Enables or disables RIP.
PROTOCOL	Specifies the RIP protocol. Choices are V1 (def) (which is RIP version 1) or V2 (RIP version 2).
METHOD	Specifies the way the RIP protocol sends out its advertisements. Choices are given below.
NONE	All routes in the router table are advertised with no modification of the metrics.
SPLIT HORIZON	Only routes not learned from this circuit are advertised.
POISON REVERSE (def)	All routes are advertised, but the routes learned from this port are "poisoned" with an infinite metric.
DIRECTION	Allows the direction at which RIP advertisements are sent and listened to be specified.
TX AND RX (def)	RIP advertisements are periodically transmitted and are listened to on this port.
TX ONLY	RIP advertisements are periodically transmitted but are not listened to on this port.
RX ONLY	RIP advertisements are not transmitted on this port, but are listened.
V2 SECRET	Enter the secret used by RIP version 2 here.

Proxy ARP

This feature allows the network portion of a group of addresses to be shared among several physical network segments. The ARP protocol provides a way for devices to create a mapping between physical addresses and logical IP addresses. Proxy ARP makes use of this mapping feature by instructing a router to answer ARP requests as a "proxy" for the IP addresses behind one of its ports. The device which sent the ARP request will then correctly assume that it can reach the requested IP address by sending packets to the physical address that was returned. This technique effectively hides the fact that a network has been (further) subnetted. If this option is set to **YES**, when an ARP request is received on the Ethernet port the address is looked up in the IP routing table. If the forwarding port is not on the Ethernet port and the route is not the default route, the Total Access 600 will answer the request with its own hardware address.

MAC Address

This is a read-only MAC address programmed at ADTRAN.

>WAN

Use the **WAN** menu (Figure 12) to configure WAN settings on the Total Access 600.



Figure 12. WAN Menu

L2 Protocol

Displays the current L2 protocol - ATM (Read Only).

ATM

Use the ATM menu to setup Data PVCs for the router.

Description

This is the text description for the PVC.

VPI

ATM virtual port identifier.

VCI

This is the ATM virtual channel identifier.

PCR (Peak Cell Rate)

Limits transmitted cells.

QOS (Quality of Service)

Indicates this PVC's traffic class.

Protocol

This is the protocol supported on the PVC.

RFC1483 IP

Use this selection to support IP on this PVC. (These settings only take effect when RFC1483 is the selected protocol.)

Active

This selection enables IP on this PVC.

Far - End IP Address

This is the address of the NEXT hop router on this interface.

IP netmask

This is the network mask used for this interface.

Local IP Address

This is the IP address for this PVC.

NAT

Use this menu to set up and use Network Address Translation on this interface.

NETWORK ADDRESS PORT TRANSLATION	By enabling port translation, IP packets are modified as they pass through this interface. During transmission, private addresses are translated into a single public (NAPT) IP address. Incoming packets are translated from the public to private address based on the protocol port numbers. Once enabled, you must set up NAT for use.
PUBLIC IP ADDRESS MODE	The port translation requires at least a single real IP address for translating. This value can use the IP assigned to the interface (or assigned via layer 2 protocol like PPP), obtained using DHCP client, or statically specified on this menu. If the address cannot be learned, then it must be specified in order for the translation to work.
TRANSLATION TABLE	Add translation entries to "fine tune" special protocols or specify private addresses.
PUBLIC ADDRESS MODE	The public IP address used for this translation entry can be the NAPT IP address assigned to the link or can be specified. You specify an address to direct packets with certain protocols to different servers.
PROTOCOL	The upper layer protocol that is to be monitored for translation. For TCP and UDP, a port number must also be specified.
PUBLIC PORT MODE	The public destination port associated with this entry can be specified to add more control over certain types of traffic. The default, ANY PORT , covers all port types.

PRIVATE ADDRESS MODE	The private IP address can be specified to steer certain protocols and ports to specific servers in the private network. Likewise, internal hosts can be steered to certain servers on the public network. A new request from the public network matching this entry's public parameters will be dropped if this mode is set to ANY INTERNAL .
PRIVATE PORT MODE	The private destination port associated with this entry can be specified to add more control over certain types of traffic. Leave as ANY PORT to cover all port types.
TRANSLATE BODY	By default, the application payload in the packet is scanned for occurrences of the private/public IP address in binary or ASCII form. Set this to No for applications where this will cause problems.
NAT VIEW	Shows the protocols that are actively being translated.
NAPT ADDRESS	Represents the public address that is being used as the NAPT address.
ENTRY COUNT	The number of entries in the NAT table.
ENTRY OVERFLOW COUNT	A count of the dropped entries due to low memory.

RIP

Use this menu to enable RIP on the WAN interface. (See *RIP* on page 322 for description of options.)

RFC 1483 Bridge

This is used to enable bridge mode on this PVC. (These settings only take effect when RFC 1483 is the selected protocol.)

PPPoATM

The Total Access 600 uses the PPPoATM profile to specify the profile used when connected using PPP.

Authentication

The authentication menu contains the required parameters for the authentication of the PPP peer and for being authenticated by the PPP peer. Authentication is applied between the Total Access 600 and the PPP peer as follows:

TX Method

This parameter specifies how the Total Access 600 is to be authenticated by the PPP peer. There are four possible selections.

NONE (def)	The connection will not allow the PPP peer to authenticate it.
PAP, CHAP, OR EAP	The connection can be authenticated using PAP, CHAP or EAP.
CHAP OR EAP	The connection can be authenticated using CHAP or EAP only.
EAP	The connection will only allow authentication by the peer using EAP.

TX Username

This is the username that is used when being authenticated by the PPP peer.

TX Password

This is the password or secret that is used when being authenticated by the PPP peer.

RX Username

This is the username used to authenticate the PPP peer.

RX Password

This is the password or secret that is used to authenticate the PPP peer.

IP

The IP menu contains the parameters for exchanging IP data with the PPP peer.

Mode

Setting to **ON** (def) will permit this connection profile to negotiate PPP IPCP with the PPP peer for exchanging of IP packets.

Local IP

This is the IP address that is assigned to the PPP link when using numbered links. Leaving this as 0.0.0.0 means the Total Access 600 will determine its IP address using PPP IPCP. If the far end router does not assign an IP address, the PPP link is left unnumbered.

Netmask

This network mask is applied to the IP/Local IP address for determining the PPP peer's network. If left as 0.0.0.0, a standard network mask is used.

Remote IP

The PPP peer's IP address or network can be set here, if known. Leaving this at 0.0.0.0 means that the Total Access 600 will determine the PPP peer's IP and network using the PPP IPCP.

NAT

The Total Access 600 can perform Network Address Translation. This feature is most widely used when connecting to the Internet. The Ethernet network can consist of private network numbers. When this profile is connected, all IP addresses on the Ethernet side are translated into the one real IP address negotiated with the PPP peer (ISP). Multiple stations on the Ethernet side can access the Internet simultaneously. Setting this option to **ON** will cause the Total Access 600 to perform NAT. In the **OFF** (def) position, the unit will route across the connection normally.

Route

The IP parameters are configured in this menu. Usually the Total Access 600 will automatically discover the PPP peer's networks using PPP IPCP and/or RIP.

- **Route/Static Route**

Selecting yes will add a static route to the remote peer to the route table.

- **Route/Private**

Selecting yes will prevent this route from being advertised.

- **Route/Hops (1-16)**

This value is the metric or number of hops that RIP will use in advertising the static route. The range is 1 to 16, where 1 is the default. The value 16 is considered an infinite distance (poisoned route).

- **Route/Force IP**

When set to **YES**, the Total Access 600 will force the PPP peer to use the IP address in the **LOCAL IP** for this profile as its WAN IP address. Normally this is set in the **No** (def) position.

RIP

The RIP parameters can be adjusted from their defaults under this menu.

- **Mode**

The Total Access 600 performs RIP over the WAN connection when this is set to **ON** (def).

- **Protocol**

The Total Access 600 performs version 1, **V1** (def), or version 2, **V2**, of RIP on this WAN connection.

- **Method**

SPLIT HORIZON	Only routes not learned on the WAN connection are advertised.
POISON REVERSE (def)	All routes are advertised, including routes learned from the WAN connection. These routes are poisoned.
NONE	All routes are advertised, including routes learned from the WAN connection. No attempt is made to poison these routes.

- **Direction**

TX AND RX (def)	RIP advertisements are transmitted and listened to on the WAN connection.
TX ONLY	RIP advertisements are transmitted and not listened to.
RX ONLY	RIP advertisements are listened to but not transmitted.

- **Triggered**

When set to **YES**, only IP RIP updates are sent when the routing table has changed and learned routes are not "aged." When set to **No** (def), updates are sent periodically.

- **Retain**

When this Connection List entry is disconnected and this parameter is set to **YES**, all routes learned from this WAN connection are retained and their routing interface is set to idle.

PPP

The Total Access 600 supports the IETF standards for the Point-to-Point Protocol. The PPP state machine running in the Total Access 600 can be fine-tuned to support many applications that can be employed. The configurable items under this menu can be changed from their default values for special cases.

VJ Compression

When this item is set to **ON**, the Total Access 600 will perform TCP/IP header compression known as Van Jacobson compression to the PPP peer.

Max Config

This value is the number of unanswered configuration-requests that should be transmitted before giving up on a call. The possible values are 5, 10 (def), 15 and 20.

Max Timer

This value is the number of seconds to wait between unanswered configuration requests. The possible values are 1 sec, 2 secs (def), 3 secs, 5 secs and 10 secs.

Max Failure

Due to the nature of PPP, configuration options may not be agreed upon between two PPP peers. This value is the number of configuration-naks that should occur before an option is configuration-rejected. This allows a connection to succeed that might otherwise fail. The possible values are 5 (def), 10, 15 and 20.

Encapsulation

This is the PPP encapsulation. (LLC or VC-Mux)

Filters

The Total Access 600 can block packets in and out of a WAN port by use of the filters. They are set up in two steps: 1) define the types of packets that would be of interest in the **CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES** menu, and 2) set up the filter type and combination of defines that will cause a packet block.

WAN-TO-LAN (In)

The packets which come into the Total Access 600 can be filtered in three ways:

DISABLED (def)	Turns off packet input filtering. No incoming packets are blocked.
BLOCK ALL	All incoming packets from the WAN are blocked except as defined in the FILTERS/IN EXCEPTIONS list.
FORWARD ALL	All incoming packets from the WAN are not blocked except as defined in the FILTERS/IN EXCEPTIONS list.

In Exceptions

This is a list of up to 32 filter entries which can be combined using the operations field. The operations are performed in the order they appear on the list.

ACTIVE	Turns this entry active when set to ON .
TYPE	Selects the filter define list to reference:
MAC	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/MAC FILTER DEFINES list.
PATTERN	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/PATTERN FILTER DEFINES list.
IP	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/IP FILTER DEFINES list.
IPX	from the CONFIGURATION/GLOBAL/SECURITY/FILTER DEFINES/IPX FILTER DEFINES list.
FILTER LIST NAME	Selects between filters defined in the list.

NEXT OPER	The next operation to use to combine with the next filter in the list:
END	the last filter to combination.
AND	logically AND this filter with the next filter in the list.
OR	logically OR this filter with the next filter in the list.

LAN-TO-WAN (Out)

The packets which come out toward the WAN from the TA600 can be filtered in three ways:

DISABLED (def)	Turns off packet input filtering. No outgoing packets are blocked.
BLOCK ALL	All outgoing packets to the WAN are blocked except as defined in the FILTERS/OUT EXCEPTIONS list.
FORWARD ALL	All outgoing packets to the WAN are not blocked except as defined in the FILTERS/OUT EXCEPTIONS list.

Out Exceptions

This is a list of up to 32 filter entries. The setup is exactly the same as the **FILTERS/IN EXCEPTIONS** list.

Configuring the Router – Status

Use the **ROUTER/STATUS** menu to view and set the parameters shown in Figure 13. The **ROUTER/STATUS** screens give the user useful information for debugging the current routes in the Total Access 600.




Figure 13. Router/Status Menu

>Session

This menu maintains statistics about the active ATM PVCs.

>ARP cache

This is a listing of the currently connected Ethernet port on the LAN.

>Bridge Table

This shows the detected MAC addresses and the interface to which they are associated.

>IP Routes

This shows the current routes in the Total Access 600 and their use.

>LAN Stats

This shows traffic over the LAN interface.

>IP Stats

This shows IP traffic through the Total Access 600.

Configuring the Router – Logs

The Logs menu (Figure 14) contains logs displaying important information about the running condition of the Total Access 600. The logs can be set to capture diagnostics of error conditions only by way of a log level. The levels are divided up as follows:

- level 0 - Fatal event (causes reset)
- level 1 - Critical event
- level 2 - Error event
- level 3 - Warning event
- level 4 - Notify event
- level 5 - Informational event
- level 6 - Debugging event




Figure 14. Router/Logs Menu

Sys log Host

Set this to the IP address or domain name (if DNS configured) of the sys log host device. All log events are sent to this device.

PPP Log

Information pertaining to the PPP negotiation and authentication is logged in the PPP log.

Connection Log

Information pertaining to the call placement and answering is logged in the Connection log.

Network Log

Information pertaining to routing protocols is placed in this log.

Each log (PPP log, Connection log, and Network log) contains the following elements.

Active

When set to **YES** (def), PPP events below or equal the log level are logged into the log.

Wrap

When set to **YES** (def), new PPP events will overwrite old PPP events when the log is full. All logging will stop when the log is full and set to **NO**.

Level

In order to log events, they must be at or below this level. Range is 0 to 6. The default is 3.

View

This menu displays the log list. The fields are as follows:

DATE/TIME	Date and time event occurred.
LEVEL	Level associated with this event (0-6).
MESSAGE	Text message for this event. If message is too long to fit on the line, another event appears below it continuing the message.

Clear

This clears the log when activated.

Configuring Voice Support – Config

Use the **VOICE/CONFIG** menu to view and set the parameters shown in Figure 15.

TA 608	TA0/Voice/Config	
Config	Call Control	None
Status	VPI	0
	VCI	39
MODE: SHDSL TA0		
		NE1: down
		*Z=help 0:07

Figure 15. Voice/Config Menu

>Call Control

The **CALL CONTROL** setting is used to configure the correct Voice Gateway protocol for voice signaling control between the Total Access 600 and the configured Gateway. The **CALL CONTROL** setting must be configured correctly before the voice circuits will work correctly. The Total Access 600 supports Jetstream, Tollbridge, and CopperCom Voice Gateways.

>VPI

The **VPI** setting is used to configure the Total Access 600 virtual path setting used to communicate with the configured Voice Gateway.

>VCI

The **VCI** setting is used to configure the Total Access 600 virtual circuit setting used to communicate with the configured Voice Gateway.

Configuring Voice Support – Status

Use the **VOICE/STATUS** menu to view and set the parameters shown in Figure 16.




Figure 16. Voice/Status Menu

>Gateway Stats

The **GATEWAY STATS** menu shows the current state of the communication link between the Total Access 600 and the Voice Gateway. The Gateway Link is indicated as **UP** or **DOWN**. A count of management messages is indicated along with the number of active calls in progress.

>PVC Stats

The **PVC STATS** menu shows the current state of the virtual circuit used between the Voice Gateway and the Total Access 600 IAD for voice signaling and voice payload delivery.

>POTS Stats

The **POTS STATS** menu shows real-time indication status of each voice port on the Total Access 600. From this menu, on a per port basis, the user can determine which ports are active/inactive. Several statistics at this menu are used only for internal ADTRAN development. Task, Inserts, and Drops indicators are for internal use only.

>Clear Stats

The **CLEAR STATS** menu can be used to clear the counters used for Voice Status menus.

Managing the Modules – Modules

Use the **MODULES** menu to view and set the parameters shown in Figure 17. The Total Access 600 contains four fixed modules: The WAN/Network interface, FXS, Echo Canceller/ADPCM module, and the V.35 interface. The **MODULES** table allows management of the on-board modules in the Total Access 600.

This menu contains **MENU**, **ALARM**, **TEST**, and **STATUS** indicators/menus customized for each module.

TA 608 TAD/Modules/Modules						
Modules	Slot	Type	Menu	Alarm	Test	Status
0.35 Setup	0	NET (SHDSL)	[+]	[n/a]	[+]	[+]
	1	FXS	[+]	[n/a]	[+]	[+]
	2	EC/ADPCM	[+]	-	-	-

Mod: SHDSL TAD	Net: down
Access module menus	^Z=help 0:09

Figure 17. Modules Menu

>NET (SHDSL)

Menu

Data Rate

Used to select data rate of the network connection. (This should match the DSLAM settings.)

Frame Mode

Used to select either SDSL Framed (def) or SDSL Framed Plesiosynchronous with bit stuffing. (This should match the DSLAM settings.)

Annex A/B

Used to select **ANNEX A**, **ANNEX B**, or both.

ITU-991.2/Gspan

Chooses between **ITU-T 991.2** or **GLOBESPAN V1.2**.

Test

These tests are meant for debug purposes only. A reboot may be required to return the Total Access 600 to normal operation.

Network Loopback

Sets the network interface in loopback mode.

Send/Check 2047

Sends and checks a 2047 BERT pattern over the network interface (assuming LTU in loopback). Results of the test can be found in Test Results.

Send/Check ALT

Sends and checks an alternating pattern over the network interface (assuming LTU in loopback). Results of the test can be found in Test Results.

Status**Signal State**

Internal ADTRAN use.

Data Rate

Rate at which the WAN has connected.

Frame Mode

Framing mode.

G.hs State

Internal ADTRAN use.

G.hs Event

Internal ADTRAN use.

>FXS

Refer to Section 4.7, *FXS User Interface Guide*.

>EC/ADPCM

Refer to Section 4.7, *FXS User Interface Guide*.

Managing the Modules – V.35 Setup

Use the **V.35 SETUP** menu to view and set the parameters shown in Figure 18.



Figure 18. V.35 Setup Menu

CHANNEL RATE and **EIA** settings are supported via this menu option. For all typical applications, these settings are left in their default states.

>ATM/FR IWF

This menu contains the setup and status for the ATM/Frame Relay interworking functions.

Mode

The **MODE** setting configures the V.35 port for FRF5 or FRF8 operation, depending upon the application being supported.

FRF5

This is also known as Network Interworking. Use this mode for Frame Relay over ATM.

FRF8

This is also known as Service Interworking. In this mode, the Total Access 600 performs a translation between Frame Relay and ATM protocols.

Configuration

The **CONFIGURATION** menu is used to support the configuration of Frame-to-ATM interworking, signaling formats, timeout values, and PVC settings.

The following settings are used for FRF5.

LAN FR MAINT PROTOCOL	Frame Relay maintenance or signaling protocol between local V.35 port and the attached DTE port, support ANSI Annex A, CCITT Q933 Annex D, CISCO LMI or Static (no signaling).
LAN FR POLL TIMEOUT T392 (5-30)	T392 for signaling protocol, typical value 15. No meaning if Maint Protocol is Static.
FRN PORT CONFIG	Logical Frame Relay ports over ATM. Up to 4 ports are supported with each port supporting up to 4 DLCI mappings. Go to NUM field. Typing "i" or "I" will insert another entry, and typing "d" or "D" will delete one entry.
NAME	To identify your port.
ATM VPI	Specifies the virtual path over which this logical port is running.
ATM VCI	Specifies the virtual circuit over which this logical port is running.
DE MAP	Frame Relay to ATM DE mapping; default value (Frn Only, ATM 0) suggested.
CLPI MAP	ATM to Frame Relay CLPI map; default value (Frn Only) suggested.
D/C	Set D/C field in the header to 0 or 1.
HEADER	Header format; only 2 bytes supported now.
MAINT PROTOCOL	Maintenance or signaling protocol over this logical Frame Relay port. Support Annex A, Annex D, CISCO LMI or Static.
MUX MODE	Many DLCIs or one DLCI mapping over this port.
DLCI MAP	Actual DLCI mappings.
LAN DLCI	The DLCI configured over local V.35 Frame Relay port.
NET DLCI	The DLCI configured over the WAN side logical Frame Relay port.
ACTIVE	Always active, not configurable.

The following settings are used for FRF8.

LAN FR MAINT PROTOCOL	Frame Relay maintenance or signaling protocol between local V.35 port and the attached DTE port, support ANSI Annex A, CCITT Q933 Annex D, CISCO LMI or Static (no signaling).
LAN FR POLL TIMEOUT T392 (5-30)	T392 for signaling protocol, typical value 15. No meaning if Maint Protocol is Static.
FR/ATM PVC MAPPING	Up to 4 mappings are supported.
FR DLCI	Frame Relay DLCI on V.35 port.
ATM VPI	Specifies the virtual path to which DLCI is mapped.
ATM VCI	Specifies the virtual circuit to which DLCI is mapped.
TRANSLATE	Translate or transparent mode between Frame Relay frames and ATM cells.
DE MAP	Map Frame Relay DE bit to ATM CLPI bit, Always 0, Always 1 or Convert each other.
FECN MAP	Map Frame Relay FECN bit to ATM EFCI bit, Always 0, Always 1 or Convert each other.

Appendix A. Voice Gateway Quick Start Procedure (Voice Turn up)

A typical VoATM application (see Figure 19) uses a Total Access 600 connected to an ATM network. For voice applications, a Voice Gateway is needed to interface with the PSTN. Jetstream, Tollbridge, and CopperCom are popular Gateway types.




Figure 19. Application Diagram

To configure a Total Access 600 for use with the Voice Gateway, you need to know the VPI and VCI to be used on the ATM network. You also need to know the format for Idle Cells and whether Data Scrambling is used on this ATM network. The following procedure will help you navigate the Total Access 600 menus for configuring the necessary elements for VoATM with the Voice Gateway.

Voice Turn Up	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. Select DSLAM TYPE and select the name of the DSLAM type you are using. (At this point you need to back out of the menu to save the changes. The unit will need to reboot if it was not previously configured for this DSLAM type.)
2.	Select DSL RATE CONFIG (BIT RATE) and change the setting to match that in your DSLAM. (If this field is read-only, allow a few seconds for autobaud to expire and the field will change to writeable.)
3.	Select WAN , and then select the ATM CONFIG menu.
4.	Enter the IDLE CELLS format for your network.
5.	Set DATA SCRAMBLING appropriately for your network.
6.	Back all the way out to the top level Total Access 600 menu, and then select the VOICE menu. (From this menu, the appropriate Voice information for working with the Voice Gateway is entered.)
7.	Select CONFIG , and from the CONFIG menu, enter the Gateway type under CALL CONTROL and enter the VPI and VCI values for communicating with that Gateway. CALL CONTROL should be set to the Gateway type, and the VPI and VCI values should be set appropriately for your network.
8.	To verify correct setup, use the STATUS menu (under the VOICE menu) to look at the current status of the voice connection. Under STATUS , you can view the GATEWAY STATS and information about the voice PVC along with information about the POTs ports available on the Gateway. The GATEWAY STATS menu should show the Gateway Link is up (if everything is configured correctly). A visual inspection of the VOICE LED on the front panel will also yield the status. Green = Up. Red = Down.

Appendix B. RFC1483 Quick Start (IP Routing)

The Total Access 600 allows for complete integration of voice and data delivery from one compact platform (see Figure 20). Once you have completed the voice turn up procedure from the previous example, adding data to the circuit requires some additional setup.




Figure 20. Application Diagram

To configure a Total Access 600 for IP routing, you need to know the VPI and VCI values for the data circuit on your network. You also need the IP address of the next hop router in the circuit.

The table on the next page shows how to configure the Total Access 600 for IP Routing.

..

IP Routing	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. (Here you set up the ATM network.)
2.	Select the ATM CONFIG menu.
3.	Enter the IDLE CELLS format for your network.
4.	Set DATA SCRAMBLING appropriately for your network.
5.	Back all the way out to the top level Total Access 600 menu, and then select the ROUTER menu.

IP Routing	
6.	Select CONFIGURATION . From the CONFIGURATION menu, you will set up addresses for your LAN and WAN. For basic IP routing, use all the default values from the GLOBAL menu.
7.	From the ETHERNET menu, enter the IP menu to enter your LAN configuration.
8.	Enter your LAN IP ADDRESS , SUBNET MASK , and DEFAULT GATEWAY information. For this example, the IP ADDRESS is 192.168.1.2, the SUBNET MASK is 255.255.255.0, and the DEFAULT GATEWAY is 10.25.4.10.
9.	Arrow back to the main ROUTER CONFIGURATION menu, and select the WAN menu and then the ATM menu. (Here you will enter your data PVC information.)
10.	Create a new PVC by entering the menu. Enter your VPI and VCI values.
11.	From the RFC1483 IP menu, enter your LAN information. For this example, the FAR END IP ADDRESS is 10.25.4.9, the IP NETMASK is 255.255.255.252, and the LOCAL IP ADDRESS is 10.25.4.10.
12.	Arrow back to the top level Total Access 600 menu to activate your changes.

Appendix C. RFC1483 Quick Start (IP Routing with NAT)

To illustrate the use of NAT, consider the example from Appendix B. To set up a single public address that will be used to access the public network, you will use the **NAT** menu on the **WAN/ATM/RFC1483 IP** menu.

IP Routing with NAT	
Step	Action
1.	From the NAT menu, set NETWORK ADDRESS PORT TRANSLATION to ENABLED . (This will enable translation and allow you to enter the NAT options.)
2.	Set PUBLIC IP ADDRESS MODE to SPECIFIED so you can enter your public address. During transmission, private addresses are translated into this public (NAPT) address.
3.	You will also need to set up the Translation Table to do translation on the body of the packets for certain protocols, such as FTP, to work correctly.
4.	From the TRANSLATION TABLE menu, create a new entry by arrowing into the table.
5.	For PUBLIC ADDRESS MODE , select NAPT ADDRESS to use the previously specified public address.
6.	For PROTOCOL , select TCP .
7.	Make sure that TRANSLATE BODY is set to YES .

Appendix D. RFC1483 Quick Start (Bridging)

The Total Access 600 allows for complete integration of voice and data delivery from one compact platform. Once you have completed the voice turn up procedure from the previous example, adding data to the circuit requires some additional setup.

To configure a Total Access 600 for Bridging, you need to know the VPI and VCI values for the data circuit on your network.

Bridging	
Step	Action
1.	From the Total Access 600 main menu, select the WAN menu. (Here you set up the ATM network.)
2.	Select the ATM CONFIG menu.
3.	Enter the IDLE CELLS format for your network.
4.	Set DATA SCRAMBLING appropriately for your network.
5.	Back all the way out to the top level Total Access 600 menu, and then select the ROUTER menu.
6.	Enter the CONFIGURATION menu. From this menu, you will set up addresses for your LAN and WAN. For basic IP routing, use all the default values from the GLOBAL menu.
7.	From the ETHERNET menu, enter the IP menu to enter your LAN configuration.
8.	Enter your LAN IP ADDRESS and SUBNET MASK . For this example, the IP ADDRESS is 192.168.1.2 and the SUBNET MASK is 255.255.255.0. This is not required, but will allow Telnet configuration and TFTP upgrades from the LAN.
9.	Arrow back to the main ROUTER CONFIGURATION menu, and select the WAN menu and then the ATM menu. (Here you will enter your data PVC information.)
10.	Create a new PVC by entering the menu. Enter your VPI and VCI values.
11.	Disable IP on the RFC1483 IP menu and enable Bridging on the RFC1483 BRIDGE menu. (This enables the Total Access 600 as a bridge.)
12.	Arrow back to the top level Total Access 600 menu to activate your changes. All packets that come in on the Ethernet will be forwarded on the WAN.

SECTION 4.7 FXS USER INTERFACE GUIDE

The FXS User Interface Guide is designed for use by network administrators and others who will configure and provision the system. It gives a general description, specifications, and a menu description for the Total Access 600 FXS Voice Ports. It is recommended that you review Section 4.1, Commons User Interface Guide in addition to this section.

CONTENTS

Total Access 600 FXS Voice Ports Overview	347
Functional Description.	347
Features	347
FXS Voice Ports Specifications	348
Wiring	348
Operation	349
LED Status	349
Methods of Operation	349
Terminal Menu Structure.	349
FXS Menu Options	350
Port.	351
Mode.	351
TX (dB)	351
RX (dB)	351
Svc Mode	351
Coding Type	351
Line Z	351
Ring V-rms	351
FXS Voice Ports Test Options	352
Port.	352
Test.	352
Test Status	352
FXS Voice Ports Status Options	352
Total Access 600 Features Used with FXS Options	352
Factory Restore	352
Echo Celler	352

1. TOTAL ACCESS 600 FXS VOICE PORTS OVERVIEW

The Total Access 600 comes complete with integrated FXS Voice ports. Each port provides an analog voice connection via any standard analog telephone. The last two digits of the product name indicate the number of on-board ports. The Total Access 604 contains four ports, the Total Access 608 contains eight ports, etc.

Functional Description

Because the FXS ports are located on-board, no installation is required. The **VOICE** indicator on the Total Access 600 front panel indicates off-hook status on any port by a flashing lamp. When all ports are on-hook, the lamp remains solid. Additional status information is available via the terminal menus, accessible through either a VT 100 terminal connected to the Total Access 600 **CRAFT** port or via a Telnet session established through the Ethernet port.



*See Section 2, Engineering Guidelines for the **CRAFT** port connection pin-out.*

Features

Features of the FXS include:

- 4,8,12,16 and 24 fixed port configurations
- μ -law encoding and decoding
- Loop start signaling
- Up to 1000 foot
- V.90 modem compliant
- Support for CLASS™ features such as Caller ID
- UL 60950 third edition compliant

2. FXS VOICE PORTS SPECIFICATIONS

The FXS conforms to the following specifications:

ELECTRICAL SPECIFICATIONS	
Loop Current	24 mA nominal 20 mA minimum
Terminating Impedance	600 ohm
Return Loss	600 ohm + 2.16 μ F, ERL > 28 dB, SRL > 20 dB
Trans Hybrid Loss	600 ohm + 2.16 μ F, ERL > 28 dB, SRL > 20 dB
Longitudinal Balance	200, 500, and 1000 Hz: > 58 dB min., > 63 dB avg. 3000 Hz: > 53 dB min., > 58 dB avg.
Frequency Response	300 to 3400 Hz: -0.5 and 1.0 dB
Idle Channel Noise	< 20 dBmC
Signal-to-Distortion Ratio	0 to -30 dBm0: > 33 dB -30 to -40 dBm0: > 27 dB

3. WIRING

A single 50-pin female amphenol connector on the rear of the Total Access 600 chassis provides the interconnect wiring for the four analog circuits on each access module. Figure 1 shows the pinout connection.




Figure 1. Connector Pin Assignments

4. OPERATION

Provisioning, status, and testing of the FXS ports are performed via the **MODULES** screen menus and a VT 100 terminal. The **VOICE** LED on the front panel provides quick status.

LED Status

After the initialization sequence, the **VOICE** LED provides collective status of the analog service.

Red	Voice Gateway or Network connection prevents analog service.
Green	Analog service is available.
Flashing	Off Hook (Busy)

Methods of Operation

You can control and configure the FXS from the terminal menus, allowing detailed configuration, status, and diagnostic. The remainder of this section describes the menu items presented when managing the Total Access 600 via the terminal menu.

Access the terminal menu using either a VT 100 terminal attached to the Total Access 600's **CRAFT** port or a Telnet session established through the unit's Ethernet port.

The factory default is no password.

Terminal Menu Structure

The Total Access 600 uses a hierarchical menu structure to provide access to all of its features. The top-most menu level leads to submenus which are grouped by functionality. All menu items display in the terminal window. To access the FXS, activate the **MODULES** menu.

From the **MODULES** menu, select the **FXS** menu, and then press **Enter** to access the features of the FXS ports.

FXS Menu Options



Some provisioning options are read-only fields. The Total Access 600 does not allow configuration of all FXS line variables.

Figures 2 and 3 show the menu options available for the FXS. (Figure 3 shows the menu options available when you scroll over by arrowing right.)

The pages following the figures describe these options.

TA 608 IAD/Modules/Modules[1]/Provisioning						
Provisioning	Port	Mode	Lx (dB)	Rx (dB)	Svc Mode	Coding type
Test	1	Loop Start	6.0	3.0	In Service	PCM (G.711)
Status	2	Loop Start	6.0	3.0	In Service	PCM (G.711)
	3	Loop Start	6.0	3.0	In Service	PCM (G.711)
	4	Loop Start	6.0	3.0	In Service	PCM (G.711)
	5	Loop Start	6.0	3.0	In Service	PCM (G.711)
	6	Loop Start	6.0	3.0	In Service	PCM (G.711)
	7	Loop Start	6.0	3.0	In Service	PCM (G.711)
	8	Loop Start	6.0	3.0	In Service	PCM (G.711)
MODE: Channelbank					NEL: down	
FXS Configuration Menu					^Z=help 0:46	

Figure 2. FXS Menu Options

TA 608 IAD/Modules/Modules[1]/Provisioning[1]/Ring U-rms						
Provisioning	Port	Svc Mode	Coding type	Line Z	Ring U-rms	
Test	1	In Service	PCM (G.711)	600 Ohms	550-rms	
Status	2	In Service	PCM (G.711)	600 Ohms	450-rms	
	3	In Service	PCM (G.711)	600 Ohms	450-rms	
	4	In Service	PCM (G.711)	600 Ohms	450-rms	
	5	In Service	PCM (G.711)	600 Ohms	450-rms	
	6	In Service	PCM (G.711)	600 Ohms	450-rms	
	7	In Service	PCM (G.711)	600 Ohms	450-rms	
	8	In Service	PCM (G.711)	600 Ohms	450-rms	
MODE: Channelbank					NEL: down *	
					^Z=help 0:37	

Figure 3. Additional FXS Menu Options

Port

Identifies the port involved.

Mode

Options are given below.

Loop Start

Sets the port to use FXS loop start signalling on the T-span and loop start supervision on the analog 2-wire interface.

TX (dB)

Indicates the Tx direction transmit level points. The transmission level is indicated in dBm.

RX (dB)

Indicates the Rx direction transmit level points. The transmission level is indicated in dBm.

Svc Mode

Indicates whether the ports are **IN SERVICE** or **OUT OF SVC**. This does not indicate whether the port has been mapped.

Coding Type

Indicates voice encoding type. **PCM** (G.711) indicates standard 8-bit sampling. **ADPCM** (G.721) indicates that 32 kbps compression is being used.



This option only appears in ATM code.

Line Z

Indicates the line impedance.

Ring V-rms

Controls the DC offset and voltage settings during the ring cycle. The following options are available: **45V-RMS (20V DC OFFSET)**, **55V-RMS (10V DC OFFSET)**, and **62V-RMS (NO DC OFFSET)**. Many analog phones work better with a DC offset. **45V-RMS** is the recommended and default setting for most scenarios.



This option is only available in the 604/608. The 612/616/624's have a ring voltage of 94 VAC.

FXS Voice Ports Test Options

Tests are conducted on the FXS ports via the **MODULES** screen menus and a VT 100 terminal.

Port

Identifies the port involved.

Test

To initiate a module test, scroll to the **TEST** column and press **Enter**. Options are detailed below.

Customer Ring Test

The Customer Ring Test will activate the unit's ring relay in a 2-on/4-off ring cadence, providing ringing to the customer loop.

Test Status

Tells whether a test is in progress.

FXS Voice Ports Status Options

The transmit and receive signalling bits are shown in the **STATUS** menu of the FXS ports.

Total Access 600 Features Used with FXS Options

Factory Restore

You can restore the factory default settings for an FXS by pressing **F** while the cursor is over the **SLT** number (this action restores the factory settings for all of the module options), while the cursor is over the **PRT** number (this action restores the factory settings for the port), or while the cursor is over an individual field (this action restores factory settings for the particular field only).

Echo Canceller

By using an integrated echo canceller and Adaptive Differential Pulse Code Modulation (ADPCM) encoder/decoder, the Total Access 600 can support a variety of voice applications. Voice over packet/cell applications require that echo cancellation techniques be applied to the voice traffic to achieve high quality voice. By using ADPCM compression schemes outlined in ITU-T G.721, the Total Access 600 can minimize bandwidth requirements and more efficiently utilize the physical link.

Echo Canceller Menus

Figure 4 shows the **MODULES** menu, from which you access echo canceller options.

Slot	Type	Menu	Alarm	Test	Status
0	NET (T1)	[+]	[+]	[+]	[+]
1	FXS	[+]	[n/a]	[+]	[+]
2	EC/ADPCM	[+]	-	-	-

MODE: Channelbank
Access module menus

NET: down
^Z=help 0:22

Figure 4. Modules Menu

Arrow to **EC/DPCM** and over to the **MENU** column. Press **Enter**. The **PROVISIONING** menu appears.

Provisioning	Echo Canceller	[+]
	ADPCM	[+]

MODE: Channelbank

NET: down
^Z=help 0:28

Figure 5. Provisioning Menu

Arrow to **ECHO CANCELLER** and press **Enter** to view choices for this menu (**ENABLE** or **DISABLE**). Arrow to **ADPCM** and press **Enter** to access the **PROVISIONING/ADPCM** menu (Figure 6).

TA 608 TAD/Modules/Modules[2]/Provisioning/ADPCM		
Echo Canceller	Chan	Mode
ADPCM	1	Disable
	2	Disable
	3	Disable
	4	Disable
	5	Disable
	6	Disable
	7	Disable
	8	Disable
MODE: Channelbank		
ADPCM Configuration Menu		
		NE1: down
		*Z=help 0:29

Figure 6. Provisioning/ADPCM Menu

DETAIL LEVEL PROCEDURES

DLP-001	Connecting the Terminal or PC to the CRAFT Port	357
DLP-002	Logging in to the System	359
DLP-003	Adding/Removing Telnet Users and Changing Password Security Levels	363
DLP-004	Setting Ethernet IP Parameters	367
DLP-005	Verifying Communications Over an IP LAN	369
DLP-006	Telnetting to the Unit	373
DLP-007	Upgrading the Firmware Using XMODEM	377
DLP-008	Upgrading the Firmware Using TFTP	381
DLP-009	Saving the Current Configuration Using TFTP	385
DLP-010	Loading the Current Configuration Using TFTP	389
DLP-011	Saving the Current Configuration Using XMODEM	393
DLP-012	Loading the Current Configuration Using XMODEM	395
DLP-013	Saving and Loading Text Configuration Using the Terminal Command Line	397
DLP-014	Unit Installation Using the Auto-Config Feature	401
DLP-015	TDM to ATM Upgrade	405
DLP-016	A.03 to A.04 Firmware Upgrade	409

CONNECTING THE TERMINAL OR PC TO THE CRAFT PORT

Introduction

Provisioning is facilitated by a series of intuitive menus that are accessible on a computer screen. Connecting either a VT100 terminal or a PC emulating a VT100 terminal to the **CRAFT** port on the rear of the unit allows access to the menus and management features of the unit. This section specifies how to connect the VT100 terminal or PC to the unit.

Access to the unit is through the port labeled **CRAFT**. It is an RJ-45 connector on the back of the unit. A special ADTRAN adapter is required for access to this port.

Prerequisite Procedures

The unit must be powered for terminal communication to function.

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-001

Perform Steps Below in the Order Listed

1. Connect a VT100 terminal to the unit.
 - Set the parameters of the VT100 terminal to:
 - 9600 baud rate
 - 8 data bits
 - No parity
 - 1 stop bit
 - No flow control
 - If the terminal has a parallel setting, disable it and use serial port.
 - Plug the RJ-45 male end of the data cable into the **CRAFT** port on the rear of the unit by using the ADTRAN-proprietary DB-9 to RJ-45 adapter. Make the connection to the VT100 terminal as appropriate for your equipment.
2. Connect a PC emulating a VT100 terminal to the unit.
3. Most personal computers or laptops can run communications software that will emulate a VT100 terminal. Windows programs such as Terminal® or Hyperterminal® are two such examples in the Windows format. However, there are many other adequate, commercially available software packages which will allow your PC or laptop to emulate a VT100 terminal. Certain configuration items must be set on a PC or laptop for it to act as a VT100 terminal for the unit.
 - Set the PC for direct connect on the appropriate com port (instead of dial-up connection).
 - Set the parameters of the communications software to:
 - 9600 baud rate
 - 8 data bits
 - No parity
 - 1 stop bit
 - No flow control
 - Plug the RJ-45 male end of the data cable into the **CRAFT** port on the rear of the unit. Make connection to the PC or laptop as appropriate for your equipment.
4. Press <Enter> or <Ctrl> <R> until Login menu appears on screen.

You are now ready to log in to the unit, as described in DLP-002, *Logging in to the System*.



A VT100 terminal program is provided with the ADTRAN Utilities.

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

LOGGING IN TO THE SYSTEM

Introduction

Once connected to the unit via either a VT100 terminal or PC configured as a VT100 terminal, it is necessary to log in to the system to gain access to the management and provisioning functions. This DLP provides specific steps for logging in to the system and accessing the various management and provisioning functions.

Prerequisite Procedures

Complete DLP-001, *Connecting the Terminal or PC to the CRAFT Port*, before logging in to a unit.

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.




NOTE

In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-002

Perform Steps Below in the Order Listed

1. After connecting to the system, a blank screen will appear.
Pressing any key will display the login screen shown below.



The cursor will blink at the **LOGIN** field, waiting for a password to be entered.


2. At the **LOGIN** field, enter the password for the unit.

Passwords are case sensitive. There is not a manufacturer's password by default. Press **<Enter>** to enter the menu.



If a customer forgets the password, they can contact ADTRAN Technical Support at 888-4ADTRAN for instructions on how to access the unit.

3. Upon entering the correct password, the **MAIN MENU** is displayed as shown below.



4. You are now logged in to the menu system.



NOTE *CONTROL L or CONTROL S will return to the login prompt shown in step 1.*

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

ADDING/REMOVING TELNET USERS AND CHANGING PASSWORD SECURITY LEVELS

Introduction

All menu items in the unit are protected by passwords of varying security levels. By assigning different passwords to different security levels, the System Administrator can control which users can view or change various menu items. You can assign multiple passwords at the same access level. This way, different users with the same access privileges can have different passwords. This procedure details the steps which must be performed to add/remove user profiles and assign password security levels in the unit.

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.
- Ethernet cable from the **10/100BaseT** port on the unit to a hub (customer-provided)
- Use Ethernet crossover if going from the unit to a PC (customer-provided).

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



NOTE

In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-003

Perform Steps Below in the Order Listed

1. Connect to the unit using either the **10/100BaseT** or **CRAFT** interfaces.

If you are not already connected to the unit's **CRAFT** interface (either with a VT100 compatible terminal or with a PC running VT100 emulation software), follow the procedure in DLP-001.

Alternately, if the unit is part of a management cluster connected to the local network, you may use a PC connected to the network to Telnet into the unit. Use the procedures in DLP-004 and DLP-006 to connect to the **10/100BaseT** interface.
2. Log in to the unit.

Log in to the unit (see DLP-002, *Logging in to the System* for details).
3. Go to the **SYSTEM CONFIG** menu and select the **MANAGEMENT** menu and press <Enter>.
4. Go to the **TELNET ACCESS** menu and press <Enter>.
5. Go to the **AUTHEN METHOD** menu and press <Enter>. Select the appropriate authentication method. The choices are **PASSWORD**, **RADIUS**, **PASSWORD/RADIUS**, and **RADIUS/PASSWORD**.
6. Go to the **USER LIST** menu and press <Enter>.
7. To add a new user profile and password, right arrow over to the right pane.
8. Give the new user profile a name by selecting the **NAME** field, pressing <Enter>, and typing the user defined name.
9. Personalize the password for the appropriate level by selecting the **PASSWORD** field, pressing <Enter>, then typing the desired password. You will have to type the new password again to confirm it.

Passwords for the unit are case sensitive. There is no default password for a new user (i.e., you can configure a user as blank with no password). The current password displays as a series of asterisks (*****).
10. Select the **IDLE TIME (MINS)** field and press <Enter>. This field defines the amount of time in minutes the session may be idle before the user is logged off. The range is **1-255**. The default value is **10**.
11. Assign the password level by selecting the **LEVEL** field and choosing from the following level descriptions.

The unit contains six different password levels. The table below gives a brief description of each level.

Security Level	Description
Full	The user has all access to view and configure all menus (same as logging in to the CRAFT port)
Support	The user has access to view SYSTEM INFO . The user has privileges to view and change everything under the SYSTEM CONFIG menu except for the CRAFT port settings, TELNET ACCESS lists, and the SNMP MANAGEMENT COMMUNITIES . The user has full access to the SYSTEM UTILITY menu, including the ability to upgrade firmware and reset the unit. The user has full access to the INTERFACES , L2 PROTOCOL , BRIDGE , ROUTER , and DS0 menus. The user does not have the ability to set RADIUS SERVER settings under the SECURITY menu.
Config	The same privileges as support, except that the user does not have privileges to download firmware or configuration from the SYSTEM UTILITY menu. The user additionally does not have the privilege to reset the unit remotely, or enter the terminal menu.
Router	The user has view only privileges of SYSTEM INFO . There is no access to the SYSTEM CONFIG menu. The user has PING and TRACEROUTE access from the SYSTEM UTILITY menu. The user is limited to Ethernet configuration and status from the INTERFACES menu. The user has full access to the BRIDGE and ROUTER menus. Access is limited to filters only from the SECURITY menu.
Voice	The user has read privileges of the SYSTEM INFO menu. The user has access to the PING and TRACEROUTE utilities from the SYSTEM UTILITIES menu. The user has full access to the FXS module from the INTERFACES menu.
Status	The user has read access of all menus except for the following: SYSTEM CONFIG/CRAFT PORT , SYSTEM CONFIG/TELNET ACCESS , SYSTEM CONFIG/SNMP MANAGEMENT , and SECURITY/RADIUS SERVER . The user does not have access to UPGRADE FIRMWARE , UPGRADE CONFIG , PING , or TRACEROUTE menus. The user cannot reset the unit or enter terminal mode.



In the A.03 firmware, only one telnet session can be active at a time. The A.04 firmware will support five simultaneous telnet sessions.



In the A.03 firmware, the default conditions for the username and password fields are to have no entries in these fields.

*In the A.04 firmware, the default username and password are **guest** and **password**, respectively.*

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

SETTING ETHERNET IP PARAMETERS

Introduction

If the unit is connected to an IP network for Telnet, TFTP, or SNMP management, several IP parameters must be set for the unit to communicate with the network. These parameters are described in this DLP along with the procedures for setting them.



*Please see your Network Administrator for the proper assignment of the following parameters: **IP ADDRESS**, **SUBNET MASK**, and **DEFAULT GATEWAY**.*

Prerequisite Procedures

This procedure assumes that the unit is connected to an IP network and is powered up.

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.
- Ethernet cable from the **10/100BASET** port on the unit to a hub (customer-provided)
- Use Ethernet crossover if going from the unit to a PC (customer-provided).



To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-004

Perform Steps Below in the Order Listed

1. Connect the unit to your VT100 system (details found in DLP-001, *Connecting the Terminal or PC to the CRAFT Port*).
2. Log in to the system with maximum rights (details for logging in are in DLP-002 and DLP-003).
3. From the **ROUTER/CONFIG/INTERFACES (ETH[1])** menu, select the **SETUP** option and press <Enter>.
4. Select the **PRIMARY IP** option and press <Enter>. Select **IP ADDRESS** and press <Enter>.
Enter the appropriate IP address.
5. From the **ROUTER/CONFIG/INTERFACES (ETH[1])/SETUP/PRIMARY IP** menu, select the **SUBNET MASK** option and press <Enter>.
Enter the appropriate Subnet Mask.
6. From the **ROUTER/CONFIG/ROUTES** menu, select the **DEFAULT GATEWAY** option and press <Enter>.
Enter the appropriate Default Gateway.
7. Escape out to the **ROUTER** menu and logoff by pressing <Ctrl + L>.

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

VERIFYING COMMUNICATIONS OVER AN IP LAN

Introduction

When an **ETHERNET** port is connected to a local area network (LAN), test steps must be performed on the unit to ensure that it is communicating properly over the network. This procedure outlines those steps.

Prerequisite Procedures

Before beginning this procedure, the unit should be physically connected to the LAN and the provisioning tasks detailed in DLP-004, *Setting Ethernet IP Parameters* should be complete.

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect the terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.
- Ethernet cable from the **10/100BASET** port on the unit to a hub (customer-provided)
- Use Ethernet crossover if going from the unit to a PC (customer-provided).

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.

NOTE

In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-005

Perform Steps Below in the Order Listed

1. Ascertain the unit IP address.

If you do not already have the IP Address for the unit, either obtain it from the Network Administrator or manually check for the address in the **ROUTER/CONFIG/INTERFACES (ETH[1])/SETUP/PRIMARY IP/IP ADDRESS** menu.



*You must log in with a security level of **CONFIG**, **SUPPORT**, or **FULL** to modify the IP parameters on the unit.*

2. Ping the unit from a remote computer on the network.

Using a remote computer system connected to the LAN, perform an ICMP Ping on the IP Address of the unit. Verify that the unit responds properly.

If the unit fails to respond, try the following:

- Verify that the proper IP Address, Subnet Mask, and Default Gateway are provisioned in the unit (see DLP-004, *Setting Ethernet IP Parameters* for details).
- Verify that the unit is properly cabled into the LAN and that the Ethernet cable is properly seated in the RJ-45 **10/100BASET** port on the rear of the unit.
- Verify the link light on the front of the unit is lit. If not lit, check the cabling between the hub and the unit.
- If the unit is connected to a hub or other network device that provides a carrier sense light for each port, verify that the carrier sense light for the port to which the unit is connected is lit. If this light is not lit, check the cabling between the hub and the unit.
- Verify the IP Address, Subnet Mask, and Default Gateway on the remote computer system.
- Use Ethernet straight-through cable for connection to hub or switch. Use Ethernet crossover if connecting to a PC.

If none of these steps are successful, contact the LAN Administrator for assistance.



*Refer to the documentation of the computer system if you are unsure how to perform a Ping command. Most computers running a networked version of Microsoft Windows™ or UNIX allow a Ping to be performed by simply typing **ping <IP Address>** at a command line prompt. Typically, the Ping program will respond by indicating that the remote IP Address has responded in a certain amount of time or that no response was received.*



*Some versions of Ping will continue running until you explicitly tell them to stop. If the program does not terminate on its own, type **<Ctrl+C>** to get the program to stop.*

3. Telnet to the unit.

From the same computer used in the previous step, Telnet to the unit and verify that the Telnet session is properly opened (see DLP-006, *Telnetting to the Unit*). Once the Telnet session is established, press **<Ctrl+L>** to log out and close the session.



*Refer to the documentation of the computer system if you are unsure how to perform a Telnet. Most computers running a networked version of Microsoft Windows™ or UNIX allow a Telnet to be performed by simply typing **Telnet <IP Address>** at a command line prompt. Telnet is a utility common on many local area networks that allows remote access to another computer or piece of equipment.*

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

TELNETTING TO THE UNIT

Introduction

If the unit is part of a management cluster connected to the local network, you may use a PC connected to the network to Telnet into the unit. This procedure details the steps which must be performed to Telnet into the unit.

Prerequisite Procedures

Complete DLP-004 and DLP-005 (steps 1 and 2 only).

Tools and Materials Required

- Access to a PC or other computer connected to the LAN.
- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.
- Ethernet cable from **10/100BASET** port on the unit to a hub (customer-provided)
- Use Ethernet crossover if going from the unit to a PC (customer-provided).



In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.




The ATM D.01.XX firmware supports one telnet session active at a time. The TDM A.03.XX firmware supports one telnet session active at a time. The TDM A.04 firmware supports five simultaneous telnet sessions.

DLP-006

Perform Steps Below in the Order Listed

1. Connect the computer to the unit's **CRAFT** port as shown in DLP-001, *Connecting the Terminal or PC to the CRAFT Port*.
2. Log in to the unit as shown in DLP-002, *Logging in to the System*.
3. Down arrow to **AUTHEN METHOD** and press <Enter>. Select **PASSWORD, RADIUS, PASSWORD/RADIUS, or RADIUS/PASSWORD** and press <Enter>.
4. Under the **SYSTEM CONFIG** menu, right arrow and select **MANAGEMENT**; press <Enter>. Right arrow and select the **TELNET ACCESS LIST**; press <Enter>. Set the **TELNET ACCESS** to **ON**. Select **USER LIST** and press <Enter>.

The following screen will appear.




5. Use the right arrow key to select the **NAME** field; press <Enter>. Enter a username to be used for Telnet logins.
6. If **PASSWORD** was selected for the **AUTHEN METHOD** in step 3, right arrow over to **PASSWORD**; press <Enter>. Enter a password to be used for Telnet logins.
7. Use the right arrow key to select **IDLE TIME (MINS)**; press <Enter>. This field defines the amount of time in minutes the Telnet session may be idle before the user is logged off. The range is **1-255**. The default value is **10** minutes. Enter the appropriate Idle Time.
8. Use the right arrow key to select **LEVEL**. Select the appropriate security level. For security level definitions, reference DLP-003 *Adding/Removing Telnet Users and Changing Password Security Levels*.
9. This completes the addition of one Telnet user. Repeat steps 1-8 for each user needing Telnet access.

10. Press <Control L> to log out of the unit.
11. From a remote computer system connected to the LAN, Telnet to the unit.




*Refer to the documentation of the computer system if you are unsure how to perform a Telnet. Most computers running a networked version of Microsoft Windows™ or UNIX allow a Telnet to be performed by simply typing **Telnet <IP Address>** at a command line prompt. Telnet is a utility common on many local area networks that allows remote access to another computer or piece of equipment.*

The following screen will appear.




12. Enter the user name assigned in step five and press <Enter>.

The following screen will appear.



13. Enter the password assigned in step 6.

Upon entering the correct password, the unit's Main Menu is displayed as shown below:



You are now Telnetted into the unit's menu system.

14. When you complete your configuration changes and save the changes (when prompted), press <Ctrl+L> to log out and close the session.

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

UPGRADING THE FIRMWARE USING XMODEM

Introduction

The unit supports firmware updates via the **10/100BASE-T** port using either TFTP from a network server or the **CRAFT** interface using XMODEM. XMODEM is found in the VT100 terminal application in the ADTRAN Utilities package and in most PC VT100 communications software packages. This procedure outlines the steps for a successful firmware upgrade using the **CRAFT** interface and XMODEM software. Firmware may be obtained from the ADTRAN website at www.adtran.com. Select **Support** and then **Post-Sales Technical Support**.

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.
- ADTRAN-provided file containing upgraded code
- XMODEM software

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-007

Perform the Steps Below in the Order Listed

1. Connect to the unit using the **CRAFT** interface.

If you are not already connected to the unit's **CRAFT** interface (either with a VT100 compatible terminal or with a PC running VT100 emulation software), follow the procedure in DLP-001, *Connecting the Terminal or PC to the CRAFT Port*. Connecting to the **CRAFT** interface limits the upgrade procedure to XMODEM Only.

2. Log in to the unit.

Log in to the unit (see DLP-002, *Logging in to the System* for details).

3. Go to the **SYSTEM UTILITY** menu and select the **UPGRADE FIRMWARE** menu; press <Enter>.
4. Go to the **TRANSFER METHOD** menu and select **XMODEM**.
5. Select **START TRANSFER** to start the update. Enter **Y** to confirm the upgrade.
6. From the terminal emulation software, begin the XMODEM upload by using the appropriate command sequence. If necessary, refer to the terminal emulation software documentation for help.

Also, when specifying the filename, ensure that the file transferred is the one provided by ADTRAN. Otherwise, the update will not complete successfully. This may take several minutes.

Because XMODEM data is being transferred in-band through the menu interface, the VT100 menus of the unit will be inoperable from the **CRAFT** interface. You can cancel the update at any time within the terminal emulation software. (Please consult the documentation provided by the terminal emulation software to determine how to do this.)

7. When the update has successfully completed, the following messages will display:

Verifying downloaded FLASH image...

Erasing FLASH...

Programming FLASH...

FLASH programmed successfully.

The unit will restart immediately and the user may then log back into the system.

Alternately, if the unit is part of a management cluster connected to the local network, you may use a PC connected to the network to Telnet into the unit. By utilizing the **10/100BASET** port, the unit may be quickly upgraded using TFTP, provided there is a TFTP server on the local network. The unit can also be upgraded across the WAN using TFTP provided there is a TFTP server accessible to the unit. The unit ships with ADTRAN Utilities software, which includes a TFTP server. See DLP-008, *Upgrading the Firmware Using TFTP*, for more details.

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

UPGRADING THE FIRMWARE USING TFTP

Introduction

The unit supports firmware updates via the **10/100BASET** Ethernet port using either TFTP from a network server or the **CRAFT** interfaces using XMODEM. The unit also supports TFTP updates across the WAN using the data/router channels. This DLP provides the steps to follow for a successful firmware upgrade using the **10/100BASET** Ethernet port and a TFTP Server.

Tools and Materials Required

- A TFTP Server accessible on the local network (a TFTP server is provided with the unit as part of the ADTRAN Utilities software) or a TFTP server accessible across the WAN
- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.
- Ethernet cable from **10/100BASET** port on the unit to a hub (customer-provided)
- Use Ethernet crossover if going from the unit to a PC (customer-provided).

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



NOTE

In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-008

Perform Steps Below in the Order Listed

For LAN Upgrades

1. Connect to the unit using the **10/100BASET** interface.

If you are not already connected to the unit's **10/100BASET** port using Telnet client software, use the procedure in DLP-006, *Telnetting to the Unit* to connect to the unit.

2. Verify the TFTP server is running on the network. The user may ping the TFTP server from the unit to verify communication.



*A TFTP server ships as part of the ADTRAN utilities. If using ADTRAN utilities, choose **START>PROGRAMS>ADTRAN UTILITIES>TFTP SERVER** to start the server.*

3. Download the firmware upgrade file to your computer.



*If using ADTRAN utilities, save the upgrade file to the “**ADTNUTIL**” directory on your hard drive.*

4. Go to the **SYSTEM UTILITY** menu and select the **UPDATE FIRMWARE** menu; press <Enter>.
5. Go to the **TRANSFER METHOD** menu and select **TFTP**.
6. Set the **TFTP SERVER ADDRESS** to the IP address of the machine running the TFTP server program.



*If using ADTRAN utilities, this will be the IP address that appears in the **TFTP SERVER STATUS** window.*

7. Enter the filename of the update file into the **TFTP SERVER FILENAME** field.
8. Select **START TRANSFER** to start the update. Enter **Y** to confirm the upgrade.

Prior to the start of the upgrade, the transfer status will display **IDLE**. During the TFTP upload, various status messages display in **TRANSFER STATUS** to indicate progress. The following table describes these messages.

Message	Meaning
Transferring... [X KB]	Indicates communication with the TFTP network server has been established and the update file is being transferred between the unit and the TFTP network server.
Flash Programmed Successfully	The unit has been upgraded successfully.
Loaded code ver x.x.x chksum = xxxx	Unit displays the version and checksum of the upgraded code.
Resetting....	Unit is power cycling.
RECV Error	Unit will display this message if server filename is incorrect.
Host Timeout	Unit will display this message if TFTP server address is incorrect.
idle	The upgrade has not yet been initiated.

- When the update has successfully completed, **FLASH PROGRAMMED SUCCESSFULLY** will display briefly in the **TRANSFER STATUS** field. This will be followed by a **LOADED CODE VER X.X.X CHKSUM = XXXX** message. Finally the **TRANSFER STATUS** field will display **RESETTING...**

The unit will restart immediately and resume operation. After giving the unit sufficient time to reboot, the user may telnet back into the unit and log in.

For WAN Upgrades

- Telnet into the unit using **FULL** or **SUPPORT** levels (refer to DLP-003, *Adding/Removing Telnet Users and Changing Password Security Levels*).
- Verify the TFTP server is running on the network. Verify that the unit can ping the TFTP server.
- Go to the **SYSTEM UTILITY** menu and select the **UPDATE FIRMWARE** menu; press **<Enter>**.
- Go to the **TRANSFER METHOD** menu and select **TFTP**.
- Set the **TFTP SERVER ADDRESS** to the IP address of the machine running the TFTP server program.



*If using ADTRAN utilities, this will be the IP address that appears in the **TFTP SERVER STATUS** window.*

- Enter the filename of the update file into the **TFTP SERVER FILENAME** field.
- Select **START TRANSFER** to start the update. Enter **Y** to confirm the upgrade.

Prior to the start of the upgrade, the transfer status will display **IDLE**. During the TFTP upload, various status messages display in **TRANSFER STATUS** to indicate progress. The following table describes these messages.

Message	Meaning
Transferring... [X KB]	Indicates communication with the TFTP network server has been established and the update file is being transferred between the unit and the TFTP network server.
Flash Programmed Successfully	The unit has been upgraded successfully.
Loaded code ver x.x.x chksum = xxxx	Unit displays the version and checksum of the upgraded code.
Resetting....	Unit is power cycling.
RECV Error	Unit will display this message if server filename is incorrect.
Host Timeout	Unit will display this message if TFTP server address is incorrect.
idle	The upgrade has not yet been initiated.

8. When the update has successfully completed, **FLASH PROGRAMMED SUCCESSFULLY** will display briefly in the **TRANSFER STATUS** field. This will be followed by a **LOADED CODE VER X.X.X CHKSUM = XXXX** message. Finally the **TRANSFER STATUS** field will display **RESETTING...**

The unit will restart immediately and resume operation. After giving the unit sufficient time to reboot, the user may telnet back into the unit and log in.

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

SAVING THE CURRENT CONFIGURATION USING TFTP

Introduction

The unit supports configuration transfers from the unit (via the **10/100BaseT** Ethernet port) to a TFTP server located on the network or a TFTP server accessible across the WAN. This DLP provides the steps to follow for a successful configuration transfer using the **10/100BaseT** Ethernet port and a TFTP Server.

Tools and Materials Required

- A PC with a Telnet client software
- A TFTP Server accessible on the local network (a TFTP server is provided with the unit as part of the ADTRAN Utilities software) or a TFTP server accessible across the WAN.
- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.
- Ethernet cable from the **10/100BaseT** port on the unit to a hub (customer-provided)
- Use Ethernet crossover if going from the unit to a PC (customer-provided).

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



NOTE

In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-009

Perform Steps Below in the Order Listed

Saving Configuration using TFTP Server on Local Network

1. Connect to the unit using the **10/100BASET** interface.

If you are not already connected to the unit's **10/100BASET** port using Telnet client software, use the procedure in DLP-006, *Telnetting to the Unit* to connect to the unit.

2. Verify the TFTP server is running on the network.



*A TFTP server ships as part of the ADTRAN utilities. If using ADTRAN utilities, choose **START>PROGRAMS>ADTRAN UTILITIES>TFTP SERVER** to start the server.*

3. Go to the **SYSTEM UTILITY** menu and select the **CONFIGURATION TRANSFER** menu; press <Enter>.
4. Verify the **TRANSFER METHOD** is set to **TFTP**.
5. Set the **TFTP SERVER IP ADDRESS** to the IP address of the machine running the TFTP Server Program.



*If you are using the ADTRAN TFTP server, the IP address displays in the **STATUS** field. For other TFTP servers, please refer to the appropriate documentation.*

6. Change **TFTP SERVER FILENAME** to a unique filename. This will be the name of the configuration file saved to the remote server. An example filename would be **ta_iad.cfg**.

Some TFTP servers constrain the format of the filename depending on the operating system of the server. For example, a TFTP server running on a PC under Windows 3.1 may only permit 8.3 format filenames (8 characters, period and three extension characters).
7. Select the **SAVE CONFIG REMOTELY** menu field and press <Enter>.

Enter **Y** to confirm the request.

8. View **CURRENT TRANSFER STATUS** to verify the progress of the current transfer. During a successful transfer, you will first see **DOWNLOAD: COPYING INTERNAL CONFIG**, and then **DOWNLOAD IN PROGRESS....**
9. When the transfer has successfully completed, **IDLE** displays in the **CURRENT TRANSFER STATUS** field.



*TFTP is **not** secure. No passwords are required for client access. Anyone can access files through the IP port on the server machine if they know the target file's name.*

Saving Configuration using TFTP Server Accessible Across the WAN

1. Telnet into the unit using **FULL** or **SUPPORT** levels (refer to DLP-003, *Adding/Removing Telnet Users and Changing Password Security Levels*).
2. Verify the TFTP server is running on the network. Verify that the unit can ping the TFTP server.
3. Go to the **SYSTEM UTILITY** menu and select the **CONFIGURATION TRANSFER** menu; press <Enter>.
4. Verify the **TRANSFER METHOD** is set to **TFTP**.
5. Set the **TFTP SERVER IP ADDRESS** to the IP address of the machine running the TFTP Server Program.



*If you are using the ADTRAN TFTP server, the IP address displays in the **STATUS** field. For other TFTP servers, please refer to the appropriate documentation.*

6. Change **TFTP SERVER FILENAME** to a unique filename. This will be the name of the configuration file saved to the remote server. An example filename would be **ta_iad.cfg**.

Some TFTP servers constrain the format of the filename depending on the operating system of the server. For example, a TFTP server running on a PC under Windows 3.1 may only permit 8.3 format filenames (8 characters, period and three extension characters).
7. Select the **SAVE CONFIG REMOTELY** menu field and press <Enter>.

Enter **Y** to confirm the request.
8. View **CURRENT TRANSFER STATUS** to verify the progress of the current transfer. During a successful transfer, you will first see **DOWNLOAD: COPYING INTERNAL CONFIG**, and then **DOWNLOAD IN PROGRESS....**
9. When the transfer has successfully completed, **IDLE** displays in the **CURRENT TRANSFER STATUS** field.



*TFTP is **not** secure. No passwords are required for client access. Anyone can access files through the IP port on the server machine if they know the target file's name.*

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

LOADING THE CURRENT CONFIGURATION USING TFTP

Introduction

The unit supports configuration uploads from a unit (via the **10/100BASET** Ethernet port) to a TFTP server located on the network or a TFTP server accessible across the WAN. This DLP provides the steps for a successful configuration upload using the **10/100BASET** Ethernet port and a TFTP server.

Tools and Materials Required

- A PC with a Telnet client software
- A TFTP server accessible on the local network (a TFTP server is provided with the unit as part of the ADTRAN Utilities software) or a TFTP server accessible across the WAN
- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.
- Ethernet cable from **10/100BASET** port on the unit to a hub (customer-provided)
- Use Ethernet crossover if going from the unit to a PC (customer-provided).

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-010

Perform Steps Below in the Order Listed

Loading Configuration using TFTP Server on Local Network

1. Connect to the unit using the **10/100BASE-T** interface.

If you are not already connected to the unit's **10/100BASE-T** port using Telnet client software, use the procedure in DLP-006, *Telnetting to the Unit* to connect to the unit.

2. Log in to the unit using a **FULL** or **SUPPORT** level password (see DLP-003, *Adding/Removing Telnet Users and Changing Password Security Levels* for details).
3. Verify the TFTP server is running on the network.



*A TFTP server ships as part of the ADTRAN utilities. If using ADTRAN utilities, choose **START>PROGRAMS>ADTRAN UTILITIES>TFTP SERVER** to start the server.*

4. Go to the **SYSTEM UTILITY** menu and select the **CONFIGURATION TRANSFER** menu, then press <Enter>.
5. Verify the **TRANSFER METHOD** is set to **TFTP**.
6. Set the **TFTP SERVER IP ADDRESS** to the IP address of the machine running the TFTP Server Program.



*If you are using the ADTRAN TFTP server, the IP address displays in the **STATUS** field. For other TFTP servers, please refer to the appropriate documentation.*

7. Change **TFTP SERVER FILENAME** to a unique filename including path. This will be the name of the configuration file retrieved from the remote server. An example filename would be **ta_iad.cfg**.
Some TFTP servers constrain the format of the filename depending on the operating system of the server. For example, a TFTP server running on a PC under Windows 3.1 may only permit 8.3 format filenames (8 characters, period and three extension characters).
8. Select the **LOAD AND USE CONFIG** menu field and press <Enter>.
Enter **Y** to confirm the request.
9. View **CURRENT TRANSFER STATUS** to verify the progress of the current upload.
10. When the upload has successfully completed, **IDLE** displays in the **CURRENT TRANSFER STATUS** field.



The unit is rebooted immediately after a configuration is successfully loaded. Any online sessions will be terminated.

11. After an appropriate length of time, the user may telnet back into the unit.



*TFTP is **not** secure. No passwords are required for client access. Anyone can access files through the IP port on the server machine if they know the target file's name.*

Loading Configuration using TFTP Server Accessible Across the WAN

1. Telnet into the unit using **FULL** or **SUPPORT** levels (refer to DLP-003, *Adding/Removing Telnet Users and Changing Password Security Levels*).
2. Verify the TFTP server is running on the network. Verify that the unit can ping the TFTP server.
3. Go to the **SYSTEM UTILITY** menu and select the **CONFIGURATION TRANSFER** menu; then press **<Enter>**.
4. Verify the **TRANSFER METHOD** is set to **TFTP**.
5. Set the **TFTP SERVER IP ADDRESS** to the IP address of the machine running the TFTP Server Program.



*If you are using the ADTRAN TFTP server, the IP address displays in the **STATUS** field. For other TFTP servers, please refer to the appropriate documentation.*

6. Change **TFTP SERVER FILENAME** to a unique filename including path. This will be the name of the configuration file retrieved from the remote server. An example filename would be **ta_iad.cfg**.
Some TFTP servers constrain the format of the filename depending on the operating system of the server. For example, a TFTP server running on a PC under Windows 3.1 may only permit 8.3 format filenames (8 characters, period and three extension characters).
7. Select the **LOAD AND USE CONFIG** menu field and press **<Enter>**.
Enter **Y** to confirm the request.
8. View **CURRENT TRANSFER STATUS** to verify the progress of the current upload.
9. When the upload has successfully completed, **IDLE** displays in the **CURRENT TRANSFER STATUS** field.



The unit is rebooted immediately after a configuration is successfully loaded. Any online sessions will be terminated.

10. After an appropriate length of time, the user may telnet back into the unit.



*TFTP is **not** secure. No passwords are required for client access. Anyone can access files through the IP port on the server machine if they know the target file's name.*

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

SAVING THE CURRENT CONFIGURATION USING XMODEM

Introduction

The unit supports configuration transfers from the unit using a VT100 terminal or terminal emulator (with XMODEM) and the **CRAFT** interface. This DLP provides the steps to follow for a successful configuration transfer using the **CRAFT** port and XMODEM.

Tools and Materials Required

- VT100 terminal or PC with VT100 terminal emulation software
- XMODEM software

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



NOTE

In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-011

Perform Steps Below in the Order Listed

1. Connect to the unit using the RJ-45 **CRAFT** interface.

If you are not already connected to the unit's **CRAFT** interface (either with a VT100 compatible terminal or with a PC running VT100 emulation software), follow the procedure in DLP-001 *Connecting the Terminal or PC to the CRAFT Port*. Connecting to the **CRAFT** port interface limits the config transfer procedure to XMODEM only.

2. Login to the unit. (See DLP-002 *Logging in to the System* for details.)
3. Go to the **SYSTEM UTILITY** menu and select **CONFIG TRANSFER** menu; press <Enter>.
4. Set the **TRANSFER METHOD** menu to **XMODEM**.
5. Select **SAVE CONFIG REMOTELY** to start the transfers. Enter **Y** to confirm the transfer and prepare the unit for the transfer download. The following message is displayed: **"This will begin sending a copy of the current system configuration."**

When the unit is ready to send the configuration file **"XMODEM/CRC: Receive CONFIG file now..."** is displayed in the bottom left corner of the terminal window. While this message is visible the menus are not available.

6. Configure the VT 100 terminal or terminal emulation software to **Receive** (you are prompted for filename).
7. From the terminal evaluation software, begin the XMODEM transfer by using the appropriate command sequence. For Windows Hyper Terminal, select **Transfer>Receive File**. Enter the filename (including path) and select XMODEM as the transfer method.

If necessary, refer to the terminal emulation software documentation for help. Also, when specifying the filename, ensure that the file save a .cfg extension. Otherwise, the file may not be available for uploading into the other units.

Because XMODEM data is being transferred in-band through the menu interface, the VT100 menus of the unit will be inoperable from the **CRAFT** interface. You can cancel the update at any time within the terminal emulation software. (Please consult the documentation provided by the terminal emulation software to determine how to do this).

8. When the transfer has successfully completed, **IDLE** displays in the **CURRENT TRANSFER STATUS** field and **UPLOAD COMPLETE** displays **THE PREVIOUS TRANSFER STATUS** field.

Follow-up Procedure

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

LOADING THE CURRENT CONFIGURATION USING XMODEM

Introduction

The unit supports configuration uploads from a unit using a VT100 terminal or terminal emulator (with XMODEM) and the **CRAFT** interface. This DLP provides the steps for a successful configuration upload using the **CRAFT** port and XMODEM.

Prerequisite Procedures

Obtain the configuration file (see for DLP-011 *Saving the Current Configuration Using XMODEM* details).

Tools and Materials Required

- VT100 terminal or PC with VT100 terminal emulation software
- XMODEM software

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



NOTE

In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-012

Perform Steps Below in the Order Listed

1. Connect to the unit using the RJ-45 **CRAFT** interface.

If you are not already connected to the unit's **CRAFT** interface (either with a VT100 compatible terminal or with a PC running VT100 emulation software), follow the procedure in DLP-001 *Connecting the Terminal or PC to the CRAFT Port*. Connecting to the **CRAFT** interface limits the config transfer procedure to XMODEM Only.

2. Login to the unit. (See DLP-002 *Logging in to the System* for details.)
3. Go to the **SYSTEM UTILITY** menu and select **CONFIGURATION TRANSFER** menu; press <Enter>
4. Set the **TRANSFER METHOD** menu to XMODEM.
5. Select **LOAD AND USE CONFIG** to start the transfer. Enter Y to confirm the transfer and prepare the unit for the transfer download.



The following message is displayed: "Warning: WAN link may be reset after transfer complete!"

When the unit is ready to receive the XMODEM configuration file, the menu screen will clear and display **XMODEM/CRC: Transmit CONFIG file now...** If this does not appear, please review the steps above for possible configuration errors.

6. From the terminal emulation software, begin the XMODEM transfer by using the appropriate command sequence. For Windows HyperTerminal, select Transfer>Send File. Enter the filename (including path) and select XMODEM as the transfer method. Configuration files should have a .cfg extension.

If necessary, refer to the terminal emulation software documentation for help.

Because XMODEM data is being transferred in-band through the menu interface, the VT100 menus of the unit will be inoperable from the **CRAFT** interface. You can cancel the update at any time within the terminal emulation software. (Please consult the documentation provided by the terminal emulation software to determine how to do this.)

7. After the config transfer is complete, the Config Transfer menu will be displayed.

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

SAVING AND LOADING TEXT CONFIGURATION USING THE TERMINAL COMMAND LINE

Introduction

The unit has the ability to download a text file, which contains the configuration of the entire unit. This configuration may then be altered in a text editor, and then uploaded to the unit.

This DLP will explain how to save and load the configuration.

Prerequisite Procedures

You must connect to the unit with a VT100 terminal session (reference DLP-001 and DLP-002) or via a Telnet session (reference DLP-006, *Telnetting to the Unit*).

Tools and Materials Required

- Access to a PC or other computer connected to the LAN (Telnet access only)
- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer-provided) for connecting to the **CRAFT** port on the rear of the unit. This adapter is ADTRAN-proprietary.
- Ethernet cable from the **10/100BASET** port on the unit to a hub (customer-provided)
- Use Ethernet crossover if going from the unit to a PC (customer-provided).

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



NOTE


In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-013


Perform Steps Below in the Order Listed

Saving the Router's Configuration

1. Establish a connection to the router with the terminal software either through the **CRAFT** port or via a Telnet session.
2. From the Main Menu, select **SYSTEM UTILITY**, then **TERMINAL MODE**, and then press <Enter>.
3. The following screen will appear.



4. At the terminal prompt, type download and then press <Enter>. The following screen will appear.



5. Don't press another key yet!
6. Enable "capture" or "logging" in the terminal software, saving it to a file on your computer.
7. Press the SPACE BAR to continue. The router will then print its configuration to the terminal screen. (With capture enabled, the terminal software will capture the configuration and write it to the file that you designated.)
8. When the configuration stops printing, end the capture. The router's configuration is now saved to the file that you designated.
9. At the terminal prompt, type **exit** to go back into the configuration menu of the router.
10. Always use **Ctrl+L** to exit the configuration menu before closing the Telnet or terminal software.

Loading a Configuration into the Router

The following steps walk through uploading the text file back into the unit. These text files can be the entire configuration, or just partial commands that affect specific configuration changes. The uploading steps are the same, no matter the size of the file.

1. Establish a connection to the router with the terminal software either through the **CRAFT** port or via a Telnet session.
2. From the Main Menu, select **SYSTEM UTILITY**, then **TERMINAL MODE**, and then press <Enter>.
3. In the terminal software, initiate a SEND TEXT FILE or SEND CFG FILE using the saved configuration file.
4. Once the file transfer is complete, type **save** to save the configuration in the unit. Then type **exit** to go back into the configuration menu of the router.
5. Always use **Ctrl+L** to exit the configuration menu before closing the Telnet or terminal software.

Entering Commands at the Command Prompt

To do this manually from the prompt, precede each instruction with a ">". **After uploading, to apply and save changes, you must issue the command "save" from the prompt.** The command will apply ALL changes to the unit (the same as escaping all the way out of the terminal menu). To do a save to flash only, but not apply the changes, you can go back to the menu system and press **Ctrl-W**. A **!exit** command executes a do not save and a do not ask function (i.e. changes will not be saved and the user will not be prompted to save the changes).

The commands are based on string comparisons with the menu system (with spaces replaced with underscores). This means that the config command will appear exactly as it appears in the terminal menus. To change a configuration, type in the option desired exactly as it appears on the menu. For example, to change the T1 timing mode, the command line would read

```
>sysconfig t1_timing_mode network or
```

```
>sysconfig t1_timing_mode internal or
```

```
>sysconfig t1_timing_mode dsx-1.
```

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

UNIT INSTALLATION USING THE AUTO-CONFIG FEATURE

Introduction

AUTO-CONFIG allows the service provider to gain initial access to a newly installed IAD while in its factory default state. This eliminates the need for a skilled technician on-site during installation, as it only requires someone to make the network interface and power connections to the IAD. After accessing the unit, the service provider remotely loads a configuration script. A fail-safe timer is then set and the configuration is saved. Next, the service provider reprovisions the network to match the IAD's configuration and accesses the unit. If the service provider can access the unit, the **AUTO-CONFIG** was successful, the unit is operational, and the fail-safe timer should be cancelled. If access is not gained prior to the fail-safe timer expiration, the fail-safe mechanism is invoked and the IAD returns to the default configuration.

This DLP details the steps involved in an IAD installation using the **AUTO-CONFIG** feature.

Prerequisite Procedures

The unit must be at factory default. If the unit is not a new unit, factory default the unit by one of the following methods:

- Select **SYSTEM UTILITY>TERMINAL MODE**. At the > prompt, type **fac**. You will then see “Restore Factory Defaults and Reset Unit? (press 'y').” Press the y key to confirm default. The unit then resets.
- If connected to the **CRAFT** port, power reset the unit and then restore power to the unit while holding down the **F** key. You will then be prompted to confirm the factory default.

Obtain the desired configuration file. The config file may be one of the following two formats:

- A .cfg file which is loaded via TFTP. See DLP-009, *Saving the Current Configuration Using TFTP*.
- A script obtained via the terminal mode. See DLP-013 (*Saving the Router's Configuration* section only).



The service provider's access network Layer 1 must be provisioned to map a single 64 K DS0 from the provider's network to DS0 24 on the customer's T1 circuit with matching circuit parameters (ESF, B8ZS).

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software (only required if unit has to be factory defaulted)
- Appropriate cable to connect terminal to the unit (customer-provided, only required if unit has to be factory defaulted)
- DB-9 female to RJ-45 female adapter (customer provided) for connecting to the **CRAFT** port on the rear of the unit (only required if unit has to be factory defaulted)
- Silver Satin Cable for **CRAFT** access (P/N 3127004 provided with unit, only required if unit has to be factory defaulted)

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.

**NOTE**

In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

DLP-014

Perform Steps Below in the Order Listed

1. Verify the unit is at factory default.
2. Connect the network interface cable to the **NTWK** port on the rear of the unit.
3. Power up the unit.
4. The unit begins the process of auto-detecting whether the packets received on the WAN interface are PPP LCP packets or Frame Relay signaling packets. When the second consecutive control packet of the same type is received, the unit configures itself for the detected L2 protocol. When the next control packet of the same type is received, the L2 protocol is confirmed, and the auto-detection of the L2 protocol is complete.

If PPP is detected:

- The unit's PPP interface is set to accept its IP address from the service provider's peer router via the PPP IPCP config-NAK mechanism as described in RFC 1332.
- The unit automatically sets its default route to the service provider's edge router address as identified by PPP IPCP.

If Frame Relay is detected:

- The frame relay network signaling is further analyzed to automatically detect the signaling protocol being used (Annex D, Annex A, or LMI).
 - Next, the unit automatically adds the first indicated Frame Relay PVC as an interface to the IAD router.
 - When the PVC becomes active, the unit broadcasts a DHCP request toward the provider edge router over the active PVC.
 - When a DHCP response is received, the unit assigns the address indicated by the DHCP server as its WAN IP address. The address indicated as the gateway address is set as the default gateway. Additional information provided may also be used such as DNS server addresses, WINS addresses, Domain name, Host name, etc.
5. Once the L2 protocol detection is complete, the service provider can telnet into the unit using the IP address assigned by the router/DHCP server.



The service provider's access network Layer 1 must be provisioned to map a single 64 K DS0 from the provider's network to DS0 24 on the customer's T1 circuit with matching circuit parameters (ESF, B8ZS).

6. Load the desired configuration file. The config file may be one of the following two formats:
 - A .cfg file which is loaded via TFTP. See DLP-009, *Saving the Current Configuration Using TFTP*.
 - A script obtained via the terminal mode. See DLP-013 (*Saving the Router's Configuration* section only).

7. Set the failsafe timer by selecting **SYSTEM UTILITY>TERMINAL MODE** and typing **fstimer start x**, (where x is in seconds) at the > prompt. Select a value for x which will allow enough time for the service provider to reconfigure the network to match the unit's new configuration and which will allow an extra 3 to 5 minutes for the unit to sync up with the network.



*Set the failsafe timer prior to doing the save. Typing **save** will apply the configuration changes, and the unit will not be accessible until the network is reconfigured.*

8. Type **Save** at the > prompt. This applies all configuration changes and the current connection is lost.
9. At this point, the service provider reconfigures the network to match the unit's new configuration.
10. After the network configuration is complete, the service provider attempts to connect to the unit. If the connection is successful, deactivate the failsafe timer by selecting **SYSTEM UTILITY>TERMINAL MODE** and typing **fstimer stop** at the > prompt.
11. If the connection is not successful, wait until the timer expires and the unit will factory default back to the **AUTO-CONFIG** mode. Repeat steps 4-10 of this DLP.

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

TDM TO ATM UPGRADE

Introduction

The Echo Canceller Module provides G.165/G.168 echo cancellation for voice over ATM applications and is available with Adaptive Differential Pulse Code Modulation (ADPCM). ADPCM is a speech coding method which uses fewer bits than traditional Pulse Code Modulation (PCM), allowing the user to get more analog voice calls on less bandwidth. Echo cancellation and ADPCM resources are built into all 600 Series units except the Total Access 612/616/624 T1 TDM units (P/N 4200612L1#TDM, 4200616L1#TDM, and 4200624L1#TDM). These units may be upgraded to include echo cancellation via three methods. This DLP discusses those three methods.

Prerequisite Procedures

Purchase the EC/ADPCM (P/N 1200613L1).

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer provided) for connecting to the **CRAFT** port on the rear of the unit

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, wear an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.



The Total Access 604/608 units and the third generation Total Access 612/616/624 units (P/N 1203612L1, 1203616L1, and 1203624L1) come with the Echo Canceller function built in, so there is no need for these units to be upgraded.

DLP-015

Perform Steps Below in the Order Listed


Purchase of Upgrade Package from ADTRAN

The upgrade package may be purchased from ADTRAN. This package includes the EC/ADPCM (P/N 1200613L1) and the ADTRAN installation and test. If this package is ordered, the customer must send the Total Access TDM 612/616/624 unit back to ADTRAN. Once received, the EC/ADPCM module is installed along with the latest VoATM firmware. The upgraded unit is then tested and returned to the customer. Please call ADTRAN CAPs department at 800-9-ADTRAN extension 7722 for this service.

Purchase and Installation of the EC/ADPCM Module by the Customer

An EC/ADPCM module may be purchased separately and installed in the Total Access 612/616/624 T1 TDM unit by the customer.

1. Remove power from the Total Access 612/616/624.
2. Remove the screws from the back of the Total Access 612/616/624, and then remove the cover.
3. Install the EC/ADPCM Module in the Total Access 612/616/624 as shown in the following figure.



4. Remove the two screws from the motherboard, install the two standoffs, and insert the screws through the top of the EC/ADPCM board into the standoffs.
5. Replace the cover on the Total Access 612/616/624 and tighten the screws.
6. Restore power to the Total Access 612/616/624.
7. Obtain the latest VoATM firmware from the ADTRAN website (<http://www.ADTRAN.com>). Select **SUPPORT>POST-SALES TECHNICAL SUPPORT>FIRMWARE UPDATES>612/616/624 ATM** or contact Post-Sales Technical Support at 888-4ADTRAN.

8. Upgrade the Total Access 612/616/624 with the latest VoATM firmware. Instructions for upgrading the unit can be found in DLP-007 and DLP-008.
9. Factory default the Total Access 612/616/624 by one of the following methods:
 - Select **SYSTEM UTILITY>TERMINAL MODE**. At the > prompt, type **fac**. You will then see "Restore Factory Defaults and Reset Unit? (press 'y')." Press the **y** key to confirm default. The unit then resets.
 - If connected to the **CRAFT** port, power reset the unit and then restore power to the unit while holding down the **F** key. You will then be prompted to confirm the factory default.
10. In the ATM code, the upgrade was successful if the following two things occur:
 - The **SYSTEM INFO>FIRMWARE REVISION** field does not display Error.
 - When you select the **MODULES>MODULES** menu, the EC/ADPCM appears in Slot 7 as shown in the following screen.

Slot	Type	Menu	Alarm	Test	Status
0	NET (T1)	[+]	[+]	[+]	[+]
1	QUAD FXS	[+]	[n/a]	[+]	[+]
2	QUAD FXS	[+]	[n/a]	[+]	[+]
3	QUAD FXS	[+]	[n/a]	[+]	[+]
4	QUAD FXS	[+]	[n/a]	[+]	[+]
5	QUAD FXS	[+]	[n/a]	[+]	[+]
6	QUAD FXS	[+]	[n/a]	[+]	[+]
7	EC/ADPCM	[+]	-	-	-

MODE: T1 TAD SLOTS 1:FXS 2:FXS 3:FXS 4:FXS 5:FXS 6:FXS NET: down
Access module menus ^Z=help 0:13

11. Reconfigure the unit for the specific application.

Purchase of a T1 TDM 612/616/624 Unit with the EC/ADPCM Card Installed for Later Upgrade to ATM

For customers who plan to operate a TDM application initially, but eventually upgrade to an ATM application, a Total Access 612/616/624 unit may be purchased with the EC/ADPCM card installed (P/N 4200612L2#TDM, 4200616L2#TDM, 4200642L2#TDM).

- When the circuit is converted to ATM, the customer may obtain the latest VoATM firmware from the ADTRAN website (<http://www.ADTRAN.com>). Select **SUPPORT>POST-SALES TECHNICAL SUPPORT>FIRMWARE UPDATES>612/616/624 ATM** or contact Post-Sales Technical Support at 888-4ADTRAN.
- Upgrade the Total Access 612/616/624 with the latest VoATM firmware. Instructions for upgrading the unit can be found in DLP-007 and DLP-008.
- Factory default the Total Access 612/616/624 by one of the following methods:
 - Select **SYSTEM UTILITY>TERMINAL MODE**. At the > prompt, type **fac**. You will then see "Restore Factory Defaults and Reset Unit? (press 'y')." Press the **y** key to confirm default. The unit then resets.
 - If connected to the **CRAFT** port, power reset the unit and then restore power to the unit while holding down the **F** key. You will then be prompted to confirm the factory default.
- In the ATM code, the upgrade was successful if the following two things occur:
 - The **SYSTEM INFO>FIRMWARE REVISION** field does not display Error.
 - When you select the **MODULES>MODULES** menu, the EC/ADPCM appears in Slot 7 as shown in the following screen.

Slot	Type	Menu	Alarm	Test	Status
0	NET (T1)	[+]	[+]	[+]	[+]
1	QUAD FXS	[+]	[n/a]	[+]	[+]
2	QUAD FXS	[+]	[n/a]	[+]	[+]
3	QUAD FXS	[+]	[n/a]	[+]	[+]
4	QUAD FXS	[+]	[n/a]	[+]	[+]
5	QUAD FXS	[+]	[n/a]	[+]	[+]
6	QUAD FXS	[+]	[n/a]	[+]	[+]
7	EC/ADPCM	[+]	-	-	-

MODE: 11 1AD SLOTS 1:FXS 2:FXS 3:FXS 4:FXS 5:FXS 6:FXS NET: down
Access module menus ^Z=help 0:13

- Reconfigure the unit for the specific application.

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

A.03 TO A.04 FIRMWARE UPGRADE

Introduction

The Total Access line of Integrated Access Devices includes both the ATM and TDM versions of the Total Access 604/608/612/616/624. Until now, the Total Access TDM units have been running firmware version A.03.xx. Recently, A.04.xx has been released to support the TDM Total Access IADs. The development of A.04.xx code is a significant step in the evolution of the Total Access product line, as it allows all Total Access family members to share the same base code. This means that features and fixes are more easily implemented and are propagated across the product line.

The two possible A.03 to A.04 upgrade paths are described in this DLP.



The choice of upgrade path will determine whether the unit's configuration is saved.



Since the A.03 and A.04 firmware loads are significantly different, the text configuration files for the two revisions are also different. It is recommended that the customer save a text configuration file for both the A.03 revision (prior to the upgrade) and for the A.04 revision (after completion of the upgrade). Refer to DLP-009 and DLP-011 for further instructions on how to save the configuration.



To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



In this DLP, unit refers to the Total Access 604, 608, 612, 616, and 624.

Prerequisite Procedures

Obtain the A.04 firmware and the A.03.90 (Transition Build) firmware from the ADTRAN website (<http://www.ADTRAN.com>).



*For the Total Access 604/608 units, select **SUPPORT>POST-SALES TECHNICAL SUPPORT>FIRMWARE UPDATES>604/608 TDM.***



*For the Total Access 612/616/624 units, select **SUPPORT>POST-SALES TECHNICAL SUPPORT>FIRMWARE UPDATES>612/616/624 TDM.***



Do not install Total Access 604/608 firmware into the Total Access 612/616/624 units or vice versa. This could result in a non-functional unit.

If further assistance is required, contact ADTRAN Technical Support at 1-888-4ADTRAN.

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 female to RJ-45 female adapter (customer provided) for connecting to the **CRAFT** port on the rear of the unit

DLP-016

Perform Steps Below in the Order Listed

Upgrade From A.03 to A.03.90 (Transition Build) to A.04

1. Upgrade the firmware from A.03 to A.03.90 (Transition Build) firmware. See DLP-007 or DLP-008 for instructions on how to perform this upgrade.
2. Once the upgrade to A.03.90 is complete, immediately upgrade the unit to A.04. See DLP-007 or DLP-008 for instructions on how to perform this upgrade.



Upgrading from A.03 to A.03.90 (Transition Build) to A.04 will save the unit's configuration.

Upgrade From A.03 to A.04 Directly

1. Upgrade the firmware from A.03 to A.04 firmware. See DLP-007 or DLP-008 for instructions on how to perform this upgrade.
2. The unit must then be factory defaulted by one of the following methods:
 - Select **SYSTEM UTILITY>TERMINAL MODE**. At the > prompt, type **fac**. You will then see "Restore Factory Defaults and Reset Unit? (press 'y')." Press the **y** key to confirm default. The unit will then automatically reset.
3. If connected to the **CRAFT** port, power reset the unit and then restore power to the unit while holding down the **F** key. You will then be prompted to confirm the factory default.
4. Reconfigure the unit for the specific application.



Upgrading from A.03 to A.04 directly (or from A.04 to A.03 directly) will erase the unit's configuration.

Follow-up Procedures

Once this procedure is complete, return to the procedure which referred you to this DLP and continue with the tasks indicated there.

ADTRAN UTILITIES

ADTRAN delivers several PC software utilities along with the unit. These utilities are located on the CD-ROM that came with your shipment. They also include MIB files (located in the MIB directory).



Review the readme file (Readme.txt) for the latest information about the utilities.

The utilities make it easier to interface with the terminal menu and transfer configuration files to and from TFTP servers. The utilities all run on Microsoft Windows 3.1 or higher. The following sections describe the Telnet, VT100, and TFTP Server utilities.

CONTENTS

Telnet Utility	415
Session Menu	415
Edit Menu	417
Options Menu	417
Capture Menu	417
Help Menu	418
VT100 Utility	418
Session Menu	419
Edit Menu	419
Port Menu	419
Options Menu	419
Capture Menu	420
Help Menu	420
TFTP Server	420
Server Menu	421
Print Log	421
Help	422
Status Field	422
Meter Field	422
Log Field	422

FIGURES

Figure 1. Telnet Menu Tree	415
Figure 2. VT100 Menu Tree	418
Figure 3. TFTP Server Interface Menu Tree	420
Figure 4. TFTP Server Interface	421



In this section, unit refers to the Total Access 604, 608, 612, 616, and 624.

1. TELNET UTILITY

The Telnet utility delivered with the unit provides enhancements to standard Telnet programs that make it easier to work with unit options.

Access the Telnet program remotely through the **10/100BASET** Ethernet port. For a detailed description of how to work with the Telnet program, refer to *Navigating the Terminal Menus* in the Commons User Interface Guide section of this manual. If you need help setting up the unit for a Telnet session, refer to the Detailed Level Procedures section of this manual.

The Telnet menus include **SESSION**, **EDIT**, **OPTIONS**, **CAPTURE**, and **HELP** (see the menu tree in Figure 1).





Figure 1. Telnet Menu Tree

Session Menu

Click on **SESSION** to open the Telnet session.

Connect

Opens dialog box for setting **HOST NAME** and **PORT** parameters for a Telnet session. Also lets you **EDIT ENTRY**, **ADD NEW** entry, and **DELETE** stored entries. When the parameters are set, click **CONNECT** to make the connection. Click **CANCEL** to end the session.

**Host Name**

Accepts and stores host names. You may either enter a name, an IP address, or a domain name directly from this field. Click on the drop-down arrow to display a complete list of previously stored host names.


Port

Provides several port options. You may enter port numbers directly into this field to connect to non-standard ports or select the drop-down combo-box to display the following options:

TELNET	establishes a Telnet session
ECHO	provides a loopback for troubleshooting
DISCARD	bit bucket; discards data
DAYTIME	returns the time
CHARGEN	displays as a unique character stream; used for self-tests

Edit Entry

Changes either the unit name or the IP address of each host. Press either **Tab**, **Return**, or a **period (.)** after each number in the IP address to move to the next field. If you press **Return** or **(.)** while the cursor is located in each IP field, that field entry is deleted.

**Add New**

Prompts you for the same information as the **EDIT ENTRY** dialog box for new host. When enabled, the **USE DNS** (Domain Name Server) feature allows users to request **DOMAIN LOOK UP** via a DNS server on the network, rather than specifying an IP address. The name then appears in the **HOST NAME** field.

Delete

Removes a host name from the list; simply select the host name you want to remove, and, at the prompt, click **DELETE**.

Connect

Establishes the Telnet session.

Disconnect

Terminates the Telnet session.

To re-establish the session, select **CONNECT** from **SESSION MENU** or press **ENTER** three times. This action restores the previous connection.

Transfer Cfg

This feature is used with ADTRAN products primarily for sending configuration files to the unit.

Exit

Ends the Telnet session and closes the Telnet screen.

Edit Menu

Provides **COPY** and **PASTE** commands.

Options Menu

Provides viewing alternatives for the terminal screen.

Colors

Three options change the color of the background window (**BACKGROUND**), bold highlights (**BOLD**), and text (**TEXT**).

Local Echo

Echoes each character that you enter.

AutoRepeat

Repeats characters you select from the keyboard, if you hold down the key.

Capture Menu

Provides options for capturing screen images.

File

Sends screen options data to a file in the format options listed below:

Start Cfg Capture

Used with the ADTRAN product line to start sending the scrolling screen capture to a file storage location.

Stop Cfg Capture

Used with the ADTRAN product line to stop sending the scrolling screen capture to a file storage location.

Buffer Size

Disables terminal window scroll bars when set to zero. This is the normal setting. This number represents the number of lines to capture in the memory buffer.

Save Buffer As

Save screen capture to a file.

Screen Capture

Copies the text on the current Telnet screen to the clipboard. You can open any word processor and paste the clipboard contents into the program. This option is helpful when debugging.

Help Menu

Provides on-line help for using the ADTRAN Utilities.

Contents

Opens the on-line help.

IP Status

Displays the local port address and the status of the connection.

About

Displays version and owner information.

2. VT100 UTILITY

Use the VT100 to configure a unit which is directly connected to a PC. The VT100 display is almost identical to the Telnet display.

For a detailed description of how to work within the terminal menu, refer to *Navigating the Terminal Menus* in the User Interface Guide section of this manual. If you need help setting up the unit for a VT100 session, refer to the Detailed Level Procedures section of this manual.

VT100 menus include **SESSION**, **EDIT**, **PORT**, **OPTIONS**, **CAPTURE**, and **HELP** (see the menu tree in Figure 2).




Figure 2. VT100 Menu Tree

Session Menu

Opens VT100 terminal emulation session.

Connect

Opens a specified serial port for a VT100 session.

Disconnect

Closes a specified serial port at the end of a VT100 session.

File Transfer

Uploads and downloads files to and from the unit.

XMODEM CRC

Selects the XMODEM file transfer protocol.

ASCII Cfg Files

Selects ASCII transfer mode. Primarily useful for configuration transfers for the ADTRAN products.

Edit Menu

Identical to the Telnet **EDIT MENU** (see *Edit Menu* on page 417).

Port Menu

Changes serial COM port **SETTINGS**. Provides data rate settings from 300—57600 bps.

Options Menu

Provides terminal screen commands.

Refresh Screen

Redraws the screen.

Connect

Provides the options **TRANSMIT WAKEUP** and **TRANSMIT REFRESH**.

Transmit Wakeup

Provides a control sequence that puts the unit **CRAFT** port online in terminal mode.

Transmit Refresh


Provides a control sequence to refresh the screen automatically when connecting. This is the default setting.

Colors

Identical to Telnet **COLORS MENU** (see *Colors* on page 417).

Local Echo

Echoes each character that you enter.



AutoRepeat

Repeats characters you select from the keyboard if you hold down the key.

Capture Menu

Identical to the Telnet **CAPTURE MENU** (see *Capture Menu* on page 417).

Help Menu

Provides on-line help and information about the version number.

Contents

Opens on-line help.

About

Displays version and owner information.

3. TFTP SERVER

The TFTP Server utility transfers configuration files to and from a TFTP server. You can install this program on a PC running any version of Microsoft Windows. The configuration of the unit can be saved offline as a backup file. The saved file may also be used to send the same configuration to multiple units. Transfer configuration files using the TFTP protocol (a TCP/IP user protocol) via the **10/100BASET** Ethernet port. The unit must have a valid IP address, subnet mask, and default gateway (if required), and be connected to an Ethernet network before proceeding. Figure 4 shows the TFTP server interface. For information on transferring and saving configurations using TFTP, refer to the Detailed Level Procedures section of this manual.



*Files must be placed in the Application directory where you installed the product.
Received files are also placed here.*




Figure 3. TFTP Server Interface Menu Tree




Figure 4. TFTP Server Interface

Only one configuration transfer session (upload or download) may be active at a time. The TCP/IP parameters are not saved or overwritten as part of the unit's transferred configuration to allow sending identical configurations to multiple units. When you start this program, a port is automatically opened.

Server Menu

Provides enable, disable, abort, and exit options.

Enable

Enables the TFTP server. The IP address displays in the Status field and Server Ready displays in the Log field.

Disable

Disables the TFTP server. When you select this option, the message PORT CLOSED displays in the Status field and Port Closed displays in the Log field.

Abort

Terminates a transfer that is in progress.

Exit

Terminates active transfers and closes the TFTP window.

Print Log

Provides print options.

...to Clipboard

Copies the information in the Log field to the clipboard. You can then open any word processor and paste the information into the program for review.

...to Printer

Sends the information in the Log field to the default printer.

Clear Log

Deletes the information stored in the Log field.

Help

Provides on-line help and version information.

Contents

Opens on-line help.

About

Displays version and owner information.

4. STATUS FIELD

This field displays general information about port and transfer status. This field is read-only. The unlabeled field in the center of the screen displays prompts about the status of active transfers, such as bytes transferred and received.

5. METER FIELD

The **XMIT** meter provides a visual record of the transfer process.

6. LOG FIELD

This field displays a record of all of the events that occur during the time the TFTP Server is enabled. Use the scroll bar to move up and down the list. To clear the information in this field, select **CLEAR LOG** from the **PRINT LOG** menu. Save this information to a file before deleting it with the **...TO CLIPBOARD** command.

MIB

This section is divided into two parts: (1) SNMP information for TDM units and (2) SNMP information for ATM units. Each section details the Management Information Bases (MIBs) supported, MIB Compilation Order, Traps Supported, and MIB Variables supported.

CONTENTS

MIBs SUPPORTED BY TDM UNITS	425
MIB Compilation Order For TDM Units	426
Traps Supported by TDM Units	426
MIB Variables Supported by TDM Units	428
MIBs SUPPORTED BY ATM UNITS	428
MIB Compilation order for ATM Units	428
Traps Supported by ATM Units	429
MIB Variables Supported by ATM Units	429



For this section, TDM units refers to Total Access 604/608/612/616/624 units running A.04 firmware or later. ATM units refers to Total Access 604/608 units running D.01.36 firmware or previous and Total Access 612/616/624 units running D.01.30 firmware or previous.



*The TDM units support SNMP Version 2.
The ATM units support SNMP Version 1.*

1. MIBs SUPPORTED BY TDM UNITS

Standard RFC MIBs:

RFC1573.mi2	IANAifType-MIB
RFC1907.mi2	SNMPv2-MIB
RFC2011.mi2	IP-MIB
RFC2096.mi2	IP-FORWARD-MIB
RFC2115.mi2	FRAME-RELAY-DTE-MIB
RFC2493.mi2	PerfHist-TC-MIB
RFC2494.mi2	DS0-MIB and DS0BUNDLE-MIB
RFC2495.mi2	DS1-MIB
RFC2665.mi2	EtherLike-MIB
RFC2863.mi2	IF-MIB
RFC3201.mi2	CIRCUIT-IF-MIB

Enterprise MIBs:

adtran.mi2	ADTRAN-MIB
adladSys.mi2	ADTRAN-ADIADSYS-MIB
adladRtr.mi2	ADTRAN-ADIADROUTER-MIB
adladVoi.mi2	ADTRAN-ADIADVOICE-MIB



SNMPv2-SMI, SNMPv2-TC, SNMPv2-TM, SNMPv2-CONF should be included with the SNMP manager.



All TDM MIBs are SNMPv2

2. MIB COMPILATION ORDER FOR TDM UNITS

IANAifType-MIB

PerfHist-TC-MIB

SNMPv2-MIB (if not included with SNMP manager)

IF-MIB

IP-MIB

IP-FORWARD-MIB

FRAME-RELAY-DTE-MIB

DS1-MIB

DS0-MIB

DS0BUNDLE-MIB

EtherLike-MIB

CIRCUIT-IF-MIB

ADTRAN-MIB

ADTRAN-IADSYS-MIB

ADTRAN-IADROUTER-MIB

3. TRAPS SUPPORTED BY TDM UNITS

From RFC1215-MIB:	coldStart linkDown linkUp authenticationFailure
-------------------	--

From ADTRAN-IADSYS-MIB:	adladWanDown - 1003203 adladWanUp - 1003204 adladBatteryAlarmAct - 1003207 adladBatteryAlarmDeact - 1003208
(T1 WAN interface only):	adladDs1RedAlarmON - 1003209 adladDs1YellowAlarmON - 1003210 adladDs1BlueAlarmON - 1003211 adladDs1RedAlarmOFF - 1003212 adladDs1YellowAlarmOFF - 1003213 adladDs1BlueAlarmOFF - 1003214 adladDs1SEF - 1003215 adladDs1FS - 1003216 adladDs1CRC - 1003217 adladDs1LCV - 1003218 adladDs1SLP - 1003219
From ADTRAN-IADVOICE-MIB:	adladVoiceTestStatusActive - 1003401 adladVoiceTestStatusClear - 1003402 adladVoiceAlarmBitActive - 1003403 adladVoiceAlarmBitInactive - 1003404 adladVoiceGatewayDown - 1003405 adladVoiceGatewayUp - 1003406 adladVoiceaLifeLineActivated - 1003407 adladVoiceaLifeLineDeactivated - 1003408

4. MIB VARIABLES SUPPORTED BY TDM UNITS

SNMPv2 states the supported MIB variables by the following method:

The unit will have a MIB called TA 6XX.mi2 that will describe what SNMP variables are supported. This MIB will contain an AGENT-CAPABILITIES MODULE that will describe the SNMP variables supported.

5. MIBs SUPPORTED BY ATM UNITS

Standard RFC MIBs:

RFC1213.mib	RFC1213-MIB
RFC1406.mib	DS1-MIB (T1 interface only)
RFC1695.mib	ATM-MIB

Enterprise MIBs:

Adtran.mib	ADTRAN-MIB
adtartr_trap.mib	ADTRAN-ADTARTR_TRAP-MIB



RFC1155-SMI, RFC1212-MIB, and RFC1215-MIB are also needed and should come standard with any SNMP Management software.



All ATM MIBs are SNMPv1.

6. MIB COMPILATION ORDER FOR ATM UNITS

RFC1213-MIB

RFC1406-MIB

RFC1695-MIB

ADTRAN-MIB

ADTRAN-ADTARTR-TRAP-MIB

7. TRAPS SUPPORTED BY ATM UNITS

From ADTARTR_TRAP MIB:	coldStart
	linkUp
	linkDown
	authenticationFailure
	adTARouterWanDown - 6645503
	adTARouterWanUp - 6645504
	adTARouterBatteryAlarmAct - 6645507
	adTARouterBatteryAlarmDeact - 6645508
	adTARouterVoiceGatewayDown - 6645509
	adTARouterVoiceGatewayUp - 6645510
	adTARouterLifeLineActivated - 6645511
	adTARouterLifeLineDeactivated - 6645512

8. MIB VARIABLES SUPPORTED BY ATM UNITS



ATM units do not support write access for SNMP (except for sysName, sysLocation, and sysContact).

system:

sysDescr	RO
sysObjectID	RO
sysUpTime	RO
sysContact	RW
sysName	RW
sysLocation	RW
sysServices	RO

interfaces:

ifIndex	RO
ifDescr	RO
ifType	RO
ifMtu	RO
ifSpeed	RO
ifPhysAddress	RO
ifOperStatus	RO
ifInOctets	RO
ifInUcastPkts	RO
ifInNUcastPkts	RO
ifInDiscards	RO
ifInErrors	RO
ifInUnknownProtos	RO
ifOutOctets	RO
ifOutUcastPkts	RO
ifOutNUcastPkts	RO
ifOutDiscards	RO
ifOutErrors	RO
ifSpecific	RO

ip:

ipForwarding	RO
ipDefaultTTL	RO
ipInReceives	RO
ipInHdrErrors	RO
ipInAddrErrors	RO
ipForwDatagrams	RO
ipInUnknownProtos	RO
ipInDiscards	RO
ipInDelivers	RO
ipOutRequests	RO
ipOutDiscards	RO
ipOutNoRoutes	RO
ipReasmOKs	RO
ipReasmFails	RO
ipFragOKs	RO
ipFragFails	RO
ipFragCreates	RO

ipAddrTable:

ipAddrEntry

ipAdEntAddr	RO
ipAdEntIfIndex	RO
ipAdEntNetMask	RO
ipAdEntBcastAddr	RO
ipAdEntReasmMaxSize	RO

ipRouteTable:

ipRouteEntry

ipRouteDest	RO
ipRouteIfIndex	RO
ipRouteMetric1	RO
ipRouteMetric2	RO
ipRouteMetric3	RO
ipRouteMetric4	RO
ipRouteNextHop	RO
ipRouteType	RO
ipRouteProto	RO
ipRouteAge	RO
ipRouteMask	RO
ipRouteMetric5	RO
ipRouteMetricInfo	RO

ipNetToMediaTable:

ipNetToMediaEntry

ipNetToMediaIfIndex	RO
ipNetToMediaPhysAddress	RO
ipNetToMediaNetAddress	RO
ipNetToMediaType	RO
ipRoutingDiscards	RO

icmp:

icmpInMsgs	RO
icmpInErrors	RO
icmpInDestUnreachs	RO
icmpInTimeExcds	RO
icmpInParmProbs	RO
icmpInSrcQuenchs	RO

icmpInRedirects	RO
icmpInEchos	RO
icmpInEchoReps	RO
icmpInTimestamps	RO
icmpInTimestampReps	RO
icmpInAddrMasks	RO
icmpInAddrMaskReps	RO
icmpOutMsgs	RO
icmpOutErrors	RO
icmpOutDestUnreachs	RO
icmpOutTimeExcds	RO
icmpOutParmProbs	RO
icmpOutSrcQuenchs	RO
icmpOutRedirects	RO
icmpOutEchos	RO
icmpOutEchoReps	RO
icmpOutTimestamps	RO
icmpOutTimestampReps	RO
icmpOutAddrMasks	RO
icmpOutAddrMaskReps	RO

tcp:

tcpRtoAlgorithm	RO
tcpRtoMin	RO
tcpRtoMax	RO
tcpMaxConns	RO
tcpActiveOpens	RO
tcpPassiveOpens	RO
tcpAttemptFails	RO
tcpEstabResets	RO

tcpCurrEstab RO

tcpInSegs RO

tcpOutSegs RO

tcpRetransSegs RO

tcpConnTable

tcpConnEntry

tcpConnState RO

tcpConnLocalAddress RO

tcpConnLocalPort RO

tcpConnRemAddress RO

tcpConnRemPort RO

tcpInErrs RO

tcpOutRsts RO

udp:

udpInDatagrams RO

udpNoPorts RO

udpInErrors RO

udpOutDatagrams RO

udpLocalAddress RO

udpLocalPort RO

udpTable

udpEntry

udpEntryLocalAddress RO

udpLocalPort RO

egp:

egpInMsgs	RO
egpInErrs	RO
egpOutMsgs	RO
egpOutErrors	RO
egpNeighState	RO
egpNeighAddr	RO
egpNeighAs	RO
egpNeighInMsgs	RO
egpNeighInErrs	RO
egpNeighOutMsgs	RO
egpNeighOutErrs	RO
egpNeighInErrMsgs	RO
egpNeighOutErrMsgs	RO
egpNeighStateUps	RO
egpNeighStateDowns	RO
egpNeighIntervalHello	RO
egpNeighIntervalPoll	RO
egpNeighMode	RO

dsx1:

dsx1ConfigTable

dsx1ConfigEntry

dsx1LineIndex	RO
dsx1IfIndex	RO
dsx1TimeElapsed	RO
dsx1ValidIntervals	RO
dsx1LineType	RO
dsx1LineCoding	RO
dsx1SendCode	RO

dsx1CircuitIdentifier	RO
dsx1LoopbackConfig	RO
dsx1LineStatus	RO
dsx1SignalMode	RO
dsx1TransmitClockSource	RO
dsx1Fdl	RO

dsx1CurrentTable

dsx1CurrentEntry

dsx1CurrentIndex	RO
dsx1CurrentESs	RO
dsx1CurrentSESSs	RO
dsx1CurrentSEFs	RO
dsx1CurrentUASs	RO
dsx1CurrentCSSs	RO
dsx1CurrentPCVs	RO
dsx1CurrentLESSs	RO
dsx1CurrentBESSs	RO
dsx1CurrentLCVs	RO

dsx1IntervalTable

dsx1IntervalEntry

dsx1IntervalIndex	RO
dsx1IntervalNumber	RO
dsx1IntervalESs	RO
dsx1IntervalSESSs	RO
dsx1IntervalSEFs	RO
dsx1IntervalUASs	RO
dsx1IntervalCSSs	RO
dsx1IntervalPCVs	RO

dsx1IntervalESs	RO
dsx1IntervalBESs	RO
dsx1IntervalLCVs	RO
dsx1TotalTable	
dsx1TotalEntry	
dsx1TotalIndex	RO
dsx1TotalESs	RO
dsx1TotalSESs	RO
dsx1TotalSEFs	RO
dsx1TotalUASs	RO
dsx1TotalCSSs	RO
dsx1TotalPCVs	RO
dsx1TotalLESs	RO
dsx1TotalBESs	RO
dsx1TotalLCVs	RO
dsx1FracTable	
dsx1FracEntry	
dsx1FracIndex	RO
dsx1FracNumber	RO
dsx1FractIfIndex	RO

snmp:

snmpInPkts	RO
snmpOutPkts	RO
snmpInBadVersions	RO
snmpInBadCommunityNames	RO
snmpInBadCommunityUses	RO
snmpInASNParseErrs	RO
snmpInTooBigs	RO
snmpInNoSuchNames	RO
snmpInBadValues	RO
snmpInReadOnlys	RO
snmpInGenErrs	RO
snmpInTotalReqVars	RO
snmpInTotalSetVars	RO
snmpInGetRequests	RO
snmpInSetRequests	RO
snmpInGetRequests	RO
snmpInTraps	RO
snmpOutTooBigs	RO
snmpOutNoSuchNames	RO
snmpOutBadValues	RO
snmpOutGenErrs	RO
snmpOutGetRequests	RO
snmpOutGetNexts	RO
snmpOutSetRequests	RO
snmpOutGetRepsonses	RO
snmpOutTraps	RO
snmpEnableAuthenTraps	RO

atm:

atmInterfaceTable

atmInterfaceEntry

atmInterfaceMaxVpcs	RO
atmInterfaceMaxVccs	RO
atmInterfaceConfVpcs	RO
atmInterfaceConfVccs	RO
atmInterfaceMaxActiveVpiBits	RO
atmInterfaceMaxActiveVciBits	RO
atmInterfaceIImiVpi	RO
atmInterfaceIImiVci	RO
atmInterfaceAddressType	RO
atmInterfaceAdminAddress	RO
atmInterfaceMyNeighborIpAddress	RO
atmInterfaceMyNeighborIfName	RO

atmInterfaceTCTable

atmInterfaceTCEntry

atmInterfaceOCDEvents	RO
atmInterfaceTCAlarmState	RO

atmTrafficDescrParamTable

atmTrafficDescrParamEntry

atmTrafficDescrParamIndex	RO
atmTrafficDescrType	RO
atmTrafficDescrParam1	RO
atmTrafficDescrParam2	RO
atmTrafficDescrParam3	RO
atmTrafficDescrParam4	RO
atmTrafficDescrParam5	RO

	atmTrafficDescrQosClass	RO
	atmTrafficDescrRowStatus	RO
atmVclTable		
atmVclEntry		
	atmVclVpi	RO
	atmVclVci	RO
	atmVclAdminStatus	RO
	atmVclOperStatus	RO
	atmVclLastChange	RO
	atmVclReceiveTrafficDescrIndex	RO
	atmVclTransmitTrafficDescrIndex	RO
	atmVccAalType	RO
	atmVccAal5CpcsTransmitSduSize	RO
	atmVccAal5CpcsReceiveSduSize	RO
	atmVccAal5EncapsType	RO
	atmVclCrossConnectIdentifier	RO
	atmVclRowStatus	RO
aal5VccTable		
aal5VccEntry		
	aal5VccVpi	RO
	aal5VccVci	RO
	aal5VccCrcErrors	RO
	aal5VccSarTimeOuts	RO
	aal5VccOverSizedSDUs	RO

