

Configuring SNMP, BootP, DHCP, and RARP Services

BayRS Version 13.10
Site Manager Software Version 7.10

BCC Version 4.10

Part No. 117362-C Rev 00
November 1998



Bay Networks

Where Information Flows.™



4401 Great America Parkway
Santa Clara, CA 95054

8 Federal Street
Billerica, MA 01821

Copyright © 1998 Bay Networks, Inc.

All rights reserved. Printed in the USA. November 1998.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Bay Networks, Inc.

The software described in this document is furnished under a license agreement and may only be used in accordance with the terms of that license. A summary of the Software License is included in this document.

Trademarks

ACE, AFN, AN, BCN, BLN, BN, BNX, CN, FRE, LN, Optivity, PPX, Quick2Config, and Bay Networks are registered trademarks and Advanced Remote Node, ANH, ARN, ASN, BayRS, BaySecure, BayStack, BayStream, BCC, BCNX, BLNX, EZ Install, EZ Internetwork, EZ LAN, FN, IP AutoLearn, PathMan, RouterMan, SN, SPEX, Switch Node, System 5000, and the Bay Networks logo are trademarks of Bay Networks, Inc.

All other trademarks and registered trademarks are the property of their respective owners.

Restricted Rights Legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

Statement of Conditions

In the interest of improving internal design, operational function, and/or reliability, Bay Networks, Inc. reserves the right to make changes to the products described in this document without notice.

Bay Networks, Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product may be Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

Bay Networks, Inc. Software License Agreement

NOTICE: Please carefully read this license agreement before copying or using the accompanying software or installing the hardware unit with pre-enabled software (each of which is referred to as “Software” in this Agreement). BY COPYING OR USING THE SOFTWARE, YOU ACCEPT ALL OF THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT. THE TERMS EXPRESSED IN THIS AGREEMENT ARE THE ONLY TERMS UNDER WHICH BAY NETWORKS WILL PERMIT YOU TO USE THE SOFTWARE. If you do not accept these terms and conditions, return the product, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

1. License Grant. Bay Networks, Inc. (“Bay Networks”) grants the end user of the Software (“Licensee”) a personal, nonexclusive, nontransferable license: a) to use the Software either on a single computer or, if applicable, on a single authorized device identified by host ID, for which it was originally acquired; b) to copy the Software solely for backup purposes in support of authorized use of the Software; and c) to use and copy the associated user manual solely in support of authorized use of the Software by Licensee. This license applies to the Software only and does not extend to Bay Networks Agent software or other Bay Networks software products. Bay Networks Agent software or other Bay Networks software products are licensed for use under the terms of the applicable Bay Networks, Inc. Software License Agreement that accompanies such software and upon payment by the end user of the applicable license fees for such software.

2. Restrictions on use; reservation of rights. The Software and user manuals are protected under copyright laws. Bay Networks and/or its licensors retain all title and ownership in both the Software and user manuals, including any revisions made by Bay Networks or its licensors. The copyright notice must be reproduced and included with any copy of any portion of the Software or user manuals. Licensee may not modify, translate, decompile, disassemble, use for any competitive analysis, reverse engineer, distribute, or create derivative works from the Software or user manuals or any copy, in whole or in part. Except as expressly provided in this Agreement, Licensee may not copy or transfer the Software or user manuals, in whole or in part. The Software and user manuals embody Bay Networks’ and its licensors’ confidential and proprietary intellectual property. Licensee shall not sublicense, assign, or otherwise disclose to any third party the Software, or any information about the operation, design, performance, or implementation of the Software and user manuals that is confidential to Bay Networks and its licensors; however, Licensee may grant permission to its consultants, subcontractors, and agents to use the Software at Licensee’s facility, provided they have agreed to use the Software only in accordance with the terms of this license.

3. Limited warranty. Bay Networks warrants each item of Software, as delivered by Bay Networks and properly installed and operated on Bay Networks hardware or other equipment it is originally licensed for, to function substantially as described in its accompanying user manual during its warranty period, which begins on the date Software is first shipped to Licensee. If any item of Software fails to so function during its warranty period, as the sole remedy Bay Networks will at its discretion provide a suitable fix, patch, or workaround for the problem that may be included in a future Software release. Bay Networks further warrants to Licensee that the media on which the Software is provided will be free from defects in materials and workmanship under normal use for a period of 90 days from the date Software is first shipped to Licensee. Bay Networks will replace defective media at no charge if it is returned to Bay Networks during the warranty period along with proof of the date of shipment. This warranty does not apply if the media has been damaged as a result of accident, misuse, or abuse. The Licensee assumes all responsibility for selection of the Software to achieve Licensee’s intended results and for the installation, use, and results obtained from the Software. Bay Networks does not warrant a) that the functions contained in the software will meet the Licensee’s requirements, b) that the Software will operate in the hardware or software combinations that the Licensee may select, c) that the operation of the Software will be uninterrupted or error free, or d) that all defects in the operation of the Software will be corrected. Bay Networks is not obligated to remedy any Software defect that cannot be reproduced with the latest Software release. These warranties do not apply to the Software if it has been (i) altered, except by Bay Networks or in accordance with its instructions; (ii) used in conjunction with another vendor’s product, resulting in the defect; or (iii) damaged by improper environment, abuse, misuse, accident, or negligence. THE FOREGOING WARRANTIES AND LIMITATIONS ARE EXCLUSIVE REMEDIES AND ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Licensee is responsible for the security of

its own data and information and for maintaining adequate procedures apart from the Software to reconstruct lost or altered files, data, or programs.

4. Limitation of liability. IN NO EVENT WILL BAY NETWORKS OR ITS LICENSORS BE LIABLE FOR ANY COST OF SUBSTITUTE PROCUREMENT; SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES; OR ANY DAMAGES RESULTING FROM INACCURATE OR LOST DATA OR LOSS OF USE OR PROFITS ARISING OUT OF OR IN CONNECTION WITH THE PERFORMANCE OF THE SOFTWARE, EVEN IF BAY NETWORKS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL THE LIABILITY OF BAY NETWORKS RELATING TO THE SOFTWARE OR THIS AGREEMENT EXCEED THE PRICE PAID TO BAY NETWORKS FOR THE SOFTWARE LICENSE.

5. Government Licensees. This provision applies to all Software and documentation acquired directly or indirectly by or on behalf of the United States Government. The Software and documentation are commercial products, licensed on the open market at market prices, and were developed entirely at private expense and without the use of any U.S. Government funds. The license to the U.S. Government is granted only with restricted rights, and use, duplication, or disclosure by the U.S. Government is subject to the restrictions set forth in subparagraph (c)(1) of the Commercial Computer Software—Restricted Rights clause of FAR 52.227-19 and the limitations set out in this license for civilian agencies, and subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause of DFARS 252.227-7013, for agencies of the Department of Defense or their successors, whichever is applicable.

6. Use of Software in the European Community. This provision applies to all Software acquired for use within the European Community. If Licensee uses the Software within a country in the European Community, the Software Directive enacted by the Council of European Communities Directive dated 14 May, 1991, will apply to the examination of the Software to facilitate interoperability. Licensee agrees to notify Bay Networks of any such intended examination of the Software and may procure support and assistance from Bay Networks.

7. Term and termination. This license is effective until terminated; however, all of the restrictions with respect to Bay Networks' copyright in the Software and user manuals will cease being effective at the date of expiration of the Bay Networks copyright; those restrictions relating to use and disclosure of Bay Networks' confidential information shall continue in effect. Licensee may terminate this license at any time. The license will automatically terminate if Licensee fails to comply with any of the terms and conditions of the license. Upon termination for any reason, Licensee will immediately destroy or return to Bay Networks the Software, user manuals, and all copies. Bay Networks is not liable to Licensee for damages in any form solely by reason of the termination of this license.

8. Export and Re-export. Licensee agrees not to export, directly or indirectly, the Software or related technical data or information without first obtaining any required export licenses or other governmental approvals. Without limiting the foregoing, Licensee, on behalf of itself and its subsidiaries and affiliates, agrees that it will not, without first obtaining all export licenses and approvals required by the U.S. Government: (i) export, re-export, transfer, or divert any such Software or technical data, or any direct product thereof, to any country to which such exports or re-exports are restricted or embargoed under United States export control laws and regulations, or to any national or resident of such restricted or embargoed countries; or (ii) provide the Software or related technical data or information to any military end user or for any military end use, including the design, development, or production of any chemical, nuclear, or biological weapons.

9. General. If any provision of this Agreement is held to be invalid or unenforceable by a court of competent jurisdiction, the remainder of the provisions of this Agreement shall remain in full force and effect. This Agreement will be governed by the laws of the state of California.

Should you have any questions concerning this Agreement, contact Bay Networks, Inc., 4401 Great America Parkway, P.O. Box 58185, Santa Clara, California 95054-8185.

LICENSEE ACKNOWLEDGES THAT LICENSEE HAS READ THIS AGREEMENT, UNDERSTANDS IT, AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. LICENSEE FURTHER AGREES THAT THIS AGREEMENT IS THE ENTIRE AND EXCLUSIVE AGREEMENT BETWEEN BAY NETWORKS AND LICENSEE, WHICH SUPERSEDES ALL PRIOR ORAL AND WRITTEN AGREEMENTS AND COMMUNICATIONS BETWEEN THE PARTIES PERTAINING TO THE SUBJECT MATTER OF THIS AGREEMENT. NO DIFFERENT OR ADDITIONAL TERMS WILL BE ENFORCEABLE AGAINST BAY NETWORKS UNLESS BAY NETWORKS GIVES ITS EXPRESS WRITTEN CONSENT, INCLUDING AN EXPRESS WAIVER OF THE TERMS OF THIS AGREEMENT.

Contents

Preface

Before You Begin	i
Text Conventions	ii
Acronyms	iii
Bay Networks Technical Publications	iv
How to Get Help	iv

Chapter 1

Starting SNMP, BootP, DHCP, and RARP Services

Starting Configuration Tools	1-2
Configuring IP for Global Protocols	1-2
Step 1: Configuring a Physical Interface	1-3
Step 2: Configuring an IP Interface	1-4
Starting SNMP Services	1-4
Customizing SNMP Services	1-6
Starting BootP Services	1-6
Enabling BootP on an Interface	1-6
Customizing BootP	1-7
Starting BootP/DHCP Relay	1-8
Enabling BootP/DHCP on an Interface	1-8
Customizing DHCP	1-9
Starting a DHCP Server	1-9
Customizing the DHCP Server	1-10
Starting RARP Services	1-11
Enabling RARP on an Interface	1-11
Customizing RARP	1-12

Chapter 2

SNMP, BootP, BootP/DHCP Relay, DHCP Server, and RARP Concepts

SNMP Overview	2-1
SNMP Messages	2-2
SNMP Communities	2-3
SNMP Implementation Notes	2-4
Internet Protocol	2-4
Events and Traps	2-4
Protocol Entities	2-5
Severity Levels	2-5
SNMP Trap Format	2-6
Thresholds	2-7
Threshold Example	2-8
Event Message Format	2-8
State of a Threshold	2-9
Memory Considerations	2-9
BootP Relay Agent Overview	2-10
DHCP Overview	2-14
Why Use DHCP?	2-14
Dynamic IP Address Allocation	2-15
DHCP Components	2-16
DHCP Clients	2-16
DHCP Server	2-16
NetID Server Manager	2-16
BootP/DHCP Relay Implementation	2-17
DHCP Server Implementation	2-18
Acquiring an IP Address from a Router Configured as a BootP Relay Agent	2-19
Identifying DHCP Servers	2-20
Requesting and Receiving IP Information	2-23
Accepting or Declining IP Information	2-24
How Clients Acquire IP Addresses Using a DHCP Server	2-24
Identifying DHCP Servers	2-25
Requesting and Receiving IP Information	2-26
Accepting or Declining IP Information	2-27
Acquiring the Same IP Address Again	2-27

Using a Router Configured as a BootP Relay Agent	2-28
Using a DHCP Server	2-28
RARP Overview	2-29

Chapter 3

Customizing SNMP

Configuring SNMP Using the BCC and Site Manager	3-2
Customizing SNMP Global Parameters	3-3
Disabling and Reenabling SNMP	3-3
Enabling and Disabling SNMP Lock Mechanism	3-4
Specifying a Lock Address	3-6
Specifying a Lock Timeout Value	3-6
Enabling and Disabling Authentication Failure Traps	3-7
Specifying the Type of Service for the SNMP Packet	3-9
Adding SNMP Communities	3-9
Specifying an SNMP Community Name	3-9
Specifying Community Access Privileges	3-10
Deleting an SNMP Community	3-12
Configuring SNMP Community Managers	3-12
Adding a Manager	3-13
Configuring a Manager to Receive Traps	3-14
Specifying the Trap Port	3-14
Specifying a Trap Type	3-16
Deleting a Manager	3-17
Configuring Traps on the Router	3-19
Specifying a Trap Entity	3-19
Specifying the Severity Level for Traps	3-21
Disabling a Trap Entity	3-22
Configuring Trap Exceptions	3-23
Deleting Trap Exceptions	3-25
Configuring Thresholds	3-26
Disabling and Reenabling Thresholds	3-27
Setting the Threshold Polling Interval	3-27
Adding a Threshold	3-28
Enabling and Disabling Thresholds for a Variable	3-29
Specifying a Value for the Threshold Level	3-30

Specifying the Severity Level for Event Messages	3-30
Specifying Threshold Units	3-31
Determining When to Record Threshold Events	3-32
Specifying Maximum Successive Alarms	3-33
Specifying Polling Intervals for Held Variables	3-34
Specifying a Threshold Object Name	3-35

Chapter 4

Customizing BootP

Customizing BootP Relay Agent Parameters	4-2
Disabling and Reenabling BootP	4-2
Specifying Maximum Number of Hops from Client to Server	4-2
Specifying a Minimum Timeout Value	4-3
Specifying the Relay Mode for Packet Forwarding	4-4
Setting Up the Routing Path Between the BootP Server and the Routers	4-5
Enabling BootP on Router Interfaces	4-5
Specifying Interfaces to Receive and Relay BOOTREQUEST Packets	4-7
Creating a BootP Relay Agent Forwarding Table	4-8
Specifying the IP Interface Input/Output Address Pair	4-8
Deleting an IP Interface Input/Output Address Pair	4-9
Disabling BootP Route Forwarding	4-10
Configuring an AN to Use EZ Install over a Frame Relay PVC	4-11
Creating a BootP Client Interface Table	4-11
Specifying the Client IP Address	4-11
Specifying the DLCI Number	4-12
Specifying Servers for BootP Services	4-13
Configuring BootP Preferred Servers	4-13
Specifying the Relay Agent IP Address	4-14
Specifying the Target Server IP Address	4-14
Specifying the Target Server's Host Name	4-15
Disabling the Forwarding Route	4-16
Filtering BootP and DHCP Packets	4-17
Deleting the BootP Relay Agent from an IP Interface	4-18
Deleting BootP Globally	4-18

Chapter 5

Customizing BootP/DHCP Relay

Setting Up the Routing Path Between the DHCP Server and a BootP Relay Agent	5-2
Specifying Interfaces to Receive and Forward DHCP Packets	5-2
Defining DHCP Servers	5-3
Deleting BootP/DHCP Relay from an IP Interface	5-4
Deleting BootP/DHCP Relay Globally	5-5

Chapter 6

Customizing the DHCP Server

Modifying the DHCP Server Configuration	6-2
Reenabling and Disabling the DHCP Server on the Router	6-2
Configuring the NetID Server Manager IP Address	6-3
Specifying the DHCP Server TCP Port Number	6-3
Determining Whether an IP Address Is Available on the Network	6-4
Changing the Ping Timeout Value	6-5
Specifying the DHCP Server Operating Mode	6-6
Specifying Maximum Number of Pending Leases	6-7
Specifying the Debug Level	6-8
Specifying the IP Address for the DHCP Server	6-9
Deleting the DHCP Server on the Router	6-9
Deleting DHCP Globally	6-10

Chapter 7

Customizing RARP

Customizing RARP Parameters	7-2
Disabling and Reenabling RARP Interfaces	7-2
Defining the RARP Mapping Table	7-3
Specifying the Client's MAC Address	7-3
Specifying the Client's IP Address	7-4
Disabling RARP Globally	7-5
Deleting RARP Globally	7-5

Appendix A

SNMP, BootP, DHCP, and RARP Parameter Descriptions

SNMP Global Parameters	A-3
SNMP Community Parameters	A-5
SNMP Manager Parameters	A-6
SNMP Trap Interface Parameters	A-7
SNMP Threshold Global Parameters	A-8
SNMP Threshold Interface Parameters	A-9
BootP and DHCP Parameters	A-16
BootP Relay Agent Interface Parameters	A-16
BootP Address Parameters	A-18
BootP Client Interface Address Parameters	A-21
BootP Preferred Server Configuration Parameters	A-22
DHCP Global Parameters	A-24
RARP Interface Parameters	A-28
RARP Address Parameters	A-28

Appendix B

Default Parameter Settings

SNMP Parameters	B-1
BootP and DHCP Parameters	B-3
RARP Parameters	B-5

Index

Figures

Figure 2-1.	Role of SNMP	2-3
Figure 2-2.	BootP Client and Server on the Same Physical Network	2-10
Figure 2-3.	BootP Client and Server on Different Physical Networks	2-11
Figure 2-4.	BOOTREQUEST and BOOTREPLY Fields	2-12
Figure 2-5.	BootP/DHCP Relay Implementation	2-18
Figure 2-6.	DHCP Server Implementation	2-19
Figure 2-7.	Identifying DHCP Servers (BootP Relay Agent)	2-20
Figure 2-8.	Requesting and Receiving IP Information (BootP Relay Agent)	2-23
Figure 2-9.	Identifying DHCP Servers	2-25
Figure 2-10.	Requesting and Receiving IP Information (DHCP Server)	2-26
Figure 2-11.	RARP Server Supplying an IP Address	2-29
Figure 4-1.	Enabling BootP in a Sample Network	4-6

Tables

Table 2-1.	Severity Levels	2-5
Table 2-2.	Example of Threshold and Severity Settings	2-8
Table 2-3.	IP Address Types Allocated by DHCP	2-15
Table 2-4.	Fields in a DHCP Packet	2-21
Table 3-1.	SNMP Configuration Tasks	3-2
Table 3-2.	Trap Types Transmitted by the SNMP Agent	3-16
Table B-1.	SNMP Global Parameters	B-1
Table B-2.	SNMP Community Parameters	B-1
Table B-3.	SNMP Manager Parameters	B-2
Table B-4.	SNMP Trap Interface Parameters	B-2
Table B-5.	SNMP Threshold Global Parameters	B-2
Table B-6.	SNMP Threshold Interface Parameters	B-2
Table B-7.	BootP Relay Agent Interface Parameters	B-3
Table B-8.	BootP Address Parameters	B-3
Table B-9.	BootP Client Interface Address Parameters	B-4
Table B-10.	BootP Preferred Server Configuration Parameters	B-4
Table B-11.	DHCP Global Parameters	B-4
Table B-12.	RARP Interface Parameters	B-5
Table B-13.	RARP Address Parameters	B-5

This guide describes Simple Network Management Protocol (SNMP), Bootstrap Protocol (BootP), BootP/Dynamic Host Configuration Protocol (DHCP) Relay, DHCP server, and Reverse Address Resolution Protocol (RARP) services and what you need to do to start and customize them on a Bay Networks® router.

You can use the Bay Command Console (BCC™) or Site Manager to configure SNMP services on a router on a router; you must use Site Manager to configure BootP, DHCP relay, DHCP server, and RARP services. In this guide, you will find instructions for using both the BCC and Site Manager.

Before You Begin

Before using this guide, you must complete the following procedures. For a new router:

- Install the router (see the installation guide that came with your router).
- Connect the router to the network and create a pilot configuration file (see *Quick-Starting Routers*, *Configuring BayStack Remote Access*, or *Connecting ASN Routers to a Network*).

Make sure that you are running the latest version of Bay Networks BayRS™ and Site Manager software. For information about upgrading BayRS and Site Manager, see the upgrading guide for your version of BayRS.

Text Conventions

This guide uses the following text conventions:

angle brackets (< >)	<p>Indicate that you choose the text to enter based on the description inside the brackets. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is: ping <ip_address>, you enter: ping 192.32.10.12</p>
bold text	<p>Indicates command names and options and text that you need to enter.</p> <p>Example: Enter show ip {alerts routes}.</p> <p>Example: Use the dinfo command.</p>
braces ({ })	<p>Indicate required elements in syntax descriptions where there is more than one option. You must choose only one of the options. Do not type the braces when entering the command.</p> <p>Example: If the command syntax is: show ip {alerts routes}, you must enter either: show ip alerts or show ip routes, but not both.</p>
brackets ([])	<p>Indicate optional elements in syntax descriptions. Do not type the brackets when entering the command.</p> <p>Example: If the command syntax is: show ip interfaces [-alerts], you can enter either: show ip interfaces or show ip interfaces -alerts.</p>
<i>italic text</i>	<p>Indicates file and directory names, new terms, book titles, and variables in command syntax descriptions. Where a variable is two or more words, the words are connected by an underscore.</p> <p>Example: If the command syntax is: show at <valid_route> <i>valid_route</i> is one variable and you substitute one value for it.</p>

screen text	Indicates system output, for example, prompts and system messages. Example: Set Bay Networks Trap Monitor Filters
separator (>)	Shows menu paths. Example: Protocols > IP identifies the IP option on the Protocols menu.
vertical line ()	Separates choices for command keywords and arguments. Enter only one of the choices. Do not type the vertical line when entering the command. Example: If the command syntax is: show ip {alerts routes} , you enter either: show ip alerts or show ip routes , but not both.

Acronyms

This guide uses the following acronyms:

ASN.1	abstract syntax notation
BCC	Bay Command Console
BootP	Bootstrap Protocol
DHCP	Dynamic Host Configuration Protocol
IP	Internet Protocol
MAC	media access control
MIB	management information base
RARP	Reverse Address Resolution Protocol
RMON	remote monitoring
PPP	Point-to-Point Protocol
SNMP	Simple Network Management Protocol
TFTP	Trivial File Transfer Protocol
UDP	User Datagram Protocol
WAN	wide area network

Bay Networks Technical Publications

You can now print Bay Networks technical manuals and release notes free, directly from the Internet. Go to support.baynetworks.com/library/tpubs/. Find the Bay Networks product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Using Adobe Acrobat Reader, you can open the manuals and release notes, search for the sections you need, and print them on most standard printers. You can download Acrobat Reader free from the Adobe Systems Web site, www.adobe.com.

You can purchase Bay Networks documentation sets, CDs, and selected technical publications through the Bay Networks Collateral Catalog. The catalog is located on the World Wide Web at support.baynetworks.com/catalog.html and is divided into sections arranged alphabetically:

- The “CD ROMs” section lists available CDs.
- The “Guides/Books” section lists books on technical topics.
- The “Technical Manuals” section lists available printed documentation sets.

Make a note of the part numbers and prices of the items that you want to order. Use the “Marketing Collateral Catalog description” link to place an order and to print the order form.

How to Get Help

For product assistance, support contracts, information about educational services, and the telephone numbers of our global support offices, go to the following URL:

<http://www.baynetworks.com/corporate/contacts/>

In the United States and Canada, you can dial 800-2LANWAN for assistance.

Chapter 1

Starting SNMP, BootP, DHCP, and RARP Services

This chapter describes how to create a basic SNMP, BootP, BootP/DHCP relay, and RARP configuration by specifying values for required parameters only, and accepting default values for all other parameters of these services.

Topic	Page
Starting Configuration Tools	1-2
Configuring IP for Global Protocols	1-2
Starting SNMP Services	1-4
Starting BootP Services	1-6
Starting BootP/DHCP Relay	1-8
Starting a DHCP Server	1-9
Starting RARP Services	1-11

For background information about these protocols, see Chapter 2. For information on how to customize these protocols by changing their default values, see Chapters 3 to 7. For information about changing the default settings, see Appendix A.

Starting Configuration Tools

Before configuring SNMP, BootP, DHCP, and RARP services, refer to the following user guides for instructions on how to start and use the Bay Networks configuration tool of your choice.

Configuration Tool	User Guide
Bay Command Console (BCC)	<i>Using the Bay Command Console (AN/BN Routers)</i>
Site Manager	<i>Configuring and Managing Routers with Site Manager</i>

These guides also describe generically how to create or modify a device configuration.

Configuring IP for Global Protocols

SNMP, BootP, DHCP, and RARP services all use the Internet Protocol (IP) for message transport. Before you configure SNMP, BootP, DHCP, and RARP services using the BCC or Site Manager, you must first start IP on the router.

Using Site Manager

Before you can select a protocol to run on the router, you must configure a circuit that the protocol can use as an interface to an attached network. For information and instructions, see *Configuring WAN Line Services* and *Configuring Ethernet, FDDI, and Token Ring Services*.

When you have successfully configured the circuit, the Select Protocols window opens. Proceed as follows:

Site Manager Procedure	
You do this	System responds
1. In the Select Protocols window, select IP . Then click on OK .	The IP Configuration window opens.
2. Set the following parameters: <ul style="list-style-type: none"> • IP Address • Subnet Mask • Transmit Bcast Addr • UnNumbered Assoc Address Click on Help or refer to <i>Configuring IP Services</i> for parameter descriptions.	
3. Click on OK .	You return to the Configuration Manager window.

Using the BCC

To start IP on the router:

1. **Configure a physical interface on an available slot/connector.**
2. **Configure an IP interface on the physical interface.**

Step 1: Configuring a Physical Interface

To configure a physical interface on a slot and connector, navigate to the top-level box prompt and enter:

```
<interface_type> slot <slot_number> connector <connector_number>
```

interface_type is the name of a link module on the router.

slot_number is the number of the slot on which the link module is located.

connector_number is the number of a connector on the link module.

For example, the following command configures an Ethernet interface on slot 1, connector 2.

```
box# ethernet slot 1 connector 2
ethernet/1/2#
```

Step 2: Configuring an IP Interface

To configure an IP interface on a physical interface, navigate to the prompt for the physical interface and enter:

ip address <address> **mask** <mask>

address and *mask* are a valid IP address and its associated mask, expressed in either dotted-decimal notation or in bit notation.

For example, the following command configures IP interface 2.2.2.2/255.0.0.0 on an Ethernet physical interface on slot 1, connector 2.

```
ethernet/1/2# ip address 2.2.2.2 mask 255.0.0.0  
ip/2.2.2.2/255.0.0.0#
```

An IP interface is now configured on the Ethernet interface with default values for all interface parameters. When you configure an IP interface, the BCC also configures IP globally on the router with default values for all IP global parameters.

You can customize IP by modifying IP global and interface parameters as described in *Configuring IP Services*.

Starting SNMP Services

You can use the BCC command line interface or the Site Manager graphical user interface to start SNMP on the router, using default values for all parameters. Before you begin, verify that you have configured IP on an interface, as described in “[Configuring IP for Global Protocols](#),” on [page 1-2](#).

Using the BCC

To configure SNMP on the router with default settings, begin in configuration mode at the box-level prompt:

1. Configure SNMP.

```
box# snmp
```

2. Display SNMP default settings.

```
snmp# info
  on box
  state enabled
  lock enabled
  lock-address 0.0.0.0
  lock-timeout 2
  authentication-traps enabled
  type-of-service reliability
  scope-delimiter 0x40
```

Using Site Manager

You can easily start SNMP services using default values for all parameters. If you decide to change some or all of the default values, refer to the instructions in Chapter 3, “Customizing SNMP.” For a list of SNMP parameters, see Appendix B, “Default Parameter Settings.”

Before you can start SNMP services, you must verify that you have configured IP on an interface, as described in [“Configuring IP for Global Protocols,” on page 1-2](#).

To start SNMP, perform the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. From the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP Global Protocols menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Global .	The Edit SNMP Global Protocols Parameter window opens.
5. Accept all default parameter values and click on OK . SNMP is now fully operational.	You return to the Configuration Manager window.

Customizing SNMP Services

The instructions in this chapter show you how to start SNMP using the default values and settings. For information about modifying SNMP default settings, refer to Chapter 3, “Customizing SNMP.”

Starting BootP Services

You must use Site Manager to start BootP. The BCC is not supported.

You can easily start BootP using default values for all parameters. If you decide to change some or all of the default values, refer to the instructions in Chapter 4.

Before you begin, verify that you have configured IP on an interface, as described in “[Configuring IP for Global Protocols](#)” on [page 1-2](#). You can, however, enable IP and BootP on an interface simultaneously. If you want to add BootP to a circuit on which you have already configured IP, refer to *Configuring and Managing Routers with Site Manager* for more information about adding a protocol.

Enabling BootP on an Interface

When you select either a link- or net-module connector, or when you finish configuring a WAN circuit, the Select Protocols window opens.



Note: The Select Protocols window displays only those protocols that the circuit type supports.

To enable BootP on an interface, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, select the link- or net-module connector on which you are enabling BootP services.	The Select Protocols window opens.
2. Choose BOOTP . When you choose BOOTP, you automatically choose IP.	The BOOTP menu opens.
3. Click on OK .	The IP Configuration window opens.
4. Specify an IP address for this interface. There is no default for the IP address. You must supply an address or enter 0.0.0.0 to indicate that this is an unnumbered interface. For information about unnumbered interfaces, see <i>Configuring IP Services</i> .	
5. Edit or accept default values for the remaining IP interface parameters: <ul style="list-style-type: none">• To accept the default values, click on OK.• To edit IP interface parameters, click on Details. For information about editing IP interface parameters, see <i>Configuring IP Services</i>.	

Customizing BootP

For information about customizing BootP parameters, see Chapter 4, “Customizing BootP.”

Starting BootP/DHCP Relay

You must use Site Manager to start BootP/DHCP relay. The BCC is not supported.

You can easily start BootP/DHCP relay using default values for all parameters. If you decide to change some or all of the default values, refer to the instructions in Chapter 5.

Before you begin, you must verify that you have configured IP on an interface, as described in “[Configuring IP for Global Protocols](#)” on [page 1-2](#). You can, however, enable IP, BootP, and BootP/DHCP on the router simultaneously.

If you want to add BootP and BootP/DHCP relay to a circuit on which you have already configured IP, see *Configuring and Managing Routers with Site Manager* for information about adding a protocol.

Enabling BootP/DHCP on an Interface

When you select either a link- or net-module connector, or when you finish configuring a WAN circuit, the Select Protocols window opens.



Note: The Select Protocols window displays only those protocols that the circuit type supports.

To enable BootP/DHCP relay on an interface, complete the following tasks:

Site Manager Procedure	
You do this	For instructions, see
1. Enable BootP on the interface.	“ Enabling BootP on an Interface ” on page 1-6 .
2. Access the BootP Relay Agent Interface Table window.	“Customizing BootP Relay Agent Parameters” on page 4-2.
3. Set the Pass Through Mode parameter to DHCP, or to BootP and DHCP. This action allows you to select either DHCP, or BootP and DHCP, for the Pass Through Mode parameter in other windows.	“Specifying the Relay Mode for Packet Forwarding” on page 4-4.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	For instructions, see
4. Click on Apply .	
5. Edit the other parameters in this window.	"Customizing BootP Relay Agent Parameters" on page 4-2.

Customizing DHCP

For information about modifying BootP/DHCP parameters, see Chapter 5, "Customizing DHCP."

Starting a DHCP Server

You must use Site Manager to start a DHCP server. The BCC is not supported.

Before you begin, you must do the following:

1. Verify that you have configured IP on an interface, as described in "[Configuring IP for Global Protocols](#)" on [page 1-2](#).
2. Configure TCP on a router. For instructions on how to configure TCP on a router, see *Configuring IP Utilities*.
3. Configure the NetID® Server Manager to communicate with the DHCP server.

For the DHCP server to operate, you must first install the NetID Server Manager on a Unix or NT workstation and configure it to communicate with the DHCP server. Typically, you install the NetID Server Manager on the same workstation as the one that contains the NetID database.

Because the DHCP server uses the information in the NetID database to assign IP addresses and host configuration information, you need to set up your network configuration using the NetID Management Console before the DHCP server can operate correctly.

Using the NetID Management Console, you configure a DHCP server and make IP addresses available for dynamic allocation. For more information about installing the NetID Server Manager and setting your network configuration using the NetID Management Console, see the *NetID System Administrator's Guide*.

To create and enable the DHCP server on the router, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.
4. Choose Create DHCP .	

After you create and enable the DHCP server on the router, you must enable the DHCP server on an IP interface. By default, the DHCP server is disabled on an IP interface. To enable the DHCP server on an IP interface, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens.
5. Set the DHCP Server Enable parameter. Click on Help or see the parameter description on page A-18.	
6. Click on Apply .	
7. Click on Done .	You return to the Configuration Manager window.

Customizing the DHCP Server

For information about modifying DHCP server parameters, see Chapter 6, “Customizing the DHCP Server.”

Starting RARP Services

Before you can enable RARP services, you must enable IP on the router. You can, however, enable IP and RARP services on the router simultaneously. If you want to add RARP to a circuit on which you have already configured IP, see *Configuring and Managing Routers with Site Manager* for information about adding a protocol.

When you enable RARP services, you are required to configure only a few parameters. The Configuration Manager supplies default values for the remaining parameters.

Enabling RARP on an Interface

When you select either a link- or net-module connector, or when you finish configuring a WAN circuit, the Select Protocols window opens.



Note: The Select Protocols window displays only those protocols that the circuit type supports.

To enable RARP on an interface, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, select the link- or net-module connector on which you are enabling RARP services.	The Select Protocols window opens.
2. Choose Reverse ARP . When you choose Reverse ARP, you automatically choose IP.	
3. Click on OK .	The IP Configuration window opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
<p>4. Specify an IP address for this interface.</p> <p>There is no default for the IP address. You must supply an address or enter 0.0.0.0 to indicate that this is an unnumbered interface. For information about unnumbered interfaces, see <i>Configuring IP Services</i>.</p>	
<p>5. Edit or accept default values for the remaining IP interface parameters.</p> <ul style="list-style-type: none">• To accept the default values, click on OK.• To edit IP interface parameters, click on Details. For information about editing IP interface parameters, see <i>Configuring IP Services</i>.	

Customizing RARP

For information about modifying RARP parameters, refer to Chapter 7, “Customizing RARP.”

Chapter 2

SNMP, BootP, BootP/DHCP Relay, DHCP Server, and RARP Concepts

This chapter describes the concepts behind SNMP, BootP, BootP/DHCP, DHCP server, and RARP services and how Bay Networks routers implement them. You can use this information to decide how to customize SNMP, BootP, BootP/DHCP relay, DHCP server, and RARP parameters for your system.

Topic	Page
SNMP Overview	2-1
SNMP Implementation Notes	2-4
BootP Relay Agent Overview	2-10
DHCP Overview	2-14
RARP Overview	2-29

SNMP Overview

SNMP is a simple request/response protocol that communicates management information between two types of SNMP software entities: *SNMP applications* (also called *SNMP managers*) and *SNMP agents*.

SNMP applications contain manager software that runs on a network management station (also known as an SNMP client), such as a PC or a workstation. The manager software implements the protocols used to exchange data with SNMP agents. SNMP applications issue queries to gather information about the status, configuration, and performance of external network devices, called *network elements* in SNMP terminology. Network elements contain an agent and perform the network management function that the network management stations request.

The Bay Networks Site Manager software is an example of a network management station, and the Bay Networks Backbone Node (BN®) router is an example of a network element.

The *SNMP agent* is a software entity that responds to information and action request messages (SNMP Set and Get requests) sent by a network management station (your Site Manager workstation). The messages exchanged between manager and router SNMP agents enable you to access and manage objects in an active or inactive (stored) management information base (MIB) on a router.


The agents also send unsolicited reports (called *traps*) back to the network management station when certain network activity occurs. An example of a trap is an overload condition as defined by the packet load's crossing some threshold. You use the management station to configure, monitor, and receive trap messages from other network devices configured as SNMP agents. The management station can get and set objects in the agents and can receive traps from the agents. The management station, therefore, has the capability to “manage” a number of agents.

SNMP Messages

SNMP managers and network elements communicate with each other by sending SNMP messages ([Figure 2-1](#)). The management station issues three types of SNMP messages to retrieve single or multiple object variables:

- *GetRequest* messages
- *GetNextRequest* messages
- *SetRequest* messages

The agent acknowledges all three types of messages by passing a *Get Response* message to the management application. In addition, an agent may issue a trap to the network management station to identify a condition, such as a threshold that exceeds a predefined value.



SNM00012A

Figure 2-1. Role of SNMP

SNMP Communities

For security reasons, the SNMP agent validates each request from an SNMP manager before responding to the request, by verifying that the manager belongs to a valid *SNMP community*.

An SNMP community is a logical relationship between an SNMP agent and one or more SNMP managers. You define communities locally at the agent. The agent establishes one community for each desired combination of authentication and access control characteristics. You assign each community a unique name (within the agent), and all members of a community have the same access privileges, either read-only or read-write:

- Read-only: members can view configuration and performance information.
- Read-write: members can view configuration and performance information, and also change the configuration.

By defining a community, an agent limits access to its MIB, to a selected set of management stations. By using more than one community, the agent can provide different levels of MIB access to different management stations.

All SNMP message exchanges consist of a community name and a data field, which contains the SNMP operation and its associated operands. You can configure the SNMP agent to receive requests and send responses only from managers that are members of a known community.

If the agent knows the community name in the SNMP message and knows that the manager generating the request is a member of that community, it considers the message to be authentic and gives it the access allowed for members of that community. In this way, the SNMP community prevents unauthorized managers from viewing or changing the configuration of a router.

SNMP Implementation Notes

This section contains information about features specific to the Bay Networks implementation of SNMP.

Internet Protocol

SNMP uses the User Datagram Protocol (UDP) to transport its messages. You must enable the Internet Protocol (IP) to use UDP and SNMP.

Events and Traps

An *event* is a change in the operating status of a router. The router stores the event as a single entry in a memory-resident log.

An *event log message* provides a brief description of an event, along with the event code associated with that event.

A *trap* is an event that the router transmits to the network management station.

SNMP allows you to configure which event log messages the agent sends to the network management station as traps. You select these traps based on slot, protocol entity, and severity level. You can also specify up to 50 *exceptions*, which are traps that the agent always sends, or never sends, regardless of slot and regardless of how you configure the trap parameters. For information about how to specify which traps the agent sends, see “Configuring Traps on the Router” on page 3-19.

Protocol Entities

Events are always associated with a particular protocol entity. An entity is the software that generates a message. Entities include Bay Networks software dedicated to the operation of a software service, such as Trivial File Transfer Protocol (TFTP) and IP, and the GAME[®] operating system.

Both events and entities are assigned entity codes. Together, this pair uniquely identifies a Bay Networks router platform event. For a complete list of entities (both their abbreviations and full names) and associated entity codes, see *Event Messages for Routers*.

Severity Levels

Event and trap messages are always associated with a severity level. [Table 2-1](#) describes the severity levels and gives the code that corresponds to each one. This guide does not cover Debug messages, because they are for Bay Networks internal use only.

Table 2-1. Severity Levels

Severity	Description	Code
Information	Indicates routine events that usually require no action.	2
Warning	Indicates that a service acted in an unexpected manner.	4
Fault	Indicates a major service disruption, usually caused by a configuration, network, or hardware problem. The entities involved keep restarting until the problem is resolved.	8

(continued)

Table 2-1. Severity Levels *(continued)*

Severity	Description	Code
Trace	Indicates information about each packet that traversed the network. Bay Networks recommends viewing this type of trap message only when diagnosing network problems.	10
Debug	Indicates information that Bay Networks Customer Support uses. These messages are not documented.	1

For detailed information about entities and severity levels, see *Event Messages for Routers*.

SNMP Trap Format

Some third-party network management applications, such as NetExpert, OpenView, and SunNet, let you trigger an operation when a specific SNMP trap is received. This section describes the SNMP trap format.

The router platform transmits a Bay Networks event log trap as a 32-bit value as follows:

- Octets 1 and 2 (the most significant 16 bits) of the specific trap ID contain values of 1 and 0, respectively, to identify a Bay Networks event log trap.
- Octet 3 of the specific trap ID contains a code that identifies the software entity that generated the trap.
- Octet 4 of the specific ID contains the event code that, in conjunction with the entity code, uniquely identifies the event.

Each 32-bit value is accompanied by three variable bindings that convey the event string that describes the trap condition, the slot that hosts the entity that generated the trap, and the trap severity (see [Table 2-1](#)).

For detailed information about the SNMP trap format, see *Event Messages for Routers*.

Thresholds

SNMP uses a management information base (MIB) to manage the router. The MIB includes an extensive collection of statistics (MIB *variables*) that track the router's performance and provide early warnings of abnormal operating conditions.

With the Site Manager threshold feature, you can configure the agent to automatically notify you when specific statistics (or *instances* of the variable) reach certain levels.

You can set a threshold for any integer, counter, gauge, or time-tick variable in the MIB. Using the threshold parameters, you:

- Select the polling interval, which specifies how often the agent checks the statistic to see if its value has reached the threshold.
- Set three threshold values (high, medium, and low).
- Specify the threshold action as *Lessthan* or *Greaterthan*.

For information about setting thresholds, see “Configuring Thresholds” on page 3-26.

When the statistic reaches the threshold, the agent generates an event. You specify the severity level at which you want the manager to log the event. [Table 2-1](#) shows the available severity levels and their suggested meanings. Depending on how you configure the SNMP trap parameters (see “Configuring Traps on the Router” on page 3-19), the agent may also send the threshold exception as an SNMP trap.

The Site Manager threshold feature is functionally similar to the RMON Alarm and Event facility, except for some minor differences. The Site Manager threshold feature provides three-tiered thresholds and defines a user-definable hysteresis mechanism. The RMON Alarm and Event facility provides a two-tiered proprietary threshold system. For information on RMON, RMON 2, and RMON alarms and events, see *Configuring RMON and RMON 2 for BayRS Routers*.

Threshold Example

Suppose you want SNMP to warn you if the number of high-priority (Priority Level 1) packets queued for transmission is approaching the maximum number supported by an interface. This maximum value is specified by the `wfCctOptsCngcCfgQp1Threshold` MIB object. Using the threshold parameters, you set a threshold for `wfCctOptsCngcCfgQp1Threshold` equal to 205.

You also set the polling interval to 20 seconds to indicate that, every 20 seconds, the agent should check variables for which you have configured thresholds. You set the threshold action to *Greaterthan* and set the threshold levels and severity of events to the values shown in [Table 2-2](#).

Table 2-2. Example of Threshold and Severity Settings

Threshold Level	Low	Medium	High
Depth of Priority 1 transmit queue	102 (40% of capacity)	153 (60% of capacity)	205 (80% of capacity)
Severity of event	INFO	INFO	WARNING

When you add this threshold to the MIB, the agent polls the variable `wfCctOptsCngcCfgQp1Threshold` every 20 seconds and responds as follows:

- If its value is greater than 102, but less than or equal to 153, the manager logs an informational event indicating that the queue depth exceeded the low threshold.
- If its value is greater than 153 but less than or equal to 205, the manager logs an informational event indicating that the queue depth exceeded the medium threshold.
- If its value is greater than 205, the manager logs a warning event indicating that the queue depth exceeded the high threshold.

Event Message Format

By default, the threshold event messages include the MIB object identifier (OID) of the variable that exceeded the threshold, the value of the variable, and the threshold level exceeded.

For example, if the `wfCctOptsCngcCfgQp1Threshold` variable has a value of 120, the agent generates an event message similar to the following:

```
#1:08/27/96 10:53:20.802 INFO SLOT 2 STA CODE: 6
Object 1.3.6.1.4.1.18.3.5.1.4.10.1.24 with value = 120 units/ hour
is > low threshold.
```

You can, however, identify objects more easily by configuring the software to report the object name rather than the OID in the event message. To configure the software to report the object name in the event message, use the Threshold Label parameter (see page A-15).

For example, if you set the Threshold Label parameter to **`wfCctOptsCngcCfgQp1Threshold`**, the agent generates an event message similar to the following:

```
#1:08/27/96 10:53:20.802 INFO SLOT 2 STA CODE: 6
Object wfCctOptsCngcCfgQp1Threshold with value = 120 units/ hour is
> low threshold.
```

State of a Threshold

If the collision rate stays above a threshold for an extended period of time, the agent continues to generate a new event every 5 seconds. You can specify the maximum number of event messages you want the agent to generate before it changes the threshold's state to *held*.

When the threshold is in a held state, the agent does not generate new events unless the statistic exceeds the threshold at a different level. If the statistic does not exceed any threshold for a specified number of polling periods, the agent no longer considers the threshold held.

Memory Considerations

Polling statistics to determine whether they have reached a threshold and reporting events when variables exceed thresholds require router processing capacity. When you set many thresholds and use shorter polling intervals, the router performance will probably decline.

BootP Relay Agent Overview

BootP is built on the client-server model and allows a diskless client to boot remotely from a server on the same network or on a different physical network. The client broadcasts a request to boot from a remote server. When a suitable server receives the BOOTREQUEST packet, it responds to the client by issuing a BOOTREPLY packet, which includes the client's IP address, the address of the gateway, and the address of a server. The server then transmits the boot file to the client via a transfer protocol, such as Trivial File Transfer Protocol (TFTP).

Figure 2-4 illustrates how BootP works when the client and the server are on the same network. The client transmits a BOOTREQUEST packet to the IP broadcast address (255.255.255.255). The server sends a BOOTREPLY packet to the client. Depending on the server's implementation, the server addresses the packet to either the broadcast or the client's IP address.




Figure 2-2. BootP Client and Server on the Same Physical Network

If, however, the client and the server are on different physical networks, a BootP *relay agent* (also known as a BootP gateway) must forward BootP packets to their correct destinations. When you configure a Bay Networks router for BootP services, the router acts as a BootP relay agent. [Figure 2-3](#) illustrates how BootP works when the client and the server are on different physical networks.




Figure 2-3. BootP Client and Server on Different Physical Networks

The client transmits a BOOTREQUEST packet to the IP broadcast address (255.255.255.255). The router receives the BOOTREQUEST packet at an interface that you configured to receive BOOTREQUEST packets (an input interface). If the BOOTREQUEST packet has an address other than 255.255.255.255, the router drops the packet.

[Figure 2-4](#) shows the fields in the BOOTREQUEST and BOOTREPLY packets.

Operation (1)*	Hardware type (1)	Hardware address length (1)	Hops (1)
Transaction ID (4)			
Seconds (2)		Flags (2)	
Client IP address (4)			
Your IP address (4)			
Server IP address (4)			
Gateway IP address (16)			
Client hardware address (16)			
Server name (64)			
File name (128)			
Vendor-specific area (64)			
*The number in parentheses indicates the number of octets in each field.			

SNM0001A

Figure 2-4. BOOTREQUEST and BOOTREPLY Fields

The packet relay process uses these fields as follows:

1. When a router interface receives a BOOTREQUEST packet, the router examines the seconds and hops fields in the packet and compares these values to BootP parameters you configured on that interface.

The seconds field contains the minimum number of seconds that the router waits before forwarding a BOOTREQUEST packet. If the value in the seconds field of the packet is less than the value of the Timeout Secs. parameter you configured on the interface, the router drops the packet.

The hops field contains the maximum number of hops that a packet can take between the source and destination devices. If the packet has traversed more hops than the value of the hops parameter you specified for that interface, the router drops the packet.

2. If the router accepts the packet, it alters the packet by:
 - Incrementing the hops field by 1
 - Writing the IP address of the input interface to the gateway IP address field
3. The router then determines which networks should receive this packet and broadcasts it to other networks through a forwarding route that you specify when you configure the router for BootP services.

If the BootP packet has to travel to a network through another router, you must specify the forwarding route using one of the following methods:

- Configure the second router for BootP services.

In this case, the second router inspects the packet in the same way as the first router, and increments the hops field by 1. The second router will not, however, replace the address in the gateway IP address field, because servers will reply to the first router that received the BOOTREQUEST packet.

- Configure the first router to forward the BOOTREQUEST packet to a specific server.

In this case, the router will unicast the BOOTREQUEST packet to the server through normal IP services.

4. Servers on other networks receive the BOOTREQUEST packet and respond with a BOOTREPLY packet. Those servers transmit the BOOTREPLY packets through normal IP services to the address of the first interface that received the BOOTREQUEST packet. That address appears in the gateway IP address field in the BOOTREQUEST packet.
5. When the router that first received the BOOTREQUEST packet receives the BOOTREPLY packet, it examines the gateway IP address field to check that the value in this field is the same as the IP destination address that the server used for the packet. If the addresses differ, the router discards the BOOTREPLY packet.
6. If the router accepts the packet, it examines the flags field and forwards the packet to the client as follows:
 - If the flags field contains the value 1, the client does not know its own IP address. The router broadcasts the BOOTREPLY packets to the IP broadcast address (255.255.255.255).

- If the flags field contains the value 0, the client knows its own IP address, which appears in the client IP address field of the BOOTREPLY packet. The router sends the BOOTREPLY packet to that IP address and the link-layer address that appears in the client hardware address field.

DHCP Overview

DHCP, described in RFC 1541, is an extension of BootP and is built on the client-server mode. DHCP allows designated DHCP servers to automatically assign IP addresses and host names to dynamically configured DHCP clients for a pre-defined period of time.

The DHCP packet format is based on a BootP packet. As a result, DHCP uses the BootP relay agent to forward DHCP packets. This scheme provides interoperability between the existing BootP clients and DHCP servers. The BootP relay agent uses the same criteria and methods for forwarding both DHCP and BootP packets. For information about the packet relay process, see “[BootP Relay Agent Overview](#),” on page [2-10](#).

Why Use DHCP?

Each DHCP client on the network requires its own IP address and configuration information. The DHCP client’s IP address is the identifier that other networked devices use to recognize the client on the network. The client’s configuration information includes the network domain name, the address of the network servers and gateways, and the subnet mask.

Without DHCP, each time you add a client to its network, you must manually assign an IP address and configuration information to the client. When clients change offices or users, or leave the network altogether, the configuration information changes as well.

DHCP facilitates network management by automating and centralizing IP address administration and by providing IP configuration information automatically to each networked device when it is needed.

DHCP can allocate three types of IP addresses to DHCP clients: static DHCP addresses, dynamic DHCP addresses, and static BootP addresses. [Table 2-3](#) describes these types of IP addresses.

Table 2-3. IP Address Types Allocated by DHCP

IP Address Type	Description
Static DHCP address	An address that the DHCP server fixes to a client by a unique key, which is typically the MAC address.
Dynamic DHCP address	An address that the DHCP server allocates to a client for fixed periods of time, called <i>lease times</i> . The client can extend the lease so that it continues to use the same dynamic address. When the client leaves the network, the client typically releases the address, and the DHCP server can assign it to another client.
Static BootP address	An address that a DHCP server allocates dynamically with no fixed time period. Unlike a dynamic DHCP address, a static BootP address has an infinite lease time. When the client leaves the network, it must send a message to the DHCP server to release the address. The address is then available for the DHCP server to reassign.

Dynamic IP Address Allocation

There are only a limited number of IP addresses in a TCP/IP network. DHCP enables you to efficiently use and reuse IP addresses by implementing a concept called *IP address leasing*. A DHCP client can lease an IP address from a DHCP server for a fixed, configurable period of time. The lease period can range from 1 minute to 99 years. If you have more clients than IP addresses, using shorter leases can prevent you from running out of addresses. If you have more addresses than clients, you can use permanent addresses or you can assign fixed addresses to specific clients.

When a lease expires, the DHCP client can contact the DHCP server to renew the lease. Typically, the client attempts to renew the lease halfway through the lease period. For example, if the client is granted an address with a lease time of one hour, it asks to renew the address approximately half an hour after the client has started to use it.

If the client does not receive an answer from the DHCP server (perhaps because the server is down at the renewal time), it can attempt to reacquire configuration parameters and an IP address from another server, or let the lease lapse, returning the IP address to a client pool. The *client pool* is a group of one or more client IDs or MAC addresses maintained by a DHCP server.

DHCP Components

The Bay Networks implementation of DHCP consists of the following components:

- DHCP clients
- DHCP server
- NetID Server Manager

The sections that follow describe these components in detail.

DHCP Clients

A DHCP client is a host that uses DHCP to obtain configuration information, such as an IP address, from a DHCP server.

DHCP Server

A DHCP server is a host that provides IP addresses and configuration parameters to DHCP clients.

NetID Server Manager

The Server Manager operates as an interface between the DHCP server (see [Figure 2-6](#)). The NetID Server Manager manages and maintains IP addresses and configuration information, and allocates IP addresses to the DHCP server. The NetID Server Manager polls the database periodically and sends configuration changes to the appropriate DHCP servers. The DHCP servers send updated information to the NetID Server Manager, and the Server Manager puts this information into the database.

For example, when the DHCP server starts up, it connects to the NetID Server Manager and requests its configuration. The DHCP server assigns IP addresses to clients that request an address using the DHCP protocol. When the DHCP server assigns an IP address to a client, it sends the client's host name and IP address to the NetID Server Manager. The NetID Server Manager then sends this information to the database.

The primary benefit of the NetID Server Manager is that it reduces the load on the database, because every DHCP server is not polling for configuration changes and does not require an active (resource consuming) connection to the database. It also reduces the load on the network, because it is the only component that polls the database for configuration changes.

BootP/DHCP Relay Implementation

The BootP/DHCP relay implementation allows you to configure a router to act as a BootP relay agent. The BootP relay agent forwards DHCPREQUEST packets to DHCP servers on other subnets and forwards DHCPREPLY packets back to DHCP clients. You must enable the BootP relay agent on the interface to the subnet to be served and configure it with the IP address of the DHCP server. For more information about configuring a BootP relay agent, see “Specifying Interfaces to Receive and Forward DHCP Packets” on page 5-2.

[Figure 2-5](#) illustrates a BootP/DHCP relay implementation.




Figure 2-5. BootP/DHCP Relay Implementation

DHCP Server Implementation

The DHCP server implementation allows you configure a router to act as a DHCP server. In this scenario, the DHCP server, acting in proxy fashion, uses the NetID Server Manager to manage and maintain IP addresses and configuration information stored in its database (see [Figure 2-6](#)). The DHCP server uses the information in the database to assign IP addresses and host configuration information to DHCP clients. For more information about configuring a DHCP server, see “Modifying the DHCP Server Configuration” on page 6-2.

[Figure 2-6](#) illustrates a DHCP server implementation.




Figure 2-6. DHCP Server Implementation

Acquiring an IP Address from a Router Configured as a BootP Relay Agent


The client acquires its IP address from a router configured as a BootP relay agent by:

- Identifying DHCP servers
- Requesting and receiving IP information
- Accepting or declining IP information

The following sections describe each of these stages in detail.

Identifying DHCP Servers

[Figure 2-7](#) shows the first stage of the process of acquiring a new IP address from a router configured as a BootP relay agent.



SNM0005A

Figure 2-7. Identifying DHCP Servers (BootP Relay Agent)

To identify DHCP servers, the DHCP client broadcasts a DHCPDISCOVER packet, which is used to locate available DHCP servers on the network. [Table 2-4](#) describes the fields in a DHCP packet.

Table 2-4. Fields in a DHCP Packet

Field	Octets	Description
Operation	1	Message operation code or message type. <ul style="list-style-type: none"> • 1= BOOTREQUEST • 2= BOOTREPLY
Hardware type	1	Hardware address type. For example, 1= 10mb Ethernet
Hardware address length	1	Hardware address length. For example, "6" for 10mb Ethernet
Hops	1	DHCP client sets to zero.
Transaction ID	4	A random number chosen by the client. The DHCP client and the DHCP server use this number to associate messages and responses exchanged between them.
Seconds	2	The number of seconds that elapsed since a client started trying to boot. The client fills in this number.
Flags	2	<p>If the flags field contains the value 1, the client does not know its own IP address. The router broadcasts the DHCPREPLY packets to the IP broadcast address (255.255.255.255).</p> <p>If the flags field contains the value 0, the client knows its own IP address, which appears in the client IP address field of the DHCPREPLY packet. The router sends the DHCPREPLY packet to that IP address and the link-layer address that appears in the client hardware address field.</p>
Client IP address	4	The DHCP client IP address. This field is filled in only if the DHCP client is in BOUND, RENEW, or REBINDING state and can respond to ARP requests.
Your IP address	4	"Your" (DHCP client) IP address.
Gateway IP address	16	IP address of the DHCP server to use in the next step of the client's bootstrap process. The DHCP server returns this address when it sends DHCPPOFFER and DHCPACK messages to the client.
Client hardware address	16	The hardware address of the client.

(continued)


Field	Octets	Description
Server name	64	Optional DHCP server host name, represented as a null terminated string.
File name	128	A boot file name. Represented as a null terminated string in a DHCPDISCOVER message, and a fully qualified directory path name in a DHCPOFFER message.
Options	312	Variable length optional parameters field.

The packet relay process uses these fields as follows:

1. The BootP relay agent receives the packet and, if it accepts the packet, transmits it to DHCP servers on other networks.
2. DHCP servers on the local segment see the broadcast packet and respond with a DHCPOFFER packet that includes an available IP address and other configuration information. Before offering the IP address, the DHCP servers may generate an ARP or ICMP echo request on the network to determine whether the IP address is already in use by another device.
3. When a DHCP server offers an IP address, that address is temporarily unavailable to other clients. If the client does not accept or reject the address within a certain period of time, the server reclaims it. The address is then available for other clients.
4. The BootP relay agent receives the DHCPOFFER packet and examines the packet. If the BootP relay agent accepts the packet, it forwards it to the client.
5. If a client does not receive a DHCPOFFER packet within a specified amount of time after broadcasting a DHCPDISCOVER packet, it sends the packet again. The client may rebroadcast the packet a number of times. However, clients operating on systems running Windows 95 broadcast 4 DHCPDISCOVER packets, each two seconds apart.
6. The client may receive DHCPOFFER packets from several potential servers. If you configure the client to wait for multiple responses, it compares configuration parameters in the DHCPOFFER packets to decide which server to target.

Requesting and Receiving IP Information

[Figure 2-8](#) shows the next stage of the process for requesting and receiving IP information using a BootP relay agent:



SNM0006A

Figure 2-8. Requesting and Receiving IP Information (BootP Relay Agent)

1. When the client has chosen a target server, it broadcasts a DHCPREQUEST packet. The DHCPREQUEST packet contains the address of the target server in the server IP address field and the lease offer that it prefers.
2. The router configured as a BootP relay agent receives the packet and forwards it to all servers.
3. Those servers examine the packet, and if their IP addresses differ from the value in the server IP address field, they reclaim the IP addresses they supplied in the DHCPOFFER packets. These addresses are now available for other clients.

Accepting or Declining IP Information

In a network configuration in which a router is configured as a BootP/DHCP relay agent, the target server recognizes its IP address in the server IP address field, and responds to the DHCPREQUEST packet as follows:

- If the target server can supply the requested configuration parameters, it sends a DHCPACK packet to the client through the BootP relay agent. The DHCPACK packet contains the committed IP address.

The client examines the configuration parameters in the DHCPACK packet and records the duration of the lease period. If the client detects a problem with the configuration parameters, it sends a DHCPDECLINE packet to the server and issues a new DHCPDISCOVER packet. Otherwise, the client accepts the configuration parameters.

- If the target server cannot supply the requested configuration parameters, it sends a DHCPNAK packet to the client through the BootP relay agent.

When the client receives the DHCPNAK packet, it broadcasts a new DHCPDISCOVER packet and the process begins again.

A client may choose to relinquish its IP address before the lease period expires by sending a DHCPRELEASE packet to the server. This packet contains the relinquished IP address in the client IP address field and the client's MAC address in the client hardware address field.

How Clients Acquire IP Addresses Using a DHCP Server


A client acquires its IP address from a DHCP server by:

- Identifying DHCP servers
- Requesting and receiving IP information
- Accepting or declining IP information

The following sections describe each of these stages in detail.

Identifying DHCP Servers

[Figure 2-9](#) shows the first stage of the process of acquiring a new IP address from a DHCP server.



DC0003A

Figure 2-9. Identifying DHCP Servers


To identify DHCP servers, the DHCP client broadcasts a DHCPDISCOVER packet on its local physical subnet. [Table 2-4](#) describes the fields in the DHCP packet. The packet release process uses these fields as follows:

1. A DHCP server receives the packet and finds an available IP address to assign to the client.
2. The DHCP server sends an ICMP echo request to the prospective IP address to determine whether the address is available. If the DHCP server receives a response, the address is unavailable because it is being used by another host on the network. The DHCP server selects another IP address to offer and sends another ICMP echo request.
3. If there is no response to the ICMP echo request, the DHCP server sends a DHCPOFFER packet that includes an available IP address to the target DHCP client.

4. If a client does not receive a DHCPOFFER packet within a specified amount of time after broadcasting a DHCPDISCOVER packet, it sends the packet again. The client may rebroadcast the packet a number of times. However, clients operating on systems running Windows 95 broadcast 4 DHCPDISCOVER packets, each two seconds apart.
5. The client may receive DHCPOFFER packets from several potential servers. If you configure the client to wait for multiple responses, it compares configuration parameters in the DHCPOFFER packets to decide which server to target.

Requesting and Receiving IP Information

[Figure 2-10](#) shows the next stage of the process of acquiring a new IP address using a DHCP server.



DC0002A

Figure 2-10. Requesting and Receiving IP Information (DHCP Server)

1. When the client has chosen a target DHCP server, it broadcasts a DHCPREQUEST packet to the server. The DHCPREQUEST packet contains the address of the target server in the server IP address field.

2. The router configured as a DHCP server examines the packet, and if its IP address differs from the value in the server IP address field, it reclaims the IP addresses it supplied in the DHCPOFFER packets. This address is now available for other clients.
3. If the DHCPREQUEST packet is valid, the DHCP server forwards the request information to the NetID Server Manager.
4. After the NetID Server Manager updates the NetID database with the new request information, the NetID Server Manager sends a committed update message back to the DHCP server.

Accepting or Declining IP Information

In a network configuration in which the router is configured as a DHCP server, the target server recognizes its IP address in the server IP address field, and responds to the DHCPREQUEST packet as follows:

- If the DHCP server can supply the requested configuration parameters, it sends a DHCPACK packet to the client through the DHCP server.

The client examines the configuration parameters in the DHCPACK packet and records the duration of the lease period. If the client detects a problem with the configuration parameters, it sends a DHCPDECLINE packet to the server and issues a new DHCPDISCOVER packet. Otherwise, the client accepts the configuration parameters.

- If the target server cannot supply the requested configuration parameters, it sends a DHCPNAK packet to the client through DHCP server.

When the client receives the DHCPNAK packet, it broadcasts a new DHCPDISCOVER packet and the process begins again.

Acquiring the Same IP Address Again

A client may want to reuse an IP address that a server allocated earlier by DHCP. In this case, the interchange between client and server omits some of the steps described in the previous section.

Using a Router Configured as a BootP Relay Agent

The client can acquire the same IP address again using a BootP relay agent by following these steps:

1. The client starts the interchange by broadcasting a DHCPREQUEST packet that contains its previous IP address in the client IP address field.
2. The BootP relay agent receives the packet and forwards it to DHCP servers on other networks.
3. DHCP servers examine the client's configuration parameters in the options field of the DHCPREQUEST packet.
4. The server that originally supplied the configuration parameters recognizes them and responds with a DHCPACK packet.
5. When a client receives a DHCPACK packet, it accepts or declines the parameters, as it would when receiving a new IP address.

If a client's request is invalid (for example, when the client has moved to a new network), servers respond with a DHCPNAK packet. If a client receives only DHCPNAK packet, it must request a new IP address by broadcasting a DHCPDISCOVER packet.

Using a DHCP Server

The client can acquire the same IP address again using a DHCP server by following these steps:

1. The client starts the interchange by broadcasting a DHCPREQUEST packet that contains its previous IP address in the client IP address field.
2. The DHCP server receives the packet, examines the client's configuration parameters in the options field of the DHCPREQUEST packet, and forwards the client request information to the NetID Server Manager.
3. The NetID Server Manager updates its database and sends a committed update message back to the DHCP server.
4. The DHCP server that originally supplied the configuration parameters recognizes them and responds with a DHCPACK packet.
5. When a client receives a DHCPACK packet from the DHCP server, it accepts or declines the parameters, as it would when receiving a new IP address.

If a client's request is invalid (for example, when the client has moved to a new network), servers respond with a DHCPNAK packet. If a client receives only a DHCPNAK packet, it must request a new IP address by broadcasting a DHCPDISCOVER packet.

RARP Overview

You can use a Bay Networks router as a Reverse Address Resolution Protocol (RARP) server that assigns IP addresses to its clients on the local area network. When you configure a router to use RARP services, it acts as a RARP server. A RARP server supplies clients on the same physical or logical LAN with IP addresses ([Figure 2-11](#)).




Figure 2-11. RARP Server Supplying an IP Address

To use RARP services, you must set up a MAC address-to-IP address mapping table. This table lists the MAC addresses of clients and the corresponding IP addresses that the RARP server assigns to those clients. When a client needs to acquire an IP address, the following interchange takes place:

1. The client broadcasts a RARP request specifying its MAC address.
2. Upon receiving a RARP request, the router refers to its MAC address-to-IP address mapping table, then sends the client a response packet containing the corresponding IP address.
3. The client examines the response packet to learn its IP address.

You can configure RARP support on Ethernet and token ring interfaces, and on the Fiber Distributed Data Interface (FDDI).

Chapter 3

Customizing SNMP

This chapter describes how to customize SNMP services. It assumes you have configured an IP interface using the default parameters, as described in Chapter 1, and that you understand the SNMP concepts in Chapter 2.

Topic	Page
Configuring SNMP Using the BCC and Site Manager	3-2
Customizing SNMP Global Parameters	3-3
Adding SNMP Communities	3-9
Configuring SNMP Community Managers	3-12
Configuring Traps on the Router	3-19
Configuring Thresholds	3-26

Configuring SNMP Using the BCC and Site Manager

[Table 3-1](#) lists SNMP configuration tasks described in this chapter and indicates whether you can use the BCC or Site Manager to perform each task.

Table 3-1. SNMP Configuration Tasks

Task	BCC	Site Manager
Disabling and Reenabling SNMP	✓	✓
Enabling and Disabling SNMP Lock Mechanism	✓	✓
Specifying a Lock Address	✓	✓
Specifying a Lock Timeout Value	✓	✓
Enabling and Disabling Authentication Failure Traps	✓	✓
Specifying the type of service for SNMP packets	✓	
Specifying an SNMP Community Name	✓	✓
Specifying Community Access Privileges	✓	✓
Deleting an SNMP Community	✓	✓
Adding a Manager	✓	✓
Configuring a Manager to Receive Traps	✓	✓
Deleting a Manager	✓	✓
Specifying a Trap Entity	✓	✓
Specifying the Severity Level for Traps	✓	✓
Disabling a Trap Entity	✓	✓
Configuring Trap Exceptions	✓	✓
Deleting Trap Exceptions	✓	✓
Disabling and Reenabling Thresholds		✓
Setting the Threshold Polling Interval		✓
Adding a Threshold		✓
Enabling and Disabling Thresholds for a Variable		✓
Specifying a Value for the Threshold Level		✓
Specifying the Severity Level for Event Messages		✓
Specifying Threshold Units		✓
Determining When to Record Threshold Events		✓

(continued)

Table 3-1. SNMP Configuration Tasks *(continued)*

Specifying Maximum Successive Alarms		✓
Specifying Polling Intervals for Held Variables		✓
Specifying a Threshold Object Name		✓

Customizing SNMP Global Parameters

You can enable SNMP services most easily by accepting all the default parameter values. However, you may want to change these values, depending on your network requirements.

Disabling and Reenabling SNMP

When you enable IP on an interface, SNMP access is automatically enabled through that interface, and default values are in effect for all SNMP parameters (see Appendix B for parameter defaults).

Using the BCC

To disable SNMP, navigate to the SNMP prompt and enter:

disable

For example, the following command disables SNMP:

```
snmp# disable
```

To reenabling SNMP, navigate to the SNMP prompt and enter:

enable

For example, the following commands reenabling SNMP and display its default values:

```
snmp# enable
snmp# info
  on box
  state enabled
  lock enabled
  lock-address 0.0.0.0lock-timeout 2
  authentication-traps enabled
  type-of-service reliability
  scope-delimiter 0x40 (=> This function is not available)
snmp#
```

Using Site Manager

Complete the tasks in the following table to disable and reenale SNMP:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Global .	The Edit SNMP Global Parameters window opens.
5. Set the Enable parameter. Click on Help or see the parameter description on page A-3.	
6. Click on OK .	You return to the Configuration Manager window.



Caution: When you disable the SNMP agent in dynamic mode, you immediately prohibit Site Manager from communicating with the router and will disconnect your Site Manager session.

Enabling and Disabling SNMP Lock Mechanism

The SNMP locking mechanism prohibits the SNMP agent from responding to multiple network management stations issuing simultaneous SNMP **set** commands to the router.

The SNMP locking mechanism is enabled by default. This means that the SNMP agent identifies the station from which it receives the next SNMP **set** command and, for a time equal to the value of the Lock TimeOut parameter, responds only to SNMP **set** commands from that station. If the agent receives an SNMP **set** command from another network management station during this time, it issues an SNMP genErr GetResponse PDU, which that station logs as an SNMP Set Error message.

To allow the SNMP agent to respond to simultaneous SNMP **set** commands from multiple network management stations, set the SNMP locking mechanism to Disable.

Using the BCC

To disable the mechanism, navigate to the SNMP prompt and enter:

lock disabled

To reenable the lock mechanism, navigate to the SNMP prompt and enter:

lock enabled

Using Site Manager

To enable and disable the SNMP lock mechanism, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Global .	The Edit SNMP Global Parameters window opens.
5. Set the Use Lock parameter. Click on Help or see the parameter description on page A-3.	
6. Click on OK .	You return to the Configuration Manager window.

Specifying a Lock Address

The default lock address is 0.0.0.0. To specify a lock address, navigate to the SNMP prompt and enter:

lock-address <address>

address is an IP address in dotted-decimal notation.



Note: There is no Site Manager command for specifying a lock address.

Specifying a Lock Timeout Value

If the SNMP locking mechanism is enabled, you can customize the lock timeout period. The lock timeout period is the maximum number of minutes the SNMP agent allows an idle network management station to hold a lock on it. During this time, the SNMP agent locks out SNMP **set** commands from other network management stations. The lock timer is reset each time the locking manager issues an SNMP **set** command.

By default, the SNMP agent allows an idle network management station to hold a lock on it for 2 minutes. To change the default lock timeout period, specify a value from 1 to 60 minutes.

Using the BCC

To specify the number of seconds, navigate to the SNMP prompt and enter:

lock-timeout <integer>

integer is the number of seconds.

Using Site Manager

To specify a lock timeout value, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Global .	The Edit SNMP Global Parameters window opens.
5. Set the Lock Time Out parameter. Click on Help or see the parameter description on page A-4.	
6. Click on OK .	You return to the Configuration Manager window.

Enabling and Disabling Authentication Failure Traps

The router generates an authentication failure trap when it receives an SNMP message from an SNMP manager falsely claiming to be in a particular community or specifying an unknown community.

When you enable the authentications failure trap feature on the router, you must configure an SNMP community manager to receive the trap. (See “[Configuring SNMP Community Managers](#)” on page [3-12](#).)

You can prohibit the router from generating authentication failure traps by disabling the authentication failure trap feature.

Using the BCC

By default, SNMP sends an authentication failure trap for sets from a false manager or community. To disable authentication traps, navigate to the SNMP prompt and enter:

authentication-traps disabled

For example, the following command line causes SNMP to send authentication failure traps from a false manager or community.

```
snmp# authentication-traps disabled
snmp#
```

To reenable authentication failure traps, navigate to the SNMP prompt and enter:

authentication-traps enabled

For example, the following command line prohibits SNMP from generating authentication failure traps from a false manager or community.

```
snmp# authentication-traps enabled
snmp#
```

Using Site Manager

To enable or disable authentication failure traps, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Global .	The Edit SNMP Global Parameters window opens.
5. Set the Authentication Failure Traps parameter. Click on Help or see the parameter description on page A-4.	
6. Click on OK .	You return to the Configuration Manager window.

Specifying the Type of Service for the SNMP Packet

Site Manager does not support this function.

You can specify the type of service in which SNMP packets will be generated by setting the type of service to either reliability or normal. For SNMP, high reliability type of services is important.

By default, the type of services is set to reliability. To specify the type of service, navigate to the SNMP prompt and enter:

type-of-service <*reliability* | *normal*>

For example, the following command line causes SNMP to generate packets with a type of service of reliability.

```
snmp# type-of-service reliability
snmp#
```

Adding SNMP Communities

An *SNMP community* is a logical relationship between an SNMP agent and one or more SNMP managers. The community has a name, and all members of a community have the same access privileges: either *read-only* (members can view configuration and performance information) or *read-write* (members can view configuration performance information, and also change the configuration).

This section describes how to add and delete the SNMP communities to which the SNMP agent responds or sends traps.

Specifying an SNMP Community Name

You can add SNMP communities by specifying the name of the community. The community name can consist of up to 63 characters, including embedded spaces.

Using the BCC

To create a community name, navigate to the SNMP prompt and enter:

community <*name*>

name is any string of printable ASCII characters, up to 63 characters in length, including embedded spaces.

For example, the following commands create a community named “Router1” and display its default values.

```
snmp# community Router1
community/Router1# info
    on snmp
    label router1
    access read-only
    scope-type {} (=> This function is not available)
```

Using Site Manager

To specify the name of a community, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Communities .	The SNMP Community List window opens.
5. Choose Community .	The Community menu opens.
6. Choose Add Community .	The SNMP Community window opens.
7. Set the Community Name parameter. Click on Help or see the parameter description on page A-5.	
8. Click on OK .	You return to the Configuration Manager window.

Specifying Community Access Privileges

After you specify the name of the community, you must assign access privileges to all members of the community. You can specify one of two types of access privileges to each community that you define: read-only or read-write.

By default, the router grants read-only access privileges to all members of an SNMP community. Read-only access allows members of a community to view configuration and performance information. Set this parameter to read-write to allow members of a community to view configuration and performance information, and also change the configuration of a router.

Using the BCC

By default, the community has read-only access. To obtain read-write access, navigate to the community-specific prompt and enter:

access readwrite

For example, the following command line allows read-write access to the community "Router1."

```
community/router1# access read-write
community/router1#
```

Using Site Manager

To specify the access privilege for a community, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Communities .	The SNMP Community List window opens.
5. Choose Community .	The Community menu opens.
6. Choose Add Community .	The SNMP Community window opens.
7. Set the Access parameter. Click on Help or see the parameter description on page A-5.	
8. Click on OK .	You return to the Configuration Manager window.

Deleting an SNMP Community

You can delete an SNMP community to which the agent responds or sends traps.

Using the BCC

To delete an SNMP community, navigate to the community-specific prompt and enter:

delete

For example, the following command line deletes the community “Router1”.

```
community/router1# delete
snmp#
```

Using Site Manager

To delete an SNMP community, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Communities .	The SNMP Community List window opens.
5. Select the community you want to delete.	The Delete Community window opens.
6. Verify that the correct community name appears on the window. Click on Cancel if you do not want to delete the selected community.	
7. Click on Delete .	Configuration Manager removes the community from the list.

Configuring SNMP Community Managers

This section describes how to add and delete SNMP community members (managers). It also describes how to configure managers to receive traps from the SNMP agent.

Adding a Manager

After you have added a community name on the router and assigned access privileges to it, you can add specific community members (called *managers*). You can add more than one manager to a community.

By default, the IP address 0.0.0.0 is a manager in the public community.



Note: When you add the first IP interface, Site Manager automatically creates a read-write public community with a wildcard manager (0.0.0.0). For security reasons, you should replace the public community and wildcard manager with a unique community specifying a limited list of managers.

Using the BCC

To add a manager to a community, navigate to the community prompt and enter:

manager address <ip_address>

For example, the following command line creates a manager with an IP address of 2.2.2.4 and assigns it to the community Router1.

```
community/router1# manager address 2.2.2.4
manager/router1/2.2.2.4#
```

Using Site Manager

To add a manager to a particular community, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Communities .	The SNMP Community List window opens.
5. Choose Community .	The Community menu opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
6. Choose Managers .	The SNMP Manager List window for that community opens.
7. Choose Manager .	The Manager menu opens.
8. Choose Add Manager .	The Add SNMP Manager window opens.
9. Enter the IP address of the SNMP manager you want to add.	
10. Click on OK .	Configuration Manager adds the manager to the community.

Configuring a Manager to Receive Traps

After you add a manager to a community, you can configure the manager to receive traps by specifying its UDP port number and the types of traps the agent transmits to that manager.

When you configure a manager to receive specific traps or all traps (see [Table 3-2](#)), the router sends this manager all enabled event traps. There is no MIB correspondence between a specific SNMP manager and a trap entity. Rather, all SNMP managers that you configure to receive specific traps receive all traps you have configured.

Specifying the Trap Port

By default, the standard port number on the managing station to which the SNMP agent transmits traps is 162. To use a different UDP port number, specify a value from 1 to 9999. Do not specify a port that another application uses.

Using the BCC

To specify the port number on the managing station on which the SNMP agent transmits traps, navigate to the manager-specific prompt and enter:

trap-port <integer>

integer is a number from 1 to 9999.

For example, the following command line causes the SNMP agent to transmit traps to manager 2.2.2.2 on port number 150.

```
manager/router1/2.2.2.2# trap-port 150
manager/router1/2.2.2.2#
```

Using Site Manager

To specify the port number on the managing station on which the SNMP agent transmits traps, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Communities .	The SNMP Community List window opens.
5. Choose Community .	The Community menu opens.
6. Choose Managers .	The SNMP Manager List window for that community opens.
7. Select the manager you want to edit.	
8. Choose Manager .	The Manager menu opens.
9. Choose Edit Manager .	The SNMP Manager window opens.
10. Set the Trap Port parameter. Click on Help or see the parameter description on page A-6.	
11. Click on OK .	You return to the Configuration Manager window.

Specifying a Trap Type

You can specify one of four types of traps that the SNMP agent can transmit to the manager: Generic, Specific, All, or None. [Table 3-2](#) describes these trap options.

Table 3-2. Trap Types Transmitted by the SNMP Agent

Trap Type	Description
Generic	This is the default trap type. It transmits the well-defined SNMP traps (cold-start, warm-start, and authentication failure traps) to the manager. The cold-start and warm-start traps are automatically active in the SNMP agent; however, you must enable the Authentication Failure Traps attribute for the agent to transmit such traps to a specified manager.
Specific	Allows you to configure the agent software to transmit all enabled log event traps to a specified manager.
All	Allows you to transmit cold-start and warm-start traps, and all enabled log event traps, to a specified manager.
None	Prohibits the SNMP agent from transmitting traps to a specified manager.

Using the BCC

By default, the SNMP agent transmits Generic traps to the manager. To specify a different type of trap, navigate to the manager-specific prompt and enter:

traps <trap_type>

trap_type is Generic, Specific, All, or None.

For example, the following command sequence causes the SNMP agent to transmit Specific traps to manager 2.2.2.2.

```
manager/router1/2.2.2.2# traps specific
manager/router1/2.2.2.2#
```

Using Site Manager

To specify a trap type, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Communities .	The SNMP Community List window opens.
5. Choose Community .	The Community menu opens.
6. Choose Managers .	The SNMP Manager List window for that community opens.
7. Select the manager you want to edit.	
8. Choose Manager .	The Manager menu opens.
9. Choose Edit Manager .	The SNMP Manager window opens.
10. Set the Trap Types parameter. Click on Help or see the parameter description on page A-6.	
11. Click on OK .	You return to the Configuration Manager window.

Deleting a Manager

You can delete a manager from its associated community by deleting the manager's IP address from the list of SNMP managers.

Using the BCC

To delete a manager, navigate to the manager-specific prompt and enter:

delete

For example, the following command line causes the SNMP agent to delete the manager 2.2.2.2 from the community router1.

```
manager/router1/2.2.2.2# delete
community/router1#
```

Using Site Manager

To delete a manager, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Communities .	The SNMP Community List window opens.
5. Select the community from which you want to delete the manager.	
6. Choose Community .	The Community menu opens.
7. Choose Managers .	The SNMP Manager List window for that community opens.
8. Select the manager you want to delete.	
9. Choose Manager .	The Manager menu opens.
10. Choose Delete Manager .	The Delete SNMP Manager window opens.
11. Make sure that the correct manager IP address appears.	
12. Click on Delete .	Configuration Manager removes the manager from the community.

Configuring Traps on the Router

A *trap* is an event that the router transmits to some external network device, such as a network management station. You can specify which log events the SNMP agent sends to the network management station as traps, based on the following:

- *Slot number*: the number of the slot on which the trap will be received
- *Entity number*: the code assigned to the entity issuing the event that uniquely identifies a router event
- *Severity level*: indicates whether the trap is a fault, warning, information, trace, or debug message

A router never broadcasts traps on the network. Rather, it sends traps to specific IP addresses, which you configure on the router as managers of a community. Traps are always sent to specific managers.

Specifying a Trap Entity

A trap entity is associated with a log event. An *entity* is the software that generates a message. Entities include Bay Networks software dedicated to the operation of a software service, such as TFTP and IP. Each entity contains a specific code that corresponds to the event you want to configure.

The entity code, together with the event code, uniquely identifies the event you want to configure as a trap. For a complete list of entities (both their abbreviations and full names) and associated entity codes, refer to *Event Messages for Routers*.

After you specify the number of the slot on which the trap will be received, you specify the entity name for which you want to configure traps.

Using the BCC

To specify a trap entity, based on slot and protocol entity, enter the following command at the SNMP prompt:

trap-entity entity <entity_number> slot <slot_number>

entity_number is the code assigned to the entity issuing the event that uniquely identifies an event.

slot_number is the number of the slot on which the trap will be received.

For example, the following command line causes the SNMP agent to send to a network management station a trap for the IP protocol (entity 2) on slot 2.

```
snmp# trap-entity entity 2 slot 2
trap-entity/2/2#
```

Using Site Manager

To specify a trap entity, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Trap Configuration .	The Trap Configuration menu opens.
5. Choose Interfaces .	The Trap Configuration window opens.
6. Select the slot for which you want to configure traps by clicking on the bar in the Slot box.	
7. Select an entity for which you want to configure traps. If you want to configure traps for all entities running on a slot, choose All Entities from the top of the column.	The entity names appear in the Available Entities column, a comprehensive list of all protocols available, regardless of the platform or software you are using.
8. Click on Update .	The entity name moves to the Current Entities column, indicating that you want to receive traps for this entity at the severity level you specified. (To move an entity from the column, select the entity name and then click on Remove .)
9. Repeat steps 6 through 8 for other slots you want to configure.	
10. Click on Save .	You return to the Configuration Manager window.

Specifying the Severity Level for Traps

Trap messages are always associated with one of five severity levels: information, warning, fault, trace, or debug. The severity level defines the type of trap that the SNMP agent sends to the network management station for the slot number and entity type you specified. For a description of the severity levels, see *Event Messages for Routers*.

Using the BCC

By default, the attribute for all levels is set to **off**.

To turn on fault-level messages, enter:

fault-log on

To turn on warning-level messages, enter:

warning-log on

To turn on information-level messages, enter:

information-log on

To turn on trace-level messages, enter:

trace-log on

To turn on debug-level messages, enter:

debug-log on

Using Site Manager

To specify a trap entity and the severity level at which you want to receive the trap, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
4. Choose Trap Configuration .	The Trap Configuration menu opens.
5. Choose Interfaces .	The Trap Configuration window opens.
6. Select the slot for which you want to configure traps by clicking on the bar in the slot box.	
7. Select the severity level at which you want to receive traps by clicking on the Events box at the bottom of the window. For a description of severity levels, see Chapter 2.	
8. Click on Update .	The entity name moves to the Current Entities column, indicating that you want to receive traps for this entity at the severity level you specified. (To move an entity from the column, select the entity name and then click on Remove .)
9. Repeat steps 6 through 8 for other slots you want to configure.	
10. Click on Save .	You return to the Configuration Manager window.

Disabling a Trap Entity

You can prevent the SMNP agent from sending a specific trap entity to a network management station regardless of slot by disabling the trap entity.

Using the BCC

Trap entities are enabled by default. To prevent the SMNP agent from sending a specific trap entity to a network management station regardless of slot, enter the following command at the trap entity-specific prompt:

disable

For example, the following command prevents the SNMP manager from sending traps for entity 2 on slot 2.

```
trap-entity/2/2# disable
trap-entity/2/2#
```

Using Site Manager

To disable a trap entity, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Trap Configuration .	The Trap Configuration menu opens.
5. In the Current Entities column, select the entity name that you want to delete.	The entity name that you selected is highlighted.
6. Click on Remove .	The entity name is removed from the Current Entities column.
7. Click on Save .	Site Manager saves the changes that you made.

Configuring Trap Exceptions

You can configure up to 50 trap exceptions, which specify that the SNMP agent always sends or never sends traps to the network management station, regardless of the trap configuration settings and regardless of the slot you specified.

You configure a trap exception by specifying the following:

- Entity code for the event for which you want to configure an exception
- Code number of the event for which you want to configure an exception
- Whether the SNMP agent always sends or never sends a trap to the network management station

For entity codes, see *Event Messages for Routers*.

Using the BCC

To specify a trap exception based on protocol entity and entity code, enter the following command at the SNMP prompt:

trap-event entity <entity_number> event <entity_code>

entity_number is the value assigned to the entity issuing the message.

entity_code is a numerical value assigned to the message.

For example, the following command causes the SNMP agent to send a network management station a trap for IP protocol (entity 2) generating messages for interfaces that transition to the down state.

```
snmp# trap-event entity 2 event 3
trap-event/2/3# info
    on snmp
    state enabled
    entity 2
    event 3
snmp#
```

Using Site Manager

To configure a trap exception, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu open.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Trap Configuration .	The Trap Configuration menu opens.
5. Choose Exceptions .	The Trap Exceptions List window opens.
6. Click on Add .	The Add Trap window opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
7. Set the following parameters: <ul style="list-style-type: none">• Entity Code• Event Code• Always/Never Trap Click on Help or see the parameter descriptions beginning on page A-7.	
8. Click on OK .	You return to the Configuration Manager window.

Deleting Trap Exceptions

You can delete a trap exception by specifying the entity number and the event code for the trap event.

Using the BCC

To delete a trap exception, navigate to the SNMP prompt and enter:

trap-event entity <entity_number> event <event_code>

entity_number is the code assigned to the entity issuing the event that uniquely identifies an event.

event_code is a unique code assigned to the event.

Together, the entity number and event code uniquely identify a router event.

For example, the following command causes the SNMP agent to delete a trap for IP protocol (entity 2) whose event code is 3.

```
snmp# trap-event entity 2 event 3  
trap-event/2/3#
```

Using Site Manager

To delete a trap exception, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose SNMP .	The SNMP menu opens.
4. Choose Trap Configuration .	The Trap Configuration menu opens.
5. Choose Exceptions .	The Trap Exceptions List window opens.
6. Select the trap for which you want to delete the exception.	
7. Click on Delete .	You return to the Configuration Manager window.

Configuring Thresholds

You cannot configure thresholds using the BCC.

You can configure thresholds for any integer, counter, gauge, or time-tick variable in the MIB. For more information about when to use thresholds, see Chapter 2.

To configure a threshold, you must have a good understanding of the MIB and be able to identify the instances of MIB objects to which you want to apply a threshold. For complete information about identifying a MIB object or an instance identifier, see the statistics section of *Configuring and Managing Routers with Site Manager*.

Disabling and Reenabling Thresholds

By default, the thresholds feature is enabled on all interfaces on which IP is configured.

To disable and reenable thresholds, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.
4. Choose Global .	The Edit Thresholds Global Parameters window opens.
5. Set the Enable/Disable parameter. Click on Help or see the parameter description on page A-8.	
6. Click on OK .	You return to the Configuration Manager window.

Setting the Threshold Polling Interval

The threshold polling interval sets the time interval at which the agent polls the variable to determine whether that variable has reached a threshold. You must set a minimum polling interval of 5 seconds; there is no maximum value. The default polling interval is 60 seconds.

When setting a polling interval, remember that the more often the agent polls the variable, the more memory it needs to manage the thresholds for this statistic.

To set the threshold polling interval, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.
4. Choose Global .	The Edit Thresholds Global Parameters window opens.
5. Set the Polling Interval parameter. Click on Help or see the parameter description on page A-9.	
6. Click on OK .	You return to the Configuration Manager window.

Adding a Threshold

To add a threshold, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.
4. Choose Global .	The Edit Thresholds Global Parameters window opens.
5. Click on Add .	The Threshold Configuration window opens, displaying a list of all MIB objects the agent supports.
6. Select the object to which you want to apply a threshold.	The object appears in the Object field.
7. Enter the instance identifier in the Instance field.	

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
8. Click on Save .	The Threshold Interface Lists window opens again.
9. Click on Apply .	
10. Repeat steps 5 through 9 to add other thresholds.	
11. Click on Done when you have finished adding thresholds.	You return to the Configuration Manager window.

Enabling and Disabling Thresholds for a Variable

You can decide whether to turn the threshold for a specific variable on or off by specifying the Threshold Enable parameter.

To tell the agent to apply the threshold to a variable, specify **Enable**. To tell the agent to ignore the threshold for a variable, specify **Disable**.

To enable or disable thresholds for a variable, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.
4. Choose Thresholds .	The Thresholds Interface Lists window opens.
5. Set the Threshold Enable parameter. Click on Help or see the parameter description on page A-9.	
6. Click on Done .	You return to the Configuration Manager window.

Specifying a Value for the Threshold Level

You can specify an integer value that determines the level (low, medium, or high) at which you want the agent to generate a threshold exception event for a variable.

To specify a value for the threshold level, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.
4. Choose Thresholds .	The Thresholds Interface Lists window opens.
5. Set the following parameters: <ul style="list-style-type: none">• Threshold Low Value• Threshold Medium Value• Threshold High Value Click on Help or see the parameter descriptions beginning on page A-10.	
6. Click on Done .	You return to the Configuration Manager window.

Specifying the Severity Level for Event Messages

You can specify the severity level of the event message that the agent generates when a variable exceeds either a low, medium, or high threshold level.

You can specify one of these severity levels:

- *Information*: allows low, medium, or high threshold exceptions to generate routine events that require no action.
- *Warning*: allows low, medium, or high threshold exceptions to generate events that indicate an unexpected situation occurred.
- *Debug*: allows low, medium, or high threshold exceptions to generate events you use to solve network problems.

To specify the severity level for event messages, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.
4. Choose Thresholds .	The Thresholds Interface Lists window opens.
5. Set the following parameters: <ul style="list-style-type: none"> • Threshold Low Event Level • Threshold Medium Event Level • Threshold High Event Level Click on Help or see the parameter descriptions beginning on page A-10.	
6. Click on Done .	You return to the Configuration Manager window.

Specifying Threshold Units

You can specify the units used to determine whether a variable has exceeded a threshold.

- To generate a threshold event when the variable's rate of change *per second* reaches one of the thresholds, set the Threshold Units parameter to Persecond.
- To generate a threshold event when the value of the variable reaches one of the three thresholds, set the Threshold Units parameter to Absolute.

To specify threshold units, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.
4. Choose Thresholds .	The Thresholds Interface Lists window opens.
5. Set the Threshold Units parameter. Click on Help or see the parameter description on page A-13.	
6. Click on Done .	You return to the Configuration Manager window.

Determining When to Record Threshold Events

You can determine when the agent generates a threshold event by setting the Threshold Action parameter.

By default, the agent generates a threshold event when the value of the variable you specify is *greater than* the threshold you specify. If you want the agent to generate threshold events when the value of the variable is *less than* the threshold you specify, set the Threshold Action parameter to Lessthan.

To determine when to record threshold events, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.
4. Choose Thresholds .	The Thresholds Interface Lists window opens.
5. Set the Threshold Action parameter. Click on Help or see the parameter description on page A-13.	
6. Click on Done .	You return to the Configuration Manager window.

Specifying Maximum Successive Alarms

A maximum successive alarm represents two or more polling periods when the agent generates an alarm as a result of an exception at the same threshold level.

You can specify an integer to determine the maximum number of successive alarms that the agent generates for a variable. When the agent exceeds the maximum number of alarms, it marks the threshold as held. The agent generates no more alarms until the variable either crosses the threshold at a different level or crosses no threshold for the number of polling intervals equal to the value of the Threshold HoldDown Intervals parameter.

To specify the maximum number of successive alarms, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.
4. Choose Thresholds .	The Thresholds Interface Lists window opens.
5. Set the Threshold Max Successive Alarms parameter. Click on Help or see the parameter description on page A-14.	
6. Click on Done .	You return to the Configuration Manager window.

Specifying Polling Intervals for Held Variables

You can specify an integer value to determine the number of exception-free polling intervals through which a variable in a held state must pass before the variable is no longer considered held. The lower the number you specify, the more likely the agent is to generate repetitive event messages for a variable that is intermittently exceeding thresholds.

To specify the number of exception-free polling intervals through which a variable in a held state must pass before the variable is no longer considered held, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
4. Choose Thresholds .	The Thresholds Interface Lists window opens.
5. Set the Threshold HoldDown Intervals parameter. Click on Help or see the parameter description on page A-14.	
6. Click on Done .	You return to the Configuration Manager window.

Specifying a Threshold Object Name

By default, the ASN.1 object identifier is the object name that appears in the Threshold Label parameter field. You can replace the ASN.1 object identifier by specifying a name for the object in string format. The string you enter appears in the log file, making it easier to identify the object that is the subject of the trap.

To specify a threshold object name, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose Thresholds .	The Thresholds menu opens.
4. Choose Thresholds .	The Thresholds Interface Lists window opens.
5. Set the Threshold Label parameter. Click on Help or see the parameter description on page A-15.	
6. Click on Done .	You return to the Configuration Manager window.

Chapter 4

Customizing BootP

This chapter describes how to customize BootP services. It assumes you have configured an IP interface and enabled BootP on this interface using the default parameters, as described in Chapter 1, and that you understand the BootP concepts in Chapter 2.

You can enable BootP services most easily by accepting all the default configuration parameter values. However, you may want to change these values, depending on your network requirements. This chapter describes choices you can make to use BootP most effectively on your network.

Topic	Page
Customizing BootP Relay Agent Parameters	4-2
Setting Up the Routing Path Between the BootP Server and the Routers	4-5
Specifying Interfaces to Receive and Relay BOOTREQUEST Packets	4-7
Configuring an AN to Use EZ Install over a Frame Relay PVC	4-11
Specifying Servers for BootP Services	4-13
Deleting the BootP Relay Agent from an IP Interface	4-18
Deleting BootP Globally	4-18

Customizing BootP Relay Agent Parameters

After you have configured all the IP interfaces for BootP services, you can configure BootP relay agent parameters for all of these IP interfaces. The BootP relay agent is responsible for transmitting BOOTREQUEST packets to servers on the network and for transmitting BOOTREPLY packets to clients.

Disabling and Reenabling BootP

When you enable IP on an interface, BootP is automatically enabled on that interface and default values are in effect for all BootP parameters (see Appendix B for parameter defaults).

To disable or reenable BootP, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens. This window lists all the IP interfaces that you have configured for BOOTP services on the router.
5. Set the Enable/Disable parameter. Click on Help or see the parameter description on page A-16.	
6. Click on Apply .	
7. Click on Done .	You return to the Configuration Manager window.

Specifying Maximum Number of Hops from Client to Server

A *hop* is the logical distance between a source device and a destination device. Source-device combinations can include a BootP relay agent and a BootP server, a client and a BootP relay agent, or two BootP relay agents.

By default, the maximum number of hops a packet can take from the source device to the destination device (client to server) is four. If the value in the hops field of a BOOTREQUEST packet is greater than the value specified for the max-hops parameter, the router drops the packet.

To specify the maximum number of hops from client to server, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens. This window lists all the IP interfaces that you have configured for BOOTP services on the router.
5. Set the Hops parameter. Click on Help or see the parameter description on page A-16.	
6. Click on Apply .	
7. Click on Done .	You return to the Configuration Manager window.

Specifying a Minimum Timeout Value

By default, the router immediately forwards BOOTREQUEST packets to the destination address in the BootP relay forwarding table. You can determine the amount of time (in seconds) that the router waits before forwarding a BOOTREQUEST packet out an interface by assigning a value to the Timeout Secs. parameter. If the value in the seconds field of a BOOTREQUEST packet is less than the value you specified for the Timeout Secs. parameter you configured on the interface, the router drops the packet.

The default value is 0 seconds. To change the default, specify a value from 1 to 65535 seconds.

To specify a minimum timeout value, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens. This window lists all the IP interfaces that you have configured for BOOTP services on the router.
5. Set the Timeout Secs. parameter. Click on Help or see the parameter description on page A-17.	
6. Click on Apply .	
7. Click on Done .	You return to the Configuration Manager window.

Specifying the Relay Mode for Packet Forwarding

BootP and DHCP use the BootP relay agent to forward packets. You can allow the BootP relay agent to forward BootP, DHCP packets, or both by specifying the Pass Through Mode parameter. The default setting is BootP, which allows the interface to transmit only BootP packets. Be sure to change the setting if you want to transmit DHCP packets.

To set the relay mode on a BootP interface, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens. This window lists all the IP interfaces that you have configured for BOOTP services on the router.
5. Set the Pass Through Mode parameter. Click on Help or see the parameter description on page A-17.	
6. Click on Apply .	
7. Click on Done .	You return to the Configuration Manager window.

Setting Up the Routing Path Between the BootP Server and the Routers

You must define the routing path between the BootP server and the routers to ensure the successful transmission of BOOTREQUEST packets from one end of the network to the other. You define this routing path by:

- Enabling BootP forwarding on upstream routers
- Specifying interfaces to receive and relay BOOTREQUEST packets
- Creating a BootP relay agent forwarding table for each router in the path

Enabling BootP on Router Interfaces

Before you enable BootP on router interfaces, make sure that the router is in forwarding mode. Setting the router to forwarding mode allows the BootP relay agent to route (forward) all BOOTREQUEST packets and to process both broadcast packets and all packets explicitly addressed to it. For instructions on configuring the router in forwarding mode, see *Configuring IP Services*.

You must enable BootP (also called BootP pass-through or gateway) on all interfaces in the paths between the routers and the BootP server. For example, you would enable BootP on the interfaces indicated in [Figure 4-1](#).




Figure 4-1. Enabling BootP in a Sample Network

To enable BootP on an interface, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, click on the connector.	The Edit Connector window opens.
2. Choose Edit Circuit .	The Circuit Definition window opens.
3. Choose Protocols .	The Protocols menu opens.
4. Choose Add .	The Select Protocols window opens.
5. Choose BOOTP .	
6. Click on OK .	
7. Choose File .	
8. Choose Exit .	You return to the Configuration Manager window.

Specifying Interfaces to Receive and Relay BOOTREQUEST Packets

You can specify a forwarding route for BOOTREQUEST packets by defining a relationship between an interface you want to receive BOOTREQUEST packets and another to transmit BOOTREQUEST packets. When you define this type of relationship, the interface pair appears in the BootP relay agent forwarding table.

Depending on the configuration of your network, you can specify:

- One input IP interface to forward packets to multiple output IP interfaces
- Multiple input interfaces to forward to multiple output interfaces
- Multiple input interfaces to forward to one output interface

Creating a BootP Relay Agent Forwarding Table

You must create a BootP relay agent forwarding table for every transient router passing BootP traffic between a router and the BootP server.

The BootP relay agent forwarding table consists of IP interfaces that you configure to receive the incoming BootP request packets and to forward the outgoing BootP request packets. The BootP relay agent forwards BootP request packets based on the IP addresses of the interfaces in this table. You can add multiple pairs of incoming and outgoing interfaces to support connections to multiple routers in your network. For more information about configuring a forwarding table, see *Configuring IP Services*.

Specifying the IP Interface Input/Output Address Pair

You create the BootP relay agent forwarding table by specifying the IP interface addresses (input and output) of the pair that you want to receive and forward BOOTREQUEST packets. If you enter an IP address that you have not configured on the router, the notation ??? appears before the IP address (example: ??? 111.111.111.111). When you configure the IP address on the router, Site Manager replaces ??? with the appropriate address.

Do not specify an unnumbered interface for the input or output IP interface address parameters. If you want to use an unnumbered interface to transmit BOOTREQUEST or DHCP packets to the servers, you must set up a preferred server in the BootP Relay Agent Interface Table window (see “[Configuring BootP Preferred Servers](#),” on [page 4-13](#)).

To specify the IP interface input/output address pair, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens. This window lists all the IP interfaces that you have configured for BOOTP services on the router.
5. Click on Forward I/F .	The BOOTP Relay Agent Forwarding Table window opens.
6. Click on Add .	The BOOTP Addresses window opens.
7. Set the following parameters: <ul style="list-style-type: none"> • Input IP Address • Output IP Address Click on Help or see the parameter descriptions beginning on page A-19.	
8. Click on OK .	The BOOTP Relay Agent Forwarding Table opens.
9. Click on Done .	You return to the Configuration Manager window.

Deleting an IP Interface Input/Output Address Pair

To delete an input/output address pair from the BootP relay agent forwarding table, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens.
5. Click on Forward I/F .	The BOOTP Relay Agent Forwarding Table window opens.
6. Select the address pair you want to delete.	

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
7. Click on Delete .	The BOOTP Relay Agent Forwarding Table window no longer displays the address pair.
8. Click on Done .	You return to the Configuration Manager window.

Disabling BootP Route Forwarding

By default, the route (interface) through which the router forwards BootP or DHCP packets to servers on the network is enabled. You can disable BootP or DHCP packet forwarding through this route by setting the Enable/Disable parameter to Disable.

To disable BootP router forwarding, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens. This window lists all the IP interfaces that you have configured for BOOTP services on the router.
5. Click on Forward I/F .	The BOOTP Relay Agent Forwarding Table window opens.
6. Select the address pair you want.	
7. Set the Enable/Disable parameter. Click on Help or see the parameter description on page A-19.	
8. Click on Apply .	
9. Click on Done .	You return to the Configuration Manager window.

Configuring an AN to Use EZ Install over a Frame Relay PVC

If you intend to configure an AN router to use EZ Install[™] over a frame relay PVC in group access mode, you must create a BootP *client interface table*. You do not need to create this table if you configured the frame relay PVC to operate in direct access mode.

The BootP client interface table allows you to specify and pair the IP address of a remote AN router with the DLCI of its frame relay group access PVC.

The *upstream router* is a booting router's next-hop router. By default, the booting router's synchronous interfaces automatically try to get IP addresses from the upstream router. This is the EZ Install process.

If a router using EZ Install gets its address from the upstream router, and the upstream router's interface to that router is a frame relay group access PVC, you must connect to the upstream router and create a BootP client interface table (in addition to a BootP relay agent forwarding table).

For information about configuring an AN to use EZ Install, see *Installing and Operating BayStack AN and ANH Systems*. For information about DLCIs and frame relay, see *Configuring Frame Relay Services*.

Creating a BootP Client Interface Table

You create a BootP client interface table by specifying the client IP address and the frame relay PVC DLCI number.

Specifying the Client IP Address

You must specify the IP address of the remote AN router that will boot using EZ Install over a frame relay group access PVC connection to the router.

To specify a client IP address, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens.
5. Click on Client I/F .	The BOOTP Client Interface window opens.
6. Click on Add .	The BOOTP Client Interface Address window opens.
7. Set the IP Address parameter. Click on Help or see the parameter description on page A-21.	
8. Click on OK .	
9. Click on Done .	You return to the Configuration Manager window.

Specifying the DLCI Number

You must specify in decimal format the frame relay PVC identification number whose destination is the remote AN that will boot using EZ Install. Use the DLCI number assigned by your frame relay service provider. The frame relay network uses the DLCI number to direct data flow.

To specify the DLCI number, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens.
5. Click on Client I/F .	The BOOTP Client Interface window opens.
6. Click on Add .	The BOOTP Client Interface Address window opens.
7. Set the DLCI Number parameter. Click on Help or see the parameter description on page A-21.	
8. Click on OK .	
9. Click on Done .	You return to the Configuration Manager window.

Specifying Servers for BootP Services

You can specify a forwarding route for BOOTREQUEST packets by defining a relationship between an input interface and a BootP server. By defining such a relationship, you can:

- Improve the efficiency of BOOTREQUEST packet relay.
- Transmit BOOTREQUEST packets through unnumbered output interfaces.

Configuring BootP Preferred Servers

You can configure a BootP preferred server by specifying the IP address of the relay agent on the router and the IP address of the target server. The router can then unicast a BOOTREQUEST packet through normal IP services to that server.

Specifying the Relay Agent IP Address

You must specify the IP address of a numbered network interface that you want to receive BOOTREQUEST or DHCP packets from clients. You can then configure this IP address on the router, if you have not already done so.

Do not specify an unnumbered interface for this parameter.

To specify the relay agent IP address, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens.
5. Click on Pref Serv.	The BOOTP Relay Agent Preferred Server Table opens.
6. Click on Add .	The BOOTP Preferred Server Configuration window opens.
7. Set the Relay Agent IP Address parameter. Click on Help or see the parameter description on page A-22.	
8. Click on OK .	
9. Click on Done .	You return to the Configuration Manager window.

Specifying the Target Server IP Address

After you specify the relay agent IP address, you must specify the IP address of the server that should receive the BOOTREQUEST or DHCP packet from the relay agent.

To specify the target server IP address, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens.
5. Click on Pref Serv.	The BOOTP Relay Agent Preferred Server Table opens.
6. Click on Add .	The BOOTP Preferred Server Configuration window opens.
7. Set the Target Server IP Address parameter. Click on Help or see the parameter description on page A-22.	
8. Click on OK .	
9. Click on Done .	You return to the Configuration Manager window.

Specifying the Target Server's Host Name

If you want to keep track of the names of BootP and DHCP servers, specify the target server's host name. The host name cannot exceed 63 ASCII characters, including embedded spaces.

To specify the target server's host name, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens.
5. Click on Pref Serv.	The BOOTP Relay Agent Preferred Server Table opens.
6. Set the Target Name parameter. Click on Help or see the parameter description on page A-23.	
7. Click on Apply .	
8. Click on Done .	You return to the Configuration Manager window.

After you specify the IP address and host name of the target server, the BootP Relay Agent Preferred Server Table window shows the address pair you added and default values for the Enable/Disable and Pass Through Mode parameters.

Disabling the Forwarding Route

By default, BootP and DHCP forwarding is enabled for the route that you configured. You can disable BootP or DHCP forwarding on this route, if you choose, by setting the Enable/Disable parameter to Disable.

To disable the forwarding router, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens.
5. Click on Pref Serv.	The BOOTP Relay Agent Preferred Server Table opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
6. Set the Enable/Disable parameter. Click on Help or see the parameter description on page A-23.	
7. Click on Apply .	
8. Click on Done .	You return to the Configuration Manager window.

Filtering BootP and DHCP Packets

You can control whether an interface transmits BootP packets, DHCP packets, or both to a server by configuring filters for these specific packets. You configure this type of filter by setting the Pass Through Mode parameter in Site Manager. The default setting is BootP and allows the interface to transmit only BootP packets. Be sure to change the setting if you want to transmit DHCP messages.

To filter BootP and DHCP packets, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens.
5. Click on Pref Serv.	The BOOTP Relay Agent Preferred Server Table opens.
6. Set the Pass Through Mode parameter. Click on Help or see the parameter description on page A-23.	
7. Click on Apply .	
8. Click on Done .	You return to the Configuration Manager window.

Deleting the BootP Relay Agent from an IP Interface

To delete a BootP relay agent from an IP interface, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens.
5. Click on the interface from which you want to delete BootP.	
6. Click on Delete .	The Configuration Manager deletes the BootP relay agent and all forwarding table entries that you specified from the selected interface.
7. Click on Done .	You return to the Configuration Manager window.

Deleting BootP Globally

To globally delete BootP from all interfaces on a router, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Delete .	The Delete menu opens.
5. Click on Delete .	Configuration Manager deletes BootP from all interfaces on the router.

Chapter 5

Customizing BootP/DHCP Relay

This chapter describes how to customize BootP/DHCP relay services. It assumes you have configured an IP interface using the default parameters and enabled BootP/DHCP relay, as described in Chapter 1, and that you understand the DHCP concepts in Chapter 2.

When you enable BootP/DHCP relay, all default parameter values are automatically enabled on that interface (refer to Appendix B for default parameters). You may want to change these default values, depending on your network requirements. This chapter describes choices you can make to use BootP/DHCP relay most effectively on your network.

Topic	Page
Setting Up the Routing Path Between the DHCP Server and a BootP Relay Agent	5-2
Deleting BootP/DHCP Relay from an IP Interface	5-4
Deleting BootP/DHCP Relay Globally	5-5

Setting Up the Routing Path Between the DHCP Server and a BootP Relay Agent

You must define a routing path between the DHCP server and the router (configured as a BootP relay agent) to ensure the successful transmission of packets from one end of the network to the other. You define this routing path by:

- Specifying interfaces to receive and forward DHCP packets
- Defining a DHCP server

Specifying Interfaces to Receive and Forward DHCP Packets

BootP/DHCP relay uses the BootP relay agent to forward packets to and receive packets from DHCP servers. You must define a forwarding route for DHCP packets by defining a relationship between an interface you configure to receive DHCP packets from servers and an interface you want to send DHCP packets to servers. When you define this type of relationship, the interface pair appears in the BootP relay agent forwarding table. For instructions, see “Specifying Interfaces to Receive and Relay BOOTREQUEST Packets” on page 4-7.

To allow the BootP relay agent to forward DHCP packets, set the Pass Through Mode parameter in the BOOTP Relay Agent Forwarding Table window to DHCP.

To specify interfaces to receive and relay DHCP packets and set DHCP as the mode for packet forwarding, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens. This window lists all the IP interfaces that you have configured for BOOTP services on the router.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
5. Click on Forward I/F.	The BOOTP Relay Agent Forwarding Table window opens.
6. Select the address pair you want.	
7. Set the Pass Through Mode parameter. Click on Help or see the parameter description on page A-23.	
8. Click on Apply.	
9. Click on Done.	You return to the Configuration Manager window.

Defining DHCP Servers

If DHCP clients obtain IP addresses and other configuration information from a DHCP server on a different subnet, connected through a router, then you must define a DHCP preferred server by specifying the IP address of the BootP relay agent on the local router and the IP address of the target server. The router can then unicast a BOOTREQUEST packet through normal IP services to that server. For instructions, see “Specifying Servers for BootP Services” on page 4-13.

To allow DHCP operation, be sure to set the Pass Through Mode parameter in the BOOTP Relay Agent Preferred Server Table window to DHCP.

To define a preferred DHCP server, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols.	The Protocols menu opens.
2. Choose IP.	The IP menu opens.
3. Choose BOOTP.	The BOOTP menu opens.
4. Choose Relay Agent Interface Table.	The BOOTP Relay Agent Interface Table window opens.
5. Click on Pref Serv.	The BOOTP Relay Agent Preferred Server Table opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
6. Set the Pass Through Mode parameter. Click on Help or see the parameter description on page A-23.	
7. Click on Apply .	
8. Click on Done .	You return to the Configuration Manager window.

Deleting BootP/DHCP Relay from an IP Interface

To delete BootP/DHCP relay from an IP interface, while maintaining BootP on that interface, set the Pass Through Mode parameter in the BOOTP Relay Agent Interface Table window to BOOTP.

To delete BootP/DHCP relay from an IP interface, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose BOOTP .	The BOOTP menu opens.
4. Choose Relay Agent Interface Table .	The BOOTP Relay Agent Interface Table window opens. This window lists all the IP interfaces that you have configured for BOOTP services on the router.
5. Click on Forward I/F .	The BOOTP Relay Agent Forwarding Table window opens.
6. Select the address pair you want.	
7. Set the Pass Through Mode parameter. Click on Help or see the parameter description on page A-23.	
8. Click on Apply .	
9. Click on Done .	You return to the Configuration Manager window.

To delete both BootP/DHCP relay and BootP from an IP interface, delete the BootP relay agent on that interface. For instructions, see “Deleting the BootP Relay Agent from an IP Interface” on page 4-18.

Deleting BootP/DHCP Relay Globally

To delete BootP/DHCP globally, you must delete BootP globally. For instructions, see “Deleting BootP Globally” on page 4-18.

Chapter 6

Customizing the DHCP Server

This chapter describes how to customize the DHCP server configuration on the router. It assumes you have configured an IP interface using the default parameters and enabled a DHCP server on the interface, as described in Chapter 1, and that you understand the DHCP server concepts in Chapter 2.

After you start the DHCP server, default parameter values are in effect for all parameters (refer to Appendix B for default parameters). You customize the DHCP server by modifying these parameters as described in the following sections.

Topic	Page
Modifying the DHCP Server Configuration	6-2
Deleting the DHCP Server on the Router	6-9
Deleting DHCP Globally	6-10

Modifying the DHCP Server Configuration

You can determine how a DHCP server functions on the router by modifying its configuration. Use the remaining sections in this chapter as a guide.

Reenabling and Disabling the DHCP Server on the Router

After you configure IP on an interface and create and enable the DHCP server, as described in Chapter 1, all DHCP server global default parameter values are automatically enabled on the interface. If you disable DHCP, it is no longer available on all IP circuits.

To disable and reenabling the DHCP server on the router, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.
4. Choose Global .	The DHCP Global Parameters window opens.
5. Set the Enable parameter. Click on Help or see the parameter description on page A-24.	
6. Click on OK .	Site Manager saves your changes and exits the window.

Configuring the NetID Server Manager IP Address

You must configure the IP address of the NetID Server Manager to allow it to communicate with the target DHCP server. To configure the IP address of the NetID Server Manager, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.
4. Choose Global .	The DHCP Global Parameters window opens.
5. Set the Server Manager IP Address parameter. Click on Help or see the parameter description on page A-24.	
6. Click on OK .	Site Manager saves your changes and exits the window.

Specifying the DHCP Server TCP Port Number

You must specify a remote TCP port number on the DHCP server to allow the DHCP server to communicate with the NetID Server Manager using TCP. This number must match the port number that you specify on the NetID Server Manager.

You specify the TCP port number on the NetID Server Manager when you install the NetID Server Manager software application. The default TCP port number is 24736. For information about specifying a remote port number for the NetID Server Manager, see the *NetID Server Products Guide*.

To specify the TCP port number on the DHCP server, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.
4. Choose Global .	The DHCP Global Parameters window opens.
5. Set the DHCP Server TCP Port Number parameter. Click on Help or see the parameter description on page A-24.	
6. Click on OK .	Site Manager saves your changes and exits the window.

Determining Whether an IP Address Is Available on the Network

Before the DHCP server assigns an IP address to a DHCP client, it must ensure that the IP address is not already in use on the network.

To verify that the IP address is available, the DHCP server sends out an ICMP Echo request, called a *ping*. If the server fails to receive a response to the request within the specified timeout period (ping request timeout), the DHCP server offers the IP address and grants a lease to the client. If the DHCP server receives a response to the request, the IP address is unavailable and therefore cannot be offered to the client.

By default, the DHCP server pings the IP address of a prospective DHCP client only once before declaring it available.

To specify the number of times the DHCP server pings a prospective DHCP client, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.
4. Choose Global .	The DHCP Global Parameters window opens.
5. Set the Number of Pings parameter. Click on Help or see the parameter description on page A-24.	
6. Click on OK .	Site Manager saves your changes and exits the window.

Changing the Ping Timeout Value

The DHCP client typically waits three-quarters of a second for a conflict detection ping to time out before determining that a DHCP server is unavailable to respond to its DHCPDISCOVER request. If you want to change the length of time (in milliseconds) that the DHCP server waits, specify a value between 1 and 5000 (5 seconds).

To change the ping timeout value for the DHCP server, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
4. Choose Global .	The DHCP Global Parameters window opens.
5. Set the Ping Timeout parameter. Click on Help or see the parameter description on page A-24.	
6. Click on OK .	Site Manager saves your changes and exits the window.

Specifying the DHCP Server Operating Mode

By default, the mode in which the DHCP server operates is called Safe Mode.

When Safe Mode is enabled, the DHCP server cannot acknowledge the DHCP client's lease request until it receives a successful lease commit acknowledgment from the NetID Server Manager. Typically, you can enable Safe Mode when you want to ensure that the client receives only successful committed leases from the DHCP server and the NetID Server Manager.

When Safe Mode is disabled, the DHCP server immediately returns a lease-granted acknowledgment to the DHCP client in response to its lease request without having to wait for a successful commit acknowledgment from the NetID Server Manager. With Safe Mode disabled, the DHCP server still can assign IP addresses to clients even if it has temporarily lost communication with the NetID Server Manager.

To enable or disable Safe Mode on the DHCP server, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
4. Choose Global .	The DHCP Global Parameters window opens.
5. Set the Safe Mode parameter. Click on Help or see the parameter description on page A-24.	
6. Click on OK .	Site Manager saves your changes and exits the window.

Specifying Maximum Number of Pending Leases

By default, the maximum number of lease requests sent to the DHCP server that are pending commitment by the NetID Server Manager is 2. You can increase the maximum number of pending leases by specifying a number from 1 to 255.

When the number of lease requests sent to the NetID Server Manager and pending commitment by the Server Manager reaches this value, the DHCP server holds all subsequent lease requests. When the number of pending request decreases to half this value, the DHCP server begins forwarding requests to the NetID Server Manager again.

To specify the maximum number of lease requests sent to the DHCP server that are pending commitment, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.
4. Choose Global .	The DHCP Global Parameters window opens.

(continued)

Site Manager Procedure <i>(continued)</i>	
You do this	System responds
5. Set the Max. No. Pending Leases parameter. Click on Help or see the parameter description on page A-24.	
6. Click on OK .	Site Manager saves your changes and exits the window.

Specifying the Debug Level

You can determine the debug messaging level you want to display in the log file for the DHCP server by entering a number from 1 to 10. Normally, only debug messages with a debug level of 0 are written to the log file.

Specifying a higher debug level causes additional messages to appear in the log file. Because additional information can rapidly fill the log file and cause loss of other information, change the debug level only to resolve critical problems.

To specify the debug messaging level you want, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.
4. Choose Global .	The DHCP Global Parameters window opens.
5. Set the Debug Level parameter. Click on Help or see the parameter description on page A-24.	
6. Click on OK .	Site Manager saves your changes and exits the window.

Specifying the IP Address for the DHCP Server

To ensure that the DHCP server can communicate with the NetID Server Manager, you must specify a local IP address that the DHCP server can use to identify itself to the NetID Server Manager. This address must correspond to the address of an actual local IP interface configured on the router. This address cannot be a circuitless IP address.

To specify a local IP address for the DHCP server, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.
4. Choose Global .	The DHCP Global Parameters window opens.
5. Set the Local IP Address parameter. Click on Help or see the parameter description on page A-24.	
6. Click on OK .	Site Manager saves your changes and exits the window.

Deleting the DHCP Server on the Router

To delete the DHCP server on the router, complete the tasks in the following table:

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose Global Protocols .	The Global Protocols menu opens.
3. Choose DHCP .	The DHCP menu opens.
4. Choose Delete DHCP .	

Deleting DHCP Globally

To delete DHCP globally, you must delete BootP globally. For instructions, see “Deleting BootP Globally” on page 4-18

Chapter 7

Customizing RARP

This chapter describes how to customize RARP services. It assumes you have configured an IP interface using the default parameters and enabled RARP services, as described in Chapter 1, and that you understand the RARP concepts in Chapter 2.

You can enable RARP services most easily by accepting all the default parameter values. However, you may want to change these values, depending on your network requirements. This chapter describes the choices you can make to use RARP most effectively on your network.

Topic	Page
Customizing RARP Parameters	7-2
Disabling and Reenabling RARP Interfaces	7-2
Defining the RARP Mapping Table	7-3
Disabling RARP Globally	7-5
Deleting RARP Globally	7-5

Customizing RARP Parameters

After you have enabled RARP services on your router (see Chapter 1), you can customize the router software for your specific requirements. Use the remaining sections in this chapter as a guide.

Disabling and Reenabling RARP Interfaces

You can disable or reenablen individual RARP interfaces by selecting them from a list of interfaces in the RARP Interface Table.

To disable and reenablen RARP interfaces, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose Reverse ARP .	The Reverse ARP menu opens.
4. Choose Interface Table .	The RARP Interface Table window opens.
5. Set the Enable/Disable parameter. Click on Help or see the parameter description on page A-28.	
6. Click on Apply .	
7. Click on Done .	You return to the Configuration Manager window.

Defining the RARP Mapping Table

The RARP mapping table lists the clients on the network that use the router's RARP services. You define the router's MAC address-to-IP address RARP mapping table by specifying the MAC addresses of clients and the corresponding IP addresses that the RARP server assigns to those clients.

Specifying the Client's MAC Address

You must specify the MAC address of each client that will use the RARP services of this router. The client will include the MAC address you specify here in RARP broadcasts to the router.

To specify the client's MAC address, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose Reverse ARP .	The Reverse ARP menu opens.
4. Choose Map Table .	The RARP Map Table window opens.
5. Click on Add .	The RARP Addresses window opens.
6. Set the MAC Address parameter. Click on Help or see the parameter description on page A-28.	
7. Click on OK .	You return to the Configuration Manager window.

Specifying the Client's IP Address

You must specify the IP address corresponding to the value of the MAC Address parameter you specify. Do not accept the default value.

When the router receives a RARP request from the client, it assigns this IP address to the client and includes it in a response packet.

To specify the client's IP address, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose Reverse ARP .	The Reverse ARP menu opens.
4. Choose Map Table .	The RARP Map Table window opens.
5. Click on Add .	The RARP Addresses window opens.
6. Set the IP Address parameter. Click on Help or see the parameter description on page A-29.	
7. Click on OK .	You return to the Configuration Manager window.

Disabling RARP Globally

To globally disable RARP from all router interfaces on which it is configured, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose Reverse ARP .	The Reverse ARP menu opens.
4. Choose Globals .	The Edit RARP Global Parameters window opens.
5. Set the Enable/Disable parameter to Disable.	
6. Click on OK .	The Configuration Manager disables RARP on all router interfaces and returns you to the Configuration Manager window.

Deleting RARP Globally

To globally delete RARP from all router interfaces on which it is configured, complete the tasks in the following table.

Site Manager Procedure	
You do this	System responds
1. In the Configuration Manager window, choose Protocols .	The Protocols menu opens.
2. Choose IP .	The IP menu opens.
3. Choose Reverse ARP .	The Reverse ARP menu opens.
4. Choose Delete RARP .	A confirmation window opens.
5. Click on OK .	The Configuration Manager deletes RARP from all router interfaces and returns you to the Configuration Manager window.

Appendix A

SNMP, BootP, DHCP, and RARP Parameter Descriptions

This appendix contains reference information about customizing the parameters for the SNMP, BootP, BootP/DHCP relay, DHCP server, and RARP interfaces you configure on the router.

Topic	Page
SNMP Global Parameters	A-3
SNMP Community Parameters	A-5
SNMP Manager Parameters	A-6
SNMP Trap Interface Parameters	A-7
SNMP Threshold Global Parameters	A-8
SNMP Threshold Interface Parameters	A-9
BootP and DHCP Parameters	A-16
BootP Address Parameters	A-18
BootP Client Interface Address Parameters	A-21
BootP Preferred Server Configuration Parameters	A-22
DHCP Global Parameters	A-24
RARP Interface Parameters	A-28
RARP Address Parameters	A-28

For each parameter, this appendix provides the following information:

- Parameter name
- Configuration Manager menu path
- Default setting
- Valid parameter options
- Parameter function
- Instructions for setting the parameter
- Management information base (MIB) object ID

The Technician Interface allows you to modify parameters by issuing **set** and **commit** commands with the MIB object ID. This process is equivalent to modifying parameters using Site Manager. For more information about using the Technician Interface to access the MIB, see *Using Technician Interface Software*.



Caution: The Technician Interface does not verify the validity of your parameter values. Entering an invalid value can corrupt your configuration.

SNMP Global Parameters

Use the following guidelines to configure SNMP global parameters in the Configuration Manager window.

Parameter: Enable

Path: Configuration Manager > Protocols > IP > SNMP > Global

Default: Enable

Options: Enable | Disable

Function: Specifies the state of the SNMP agent on all interfaces that support IP.

Instructions: Select Enable to enable the SNMP agent; select Disable to disable the SNMP agent.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.1.1

Parameter: Use Lock

Path: Configuration Manager > Protocols > IP > SNMP > Global

Default: Enable

Options: Enable | Disable

Function: Specifies whether the agent responds to multiple network management stations issuing simultaneous SNMP **set** commands to the router. When you set this parameter to Enable, the agent identifies the station from which it receives the next SNMP **set** command and, for a time equal to the value of the Lock Time Out parameter, responds only to SNMP **set** commands from that station. If the agent receives an SNMP **set** command from another network management station during this time, it issues an SNMP genErr GetResponse PDU, which that station logs as an SNMP set error message.

Instructions: Select Enable to prohibit the agent from responding to simultaneous SNMP commands from multiple network management stations.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.1.2

Parameter: Lock Time Out

Path: Configuration Manager > Protocols > IP > SNMP > Global

Default: 2 (minutes)

Options: 1 to 60 (minutes)

Function: Specifies the maximum number of minutes the agent allows an idle network management station to hold a lock on it. During this time, the agent locks out SNMP **set** commands from other network management stations. The lock timer is reset each time the locking manager issues an SNMP **set** command.

Instructions: Enter the number of minutes only if you set the Use Lock parameter to Enable.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.1.4

Parameter: Authentication Failure Traps

Path: Configuration Manager > Protocols > IP > SNMP > Global

Default: Enable

Options: Enable | Disable

Function: Specifies whether the router attempts to generate an authentication failure trap when it receives an SNMP message from an SNMP manager falsely claiming to be in a particular community or specifying an unknown community.

Instructions: Select Enable to enable the router to generate authentication failure traps. If you select Enable, you must configure an SNMP manager to receive the trap. You configure a trap in the Trap Configuration window.

Select Disable to prohibit the router from generating authentication failure traps.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.1.3.5

SNMP Community Parameters

Use the following guidelines to configure SNMP community parameters in the SNMP Community window.

Parameter: Community Name

Path: Configuration Manager > Protocols > IP > SNMP > Communities > Community > Add Community | Edit Community

Default: None

Options: Any string of printable ASCII characters, up to 63 characters in length, including embedded spaces

Function: Specifies the name of the SNMP community.

Instructions: Enter the SNMP community name.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.2.1.3

Parameter: Access

Path: Configuration Manager > Protocols > IP > SNMP > Communities > Community > Add Community | Edit Community

Default: Read Only

Options: Read Only | Read-Write

Function: Specifies the access privileges that the router grants to all members of this SNMP community.

Instructions: Select Read Only to allow members of this community to only view configuration and performance information about this router.

Select Read-Write to allow members of this community to not only view configuration and performance information about this router, but also change the router's configuration.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.2.1.4

SNMP Manager Parameters

Use the following guidelines to configure SNMP manager parameters in the SNMP Manager window.

Parameter: Trap Port

Path: Configuration Manager > Protocols > IP > SNMP > Communities > Community > Managers > Manager > Add Manager | Edit Manager

Default: 162

Options: 1 to 9999

Function: Specifies the number of the port on the management station to which the agent sends traps.

Instructions: The standard port number for trap messages is 162; however, you may enter a different port number. Be sure not to specify a port that another application uses.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.3.1.5

Parameter: Trap Types

Path: Configuration Manager > Protocols > IP > SNMP > Communities > Community > Managers > Manager > Add Manager | Edit Manager

Default: Generic

Options: None | Generic | Specific | All

Function: Specifies the type of trap the agent sends to this manager.

Instructions: Select None to prohibit the agent from sending traps to this manager.

Select Generic to configure the agent to send the well-defined SNMP traps (cold-start, warm-start, and authentication failure traps) to the manager. The cold-start and warm-start traps are automatically active in the SNMP agent; however, you must enable the Authentication Failure Traps global parameter for the agent to send such traps to this manager.

Select Specific to configure the agent software to send all enabled log event traps to this manager.

Select All to send cold-start traps, warm-start traps, and all enabled log event traps to this manager.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.3.1.6

SNMP Trap Interface Parameters

Use the following guidelines to configure SNMP trap interface parameters in the Add Trap window.

Parameter: Entity Code

Path: Configuration Manager > Protocols > IP > SNMP > Trap Configuration > Exceptions > **Add**

Default: None

Options: Any valid entity code

Function: Specifies the entity code for the event for which you want to configure an exception.

Instructions: Enter the entity code for the event for which you want to configure an exception. See *Event Messages for Routers* for entity codes.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.6.1.3

Parameter: Event Code

Path: Configuration Manager > Protocols > IP > SNMP > Trap Configuration > Exceptions > **Add**

Default: None

Options: Any valid event code number

Function: Specifies the code number for the event for which you want to configure an exception.

Instructions: Enter the event code number for the event for which you want to configure an exception. See *Event Messages for Routers* for event code numbers.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.6.1.4

Parameter: Always/Never Trap

Path: Configuration Manager > Protocols > IP > SNMP > Trap Configuration > Exceptions > **Add**

Default: None

Options: Always | Never

Function: Specifies whether the SNMP agent always sends or never sends this trap to the network management station. The instructions you specify in this field override the settings in the Trap Configuration window, and affect traps sent from every slot in the router.

Instructions: Select Always or Never.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.5.6.1.2

SNMP Threshold Global Parameters

Use the following guidelines to configure SNMP threshold global parameters in the Edit Thresholds Global Parameters window.

Parameter: Enable/Disable

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Global

Default: Enable

Options: Enable | Disable

Function: Enables or disables the threshold feature on a router.

Instructions: Select Enable to enable thresholds. Select Disable to disable thresholds.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.1.1

Parameter: Polling Interval

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Global

Default: 60 (seconds)

Options: 5 seconds minimum; no maximum value

Function: Sets the time interval at which the agent polls the variable to determine whether that variable has reached the threshold.

Instructions: Specify the number of seconds for the polling interval. Remember that the more often the agent polls the variable, the more memory it needs to manage the thresholds for this statistic.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.1.2

SNMP Threshold Interface Parameters

Use the following guidelines to configure SNMP threshold interface parameters in the Thresholds Interface Lists window.

Parameter: Threshold Enable

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: Enable

Options: Enable | Disable

Function: Turns the threshold for this variable on and off.

Instructions: Select Enable if you want the agent to apply the threshold to this variable.

Select Disable if you want the agent to ignore the threshold for this variable.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.2

Parameter: Threshold Low Value

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: 0

Options: Any integer value

Function: Sets the value of the low threshold for this variable.

Instructions: Specify the level at which you want the agent to generate a low-threshold exception event.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.5

Parameter: Threshold Low Event Level

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: Info

Options: Info | Warning | Debug

Function: Specifies the severity level of the event message the agent generates when a variable exceeds the low threshold.

Instructions: Select Info if you want low-threshold exceptions to generate routine events that require no action.

Select Warning if you want low-threshold exceptions to generate events that indicate an unexpected situation occurred.

Select Debug if you want low-threshold exceptions to generate events you use to solve network problems.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.6

Parameter: Threshold Medium Value

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: 0

Options: Any integer value

Function: Sets the value of the medium threshold for this variable.

Instructions: Specify the level at which you want the agent to generate a medium-threshold exception event.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.7

Parameter: Threshold Medium Event Level

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: Info

Options: Info | Warning | Debug

Function: Specifies the severity level of the event message the agent generates when a variable exceeds the medium threshold.

Instructions: Select Info if you want medium-threshold exceptions to generate routine events that require no action.

Select Warning if you want medium-threshold exceptions to generate events that indicate an unexpected situation occurred.

Select Debug if you want medium-threshold exceptions to generate events you use to solve network problems.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.8

Parameter: Threshold High Value

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: 0

Options: Any integer value

Function: Sets the value of the high threshold for this variable.

Instructions: Specify the level at which you want the agent to generate a high-threshold exception event.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.9

Parameter: Threshold High Event Level

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: Info

Options: Info | Warning | Debug

Function: Specifies the severity level of the event message the agent generates when a variable exceeds the high threshold.

Instructions: Select Info if you want high-threshold exceptions to generate routine events that require no action.

Select Warning if you want high-threshold exceptions to generate events that indicate an unexpected situation occurred.

Select Debug if you want high-threshold exceptions to generate events you use to solve network problems.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.10

Parameter: Threshold Units

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: Persecond

Options: Persecond | Absolute

Function: Specifies the units used to determine whether a variable has exceeded a threshold.

Instructions: Select Persecond if you want the agent to generate a threshold event when the variable's rate of change *per second* reaches one of the thresholds.

Select Absolute if you want the agent to generate a threshold event when the value of the variable reaches one of the thresholds.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.12

Parameter: Threshold Action

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: Greaterthan

Options: Greaterthan | Lessthan

Function: Specifies when the agent generates a threshold event.

Instructions: Select Greaterthan if you want to record threshold events when the value of the variable is *greater than* the threshold specified.

Select Lessthan if you want to record threshold events when the value of the variable is *less than* the threshold specified.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.13

Parameter: Threshold Max Successive Alarms

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: 5

Options: Any integer value

Function: Specifies the maximum number of successive alarms that the agent generates for this variable. A successive alarm represents two or more polling periods when the agent generates an alarm as a result of an exception at the same threshold level.

Instructions: Specify the maximum number of successive alarms. When the agent exceeds the maximum number of alarms, it marks the threshold as held. The agent generates no more alarms until the variable either crosses the threshold at a different level or crosses no threshold for the number of polling intervals equal to the value of the Threshold HoldDown Intervals parameter.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.14

Parameter: Threshold HoldDown Intervals

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: 1

Options: Any integer value

Function: Specifies the number of exception-free polling intervals through which a variable in a held state must pass before the variable is no longer considered held.

Instructions: Specify the number of exception-free polling intervals. The lower the number you select, the more likely the agent is to generate repetitive event messages for a variable that is intermittently exceeding thresholds.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.15

Parameter: Threshold Label

Path: Configuration Manager > Protocols > Global Protocols > Thresholds > Thresholds

Default: ASN.1 OID

Options: ASN.1 OID | String identifier

Function: Specifies a name for the MIB object in string format to replace the ASN.1 object identifier. The string you enter appears in the log file, making it easier to identify the object that is the subject of the trap.

Instructions: Type a name for the MIB object, or leave this field empty to use the ASN.1 object identifier.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.6.2.1.22

BootP and DHCP Parameters

Use the following guidelines to configure BootP and DHCP parameters in the BOOTP Relay Agent Interface Table window.

BootP Relay Agent Interface Parameters

Parameter: Enable/Disable

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table

Default: Enable

Options: Enable | Disable

Function: Specifies whether BootP is active on the network interface.

Instructions: Select Enable to enable BootP on the network interface. Select Disable to disable BootP on the network interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.1.1.2

Parameter: Hops

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table

Default: 4 (hops)

Options: 1 to 16 (hops)

Function: Specifies the maximum number of hops from the client to the server. A hop is the logical distance between two devices. If the value in the hops field of a BOOTREQUEST packet is greater than the number you specify for this parameter, the router drops the packet.

Instructions: Accept the default of 4 hops or specify a number from 1 to 16.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.1.1.5

Parameter: Timeout Secs.

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table

Default: 0 (seconds)

Options: 0 to 65535 (seconds)

Function: Specifies the minimum number of seconds that the router waits before forwarding a BOOTREQUEST packet. If the value in the seconds field of a BOOTREQUEST packet is less than the value you specify for this parameter, the router drops the packet.

Instructions: Accept the default, 0, or specify a number from 1 to 65535.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.1.1.6

Parameter: Pass Through Mode

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table

Default: BOOTP

Options: BOOTP | DHCP | BOOTP and DHCP

Function: Specifies whether the interface relays BootP, DHCP, or both BootP and DHCP requests.

Instructions: Select BOOTP to relay BootP requests. Select DHCP to relay DHCP requests. Select BOOTP and DHCP to relay both kinds of requests.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.1.1.16

Parameter: Interface Priority

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table

Default: 0

Options: 0 to 16

Function: Indicates priority of the interface on a multinetted interface.

Instructions: Enter a integer from 1 to 16 to indicate the priority of the interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.1.1.20

Parameter: DHCP Server Enable

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table

Default: Disable | Enable

Options: Disable

Function: Specifies whether the DHCP server is enabled or disabled on this network interface

Instructions: Select Enable to enable the DHCP server on the network interface. Select Disable to disable the DHCP server on the network interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.1.1.21

BootP Address Parameters

Use the following guidelines to configure BootP and DHCP parameters in the BOOTP Addresses window.

Parameter: Input IP Address

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Forward I/F > Add**

Default: None

Options: Any valid IP address

Function: Specifies the IP interface that receives BOOTREQUEST packets from clients.

Instructions: Enter the IP address of a numbered network interface that you want to receive BOOTREQUEST or DHCP packets from clients, then configure this IP address on the router, if you have not already done so.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.2.1.3

Parameter: Output IP Address

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Forward I/F > Add**

Default: None

Options: Any valid IP address

Function: Specifies the IP interface that forwards BOOTREQUEST packets to an external network.

Instructions: Enter the IP address of a numbered network interface that you want to send BOOTREQUEST or DHCP packets to servers, and then configure this IP address on the router, if you have not already done so.

Do not specify an unnumbered interface for this parameter. If you want to use an unnumbered interface to send BOOTREQUEST or DHCP packets to servers, you must set up a preferred server from the BOOTP Relay Agent Interface Table window.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.2.1.4

Parameter: Enable/Disable

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Forward I/F > Add**

Default: Enable

Options: Enable | Disable

Function: Specifies whether this forwarding route is active.

Instructions: Select Enable to allow BootP or DHCP forwarding through this route. Select Disable to prevent BootP or DHCP forwarding through this route.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.2.1.2

Parameter: Pass Through Mode

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Forward I/F** > **Add**

Default: BOOTP

Options: BOOTP | DHCP | BOOTP and DHCP

Function: Specifies whether the interface relays BootP, DHCP, or both BootP and DHCP requests.

Instructions: Select BOOTP to relay BootP requests. Select DHCP to relay DHCP requests. Select BOOTP and DHCP to relay both kinds of requests.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.2.1.5

BootP Client Interface Address Parameters

Use the following guidelines to configure BootP and DHCP parameters in the BOOTP Client Interface window.

Parameter: IP Address

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Client I/F > Add**

Default: None

Options: Any valid IP address

Function: Specifies the IP address of the remote AN that will boot using EZ-Install over a frame relay group access PVC connection to the router.

Instructions: Enter the IP address of the remote AN.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.1.1.1.3

Parameter: DLCI Number

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Client I/F > Add**

Default: None

Options: 16 to 1007

Function: Specifies the frame relay PVC identification number whose destination is the remote AN that will boot using EZ-Install. The frame relay network uses the DLCI number to direct data flow.

Instructions: Enter the DLCI number, in decimal format, for the group access PVC to the remote AN. Use the DLCI number assigned by your frame relay service provider.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.1.1.1.2

BootP Preferred Server Configuration Parameters

Use the following guidelines to configure BootP and DHCP preferred server configuration parameters.

Parameter: Relay Agent IP Address

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Pref Serv** > **Add**

Default: None

Options: Any valid IP address

Function: Specifies the IP interface that receives BOOTREQUEST packets from clients.

Instructions: Enter the IP address of a numbered network interface that you want to receive BOOTREQUEST or DHCP packets from clients, and then configure this IP address on the router, if you have not already done so.

Do not specify an unnumbered interface for this parameter.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.3.1.3

Parameter: Target Server IP Address

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Pref Serv** > **Add**

Default: None

Options: Any valid IP address

Function: Specifies the address of a server that should receive BOOTREQUEST or DHCP packets.

Instructions: Enter the IP address of the server that should receive the BOOTREQUEST or DHCP packets.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.3.1.4

Parameter: Enable/Disable

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Pref Serv > Add**

Default: Enable

Options: Enable | Disable

Function: Specifies whether the forwarding route is active.

Instructions: Select Enable to allow BootP or DHCP forwarding through this route. Select Disable to prevent BootP or DHCP forwarding through this route.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.3.1.2

Parameter: Target Name

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Pref Serv > Add**

Default: None

Options: Any string of printable ASCII characters, up to 63 characters in length, including embedded spaces

Function: Specifies the target server's host name.

Instructions: If you want to keep track of the names of BootP or DHCP servers, enter the target server's host name.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.3.1.5

Parameter: Pass Through Mode

Path: Configuration Manager > Protocols > IP > BOOTP > Relay Agent Interface Table > **Pref Serv > Add**

Default: BOOTP

Options: BOOTP | DHCP | BOOTP and DHCP

Function: Specifies whether the interface relays BootP, DHCP, or both BootP and DHCP requests.

Instructions: Select BOOTP to relay BootP requests. Select DHCP to relay DHCP requests. Select BOOTP and DHCP to relay both kinds of requests.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.3.1.6

DHCP Global Parameters

Use the following guidelines to configure DHCP server global interface parameters in the DHCP Global Parameters window.

Parameter: Enable

Path: Configuration Manager > Protocols > Global Protocols> DHCP Global

Default: Disable

Options: Disable | Enable

Function: Specifies whether the DHCP server is enabled or disabled on the router.

Instructions: Select Enable to enable the DHCP server on the router. Select Disable to disable the DHCP server on the router.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.24.1.1.2

Parameter: Server Manager IP Address

Path: Configuration Manager > Protocols > Global Protocols> DHCP Global

Default: None

Options: Any valid IP address

Function: Specifies the IP address of the NetID Server Manager that provides and manages DHCP lease information for this DHCP server.

Instructions: Enter the IP address of the NetID DCHP Server Manager.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.24.1.1.3

Parameter: DHCP Server TCP Port Number

Path: Configuration Manager > Protocols > Global Protocols> DHCP Global

Default: None

Options: A valid port number

Function: Specifies the remote port number over which the DHCP server communicates with the NetID Server Manager.

Instructions: Enter a remote port number on the DHCP server that matches the port number for the NetID Server Manager. For information about specifying a remote port number for the NetID Server Manager, see the *NetID System Administrator's Guide*.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.24.1.1.4

Parameter: Number of Pings

Path: Configuration Manager > Protocols > Global Protocols> DHCP Global

Default: 1

Options: 1 to 9999

Function: The number of ping attempts that the DHCP server makes to the IP address of the prospective DHCP client to detect possible conflicts before declaring the client address unavailable.

Instructions: Accept the default, 1, or specify a number from 1 to 9999 to determine the number of ping attempts that the DHCP server makes to the prospective DHCP client. Normally, a DHCP server makes only one ping attempt.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.24.1.1.5

Parameter: Ping Timeout

Path: Configuration Manager > Protocols > Global Protocols> DHCP Global

Default: 750

Options: 1 to 5000

Function: Specifies the amount of time (in milliseconds) that the DHCP server waits for a conflict detection ping to time out.

Instructions: Accept the default, 750 milliseconds, or specify a value from 1 to 5000. Typical DHCP clients retransmit a DHCPDISCOVER message after two seconds. Thus, if you specify a value greater than 2000 (that is, 2 seconds), the router may transmit spurious messages. The same condition applies if you set the value of the ping timeout and the number of pings so that their product (timeout value times the number of pings) is greater than 2000.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.24.1.1.6

Parameter: Safe Mode

Path: Configuration Manager > Protocols > Global Protocols> DHCP Global

Default: Enable

Options: Enable | Disable

Function: Specifies whether the DHCP server must wait until the NetID Server Manager acknowledges receipt of a successful lease commitment before sending a lease-granted acknowledgment to the DHCP client.

Instructions: Select Enable if you want the DHCP server to wait for the NetID Server Manager to confirm receipt of the successful lease commitment. Select Disable if you want the DHCP server to immediately send back a lease-granted acknowledgment to the DHCP client without waiting for a commit-succeeded acknowledgment from the NetID Server Manager.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.24.1.1.7

Parameter: Max. No. Pending Leases

Path: Configuration Manager > Protocols > Global Protocols> DHCP Global

Default: 2

Options: 1 to 255

Function: Specifies the maximum number of lease requests sent to the DHCP server that are pending commitment by the NetID Server Manager. When the number of lease requests sent to the NetID Server Manager and pending commitment by the NetID Server Manager reaches this value, the DHCP server holds all subsequent lease requests until the number of requests pending decreases to half this value. Then the DHCP server begins transmitting requests to the NetID Server Manager again.

Instructions: Accept the default, 2, or specify a number from 1 to 255.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.24.1.1.8

Parameter: Debug Level

Path: Configuration Manager > Protocols > Global Protocols> DHCP Global

Default: 0

Options: 1 to 10

Function: Specifies the debug level messaging you want to display in the log file for the DHCP server. Normally, only debug messages with a debug level of 0 are written to the log file.

Instructions: Enter the debug messaging level you want. Specifying a higher debug level causes additional messages to appear in the log file. Because additional information can rapidly fill the log file and cause loss of other information, change the debug level only to resolve critical problems.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.24.1.1.9

Parameter: Local IP Address

Path: Configuration Manager > Protocols > Global Protocols> DHCP Global

Default: 0.0.0.0

Options: Valid IP address

Function: Specifies the IP address that the DHCP server uses to identify itself to the NetID Server Manager serving this DHCP server.

Instructions: Enter the IP address of the DHCP server. This address must correspond to the address of an actual local interface configured on the router.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.24.1.1.10

RARP Interface Parameters

Use the following guidelines to configure RARP interface parameters in the RARP Interface Table window.

Parameter: Enable/Disable

Path: Configuration Manager > Protocols > IP > Reverse ARP > Interface Table

Default: Enable

Options: Enable | Disable

Function: Reenable or disable the RARP interface you selected from the list of interfaces.

Instructions: Select Enable to reenable a disabled interface. Select Disable to disable an interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.9.3.1.2

RARP Address Parameters

Use the following guidelines to configure RARP address parameters in the RARP Addresses window.

Parameter: MAC Address

Path: Configuration Manager > Protocols > IP > Reverse ARP > Map Table > **Add**

Default: None

Options: Any valid MAC address

Function: Specifies the MAC address of a client that will use the RARP services of this router.

Instructions: Enter the MAC address of a client.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.9.2.1.2

Parameter: IP Address

Path: Configuration Manager > Protocols > IP > Reverse ARP > Map Table > **Add**

Default: 0.0.0.0

Options: Any valid IP address

Function: Specifies the corresponding IP address for the client with the MAC address you specified using the MAC Address parameter.

When the router receives a RARP request from the client, the router assigns this IP address to the client and includes it in a response packet.

Instructions: Enter the IP address corresponding to the value of the MAC Address parameter. Do not accept the default value.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.9.2.1.3

Appendix B

Default Parameter Settings

SNMP Parameters

[Table B-1](#) to [Table B-6](#) list the Site Manager default parameter settings for SNMP.

Table B-1. SNMP Global Parameters

Parameter	Default
Enable	Enable
Use Lock	Enable
Lock Time Out	2 minutes
Authentication Failure Traps	Enable

Table B-2. SNMP Community Parameters

Parameter	Default
Community Name	None
Access	Read Only

Table B-3. SNMP Manager Parameters

Parameter	Default
Trap Port	162
Trap Types	Generic

Table B-4. SNMP Trap Interface Parameters

Parameter	Default
Entity Code	None
Event Code	None
Always/Never Trap	None

Table B-5. SNMP Threshold Global Parameters

Parameter	Default
Enable/Disable	Enable
Polling Interval	60 seconds

Table B-6. SNMP Threshold Interface Parameters

Parameter	Default
Threshold Enable	Enable
Threshold Low Value	0
Threshold Low Event Level	Info
Threshold Medium Value	0
Threshold Medium Event Level	Info

(continued)

Table B-6. SNMP Threshold Interface Parameters *(continued)*

Parameter	Default
Threshold High Value	0
Threshold High Event Level	Info
Threshold Units	Persecond
Threshold Action	Greaterthan
Threshold Max Successive Alarms	5
Threshold HoldDown Intervals	1
Threshold Label	ASN.1 OID

BootP and DHCP Parameters

Tables [B-7](#) to [B-10](#) list the Site Manager default parameter settings for BootP and DHCP.

Table B-7. BootP Relay Agent Interface Parameters

Parameter	Default
Enable/Disable	Enable
Hops	4
Timeout Secs.	0 seconds
Pass Through Mode	BOOTP
Interface Priority	0
DHCP Server Enable	Disable

Table B-8. BootP Address Parameters

Parameter	Default
Input IP Address	None
Output IP Address	None

(continued)

Table B-8. BootP Address Parameters

Parameter	Default
Enable/Disable	Enable
Pass Through Mode	BOOTP

Table B-9. BootP Client Interface Address Parameters

Parameter	Default
IP Address	None
DLCI Number	None

Table B-10. BootP Preferred Server Configuration Parameters

Parameter	Default
Relay Agent IP Address	None
Target Server IP Address	None
Enable/Disable	Enable
Target Name	None
Pass Through Mode	BOOTP

Table B-11. DHCP Global Parameters

Parameter	Default
Enable	Disable
Server Manager IP Address	0.0.0.0
DHCP Server TCP Port Number	0
Number of Pings	1
Ping Timeout	750
Safe Mode	Enable

Table B-11. DHCP Global Parameters

Parameter	Default
Max. No. Pending Leases	2
Debug Level	0
Local IP Address	0.0.0.0

RARP Parameters

Tables [B-12](#) and [B-13](#) list the Site Manager default parameter settings for RARP.

Table B-12. RARP Interface Parameters

Parameter	Default
Enable/Disable	Enable

Table B-13. RARP Address Parameters

Parameter	Default
MAC Address	None
IP Address	0.0.0.0

A

- acronyms, iii
- adding a manager, 3-13

B

BootP

- client interfaces table, creating, 4-11
- configuring preferred servers, 4-13
- customizing, 1-7
- customizing relay agent parameters, 4-2 to 4-5
- deleting IP interface input and output address pair, 4-9
- disabling, 4-2
- enabling, 4-2
- enabling on router interfaces, 4-5
- filtering packets, 4-17
- overview, 2-10
- packet, 2-10 to 2-13
- relay agent, 2-10, 2-22, 4-7
- relay agent forwarding table, 4-7
- route forwarding, 4-10
- setting up routing paths between BootP server and router, 4-5
- specifying
 - IP interface input/output address pair, 4-8
 - maximum number of hops, 4-2
 - minimum seconds, 4-2
 - relay mode, 4-4

- BootP parameters
 - defaults, B-3 to B-4

C

- communities
 - access privileges, 2-4
 - names, 2-4

- configuring
 - SNMP thresholds, 3-26
 - threshold polling interval, 3-27
 - thresholds, A-8 to A-15
 - trap exceptions, 3-23
 - traps, 3-19 to 3-26
- conventions, text, ii
- customizing
 - BootP relay agent parameters, 4-2 to 4-5
 - DHCP parameters, 1-9, 1-10, 5-3
 - global SNMP parameters, 3-3
 - IP parameters, 1-6
 - RARP parameters, 1-12, 7-2 to 7-5

D

- defaults
 - for BootP and DHCP parameters, B-3 to B-4
 - for RARP parameters, B-5
 - for SNMP parameters, B-1
- deleting
 - DHCP globally, 5-5, 6-10
 - exceptions, 3-26
 - RARP services, 7-5
 - SNMP managers, 3-17
- DHCP
 - customizing, 1-9, 1-10
 - deleting from an IP interface, 5-4
 - deleting globally, 5-5, 6-10
 - enabling on an interface, 1-8
 - packet, 2-20, 2-25 to 2-27
 - specifying
 - maximum number of hops, 4-2
 - minimum seconds, 4-2
 - relay mode, 4-4
 - servers for, 5-3
 - starting, 1-8

- DHCP parameters
 - defaults, B-3 to B-4
- disabling globally
 - RARP, 7-5

E

- editing
 - RARP parameters, 7-2 to 7-5
- educational services, iv
- event messages, 2-4
 - format, 2-9
 - protocol entities, 2-5
 - severity levels, 2-5
- exceptions
 - deleting, 3-26

I

- implementation notes, for SNMP, 2-4 to 2-9
- IP
 - address
 - acquiring through DHCP services, 2-14 to 2-29
 - acquiring through RARP services, 2-29
 - customizing, 1-6
 - starting, 1-2
- IP Address parameter
 - IP configuration, 1-3

M

- managers, for SNMP
 - deleting, 3-17
- memory use
 - for configuring thresholds, 2-9

P

- packet
 - BootP, 2-10 to 2-13
 - DHCP, 2-20, 2-25 to 2-27
- parameters
 - See* BOOTP parameters
 - See* RARP parameters
 - See* SNMP parameters

- product support, iv
- publications, Bay Networks, iv

R

- RARP
 - customizing, 1-12
 - customizing parameters, 7-2 to 7-4
 - defining the mapping table for, 7-3
 - deleting globally, 7-5
 - disabling globally, 7-5
 - disabling interfaces, 7-2
 - enabling on an interface, 1-11
 - enabling on an IP interface, 1-11
 - overview, 2-29
 - reenabling interfaces, 7-2
- RARP parameters
 - defaults, B-5
- RARP services
 - starting, 1-11
- Reverse Address Resolution Protocol. *See* RARP

S

- Simple Network Management Protocol
 - See* SNMP
- SNMP
 - adding a community, 3-9
 - adding a manager
 - using Site Manager, 3-13
 - using the BCC, 3-13
 - adding a threshold, 3-28
 - agents, 2-1
 - applications, 2-1
 - community, 2-4
 - community managers, 3-12
 - configuring a manager to receive traps
 - using Site Manager, 3-15
 - using the BCC, 3-15
 - configuring trap exceptions, 3-23
 - deleting a community
 - using Site Manager, 3-12
 - using the BCC, 3-12
 - deleting a manager
 - using Site Manager, 3-18
 - deleting trap exceptions, 3-26

- determining when to record threshold events, 3-32
- disabling a trap entity, 3-22
- disabling and reenabling
 - using Site Manager, 3-3
 - using the BCC, 3-3
- disabling thresholds, 3-27
- enabling authentication failure traps
 - using Site Manager, 3-8
 - using the BCC, 3-7
- enabling SNMP lock mechanism
 - using Site Manager, 3-4
 - using the BCC, 3-4
- enabling thresholds for a variable, 3-29
- global parameters, customizing, 3-3
- implementation notes, 2-4 to 2-9
- messages
 - GetNextRequest, 2-2
 - GetRequest, 2-2
- network elements, 2-1
- network management station, 2-1
- overview, 2-1
- security, 2-3
- setting the threshold polling level, 3-27
- specifying a lock address, 3-6
- specifying a lock timeout value
 - using Site Manager, 3-7
 - using the BCC, 3-6
- specifying a threshold object name, 3-35
- specifying a trap entity
 - using the BCC, 3-19
- specifying a trap type
 - using Site Manager, 3-17
 - using the BCC, 3-16
- specifying a value for the threshold level, 3-30
- specifying an SNMP community name
 - using Site Manager, 3-9
 - using the BCC, 3-9
- specifying community access privileges
 - using Site Manager, 3-11
 - using the BCC, 3-11
- specifying polling intervals for help variables, 3-34
- specifying the severity level
 - using Site Manager, 3-21
 - using the BCC, 3-21
- specifying the severity level for event messages, 3-30
- specifying threshold units, 3-31
- traps, 2-2, 2-5

- SNMP messages
 - SetRequest, 2-2
- SNMP parameters
 - defaults, B-1
 - threshold interface
 - Threshold Action, A-13
 - Threshold High Event Level, A-12
 - Threshold High Value, A-12
 - Threshold Label, A-15
 - Threshold Low Event Level, A-10
 - Threshold Low Value, A-10
 - Threshold Max Successive Alarms, A-14
 - Threshold Medium Event Level, A-11
 - Threshold Medium Value, A-11
 - Threshold Units, A-13
- SNMP thresholds
 - configuring, 3-26
- starting
 - DHCP, 1-8
 - IP, 1-2
 - RARP services, 1-11
- Subnet Mask parameter
 - IP configuration, 1-3
- support, Bay Networks, iv

T

- technical publications, iv
- technical support, iv
- text conventions, ii
- Threshold Action parameter, A-13
- Threshold High Event Level parameter, A-12
- Threshold High Value parameter, A-12
- Threshold Label parameter, 2-9, A-15
- Threshold Low Event Level parameter, A-10
- Threshold Low Value parameter, A-10
- Threshold Max Successive Alarms parameter, A-14
- Threshold Medium Event Level parameter, A-11
- Threshold Medium Value parameter, A-11
- threshold polling interval, 3-27
- Threshold Units parameter, A-13
- thresholds
 - adding, 3-28

- configuring, A-8 to A-15
- defining state of, 2-9
- definition, 2-7
- disabling, 3-27
- enabling, 3-27
- memory considerations, 2-9
- severity levels, 2-8

- Transmit Bcast Addr parameter
 - IP configuration, 1-3

- trap messages, 2-5
 - format, 2-6
 - severity levels, 2-5

- traps, 2-2
 - configuring, 3-19 to 3-26
 - exceptions, 3-23

U

- UnNumbered Assoc Address parameter
 - IP configuration, 1-3

- unnumbered interfaces, using for BootP and DHCP services, 4-13