

Cisco NCS5500

IOS-XR Release 26.1.1

IOS-XR System Upgrade Procedure

Table of Contents

1 Introduction	3
1.1 Purpose, Scope and Audience.....	3
1.2 Upgrade/downgrade Matrix.....	3
1.3 NOTE	3
1.4 Summary of Upgrade Steps	4
1.5 Bridge SMUs	4
1.6 Packages for Upgrade	5
1.7 Required Package files	5
2 Pre-Upgrade Task	6
2.1 Configuration Backup	6
2.2 System Stability check.....	7
2.3 Cost out IGP:.....	8
2.4 Enable auto-fpd upgrade	8
2.5 Disk Cleanup.....	8
3 Software Upgrade	10
3.1 Single-Command Upgrade using install-source:.....	10
3.2 Classic Upgrade (install add & activate image/SMUs):.....	11
4 Post Upgrade Tasks	13
5 Other Boot Options (GISO/IPXE/USB)	14
6 FPD Upgrade	15
7 Downgrade from 26.1.1 IOS XR Release	16
7.1 Post Downgrade Tasks	16
8 Caveats.....	18

1 Introduction

1.1 Purpose, Scope and Audience

The purpose of this document is to describe the upgrade and downgrade procedure for the Cisco NCS 5500 Series Network Convergence System Router, Release IOS-XR 26.1.1

Audience: This guide is for Cisco Systems Field Engineers and Network Operators. It is split into four sections.

- Simple one command install upgrade process & detailed IOS XR install upgrade process.
- Other Boot Options
- FPD upgrade
- Caveats and CLI changes

1.2 Upgrade/downgrade Matrix

Single Step Upgrade/Downgrade is supported for following releases:

Platform	Supported From	To
NCS5500 Fixed + Modular Chassis	IOS-XR 7.11.2/7.11.21/24.1.2/24.2.2/24.2.20/24.2.21/24.2.201/24.2.202/24.2.203/24.2.204/24.3.1/24.3.2/24.3.20/24.3.30/24.4.2/24.4.30/25.1.x/25.2.x/25.3.1/25.4.x	IOS-XR 26.1.1

1.4 Summary of Upgrade Steps

1. Perform upgrade using “install source” cli mentioned in this document.
2. Release IOS-XR 26.1.1 introduces the below mentioned PIDs:
 - NA
3. Following cards will not be supported from release IOS-XR 26.1.1:
 - NA

1.5 Bridge SMUs

The following table outlines the SMUs that must be installed for upgrade and downgrade procedure.

Table 1: Needed Bridge SMUs

Device	From Release	To Release	Bridge SMUs	Caveat SMU	From Release	To Release	Bridge SMUs
NCS5500	25.4.2	26.1.1			26.1.1	25.4.2	
NCS5500	25.4.1	26.1.1			26.1.1	25.4.1	
NCS5500	25.3.1	26.1.1			26.1.1	25.3.1	
NCS5500	25.2.2	26.1.1			26.1.1	25.2.2	
NCS5500	25.2.1	26.1.1		CSCwn05862 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	25.2.1	
NCS5500	25.1.2	26.1.1			26.1.1	25.1.2	
NCS5500	25.1.1	26.1.1			26.1.1	25.1.1	
NCS5500	24.4.30	26.1.1			26.1.1	24.4.30	
NCS5500	24.4.2	26.1.1			26.1.1	24.4.2	
NCS5500	24.3.30	26.1.1			26.1.1	24.3.30	
NCS5500	24.3.20	26.1.1			26.1.1	24.3.20	
NCS5500	24.3.2	26.1.1			26.1.1	24.3.2	
NCS5500	24.3.1	26.1.1		CSCwn05862 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	24.3.1	
NCS5500	24.2.2	26.1.1		CSCwn05862 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	24.2.2	
NCS5500	24.2.21	26.1.1		CSCwn05862 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	24.2.21	
NCS5500	24.2.20	26.1.1		CSCwn05862 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	24.2.20	
NCS5500	24.2.201	26.1.1		CSCwn05862 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	24.2.201	
NCS5500	24.2.202	26.1.1		CSCwn05862 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	24.2.202	
NCS5500	24.2.203	26.1.1		CSCwn05862 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	24.2.203	
NCS5500	24.2.204	26.1.1		CSCwn05862 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	24.2.204	

NCS5500	24.1.2	26.1.1	CSCwj57418	CSCwn05862 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	24.1.2	
NCS5500	7.11.21	26.1.1		CSCwr10451 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	7.11.21	
NCS5500	7.11.2	26.1.1	CSCwj57418	CSCwr10451 (This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system)	26.1.1	7.11.2	

Note:

- A direct, single-step upgrade from any release prior to 7.11.2 to 26.1.1 is not supported. You must first upgrade to the intermediate release 7.11.2 before proceeding with the upgrade to 26.1.1
- USB/PXE boot is an option for single-step install directly to 26.1.1
- For downgrades, please check show install upgrade-matrix running for all supported downgrades from IOS-XR 26.1.1 release. To downgrade to an unsupported version Eg: 7.5.2, please do USB/PXE boot.

CSCwn05862/CSCwr10451 - This SMU is applicable only when ARM diskboot of NCS5508 variant card present in system

CSCwj57418 - SMU for XR releases to support new root-fs resize requirement. This is a superset SMU having fix of CSCwn05862/CSCwr10451 as well for the mentioned releases

1.6 Packages for Upgrade

Following files are available to download for various boot options:

Table 2: IOS-XR Software files available for download

#	File	Contents	Comment
1	NCS5500-iosxr-26.1.1.tar	NCS 5500 IOS XR Software	Contains all rpms except k9sec
2	NCS5500-iosxr-k9-26.1.1.tar	NCS 5500 IOS XR Software 3DES	Contains all rpms including k9sec
3	ncs5500-usb_boot-26.1.1.zip	NCS 5500 IOS XR Software	Contains USB Boot Package

1.7 Required Package files

Mini ISO Package is mandatory to perform the System Upgrade and upgrade needs to be done from XR VM. Additional XR packages listed below are needed depending on the router configuration and required features:

Description	Package Name
Boot Image	ncs5500-mini-x-26.1.1.iso
mpls	ncs5500-mpls-1.0.0.0-r2611.x86_64.rpm
mpls-rsvp-te	ncs5500-mpls-te-rsvp-1.0.0.0-r2611.x86_64.rpm
multicast	ncs5500-mcast-1.0.0.0-r2611.x86_64.rpm
ospf	ncs5500-ospf-1.0.0.0-r2611.x86_64.rpm
isis	ncs5500-isis-1.0.0.0-r2611.x86_64.rpm
li	ncs5500-li-1.0.0.0-r2611.x86_64.rpm
eigrp	ncs5500-eigrp-1.0.0.0-r2611.x86_64.rpm
k9sec	ncs5500-k9sec-1.0.0.0-r2611.x86_64.rpm
mgbl	ncs5500-mgbl-1.0.0.0-r2611.x86_64.rpm
lictrl	ncs5500-lictrl-1.0.0.0-r2611.x86_64.rpm
healthcheck	ncs5500-healthcheck-1.0.0.0-r2611.x86_64.rpm
ponctrl	ncs5500-pon-ctrl-1.0.0.0-r2611.x86_64.rpm

2 Pre-Upgrade Task

Note: Config backup, precheck, Image download, tar file copy to router and install add are hitless operation and can be done outside of MW.

2.1 Configuration Backup

- Copy the running-configuration to a harddisk: on the router.

```
RP/0/RP0/CPU0:55XX# copy running-config harddisk:/running_config
```

- Copy the running-configuration to a remote scp server

```
RP/0/RP0/CPU0:55XX#scp harddisk:/<file name> <user_name>@<server  
ip>:/<path>
```

2.2 System Stability check

- The following commands should be executed to verify basic system stability before the upgrade. At the XR prompt:

show platform	verify that all nodes are in "IOS XR RUN/OPERATIONAL" state
show platform vm	verify that all nodes are in "FINAL Band" state
show redundancy	verify that a Standby RP is available and the system is in "NSR-ready" state
show ipv4 interface brief <or> show ipv6 interface brief <or> show interface summary	verify that all necessary interfaces are "UP"
show install active	verify that the proper set of packages are active
admin show install active	verify on sysadmin plane
show install committed	verify that the proper set of committed packages are same as active. If not, execute 'install commit'
cfs check clear configuration inconsistency	verify configuration file system to fix configuration file system
show hw-module fpd	Ensure all the FPD versions status are CURRENT Please refer to "Field Programmable Versions Document" for FPD version information.
show alarms	Shows any outstanding alarms in system
admin show environment all	Shows temperature, Fan, Voltage, Power status
Admin show led	Shows LED status
show media (both XR and Admin mode)	Shows the disk usage in XR and admin state
show inventory	Shows chassis inventory information
show logging	Capture show logging to check for any errors

2.3 Cost out IGP:

Cost-out IGP: To minimize traffic loss during the upgrade please follow below steps:

For OSPF use “max-metric” command.

```
RP/0/RP0/CPU0:55XX(config-ospf)# max-metric router-lsa
```

For ISIS use “set-overload-bit” command.

```
RP/0/RP0/CPU0:55XX(config-isis)# set-overload-bit
```

2.4 Enable auto-fpd upgrade:

Enable auto FPD auto upgrade from XR and Sysadmin if it is not enabled already.

```
RP/0/RP0/CPU0:55XX(config)#fpd auto-upgrade enable
RP/0/RP0/CPU0:55XX(config)#commit
```

2.5 Disk Cleanup:

Check available space in install repository. At least 2G of free space is required to perform system upgrade. If user is going to copy the packages and SMU's to the harddisk, please ensure enough free space is available on the harddisk. Check in Both XR and admin plane

XR:

```
RP/0/RP0/CPU0:55XX# show media location 0/RP0/CPU0
RP/0/RP0/CPU0:55XX# show media location 0/RP1/CPU0
```

Admin:

```
sysadmin-vm:0_RP0# show media location 0/RP0
sysadmin-vm:0_RP0# show media location 0/RP1
```

Check inactive packages and remove them before upgrading in XR and Admin plane.

XR:

```
RP/0/RP0/CPU0:55XX#install remove inactive all
```

Admin:

```
sysadmin-vm:0_RP0# install remove inactive
```

Check and delete core files and any other files which are not required in harddisk in XR and admin plane

XR:

```
RP/0/RP0/CPU0:55XX#run
[xr-vm_node0_RP0_CPU0:~]$cd /misc/disk1
[xr-vm_node0_RP0_CPU0:/misc/disk1]$rm *core*
```

Admin:

```
RP/0/RP0/CPU0:55XX#admin
sysadmin-vm:0_RP0# run
[sysadmin-vm:0_RSP0:~]$ cd /misc/disk1
[sysadmin-vm:0_RSP0:~]$ rm *core*
```

3 Software Upgrade

All System Upgrade related install operations should be done in the XR VM plane. The optional packages (mpls, mcast, mgbl etc.) that are being installed/upgraded must match the active packages, else the install will fail.

3.1 Single-Command Upgrade using install-source:



Note

Cisco recommends using this single cli method to perform software upgrade.

- Download IOS-XR 26.1.1 image from CCO.
 - Copy the tar file to scp/sftp server. Verify that the md5 checksum of tar file matches with CCO server
 - Untar and verify the contents of the tar file.
- Execute the below mentioned CLI from XR to perform one step upgrade.
 - ‘install source’ will identify and install dependent rpm’s automatically even though when we enter mini.iso only as input in CLI. User should ensure mini.iso and rpm’s are placed in same folder while doing untar of the tar file.



Note

Please verify the reachability to scp/sftp server and access to image path/files before proceeding with install operation. Please ensure only mini.iso and required rpm packages for ncs5500 are available in this folder, no other files should be present in the same folder.

Example for scp:

```
RP/0/RP0/CPU0:55XX# install source scp://<user>@<server-ip>/<image-path>  
ncs5500-mini-x-26.1.1.iso noprompt
```

<OR>

If user wants to copy the tar file to router harddisk to perform install operation, please refer below steps

Copy the tar file to router harddisk:

```
RP/0/RP0/CPU0:55XX#scp <user_name>@<server ip>:/<path>/<image-tar-file>  
/misc/disk1/image/
```

Untar the file to same folder in harddisk:

```
[xr-vm_node0_RP0_CPU0:/misc/disk1/image]$ tar -xvf NCS5500-iosxr-k9-  
26.1.1.tar
```

Now perform the install operation using below cli:

```
RP/0/RP0/CPU0:55XX#install source harddisk:/image/ ncs5500-mini-x-  
26.1.1.iso noprompt
```

- Verify that all the packages are installed correctly in XR and SysAdmin

```
RP/0/RP0/CPU0:55XX#show install active
sysadmin-vm:0_RP0# show install active
```

- Verify system stability through commands described under Check System Stability section (2.2) after router comes up with new software.
- Verify show version to check router is upgraded.

```
RP/0/RP0/CPU0:Router#show version
RP/0/RP0/CPU0:PE11_5516#show version
Thu Feb 26 00:09:24.727 PST
Cisco IOS XR Software, Version 26.1.1
Copyright (c) 2013-2026 by Cisco Systems, Inc.
```

Build Information:

```
Built By   : swtools
Built On   : Wed Feb 25 10:18:37 PST 2026
Built Host : iox-lnx-117
Workspace  : /auto/srcarchive12/prod/26.1.1/ncs5500/ws
Version    : 26.1.1
Location   : /opt/cisco/XR/packages/
Label      : 26.1.1-iso
```

```
cisco NCS-5500 () processor
System uptime is 1 hour 45 minutes
RP/0/RP0/CPU0:Router#
```

- Check to see if there were any failed startup configurations.

```
RP/0/RP0/CPU0:55XX#show configuration failed startup
```

- Perform install commit after router reload

```
RP/0/RP0/CPU0:55XX#install commit
```

3.2 Classic Upgrade (install add & activate image/SMUs):

Classic upgrade method requires user to perform install add and install activate operation to complete the upgrade.

- Download IOS-XR 26.1.1 image from CCO.
Copy tar file to scp server. Verify that the md5 checksum of tar file matches with CCO
Untar and verify the contents of the tar file.
- Copy the IOS-XR 26.1.1 tar file to the router harddisk and verify that file is copied successfully
RP/0/RP0/CPU0:55XX#scp <user_name>@<server ip>:/<path>/<image> /misc/disk1/.
- Verify the md5 checksum of the tar file with the original MD5 values on CCO
[xr-vm_node0_RP0_CPU0:/misc/disk1]\$md5sum NCS5500-iosxr-k9-26.1.1.tar

- Perform 'install add' of NCS5500-iosxr-k9-26.1.1.tar file:

```
RP/0/RP0/CPU0:55XX#install add source harddisk:/ NCS5500-iosxr-k9-26.1.1.tar
```

- Take a note of the install operation id generated by the add operation in previous step.

```
Install operation #id finished successfully
```

- Activate all the packages from install add operation by using the same operation #id noted from above step.

```
RP/0/RP0/CPU0:55XX#install activate id <#id> noprompt
```

- Router will reload at the end of activation to start using the new packages.



Note

This operation may take up to 30 minutes to complete.

- Verify that all the packages are installed correctly in XR and SysAdmin

```
RP/0/RP0/CPU0:55XX#show install active
sysadmin-vm:0_RP0# show install active
```

- Verify system stability through commands described under Check System Stability section (2.2) after router comes up with new software.
- Verify show version to check router is upgraded.

```
RP/0/RP0/CPU0:Router#show version
RP/0/RP0/CPU0:PE11_5516#show version
Thu Feb 26 00:09:24.727 PST
Cisco IOS XR Software, Version 26.1.1
Copyright (c) 2013-2026 by Cisco Systems, Inc.
```

Build Information:

```
Built By   : swtools
Built On   : Wed Feb 25 10:18:37 PST 2026
Built Host : iox-lnx-117
Workspace  : /auto/srcarchive12/prod/26.1.1/ncs5500/ws
Version    : 26.1.1
Location   : /opt/cisco/XR/packages/
Label      : 26.1.1-iso
```

```
cisco NCS-5500 () processor
System uptime is 1 hour 45 minutes
```

- RP/0/RP0/CPU0:Router#Check to see if there were any failed startup configurations.

```
RP/0/RP0/CPU0:55XX#show configuration failed startup
```

- Execute 'install commit' to commit the newly active software (install commit is required after any install activate operation else after router reload, nodes will go back to previously committed software)

```
RP/0/RP0/CPU0:55XX#install commit
```

4 Post Upgrade Tasks

- Disk cleanup: Once software upgrade has been completed, disk space can be recovered by removing any inactive packages that are no longer needed (if the packages are required later, they can be re-added):

```
RP/0/RP0/CPU0:55XX#install remove inactive all
```

- Verify/fix configuration file system (mandatory):

```
RP/0/RP0/CPU0:55XX#cfs check
```

- Verify fpd versions running are current:

```
RP/0/RP0/CPU0:55XX#show hw-module fpd
```

- Restore IGP metric if changed before the upgrade (this is done from xr vm)

OSPF

```
RP/0/RP0/CPU0:55XX# (config-ospf)# no max-metric router-lsa
```

ISIS

```
RP/0/RP0/CPU0:55XX# (config-isis)# no set-overload-bit
```

5 Other Boot Options (GISO/IPXE/USB)

Please refer below for various boot options:

Router Bring up:

<https://www.cisco.com/c/en/us/td/docs/iosxr/ncs5500/system-setup/77x/b-system-setup-cg-ncs5500-77x/m-bring-up-the-router.html>

GISO:

<https://www.cisco.com/c/en/us/td/docs/iosxr/ncs5500/system-setup/77x/b-system-setup-cg-ncs5500-77x/m-golden-iso.html>

IPXE and USB Boot option:

<https://www.cisco.com/c/en/us/td/docs/iosxr/ncs5500/system-setup/77x/b-system-setup-cg-ncs5500-77x/m-perform-disaster-recovery.html>

Please find below the link for more information about installation of optional rpms.

<https://www.cisco.com/c/en/us/td/docs/iosxr/ncs5500/system-setup/77x/b-system-setup-cg-ncs5500-77x/m-performing-system-upgrade-and-installing-packages.html> _

6 FPD Upgrade

Fpd auto-upgrade feature if it is configured on router should take care of the fpd upgrade. Otherwise, manual fpd upgrade can be performed after IOS-XR 26.1.1 upgrade is install committed. Run the “show hw-module fpd” command to check which firmware files need to be upgraded, by inspecting the ‘Status’ column. If there is any ‘NEED UPGD’ marked, manual upgrade is required. After Manual upgrade, a reload is required for the fpd to take effect. Issue the following command to upgrade FPD:

RP/0/RP0/CPU0:router#upgrade hw-module location all fpd all

TimingIC-A, TimingIC-B-0, TimingIC-B-1 fpds will not be upgraded even with “fpd auto-upgrade enable” configured.

A manual fpd upgrade needs to be triggered for the TimingIC fpds.

RP/0/RP0/CPU0:router#upgrade hw-module location 0/RP0 fpd TimingIC-B-0

7 Downgrade from 26.1.1 IOS XR Release

Downgrade can be performed by following options.

Option 1: If install commit was not done post upgrade, router reload will bring it back to previous install committed image.

Option 2: If downgrade image is part of inactive packages (the mini ISO is broken down into individual ISOs (XR, sysadmin and host) ex – ncs5500-mini-x-7.6.2, ncs5500-xr-7.6.2

install remove ncs5500-mini-x-7.6.2.iso (This will remove the mini as well as individual ISOs)

Install add/activate the packages along with iso.

```
Example: install add source harddisk: <tar file>
```

```
install activate id <> noprompt
```

Option 3: Single-command install operation using downgrade version image files as described in section 3.1

```
Example: install source scp://<user>@<server-ip>/<image-  
path> <downgrade iso file> noprompt
```

Note: Please do refer the caveats for known anomalies.

If FPD upgrade was done as part of IOS-XR 24.3.2 installation, FPDs do not need to be updated again once the downgrade version is activated.

7.1 Post Downgrade Tasks

- Disk cleanup: Once software upgrade has been completed, disk space can be recovered by removing any inactive packages that are no longer needed (if the packages are required later, they can be re-added):

```
RP/0/RP0/CPU0:55XX#install remove inactive all
```

- Verify/fix configuration file system (mandatory):

```
RP/0/RP0/CPU0:55XX#cfs check
```

- Verify fpd versions running are current:

```
RP/0/RP0/CPU0:55XX#show hw-module fpd
```

- Restore IGP metric if changed before the upgrade (this is done from xr vm)

OSPF

```
RP/0/RP0/CPU0:55XX(config-ospf)# no max-metric router-lsa
```

ISIS

```
RP/0/RP0/CPU0:55XX(config-isis)# no set-overload-bit
```

8 Caveats

The caveats listed below may be summaries only. Please review release note enclosure (RNE) , R-comments for each DDTS for complete details (Including known workarounds and/or actions to take).

DDTS	Description
Cws23426	Exr auto-fpd upgrade is not working during SU from XR version lower than 25.2.1 to 25.2.1 or higher releases