



# Cisco TelePresence Video Communication Server (Cisco VCS) IP Port Usage for Firewall Traversal

---

Cisco VCS X8.2

D14606.06 DRAFT A

June 2014

Many of the new features described herein remain in varying stages of development and will be offered on a when-and-if-available basis. The features in the EFT and any future product release are subject to change at the sole discretion of Cisco. Accordingly, Cisco will have no liability for delay in the delivery or failure to deliver any future products or features described in this document and any such delay or failure would not in any way imply the right to return any previously purchased Cisco products.

# Contents: Cisco VCS IP port usage


---

Which IP ports are used with Cisco VCS?


Which IP ports need to be allowed through firewalls?

- Format of information
- Traversing firewalls
  - Administration
  - SIP calls
  - H.323 calls
- Internal
  - Administration
  - SIP calls
  - H.323 calls

# Guide to this document: format of information



# Administration: Cisco VCS Expressway




		Management system source port	VCS Expressway server (listening) port
Management control		Private to DMZ	
Open firewall		Private to DMZ	
IP address		IP address of management computer(s)	IP address of VCS Expressway
IP Ports	http	TCP <b>S</b> >= 1024	TCP <b>80</b> 80
	https	TCP <b>S</b> >= 1024	TCP <b>443</b> 443
	ssh	TCP <b>S</b> >= 1024	TCP <b>22</b> 22
	SNMP	UDP <b>S</b> >= 1024	UDP <b>161</b> 161

Management ports

... only open ports for the management methods to be used

**S** = Source port , typically >= 1024

# Administration: Cisco VCS Expressway



		PC listening port	VCS Expressway source port
Management control		DMZ to private	
Open firewall		DMZ to private	
IP address		IP address of management computer(s)	IP address of VCS Expressway
IP Ports	NTP	UDP <b>123</b> 123	UDP <b>123</b> 123
	LDAP (for login)	TCP <b>389 or 636</b> 389 or 636	TCP <b>Ue</b> 30000 to 35999 *
	Syslog	UDP <b>514</b> 514	UDP <b>Ve</b> 30000 to 35999 *

Management ports


... only open ports for the management methods to be used



**Ue** = VCS TCP ephemeral port range defaults to 30000 to 35999 \*

**Ve** = VCS UDP ephemeral port range defaults to 30000 to 35999 \*

\* The default ephemeral port range of 30000 – 35999 applies to new installations of X8.1 or later; the previous default range of 40000 - 49999 still applies to earlier releases that have upgraded to X8.1.

# Administration: Cisco VCS Expressway





		TMS source port	VCS Expressway (listening) port	TMS (listening) port	VCS Expressway source port
					
Call direction		TMS to VCS Expressway		VCS Expressway to TMS	
Open firewall		n/a		n/a	
IP address		External IP address of TMS	IP address of VCS Expressway	External IP address of TMS	IP address of VCS Expressway
IP Ports	https (TMS to VCS and secure feedback from VCS to TMS)	TCP <b>S</b> $\geq 1024$	TCP <b>443</b> 443	TCP <b>443</b> 443	TCP <b>S</b> $\geq 1024$
	http (feedback to TMS)	-	-	TCP <b>80</b> 80	TCP <b>S</b> $\geq 1024$
	SNMP (To TMS)	UDP <b>S</b> $\geq 1024$	UDP <b>161</b> 161		

**S** = Source port , typically  $\geq 1024$


# Administration: Cisco VCS Expressway



		VCS Expressway source port 	Server listening port 
Management control		DMZ to public	
Open firewall		DMZ to public	
IP address		IP address of VCS Expressway	IP address of DNS Server
IP Ports	DNS	UDP <b>S</b> >= 1024	UDP <b>53</b> 53

**S** = Source port , typically >= 1024

# SIP traversal call



		VCS Control source port	VCS Expressway server (listening) port
Call direction		Inbound and outbound calls	
Open firewall		Private to DMZ	
IP address		IP address of VCS Control	IP address of VCS Expressway
IP Ports	SIP signaling	TCP & TLS <b>A</b> 25000 to 29999	TCP and TLS <b>B</b> 7001
	Assent RTP (traversal media)	UDP <b>Y<sub>C</sub></b> 36002 to 59999 **	UDP <b>Y<sub>E</sub></b> 36000 to 36001 ***
	Assent RTCP (traversal media)	UDP <b>Y<sub>C</sub></b> 36002 to 59999 **	UDP <b>Y<sub>E</sub></b> 36000 to 36001 ***

**A** = Protocols > SIP > TCP Outbound port start to end: *default = 25000 to 29999*

**B** = Zones > Traversal Client > SIP port, typically 7001 for first traversal zone, 7002 for second etc.

**Y<sub>C</sub>** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Control): *default = 36000 to 59999 \*\**


**Y<sub>E</sub>** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway): *default = 36000 to 59999 \*\* / \*\*\**



\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

\*\*\* Systems prior to X8 that are upgraded to X8.2 or later will continue to use the previous media demultiplexing RTP /RTCP ports, typically 2776/2777.



# SIP call to endpoint with public IP address



		VCS Expressway source port	Internet endpoint server (listening) port	VCS Expressway server (listening) port	Internet endpoint source port
		 			
Call direction		Outbound to an endpoint in the Internet		Inbound from an endpoint in the Internet	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		IP address of VCS Expressway	Any IP address	IP address of VCS Expressway	Any IP address
IP Ports	SIP signaling	UDP <b>C</b> 5060 TCP & TLS <b>A</b> 25000 to 29999	UDP & TCP & TLS <b>F</b> 5060 or $\geq 1024$	UDP: <b>C</b> 5060 TCP: <b>K</b> 5060 TLS: <b>L</b> 5061	UDP <b>G</b> 5060 or $\geq 1024$ TCP & TLS <b>H</b> $\geq 1024$
	RTP	UDP <b>Y<sub>E</sub></b> 36002 to 59998 **	UDP <b>E</b> $\geq 1024$	UDP <b>Y<sub>E</sub></b> 36002 to 59998 **	UDP <b>E</b> $\geq 1024$
	RTCP	UDP <b>Y<sub>E</sub></b> 36003 to 59999 **	UDP <b>E</b> $\geq 1024$	UDP <b>Y<sub>E</sub></b> 36003 to 59999 **	UDP <b>E</b> $\geq 1024$

**C** = Protocols > SIP > UDP port: *default* = 5060

**A** = Protocols > SIP > TCP Outbound port start to end: *default* = 25000 to 29999

**F** = defined by endpoint's registration (or not registered, IP port is defined by DNS lookup) any port  $\geq 1024$ , often 5060 for UDP

**K** = Protocols > SIP > TCP port: *default* = 5060

**L** = Protocols > SIP > TLS port: *default* = 5061

**G** = any port  $\geq 1024$ , often 5060 for hard endpoints


**H** = any port  $\geq 1024$

**Y<sub>E</sub>** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway): *default* = 36000 to 59999 \*\*

**E** = Endpoint media port range; value used is specified in the SDP:  
 = any IP port above 1024  
 = 36000 to 59999 \*\* for another VCS  
 = 2326 to 2385 for MXP static setting  
 = 11000 to 65000 for MXP dynamic setting

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

# SIP call to endpoint behind non SIP-aware firewall



		VCS Expressway source port	Internet endpoint server (listening) port	VCS Expressway server (listening) port	Internet endpoint source port
Call direction		Outbound to an endpoint behind a firewall		Inbound from an endpoint behind a firewall	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		IP address of VCS Expressway	Any IP address	IP address of VCS Expressway	Any IP address
IP Ports	SIP signaling	UDP <b>C</b> 5060 TCP & TLS <b>A</b> 25000 to 29999	UDP & TCP & TLS <b>F</b> 5060 or $\geq 1024$	UDP: <b>C</b> 5060 TCP: <b>K</b> 5060 TLS: <b>L</b> 5061	UDP, TCP & TLS: <b>Q</b> $\geq 1024$
	RTP	UDP <b>Y<sub>E</sub></b> 36002 to 59998 **	UDP <b>N</b> $\geq 1024$	UDP <b>Y<sub>E</sub></b> 36002 to 59998 **	UDP <b>N</b> $\geq 1024$
	RTCP	UDP <b>Y<sub>E</sub></b> 36003 to 59999 **	UDP <b>N</b> $\geq 1024$	UDP <b>Y<sub>E</sub></b> 36003 to 59999 **	UDP <b>N</b> $\geq 1024$

**C** = Protocols > SIP > UDP port: *default* = 5060

**A** = Protocols > SIP > TCP Outbound port start to end: *default* = 25000 to 29999

**F** = defined by endpoint's registration (or if call is to a non registered endpoint, IP port is defined by DNS lookup) any port  $\geq 1024$ , often 5060 for UDP

**K** = Protocols > SIP > TCP port: *default* = 5060

**L** = Protocols > SIP > TLS port: *default* = 5061


**Q** = Egress IP port from far end non-NAT aware firewall: any port  $\geq 1024$

**Y<sub>E</sub>** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway): *default* = 36000 to 59999 \*\*

**N** = VCS waits until it receives media, then it sends its media to the IP port from which the media was received (egress port of the media from the far end non SIP-aware firewall): any port  $\geq 1024$

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

# SIP – additional ports for ICE



		VCS Expressway source port	Internet endpoint server (listening) port	VCS Expressway server (listening) port	Internet endpoint source port
message direction		Outbound from VCS to endpoint in internet		Inbound from an endpoint in internet to VCS	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		IP address of VCS Expressway	Any IP address	IP address of VCS Expressway	Any IP address
IP Ports	TURN server control	N/A	N/A	UDP <b>R</b> 3478 (to 3483)	UDP <b>M</b> ≥ 1024
	TURN server media	UDP 24000 to 29999 *	UDP <b>N</b> ≥ 1024	UDP 24000 to 29999 *	UDP <b>N</b> ≥ 1024


**M** = IP port of signalling from endpoint – may be ephemeral IP port of endpoint (if no firewall), or IP port of the outside firewall :  
= any IP port above 1024

**N** = IP port of relevant ICE candidate – host IP port, Server reflexive IP port (outside firewall port) or TURN server port:  
= any IP port above 1024

**R** = On Large VCS systems you can configure a range of TURN request listening ports

\* For new installations of X8.1 or later, the default range for TURN relay media ports is 24000 – 29999. The previous default range of 60000 – 61799 still applies to earlier releases that have upgraded to X8.1.

# H.323 traversal call using Assent



		VCS Control source port	VCS Expressway server (listening) port
Call direction		Inbound and outbound calls	
Open firewall		Private to DMZ	
IP address		IP address of VCS Control	IP address of VCS Expressway
IP Ports	Initial RAS connection	UDP $R_C$ 1719	UDP $D$ 6001
	Q 931 / H.225 signaling	TCP $P$ 15000 to 19999	TCP $T$ 2776
	H.245	TCP $P$ 15000 to 19999	TCP $T$ 2776
	Assent RTP (traversal media)	UDP $Y_C$ 36002 to 59998 **	UDP $Y_E$ 36000 ***
	Assent RTCP (traversal media)	UDP $Y_C$ 36003 to 59999 **	UDP $Y_E$ 36001 ***

$R_C$  = Protocols > H.323 > Gatekeeper > Registration UDP port: *default* = 1719

$P$  = Protocols > H.323 > Gatekeeper > Call signaling port range start to end: *default* = 15000 to 19999

$D$  = Zones > Traversal Zone > H.323 port, typically 6001 for first traversal zone, 6002 for second etc.

$T$  = Traversal > Ports > H.323 Assent call signaling port: *default* = 2776


$Y_C$  = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Control): *default* = 36000 to 59999 \*\*

$Y_E$  = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway): *default* = 36000 to 59999 \*\* / \*\*\*

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

\*\*\* Systems prior to X8 that are upgraded to X8.2 or later will continue to use the previous media demultiplexing RTP /RTCP ports, typically 2776/2777.

# H.323 traversal call using H.460.18 / 19 non-muxed media



		VCS Control source port	VCS Expressway server (listening) port
Call direction		Inbound and outbound calls	
Open firewall		Private to DMZ	
IP address		IP address of VCS Control	IP address of VCS Expressway
IP Ports	Initial RAS connection	UDP $R_C$ 1719	UDP $D$ 6001
	Q 931 / H.225 signaling	TCP $P$ 15000 to 19999	TCP $M$ 1720
	H.245	TCP $P$ 15000 to 19999	TCP $U$ 2777
	Assent RTP (traversal media)	UDP $Y_C$ 36002 to 59998 **	UDP $Y_E$ 36002 to 59998 **
	Assent RTCP (traversal media)	UDP $Y_C$ 36003 to 59999 **	UDP $Y_E$ 36003 to 59999 **

$R_C$  = Protocols > H.323 > Gatekeeper > Registration UDP port: *default* = 1719

$P$  = Protocols > H.323 > Gatekeeper > Call signaling port range start to end: *default* = 15000 to 19999

$D$  = Zones > Traversal Zone > H.323 port, typically 6001 for first traversal zone, 6002 for second etc.

$M$  = Protocols > H.323 Call signaling TCP port: *default* = 1720


$U$  = Traversal > Ports > H.323 H.460.18 call signaling port: *default* = 2777

$Y_C$  = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Control): *default* = 36000 to 59999 \*\*

$Y_E$  = Local Zone < Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway) : *default* = 36000 to 59999 \*\*

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

# H.323 traversal call using H.460.18 / 19 multiplexed media



		VCS Control source port	VCS Expressway server (listening) port
Call direction		Inbound and outbound calls	
Open firewall		Private to DMZ	
IP address		IP address of VCS Control	IP address of VCS Expressway
IP Ports	Initial RAS connection	UDP $R_C$ 1719	UDP $D$ 6001
	Q 931 / H.225 signaling	TCP $P$ 15000 to 19999	TCP $M$ 1720
	H.245	TCP $P$ 15000 to 19999	TCP $U$ 2777
	Assent RTP (traversal media)	UDP $Y_C$ 36002 to 59998 **	UDP $Y_E$ 36000 ***
	Assent RTCP (traversal media)	UDP $Y_C$ 36003 to 59999 **	UDP $Y_E$ 36001 ***

$R_C$  = Protocols > H.323 > Gatekeeper > Registration UDP port: *default* = 1719

$P$  = Protocols > H.323 > Gatekeeper > Call signaling port range start to end: *default* = 15000 to 19999

$D$  = Zones > Traversal Zone > H.323 port, typically 6001 for first traversal zone, 6002 for second etc.

$M$  = Protocols > H.323 Call signaling TCP port: *default* = 1720

$U$  = Traversal > Ports > H.323 H.460.18 call signaling port: *default* = 2777

$Y_C$  = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Control): *default* = 36000 to 59999 \*\*


$Y_E$  = Local Zone < Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway) : *default* = 36000 to 59999 \*\* / \*\*\*

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

\*\*\* Systems prior to X8 that are upgraded to X8.2 or later will continue to use the previous media demultiplexing RTP /RTCP ports, typically 2776/2777.



# H.323 call with registered endpoint with public IP address



		VCS Expressway source port	Internet endpoint server (listening) port	VCS Expressway server (listening) port	Internet endpoint source port
Call direction		Outbound to an endpoint in the Internet		Inbound from an endpoint in the Internet	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		IP address of VCS Expressway	Any IP address	IP address of VCS Expressway	Any IP address
IP Ports	Initial RAS connection	-	-	UDP $R_E$ 1719	UDP $J$ 1719
	Q 931 / H.225 signaling	TCP $P$ 15000 to 19999	TCP $G$ 1720	TCP $M$ 1720	TCP $K$ 1720
	H.245	TCP $P$ 15000 to 19999	TCP $H$ $\geq 1024$	TCP $P$ 15000 to 19999	TCP $H$ $\geq 1024$
	RTP	UDP $Y_E$ 36000 to 59998 **	UDP $E$ $\geq 1024$	UDP $Y_E$ 36000 to 59998 **	UDP $E$ $\geq 1024$
	RTCP	UDP $Y_E$ 36001 to 59999 **	UDP $E$ $\geq 1024$	UDP $Y_E$ 36001 to 59999 **	UDP $E$ $\geq 1024$

$R_E$  = Protocols > H.323 > Gatekeeper Registration > UDP port, *default* = 1719

$J$  = Endpoint RAS source port, typically 1719

$P$  = Protocols > H.323 > Gatekeeper > Call signaling port range start to end: *default* = 15000 to 19999

$G$  = Endpoint signaling port, specified in registration: any port  $\geq 1024$ , typically 1720

$M$  = Protocols > H.323 Call signaling TCP port: *default* = 1720

$K$  = Endpoint signaling port: any port  $\geq 1024$ , typically 1720

$H$  = Endpoint H.245 signaling port: = any IP port  $\geq 1024$

= 15000 to 19999 to another VCS  
= 5555 to 5574 for MXP static setting  
= 11000 to 65000 for MXP dynamic setting


$Y_E$  = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway): *default* = 36000 to 59999 \*\*

$E$  = Endpoint media port range; value used is specified in codec negotiations: = any IP port above 1024

= 36000 to 59999 \*\* for another VCS  
= 2326 to 2385 for MXP static setting  
= 11000 to 65000 for MXP dynamic setting

\*\* The default media port range of 36000 – 59999 applies to new installations of X8.1 or later; the previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1.

# H.323 call with a non-registered endpoint with public IP



		VCS Expressway source port	Internet endpoint server (listening) port	VCS Expressway server (listening) port	Internet endpoint source port
Call direction		Outbound to an endpoint in the Internet		Inbound from an endpoint in the Internet	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		IP address of VCS Expressway	Any IP address	IP address of VCS Expressway	Any IP address
IP Ports	Initial RAS connection	-	-	-	-
	Q 931 / H.225 signaling	TCP <b>P</b> 15000 to 19999	TCP <b>G</b> 1720	TCP <b>M</b> 1720	TCP <b>K</b> 1720
	H.245	TCP <b>P</b> 15000 to 19999	TCP <b>H</b> ≥ 1024	TCP <b>P</b> 15000 to 19999	TCP <b>H</b> ≥ 1024
	RTP	UDP <b>Y<sub>E</sub></b> 36000 to 59998 **	UDP <b>E</b> ≥ 1024	UDP <b>Y<sub>E</sub></b> 36000 to 59998 **	UDP <b>E</b> ≥ 1024
	RTCP	UDP <b>Y<sub>E</sub></b> 36001 to 59999 **	UDP <b>E</b> ≥ 1024	UDP <b>Y<sub>E</sub></b> 36001 to 59999 **	UDP <b>E</b> ≥ 1024

**P** = Protocols > H.323 > Gatekeeper > Call signaling  
port range start to end: *default* = 15000 to 19999

**G** = Endpoint signaling port, specified by  
a) IP Port in call request  
b) DNS lookup for URI to call  
c) 1720 if IP address but no port specified  
Can be: any port ≥ 1024, typically 1720

**M** = Protocols > H.323 Call signaling TCP port: *default*  
= 1720

**K** = Endpoint signaling port: any port ≥ 1024,  
typically 1720

**H** = Endpoint H.245 signaling port:  
= any IP port ≥ 1024  
= 15000 to 19999 to another VCS  
= 5555 to 5574 for MXP static setting  
= 11000 to 65000 for MXP dynamic setting


**Y<sub>E</sub>** = Local Zone > Traversal Subzone > Traversal  
Media port start to end (configured on VCS  
Expressway): *default* = 36000 to 59999 \*\*

**E** = Endpoint media port range; value used is specified  
in codec negotiations:  
= *any IP port above 1024*  
= 36000 to 59999 \*\* for another VCS  
= 2326 to 2385 for MXP static setting  
= 11000 to 65000 for MXP dynamic setting

\*\* The default media port range of 36000 – 59999 applies to  
new installations of X8.1 or later; the previous default range  
of 50000 - 54999 still applies to earlier releases that have  
upgraded to X8.1.



# H.323 call with endpoint supporting Assent behind firewall



		VCS Expressway server (listening) port	Firewall source port
Call direction		Inbound from or outbound to an endpoint in the Internet behind a firewall	
Open firewall		Internet to DMZ	
IP address		IP address of VCS Expressway	Any IP address
IP Ports	Initial RAS connection	UDP $R_E$ 1719	UDP $Q$ $\geq 1024$
	Q 931 / H.225 signaling	TCP $T$ 2776	TCP $Q$ $\geq 1024$
	H.245	TCP $T$ 2776	TCP $Q$ $\geq 1024$
	RTP	UDP $Y_E$ 36000 ** / ***	UDP $N$ $\geq 1024$
	RTCP	UDP $Y_E$ 36001 ** / ***	UDP $N$ $\geq 1024$

$R_E$  = Protocols > H.323 > Gatekeeper Registration > UDP port, *default* = 1719

$Q$  = Egress IP port from far end non-H.323 aware firewall: any port  $\geq 1024$

$T$  = Traversal > Ports > H.323 Assent call signaling port: *default* = 2776

$Y_E$  = Local Zone < Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway) : *default* = 36000 to 59999 \*\* / \*\*\*

$N$  = Egress IP port of media from far end non-H.323 aware firewall: any port  $\geq 1024$


For calls made from the VCS Expressway to the endpoint:

1. VCS Expressway sends a message to the endpoint using the return path of the established RAS (registration) connection
2. The endpoint then makes a TCP connection out through its firewall to the VCS Expressway (port  $T$  - 2776 must be open on the firewall local to the VCS Expressway)
3. Any further connections required (e.g. H.245) are requested by the VCS Expressway over the established TCP connection, and the endpoint initiates them (to port  $T$  - 2776)

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

\*\*\* Systems prior to X8 that are upgraded to X8.2 or later will continue to use the previous media demultiplexing RTP /RTCP ports, typically 2776/2777.

# H.323 call with endpoint supporting H.460.18 / 19 non-mux media



		VCS Expressway server (listening) port	Firewall source port
Call direction		Inbound from or outbound to an endpoint in the Internet behind a firewall	
Open firewall		Internet to DMZ	
IP address		IP address of VCS Expressway	Any IP address
IP Ports	Initial RAS connection	UDP $R_E$ 1719	UDP $Q$ $\geq 1024$
	Q 931 / H.225 signaling	TCP $M$ 1720	TCP $Q$ $\geq 1024$
	H.245	TCP $U$ 2777	TCP $Q$ $\geq 1024$
	RTP	UDP $Y_E$ 36002 to 59998 **	UDP $N$ $\geq 1024$
	RTCP	UDP $Y_E$ 36003 to 59999 **	UDP $N$ $\geq 1024$

$R_E$  = Protocols > H.323 > Gatekeeper Registration > UDP port, *default* = 1719

$Q$  = Egress IP port from far end non-H.323 aware firewall: any port  $\geq 1024$

$M$  = Protocols > H.323 Call signaling TCP port: *default* = 1720

$U$  = Traversal > Ports > H.323 H.460.18 call signaling port: *default* = 2777

$Y_E$  = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway): *default* = 36000 to 59999 \*\*


$N$  = Egress IP port of media from far end non-H.323 aware firewall: any port  $\geq 1024$

For calls made from the VCS Expressway to the endpoint:

1. VCS Expressway sends a message to the endpoint using the return path of the established RAS (registration) connection
2. The endpoint then makes a TCP connection out through its firewall to the VCS Expressway (port  $M$  - 1720 must be open on the firewall local to the VCS Expressway)
3. Any further connections required (e.g. H.245) are requested by the VCS Expressway over the established TCP connection, and the endpoint initiates them (to port  $U$  - 2777)

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

# H.323 call with endpoint supporting H460.18 / 19 multiplexed media



		VCS Expressway server (listening) port	Firewall source port
Call direction		Inbound from or outbound to an endpoint in the Internet behind a firewall	
Open firewall		Internet to DMZ	
IP address		IP address of VCS Expressway	Any IP address
IP Ports	Initial RAS connection	UDP $R_E$ 1719	UDP $Q$ $\geq 1024$
	Q 931 / H.225 signaling	TCP $M$ 1720	TCP $Q$ $\geq 1024$
	H.245	TCP $U$ 2777	TCP $Q$ $\geq 1024$
	RTP	UDP $Y_E$ 36000 ** / ***	UDP $N$ $\geq 1024$
	RTCP	UDP $Y_E$ 36001 ** / ***	UDP $N$ $\geq 1024$

$R_E$  = Protocols > H.323 > Gatekeeper Registration > UDP port, *default* = 1719

$Q$  = Egress IP port from far end non-H.323 aware firewall: any port  $\geq 1024$

$M$  = Protocols > H.323 Call signaling TCP port: *default* = 1720

$U$  = Traversal > Ports > H.323 H.460.18 call signaling port: *default* = 2777

$Y_E$  = Local Zone < Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway) : *default* = 36000 to 59999 \*\*

$N$  = Egress IP port of media from far end non-H.323 aware firewall: any port  $\geq 1024$


For calls made from the VCS Expressway to the endpoint:

1. VCS Expressway sends a message to the endpoint using the return path of the established RAS (registration) connection
2. The endpoint then makes a TCP connection out through its firewall to the VCS Expressway (port  $M$  - 1720 must be open on the firewall local to the VCS Expressway)
3. Any further connections required (e.g. H.245) are requested by the VCS Expressway over the established TCP connection, and the endpoint initiates them (to port  $U$  - 2777)

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

\*\*\* Systems prior to X8 that are upgraded to X8.2 or later will continue to use the previous media demultiplexing RTP /RTCP ports, typically 2776/2777.

# SIP/H.323 Authentication: Cisco VCS Expressway



		PC listening port	VCS Expressway source port
Management control		DMZ to private	
Open firewall		DMZ to private	
IP address		IP address of management computer(s)	IP address of VCS Expressway
IP Ports	H.350	TCP <b>389 or 636</b> 389 or 636	TCP <b>Ue</b> 30000 to 35999 *
	Active Directory direct	UDP <b>53</b> UDP <b>88</b> TCP <b>88</b> UDP <b>389</b> TCP <b>389 or 636</b> TCP <b>445 or 139</b> 53, 88, 389 or 636, 445 or 139	UDP <b>Ve</b> 30000 to 35999 * TCP <b>Ue</b> 30000 to 35999 *

Management ports


... only open ports for the management methods to be used

**Ue** = VCS TCP ephemeral port range defaults to 30000 to 35999 \*

**Ve** = VCS UDP ephemeral port range defaults to 30000 to 35999 \*

\* The default ephemeral port range of 30000 – 35999 applies to new installations of X8.1 or later; the previous default range of 40000 - 49999 still applies to earlier releases that have upgraded to X8.1.


# Administration: Cisco VCS Control



		Management system source port	VCS Control listening port
Management control		Private network	
Open firewall		n/a	
IP address		IP address of management computer(s)	IP address of VCS Control
IP Ports	http	TCP <b>S</b> >= 1024	TCP <b>80</b> 80
	https	TCP <b>S</b> >= 1024	TCP <b>443</b> 443
	ssh	TCP <b>S</b> >= 1024	TCP <b>22</b> 22
	SNMP	UDP <b>S</b> >= 1024	UDP <b>161</b> 161

**S** = Source port , typically >= 1024

# Administration: Cisco VCS Control




		Management system listening port	VCS Control source port
Management control		Private network	
Open firewall		n/a	
IP address		IP address of management computer(s)	IP address of VCS Control
IP Ports	NTP	UDP 123 123	UDP 123 123
	LDAP	TCP 389 389	TCP S >= 1024
	http (feedback to TMS)	TCP 80 80	TCP S >= 1024
	DNS	UDP 53 53	UDP S >= 1024

**S** = Source port , typically  $\geq 1024$

# Administration: local endpoint



		Management system source port	Endpoint listening port
			
Management control		Private network	
Open firewall		n/a	
IP address		IP address of management computer(s)	IP address of Endpoint
IP Ports	http	TCP <b>S</b> ≥ 1024	TCP <b>80</b> 80
	https	TCP <b>S</b> ≥ 1024	TCP <b>443</b> 443
	ssh	TCP <b>S</b> ≥ 1024	TCP <b>22</b> 22
	telnet	TCP <b>S</b> ≥ 1024	TCP <b>23</b> 23
	SNMP	UDP <b>S</b> ≥ 1024	UDP <b>161</b> 161

**S** = Source port , typically ≥ 1024

# Administration: local endpoint




		Management system source port	VCS Control source port
Management control		Private network	
Open firewall		n/a	
IP address		IP address of management computer(s)	IP address of VCS Control
IP Ports	NTP	UDP 123 123	UDP 123 123
	http (feedback to TMS)	TCP 80 80	TCP S ≥ 1024
	DNS	UDP 53 53	UDP S ≥ 1024

**S** = Source port , typically ≥ 1024



# SIP: internal



		VCS Control source port	Endpoint listening port	VCS Control listening port	Endpoint source port
Call direction		VCS Control to endpoint		Endpoint to VCS Control	
Open firewall		n/a		n/a	
IP address		IP address of VCS Control	IP address of endpoint	IP address of VCS Control	IP address of endpoint
IP Ports	SIP signaling	UDP <b>C</b> 5060 TCP & TLS <b>A</b> 25000 to 29999	UDP & TCP & TLS <b>F</b> 5060 or >= 1024	UDP: <b>C</b> 5060 TCP: <b>K</b> 5060 TLS: <b>L</b> 5061	UDP <b>G</b> 5060 or >= 1024 TCP & TLS <b>H</b> >= 1024
	RTP	UDP <b>Y<sub>C</sub></b> 36002 to 59998 **	UDP <b>E</b> >= 1024	UDP <b>Y<sub>C</sub></b> 36002 to 59998 **	UDP <b>E</b> >= 1024
	RTCP	UDP <b>Y<sub>C</sub></b> 36003 to 59999 **	UDP <b>E</b> >= 1024	UDP <b>Y<sub>C</sub></b> 36003 to 59999 **	UDP <b>E</b> >= 1024

**C** = Protocols > SIP > UDP port: *default* = 5060

**A** = Protocols > SIP > TCP Outbound port start to end: *default* = 25000 to 29999

**F** = defined by endpoint's registration (or if call is to a non-registered endpoint, IP port is defined by DNS lookup) any port >= 1024, often 5060 for UDP

**K** = Protocols > SIP > TCP port: *default* = 5060

**L** = Protocols > SIP > TLS port: *default* = 5061

**G** = any port >= 1024, often 5060 for hard endpoints

**H** = any port >= 1024

**Y<sub>C</sub>** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Control): *default* = 36000 to 59999 \*\*

**E** = Endpoint media port range; value used is specified in the SDP:

= any IP port above 1024


= 36000 to 59999 \*\* for another VCS

= 2326 to 2385 for MXP static setting

= 11000 to 65000 for MXP dynamic setting

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

# H.323: internal



		VCS Control source port	Endpoint listening port	VCS Control listening port	Endpoint source port
Call direction		VCS Control to endpoint		Endpoint to VCS Control	
Open firewall		n/a		n/a	
IP address		IP address of VCS Control	Any IP address	IP address of VCS Control	Any IP address
IP Ports	Initial RAS connection	-	-	UDP $R_C$ 1719	UDP $J$ 1719
	Q 931 / H.225 signaling	TCP $P$ 15000 to 19999	TCP $G$ 1720	TCP $M$ 1720	TCP $K$ 1720
	H.245	TCP $P$ 15000 to 19999	TCP $H$ $\geq 1024$	TCP $P$ 15000 to 19999	TCP $H$ $\geq 1024$
	RTP	UDP $Y_C$ 36002 to 59998 **	UDP $E$ $\geq 1024$	UDP $Y_C$ 36002 to 59998 **	UDP $E$ $\geq 1024$
	RTCP	UDP $Y_C$ 36003 to 59999 **	UDP $E$ $\geq 1024$	UDP $Y_C$ 36003 to 59999 **	UDP $E$ $\geq 1024$

$R_C$  = Protocols > H.323 > Gatekeeper Registration > UDP port, *default* = 1719

$J$  = Endpoint RAS source port, typically 1719

$P$  = Protocols > H.323 > Gatekeeper > Call signaling port range start to end: *default* = 15000 to 19999

$G$  = Endpoint signaling port, specified in registration: any port  $\geq 1024$ , typically 1720

$M$  = Protocols > H.323 Call signaling TCP port: *default* = 1720

$K$  = Endpoint signaling port: any port  $\geq 1024$ , typically 1720

$H$  = Endpoint H.245 signaling port:

= any IP port  $\geq 1024$

= 15000 to 19999 to another VCS

= 5555 to 5574 for MXP static setting

= 11000 to 65000 for MXP dynamic setting

$Y_C$  = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Control): *default* = 36000 to 59999 \*\*

$E$  = Endpoint media port range; value used is specified in codec negotiations:

= any IP port above 1024


= 36000 to 59999 \*\* for another VCS

= 2326 to 2385 for MXP static setting

= 11000 to 65000 for MXP dynamic setting

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

# Unified Communications : VCS Control to Unified CM, IM&P






		Management system listening port	VCS Control source port
Management control		Private network	
Open firewall		n/a	
IP address		IP address of Unified CM, IM and Presence servers and CUC	IP address of VCS Control
IP Ports	XMPP (IM and Presence)	TCP 7400 (IM&P server)	TCP <b>Ue</b> 30000 to 35999 *
	UDS (provisioning and phonebook)	TCP 8443 (Unified CM server)	TCP <b>Ue</b> 30000 to 35999 *
	HTTP (configuration file retrieval)	TCP 6970 (Unified CM server)	TCP <b>Ue</b> 30000 to 35999 *
	CUC (voicemail)	TCP 443 (CUC server)	TCP <b>Ue</b> 30000 to 35999 *

**Ue** = VCS TCP ephemeral port range defaults to 30000 – 35999 \*

\* The default range of 30000 – 35999 applies to new installations of X8.1 or later; the previous default range of 40000 - 49999 still applies to earlier releases that have upgraded to X8.1.

# Unified Communications : Control (private) to Expressway (DMZ)



		VCS Control source port 	VCS Expressway server (listening) port 
Message direction		Inbound and outbound calls	
Open firewall		Private to DMZ	
IP address		IP address of VCS Control	IP address of VCS Expressway
IP Ports	XMPP (IM and Presence)	TCP <b>U<sub>e</sub></b> 30000 to 35999 *	TCP 7400
	SSH (HTTP/S tunnels)	TCP <b>U<sub>e</sub></b> 30000 to 35999 *	TCP 2222
	SIP signaling	TCP & TLS <b>A</b> 25000 to 29999	TCP and TLS <b>B</b> 7001
	SIP media	UDP <b>Y<sub>C</sub></b> 36002 to 59999 **	UDP <b>Y<sub>E</sub></b> 36000 / 36001 ***
	TURN server control	UDP ≥ 1024	UDP 3478 (to 3483) <b>R</b>

**A** = Protocols > SIP > TCP Outbound port start to end: *default* = 25000 to 29999

**B** = Zones > Traversal Client > SIP port, typically 7001 for first traversal zone, 7002 for second etc.

**R** = On Large VCS systems you can configure a range of TURN request listening ports

**U<sub>e</sub>** = VCS TCP ephemeral port range defaults to 30000 to 35999 \*

**Y<sub>C</sub>** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Control): *default* = 36000 to 59999 \*\*


**Y<sub>E</sub>** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway): *default* = 36000 to 59999 \*\* / \*\*\*

\* The default ephemeral port range of 30000 – 35999 applies to new installations of X8.1 or later; the previous default range of 40000 - 49999 still applies to earlier releases that have upgraded to X8.1.

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

\*\*\* Systems prior to X8 that are upgraded to X8.2 or later will continue to use the previous media demultiplexing RTP /RTCP ports, typically 2776/2777.

# Unified Communications: Expressway (DMZ) to public internet



		VCS Expressway source port	Internet endpoint server (listening) port	VCS Expressway server (listening) port	Internet endpoint source port
Message direction		Outbound to an endpoint in the Internet		Inbound from an endpoint in the Internet	
Open firewall		DMZ to Internet		Internet to DMZ	
IP address		Address of VCS Expressway	Any IP address	Address of VCS Expressway	Any IP address
IP Ports	XMPP (IM and Presence)	n/a	n/a	TCP 5222	TCP <b>S</b> $\geq 1024$
	UDS (phonebook and provisioning)	n/a	n/a	TCP 8443	TCP <b>S</b> $\geq 1024$
	TURN server control / media	n/a	n/a	UDP 3478 (to 3483) <b>R</b> / 24000 to 29999 *	UDP <b>S</b> $\geq 1024$
	SIP signaling	TLS 25000 to 29999	TLS <b>S</b> $\geq 1024$	TLS 5061	TLS <b>S</b> $\geq 1024$
	SIP media	UDP <b>Y<sub>E</sub></b> 36002 to 59999 **	UDP <b>N</b> $\geq 1024$	UDP <b>Y<sub>E</sub></b> 36002 to 59999 **	UDP <b>N</b> $\geq 1024$

**N** = VCS waits until it receives media, then it sends its media to the IP port from which the media was received (egress port of the media from the far end non SIP-aware firewall): any port  $\geq 1024$

**R** = On Large VCS systems you can configure a range of TURN request listening ports


**S** = Source port, typically  $\geq 1024$

**Y<sub>E</sub>** = Local Zone > Traversal Subzone > Traversal Media port start to end (configured on VCS Expressway): default = 36000 to 59999 \*\*

\* For new installations of X8.1 or later, the default range for TURN relay media ports is 24000 – 29999. The previous default range of 60000 – 61799 still applies to earlier releases that have upgraded to X8.1.

\*\* The default media port range of 36000 to 59999 applies to new installations of X8.1 or later. In Large systems the first 12 ports in the range – 36000 to 36011 – are used for multiplexed traffic only. In Small/Medium systems you can either explicitly specify the 2 ports to use for multiplexed traffic or use the first 2 ports from the media port range. The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later.

# Unified Communications: Jabber Guest (internet to VCS Expressway)




S = Source port, typically  $\geq 1024$

		VCS Expressway Listening Port	Internet SIP UA Source Port
Management Control		Inbound from SIP UA in the Internet	
Open Firewall		Internet to DMZ	
IP Address		IP address of - VCS Expressway	IP address of - Any (or specific IP)
IP Ports	HTTPS traffic	TCP 9443	TCP S (to TCP 443)
	HTTP traffic	TCP 9980	TCP S (to TCP 80)
	TURN Server Control	UDP 3478 (to 3483)	UDP S $\geq 1024$

**Must translate the destination port of 443 to 9443 for all HTTPS (and 80 to 9980 for HTTP) traffic that targets the VCS Expressway address from Jabber Guest clients.**

# Unified Communications: Jabber Guest (VCS Control to VCS Expressway)



		VCS Control Source Port	VCS Expressway Listening Port
Management Control		Outbound from VCS Control to VCS Expressway	
Open Firewall		Private to Public NAT'd	
IP Address		IP address of - VCS Control	IP address of - VCS Expressway (public)
IP Ports	SSH (HTTP/S tunnels)	TCP <b>E</b> 30000 to 35999 *1	SSH 2222
	Traversal Zone SIP signal	TLS <b>T<sub>C</sub></b> 25000 to 29999 *2	TLS <b>T<sub>E</sub></b>
	Media	UDP <b>Y<sub>C</sub></b> 36002 to 59999 *3	UDP <b>Y<sub>E</sub></b> 24000 to 29999 *4

**E** = Configurable TCP ephemeral port range (on VCS Control)

**T<sub>C</sub>** = Configurable TCP outbound port range (on VCS Control)

**T<sub>E</sub>** = Configurable SIP port for Unified Communications traversal zone between VCS Control (on VCS Expressway)

**Y<sub>C</sub>** = Configurable traversal media ports range (on VCS Control)

**Y<sub>E</sub>** = Non-Configurable TURN relays media ports range (VCS Expressway)


\*1 The default ephemeral port range of 30000 - 35999 applies to new installations of X8.1 or later  
The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1

\*2 The default outbound port range of 25000 - 29999 applies to new installations of X8.1 or later and earlier releases that have upgraded to X8.1

\*3 The default media port range of 36000 - 59999 applies to new installations of X8.1 or later  
The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1 or later

\*4 The default TURN relay media port range of 24000 - 29999 applies to new installations of X8.1 or later  
The previous default range of 60000 - 61799 still applies to earlier releases that have upgraded to X8.1

# Unified Communications: Jabber Guest (VCS Expressway to VCS Control)



		VCS Control Listening Port	VCS Expressway Source Port
Management Control		Inbound from VCS Expressway (public) to VCS Control	
Open Firewall		Public NAT'd to Private	
IP Address		IP address of - VCS Control	IP address of - VCS Expressway (Public)
Ports	Media	UDP $Y_C$ 36000 to 59999 *1	UDP $Y_E$ 24000 to 29999 *2

$Y_C$  = Configurable traversal media ports range (on VCS Control)

$Y_E$  = Non-Configurable TURN relays media ports range (on VCS Expressway)


\*1 The default media port range of 36000 - 59999 applies to new installations of X8.1 or later

The previous default range of 50000 - 54999 still applies to earlier releases that have upgraded to X8.1

\*2 The default TURN relay media port range of 24000 - 29999 applies to new installations of X8.1 or later  
The previous default range of 60000 - 61799 still applies to earlier releases that have upgraded to X8.1



# Unified Communications: XMPP federation (VCS Control VCS Expressway / IM&P Server)




		VCS Control Source Port	VCS Expressway Listening Port
XMPP		Outbound from VCS Control to VCS Expressway (DMZ)	
Open Firewall		Private to DMZ	
IP Address		IP address of - VCS Control	IP address of - VCS Expressway
IP Ports	XMPP	TCP E (Ephemeral port)	TCP 7400
		IM&P Server Listening Port	VCS Control Source Port
XMPP		Outbound from VCS Control to IM&P Server	
Open Firewall		-	
IP Address		IP address of - IM&P Server	IP address of - VCS Control
IP Ports	XMPP	TCP 7400	TCP E (Ephemeral port)

**E**= VCS TCP ephemeral port range defaults to 30000 – 35999 \*

\* The default range of 30000 – 35999 applies to new installations of X8.1 or later; the previous default range of 40000 - 49999 still applies to earlier releases that have upgraded to X8.1.

# Unified Communications: XMPP federation (VCS Expressway and Internet)




		VCS Expressway Listening Port	Federated XMPP Server Source Port
XMPP		Inbound from public internet to VCS Expressway (DMZ)	
Open Firewall		Internet to DMZ	
IP Address		IP address of - VCS Expressway	IP address of - Federated XMPP Server
IP Ports	XMPP	TCP 5269	TCP Ephemeral port
		VCS Expressway Source Port	Federated XMPP Server Listening Port
XMPP		Outbound from VCS Expressway (DMZ) to public internet	
Open Firewall		DMZ to Internet	
IP Address		IP address of - VCS Expressway	IP address of - Federated XMPP Server
IP Ports	XMPP	TCP <b>E</b> (Ephemeral port)	TCP 5269

**E**= VCS TCP ephemeral port range defaults to 30000 – 35999 \*

\* The default range of 30000 – 35999 applies to new installations of X8.1 or later; the previous default range of 40000 - 49999 still applies to earlier releases that have upgraded to X8.1.

# SIP B2BUA and Microsoft Lync



\* On Large VCS systems you can configure a range of TURN request listening ports (3478 to 3483) . For new installations of X8.1 or later, the default range for TURN relay media ports is 24000 – 29999. The previous default range of 60000 – 61799 still applies to earlier releases that have upgraded to X8.1.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2014 Cisco Systems, Inc. All rights reserved.