



# **Intel® Dialogic® System Release 6.1 CompactPCI for Windows**

**Administration Guide**

---

*April 2006*



INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH INTEL® PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN INTEL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, INTEL ASSUMES NO LIABILITY WHATSOEVER, AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF INTEL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT. Intel products are not intended for use in medical, life saving, or life sustaining applications.

Intel may make changes to specifications and product descriptions at any time, without notice.

This document as well as the software described in it is furnished under license and may only be used or copied in accordance with the terms of the license. The information in this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by Intel Corporation. Intel Corporation assumes no responsibility or liability for any errors or inaccuracies that may appear in this document or any software that may be provided in association with this document.

Except as permitted by such license, no part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means without express written consent of Intel Corporation.

Copyright © 2004-2006 Intel Corporation.

Dialogic, DM3, Intel, Intel logo, and Intel NetStructure are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

\*Other names and brands may be claimed as the property of others.

Publication Date: April 2006

Intel Converged Communications  
1515 Route 10  
Parsippany, NJ 07054

For **Technical Support**, visit the Intel Telecom Support Resources website at:  
<http://developer.intel.com/design/telecom/support/>

For **Products and Services Information**, visit the Intel Communications Systems Products website at:  
<http://www.intel.com/design/network/products/telecom/index.htm>

For **Sales Offices** and other contact information, visit the Intel Telecom Building Blocks Sales Offices page at:  
<http://www.intel.com/buy/networking/telecom.htm>



# Contents

---

	<b>Revision History</b> .....	9
	<b>About This Publication</b> .....	11
	Purpose .....	11
	Intended Audience .....	11
	How to Use This Publication .....	11
	Related Information .....	12
<b>1</b>	<b>Administration Overview</b> .....	13
1.1	Stopping and Starting the System .....	13
1.2	High Availability Support .....	13
1.2.1	Redundant Host .....	13
1.2.2	Peripheral Hot Swap .....	14
1.3	Administrative Utilities .....	15
1.4	Troubleshooting .....	15
<b>2</b>	<b>Stopping and Starting the System</b> .....	17
2.1	Stopping the System .....	17
2.2	Starting the System .....	17
2.2.1	Starting the Devices After a Reboot .....	17
2.3	Applying Configuration Changes .....	19
2.3.1	System Level Changes .....	19
2.3.2	Board Level Changes .....	19
<b>3</b>	<b>Peripheral Hot Swap</b> .....	21
3.1	Adding a New CompactPCI Board to an Active System .....	21
3.2	Removing a CompactPCI Board From an Active System .....	23
3.3	Replacing a CompactPCI Board in an Active System .....	24
<b>4</b>	<b>Administrative Utilities</b> .....	27
4.1	QScript Utilities .....	27
4.1.1	QScript Utility Requirements .....	28
4.2	Alarms Utility .....	29
4.3	Event Viewer Utility .....	29
4.4	IPT Admin Utility .....	30
4.5	LineAdmin Utility .....	31
4.6	Listboards Utility .....	32
4.6.1	Options .....	33
4.6.2	Guidelines .....	33
4.7	STD Config Utility .....	34
4.8	TSP Config .....	36
4.9	TSP Monitor .....	37
4.10	TSP Tracer .....	38
<b>5</b>	<b>Troubleshooting</b> .....	41
5.1	General Troubleshooting Information .....	41

5.2	Checking Configuration .....	41
5.3	Event Viewer.....	41
5.4	Checking Which Packages Are Installed .....	42
5.5	Checking Hardware .....	42
<b>Index</b>	.....	<b>43</b>



## Figures

---

1	High Availability Capability . . . . .	14
2	DCM Main Window - System Menu . . . . .	18
3	DCM Main Window - Device Menu . . . . .	20
4	DCM Main Window - Settings Menu . . . . .	22
5	DCM Main Window - Device Menu . . . . .	23
6	Alarms Display . . . . .	29
7	DCM Main Window - View Menu . . . . .	30
8	Line Admin Display . . . . .	32
9	Listboards Display . . . . .	34
10	STD Config Display . . . . .	35
11	TSP Config Display . . . . .	37
12	TSP Monitor Display . . . . .	38
13	TSP Tracer Display . . . . .	39





## ***Tables***

---

1	Administrative Utilities .....	15
---	--------------------------------	----







## Revision History

---

This revision history summarizes the changes made in each published version of this document.

Document No.	Publication Date	Description of Revisions
05-1884-003	April 2006	Global: Branding, cross reference, and hypertext link updates. Changed “Redundant System Slot” to “Redundant Host.” <a href="#">Administrative Utilities</a> : In Table 1, changed description of stdconfig utility. <a href="#">QScript Utilities</a> : In <a href="#">File Directories</a> , revised location for tools. <a href="#">LineAdmin Utility</a> : Revised parameter description for -line <n>. <a href="#">Redundant Host</a> : Added a note about Redundant Host failover. Changed title of section from Redundant System Slot to Redundant Host.
05-1884-002	September 2004	section: Added that Redundant Host is supported by Windows 2000* only and when a failover occurs, the SBC that went from ACTIVE to STANDBY must be rebooted before becoming ACTIVE again. Added note about Redundant Host steps required after initial installation of the Intel® Dialogic® System Software.
05-1884-001	October 2002	Initial version of document.





# About This Publication

---

The following topics provide information about this publication:

- [Purpose](#) ..... 11
- [Intended Audience](#) ..... 11
- [How to Use This Publication](#) ..... 11
- [Related Information](#) ..... 12

## Purpose

This publication provides information about performing administrative tasks on an active Windows\*-based system that uses the Intel® Dialogic® System Release Software. The information applies to a system that has been successfully installed and configured, and has been in operation.

## Intended Audience

This publication is written for the following audience:

- System Integrators
- Independent Software Vendors (ISVs)
- Original Equipment Manufacturers (OEMs)
- Telephony Equipment Manufacturers (TEMs)
- Network Equipment Providers
- Distributors

## How to Use This Publication

Refer to this publication after you have installed and configured the Intel Dialogic System Software and associated hardware. This publication assumes that you are familiar with the Windows operating system.

The information in this guide is organized as follows:

- [Chapter 1, “Administration Overview”](#) provides an overview of the administrative tasks associated with a system using the Intel Dialogic System Software.
- [Chapter 2, “Stopping and Starting the System”](#) provides information about stopping and starting the Intel Dialogic system and applying configuration changes to supported boards.
- [Chapter 3, “Peripheral Hot Swap”](#) provides procedures for adding, removing, or replacing boards in an active system.

- [Chapter 4, “Administrative Utilities”](#) describes the administrative utilities, including a description of each parameter used with that utility. The utilities are listed in alphabetical order.
- [Chapter 5, “Troubleshooting”](#) provides general information about troubleshooting a system that uses the Intel Dialogic System Software.

## Related Information

Refer to the following documents for more information about the System Release Software:

- For timely information that may affect installation and configuration, refer to the *Release Guide* and *Release Update*.  
Be sure to check the *Release Update* for the system release you are using for any updates or corrections to this publication. The *Release Update* is available on the Telecom Support Resources Web site at <http://resource.intel.com/telecom/support/documentation/releases/index.htm>.
- For information about installing the system software, refer to the *Intel® Dialogic® System Release Software Installation Guide*.
- For information about configuring the Intel® boards, refer to the *Intel NetStructure® DM3 Architecture for CompactPCI on Windows Operating Systems Configuration Guide*.
- For diagnostics information, refer to the *Intel® Dialogic® System Software Diagnostics Guide*.
- For information about using the SNMP Agent Software, refer to the *SNMP Agent Software for Windows Operating Systems Administration Guide*.
- For development software documentation relating to administrative tasks see the *Standard Runtime Library (SRL) API for Windows Operating Systems Library Reference* and the *Event Service API for Windows Operating Systems Library Reference*.
- For hardware installation instructions, see the *Quick Install Card* that comes with each board. Quick Install Cards also can be accessed from the Intel® Networking and Communications Telecom Support Resources Web site at <http://developer.intel.com/design/telecom/support>.  
The Intel Networking and Communications Telecom Support Resources Web site provides technical support and wide-ranging information in the form of technical notes, problem tracking reports, application notes, and other helpful documentation.
- For product information, visit the Intel® Telecom Products Web site at <http://www.intel.com/design/network/products/telecom/index.htm>.

This chapter provides an overview of the administrative tasks that can be performed on a system that uses the Intel® Dialogic® System Software. These tasks include:

- Stopping and Starting the System ..... 13
- High Availability Support ..... 13
- Administrative Utilities ..... 15
- Troubleshooting ..... 15

## 1.1 Stopping and Starting the System

To reconfigure the Intel Dialogic System Software, the system must first be stopped and then restarted again, after the configuration has been completed, so that the new configuration will take effect. Selecting the Stop System option from the Intel® Dialogic® Configuration Manager (DCM) Service pulldown menu stops all Intel computer telephony system resources in the system. Selecting the Start System option from the DCM System pulldown menu starts all Intel computer telephony system resources in the system.

- Notes:**
1. Stopping and starting the Intel Dialogic System Software stops and starts all of the active boards installed in the system.
  2. When the system is rebooted, the Intel Dialogic System Software can be configured to start automatically.

## 1.2 High Availability Support

The Intel Dialogic System Release Software supports high availability by providing redundant Single Board Computers (SBCs) in the Intel NetStructure® High Availability Platform, as well as basic Hot Swap in out-of-box configurations. Figure 1 shows the high availability capability provided.

The following sections provide additional information about specific High Availability capability:

- Redundant Host
- Peripheral Hot Swap

### 1.2.1 Redundant Host

For additional information about Redundant Host operation, refer to the documentation included with the Intel NetStructure High Availability Platform and the *High Availability for Windows Operating Systems Demo Guide*.


**Note:** Redundant Host has also been known as Redundant System Slot.

The Intel NetStructure® High Availability Platform supports Redundant Host operation on Windows 2000\* only. When used in conjunction with a user application based on sample code provided by the High Availability Demo, one of the Single Board Computers (SBCs) operates in the active mode, while the second (redundant) SBC operates in the standby mode.

When Redundant Host is fully operational, the drivers of the active SBC are loaded during initialization and the application starts. If during operation, the system senses a problem with the active SBC, the system will automatically switch operation to the standby SBC. The drivers of the standby SBC are loaded, the Intel Dialogic System Service restarts (re initializes) all boards in the system, and the application can then be restarted, using the standby SBC. This is referred to as a failover. However, keep in mind that when a failover occurs, the SBC that went from Active to Standby must be rebooted before becoming Active again.

- Notes:**
1. After Redundant Host failover, the Standby SBC must be rebooted before failover can occur again.
  2. When the Intel Dialogic System Software is installed for the *first time* on both SBCs, only the Active SBC will have the drivers installed and the boards enumerated. The Standby SBC will not have the boards enumerated in the system. To address this, you must prep the boards on the Standby SBC by performing a cooperative switchover and enabling the boards. After this is done, the Standby SBC can download and activate the boards when a failover occurs.

**Figure 1. High Availability Capability**



## 1.2.2 Peripheral Hot Swap

A CompactPCI peripheral board can be replaced, without interrupting the system services, by stopping the individual board, removing the board, installing a replacement board, and then starting the new (replacement) board. This is referred to as Basic Hot Swap. Also, a new board may be added to an active system without interrupting the system service.

## 1.3 Administrative Utilities

A number of utilities allow you to perform administrative tasks on a system using Intel NetStructure boards. Table 1, “Administrative Utilities” lists these utilities.

**Table 1. Administrative Utilities**

Utility	Description
alarms	Monitors the alarms on a T-1 or E-1 line.
signaleditor	Allows you to dynamically view and modify CAS signal identification parameters (transitions, pulses, trains, or sequences) so you can test them before changing the <i>.config</i> file.
Event Viewer	Displays error and administrative messages using the Windows Event Viewer.
lineadmin	Puts lines into service so you can run a number of the other utilities. Also, monitors T-1 and E-1 alarms.
listboards	Displays information about the Intel NetStructure boards that are installed in the system.
pmacadmin	Allows you to reset an Intel NetStructure IPT Series board.
stdconfig	Configures component parameters.
tspconfig	Allows you to change T-1 CAS or ISDN protocol variant parameters.
tspmon	Allows you to monitor the Global Call Resource protocol.
tspttrace	Allows you to trace CAS protocol operations and includes timing information.

## 1.4 Troubleshooting

After a condition has been diagnosed, troubleshooting can be performed to correct the faulty condition. Troubleshooting tasks that apply to an initial startup include checking the configuration files, checking which packages have been installed, and checking that all boards have been securely installed in their slots.

Additional troubleshooting information is available at the following Web site:  
<http://developer.intel.com/design/telecom/support>





# Stopping and Starting the System 2

---

This chapter covers the following topics about starting and stopping the Intel® Dialogic® System Service:

- Stopping the System ..... 17
- Starting the System ..... 17
- Applying Configuration Changes ..... 19

## 2.1 Stopping the System

Before you stop the system, the application must be stopped and the application must ensure that all channels have been closed.

The system is stopped using the Intel® Dialogic® Configuration Manager (DCM). From the DCM main window, click the Stop System option from the System pulldown menu or click the Stop All Enabled Devices icon. See Figure 2 for a display of the DCM main window.

## 2.2 Starting the System

Startup should only be performed when the system is stopped.

You only have to reboot the system for the **initial** startup. To start the system at any time after the initial startup, from the DCM main window, click the Start System option from the System pulldown menu or click the Start All Enabled Devices icon. See Figure 2 for a display of the DCM main window.

For information about startup messages, see the *Intel® Dialogic® System Release Software Installation Guide*.

### 2.2.1 Starting the Devices After a Reboot

The Intel Dialogic devices may be configured to start automatically or manually after the system is rebooted. The default configuration is for the devices to be manually started. The DCM Settings pulldown menu option Device Autostart is set by default to Detect Only (Don't Start). If the system is rebooted with this configuration selected, you will then need to manually restart the devices by selecting the Start System option from the DCM System pulldown menu.


To change the system to automatically start the Intel Dialogic system devices after a reboot, perform the following:

1. Stop the application and ensure that all channels have been closed.

2. Click the Stop System option from the System pulldown menu on the DCM main window or click the Stop All Enabled Devices icon.
3. From the DCM main window, click Detect and Start Device from the Settings pulldown menu Device Autostart option.
4. Reboot the system.
5. Restart the application.

**Note:** Do not use the Windows Services menu to change the Intel Dialogic System Service startup mode from Automatic to Manual. Always use the DCM menu options to modify the behavior of the Intel Dialogic System Service.

**Figure 2. DCM Main Window - System Menu**



## 2.3 Applying Configuration Changes

Configuration changes can be made at both the system level and board level. The following topics are included in this section:

- System Level Changes
- Board Level Changes

### 2.3.1 System Level Changes

Whenever a system-level configuration change is made, the system must first be stopped before the change is made and then restarted after the change has been made, but you do not have to reboot the system.

1. Before you stop the system, the application must be stopped and the application must ensure that all channels have been closed.
2. Stop the system from the DCM main window by clicking the Stop System option from the System pulldown menu or by clicking the Stop All Enabled Devices icon. See Figure 2 for a display of the DCM main window.
3. Modify configuration parameters as necessary.
4. Start the system from the DCM main window by clicking the Start System option from the System pulldown menu or by clicking the Start All Enabled Devices icon. See Figure 2 for a display of the DCM main window.
5. Restart the application.


For information about startup messages, refer to the *Intel® Dialogic® System Release Software Installation Guide*.

### 2.3.2 Board Level Changes

To modify one or more parameters on a single board without stopping the system, perform the following:

1. Inform the application to stop all activity on the board and close all open device handles.  
  
The Standard Runtime Library (SRL) functions can be used to determine the devices on the board with the specified AUID, and the devices can be closed using `dx_close()`, `dt_close()`, etc. For information about these functions, see the *Standard Runtime Library (SRL) API for Windows Operating Systems Library Reference*.
2. When the application has stopped using devices associated with the board, use the Intel Dialogic Configuration Manager (DCM) to stop the board. From the DCM main window, highlight the board that you wish to stop and then click the Stop Device option from the Device pulldown menu to inform the driver to release the operating system resources assigned to the board. See Figure 3 for a display of the Device menu.

Figure 3. DCM Main Window - Device Menu



The board and all virtual devices associated with the board must not be used until the board is restarted.

3. Start the board using the DCM. From the DCM main window, with the board still highlighted, click the Start Device option from the Device pulldown menu to download the revised configuration and initialize the board.

The board and all virtual devices on the board can be used once the download and initialization have completed.

**Note:** When the board is started, the DLGC\_EVT\_BLADE\_STARTED event is generated by the event notification framework. For an application to receive this event, the application must be registered with the ADMIN\_CHANNEL. For additional information about events, refer to the *Event Service API for Windows Operating Systems Library Reference*.

4. Inform the application to start using the board.

The standard runtime library (SRL) functions can be used to determine the devices that are in service again on the board with the specified AUID, and the devices can be opened using `dx_open()`, `dt_open()`, etc. For information about these functions, see the *Standard Runtime Library (SRL) API for Windows Operating Systems Library Reference*.

This chapter provides information and procedures associated with the peripheral hot swap capability. The following topics are included:

- [Adding a New CompactPCI Board to an Active System . . . . . 21](#)
- [Removing a CompactPCI Board From an Active System. . . . . 23](#)
- [Replacing a CompactPCI Board in an Active System. . . . . 24](#)

**Note:** The procedures described in this section require that you have the Windows Hot Swap Kit (HSK) installed on your system.

## 3.1 Adding a New CompactPCI Board to an Active System

The following procedure describes how to add a new CompactPCI board to an active system.

1. If the new cPCI board includes a rear I/O module, install the rear I/O module following the instructions provided with the *Quick Install Card*.
2. Install the baseboard following the instructions provided with the *Quick Install Card*. Depending on the DCM System/Device Autostart option selected, the new board will be detected by the system and either be started using the default values, or remain in the stopped state, allowing you to manually configure and start the board.

**Note:** How the system reacts to adding a new board depends on how the system settings have been configured using DCM. If the DCM Settings>System/Device Autostart option has been set to Detect and Start, the new board will be detected by the system, displayed in the DCM main window, and automatically started, once the POST has successfully completed, using the system default configuration for that board type. See Figure 4 for a display of the DCM main window. If the Detect Only (Don't Start) option has been selected, then the new board will be detected by the system and displayed in the DCM main window, but will not be started.

3. Ensure that the new board's Power On Self Test (POST) has completed. This will be indicated by the LEDs on the board becoming extinguished. For detailed information about POST, refer to the *Intel® Dialogic® System Software Diagnostics Guide*.

**Note:** This does not apply to the Intel NetStructure IPT Series boards. In this case, you should wait about 80 seconds for the POST to complete.

4. If the System/Device Autostart option is set to Detect Only (Don't Start), start the new board using the DCM. From the DCM main window, highlight the new board and then click the Start Device option from the Device pulldown menu to download and initialize the board.


The board and all virtual devices that will use the board can be used once the download and initialization have completed.

**Note:** When the board is started, the DLGC\_EVT\_BLADE\_STARTED event is generated by the event notification framework. For an application to receive this event, the application must be registered with the ADMIN\_CHANNEL. For additional information about events, refer to the *Event Service API for Windows Operating Systems Library Reference*.

5. Inform the application to start using the board.

The standard runtime library (SRL) functions can be used to determine the devices that are in service on the board with the specified AUID, and the devices can be opened using **dx\_open()**, **dt\_open()**, etc. For information about these functions, see the *Standard Runtime Library (SRL) API for Windows Operating Systems Library Reference*.

**Figure 4. DCM Main Window - Settings Menu**



## 3.2 Removing a CompactPCI Board From an Active System


The following procedure describes the basic steps for removing a CompactPCI board from an active system.

1. Inform the application to stop all activity on the board and close all open device handles.

The Standard Runtime Library (SRL) functions can be used to determine the devices on the board with the specified AUID, and the devices can be closed using `dx_close()`, `dt_close()`, etc. For information about these functions, see the *Standard Runtime Library (SRL) API for Windows Operating Systems Library Reference*.

2. When the application has stopped using devices associated with the board, use the Intel Dialogic Configuration Manager (DCM) to stop the board. From the DCM main window, highlight the board that you wish to stop and then click the Remove/Uninstall Device option from the Device pulldown menu to inform the driver to release the operating system resources assigned to the board. See Figure 5 for a display of the Device menu.

Figure 5. DCM Main Window - Device Menu



**Note:** When the board has been stopped, the DLGC\_EVT\_BLADE\_REMOVED event is generated by the event notification framework. For an application to receive this event, the application must be registered with the ADMIN\_CHANNEL. For additional information about events, refer to the *Event Service API for Windows Operating Systems Library Reference*.

3. After the OUT OF SERVICE LED on the faceplate of the cPCI baseboard lights, physically remove the board according to the instructions in the *Quick Install Card* that came with the board. If the board uses a rear I/O Module, remove the baseboard first, and then remove the rear I/O Module.
4. If the board uses a rear I/O Module, remove the rear I/O Module following the instructions provided with the *Quick Install Card*.

### 3.3 Replacing a CompactPCI Board in an Active System

The following procedure describes the basic steps for removing and replacing a CompactPCI board in an active system.

1. Inform the application to stop all activity on the board and close all open device handles.

The Standard Runtime Library (SRL) functions can be used to determine the devices on the board with the specified AUID, and the devices can be closed using `dx_close()`, `dt_close()`, etc. For information about these functions, see the *Standard Runtime Library (SRL) API for Windows Operating Systems Library Reference*.

**Note:** If the board being replaced was previously functioning as the Primary Clock Master or Reference Master, and the system has now automatically switched to a backup Clock Master and/or Reference Master because this board failed, replacing this board will not cause the system to automatically revert back to using the replacement board as the Primary Clock Master and/or Reference Master.

2. When the application has stopped using devices associated with the board, use the Intel Dialogic Configuration Manager (DCM) to stop the board. From the DCM main window, highlight the board that you wish to stop and then click the Remove/Uninstall Device option from the Device pulldown menu to inform the driver to release the operating system resources assigned to the board. See Figure 5 for a display of the Device menu.

**Note:** When the board has been stopped, the DLGC\_EVT\_BLADE\_REMOVED event is generated by the event notification framework. For an application to receive this event, the application must be registered with the ADMIN\_CHANNEL. For additional information about events, refer to the *Event Service API for Windows Operating Systems Library Reference*.

The board and all virtual devices associated with the board must not be used until the replacement board is restarted.

3. After the OUT OF SERVICE LED on the faceplate of the CompactPCI baseboard lights, physically remove the board according to the instructions in the *Quick Install Card* that came with the board. If the board uses a rear I/O Module, remove the baseboard first, and then remove the rear I/O Module.



4. If the baseboard uses a rear I/O Module, remove and replace the rear I/O Module following the instructions provided with the *Quick Install Card*.
5. Insert the replacement baseboard in the vacated slot following the instructions provided with the *Quick Install Card*. Depending on the DCM System/Device Autostart option selected, the new board will be detected by the system and either be started using the default values, or remain in the stopped state, allowing you to manually configure and start the board.

**Note:** How the system reacts to replacing a board depends on how the system settings have been configured using DCM. If the DCM Settings>System/Device Autostart option has been set to Detect and Start, the new board will be detected by the system, displayed in the DCM main window, and automatically started, once the POST has successfully completed, using the system default configuration for that board type. See Figure 4 for a display of the DCM main window. If the Detect Only (Don't Start) option has been selected, then the new board will be detected by the system and displayed in the DCM main window, but will not be started.

6. Ensure that the new board's Power On Self Test (POST) has completed. This will be indicated by the LEDs on the board becoming extinguished. For detailed information about POST, refer to the *Intel® Dialogic® System Software Diagnostics Guide*.

**Note:** This does not apply to the Intel NetStructure IPT Series boards. In this case, you should wait about 80 seconds for the POST to complete.

7. If the System/Device Autostart option is set to Detect Only (Don't Start), start the new board using the DCM. From the DCM main window, highlight the new board and then click the Start Device option from the Device pulldown menu to download and initialize the board.

The board and all virtual devices on the board can be used once the download and initialization have completed.

**Note:** When the board is started, the DLGC\_EVT\_BLADE\_STARTED event is generated by the event notification framework. For an application to receive this event, the application must be registered with the ADMIN\_CHANNEL. For additional information about events, refer to the *Event Service API for Windows Operating Systems Library Reference*.

8. Inform the application to start using the board.

The standard runtime library (SRL) functions can be used to determine the devices that are in service again on the board with the specified AUID, and the devices can be opened using **dx\_open( )**, **dt\_open( )**, etc. For information about these functions, see the *Standard Runtime Library (SRL) API for Windows Operating Systems Library Reference*.



This section gives a description and parameters for each administrative utility. The utilities are listed alphabetically. A description of each utility is provided, including a description of each associated parameter. This section includes the following:

• Alarms Utility .....	29
• Event Viewer Utility .....	29
• IPT Admin Utility .....	30
• LineAdmin Utility .....	31
• Listboards Utility .....	32
• STD Config Utility .....	34
• TSP Config .....	36
• TSP Monitor .....	37
• TSP Tracer .....	38

**Note:** With the exception of the Event Viewer and IPT Admin utilities, the utilities documented in this section do not apply to Intel NetStructure IPT Series boards.

## 4.1 QScript Utilities

The QScript utilities are a subset of the administrative utilities. QScript is an object-oriented scripting tool developed for the Intel NetStructure on DM3 architecture products. QScript is intended for use while developing demonstration or test programs and is implemented using the Tcl/Tk generic scripting language. All Qscript utilities can be run from the Windows operating system.

QScript utilities use board and line numbers as follows: board numbers are 0-based and line numbers are 1-based. That is, the first board is typically board 0 and the first line is line 1.

The following administrative utilities use QScript:

- Alarms Utility
- LineAdmin Utility
- STD Config Utility
- TSP Config
- TSP Monitor
- TSP Tracer

## 4.1.1 QScript Utility Requirements

The following information gives details specific to QScript utilities:

- File Directories
- QScript Environment Variables

### 4.1.1.1 File Directories

The directory for the Windows batch file used to invoke the QScript tools is:

```
%systemroot%\program files\dialogic\bin
```

The QScript tools developed by Intel Dialogic are located in:

```
%systemroot%\program files\dialogic\qscript\tools
```

**Note:** Do not run a *<toolname>.qs* file directly. Batch files have been created which call the QScript interpreter to run the *<toolname>.qs* file. To use a QScript utility, specify the utility name and parameters on the command line.

### 4.1.1.2 QScript Environment Variables

#### ***QSCRIPT\_DIR Environment Variable:***

In a Windows environment, this variable is set during the Intel Dialogic System Release install.

#### ***Single Session Variable:***

Set the variable for a single session using the `set` command. To permanently set the environment variable for all login sessions, update the variable in the **System Properties Environment** tab.

#### ***Remote Systems:***

The remote system containing the board does not need to have QScript installed, but must be running the RemoteQHostServer application included with QScript and installed in the bin directory.

To run QScript tools against a board in a remote system, set the REMOTE\_QHOST environment variable to the name of the machine that contains the board you want to access. Set REMOTE\_QHOST to:

```
hostname:port
```

where hostname is the machine name or TCP/IP address, and port is optional and specified only if RemoteQHostServer was started on a special port.

## 4.2 Alarms Utility

The *Alarms* utility is used for sending and monitoring the alarm states on a T-1 or E-1 line. However, if you are already using the *LineAdmin* utility to put lines into service, you may not need to use *Alarms* because *LineAdmin* displays much of the same information. See [Section 4.5, “LineAdmin Utility”](#), on page 31 for information about the *LineAdmin* utility.

**Command Line:** `alarms [parameter_list]`

The *Alarms* utility uses the following command line parameters:


Parameter	Description
-board <n>	Board number (required). Use the <i>Listboards</i> utility to obtain the board number.
-line <n>	Line number (required)

**Example:** This example monitors the alarm states on line 1 of board 0:

```
alarms -board 0 -line 1
```

Figure 6 shows a typical *Alarms* display.


**Figure 6. Alarms Display**



## 4.3 Event Viewer Utility

The *Event Viewer* utility displays the Windows Event Viewer which allows you to view error and administrative messages generated by the system. The *Event Viewer* utility is accessed through the Intel Dialogic Configuration Manager (DCM). From the DCM main window, click the Log File option from the View pulldown menu to display the Windows Event Viewer. See [Figure 7](#) for a display of the DCM main window.

Figure 7. DCM Main Window - View Menu



## 4.4 IPT Admin Utility

The *IPT Admin* utility is used to reset an Intel NetStructure IPT Series board. The board may require resetting if an IPML-based application receives IPMEV\_ERROR events or if a Global Call-based application receives GCEV\_TASKFAIL events.

**Command Line:** pmacadmin [parameter\_list]

The *IPT Admin* utility uses the following command line parameters:

Parameter	Description
-e	Causes a hard reset of the Intel NetStructure IPT Series board.
-i	Initializes the Intel NetStructure IPT Series board.
-c	Sets the Intel NetStructure IPT Series board to the configured state.
-s	Starts the Intel NetStructure IPT Series board.

Parameter	Description
-B <pcibus> -S <pcislot>	Specifies the Intel NetStructure IPT Series board identified by this PCIBus and PCISlot number. Use the Intel Dialogic Configuration Manager (DCM) to obtain the board's PCIBus number and PCISlot number.
-P <slot>	Specifies the Intel NetStructure IPT Series board located in this physical slot. Physical slots are numbered from left to right on a chassis, starting with the number 1. Use the DCM to obtain the board's physical slot number.

### Examples:

This example, in sequence, resets, initializes, configures and then starts all Intel NetStructure IPT Series boards in the system:

```
pmacadmin -eics
```

This example, in sequence, resets, initializes, configures and then starts the Intel NetStructure IPT Series board in physical slot 8:

```
pmacadmin -eics -P 8
```

## 4.5 LineAdmin Utility

The *LineAdmin* utility puts lines into service so you can run many of the other diagnostic utilities. *LineAdmin*, like *Alarms*, is used for sending and monitoring the alarm states on a T-1 or E-1 line but *LineAdmin* is recommended as a more useful tool.

A flexible logging feature is available that includes the ability to log the status of the DM3 trunks and alarm conditions.

**Command Line:** lineadmin [parameter\_list]

The *LineAdmin* utility uses the following command line parameters:

Parameter	Description
-board <n>	Board number (required). Use the <i>Listboards</i> utility to obtain the board number.
-line <n>	Line number (optional, default is all lines). If no -line parameter is provided, the display will show all lines.
-lines {n n+ ...}	Line numbers. This parameter is used when more than 1 line is monitored (optional, default is {1 2 3 4})
-advanced <n>	The presence or absence of the following alarms on the line: AIS, CRC, and D-Channel


**Example:** This example runs the *LineAdmin* utility on board 1, lines 1, 2, 3, and 4:



```
lineadmin -board 1 -lines {1 2 3 4}
```

Figure 8 shows the *LineAdmin* display. This example shows four trunks (an Intel NetStructure<sup>®</sup> DMV product). The alarm setting is on the left and the alarm indicators are on the right.

Figure 8. Line Admin Display



## 4.6 Listboards Utility

*Listboards* displays information for DM3 board(s) present in the system and recognized by the device driver. *Listboards* displays complete information regarding the current status of the baseboard along with a list of attached digital network interface and processing daughter boards (if any).



## 4.6.1 Options

**Command Line:** `listboards [parameter_list]`

The *Listboards* utility uses the following command line parameters:

Parameters	Description
-b <n>	Board number (optional). If no board number is specified, the status of all boards in the system will be given.
-d <level>	Application debug level (optional)
-h	Help (optional)
-i <board number>	Retrieve hardware information (optional)
-v	Version (optional)

**Example:** This example lists all the board attributes for board 0. If any daughter boards are present, their attributes are also listed:

```
listboards -b0
```

## 4.6.2 Guidelines


*Listboards* only provides a logical board number. The *logical* board number should be used when running any of the administrative utilities that require a board number.

Board numbers are dynamically assigned. *Listboards* prints out the logical board number along with the board's serial number. Use the serial number to physically identify the board on the CompactPCI chassis.

**Note:** *Listboards* will fail if you specify a board number that does not exist on the system.

To use *Listboards*, you must start the boards using the Intel® Dialogic® Configuration Manager (DCM). Then invoke *listboards* from the Command Prompt window. Figure 9 shows the results of running *listboards*.

Figure 9. Listboards Display



```

C:\>listboards -b0
=====
Listboards - Version 2.00 Beta 4 Build: 07
=====

MNTI Library version: 1.16
DM3pp Library version: 1.20 Beta 1 Build: 1
Driver version       : v1.16

Logical Board Number is : 0
Physical Board Number is : 0

=====> Board: 0
=====
Generic info
=====
Number of SP daughterboards      : 1
Number of Comm boards           : 0
Number of Network IF daughterboards: 0
Serial Number                   : FT000587

=====
BaseBoard info
=====
BoardType      : <0x9> Compact PCI Baseboard
HardwareVersion : 0x4
Host memory size : 17 <0x11>
CP local memory size: 21 <0x15>
Flash memory size : 18 <0x12>
Global memory size : 16 <0x10>

=====
Daughterboards
=====
SP Daughterboard ==> 1
BoardType      : Motorola Onyx SP Daughterboard
HWVersion      : 0x3
Number of procs: 6
=====

```

## 4.7 STD Config Utility

The *STD Config* utility provides a flexible way to configure DM3 component parameters. You put the parameters to be set and retrieved for a particular component into a file. You can create and modify these files. When used in conjunction with the *STD Config* utility these component parameters (for example, lineadmin, CCS, player) can be easily configured.

**Command Line:** stdconfig [parameter\_list]

The *STD Config* utility uses the following command line parameters:


Parameter	Description
-board <n>	Board number (required). Use the <i>Listboards</i> utility to obtain the board number.
-file <name.ext>	The file name of the containing the relevant parameters of the component to be configured (such as tsc.prm, ccscomp.prm).
-inst <n>	Specifies the particular instance (of the component) whose parameters the user wants to modify.
-comptype <n>	Standard Dialogic component types (1 - 255).
-class <name>	One of the standard Dialogic components (such as TSC, LCON, CHP). This should match the relevant -file parameter.

**Example:** This example runs the *STD Config* utility on board 0:

```
stdconfig -board 0
```

Figure 10 shows the *STD Config* display.

**Figure 10. STD Config Display**



## 4.8 TSP Config

The *TSP Config* utility sets and retrieves DM3 protocol variant parameters. Using this utility the user can change protocol variant parameters dynamically from one call to the next.

This tool can be used on any DM3 product that has a T1 CAS or T1/E1 ISDN TSP resource. The tool does not work for R2MF protocols or Analog protocols.

**Command Line:** `tspconfig [parameter_list]`

The *TSP Config* utility uses the following command line parameters:


Parameter	Description
-board <n>	Board number (required). Use the <i>Listboards</i> utility to obtain the board number.
-id <n>	Protocol variant id (1 - 32), whose parameters you are configuring dynamically. For example, <code>tspconfig -board 0 -id 2</code> , will display the parameters of protocol variant id 2.

**Example:** This example runs the *TSP Config* utility on board 0:

```
tspconfig -board 1
```

Figure 11 shows the *TSP Config* display.

Figure 11. TSP Config Display



## 4.9 TSP Monitor

*TSP Monitor* performs the following:

- Monitors one or two DM3 GlobalCall resource channels.
- Traces all levels of the protocol including:
  - DM3 GlobalCall resource call control operations from clients
  - DM3 GlobalCall resource call state changes
  - DM3 GlobalCall resource channel state changes
  - CAS signaling bits
- Launches an audio tool for recording/playback purposes on the channel(s). It plays audio data (a file from the host) using the TSP.
- Checks timing via point and click on GUI
- Tunes protocols and identifies configuration problems

**Command Line:** `tspmon [parameter_list]`

The *TSP Monitor* utility uses the following command line parameters:


Parameter	Description
-board <n>	Board number (required). Use the <i>Listboards</i> utility to obtain the board number.
-line <n>	Line number (optional, default is 1)
-chan <n>	Channel number (optional, default is 1)

**Example:** This example runs the TSP Monitor utility on board 0, line 1, channel 1:

```
tspmon -board 0 -line 1 -chan 1
```

Figure 12 shows the *TSP Monitor* display.

**Figure 12. TSP Monitor Display**



## 4.10 TSP Tracer

*TSP Tracer* traces CAS protocols with timing information and saves trace information to a log file. The *TSP Tracer* utility does not support ISDN protocol tracing. For ISDN protocol tracing, use the *TSP Monitor* utility, which supports all protocols.

**Command Line:** `tsptrace [parameter_list]`

The *TSP Tracer* utility uses the following command line parameters:


Parameter	Description
-board <n>	Board number (required). Use the <i>Listboards</i> utility to obtain the board number.
-line <n>	Line number (optional, default is 1)
-chan <n>	Channel number (optional, default is 1)

**Example:** This example runs the TSP Tracer utility on board 0, line 1, channel 1:

```
tsptrace -board 0 -line 1 -chan 1
```

**Figure 13** shows a typical *TSP Tracer* display.

**Figure 13. TSP Tracer Display**







This chapter discusses the following topics about troubleshooting:

- General Troubleshooting Information . . . . . 41
- Checking Configuration. . . . . 41
- Event Viewer . . . . . 41
- Checking Which Packages Are Installed. . . . . 42
- Checking Hardware . . . . . 42

## 5.1 General Troubleshooting Information

Solutions to many problems can be found in the technical notes on the Intel® Telecom Support Resources Web site at <http://developer.intel.com/design/telecom/support..> In addition, check the online *Release Update* for the latest information about any issues, restrictions, or limitations that may affect the installation.

Problems on initial startup are typically caused by errors in your configuration. Hardware related problems are also a possibility. The following sections provide some general information for troubleshooting these problems.

In addition, refer to the *Intel® Dialogic® System Release Software Installation Guide* and check that all of the necessary procedures were performed.

## 5.2 Checking Configuration

Check that your system has been configured correctly. Use the Intel® Dialogic® Configuration Manager (DCM) to verify the configuration.

For a new configuration to take effect if system-level changes are made, the system must first be stopped and then restarted after the changes have been made. For configuration changes to a single board to take effect, the board must first be stopped and then restarted after the changes have been made. See Chapter 2, “Stopping and Starting the System”.

## 5.3 Event Viewer

Check the Windows\* Event Viewer for error and event messages. The Event Viewer can be accessed through DCM.

From the DCM main window, click the Log File option from the View pulldown menu to display the Event Viewer. Highlight System Log to display the Intel® Dialogic® system error and event messages.

## 5.4 Checking Which Packages Are Installed

Ensure that you installed all of the packages that you need. For a list and description of all system release software packages, see *Checking Which Packages to Install* in the in the *Intel® Dialogic® System Release Software Installation Guide*.

## 5.5 Checking Hardware

Ensure that each board is securely installed in its slot. Check that the correct cables are used and that they are connected properly.

For hardware testing information, see the *Intel® Dialogic® System Release Diagnostics Guide*.

## A

- adding a board to an active system 21
- administrative utilities
  - overview of 15
- Alarms utility 29
- applying board-level configuration changes 19
- applying system-level configuration changes 19

## B

- basic hot swap 14
- board
  - adding 21
  - removing 23
  - replacing 24
- board power on self test 21, 25
- board removal procedure 23
- board replacement procedure 24
- board-level configuration changes 19

## C

- changing system startup mode 17
- checking error and event messages 41
- checking hardware 42
- checking installed packages 42
- checking the configuration 41
- configuration changes
  - board level 19
  - system level 19

## D

- DCM
  - Remove/Uninstall Device option 23, 24
  - Start Device option 21, 25
  - System/Device Autostart option 21, 25
- displayed messages 17

## E

- error and event messages 41
- event viewer 41

## H

- hardware installation
  - troubleshooting 42
- high availability
  - peripheral hot swap 14
  - Redundant Host 14
  - support 13
- high availability platform 14
- high availability support 13
- how to use this publication 11

## I

- Intel® Dialogic® devices
  - starting after a reboot 17
- Intel® Dialogic® system
  - applying board-level configuration changes 19
  - applying system-level configuration changes 19
  - starting after initial startup 17
  - stopping 17
- intended audience 11
- IPT Admin utility 30

## L

- LineAdmin utility 29, 31
- Listboards utility 32

## M

- messages 17
- messages displayed 17

## O

- OUT OF SERVICE LED 24



## overview

- administrative utilities 15
- high availability support 13
- peripheral hot swap 14
- Redundant Host 14
- single board computer 14
- starting and stopping the system 13
- troubleshooting 15

## P

- peripheral hot swap
  - overview 14

POST 21, 25

power on self test 21, 25

primary clock master 24

## procedures

- adding a board to an active system 21
- removing a board in an active system 23
- replacing a board in an active system 24

## publication

- how to use 11
- intended audience 11

## Q

## Qscript utilities

- environment variables 28
- file directories 28
- QSCRIPT\_DIR environment variables 28
- remote systems 28
- single session variable 28

## R

Redundant Host 14

redundant single board computer 14

Redundant System Slot 13

reference master 24

related information 12

remote systems, Qscript utilities 28

Remove/Uninstall Device option 23, 24

removing a board in an active system 23

replacing a board in an active system 24

## S

single board computer 14

single session variable, Qscript utilities 28

Start Device option 21, 25

starting and stopping the system

- overview of 13

starting devices after a reboot 17

starting the Intel® Dialogic® system 17

starting the system 17

STD Config utility 34

stopping the Intel® Dialogic system 17

stopping the system 17

system startup mode

- changing 17

System/Device Autostart option 21, 25

system-level configuration changes 19

## T

## troubleshooting

- checking configuration 41
- checking event and error messages 41
- general information 41
- hardware 42
- overview of 15
- package installation 42

TSP Config utility 36

TSP Monitor utility 37

TSP Trace utility 38

## U

## utilities

- Alarms 29
- IPT Admin 30
- LineAdmin 31
- Listboards 32
- STD Config 34
- TSP Config 36
- TSP Monitor 37
- TSP Trace 38

## W

Windows® Event Viewer 41

Windows® Hot Swap Kit 21



