

DF850

Disk Array System

Maintenance Manual

REV.24

Read this manual carefully and keep it.

- Before starting operation, read the safety instructions carefully and fully understand them.
- After reading this manual, keep it at hand for your reference.

HITACHI

Preface

This manual explains the operation introduction, installation, maintenance, and WEB of the DF850 disk array system for service personnel to make them understand the DF850.

This manual contains information on maintenance works of the DF850 series disk array system such as array outline, structure, installation, and actions against failures.

When performing a maintenance work, read this manual carefully, and fully understand the Introduction of operation, operation procedure, and instructions before starting the work.

This manual was carefully prepared and reviewed for completeness and correctness. However, please feel free to contact us concerning any question, mistake, omission, or any other issues about this manual.

Contact address : Hitachi, Ltd. Information & Telecommunication Systems Company
IT Platform R & D Management Division
Storage Systems Development Operation
Storage Hardware Development/Storage Software Development III


Cautionary Notes

On This Manual

- Hitachi, Ltd. owns the copyrights of the DF850 Maintenance Manual. No part of this manual may be reused or reproduced without permission of Hitachi, Ltd.
 - Hitachi, Ltd. is not liable for any troubles or accidents which are caused by operation not written in this manual.
 - The DF850 Maintenance Manual may be revised without prior notice.
 - Although this array has the built-in laser diode, it meets the laser system standard of class 1. It does not emit the laser beam, which is harmful to a human body, outside the array in the usual operation.
- Operate the array according to this manual. Otherwise, it may cause unexpected accidents or failures.

General Cautionary Notes

- It is feared that user data is lost unless the power is turned off correctly following the specified procedure.
- The Drives are precision components. Never apply any shock or vibration to them.
- After replacing the Cache Backup Battery, connect the power cables to the Power Units, and deliver it to the customer after charging the battery. (It is about 3 hours at the maximum.)
- In order to protect parts from the electrostatic discharge, every worker must put a wrist strap on his/her wrist before starting installation or maintenance work and start the work after connecting the grounding clip to a metallic portion of the frame. (The wrist strap must be put on when connecting the LAN cable.)
- Do the work with the wrist strap put on. Do not put off the wrist strap till the work is finished.
- When handling a part, hold it in the way that fingertips of the hand putting the wrist strap on touch a metallic portion of the part. (The above is necessary in order to discharge the charged static electricity and prevent a charge caused by handling.)
- Be sure to touch the array with the wrist strap put on. If you touch the array without putting on the wrist strap, the static electricity charged on your body flows to the array in an instant because no resistance exists between your body and the array causing an array trouble.



Trademarks

AIX is a trademark of International Business Machines Corporation in the United States, other countries, or both.

Firefox is a registered trademark of the Mozilla Foundation.

HP-UX is a product name of Hewlett-Packard Development Company, L.P. in the U.S. and other countries.

IRIX is a registered trademark of Silicon Graphics, Inc.

Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.

Microsoft, Windows, Windows NT, Windows Sever, Windows Vista and Internet Explorer are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Mozilla is a trademark of the Mozilla Foundation in the U.S and other countries.

Novell, and NetWare are either registered trademarks or trademarks of Novell, Inc. in the United States and other countries.

OpenView is a trademark of Hewlett-Packard Development Company, L.P. in the U.S. and other countries.

Red Hat is a trademark or a registered trademark of Red Hat Inc. in the United States and other countries.

UNIX is a registered trademark of The Open Group in the United States and other countries.

VMware is a registered trademark or a trademark of VMware, Inc. in the United States and/or other jurisdictions.

Other company and product names mentioned in this document may be the trademarks of their respective owners.

Note

EMI Regulation

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference in which case the user will be required to correct the interference at his own expense. Testing was done with shielded cables. Therefore, in order to comply with the FCC regulations, you must use shielded cables with you installation.

- This product must not be used in residential areas.
- This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

EMI Regulation Labels Affixed on the Array.

この装置はクラスA情報技術装置です。
この装置を家庭環境で使用すると電波妨害を引き起こすことが
あります。この場合には使用者が適切な対策を講ずるよう
要求されることがあります。 VCCI-A

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用する
と電波妨害を引き起こすことがあります。この場合には使用者が適切な対策
を講ずるよう要求されることがあります。 VCCI-A

"This equipment complies with the requirements in part 15 of FCC Rules for a Class A computing device and Part II, Vol. 122, No. 20 of Canada Gazette for a Class A digital apparatus. Operation of this equipment in a residential area may cause unacceptable interference to radio and TV reception requiring the operator to take whatever steps are necessary to correct the interference."

This Class A digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

The EMI test was done in the following configuration.

If a trouble occurs in another configuration, a user may be requested to take appropriate preventive measures.

- DF850-CBSL/CBSS+DBL/DBS(×4)+RK40
- DF850-CBL+DBL/DBS(×4)+RK40
- DF850-CBSL/CBSS+DBL/DBS(×2)+DBX(×2)+RK40
- DF850-CBXSL/CBXSS+DBL/DBS(×2)+RK40
- DF850-CBLD+DBLD(×3)+DBSD(×3)+RK40
- DF850-CBL+DBW(×4)+RK40

Model Name Conversion

Throughout this document, product model name is written as “DF850”. When you want to use this document for the HT-4066 series, please read the model name “DF850” as “HT-4066”.

Table 1 Conversion Table for Model Name and Other Model Name

The model name which is used in this document	The model name replace to DF850	Type
DF850-xxx	HT-4066-xxx	(DF850-CBx)
DF-F850-xxxx	HT-F4066-xxxx	Optional component Accessory component

Throughout this document, array name “Hitachi Unified Storage” is abbreviated as “HUS” in some places. Read each array model names as shown in the table below.

Table 2 Conversion Table for Array Model Name

Model name	Abbreviation for Model Name
Hitachi Unified Storage 130	HUS130
Hitachi Unified Storage 150	HUS150
Hitachi Unified Storage 110	HUS110
Hitachi Unified Storage 100 Series	HUS100 Series

This manual does not describe CBLE except for the installing the encryption module. CBLE have the same procedures for CBL. Therefore, read CBL as CBLE except for the shared part.

This manual does not describe CBLD, DBLD and DBSD except for the following differences. CBLD, DBLD and DBSD have the same procedures for CBL, DBL and DBS, respectively. Therefore, read CBL as CBLD, DBL as DBLD and DBS as DBSD except for the shared part.

Table 3 Difference between CBL/CBLD, DBL/DBLD and DBS/DBSD

Chassis Name	Power specification
CBL	AC power supply
CBLD	DC power supply
DBL	AC power supply
DBLD	DC power supply
DBS	AC power supply
DBSD	DC power supply

Manual Composition

This Maintenance Manual is composed of 12 volumes: Safety Summary, Introduction, Installation, Firmware, System Parameter, Addition/Removal/Relocation, Upgrade, Troubleshooting, Messages, Replacement, Parts Catalog, and WEB. Each volume and chapter has table of contents to help readers to find just the page they want.

For the composition of the each volume, refer to the following.

Safety Summary :

This “Safety Summary” volume describes the cautionary notes to handle the maintenance work safely.

Introduction :

This “Introduction” volume describes the cautionary/prohibited notes in the maintenance work, the outline of the array, and the configuration, etc.

Installation :

This “Installation” volume describes the setting of the array and the installation of the parts, etc.

Firmware :

This “Firmware” volume describes the update installation of the firmware.

System Parameter :

This “System Parameter” volume describes the setting of the system parameter of the array, etc.

Addition/Removal/Relocation :

This “Addition/Removal/Relocation” volume describes the addition, removal and relocation related to the setting of the array.

Upgrade :

This Upgrade Volume describes the procedure for upgrading from the existing model to the upper model and the procedure for upgrading the HUS150 to the Drive I/O Module (Encryption) ([Chapter 8](#)).

Troubleshooting :

This “Troubleshooting” volume describes the trouble analysis of the array, etc.

Messages:

This “Message” volume describes the content of the message which occurs at the time of the array failure.

Replacement :

This “Parts Replacement” volume describes the replacement work of each part and the periodic maintenance, etc.

Parts Catalog :

This “Parts Catalog” volume describes each part installed in the array.

WEB :

This “WEB” volume describes the operating procedure for WEB.

Contents

Preface	GENE 0010
Cautionary Notes	GENE 0020
Note	GENE 0040
Model Name Conversion	GENE 0050
Manual Composition	GENE 0060

[Safety Summary]

 SAFETY SUMMARY	SAFE 0020
--	-----------

[Introduction]

Chapter 1. Outline	INTR 01-0000
1.1 What is RAID	INTR 01-0000
1.1.1 Application of RAID Technology	INTR 01-0010
1.1.2 RAID Levels	INTR 01-0020
1.2 Overview of the DF850	INTR 01-0040
1.2.1 Overview of Functions	INTR 01-0040
1.3 Structure	INTR 01-0090
1.3.1 Appearances	INTR 01-0110
1.3.2 System Configuration of the Rackmount Model	INTR 01-0150
1.3.3 Configuration of Rackmount Model with RK40 Rack Frame	INTR 01-0260
1.3.4 Specification of the Drive Box Connection	INTR 01-0270
1.4 Configuration of Internal Power Supply System	INTR 01-0340
1.5 Configuration of Internal Data System	INTR 01-0410
1.6 Configuration of Built-in Software	INTR 01-0630
1.6.1 Block Diagram of Built-in Software Configuration	INTR 01-0630
1.6.2 Storages for Parameters	INTR 01-0660
Chapter 2. Major Specifications	INTR 02-0000
2.1 Basic Specifications	INTR 02-0020
2.2 Environmental Specifications	INTR 02-0410
2.3 Basic Specifications of the Drive	INTR 02-0440

Chapter 3. Introduction of Operation	INTR 03-0000
3.1 Power On/Off Sequence	INTR 03-0000
3.1.1 IMPL Sequence	INTR 03-0000
3.1.2 Drive Powering On Sequence	INTR 03-0020
3.1.3 Sequential Shutdown	INTR 03-0110
3.2 Data Format	INTR 03-0120
3.3 Read/Write Operation	INTR 03-0130
3.3.1 Command Execution	INTR 03-0130
3.3.2 Dual System Configuration	INTR 03-0150
3.4 Cache Memory Control	INTR 03-0160
3.4.1 Purpose of Cache Memory	INTR 03-0160
3.4.2 Cache Memory Configuration	INTR 03-0170
3.4.3 Cache Memory Structure	INTR 03-0180
3.4.4 Basic Operation of Cache Control	INTR 03-0200
3.4.5 Destaging Operation	INTR 03-0210
3.4.6 Staging Operation (Writing to the Cache Memory)	INTR 03-0220
3.4.7 Flash Backup Function	INTR 03-0230
3.5 E-mail Alert Function	INTR 03-0240
3.5.1 Overview and Restriction	INTR 03-0240
3.5.2 Details of Sent Mails	INTR 03-0250
3.6 Operation Against Disk Failure	INTR 03-0300
3.7 Setting RAID Group	INTR 03-0420
3.8 Online Verify	INTR 03-0510
3.9 Setting of LAN Interface	INTR 03-0540
Chapter 4. Outline of P.P.	INTR 04-0000
4.1 Optional Functions	INTR 04-0000

[Installation]

Chapter 1. Before Starting Installation Work	INST 01-0000
1.1 Before Starting Installation Work	INST 01-0000
1.2 Model Name	INST 01-0040
1.3 Structure of Installing Array	INST 01-0120
1.4 How to Open/Close Door or Attach/Remove Front Bezel/ Rear Door	INST 01-0140
1.4.1 How to Attach/Remove Front Bezel	INST 01-0140
1.4.2 How to Open/Close the Rear Door of RK40 Rack Frame	INST 01-0210

1.5	Power On/Off Procedure	INST 01-0220
1.5.1	Array Power On.....	INST 01-0230
1.5.2	Array Power Off (Sequential Shutdown).....	INST 01-0260
1.6	Setting the Power Interlock Mode	INST 01-0270
Chapter 2.	Installing Array	INST 02-0000
2.1	Procedures for Installing Array	INST 02-0000
2.2	Unpacking and Installing Rack Frame.....	INST 02-0030
2.2.1	RK40 Rack Frame (Unpacking/Installing and Installation Areas/ Maintenance Areas)	INST 02-0030
2.2.2	Installing Rails	INST 02-0160
2.3	Unpacking the Arrays.....	INST 02-0390
2.4	Installing the Rackmount Model	INST 02-0410
2.4.1	Work Procedure before Installing the Rack Mounting	INST 02-0410
2.4.2	Removing Components	INST 02-0410
2.4.3	Mounting on Rack Frame	INST 02-0530
2.4.4	Mounting Lifter on Rack Frame	INST 02-0540
2.4.5	Mounting Array on Rack Frame	INST 02-0560
2.4.6	Fastening the Array	INST 02-0580
2.4.7	Installing Components	INST 02-0640
2.4.8	Installing the Cables Routing Bars	INST 02-0820
2.4.9	Connecting the Cables	INST 02-0850
2.4.10	Connecting the Interface Cables	INST 02-0940
2.4.11	Connecting the SAS(ENC) Cables	INST 02-0990
2.4.12	Connecting the Power Cables.....	INST 02-1270
2.4.13	Connecting the Power Cables (Rack Frame PDB)	INST 02-1320
2.4.14	Routing the Cables for DBX	INST 02-1330
2.4.15	Attaching Decoration Panels.....	INST 02-1400
2.4.16	Closing Door or Attaching Front Bezel	INST 02-1410

[Firmware]

Chapter 1.	Installation of Firmware	FIRM 01-0000
1.1	Materials Necessary for Installation.....	FIRM 01-0000
1.2	Outline of Procedure for Installation (Update Installation)	FIRM 01-0010
1.3	Preparation for Installation of Firmware.....	FIRM 01-0020
1.3.1	Hierarchy of Firmware Storage Directories	FIRM 01-0020
1.4	Procedure for Installation	FIRM 01-0030
1.4.1	The Point to be Checked before Installation	FIRM 01-0030
1.4.2	Update Installation of Firmware.....	FIRM 01-0040
1.4.3	Procedure for the Version Downgrade	FIRM 01-1510

1.5	Checking the Start and the Termination of the ENC Firmware/ Backup Controller Firmware Automatic Download.....	FIRM 01-1550
1.6	Checking the Start and End of the Drive Firmware Automatic Download	FIRM 01-1590
1.7	Restrictions of the Version Downgrade of the Firmware	FIRM 01-1640
1.8	Adaptable Firmware Revision	FIRM 01-1670
Chapter 2.	Procedure for Recovery from a Failure	FIRM 02-0000
2.1	Procedure for Recovery from a Failure during Installation	FIRM 02-0000
Chapter 3.	Procedure for Isolating Cause of Drive Failure when “Install partially complete” Message is Output	FIRM 03-0000
3.1	Procedure for Checking whether System Copy Operation Occurred.....	FIRM 03-0020
3.2	Procedure for Checking the Status of System Copy Complete.....	FIRM 03-0030

[System Parameter]

Chapter 1.	Setting (Hitachi Storage Navigator Modular 2).....	SYSR 01-0000
1.1	Procedure for Connecting Hitachi Storage Navigator Modular 2 with the Array.....	SYSR 01-0020
1.2	LAN Port Number Change by Hitachi Storage Navigator Modular 2	SYSR 01-0120
Chapter 2.	Component Status	SYSR 02-0000
Chapter 3.	Wizard.....	SYSR 03-0000
3.1	Initial Setup	SYSR 03-0000
3.2	Creating and Mapping Volume	SYSR 03-0080
3.3	Install License	SYSR 03-0120
Chapter 4.	Setting the RAID/Volume/Spare Drive	SYSR 04-0000
4.1	Flow of Setting the RAID Group/Volume/Spare Drive.....	SYSR 04-0000
4.2	Setting RAID Group	SYSR 04-0030
4.2.1	Preparing and Confirming RAID Group Setting	SYSR 04-0030
4.2.2	Creating RAID Group.....	SYSR 04-0050
4.2.3	Verifying the RAID Group	SYSR 04-0090
4.2.4	Deleting RAID Group	SYSR 04-0100
4.2.5	Expanding the RAID Group.....	SYSR 04-0130
4.3	Setting Volume	SYSR 04-0250
4.3.1	Preparing for Volume Setting	SYSR 04-0290
4.3.2	Creating Volume.....	SYSR 04-0310
4.3.3	Verifying the Volume	SYSR 04-0420
4.3.4	Deleting Volume.....	SYSR 04-0430
4.3.5	Changing the Capacity of Volumes	SYSR 04-0460

4.3.6	Formatting Volume	SYSR 04-0500
4.3.7	Setting the Format Mode	SYSR 04-0600
4.4	Setting Spare Drive	SYSR 04-0630
4.4.1	Preparing for Spare Drive Setting	SYSR 04-0640
4.4.2	Setting Spare Drive	SYSR 04-0650
4.4.3	Deleting Spare Drive	SYSR 04-0660
4.4.4	Verifying the Spare Drive	SYSR 04-0670
4.5	Checking the Status of Drive	SYSR 04-0680
4.6	Checking the Drive which Configures the RAID Group	SYSR 04-0710
4.7	Volume Unification	SYSR 04-0730
4.7.1	Preparing for Volume Unification Setting	SYSR 04-0730
4.7.2	Creating Unified Volume	SYSR 04-0740
4.7.3	Separating Unified Volume	SYSR 04-0770
Chapter 5.	Setting Host Group/Targets	SYSR 05-0000
5.1	Setting Host Group/Target Options	SYSR 05-0000
5.2	Setting LU Mapping	SYSR 05-0100
5.2.1	Assigning and Releasing Volume for the Fibre Model	SYSR 05-0100
5.2.2	Assigning and Releasing Volume for the iSCSI Model	SYSR 05-0170
5.2.3	Setting Mapping Mode	SYSR 05-0240
5.2.4	Setting Mapping Guard	SYSR 05-0270
5.3	Setting Fibre Channel	SYSR 05-0290
5.4	Setting iSCSI	SYSR 05-0330
5.4.1	Setting iSCSI Port Information	SYSR 05-0330
5.4.2	Setting Target Information	SYSR 05-0360
5.4.3	Setting CHAP Authentication	SYSR 05-0430
5.4.4	Setting iSNS	SYSR 05-0500
5.4.5	Sending Ping	SYSR 05-0520
5.5	System Parameter Setting List	SYSR 05-0540
Chapter 6.	Setting Date and Time	SYSR 06-0000
Chapter 7.	Setting LAN Related	SYSR 07-0000
7.1	Setting Maintenance LAN	SYSR 07-0000
7.2	Setting LAN	SYSR 07-0040
7.3	Setting LAN Port Number	SYSR 07-0100
7.3.1	Changing the Setting with LAN connection to Both Controllers	SYSR 07-0100
7.3.2	Changing the Setting with LAN connection to One of the Controllers	SYSR 07-0140
7.3.3	Recovery Method	SYSR 07-0190
7.4	Setting of the secure LAN	SYSR 07-0220
7.4.1	Changing the normal port status	SYSR 07-0220
7.4.2	Changing the packet filtering	SYSR 07-0250

7.4.3 Changing the Port 80 Block.....	SYSR 07-0280
Chapter 8. Setting Basic Parameters for the System	SYSR 08-0000
8.1 Setting Boot Options.....	SYSR 08-0000
8.2 Setting System Parameters	SYSR 08-0040
8.3 Setting Port Options	SYSR 08-0080
Chapter 9. E-mail Alert Function	SYSR 09-0000
9.1 Setting Procedure	SYSR 09-0000
9.1.1 Displaying Setting Window	SYSR 09-0010
9.1.2 Checking E-mail Alert Disabled	SYSR 09-0030
9.1.3 Entering Setting Items	SYSR 09-0040
9.1.4 Sending a Test Mail	SYSR 09-0060
9.1.5 Maintenance when the Mail Does Not Reach the Destination	SYSR 09-0070
9.1.6 Enabling E-mail Alert	SYSR 09-0100
9.2 Procedure for Canceling E-mail Error Report.....	SYSR 09-0110
9.3 Correspondence by Report Messages	SYSR 09-0120
Chapter 10. Setting Constitute Array	SYSR 10-0000
Chapter 11. Setting Drive	SYSR 11-0000
11.1 Setting Drive Recovery.....	SYSR 11-0000
11.2 Setting the Flash Drive Write Endurance Threshold	SYSR 11-0050
11.3 Setting the Flash Drive (FMD) Battery Life Threshold Value.....	SYSR 11-0090
Chapter 12. Setting Verification	SYSR 12-0000
Chapter 13. Setting Performance.....	SYSR 13-0000
13.1 Setting Monitoring	SYSR 13-0000
13.1.1 Changing Measurement Items.....	SYSR 13-0020
13.1.2 Getting Performance.....	SYSR 13-0040
13.2 Setting Tuning Parameter	SYSR 13-0050
13.2.1 Setting Multi Stream	SYSR 13-0070
13.2.2 Setting System Tuning	SYSR 13-0110
13.2.3 Setting LU Ownership	SYSR 13-0130
Chapter 14. Setting Licenses	SYSR 14-0000
14.1 Procedure for Unlocking the License of Priced Option	SYSR 14-0000
14.2 Procedure for Locking the License of Priced Option.....	SYSR 14-0020
14.3 Setting Enabling or Disabling of the License	SYSR 14-0040
Chapter 15. Setting Command Device and DMLU	SYSR 15-0000
15.1 Setting Command Device.....	SYSR 15-0000
15.2 Setting DMLU	SYSR 15-0020
Chapter 16. Setting Power Interlock.....	SYSR 16-0000

Chapter 17. Setting Air Filter Information.....	SYS-PR 17-0000
17.1 Changing Air Filter timer function.....	SYS-PR 17-0000
17.2 Initializing Air Filter Running Time	SYS-PR 17-0030

[Addition/Removal/Relocation]

Chapter 1. Adding Optional Components	ADD 01-0000
1.1 Before Starting Addition of Optional Components.....	ADD 01-0000
1.2 Procedures for Adding Optional Components	ADD 01-0020
1.2.1 Unpacking	ADD 01-0090
1.3 Mounting on Rack Frame.....	ADD 01-0100
1.4 Adding Optional Components	ADD 01-0110
1.4.1 Optional Components for Addition	ADD 01-0110
1.4.2 Adding a Drive	ADD 01-0120
1.4.3 Adding a Cache Memory.....	ADD 01-0460
1.4.4 Adding a FC Host I/O Board/Module	ADD 01-0500
1.4.5 Adding an iSCSI Host I/O Board/Module	ADD 01-0570
1.4.6 Adding a Controller	ADD 01-0640
1.5 Adding Other Optional Devices	ADD 01-0650
1.5.1 Other Optional Additional Devices	ADD 01-0650
1.5.2 Mounting a PDB (A-F6516-PDU6).....	ADD 01-0660
1.6 Adding the Drive Box to the Rack Frame.....	ADD 01-0690
1.6.1 Procedure for Adding Drive Box to Rack Frame	ADD 01-0700
1.6.2 Connection and Recognition of the Drive Box	ADD 01-0770
Chapter 2. Removing Optional Components.....	ADD 02-0000
2.1 Before Starting Removal of Optional Components	ADD 02-0000
2.1.1 Preparatory Works for Removal.....	ADD 02-0020
2.2 Procedures for Removing Optional Components.....	ADD 02-0100
2.3 Removing Drive Box on Rack Frame.....	ADD 02-0130
2.3.1 Removing Drive Box on Rack Frame	ADD 02-0130
2.3.2 Post process for the drives that have been assigned encryption keys in the removed drive unit	ADD 02-0161
2.4 Removing Optional Components.....	ADD 02-0170
2.4.1 Optional Components for Removal	ADD 02-0170
2.4.2 Removing a Drive.....	ADD 02-0190
2.4.3 Removing a Cache Memory	ADD 02-0320
2.4.4 Removing a FC Host I/O Board/Module.....	ADD 02-0370
2.4.5 Removing an iSCSI Host I/O Board/Module	ADD 02-0440
2.4.6 Removing a Controller	ADD 02-0510

2.5 Removing Other Optional Devices.....	ADD 02-0520
2.5.1 Other Optional Removal Devices	ADD 02-0520
2.5.2 Removing a PDB (A-F6516-PDU6)	ADD 02-0530
Chapter 3. Relocation/Removal Work.....	ADD 03-0000
3.1 Before Starting Relocation/Removal Work	ADD 03-0000
3.2 Procedures for Relocating or Removing Array.....	ADD 03-0020
3.2.1 Disconnecting the Power Cables.....	ADD 03-0050
3.2.2 Disconnecting the Power Cables (for Supplying Power to Rack Frame)	ADD 03-0060
3.2.3 Disconnecting Interface Cables	ADD 03-0070
Chapter 4. Drive Replacement for Changing the Drive Type.....	ADD 04-0000
4.1 Before Starting Replacement	ADD 04-0000
4.2 Procedure for Replacing Drives for Changing the Drive Type.....	ADD 04-0020
4.3 Removing the Drives.....	ADD 04-0040
4.4 Installing Drives	ADD 04-0060
Chapter 5. Host I/O Replacement for Changing the Host I/O Type.....	ADD 05-0000
5.1 Before Starting Replacement	ADD 05-0000
5.2 Replacing Host I/O for Changing the Host I/O Type	ADD 05-0030
5.2.1 Replacing Host I/O Boards/Modules Online (Host is Operating)	ADD 05-0040
5.2.2 Replacing Host I/O Boards/Modules Offline (Power is Turned Off) ..	ADD 05-0150

[Upgrade]

Chapter 1. Outline	UP 01-0000
Chapter 2. Tools and Arranged Parts Required for Upgrade	UP 02-0000
2.1 Arranged Parts Required for Upgrade	UP 02-0000
Chapter 3. Before Starting Upgrade Operation	UP 03-0000
3.1 Prerequisites.....	UP 03-0000
3.2 Before Starting Upgrade Work	UP 03-0020
3.3 Notes.....	UP 03-0030
Chapter 4. Flow of Upgrade Operation Procedure	UP 04-0000
4.1 Flow of the Procedure for Upgrade Work from CBSL/CBSS to CBL.....	UP 04-0000
Chapter 5. Upgrade Work	UP 05-0000
5.1 Suspend the Work of the Host computer.....	UP 05-0010
5.2 User's Data Backup.....	UP 05-0010
5.3 Lock the Priced Option.....	UP 05-0020
5.3.1 Before Locking the Priced Option	UP 05-0020
5.3.2 Procedure for Locking the Priced Option	UP 05-0020

5.4	Unpacking Parts for Upgrade.....	UP 05-0030
5.5	Connection of the Maintenance PC	UP 05-0060
5.6	Changing Mode of Hitachi Storage Navigator Modular 2 and Registering Array	UP 05-0060
5.7	Remove the Interface Cables	UP 05-0070
5.8	Firmware Update Installation for Array before Upgrade	UP 05-0090
5.9	Collecting Simple Trace.....	UP 05-0152
5.10	Collecting Serial Numbers of Drives	UP 05-0160
5.11	Array Power Off	UP 05-0190
5.12	Hardware Upgrade Work	UP 05-0200
5.12.1	Note on Hardware Upgrade Works	UP 05-0220
5.12.2	Open/Close Door or Attach/Remove Front Bezel/Rear Door	UP 05-0250
5.12.3	Removing the Cables of the Drive Box	UP 05-0260
5.12.4	Removing a Drive	UP 05-0300
5.12.5	Removing a Drive Box	UP 05-0340
5.12.6	Removing the Rack Rails.....	UP 05-0390
5.12.7	Installing the Rack Rails	UP 05-0410
5.12.8	Installing a Chassis	UP 05-0460
5.12.9	Installing a Drive	UP 05-0490
5.12.10	Attaching a Front Bezel	UP 05-0530
5.12.11	Installing a Drive BOX.....	UP 05-0540
5.12.12	Removing the Cables of the Controller Box	UP 05-0550
5.12.13	Removing a Drive.....	UP 05-0560
5.12.14	Removing/Installing the Rack Rails.....	UP 05-0630
5.12.15	Installing DBL/DBS on Rack Frame	UP 05-0660
5.12.16	Installing a Drive	UP 05-0710
5.12.17	Installing CBL on Rack Frame	UP 05-0740
5.12.18	Connecting Cables	UP 05-0750
5.13	Array Power On	UP 05-0760
5.14	Firmware Update Installation for Array after Upgrade.....	UP 05-0780
5.15	Changing the Number of Drive I/O Modules.....	UP 05-0850
5.16	Setting Serial Number of Array	UP 05-0870
5.17	Registering Array after Upgrade	UP 05-0910
5.18	Setting Power Interlock	UP 05-0930
5.19	Changing the Registration Information for the Monitoring Failures.....	UP 05-0940
5.20	Works to be done after the Upgrade is Completed	UP 05-0940
5.21	Using the Priced Option	UP 05-0940
5.22	Resetting of the Host	UP 05-0940
5.23	Restart the Work of the Host Computer	UP 05-0940

Chapter 6. Troubleshooting at the Time of Upgrade	UP 06-0000
6.1 Error Messages.....	UP 06-0000
6.1.1 Flash Detected Messages.....	UP 06-0000
6.1.2 Failure Messages	UP 06-0000
6.1.3 Progress Messages.....	UP 06-0000
6.1.4 WEB Error Messages.....	UP 06-0000
6.1.5 Other Messages	UP 06-0000
6.2 When “RB8300 Empty System retry full install” Occurs	UP 06-0010
6.3 When a Drive was inserted in a Wrong Location	UP 06-0020
6.4 When Returning Configuration of the Array after the Upgrade to that of the Chassis before the Upgrade	UP 06-0040
6.4.1 Procedure for Removing Guard Check against Installation of the Firmware for the Chassis before the Upgrade	UP 06-0060
6.4.2 Procedure for Removing Downgrade Check.....	UP 06-0070
6.4.3 System Power Off	UP 06-0080
Chapter 7. For Setting Changes in Host Computer and Others	UP 07-0000
Chapter 8. Upgrading to the Drive I/O Module (Encryption)	UP 08-0000
8.1 Tools Required for Upgrade	UP 08-0000
8.2 Arranged Parts Required for Upgrade	UP 08-0000
8.3 Upgrade Procedure	UP 08-0010
8.3.1 Upgrade Procedure in the Status where the Power Unit is Turned Off.....	UP 08-0020
8.3.2 Upgrade Procedure in the Status where the Power Unit is Turned On	UP 08-0050

[Troubleshooting]

Chapter 1. Flowchart for Troubleshooting.....	TRBL 01-0000
Chapter 2. Before Maintenance Work	TRBL 02-0000
2.1 Precautions	TRBL 02-0000
2.2 Confirming and Setting RTC (Real Time Clock)	TRBL 02-0010
2.3 Indications and their Functions.....	TRBL 02-0030
Chapter 3. Before Starting WEB Connection	TRBL 03-0000
3.1 Procedure to WEB Connection	TRBL 03-0000
3.2 When the WEB has Already been Connected	TRBL 03-0080
3.3 Note on WEB Connecting	TRBL 03-0090
3.4 Procedure for Specifying Maintenance Port IP Address	TRBL 03-0120
3.5 Procedure to Search IP Address of Maintenance Port	TRBL 03-0130

Chapter 4. Trouble Analysis by WEB Connection	TRBL 04-0000
4.1 Confirm State of Unit	TRBL 04-0010
4.2 Confirm State of Each Part	TRBL 04-0040
4.3 Confirm Log Messages	TRBL 04-0120
4.4 TrueCopy remote replication/ TrueCopy Extended Distance Path Confirm State	TRBL 04-0190
4.5 The Priority Error Messages when “CTL alarm” is Displayed	TRBL 04-0200
Chapter 5. Collecting Error Information.....	TRBL 05-0000
5.1 Time to Collect Failure Information	TRBL 05-0010
5.2 Judging Collection of Failure Information	TRBL 05-0020
5.3 Collecting Simple Trace.....	TRBL 05-0040
5.4 Collecting CTL Alarm Trace	TRBL 05-0130
5.5 Collecting Full Dump	TRBL 05-0180
5.6 Dump Collection of Flash Drives (FMD)	TRBL 05-0300
5.6.1 Restrictions on Dump Collection of Flash Drives (FMD)	TRBL 05-0300
5.6.2 Procedure for Collecting the Dump of Flash Drives (FMD)	TRBL 05-0300
Chapter 6. Data Collection when a Failure Occurs in Program Product (P.P.) ...	TRBL 06-0000
6.1 P.P.s Required for Maintenance	TRBL 06-0000
6.2 Locating Failed Part	TRBL 06-0010
6.2.1 When a Failure Occurs in the DF850 Main Body	TRBL 06-0030
6.2.2 When a Failure Occurs in a Host System Server.....	TRBL 06-0030
6.2.3 When a Failure Occurs in a Server for Monitoring and Setting.....	TRBL 06-0030
6.3 List of Data to be Collected when a P.P. Failure Occurs	TRBL 06-0040
Chapter 7. Trouble Analysis by LED Indication	TRBL 07-0000
7.1 Trouble Analysis by LED Indication of Front Bezel.....	TRBL 07-0000
7.2 Trouble Analysis by LED Indication of Each Part.....	TRBL 07-0170
Chapter 8. Trouble Analysis by Failure Monitoring Function	TRBL 08-0000
8.1 Trouble Analysis by SNMP Agent Support Function	TRBL 08-0000
8.1.1 Maintenance with TRAP Codes	TRBL 08-0000
8.1.2 Maintenance with MIB (df Regression) Values	TRBL 08-0060
8.2 Trouble Analysis by Hitachi Storage Navigator Modular 2	TRBL 08-0090
8.2.1 Maintenance with the Hitachi Storage Navigator Modular 2 (GUI Version).....	TRBL 08-0090
8.3 Hitachi Storage Navigator Modular 2 Maintenance Function.....	TRBL 08-0110
8.3.1 Displaying Volume Failure Data Information.....	TRBL 08-0130
8.3.2 Setting Pre-fetch Information.....	TRBL 08-0150
8.3.3 Setting a Threshold for Preventive Maintenance	TRBL 08-0180
8.3.4 Drive Maintenance	TRBL 08-0210

8.3.5	Setting a Mode for Reporting to the Host Using an SSB	TRBL 08-0240
8.3.6	Replacing the Online ENC Firmware	TRBL 08-0270
8.3.7	Drive Performance Delay Diagnostic Function.....	TRBL 08-0300
8.3.8	Setting the Drive Firmware Download	TRBL 08-0340
8.3.9	Displaying Temperature in the Basic Unit.....	TRBL 08-0370
8.3.10	Setting the Host Reservation Forced Release Function.....	TRBL 08-0400
Chapter 9. Procedure for Investigating Array Regarding Fibre Channel Failure ... TRBL 09-0000		
Chapter 10. Procedure for the iSCSI System Failure Determination on the Array Side..... TRBL 10-0000		
Chapter 11. Details of Recovery Methods..... TRBL 11-0000		
11.1	Error Recovery Methods	TRBL 11-0000
11.1.1	System Down	TRBL 11-0040
11.1.2	The Array does not Become Ready : Case 1 (Loading Failure)	TRBL 11-0070
11.1.3	The Failure Occurred Immediately after Being Ready (Forced Parity Correction).....	TRBL 11-0150
11.1.4	The Power cannot be Turned Off : Case 1 (The Number of PIN Data is Too Large).....	TRBL 11-0600
11.1.5	The Power cannot be Turned Off : Case 2 (Hardware Failure).....	TRBL 11-0640
11.1.6	The Power cannot be Turned Off : Case 3 (Controller Failure)	TRBL 11-0660
11.1.7	The Power cannot be Turned Off : Case 4 (Cache Memory Failure).....	TRBL 11-0680
11.1.8	Data Recovery does not Terminate Normally : Case 1 (Read Error)	TRBL 11-0700
11.1.9	Data Recovery does not Terminate Normally : Case 2 (Drive Failure)	TRBL 11-0720
11.1.10	Data Recovery does not Terminate Normally : Case 3 (Spare Drive Failure).....	TRBL 11-0740
11.1.11	A Failure Occurred during Operation : Case 1 (PIN Over)	TRBL 11-0760
11.1.12	A Failure Occurred during Operation : Case 2 (LA/LRC Error)	TRBL 11-0800
11.1.13	A Failure Occurred during Operation : Case 3 (Volume Blockade).....	TRBL 11-0820
11.1.14	A Failure Occurred during Operation : Case 4 (Incomplete Writing)	TRBL 11-0840
11.1.15	The Incomplete Write Area was Registered in the Restored Volume	TRBL 11-0850
11.1.16	Recovery Method of the Modular Volume Migration which Terminated Abnormally	TRBL 11-0880
11.1.17	Path Blockade Occurs in the TrueCopy remote replication/ TrueCopy Extended Distance Function	TRBL 11-0910
11.1.18	Recovery Method for Drives which Skipped Drive Firmware Replacement	TRBL 11-1020

11.1.19	Recovery Method when the Down of the Array Occurred due to the Incorrect SAS(ENC) Cable Connection	TRBL 11-1030
11.1.20	Recovery Method when a Power Unit Failure of the Drive Box Occurred	TRBL 11-1050
11.1.21	Recovery Method when the Creation of the SSL User Certificate File Failed	TRBL 11-1060
11.1.22	Recovery Method when Detecting the Mismatch of the Controllers between the Controllers.....	TRBL 11-1080
11.1.23	Recovery Method when the Spin-up of the System Drive Failed..	TRBL 11-1100
11.1.24	Recovery Method when the Array went Down because the Load of the DP Management Information.....	TRBL 11-1120
11.1.25	Recovery Method when the Firmware Detected an Error of the DP Management Information and the Controller was Blocked	TRBL 11-1180
11.1.26	Recovery Method when the Drive Serial Number Acquired at the time of Starting the Array and the Serial Number of the Configuration Information do not Match	TRBL 11-1200
11.1.27	Procedure for Starting the Array by Removing the Failed Drive when the Array is not Ready	TRBL 11-1220
11.1.28	Failure Determination and Recovery Methods of Fibre Channel Port Path	TRBL 11-1250
11.1.29	Recovery Method when the Multiple Suspected Failed Parts were Detected in the Backend.....	TRBL 11-1390
11.1.30	Recovery Method when the Planned Shutdown of the Array was Executed Automatically	TRBL 11-1430
11.1.31	Recovery Method when a FAN Failure of the CBL Occurs.....	TRBL 11-1450
11.1.32	Recovery Method at the Time of Management Module Blockade.	TRBL 11-1530
11.1.33	Recovery Method at the Time of Drive I/O Module Blockade	TRBL 11-1680
11.1.34	Recovery Method at the Time of Host I/O Module Blockade	TRBL 11-2180
11.1.35	Recovery Method at the Time of Host I/O Board Blockade.....	TRBL 11-2540
11.1.36	The Array does not Start Due to the Incorrect Setting of the Power Interlock Mode	TRBL 11-2870
11.1.37	Recovery Method of the Failures Occurred in Two Interfaces in DBW	TRBL 11-2910
11.1.38	The Recovery Method when the Copy-Back Operates Regardless of the Copy-Back-Less Setting if Power Saving/Power Saving Plus is Enabled and Performs the Drive Restoration	TRBL 11-2930
11.1.39	Recovery Method when the DIP-Switch Setting of the I/O Module (ENC) is Incorrect	TRBL 11-2950
11.1.40	Recovery Method when Flash Drives (FMD) are Blocked Due to Uncharged Batteries	TRBL 11-2970
11.1.41	Recovery Method when Multiple Flash Drives (FMD) in the Same Array Go Down due to the Uncharged Battery Status.....	TRBL 11-2980
11.1.42	Recovery Method when Incomplete Write was Registered in the DMLU, Replication DP Pool or Management Area DP Pool ..	TRBL 11-2990

Chapter 12. Procedure for Online ENC Firmware Download.....	TRBL 12-0000
12.1 Outline of Online ENC Firmware Download	TRBL 12-0000
12.2 Preconditions for Online ENC Firmware Download.....	TRBL 12-0010
12.3 Restriction of Online ENC Firmware Download	TRBL 12-0020
12.4 Time Required for Online ENC Firmware Download	TRBL 12-0030
12.5 Before Starting Online ENC Firmware Download	TRBL 12-0040
12.5.1 Hierarchy of ENC Firmware Storage Directories	TRBL 12-0050
12.6 Procedure for Online ENC Firmware Download	TRBL 12-0060
12.6.1 Flowchart	TRBL 12-0070
12.6.2 Connecting the PC Used for Maintenance	TRBL 12-0080
12.6.3 Online ENC Firmware Download.....	TRBL 12-0110
12.7 Procedure for Displaying ENC Firmware/Backup Controller Firmware Version Using Web	TRBL 12-0250
Chapter 13. Procedure for Offline ENC Firmware Download	TRBL 13-0000
13.1 Offline ENC Firmware Download Overview	TRBL 13-0000
13.2 Offline ENC Firmware Download Prerequisites	TRBL 13-0010
13.3 Restriction and Notes of Offline ENC Firmware Download.....	TRBL 13-0040
13.4 Offline ENC Firmware Download Time	TRBL 13-0050
13.5 Before Beginning an Offline ENC Firmware Download.....	TRBL 13-0070
13.5.1 Hierarchy of ENC Firmware Storage Directories	TRBL 13-0100
13.6 Offline ENC Firmware Download Procedure (Dual Controller)	TRBL 13-0110
13.6.1 Flowchart (General).....	TRBL 13-0120
13.6.2 Flowchart (Detailed)	TRBL 13-0140
13.6.3 Connecting the PC Used for Maintenance	TRBL 13-0150
13.6.4 Deleting Browser History Information	TRBL 13-0180
13.6.5 Downloading Offline ENC Firmware	TRBL 13-0200
13.7 Offline ENC Firmware Download Procedure (Single Controller)	TRBL 13-0310
13.7.1 Flowchart (General).....	TRBL 13-0320
13.7.2 Flowchart (Detailed)	TRBL 13-0340
13.7.3 Offline ENC Firmware Download Procedure Screen (Single Controller)	TRBL 13-0350
13.8 Offline ENC Firmware Download Web Display Screen	TRBL 13-0360
13.8.1 URLs.....	TRBL 13-0360
13.8.2 Web Screen Image	TRBL 13-0370
13.8.3 Side Frame and Top Frame Image Screen Details	TRBL 13-0380
13.8.4 Select Frame Image Screen Details	TRBL 13-0390
13.9 Procedure for Invalidating the Automatic ENC Firmware and Backup Controller Firmware Downloading Function	TRBL 13-0400

Chapter 14. Procedure for Replacing the Offline Drive Firmware.....	TRBL 14-0000
14.1 Overview of the Offline Drive Firmware Replacement Function	TRBL 14-0000
14.2 Prerequisites	TRBL 14-0020
14.3 Restrictions.....	TRBL 14-0040
14.4 Offline Drive Firmware Replacement Time	TRBL 14-0050
14.5 Before Replacing the Offline Drive Firmware.....	TRBL 14-0060
14.6 Procedure for Replacing the Offline Drive Firmware	TRBL 14-0080
14.6.1 Replacing Procedure	TRBL 14-0080
14.6.2 Procedure Screen.....	TRBL 14-0180
14.7 Web Screen of the Drive Firmware	TRBL 14-0250
14.7.1 URL.....	TRBL 14-0250
14.7.2 Web Screen Image.....	TRBL 14-0250
14.8 Method of Checking the Drive Firmware Revision.....	TRBL 14-0280
14.8.1 The Check Method by WEB Connection	TRBL 14-0280
14.8.2 The Check Method by Trace Analysis.....	TRBL 14-0300
14.8.3 The Procedure to Check the Drive Firmware Revision Using the Hitachi Storage Navigator Modular 2.....	TRBL 14-0310

[Message]

Chapter 1. Before Starting Trouble Analysis	MSG 01-0000
Chapter 2. CUDG Detected Messages.....	MSG 02-0000
Chapter 3. Failure Messages	MSG 03-0000
Chapter 4. Progress Messages	MSG 04-0000
Chapter 5. Flash Detected Messages	MSG 05-0000
Chapter 6. Warning Messages.....	MSG 06-0000
Chapter 7. Web Error Messages	MSG 07-0000
7.1 Web Error Messages (Uploading Function)	MSG 07-0000
7.2 Web Error Messages (Simple Trace).....	MSG 07-0110
7.3 Web Error Messages (Web Control Management)	MSG 07-0120
Chapter 8. Hitachi Storage Navigator Modular 2 Error Messages.....	MSG 08-0000
Chapter 9. Failure Analysis by Sense Data.....	MSG 09-0000
9.1 Details of Sense Code	MSG 09-0000
9.2 List of Detail Codes of Sense Code (5/9FFE)	MSG 09-0250
9.3 List of Detail Codes of Sense Code (5/9FFF)	MSG 09-1210
Chapter 10. Failure Factor Codes of the Modular Volume Migration.....	MSG 10-0000

[Replacement]

Chapter 1. Before Starting Maintenance Work	REP 01-0000
1.1 Before Starting Maintenance Work	REP 01-0000
1.1.1 Cautionary Notes	REP 01-0000
1.1.2 Procedure for Making Sure of Model Name and Drive Firmware of Drive	REP 01-0040
Chapter 2. Parts Replacement	REP 02-0000
2.1 Locations of Replacement Components	REP 02-0000
2.1.1 Parts Locations	REP 02-0030
2.2 Components Replacement	REP 02-0050
2.2.1 Replacing a Drive	REP 02-0050
2.2.2 Replacing a Cache Backup Battery	REP 02-0430
2.2.3 Replacing a Fan Module	REP 02-0520
2.2.4 Replacing a Power Unit	REP 02-0560
2.2.5 Replacing a Controller	REP 02-0700
2.2.6 Replacing a Cache Memory	REP 02-0920
2.2.7 Replacing a Host I/O Board/Module	REP 02-1100
2.2.8 Replacing a Host Connector	REP 02-1230
2.2.9 Replacing a Drive I/O Module	REP 02-1320
2.2.10 Replacing a Management Module	REP 02-1410
2.2.11 Replacing an I/O Module(ENC) or I/O Card(ENC)	REP 02-1500
2.2.12 Replacing a SAS(ENC) Cable	REP 02-1680
2.2.13 Replacing a Controller Box	REP 02-1840
2.2.14 Replacing a Drive Box	REP 02-1900
2.2.15 Replacing a Front Bezel	REP 02-1980
2.2.16 Replacing a Side Card	REP 02-2030
Chapter 3. Periodic Maintenance	REP 03-0000
3.1 Periodic Maintenance Items	REP 03-0000
3.2 Inspecting and Cleaning Rackmount Model with RK40 Rack Frame	REP 03-0010
3.2.1 Inspecting Fans	REP 03-0010
3.2.2 Cleaning	REP 03-0020
3.3 Replacing Periodical Replacement Parts	REP 03-0040
3.3.1 Replacing Battery	REP 03-0040
3.3.2 Replacing the Air Filter of the Front Bezel	REP 03-0050
Chapter 4. Maintenance Tools	REP 04-0000
4.1 Maintenance Tools for Hardware	REP 04-0000
4.2 Maintenance Tools for Software	REP 04-0010

Chapter 5. Recycling REP 05-0000

[Parts Catalog]

Chapter 1. Parts Catalog.....	PARTS 01-0000
1.1 How to Use This Parts Catalog	PARTS 01-0000
1.2 System of Parts Catalog.....	PARTS 01-0010
1.3 Parts Catalog	PARTS 01-0020

[WEB]

Chapter 1. Before Using Web	WEB 01-0000
1.1 The Operating Environment	WEB 01-0000
1.2 Notices on (Restriction of) the Support Browser.....	WEB 01-0010
1.3 The Characteristic of the Network Function	WEB 01-0020
1.4 Support Browser List	WEB 01-0060
Chapter 2. The Normal Mode Operation Procedure	WEB 02-0000
2.1 Transferring to the Normal Mode.....	WEB 02-0000
2.2 Screen Outline.....	WEB 02-0010
2.3 Main Screen of the Normal Mode	WEB 02-0030
2.4 Display of Exchangeable Parts Status (Parts Information).....	WEB 02-0070
2.5 Information Message.....	WEB 02-0150
2.6 Network Information	WEB 02-0160
2.7 Collecting Simple Trace.....	WEB 02-0170
2.8 Collecting CTL Alarm Trace	WEB 02-0210
2.9 Host Command Trace Download.....	WEB 02-0240
2.10 Dump Collection of Flash Drives (FMD).....	WEB 02-0280
2.10.1 Restrictions on Dump Collection of Flash Drives (FMD).....	WEB 02-0280
2.10.2 Procedure for Collecting the Dump of Flash Drives (FMD)	WEB 02-0280
Chapter 3. The Maintenance Mode Operation Procedure	WEB 03-0000
3.1 Transferring to the Maintenance Mode	WEB 03-0000
3.1.1 WEB Operation in the Maintenance Mode During the Cache Memory Access Failure	WEB 03-0050
3.2 Reference/Setting of the System Parameter and Initialize	WEB 03-0060
3.2.1 System	WEB 03-0070
3.2.2 Host Interface	WEB 03-0120
3.2.3 Network.....	WEB 03-0160
3.2.4 Name	WEB 03-0210

3.2.5 ALL	WEB 03-0250
3.3 Setup.....	WEB 03-0270
3.3.1 Microprogram	WEB 03-0270
3.4 Reference	WEB 03-0390
3.4.1 Information Message.....	WEB 03-0390
3.5 Trace/Dump	WEB 03-0400
3.5.1 Collecting Simple Trace.....	WEB 03-0400
3.5.2 Collecting CTL Alarm Trace	WEB 03-0440
3.5.3 Collecting Full Dump	WEB 03-0470
3.6 Other	WEB 03-0510
3.7 Return Method to the Normal Mode.....	WEB 03-0530

[REV]