Rev.0 / Sep.2010

REP00-00

Copyright © 2010, Hitachi, Ltd.

REPLACE SECTION

A SAFETY SUMMARY

Notes on the operation on the password inputting screen.

The password inputting screen is displayed on the SVP screen to arouse maintenance person's attention when the operation concerned can cause a serious failure such as a system down or a data loss.

- When the password inputting screen is displayed, be sure to observe the cautions given in the procedure concerned in the maintenance manual.
- When a confirmation by the technical support division is required in the maintenance manual, be sure to get it before executing the maintenance procedure concerned.
- Each PCB is operated by the microprogram owned by it individually.
 If the PCB is replaced in the procedure that makes the version of the microprogram disagree with that of the PCB, the subsystem cannot operate normally. Be sure to make the revisions consistent each other.

REP00-10

Copyright © 2010, 2013, Hitachi, Ltd.

Contents

REP01-10	1. Hot Replace
REP01-10	1.1 Hot Replace Flowchart
REP01-30	1.2 Concept of Drive Maintenance
REP01-110	1.3 Concept of Cache Maintenance
REP01-120	1.4 How to Interpret the Hot Replace Procedure
REP01-170	1.5 Parts Replacement Process Table
REP01-260	1.6 Availability of the online maintenance when TrueCopy for Mainframe/
	TrueCopy/HAM is used
REP01-280	1.7 Availability of the online maintenance when ShadowImage for Mainframe.
	ShadowImage is used
REP01-290	1.8 Availability of the online maintenance when XRC is used
REP01-300	1.9 Availability of the online maintenance when UR is used
REP01-320	1.10 About the storage media used for installation/maintenance process
REP02-01-10	2. PRE-PROCEDURE
REP02-01-10	[PRE-PROCEDURE A]
REP02-02-10	[PRE-PROCEDURE B]

Copyright © 2010, 2013, Hitachi, Ltd.

REP03-01-10	3. REPLACEMENT PROCESSING
REP03-01-10	[DRIVE REPLACEMENT PROCESSING - RDK1]
REP03-02-10	[DRIVE REPLACEMENT PROCESSING - RDK2]
REP03-03-10	[DRIVE REPLACEMENT PROCESSING - RDK3]
REP03-04-10	[DRIVE REPLACEMENT PROCESSING - RDK4]
REP03-05-10	[DRIVE REPLACEMENT PROCESSING - RDK5]
REP03-10-10	[CACHE REPLACEMENT PROCESSING - RCA1]
REP03-11-10	[MPB REPLACEMENT PROCESSING - RMP1]
REP03-12-10	[Fibre CHA REPLACEMENT PROCESSING - RCH1]
REP03-13-10	[Mainframe Fibre CHA REPLACEMENT PROCESSING - RCH2]
REP03-14-10	[DKA REPLACEMENT PROCESSING - RDA1]
REP03-15-10	[ESW REPLACEMENT PROCESSING - RES1]
REP03-16-10	[DKCPANEL REPLACEMENT PROCESSING - RTC1]
REP03-17-10	[SSVPMN REPLACEMENT PROCESSING - RTC2]
REP03-18-10	[DKCFAN(60sq) REPLACEMENT PROCESSING - RTC3]
REP03-19-10	[DKCFAN(80sq) REPLACEMENT PROCESSING - RTC4]
REP03-20-10	[SVP REPLACEMENT PROCESSING - RTC5]
REP03-21-10	[HUBBOX REPLACEMENT PROCESSING - RTC6]
REP03-22-10	[Battery REPLACEMENT PROCESSING - RTC7]
REP03-23-10	[DKCPS REPLACEMENT PROCESSING - RTC8]
REP03-24-10	[SFP REPLACEMENT PROCESSING - RTC9]
REP03-26-10	[2.5 inch SSW REPLACEMENT PROCESSING - RU21]
REP03-27-10	[3.5 inch SSW REPLACEMENT PROCESSING - RU31]
REP03-28-10	[2.5 inch HDDPWR REPLACEMENT PROCESSING - RU22]
REP03-29-10	[3.5 inch HDDPWR REPLACEMENT PROCESSING - RU32]
REP03-30-10	[2.5 inch DKUPS REPLACEMENT PROCESSING - RU23]
REP03-31-10	[3.5 inch DKUPS REPLACEMENT PROCESSING - RU33]
REP03-32-10	[2.5 inch HDDFAN REPLACEMENT PROCESSING - RU24]
REP03-33-10	[3.5 inch HDDFAN REPLACEMENT PROCESSING - RU34]
REP03-34-10	[PDU REPLACEMENT PROCESSING]
REP03-35-10	[FCoE CHA REPLACEMENT PROCESSING - RCH3]
REP03-36-10	[SSD REPLACEMENT PROCESSING - RSS1]
REP03-37-10	[FBX SSW REPLACEMENT PROCESSING - RUF1]
REP03-38-10	[FBX DKUPS REPLACEMENT PROCESSING - RUF3]
REP03-39-10	[Fibre CHA Dummy REPLACEMENT PROCESSING - RCD1]
REP04-01-10	4. POST-PROCEDURE
REP04-01-10	[POST-PROCEDURE]


Rev.0 / Sep.2010

REP01-10

Copyright © 2010, Hitachi, Ltd.

1. Hot Replace

1.1 Hot Replace Flowchart



*1: When there are some parts to exchange and the HDDFAN (FAN Assembly) is contained in the parts, the HDDFAN must be exchanged first.

Rev.1 / Sep.2010, Oct.2012

REP01-20

Copyright © 2010, 2012, Hitachi, Ltd.

Note:

SVP pre-procedure: An SVP (PC) process of issuing a maintenance block instruction after

checking the status of the parts to be replaced so that the live parts can

be removed and replaced.

Hardware procedure: A process of removing a parts to be replaced (shut down LED on) and

installing a maintenance package.

Be sure to wear your wrist strap, and attach to ground, prior to

performing the following work.

This will insure that the IC and LSI on the PCB, are protected from

static electricity.


SVP post-procedure: An SVP (PC) process of making functional checks (CUDG and

INLINE) on the replacement package and building it into the

subsystem.

1.2 Concept of Drive Maintenance

[Spare drive present]




[Spare drive present]

[Case 2] A case where the one drive is blocked


When a spare drive exists, a correction copy from the blocked drive is started automatically. In this case, go to Case 2.1 when the blocked drive is to be replaced during the correction copy from it and a copy back that follows is to be made automatically, or go to Case 2.2 when the blocked drive is to be replaced after the correction copy is completed.


[Case 2.1] A case where the one drive is blocked and it is replaced during an automatic correction copy is made from it



Lege	Parity group	Normal drive W Warning error drive B Error-blocked drive	Spare drive Spare drive (data saved) N New drive (maintenance part)	R5 : RAID5 R1 : RAID1 R6 : RAID6
		(B()Error-blocked drive	New drive (maintenance part)	(Note)

[Spare drive present]







[Legends]

| Normal drive | Normal drive | New drive (maintenance part) | R5 : RAID5 | R1 : RAID1 | R6 : RAID6 | R6 : RAID6 |
| B | Error-blocked drive | (Note)

[Case in which a secondary error occurred during error]





Note: In the RAID system, two drives form a mirroring pair and the two mirroring pairs (four drives) compose the RAID. In the above diagram, only the two mirroring pairs are shown.

SD Spare drive (data saved)

New drive (maintenance part)

Warning error drive

(B) Error-blocked drive

(SB) Error-block drive (spare drive)


Parity group

R1 : RAID1

R6: RAID6

(Note)






[Case 10] A case where the copy destination drive is blocked during the automatic correction copy (and a unused spare drive exists)

When the blocked drive has been replaced through performance of the operation for Case 2.1, go to Case 10.1 or otherwise, go to Case 10.2.

[Case 10.1] When the blocked drive has been replaced through performance of the operation for Case 2.1


Condition item	Procedure					
	SVP Pre-procedure					
	Starting collection copy automatically Maintenance block					
Destination blocked during automatic correction copy (unused spare present)	R5,R6 N N N N N N N N N N N N N N N N N N N	2 R5.R6 R1 N GE	3 RS,R6 R1 R1 Perform [case 15] after recovery.			

[Case 10.2] When the operation for Case 2.1 has not been performed




g 13			
[Legends] Parity group	Normal drive B Error-blocked drive	S Spare drive N New drive (maintenance part)	R5 : RAID5 R1 : RAID1 R6 : RAID6
	SB Error-block drive (spare SD Spare drive (data saved)	drive)	(Note)

[Case in which a secondary error occurred during error recovery]



[Spare drive present]



[Spare drive present]

[Case 13] RAID6 When two drives are blocked


- When you replace the two blocked drives while making an automatic correction copy from them, go to Case 13.1.
- When you replace the two blocked drives after making an automatic correction copy from them, go to Case 13.2.
- When you replace one of the two blocked drives from each of which an automatic correction copy is being made, go to Case 13.3.

[Case 13.1] RAID6 A case where the two drives is blocked and it is replaced while an automatic correction copy is made from it


made non it							
Conditio	on item	Condi-	Procedure				
		tion	SVP Pre	-procedure	Hardware-procedure		
			Detachment of the two drives	Maintenance block	Replacement of the first drive		
Threshold value exceeded	Warning Block	- 0	Automatic correction copy (allowed to be made up to twice)	2 A blocked drive is replaced during an automatic correction copy. Maintenance block	A blocked drive is replaced during an automatic correction copy.		
Other case (secondary measure)		ure)	Block destination (a) Unused spare present (case 10) (b) Unused spare absent (case 11)	Note: When the blocked drive is replaced while an automatic correction copy is being made from it, the copy-back written in Item [5] is started automatically. When you replace the drive after the automatic correction copy is completed, refer to Case 13.2.	(S) (S)		
				Procedure			
				SVP Post-procedure			
			INLINE test of the first drive	Copy back to the first drive	Recovery		
			4 INLINE R6 NN S S S	The copy-back is started automatically after the correction copy is completed.	6 R6 DDD SSS		
			① Block new drive (case 8)	Block source drive (case 9)Block destination (case 8)			

[Lege	Parity group	Normal drive W Warning error drive B Error-blocked drive	S Spare drive SD Spare drive (data saved) New drive (maintenance part)	R6: RAID6
		(B) Error-blocked drive	New drive (maintenance part))

[Spare drive present]



[Spare drive present]



New drive (maintenance part)

(B) Error-blocked drive

[Spare drive present]

[Case 14] RAID6 When a drive is blocked and another drive exceeds the warning threshold value


- When replacing a blocked drive while an automatic correction copy is being made from it, go to Case 14.1.
- When replacing a blocked drive after the automatic correction copy from it is completed, go to Case 14.2.

[Case 14.1] When replacing a blocked drive while an automatic correction copy is being made from it

[Case 14.1] W	men i	hen replacing a blocked drive while an automatic correction copy is being made from it					
Condition item	Condi-		·				
	tion	SVP Pre-	-procedure	Hardware-procedure			
		Detachment of the two drives	Maintenance block	Replacement of the first drive			
Threshold value exceeded Block	0	Automatic correction copy + Automatic saving to the spare disk	2 Maintenance block A blocked drive is replaced during an automatic correction copy.	3 BI R6 NWD			
Other case (secondary meas	ure)	Block destination (a) Unused spare present (case 10) (b) Unused spare absent (case 11)	Note: When an automatic saving to a spare drive is completed before this operation is performed, the following Items [6] and [7] may be executed in advance.				
			Procedure				
		SVP Post	t-procedure	Hardware-procedure			
		INLINE test of the first drive	Copy back to the first drive	Replacement of the second drive during the copy back to the first drive			
		R6 NWD	A blocked drive is replaced during an automatic correction copy.	R6 NN			
		① Block new drive (case 8)	Block source drive (case 9)Block destination (case 8)				
			Procedure				
			SVP Post-procedure				
		INLINE test of the second drive	Copy back to the second drive	Recovery			
		7 INLINE R6 NN SDSD	8 R6 NN	9 R6 DDD SSS			
		① Block new drive (case 8)	Block source drive (case 9)Block destination (case 8)				


[Lege	Parity group	Normal drive W Warning error drive B Error-blocked drive	S Spare drive SD Spare drive (data saved) N New drive (maintenance part)	R6: RAID6
		<u> </u>	.	

[Spare drive present]




[Legends]				
[Legenus]	f	9	O	R6: RAID6
	(Normal drive	S Spare drive	
Domitru om	\ f	Warning error drive	SD Spare drive (data saved)	
(Parity gr	յաթ / Մ	warning error drive	SD Spare drive (data saved)	
	(i	B () Error-blocked drive	New drive (maintenance par	+)
	٠	D D Error blocked drive	IV Ivew drive (maintenance par	.)






[Other Cases]



Rev.0 / Sep.2010

REP01-110

1.3 Concept of Cache Maintenance



Copyright © 2010, Hitachi, Ltd.

Rev.0 / Sep.2010

REP01-120

1.4 How to Interpret the Hot Replace Procedure

[In case of replacement when SIM was reported]

- ① Search a work ID which coincides with the work ID corresponding to SIM ACC (FPC) (refer to FPC list on page ACC04-10) from Parts Replacement Process Table on page REP01-170. Search a work ID corresponding to the pertinent condition if "Condition Item" is described in Parts Replacement Process Table.
- ② If the work ID is found,
 - Take actions according to the SVP pre-procedure, hardware procedure, SVP post-procedure number that match the work ID.

If no work ID is found,

- Search a work ID corresponding to SIM ACC (FPC, and error details) from Parts Replacement Process Table on page REP01-170.
- Take actions according to the SVP pre-procedure, hardware procedure, SVP post-procedure number that match the work ID.

Note: See page REP01-150 for the procedure for searching a work ID to replace a drive. When replacing a drive, be sure to see page REP01-130 and REP01-140.

[In case of replacement when SIM was not reported]

- ① Search a work ID corresponding to the part to be replaced from Parts Replacement Process Table on page REP01-170.
- ② Take actions according to the SVP pre-procedure, hardware procedure, SVP post-procedure number that match the work ID.

Note: See page REP01-150 for the procedure for searching the work ID to replace a drive. When replacing a drive, be sure to see page REP01-130 and REP01-140.

Condition to replace

SIM was reported

Work ID corresponding to SIM ACC FPC is RCA1

* Search an applicable Work ID identified by shaded area in the following sample of Parts Replacement Process Table under the above conditions.

<Cache Memory>

Work ID	Part Name	Procedure			Replacing
		Pre-procedure	Replacement processing	Post-procedure	Time (*1)(*2)
RCA1	Cache Memory Module(*3) SSD	(REP02-02-10) (*3: PRE-PROCEDURE	CACHE REPLACEMENT PROCESSING - RCA1 (REP03-10-10)	POST-PROCEDURE (REP04-01-10)	20 min

Copyright © 2010, Hitachi, Ltd.

PROCEDURE BEFORE PDEV EXCHANGE AND CORRECTION COPY


Instructions before blocking and exchanging PDEV with a drive failure error is listed below: When exchanging unblocked PDEV, redundancy in the ECC group is lost. Therefore, during PDEV exchange, the other PDEV in the same ECC group is fenced by a drive failure error, all the LDEV in the ECC group is fenced. Accordingly, to prevent the above problem from occurring, the status of PDEV. When there is a PDEV in the same ECC group having more drive failure errors than the exchanging PDEV exists, replace the PDEV with highest drive failure errors.

Table 1.4-1 Before PDEV exchange, following items are checked.

#	Items checked	Procedure
1	Error Count	"Threshold Counter Display" (See SVP02-580)
2	ORM Over Rate	"ORM Over Rate HDD# Display" (See SVP02-390)
3	Write Error	"Pinned Track Display" (See SVP02-1130)
4	PDEV Erase	Confirm that Start Drive Erase SIM (*1) is not logged. If Start Drive Erase SIM (*1) is logged, wait until End Drive Erase SIM (*1) (*2) is logged. If Drive Replace is executed before End Drive Erase SIM (*1) is logged, Drive Erase may be abnormal end and Abnormal End Drive Erase SIM (*1) is logged. In that case, the drive can not be reused, and can not be ensured that the drive erase is completed.


*1: Start Drive Erase SIM = 0x4C1xyy
End Drive Erase SIM = 0x4C2xyy
Abnormal end Drive Erase SIM = 0x4C3xyy

A detail of "xyy" in each SIM indicates CDEV#/RDEV#. See the table below.




*2: Confirm that CDEV#/RDEV# of End Drive Erase SIM (*1) corresponds to CDEV#/RDEV# of Start Drive Erase SIM (*1).

PROCEDURE BEFORE PDEV EXCHANGE AND CORRECTION COPY



How to search a Work ID to replace a drive



Rev.0 / Sep.2010

REP01-160

Copyright © 2010, Hitachi, Ltd.

-----<<Example>>-----

- SIM was reported.
- Level of the SIM is not "Serious". = Condition Item[Condition] is "Warning SIM".
- There is the SIM that RC is 4510 in the drive. = Condition Item[Configuration] is "Unused spare drive exists".
- The drive to be replaced is not a spare drive. = "Data Drive"
- * Under the above conditions, the shaded area is searched from Parts Replacement Process Table. Therefore, in this example Work ID should be RDK1.

<Data Drive, Spare Drive>

Work	Parts	(Cond	lition	Item		Procedure		R	eference information	on
ID	Name	Co	nditi	on	Config-	Pre-procedure	Replacement	Post-procedure	Replacing	Outline	Case
					uration		processing		time		
		Fai	lure	Pre	Unus drive						
		Warning SIM	Block SIM	ventive	Unused Spare drive						
RDK1	Data Drive	×	×	_	Yes	PRE- PROCEDURE A (REP02-01-10)	DRIVE REPLACEME NT PROCESSING - RDK1 (REP03-01-10)	POST- PROCEDURE (REP04-01-10)	20 min	Drive replace ~ Copy back	Case 1 Case 2

Rev.0 / Sep.2010

REP01-170

1.5 Parts Replacement Process Table

Note: If any other message that is not explained below is displayed, see the SVP Message Section (SVPMSG00-00).

<Data Drive, Spare Drive>

Work	Parts		Conc	lition	Item		Procedure		R	eference informatio	n
ID	Name	Co	ondit	ion	Config- uration	Pre- procedure	Replacement processing	Post- procedure	Replacing time	Outline	Case *1
		Fai Warning SIM	lure Block SIM	Preventive	Unused Spare drive				*2 *8 *9		
RDK1	Data Drive *3	×	×		Yes	PRE- PROCEDURE A (REP02-01-10)	DRIVE REPLACEMENT PROCESSING - RDK1 (REP03-01-10)	POST- PROCEDURE (REP04-01-10)	20 min	Drive replace ~ Copy back	Case 1 Case 2
RDK2	Data Drive *3			×	Yes	PRE- PROCEDURE A (REP02-01-10)	DRIVE REPLACEMENT PROCESSING - RDK2 (REP03-02-10)	POST- PROCEDURE (REP04-01-10)		Copy to Spare drive ~ Drive replace ~ Copy back	Case 17
RDK3	Data Drive *3, *6	×	×	×	No	PRE- PROCEDURE A (REP02-01-10)	DRIVE REPLACEMENT PROCESSING - RDK3 (REP03-03-10)	POST- PROCEDURE (REP04-01-10)	20 min	Drive replace ~ Correction copy	Case 3 Case 4 Case 18
RDK4 *4, *5	Data Drive *3	*4				PRE- PROCEDURE A (REP02-01-10)	DRIVE REPLACEMENT PROCESSING - RDK4 (REP03-04-10)	POST- PROCEDURE (REP04-01-10)		LDEV formatting after replacing all the HDDs blocked in a parity group *5	Case 16
RDK5	Spare Drive *3					PRE- PROCEDURE A (REP02-01-10)	DRIVE REPLACEMENT PROCESSING - RDK5 (REP03-05-10)	POST- PROCEDURE (REP04-01-10)	20 min	Spare drive replace	Case 15

Copyright © 2010, Hitachi, Ltd.

REP01-180

- *1: Refer to REP01-20
- *2: This time does not include copy back time of data in HDD. Refer to *8 for the HDD copy time.
- *3: Parts Name indicates attribute of a drive.

 Data Drive: The drive is installed in the position for a drive except spare drive (Data Drive).
 - Spare Drive: The drive is installed in the position for a spare drive.
- *4: RDK4 is a Work ID for a work which is applicable to a case that two or more drives in a same parity group are blocked. As to RAID 6, when three or more drives are blocked. When the procedures instructed by RDK7 are executed, data will be lost. Ask the technical support division about the appropriateness of the operation. When you want to restore LDEV status for the purpose of data backup, please go to TRBL05-360.
- *5: Confirm the parity group and the LDEV No. corresponding to the HDD through the SVP STATUS. See page SVP03-220 for the procedure for referring to SVP STATUS
- *6: See "PROCEDURE BEFORE PDEV EXCHANGE AND CORRECTION COPY" (REP01-130).
- *7: In case of RAID6, when two HDDs were blocked in the parity group, you can start the replacement from either of two HDDs.

Note: If a Work ID cannot be found or if multiple drive error is occurring, see page TRBL05-160 on TROUBLE SHOOTING section. Rev.9 / Nov.2013, Feb.2014

- *8: HDD copy time
- (1) No I/O, Other than OPEN-V Copy Mode = Interleave Medium
- When the micro version is lower than 70-03-0x-xx/xx.

HDD type	Copy type	RAID1 (2D+2D)	RAID5 (3D+1P)	RAID5 (7D+1P)	RAID6 (6D+2P)
K146	Drive copy	1h00m	←	←	←
(15Krpm)	Correction copy	↑	2h00m	2h20m	2h30m
J600	Drive copy	3h20m	←	←	←
(10Krpm)	Correction copy	↑	9h20m	14h40m	16h40m
J300	Drive copy	1h40m	←	←	←
(10Krpm)	Correction copy	↑	3h40m	5h30m	6h20m
H2R0	Drive copy	11h10m	←	←	←
(7.2Krpm)	Correction copy	↑	28h30m	37h00m	38h00m
H1R0	Drive copy	6h30m	←	←	←
(7.2Krpm)	Correction copy	↑	13h20m	21h10m	24h00m
H500	Drive copy	3h40m	←	←	←
(7.2Krpm)	Correction copy	↑	8h50m	14h00m	15h50m
H2R0AT	Drive copy	29h00m	←	←	←
(SATA-W/V)	Correction copy	↑	30h20m	33h40m	38h50m
S400	Drive copy	2h00m	←	←	←
(SSD)	Correction copy	<u></u>	3h00m	4h10m	4h30m
S200	Drive copy	1h00m	←	←	←
(SSD)	Correction copy	↑	1h30m	2h10m	2h30m

• When the micro version is 70-03-0x-xx/xx or later.

HDD type	Drive copy	Correction copy (Other than 14D+2P)	Correction copy (14D+2P)
K300 (15Krpm)	1h20m	←	←
K146 (15Krpm)	1h00m	←	←
J1R2 (10Krpm)	4h00m	←	5h30m
J900 (10Krpm)	3h30m	←	5h00m
J600 (10Krpm)	3h20m	←	4h40m
J300 (10Krpm)	1h40m	←	2h20m
H4R0 (7.2Krpm)	14h10m	←	24h00m
H3R0 (7.2Krpm)	13h30m	←	17h40m
H2R0 (7.2Krpm)	11h10m	←	←
H1R0 (7.2Krpm)	6h30m	←	←
H500 (7.2Krpm)	3h40m	←	←
H2R0AT (SATA-E)	14h50m	←	22h40m
H2R0AT (SATA-W/V)	29h00m	←	50h40m
M800 (SSD)	3h20m	←	4h00m
S400/M400 (SSD)	2h00m	←	2h20m
S200/M200 (SSD)	1h00m	←	1h20m
P1R6 (FMD)	7h50m	←	11h10m
P3R2 (FMD)	15h40m	←	22h20m

(2) No I/O, OPEN-V Copy Mode = Interleave Medium

• When the micro version is lower than 70-03-0x-xx/xx.

HDD type	Copy type	RAID1 (2D+2D)	RAID5 (3D+1P)	RAID5 (7D+1P)	RAID6 (6D+2P)
K146	Drive copy	1h00m	←	←	←
(15Krpm)	Correction copy	↑	1h50m	2h00m	2h00m
J600	Drive copy	2h50m	←	←	←
(10Krpm)	Correction copy	↑	5h40m	7h40m	7h50m
J300	Drive copy	1h30m	←	←	←
(10Krpm)	Correction copy	↑	2h20m	3h00m	3h20m
H2R0	Drive copy	11h00m	←	←	←
(7.2Krpm)	Correction copy	↑	17h30m	22h30m	24h30m
H1R0	Drive copy	5h30m	←	←	←
(7.2Krpm)	Correction copy	↑	8h40m	11h10m	12h10m
H500	Drive copy	3h10m	←	←	←
(7.2Krpm)	Correction copy	↑	5h40m	7h20m	8h00m
H2R0AT	Drive copy	27h40m	←	←	←
(SATA-W/V)	Correction copy	↑	28h50m	31h50m	36h50m
S400	Drive copy	1h50m	←	←	←
(SSD)	Correction copy	1	3h10m	4h10m	4h30m
S200	Drive copy	50m	←	←	←
(SSD)	Correction copy	↑	1h40m	2h10m	2h30m

• When the micro version is 70-03-0x-xx/xx or later.

HDD type	Drive copy	Correction copy (Other than 14D+2P)	Correction copy (14D+2P)
K300 (15Krpm)	1h20m	←	1h40m
K146 (15Krpm)	1h00m	←	←
J1R2 (10Krpm)	3h50m	←	6h50m
J900 (10Krpm)	3h20m	←	5h10m
J600 (10Krpm)	2h50m	←	4h35m
J300 (10Krpm)	1h30m	←	2h10m
H4R0 (7.2Krpm)	13h50m	←	23h50m
H3R0 (7.2Krpm)	13h20m	←	17h00m
H2R0 (7.2Krpm)	11h00m	←	←
H1R0 (7.2Krpm)	5h30m	←	←
H500 (7.2Krpm)	3h10m	←	←
H2R0AT (SATA-E)	11h30m	←	←
H2R0AT (SATA-W/V)	27h40m	←	48h00m
M800 (SSD)	2h50m	←	5h00m
S400/M400 (SSD)	1h50m	←	2h10m
S200/M200 (SSD)	50m	←	1h10m
P1R6 (FMD)	5h40m	←	11h20m
P3R2 (FMD)	11h20m	←	22h40m

• When CVS is used, the copy time is proportional to the amount of LDEV assigned in the parity group.

(Eg: If the amount of LDEV assigned is 50%, the copy time is half the above-mentioned values.)

- When the parity group is used for HTI/HDP/HDT-POOL, depending on the POOL used amount, the copy time becomes shorter than the above-mentioned values.
- When the copy is executed while executing the Quick Format, the copy might be completed earlier than the above-mentioned values because the area under the format is not copied.
- Copy time may become about 30% slower compared with the value in the table by machine configuration.
- The described copy time is a standard. The real format time may be different by RAID GROUP, an emulation type the generation and a drive type.
- *9: The drive copy to the spare drive of the RAID1 is copied from the drive (normal drive) of the pair of which the failure occurred.

(Because there is a case where a failure occurs in the copy source drive and the copy time is delayed in the usual form that performs copying from the drive of which the failure occurred.)

However, the copy back (copy from the spare drive to the data drive) is copied from the spare drive as usual.

Rev.1 / Sep.2010, Mar.2011

REP01-220

Copyright © 2010, 2011, Hitachi, Ltd.

<Cache Memory>

Work ID	Part Name		Replacing		
		Pre-procedure	Replacement processing	Post-procedure	Time (*1)(*2)
RCA1	Cache Memory PCB Cache Memory Module	PRE-PROCEDURE A (REP02-01-10)	CACHE REPLACEMENT PROCESSING - RCA1 (REP03-10-10)	POST-PROCEDURE (REP04-01-10)	20 min
RSS1	SSD	PRE-PROCEDURE A (REP02-01-10)	SSD REPLACEMENT PROCESSING - RSS1 (REP03-36-10)	POST-PROCEDURE (REP04-01-10)	20 min

^{*1:} The destaging operation takes 30 minutes to 2 hours (SVP time out).

Note: When a cache PCB is replaced for preventive reasons, one side of cache is blocked. As a result, the subsystem performance may degrade.

^{*2:} The time for the dump is not included.

<CHA, DKA, SSW, and ESW>

Work ID	Part Name		Procedure				
		Pre-procedure	Replacement processing	Post-procedure	Time (*2)		
RMP1	МРВ	PRE-PROCEDURE A (REP02-01-10)	MPB REPLACEMENT PROCESSING - RMP1 (REP03-11-10)	POST-PROCEDURE (REP04-01-10)	20 min		
RCH1	Fibre-T CHA	PRE-PROCEDURE A (REP02-01-10)	Fibre CHA REPLACEMENT PROCESSING - RCH1 (REP03-12-10)	POST-PROCEDURE (REP04-01-10)	20 min		
RCH2	Mainframe Fibre CHA	PRE-PROCEDURE A (REP02-01-10)	Mainframe Fibre CHA REPLACEMENT PROCESSING - RCH2 (REP03-13-10)	POST-PROCEDURE (REP04-01-10)	20 min		
RCH3	FCoE CHA	PRE-PROCEDURE A (REP02-01-10)	FCoE CHA REPLACEMENT PROCESSING - RCH3 (REP03-35-10)	POST-PROCEDURE (REP04-01-10)	20 min		
RDA1	DKA	PRE-PROCEDURE A (REP02-01-10)	DKA REPLACEMENT PROCESSING - RDA1 (REP03-14-10)	POST-PROCEDURE (REP04-01-10)	20 min		
RES1	ESW	PRE-PROCEDURE A (REP02-01-10)	ESW REPLACEMENT PROCESSING - RES1 (REP03-15-10)	POST-PROCEDURE (REP04-01-10)	13 min		
RCD1	Fibre-T CHA	PRE-PROCEDURE A (REP02-01-10)	Fibre CHA Dummy REPLACEMENT PROCESSING - RCD1 (REP03-39-10)	POST-PROCEDURE (REP04-01-10)	20 min		

^{*2:} The time for the dump is not included.

Note: Replacing a MPB may affect I/O when there is much write pending data in cache. We recommend to replace a MPB when all the cache write pending rate per CLPR in a MPB is less than 40%.

If a failure occurs in replacing a channel adaptor or a disk adaptor, see "5.3 Error Recovery Procedure during CHA/DKA replacement" (TRBL05-70).

<Other Parts of DKC>

Work ID	Part Name	Procedure					
		Pre-procedure	Replacement processing	Post-procedure	Time		
RTC1	DKCPANEL	PRE-PROCEDURE A (REP02-01-10)	DKCPANEL REPLACEMENT PROCESSING - RTC1 (REP03-16-10)	POST-PROCEDURE (REP04-01-10)	16 min		
RTC2	SSVPMN	PRE-PROCEDURE A (REP02-01-10)	SSVPMN REPLACEMENT PROCESSING - RTC2 (REP03-17-10)	POST-PROCEDURE (REP04-01-10)	22 min		
RTC3	FAN(60sp) Assembly	PRE-PROCEDURE A (REP02-01-10)	DKCFAN(60sq) REPLACEMENT PROCESSING - RTC3 (REP03-18-10)	POST-PROCEDURE (REP04-01-10)	8 min		
RTC4	FAN(80sp) Assembly	PRE-PROCEDURE A (REP02-01-10)	DKCFAN(80sq) REPLACEMENT PROCESSING - RTC4 (REP03-19-10)	POST-PROCEDURE (REP04-01-10)	8 min		
RTC5	SVP Unit	PRE-PROCEDURE A (REP02-01-10) (*1)	SVP REPLACEMENT PROCESSING - RTC5 (REP03-20-10)	POST-PROCEDURE (REP04-01-10)	40 min(*2) 85 min(*3)		
RTC6	HUBBOX	PRE-PROCEDURE A (REP02-01-10)	HUBBOX REPLACEMENT PROCESSING - RTC6 (REP03-21-10)	POST-PROCEDURE (REP04-01-10)	40 min		
RTC7	Battery	PRE-PROCEDURE A (REP02-01-10)	Battery REPLACEMENT PROCESSING - RTC7 (REP03-22-10)	POST-PROCEDURE (REP04-01-10)	11 min		
RTC8	DKCPS	PRE-PROCEDURE A (REP02-01-10)	DKCPS REPLACEMENT PROCESSING - RTC8 (REP03-23-10)	POST-PROCEDURE (REP04-01-10)	11 min		
RTC9	Fibre SFP Transceiver	PRE-PROCEDURE A (REP02-01-10)	SFP REPLACEMENT PROCESSING - RTC9 (REP03-24-10)	POST-PROCEDURE (REP04-01-10)	5 min		
_	PDU	_	PDU REPLACEMENT PROCESSING (REP03-34-10)	POST-PROCEDURE (REP04-01-10)	30 min		

- *1: When SVP is not able to operate, start from "2. HARDWARE REPLACEMENT PROCESSING" in "SVP REPLACEMENT PROCESSING RTC5". (When SVP High Reliability Kit is not installed.)
- *2: Replace time when SVP High Reliability Kit is not installed or when SVP High Reliability Kit is installed and target is Standby SVP.
- *3: Replace time when SVP High Reliability Kit is installed and target is Master SVP.

<Other Parts of DKU>

Work ID	Part Name		Procedure		Replacing
		Pre-procedure	Replacement processing	Post-procedure	Time
RU21	SSW	PRE-PROCEDURE A (REP02-01-10)	2.5 inch SSW REPLACEMENT PROCESSING - RU21 (REP03-26-10)	POST-PROCEDURE (REP04-01-10)	10 min
RU31	SSW	PRE-PROCEDURE A (REP02-01-10)	3.5 inch SSW REPLACEMENT PROCESSING - RU31 (REP03-27-10)	POST-PROCEDURE (REP04-01-10)	10 min
RU22	HDDPWR	PRE-PROCEDURE A (REP02-01-10)	2.5 inch HDDPWR REPLACEMENT PROCESSING - RU22 (REP03-28-10)	POST-PROCEDURE (REP04-01-10)	10 min
RU32	HDDPWR	PRE-PROCEDURE A (REP02-01-10)	3.5 inch HDDPWR REPLACEMENT PROCESSING - RU32 (REP03-29-10)	POST-PROCEDURE (REP04-01-10)	10 min
RU23	DKUPS	PRE-PROCEDURE A (REP02-01-10)	2.5 inch DKUPS REPLACEMENT PROCESSING - RU23 (REP03-30-10)	POST-PROCEDURE (REP04-01-10)	10 min
RU33	DKUPS	PRE-PROCEDURE A (REP02-01-10)	3.5 inch DKUPS REPLACEMENT PROCESSING - RU33 (REP03-31-10)	POST-PROCEDURE (REP04-01-10)	10 min
RU24	FAN Assembly (*1)	PRE-PROCEDURE A (REP02-01-10)	2.5 inch HDDFAN REPLACEMENT PROCESSING - RU24 (REP03-32-10)	POST-PROCEDURE (REP04-01-10)	10 min
RU34	FAN Assembly (*1)	PRE-PROCEDURE A (REP02-01-10)	3.5 inch HDDFAN REPLACEMENT PROCESSING - RU34 (REP03-33-10)	POST-PROCEDURE (REP04-01-10)	10 min
RUF1	SSW	PRE-PROCEDURE A (REP02-01-10)	FBX SSW REPLACEMENT PROCESSING - RUF1 (REP03-37-10)	POST-PROCEDURE (REP04-01-10)	10 min
RUF3	DKUPS	PRE-PROCEDURE A (REP02-01-10)	FBX DKUPS REPLACEMENT PROCESSING - RUF3 (REP03-38-10)	POST-PROCEDURE (REP04-01-10)	10 min

^{*1:} When there are some parts to exchange and the HDDFAN (FAN Assembly) is contained in the parts, the HDDFAN must be exchanged first.

1.6 Availability of the online maintenance when TrueCopy for Mainframe/TrueCopy/HAM is used

Component	Maintenance Type	Condition	TC-MF path	established	During in	nitial copy		mpleting I copy
			MCU	RCU	MCU	RCU	MCU	RCU
Logical	Blockade	_	×	×	SVP2031W (*2)	SVP2034W (*2)	SVP2031W (*2)	SVP2034W (*2)
Device	Recovery	_	×	×	SVP2031W (*2)	SVP2034W (*2)	SVP2031W (*2)	SVP2034W (*2)
	Format	_	×	×	SVP2031W (*2)	SVP2034W (*2)	SVP2031W (*2)	SVP2034W (*2)
	Verify	_	×	×	×	×	×	×
HDD canister	Replace	_	×	×	×	×	×	×
CACHE	Replace	_	×	×	SVP2059W	SVP2079W	×(*1)	×(*1)
СНА	Replace	With Alternate path.	×	×	×	SVP2038W	×	SVP2038W
		Without Alternate path.	×	×	SVP2073W	SVP2038W	SVP2074W	SVP2038W
DKA	Replace	_	×	×	×	×	×	×
DKC	Replace	With Alternate path.	×	×	SVP2059W	SVP2079W		SVP2038W
		Without Alternate path.	×	×	SVP2059W	SVP2079W	SVP2074W	SVP2038W
MP	Replace	_	×	×	×	×	×	×

Component	Maintenance	Condition	Suspend		
	Type		MCU	RCU	
Logical	Blockade		SVP2031W (*2)	SVP2034W (*2)	
Device	Recovery		SVP2031W (*2)	SVP2034W (*2)	
	Format		SVP2031W (*2)	SVP2034W (*2)	
	Verify	_	×	×	
HDD canister	Replace		×	×	
Cache or SM	Replace		×	×	
CHE or CHF	Replace	With Alternate path.	×	SVP2038W	
		Without Alternate path.	×	SVP2038W	
DKA	Replace		×	×	
DKC	Replace	With Alternate path.	×	SVP2038W	
		Without Alternate path.	×	SVP2038W	
MP	Replace	_	×	×	

×: Maintenance is available.

 $\ensuremath{\mathsf{SVPXXXXW}}$: Maintenance is not available based on the specification.

Refer to SVP MESSAGE SECTION.

Rev.0 / Sep.2010

REP01-270

Note: About replacement of CHE in the RCU side.

If the CHE that will be replaced is connected to a path, from MCU please confirm that the Path is deleted from MCU.

After replacement, please add the Path.

The pair can be suspended if the ESTPAIR or paircreate (pairresync) command is issued during the HDD Canister or the Cache PCB replacement. Please ask your customer before the online maintenance operation.

*1: In the case of distinct UR pairs, it is recommended to execute the maintenance activity involving cache blockade at primary / secondary sites of Sync Pairs, keeping the write-pending data volumes at below 20%.

Also, if the maintenance activity is carried out at the aforesaid sites, maintenance activity consumes time, further there is a possibility of MIH occurrence etc., to the extent of affecting the processing on the host.

Note the following when performing a maintenance operation in an environment where TPC-R, which is disaster recovery software of IBM, is used.

*2: If you need to delete a pair used by TrueCopy for Mainframe when performing a maintenance operation, delete the TrueCopy for Mainframe pair by using Web Console.

After the maintenance operation is completed, you can restore the status of the TrueCopy for Mainframe pair by performing operations using TPC-R.

Copyright © 2010, Hitachi, Ltd.

1.7 Availability of the online maintenance when ShadowImage for Mainframe/ ShadowImage is used

Component	Maintenance Type	Cond- ition	Reserve- Volume	Pending/Resync/ SP-PEND		Duplex		Split		Suspend	
				S-VOL/ P-VOL	T-VOL/ S-VOL	S-VOL/ P-VOL	T-VOL/ S-VOL	S-VOL/ P-VOL	T-VOL/ S-VOL	S-VOL/ P-VOL	T-VOL/ S-VOL
Logical	Blockade	_	SVP2484W	SVP2483W	SVP2485W	SVP2483W	SVP2485W	SVP2483W	SVP2485W	>	×
Device	Restore		×	SVP2483W	SVP2485W	SVP2483W	SVP2485W	SVP2483W	SVP2485W	>	×
	Format	_	×	SVP2483W	SVP2485W	SVP2483W	SVP2485W	SVP2483W	SVP2485W	>	×
	Verify	_	×	;	×	,	×	>	<	>	×
HDD	Replace		×	;	×	>	×	>	<	>	×
canister	Dynamic Sparing	_	×	;	×	>	×	>	<	>	×
	Correction Copy	_	×	;	×	>	×	>	<	>	×
Cache PCB	Replace	_	×)	×	,	×	>	<	>	×
СНА	Replace	_	×	× (*1)	× (*1)	× (*1)	× (*1)
DKA	Replace	_	×	;	×	,	×	>	<	>	×
MP	Replace	_	×	,	×	,	×	>	<	>	×

^{*1:} In the case of SI-MF, when all CHM is specified to de-install with pair includes 3390-A volume, the alert message of 'SVPXXXXW' is shown.

REP01-290

1.8 Availability of the online maintenance when XRC is used

Component	Maintenance	During in	nitial copy	Estab	lished	Suspend		
	Type	Primary	Secondary	Primary	Secondary	Primary	Secondary	
Logical	Blockade	**	**	**	**	**	**	
Device	Recovery	**	**	**	**	**	**	
	Format	**	**	**	**	**	**	
	Verify	×	×	×	×	×	×	
HDD canister	Replace	×	×	×	×	×	×	
Cache PCB	Replace	*	×	*	×	*	×	
СНА	Replace	×	×	×	×	×	×	
DKA	Replace	×	×	×	×	×	×	
MP	Replace	*	×	*	×	*	×	
ESW PCB	Replace	×	×	×	×	×	×	

- ×: Maintenance is available
- *: When a maintenance operation is needed while XRC is being used, I/O's for XRC pair volumes or XRC itself should be stopped before the maintenance operation.

 If the maintenance operation must be done while XRC is being used, you must confirm that the usage of Sidefile monitor is less than 20% of total Cache capacity by monitoring each combination of MPPK and CLPR usage before you start the maintenance operation. Only when the usage of Sidefile monitor is less than 20% of total Cache capacity, you can proceed the maintenance operation.

Refer to SVP SECTION "2.4 Monitoring" (SVP02-240) about Sidefile monitor.

Select the [Monitor] icon in the 'SVP' window.

Next select the [Monitor] menu in the 'Information' window and select [start....].

Next select the 'Sidefile' box in the 'Item' menu in the 'Monitoring' window and select [OK].

**: When a maintenance operation is needed while XRC is being used, XRC should be stopped before the maintenance operation.

1.9 Availability of the online maintenance when UR is used

JNL-GROUP

Component	Maintenance	Condition	TC-MF path	established	Ini	tial	Ac	tive
	Type		MCU	RCU	MCU	RCU	MCU	RCU
Logical Device	Blockade	_	×	×	SVP3825W	SVP3825W	SVP3825W	SVP3825W
	Recovery	_	×	×	SVP3825W	SVP3825W	SVP3825W	SVP3825W
	Format	_	×	×	SVP3825W	SVP3825W	SVP3825W	SVP3825W
	Verify	_	×	×	×	×	×	×
HDD canister	Replace	_	×	×	×	×	×	×
CACHE	Replace	_	×	×	×	×	×	×
СНА	Replace	With Alternate path	×	×	×	×	×	×
		Without Alternate path	×	×	×	×	×	×
DKA	Replace	_	×	×	×	×	×	×
DKC	Replace	With Alternate path	×	×	×	×	×	×
		Without Alternate path	×	×	×	×	×	×
MP	Replace	_	×	×	×	×	×	×

Component	Maintenance	Condition	Hal	ting	Stop		Stopping	
	Type		MCU	RCU	MCU	RCU	MCU	RCU
Logical Device	Blockade	_	SVP3825W	SVP3825W	SVP3825W	SVP3825W	SVP3825W	SVP3825W
	Recovery	_	SVP3825W	SVP3825W	SVP3825W	SVP3825W	SVP3825W	SVP3825W
	Format	_	SVP3825W	SVP3825W	SVP3825W	SVP3825W	SVP3825W	SVP3825W
	Verify	_	×	×	×	×	×	×
HDD canister	Replace	_	×	×	×	×	×	×
CACHE	Replace	_	×	×	×	×	×	×
СНА	Replace	With Alternate path	×	×	×	×	×	×
		Without Alternate path	×	×	×	×	×	×
DKA	Replace	_	×	×	×	×	×	×
DKC	Replace	With Alternate path	×	×	×	×	×	×
		Without Alternate path	×	×	×	×	×	×
MP	Replace	_	×	×	×	×	×	×

Rev.1 / Sep.2010, Dec.2010

REP01-310

DATA-VOL

Component	Maintenance Type	Condition	TC-MF path	n established	During initial copy		After completing initial copy	
			MCU	RCU	MCU	RCU	MCU	RCU
Logical Device	Blockade	_	×	×	SVP2031W	SVP2034W	SVP2031W	SVP2034W
	Recovery	_	×	×	SVP2031W	SVP2034W	SVP2031W	SVP2034W
	Format	_	×	×	SVP2031W	SVP2034W	SVP2031W	SVP2034W
	Verify	_	×	×	×	×	×	×
HDD canister	Replace	_	×	×	×	×	×	×
CACHE	Replace	_	×	×	SVP2059W	SVP2079W	×	×
CHF	Replace	With Alternate path	×	×	SVP3848W	×	SVP3848W	×
		Without Alternate path	×	×	SVP3848W	SVP2073W	SVP3848W	SVP2074W
СНМ	Replace	_	×	×	×	SVP4291W (*1)	×	SVP4291W (*1)
DKA	Replace	_	×	×	×	×	×	×
DKC	Replace	With Alternate path	×	×	SVP3848W	×	SVP3848W	×
		Without Alternate path	×	×	SVP3848W	SVP2073W	SVP3848W	SVP2074W
MP	Replace	_	×	×	×	×	×	×

Component	Maintenance	Condition	Susj	pend	Suspe	ending	Dele	eting
	Type		MCU	RCU	MCU	RCU	MCU	RCU
Logical Device	Blockade	_	SVP2031W	SVP2034W	SVP2031W	SVP2034W	SVP2031W	SVP2034W
	Recovery	_	SVP2031W	SVP2034W	SVP2031W	SVP2034W	SVP2031W	SVP2034W
	Format	_	SVP2031W	SVP2034W	SVP2031W	SVP2034W	SVP2031W	SVP2034W
	Verify	_	×	×	×	×	×	×
HDD canister	Replace	_	×	×	×	×	×	×
CACHE	Replace	_	×	×	×	×	×	×
CHF	Replace	With Alternate path	SVP3848W	×	SVP3848W	×	SVP3848W	×
		Without Alternate path	SVP3848W	×	SVP3848W	SVP2075W	SVP3848W	SVP2075W
СНМ	Replace	_	×	×	×	SVP4291W (*1)	×	SVP4291W (*1)
DKA	Replace	_	×	×	×	×	×	×
DKC	Replace	With Alternate path	SVP3848W	×	SVP3848W	×	SVP3848W	×
		Without Alternate path	SVP3848W	×	SVP3848W	SVP2075W	SVP3848W	SVP2075W
MP	Replace	_	×	×	×	×	×	×

×: Maintenance is available

SVPXXXXW: Maintenance is not available based on the specification. Refer to SVP MESSAGE SECTION.

*1: In this operation, when the normal CHM disappear, the warning message of 'SVP4291W' will be outputted.

Copyright © 2010, Hitachi, Ltd.

1.10 About the storage media used for installation/maintenance process

The media showed in following table are attached in subsystem, in order to advance installation, maintenance, and failure analysis smoothly. Please implement installation or collect information according to the work procedure indicated in each section.

No.	Media	Description	Installation device	Remarks
1	CD-ROM	CD-R for micro program storage. Used for installation or micro program download in time of micro FC.	CD-R Drive of CE Laptop PC	Attached to the device
2	USB Memory	The USB memory for configuration information backup. Used for configuration information storage in time of device configuration change.	USB Connector of SVP	Attached to the device
3	USB Memory	USB memory for collecting device dump information. Used for collecting dump information in time of failure analysis or operation investigation.	USB Connector of SVP	Attached to the device




Fig. 1.10-1 Information Collection Device for each Media

Rev.0 / Sep.2010

REP02-01-10

Copyright © 2010, Hitachi, Ltd.

[PRE-PROCEDURE A]

- OUTLINE -

- ① Display Initial Screen
- ② Change SVP operation mode
- ③ Open Maintenance window


REP02-01-20

1. <Initial screen>

Display the SVP initial screen from SVP Section "1. How to Operate the SVP (PC)" (SVP01-10).

For CE Laptop PC, please refer to 3.1.5.3.

- "3.1.5.3 Attachment/Removal Procedure of CE Laptop PC" (INST03-01-120)
- 2. <Maintenance Other Components>
 Select the [Maintenance Components]-[Maintenance Other Components] from Action Menu.
 And open the 'Maintenance Other Components' window.
- 3. <Operation mode change>
 Change the mode to [Modify Mode].
 Select (CL) [Maintenance].
- 4. <Maintenance window>
 The 'Maintenance' window is displayed.



Copyright © 2010, 2012, Hitachi, Ltd.

Rev.0 / Sep.2010

REP02-02-10

Copyright © 2010, Hitachi, Ltd.

[PRE-PROCEDURE B]

- OUTLINE -


- ① Installation of USB memory
- ② Display Initial Screen
- ③ Open Maintenance window

A USB memory is being provided with each replacement SSW, CACHE, ESW, DKA and CHAs assembly to collect more detailed information about transient failures. Return the USB memory that contains the failure information together with the failed PCB after the failed PCB replacement.

1. Installation of USB memory

- (1) Collecting information to the external USB memory.

 Connect the USB memory to one of the USB ports on the SVP in the array as shown below. If the Additional SVP is installed, the USB memory must be installed in the SVP that is the active SVP.
 - ① Insert the USB memory in USB port on the SVP.




Copyright © 2010, 2012, Hitachi, Ltd.

REP02-02-30

<Initial screen>
 Display the SVP initial screen from SVP Section "1. How to Operate the SVP (PC)" (SVP01-10).

- 3. <Maintenance Other Components>
 Select the [Maintenance Components]-[Maintenance Other Components] from Action Menu.
 And open the 'Maintenance Other Components' window.
- 4. <Operation mode change>
 Change the mode to [Modify Mode].
 Select (CL) [Maintenance].
- 5. <Maintenance window>
 The 'Maintenance' window is displayed.



[DRIVE REPLACEMENT PROCESSING - RDK1]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - Select drive (status check)
 - ② Check progress of copy processing
 - 3 Specify Replacement
 - Place HDD into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Execute CUDG on P-DEV
 - ② Specify recovery
 - 3 Copy back

A CAUTION

If No Charging of FMD (SIM = 50EXYY) occurs in replacement of a FMD, the FMD ACTIVE LED will change to low-speed blinking. In this case, it takes 90 minutes at most for the FMD ACTIVE LED to go out and for the battery in the FMD to be fully charged.

Notice: If Drive Replacement is operated during running Drive Erase, Drive Erase may be abnormal end. The drive can not be reused, and can not be ensured that the drive erase is completed.

Rev.0 / Sep.2010


REP03-01-20

Copyright © 2010, Hitachi, Ltd.

1. PRE-PROCESSING of SVP


1-1. <Maintenance window>

Open the 'Maintenance' window according to PRE PROCEDURE A (REP02-01-10). Select (CL) the DKU information [DKU-nn] of the DKU which installs the HDD to be replaced in the 'Maintenance' window.




1-2. <Select HDU>

Select (CL) the HDU information [HDUn] of the HDU which installs the HDD to be replaced.



1-3. <Select HDD>

Check and select (CL) [nn] to be replaced.



Rev.1 / Sep.2010, Oct.2012


REP03-01-30

Copyright © 2010, 2012, Hitachi, Ltd.

1-4. <Specify replacement of HDD>

Make sure that the "Device Status" is [Failed] or [Warning] or [Reserved].

Select (CL) [Replace]-[Replace].



1-5. < Checking the P-DEV status>



When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

"Checking..." is displayed.

Rev.0 / Sep.2010

REP03-01-31

1-6. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).

(2)


In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-3.

When [No] is selected (CL), returned to Step 1-6.



Copyright © 2010, Hitachi, Ltd.






device?".

REP03-01-32

1-7. <P-DEV blocking> Select (CL) [Yes] in response to "Are you sure you want to replace the physical




- 1-8. <Blocking the Physical device> "Blocking..." is displayed.
- 1-9. <Spin down the Physical device> "Spinning down..." is displayed.

Perform the dummy replacement of the displayed SSW(s) when the window is displayed. Select the DKU list and record the target SSW(s) because two or more DKU might be listed.

Select (CL) [Close] button and perform the dummy replacement of the target SSW(s).

Retry the replacement after completing the dummy replacement of SSW.



Rev.0 / Sep.2010

REP03-01-40

1-10. <Check shut down LED>



A CAUTION


If a wrong HDD is removed, a data loss or a system down may occur.

Check the shut down LED on the HDD to be replaced.

If LED is off, reconfirm the location of the HDD to be replaced with LOCATION SECTION before replacing the hardware.

1-11. <Confirm Removal>

Select (CL) [OK] in response to "Check the location of the disk drive that you want to remove, because an LED of some other disk drives might be on. After the check, remove the disk drive, then select [OK] button. (HDDxnn-nn)" after the unit is removed. (Step 2-3)



Copyright © 2010, Hitachi, Ltd.

1-12. <Replace HDD>

Replace HDD.

Go to "2. HARDWARE REPLACEMENT PROCESSING".

Copyright © 2010, 2014, Hitachi, Ltd.


2. HARDWARE REPLACEMENT PROCESSING

Location		Function Name of Component	Part Name	HDA Label
DKU	1	Disk Drive (HDD)	HDU700-146KCMSS	S5B-K146SS
		, ,		S5C-K146SS
			HDU700-300JCMSS	R5C-J300SS
				R5D-J300SS
				S5B-J300SS
				S5D-J300SS
				S5E-J300SS
			HDU700-300KCMSS	R5C-K300SS
				S5C-K300SS
			HDU700-500HCMSS	S5A-H500SS
				S5B-H500SS
			HDU700-600JCMSS	R5C-J600SS
				R5D-J600SS
				S5C-J600SS
				S5D-J600SS
				S5E-J600SS
			HDU700-900JCMSS	R5D-J900SS
				S5D-J900SS
				S5E-J900SS
			HDU700-1R0HCMSS	S5B-H1R0SS
			HDU700-1R2JCMSS	R5E-J1R2SS
			112 0 7 0 0 11120 011120	S5F-J1R2SS
			HDU700-2R0H2MAT	R2C-H2R0AT
				R2D-H2R0AT
				R2E-H2R0AT
			HDU700-2R0H3MSS	S2C-H2R0SS
			TID 6 700 EROTIONISS	S2D-H2R0SD
				S2D-H2R0SS
				S2P-H2R0SS
				S2E-H2R0SS
				W2E-H2R0SS
			HDU700-3R0H3MSS	S2D-H3R0SS
			TIBE 700 SKOTISMISS	S2E-H3R0SS
				W2E-H3R0SS
			HDU700-4R0H3MSS	S2E-H4R0SS
			TIBE 700 IROIISINISS	W2E-H4R0SS
	2	Flash Drive (SSD)	HDU700-200MCMSS	B5A-M200SS
	-	This Drive (SSD)	TIDE 700 Z00IVIENIBB	R5B-M200SS
			HDU700-200SAMSS	T5A-S200SS
			112 0 , 00 20001111100	T5C-S200SS
			HDU700-200SCMSS	R5A-S200SS
			1120700 2000011100	R5B-S200SS
			HDU700-400MCMSS	B5A-M400SS
				R5B-M400SS
			HDU700-400SCMSS	R5A-S400SS
			TIDE / OU TOUS CIVIS	R5B-S400SS
			HDU700-800MCMSS	B5A-M800SS
			HDU700-400S1MSS	T2A-S400SS
			1100/00-4000111000	T2C-S400SS
Front View of	3	Flash Module Drive (FMD)	HDU700-1R6FMSS	H1A-P1R6SS
FBX DKU	3	1 14511 MOUNTE DITAC (LIMD)	ITDO (00-IKOLMISS	H1C-P1R6SS
ΓΔΛ ΔΚυ			HDU700-3R2FMSS	
			UDO 100-3K2FINISS	H1B-P3R2SS H1C-P3R2SS
				111C-F3K233


Hitachi Proprietary

DKC710I


Rev.1 / Sep.2011, Oct.2012 **REP03-01-51**



Front or Rear View of DKU
(In case of 3.5inch Drive)



DKU
(In case of 2.5inch Drive)



Front View of DKU (In case of FMD)

NOTICE:

- Replace the drive in the subsystem in power on status only. Do not replace the drive in power off status.
- Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.
- HDD is a precise component. Be careful in handling HDD to avoid vibration and impact.

- 2-1. Open the FAN door.
- 2-1-1. In case of 3.5inch/2.5inch drive
 - a. Put the stopper of the FAN door into the open able and closable state. (Refer to the INST03-01-160.)
 - b. Loosen the two screws and open the FAN door.
- 2-1-2. In case of FMD
 - a. Go to procedure 2-2. Check the Shut Down LED.




Fig. 3.1.2-1 FAN Door Opening

- 2-2. Check the Shut Down LED.
- 2-2-1. In case of 3.5inch/2.5inch drive
 - a. Check that the Shut Down LED on the HDDPWR corresponding to drive (HDD/SSD) is turned on. Refer to Fig. 3.1.2-2 or 3.1.2-3.






Fig. 3.1.2-2 Checking of Shut Down LED (In case of 3.5inch Drive)

Copyright © 2010, Hitachi, Ltd.






Fig. 3.1.2-3 Checking of Shut Down LED (In case of 2.5inch Drive)


Rev.0 / Oct.2012

REP03-01-81

Copyright © 2012, Hitachi, Ltd.

2-2-2. In case of FMD

a. Check that the Shut Down LED on drive is turned on.



Front View of FBX DKU




Fig. 3.1.2-3A Checking of Shut Down LED (In case of FMD)

Rev.2 / Dec.2011, Oct.2012

- 2-3. Remove the drive.
- 2-3-1. In case of 3.5inch drive.
 - Push up the stopper of drive, and bring the handle down. Don't pull the handle during this process.
 - b. Push down the handle.
 - c. Pull out the drive.
 - d. Fig. 3.1.2-5 illustrates the case of wrong procedure.





Fig. 3.1.2-5 Removal of Drive (Wrong Procedure)

DKC710I

Copyright © 2010, 2012, Hitachi, Ltd.

2-3-2. In case of 2.5inch drive.



- a. Push the stopper of drive, and bring the handle down. Don't pull the handle during this process.
- b. Push down the handle.
- c. Pull out the drive.
- d. Fig. 3.1.2-7 illustrates the case of wrong procedure.




Fig. 3.1.2-6 Removal of Drive

Rev.0 / Sep.2010

Copyright © 2010, Hitachi, Ltd. REP03-01-101




Fig. 3.1.2-7 Removal of Drive (Wrong Procedure)

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd.

REP03-01-102

2-3-3. In case of FMD

Notice: When the FMD is removed in replacing procedure, the fans of the DKUPS equipped in the rear of the FBX DKU rotate at the highest speed. When the spare FMD is installed, the fans of the DKUPS rotate at the speed suitable for environmental temperature.

- a. Pull the stopper of the drive handle toward you to have the lock off.
- b. Tilt the handle toward you, and then remove the drive by pulling it out taking care not to apply a shock to it.

Note: When handling the drive, hold the rail side because the shield spring is subject to breakage.





Fig. 3.1.2-7A Removal of Drive (In case of FMD)


Rev.0 / Feb.2014

Copyright © 2014, Hitachi, Ltd.

REP03-01-103

c. Check whether a failure of the battery built in the FMD has occurred by using the flowchart below. If a battery failure has occurred, remove the battery from the FMD. If no battery failure has occurred, go to Procedure 2-4.





- d. FMD Battery Removing Procedure
 - (d)-1 Remove 4 Screws (SB310N) on the bottom side of FMD by using cross-head screw driver.




Fig. 3.1.2-7B Removing Screws

(d)-2 Remove Top Cover and Bottom Cover.




Fig. 3.1.2-7C Removing Covers

(d)-3 Remove 2 sets of Tapping-screw and Washer by using cross-head screw driver.




Fig. 3.1.2-7D Removing Tapping-screws and Washers

(d)-4 Move the Battery to the bezel side and disconnect the Battery from the circuit board.




Fig. 3.1.2-7E Disconnecting from Connector

(d)-5 Remove the Battery to the bottom side of FMD. (After the connector comes off, battery is lowered below.)




Fig. 3.1.2-7F Removing Battery

- (d)-6 Attach Top Cover and Bottom Cover.
- (d)-7 Attach 4 Screws (SB310N) on the bottom side of FMD.




Fig. 3.1.2-7G Reassembling FMD

(d)-8 Dispose of the Tapping-screws, Washers and Battery removed in procedures (d)-3 and (d)-5.


When dispose of the Battery, follow the directions given by the local law where the product is used.

REP03-01-110

2-4. Check and handling of the drive.


(1) <Confirm Removal>


Select (CL) [OK] in response to "Check the location of the disk drive that you want to remove, because an LED of some other disk drives might be on. After the check, remove the disk drive, then select [OK] button. (HDDxnn-nn)" after the unit is removed. (Step 2-3)




(2) < Confirm Insertion>


"Check the location of the disk drive that you want to insert. After the check, insert the disk drive, then select [OK] button. (HDDnnn-nn)" is displayed.







2-5. Install the drive.



Instruction for the insertion and removal of the 2.5-inch drive:

The upper part of HDDPWR might come in contact with the lower part of the drive, and it becomes an obstruction of the insertion and removal at the time of the 2.5-inch drive insertion and removal. In this case, avoid the HDDPWR by lifting the drive lightly.

Caution – Back Board, or drive connector or drive handle may be damaged when the drive is forcibly inserted.

If the drive cannot be easily inserted until the claws on the handle reach the DKU, or if the handle binds or stops before it can be locked, then remove the drive and perform inspection:

- a) Check the drive slot in DKU to be free and clear of obstructions.
- b) Check connector on back board for visible defects.
- c) Inspect connector on drive for visible defects.
- d) Inspect drive top and bottom guide for defects. Note special alignment tab on bottom guide on some drive. A damaged tab can bind on the lower slot guides in DKU.
- e) During installation make sure the drive is inserted in alignment with slot guides.
- f) Check upper rear spring on SSD has been removed. (This applies only on SSD) Reinsert drive after inspections have passed.

Rev.2 / Oct.2010, Oct.2012

REP03-01-121


Copyright © 2010, 2012, Hitachi, Ltd.

2-5-1. In case of 3.5inch/2.5inch drive

- Insert the drive into the HDU holding its handle. (Insert the canister until the claws that are located at the bottom of the handle come in contact with the front side of the HDU.)
- b. Turn the handle at a stroke by pushing its top with your thumb. (Turn the handle until it latches with the stopper. Do not stop the handle on its way of turning.)

a. Insert the HDD/SSD canister into the HDU holding its handle.

A gap exists between the connectors.



b. Turn the handle at a stroke by pushing its top with your thumb. (Do not stop the handle on its way of turning.)




Fig. 3.1.2-8 Method of Installing Drive

- c. Close the FAN door and tighten the screws. (Refer to Fig. 3.1.2-1.)
- d. Put the FAN door stopper into the neutral state.

Rev.0 / Oct.2012

REP03-01-122

Copyright © 2012, Hitachi, Ltd.

2-5-2. In case of FMD

Note: When handling the drive, hold the rail side because the shield spring is subject to breakage.

- a. Open the handle fully and fit the drive in the guide rail and slide it in the direction shown by the arrow not to give a shock.
- b. Push the drive in until it reaches the position where a hook of the handle can be entered into the square hole on a frame.
- c. Pull the stopper lightly and close the handle, and then press the stopper to have the lock on. If the handle is closed in the state where the hook of the handle cannot enter into the square hole, the drive cannot be installed correctly because it runs into the frame of the FBX DKU.




Fig. 3.1.2-9 Installation of Drive (In case of FMD)

2-6. Go to "3. POST-PROCESSING of SVP".


Before starting the <Check the beginning of recovery> operation in POST-PROCEDURES of SVP, be sure to insert a removable media for dump, collect failure information, and return the removable media with the failed HDD.

A dump removable media is attached with a Spare HDD.

POST-PROCESSING of SVP


3-1. <Confirm Insertion>


"Check the location of the disk drive that you want to insert. After the check, insert the disk drive, then select [OK] button. (HDDnnnnn)"is displayed.



3-2. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].





"Insert a removable media for gathering error information and select [OK].

The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.


Select a Client PC arbitrary drive, and select (CL) [Ok].

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the

screen, and select an arbitrary drive letter from the pull-down menu.

The drive letter becomes the drive letter of console PC connected with SVP.



Rev.1 / Sep.2010, Oct.2010


REP03-01-140

Copyright © 2010, Hitachi, Ltd.

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.


Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.



Select (CL) [Save] when saving a file in a specified directory. It returns to the drive selection screen when [Cancel] is selected (CL).

3-3. <Copy of the error information>

The error information is copied onto media.



"Remove the media." is displayed. Select (CL) [OK].



3-4. <Spin up the Physical Drive>

"Spinning up..." is displayed.

3-5. <DKU INLINE>

"DKU INLINE is now running..." is displayed.

3-6. < Replacement of the DKU micro-program>

When the revision of the DKU micro-program in the SVP hard disk is newer than that in the PDEV, the following message appears on the screen.

The message "Exchanging DKU micro-program..." appears.

3-7. < Restore Physical Drive>

"Restoring..." is displayed.

3-8. < Check the Physical Drive>


"Checking..." is displayed.

3-9. < Check the beginning of copy-back>

A message, which asks for confirmation of whether or not to start a copy-back or to make the automatic copy-back, is displayed.

[Confirmation of starting a copy-back] Select (CL) [Yes] in response to "Are you sure you want to copy data in spare device to the physical device?.".

Go to Step 3-10.



[Confirmation of making an automatic copy-back]

Select (CL) [OK] in response to a message, "After data is copied to the spare device, copy-back will be performed.".



It goes to 3-11 when HDDFAN doors of the object are not closed.

It goes to 3-12 when HDDFAN doors of the object are closed.

3-10. <Check starting of copyback>

"Copying..." is displayed.

Select (CL) [OK] in response to "Copying data in spare device to the physical device has been started.".

It goes to 3-11 when HDDFAN doors of the object are not closed.

Replace

[ONL2399i]
Copying data in spare device to the physical device has been started.

OK

It goes to 3-12 when HDDFAN doors of the object are closed.

3-11. <Warning of HDDFAN door open>

(1)

"The FAN Door of HDDFAN-xxx is open. Close the FAN Door, and select [OK].


The FAN Door checking is executed up to 3 times. (n/3)" is displayed.

After the FAN door is closed, select (CL) [OK] in response to this message.

It returns to 3-11 when HDDFAN doors of the object are not closed.

It goes to (2) when HDDFAN doors of the object are closed.

Note: It goes to 3-12 when it cannot be confirmed that the FAN doors are closed in the three times FAN door check.



(2)

"A problem in HDDFAN or a FAN Door open might be occurred.


After completing the maintenance process, check the Maintenance or Information window in an error status or an error log is shown on the window, then execute troubleshooting." is displayed.

Select (CL) [OK] in response to this message.



3-12.

When interrupting a copy, select (CL) the [Drive Interrupt] button.



3-13.

Go to POST-PROCEDURE [REP04-01-10].

[DRIVE REPLACEMENT PROCESSING - RDK2]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select drive (status check)
 - ② Specify Replacement
 - 3 Save Spare
 - Select drive (status check)
 - © Check progress of copy processing
 - © Specify Replacement
 - Place HDD into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Execute CUDG on P-DEV
 - ② Specify recovery
 - 3 Copy back

A CAUTION

If No Charging of FMD (SIM = 50EXYY) occurs in replacement of a FMD, the FMD ACTIVE LED will change to low-speed blinking. In this case, it takes 90 minutes at most for the FMD ACTIVE LED to go out and for the battery in the FMD to be fully charged.

Rev.0 / Sep.2010

REP03-02-20


2-20

1 1

1-1. <Maintenance window>

PRE-PROCESSING of SVP


Open the 'Maintenance' window according to PRE PROCEDURE A (REP02-01-10). Select (CL) the DKU information [DKU-nn] of the DKU which installs the HDD to be replaced in the 'Maintenance' window.



Copyright © 2010, Hitachi, Ltd.

1-2. <Select HDU>

Select (CL) the HDU information [HDUn] of the HDU which installs the HDD to be replaced.




Rev.0 / Sep.2010

REP03-02-30


1-3. <Select HDD>

Check and select (CL) [nn] to be replaced.



Copyright © 2010, Hitachi, Ltd.

1-4. <Specify replacement of HDD> Select (CL) [Other]-[Spare Disk].



REP03-02-40

1-5. < Checking the P-DEV status>



A CAUTION

When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support division to ask for instructions.


If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

"Checking..." is displayed.

1-6. <Saving the spare> Select (CL) [Yes] in response to "Are you sure you want to copy data in the physical device to spare?".



- 1-7. <Saving in process> "Copying..." is displayed.
- 1-8. <End of spare saving> Select (CL) [OK] in response to "Copying data in the physical device to spare has been started.".




Rev.0 / Sep.2010

REP03-02-50

1-9.

When interrupting a copy, select (CL) the [Drive Interrupt] button.




Copyright © 2010, Hitachi, Ltd.

Rev.0 / Sep.2010

REP03-02-60


1-10. <Maintenance window>
Select (CL) the DKU information [DKU-nn]
of the DKU which installs the SSW to be
replaced in the 'Maintenance' window.



Copyright © 2010, Hitachi, Ltd.

1-11. <Select HDU>


Select (CL) the HDU information [HDUn] of the HDU which installs the HDD to be replaced.



REP03-02-70

1-12. <Select HDD>


Check and select (CL) [nn] to be replaced.



1-13. <Specify replacement of HDD>

Make sure that the "Device Status" is [Failed] or [Warning] or [Reserved].

Select (CL) [Replace]-[Replace].



1-14. < Checking the P-DEV status >

A CAUTION

When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

"Checking..." is displayed.

Rev.0 / Sep.2010

REP03-02-80

1-15. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).

(2)


In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped.


[No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-12.

When [No] is selected (CL), returned to Step 1-15.



Copyright © 2010, Hitachi, Ltd.






Rev.1 / Sep.2010, Oct.2012

Copyright © 2010, 2012, Hitachi, Ltd.

REP03-02-81

1-16. <P-DEV blocking>
Select (CL) [Yes] in response to "Are you sure you want to replace the physical device?".



1-17. <Blocking the Physical device> "Blocking..." is displayed.

Rev.0 / Sep.2010


REP03-02-90

1-18. <Spin down the Physical device> "Spinning down..." is displayed.

Perform the dummy replacement of the displayed SSW(s) when the window is displayed. Select the DKU list and record the target SSW(s) because two or more DKU might be listed.

Select (CL) [Close] button and perform the dummy replacement of the target SSW(s).

Retry the replacement after completing the dummy replacement of SSW.



Copyright © 2010, Hitachi, Ltd.

1-19. <Check shut down LED>



CAUTION


If a wrong HDD is removed, a data loss or a system down may occur.

Check the shut down LED on the HDD to be replaced.

If LED is off, reconfirm the location of the HDD to be replaced with LOCATION SECTION before replacing the hardware.

1-20. <Confirm Removal>

Select (CL) [OK] in response to "Check the location of the disk drive that you want to remove, because an LED of some other disk drives might be on. After the check, remove the disk drive, then select [OK] button. (HDDxnn-nn)" after the unit is removed. (Step 2-3)



1-21. <Replace HDD>

Replace HDD.


Go to "2. HARDWARE REPLACEMENT PROCESSING".

2. HARDWARE REPLACEMENT PROCESSING


Location	L	Function Name of Component	Part Name	HDA Label
DKU	1	Disk Drive (HDD)	HDU700-146KCMSS	S5B-K146SS
				S5C-K146SS
			HDU700-300JCMSS	R5C-J300SS
				R5D-J300SS
				S5B-J300SS
				S5D-J300SS
				S5E-J300SS
			HDU700-300KCMSS	R5C-K300SS
				S5C-K300SS
			HDU700-500HCMSS	S5A-H500SS
				S5B-H500SS
			HDU700-600JCMSS	R5C-J600SS
				R5D-J600SS
				S5C-J600SS
				S5D-J600SS
				S5E-J600SS
			HDU700-900JCMSS	R5D-J900SS
				S5D-J900SS
				S5E-J900SS
			HDU700-1R0HCMSS	S5B-H1R0SS
			HDU700-1R2JCMSS	R5E-J1R2SS
			TIDE 700 TRESCIVISS	S5F-J1R2SS
			HDU700-2R0H2MAT	R2C-H2R0AT
			TIDE 700 ZIKOTIZIVITYT	R2D-H2R0AT
				R2E-H2R0AT
			HDU700-2R0H3MSS	S2C-H2R0SS
			11D0700-2R01131VISS	S2D-H2R0SD
				S2D-H2R0SS
				S2P-H2R0SS
				S2E-H2R0SS
				W2E-H2R0SS
			HDU700-3R0H3MSS	S2D-H3R0SS
			11D0700-3K0113M3S	S2E-H3R0SS
				W2E-H3R0SS
			HDU700-4R0H3MSS	S2E-H4R0SS
			11D0700-4K0113MISS	W2E-H4R0SS
	2	Flash Drive (SSD)	HDU700-200MCMSS	B5A-M200SS
	2	Plasti Drive (SSD)	HD0700-200MCMSS	R5B-M200SS
			HDU700-200SAMSS	T5A-S200SS
			HDU 700-2005AMSS	T5C-S200SS
			HDU700-200SCMSS	R5A-S200SS
			про /00-2003CM33	R5A-S200SS R5B-S200SS
			LIDUZOO 400MCMCC	
			HDU700-400MCMSS	B5A-M400SS
			LIDITOO AOOGOMAGA	R5B-M400SS
			HDU700-400SCMSS	R5A-S400SS
			LIDITOO OOOMONAGA	R5B-S400SS
			HDU700-800MCMSS	B5A-M800SS
			HDU700-400S1MSS	T2A-S400SS
Front View of FBX DKU	3	Flash Module Drive (FMD)	HDU700-1R6FMSS	T2C-S400SS
				H1A-P1R6SS
				H1C-P1R6SS
			HDU700-3R2FMSS	H1B-P3R2SS
				H1C-P3R2SS

Hitachi Proprietary


Rev.1 / Sep.2011, Oct.2012 **REP03-02-101**



Front or Rear View of DKU
(In case of 3.5inch Drive)



DKU
(In case of 2.5inch Drive)



Front View of DKU (In case of FMD)

NOTICE:

- Replace the drive in the subsystem in power on status only. Do not replace the drive in power off status.
- Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.
- HDD is a precise component. Be careful in handling HDD to avoid vibration and impact.

REP03-02-110

- 2-1. Open the FAN door.
- 2-1-1. In case of 3.5inch/2.5inch drive
 - a. Put the stopper of the FAN door into the open able and closable state. (Refer to the INST03-01-160.)
 - b. Loosen the two screws and open the FAN door.
- 2-1-2. In case of FMD
 - a. Go to procedure 2-2. Check the Shut Down LED.





Fig. 3.2.2-1 FAN Door Opening

- 2-2. Check the Shut Down LED.
- 2-2-1. In case of 3.5inch/2.5inch drive
 - a. Check that the Shut Down LED on the HDDPWR corresponding to drive (HDD/SSD) is turned on. Refer to Fig. 3.2.2-2 or 3.2.2-3.






Fig. 3.2.2-2 Checking of Shut Down LED (In case of 3.5inch Drive)

Copyright © 2010, Hitachi, Ltd.




Fig. 3.2.2-3 Checking of Shut Down LED (In case of 2.5inch Drive)

→DKC No. (0, 1)


Rev.0 / Oct.2012

REP03-02-131

Copyright © 2012, Hitachi, Ltd.

2-2-2. In case of FMD

a. Check that the Shut Down LED on drive is turned on.



Front View of FBX DKU




Fig. 3.2.2-3A Checking of Shut Down LED (In case of FMD)

- 2-3. Remove the drive.
- 2-3-1. In case of 3.5inch drive.
 - a. Push up the stopper of drive, and bring the handle down. Don't pull the handle during this process.
 - b. Push down the handle.
 - c. Pull out the drive.
 - d. Fig. 3.2.2-5 illustrates the case of wrong procedure.





Fig. 3.2.2-5 Removal of Drive (Wrong Procedure)

2-3-2. In case of 2.5inch drive.



- a. Push the stopper of drive, and bring the handle down. Don't pull the handle during this process.
- b. Push down the handle.
- c. Pull out the drive.
- d. Fig. 3.2.2-7 illustrates the case of wrong procedure.




Fig. 3.2.2-6 Removal of Drive

REP03-02-151




Fig. 3.2.2-7 Removal of Drive (Wrong Procedure)

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd.

REP03-02-152

2-3-3. In case of FMD

Notice: When the FMD is removed in replacing procedure, the fans of the DKUPS equipped in the rear of the FBX DKU rotate at the highest speed. When the spare FMD is installed, the fans of the DKUPS rotate at the speed suitable for environmental temperature.

- a. Pull the stopper of the drive handle toward you to have the lock off.
- b. Tilt the handle toward you, and then remove the drive by pulling it out taking care not to apply a shock to it.

Note: When handling the drive, hold the rail side because the shield spring is subject to breakage.





Fig. 3.2.2-7A Removal of Drive (In case of FMD)

Rev.0 / Feb.2014


REP03-02-153

Copyright © 2014, Hitachi, Ltd.

c. Check whether a failure of the battery built in the FMD has occurred by using the flowchart below. If a battery failure has occurred, remove the battery from the FMD. If no battery failure has occurred, go to Procedure 2-4.



REP03-02-154



- d. FMD Battery Removing Procedure
 - (d)-1 Remove 4 Screws (SB310N) on the bottom side of FMD by using cross-head screw driver.




Fig. 3.2.2-7B Removing Screws

(d)-2 Remove Top Cover and Bottom Cover.




Fig. 3.2.2-7C Removing Covers

(d)-3 Remove 2 sets of Tapping-screw and Washer by using cross-head screw driver.




Fig. 3.2.2-7D Removing Tapping-screws and Washers

(d)-4 Move the Battery to the bezel side and disconnect the Battery from the circuit board.




Fig. 3.2.2-7E Disconnecting from Connector

(d)-5 Remove the Battery to the bottom side of FMD. (After the connector comes off, battery is lowered below.)




Fig. 3.2.2-7F Removing Battery

- (d)-6 Attach Top Cover and Bottom Cover.
- (d)-7 Attach 4 Screws (SB310N) on the bottom side of FMD.




Fig. 3.2.2-7G Reassembling FMD

(d)-8 Dispose of the Tapping-screws, Washers and Battery removed in procedures (d)-3 and (d)-5.


When dispose of the Battery, follow the directions given by the local law where the product is used.

REP03-02-160

2-4. Check and handling of the drive.


(1) <Confirm Removal>


Select (CL) [OK] in response to "Check the location of the disk drive that you want to remove, because an LED of some other disk drives might be on. After the check, remove the disk drive, then select [OK] button. (HDDxnn-nn)" after the unit is removed. (Step 2-3)




(2) < Confirm Insertion>


"Check the location of the disk drive that you want to insert. After the check, insert the disk drive, then select [OK] button. (HDDnnn-nn)" is displayed.







2-5. Install the drive.



Instruction for the insertion and removal of the 2.5-inch drive:

The upper part of HDDPWR might come in contact with the lower part of the drive, and it becomes an obstruction of the insertion and removal at the time of the 2.5-inch drive insertion and removal. In this case, avoid the HDDPWR by lifting the drive lightly.

Caution – Back Board, or drive connector or drive handle may be damaged when the drive is forcibly inserted.

If the drive cannot be easily inserted until the claws on the handle reach the DKU, or if the handle binds or stops before it can be locked, then remove the drive and perform inspection:

- a) Check the drive slot in DKU to be free and clear of obstructions.
- b) Check connector on back board for visible defects.
- c) Inspect connector on drive for visible defects.
- d) Inspect drive top and bottom guide for defects. Note special alignment tab on bottom guide on some drive. A damaged tab can bind on the lower slot guides in DKU.
- e) During installation make sure the drive is inserted in alignment with slot guides.
- f) Check upper rear spring on SSD has been removed. (This applies only on SSD) Reinsert drive after inspections have passed.

Rev.2 / Oct.2010, Oct.2012

REP03-02-171


Copyright © 2010, 2012, Hitachi, Ltd.

2-5-1. In case of 3.5inch/2.5inch drive

- Insert the drive into the HDU holding its handle. (Insert the canister until the claws that are located at the bottom of the handle come in contact with the front side of the HDU.)
- b. Turn the handle at a stroke by pushing its top with your thumb. (Turn the handle until it latches with the stopper. Do not stop the handle on its way of turning.)

a. Insert the HDD/SSD canister into the HDU holding its handle.

A gap exists between the connectors.



b. Turn the handle at a stroke by pushing its top with your thumb. (Do not stop the handle on its way of turning.)




Fig. 3.2.2-8 Method of Installing Drive

- c. Close the FAN door and tighten the screws. (Refer to Fig. 3.2.2-1.)
- d. Put the FAN door stopper into the neutral state.

Rev.0 / Oct.2012

REP03-02-172

Copyright © 2012, Hitachi, Ltd.

2-5-2. In case of FMD

Note: When handling the drive, hold the rail side because the shield spring is subject to breakage.

- a. Open the handle fully and fit the drive in the guide rail and slide it in the direction shown by the arrow not to give a shock.
- b. Push the drive in until it reaches the position where a hook of the handle can be entered into the square hole on a frame.
- c. Pull the stopper lightly and close the handle, and then press the stopper to have the lock on. If the handle is closed in the state where the hook of the handle cannot enter into the square hole, the drive cannot be installed correctly because it runs into the frame of the FBX DKU.




Fig. 3.2.2-9 Installation of Drive (In case of FMD)

2-6. Go to "3. POST-PROCESSING of SVP".

REP03-02-180


Before starting the <Check the beginning of recovery> operation in POST-PROCEDURES of SVP, be sure to insert a removable media for dump, collect failure information, and return the removable media with the failed HDD.

A dump removable media is attached with a Spare HDD.

POST-PROCESSING of SVP


3-1. <Confirm Insertion>


"Check the location of the disk drive that you want to insert. After the check, insert the disk drive, then select [OK] button. (HDDnnnnn)"is displayed.



3-2. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].





"Insert a removable media for gathering error information and select [OK].

The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.


Select a Client PC arbitrary drive, and select (CL) [Ok].

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the

screen, and select an arbitrary drive letter from the pull-down menu.

The drive letter becomes the drive letter of console PC connected with SVP.




Copyright © 2010, Hitachi, Ltd.

REP03-02-190

When Client PC is selected, the directory selection dialog is displayed. Please select an arbitrary directory if


Please select an arbitrary directory if necessary.

Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.



Select (CL) [Save] when saving a file in a specified directory. It returns to the drive selection screen when [Cancel] is selected (CL).

3-3. < Copy of the error information > The error information is copied onto media.



"Remove the media." is displayed. Select (CL) [OK].



REP03-02-200

3-4. <Spin up the Physical Drive>

"Spinning up..." is displayed.

3-5. <DKU INLINE>

"DKU INLINE is now running..." is displayed.

3-6. < Replacement of the DKU micro-program>

When the revision of the DKU micro-program in the SVP hard disk is newer than that in the PDEV, the following message appears on the screen.

The message "Exchanging DKU micro-program..." appears.

3-7. < Restore Physical Drive>

"Restoring..." is displayed.

3-8. < Check the Physical Drive>

"Checking..." is displayed.

3-9. <Check the beginning of copy-back>

A message, which asks for confirmation of whether or not to start a copy-back or to make the automatic copy-back, is displayed.


[Confirmation of starting a copy-back] Select (CL) [Yes] in response to "Are you sure you want to copy data in spare device to the physical device?.".

Go to Step 3-10..



[Confirmation of making an automatic copy-back]

Select (CL) [OK] in response to a message, "After data is copied to the spare device, copy-back will be performed.".



It goes to 3-11 when HDDFAN doors of the object are not closed.

It goes to 3-12 when HDDFAN doors of the object are closed.

REP03-02-210

3-10. <Check starting of copyback>

"Copying..." is displayed.

Select (CL) [OK] in response to "Copying data in spare device to the physical device has been started.".

It goes to 3-11 when HDDFAN doors of the object are not closed.

Replace

[ONL2399i]
Copying data in spare device to the physical device has been started.

OK

It goes to 3-12 when HDDFAN doors of the object are closed.

3-11. <Warning of HDDFAN door open>

(1)

"The FAN Door of HDDFAN-xxx is open. Close the FAN Door, and select [OK].


The FAN Door checking is executed up to 3 times. (n/3)" is displayed.

After the FAN door is closed, select (CL) [OK] in response to this message.

It returns to 3-11 when HDDFAN doors of the object are not closed.

It goes to (2) when HDDFAN doors of the object are closed.

Note: It goes to 3-12 when it cannot be confirmed that the FAN doors are closed in the three times FAN door check.



Rev.2 / Sep.2011, Dec.2011

REP03-02-220

(2)

"A problem in HDDFAN or a FAN Door open might be occurred.

After completing the maintenance process, check the Maintenance or Information window in an error status or an error log is shown on the window, then execute troubleshooting." is displayed.


Select (CL) [OK] in response to this message.



Copyright © 2011, Hitachi, Ltd.

3-12.

When interrupting a copy, select (CL) the [Drive Interrupt] button.



3-13.

Go to POST-PROCEDURE [REP04-01-10].

[DRIVE REPLACEMENT PROCESSING - RDK3]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select P-DEV (status check)
 - ② Specify Replacement
 - 3 Place HDD into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Execute CUDG on P-DEV
 - ② Specify recovery
 - 3 Correction copy



If No Charging of FMD (SIM = 50EXYY) occurs in replacement of a FMD, the FMD ACTIVE LED will change to low-speed blinking. In this case, it takes 90 minutes at most for the FMD ACTIVE LED to go out and for the battery in the FMD to be fully charged.

Rev.0 / Sep.2010


REP03-03-20

Copyright © 2010, Hitachi, Ltd.

1. PRE-PROCESSING of SVP


1-1. <Maintenance window>

Open the 'Maintenance' window according to PRE PROCEDURE A (REP02-01-10). Select (CL) the DKU information [DKU-nn] of the DKU which installs the HDD to be replaced in the 'Maintenance' window.



1-2. <Select HDU>

Select (CL) the HDU information [HDUn] of the HDU which installs the HDD to be replaced.




Rev.0 / Sep.2010

REP03-03-30

1-3. <Select HDD>

Check and select (CL) [nn] to be replaced.




Copyright © 2010, Hitachi, Ltd.

1-4. <Specify replacement of HDD>

Make sure that the "Device Status" is [Failed] or [Warning].

Select (CL) [Replace]-[Replace].



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-03-40

Copyright © 2010, Hitachi, Ltd.

1-5. < Checking the P-DEV status & saving the spare>



CAUTION

When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support division to ask for instructions.


If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Replace

"Checking..." is displayed.

1-6. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).



(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped. [No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-3.

When [No] is selected (CL), returned to Step 1-6.




Rev.0 / Sep.2010

REP03-03-41

Copyright © 2010, Hitachi, Ltd.

1-7. <P-DEV blocking>

Select (CL) [Yes] in response to "Are you sure you want to replace the physical device?".



1-8. <Blocking the Physical device> "Blocking..." is displayed.

Rev.0 / Sep.2010

REP03-03-50


Copyright © 2010, Hitachi, Ltd.

1-9. <Spin down the Physical device> "Spinning down..." is displayed.

Perform the dummy replacement of the displayed SSW(s) when the window is displayed. Select the DKU list and record the target SSW(s) because two or more DKU might be listed.

Select (CL) [Close] button and perform the dummy replacement of the target SSW(s).

Retry the replacement after completing the dummy replacement of SSW.



1-10. <Check shut down LED>



CAUTION


If a wrong HDD is removed, a data loss or a system down may occur.

Check the shut down LED on the HDD to be replaced.

If LED is off, reconfirm the location of the HDD to be replaced with LOCATION SECTION before replacing the hardware.

1-11. <Confirm Removal>

Select (CL) [OK] in response to "Check the location of the disk drive that you want to remove, because an LED of some other disk drives might be on. After the check, remove the disk drive, then select [OK] button. (HDDxnn-nn)" after the unit is removed. (Step 2-3)



1-12. <Replace HDD>

Replace HDD.

Go to "2. HARDWARE REPLACEMENT PROCESSING".

REP03-03-60

2. HARDWARE REPLACEMENT PROCESSING


Location		Function Name of Component	Part Name	HDA Label
DKU	1	Disk Drive (HDD)	HDU700-146KCMSS	S5B-K146SS
				S5C-K146SS
			HDU700-300JCMSS	R5C-J300SS
				R5D-J300SS
				S5B-J300SS
				S5D-J300SS
				S5E-J300SS
			HDU700-300KCMSS	R5C-K300SS
				S5C-K300SS
			HDU700-500HCMSS	S5A-H500SS
				S5B-H500SS
			HDU700-600JCMSS	R5C-J600SS
				R5D-J600SS
				S5C-J600SS
				S5D-J600SS
				S5E-J600SS
			HDU700-900JCMSS	R5D-J900SS
			TIDE 700 700 CIVISS	S5D-J900SS
				S5E-J900SS
			HDU700-1R0HCMSS	S5B-H1R0SS
			HDU700-1R01/CMSS	R5E-J1R2SS
			TIDE 700-TRZJEWISS	S5F-J1R2SS
			HDU700-2R0H2MAT	R2C-H2R0AT
			IIDU 700-2K0H2MAT	R2D-H2R0AT
				R2E-H2R0AT
			HDU700-2R0H3MSS	S2C-H2R0SS
			HDU/00-2K0H3M3S	S2D-H2R0SD
				S2D-H2R0SD S2D-H2R0SS
				S2P-H2R0SS
				S2E-H2R0SS
			LIDUZOO 2DOU2MEE	W2E-H2R0SS
			HDU700-3R0H3MSS	S2D-H3R0SS
				S2E-H3R0SS
			HD1/200 4D01/31/49	W2E-H3R0SS
			HDU700-4R0H3MSS	S2E-H4R0SS
		Flock Dwine (SSD)	LIDITZOO 200MCMCC	W2E-H4R0SS
	2	Flash Drive (SSD)	HDU700-200MCMSS	B5A-M200SS
				R5B-M200SS
			HDU700-200SAMSS	T5A-S200SS
			HDHEO COCCACA	T5C-S200SS
			HDU700-200SCMSS	R5A-S200SS
			11011000 100110150	R5B-S200SS
			HDU700-400MCMSS	B5A-M400SS
			**************************************	R5B-M400SS
			HDU700-400SCMSS	R5A-S400SS
				R5B-S400SS
			HDU700-800MCMSS	B5A-M800SS
			HDU700-400S1MSS	T2A-S400SS
				T2C-S400SS
Front View of FBX DKU	3	Flash Module Drive (FMD)	HDU700-1R6FMSS	H1A-P1R6SS
				H1C-P1R6SS
			HDU700-3R2FMSS	H1B-P3R2SS
				H1C-P3R2SS

Hitachi Proprietary


DKC710I

Copyright © 2011, 2012, Hitachi, Ltd.


Rev.1 / Sep.2011, Oct.2012 REP03-03-61



Front or Rear View of DKU
(In case of 3.5inch Drive)



DKU
(In case of 2.5inch Drive)



Front View of DKU (In case of FMD)

NOTICE:

- Replace the drive in the subsystem in power on status only. Do not replace the drive in power off status.
- Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.
- HDD is a precise component. Be careful in handling HDD to avoid vibration and impact.

- 2-1. Open the FAN door.
- 2-1-1. In case of 3.5inch/2.5inch drive
 - a. Put the stopper of the FAN door into the open able and closable state. (Refer to the INST03-01-160.)
 - b. Loosen the two screws and open the FAN door.
- 2-1-2. In case of FMD
 - a. Go to procedure 2-2. Check the Shut Down LED.





Fig. 3.3.2-1 FAN Door Opening

- 2-2. Check the Shut Down LED.
- 2-2-1. In case of 3.5inch/2.5inch drive
 - a. Check that the Shut Down LED on the HDDPWR corresponding to drive (HDD/SSD) is turned on. Refer to Fig. 3.3.2-2 or 3.3.2-3.



Note: HDDPWR-xyz →HDU No. (0, 1, 2,, 7) →DKU No. (0, 1, 2,, 7) →DKC No. (0, 1)

Fig. 3.3.2-2 Checking of Shut Down LED (In case of 3.5inch Drive)

Copyright © 2010, Hitachi, Ltd.






Fig. 3.3.2-3 Checking of Shut Down LED (In case of 2.5inch Drive)


Rev.0 / Oct.2012

REP03-03-91

Copyright © 2012, Hitachi, Ltd.

2-2-2. In case of FMD

a. Check that the Shut Down LED on drive is turned on.



Front View of FBX DKU




Fig. 3.3.2-3A Checking of Shut Down LED (In case of FMD)

- 2-3. Remove the drive.
- 2-3-1. In case of 3.5inch drive.
 - a. Push up the stopper of drive, and bring the handle down. Don't pull the handle during this process.
 - b. Push down the handle.
 - c. Pull out the drive.
 - d. Fig. 3.3.2-5 illustrates the case of wrong procedure.





Fig. 3.3.2-5 Removal of Drive (Wrong Procedure)

2-3-2. In case of 2.5inch drive.



- a. Push the stopper of drive, and bring the handle down. Don't pull the handle during this process.
- b. Push down the handle.
- c. Pull out the drive.
- d. Fig. 3.3.2-7 illustrates the case of wrong procedure.




Fig. 3.3.2-6 Removal of Drive

Rev.0 / Sep.2010

REP03-03-111

Copyright © 2010, Hitachi, Ltd.




Fig. 3.3.2-7 Removal of Drive (Wrong Procedure)

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd.

REP03-03-112

2-3-3. In case of FMD

Notice: When the FMD is removed in replacing procedure, the fans of the DKUPS equipped in the rear of the FBX DKU rotate at the highest speed. When the spare FMD is installed, the fans of the DKUPS rotate at the speed suitable for environmental temperature.

- a. Pull the stopper of the drive handle toward you to have the lock off.
- b. Tilt the handle toward you, and then remove the drive by pulling it out taking care not to apply a shock to it.

Note: When handling the drive, hold the rail side because the shield spring is subject to breakage.






Fig. 3.3.2-7A Removal of Drive (In case of FMD)

REP03-03-113

c. Check whether a failure of the battery built in the FMD has occurred by using the flowchart below. If a battery failure has occurred, remove the battery from the FMD. If no battery failure has occurred, go to Procedure 2-4.





Copyright © 2014, Hitachi, Ltd. REP03-03-115

d. FMD Battery Removing Procedure

(d)-1 Remove 4 Screws (SB310N) on the bottom side of FMD by using cross-head screw driver.




Fig. 3.3.2-7B Removing Screws

(d)-2 Remove Top Cover and Bottom Cover.




Fig. 3.3.2-7C Removing Covers

(d)-3 Remove 2 sets of Tapping-screw and Washer by using cross-head screw driver.




Fig. 3.3.2-7D Removing Tapping-screws and Washers

(d)-4 Move the Battery to the bezel side and disconnect the Battery from the circuit board.




Fig. 3.3.2-7E Disconnecting from Connector

(d)-5 Remove the Battery to the bottom side of FMD. (After the connector comes off, battery is lowered below.)




Fig. 3.3.2-7F Removing Battery

- (d)-6 Attach Top Cover and Bottom Cover.
- (d)-7 Attach 4 Screws (SB310N) on the bottom side of FMD.




Fig. 3.3.2-7G Reassembling FMD

(d)-8 Dispose of the Tapping-screws, Washers and Battery removed in procedures (d)-3 and (d)-5.


When dispose of the Battery, follow the directions given by the local law where the product is used.

REP03-03-120

2-4. Check and handling of the drive.


(1) <Confirm Removal>


Select (CL) [OK] in response to "Check the location of the disk drive that you want to remove, because an LED of some other disk drives might be on. After the check, remove the disk drive, then select [OK] button. (HDDxnn-nn)" after the unit is removed. (Step 2-3)




(2) < Confirm Insertion>


"Check the location of the disk drive that you want to insert. After the check, insert the disk drive, then select [OK] button. (HDDnnn-nn)" is displayed.







2-5. Install the drive.



Instruction for the insertion and removal of the 2.5-inch drive:

The upper part of HDDPWR might come in contact with the lower part of the drive, and it becomes an obstruction of the insertion and removal at the time of the 2.5-inch drive insertion and removal. In this case, avoid the HDDPWR by lifting the drive lightly.

Caution – Back Board, or drive connector or drive handle may be damaged when the drive is forcibly inserted.

If the drive cannot be easily inserted until the claws on the handle reach the DKU, or if the handle binds or stops before it can be locked, then remove the drive and perform inspection:

- a) Check the drive slot in DKU to be free and clear of obstructions.
- b) Check connector on back board for visible defects.
- c) Inspect connector on drive for visible defects.
- d) Inspect drive top and bottom guide for defects. Note special alignment tab on bottom guide on some drive. A damaged tab can bind on the lower slot guides in DKU.
- e) During installation make sure the drive is inserted in alignment with slot guides.
- f) Check upper rear spring on SSD has been removed. (This applies only on SSD) Reinsert drive after inspections have passed.


REP03-03-131

2-5-1. In case of 3.5inch/2.5inch drive

- Insert the drive into the HDU holding its handle. (Insert the canister until the claws that are located at the bottom of the handle come in contact with the front side of the HDU.)
- b. Turn the handle at a stroke by pushing its top with your thumb. (Turn the handle until it latches with the stopper. Do not stop the handle on its way of turning.)

a. Insert the HDD/SSD canister into the HDU holding its handle.

A gap exists between the connectors.



b. Turn the handle at a stroke by pushing its top with your thumb. (Do not stop the handle on its way of turning.)




Fig. 3.3.2-8 Method of Installing Drive

- c. Close the FAN door and tighten the screws. (Refer to Fig. 3.3.2-1.)
- d. Put the FAN door stopper into the neutral state.

Rev.0 / Oct.2012

REP03-03-132

Copyright © 2012, Hitachi, Ltd.

2-5-2. In case of FMD

Note: When handling the drive, hold the rail side because the shield spring is subject to breakage.

- a. Open the handle fully and fit the drive in the guide rail and slide it in the direction shown by the arrow not to give a shock.
- b. Push the drive in until it reaches the position where a hook of the handle can be entered into the square hole on a frame.
- c. Pull the stopper lightly and close the handle, and then press the stopper to have the lock on. If the handle is closed in the state where the hook of the handle cannot enter into the square hole, the drive cannot be installed correctly because it runs into the frame of the FBX DKU.




Fig. 3.3.2-9 Installation of Drive (In case of FMD)

2-6. Go to "3. POST-PROCESSING of SVP".

REP03-03-140


Before starting the <Check the beginning of recovery> operation in POST-PROCEDURES of SVP, be sure to insert a removable media for dump, collect failure information, and return the removable media with the failed HDD.

A dump removable media is attached with a Spare HDD.

POST-PROCESSING of SVP


3-1. <Confirm Insertion>


"Check the location of the disk drive that you want to insert. After the check, insert the disk drive, then select [OK] button. (HDDnnnnn)"is displayed.



3-2. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].





"Insert a removable media for gathering error information and select [OK].

The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.


Select a Client PC arbitrary drive, and select (CL) [Ok].

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the

screen, and select an arbitrary drive letter from the pull-down menu.

The drive letter becomes the drive letter of console PC connected with SVP.



Rev.1 / Sep.2010, Oct.2010


REP03-03-150

Copyright © 2010, Hitachi, Ltd.

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.


Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.



Select (CL) [Save] when saving a file in a specified directory. It returns to the drive selection screen when [Cancel] is selected (CL).

3-3. < Copy of the error information>

The error information is copied onto media.



"Remove the media." is displayed. Select (CL) [OK].



3-4. <Spin up the Physical Drive> "Spinning up..." is displayed.

3-5. <DKU INLINE>

"DKU INLINE is now running..." is displayed.

Rev.0 / Sep.2010

REP03-03-160


3-6. < Replacement of the DKU micro-program>

When the revision of the DKU micro-program in the SVP hard disk is newer than that in the PDEV, the following message appears on the screen.

The message "Exchanging DKU micro-program..." appears.

- 3-7. < Restore Physical Drive>
 - "Restoring..." is displayed.
- 3-8. <Check the Physical Drive>
 "Checking..." is displayed.

 Device is still blocked.
- 3-9. <Check the beginning of correction copy> Select (CL) [Yes] in response to "Are you sure you want to correct data in the physical device?".



Copyright © 2010, Hitachi, Ltd.

3-10. <Correct data>

"Correcting..." is displayed.

OΚ

REP03-03-170

3-11. <Check the starting of Correction copy> Select (CL) [OK] in response to "Correcting data in the physical device has been started.".

It goes to 3-12 when HDDFAN doors of the object are not closed.

It goes to 3-13 when HDDFAN doors of the object are closed.



The FAN Door of HDDFAN-000 is open.

The FAN Door checking is executed up to 3 times.(1/3).

Close the FAN Door, and select [OK].

3-12. <Warning of HDDFAN door open>

(1)

"The FAN Door of HDDFAN-xxx is open. Close the FAN Door, and select [OK]. The FAN Door checking is executed up to 3 times. (n/3)" is displayed.

After the FAN door is closed, select (CL) [OK] in response to this message.

It returns to 3-12 when HDDFAN doors of the object are not closed.

It goes to 3-13 when HDDFAN doors of the object are closed.

Note: It goes to (2) when it cannot be confirmed that the FAN doors are closed in the three times FAN door check.

Replace

[ONL4288i]

(2)

"A problem in HDDFAN or a FAN Door open might be occurred.

After completing the maintenance process, check the Maintenance or Information window in an error status or an error log is shown on the window, then execute troubleshooting." is displayed.

Select (CL) [OK] in response to this message.



Rev.2 / Mar.2011, Sep.2011

REP03-03-180


Copyright © 2010, 2011, Hitachi, Ltd.

3-13. <Check the end of P-DEV recovery> Select (CL) [OK] in response to "Replace finished.".



3-14.

When interrupting the correction copy, select the PDEV to which the copy is being made and select (CL) the [Drive Interrupt] button.



3-15.

Go to POST-PROCEDURE [REP04-01-10].

[DRIVE REPLACEMENT PROCESSING - RDK4]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select P-DEV (status check)
 - ② Specify Replacement
 - 3 Block parity group (enter password)
 - Restore the Logical Device
 - S Place HDD into unpluggable state
 - © Replace HDD
 - Perform steps ② to ⑤ on blocked drives in parity group
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Execute CUDG on P-DEV
 - ② Perform L-DEV formatting on P-DEV
 - ③ Recover with backup data

A CAUTION

This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss and requires an input of a password. Ask the technical support division about the appropriateness of the operation, and input the password after getting an approval of executing the operation.

A CAUTION

If No Charging of FMD (SIM = 50EXYY) occurs in replacement of a FMD, the FMD ACTIVE LED will change to low-speed blinking. In this case, it takes 90 minutes at most for the FMD ACTIVE LED to go out and for the battery in the FMD to be fully charged.

Rev.0 / Sep.2010


REP03-04-20

Copyright © 2010, Hitachi, Ltd.

1. PRE-PROCESSING of SVP


1-1. <Maintenance window>

Open the 'Maintenance' window according to PRE PROCEDURE A (REP02-01-10). Select (CL) the DKU information [DKU-nn] of the DKU which installs the HDD to be replaced in the 'Maintenance' window.



1-2. <Select HDU>

Select (CL) the HDU information [HDUn] of the HDU which installs the HDD to be replaced.




Rev.0 / Sep.2010

REP03-04-30

1-3. <Select HDD>

Check and select (CL) [nn] to be replaced.




Copyright © 2010, Hitachi, Ltd.

1-4. <Specify replacement of HDD>

Make sure that the "Device Status" is
[Failed].

Select (CL) [Replace]-[Replace].



Rev.0 / Sep.2010

REP03-04-40

Copyright © 2010, Hitachi, Ltd.

1-5. <Confirm lost data>



A CAUTION

Executing this operation may cause a serious error such as a system down or a data loss. Accordingly, confirmation of the appropriateness of the operation and input of a password on the succeeding password input screen is required.

Select (CL) [No] in response to "Redundancy is lost and blocking this part stops subsystem functionality. Do you want to stop this process?".



1-6. <Enter password>



A CAUTION

This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss and requires an input of a password. Ask the technical support division about the appropriateness of the operation, and input the password after getting an approval of executing the operation.

Enter the password in response to "Ask the Technical Support Division about the appropriateness of this operation, and enter the password." and select (CL) [OK]. Password is needed for this operation.



Rev.0 / Sep.2010

REP03-04-50

1-7. < Checking the P-DEV status>

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

"Checking..." is displayed.

When "You can restore the replaced physical device by restoring logical devices. Do you continue to this operation?" is displayed, PDEV is automatically recovered by recovering LDEV.



Copyright © 2010, Hitachi, Ltd.

When you replace PDEV and format LDEV, please select (CL) [Yes].

When you want to change LDEV into a collection access state for the purpose of data backup, please select [No] and go to LDEV recovery for multiple PDEV failures (step 1-7-1).

Rev.0 / Sep.2010

REP03-04-60

Copyright © 2010, Hitachi, Ltd.

1-7-1. Restore the Logical Device


Notice:

Executing this operation may cause a serious error such as a system down or a data loss. Accordingly, confirmation of the appropriateness of the operation and input of a password on the succeeding password input screen is required.

(1) <Preparation>
Close each menu of the starting SVP entirely.

(2) <Start>


Change the mode to [Modify Mode].



Select (CL) the [Maintenance] in the 'SVP' window.



Select (CL) [LDEV...] on the dialog bar in the 'Maintenance' window.



Rev.0 / Sep.2010

REP03-04-70


Copyright © 2010, Hitachi, Ltd.

(3) <Selection of Logical Device>

Notice:

Be careful enough not to make a mistake in selecting a device.

Select (CL) the target device (or group) from the list in the right of the 'Logical Device' window.



(4) <Execution>
Select (CL) [Restore] on the tool bar in the 'Logical Device' window.




Rev.0 / Sep.2010

REP03-04-80

(5) <Check>

Check the device (or group) to be restored in the 'LDEV Maintenance' window, and select (CL) [Restore].



Copyright © 2010, Hitachi, Ltd.

(6) <Selection of Recovery Processing>
Select (CL) [Restore Type] in the 'Restore Logical Devices' window, and select (CL) [OK].

"Normal Restoration"

"Forcible Restoration"



■Normal Restoration

Explanation:

In case LDEV(s) is (are) blocked due to multiple PDEV failures in one parity group, this option spins up the PDEV which was blocked last to restore the LDEV(s).

When to choose this option?

Use this option when you would like to restore the LDEV(s) that is (are) blocked due to multiple PDEV failures in one parity group.

Notice:

The purpose of this action is to restore the PDEV blocked last and restore the parity group status to "correction access". Therefore do not replace or self-replace any failed HDD in the parity group before performing this action.

Rev.0 / Sep.2010

REP03-04-90

Copyright © 2010, Hitachi, Ltd.

■ Forcible Restoration

Explanation:

This option restores only the LDEV status forcibly without considering data consistency etc.

When all PDEV status in the parity group is "normal", the LDEV status is changed from "blocked" to "normal".

When to choose this option?

In case "Normal Restoration" cannot restore LDEV, use this option by following the instructions of the technical support division.

After PDEV is manually restored, the LDEV status is changed to "normal" forcibly.

Notice:

The data consistency may not be guaranteed. Contact the technical support division to ask for instructions.

(7) <Password Input>


This operation is required only when "Forcible Restoration" is selected in Step (6).

Notice:

This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss and requires an input of a password. Ask the technical support division about the appropriateness of the operation, and input the password after getting an approval of executing the operation.

Corresponding to the following message, enter the password and select (CL) the [OK] button.

"Ask the Technical Support Division about the appropriateness of this operation, and enter the password."



Rev.0 / Sep.2010

Copyright © 2010, Hitachi, Ltd. REP03-04-100

(8) <Processing Wait>

The following message is displayed.

"Restoring the logical device..."


In case that, "Normal Restoration" is selected in Step (6).

If multiple PDEV failures, the restoration processing of the recoverable PDEV is performed here.

This processing cannot recover it when the following message is displayed.

"The replaced physical devices could not spin up."


Perform the procedure RDK4 refer to REP01-170.



(9) <Completion Check>

When the restoration is completed, the following message is displayed. Select (CL) [OK].

"Restoring the logical device is completed."



(10) < Check of Device Status>

Check the target device status in the 'Logical Device' window.

(11) <Post-processing>

Close the 'Logical Device' window.

Close the 'Maintenance' window.

Change the mode to [View Mode].

Replace

Replace

[ONL4271i]

Rev.0 / Sep.2010

REP03-04-110

1-8. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

[ONL4270W]

To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.

Copyright © 2010, Hitachi, Ltd.

(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).

(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-3.

When [No] is selected (CL), returned to Step 1-8.




Did you put on a wrist strap on your wrist?

Yes

Νo

1-9. <P-DEV blocking>

Select (CL) [Yes] in response to "Are you sure you want to replace the physical device?".



1-10. <Blocking the Physical device> "Blocking..." is displayed.

Rev.0 / Sep.2010


REP03-04-120

1-11. <Spin down the Physical device>
"Spinning down..." is displayed.
The Shut down LED is lit.

Perform the dummy replacement of the displayed SSW(s) when the window is displayed. Select the DKU list and record the target SSW(s) because two or more DKU might be listed.

Select (CL) [Close] button and perform the dummy replacement of the target SSW(s).


Retry the replacement after completing the dummy replacement of SSW.



Copyright © 2010, Hitachi, Ltd.

1-12. <Confirm Removal>

Select (CL) [OK] in response to "Check the location of the disk drive that you want to remove, because an LED of some other disk drives might be on. After the check, remove the disk drive, then select [OK] button. (HDDxnn-nn)" after the unit is removed. (Step 2-3)



1-13. <Replace HDD>

Replace HDD.


Go to "2. HARDWARE REPLACEMENT PROCESSING".

Rev.13 / May.2014, Aug.2014


2. HARDWARE REPLACEMENT PROCESSING

Location		Function Name of Component	Part Name	HDA Label
DKU	1	Disk Drive (HDD)	HDU700-146KCMSS	S5B-K146SS
				S5C-K146SS
			HDU700-300JCMSS	R5C-J300SS
				R5D-J300SS
				S5B-J300SS
				S5D-J300SS
				S5E-J300SS
			HDU700-300KCMSS	R5C-K300SS
				S5C-K300SS
			HDU700-500HCMSS	S5A-H500SS
				S5B-H500SS
			HDU700-600JCMSS	R5C-J600SS
				R5D-J600SS
				S5C-J600SS
				S5D-J600SS
				S5E-J600SS
			HDU700-900JCMSS	R5D-J900SS
			TIDE 700 700 CIVISS	S5D-J900SS
				S5E-J900SS
			HDU700-1R0HCMSS	S5B-H1R0SS
			HDU700-1R01/CMSS	R5E-J1R2SS
			TIDE 700-TRZJEWISS	S5F-J1R2SS
			HDU700-2R0H2MAT	R2C-H2R0AT
			IIDU 700-2K0H2MAT	R2D-H2R0AT
				R2E-H2R0AT
			HDU700-2R0H3MSS	S2C-H2R0SS
			HDU/00-2K0H3M3S	S2D-H2R0SD
				S2D-H2R0SD S2D-H2R0SS
				S2P-H2R0SS
				S2E-H2R0SS
			LIDUZOO 2DOU2MEE	W2E-H2R0SS
			HDU700-3R0H3MSS	S2D-H3R0SS
				S2E-H3R0SS
			HD1/200 4D01/31/49	W2E-H3R0SS
			HDU700-4R0H3MSS	S2E-H4R0SS
		Flock Dwine (SSD)	LIDITZOO 200MCMCC	W2E-H4R0SS
	2	Flash Drive (SSD)	HDU700-200MCMSS	B5A-M200SS
				R5B-M200SS
			HDU700-200SAMSS	T5A-S200SS
			HDHEO COCCACA	T5C-S200SS
			HDU700-200SCMSS	R5A-S200SS
			11011000 100110150	R5B-S200SS
			HDU700-400MCMSS	B5A-M400SS
			**************************************	R5B-M400SS
			HDU700-400SCMSS	R5A-S400SS
				R5B-S400SS
			HDU700-800MCMSS	B5A-M800SS
			HDU700-400S1MSS	T2A-S400SS
				T2C-S400SS
Front View of FBX DKU	3	Flash Module Drive (FMD)	HDU700-1R6FMSS	H1A-P1R6SS
				H1C-P1R6SS
			HDU700-3R2FMSS	H1B-P3R2SS
				H1C-P3R2SS


Hitachi Proprietary



Front or Rear View of DKU
(In case of 3.5inch Drive)



DKU
(In case of 2.5inch Drive)



Front View of DKU (In case of FMD)

NOTICE:

- Replace the drive in the subsystem in power on status only. Do not replace the drive in power off status.
- Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.
- HDD is a precise component. Be careful in handling HDD to avoid vibration and impact.

REP03-04-140

- 2-1. Open the FAN door.
- 2-1-1. In case of 3.5inch/2.5inch drive
 - a. Put the stopper of the FAN door into the open able and closable state. (Refer to the INST03-01-160.)
 - b. Loosen the two screws and open the FAN door.
- 2-1-2. In case of FMD
 - a. Go to procedure 2-2. Check the Shut Down LED.





Fig. 3.4.2-1 FAN Door Opening

REP03-04-150

- 2-2. Check the Shut Down LED.
- 2-2-1. In case of 3.5inch/2.5inch drive
 - a. Check that the Shut Down LED on the HDDPWR corresponding to drive (HDD/SSD) is turned on. Refer to Fig. 3.4.2-2 or 3.4.2-3.






Fig. 3.4.2-2 Checking of Shut Down LED (In case of 3.5inch Drive)




Fig. 3.4.2-3 Checking of Shut Down LED (In case of 2.5inch Drive)


→DKC No. (0, 1)

Rev.0 / Oct.2012

Copyright © 2012, Hitachi, Ltd. REP03-04-161

2-2-2. In case of FMD

a. Check that the Shut Down LED on drive is turned on.



Front View of FBX DKU




Fig. 3.4.2-3A Checking of Shut Down LED (In case of FMD)

REP03-04-170

- 2-3. Remove the drive.
- 2-3-1. In case of 3.5inch drive.
 - a. Push up the stopper of drive, and bring the handle down. Don't pull the handle during this process.
 - b. Push down the handle.
 - c. Pull out the drive.
 - d. Fig. 3.4.2-5 illustrates the case of wrong procedure.





Fig. 3.4.2-5 Removal of Drive (Wrong Procedure)

2-3-2. In case of 2.5inch drive.



- a. Push the stopper of drive, and bring the handle down. Don't pull the handle during this process.
- b. Push down the handle.
- c. Pull out the drive.
- d. Fig. 3.4.2-7 illustrates the case of wrong procedure.




Fig. 3.4.2-6 Removal of Drive

REP03-04-181




Fig. 3.4.2-7 Removal of Drive (Wrong Procedure)

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd.

REP03-04-182

2-3-3. In case of FMD

Notice: When the FMD is removed in replacing procedure, the fans of the DKUPS equipped in the rear of the FBX DKU rotate at the highest speed. When the spare FMD is installed, the fans of the DKUPS rotate at the speed suitable for environmental temperature.

- a. Pull the stopper of the drive handle toward you to have the lock off.
- b. Tilt the handle toward you, and then remove the drive by pulling it out taking care not to apply a shock to it.

Note: When handling the drive, hold the rail side because the shield spring is subject to breakage.





Fig. 3.4.2-7A Removal of Drive (In case of FMD)

Rev.0 / Feb.2014


REP03-04-183

Copyright © 2014, Hitachi, Ltd.

c. Check whether a failure of the battery built in the FMD has occurred by using the flowchart below. If a battery failure has occurred, remove the battery from the FMD. If no battery failure has occurred, go to Procedure 2-4.



REP03-04-184



- d. FMD Battery Removing Procedure
 - (d)-1 Remove 4 Screws (SB310N) on the bottom side of FMD by using cross-head screw driver.




Fig. 3.4.2-7B Removing Screws

(d)-2 Remove Top Cover and Bottom Cover.




Fig. 3.4.2-7C Removing Covers

(d)-3 Remove 2 sets of Tapping-screw and Washer by using cross-head screw driver.




Fig. 3.4.2-7D Removing Tapping-screws and Washers

(d)-4 Move the Battery to the bezel side and disconnect the Battery from the circuit board.




Fig. 3.4.2-7E Disconnecting from Connector

(d)-5 Remove the Battery to the bottom side of FMD. (After the connector comes off, battery is lowered below.)




Fig. 3.4.2-7F Removing Battery

- (d)-6 Attach Top Cover and Bottom Cover.
- (d)-7 Attach 4 Screws (SB310N) on the bottom side of FMD.




Fig. 3.4.2-7G Reassembling FMD

(d)-8 Dispose of the Tapping-screws, Washers and Battery removed in procedures (d)-3 and (d)-5.


When dispose of the Battery, follow the directions given by the local law where the product is used.

REP03-04-190

2-4. Check and handling of the drive.


(1) <Confirm Removal>


Select (CL) [OK] in response to "Check the location of the disk drive that you want to remove, because an LED of some other disk drives might be on. After the check, remove the disk drive, then select [OK] button. (HDDxnn-nn)" after the unit is removed. (Step 2-3)




(2) < Confirm Insertion>


"Check the location of the disk drive that you want to insert. After the check, insert the disk drive, then select [OK] button. (HDDnnn-nn)" is displayed.







2-5. Install the drive.



Instruction for the insertion and removal of the 2.5-inch drive:

The upper part of HDDPWR might come in contact with the lower part of the drive, and it becomes an obstruction of the insertion and removal at the time of the 2.5-inch drive insertion and removal. In this case, avoid the HDDPWR by lifting the drive lightly.

Caution – Back Board, or drive connector or drive handle may be damaged when the drive is forcibly inserted.

If the drive cannot be easily inserted until the claws on the handle reach the DKU, or if the handle binds or stops before it can be locked, then remove the drive and perform inspection:

- a) Check the drive slot in DKU to be free and clear of obstructions.
- b) Check connector on back board for visible defects.
- c) Inspect connector on drive for visible defects.
- d) Inspect drive top and bottom guide for defects. Note special alignment tab on bottom guide on some drive. A damaged tab can bind on the lower slot guides in DKU.
- e) During installation make sure the drive is inserted in alignment with slot guides.
- f) Check upper rear spring on SSD has been removed. (This applies only on SSD) Reinsert drive after inspections have passed.


REP03-04-201

2-5-1. In case of 3.5inch/2.5inch drive

- a. Insert the drive into the HDU holding its handle.
 (Insert the canister until the claws that are located at the bottom of the handle come in contact with the front side of the HDU.)
- b. Turn the handle at a stroke by pushing its top with your thumb.(Turn the handle until it latches with the stopper. Do not stop the handle on its way of turning.)

a. Insert the HDD/SSD canister into the HDU holding its handle.

A gap exists between the connectors.



b. Turn the handle at a stroke by pushing its top with your thumb. (Do not stop the handle on its way of turning.)




Fig. 3.4.2-8 Method of Installing Drive

- c. Close the FAN door and tighten the screws. (Refer to Fig. 3.4.2-1.)
- d. Put the FAN door stopper into the neutral state.

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd. REP03-04-202

2-5-2. In case of FMD

Note: When handling the drive, hold the rail side because the shield spring is subject to breakage.

- Open the handle fully and fit the drive in the guide rail and slide it in the direction shown by the arrow not to give a shock.
- b. Push the drive in until it reaches the position where a hook of the handle can be entered into the square hole on a frame.
- Pull the stopper lightly and close the handle, and then press the stopper to have the lock on. If the handle is closed in the state where the hook of the handle cannot enter into the square hole, the drive cannot be installed correctly because it runs into the frame of the FBX DKU.




Fig. 3.4.2-9 Installation of Drive (In case of FMD)

2-6. Go to "3. POST-PROCESSING of SVP".

Rev.1 / Sep.2010, Oct.2010

REP03-04-210

Copyright © 2010, Hitachi, Ltd.




Before starting the <Check the beginning of recovery> operation in POST-PROCEDURES of SVP, be sure to insert a removable media for dump, collect failure information, and return the removable media with the failed HDD.

A dump removable media is attached with a Spare HDD.

3. POST-PROCESSING of SVP


3-1. <Confirm Insertion>


"Check the location of the disk drive that you want to insert. After the check, insert the disk drive, then select [OK] button. (HDDnnnnnn)"is displayed.



3-2. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].





Rev.0 / Oct.2010

REP03-04-211

Copyright © 2010, Hitachi, Ltd.

"Insert a removable media for gathering error information and select [OK].

The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.


Select a Client PC arbitrary drive, and select (CL) [Ok].

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the

screen, and select an arbitrary drive letter from the pull-down menu.

The drive letter becomes the drive letter of console PC connected with SVP.




REP03-04-220

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.


Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.



Select (CL) [Save] when saving a file in a specified directory. It returns to the drive selection screen when [Cancel] is selected (CL).

3-3. < Copy of the error information>

The error information is copied onto media.



"Remove the media." is displayed. Select (CL) [OK].



Rev.0 / Sep.2010

REP03-04-230

Copyright © 2010, Hitachi, Ltd.

3-4. <Spin up the Physical Drive> "Spinning up..." is displayed.

3-5. < DKU INLINE>

"DKU INLINE is now running..." is displayed.

3-6. < Replacement of the DKU micro-program>

When the revision of the DKU micro-program in the SVP hard disk is newer than that in the PDEV, the following message appears on the screen.

The message "Exchanging DKU micro-program..." appears.

3-7. < Restore Physical Drive>

"Restoring..." is displayed.

3-8. < Check the Drive status>

"Checking..." is displayed.


3-9. < Correction Copy disable message>



CAUTION

If a blocked HDD exists in the same parity group, replace the HDD. After confirming that "NORMAL" is indicated for all the HDDs in the same parity group, execute an L-DEV formatting following the procedure below.


Select (CL) [OK] in response to "Correcting data in the physical device could not be done.".



REP03-04-240

(1)

"The FAN Door of HDDFAN-xxx is open. Close the FAN Door, and select [OK]. The FAN Door checking is executed up to 3 times. (n/3)" is displayed. After the FAN door is closed, select (CL) [OK] in response to this message.



It returns to (1) when HDDFAN doors of the object are not closed.

It goes to 3-10 when HDDFAN doors of the object are closed.


Note: It goes to (2) when it cannot be confirmed that the FAN doors are closed in the three times FAN door check.

(2)

"A problem in HDDFAN or a FAN Door open might be occurred.

After completing the maintenance process, check the Maintenance or Information window in an error status or an error log is shown on the window, then execute troubleshooting." is displayed.

Select (CL) [OK] in response to this message.



3-10. <Select [Logical Device]>




CAUTION

Before you perform following steps, be sure to call T.S.D.

Data stored in Logical Device will be lost due to formatting Logical Device.


Select (CL) [Logical Device] from [Maintenance].



Rev.0 / Sep.2010


REP03-04-250

3-11. <Logical Device Status> Select (CL) [Format].



Copyright © 2010, Hitachi, Ltd.

3-12. <Format Logical Device> Select (CL) [Format] or [Quick Format]. If the target LDEV is not blocked, return to 'Logical Device' dialog box.



3-13. < Caution message for DATA lost>



CAUTION

This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss and requires an input of a password. Ask the technical support division about the appropriateness of the operation, and input the password after getting an approval of executing the operation.

"Data in the specified logical device may be lost due to this operation. You need the password to continue." is displayed. Enter the password and select (CL) [OK].




Rev.2 / Oct.2010, Sep.2011

Copyright © 2010, 2011, Hitachi, Ltd.


REP03-04-260

- 3-14. <Confirmation of processing progress>
 - In case of LDEV formatting "Formatting logical devices..." is displayed.




Format


In case of Quick Format
 "Preparing Quick Format logical devices..." is
 displayed.



- 3-15. <Confirmation of processing end>
 - In case of LDEV formatting Select (CL) [OK] in response to "Formatting was finished.".



In case of Quick Format
 Select (CL) [OK] in response to
 "Preparing Quick Format processing has
 finished.".



Rev.1 / Sep.2010, Sep.2011

REP03-04-270

3-16. < Recover data >

Ask the customer for recovering data with backup data. Go to POST-PROCEDURE [REP04-01-10].

REP03-04-270

Copyright © 2010, 2011, Hitachi, Ltd.

[DRIVE REPLACEMENT PROCESSING - RDK5]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select P-DEV (status check)
 - ② Specify Replacement
 - 3 Place HDD into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Execute CUDG on P-DEV
 - ② Specify recovery

A CAUTION

If No Charging of FMD (SIM = 50EXYY) occurs in replacement of a FMD, the FMD ACTIVE LED will change to low-speed blinking. In this case, it takes 90 minutes at most for the FMD ACTIVE LED to go out and for the battery in the FMD to be fully charged.

Rev.0 / Sep.2010


REP03-05-20

Copyright © 2010, Hitachi, Ltd.

1. PRE-PROCESSING of SVP


1-1. <Maintenance window>

Open the 'Maintenance' window according to PRE PROCEDURE A (REP02-01-10). Select (CL) the DKU information [DKU-nn] of the DKU which installs the HDD to be replaced in the 'Maintenance' window.



1-2. <Select HDU>

Select (CL) the HDU information [HDUn] of the HDU which installs the HDD to be replaced.




Copyright © 2010, 2014, Hitachi, Ltd.

Rev.1 / Sep.2010, Aug.2014 **REP03-05-30**

1-3. <Select HDD>

Check and select (CL) [nn] to be replaced.




1-4. <Specify replacement of HDD>

Make sure that the "Device Status" is [Failed] or [Warning].

Note: When exchanging in a state where the spare drive is normal like preventive maintenance, confirm "Device Status" is [Spare].

Select (CL) [Replace]-[Replace].



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-05-40

Copyright © 2010, Hitachi, Ltd.

1-5. < Checking the P-DEV status & saving the spare>



CAUTION


When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

"Checking..." is displayed.

1-6. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).



(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped. [No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-3.


When [No] is selected (CL), returned to Step 1-6.



Rev.0 / Sep.2010 REP03-05-41 Copyright © 2010, Hitachi, Ltd.

1-7. <P-DEV blocking>

Select (CL) [Yes] in response to "Are you sure you want to replace the physical device?".



1-8. <Blocking the Physical device> "Blocking..." is displayed.

Rev.0 / Sep.2010


REP03-05-50

1-9. <Spin down the Physical device> "Spinning down..." is displayed.

> Perform the dummy replacement of the displayed SSW(s) when the window is displayed. Select the DKU list and record the target SSW(s) because two or more DKU might be listed.

Select (CL) [Close] button and perform the dummy replacement of the target SSW(s).

Retry the replacement after completing the dummy replacement of SSW.



Copyright © 2010, Hitachi, Ltd.

1-10. <Check shut down LED>



CAUTION


If a wrong HDD is removed, a data loss or a system down may occur.

Check the shut down LED on the HDD to be replaced.

If LED is off, reconfirm the location of the HDD to be replaced with LOCATION SECTION before replacing the hardware.

1-11. <Confirm Removal>

Select (CL) [OK] in response to "Check the location of the disk drive that you want to remove, because an LED of some other disk drives might be on. After the check, remove the disk drive, then select [OK] button. (HDDxnn-nn)" after the unit is removed. (Step 2-3)



1-12. <Replace HDD>

Replace HDD.

Go to "2. HARDWARE REPLACEMENT PROCESSING".


Rev.13 / May.2014, Aug.2014

2. HARDWARE REPLACEMENT PROCESSING


Location		Function Name of Component	Part Name	HDA Label
DKU	1	Disk Drive (HDD)	HDU700-146KCMSS	S5B-K146SS
		, ,		S5C-K146SS
			HDU700-300JCMSS	R5C-J300SS
				R5D-J300SS
				S5B-J300SS
				S5D-J300SS
				S5E-J300SS
			HDU700-300KCMSS	R5C-K300SS
			TIDE 700 SOOKENISS	S5C-K300SS
			HDU700-500HCMSS	S5A-H500SS
			HD0700-300HCM33	S5B-H500SS
			LIDITZOO COOLCINES	III
			HDU700-600JCMSS	R5C-J600SS
				R5D-J600SS
				S5C-J600SS
				S5D-J600SS
				S5E-J600SS
			HDU700-900JCMSS	R5D-J900SS
				S5D-J900SS
				S5E-J900SS
			HDU700-1R0HCMSS	S5B-H1R0SS
			HDU700-1R2JCMSS	R5E-J1R2SS
				S5F-J1R2SS
			HDU700-2R0H2MAT	R2C-H2R0AT
				R2D-H2R0AT
				R2E-H2R0AT
			HDU700-2R0H3MSS	S2C-H2R0SS
				S2D-H2R0SD
				S2D-H2R0SS
				S2P-H2R0SS
				S2E-H2R0SS
				W2E-H2R0SS
			HDU700-3R0H3MSS	S2D-H3R0SS
			11D0700-3K0113WISS	S2E-H3R0SS
			HDU700-4R0H3MSS	W2E-H3R0SS S2E-H4R0SS
			HDU /00-4R0H3M3S	
		El 1 D ; (ddD)	11011700 2001/01/00	W2E-H4R0SS
	2	Flash Drive (SSD)	HDU700-200MCMSS	B5A-M200SS
			HD11700 2003 13 432	R5B-M200SS
			HDU700-200SAMSS	T5A-S200SS
			***************************************	T5C-S200SS
			HDU700-200SCMSS	R5A-S200SS
				R5B-S200SS
			HDU700-400MCMSS	B5A-M400SS
				R5B-M400SS
			HDU700-400SCMSS	R5A-S400SS
				R5B-S400SS
			HDU700-800MCMSS	B5A-M800SS
			HDU700-400S1MSS	T2A-S400SS
				T2C-S400SS
Front View of FBX DKU	3	Flash Module Drive (FMD)	HDU700-1R6FMSS	H1A-P1R6SS
				H1C-P1R6SS
			HDU700-3R2FMSS	H1B-P3R2SS
				H1C-P3R2SS
		<u>I</u>	I	11101010100

Hitachi Proprietary


REP03-05-61



Front or Rear View of DKU
(In case of 3.5inch Drive)



DKU
(In case of 2.5inch Drive)



Front View of DKU (In case of FMD)

NOTICE:

- Replace the drive in the subsystem in power on status only. Do not replace the drive in power off status.
- Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.
- HDD is a precise component. Be careful in handling HDD to avoid vibration and impact.

- 2-1. Open the FAN door.
- 2-1-1. In case of 3.5inch/2.5inch drive
 - a. Put the stopper of the FAN door into the open able and closable state. (Refer to the INST03-01-160.)
 - b. Loosen the two screws and open the FAN door.
- 2-1-2. In case of FMD
 - a. Go to procedure 2-2. Check the Shut Down LED.






Fig. 3.5.2-1 FAN Door Opening

- 2-2. Check the Shut Down LED.
- 2-2-1. In case of 3.5inch/2.5inch drive
 - a. Check that the Shut Down LED on the HDDPWR corresponding to drive (HDD/SSD) is turned on. Refer to Fig. 3.5.2-2 or 3.5.2-3.



→ DKC No. (0, 1)

Fig. 3.5.2-2 Checking of Shut Down LED (In case of 3.5inch Drive)






Fig. 3.5.2-3 Checking of Shut Down LED (In case of 2.5inch Drive)


Rev.0 / Oct.2012

REP03-05-91

Copyright © 2012, Hitachi, Ltd.

2-2-2. In case of FMD

a. Check that the Shut Down LED on drive is turned on.



Front View of FBX DKU




Fig. 3.5.2-3A Checking of Shut Down LED (In case of FMD)

- 2-3. Remove the drive.
- 2-3-1. In case of 3.5inch drive.
 - a. Push up the stopper of drive, and bring the handle down. Don't pull the handle during this process.
 - b. Push down the handle.
 - c. Pull out the drive.
 - d. Fig. 3.5.2-5 illustrates the case of wrong procedure.





Fig. 3.5.2-5 Removal of Drive (Wrong Procedure)

Copyright © 2010, Hitachi, Ltd.

2-3-2. In case of 2.5inch drive.



- a. Push the stopper of drive, and bring the handle down. Don't pull the handle during this process.
- b. Push down the handle.
- c. Pull out the drive.
- d. Fig. 3.5.2-7 illustrates the case of wrong procedure.




Fig. 3.5.2-6 Removal of Drive

Rev.0 / Sep.2010

REP03-05-111

Copyright © 2010, Hitachi, Ltd.




Fig. 3.5.2-7 Removal of Drive (Wrong Procedure)

Rev.0 / Oct.2012

REP03-05-112

Copyright © 2012, Hitachi, Ltd.

2-3-3. In case of FMD

Notice: When the FMD is removed in replacing procedure, the fans of the DKUPS equipped in the rear of the FBX DKU rotate at the highest speed. When the spare FMD is installed, the fans of the DKUPS rotate at the speed suitable for environmental temperature.

- a. Pull the stopper of the drive handle toward you to have the lock off.
- b. Tilt the handle toward you, and then remove the drive by pulling it out taking care not to apply a shock to it.

Note: When handling the drive, hold the rail side because the shield spring is subject to breakage.





Fig. 3.5.2-7A Removal of Drive (In case of FMD)


Rev.0 / Feb.2014

REP03-05-113

Copyright © 2014, Hitachi, Ltd.

c. Check whether a failure of the battery built in the FMD has occurred by using the flowchart below. If a battery failure has occurred, remove the battery from the FMD. If no battery failure has occurred, go to Procedure 2-4.





Copyright © 2014, Hitachi, Ltd.

d. FMD Battery Removing Procedure

(d)-1 Remove 4 Screws (SB310N) on the bottom side of FMD by using cross-head screw driver.




Fig. 3.5.2-7B Removing Screws

(d)-2 Remove Top Cover and Bottom Cover.




Fig. 3.5.2-7C Removing Covers

(d)-3 Remove 2 sets of Tapping-screw and Washer by using cross-head screw driver.




Fig. 3.5.2-7D Removing Tapping-screws and Washers

(d)-4 Move the Battery to the bezel side and disconnect the Battery from the circuit board.




Fig. 3.5.2-7E Disconnecting from Connector

(d)-5 Remove the Battery to the bottom side of FMD. (After the connector comes off, battery is lowered below.)




Fig. 3.5.2-7F Removing Battery

- (d)-6 Attach Top Cover and Bottom Cover.
- (d)-7 Attach 4 Screws (SB310N) on the bottom side of FMD.




Fig. 3.5.2-7G Reassembling FMD

(d)-8 Dispose of the Tapping-screws, Washers and Battery removed in procedures (d)-3 and (d)-5.


When dispose of the Battery, follow the directions given by the local law where the product is used.

REP03-05-120

2-4. Check and handling of the drive.


(1) <Confirm Removal>


Select (CL) [OK] in response to "Check the location of the disk drive that you want to remove, because an LED of some other disk drives might be on. After the check, remove the disk drive, then select [OK] button. (HDDxnn-nn)" after the unit is removed. (Step 2-3)




(2) < Confirm Insertion>


"Check the location of the disk drive that you want to insert. After the check, insert the disk drive, then select [OK] button. (HDDnnn-nn)" is displayed.







2-5. Install the drive.



Instruction for the insertion and removal of the 2.5-inch drive:

The upper part of HDDPWR might come in contact with the lower part of the drive, and it becomes an obstruction of the insertion and removal at the time of the 2.5-inch drive insertion and removal. In this case, avoid the HDDPWR by lifting the drive lightly.

Caution – Back Board, or drive connector or drive handle may be damaged when the drive is forcibly inserted.

If the drive cannot be easily inserted until the claws on the handle reach the DKU, or if the handle binds or stops before it can be locked, then remove the drive and perform inspection:

- a) Check the drive slot in DKU to be free and clear of obstructions.
- b) Check connector on back board for visible defects.
- c) Inspect connector on drive for visible defects.
- d) Inspect drive top and bottom guide for defects. Note special alignment tab on bottom guide on some drive. A damaged tab can bind on the lower slot guides in DKU.
- e) During installation make sure the drive is inserted in alignment with slot guides.
- f) Check upper rear spring on SSD has been removed. (This applies only on SSD) Reinsert drive after inspections have passed.


REP03-05-131

2-5-1. In case of 3.5inch/2.5inch drive

- a. Insert the drive into the HDU holding its handle.
 (Insert the canister until the claws that are located at the bottom of the handle come in contact with the front side of the HDU.)
- b. Turn the handle at a stroke by pushing its top with your thumb.(Turn the handle until it latches with the stopper. Do not stop the handle on its way of turning.)

a. Insert the HDD/SSD canister into the HDU holding its handle.

A gap exists between the connectors.



b. Turn the handle at a stroke by pushing its top with your thumb. (Do not stop the handle on its way of turning.)




Fig. 3.5.2-8 Method of Installing Drive

- c. Close the FAN door and tighten the screws. (Refer to Fig. 3.5.2-1.)
- d. Put the FAN door stopper into the neutral state.

Rev.0 / Oct.2012

REP03-05-132

Copyright © 2012, Hitachi, Ltd.

2-5-2. In case of FMD

Note: When handling the drive, hold the rail side because the shield spring is subject to breakage.

- a. Open the handle fully and fit the drive in the guide rail and slide it in the direction shown by the arrow not to give a shock.
- b. Push the drive in until it reaches the position where a hook of the handle can be entered into the square hole on a frame.
- c. Pull the stopper lightly and close the handle, and then press the stopper to have the lock on. If the handle is closed in the state where the hook of the handle cannot enter into the square hole, the drive cannot be installed correctly because it runs into the frame of the FBX DKU.




Fig. 3.5.2-9 Installation of Drive (In case of FMD)

2-6. Go to "3. POST-PROCESSING of SVP".

Rev.1 / Sep.2010, Oct.2010

REP03-05-140

Copyright © 2010, Hitachi, Ltd.


Before starting the <Check the beginning of recovery> operation in POST-PROCEDURES of SVP, be sure to insert a removable media for dump, collect failure information, and return the removable media with the failed HDD.

A dump removable media is attached with a Spare HDD.

3. POST-PROCESSING of SVP


3-1. <Confirm Insertion>


"Check the location of the disk drive that you want to insert. After the check, insert the disk drive, then select [OK] button. (HDDnnn-nn)" is displayed.



3-2. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].





Rev.0 / Oct.2010

REP03-05-141

Copyright © 2010, Hitachi, Ltd.

"Insert a removable media for gathering error information and select [OK].

The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.

Select a Client PC arbitrary drive, and select (CL) [Ok].

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the

screen, and select an arbitrary drive letter from the pull-down menu.

The drive letter becomes the drive letter of console PC connected with SVP.



Copyright © 2010, Hitachi, Ltd.

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.


Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.



Select (CL) [Save] when saving a file in a specified directory. It returns to the drive selection screen when [Cancel] is selected (CL).

3-3. <Copy of the error information>

The error information is copied onto media.



"Remove the media." is displayed. Select (CL) [OK].



Rev.2 / Oct.2010, Mar.2011

REP03-05-160

3-4. <Check the spin up process> "Spinning up..." is displayed.

3-5. < Check the INLINE process>

"DKU INLINE is now running..." is displayed.

3-6. < Replacement of the DKU micro-program>

When the revision of the DKU micro-program in the SVP hard disk is newer than that in the PDEV, the following message appears on the screen.

The message "Exchanging DKU micro-program..." appears.

3-7. < Restore Physical Drive>


"Restoring..." is displayed.

(1)


"The FAN Door of HDDFAN-xxx is open. Close the FAN Door, and select [OK]. The FAN Door checking is executed up to 3 times. (n/3)" is displayed.

After the FAN door is closed, select (CL) [OK] in response to this message.

It returns to (1) when HDDFAN doors of the object are not closed.



Note: It goes to (2) when it cannot be confirmed that the FAN doors are closed in the three times FAN door check.



Copyright © 2010, 2011, Hitachi, Ltd.

Rev.3 / Sep.2011, Dec.2011

REP03-05-170

(2)

"A problem in HDDFAN or a FAN Door open might be occurred.

After completing the maintenance process, check the Maintenance or Information window in an error status or an error log is shown on the window, then execute troubleshooting." is displayed.

Select (CL) [OK] in response to this message.



3-8. <Check the end of PDEV recovery> Select (CL) [OK] in response to "Replace finished.".



Copyright © 2010, 2011, Hitachi, Ltd.

3-9.

Go to POST-PROCEDURE [REP04-01-10].

[CACHE REPLACEMENT PROCESSING - RCA1]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select cache (status check)
 - ② Specify Replacement
 - ③ Place PCB into blocked state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Execute CUDG on cache
 - ② Specify recovery
 - ③ Version of Microprogram

Rev.0 / Sep.2010

REP03-10-20


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.




Copyright © 2010, Hitachi, Ltd.

1-2. <DKC window>
Select (CL) [DKC-n Front] in the 'DKC' window.



1-3. <Select Cache> Select (CL) Cache.



Rev.1 / Sep.2010, Mar.2011

REP03-10-30

Copyright © 2010, 2011, Hitachi, Ltd.

1-4. <Specify replacement of cache>


A CAUTION

When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Check status display.

Select (CL) [Replace], and select(CL)
[CACHE PCB].



Rev.0 / Sep.2010

REP03-10-31

1-5. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).

(2)


In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-4.

When [No] is selected (CL), returned to Step 1-5.



Copyright © 2010, Hitachi, Ltd.





Rev.0 / Sep.2010


REP03-10-40

Copyright © 2010, Hitachi, Ltd.

1-6. <Check the beginning of cache replace>
Select (CL) [Yes] after making sure that the package to be replaced is correct in response to "Do you want to replace the PCB(s)(CACHE-nnn)? If [Yes] is selected, the PCB(s) needs to be removed and inserted again.".




1-7. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.



1-8. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].






REP03-10-50

"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.



*: When Cache Memory Module is replaced, select (CL) [Cancel] because the dump is not required.

A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format

"[factory_cd]_[Pcb_type]_[Pcb_SerialNo]_YYMMDDhhmmss.tgz".


(YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes Minute, and ss denotes Second)

When Client PC is selected, the directory selection dialog is displayed. Please select an arbitrary directory if

Please select an arbitrary directory if necessary.

Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\\F and \\F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.



It returns to the drive selection screen when [Cancel] is selected (CL).

Rev.1 / Sep.2010, Oct.2010

REP03-10-60

• When the destination media is write-protected.

<For Windows XP>



You don't have permission to save in this location.

Would you like to save in the Administrator folder instead?

Contact the administrator to obtain permission.

\\tsclient\G\080320180607.tgz


Copyright © 2010, Hitachi, Ltd.

<u>N</u>o


<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.


Please appoint another destination
whether you remove write protect when you save it and carry it out.



Select a dump file




At the time of the above operation completion, the information collection is not carried out.



Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.

Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".



Rev.0 / Sep.2010


REP03-10-70

1-9. < Confirmation of amount of opposite cluster battery charge>

(1)

• When there is PCB whose amount of battery charge is less than 50% in the opposite cluster:

"A battery whose charge capacity is less than 50% is in the cluster of opposite site to be replaced. If there is a battery problem on the battery, replace it. If there is no battery problem on the battery, wait the operation until the charge capacity of the battery becomes 50% or more (maximum 90 min.). Do you want to stop this process?".



Copyright © 2010, Hitachi, Ltd.

When [Yes] is selected (CL), returned to REP03-10-30 Step 1-4. When [No] is selected (CL), go to Step (2)

- When there is no PCB whose amount of charge of the Cache battery is less than 50%: go to Step 1-10.
- (2) <Input password>
 Enter the password and select (CL) [OK].



Notice: This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss if a wrong part to be removed is selected, and requires an input of a password. Ask the technical support division about the appropriateness of the operation, and input the password after getting an approval of executing the operation.

1-10. < Cache blocking >

"The Cache Memory PCB (CACHE-nnn) is being blocked." is displayed.

Replace

[ONL0843i]

Rev.1 / Sep.2010, Oct.2010


REP03-10-80

1-11. <Check shut down LED>

Select (CL)

- * [Yes] if LED is on
- * [No] if LED is off

in response to "Is the LED of the target PCB(s) lit?".



Check the location of the target PCB(s)(CACHE-1CA), then pull out

the PCB(s) without considering the status of LED.

Copyright © 2010, Hitachi, Ltd.

OK

If [No] is selected:

Select (CL) [OK] in response to "Check the location of the target PCB(s)(CACHE-nnn), then pull out the PCB(s) without considering the status of LED.". (Refer to "2. HARDWARE REPLACEMENT

PROCESSING")


Note: Select (CL) [OK] after pulling out the PCB.

Go to Step 1-12.

1-12. <Cache Replacement>

"Please replace the PCB(s)(CACHE-nnn). After replacement, please select [OK]." is displayed.

Select (CL) [OK] after replacing the PCB.




1-13. <Replace cache PCB> Replace cache.

Go to "2. HARDWARE REPLACEMENT PROCESSING".

REP03-10-90

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Front View of DKC	1 CM (Cache Memory) PCB		• WP741-A
	2	CM Module (Non-RoHS2 compliant part)	• 4GB DIMM (C16G) • 8GB DIMM (C32G)
		CM Module (RoHS2 compliant part)	• 4GB DIMM (C16GR) • 8GB DIMM (C32GR)



Front View of DKC

NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

2-1 CM (Cache Memory) PCB

2-1-1. Remove the CM PCB.

- a. Open the DKCPANEL when the replacing CM PCB locations are CACHE-2CD, 2CG, 2CH, 2CM, 2CQ or 2CR.
 - For the CM PCB location other than the above, go to the procedure c.
- b. Loosen the screw, slide the DKCPANEL to the far right, and open the DKCPANEL.




Fig. 3.10.2-1 Shifting of DKCPANEL

c. Check that the Shut Down LED is on. (only hot replace)





Fig. 3.10.2-2 Confirmation of Shut Down LED

REP03-10-110

d. Remove the two screws and remove the CM PCB.



Note: After removing the PCB, install the spare PCB immediately.

If the PCB is kept removed for a long time, the wind doesn't flow among installed PCBs, causing the PCBs' temperature rise which may result in temperature warning or temperature alarm.




Fig. 3.10.2-3 Removal of CM PCB

Rev.0 / Sep.2010

REP03-10-120

Copyright © 2010, Hitachi, Ltd.

2-1-2. Move the CM module.

a. Loosen the two screws and remove the cover.





Fig. 3.10.2-4 Removal of Cover

REP03-10-130

- b. Move all the cache memory modules (including dust covers if any) mounted on an extracted PCB to the same mounting positions on the spare PCB.
- c. Attach the cover and tighten the screws. (Refer to Fig. 3.10.2-4.)



Installation

- ① Position the cut of the memory module with the projection inside the slot, and place the memory module on the socket.
- ② Hold both ends of the memory module by the fingers, and fit it into the socket.
- 3 Make sure that the lever is firmly fitted in the memory module.

Caution: Do not put intense pressure to which the PCB greatly bends on the memory module after the memory module is secured with the lever at the time equipped with the memory module. The PCB may be damaged, when the intense pressure is applied.

Removal

① Pull the lever outward, and remove the memory module by the inverse process of the installation.

Fig. 3.10.2-5 Insertion Location of CM Module

Rev.0 / Sep.2010

REP03-10-140

2-1-3. Move the SSD Memory.

- a. Loosen the two screws in the front side of the CM PCB, and remove the cover.
- b. Remove the Basic SSD memory from the CM PCB after loosen the screws and put the stopper up.
- c. Install the Basic SSD memory in the CM PCB of the spare parts, and put the stopper down, and then secure it with the screws.
- d. Move SSD memory in reference to procedure a. to c., if the Option SSD memory is also installed.




Fig. 3.10.2-6 Movement the SSD memory

Copyright © 2010, Hitachi, Ltd.

Rev.1 / Sep.2010, Oct.2010

Copyright © 2010, Hitachi, Ltd.

REP03-10-150

- e. After removing the battery cable, loosen the screw and remove the battery.
- f. Install the battery in the CM package of the maintenance parts, tighten the screw, and then connect the battery cable.
- g. Install the cover that is removed in procedure a. to the front side of the CM PCB, and secure it with the two screws.





Fig. 3.10.2-7 Movement the Battery

2-1-4. Insert the CM PCB.

a. Insert the CM PCB and tighten the screws.



b. Replace the DKCPANEL and secure it with the screw if the DKCPANEL is opened. (Refer to Fig. 3.10.2-1.)

2-1-5. Go to "3.POST-PROCESSING of SVP" (REP03-10-250).

Rev.0 / Sep.2010

REP03-10-160

Copyright © 2010, Hitachi, Ltd.

2-2 CM Module

2-2-1. Remove the CM PCB.

- a. Open the DKCPANEL when the removing CM PCB locations are CACHE-2CD, 2CG, 2CH, 2CM, 2CQ or 2CR.
 - For the CM PCB location other than the above, go to the procedure c.
- b. Loosen the screw, slide the DKCPANEL to the far right, and open the DKCPANEL.




Fig. 3.10.2-8 Shifting of DKCPANEL

c. Check that the Shut Down LED is on. (only hot replace)





Fig. 3.10.2-9 Confirmation of Shut Down LED

REP03-10-170

d. Remove the two screws and remove the CM PCB.



Note: After removing the PCB, replace memory modules immediately and install the extracted PCB.

If the PCB is kept removed for a long time, the wind doesn't flow among installed PCBs, causing the PCBs' temperature rise which may result in temperature warning or temperature alarm.




Fig. 3.10.2-10 Removal of CM PCB

Rev.0 / Sep.2010

REP03-10-180

Copyright © 2010, Hitachi, Ltd.

2-2-2. Replace the CM module.

a. Loosen the two screws and remove the cover.






Fig. 3.10.2-11 Removal of Cover

REP03-10-190

b. Replace the CM Module.





Installation

- ① Position the cut of the memory module with the projection inside the slot, and place the memory module on the socket.
- ② Hold both ends of the memory module by the fingers, and fit it into the socket.
- 3 Make sure that the lever is firmly fitted in the memory module.

Caution: Do not put intense pressure to which the PCB greatly bends on the memory module after the memory module is secured with the lever at the time equipped with the memory module. The PCB may be damaged, when the intense pressure is applied.

Removal

① Pull the lever outward, and remove the memory module by the inverse process of the installation.

Memory Module Appearance

There are two types of memory modules. One has a heat spreader and the other has no heat spreaders. Both memory modules can be used because they are compatible with each other.





Fig. 3.10.2-12 Replacement of CM Module

REP03-10-200

2-2-3. Insert the CM PCB.

a. Insert the CM PCB and tighten the screws.



b. Replace the DKCPANEL and secure it with the screw if the DKCPANEL is opened. (Refer to Fig. 3.10.2-8.)

2-2-4. Go to "3. POST-PROCESSING of SVP" (REP03-10-250).

Rev.1 / Sep.2010, Mar.2011

REP03-10-210

Copyright © 2010, 2011, Hitachi, Ltd.

Rev.1 / Sep.2010, Mar.2011

REP03-10-220

Copyright © 2010, 2011, Hitachi, Ltd.

Rev.1 / Sep.2010, Mar.2011

REP03-10-230

Copyright © 2010, 2011, Hitachi, Ltd.

Hitachi Proprietary DKC710I Copyright © 2010, 2011, Hitachi, Ltd.

Rev.2 / Oct.2010, Mar.2011


REP03-10-240

REP03-10-250

3. POST-PROCESSING of SVP

3-1. <Cache Replacement>

Select (CL) [OK] in response to "Please replace the PCB(s)(CACHE-nnn). After replacement, please select [OK]." after replacement.



3-2. <INLINE CUDG>

Go to step 3-6.

"INLINE CUDG is now running..." is displayed.

3-3. < Restore the Cache Memory>

"Restoring the Cache Memory PCB..." is displayed.

If the display of Battery Life Warning SIM is disabled, go to step 3-6. When the amount of charge of the battery in PCB to be replaced is 50% or more, go to step 3-7.

3-4.

In response to a message, "Do you want to change the setting of Battery Life Warning SIM?".

Select [Yes] when you exchange CM Battery. Go to step 3-5.

Select [No] when you use existing CM Battery.



REP03-10-260


3-5. < Setting Battery Life>

(1)

Select (CL) the target CM Battery in the 'Battery Life Warning SIM' screen, and then select (CL) [Set...].
Go to step (2).

Make sure that the all input items are correct and select (CL) [OK].

Note: If the date is displayed as "****/**", follow step (2) to set the date.



(2)

Select (CL) [OK] after inputting the remainder days until Warning SIM is reported.

Return to step (1).

Current Date: 2011/03/29

Remained Battery life: 990

Cancel

Note: After executing the periodical exchange of a battery, set 33 month (990 days).


Note: Default value is 33 month (990 days), which is 3 month earlier than the lifetime of a battery (3 years).

Determine the number of days remained based on your maintenance plan.

Note: The input ranges of "Remained Battery life" are from 1 to 3650.

3-6.

Select (CL) [OK] in response to "Approx. 90 minutes (max.) will be required to have 50% or more of charging capacity for the battery.".



Rev.1 / Jun.2011, Sep.2011

REP03-10-270

Copyright © 2011, Hitachi, Ltd.

3-7. <Check the end of Cache recovery> Select (CL) [OK] in response to "Replace finished.".



A CAUTION

Confirm the version of the exchanged CACHE microprogram on the 'STATUS' screen.

If the CMBK microprogram version of the CACHE that is target to be maintained is lower than in the SVP, replace CACHE again.

REP03-10-280

3-8. <Version of Microprogram>

Select (CL) [Version]-[CM Ver.] in the 'Maintenance' window.




Table 3.10.3-1 Information to Be Displayed

Item	Description		
• Display of "CMBK"			
Display of "Current"	"SVP" : Latest version of the drive microprogram stored in the SVP. "Previous" : Previous version of the drive microprogram stored in the SVP. "CM PCB" : CM name "CMBK" : CMBK micro version information (It is stored in FM) that each CM PCB has is displayed.		
• Display of "CMSSD"			
Display of "Current"	Current Version. "Type": SSD type model "Version": Version of SSD microprogram		
Display of "SVP"	Latest version of the SSD microprogram stored in the SVP. "Type": SSD type "Version": Version of SSD microprogram		
Display of "Previous"	Former version of the SSD microprogram stored in the SVP. "Type": SSD type "Version": Version of SSD microprogram		

3-9.

Go to POST-PROCEDURE [REP04-01-10].

[MPB REPLACEMENT PROCESSING - RMP1]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select MPB (status check)
 - ② Specify Replacement
 - 3 Place PCB into blocked state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify recovery for MPB
 - 2 Version of Microprogram

Rev.0 / Sep.2010

REP03-11-20


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.




Copyright © 2010, Hitachi, Ltd.

1-2. <DKC window>
Select (CL) [DKC-n Front] in the 'DKC' window.



1-3. <Select MP PCB> Select (CL) MP PCB.



Rev.1 / Sep.2010, Mar.2011

REP03-11-30

Copyright © 2010, 2011, Hitachi, Ltd.


1-4. <Specify replacement of MPB>



When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Check status display. Select (CL) [Replace].



Rev.0 / Sep.2010

REP03-11-31

1-5. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).

(2)


In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped.


[No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-4.

When [No] is selected (CL), returned to Step 1-5.



Copyright © 2010, Hitachi, Ltd.





Rev.0 / Sep.2010


REP03-11-32

Copyright © 2010, Hitachi, Ltd.

1-6. <Check the beginning of MPB replace>
Select (CL) [Yes] after making sure that the package to be replaced is correct in response to "Do you want to replace the PCB(s)(MPB-nnn)? If [Yes] is selected, the PCB(s) needs to be removed and inserted again.".





1-7. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.



1-8. <Get the error information>


Input the Field Failure Information, and select (CL) [OK].





"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed. Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.



A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format

"[factory_cd]_[Pcb_type]_[Pcb_SerialNo]_YYMMDDhhmmss.tgz".

(YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes Minute, and ss denotes Second)

🔟 Select a dump file

Select a dump file

\\tsclient\G\080320180607.tgz

Copyright © 2010, Hitachi, Ltd.

×

Νo


When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.

Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.

It returns to the drive selection screen when [Cancel] is selected (CL).




You don't have permission to save in this location. Contact the administrator to obtain permission.

Would you like to save in the Administrator folder instead?

<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.

Please appoint another destination whether you remove write protect when you save it and carry it out.




• When the memory in the destination drive specified with the Client PC is corrupted. The dialog remains displayed after selecting (CL) [OK].

At the time of the above operation completion, the information collection is not carried out.



Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.

Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".



Rev.0 / Oct.2010

REP03-11-42

Copyright © 2010, Hitachi, Ltd.

1-9. < Caution message for system down>




Select (CL) [Yes] in response to the message below.

"Do you want to replace the PCB(s) by using the normal replacement procedure?

Yes = Normal replacement

No = Forcible replacement.

(Possible critical errors)" is displayed.



1-10. <MPB blocking>

"The MPB (MPB-nnn) is being blocked." is displayed.

REP03-11-50

1-11. <Check shut down LED>

Select (CL)

- * [Yes] if LED is on
- * [No] if LED is off

in response to "Is the LED of the target PCB(s) lit?".

When [No] is selected, the same message is displayed again.


Check the LED and then reply to the message.


If [No] is selected twice:

Select (CL) [OK] in response to "Check the location of the target PCB(s)(MPB-nnn), then pull out the PCB(s) without considering the status of LED.". (Refer to "2. HARDWARE REPLACEMENT PROCESSING")

Note: Select (CL) [OK] after pulling out the PCB.

Go to Step 1-12.






1-12. <MPB Replacement>

"Please replace the PCB(s)(MPB-nnn). After replacement, please select [OK]." is displayed.

Select (CL) [OK] after replacing the PCB.




1-13. <Replace MPB> Replace MPB.


Go to "2. HARDWARE REPLACEMENT PROCESSING".

REP03-11-60

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Front View of DKC	1	MPB (Two MP Memory Modules are included.) (Non-RoHS2 compliant part)	• WP752-A
		MPB (Two MP Memory Modules are included.) (RoHS2 compliant part)	• WP752-B
	2	MP Memory Module (Non-RoHS2 compliant part)	• DDR2 2GB DIMM
		MP Memory Module (RoHS2 compliant part)	• DDR2 2GB DIMM





NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-11-70

2-1 MPB

2-1-1. Remove the MPB.

a. Check that the Shut Down LED is on. (only hot replace)





Fig. 3.11.2-1 Confirmation of Shut Down LED

Copyright © 2010, Hitachi, Ltd.

b. Remove the two screws and remove the failed MPB.







Fig. 3.11.2-2 Removal of MPB

Rev.1 / Sep.2010, Oct.2010

REP03-11-90

2-1-2. Insert the spare MPB.

a. Insert the spare MPB to the correct location and tighten the screws.



2-1-3. Go to "3. POST-PROCESSING of SVP".

Copyright © 2010, Hitachi, Ltd.

Rev.0 / Sep.2010

REP03-11-100

Copyright © 2010, Hitachi, Ltd.

2-2 MP Memory Module

2-2-1. Remove the MP PCB.

a. Check that the Shut Down LED is on. (only hot replace)





Fig. 3.11.2-3 Confirmation of Shut Down LED

b. Remove the two screws and remove the failed MPB.






Fig. 3.11.2-4 Removal of MPB

Rev.0 / Sep.2010

REP03-11-120

2-2-2. Replace the MP Memory Module.

- a. Remove the two screws ①.
- b. Loosen the two screws ② and remove the cover.





Fig. 3.11.2-5 Removal of Cover

Copyright © 2010, Hitachi, Ltd.

REP03-11-130


- c. Remove the failed MP memory module and insert the spare MP memory module.
- d. Attach the cover and tighten the four screws. (Refer to Fig. 3.11.2-5.)



Installation

- ① Position the cut of the memory module with the projection inside the slot, and place the memory module on the socket.
- ② Hold both ends of the memory module by the fingers, and fit it into the socket.
- 3 Make sure that the lever is firmly fitted in the memory module.

Caution: Do not put intense pressure to which the PCB greatly bends on the memory module after the memory module is secured with the lever at the time equipped with the memory module. The PCB may be damaged, when the intense pressure is applied.



Removal

- ① Pull the lever outward.
- ② Hold both ends of the memory module by the fingers, and pull out the memory module from the socket.





Fig. 3.11.2-6 Replacement of MP Memory Module

Rev.1 / Sep.2010, Oct.2010

REP03-11-140

2-2-3. Insert the spare MPB.

a. Insert the spare MPB to the correct location and tighten the screws.



2-2-4. Go to "3. POST-PROCESSING of SVP".

Copyright © 2010, Hitachi, Ltd.


Rev.2 / Oct.2010, Sep.2011

REP03-11-150

Copyright © 2010, 2011, Hitachi, Ltd.

3. POST-PROCESSING of SVP

3-1. <MPB Replacement>
Select (CL) [OK] in response to "Please replace the PCB(s)(MPB-nnn). After replacement, please select [OK]."



3-2. < Waiting for Power Event>

"Waiting for Power Event...

Usually several minutes (maximum 15 minutes)." is displayed.

A CAUTION

Confirm the version of the exchanged MP microprogram on the 'STATUS' screen. Check whether the version of all processors accords.

If the DKCMAIN microprogram version of the MPB that is target to be maintained is lower than in the SVP, replace MPB again.

3-3. <Check the end of MPB recovery> Select (CL) [OK] in response to "Replace finished.".



3-4. Version of Microprogram

Select (CL) [Version]-[MP Ver.(Curt./Running)] in this order in the 'Maintenance' window. The 'Version' window is displayed.




Table 3.11.3-1 Information to Be Displayed

Item	Description
DKC Current Version area	Major version of the microprogram currently running. In regard to a version inconsistent with a corresponding version in the MP Version area or a binary version (Internal administrative information), the area concerned is displayed in red-white-reversal with an asterisk ("*").
MP Version area	Version of the microprogram of each processor currently running. A version, which is displayed in red-white-reversal, is inconsistent with the DKC Current Version. A version displayed with an asterisk ("*") at the end of it is the inconsistent one.
CHA PORT area	The version is displayed. Running version of port program (HTP) of each Port is displayed. The target type name is displayed.
DKA PORT area	The SAS-CON Running version is displayed. The Location name is displayed.

Concerning this item, when even a single piece of information is inconsistent, an icon "L", which shows an error, is displayed in the tab portion.

Select (CL) [Version]-[MP Ver.(Curt./FM)] in this order in the 'Maintenance' window.




Table 3.11.3-2 Information to Be Displayed

Item	Description			
DKC Current Version area	Major version of the microprogram currently running. In regard to a version inconsistent with a corresponding version in the M Version area or a binary version (Internal administrative information), the concerned is displayed in red-white-reversal with an asterisk ("*").			
FM Version area	Version of FM microprogram of each processor. A version, which is displayed in red-white-reversal, is inconsistent with the DKC Current Version. A version displayed with an asterisk ("*") at the end of it is the inconsistent one.			

Concerning this item, when even a single piece of information is inconsistent, an icon "\textstar" which shows an error, is displayed in the tab portion.

Rev.0 / Sep.2010 **REP03-11-180** Copyright © 2010, Hitachi, Ltd.

3-5.

Go to POST-PROCEDURE [REP04-01-10].

[Fibre CHA REPLACEMENT PROCESSING - RCH1]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select CHA (status check)
 - ② Specify Replacement
 - ③ Place PCB into blocked state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify recovery for CHA
 - ② Path online (for CHA)

Rev.0 / Sep.2010

REP03-12-20

1. PRE-PROCESSING of SVP

1-1. <Set path offline or switch of channel path>

A CAUTION

For Mainframe, the path to be placed offline is that connected with the CHA concerned. For Open host, the switch to the alternate channel path or host shutdown is that connected with the CHA concerned.

As for other channel path, switching to the alternate channel path or host shutdown is unnecessary.

However, the host must be shut down when the Pinned track in CHA connected port.

Copyright © 2010, Hitachi, Ltd.

Hitachi Proprietary

Rev.0 / Sep.2010

Copyright © 2010, Hitachi, Ltd.


REP03-12-30

Blank Sheet

Rev.0 / Sep.2010


REP03-12-40

1-2. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.




Copyright © 2010, Hitachi, Ltd.

1-3. <DKC window>
Select (CL) [DKC-n Back] in the 'DKC' window.



REP03-12-50

1-4. <Select CHA> Select (CL) CHA.




1-5. <Specify Replacement of CHA>

A CAUTION

- When the path to the PCB to be replaced is online, ask the customer to place it offline. (For CHA replacement)
- For Open host, switch to the alternate channel path or shut down the host. However, the host must be shut down when the Pinned track in CHA connected port.
- When the screen requests an operator to input a password in order to prevent multiple maintenance, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Make sure that the status is WARNING. Select (CL) [Replace].



Replace

Rev.0 / Sep.2010

REP03-12-60

1-6. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

[ONL4270W]

To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.

Copyright © 2010, Hitachi, Ltd.

(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).

(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped. [No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-5.

When [No] is selected (CL), returned to Step 1-6.






1-7.<CHA replace>

Select (CL) [Yes] in response to:

"Do you want to replace the PCB(s)(CHA-nnn)? If [Yes] is selected, the PCB(s) needs to be removed and inserted again.".




(Eg. CHA)

Rev.0 / Sep.2010

REP03-12-70

Copyright © 2010, Hitachi, Ltd.

1-8. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.




Copyright © 2010, Hitachi, Ltd.


DKC710I

REP03-12-80

1-9. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].






"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.



A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format

"[factory_cd]_[Pcb_type]_[Pcb_SerialNo]_YYMMDDhhmmss.tgz".

(YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes Minute, and ss denotes Second)

Rev.1 / Sep.2010, Oct.2010

REP03-12-90

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.


Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.

It returns to the drive selection screen when [Cancel] is selected (CL).

• When the destination media is write-protected.

<For Windows XP>



Copyright © 2010, Hitachi, Ltd.



You don't have permission to save in this location. Contact the administrator to obtain permission.

Would you like to save in the Administrator folder instead?

<u>Y</u>es

<u>N</u>o

\\tsclient\G\080320180607.tgz

<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.

Please appoint another destination

whether you remove write protect when you save it and carry it out.

• When dialog of the destination drive specified with the Client PC is open, the media is removed, and then select (CL) [Save].

Select a dump file

Copyright © 2010, Hitachi, Ltd.


 When the memory in the destination drive specified with the Client PC is corrupted.
 The dialog remains displayed after selecting (CL) [OK].

At the time of the above operation completion, the information collection is not carried out.



Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.


Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".



1-10. <Confirm Channel Path offline>
Select (CL) [Yes] in response to following message.

For Fiber CHA:

"Confirm that you have already shut down the corresponding connected host(s) or switched to the alternate channel path(s) for all HOST connected to this PCB. Do you want to continue processing?".



Rev.0 / Oct.2010

REP03-12-101

Copyright © 2010, Hitachi, Ltd.

1-11. <Caution message for system down>



A CAUTION


Select (CL) [Yes] in response to the message below.

"Do you want to replace the PCB(s) by using the normal replacement procedure?

Yes = Normal replacement

No = Forcible replacement.

(Possible critical errors)".



REP03-12-110

1-12. <CHA blocking>

"CHA-xxx is being blocked... Usually, several minutes (maximum 15 minutes)"


"CHA-xxx is lighting the LED..."

1-13. <Check shut down LED>

Select (CL)

- * [Yes] if LED is on
- * [No] if LED is off

in response to "Is the LED of the target PCB(s) lit?".



If [No] is selected:

Select (CL) [OK] in response to "Check the location of the target PCB(s)(CHA-nnn), then pull out the PCB(s) without considering the status of LED.". (Refer to "2. HARDWARE REPLACEMENT PROCESSING")

Note: Select (CL) [OK] after pulling out the PCB.

[ONL0843i]
Check the location of the target PCB(s)(CHA-1EU), then pull out the PCB(s) without considering the status of LED.


Go to Step 1-14.

1-14. < Beginning of CHA replacement>

"Please replace the PCB(s)(CHA-nnn). After replacement, please select [OK]." is displayed.

Select (CL) [OK] after replacing the CHA.


Go to "2. HARDWARE REPLACEMENT PROCESSING".



REP03-12-120

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Rear View of DKC	1	CHA (Channel Adapter) PCB for Fibre (8Gbps) (Fibre 4-port Adapter PCB) (Non-RoHS2 compliant part)	• WP712-B (8UFC)
		CHA PCB for Fibre (8Gbps) (Fibre 4-port Adapter PCB) (RoHS2 compliant part)	• WP712-D (8UFCR)
	2	CHA PCB for Fibre (8Gbps) (Fibre 8-port Adapter PCB) (Non-RoHS2 compliant part)	• WP712-A (16UFC)
		CHA PCB for Fibre (8Gbps) (Fibre 8-port Adapter PCB) (RoHS2 compliant part)	• WP712-C (16UFCR)



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-12-130

Copyright © 2010, Hitachi, Ltd.

- 2-1. Remove the Channel Adapter PCB.
 - a. Check that the Shut Down LED is on. (only hot replace)





Fig. 3.12.2-1 Confirmation of Shut Down LED

- b. Disconnect the optical fibre cables from the failed Channel Adapter PCB.
- c. Remove the two screws and remove the failed PCB.



Note: After removing the PCB, install the spare PCB immediately.

If the PCB is kept removed for a long time, the wind doesn't flow among installed PCBs, causing the PCBs' temperature rise which may result in temperature warning or temperature alarm.





Fig. 3.12.2-2 Removal of PCB

REP03-12-150

2-2. Insert the spare PCB.

a. Insert the spare PCB to the correct location and tighten the screws.



2-3. Cleaning the fibre cable connectors.

For the tools needed for the cleaning, refer to the tool list on page PARTS06-10.

- a. Blow compressed gas against the connector using an air sprayer (for about five seconds).
- b. Wipe the connector lightly with a piece of cut gauze wet with ethyl alcohol.
- c. Blow compressed air again and check the result of the cleaning. (None of dust, sticking of foreign matter, and dirt must be observed.)
- 2-4. Connect the optical fibre cables to the spare PCB.
- 2-5. Go to "3. POST-PROCESSING of SVP".


Rev.0 / Sep.2010

REP03-12-160

Copyright © 2010, Hitachi, Ltd.

3. POST-PROCESSING of SVP

3-1. <Beginning of CHA Replacement>
Select (CL) [OK] in response to "Please replace the PCB(s)(CHA-nnn). After replacement, please select [OK]." after replacement.



3-2. <Check the end of CHA recovery>
Select (CL) [OK] in response to "Replace finished.".



Rev.0 / Sep.2010

REP03-12-170

Copyright © 2010, Hitachi, Ltd.

3-3. <Path on-line when CHA is replaced>
When a CHA is replaced, set the path (from the host) on the replaced CHA to ONLINE by your customer.

3-4.

Go to POST-PROCEDURE [REP04-01-10].

[Mainframe Fibre CHA REPLACEMENT PROCESSING - RCH2]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select CHA (status check)
 - ② Specify Replacement
 - ③ Place PCB into blocked state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify recovery for CHA
 - ② Path online (for CHA)

Rev.0 / Sep.2010

REP03-13-20

1. PRE-PROCESSING of SVP

1-1. <Set path offline or switch of channel path>

A CAUTION

For Mainframe, the path to be placed offline is that connected with the CHA concerned. For Open host, the switch to the alternate channel path or host shutdown is that connected with the CHA concerned.

As for other channel path, switching to the alternate channel path or host shutdown is unnecessary.

However, the host must be shut down when the Pinned track in CHA connected port.

Copyright © 2010, Hitachi, Ltd.

Hitachi Proprietary

Rev.0 / Sep.2010

Copyright © 2010, Hitachi, Ltd.

REP03-13-30


Blank Sheet

Rev.0 / Sep.2010


REP03-13-40

Copyright © 2010, Hitachi, Ltd.

1-2. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.




1-3. <DKC window>
Select (CL) [DKC-n Back] in the 'DKC' window.



REP03-13-50

1-4. <Select CHA> Select (CL) CHA.




1-5. < Specify Replacement of CHA>

A CAUTION

- When the path to the PCB to be replaced is online, ask the customer to place it offline. (For CHA replacement)
- For Mainframe, vary off the concerned channel paths.
- When the screen requests an operator to input a password in order to prevent multiple maintenance, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Make sure that the status is WARNING. Select (CL) [Replace].



Rev.0 / Sep.2010

REP03-13-60

1-6. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

(1) <Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).

(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped. [No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-5.

When [No] is selected (CL), returned to Step 1-6.

Replace [ONL4270W] To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.

Copyright © 2010, Hitachi, Ltd.






1-7. <CHA replace>

Select (CL) [Yes] in response to:

"Do you want to replace the PCB(s)(CHA-nnn)? If [Yes] is selected, the PCB(s) needs to be removed and inserted again.".




(Eg. CHA)

Rev.0 / Sep.2010

REP03-13-70

Copyright © 2010, Hitachi, Ltd.

1-8. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.





1-9. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].

FFI (Field Failure Information)

FFI (Field Failure Information)






Copyright © 2010, Hitachi, Ltd.

"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.



A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format

"[factory_cd]_[Pcb_type]_[Pcb_SerialNo]_YYMMDDhhmmss.tgz".

(YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes Minute, and ss denotes Second)


When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if

Please select an arbitrary directory if necessary.

Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.



It returns to the drive selection screen when [Cancel] is selected (CL).

Rev.1 / Sep.2010, Oct.2010

REP03-13-90

• When the destination media is write-protected. <For Windows XP>



Copyright © 2010, Hitachi, Ltd.

<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.

\\tsclient\G\080320180607.tgz You don't have permission to save in this location. Contact the administrator to obtain permission. Would you like to save in the Administrator folder instead? <u>N</u>o whether you remove write protect when you save it and carry it out.

Select a dump file

Please appoint another destination


- When dialog of the destination drive specified with the Client PC is open, the media is removed, and then select (CL) [Save].
- When the memory in the destination drive specified with the Client PC is corrupted. The dialog remains displayed after selecting (CL) [OK].

At the time of the above operation completion, the information collection is not carried out.



Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.

Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".



Rev.0 / Sep.2010


REP03-13-100

Copyright © 2010, Hitachi, Ltd.

1-10. <Confirm Channel Path offline> Select (CL) [OK] in response to following message.

For Mainframe Fiber CHA:

"Please confirm you have already varied off the concerned Channel paths for all HOST connected to this PCB. If OK, please press [OK].".



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-13-110

Copyright © 2010, Hitachi, Ltd.

1-11. < Caution message for system down>



A CAUTION


Select (CL) [Yes] in response to the message below.

"Do you want to replace the PCB(s) by using the normal replacement procedure?

Yes = Normal replacement

No = Forcible replacement.

(Possible critical errors)".



1-12. <CHA blocking>

"CHA-xxx is being blocked... Usually, several minutes (maximum 15 minutes)"

"CHA-xxx is lighting the LED..."


REP03-13-120

1-13. <Check shut down LED>

Select (CL)

- * [Yes] if LED is on
- * [No] if LED is off

in response to "Is the LED of the target PCB(s) lit?".




If [No] is selected:

Select (CL) [OK] in response to "Check the location of the target PCB(s)(CHA-nnn), then pull out the PCB(s) without considering the status of LED.". (Refer to "2. HARDWARE REPLACEMENT PROCESSING")

Note: Select (CL) [OK] after pulling out the PCB.

Go to step 1-14.




1-14. <Beginning of CHA replacement>

"Please replace the PCB(s)(CHA-nnn). After replacement, please select [OK]." is displayed.

Select (CL) [OK] after replacing the CHA.


Go to "2. HARDWARE REPLACEMENT PROCESSING".



REP03-13-130

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Front DKC or Rear DKC	1	CHA (Channel Adapter) PCB for Mainframe Fibre (4Gbps) (MF Fibre 8-port Adapter PCB)	• WP711-A (16MFS)
	2	CHA PCB for Mainframe Fibre (4Gbps) (MF Fibre 8-port Adapter PCB)	• WP711-B (16MFL)
	3	CHA PCB for Mainframe Fibre (8Gbps) (MF Fibre 8-port Adapter PCB) (Non-RoHS2 compliant part)	• WP711-E (16MUS)
		CHA PCB for Mainframe Fibre (8Gbps) (MF Fibre 8-port Adapter PCB) (RoHS2 compliant part)	• WP711-G (16MUSR)
	4	CHA PCB for Mainframe Fibre (8Gbps) (MF Fibre 8-port Adapter PCB)	• WP711-F (16MUL)



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-13-140

Copyright © 2010, Hitachi, Ltd.

2-1. Remove the Channel Adapter PCB.

a. Check that the Shut Down LED is on. (only hot replace)





Fig. 3.13.2-1 Confirmation of Shut Down LED

REP03-13-150

- b. Disconnect the optical fibre cables from the failed Channel Adapter PCB.
- c. Remove the two screws and remove the failed PCB.



Note: After removing the PCB, install the spare PCB immediately.

If the PCB is kept removed for a long time, the wind doesn't flow among installed PCBs, causing the PCBs' temperature rise which may result in temperature warning or temperature alarm.





Fig. 3.13.2-2 Removal of PCB

2-2. Insert the spare PCB.

a. Insert the spare PCB to the correct location and tighten the screws.



2-3. Cleaning the fibre cable connectors.


For the tools needed for the cleaning, refer to the tool list on page PARTS06-10.

- a. Blow compressed gas against the connector using an air sprayer (for about five seconds).
- b. Wipe the connector lightly with a piece of cut gauze wet with ethyl alcohol.
- c. Blow compressed air again and check the result of the cleaning. (None of dust, sticking of foreign matter, and dirt must be observed.)
- 2-4. Connect the optical fibre cables to the spare PCB.
- 2-5. Go to "3. POST-PROCESSING of SVP".

REP03-13-170

3. POST-PROCESSING of SVP

3-1. <Beginning of CHA Replacement>
Select (CL) [OK] in response to "Please replace the PCB(s)(CHA-nnn). After replacement, please select [OK]." after replacement.



3-2. <Check the end of CHA recovery> Select (CL) [OK] in response to "Replace finished.".



- 3-3. <Path on-line when CHA is replaced>
 When a CHA is replaced, set the path (from the host) on the replaced CHA to ONLINE by your customer.
- 3-4. Go to POST-PROCEDURE [REP04-01-10].

[DKA REPLACEMENT PROCESSING - RDA1]


— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select DKA (status check)
 - ② Specify Replacement
 - 3 Place PCB into blocked state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify recovery for DKA


REP03-14-20

1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.



1-2. <DKC window>
Select (CL) [DKC-n Back] in the 'DKC' window.



DKC710I Hitachi Proprietary


Rev.1 / Sep.2010, Apr.2013

REP03-14-30

Copyright © 2010, 2013, Hitachi, Ltd.

1-3. <Select DKA>

Select (CL) DKA.



1-4. <Specify Replacement of DKA>




A CAUTION

When the screen requests an operator to input a password in order to prevent multiple maintenance, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP Message Section (SVPMSG00-00).

Make sure that the status is WARNING. Select (CL) [Replace].



1-5. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).

(2)


In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-4.

When [No] is selected (CL), returned to Step 1-5.







Rev.1 / Sep.2010, Apr.2013


REP03-14-50

1-6. <DKA replace>

Select (CL) [Yes] in response to: "Do you want to replace the PCB(s)(DKAnnn)? If [Yes] is selected, the PCB(s) needs to be removed and inserted again."





1-7. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.



1-8. < Get the error information >

Input the Field Failure Information, and select (CL) [OK].






"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.



A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format

"[factory_cd]_[Pcb_type]_[Pcb_SerialNo]_YYMMDDhhmmss.tgz".

(YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes Minute, and ss denotes Second)

🔟 Select a dump file

Name

鷆 Data

Save in: | ¥¥tsclient¥F

Type

Rev.1 / Sep.2010, Apr.2013

REP03-14-61

Copyright © 2010, 2013, Hitachi, Ltd.

Date modified

← <a>E <a>E</

×

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.


Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.

It returns to the drive selection screen when [Cancel] is selected (CL).

• When the destination media is write-protected.

<For Windows XP>



Check security privileges over the network drive.

OK

<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.

Please appoint another destination

whether you remove write protect when you save it and carry it out.

You don't have permission to save in this location. Contact the administrator to obtain permission. Would you like to save in the Administrator folder instead? <u>Y</u>es <u>N</u>o

Select a dump file

Select a dump file

080314172442 Cannot access this file.

\\tsclient\G\080320180607.tgz

• When dialog of the destination drive specified with the Client PC is open, the media is removed, and then select (CL) [Save].

Rev.2 / Oct.2010, Apr.2013

REP03-14-70


 When the memory in the destination drive specified with the Client PC is corrupted.
 The dialog remains displayed after selecting (CL) [OK].

At the time of the above operation completion, the information collection is not carried out.



Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.

Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".



Rev.2 / Oct.2010, Apr.2013

REP03-14-80


Copyright © 2010, 2013, Hitachi, Ltd.

1-9. < Caution message for system down>



Select (CL) [Yes] in response to the message below.

"Do you want to replace the PCB(s) by using the normal replacement procedure? Yes = Normal replacement No = Forcible replacement. (possible critical errors)".



$1\text{-}10. < \!\! \mathsf{DKA} \mathsf{\ blocking} \!\! >$

- "DKA is being blocked..."
- "DKA-xxx is lighting the LED..."

Copyright © 2010, 2013, Hitachi, Ltd.

Rev.2 / Oct.2010, Apr.2013


REP03-14-90

1-11. <Check shut down LED>

Select (CL)

- * [Yes] if LED is on
- * [No] if LED is off

in response to "Is the LED of the target PCB(s) lit?".




If [No] is selected:

Select (CL) [OK] in response to "Check the location of the target PCB(s)(DKA-nnn), then pull out the PCB(s) without considering the status of LED.". (Refer to "2. HARDWARE REPLACEMENT PROCESSING")

Note: Select (CL) [OK] after pulling out the PCB.

Go to Step 1-12.



1-12. <Beginning of DKA replacement>

"Please replace the PCB(s)(DKA-nnn). After replacement, please select [OK]." is displayed.

Select (CL) [OK] after replacing the PCBs.

Go to "2. HARDWARE REPLACEMENT PROCESSING".



Rev.1 / Sep.2010, Apr.2013

REP03-14-100

Copyright © 2010, 2013, Hitachi, Ltd.

Blank Sheet

DKC710I Hitachi Proprietary Copyright © 2010, 2013, Hitachi, Ltd.


Rev.2 / Oct.2010, Apr.2013

REP03-14-110

Blank Sheet

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Rear DKC	1	DKA (Disk Adapter) PCB	• WP720-A



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-14-130

Copyright © 2010, Hitachi, Ltd.

2-1. Remove the DKA PCB.

a. Check that the Shut Down LED is on. (only hot replace)





Fig. 3.14.2-1 Confirmation of Shut Down LED

REP03-14-140

- b. Disconnect the cables from the failed DKA PCB.
- c. Remove the two screws and remove the failed PCB.



Note: After removing the PCB, install the spare PCB immediately.

If the PCB is kept removed for a long time, the wind doesn't flow among installed PCBs, causing the PCBs' temperature rise which may result in temperature warning or temperature alarm.





Fig. 3.14.2-2 Removal of PCB

REP03-14-150

2-2. Insert the spare PCB.

a. Insert the spare PCB to the correct location and tighten the screws.



b. Connect the cables to the spare PCB after checking "3.1.7 Notes when connecting the DEV interface cable" (INST03-01-180).

2-3. Go to "3. POST-PROCESSING of SVP".


Rev.0 / Sep.2010

REP03-14-160

Copyright © 2010, Hitachi, Ltd.

3. POST-PROCESSING of SVP

3-1. <Beginning of DKA Replacement>
Select (CL) [OK] in response to "Please replace the PCB(s)(DKA-nnn). After replacement, please select [OK]." after replacement.



3-2. < Check the recovery processing>

The following message is displayed:

- "Restoring the DKA-xxx..."
- "DKA-xxx is being path recovered..."
- 3-3.

"DKU PATH INLINE is now running..." is displayed.

3-4. <Check the recovery processing>
The following message is displayed:

"Restoring the DKA..."

Rev.2 / Oct.2010, Sep.2011

REP03-14-170

Copyright © 2010, 2011, Hitachi, Ltd.

3-5. <Check the end of DKA recovery> Select (CL) [OK] in response to "Replace finished.".



3-6.

Go to POST-PROCEDURE [REP04-01-10].

[ESW REPLACEMENT PROCESSING - RES1]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select ESW (status check)
 - ② Specify Replacement
 - ③ Place PCB into blocked state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify recovery of ESW

Rev.0 / Sep.2010

REP03-15-20


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.




Copyright © 2010, Hitachi, Ltd.

1-2. <DKC window>
Select (CL) [DKC-n Back] in the 'DKC' window.



1-3. <Select ESW> Select (CL) ESW.



Rev.0 / Sep.2010

REP03-15-30

Copyright © 2010, Hitachi, Ltd.

1-4. <Specify replacement>



CAUTION

Be sure to operate procedure 1-5 to 1-7 within thirty minutes.


Select (CL) [Execute].

Selecting (CL) [Cancel] returns you to Step 1-3.



1-5. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



(1) <Confirm wearing wrist strap>
In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).



(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-3.

When [No] is selected (CL), returned to Step 1-5.



Rev.0 / Sep.2010

REP03-15-31

1-6. <ESW replace>

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).


Select (CL) [Yes] in response to: "Do you want to replace the PCB(s)(ESW-nnn)? If [Yes] is selected, the PCB(s) needs to be removed and inserted again.".



Rev.1 / Sep.2010, Oct.2010

REP03-15-40

1-7. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.



Copyright © 2010, Hitachi, Ltd.


1-8. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].

FILE (Field Failure Information)

FILE (Field Failure Information)






Rev.0 / Oct.2010

REP03-15-41

"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed. Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.



Copyright © 2010, Hitachi, Ltd.

A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format

"[factory_cd]_[Pcb_type]_[Pcb_SerialNo]_YYMMDDhhmmss.tgz".

(YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes Minute, and ss denotes Second)

Rev.1 / Sep.2010, Oct.2010

REP03-15-50

Copyright © 2010, Hitachi, Ltd.

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.


Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.

It returns to the drive selection screen when [Cancel] is selected (CL).

• When the destination media is write-protected.

<For Windows XP>



080314172442 Cannot access this file. Check security privileges over the network drive. OK Select a dump file

Select a dump file

\\tsclient\G\080320180607.tgz

You don't have permission to save in this location. Contact the administrator to obtain permission.

Would you like to save in the Administrator folder instead?

<u>Y</u>es

<u>N</u>o

<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.

Please appoint another destination

whether you remove write protect when you save it and carry it out.

• When dialog of the destination drive specified with the Client PC is open, the media is removed, and then select (CL) [Save].

Rev.1 / Sep.2010, Oct.2010

REP03-15-60

• When the memory in the destination drive specified with the Client PC is corrupted. The dialog remains displayed after selecting (CL) [OK].


At the time of the above operation completion, the information collection is not carried out.



Copyright © 2010, Hitachi, Ltd.

Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.

Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".



1-9. < Check ESW blocking>

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).


"Blocking the ESW..." is displayed.

1-10. <Check shut down LED>

Select (CL)

- * [Yes] if LED is on
- * [No] if LED is off

in response to "Is the LED of the target PCB(s) lit?".




If [No] is selected:

Select (CL) [OK] in response to "Check the location of the target PCB(s)(ESW-nnn), then pull out the PCB(s) without considering the status of LED.". (Refer to "2. HARDWARE REPLACEMENT PROCESSING")

Note: Select (CL) [OK] after pulling out the PCB.

Go to Step 1-11.




1-11. <Beginning of ESW replacement>

"Please replace the PCB(s)(ESW-nnn). After replacement, please select [OK]." is displayed.

Select (CL) [OK] after replacing the ESW.

Go to "2. HARDWARE REPLACEMENT PROCESSING".




Rev.0 / Sep.2010

REP03-15-80

Copyright © 2010, Hitachi, Ltd.

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Rear View of DKC	1	ESW PCB	• WP730-A



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-15-90

2-1. Remove the ESW PCB.

a. Check that the Shut Down LED is on. (only hot replace)





Fig. 3.15.2-1 Confirmation of Shut Down LED

Rev.0 / Sep.2010

REP03-15-100

- b. Disconnect the cable from the failed ESW PCB.
- c. Remove the two screws and remove the failed PCB.






Fig. 3.15.2-2 Removal of PCB


Rev.1 / Sep.2010, Oct.2010

REP03-15-110

15-110

2-2. Insert the spare PCB.

a. Insert the spare PCB to the correct location and tighten the screws.



2-3. Connect the cable to the spare PCB.


2-4. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Sep.2010 REP03-15-120 Copyright © 2010, Hitachi, Ltd.

3. POST-PROCESSING of SVP

3-1. < Check replacement of ESW>

Select (CL) [OK] in response to "Please replace the PCB(s)(ESW-nnn). After replacement, please select [OK]." after replacement.



- 3-2. <Check the ESW recovery procedure> "Restoring the ESW..." is displayed.
- 3-3. <Check the ESW replace finished>
 Select (CL) [OK] in response to "Replace finished.".



3-4.

Go to POST-PROCEDURE [REP04-01-10].

[DKCPANEL REPLACEMENT PROCESSING - RTC1]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select DKCPANEL (status check)
 - ② Stop environment monitor
 - 3 Specify Replacement
 - Detach DKCPANEL
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of DKCPANEL replacement
 - ② Reinstall related parts
 - 3 Start environment monitor

Rev.0 / Sep.2010

REP03-16-20


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
In the 'Maintenance' window, check and select (CL) [DKC-x] to be replaced.



Copyright © 2010, Hitachi, Ltd.

1-2. <Specify DKCPANEL > Select (CL) [PNLx].



Rev.0 / Sep.2010

REP03-16-30

Copyright © 2010, Hitachi, Ltd.

1-3. <Execute>



When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




(Eg. DKCPANEL-0)

Rev.0 / Sep.2010

REP03-16-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.




"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].



DKC710I

Copyright © 2010, Hitachi, Ltd.

Rev.1 / Sep.2010, Dec.2010

REP03-16-32

1-5. < Check beginning of DKCPANEL Replacement>

Select (CL) [Yes] in response to "Do you want to replace "DKCPANEL-n"? While replacing the parts, the rotational speed of the other fans will reach the maximum.".




(Eg. DKCPANEL-0)

1-6. <Check environment monitor stopped state>
The message "Processing to disable the environment check..." is displayed.




1-7. <Processing before exchanges>
The message "Turning on the LED of the target component..." is displayed.



1-8. < Checking lighting of the LED on the PCB to be pulled out>


Check the Module Number before working.

Toward the system connected to MODULE, and the basic rack frame of the right side is MODULE-0, basic rack frame of the left is MODULE-1.




In addition, there is a confirmation method such as follows. The device which READY lamp of DKC BEZEL turns on is MODULE-0.

When an READY lamp does not turn on, it is MODULE-0 that I throw an OP panel cover open, and I see an SW panel.



Loosen the screw, and remove the jumper cover.



Rev.0 / Sep.2010


REP03-16-41

Copyright © 2010, Hitachi, Ltd.

The message "Is the REPLACE LED of the (DKCPANEL-n) to be replaced on?" is displayed.

When the REPLACE LED on the component to be pulled out is on, select (CL) [Yes] and go to Step 1-10.

When the REPLACE LED on the component to be pulled out is kept off, select (CL) [No] and go to Step 1-9.




(Eg. DKCPANEL-0)

1-9. <Making sure of the DKCPANEL location>
The message "Check the location of the target component." is displayed.

See the "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the DKCPANEL location, select (CL) [OK] and go to Step 1-10.



1-10. <Check beginning of DKCPANEL Replacement>

The message "Please replace the "DKCPANEL-n." After replacement, press OK." is displayed.

(Reply with [OK] after replacing the special part.)


Go to "2. HARDWARE REPLACEMENT PROCESSING".



(Eg. DKCPANEL-0)

2. HARDWARE REPLACEMENT PROCESSING


Location	Function Name of Component		Part Name
Front of DKC	1	DKCPANEL	· SH525-A




DKCPANEL-1

Front View of DKC-0

Front View of DKC-1





Attached cover for covering the LEDs and switches.

NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-16-60

Copyright © 2010, Hitachi, Ltd.

2-1 DKCPANEL

2-1-1. Check the REPLACE LED of DKCPANEL.

a. Loosen the screw, and remove the jumper cover.




Fig. 3.16.2-1 Removal of Jumper Cover

b. Check that the REPLACE LED is on.




Fig. 3.16.2-2 Confirmation of REPLACE LED

- 2-1-2. Switches and Jumpers Setting on the DKCPANEL PCB of Spare Parts
 - a. Set the switches on the DKCPANEL PCB of spare parts as well as the switches on the DKCPANEL PCB that will be removed.
 - b. Set the jumpers on the DKCPANEL PCB of spare parts as well as the Jumpers on the DKCPANEL PCB that will be removed.

Rev.0 / Sep.2010

REP03-16-70

2-1-3. Replace the DKCPANEL PCB.

a. Loosen the two screws, and remove the cover.




Fig. 3.16.2-3 Removal of Cover

- b. Remove the Cable (P1) from the DKCPANEL PCB.
- c. Loosen the two screws, and remove the DKCPANEL PCB.




Fig. 3.16.2-4 Removal of DKCPANEL PCB

Copyright © 2010, Hitachi, Ltd.

Rev.0 / Sep.2010

REP03-16-80

Copyright © 2010, Hitachi, Ltd.

d. Remove the LIGHTPIPE on the DKCPANEL PCB, and attach it to the DKCPANEL PCB of spare parts.




Fig. 3.16.2-5 Removal/Attachment of LIGHTPIPE

- e. Attach the DKCPANEL PCB of spare parts, and tighten the screws. (Refer to Fig. 3.16.2-4.)
- f. Connect the cable (P1) to the DKCPANEL PCB.

2-1-4. Attach the Cover.

- a. Attach the cover, and tighten the two screws. (Refer to Fig. 3.16.2-3)
- b. Attach the jumper cover, and tighten the screw. (Refer to Fig. 3.16.2-1)


2-1-5. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Sep.2010

REP03-16-90

3. POST-PROCESSING of SVP

3-1. <Check replacement of DKCPANEL> Select (CL) [OK] in response to "Please replace the "DKCPANEL-n." After replacement, press OK.".




Copyright © 2010, Hitachi, Ltd.

(Eg. DKCPANEL-0)

3-2.


Select (CL) [OK] in response to "REMOTE MAINTENANCE SWITCH TEST: After turning switch to ENABLE position, press OK.".

When DKCPANEL on module1 side is exchanged, it is unnecessary.



3-3.

Select (CL) [OK] in response to "REMOTE MAINTENANCE SWITCH TEST: After turning switch to DISABLE position, Press OK.".



Rev.0 / Sep.2010


REP03-16-100

3-4.

Select (CL) [OK] in response to "RESTART JP TEST:

Execute the following procedures.

- 1. Attach the RESTART JP to DKCPANEL.
- 2. Detach the RESTART JP from DKCPANEL.
- 3. Select [OK]." is displayed.



Copyright © 2010, Hitachi, Ltd.





Fig. 3.16.3-1 Place of RESTART JP in DKCPANEL package

Rev.0 / Sep.2010


REP03-16-110

Copyright © 2010, Hitachi, Ltd.


3-5. <Processing after exchanges>
The message "Turning off the LED of the target component..." is displayed.



3-6. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-7. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "DKCPANEL-n" is
done.".



(Eg. DKCPANEL-0)

3-8.

Go to POST-PROCEDURE [REP04-01-10].

[SSVPMN REPLACEMENT PROCESSING - RTC2]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select SSVPMN (status check)
 - ② Specify Replacement
 - ③ Detach SSVPMN
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of SSVPMN replacement
 - ② Reinstall related parts


Rev.0 / Sep.2010

REP03-17-20


Copyright © 2010, Hitachi, Ltd.

1. PRE-PROCESSING of SVP


1-1. <Maintenance window>
In the 'Maintenance' window, check and select (CL) [DKC-x] to be replaced.



1-2. <Specify SSVPMN > Select (CL) [DKC-x Back].



[DKC-x Back] Select (CL) [SSVPMNx].



REP03-17-30

Copyright © 2010, 2013, Hitachi, Ltd.

1-3. < Execute >



When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

When the SVP High Reliability Kit has been installed and an SVP fail over (SIM=7FF3XX) is detected, at first, take actions to resolve the failure (SIM=7FF3XX).

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).


A window shown on the right is displayed.

Select (CL) [Execute] if PCI Option is not installed.



(Eg. PCI Option is not installed)

Select (CL) "SSVPMN", and select (CL) [Ok] if PCI Option is installed.




(Eg. PCI Option is installed)

Rev.0 / Sep.2010

REP03-17-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.




"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].



REP03-17-40


1-5. < Check beginning of SSVPMN Replacement>

The message "During the replacement of the target parts:

- RESTART switch, REMOTE MAINTENANCE switch and the environment monitoring will be disabled.
- The rotation speed of the FAN will be increased.
- The communication between SVP and SSVP will be blocked.

Do you want to replace "SSVPMN-n"?" is displayed.

Select (CL) [Yes].




Copyright © 2010, Hitachi, Ltd.

(Eg. SSVPMN-0)

1-6. <Processing before exchanges>


The message "Turning on the LED of the target component..." is displayed.



1-7. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the REPLACE LED of the (SSVPMN-n) to be replaced on?" is displayed.

When the REPLACE LED on the component to be pulled out is on, select (CL) [Yes] and go to Step 1-9.



(Eg. SSVPMN-0)

When the REPLACE LED on the component


to be pulled out is kept off, select (CL) [No] and go to Step 1-8.

1-8. <Making sure of the SSVPMN location>

The message "Check the location of the target component." is displayed.

See the "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the SSVPMN location, select (CL) [OK] and go to Step 1-9.



Rev.0 / Sep.2010

REP03-17-50

1-9. <Check beginning of SSVPMN Replacement>
The message "Please replace the "SSVPMNn." After replacement, press OK." is
displayed.

Go to "2. HARDWARE REPLACEMENT PROCESSING".




Copyright © 2010, Hitachi, Ltd.

(Eg. SSVPMN-0)

2. HARDWARE REPLACEMENT PROCESSING

Location		Function Name of Component	Part Name
Rear of DKC	1	SSVPMN	· SH524-A



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Copyright © 2010, 2014, Hitachi, Ltd.

2-1 SSVPMN

2-1-1. Remove the SSVPMN.

- a. Check that the REPLACE LED is on.
- b. Loosen the screw and remove the fixed plate.
- c. Operate the levers and remove the SSVPMN PCB.




Fig. 3.17.2-1 Removal of SSVPMN


Rev.0 / Feb.2014

REP03-17-71

Copyright © 2014, Hitachi, Ltd.

2-1-2. Set the Jumpers.

a. Set the jumpers (JP1 and JP2) in the spare SSVPMN. For jumper settings, refer to LOC06-160.




Top View of SSVPMN

Fig. 3.17.2-2 Jumper Setting of SSVPMN

$\overline{2}$ -1-3. Insert the SSVPMN.

- a. Insert the spare SSVPMN PCB. (Refer to Fig. 3.17.2-1.).
- b. Attach the fixed plate and tighten the screw.
- c. Check that the REPLACE LED is off.




2-1-4. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Sep.2010

REP03-17-80

3. POST-PROCESSING of SVP

3-1. <Check replacement of SSVPMN>
Select (CL) [OK] in response to "Please replace the "SSVPMN-n." After replacement, press OK.".




Copyright © 2010, Hitachi, Ltd.

(Eg. SSVPMN-0)

3-2. <Warning message>

If the target is SSVPMN-1, go to Step 3-4. When the versions of two microprograms, one is to be downloaded to the SSVPMN and the other is stored in an ROM of the SSVPMN, are the same, a message, "The version of SSVP microprogram in SSVPMN and SVP



are the same. So microprogram is not downloaded." is displayed. Select (CL) [OK] and go to Step 3-4.

When the number of times of the SSVP microprogram downloading exceeds 100, a message, "Write count of SSVP micro program exceeds warranted value (100). Do you want to continue?" is displayed. When you download the microprogram, select (CL) [Yes] and go to Step 3-3.



When you do not download the microprogram, select (CL) [No] and go to Step 3-4.

A CAUTION

When you download the microprogram, an entry of a password is requested. Contact the Technical Support Division to ask for an instruction.

Rev.0 / Sep.2010

REP03-17-90


Copyright © 2010, Hitachi, Ltd.

3-3.

The message "SSVP microprogram download. (n/15)" is displayed.



3-4. <Check end of replacement>
Select (CL) [OK] in response to "Replacement of the "SSVPMN-n" is done.".



(Eg. SSVPMN-0)

3-5.

Go to POST-PROCEDURE [REP04-01-10].

[DKCFAN(60sq) REPLACEMENT PROCESSING - RTC3]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select DKCFAN(60sq) (status check)
 - ② Stop environment monitor
 - 3 Specify Replacement
 - Detach DKCFAN(60sq)
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of DKCFAN(60sq) replacement
 - ② Reinstall related parts
 - 3 Start environment monitor

Rev.0 / Sep.2010

REP03-18-20


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
In the 'Maintenance' window, check and select (CL) [DKC-x] to be replaced.




Copyright © 2010, Hitachi, Ltd.

1-2. <Specify special part DKCFAN> Select (CL) [DKC-x Back].



[DKC-x Back] Select (CL) [FANnnn].



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-18-30

Copyright © 2010, Hitachi, Ltd.

1-3. <Execute>



A CAUTION

When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




(Eg. DKCFAN-010)

Rev.0 / Sep.2010

REP03-18-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.




"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].



Rev.0 / Sep.2010

REP03-18-32

Copyright © 2010, Hitachi, Ltd.

1-5. <Check beginning of DKCFAN Replacement> Select (CL) [Yes] in response to "Do you want to replace "DKCFAN-nnn"? While replacing the parts, the rotational speed of the other fans will reach the maximum.".




(Eg. DKCFAN-010)

1--6. < Checking the FAN >

The SVP automatically checks the DKC FAN to see if it is replaceable.

1-7. <Check environment monitor stopped state>
The message "Processing to disable the environment check..." is displayed.




Rev.0 / Sep.2010

REP03-18-40

1-8. < Processing before exchanges>

The message "Turning on the LED of the target component..." is displayed.



Copyright © 2010, Hitachi, Ltd.

1-9. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the REPLACE LED of the (DKCFAN-nnn) to be replaced on?" is displayed.

When the REPLACE LED on the component to be pulled out is on, select (CL) [Yes] and go to Step 1-11.



(Eg. DKCFAN-010)


When the REPLACE LED on the component

to be pulled out is kept off, select (CL) [No] and go to Step 1-10.

1-10. <Making sure of the DKCFAN location> The message "Check the location of the target component." is displayed.

See the "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the DKCFAN location, select (CL) [OK] and go to Step 1-11.



1-11. <Check beginning of DKCFAN Replacement>

The message "Please replace the "DKCFANnnn." After replacement, press OK." is displayed.

(Reply with [OK] after replacing the special part.)

Go to "2. HARDWARE REPLACEMENT PROCESSING".



(Eg. DKCFAN-010)


Rev.0 / Sep.2010

REP03-18-50

Copyright © 2010, Hitachi, Ltd.

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component	Part Name
Rear of DKC	1 FAN (60sq) Assembly	



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-18-60

Copyright © 2010, Hitachi, Ltd.

2-1 FAN (60sq) Assembly

A CAUTION

Hazardous rotating mechanism:

Can cause injury if touched. Stay clear of it when machine is running.

2-1-1. Replace the FAN (60sq) Assembly.

- a. Check that the REPLACE LED is on.
- b. Loosen the screw and remove the failed FAN (60sq) Assembly.
- c. Take time for 10 seconds from removing the FAN (60sq) Assembly to the installation.
- d. Attach the spare FAN (60sq) Assembly and tighten the screw.
- e. Make sure the replaced LED has been turned off after 30 seconds have passed since the FAN (60sq) Assembly was replaced.




Fig. 3.18.2-1 Replacement of FAN (60sq) Assembly


2-1-2. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Sep.2010

REP03-18-70

3. POST-PROCESSING of SVP

3-1. <Check replacement of DKCFAN>
Select (CL) [OK] in response to "Please replace the "DKCFAN-nnn." After replacement, press OK." After replacement, press OK."




Copyright © 2010, Hitachi, Ltd.


(Eg. DKCFAN-010)

3-2. <Processing after exchanges>
The message "Turning off the LED of the target component..." is displayed.

If the LED is lit, it turns off in this screen.



3-3. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-4. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "DKCFAN-nnn" is
done.".



(Eg. DKCFAN-010)

Rev.0 / Sep.2010

REP03-18-80

$3\text{-}5. < \!\! \text{Confirm status} \!\! >$

Confirm the status display.

If button is normal (The string is normally display), go to step 3-6.

If button is abnormal (The string is blinking), replace the target part again, or see TROUBLE SHOOTING SECTION.

3-6.

Go to POST-PROCEDURE [REP04-01-10].

Copyright © 2010, Hitachi, Ltd.

[DKCFAN(80sq) REPLACEMENT PROCESSING - RTC4]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select DKCFAN(80sq) (status check)
 - ② Stop environment monitor
 - 3 Specify Replacement
 - Detach DKCFAN(80sq)
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of DKCFAN(80sq) replacement
 - ② Reinstall related parts
 - 3 Start environment monitor

Rev.0 / Sep.2010

REP03-19-20


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
In the 'Maintenance' window, check and select (CL) [DKC-x] to be replaced.



Copyright © 2010, Hitachi, Ltd.

1-2. <Specify DKCFAN>
[DKC-x Front]
Select (CL) [FANnnn].



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-19-30

Copyright © 2010, Hitachi, Ltd.

1-3. <Execute>



A CAUTION

When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




(Eg. DKCFAN-010)

Rev.0 / Sep.2010

REP03-19-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.


When the processing will be stopped, select (CL) [Yes].



Rev.0 / Sep.2010

REP03-19-32

1-5. <Check beginning of DKCFAN Replacement>
Select (CL) [Yes] in response to "Do you want to replace "DKCFAN-nnn"? While replacing the parts, the rotational speed of the other fans will reach the maximum.".




Copyright © 2010, Hitachi, Ltd.

(Eg. DKCFAN -010)

1--6. < Checking the FAN >

The SVP automatically checks the DKC FAN to see if it is replaceable.

1-7. <Check environment monitor stopped state>
The message "Processing to disable the environment check..." is displayed.




Rev.0 / Sep.2010

REP03-19-40

1-8. < Processing before exchanges>

The message "Turning on the LED of the target component..." is displayed.



Copyright © 2010, Hitachi, Ltd.

1-9. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the REPLACE LED of the (DKCFAN-nnn) to be replaced on?" is displayed.

When the REPLACE LED on the component to be pulled out is on, select (CL) [Yes] and go to Step 1-11.



(Eg. DKCFAN-010)


When the REPLACE LED on the component

to be pulled out is kept off, select (CL) [No] and go to Step 1-10.

1-10. <Making sure of the DKCFAN location>
The message "Check the location of the target component." is displayed.

See the "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the DKCFAN location, select (CL) [OK] and go to Step 1-11.




1-11. <Check beginning of DKCFAN Replacement>

The message "Please replace the "DKCFANnnn." After replacement, press OK." is displayed.

(Reply with [OK] after replacing the special part.)


Go to "2. HARDWARE REPLACEMENT PROCESSING".



(Eg. DKCFAN-010)

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component	Part Name
Front of DKC	1 FAN (80sq) Assembly	



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-19-60

Copyright © 2010, Hitachi, Ltd.

2-1 FAN (80sq) Assembly

A CAUTION

Hazardous rotating mechanism:

Can cause injury if touched. Stay clear of it when machine is running.

2-1-1. Replace the FAN (80sq) Assembly.

- a. Check that the REPLACE LED is on.
- b. Loosen the screw and remove the failed FAN (80sq) Assembly.
- c. Take time for 10 seconds from removing the FAN (80sq) Assembly to the installation.
- d. Attach the spare FAN (80sq) Assembly and tighten the screw.
- e. Make sure the replaced LED has been turned off after 30 seconds have passed since the FAN (80sq) Assembly was replaced.




Fig. 3.19.2-1 Replacement of FAN (80sq) Assembly

2-1-2. Go to "3. POST-PROCESSING of SVP".


Rev.0 / Sep.2010

REP03-19-70

Copyright © 2010, Hitachi, Ltd.

3. POST-PROCESSING of SVP


3-1. <Check replacement of DKCFAN> Select (CL) [OK] in response to "Please replace the "DKCFAN-nnn." After replacement, press OK.".




(Eg. DKCFAN-010)

3-2. <Processing after exchanges>
The message "Turning off the LED of the target component..." is displayed.


If the LED is lit, it turns off in this screen.



3-3. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-4. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "DKCFAN-nnn" is
done.".



(Eg. DKCFAN-010)

Rev.0 / Sep.2010

REP03-19-80

$3\text{-}5. < \!\! \text{Confirm status} \!\! >$

Confirm the status display.

If button is normal (The string is normally display), go to step 3-6.

If button is abnormal (The string is blinking), replace the target part again, or see TROUBLE SHOOTING SECTION.

3-6.

Go to POST-PROCEDURE [REP04-01-10].

Copyright © 2010, Hitachi, Ltd.

[SVP REPLACEMENT PROCESSING - RTC5]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select SVP (status check)
 - ② Specify Replacement
 - 3 Detach SVP
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① SVP setting
 - ② Config Backup

— Advance preparation—OSS mediaMicro program mediaBackup Config media

When SVP is not able to operate, start from "2. HARDWARE REPLACEMENT PROCESSING. (When SVP High Reliability Kit is not installed.)

1. PRE-PROCESSING of SVP

A CAUTION

<When the parts to be replaced is the SVP>

When the Audit Log information which is not downloaded remains, ask the customer to download the Audit Log information as needed.

When the customer needed to download Performance Monitor of Web Console, ask the customer to download the Performance data.

When the customer uses original key and manifest file for SSL communication of Web Console, ask the customer to prepare these data, see "Hitachi Storage Navigator User Guide".

When the SVP High Reliability Kit has been installed and an SVP fail over (SIM=7FF3XX) is detected, at first, take actions to resolve the failure (SIM=7FF3XX).

(1) <Operation Mode Change>
Change the mode to [Modify Mode].
Select (CL) the [Maintenance] button.

<When the SVP High Reliability Kit has been added. And [master svp] >

The SVP to be replaced must be a standby SVP. When the SVP to be replaced is a master SVP, replace it after switching its status to standby. Replace the master SVP only when the SVP status cannot be switched to standby.

Go to Step 1-1

<When the SVP High Reliability Kit has been not added. or [standby svp]>

Ask the customer to backup the user account information and the environment setting information of Web Console. Please refer to "Hitachi Storage Navigator User Guide" for the backup method.

Go to step 1-2

1-1. SVP Switching

This function is valid when the SVP High Reliability Kit is installed.

Notice: This operation needs that Standby SVP (IP Address: xxx.xxx.xxx.14) is a View mode.

Notice: When screen saver operates (60 minutes pass without operation) with a Standby SVP having been connected to the remote desktop, this operation fails.


Rev.0 / Sep.2010

REP03-20-30


Copyright © 2010, Hitachi, Ltd.

(1)

Select (CL) [Maintenance]-[SVP]-[Switch SVP] from the menu.



(2) <Execution>
 Execute switching.Select (CL) [Yes].* Switching takes about 20 minutes.



(3) <Configuration Information Transfer> The message "Transferring subsystem configuration data..." is displayed.

Transferring subsystem configuration data...

The SVP transfers the configuration information automatically to reflect the configuration

information of the master SVP on the standby side SVP. Therefore, if the transfer processing of the configuration information overlaps, the actually transferred status display may be repeated.

Rev.0 / Sep.2010

REP03-20-40

(4) <SVP Switching Start Check>

The message "Switching SVPs has started." is displayed.

The subsystem is automatically restarted and in the Standby status by SVP switching.

(SVP and Console PC are disconnected.)



Copyright © 2010, Hitachi, Ltd.

(5) <Connection to SVP after Switching Operation>

It waits for about 3 minutes until a change is completed.


After Standby SVP starts as Master SVP by the switching indication, use the connection utility connect Console PC and the switched SVP.

Select (CL) IP Address of SVP in the "SvpConnectUtility" window and select (CL) [Connect].


(IP Address is the same with that of SVP at the time of the SVP switching indication.)

(6) <Initial Window>
Press the "Web Server Status" button.

(7) <Web Server Status Window>
If all function's Status displays Ready, switching is completed.



Note: The message "A duplicate name exists on the network." may be displayed by network environment after a change. Although the message may be displayed, there is especially no problem.




Rev.0 / Sep.2010

REP03-20-50

ep.2010 Copyright © 2010, Hitachi, Ltd. **20-50**

1-2. <Maintenance window>

In the 'Maintenance' window, check and select (CL) [DKC-x] to be replaced.



1-3. <Specify SVP>

Select (CL) the button to indicate the parts to be replaced.


[DKC-x Back]

· MASTER SVP ----- [SVP-BASIC]

1-3-1(REP03-20-60)

· STANDBY SVP ----- [SVP-OPTION]

1-3-2(REP03-20-110)



Rev.0 / Sep.2010

REP03-20-60

Copyright © 2010, Hitachi, Ltd.

1-3-1. MASTER SVP

1-3-1.1. <Execute>

A CAUTION

When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute]. Go to Step 1-3-1.2.




Rev.0 / Sep.2010

REP03-20-61

1-3-1.2. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-3-1.3.




"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].



Others

[SPC3397W]

maintenance manual.

Do you want to replace SVP-BASIC?

Rev.0 / Sep.2010

REP03-20-70


Copyright © 2010, Hitachi, Ltd.

<u>Ν</u>ο

1-3-1.3. <Check beginning of SVP Replacement>

<When the SVP High Reliability Support Kit has not been added>

The message, "DKC-SVP communication will be blocked. Do you want to replace the "SVP-BASIC?"" is displayed.
When you perform the replacement, select (CL) [Yes].
Go to Step 1-3-1.4.



There are duplicated SVPs. It is safer if you switch to the other SVP and replace SVP-BASIC according to the instruction in the


<u>Y</u>es

<When the SVP High Reliability Support Kit has been added>

The message, "There are duplicated SVPs. It is safer if you switch to the other SVP and replace SVP-BASIC according to the instruction in the maintenance manual. Do you want to replace SVP-BASIC?" is displayed.

When you perform the replacement, select (CL) [Yes].

The message, "DKC-SVP communication will be blocked. Do you want to replace the "SVP-BASIC?"" is displayed. When you perform the replacement, select (CL) [Yes]. Go to Step 1-3-1.4.



Rev.0 / Sep.2010


REP03-20-80

1-3-1.4. <Attaching a jumper plug>

Attach a maintenance jumper plug to the jumper pin JP1 of the SVP-BASIC to be replaced and select (CL) [OK] following the message, "Attach a jumper plug for JP1 to SVP-BASIC, and then select [OK]."



Copyright © 2010, Hitachi, Ltd.



Go to Step 1-3-1.6. When the maintenance jumper plug is not attached, go to Step 1-3-1.5.

Rev.0 / Sep.2010

REP03-20-90

1-3-1.5. < Checking re-attachment of the jumper plug>

When the jumper plug is not attached, the message, "A jumper plug for JP1 is not attached to SVP-BASIC. If you want to replace the SVP-BASIC, attach the jumper plug, and then select [OK]." is displayed. Attach the jumper plug to the jumper pin JP1 of the SVP to be replaced and select (CL) [OK].



Copyright © 2010, Hitachi, Ltd.

Go to Step 1-3-1.6.

When the jumper plug is not attached, re-execute Step 1-3-1.4.

1-3-1.6. <Powering off the SVP>


The message, "After the SVP was turned off automatically, replace the SVP-BASIC." is displayed.

Select (CL) [OK].




1-3-1.7. <The check of Console PC shut down>
The message, "If you shut down this remote computer, no one can use it until someone at the remote location manually restart it. Do you want to continue shutting down?" is displayed.


Select (CL) [Yes].



REP03-20-100

1-3-1.8. <SVP power supply OFF confirmation>





It is confirmed that SVP POWER LED(①) in front of the main body of SVP disappears.

1-3-1.9. <SVP replacement> Replace the SVP.

The message "The remote so

The message, "The remote session to the remote computer was ended by means of an administration tool. Your administrator might have ended your connection." is displayed.



Select (CL) [OK].

Go to "2. HARDWARE REPLACEMENT PROCESSING". (REP03-20-140)

Rev.0 / Sep.2010

REP03-20-110

Copyright © 2010, Hitachi, Ltd.

1-3-2. STANDBY SVP

1-3-2.1. <Execute>

A CAUTION

When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

<When the SVP High Reliability Support Kit has been added>

The SVP to be replaced must be a standby SVP. When the SVP to be replaced is a master SVP, replace it after switching its status to standby. (See step 1-1) Replace the master SVP only when the SVP status cannot be switched to standby.

A window shown on the right is displayed. Select (CL) [Execute]. Go to Step 1-3-2.2.




Rev.0 / Sep.2010

REP03-20-111

1-3-2.2. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-3-2.3.




"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].



Rev.0 / Sep.2010

REP03-20-120

Copyright © 2010, Hitachi, Ltd.

1-3-2.3. <Check beginning of SVP Replacement>

The message, "DKC-SVP communication will be blocked. Do you want to replace the "SVP-OPTION?"" is displayed.

When you perform the replacement, select (CL) [Yes].


Go to Step 1-3-2.4.



1-3-2.4. < Attaching a jumper plug>

Attach a maintenance jumper plug to the jumper pin JP1 of the SVP-OPTION to be replaced and select (CL) [OK] following the message, "Attach a jumper plug for JP1 to SVP-OPTION, and then select [OK]."





Go to Step 1-3-2.5.

REP03-20-130

1-3-2.5. <Check beginning of SVP Replacement>

The message "Please replace the "SVP-OPTION." After replacement, press OK." is displayed.

(Reply with [OK] after 3-13 Resetting the SSVP.)



1-3-2.6. <Disconnecting the SVP>


Select (CL) [Disconnect] from the [Start] menu.

Go to "2. HARDWARE REPLACEMENT PROCESSING". (REP03-20-140)



2. HARDWARE REPLACEMENT PROCESSING

Location		Function Name of Component	Part Name
Rear of DKC	1	SVP	•



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.1 / Sep.2010, Sep.2011

REP03-20-150

SVP

2-1

Copyright © 2010, 2011, Hitachi, Ltd.


2-1-1. SVP PS OFF

a. Check that the SVP POWER LED is off.

When the SVP POWER LED is still on, press the SVP PS OFF switch on the SVP and check if the SVP POWER LED is off.

When the SVP POWER LED is still on even if three minutes have passed since the SVP PS OFF switch was pressed, press the SVP PS OFF switch and the SVP PS ON switch on the SVP at the same time for five seconds or more (forced power off) and check if the SVP POWER LED is off.

b. Check that the SVP SHUT DOWN LED of the SVP is on.






Fig. 3.20.2-1 SVP PS OFF


Rev.0 / Sep.2010

REP03-20-160

Copyright © 2010, Hitachi, Ltd.

2-1-2. Remove the SVP

- a. Disconnect all the cables from the failed SVP.
- b. Loosen the two screws and remove the failed SVP.






Fig. 3.20.2-2 Removal of SVP

Rev.0 / Sep.2010

REP03-20-170

2-1-3. Set the Jumper

- a. When the maintenance jumper is inserted into the JP1 on the failed SVP, remove the maintenance jumper.
- b. Insert the maintenance jumper into the JP1 on the spare SVP.




Fig. 3.20.2-3 Insertion of Maintenance Jumper

Copyright © 2010, Hitachi, Ltd.

Rev.1 / Sep.2010, Oct.2010

REP03-20-180

Copyright © 2010, Hitachi, Ltd.

2-1-4. Install the spare SVP

- a. Install the spare SVP and tighten the two screws. (Refer to Fig. 3.20.2-2.)
 Note: Confirm the vertical direction of the SVP. If the direction was wrong, the SVP will not be ON.
- b. Connect all the cables to the spare SVP.

2-1-5. SVP PS ON

a. Check that the SVP POWER LED of the SVP is on. (Refer to Fig. 3.20.2-1.)

2-1-6. Go to "3. POST-PROCESSING of SVP".


REP03-20-190

3. POST-PROCESSING of SVP

<Post operation of STANDBY SVP replace>


(1)

When SVP High Reliability Support Kit is set and replaced STANDBY SVP, switch to MASTER SVP (IP address: xxx.xxx.xxx.15), select (CL) the [OK] for "Please replace the "SVP-OPTION." After replacement, press OK.".



(2)

For a message "Refer to the maintenance manual to set up the SVP-OPTION.
Select [OK] after the settings are completed.", operate the following.



3-1. Powering up the SVP

A CAUTION

If the MESSAGE LED on DKCPANEL has lit on when power on SVP, please complete SIM before operation.

(When the SVP high-reliability kit is installed, SIM RC=BF85A3 (Basic SVP JP1 setting error), BF86A3 (Optional SVP JP1 setting error), BFE3A2 (SVP duplication setting defect) and 7FF201 (standby SVP failure detection) may occur but there is no problem because they occur in process of the SVP replacement.)



When an SSVP alarm is issued during replacement of the SVP, reset the SSVP.



If the message "Do you want to restart your computer now?" is displayed during the SVP reboot after replacement, select (CL) [Yes].

Rev.0 / Aug.2014

REP03-20-191

3-1-1. Connecting the Console PC

Connect the console PC to the SVP has been replaced using the utility for connection. Please refer to SVP01-60 for the usage of the utility for connection.

The login user is different by the presence of the microprogram.

[Connection destination] 126.255.255.15

Note: Keep the IP address of Console PC, and set it to 126.255.255.x (x is the available value which is 13 or less. For example 12.) before connection. Reset it after the SVP setup. The SVP and the Console PC communicate by the auto negotiation, 1Gbps or less (Depend on the specification of console PC).

It waits for about 10 minutes the start.

In this section, using two user type to connect with the SVP. If you don't know the password, please contact with the technical support division. When there is no description, using "Installed User".

After you input a user name and the password, input "Maintenance Password". If you don't know the "Maintenance Password", please contact with the technical support division.


Copyright © 2014, Hitachi, Ltd.

Rev.0 / Sep.2010

REP03-20-200

Copyright © 2010, Hitachi, Ltd.


- 3-1-2. Setting the Data and Time
 - <Making sure of the setting of a time zone>
 - (1) Open the 'Control Panel' window. Select (DR) [Settings]-[Control Panel] from the [Start] menu.



(2) Open the 'Date and Time' window. Select (DC) [Date and Time] in the [Control Panel] window.



(3) Select [Change time zone]. Select (CL) [Change time zone...].



Rev.0 / Sep.2010

REP03-20-210

Copyright © 2010, Hitachi, Ltd.

(4) Make sure of the setting of the [Time Zone Settings].

Make sure that the [Time Zone Settings] is set as "[GMT] Greenwich Mean Time; Dublin, Edinburgh, Lisbon, London" irrespective of a place where the subsystem is installed.

Besides, make sure that the check box to the left of the statement, "Automatically adjust clock for Daylight Saving Time" is blank (not checked).



Notice: When a setup of [Time Zone] and "Automatically adjust clock for daylight saving changes" are changed after installation of a SVP micro program, please be sure to reboot SVP after a setup.

(5) <Set the [Date and Time Settings]> Check if the [Date and Time Settings] is set to the current time and date.

If not, reset it correctly. Then, select (CL) [OK].



(6) Close the 'Control Panel' window. Select (DR) [File] and [Close] in this order in the "Control Panel" window.

Rev.2 / Oct.2010, Dec.2010

REP03-20-220


Copyright © 2010, Hitachi, Ltd.

3-2. <Installing the Microprogram>

3-2-1. Preparation

When the Microprogram has already been installed in the SVP (when "Wait for Storage Navigator Start" is displayed in desktop window) in replaced SVP (service parts), perform the following operations. When the Microprogram is not installed, go to 3-2-2.

① Perform uninstalling Apache program. (Go to 3-2-1.1 Uninstalling Apache)



- ② Perform uninstalling Tomcat program. (Go to 3-2-1.2 Uninstalling Tomcat program)
- ③ Perform uninstalling SMI-S Provider program. (Go to 3-2-1.3 Uninstalling SMI-S Provider program)
- 4 Perform uninstalling Java program. (Go to 3-2-1.4 Uninstalling Java program)
- © Perform uninstalling Perl program. (Go to 3-2-1.5 Uninstalling Perl program)
- © Perform uninstalling Flash Player program. (Go to 3-2-1.6 Uninstalling Flash Player program)

Rev.0 / Sep.2010

REP03-20-230

3-2-1.1. Uninstalling Apache

(1) Mount the OSS media
Insert the OSS media (the second media) to the CD-ROM drive in the Console PC.

(2) Launch the Command Prompt as administrator Select (CL) [Start]-[Programs][Accessories], and launch the Command Prompt with 'Run as administrator' in right-click menu.




Copyright © 2010, Hitachi, Ltd.

(3) Launch the uninstallation batch Enter

"\\tsclient\e\JavaAp\Apache\ApacheUnIn st.bat" into the Command Prompt, and press the Enter key.

At the end of this process, the Command Prompt will close automatically.



Note: The input value is the form of

"\\tsclient\<drive letter>\ JavaAp\Apache\ApacheUnInst.bat".

A drive letter is made the drive which inserted the OSS media.

The above is a case where the CD-ROM drive is assigned a drive letter E.

(4) Take out the OSS media

Take out the OSS media (the second media) from the CD-ROM drive in the Console PC.


REP03-20-240

3-2-1.2. Uninstalling Tomcat program


(1) Select (CL) [Start]-[Settings]-[Control Panel].



(2) Select (DC) [Programs and Features].




(3)
Select (CL) [Apache Tomcat 6.0 (remove only)], and select (CL)
[Uninstall/Change].
If there is no [Apache Tomcat 6.0 (remove only)] in the list, go to 3-2-1.3.



Rev.1 / Sep.2010, Aug.2014


REP03-20-250

(4) Select (CL) [Uninstall].




(5) If the following message box is displayed, select (CL) [Yes].

If "Note: C:\Program Files (x86)\Apache Software Foundation\Tomcat 6.0 could not be removed." is displayed, select (CL) [OK].




(6)
When "Uninstallation Complete"
dialogue box is displayed, select (CL)
[Close].



(7)

[Apache Tomcat 6.0 (remove only)] in 'Programs and Features' window was deleted.

Close the window.



Notice: Until procedure 3-2-1 is finished, please don't logout or shutdown SVP. If you do them, SVP may no longer work properly. If a shutdown request message is displayed, please don't shutdown.


Copyright © 2010, Hitachi, Ltd.

3-2-1.3. Uninstalling SMI-S Provider program


(1) Launch the Control Panel Select (CL) [Start]-[Settings]-[Control Panel].



(2) Launch the Program and Features Select (DC) [Programs and Features].



(3) Run uninstallation
Select (CL) [Embedded SMI-S Provider],
and select (CL) [Uninstall] button.
If there is no [Embedded SMI-S Provider]
in the list, go to 3-2-1.4.



Rev.0 / Dec.2010

REP03-20-262

(4) Make sure the massage If following message box is displayed, select (CL) [Yes].

"Are you sure you want to uninstall Embedded SMI-S Provider?"




Copyright © 2010, Hitachi, Ltd.

(5) The dialog box is displayed while processing the uninstallation.

At the end of this process, the dialog box.

Embedded SMI-S Provider.

At the end of this process, the dialog box will close automatically.




(6) Check the result and close the window. [Embedded SMI-S Provider] in 'Programs and Features' window was deleted.

Close the window.

Notice: When the SVP High Reliability Kit is installed, you need to install it for the standby SVP in the same procedure. About the switching SVP, refer

to Post-Procedure "2.18. SVP Switching" in the "SVP SECTION".




3-2-1.4. Uninstalling Java program


(1) Select (CL) [Start]-[Settings]-[Control Panel] in this order.



(2) Select (DC) [Programs and Features].



(3)
Select [Java(TM) SE Development Kit 6
Update 12], and then select (CL)
[Uninstall/Change].
If there is no [Java(TM) SE Development
Kit 6 Update 12] in the list, go to (8).



(4)

A message, "Are you sure you want to uninstall Java(TM) SE Development Kit 6 Update 12?" is displayed. Select (CL) [Yes].



(5)

Uninstallation of Java is started.



(6)

When this window is not displayed, go to (7).

When this window is displayed, select (CL) [No]. (*1)


Notice: Don't select [Yes]. If you do them, SVP may no longer work properly.



- *1: If selecting (CL) [Yes], SVP will be rebooted. In this case, follow the procedures below.
 - Login to SVP after rebooting.
 Refer to "3-1-1. Connecting the Console PC" (REP03-20-190) to choose login user name
 - When the following message is displayed, select (CL) [OK]. "Unable to log into the SVP, because there is a problem with its system requirements. Reboot it, and then reconfigure the SVP."
 - Continue procedures from (8) after SVP rebooting.
 Refer to "3-1-1. Connecting the Console PC" (REP03-20-190). Please use "Preinstalled User".
- (7)

The [Java(TM) SE Development Kit 6 Update 12] is deleted from the 'Programs and Features' window.


Close the window by selecting (CL) the $[\times]$ button.



Rev.2 / Oct.2010, Dec.2010


REP03-20-290

(8) Select (CL) [Start] -[Settings]-[Control Panel] in this order.




Copyright © 2010, Hitachi, Ltd.

(9) Select (DC) [Programs and Features].



(10)
Select [Java(TM) 6 Update 12], and then select (CL) [Uninstall/Change].
If there is no [Java(TM) 6 Update 12] in the list, go to 3-2-1.5.




Rev.0 / Sep.2010

REP03-20-300

(11)

A message, "Are you sure you want to uninstall Java(TM) 6 Update 12?" is displayed.


Select (CL) [Yes].



Copyright © 2010, Hitachi, Ltd.

(12)

Uninstallation of Java is started.




(13)

When this window is not displayed, go to (14).

When this window is displayed, select (CL) [No]. (*1)

Notice: Don't select [Yes]. If you do them, SVP may no longer work properly.




- *1: If selecting (CL) [Yes], SVP will be rebooted. In this case, follow the procedures below.
 - Login to SVP after rebooting.
 Refer to "3-1-1. Connecting the Console PC" (REP03-20-190) to choose login user name.
 - When the following message is displayed, select (CL) [OK]. "Unable to log into the SVP, because there is a problem with its system requirements. Reboot it, and then reconfigure the SVP."
 - Continue procedures from 3-2-1.5. after SVP rebooting.
 Refer to "3-1-1. Connecting the Console PC" (REP03-20-190). Please use "Preinstalled User".

(14)

The [Java(TM) 6 Update 12] is deleted from the 'Programs and Features' window.

Close the window by selecting (CL) the $\lceil \times \rceil$ button.




3-2-1.5. Uninstalling Perl program


(1) Select (CL) [Start] -[Settings]-[Control Panel] in this order.



(2) Select (DC) [Programs and Features].



(3)
Select [ActivePerl 5.10.0 Build 1004 (64-bit)], and then select (CL) [Uninstall].
If there is no [ActivePerl 5.10.0 Build 1004 (64-bit)] in the list, go to 3-2-1.6.



Rev.0 / Sep.2010

REP03-20-330

Copyright © 2010, Hitachi, Ltd.

(4)

A message, "Are you sure you want to uninstall ActivePerl 5.10.0 Build 1004 (64-bit)?" is displayed. Select (CL) [Yes].




(5) Uninstallation of Perl is started.



(6)

The [ActivePerl 5.10.0 Build 1004 (64-bit)] is deleted from the 'Programs and Features' window.

Close the window by selecting (CL) the $[\times]$ button.




3-2-1.6. Uninstalling Flash Player program


(1) Select (CL) [Start] -[Settings]-[Control Panel] in this order.



(2) Select (DC) [Programs and Features].



(3)
Select [Adobe Flash Player 10 ActiveX],
and then select (CL) [Uninstall].
If there is no [Adobe Flash Player 10
ActiveX] in the list, go to 3-2-2.



Rev.0 / Sep.2010

REP03-20-350

(4) Starting uninstallation Select (CL) [UNINSTALL].




Copyright © 2010, Hitachi, Ltd.

(5) Finishing application
If some applications were using Flash
Player, the application name is displayed.
Please finish the applications.




(6) Finishing uninstallation Selecct (CL) [DONE].



(7)

The [Adobe Flash Player 10 ActiveX] is deleted from the 'Programs and Features' window.

Close the window by selecting (CL) the $[\times]$ button.



Rev.0 / Sep.2010

REP03-20-360

Copyright © 2010, Hitachi, Ltd.

3-2-2. <Starting Installation>


- ① Insert a micro program media in the CD-ROM drive of Client PC and wait for one minutes or so.
- ② Select (CL) [RUN...] from the "Start" menu on SVP. Enter "\\tsclient\E\setup.exe" and select (CL) the [OK] button.

Notice1: Select the drive which inserted a CD-R in ②.


"\\text{tsclient\E\setup.exe"} Input the drive name of the CD-ROM drive of Client PC.

Indicate Client PC. (This spelling is inputted.)

Notice: When the SVP is running, the message "Initializing the SVP that is currently operating. Do you want to continue?" is displayed. Select (CL) [Yes].



Then, the message "The SVP is running. The PC will be rebooted to stop the SVP. Please retry the setup operation after the PC reboots." is displayed, and the SVP reboots if selecting (CL) [OK]. After waiting for about five minutes, install the



microprogram again from 3-2-2 $\@ifnextchar[{\@model{2}}{@}$ after rebooting the SVP.

Refer to "3-1-1. Connecting the Console PC" (REP03-20-190). Please use "Preinstalled User" to connect with SVP.

"The publisher could not be verified. Are you sure you want to run this software?" is displayed. Select (CL) [Yes].



Rev.0 / Sep.2010


REP03-20-370

Copyright © 2010, Hitachi, Ltd.

- 3-3. <Using another media>
- 3-3-1. < Installing the Configuration Information>
 - (1) Prepare the Config media which did backup.

(2)
Select (CL) C in the 'Select Setup
Config' window and select (CL) the [OK]
button.

"CD-R": Use Only With Technical Support Authorization.




Rev.0 / Sep.2010

REP03-20-380

(3)

Select the drive which insert the Backup Config Media (prepared with step (1)), and select (CL) the [OK] button.

Select (CL) [Refresh] button, Disk is updated to the latest information.




Copyright © 2010, Hitachi, Ltd.


(4)

Perform copy processing of the configuration information from the Backup Config Media to the SVP.

The 'CNFCPY Wait...' window is displayed during this time.



(5)
Select (CL) the [OK] button after removing the configuration information media.



 Hitachi Proprietary
 DKC710I

 Rev.0 / Sep.2010
 Copyright © 2010, Hitachi, Ltd.

 REP03-20-390

Blank Sheet

3-3-2. <Installing the RAID Manager>

(1)


Select (CL) [Next>].



(2) Select (CL) [Next>].



(3) Select (CL) [Finish].



REP03-20-410

3-3-3. <Installing the OSS media>

(1)

When the message of "Insert the second CD-R." is displayed, replace it to the second media. Select (CL) [OK] after the replacement.



Installed versions of each OSS are different by OSS media versions. Installed versions of each OSS refer to following "Table 3.20.3-1 Installed OSS properties".

Table 3.20.3-1 Installed OSS properties

OSS media	Apache	Java	Tomcat	Flash	Perl
70-01-00/00 ~	Apache2.2.10 (0.9.8o)	6Update12	6.0.16	10.1	5.10.0.1004
70-06-05/xx ~	Apache2.2.27 (1.0.1h)	6Update12	6.0.41	10.1	5.10.0.1004

Rev.0 / Sep.2010

REP03-20-420

Copyright © 2010, Hitachi, Ltd.


3-4. <Setting Up JAVA>

Perform setting up operation of Java. When JAVA has already been installed, go to Section 3-5.


(1) Select (CL)[Accept>].



(2) Select (CL) [Next>].




(3) Copying of the file is started.



Hitachi Proprietary

(4) Select (CL) [Next>].



(5)
Select (CL) [Finish].
If [Register your JDK] window opens, close it.



(6)

When this window is not displayed, go to Section 3-5.

When this window is displayed, select (CL) [No].

Notice: Don't select [Yes]. If you do them, SVP may no longer work properly.



Notice: Until SVP is shutdown in procedure 3-9, please don't logout or shutdown SVP. If you do them, SVP may no longer work properly. If a shutdown request message is displayed, please don't shutdown.

3-5. The Setting of Apache SSL communication

The things of default are set in the key creation for SSL communication and the certificate file. When you install an SSL communication key and a certificate file responding to the customer's request, see "Hitachi Storage Navigator User Guide".

It advances to step 3-6 when setting it by default.

Rev.0 / Sep.2010

REP03-20-440

Copyright © 2010, Hitachi, Ltd.


3-6. Setting Up of Perl

Perform setting up operation of Perl. When Perl has already been installed, go to Section 3-7.

(1) Select (CL) [Next>].



(2) After selecting "I accept the terms in the License Agreement", select (CL) [Next>].



(3) Select (CL) [Next>].



Rev.0 / Sep.2010


REP03-20-450

Copyright © 2010, Hitachi, Ltd.

(4) Select (CL) [Next>].



(5)
Select (CL) [Install].
Copying of the file is started.



When the copying of the file is completed, this window is displayed.

Remove the check mark from the left side check box of the "Display the release notes" and select (CL) [Finish].



Rev.1 / Sep.2010, Aug.2014


REP03-20-460

3-7. Setting Up of Tomcat

Perform setting up operation of Tomcat.


When Tomcat has already been installed, go to Section 3-8.

(1) Select (CL) [Next>].



Copyright © 2010, 2014, Hitachi, Ltd.

(2) Select (CL) [I Agree].




Rev.0 / Aug.2014

REP03-20-461

(3)


Select (CL) [Next>].



Copyright © 2014, Hitachi, Ltd.


This screen is displayed in OSS version 70-06-05/xx or later.

Select (CL) [Next>].




(4)

Select (CL) [Next>].



This screen is displayed in OSS version 70-06-05/xx or later.

Select (CL) [Next>].




Rev.0 / Aug.2014

REP03-20-471

(5)


Select (CL) [Next>].



Copyright © 2014, Hitachi, Ltd.

This screen is displayed in OSS version 70-06-05/xx or later.

Select (CL) [Next>].




Rev.0 / Aug.2014

REP03-20-472

Copyright © 2014, Hitachi, Ltd.


(6)

Select (CL) [Install].



This screen is displayed in OSS version 70-06-05/xx or later.


Select (CL) [Install].



(7)

Wait while installing.

If the message, "The specified installation directory is not empty. Do you wish to continue?" is displayed, select (CL) [OK].



(8) Uncheck all the checkboxes, and select (CL) [Finish].



- When installed Tomcat 6.0.41 (OSS versions 70-06-05/xx or later) in SVP, not downgrade SVP version less than 70-06-15/00.
 When downgrade SVP version less than 70-06-15/00, must install Tomcat version Tomcat 6.0.16 (OSS version less than 70-06-05/xx) before.
 (Refer to WEB CONSOLE SECTION "5.2.1 Uninstallation of Tomcat" (WEB05-30) and "5.2.2 Installation of Tomcat" (WEB05-61))
 - If SVP is downgraded to less than 70-06-15/00 after installing Tomcat 6.0.41 (OSS media version 70-06-05/xx or later), SVP failure may occur. If SVP failure occurs, please refer to Technical Support Division.

Rev.0 / Sep.2010

REP03-20-490

3-8. Setting Up of Flash Player

Perform setting up operation of Flash Player. When Flash Player has already been installed, go to Section 3-9.

(1) Starting installation
Select (CL) [I have read and agree to the terms of the license agreement], and select (CL) [INSTALL].




Copyright © 2010, Hitachi, Ltd.

(2) Finishing application
If some applications were using Flash
Player, the application name is displayed.
Please finish the applications.



(3) Finishing installation Select (CL) [DONE].



Rev.3 / Dec.2010, Aug.2014


REP03-20-500

Copyright © 2010, 2014, Hitachi, Ltd.

3-9. < Restarting the SVP>

When the setting up is completed, the following window is displayed. Take out the CD-ROM and select (CL) [Finish]. The SVP is restarted (disconnected from the console PC).

After waiting for about five minutes, reconnect the console PC to the SVP that has been replaced.



Rev.0 / Sep.2010

REP03-20-510

3-10. < Removing the JP1 Jumper>

When SVP High Reliability Support Kit is not set, remove the maintenance jumper that has been attached to the JP1 of the SVP.

When SVP High Reliability Support Kit is set go to the next step.

A CAUTION


The SIM bf85a3, bf86a3 may be reported, however, it is not a problem because it is one of the normal processes of the SVP replacement.

Complete the SIM concerned.

Copyright © 2010, Hitachi, Ltd.

3-11. <Setting the IP Address of the SVP>

(1) <Starting SVP program>
<When Web Console isn't working>
Select (CL) [Start SVP].




<When Web Console is working> Select (CL) [Maintenance]-[Maintenance Components (General)].



(2) <Mode change>
Select (CL) the [Vie

Select (CL) the [View Mode] of SVP main screen. When it becomes [Modify Mode (Unlocked)] and the next message is displayed, select (CL) the [OK] button and go to (3).

"The available maintenance operations are limited due to lock process failure. If you want to make all the maintenance



operations operable, check that the communication error has not occurred between SVP and DKC, and then retry the operation. If this status is still unrecoverable, reboot the SVP.".


Select (CL) the [View Mode] of the SVP main screen. When it becomes to [Modify Mode] from [View Mode] too, select (CL) the [OK] button and go to (3).

(3) <Opening the 'Install' window> Select (CL) [Install] in the [SVP] menu.

Rev.1 / Sep.2010, Oct.2012

REP03-20-530

(4) <Selecting [Set SVP IP address]> Select (CL) [Set IP address] in the 'Install' window.




Copyright © 2010, 2012, Hitachi, Ltd.


Note: Although it may be an error display if the Web Server Status window is displayed before the IP address setting work of SVP is completed, there is no problem because it is the one by the process of the SVP replacement.

(5) <Setting the IP address> Select (CL) [SVP], make sure of the IP Address and Subnet Mask of the Internal IP Address and the External IP Address, and select (CL) the [OK] button. When the "IP Address" and/or "Subnet Mask" are/is wrong, enter the correct one(s).


Note: Please select [OK] absolutely (CL). And, [Cancel] is not reflected in the setting.



When SVP High Reliability Support Kit is set (in the Master SVP)



When SVP High Reliability Support Kit is not set




When SVP High Reliability Support Kit is set (in the Standby SVP)

Note: When setting the High Reliability kit, select (CL) "Use Duplex SVP".

You can use the LED of SVP to verify the SVP, which is in operation and is not to be replaced, whether it is the master one or the standby one and whether it is in operation or not (for more information, see section SVP).

State of LED at SVP usually

State of LED at standby



If the SVP, which is in operation, is a master one, select (CL) "Standby SVP" for the replaced SVP.


If the SVP, which is in operation, is a standby one, select (CL) "Master SVP" for the replaced SVP.

Rev.0 / Sep.2010

REP03-20-550

(6) <Making sure of the setting of the external IP address>


When a message, "When there are directions to set the external IP address, please set the external IP address from the "Control Panel" of Windows after performing this operation," is displayed, select (CL) the [OK] button.



Copyright © 2010, Hitachi, Ltd.

(7) < Inserting the medium containing the configuration information>

Insert the medium containing the configuration information in the specified location and select (CL) the [OK] button.



(8) < Taking out the medium containing the configuration information>

When the copying of the configuration information is completed, a message, "Please remove the configuration information media." is displayed.

Take out the medium containing the configuration information and select (CL) the [OK] button.



Rev.0 / Sep.2010

REP03-20-560

(9) <Making sure of the restart of the SVP> Select (CL) the [OK] button.

The SVP is disconnected from the console PC. After waiting for about five minutes, reconnect the SVP that has been replaced to the console PC.





Copyright © 2010, Hitachi, Ltd.

(10) < LED state confirmation of SVP >

It confirms it with LED of SVP. Please do over again from (2) when you turn off LED.

State of LED at SVPusually





[Connection destination]

- When SVP High Reliability Support Kit is not set: xxx.xxx.xxx.15
- When SVP High Reliability Support Kit is set:

When the Master SVP was replaced: xxx.xxx.xxx.15
When the Standby SVP was replaced: xxx.xxx.xxx.14

Note: If the IP address of the Console PC has been changed to 126.255.255.x, reset to the original IP address before connection.

When the SVP, which is an object of the operation, cannot be detected, retry the connection after a while (about one minute).

Rev.0 / Sep.2010

REP03-20-570

- (11) <Setting the external IP address>
 - (a) <Opening the Control Panel window> Select (DR) [Settings]-[Control Panel] from the [Start] menu.
 - (b) < Opening the Network and Sharing Center window> Select (CL) [Network and Sharing Center] in the 'Control Panel' Control Panel' Window.




Copyright © 2010, Hitachi, Ltd.


(c) < Opening the Manage network connections window> Select (CL) [Manage network connections] in the 'Network and Sharing Center' window.



(d) < Opening the Public LAN Properties window> Select (CL) [Public LAN] in the 'Network Connections' window and select (CL) [Properties] by clicking the right mouse button.




(e)
Select (CL) [Internet Protocol Version 4 (TCP/IPv4)]
in the 'Public LAN Properties' window and select
(CL) the [Properties] button.




(f) <Setting the external IP address>Set the "IP address", "Subnet mask","Default gateway", "Preferred DNS server" and"Alternate DNS server" and select (CL) the [OK] button.


When you do not set IPv6, go to step (i).



(g)
Select (CL) [Internet Protocol Version 6 (TCP/IPv6)]
in the 'Public LAN Properties' window and select
(CL) the [Properties] button.



- (h) <Setting the external IP address> Set the
 - "IPv6 address",
 - "Subnet prefix length",
 - "Default gateway",
 - "Preferred DNS server" and
 - "Alternate DNS server" and select (CL) the [OK] button.



(i)

After the setting is completed, select (CL) the [OK] button in the "Public LAN Properties" window.

Close the 'Manage network connections' window.

3-12. <Removing the JP1 Jumper and connection of cable (2)>

When SVP High Reliability Support Kit is set, remove the maintenance jumper that has been attached to the JP1 of the SVP.

When SVP High Reliability Support Kit is not set, go to 3-17.

Rev.3 / Oct.2012, Apr.2013

Copyright © 2010, 2013, Hitachi, Ltd.


REP03-20-600

3-13. <Resetting the SSVP>

When the SVP high-reliability kit is set, insert the maintenance jumper into SSVP ALARM RESET jumper (JP3) on the DKCPANEL more than one second. And then, remove the maintenance jumper. Confirm that four SSVP STATUS LED of DKCPANEL turns on and turns off the light.

When a dump is necessary, carry it out earlier than SSVP reset.

Please set the maintenance jumper in JP4 of DKC PANEL, and remove the jumper. (Refer to LOC06-40)




Copyright © 2011, 2014, Hitachi, Ltd.

Rev.1 / Sep.2011, Aug.2014

REP03-20-601

3-14. <Post operation of STANDBY SVP replace>
When SVP High Reliability Support Kit is set
and replaced STANDBY SVP, switch to
MASTER SVP (IP address: xxx.xxx.xxx.15),
select (CL) the [OK] for "Refer to the
maintenance manual to set up the SVPOPTION. Select [OK] after the settings are
completed." after setting the SVP.




3-14-1. < Detach the JP1>

Confirm that the JP1 was detached and select (CL) the [OK].



3-14-2. <Replacement of the SVP PC is done> Select (CL) the [OK] for "Replacement of the "SVP-XXXXX" is done."



3-15. <Transferring the Configuration Information>

When SVP High Reliability Support Kit is set, transfer the configuration information. (When the Master SVP has been replaced, do the same in order to make sure of the setting of the Master SVP.)

Perform the following operation for the Master SVP (IP address: xxx.xxx.xxx.15)

When the SVP, which is an object of the operation, cannot be detected, retry the connection after a while (about one minute).

3-15-1. < Configuration Information Transfer>

This function is valid when the SVP High Reliability Kit is installed.

Notice: This operation needs that Standby SVP is a View mode.

Notice: When screen saver operates (60 minutes pass without operation) with a Standby SVP

having been connected to the remote desktop, this operation fails.

Execute the following operation for Master SVP.


(1) <Execute Maintenance>

When the Master SVP was replaced, change the mode to [Modify Mode].

Select (CL) the [Maintenance] button.

When the Standby SVP was replaced, go to (2).

(2)
Select (CL) [Maintenance]-[SVP][Transfer Config] from the menu.




(3) Select (CL) [Yes] for the message "Do you want to transfer configuration data?".



(4) The message "Transferring subsystem configuration data..." is displayed.


The SVP transfers the configuration information automatically to reflect the configuration



information of the master SVP on the standby side SVP. Therefore, if the transfer processing of the configuration information overlaps, the actually transferred status display may be repeated.

When configuration data has been transferred, the message "Configuration data has been transferred." is displayed. Select (CL) [OK].

If errors occur on the way, check the problems of connection and setting of the replaced SVP (Standby).




- (6) Close the "Maintenance" window.
- (7) Change the SVP mode to [View Mode].


3-16. <Setting the TOD>

When SVP High Reliability Support Kit is not set or Master SVP is replaced after SVP High Reliability Support Kit is set, set the TOD after the message, "Loading SVP Program... SVP requests to DKC cannot be performed presently. Please wait..." disappears. When SVP High Reliability Support Kit is set, go to the next step.

- (1) <Changing the mode>
 Change the mode to Modify Mode.
- (2) <Opening the 'Install' window> Select (CL) [Install] in the [SVP] menu.
- (3) <Selecting [Set Subsystem Time] > Select (CL) [Set Subsystem Time] in the 'Install' window.




(4)
Select (CL) [TOD Change] in the 'Set
Subsystem Time' window, and then select
(CL) [OK].



(5)

Enter a date (year, month, and day) and time (hours, minutes, and seconds), and then select (CL) the [OK] button.



(6)

Close the 'Install' window.

3-17. < Loading the configuration information from the SM to an HDD of the SVP>

When SVP High Reliability Support Kit is not set, load the configuration information from the SM to an HDD of the SVP.

When SVP High Reliability Support Kit is set, go to the next step.

- (1) <Opening the 'Maintenance' window> Select (CL) [Maintenance] from the "SVP" window.
- (2) Make sure that the message, "Connection error occurred SVP-DKC," is not displayed. If the above message is displayed, refer to page TRBL05-80.
- (3) <Selecting [Exit]>
 Select (CL) [File] from the 'Maintenance' window.
 Select (CL) the [Exit] button.

3-18. <Setting the Web Console>

If the customer don't use Web Console (Storage Navigator), 3-18-3 and 3-18-4 are not required.

If the customer uses neither Web Console nor SNMP Agent, 3-18-1,2,3 and 3-18-4 are not required.

Copyright © 2010, 2011, Hitachi, Ltd.

Rev.1 / Sep.2010, Sep.2011 **REP03-20-650**

3-18-1. <Setting the Web Console>

3-18-1.1. Setting IP Address and Network

When using Web Console from a remote personal computer or using the SNMP Agent function, a connection to an external LAN and a setting of a network is required (See LOC04-70).


Please setup according to the worksheet which the user's administrator indicated at the time of a new Installation.

Please setup the contents which took the duplicate from a set up on SVP before REPLACE.

Note: Don't change connection name. If you do so, Web Console will not work.


- (1) <Setting IP address>
 - (a) Opening the Control Panel window Select (CL) [Control Panel] from the [Start]-[Settings] menu.
 - (b) Opening the Network and Sharing Center window

 Double-click [Network and Sharing Center] in the 'Control Panel' window.




Copyright © 2010, Hitachi, Ltd.


(c) Opening the Manage network connections window Select (CL) [Manage network connections] in the left side of 'Network and Sharing Center' window.



(d) Opening the Public LAN Properties window Select (CL) [Public LAN Properties] in the 'Network Connections' window and select (CL) [Properties] by clicking the right mouse button.




(e) Opening the Internet Protocol Version 4 (TCP/IPv4) Properties window Select (CL) [Internet Protocol Version 4 (TCP/IPv4)] in the 'Public LAN Properties' window and select (CL) the [Properties] button.




(f) Setting the external IP address

Set the "IP address", "Subnet mask", "Default gateway", "Preferred DNS server" and "Alternate DNS server" and select (CL) the [OK] button.

When you do not set IPv6, go to step (i).




(g) Opening the Internet Protocol Version 6 (TCP/IPv6) Properties window Select (CL) [Internet Protocol Version 6 (TCP/IPv6)] in the 'Public LAN Properties' window and select (CL) the [Properties] button.



(h) Setting the external IP address

Set the "IPv6 address", "Subnet prefix length", "Default gateway", "Preferred DNS server" and "Alternate DNS server" and select (CL) the [OK] button.



(i) Closing the window

After the setting is completed, select (CL) the [OK] button in the "Public LAN Properties" window.

Close the 'Manage network connections' window.

(2) <Setting Network Connection Properties>

Checking whether the setting of the network (setting of Config) must be changed or not. Ask the customer about the setting of the switch (HUB) connected to the SVP. When the case is not the above, terminate the operation by selecting (CL) the [OK] button.

There is a case where the setting must be changed depending on the customer's environment. The case where the change is required is as follows.

(Normally, no setting change is required.)


When the switch (HUB), setting of which is fixed as '100M Full Duplex', is connected to the PC of the SVP.

Note: The setting of the SVP made is "Auto Negotiation".

- (a) Opening the configuration windows

 Select (CL) the [Configure] button in the window for Step (1) (d), Step (1) (g).
- (b) Switching the tab

After the [Configure] button is pressed, the following window is displayed. Select (CL) the 'Advanced' tab in the following window.




Rev.0 / Sep.2010

REP03-20-700

Copyright © 2010, Hitachi, Ltd.

(c) Setting the Connection Properties After the 'Advanced' tab is selected, the following window is displayed. Change the value of 'Speed and Duplex' from 'Auto Detect' to '100Mbps Full Duplex'.



(d) Applying the settings and closing the window Return the window to 'Public LAN Properties' by pressing (CL) the [OK] button and close the window by pressing the [OK] button.


When you use Web Console only with the IPv6 connection, set it referring to next step.

Rev.0 / Sep.2010

REP03-20-710


Perform the following when using Web Console only with IPv6.

(1) Launch the Network and Sharing Center Select (CL) [Start]-[Settings]-[Control Panel] and launch (double-click) the "Network and Sharing Center".




Copyright © 2010, Hitachi, Ltd.


(2) Launch the Network Connections Select (CL) "Manage network connections".



(3) Open the Connection Properties window Right-click on the icon of "Public LAN" and select "Properties" from the displayed popup menu. Select (CL) "Continue" when the confirmation window is displayed.



(4) Set properties
When the property is displayed, uncheck the checkbox of "Internet Protocol Version 4
(TCP/IPv4)" in the list. Select (CL) [OK] and close




(5) Operate SVP window Change to [Modify Mode].

the window.



(6) Open Install window Select (CL) [Install] from [SVP].



Rev.1 / Sep.2010, Oct.2012

Copyright © 2010, 2012, Hitachi, Ltd.


REP03-20-730

(7) Set SVP properties
 Select (CL) [Set IP address] from the
 'Install' window.
 Check the checkbox of IPv4 of "Use
 Internet Protocol".

Uncheck the checkbox of IPv4 of "Use Internet Protocol".

Select (CL) the [OK] button.

Note: Please select [OK] absolutely (CL). And, [Cancel] is not reflected in the setting.




(8) <Making sure of the setting of the external IP address>

When a message, "When there are directions to set the external IP address, please set the external IP address from the "Control Panel" of Windows after performing this operation," is displayed, select (CL) the [OK] button.



(9) < Inserting the medium containing the configuration information>

Insert the medium containing the configuration information in the specified location and select (CL) the [OK] button.



DKC710I Hitachi Proprietary

Rev.0 / Oct.2012

Copyright © 2012, Hitachi, Ltd. REP03-20-731

(10) < Taking out the medium containing the configuration information>

When the copying of the configuration information is completed, a message, "Please remove the configuration information media." is displayed. Take out the medium containing the configuration information and select (CL) the [OK] button.



(11) < Making sure of the restart of the SVP> Select (CL) the [OK] button.

The SVP is disconnected from the console PC. After waiting for about five minutes, reconnect the SVP that has been replaced to the console PC.



Hitachi Proprietary

DKC710I

REP03-20-740

Rev.3 / Dec.2010, Sep.2011

3-18-1.2. Check of Configuring Web Console over a Firewall

When you connect Web Console and the SVP over a firewall, make sure to connect them through the following TCP/IP port numbers to configure the firewall:

- FTP (File Transfer Protocol): 21 (TCP)
- HTTP (Hypertext Transfer Protocol): 80 (TCP)
- SNMP (Simple Network Management Protocol): 161 (UDP)
- SLP (Service Location Protocol): 427 (TCP)
- HTTPs (Hypertext Transfer Protocol over Secure Socket Layer): 443 (TCP)
- RMI (Remote Method Invocation): 1099 (TCP)
- SMI-S: 5989 (TCP)
- RMI: 51099 (TCP)
- RMI: 51100 (TCP)

Ask the customer to configure network setting as necessary.

Notice: If the operating system of your Web Console computer is Windows Vista, you must configure a firewall so that Web Console and the SVP can communicate through these ports because Windows Vista uses a firewall by default.

Copyright © 2010, 2011, Hitachi, Ltd.

Rev.1 / Sep.2010, Sep.2011

REP03-20-750

3-18-2. <Setting SNMP>

- ① Please perform the following procedure, when you use SNMP Agent.
 - 1. Select (CL) the following menu item on Web Console. [Settings]-[Environmental Setting]-[SNMP Information...]
 - 2. Select (CL) [mode change] button to change from View mode into Modify mode.
 - 3. Select (CL) [Apply] button after checking Extension SNMP.
- ② Please perform the following procedure, when you don't use SNMP Agent.
 - 1. Select (CL) the following menu item on Web Console. [Settings]-[Environmental Setting]-[SNMP Information...]
 - 2. Select (CL) [mode change] button to change from View mode into Modify mode.
 - 3. Select (CL) [Apply] button after un-checking Extension SNMP.
 - 4. Select (CL) [Edit Storage System] button on Web Console.
 - 5. Set Name / Contact / Location again and then select (CL) [Apply] button after your confirmation.

Refer to "Hitachi SNMP Agent User Guide" "The operation of SNMP" to know how to setting.

3-18-3. <Setting the user account information and the environment setting information>
(The setting is not required if the SVP High Reliability Support Kit is set.)

Ask the customer to restore the user account information and the environment setting information of Web Console using the backup which he/she is keeping.

If the backup is not kept, ask him/her to reset it.

Please refer to "Hitachi Storage Navigator User Guide" "New Users", "Environment Parameters", and "Restoring Backups of Configuration Files" for the restoration method and the setting method.

3-18-4. <Setting Audit Log>

When the customer is using the Syslog function of Audit Log or the FTP transfer function, request the customer to restore it by using the backup that he/she is keeping.

If the backup is not kept, ask him/her to reset it.

Please refer to "Hitachi Audit Log User Guide" "Transferring audit log files to FTP servers", "Transferring audit log files to syslog servers", and "Hitachi Storage Navigator User Guide" "Postering Realizing of the Configuration Files" for the restoration method and the setting

"Restoring Backups of the Configuration Files" for the restoration method and the setting method.

Copyright © 2010, 2011, Hitachi, Ltd.

Rev.1 / Sep.2010, Sep.2011

REP03-20-760

Copyright © 2010, 2011, Hitachi, Ltd.

$3\text{-}19. < \!\! \text{Backing Up the Configuration Information} \!\!>$

In the case where SVP High Reliability Support Kit is not set and where SVP High Reliability Support Kit is set and the Master SVP has been replaced, make a backup of the configuration information (See "3-19-1 Config Backup").

In the case where SVP High Reliability Support Kit is set and the Standby SVP has been replaced, go to 3-20.


REP03-20-760

Copyright © 2010, 2011, Hitachi, Ltd.

Rev.2 / Dec.2010, Sep.2011 **REP03-20-770**

3-19-1. <Config Backup>

- (1) Select (CL) [Install] in the 'SVP' window and select (CL) [Copy Config Files] in the 'Install'.
- (2) Select (CL) [Create Configuration Backup] in the 'Copy Config Files'.



(3)

Execute an operation for backing up the configuration information.

Prepare the removable media for backup and insert the media.

Please select (CL) the [Refresh] button, and update drive information.

Select (CL) the drive and the PC in which the media was inserted. Select (CL) the [OK] button.

Note: For the procedure of backing up the configuration information to a CD-R, see step 3-19-2.



(4) When w

When you want to continue the process, select the [Yes] button. When the backup to the Config media is not necessary, select the [No] button.




Rev.0 / Sep.2010

REP03-20-780

Copyright © 2010, Hitachi, Ltd.

(5)

Backup the configuration information to the Config media for backup. While this operation is being done, the 'CNFCPY Wait...' window is displayed.



(6)
After the Config media is pulled out, select (CL) the [OK] in response to the message "Please remove the configuration information media.".



(7) Select (CL) [Exit] of the 'Copy Config Files' to finish this operation.

Rev.1 / Sep.2010, Sep.2011

REP03-20-790

- 3-19-2. <Storing a backup of configuration information (config) to a CD-R>
 - (1) To store a backup of the config, prepare a blank CD-R.
 - (2) If the DKC200 directory exists in the root of the hard disk (C drive) of the client PC to which the backup of the config is stored temporarily, delete the DKC200 directory.
 - Perform the backup processing of the config.

Select the drive (C drive) prepared in (2).



(4) The backup processing is performed. The 'CNFCPY Wait...' window appears.



Rev.1 / Sep.2010, Sep.2011

Copyright © 2010, 2011, Hitachi, Ltd.

REP03-20-800

(5) Select (CL) the [OK] button.



(6)
The DKC200 directory exists in the root of the drive (C drive) specified in (3). Use the CD writing tool to copy the DKC200 directory to the root directory of the CD-R, which was prepared in (1).

3-20.

Go to POST-PROCEDURE [REP04-01-10].

[HUBBOX REPLACEMENT PROCESSING - RTC6]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select HUBBOX (status check)
 - ② Specify Replacement
 - ③ Detach HUBBOX
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of HUBBOX replacement
 - 2 Reinstall related parts
 - 3 Start environment monitor


Rev.0 / Sep.2010

REP03-21-20


Copyright © 2010, Hitachi, Ltd.

1. PRE-PROCESSING of SVP


1-1. <Maintenance window>
In the 'Maintenance' window, check and select (CL) [DKC-x] to be replaced.



1-2. <Specify HUB BOX> Select (CL) [DKC-x Back]. [DKC-x Front]



[DKC-x Back] Select (CL) [HUBBOX-nn].



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-21-30

Copyright © 2010, Hitachi, Ltd.

1-3. <Execute>



A CAUTION

When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




Rev.0 / Sep.2010

REP03-21-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].




Copyright © 2010, Hitachi, Ltd.

Rev.1 / Sep.2010, Dec.2010 **REP03-21-40**

1-5. <Check beginning of HUBBOX Replacement> (HUBBOX-00)


Select (CL) [Yes] in response to "Do you want to replace the "HUBBOX-00?"".



(Eg. HUBBOX-00)

(HUBBOX-01, HUBBOX-02)


Select (CL) [Yes] in response to "Do you want to replace "HUBBOX-nn"? While replacing the parts, the rotational speed of the other fans will reach the maximum.".



(Eg. HUBBOX-01)

1-6. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the LED of the parts to be replaced(HUBBOX-nn) lit?" is displayed. When the LED on the PCB to be pulled out is on, select (CL) [Yes] and go to Step 1-8. When the LED on the PCB to be pulled out is kept off, select (CL) [No] and go to Step 1-7.




(Eg. HUBBOX-01)

1-7. <Making sure of the HUBBOX location>
The message "Check the location of the target component." is displayed.

See the "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the HUBBOX location, select (CL) [OK] and go to Step 1-8.



Rev.0 / Dec.2010

REP03-21-41

Copyright © 2010, Hitachi, Ltd.

1-8. < Check beginning of HUB BOX Replacement>

The message "Please replace the "HUBBOX-nn." After replacement, press OK." is displayed.

(Reply with [OK] after replacing the special part.)


Go to "2. HARDWARE REPLACEMENT PROCESSING".



(Eg. HUBBOX-01)

2. HARDWARE REPLACEMENT PROCESSING

Location		Function Name of Component	Part Name
Rear of DKC	1	HUBBOX	



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.2 / Oct.2010, Dec.2011

REP03-21-60

2-1

Copyright © 2010, 2011, Hitachi, Ltd.

Replacement of HUBBOX

2-1-1. Replace the HUBBOX.

a. Check that the Shut Down LED is on.

HUBBOX will not be ON.

- b. In case that the replacing HUBBOX is the HUBBOX-10, remove the LAN cable (P83). In case that the replacing HUBBOX is other than the HUBBOX-10, go to the procedure c.
- c. Loosen the two screws and remove the failed HUBBOX.
- d. Install the spare HUBBOX and tighten the two screws.

 Note: Confirm the vertical direction of the HUBBOX. If the direction was wrong, the
- e. If the LAN cable was removed in the procedure b, connect the LAN cable to the HUBBOX.




Fig. 3.21.2-1 Replacement of HUBBOX

2-1-2. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Sep.2010

REP03-21-70

Copyright © 2010, Hitachi, Ltd.


3. POST-PROCESSING of SVP

3-1. <Check replacement of HUBBOX> Select (CL) [OK] in response to "Please replace the "HUBBOX-nn." After replacement, press OK.".




(Eg. HUBBOX-01)

3-2. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "HUBBOX-nn" is
done."



(Eg. HUBBOX-01)

- 3-3. < Operation mode change> Select (CL) [Diagnosis].
- 3-4. <Activating LAN>
 Select (CL) [LAN].
 (The screen is changed to the LAN Check menu screen.)



Rev.0 / Sep.2010

REP03-21-80

3-5. <Starting LAN Check>

Select (CL) [Start] in the 'LAN Check' window.

<Supplementary explanation>

Although an installed processor is set to be default to execute a hardware diagnosis, all processors can be selected.

Installed processor: Select (CL) [Target MP] and then

select (DR) [Equipped MP].

All processors : Select (CL) [Target MP] and then select (DR) [All MP].



Copyright © 2010, Hitachi, Ltd.

3-6. < Displaying Wait message>

The Wait message is displayed. The screen will change to the result display screen in a few minutes.



Rev.0 / Sep.2010

REP03-21-90

3-7. < Displaying result>

(1) Adapter status display

When the Adapter button is selected, the screen is changed to the MP status screen.

The screen is returned to the LAN Check menu screen by selecting (CL) [OK].


[Explanation on statuses]

The status is shown by the appearance of the button as follows:

Black : The test object is normal.

Blinking : The test object is abnormal.

Gray : The test object is not installed.



Copyright © 2010, Hitachi, Ltd.

Rev.0 / Sep.2010

REP03-21-100

(2) MP status display

When the MP button is selected, the screen is changed to the detailed status screen.

The screen is returned to the adapter status screen by selecting (CL) [OK].

[Explanation on statuses]

The status is shown by the appearance of the MP button as follows:

Black : The concerning MP is normal.

Blinking: The test object is abnormal. However, for the MP which

was normal at the time of an FF-Ping, "#" is indicated in

front of the MP name.

Gray : The test object is not installed.

[Supplemental explanation]

When the test object is not installed in the state that the hardware is abnormal:

The concerning MP is indicated in gray.

When the test object is not installed in the state that the hardware is normal:

The indication of the concerning MP is grayed and blinks.

When the test object is installed by an FF-Ping:

A character "#" is indicated in front of the MP name, and the name indication blinks.

When the test object is connected by an FF-Ping but not installed:

A character "#" is indicated in front of the MP name, and the name indication is grayed and blinks.



Copyright © 2010, Hitachi, Ltd.

Rev.0 / Sep.2010

REP03-21-110

Copyright © 2010, Hitachi, Ltd.

(3) Detailed status display

Detailed information on the concerning MP is displayed.

The screen is returned to the MP status screen by selecting (CL) [OK].

[Explanation on statuses]

The test result is shown by the appearance of the Task button as follows:

Black : The MP is normal from the

viewpoint of software.

Blinking: The blinking part has a problem.

Gray : Not diagnosed yet.

[Supplemental explanation]

There are five types of status as shown below:

When the hardware is abnormal: Rcv., I/F-JOB, and R-JOB are indicated in gray.

When the software is normal: Rcv., I/F-JOB, and R-JOB are indicated in black.

When the Rcv. is abnormal: Rcv. indication blinks, and I/F-JOB and R-JOB are

indicated in gray.

When the I/F-JOB is abnormal: Rcv. is indicated in black, I/F-JOB indication blinks, and

R-JOB is indicated in gray.


When the R-JOB is abnormal : Rcv. and I/F JOB are indicated in black and R-JOB

indication blinks.

3-8. <Exiting from LAN Check> Select (CL) [Exit] in the 'LAN Check' window.

Go to POST-PROCEDURE [REP04-01-10].





[Battery REPLACEMENT PROCESSING - RTC7]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Check beginning of Battery Replacement
 - ② Check battery charge opposite cluster
 - 3 Enter the password
 - Check with battery storage period
 - ⑤ Check the LED blinks
 - © Replacement
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Check beginning of CACHE Battery Replacement
 - ② Check the battery status
 - 3 Setting Battery Life
 - ④ Check end of replacement

Rev.0 / Sep.2010

REP03-22-11


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.




Copyright © 2010, Hitachi, Ltd.

1-2. <DKC window>
Select (CL) [DKC-n Front] in the 'DKC' window.



1-3. <Select Cache> Select (CL) Cache.



DKC710I Hitachi Proprietary

Rev.1 / Sep.2010, Mar.2011

REP03-22-12

Copyright © 2010, 2011, Hitachi, Ltd.

1-4. <Specify replacement of cache>




A CAUTION

When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Check status display.

Select (CL) [Replace], and select (CL) [Cache Battery].




Rev.0 / Sep.2010

REP03-22-20

1-5. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-6.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].




Rev.0 / Sep.2010

REP03-22-21

Copyright © 2010, Hitachi, Ltd.

1-6. <Check beginning of Battery Replacement> Start battery replacement. Select (CL) [Yes] in response to "Do you want to replace the "BATTERY-nnn"?".




(Eg. BATTERY-1CA)

1-7. < Check battery charge opposite cluster>

Automatically, the battery's charge is measured in the opposite cluster.

• More than 50% charge capacity, or "being measured", go to Step 1-9.

Charge capacity of less than 50%, the following message "A battery whose charge capacity is less than 50% is in the cluster of opposite site to be replaced. If there is a battery problem on the battery, replace it. If there is no battery problem on the battery, wait the operation until the charge capacity of



the battery becomes 50% or more (maximum 90 min.). Do you want to stop this process?" is displayed.

If you stop for battery replacement, select (CL) [Yes], go to Step 3-4.

To continue the replacement battery, select (CL) [No], go to Step 1-8.

1-8. <Enter the password>

Corresponding to the following message, enter the password and select (CL) the [OK] button.

"Ask the Technical Support Division about the appropriateness of this operation, and enter the password."

Go to Step 1-9.

If you stop for a replacement, [Cancel]. Go to Step 1-7.




Hitachi Proprietary

1-9. < Check with battery storage period>

Check the date that is mentioned in the final charge to replace the battery.


"Check the last charged dates written on the batteries. Are the dates for all of the batteries to be replaced within six months of the last charged dates?" is displayed.



- Within six months from the date when the final charge, select (CL) [Yes].
- When more than 6 months from the date of the last charge, select (CL) [No].

And Processing. Go to Step 1-10.





[Check of refilling charge dates]

When refilling charge dates ① are written, check them.

When refilling charge dates ① are not written, check refilling charge dates ②.

*1: Some batteries don't have the label for refilling charge dates ①.

Fig.3.22.1-1 Check of Refilling Charge Dates

Rev.0 / May.2012

REP03-22-31

Copyright © 2012, Hitachi, Ltd.


1-10. <Check the LED blinks>

Before replacing the battery, LED blinks to confirm.

"Is the LED of the target parts(CACHE-nnn) blinking?" is displayed.

If the LED is blinking, select (CL) [Yes].

Go to Step 1-11.



(Eg. CACHE-1CA)

1-11. <Replacement>

The message "Please replace the "BATTERY-nnn" After replacement, press OK." is displayed.

Reply with [OK] after replacing the special part.


Go to "2. HARDWARE REPLACEMENT PROCESSING"



(Eg. BATTERY-1CA)

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Inside of CM PCB	1 Battery		



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-22-50

2-1 Replacement of Battery



Watching for short-circuits:

A Short-circuit may cause a fire.

Never insert metal or the like into the battery box connector or a short-circuit may occur.

2-1-1. Replacement of Battery

- a. Open the DKCPANEL when the removing CM PCB locations are CACHE-2CD, 2CG, 2CH, 2CM, 2CQ or 2CR.
 - For the CM PCB location other than the above, go to the procedure c.
- b. Loosen the screw, slide the DKCPANEL to the far right, and open the DKCPANEL.




Fig. 3.22.2-1 Shifting of DKCPANEL

Copyright © 2010, Hitachi, Ltd.

Rev.0 / Sep.2010

REP03-22-60

Copyright © 2010, Hitachi, Ltd.

c. Loosen the two screws and remove the plate from the target CM PCB.




Fig. 3.22.2-2 Removal of Plate

Rev.1 / Sep.2010, Oct.2010

Copyright © 2010, Hitachi, Ltd.

REP03-22-70

- d. Disconnect the battery cable from the CM PCB.
- e. Loosen the screw and remove the battery.
- f. Insert the spare battery and tighten the screw.
- g. Connect the battery cable to the CM PCB.
- h. Attach the plate to the CM PCB and tighten the two screws. (Refer to Fig. 3.22.2-2.)
- i. Replace the DKCPANEL and secure it with the screws if the DKCPANEL is opened. (Refer to Fig. 3.22.2-1.)




Fig. 3.22.2-3 Replacement of Battery

2-1-2. Go to "3. POST-PROCESSING of SVP".

Copyright © 2010, 2011, Hitachi, Ltd.

Rev.2 / Mar.2011, Jun.2011 **REP03-22-80**

3. POST-PROCESSING of SVP

3-1. < Check beginning of CACHE Battery Replacement>

Select (CL) [OK] in response to "Please replace the "BATTERY-nnn." After replacement, press OK."




(Eg. BATTERY-1CA)

3-2. <Check the battery status>

Automatically check the status of the battery replacement.

Select (CL) [OK] after you confirmed the content.

If more than six months from the date of the



final charge the battery storage period, "Approx. 90 minutes (max.) will be required to have 50% or more of charging capacity for the battery. And you need to wait the process of cache and battery maintenance until the charging capacity becomes 50% or more." is displayed.

Go to Step 3-3.

If the display of Battery Life Warning SIM is disabled, go to step 3-5.

3-3.

In response to a message, "Do you want to change the setting of Battery Life Warning SIM?".

Select [Yes] when you exchange CM Battery. Go to step 3-4.

REPLACE

[SVP4317i]

Do you want to change the setting of Battery Life Warning SIM?

Yes No

Select [No] when you use existing CM Battery. Go to step 3-5.

DKC710I

Rev.2 / Mar.2011, Jun.2011 REP03-22-90


3-4. <Setting Battery Life>

(1)

Select (CL) the target CM Battery in the 'Battery Life Warning SIM' screen, and then select (CL) [Set...]. Go to step (2).

Make sure that the all input items are correct and select (CL) [OK].

Note: If the date is displayed as "****/**", follow step (2) to set the date.



Battery Life Warning SIM

Remained Battery life: 990

Current Date: 2011/03/29

Copyright © 2010, 2011, Hitachi, Ltd.

(2)

Select (CL) [OK] after inputting the remainder days until Warning SIM is reported. Return to step (1).


Note: After executing the periodical exchange of a battery, set 33 month (990 days).

Note: Default value is 33 month (990 days), which is 3 month earlier than the lifetime of a battery (3 years).

Determine the number of days remained based on your maintenance plan.

Note: The input ranges of "Remained Battery life" are from 1 to 3650.

3-5. < Check end of replacement> Select (CL) [OK] in response to "Replacement of the "BATTERY-nnn" is done."



(Eg. BATTERY-1CA)

3-6.

Go to POST-PROCEDURE [REP04-01-10].

X

ÖK

Cancel

[DKCPS REPLACEMENT PROCESSING - RTC8]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select DKCPS (status check)
 - ② Specify Replacement
 - 3 Detach DKCPS
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of DKCPS replacement
 - ② Reinstall related parts


Rev.0 / Sep.2010

REP03-23-20


Copyright © 2010, Hitachi, Ltd.

1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
In the 'Maintenance' window, check and select (CL) [DKC-x] to be replaced.




1-2. <Specify DKCPS> Select (CL) [DKC PS Box Back].



Please select replaced parts after selecting the button.

[DKC-x Back] Select (CL) [PS-nn].



Rev.0 / Sep.2010

REP03-23-30

Copyright © 2010, Hitachi, Ltd.

1-3. <Execute>



When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




(Eg. DKCPS-00)

Rev.0 / Sep.2010

REP03-23-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].



DKC710I

Rev.1 / Sep.2010, Dec.2010 Copyright © 2010, Hitachi, Ltd.

REP03-23-32

1-5. <Check beginning of DKCPS Replacement> Select (CL) [Yes] in response to "Do you want to replace "DKCPS-nn"? While replacing the parts, the rotational speed of the other fans will reach the maximum.".



(Eg. DKCPS-00)


- 1-6. <Checking power supply>
 The SVP automatically checks the DKC PS to see if it is replaceable.
- 1-7. <Check environment monitor stopped state>
 The message "Processing to disable the environment check..." is displayed.



Rev.0 / Sep.2010

REP03-23-40

1-8. <Processing before exchanges>
The message "Turning on the LED of the target component..." is displayed.




Copyright © 2010, Hitachi, Ltd.

1-9. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the REPLACE LED of the (DKCPS-nn) to be replaced on?" is displayed. When the REPLACE LED on the component to be pulled out is on, select (CL) [Yes] and go to Step 1-11.

When the REPLACE LED on the component to be pulled out is kept off, select (CL) [No] and go to Step 1-10.




(Eg. DKCPS-00)

1-10. <Making sure of the DKCPS location>
The message "Check the location of the target component." is displayed.

See the "2. HARDWARE REPLACEMENT PROCESSING".


After making sure of the DKCPS location, select (CL) [OK] and go to Step 1-11.



1-11. <Check beginning of DKCPS Replacement>
The message "Please replace the "DKCPSnn." After replacement, press OK." is
displayed.

(Reply with [OK] after replacing the special part.)

Go to "2. HARDWARE REPLACEMENT PROCESSING".




(Eg. DKCPS-00)

REP03-23-50

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name	
Rear of DKC	1	DKCPS		



Caution: Reverse the lower side DKCPS (DKCPS-x0, x3) insertion direction with upper side DKCPS insertion direction.

Therefore, deserve close attention to the direction when the replacement of DKCPS.

NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-23-60

Copyright © 2010, Hitachi, Ltd.

Replacement of DKCPS

2-1-1. Replacement of DKCPS


a. Check that the REPLACE LED is on.



A CAUTION

A system down may be caused by a replacement of the DKCPS other than that to be replaced. Make sure that it is a DKCPS to be replaced.

DKCPS-x1/x2



DKCPS-x0/x3




Fig. 3.23.2-1 Confirmation of REPLACE LED

Rev.0 / Sep.2010

REP03-23-70

Copyright © 2010, Hitachi, Ltd.

b. Remove the stopper on the failed DKCPS and disconnect the cable.



Watching for short-circuits:

A Short-circuit may cause a fire.

Never insert metal or the like into the cable connector or a short-circuit may occur.

- c. Loosen the two screws. Operate the levers and remove the DKCPS.
- d. Operate the levers and attach the spare DKCPS. Tighten the screws.
- e. Connect the cable and secure it with the stopper.
- f. Check that the REPLACE LED is off. (Refer to Fig. 3.23.2-1.)




Fig. 3.23.2-1 Replacement of DKCPS

2-1-2. Go to "3.POST-PROCESSING of SVP".

Rev.0 / Sep.2010

REP03-23-80

Copyright © 2010, Hitachi, Ltd.

3. POST-PROCESSING of SVP

3-1. <Check replacement of DKCPS>
Select (CL) [OK] in response to "Please replace the "DKCPS-nn." After replacement, press OK.".




(Eg. DKCPS-00)


3-2. < Processing after exchanges>

The message "Turning off the LED of the target component..." is displayed.


If the LED is lit, it turns off in this screen.



3-3. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-4. <Check end of replacement>
Select (CL) [OK] in response to "Replacement of the "DKCPS-nn" is done.".



(Eg. DKCPS-00)

Rev.0 / Sep.2010

REP03-23-90

3-5. <Confirm status>

Confirm the status display.

If button is normal (The string is normally display), go to step 3-6.

If button is abnormal (The string is blinking), replace the target part again, or see TROUBLE SHOOTING SECTION.

3-6.

Go to POST-PROCEDURE [REP04-01-10].

Copyright © 2010, Hitachi, Ltd.

[SFP REPLACEMENT PROCESSING - RTC9]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select Port (SFP information check)
 - ② Specify Replacement
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Check the port Wave information

Rev.0 / Sep.2010

REP03-24-20


1. PRE-PROCESSING of SVP

1-1. <Set path offline>

A CAUTION


The path to be placed offline is that connected with the CHA concerned.

1-2. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.



Copyright © 2010, Hitachi, Ltd.

1-3. <DKC window>
Select (CL) [DKC-n Back] in the 'DKC' window.




Rev.0 / Sep.2010


REP03-24-30

Copyright © 2010, Hitachi, Ltd.

1-4. <Selecting CHA> Select (CL) the target CHA.




1-5. <SFP Maintenance window is displayed> Select (CL) [Other]-[SFP Maintenance].



1-6. <Specify SFP replacement>
Select the button of the port for which the SFP is to be replaced and select (CL) the [Replace] button.

(The plural can be selected.)




Rev.0 / Sep.2010

REP03-24-40

1-7. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-8.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].



1-8. < Replacing the SFP>

A message, "Please replace the "SFP(Portnn, ...)." After replacement, press OK." is displayed.

(Select (CL) [OK] after replacing the SFP.)


Go to "2. HARDWARE REPLACEMENT PROCESSING".



REP03-24-50

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Rear of DKC	1	SFP (4Gbps) (DKC-F710I-16MFS/16MFL)	• SFP (SHORT) • SFP (LONG)
	2	SFP (8Gbps) (Non-RoHS2 compliant part) (DKC-F710I-8UFC/16UFC/16MUS/16MUL)	• SFP (SHORT) (1US)
		SFP (8Gbps) (RoHS2 compliant part) (DKC-F710I-8UFC/8UFCR/16UFC/16CFCR/ 16MUS/16MUSR/16MUL)	• SFP (SHORT) (1USR) • SFP (LONG) (1UL)
	3	SFP (10Gbps) (DKC-F710I-8FOE)	• SFP (SHORT)



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

REP03-24-60

2-1 SFP

2-1-1. Replacement of SFP

a. Make sure of the CHA and Port Locations of the SFP to be replaced. (Refer to pages LOC04-10 through LOC04-62.)

A CAUTION

If the SFP of a wrong port is removed, a system down may be caused. Make sure that the location of the SFP to be replaced is correct.

b. Disconnect the optical fibre cable from the SFP to be replaced.




Fig. 3.24.2-1 Disconnection of Cable

c. Pull the lever to the front and remove the SFP.




Fig. 3.24.2-2 Removal of SFP

Rev.0 / Sep.2010

Copyright © 2010, Hitachi, Ltd. REP03-24-80

- d. Insert the spare SFP to the CHA PCB.
- Connect the optical fibre cable to the SFP.

How to distinguish between SFP (SHORT) and SFP (LONG)

The whole or a part of the lever is a black for the SFP (SHORT). The whole or a part of the lever is a blue for the SFP (LONG).

[Example]




Fig. 3.24.2-3 How to distinguish between SFP(SHORT) and SFP(LONG)

2-1-2. Go to "3. POST-PROCESSING of SVP".

REP03-24-90

3. POST-PROCESSING of SVP


3-1. <Replacing the SFP>
Select (CL) [OK] in response to "Please replace the "SFP(Port-nn, ...)." After replacement, press OK.".



3-2. <Check the end of SFP replace>
Select (CL) [OK] in response to "Replace finished.".



3-3. <Confirming SFP type information>
Confirm that the SFP type information on the port information list.



3-4.

Go to POST-PROCEDURE [REP04-01-10].

[2.5 inch SSW REPLACEMENT PROCESSING - RU21]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select SSW
 - ② Specify Replacement
 - 3 Place SSW into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify recovery of DKA Port connected to SSW

Rev.0 / Sep.2010

REP03-26-20

1. PRE-PROCESSING of SVP


1-1. <Maintenance window>
Select (CL) the DKU information [DKU-nn]
of the DKU which installs the SSW to be
replaced in the 'Maintenance' window.



Copyright © 2010, Hitachi, Ltd.

1-2. < Select SSW >

Check and select (CL) [SSWn-X] to be replaced.



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-26-30

Copyright © 2010, Hitachi, Ltd.

1-3. < Specify replacement>



A CAUTION

When the screen requests an operator to input a password in order to prevent multiple maintenance, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Select (CL) [Execute].

Selecting (CL) [Cancel] returns you to Step 1-2.



Rev.0 / Sep.2010

REP03-26-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).


(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped. [No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-2.

When [No] is selected (CL), returned to Step 1-4.



Copyright © 2010, Hitachi, Ltd.






Copyright © 2010, Hitachi, Ltd.


REP03-26-40


1-5. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.



1-6. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].





Rev.0 / Oct.2010

REP03-26-41


displayed.

"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.

Minute, and ss denotes Second)



Copyright © 2010, Hitachi, Ltd.

A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format "SH528_YYMMDDhhmmss.tgz". (YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes

Rev.1 / Sep.2010, Oct.2010

REP03-26-50

Copyright © 2010, Hitachi, Ltd.

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.

Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.

It returns to the drive selection screen when [Cancel] is selected (CL).

Note: The message is displayed two or more times. Please only operate the SSW selected by 1-3. <Specify replacement>.

• When the destination media is write-protected.

<For Windows XP>




<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.

Please appoint another destination

whether you remove write protect when you save it and carry it out.

• When dialog of the destination drive specified with the Client PC is open, the media is removed, and then select (CL) [Save].



Rev.1 / Sep.2010, Oct.2010

REP03-26-60

 When the memory in the destination drive specified with the Client PC is corrupted.
 The dialog remains displayed after selecting (CL) [OK].


At the time of the above operation completion, the information collection is not carried out.



Copyright © 2010, Hitachi, Ltd.

Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.

Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".



Rev.0 / Sep.2010

REP03-26-70

Copyright © 2010, Hitachi, Ltd.

1-7. <Check beginning of DKA Port blocking>
Select (CL) [Yes] in response to "Are you sure you want to replace the SSW? If you select [Yes], blocking of the DKA port will be unavoidable.".



1-8. <Check DKA Port blocking>
"The DKA Port is being blocked..." is displayed.

Rev.1 / Sep.2010, Mar.2011

REP03-26-80


1-9. <Replace SSW>

"Please replace the SSW, and then select [OK]. (SSWnnn-xxx)

When selected SSW and other SSW locations are displayed replace it too.

If there are two or more SSWs to be replaced, remove all the SSWs whose locations are displayed and then install the new ones.

The LED of the target SSW will not be turned off until you select [OK]." is displayed.



Copyright © 2010, 2011, Hitachi, Ltd.


Make sure of the SSW PCB location is displayed, select (CL) the [OK] button after replaced target SSW PCB.

If the SSW LED is not turned on, please replace SSW PCB.

Go to "2. HARDWARE REPLACEMENT PROCESSING".

2. HARDWARE REPLACEMENT PROCESSING

Location		Function Name of Component	Part Name
Front or Rear of DKU	1	SSW	• SH528-A



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

2-1 Replacement of SSW

2-1-1. Open the FAN door.

- a. Put the stopper of the FAN door into the openable and closable state. (Refer to the INST03-01-160.)
- b. Loosen the two screws and open the FAN door.




Fig. 3.26.2-1 Opening of FAN Door

REP03-26-110

- 2-1-2. Replace the SSW PCB.
 - a. Check Shut Down LED on the SSW PCB.

CAUTION: A system down is caused by a replacement of the SSW PCB other than that to be replaced. Make sure that it is the SSW PCB to be replaced.




Fig. 3.26.2-2 Confirmation of Shut Down LED

b. Disconnect the cables from the SSW PCB.




Fig. 3.26.2-3 Disconnection of Cables

Rev.1 / Sep.2010, Oct.2010


Copyright © 2010, Hitachi, Ltd.

REP03-26-130

- c. Loosen the two screws and remove the SSW PCB.
- d. Set the jumpers of the spare SSW PCB. For jumper settings, refer to LOC06-50 through 130.

Note: Use the insulated radio pliers of the maintenance tools when setting the SSW jumpers.

- e. Take time for 10 seconds or more from removing the PCB to the installation.
- f. Attach the spare SSW PCB and tighten the two screws.






Fig. 3.26.2-4 Insertion of SSW PCB

- g. Connect the cables to the SSW PCB after checking "3.1.7 Notes when connecting the DEV interface cable" (INST03-01-180). (Refer to Fig. 3.26.2-3.)
- h. Close the FAN door and tighten the screws. (Refer to Fig. 3.26.2-1.)
- i. Put the FAN door stopper into the neutral state.

Rev.2 / Mar.2011, Oct.2012 Copyright © 2010, 2012, Hitachi, Ltd.

REP03-26-140

3. POST-PROCESSING of SVP

3-1. < Check replacement of SSW>


Select (CL) [OK] in response to "Please replace the SSW, and then select [OK]. (SSWnnn-xxx)

When selected SSW and other SSW locations are displayed replace it too.

If there are two or more SSWs to be replaced, remove all the SSWs whose locations are displayed and then install the new ones.

The LED of the target SSW will not be turned

off until you select [OK]." After replacement, press OK.



Make sure that the SSW PCB location is displayed, select (CL) the [OK] button after replacing target SSW PCBs.

Even if the SSW LED is not turned on, please replace the SSW PCBs.

Notice: The LED lights up also for an SSW connected with the same SAS interface cable as that of the specified SSW. The light turns off if you select (CL) on the [OK] button.

3-2. <Check the beginning of DKA Port recovery> Select (CL) [Yes] in response to "Do you want to restore the DKA ports now?".



3-3. <DKU PATH INLINE>

"DKU PATH INLINE is now running..." is displayed.



When a failure is found during DKU PATH INLINE, the DKA Port connected to the loop are blocked.

Confirm the Diagnosis Log and solve the problem.

DKC710I

Copyright © 2010, 2011, Hitachi, Ltd.

REP03-26-150

Rev.1 / Sep.2010, Mar.2011

- 3-4. <Check DKA Port recovery processing> "Restoring the DKA Port..." is displayed.
- "The FAN Door of HDDFAN-xxx is open.
 Close the FAN Door, and select [OK].
 The FAN Door checking is executed up to 3 times. (n/3)" is displayed.
 After the FAN door is closed, select (CL)
 [OK] in response to this message.



It returns to (1) when HDDFAN doors of the object are not closed.


It goes to 3-5 when HDDFAN doors of the object are closed.

Note: It goes to (2) when it cannot be confirmed that the FAN doors are closed in the three times FAN door check.

"A problem in HDDFAN or a FAN Door open might be occurred.After completing the maintenance process,

After completing the maintenance process, check the Maintenance or Information window in an error status or an error log is shown on the window, then execute troubleshooting." is displayed.

Select (CL) [OK] in response to this message.




Rev.1 / Mar.2011, Sep.2011

REP03-26-160

Copyright © 2011, Hitachi, Ltd.

3-5. <Check the end of SSW replace>
Select (CL) [OK] in response to "Replace finished.".



3-6.

Go to POST-PROCEDURE [REP04-01-10].

[3.5 inch SSW REPLACEMENT PROCESSING - RU31]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select SSW
 - ② Specify Replacement
 - 3 Place SSW into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify recovery of DKA Port connected to SSW

Rev.0 / Sep.2010

REP03-27-20

1. PRE-PROCESSING of SVP


1-1. <Maintenance window>
Select (CL) the DKU information [DKU-nn]
of the DKU which installs the SSW to be
replaced in the 'Maintenance' window.



Copyright © 2010, Hitachi, Ltd.

1-2. <Select SSW>
Check and select (CL) [SSWn-X] to be

replaced.



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-27-30

Copyright © 2010, Hitachi, Ltd.

1-3. < Specify replacement>



A CAUTION

When the screen requests an operator to input a password in order to prevent multiple maintenance, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Select (CL) [Execute].

Selecting (CL) [Cancel] returns you to Step 1-2.



Rev.0 / Sep.2010

REP03-27-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

(1) <Confirm wearing wrist strap>
In response to a message, "Did you put on a

wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).


(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped. [No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-2.

When [No] is selected (CL), returned to Step 1-4.



Copyright © 2010, Hitachi, Ltd.






Rev.1 / Sep.2010, Oct.2010

REP03-27-40

1-5. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.




Copyright © 2010, Hitachi, Ltd.

1-6. < Get the error information >

Input the Field Failure Information, and select (CL) [OK].






Rev.0 / Oct.2010

REP03-27-41

"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.



Copyright © 2010, Hitachi, Ltd.

A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format "SH528_YYMMDDhhmmss.tgz". (YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes

Minute, and ss denotes Second)

Rev.1 / Sep.2010, Oct.2010

REP03-27-50

Copyright © 2010, Hitachi, Ltd.

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.

Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.

It returns to the drive selection screen when [Cancel] is selected (CL).

Note: The message is displayed two or more times. Please only operate the SSW selected by 1-3. <Specify replacement>.

• When the destination media is write-protected.

<For Windows XP>




<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.

Please appoint another destination

whether you remove write protect when you save it and carry it out.

• When dialog of the destination drive specified with the Client PC is open, the media is removed, and then select (CL) [Save].



Rev.1 / Sep.2010, Oct.2010

REP03-27-60

 When the memory in the destination drive specified with the Client PC is corrupted.
 The dialog remains displayed after selecting (CL) [OK].


At the time of the above operation completion, the information collection is not carried out.



Copyright © 2010, Hitachi, Ltd.

Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.

Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".




Rev.0 / Sep.2010

REP03-27-70

Copyright © 2010, Hitachi, Ltd.

1-7. <Check beginning of DKA Port blocking>
Select (CL) [Yes] in response to "Are you sure you want to replace the SSW? If you select [Yes], blocking of the DKA port will be unavoidable.".



1-8. <Check DKA Port blocking>
"The DKA Port is being blocked..." is displayed.

Rev.1 / Sep.2010, Mar.2011


REP03-27-80

1-9. <Replace SSW>

"Please replace the SSW, and then select [OK]. (SSWnnn-xxx)

When selected SSW and other SSW locations are displayed replace it too.

If there are two or more SSWs to be replaced, remove all the SSWs whose locations are displayed and then install the new ones. The LED of the target SSW will not be turned off until you select [OK]." is displayed.



Copyright © 2010, 2011, Hitachi, Ltd.


Make sure of the SSW PCB location is displayed, select (CL) the [OK] button after replaced target SSW PCB.

If the SSW LED is not turned on, please replace SSW PCB.

Go to "2. HARDWARE REPLACEMENT PROCESSING".

2. HARDWARE REPLACEMENT PROCESSING

Location		Function Name of Component	Part Name
Front or Rear of DKU	1	SSW	• SH528-A



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

.

Rev.0 / Sep.2010

REP03-27-100

Copyright © 2010, Hitachi, Ltd.

2-1 Replacement of SSW

2-1-1. Open the FAN door.

- a. Put the stopper of the FAN door into the openable and closable state. (Refer to the INST03-01-160.)
- b. Loosen the two screws and open the FAN door.




Fig. 3.27.2-1 Opening of FAN Door

2-1-2. When the SSW installed on the right side of the DKU is replaced, take out the jig from the Pocket ASSY.

When the SSW installed on the left side of the DKU is replaced, proceed to the step 2-1-3.




Fig. 3.27.2-2 SSW Position

- a. Remove the pocket ASSY from the front of the RACK-x0.
- b. Take the jig out from the pocket ASSY.
- c. Install the pocket ASSY in the front of the frame.




Fig. 3.27.2-3 Removal of Jig

2-1-3. Replace the SSW PCB.

a. Check Shut Down LED on the SSW PCB.

CAUTION: A system down is caused by a replacement of the SSW PCB other than that to be replaced. Make sure that it is the SSW PCB to be replaced.




Fig. 3.27.2-4 Confirmation of Shut Down LED

REP03-27-120

b. Disconnect the cables from the SSW PCB.Use the jig when the SSW installed on the right side of the DKU is replaced.




Fig. 3.27.2-5 Disconnection of Cables

Rev.1 / Sep.2010, Oct.2010


REP03-27-130

Copyright © 2010, Hitachi, Ltd.

- c. Loosen the two screws and remove the SSW PCB.
- d. Set the jumpers of the spare SSW PCB. For jumper settings, refer to LOC06-50 through 130.

Note: Use the insulated radio pliers of the maintenance tools when setting the SSW jumpers.

- e. Take time for 10 seconds or more from removing the PCB to the installation.
- f. Attach the spare SSW PCB and tighten the two screws.






Fig. 3.27.2-6 Insertion of SSW PCB

- g. Connect the cables to the SSW PCB after checking "3.1.7 Notes when connecting the DEV interface cable" (INST03-01-180). (Refer to Fig. 3.27.2-5.)
- h. Close the FAN door and tighten the screws. (Refer to Fig. 3.27.2-1.)
- i. Put the FAN door stopper into the neutral state.

Rev.1 / Oct.2010, Dec.2010

Copyright © 2010, Hitachi, Ltd.

REP03-27-131

2-1-4. When the jig was used, put the jig back to the pocket ASSY.

Proceed to the step 2-1-5 if the jig is not used.

- a. Remove the pocket ASSY from the front of the RACK-x0. (Refer to Fig. 3.27.2-3.)
- b. Put the jig back to the pocket ASSY.
- c. Install the pocket ASSY in the front of the frame.
- 2-1-5. Go to "3. POST-PROCESSING of SVP".

Copyright © 2010, 2012, Hitachi, Ltd.

3. POST-PROCESSING of SVP

3-1. <Check replacement of SSW>


Select (CL) [OK] in response to "Please replace the SSW, and then select [OK]. (SSWnnn-xxx)

When selected SSW and other SSW locations are displayed replace it too.

If there are two or more SSWs to be replaced, remove all the SSWs whose locations are displayed and then install the new ones.

The LED of the target SSW will not be turned

off until you select [OK]." After replacement, press OK.




Make sure that the SSW PCB location is displayed, select (CL) the [OK] button after replacing target SSW PCBs.

Even if the SSW LED is not turned on, please replace the SSW PCBs.

Notice: The LED lights up also for an SSW connected with the same SAS interface cable as that of the specified SSW. The light turns off if you select (CL) on the [OK] button.

3-2. <Check the beginning of DKA Port recovery> Select (CL) [Yes] in response to "Do you want to restore the DKA ports now?".



3-3. < DKU PATH INLINE>

"DKU PATH INLINE is now running..." is displayed.



CAUTION

When a failure is found during DKU PATH INLINE, the DKA Port connected to the loop are blocked.

Confirm the Diagnosis Log and solve the problem.

DKC710I

Copyright © 2010, 2011, Hitachi, Ltd.

REP03-27-150

Rev.1 / Sep.2010, Mar.2011

- 3-4. <Check DKA Port recovery processing> "Restoring the DKA Port..." is displayed.
- "The FAN Door of HDDFAN-xxx is open.
 Close the FAN Door, and select [OK].
 The FAN Door checking is executed up to 3 times. (n/3)" is displayed.
 After the FAN door is closed, select (CL)
 [OK] in response to this message.



It returns to (1) when HDDFAN doors of the object are not closed.


It goes to 3-5 when HDDFAN doors of the object are closed.

Note: It goes to (2) when it cannot be confirmed that the FAN doors are closed in the three times FAN door check.

"A problem in HDDFAN or a FAN Door open might be occurred.After completing the maintenance process,

After completing the maintenance process, check the Maintenance or Information window in an error status or an error log is shown on the window, then execute troubleshooting." is displayed.

Select (CL) [OK] in response to this message.



Rev.1 / Mar.2011, Sep.2011

REP03-27-160

Copyright © 2011, Hitachi, Ltd.

3-5. <Check the end of SSW replace>
Select (CL) [OK] in response to "Replace finished.".



3-6.

Go to POST-PROCEDURE [REP04-01-10].

[2.5 inch HDDPWR REPLACEMENT PROCESSING - RU22]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select 2.5 inch HDDPWR (status check)
 - ② Specify Replacement
 - 3 Detach 2.5 inch HDDPWR
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of 2.5 inch HDDPWR replacement
 - ② Reinstall related parts
 - 3 Start environment monitor

Rev.0 / Sep.2010

REP03-28-20


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
Select (CL) [Disk Unit – DKU-XX] in the 'Maintenance' window.




Copyright © 2010, Hitachi, Ltd.

1-2. <Specify HDU> Select (CL) [DKUnx].



1-3. <Specify HDDPWR> Select (CL) [HDDPWR-nnnn].



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-28-30

Copyright © 2010, Hitachi, Ltd.

1-4. <Execute>



A CAUTION

When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




Rev.0 / Sep.2010

REP03-28-31

1-5. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-6.




"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].




Rev.0 / Sep.2010


REP03-28-40

Copyright © 2010, Hitachi, Ltd.

1-6. <Check beginning of HDDPWR replacement> Select (CL) [Yes] in response to "Do you want to replace the "HDDPWR-nnnn?""




1-7. <Check environment monitor stopped state>
The message "Processing to disable the environment check..." is displayed.



1-8. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the LED of the parts to be replaced (HDDPWR-nnnn) lit?" is displayed.


When the LED on the PCB to be pulled out is on, select (CL) [Yes] and go to Step 1-10. When the LED on the PCB to be pulled out is kept off, select (CL) [No] and go to Step 1-9.



1-9. <Making sure of the HDDPWR location>
The message "Check the location of the target component." is displayed.

See "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the HDDPWR location, select (CL) [OK] and go to Step 1-10.



Rev.0 / Sep.2010

REP03-28-50

1-10. <Check beginning of HDDPWR replacement>

The message "The replacement parts may be mounted on DKUs that are not indicated on the Maintenance panel. Please make sure that the location of the replacement parts matches with the label of the DKU. (HDDPWR-nnnn)" is displayed.

Select (CL) [OK] after you confirmed the content.


The message "Have you checked the label and verified that these replacement parts are the right parts? (HDDPWR-nnnn)" is displayed.

Select (CL) [Yes] after you confirmed the content.

The message "Please replace the "HDDPWR-nnnn." After replacement, press OK." is displayed.

Reply with [OK] after replacing the special part.

Go to "2. HARDWARE REPLACEMENT PROCESSING".







(Eg. HDDPWR-0000)

HDDPWR

-HDDPWR

HDDPWR

HDDPWR

-xy61

-xy60

-xy21


-xy20

→DKC No. (0, 1)

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Front or Rear of	1	HDDPWR	· SH499-A
DKU for 2.5 inch Drive			

DKU for 2.5 inch Drive



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Sep.2010

REP03-28-70

2-1 Replacement of HDDPWR

2-1-1. Open the FAN door.

- a. Put the stopper of the FAN door into the openable and closable state. (Refer to the INST03-01-160.)
- b. Loosen the two screws and open the FAN door.




Fig. 3.28.2-1 Opening of FAN Door

Rev.0 / Sep.2010

REP03-28-80

2-1-2. Replacement of HDDPWR

- a. Check that the Shut Down LED is on.
- b. Loosen the screw and remove the HDDPWR from the DKU.




Fig. 3.28.2-2 Replacement of HDDPWR

Rev.0 / Sep.2010

REP03-28-90

- c. Remove the two push rivets and remove the HDDPWR PCB from the bracket.
- d. Fit the HDDPWR PCB of the maintenance parts into the guides of the bracket.
- e. Secure the HDDPWR PCB with the two push rivets of the maintenance parts.





Fig. 3.28.2-3 Replacement of PCB

REP03-28-91

f. Attach the spare HDDPWR. (Refer to Fig. 3.28.2-2.)



g. Tighten the screw while holding down the right side of the HDD PWR with fingers.




Fig. 3.28.2-4 Securing of HDDPWR

- h. Close the FAN door and tighten the screws. (Refer to Fig. 3.28.2-1.)
- i. Put the FAN door stopper into the neutral state.

2-1-3. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Sep.2010

REP03-28-100

Copyright © 2010, Hitachi, Ltd.


3. POST-PROCESSING of SVP

3-1. <Check beginning of HDDPWR Replacement> Select (CL) [OK] in response to "Please replace the "HDDPWR-nnnn." After replacement, press OK."




(Eg. HDDPWR-0000)

3-2. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-3. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "HDDPWR-nnnn" is
done."



(Eg. HDDPWR-0000)

3-4. <Confirm status>

Confirm the status display.

If button is normal (The string is normally display), go to Step 3-5.

If button is abnormal (The string is blinking), replace the target part again, or see TROUBLE SHOOTING SECTION.

3-5.

Go to POST-PROCEDURE [REP04-01-10].

[3.5 inch HDDPWR REPLACEMENT PROCESSING - RU32]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select 3.5 inch HDDPWR (status check)
 - ② Specify Replacement
 - 3 Detach 3.5 inch HDDPWR
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of 3.5 inch HDDPWR replacement
 - ② Reinstall related parts
 - 3 Start environment monitor

Rev.0 / Sep.2010


Copyright © 2010, Hitachi, Ltd. REP03-29-20

1. PRE-PROCESSING of SVP


1-1. <Maintenance window> Select (CL) [Disk Unit – DKU-XX] in the 'Maintenance' window.



1-2. <Specify HDU> Select (CL) [HDUnx].



1-3. <Specify HDDPWR> Select (CL) [HDDPWR-nnn].



Rev.0 / Sep.2010

REP03-29-30

Copyright © 2010, Hitachi, Ltd.

1-4. <Execute>



When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].



1-5. < Checking HDDPWR>


The SVP automatically checks the HDDPWR to see if it is replaceable.

Rev.0 / Sep.2010

REP03-29-31

1-6. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-7.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].




Rev.0 / Sep.2010


REP03-29-40

Copyright © 2010, Hitachi, Ltd.

1-7. <Check beginning of HDDPWR replacement> Select (CL) [Yes] in response to "Do you want to replace the "HDDPWR-nnn?""



1-8. <Check environment monitor stopped state>
The message "Processing to disable the environment check..." is displayed.



1-9. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the LED of the parts to be replaced (HDDPWR-nnn) lit?" is displayed.


When the LED on the PCB to be pulled out is on, select (CL) [Yes] and go to Step 1-11. When the LED on the PCB to be pulled out is kept off, select (CL) [No] and go to Step 1-10.



1-10. <Making sure of the HDDPWR location>
The message "Check the location of the target component." is displayed.

See "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the HDDPWR location, select (CL) [OK] and go to Step 1-11.




Rev.0 / Sep.2010

REP03-29-50

1-11. < Check beginning of HDDPWR replacement>

The message "The replacement parts may be mounted on DKUs that are not indicated on the Maintenance panel. Please make sure that the location of the replacement parts matches with the label of the DKU. (HDDPWR-nnn)" is displayed.



Copyright © 2010, Hitachi, Ltd.

Select (CL) [OK] after you confirmed the content.

The message "Have you checked the label and verified that these replacement parts are the right parts? (HDDPWR-nnn)" is displayed.

Select (CL) [Yes] after you confirmed the content.

The message "Please replace the "HDDPWR-nnn." After replacement, press OK." is displayed.

Reply with [OK] after replacing the special part.






(Eg. HDDPWR-000)

Go to "2. HARDWARE REPLACEMENT PROCESSING".

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Front or Rear of	1	HDDPWR	· SH499-A
DKU for 3.5 inch Drive			

DKU for 3.5 inch Drive



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Replacement of HDDPWR

2-1-1. Open the FAN door.

- a. Put the stopper of the FAN door into the openable and closable state. (Refer to the INST03-01-160.)
- b. Loosen the two screws and open the FAN door.




Fig. 3.29.2-1 Opening of FAN Door

Rev.0 / Sep.2010

REP03-29-80

2-1-2. Replacement of HDDPWR

- a. Check that the Shut Down LED is on.
- b. Loosen the two screws and remove the HDDPWR from the DKU.




Fig. 3.29.2-2 Replacement of HDDPWR

Rev.1 / Sep.2010, Oct.2010

Copyright © 2010, Hitachi, Ltd.

REP03-29-90

- c. Remove the two push rivets and remove the HDDPWR PCB from the bracket.
- d. Fit the spare HDD PWR PCB into the guides of the bracket.
- e. Secure the HDDPWR PCB with the two push rivets of the spare parts.





Fig. 3.29.2-3 Replacement of PCB

f. Attach the spare HDDPWR and tighten the two screws. (Refer to Fig. 3.29.2-2.)



- g. Close the FAN door and tighten the screws. (Refer to Fig. 3.29.2-1.)
- h. Put the FAN door stopper into the neutral state.

Rev.0 / Sep.2010

REP03-29-100

Copyright © 2010, Hitachi, Ltd.


3. POST-PROCESSING of SVP

3-1. <Check beginning of HDDPWR Replacement> Select (CL) [OK] in response to "Please replace the "HDDPWR-nnn." After replacement, press OK."




(Eg. HDDPWR-000)

3-2. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-3. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "HDDPWR-nnn" is
done."



3-4. <Confirm status>

Confirm the status display.

If button is normal (The string is normally display), go to Step 3-5.

If button is abnormal (The string is blinking), replace the target part again, or see TROUBLE SHOOTING SECTION.

3-5.

Go to POST-PROCEDURE [REP04-01-10].

[2.5 inch DKUPS REPLACEMENT PROCESSING - RU23]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select 2.5 inch DKUPS (status check)
 - ② Specify Replacement
 - 3 Detach 2.5 inch DKUPS
 - Place part into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of 2.5 inch DKUPS replacement
 - ② Reinstall related parts
 - 3 Start environment monitor

Rev.0 / Sep.2010

REP03-30-20


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
Select (CL) [DKU-XX] in the 'Maintenance' window.



Copyright © 2010, Hitachi, Ltd.

1-2. <Specify DKUPS> Select (CL) [PSn].



Rev.0 / Sep.2010

REP03-30-30

Copyright © 2010, Hitachi, Ltd.

1-3. <Execute>



When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




Rev.0 / Sep.2010

REP03-30-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].




Rev.1 / Sep.2010, Dec.2011

Copyright © 2010, 2011, Hitachi, Ltd.


REP03-30-40

1-5. <Check beginning of DKUPS Replacement> Select (CL) [Yes] in response to "Do you want to replace the "DKUPS-nnn?"".



(Eg. DKUPS-001)


1-6. <Check environment monitor stopped state>
The message "Processing to disable the environment check..." is displayed.



1-7. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the LED of the parts to be replaced (DKUPS-nnn) lit?" is displayed.


When the LED on the PCB to be pulled out is on, select (CL) [Yes] and go to Step 1-9. When the LED on the PCB to be pulled out is kept off, select (CL) [No] and go to Step 1-8.



1-8. <Making sure of the DKUPS location>
The message "Check the location of the target component." is displayed.

See "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the DKUPS location, select (CL) [OK] and go to Step 1-9.



Rev.0 / Sep.2010

REP03-30-50

1-9. < Check beginning of DKUPS replacement>

The message "The replacement parts may be mounted on DKUs that are not indicated on the Maintenance panel. Please make sure that the location of the replacement parts matches with the label of the DKU. (DKUPS-nnn)" is displayed.


Select (CL) [OK] after you confirmed the content.

The message "Have you checked the label and verified that these replacement parts are the right parts? (DKUPS-nnn)" is displayed. Select (CL) [Yes] after you confirmed the content.


The message "Please replace the "DKUPSnnn." After replacement, press OK." is displayed.

Reply with [OK] after replacing the special part.

Go to "2. HARDWARE REPLACEMENT PROCESSING".







(Eg. DKUPS-001)

Rev.0 / Sep.2010


REP03-30-60

Copyright © 2010, Hitachi, Ltd.

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Front or Rear of DKU	1	DKUPS	

DKU for 2.5 inch Drive



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.1 / Sep.2010, Sep.2011

REP03-30-70

Copyright © 2010, 2011, Hitachi, Ltd.

2-1 Replacement of DKUPS

- 1. Replacement of DKUPS
 - a. Check that the REPLACE LED is on.



A system down may be caused by a replacement of the DKUPS other than that to be replaced. Make sure that it is a DKUPS to be replaced.




Fig. 3.30.2-1 Check of REPLACE LED

b. Remove the stopper on the failed DKUPS and disconnect the cable.



Watching for short-circuits:

A Short-circuit may cause a fire.

Never insert metal or the like into the cable connector or a short-circuit may occur.

c. Loosen the two screws and remove the insulation from the screws.




Fig. 3.30.2-2 Disconnection of Cable

Rev.2 / Oct.2012, Mar.2014 REP03-30-90

- d. Loosen the two screws and remove the DKUPS turning over the insulation.
- Attach the spare DKUPS turning over the insulation and tighten the screws.
- Return the insulation to original position and tighten the screws. (Refer to Fig. 3.30.2-2.) f.
- g. Connect the cable and secure it with the stopper.

Note: When connecting the cable to DKUPS-xy2, run the cable through the through hole.




Fig. 3.30.2-3 Replacement of DKUPS


2. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Sep.2010

REP03-30-100

3. POST-PROCESSING of SVP


3-1. <Check beginning of DKUPS Replacement> Select (CL) [OK] in response to "Please replace the "DKUPS-nnn." After replacement, press OK."




Copyright © 2010, Hitachi, Ltd.

(Eg. DKUPS-001)

3-2. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-3. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "DKUPS-nnn" is done."



(Eg. DKUPS-001)

3-4. <Confirm status>

Confirm the status display.

If button is normal (The string is normally display), go to Step 3-5.

If button is abnormal (The string is blinking), replace the target part again, or see TROUBLE SHOOTING SECTION.

3-5.

Go to POST-PROCEDURE [REP04-01-10].

[3.5 inch DKUPS REPLACEMENT PROCESSING - RU33]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select 3.5 inch DKUPS (status check)
 - ② Specify Replacement
 - 3 Detach 3.5 inch DKUPS
 - Place part into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of 3.5 inch DKUPS replacement
 - ② Reinstall related parts
 - 3 Start environment monitor

Rev.0 / Sep.2010

REP03-31-20


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
Select (CL) [DKU-XX] in the 'Maintenance' window.



Copyright © 2010, Hitachi, Ltd.

1-2. <Specify DKUPS> Select (CL) [PSn].



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-31-30

Copyright © 2010, Hitachi, Ltd.

1-3. <Execute>



A CAUTION

When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




Rev.0 / Sep.2010

REP03-31-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].




Rev.0 / Sep.2010

REP03-31-40


Copyright © 2010, Hitachi, Ltd.

1-5. <Check beginning of DKUPS Replacement> Select (CL) [Yes] in response to "Do you want to replace the "DKUPS-nnn"?"



(Eg. DKUPS-001)


1-6. <Check environment monitor stopped state>
The message "Processing to disable the environment check..." is displayed.



1-7. < Checking lighting of LED on the PCB to be pulled out>

The message "Is the LED of the parts to be replaced (DKUPS-nnn) lit?" is displayed.


When the LED on the PCB to be pulled out is on, select (CL) [Yes] and go to Step 1-9. When the LED on the PCB to be pulled out is kept off, select (CL) [No] and go to Step 1-8.



1-8. <Making sure of the DKUPS location>
The message "Check the location of the target component." is displayed.

See "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the DKUPS location, select (CL) [OK] and go to Step 1-9.



Rev.0 / Sep.2010

REP03-31-50

1-9. < Check beginning of DKUPS Replacement>

The message "The replacement parts may be mounted on DKUs that are not indicated on the Maintenance panel. Please make sure that the location of the replacement parts matches with the label of the DKU. (DKUPS-nnn)" is displayed.


Select (CL) [OK] after you confirmed the content.

The message "Have you checked the label and verified that these replacement parts are the right parts? (DKUPS-nnn)" is displayed. Select (CL) [Yes] after you confirmed the content.

The message "Please replace the "DKUPSnnn." After replacement, press OK." is displayed.


Reply with [OK] after replacing the special part.

Go to "2. HARDWARE REPLACEMENT PROCESSING".



Copyright © 2010, Hitachi, Ltd.






(Eg. DKUPS-001)

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Front or Rear of DKU	1	DKUPS	

DKU for 3.5 inch Drive



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.1 / Sep.2010, Sep.2011

REP03-31-70

Copyright © 2010, 2011, Hitachi, Ltd.

2-1 Replacement of DKUPS

- 1. Replacement of DKUPS
 - a. Check that the REPLACE LED is on.

A CAUTION

A system down may be caused by a replacement of the DKUPS other than that to be replaced. Make sure that it is a DKUPS to be replaced.




Fig. 3.31.2-1 Check of REPLACE LED

Rev.0 / Sep.2010

REP03-31-80

Copyright © 2010, Hitachi, Ltd.

b. Remove the stopper on the failed DKUPS and disconnect the cable.



Watching for short-circuits:

A Short-circuit may cause a fire.

Never insert metal or the like into the cable connector or a short-circuit may occur.

c. Loosen the two screws and remove the insulation from the screws.




Fig. 3.31.2-2 Disconnection of Cable

Rev.2 / Oct.2012, Mar.2014

REP03-31-90

- d. Loosen the two screws and remove the DKUPS turning over the insulation.
- e. Attach the spare DKUPS turning over the insulation and tighten the screws.
- f. Return the insulation to original position and tighten the screws. (Refer to Fig. 3.31.2-2.)
- g. Connect the cable and secure it with the stopper.

Note: When connecting the cable to DKUPS-xy2, run the cable through the through hole.




Fig. 3.31.2-3 Replacement of DKUPS

2. Go to "3. POST-PROCESSING of SVP".


Copyright © 2010, 2014, Hitachi, Ltd.

Rev.0 / Sep.2010

REP03-31-100

3. POST-PROCESSING of SVP


3-1. <Check beginning of DKUPS Replacement> Select (CL) [OK] in response to "Please replace the "DKUPS-nnn." After replacement, press OK."




Copyright © 2010, Hitachi, Ltd.

(Eg. DKUPS-001)

3-2. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-3. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "DKUPS-nnn" is done."



(Eg. DKUPS-001)

3-4. <Confirm status>

Confirm the status display.

If button is normal (The string is normally display), go to Step 3-5.

If button is abnormal (The string is blinking), replace the target part again, or see TROUBLE SHOOTING SECTION.

3-5.

Go to POST-PROCEDURE [REP04-01-10].

[2.5 inch HDDFAN REPLACEMENT PROCESSING - RU24]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select 2.5 inch HDDFAN (status check)
 - ② Specify Replacement
 - 3 Detach 2.5 inch HDDFAN
 - Place part into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of 2.5 inch HDDFAN replacement
 - ② Reinstall related parts
 - 3 Start environment monitor

Rev.0 / Sep.2010


Copyright © 2010, Hitachi, Ltd. REP03-32-20

1. PRE-PROCESSING of SVP

1-1. <Maintenance window> Select (CL) [DKU-XX] in the 'Maintenance' window.



1-2. <Specify HDDFAN> Select (CL) [FANn].



Rev.0 / Sep.2010

REP03-32-30

Copyright © 2010, Hitachi, Ltd.

1-3. <Execute>



A CAUTION

When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




Rev.0 / Sep.2010

REP03-32-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].



Rev.0 / Sep.2010

REP03-32-40


Copyright © 2010, Hitachi, Ltd.

1-5. <Check beginning of HDDFAN Replacement>
Select (CL) [Yes] in response to "Do you
want to replace the "HDDFAN-nnn?""



(Eg. HDDFAN-000)


1-6. <Check environment monitor stopped state>
The message "Processing to disable the environment check..." is displayed.



1-7. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the LED of the parts to be replaced (HDDFAN-000) lit?" is displayed.

When the LED on the PCB to be pulled out is on, select (CL) [Yes] and go to Step 1-9. When the LED on the PCB to be pulled out is kept off, select (CL) [No] and go to Step 1-8.




(Eg. HDDFAN-000)

1-8. <Making sure of the HDDFAN location>
The message "Check the location of the target component." is displayed.

See "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the HDDFAN location, select (CL) [OK] and go to Step 1-9.



Rev.1 / Sep.2010, Dec.2011

1-9. < Check beginning of HDDFAN Replacement>

The message "The replacement parts may be mounted on DKUs that are not indicated on the Maintenance panel. Please make sure that the location of the replacement parts matches with the label of the DKU. (HDDFAN-nnn)" is displayed.

Select (CL) [OK] after you confirmed the content.


The message "Have you checked the label and verified that these replacement parts are the right parts? (HDDFAN-nnn)" is displayed.

Select (CL) [Yes] after you confirmed the content.

The message "Please replace the "HDDFANnnn." After replacement, press OK." is displayed.

Reply with [OK] after replacing the special part.

Go to "2. HARDWARE REPLACEMENT PROCESSING".








(Eg. HDDFAN-000)

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Front of DKU	1	FAN (front) Assembly	HDDFAN
Rear of DKU	2	FAN (rear) Assembly	HDDFAN

DKU for 2.5 inch Drive



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.1 / Sep.2010, Oct.2012

REP03-32-70

Copyright © 2010, 2012, Hitachi, Ltd.

2-1 Replacement of HDDFAN (FAN (front/rear) Assembly)

A CAUTION

Hazardous rotating mechanism:

Can cause injury if touched. Stay clear of it when machine is running.

2-1-1. Replace the HDDFAN (FAN Assembly).

- a. Put the stopper of the FAN door into the openable and closable state. (Refer to INST03-01-160.)
- b. Loosen the two screws and open the FAN door.
- c. Disconnect the cable (#-P502) from the SSW PCB.




Fig. 3.32.2-1 Disconnection of Cable

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd.

REP03-32-71

- d. Loosen the two screws and remove the cover from the failed HDDFAN.
- e. Disconnect the cable (#-P601) from the HDDFAN.




Fig. 3.32.2-2 Removal of Cable

f. Loosen the two screws at the rear view of the FAN door.




Fig. 3.32.2-3 Removal of Screw

- g. Remove the failed HDDFAN from the front side of the FAN door.
- h. Attach the spare HDDFAN.
- i. Fasten the two screws at the rear view of the FAN door. (Refer to Fig. 3.32.2-3.)




Fig. 3.32.2-4 Replacement of HDDFAN

2-1-2. Replace the cable.

a. Loosen the repeat binder, and remove the cable from the DKU.




Fig. 3.32.2-5 Removal of Cable

REP03-32-90

b. Attach the label of the same color and number as the removed cable to the cable in the spare parts.




Fig. 3.32.2-6 Attaching Label

- c. Attach the cover to the HDDFAN and tighten the two screws. (Refer to Fig. 3.32.2-2.)
- d. Connect the cable (#-P601) to the HDDFAN.
- e. Wire the cable in the spare parts in the same route as the removed cable. (Refer to Fig. 3.32.2-5.)
- f. Connect the cable (#-P502) to the SSW PCB.
- g. Secure the tip of the repeat binder to avoid contact with the FAN door.
- h. Close the FAN door and tighten the two screws.
- i. Put the FAN door stopper into the neutral state.

2-1-3. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Sep.2010

REP03-32-100

3. POST-PROCESSING of SVP


3-1. <Check beginning of HDDFAN Replacement>
Select (CL) [Yes] in response to "Please
replace the "HDDFAN-nnn." After
replacement, press OK."




Copyright © 2010, Hitachi, Ltd.

(Eg. HDDFAN-000)

3-2. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-3. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "HDDFAN-nnn" is
done."



(Eg. HDDFAN-000)

3-4. <Confirm status>

Confirm the status display.

If button is normal (The string is normally display), go to Step 3-5.

If button is abnormal (The string is blinking), replace the target part again, or see TROUBLE SHOOTING SECTION.

3-5.

Go to POST-PROCEDURE [REP04-01-10].

[3.5 inch HDDFAN REPLACEMENT PROCESSING - RU34]

— OUTLINE —


- 1. PRE-PROCESSING of SVP
 - ① Select 3.5 inch HDDFAN (status check)
 - 2 Specify Replacement
 - 3 Detach 3.5 inch HDDFAN
 - Place part into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of 3.5 inch HDDFAN replacement
 - ② Reinstall related parts
 - 3 Start environment monitor

Rev.0 / Sep.2010

REP03-33-20


1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
Select (CL) [DKU-XX] in the 'Maintenance' window.



Copyright © 2010, Hitachi, Ltd.

1-2. <Specify HDDFAN> Select (CL) [FANn].



DKC710I Hitachi Proprietary

Rev.0 / Sep.2010

REP03-33-30

Copyright © 2010, Hitachi, Ltd.

1-3. <Execute>



CAUTION

When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




Rev.0 / Sep.2010

REP03-33-31

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2010, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.


[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].




Rev.1 / Sep.2010, Dec.2011 **REP03-33-40**

1-5. <Check beginning of HDDFAN Replacement> Select (CL) [Yes] in response to "Do you want to replace the "HDDFAN-nnn?"".



(Eg. HDDFAN-000)


1-6. <Check environment monitor stopped state>
The message "Processing to disable the environment check..." is displayed.



1-7. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the LED of the parts to be replaced (HDDFAN-nnn) lit?" is displayed.


When the LED on the PCB to be pulled out is on, select (CL) [Yes] and go to Step 1-9. When the LED on the PCB to be pulled out is kept off, select (CL) [No] and go to Step 1-8.



1-8. <Making sure of the HDDFAN location>
The message "Check the location of the target component." is displayed.

See "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the HDDFAN location, select (CL) [OK] and go to Step 1-9.



Rev.0 / Sep.2010

REP03-33-50

1-9. < Check beginning of HDDFAN Replacement>

The message "The replacement parts may be mounted on DKUs that are not indicated on the Maintenance panel. Please make sure that the location of the replacement parts matches with the label of the DKU. (HDDFAN-nnn)" is displayed.

Select (CL) [OK] after you confirmed the content.


The message "Have you checked the label and verified that these replacement parts are the right parts? (HDDFAN-nnn)" is displayed.

Select (CL) [Yes] after you confirmed the content.

The message "Please replace the "HDDFANnnn." After replacement, press OK." is displayed.

Reply with [OK] after replacing the special part.

Go to "2. HARDWARE REPLACEMENT PROCESSING".



Copyright © 2010, Hitachi, Ltd.






(Eg. HDDFAN-000)

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Front of DKU	1	FAN (front) Assembly	HDDFAN
Rear of DKU	2	FAN (rear) Assembly	HDDFAN

DKU for 3.5 inch Drive



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Copyright © 2010, 2012, Hitachi, Ltd.

2-1 | Replacement of HDDFAN (FAN (front/rear) Assembly)

A CAUTION

Hazardous rotating mechanism:

Can cause injury if touched. Stay clear of it when machine is running.

2-1-1. Replace the HDDFAN (FAN Assembly).

- a. Put the stopper of the FAN door into the openable and closable state. (Refer to INST03-01-160.)
- b. Loosen the two screws and open the FAN door.
- c. Disconnect the cable (#-P502) from the SSW PCB.




Fig. 3.33.2-1 Disconnection of Cable

Rev.0 / Oct.2012

REP03-33-71

Copyright © 2012, Hitachi, Ltd.

- d. Loosen the two screws and remove the cover from the failed HDDFAN.
- e. Disconnect the cable (#-P601) from the HDDFAN.




Fig. 3.33.2-2 Removal of Cable

f. Loosen the two screws at the rear view of the FAN door.




Fig. 3.33.2-3 Removal of Screw

- g. Remove the failed HDDFAN from the front side of the FAN door.
- h. Attach the spare HDDFAN.
- i. Fasten the two screws at the rear view of the FAN door. (Refer to Fig. 3.33.2-3.)




Fig. 3.33.2-4 Replacement of HDDFAN

REP03-33-81

2-1-2. Replace the cable.

a. Remove the two hangers, and remove the cable from the DKU.




Fig. 3.33.2-5 Removal of Cable

REP03-33-90

b. Attach the label of the same color and number as the removed cable to the cable in the spare parts.




Fig. 3.33.2-6 Attaching Label

- c. Attach the cover to the HDDFAN and tighten the two screws. (Refer to Fig. 3.33.2-2.)
- d. Connect the cable (#-P601) to the HDDFAN.
- e. Wire the cable in the spare parts in the same route as the removed cable. (Refer to Fig. 3.33.2-5.)
- f. Connect the cable (#-P502) to the SSW PCB.
- g. Install the two hangers.
- h. Close the FAN door and tighten the two screws.
- i. Put the FAN door stopper into the neutral state.

2-1-3. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Sep.2010

REP03-33-100

3. POST-PROCESSING of SVP


3-1. <Check beginning of HDDFAN Replacement>
Select (CL) [OK] in response to "Please
replace the "HDDFAN-nnn." After
replacement, press OK."




Copyright © 2010, Hitachi, Ltd.

(Eg. HDDFAN-000)

3-2. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-3. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "HDDFAN-nnn" is
done."



(Eg. HDDFAN-000)

3-4. <Confirm status>

Confirm the status display.

If button is normal (The string is normally display), go to Step 3-5.

If button is abnormal (The string is blinking), replace the target part again, or see TROUBLE SHOOTING SECTION.

3-5.

Go to POST-PROCEDURE [REP04-01-10].

[PDU REPLACEMENT PROCESSING]


— OUTLINE —

1. HARDWARE REPLACEMENT PROCESSING

Rev.1 / Mar.2011, Oct.2012

1. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Rear of RACK	1	PDU30 (Longitudinal installation)	
	2	PDU30 (Lateral installation)	



Front View of PDU30 (Longitudinal installation)

Front View of PDU30 (Lateral installation)

NOTICE:

- Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.
- Other devices may be connected to PDU.
 When it is replaced, check the notes on the connected devices, and then replace it.

Copyright © 2011, 2012, Hitachi, Ltd.

1 Replacement of PDU30 (Longitudinal installation)



WARNING

Hazardous voltage:

Contact could cause electric shock or burn. Turn off all related breakers and discharge residual voltage, as shown below. (Follow next procedures.)



CAUTION

The device may be powered off when turning off the breakers not shown below.

1-1. Power Off the Component to be replaced

a. Turn off the breaker for the PDU to be replaced.




Fig. 3.34.1-1 Turn off the Breaker

- b. Turn off the circuit breaker on the power distribution panel in the plant that is connected to the PDU to be replaced.
- c. The circuit has residual voltage after turning off the breakers, so wait for one minute.

1-2. Removal of Power Cable

When wiring for the power cables from the round opening of the top cover

- a. Disconnect the power cable from the power distribution panel.
- b. Open the clamp tapes on the rear side of the rack, and remove the power cable.




Fig. 3.34.1-2 Removal of Power Cable (Round Opening)

When wiring for the power cables from the window opening of the top cover

- a. Disconnect the power cable from the power distribution panel.
- b. Loosen the two screws of the top cover, and slide the window opening toward the front side.
- c. Open the clamp tapes on the rear side of the rack, and remove the power cable.




Fig. 3.34.1-3 Removal of Power Cable (Window Opening)

1-3. Replacement of PDU30

- a. Open the stoppers and disconnect the cables.
- b. Loosen the two screws and remove the failed PDU30.
 Do not remove the screw when remove the failed PDU. There is a possibility that the failed PDU falls.




Fig. 3.34.1-4 Removal of PDU

- c. Remove the four screws of the PDU30, and remove the two brackets.
- d. Attach the two brackets to the spare PDU30, and fix them with the four screws.
- e. Attach the spare PDU30 with the two screws. (Refer to Fig. 3.34.1-4.)
- f. Connect the cables to the PDU30, and fix them with the stoppers.




Fig. 3.34.1-5 Removal of Brackets

1-4. Attachment of Power Cable

When wiring for the power cables from the round opening of the top cover

- a. Wire the power cable of the PDU30, and secure it with the clamp tapes. (Refer to Fig. 3.34.1-2.)
- b. Connect the power cable to the power distribution panel.

When wiring for the power cables from the window opening of the top cover

- a. Wire the power cable of the PDU30, and secure it with the clamp tapes. (Refer to Fig. 3.34.1-3.)
- b. Slide the window to close the opening, and retighten it with the two screws.
- c. Connect the power cable to the power distribution panel.

1-5. Power On the replacement component

- a. Turn on the breaker on the power distribution panel that is connected to PDU.
- b. Turn on the breaker on the PDU.




Fig. 3.34.1-6 Turn on the Breaker

Rev.1 / Mar.2011, Jun.2011

REP03-34-90

Copyright © 2011, Hitachi, Ltd.

1-6. Go to POST-PROCEDURE [REP04-01-10].

Rev.0 / Oct.2012

REP03-34-100

Copyright © 2012, Hitachi, Ltd.

Replacement of PDU30 (Lateral installation)



WARNING

Hazardous voltage:

Contact could cause electric shock or burn. Turn off all related breakers and discharge residual voltage, as shown below. (Follow next procedures.)




CAUTION

The device may be powered off when turning off the breakers not shown below.

2-1. Power Off the Component to be replaced

Turn off the breaker for the PDU to be replaced.

In case of PDU-x61/x71/x81



Front View of PDU30

In case of PDU-x60/x70/x80




Fig. 3.34.2-1 Turn off the Breaker

- b. Turn off the circuit breaker on the power distribution panel in the plant that is connected to the PDU to be replaced.
- c. The circuit has residual voltage after turning off the breakers, so wait for one minute.

2-2. Removal of Power Cable

When wiring for the power cables from the round opening of the top cover

- Disconnect the power cable from the power distribution panel.
- b. Open the clamp tapes on the rear side of the rack, and remove the power cable. (Refer to Fig. 3.34.2-2 or Fig. 3.34.2-3.)




Fig. 3.34.2-2 Removal of Power Cable (When PDU30 installed in the Bottom of Rack)

REP03-34-120




Fig. 3.34.2-3 Removal of Power Cable (When PDU30 Installed in the Top of Rack)

When wiring for the power cables from the window opening of the top cover

- a. Disconnect the power cable from the power distribution panel.
- b. Loosen the two screws of the top cover, and slide the window opening toward the front side. (Refer to Fig. 3.34.2-4 or Fig. 3.34.2-5.)
- c. Open the clamp tapes on the rear side of the rack, and remove the power cable.




Fig. 3.34.2-4 Removal of Power Cable (When PDU30 Installed in the Bottom of Rack)




Fig. 3.34.2-5 Removal of Power Cable (When PDU30 Installed in the Top of Rack)

Rev.0 / Oct.2012

REP03-34-150

34-150

2-3. Replacement of PDU30

- a. Open the stoppers and disconnect the power cables.
- b. Loosen the four screws and remove the failed PDU30.
 Do not remove the screw when remove the failed PDU. There is a possibility that the failed PDU falls.




Fig. 3.34.2-6 Removal of PDU

Copyright © 2012, Hitachi, Ltd.

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd.

REP03-34-160

- c. Remove the four screws of the PDU30, and remove the two brackets.
- d. Attach the two brackets to the spare PDU30, and fix them with the four screws.
- e. Attach the spare PDU30 with the four screws. (Refer to Fig. 3.34.2-6.)
- f. Connect the power cables to the PDU30, and fix them with the stoppers.




Fig. 3.34.2-7 Removal of Brackets

2-4. Attachment of Power Cable

When wiring for the power cables from the round opening of the top cover

- a. Wire the power cable of the PDU30, and secure it with the clamp tapes. (Refer to Fig. 3.34.2-2 or Fig. 3.34.2-3.)
- b. Connect the power cable to the power distribution panel.


When wiring for the power cables from the window opening of the top cover

- a. Wire the power cable of the PDU30, and secure it with the clamp tapes. (Refer to Fig. 3.34.2-4 or Fig. 3.34.2-5.)
- b. Slide the window to close the opening, and retighten it with the two screws.
- c. Connect the power cable to the power distribution panel.

2-5. Power On the replacement component

- a. Turn on the breaker on the power distribution panel that is connected to PDU.
- b. Turn on the breaker on the PDU.

In case of PDU-x61/x71/x81



Front View of PDU30

In case of PDU-x60/x70/x80




Fig. 3.34.2-8 Turn on the Breaker

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd.

REP03-34-180

2-6. Go to POST-PROCEDURE [REP04-01-10].

[FCoE CHA REPLACEMENT PROCESSING - RCH3]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select CHA (status check)
 - ② Specify Replacement
 - ③ Place PCB into blocked state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify recovery for CHA
 - ② Path online (for CHA)

Rev.0 / Mar.2011

REP03-35-20

1. PRE-PROCESSING of SVP

1-1. <Set path offline or switch of channel path>



A CAUTION

For Mainframe, the path to be placed offline is that connected with the CHA concerned. For Open host, the switch to the alternate channel path or host shutdown is that connected with the CHA concerned.

As for other channel path, switching to the alternate channel path or host shutdown is unnecessary.


However, the host must be shut down when the Pinned track in CHA connected port.

Copyright © 2011, Hitachi, Ltd.

Rev.0 / Mar.2011


REP03-35-30

1-2. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.



Copyright © 2011, Hitachi, Ltd.


1-3. <DKC window>
Select (CL) [DKC-n Back] in the 'DKC' window.



REP03-35-40

Copyright © 2011, 2012, Hitachi, Ltd.

1-4. <Select CHA> Select (CL) CHA.




1-5. <Specify Replacement of CHA>

A CAUTION

- When the path to the PCB to be replaced is online, ask the customer to place it offline. (For CHA replacement)
- For Open host, switch to the alternate channel path or shut down the host. However, the host must be shut down when the Pinned track in CHA connected port.
- When the screen requests an operator to input a password in order to prevent multiple maintenance, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Make sure that the status is WARNING. Select (CL) [Replace].



REP03-35-50

1-6. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

| CONL4270W]

To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.

(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).

(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped. [No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-5.

When [No] is selected (CL), returned to Step 1-6.


Replace [ONL4271i] Did you put on a wrist strap on your wrist? Yes No



1-7.<CHA replace>

Select (CL) [Yes] in response to:

"Do you want to replace the PCB(s)(CHAnnnn)? If [Yes] is selected, the PCB(s) needs to be removed and inserted again.".




(Eg. CHA)

Rev.0 / Mar.2011

REP03-35-60


Copyright © 2011, Hitachi, Ltd.


1-8. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.



1-9. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].






"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.



A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format

"[factory_cd]_[Pcb_type]_[Pcb_SerialNo]_YYMMDDhhmmss.tgz".

(YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes Minute, and ss denotes Second)

Rev.0 / Mar.2011

REP03-35-80

Copyright © 2011, Hitachi, Ltd.

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.


Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.

It returns to the drive selection screen when [Cancel] is selected (CL).

• When the destination media is write-protected.

<For Windows XP>



Check security privileges over the network drive. OK Select a dump file

Select a dump file

080314172442 Cannot access this file.

\\tsclient\G\080320180607.tgz

You don't have permission to save in this location. Contact the administrator to obtain permission.

Would you like to save in the Administrator folder instead?

<u>Y</u>es

<u>N</u>o

<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.

Please appoint another destination

whether you remove write protect when you save it and carry it out.

• When dialog of the destination drive specified with the Client PC is open, the media is removed, and then select (CL) [Save].

Rev.0 / Mar.2011

REP03-35-90

Copyright © 2011, Hitachi, Ltd.


 When the memory in the destination drive specified with the Client PC is corrupted.
 The dialog remains displayed after selecting (CL) [OK].

At the time of the above operation completion, the information collection is not carried out.



Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.


Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".



1-10. <Confirm Channel Path offline>
Select (CL) [Yes] in response to following message.

For Fiber CHA:

"Confirm that you have already shut down the corresponding connected host(s) or switched to the alternate channel path(s) for all HOST connected to this PCB. Do you want to continue processing?".



Rev.0 / Mar.2011

REP03-35-100

Copyright © 2011, Hitachi, Ltd.

1-11. <Caution message for system down>



A CAUTION


Select (CL) [Yes] in response to the message below.

"Do you want to replace the PCB(s) by using the normal replacement procedure?

Yes = Normal replacement

No = Forcible replacement.

(Possible critical errors)".



Rev.0 / Mar.2011

REP03-35-110

1-12. <CHA blocking>

"CHA-xxx is being blocked... Usually, several minutes (maximum 15 minutes)"


"CHA-xxx is lighting the LED..."

1-13. <Check shut down LED>

Select (CL)

- * [Yes] if LED is on
- * [No] if LED is off

in response to "Is the LED of the target PCB(s) lit?".




Copyright © 2011, Hitachi, Ltd.

If [No] is selected:

Select (CL) [OK] in response to "Check the location of the target PCB(s)(CHA-nnn), then pull out the PCB(s) without considering the status of LED.". (Refer to "2. HARDWARE REPLACEMENT PROCESSING")

Note: Select (CL) [OK] after pulling out the PCB.

Go to Step 1-14.




1-14. <Beginning of CHA replacement>

"Please replace the PCB(s)(CHA-nnn). After replacement, please select [OK]." is displayed.


Select (CL) [OK] after replacing the CHA.

Go to "2. HARDWARE REPLACEMENT PROCESSING".



2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Rear View of		CHA PCB for FCoE (10Gbps)	• WP713-A (8FOE)
DKC		(CHG 4P 10Gbps Assembly)	



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Mar.2011 Copyright © 2011, Hitachi, Ltd.

REP03-35-130

- 2-1. Remove the Channel Adapter PCB.
 - a. Check that the Shut Down LED is on. (only hot replace)





Fig. 3.35.2-1 Confirmation of Shut Down LED

REP03-35-140

- b. Disconnect the optical fibre cables from the failed Channel Adapter PCB.
- c. Remove the two screws and remove the failed PCB.



Note: After removing the PCB, install the spare PCB immediately.

If the PCB is kept removed for a long time, the wind doesn't flow among installed PCBs, causing the PCBs' temperature rise which may result in temperature warning or temperature alarm.





Fig. 3.35.2-2 Removal of PCB

REP03-35-150

2-2. Insert the spare PCB.

a. Insert the spare PCB to the correct location and tighten the screws.



2-3. Cleaning the fibre cable connectors.

For the tools needed for the cleaning, refer to the tool list on page PARTS06-10.

- Blow compressed gas against the connector using an air sprayer (for about five seconds).
- b. Wipe the connector lightly with a piece of cut gauze wet with ethyl alcohol.
- c. Blow compressed air again and check the result of the cleaning. (None of dust, sticking of foreign matter, and dirt must be observed.)
- 2-4. Connect the optical fibre cables to the spare PCB.
- 2-5. Go to "3. POST-PROCESSING of SVP".


Rev.0 / Mar.2011

REP03-35-160

Copyright © 2011, Hitachi, Ltd.

3. POST-PROCESSING of SVP

3-1. <Beginning of CHA Replacement>
Select (CL) [OK] in response to "Please replace the PCB(s)(CHA-nnn). After replacement, please select [OK]." after replacement.



3-2. <Check the end of CHA recovery>
Select (CL) [OK] in response to "Replace finished.".



Rev.0 / Mar.2011

REP03-35-170

3-3. <Path on-line when CHA is replaced>
When a CHA is replaced, set the path (from the host) on the replaced CHA to ONLINE by your customer.

3-4.

Go to POST-PROCEDURE [REP04-01-10].

Copyright © 2011, Hitachi, Ltd.

DKC710I

[SSD REPLACEMENT PROCESSING - RSS1]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select SSD (status check)
 - ② Specify Replacement
 - 3 Place PCB into blocked state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Execute CUDG on SSD
 - ② Specify recovery


Rev.0 / Mar.2011

REP03-36-20


Copyright © 2011, Hitachi, Ltd.

1. PRE-PROCESSING of SVP


1-1. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.



1-2. <DKC window>
Select (CL) [DKC-n Front] in the 'DKC' window.



1-3. <Select Cache> Select (CL) Cache.



Rev.0 / Mar.2011

REP03-36-30

Copyright © 2011, Hitachi, Ltd.


1-4. <Specify replacement of cache>



When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Select (CL) [Replace], and select (CL) [SSDx].



Rev.0 / Mar.2011

REP03-36-40

1-5. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

[ONL4270W]

To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.

Copyright © 2011, Hitachi, Ltd.

(1) <Confirm wearing wrist strap>
In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).



(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-4.

When [No] is selected (CL), returned to Step 1-5.



Rev.1 / Mar.2011, Dec.2011


REP03-36-50

Copyright © 2011, Hitachi, Ltd.

1-6. <Check the beginning of cache replace>
Select (CL) [Yes] after making sure that the package to be replaced is correct in response to "Do you want to replace the SSD(SSDn)?
If [Yes] is selected, the SSD needs to be removed and inserted again.".




1-7. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.



1-8. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].





"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.



A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format "SHSSD_YYMMDDhhmmss.tgz". (YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes Minute, and ss denotes Second

🔟 Select a dump file

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if

necessary.

Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.

Save in:

| \(\frac{1}{2} \) \(\frac{1}{2} \

It returns to the drive selection screen when [Cancel] is selected (CL).

Rev.0 / Mar.2011

REP03-36-70

Copyright © 2011, Hitachi, Ltd.

When the destination media is write-protected.
 <For Windows XP>



<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.

\\\tsclient\\G\080320180607.tgz
You don't have permission to save in this location.
Contact the administrator to obtain permission.

Would you like to save in the Administrator folder instead?

Please appoint another destination

whether you remove write protect when you save it and carry it out.

• When dialog of the destination drive specified with the Client PC is open, the media is removed, and then select (CL) [Save].

Select a dump file


 When the memory in the destination drive specified with the Client PC is corrupted.
 The dialog remains displayed after selecting (CL) [OK].

At the time of the above operation completion, the information collection is not carried out.



Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.

Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".



Rev.0 / Mar.2011

REP03-36-80


Copyright © 2011, Hitachi, Ltd.

1-9. < Confirmation of amount of opposite cluster battery charge>

(1)

• When there is PCB whose amount of battery charge is less than 50% in the opposite cluster:

"A battery whose charge capacity is less than 50% is in the cluster of opposite site to be replaced. If there is a battery problem on the battery, replace it. If there is no battery problem on the



battery, wait the operation until the charge capacity of the battery becomes 50% or more (maximum 90 min.). Do you want to stop this process?".

When [Yes] is selected (CL), returned to Step 1-4. When [No] is selected (CL), go to Step (2)

- When there is no PCB whose amount of charge of the Cache battery is less than 50%: go to Step 1-10.
- (2) <Input password>
 Enter the password and select (CL) [OK].



Notice: This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss if a wrong part to be removed is selected, and requires an input of a password. Ask the technical support division about the appropriateness of the operation, and input the password after getting an approval of executing the operation.

1-10. <SSD blocking>

"The SSD (SSDn) is being blocked." is displayed.

Rev.1 / Mar.2011, Dec.2011


REP03-36-90

1-11. <Check shut down LED>

(1)

Select (CL)


- * [Yes] if LED is blinking
- * [No] if LED is off in response to "Is the LED of the target parts(SSDn) blinking?".



Copyright © 2011, Hitachi, Ltd.


(2)

"The LED cannot be blinking. CACHEnnn might have an error. Replace the CACHE-nnn first." is displayed. Select (CL) [OK] after replacing the PCB. Returned to Step 1-4.



1-12. <Cache Replacement>

"Replace the target parts (SSDn), then select [OK] button. The LED of the target parts will not be turned off until you select [OK]." is displayed.




1-13. < Replace cache PCB> Replace cache.

Go to "2. HARDWARE REPLACEMENT PROCESSING".

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component	Part Name
cont View of DKC	of DKC 1 SSD (Cache SSD)	• 32GB SSD(BM64)
cont View of DKC	of DKC 1 SSD (Cache SSD)	• 32GB SSD(BM64) • 64GB SSD(BM128)



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Mar.2011

REP03-36-110

2-1 SSD

2-1-1. Check that the Shut Down LED blinks.

- a. Open the DKCPANEL when the target CM PCB locations are CACHE-2CD, 2CG, 2CH, 2CM, 2CQ or 2CR.
 - For the CM PCB location other than the above, go to the procedure c.
- b. Loosen the screw, slide the DKCPANEL to the far right, and open the DKCPANEL.




Fig. 3.36.2.1-1 Shifting of DKCPANEL

Copyright © 2011, Hitachi, Ltd.

Rev.0 / Mar.2011

REP03-36-120

Copyright © 2011, Hitachi, Ltd.

c. Check the Shut Down LED on the target CM PCB in the DKC to see that it blinks. (only hot replace)

When the SSD that intends to replace is the SSD0, the Shut Down LED blinks twice per two seconds. (ON: twice in about 0.6 seconds, OFF: about 1.4 seconds)

When the SSD that intends to replace is the SSD1, the Shut Down LED blinks three times per two seconds. (ON: three times in about one second. OFF: about one second)




Fig. 3.36.2.1-2 Confirmation of Shut Down LED


Rev.0 / Mar.2011

REP03-36-130

Copyright © 2011, Hitachi, Ltd.

2-1-2. Replace the SSD.

- a. Loosen the two screws in the front side of the CM PCB, and remove the cover.
- b. Remove the replaced SSD from the CM PCB after loosen the screw and put the stopper up.
- c. Install the spare SSD in the CM PCB, and put the stopper down, and then secure it with the screw.
- d. Install the cover that is removed in procedure a. to the front side of the CM PCB, and secure it with the two screws.
- e. Replace the DKCPANEL and secure it with the screw if the DKCPANEL is opened. (Refer to Fig. 3.36.2.1-1.)






Fig. 3.36.2.1-3 Replacement of SSD

Rev.0 / Mar.2011

REP03-36-140

2-1-3. Go to "3. POST-PROCESSING of SVP".

Copyright © 2011, Hitachi, Ltd.

Rev.2 / Sep.2011, Dec.2011


REP03-36-150

3. POST-PROCESSING of SVP

3-1. < Cache Replacement>

"Replace the target parts (SSDn), then select [OK] button. The LED of the target parts will not be turned off until you select [OK]." is displayed.

Select (CL) [OK] after replacing the PCB.



Copyright © 2011, Hitachi, Ltd.

3-2. <INLINE CUDG>

"INLINE CUDG is now running..." is displayed.

3-3. <Restore the SSD>

"Restoring the SSD..." is displayed.

3-4. <Check the end of Cache recovery> Select (CL) [OK] in response to "Replace finished.".



Rev.1 / Mar.2011, Sep.2011

REP03-36-160

Copyright © 2011, Hitachi, Ltd.

3-5.

Go to POST-PROCEDURE [REP04-01-10].

[FBX SSW REPLACEMENT PROCESSING - RUF1]

- OUTLINE -


- 1. PRE-PROCESSING of SVP
 - ① Select SSW
 - 2 Specify Replacement
 - 3 Place SSW into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify recovery of DKA Port connected to SSW

Rev.0 / Oct.2012

REP03-37-20

1. PRE-PROCESSING of SVP


1-1. <Maintenance window>
Select (CL) the DKU information [DKU-nn]
of the DKU which installs the SSW to be
replaced in the 'Maintenance' window.



Copyright © 2012, Hitachi, Ltd.

1-2. <Select SSW>
Check and select (CL) [SSWn-X] to be

replaced.



DKC710I Hitachi Proprietary

Rev.0 / Oct.2012

REP03-37-30

Copyright © 2012, Hitachi, Ltd.

1-3. < Specify replacement>



A CAUTION

When the screen requests an operator to input a password in order to prevent multiple maintenance, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Select (CL) [Execute].

Selecting (CL) [Cancel] returns you to Step 1-2.



Rev.0 / Oct.2012

REP03-37-40

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

(1) < Confirm wearing wrist strap>

In response to a message, "Did you put on a wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).


(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?

[Yes]: This processing will be stopped. [No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-2.

When [No] is selected (CL), returned to Step 1-4.



Copyright © 2012, Hitachi, Ltd.






Rev.0 / Oct.2012

REP03-37-50


1-5. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.




Copyright © 2012, Hitachi, Ltd.

1-6. <Get the error information>

Input the Field Failure Information, and select (CL) [OK].





Rev.0 / Oct.2012


REP03-37-60

"Insert a removable media for gathering error information and select [OK]. The information will be essential to investigate the problem of the hardware. You can select [Cancel] only when removable media is not available." is displayed.

Trouble information is preserved in console PC connected with SVP.

Please select the Client PC radio button of the screen, and select an arbitrary drive letter from the pull-down menu. The drive letter becomes the drive letter of console PC connected with SVP.

Minute, and ss denotes Second)



Copyright © 2012, Hitachi, Ltd.

A Primary copy is always placed on the SVP HD in the "c:\dkc200\others\pcbinfo\" directory with the following file name format "SH528_YYMMDDhhmmss.tgz". (YY denotes Year, MM denotes Month, DD denotes Day, hh denotes Hour, mm denotes

Rev.0 / Oct.2012

REP03-37-70

Copyright © 2012, Hitachi, Ltd.

When Client PC is selected, the directory selection dialog is displayed.

Please select an arbitrary directory if necessary.

Console PC that \\tsclient connects with SVP is shown when it is a directory display, and \\tsclient\F and \F shows F drive of console PC.

Select (CL) [Save] when saving a file in a specified directory.

It returns to the drive selection screen when [Cancel] is selected (CL).

Note: The message is displayed two or more times. Please only operate the SSW selected by 1-3. <Specify replacement>.

• When the destination media is write-protected.

<For Windows XP>




<For Windows Vista>

Selecting (CL) [Yes] displays the "C:\users\Administrator" folder of SVP. Selecting (CL) [No] displays the folder selected with the Client PC.

Please appoint another destination

whether you remove write protect when you save it and carry it out.

• When dialog of the destination drive specified with the Client PC is open, the media is removed, and then select (CL) [Save].



Rev.0 / Oct.2012

REP03-37-80

Copyright © 2012, Hitachi, Ltd.


 When the memory in the destination drive specified with the Client PC is corrupted.
 The dialog remains displayed after selecting (CL) [OK].

At the time of the above operation completion, the information collection is not carried out.



Please choose another directory again after having closed a system message whether you reconnect the drive that you removed when you save it and carry it out.

Select (CL) [OK] in response to "The acquisition of the information has completed. Click the [OK] button, and continue replace processing.".




Rev.0 / Oct.2012

REP03-37-90

unavoidable.".

1-7. <Check beginning of DKA Port blocking>
Select (CL) [Yes] in response to "Are you sure you want to replace the SSW? If you select [Yes], blocking of the DKA port will be



Copyright © 2012, Hitachi, Ltd.

1-8. <Check DKA Port blocking>
"The DKA Port is being blocked..." is displayed.

Rev.0 / Oct.2012

REP03-37-100


37-100

1-9. <Replace SSW>

"Please replace the SSW, and then select [OK]. (SSWnnn-xxx)

When selected SSW and other SSW locations are displayed replace it too.

If there are two or more SSWs to be replaced, remove all the SSWs whose locations are displayed and then install the new ones. The LED of the target SSW will not be turned off until you select [OK]." is displayed.



Copyright © 2012, Hitachi, Ltd.

Make sure of the SSW PCB location is displayed, select (CL) the [OK] button after replaced target SSW PCB.


If the SSW LED is not turned on, please replace SSW PCB.

Go to "2. HARDWARE REPLACEMENT PROCESSING".

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Rear of FBX DKU	1	SSW	

DKU for FMD



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Oct.2012

REP03-37-120

Copyright © 2012, Hitachi, Ltd.

2-1 Replacement of SSW

2-1-1. Replace the SSW.

a. Check Shut Down LED on the SSW.

CAUTION: A system down is caused by a replacement of the SSW PCB other than that to be replaced. Make sure that it is the SSW PCB to be replaced.




Fig. 3.37.2-1 Confirmation of Shut Down LED

b. Disconnect the cables from the SSW.




Fig. 3.37.2-2 Disconnection of Cables

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd.

REP03-37-130

- c. Press the latches of the SSW inward to unlock the levers.
- d. Pull the levers of the SSW toward you and remove the SSW from the FBX DKU.




Fig. 3.37.2-3 Removal of SSW PCB

Rev.0 / Oct.2012

REP03-37-140

Copyright © 2012, Hitachi, Ltd.

2-1-2. Set the SSW jumpers.

- a. Loosen the screw on the spare SSW and open the cover.
- b. Set the jumpers of the spare SSW. For jumper settings, refer to LOC06-170 through 250.

Note: Use the insulated radio pliers of the maintenance tools when setting the SSW jumpers.

c. Close the cover of the spare SSW and tighten the screw.





Fig. 3.37.2-4 Opening Cover

2-1-3. Insert the spare SSW.

- a. Fully open the levers of the spare SSW. (Refer to Fig. 3.37.2-3.)
- b. Insert the SSW until the edge of the levers comes in contact with the FBX DKU.



- c. Close the levers and completely insert the SSW. Then confirm that the latches hold the levers.
- d. Connect the cables to the SSW after checking "3.1.7 Notes when connecting the DEV interface cable" (INST03-01-180). (Refer to Fig. 3.37.2-2.)

2-1-4. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Oct.2012

REP03-37-150

3. POST-PROCESSING of SVP

3-1. <Check replacement of SSW>


Select (CL) [OK] in response to "Please replace the SSW, and then select [OK]. (SSWnnn-xxx)

When selected SSW and other SSW locations are displayed replace it too.

If there are two or more SSWs to be replaced, remove all the SSWs whose locations are displayed and then install the new ones.

The LED of the target SSW will not be turned

off until you select [OK]." After replacement, press OK.




Copyright © 2012, Hitachi, Ltd.

Please only replace the SSW selected by 1-3. <Specify replacement>. Make sure that the SSW PCB location is displayed, select (CL) the [OK] button after replacing target SSW PCBs. Even if the SSW LED is not turned on, please replace the SSW PCBs.

Notice: The LED lights up also for an SSW connected with the same SAS interface cable as that of the specified SSW. The light turns off if you select (CL) on the [OK] button.

3-2. <Check the beginning of DKA Port recovery> Select (CL) [Yes] in response to "Do you want to restore the DKA ports now?".



3-3. <DKU PATH INLINE>

"DKU PATH INLINE is now running..." is displayed.



CAUTION

When a failure is found during DKU PATH INLINE, the DKA Port connected to the loop are blocked.


Confirm the Diagnosis Log and solve the problem.

Rev.0 / Oct.2012

REP03-37-160

3-4. <Check DKA Port recovery processing> "Restoring the DKA Port..." is displayed.

"The FAN Door of HDDFAN-xxx is open.
Close the FAN Door, and select [OK].
The FAN Door checking is executed up to 3 times. (n/3)" is displayed.
After the FAN door is closed, select (CL)
[OK] in response to this message.



Copyright © 2012, Hitachi, Ltd.

It returns to (1) when HDDFAN doors of the object are not closed.


It goes to 3-5 when HDDFAN doors of the object are closed.

Note: It goes to (2) when it cannot be confirmed that the FAN doors are closed in the three times FAN door check.

"A problem in HDDFAN or a FAN Door open might be occurred.

After completing the maintenance process, check the Maintenance or Information window in an error status or an error log is shown on the window, then execute troubleshooting." is displayed.

Select (CL) [OK] in response to this message.



Rev.0 / Oct.2012

REP03-37-170

Copyright © 2012, Hitachi, Ltd.

3-5. <Check the end of SSW replace>
Select (CL) [OK] in response to "Replace finished.".



3-6.

Go to POST-PROCEDURE [REP04-01-10].

[FBX DKUPS REPLACEMENT PROCESSING - RUF3]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select FBX DKUPS (status check)
 - ② Specify Replacement
 - ③ Detach FBX DKUPS
 - Place part into unpluggable state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify end of FBX DKUPS replacement
 - ② Reinstall related parts
 - 3 Start environment monitor


Rev.0 / Oct.2012

REP03-38-20


Copyright © 2012, Hitachi, Ltd.

1. PRE-PROCESSING of SVP

1-1. <Maintenance window>
Select (CL) [DKU-XX] in the 'Maintenance' window.



1-2. <Specify DKUPS> Select (CL) [DKUPS-nnnn].



DKC710I Hitachi Proprietary

Rev.0 / Oct.2012

REP03-38-30

Copyright © 2012, Hitachi, Ltd.

1-3. <Execute>



A CAUTION

When the screen prompting an operator to input a password in order to prevent a multiple maintenance, contact the technical support division to ask for an instruction.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

A window shown on the right is displayed. Select (CL) [Execute].




Rev.0 / Oct.2012

REP03-38-40

1-4. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".



Copyright © 2012, Hitachi, Ltd.

"Did you put on a wrist strap on your wrist?" is displayed.

select (CL) [Yes] and go to Step 1-5.



"This operation cannot be executed, because the wrist strap has not been worn.

Do you want to stop this process?

[Yes]: This processing will be stopped.

[No]: The confirming message will appear." is displayed.

When the processing will be stopped, select (CL) [Yes].




Rev.0 / Oct.2012

REP03-38-50

Copyright © 2012, Hitachi, Ltd.

1-5. <Check beginning of DKUPS Replacement> Select (CL) [Yes] in response to "Do you want to replace the "DKUPS-nnnn?"".



(Eg. DKUPS-0000)


1-6. <Check environment monitor stopped state>
The message "Processing to disable the environment check..." is displayed.



1-7. < Checking lighting of the LED on the PCB to be pulled out>

The message "Is the REPLACE LED of the (DKUPS-nnnn) to be replaced on?" is displayed.

When the LED on the PCB to be pulled out is on, select (CL) [Yes] and go to Step 1-9. When the LED on the PCB to be pulled out is kept off, select (CL) [No] and go to Step 1-8.




(Eg. DKUPS-0000)

1-8. <Making sure of the DKUPS location>
The message "Check the location of the target component." is displayed.

See "2. HARDWARE REPLACEMENT PROCESSING".

After making sure of the DKUPS location, select (CL) [OK] and go to Step 1-9.



Rev.0 / Oct.2012

REP03-38-60

1-9. <Check beginning of DKUPS replacement>

The message "The replacement parts may be mounted on DKUs that are not indicated on the Maintenance panel. Please make sure that the location of the replacement parts matches with the label of the DKU. (DKUPS-nnnn)" is displayed.


Select (CL) [OK] after you confirmed the content.

The message "Have you checked the label and verified that these replacement parts are the right parts? (DKUPS-nnnn)" is displayed. Select (CL) [Yes] after you confirmed the content.

The message "Please replace the "DKUPSnnnn." After replacement, press OK." is displayed.


Reply with [OK] after replacing the special part.

Go to "2. HARDWARE REPLACEMENT PROCESSING".



Copyright © 2012, Hitachi, Ltd.






(Eg. DKUPS-0000)

2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Rear of FBX DKU	1	DKUPS	

DKU for FMD



FBX DKU



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Oct.2012

REP03-38-80

Copyright © 2012, Hitachi, Ltd.

2-1 Replacement of DKUPS


2-1-1. Replacement of DKUPS

a. Check that the REPLACE LED is on.



CAUTION

A system down may be caused by a replacement of the DKUPS other than that to be replaced. Make sure that it is a DKUPS to be replaced.



Front View of DKUPS

Fig. 3.38.2-1 Check of REPLACE LED

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd.

REP03-38-90

- b. Pull and open the cable clamp.
- c. Disconnect the PS cable from the DKUPS.

A CAUTION

Watching for short-circuits:

A Short-circuit may cause a fire.

Never insert metal or the like into the cable connector or a short-circuit may occur.




Fig. 3.38.2-2 Disconnection of PS Cable

Rev.0 / Oct.2012 Copyright © 2012, Hitachi, Ltd.

REP03-38-100

- d. Have the handle down (②) while pressing the latches of the DKUPS to the right (①).
- e. Pull the handle and detach the DKUPS from the FBX DKU.
- f. Open the handle on the spare DKUPS.
- g. Insert the spare DKUPS until the pin on it comes into contact with the mounting portion of the FBX DKU.
- h. Push up the handle and fully insert the spare DKUPS. Then confirm that the latches hold the handle.
- i. Connect the PS cable to the DKUPS and fix the PS cable with the cable clamp.
- j. Push the cable clamp toward the DKUPS.




Fig. 3.38.2-3 Replacement of DKUPS


2-1-2. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Oct.2012

REP03-38-110

3. POST-PROCESSING of SVP


3-1. <Check beginning of DKUPS Replacement> Select (CL) [OK] in response to "Please replace the "DKUPS-nnnn." After replacement, press OK."




Copyright © 2012, Hitachi, Ltd.

(Eg. DKUPS-0000)

3-2. <Check environment monitor start processing>
The message "Processing to enable the environment check..." is displayed.



3-3. <Check end of replacement>
Select (CL) [OK] in response to
"Replacement of the "DKUPS-nnnn" is
done."



(Eg. DKUPS-0000)

3-4. <Confirm status>

Confirm the status display.

If button is normal (The string is normally display), go to Step 3-5.

If button is abnormal (The string is blinking), replace the target part again, or see TROUBLE SHOOTING SECTION.

3-5.

Go to POST-PROCEDURE [REP04-01-10].

[Fibre CHA Dummy REPLACEMENT PROCESSING - RCD1]

— OUTLINE —

- 1. PRE-PROCESSING of SVP
 - ① Select CHA (status check)
 - ② Specify Replacement
 - ③ Place PCB into blocked state
- 2. HARDWARE REPLACEMENT PROCESSING
- 3. POST-PROCESSING of SVP
 - ① Specify recovery for CHA
 - ② Path online (for CHA)

Rev.0 / Apr.2013

REP03-39-20

1. PRE-PROCESSING of SVP

1-1. <Set path offline or switch of channel path>

A CAUTION

For Mainframe, the path to be placed offline is that connected with the CHA concerned. For Open host, the switch to the alternate channel path or host shutdown is that connected with the CHA concerned.

As for other channel path, switching to the alternate channel path or host shutdown is unnecessary.


However, the host must be shut down when the Pinned track in CHA connected port.

Copyright © 2013, Hitachi, Ltd.

Rev.0 / Apr.2013


REP03-39-30

1-2. <Maintenance window>
Select (CL) [DKC-n] in the 'Maintenance' window.



Copyright © 2013, Hitachi, Ltd.

1-3. <DKC window>
Select (CL) [DKC-n Back] in the 'DKC' window.




Rev.0 / Apr.2013

REP03-39-40

Copyright © 2013, Hitachi, Ltd.

1-4. <Select CHA> Select (CL) CHA.




1-5. < Specify Replacement of CHA>

A CAUTION

- When the path to the PCB to be replaced is online, ask the customer to place it offline. (For CHA replacement)
- For Open host, switch to the alternate channel path or shut down the host. However, the host must be shut down when the Pinned track in CHA connected port.
- When the screen requests an operator to input a password in order to prevent multiple maintenance, contact the technical support division to ask for instructions.

If any other message that is not explained below is displayed, see the SVP MESSAGE SECTION (SVPMSG00-00).

Make sure that the status is WARNING. Select (CL) [Replace].



Rev.0 / Apr.2013

REP03-39-50

1-6. <Wear a wrist strap>

Select (CL) [OK] in response to "To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.".

(1) <Confirm wearing wrist strap>
In response to a message, "Did you put on a

wrist strap on your wrist?".

Select (CL) [Yes] when wrist strap is on your wrist.

Select (CL) [No] when there is no wrist strap on your wrist.

When [No] is selected (CL), go to Step (2).

(2)

In response to a message, "This operation cannot be executed, because the wrist strap has not been worn. Do you want to stop this process?


[Yes]: This processing will be stopped. [No]: The confirming message will appear."

When [Yes] is selected (CL), returned to Step 1-5.

When [No] is selected (CL), returned to Step 1-6.

[ONL4270W] To prevent serious failures caused by the static electrical charge, be sure to wear a wrist strap on your wrist and connect the earth clip attached on the other side of the wrist strap to the chassis frame (metal part) before starting operation.

Copyright © 2013, Hitachi, Ltd.






1-7.<CHA replace>

Select (CL) [Yes] in response to:

"Do you want to replace the PCB(s)(CHA-nnn)? If [Yes] is selected, the PCB(s) needs to be removed and inserted again.".




(Eg. CHA)

Rev.0 / Apr.2013

REP03-39-60


Copyright © 2013, Hitachi, Ltd.


1-8. <Compression of the error information>
The error information is compressed.
The dialog of FD Copy is displayed.



1-9. <Get the error information>

There is no need to get error information in dummy replacement. Select (CL) [Cancel].





Rev.0 / Apr.2013


REP03-39-70

Copyright © 2013, Hitachi, Ltd.

1-10. <Confirm Channel Path offline> Select (CL) [Yes] in response to following message.

For Fiber CHA:

"Confirm that you have already shut down the corresponding connected host(s) or switched to the alternate channel path(s) for all HOST connected to this PCB. Do you want to continue processing?".



1-11. <Caution message for system down>



CAUTION


Select (CL) [Yes] in response to the message below.

"Do you want to replace the PCB(s) by using the normal replacement procedure?

Yes = Normal replacement

No = Forcible replacement.

(Possible critical errors)".



Rev.0 / Apr.2013

Copyright © 2013, Hitachi, Ltd.

REP03-39-80

1-12. <CHA blocking>

"CHA-xxx is being blocked... Usually, several minutes (maximum 15 minutes)"


"CHA-xxx is lighting the LED..."

1-13. <Check shut down LED>

Select (CL)

- * [Yes] if LED is on
- * [No] if LED is off

in response to "Is the LED of the target PCB(s) lit?".




If [No] is selected:

Go to Step 1-14.

Select (CL) [OK] in response to "Check the location of the target PCB(s)(CHA-nnn), then pull out the PCB(s) without considering the status of LED.". (Refer to "2. HARDWARE REPLACEMENT PROCESSING")

Note: Select (CL) [OK] after pulling out the PCB.

TCD.




1-14. <Beginning of CHA replacement>

"Please replace the PCB(s)(CHA-nnn). After replacement, please select [OK]." is displayed.


Select (CL) [OK] after replacing the CHA.

Go to "2. HARDWARE REPLACEMENT PROCESSING".



2. HARDWARE REPLACEMENT PROCESSING

Location	Function Name of Component		Part Name
Rear View of DKC	1	CHA (Channel Adapter) PCB for Fibre (8Gbps) (Fibre 4-port Adapter PCB) (Non-RoHS2 compliant part)	• WP712-B (8UFC)
		CHA PCB for Fibre (8Gbps) (Fibre 4-port Adapter PCB) (RoHS2 compliant part)	• WP712-D (8UFCR)
	2	CHA PCB for Fibre (8Gbps) (Fibre 8-port Adapter PCB) (Non-RoHS2 compliant part)	• WP712-A (16UFC)
		CHA PCB for Fibre (8Gbps) (Fibre 8-port Adapter PCB) (RoHS2 compliant part)	• WP712-C (16UFCR)



NOTICE:

Be sure to wear your wrist strap and attach to ground prior to performing the following work. This will ensure that the IC and LSI on the PCB are protected from static electricity.

Rev.0 / Apr.2013

REP03-39-100

Copyright © 2013, Hitachi, Ltd.

2-1. Remove the Channel Adapter PCB.

a. Check that the Shut Down LED is on. (only hot replace)





Fig. 3.39.2-1 Confirmation of Shut Down LED

Rev.0 / Apr.2013

REP03-39-110

Copyright © 2013, Hitachi, Ltd.

- b. Disconnect the optical fibre cables from the Channel Adapter PCB.
- c. Remove the two screws and remove the PCB.



Note: After removing the PCB, install the PCB immediately.

If the PCB is kept removed for a long time, the wind doesn't flow among installed PCBs, causing the PCBs' temperature rise which may result in temperature warning or temperature alarm.





Fig. 3.39.2-2 Removal of PCB

REP03-39-120

2-2. Insert the PCB.

a. Insert the PCB to the correct location and tighten the screws.



2-3. Cleaning the fibre cable connectors.


For the tools needed for the cleaning, refer to the tool list on page PARTS06-10.

- a. Blow compressed gas against the connector using an air sprayer (for about five seconds).
- b. Wipe the connector lightly with a piece of cut gauze wet with ethyl alcohol.
- c. Blow compressed air again and check the result of the cleaning. (None of dust, sticking of foreign matter, and dirt must be observed.)
- 2-4. Connect the optical fibre cables to the spare PCB.
- 2-5. Go to "3. POST-PROCESSING of SVP".

Rev.0 / Apr.2013 REP03-39-130 Copyright © 2013, Hitachi, Ltd.

3. POST-PROCESSING of SVP

3-1. <Beginning of CHA Replacement>
Select (CL) [OK] in response to "Please replace the PCB(s)(CHA-nnn). After replacement, please select [OK]." after replacement.



3-2. <Check the end of CHA recovery>
Select (CL) [OK] in response to "Replace finished.".



Rev.0 / Apr.2013

REP03-39-140

3-3. <Path on-line when CHA is replaced>
When a CHA is replaced, set the path (from the host) on the replaced CHA to ONLINE by your customer.

3-4.

Go to POST-PROCEDURE [REP04-01-10].

Copyright © 2013, Hitachi, Ltd.

[POST-PROCEDURE]

- OUTLINE -

- ① SIM Log Complete
- ② Change the SVP operation mode
- 3 Maintenance Window

DKC710I Hitachi Proprietary

Rev.0 / Sep.2010


Copyright © 2010, Hitachi, Ltd. REP04-01-20

SIM Log Complete


(1)

Change the mode from [View Mode] to [Modify Mode]. Select (CL) [Information].


(2) Select (CL) [Log...] in the 'Information' dialog box.



(3) Select (CL) [SIM] and [List...] in the 'Log'.




(4) Select (CL) data to be completed in the 'List-SIM' dialog box and select (CL) [Complete].




REP04-01-30

(5) Select (CL) [Yes] in the 'Complete' dialog box.



Copyright © 2010, Hitachi, Ltd.

(6) In the 'List-SIM' dialog box, make sure that "Completed" is displayed in the Status.



(7)

Select (CL) [Close] in the 'List-SIM' dialog box.

Close the 'Log' dialog box and close the 'Information' window.

Change the mode from [Modify Mode] to [View Mode].

Note: Even if SIM Complete was performed, the MESSAGE of the Operator Panel may be on. Display all the SIMs to make sure they are completed. If not, please wait for 5 minutes and operate SIM Log Complete again.

2. <Maintenance window>

In the 'Maintenance' window, check the status of subsystem.

Recover the parts if the other parts are blocked.

Close the 'Maintenance' window if there is no problem.

3. <Changing the SVP operation mode>
In the 'SVP' window, change the mode to [View Mode].

Please up-load trouble information gathered in console PC to the server by using OnlineDumpTool. (SVP02-1900)