



Hitachi Virtual Storage Platform G200, G400, G600

Service Guide

No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or stored in a database or retrieval system for any purpose without the express written permission of Hitachi, Ltd.

Hitachi, Ltd., reserves the right to make changes to this document at any time without notice and assumes no responsibility for its use. This document contains the most current information available at the time of publication. When new or revised information becomes available, this entire document will be updated and distributed to all registered users.

Some of the features described in this document might not be currently available. Refer to the most recent product announcement for information about feature and product availability, or contact Hitachi Data Systems Corporation at <https://portal.hds.com>.

Notice: Hitachi, Ltd., products and services can be ordered only under the terms and conditions of the applicable Hitachi Data Systems Corporation agreements. The use of Hitachi, Ltd., products is governed by the terms of your agreements with Hitachi Data Systems Corporation.

By using this software, you agree that you are responsible for:

- a) Acquiring the relevant consents as may be required under local privacy laws or otherwise from employees and other individuals to access relevant data; and
- b) Verifying that data continues to be held, retrieved, deleted, or otherwise processed in accordance with relevant laws.

Hitachi is a registered trademark of Hitachi, Ltd., in the United States and other countries. Hitachi Data Systems is a registered trademark and service mark of Hitachi, Ltd., in the United States and other countries.

Archivas, Essential NAS Platform, HiCommand, Hi-Track, ShadowImage, Tagmaserve, Tagmasoft, Tagmasolve, Tagmastore, TrueCopy, Universal Star Network, and Universal Storage Platform are registered trademarks of Hitachi Data Systems.

AIX, AS/400, DB2, Domino, DS6000, DS8000, Enterprise Storage Server, ESCON, FICON, FlashCopy, IBM, Lotus, MVS, OS/390, RS/6000, S/390, System z9, System z10, Tivoli, VM/ESA, z/OS, z9, z10, zSeries, z/VM, and z/VSE are registered trademarks or trademarks of International Business Machines Corporation.

iPad is a trademark of Apple Inc., registered in the U.S. and other countries.

All other trademarks, service marks, and company names in this document or web site are properties of their respective owners.

Microsoft product screen shots are reprinted with permission from Microsoft Corporation.

Notice on Export Controls. The technical data and technology inherent in this Document may be subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Reader agrees to comply strictly with all such regulations and acknowledges that Reader has the responsibility to obtain licenses to export, re-export, or import the Document and any Compliant Products.

Equipment warranty

The term of guarantee of normal operation of the storage system and free service is one year from date of purchase.

If a failure occurs multiple times, the storage system might shut off to avoid a serious accident.

Backup

Hitachi cannot guarantee against data loss due to failures. Therefore, back up your data to minimize chances for data loss.

Data backup is also critical when hardware components are added or replaced, because performing such hardware procedures restores parameter settings that can affect how data is managed on the storage systems.

Disposal



This symbol on the product or on its packaging means that your electrical and electronic equipment should be disposed at the end of life separately from your household wastes.

There are separate collection systems for recycling in the European Union. For more information, contact the local authority or the dealer where you purchased the product.

UEFI Development Kit 2010

This product includes UEFI Development Kit 2010 written by the UEFI Open Source Community. For more information, see the UEFI Development Kit website:

<http://sourceforge.net/apps/mediawiki/tianocore/index.php?title=UDK2010>

© 2004, Intel Corporation.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

Neither the name of the Intel Corporation nor the names of its contributors might be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



Contents

Preface.....	11
Safety and environmental notices.....	12
General safety guidelines.....	13
Handling of heavy parts.....	14
Preventing electric shock.....	14
Avoiding rotating or moving parts.....	14
Preventing machine damage.....	15
Working when the storage system is turned on.....	15
Precautions when using the storage system.....	15
Procedures in an emergency.....	16
For electric shock.....	16
For fire.....	16
Audience and qualifications.....	16
Product version.....	17
Release notes.....	17
Document conventions.....	17
Conventions for storage capacity values.....	18
Accessing product documentation.....	19
Getting help.....	19
Comments.....	19
1 Verifying component failures.....	21
Replaceable parts.....	22
Identifying hardware faults.....	22
2 Hardware description.....	31
Storage system controllers.....	32
CBSS controller.....	32
CBSS with front panel bezel.....	32
CBSS front panel without bezel.....	33
CBSS rear panel.....	33
CBSL controller.....	35

CBSL with front panel bezel.....	35
CBSL front panel without bezel.....	36
CBSL rear panel.....	36
CBLM controller.....	38
CBLM with front panel bezel.....	38
CBLM front panel without bezel.....	39
CBLM rear panel.....	40
Controller interfaces.....	41
Front end module descriptions.....	41
8 Gbps Fibre Channel board LEDs and connectors.....	41
16 Gbps Fibre Channel board LEDs and connectors.....	42
10 Gbps iSCSI board LEDs and connectors.....	43
Back end module LEDs and connectors.....	44
Power supply unit LEDs and connectors.....	45
Power supply unit LEDs and connectors.....	45
Storage system drive trays.....	46
Small form factor (SFF) drive tray.....	46
SFF with front panel bezel.....	46
SFF front panel without bezel.....	46
SFF rear panel.....	47
Large form factor (LFF) drive tray.....	48
LFF with front panel bezel.....	48
LFF front panel without bezel.....	49
LFF rear panel.....	49
Flash module drive (FMD) tray.....	50
FMD with front panel bezel.....	50
FMD front panel without bezel.....	51
FMD rear panel.....	52
Dense intermix drive tray.....	53
Dense intermix drive tray with front panel bezel.....	53
Dense intermix drive tray display LEDs.....	53
Dense intermix drive tray rear panel.....	54
Service Processor.....	55
SVP front panel.....	56
SVP rear panel.....	57

3 Replacing components..... 59

Electrostatic discharge precautions.....	60
Unpacking replacement components.....	60
Follow appropriate power on and power off work procedures.....	60
Safety considerations.....	61
Guidelines to follow when replacing a component.....	62
Guidelines to follow after replacing a component.....	62
Starting the maintenance utility.....	63
Starting the maintenance utility from Hitachi Command Suite.....	63
Starting the maintenance utility from Hitachi Device Manager - Storage Navigator	64
Replacement parts.....	66
Removing and replacing the front bezel.....	69
Removing the front bezel from a DBS or DBL drive tray.....	69
Replacing the front bezel for a CBSS or CBSL controller.....	70

Removing the front bezel from SFF, LFF, and FMD drive trays.....	71
Replacing the front bezel from a SFF, LFF, or FMD drive tray.....	72
Remove the front bezel from a CBLM or CBLH controller.....	73
Replacing the front bezel.....	74
Attaching the front bezel to a dense intermix drive tray.....	75
Removing the front bezel from a dense intermix drive tray.....	76
Checking recovery after replacing components.....	77
4 Replacing a drive.....	79
Checking a drive.....	80
Blocking the drive.....	81
Replacing a drive for a CBSS or SFF drive tray.....	82
Replacing a drive for a CBSL or LFF drive tray.....	83
Replacing a drive for a flash module drive tray.....	85
Replacing a drive for the dense intermix drive tray.....	85
Checking the drive status.....	86
5 Replacing a battery.....	89
Checking the battery.....	90
Replacing the battery.....	90
6 Replacing a fan.....	93
Blocking the controller.....	94
Replacing a fan.....	96
Restoring a fan.....	98
7 Replacing a power supply.....	101
Checking the power supply.....	102
Replacing a power supply for a CBSS or CBSL.....	102
Replacing a power supply for a CBLM or CBLH.....	104
Replacing a power supply for SFF and LFF drive trays.....	105
Replacing a power supply for a FMD drive tray.....	107
Confirming the power supply unit status.....	108
8 Replacing a controller.....	111
Blocking the controller.....	112
Replacing a controller for a CBSS or CBSL controller.....	114
Removing the controller.....	114
Removing and installing the fan.....	116
Removing and installing cache memory.....	117
Removing and installing a front end module.....	119
Removing and installing cache flash memory.....	120
Removing and installing the backup module.....	121
Installing a controller.....	121
Replacing a CBLM or CBLH controller.....	122
Removing a CBLM or CBLH controller.....	122
Removing and installing cache memory.....	125
Removing and installing cache flash memory for a CBLM or CBLH controller.....	127

Installing a controller in a CBLM or CBLH controller.....	129
Restoring a controller.....	130
9 Replacing cache memory.....	133
Checking cache memory.....	134
Replacing cache memory for a CBLM or CBLH controller.....	136
Replacing cache memory for a CBSS or CBSL controller.....	137
Replacing cache memory for a CBLM or CBLH controller.....	141
Restoring cache memory.....	145
10 Replacing a front end module.....	147
Blocking a front end module.....	148
Adding a front end module.....	150
Restoring a front end module.....	152
11 Replacing a small form-factor pluggable (SFP).....	153
Checking an SFP.....	154
Replacing an SFP.....	154
12 Replacing an ENC.....	159
Blocking an ENC.....	160
Replacing the ENC for SFF and LFF drive trays.....	162
Replacing the ENC for a FMD drive tray.....	163
Restoring an ENC.....	164
13 Replacing a SAS cable.....	165
Replacing SAS cables connected to a CBSS or CBSL controller.....	167
Replacing SAS cables connected to a CBLM or CBLH controller.....	171
Replacing SAS cables on a drive tray.....	174
14 Replacing cache flash memory.....	181
Blocking the CFM.....	182
Replacing the CFM.....	184
Restoring a CFM.....	186
15 Replacing a LAN blade.....	187
Blocking the controller.....	188
Replacing the LAN blade.....	190
Restoring the LAN blade.....	191
16 Replacing a backup module.....	193
Replacing a BKM.....	194
Checking the BKM backup module.....	194
Replacing the BKM backup module.....	194
Replacing a BKMF.....	195

Blocking a BKMF.....	195
Replacing the BKMF backup module.....	196
17 General maintenance.....	199
Periodic maintenance.....	200
Cleaning the storage system.....	200
Inspecting fans.....	200
Replacing the battery.....	201
Checking for loose or damaged cables or connectors.....	201
Restarting the storage system.....	201
Storing the storage system.....	201
18 Troubleshooting.....	203
General troubleshooting.....	204
Correct values for the storage system IP address.....	204
DHCPv4 configuration for storage systems.....	204
IP address being used by other storage systems or hosts.....	204
IP address configuration for the host.....	205
TCP/UDP port filtering being performed on the network switch.....	205
Search Storage system performed across the IPv6 routers.....	205
Troubleshooting Hitachi Device Manager - Storage Navigator.....	205
Dump tool.....	206
About the Dump tool.....	206
Using the Dump tool.....	207
Collecting dump files manually.....	207
Troubleshooting the maintenance utility.....	208
JavaScript security.....	208
Compatibility view.....	209
Clearing the browser cache.....	209
Forcing browser refreshes of the Maintenance Utility window.....	209
Maintenance Utility window hangs.....	209
Checking alerts.....	210
Turning the storage system on or off using the maintenance utility.....	216
Using LEDs to diagnose problems.....	216
POWER LED does not go on.....	216
POWER LED turned off	217
READY LED does not go on or READY LED went on and then off.....	218
ALARM LED is on.	218
WARNING LED goes on or blinks.....	218
A Warning labels on the storage system.....	219
CBSS controller.....	221
CBSL controller.....	222
CBLM controller.....	223
Small form factor drive tray.....	223
Large form factor drive tray.....	224
Flash module drive tray.....	226
Dense intermix drive tray.....	227
CBSS/CBSL controller.....	227

CBLM controller.....	228
Drive for a CBSS/small form factor drive tray.....	228
Drive for a small form factor drive tray.....	229
Drive for a CBSL/large form factor drive tray.....	229
Drive for a large form factor drive tray.....	229
Drive for a flash module drive tray.....	230
Drive for a dense intermix drive tray.....	230
CBSS/CBSL power unit.....	230
CBLM power supply.....	231
Power supply for small and large form factor drive trays.....	231
Flash module drive tray power supply.....	231
Dense intermix drive tray power supply.....	232
Front end module (Fibre Channel/iSCSI).....	232
Back end module.....	233
ENC for small and large form factor drive trays.....	233
ENC for a dense intermix drive tray.....	233
CMA (used to secure dense intermix drive tray).....	234
Battery.....	234



Preface

Before you install a Hitachi Virtual Storage Platform (VSP) storage system, it is important to confirm that your site is ready to support your storage system.

This guide describes how to plan and prepare for the installation of a Hitachi VSP storage system.

As part of the site-preparation process, customers are required to purchase site-preparation services from Hitachi Global Services. These services include:

- A telephone predelivery site survey to confirm power, location of equipment, access, and expectations.
- Telephone consultation to determine a customer's optimum configuration.

- ☐ [Safety and environmental notices](#)
- ☐ [General safety guidelines](#)
- ☐ [Audience and qualifications](#)
- ☐ [Product version](#)
- ☐ [Release notes](#)
- ☐ [Document conventions](#)
- ☐ [Conventions for storage capacity values](#)
- ☐ [Accessing product documentation](#)
- ☐ [Getting help](#)
- ☐ [Comments](#)

Safety and environmental notices

Equipment warranty

The term of guarantee of normal operation of the storage system and free service is one year from date of purchase.

If a failure occurs multiple times, the storage system might shut off to avoid a serious accident.

Notice of export controls

Export of technical data contained in this document might require an export license from the United States government, the government of Japan. or both. Contact the Hitachi Legal Department for guidance about any export compliance questions.

Backup

Hitachi cannot guarantee against data loss due to failures. Therefore, back up your data to minimize chances for data loss.

Data backup is also critical when hardware components are added or replaced, because performing such hardware procedures restores parameter settings that can affect how data is managed on the storage systems.

Disposal



This symbol on the product or on its packaging means that your electrical and electronic equipment should be disposed at the end of life separately from your household wastes.

There are separate collection systems for recycling in the European Union. For more information, contact the local authority or the dealer where you purchased the product.

UEFI Development Kit 2010

This product includes UEFI Development Kit 2010 written by the UEFI Open Source Community. For more information, see the UEFI Development Kit website:

© 2004, Intel Corporation.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

Neither the name of the Intel Corporation nor the names of its contributors might be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

General safety guidelines

Before starting maintenance:

- Maintenance must be performed by trained and qualified engineers only.
- The safety guidelines and procedures in this manual must be read and followed.
- In this manual and on the storage system, hazard warnings are provided to aid you in preventing or reducing the risk of death, personal injury, or product damage. Understand and follow these hazard warnings fully.
- If warning labels on the storage system become dirty or start peeling off, replace them.
- If an anomaly such as an unusual noise, smell, or smoke occurs on the storage system while it is running, power off or remove the power cables immediately.

- Hazard warnings in this manual or on the storage system cannot cover every possible case, because it is impossible to predict and evaluate all circumstances beforehand. Be alert and use common sense.
- To ensure normal operation, operate the storage system according to the information in this manual.

Read the following safety guidelines carefully and follow them when you conduct maintenance of the machine:

- Do not use materials that are outside the specifications for the storage system.
- Use the spare parts, consumables, and materials for maintenance that are specified in this manual; otherwise, personal injury, system damage, and degradation in system quality can occur.
- Keep the maintenance area neat.
- Always put away parts, materials, and tools when not in use.

Handling of heavy parts

- When lifting a heavy object, hold it close to yourself and keep your back erect to prevent back injury.
- When lifting an object designated with a caution in this manual, use a proper lifting tool or have somebody assist you.

Preventing electric shock

- Before starting work, be sure that, unless otherwise specifically instructed, there is no potential electric hazard in the maintenance area such as insufficient grounding or a wet floor.
- Before starting work, know where the emergency power-off switches are located and be sure you know how to operate them.
- Unless otherwise specifically instructed, remove all power sources to the machine before starting maintenance. Switching off the storage system power supplies is usually not sufficient.
- Do not touch any uninsulated conductor or surface that remains charged for a limited time after the external power supply to the storage system is disconnected.
- Do not replace parts during a thunderstorm.

Avoiding rotating or moving parts

- Do not supply power to any device with rotating or moving parts that are not properly covered.
- Tuck in your tie, scarf, shirt, or any other loose clothing to prevent it from getting caught by a rotating or moving part.

Preventing machine damage

- Use the tools and instruments, as instructed in this manual, or equivalent commercially available tools and instruments suited for the purpose.
- Use measurement instruments and powered tools that are properly calibrated or periodically inspected.
- Before finishing your work, be sure all parts removed during maintenance have been installed in their original positions in the storage system. Do not leave any tools or foreign material in the storage system.

Working when the storage system is turned on

Observe the following safety measures when working on the storage system with the system power turned on. When you perform maintenance, do not touch live electric parts to prevent an electric shock.

- Do not touch heat sinks immediately after a board is removed because the heat sinks are extremely hot.
- While performing maintenance, do not drop tools, screws, or other items into the storage system, because doing so can cause a short circuit.
- While performing maintenance, do not damage or pinch wires.
- When moving a heavy object, have at least two people move the object after confirming there are no obstacles nearby.

Precautions when using the storage system

- Use the supplied power cords included with the storage system. Do not use the supplied power cords for other products. Do not use other power cords with the storage system.
- Shut off the power feed to the equipment and inform the system administrator immediately if you notice an unusual smell, abnormal heat generation, or smoke emission. Leaving such conditions unattended can cause electric shock or fire.
- Exercise care when handling the storage system and its parts. Do not drop the equipment or parts.
- Do not stand on the storage system. Avoid using the storage system for any use other than the one for which it was originally designed.
- Do not place heavy objects on the storage system, near the vents on the front and rear panels, or on the cables attached to the storage system.
- Do not put a container with water, paper clips, or the like on the storage system or near the power supply.
- Route cables in a way to prevent people from tripping over them.
- Do not operate the storage system in a moist or dusty place.
- Keep these vents open and be sure they are not blocked to keep the storage system ventilated. Cool air enters the storage system from the air vent on the front panel and exits through the vent on the rear panel.

- If a failure occurs in the storage system, follow the instructions in this manual. If the problem is not covered by this manual, contact your system administrator.

Procedures in an emergency

For electric shock

- Before performing maintenance, be sure that there is no potential electric hazard in the maintenance area, such as insufficient grounding or a wet floor.
- Before performing maintenance, observe where the emergency poweroff switches are located and be sure you know how to operate them.
- Unless otherwise instructed, remove all power sources to the storage system before starting work. Switching off the storage system power supplies is not sufficient. When power is fed from a wall or floor outlet, unplug the power supply cord, or turn off the switch on the power distribution panel or board.
- If the power supply has a lockout device, lock the device after powering off the storage system and retain the key. Attach a notice on the panel or board prohibiting the use of the switch.
- If the machine power has been already turned off, confirm that these conditions have been satisfied.

For fire

- Shut off all the power to the machine.
- Turn off the emergency power switch or stop the power supply to the storage system.
- If the fire continues to burn after the power is shut off, take suitable actions, including the use of a fire extinguisher, or call the fire department.

Audience and qualifications

This guide is intended for data center administrators, facility managers, and others who perform the planning and preparation work for storage system installations. It references skilled tasks and describes important safety considerations, and is not intended as a training aid for untrained personnel.

The information in this guide assumes the reader has the following abilities:

- Is familiar with computing terminology, RAID technology, and optical and Ethernet connectivity.
- Understands networking concepts, network switch technology, and network cabling.
- Knows how to calculate floor loads and power budgeting.
- Understands the procedures for installing rack-mounted components and is trained in safe work procedures.

- Is familiar with high-speed interconnects for modular storage systems.

Product version

This document revision applies to Hitachi Virtual Storage Platform G200, G400, G600 firmware 83-01-0x or later.

Release notes





Read the release notes before installing and using this product. They may contain requirements or restrictions that are not fully described in this document or updates or corrections to this document.

Document conventions

This document uses the following typographic conventions:

Convention	Description
Bold	Indicates text on a window, other than the window title, including menus, menu options, buttons, fields, and labels. Example: Click OK .
<i>Italic</i>	Indicates a variable, which is a placeholder for actual text provided by the user or system. Example: <i>copy source-file target-file</i> Note: Angled brackets (< >) are also used to indicate variables.
Monospace	Indicates text that is displayed on screen or entered by the user. Example: <code>pairdisplay -g oradb</code>
< > angled brackets	Indicates a variable, which is a placeholder for actual text provided by the user or system. Example: <code>pairdisplay -g <group></code> Note: Italic font is also used to indicate variables.
[] square brackets	Indicates optional values. Example: [a b] indicates that you can choose a, b, or nothing.
{ } braces	Indicates required or expected values. Example: { a b } indicates that you must choose either a or b.
vertical bar	Indicates that you have a choice between two or more options or arguments. Examples: [a b] indicates that you can choose a, b, or nothing. { a b } indicates that you must choose either a or b.

This document uses the following icons to draw attention to information:

Icon	Label	Description
	Note	Calls attention to important or additional information.
	Tip	Provides helpful information, guidelines, or suggestions for performing tasks more effectively.
	Caution	Warns the user of adverse conditions or consequences (for example, disruptive operations).
	WARNING	Warns the user of severe conditions or consequences (for example, destructive operations).

Conventions for storage capacity values

Physical storage capacity values (for example, disk drive capacity) are calculated based on the following values:

Physical capacity unit	Value
1 kilobyte (KB)	1,000 (10^3) bytes
1 megabyte (MB)	1,000 KB or $1,000^2$ bytes
1 gigabyte (GB)	1,000 MB or $1,000^3$ bytes
1 terabyte (TB)	1,000 GB or $1,000^4$ bytes
1 petabyte (PB)	1,000 TB or $1,000^5$ bytes
1 exabyte (EB)	1,000 PB or $1,000^6$ bytes

Logical storage capacity values (for example, logical device capacity) are calculated based on the following values:

Logical capacity unit	Value
1 block	512 bytes
1 KB	1,024 (2^{10}) bytes
1 MB	1,024 KB or $1,024^2$ bytes
1 GB	1,024 MB or $1,024^3$ bytes
1 TB	1,024 GB or $1,024^4$ bytes
1 PB	1,024 TB or $1,024^5$ bytes
1 EB	1,024 PB or $1,024^6$ bytes

Accessing product documentation

Product user documentation is available on the Hitachi Data Systems Portal: <https://portal.hds.com>. Check this site for the most current documentation, including important updates that may have been made after the release of the product.

Getting help

[Hitachi Data Systems Support Portal](https://portal.hds.com) is the destination for technical support of your current or previously-sold storage systems, midrange and enterprise servers, and combined solution offerings. The Hitachi Data Systems customer support staff is available 24 hours a day, seven days a week. If you need technical support, log on to the Hitachi Data Systems Support Portal for contact information: <https://portal.hds.com>.

[Hitachi Data Systems Community](https://community.hds.com) is a new global online community for HDS customers, partners, independent software vendors, employees, and prospects. It is an open discussion among these groups about the HDS portfolio of products and services. It is the destination to get answers, discover insights, and make connections. The HDS Community complements our existing Support Portal and support services by providing an area where you can get answers to non-critical issues and questions. **Join the conversation today!** Go to community.hds.com, register, and complete your profile.

Comments

Please send us your comments on this document to doc.comments@hds.com. Include the document title and number, including the revision level (for example, -07), and refer to specific sections and paragraphs whenever possible. All comments become the property of Hitachi Data Systems Corporation.

Thank you!

Verifying component failures

This chapter describes how to use the maintenance utility to confirm component failures.

- ☐ [Replaceable parts](#)
- ☐ [Identifying hardware faults](#)

Replaceable parts

The following list shows the components that you can replace on site for the storage systems.



Note: For the dense intermix drive tray, the only user-replacement procedure supported by Hitachi is installing or replacing disk drives.

- Drive (replacing drives on the flash module drive tray is not supported)
- Battery
- Fan for CBSS or CBSL
- Power supply unit
- Controller
- Cache memory
- Front end module
- Small Form-Factor Pluggable
- Back end module for CBLM or CBLH
- ENC
- SAS cable
- Cache Flash Memory
- LAN blade
- Backup Module (BKM) for CBSS or CBSL
- Backup Module (BKMF) for CBLM or CBLH

Identifying hardware faults

There are several ways the storage system can alert you to failures:

- When notified about an error by email, the maintenance utility, or the Simple Management Network Protocol (SNMP).
- When a failure is indicated by storage system LED (for example, `WARNING` or `ALARM` LED goes on or `READY` LED does not go on).

To identify a failed part and recover the storage system:

Procedure

1. Check the serial number of the storage system referenced in the email notification or SNMP alert.
2. Start the maintenance utility (see [Starting the maintenance utility](#)).


3. In the **Maintenance Utility** window, check the serial number of the storage system where the error was reported.






The screenshot displays the Hitachi Maintenance Utility interface. On the left sidebar, the 'Storage System' section is selected, and the 'S/N: 400001' entry is circled in red. The main panel shows the 'S/N: 400001' storage system details. A red line points from the 'Serial number' label to the 'Serial Number' field in the 'Storage System Information' table, which contains the value '400001'.

Storage System Information			
Storage System Name	StorageSystem	IPv4 Address	CTL1 10.0.0.18
Contact	03-xxxx-xxxx	IPv4 Address	CTL2 10.0.0.17
Location	Tokyoxxxx	IPv6 Address	CTL1 :
Storage System Type	VSP G200	IPv6 Address	CTL2 :
Serial Number	400001	Temperature	23 degrees C
Number of Drives	73	Spare	9
Drive Capacity	17.76 TB	Free	2.05 TB
		Total	23.47 TB

Serial number


4. In the left pane of the **Maintenance Utility** window (circled in the figure below), check the **Status** of the storage system.



Status	Description	Navigation area
Failed	The storage system might be down.	
Warning	The part status might have a Blocked, Failed, or Warning status.	
Information	Check the status of unimplemented SIMs, regardless of part status.	
Ready	All parts have a normal status.	
Power-on in progress	Power-on is in progress.	

Status	Description	Navigation area
Power-off in progress	Power-off is in progress.	Power-off in progress
(Other than shown above)	Power-off status	Unknown

- At the top-right of the **Maintenance Utility** window, click **Alert**. The window switches to the **Alerts** tab.



6. Click the **Alert ID**.
The **Alert Detail** window shows the failed part that must be replaced.

The screenshot shows the 'Alert Detail' window. At the top, there is a message: 'Contact the Hitachi Data Systems customer support.' Below this is a table with the following data:

Alert ID	24
Date and Time	2014/08/29 02:06:07
Reference Code	627001
Error Level	Moderate
Error Section	Environment error
Error Detail	UNIT connection error
Location	
Concerned Alerts	

Below the table is a section titled 'Action Codes' containing a table with two columns: 'Action Code' and 'Possible Failure Parts'.

Action Code	Possible Failure Parts
41040003	Drive
41800100	CTL


Red boxes highlight the 'Action Code' column and the 'Possible Failure Parts' column. A red arrow points from the text 'Parts that need replacement' to the 'Possible Failure Parts' column. Another red arrow points from the text 'Action code' to the 'Action Code' column. At the bottom right of the 'Action Codes' section, it says 'Total: 2'. A 'Close' button is located at the bottom right of the window.


- Click **Action Code** to confirm the replacement procedure.



Note: If **SEE MANUAL** appears under **Location** in the **Alert Detail** window, contact the HDS Portal to have an authorized person make the repair: <https://portal.hds.com>.

Alert Detail

 Contact the Hitachi Data Systems customer support.

Alert ID	24
Date and Time	2014/08/29 02:06:07
Reference Code	627001
Error Level	 Moderate
Error Section	Environment error
Error Detail	UNIT connection error
Location	
Concerned Alerts	

Action Codes

Action Code	Possible Failure Parts	Location
58000000	TROUBLESHOOT SECTION	SEE MANUAL
41040003	Drive	HDD00-03
41800100	CTL	CTL2

Total: 2

Close

8. When the **Recovery Procedure** window appears, check the failed part and order a replacement for that part.

The following window shows an example of a drive failure

Recovery Procedure HITACHI

Drive failure (HDD00-03)

Location	Drive	HDD00-03
	DB	DB-00

Step1 Check the alert part.

Please push the alert part to check that the part is firmly seated. Please DO NOT remove the part and re-insert the same part. Please insert the new replacement part only. If the failure remains, do the following steps.

Step2 Order a replacement part.

To order a replacement part, please access to [support site](#). Then input the following information.

Storage System Type	xxxxxx
Serial number	xxxxxx
Action Code	xxxxxxxx

Step3 Replace the alert part.

After receiving a replacement part, please replace the part according to the LED.
The hardware replacement procedure is [here](#).

Step4 Confirm the failure recovery.

After replacement, confirm the failure recovery. Contact the support center if the failure status persists.

Step5 Send back the failed part.

After recovery confirmation, please send back the failed part according to the document.

[Close](#)

In this example:

- **Drive** = location of the drive in the drive tray.
- **DB** = number of the drive tray.

The following table describes the possible status conditions.

Status	Description
Normal	Normal status.
Warning	A part failed or is being affected by a failure somewhere else in the storage system. The status changes to Normal after the part is replaced.

Failed	A part failed.
Blocked	A part has become blocked. Use the maintenance utility to identify the problem and replace the part if necessary.
Not fix	SFP Status-limited Undetermined status.
Warning (Port n failed)	Drive Status-limited Drive port <i>n</i> is in a failed status.
Copying n % (TYPE to DRIVE)	Drive Status-limited Copying is in progress. <ul style="list-style-type: none"> <i>n</i> = copy-progress rate. <i>TYPE</i>= Correction copy, Copy back, Dynamic sparing, or Drive copy. <i>DRIVE</i> = copy destination drive location. If the drive is a copy destination drive in Correction copy, DRIVE appears as this Drive.) If multiple copy statuses exist, a line break is added to every copy status line, and then the information is displayed.
Copying n % (TYPE from DRIVE)	Drive Status-limited Copying is in progress. <ul style="list-style-type: none"> <i>n</i> = copy-progress rate. <i>TYPE</i> = Copy back, Dynamic sparing, or Drive copy. <i>DRIVE</i> = copy source drive location If multiple copy statuses exist, a line break is added to every copy status line, and then the information is displayed.
Pending (TYPE to DRIVE)	Drive Status-limited Copying is in a suspended status. <ul style="list-style-type: none"> <i>TYPE</i> = Correction copy, Copy back, Dynamic sparing, or Drive copy. <i>DRIVE</i> = copy destination drive location. If the drive is a copy destination drive in Correction copy, DRIVE appears as this Drive.) If multiple copy statuses exist, a line break is added to every copy status line, and then the information is displayed.
Pending (TYPE from DRIVE)	Drive Status-limited Copying is in a suspended status. <ul style="list-style-type: none"> <i>TYPE</i> = Copy back, Dynamic sparing, or Drive copy. <i>DRIVE</i> = copy source drive location If multiple copy statuses exist, a line break is added to every copy status line, and then the information is displayed.

Copy incomplete	Drive Status-limited Data-copy operation is not complete.
Reserved	Drive Status-limited Spare drive has an usable status.

Hardware description

This chapter provides a tour of the storage system hardware.

- ☐ [Storage system controllers](#)
- ☐ [Controller interfaces](#)
- ☐ [Storage system drive trays](#)
- ☐ [Service Processor](#)


Storage system controllers

Every storage system has two controllers. The controllers contain fans and power supplies, and provide the interfaces between a host and the storage system.

A controller manages the I/O between the host system and data volumes.

CBSS controller


CBSS with front panel bezel



Number	Item	Description
1	POWER LED	Green: storage system is powered on. Amber: storage system is receiving power.
2	READY LED	Green: normal operation.
3	WARNING LED	Off: normal operation. Amber: component requires maintenance. Blink: failure requires maintenance. LED might go OFF during user maintenance.
4	ALARM LED	Off: normal operation. Red: processor failure (system may be down). See the HDS Support Portal at https://portal.hds.com
5	POWER ON/OFF (main switch)	Powers the storage system.
6	Lock	Locks and unlocks the front panel bezel using the supplied key.


Note: Removing a controller can cause the POWER, READY, WARNING, and ALARM LEDs on the front panel to go off. These LEDs return to their on state after the storage system recovers from the controller replacement.

CBSS front panel without bezel



Number	Item	Description
1	ACT LED	Green: normal operation. Blink green: drive is being accessed.
2	ALM LED	Red: drive stopped due to a failure and can be removed safely.
3	POWER, READY, WARNING, ALARM LEDs	See previous table.
4	POWER ON/OFF (main switch)	Powers the storage system.
5	Small form factor drives	Twenty-four 2.5-inch small form factor drives oriented vertically. Slots are designated 0-23 ,moving from left to right.

CBSS rear panel




Number	Item	Description
1	Controllers	Controller 1 (left) and Controller 2 (right).
2	Front end module	N/A
3	CTL ALM LED	Red: controller can be removed safely. Blink red: failure with the controller's power supply unit. Amber: LAN reset switch was pressed.
4	BACKUP STTS LED	Green: power restoration in progress following power outage. Fast blink green: restoring. Slow blink green: restoring or sequential shutdown in progress.
5	CTL WARN LED	Amber blink one time: failure with fan 0. Amber blink two times: failure with fan 1.
6	Cache flash memory	N/A
7	LAN-RST switch	Use only when instructed by Hitachi Support.
8	LAN port	Maintenance LAN port (left) and user LAN port (right).
9	Uninterruptible power supply port	N/A
10	ALARM LED (for cache flash memory)	Red: cache flash memory can be removed safely.
11	Backup module	N/A
12	STATUS	Green: charging of the battery in the backup module is complete. Blink green: battery in the backup module is charging or discharging. Red: backup module can be removed safely. Blink red: backup module can be removed safely. Blink red one time: battery failure

Number	Item	Description
		Off: battery is not installed, failure occurred, or firmware is being upgraded.
13	SAS port	N/A
14	Power supply unit	N/A

CBSL controller

CBSL with front panel bezel




Number	Item	Description
1	POWER LED	Green: storage system is powered on. Amber: storage system is receiving power.
2	READY LED	Green: normal operation.
3	WARNING LED	Off: normal operation. Amber: component requires maintenance. Blink: failure requires maintenance. LED might go OFF during user maintenance.
4	ALARM LED	Off: normal operation. Red: processor failure (system may be down). See the HDS Support Portal at https://portal.hds.com
5	POWER ON/OFF (main switch)	Powers the storage system.
6	Lock	Locks and unlocks the front panel bezel using the supplied key.




Note: Removing a controller can cause the POWER, READY, WARNING, and ALARM LEDs on the front panel to go off. These LEDs return to their on state after the storage system recovers from the controller replacement.

CBSL front panel without bezel



Number	Item	Description
1	ACT LED	Green: normal operation. Blink green: drive is being accessed.
2	ALM LED	Red: drive stopped due to a failure and can be removed safely.
3	POWER, READY, WARNING, ALARM LEDs	See previous table.
4	POWER ON/OFF (main switch)	Powers the storage system.
5	Large Form Factor Drives	Twelve 3.5-inch large form factor drives stacked horizontally. Slots are designated the following way: 8 9 10 11 4 5 6 7 0 1 2 3

CBSL rear panel




Number	Item	Description
1	Controllers	Controller 1 (left) and Controller 2 (right).
2	Front end module	N/A
3	CTL ALM LED	Red: controller can be removed safely. Blink red: failure with the controller's power supply unit. Amber: LAN reset switch was pressed.
4	BACKUP STTS LED	Green: power restoration in progress following power outage. Fast blink green: restoring. Slow blink green: restoring or sequential shutdown in progress.
5	CTL WARN LED	Amber blink one time: failure with fan 0. Amber blink two times: failure with fan 1.
6	Cache flash memory	N/A
7	LAN-RST switch	Use only when instructed by Hitachi Support.
8	LAN port	Maintenance LAN port (left) and user LAN port (right).
9	Uninterruptible power supply port	N/A
10	ALARM LED (for cache flash memory)	Red: cache flash memory can be removed safely.
11	Backup module	N/A

Number	Item	Description
12	STATUS	<p>Green: charging of the battery in the backup module is complete.</p> <p>Blink green: battery in the backup module is charging or discharging.</p> <p>Red: backup module can be removed safely.</p> <p>Blink red: backup module can be removed safely.</p> <p>Blink red one time: battery failure</p> <p>Off: battery is not installed, failure occurred, or firmware is being upgraded.</p>
13	SAS port	N/A
14	Power supply unit	N/A

CBLM controller

CBLM with front panel bezel




Number	Item	Description
1	POWER LED	<p>Green: storage system is powered on.</p> <p>Amber: storage system is receiving power.</p>
2	READY LED	Green: normal operation.

Number	Item	Description
3	WARNING LED	Off: normal operation. Amber: component requires maintenance. Blink: failure requires maintenance. LED might go OFF during user maintenance.
4	ALARM LED	Off: normal operation. Red: processor failure (system may be down). See the HDS Support Portal at https://portal.hds.com
5	POWER ON/OFF (main switch)	Powers the storage system.
6	Lock	Locks and unlocks the front panel bezel using the supplied key.



Note: Removing a controller can cause the POWER, READY, WARNING, and ALARM LEDs on the front panel to go off. These LEDs return to their on state after the storage system recovers from the controller replacement.


CBLM front panel without bezel



Number	Item	Description
1	POWER ON/OFF (main switch)	Powers the storage system.
2	POWER, READY, WARNING, ALARM LEDs	See previous table.

Number	Item	Description
3	Controllers	Controller 1 (top) and Controller 2 (bottom).
4	Backup module	N/A
5	BACKUP	Green: power restoration in progress following power outage. Fast blink green: restoring. Slow blink green: restoring or sequential shutdown in progress.
6	Cache flash memory	N/A
7	ALM LED (for cache flash memory)	Red: cache flash memory can be removed safely.
8	CTL ALM LED	Red: controller can be removed safely. Blink red: failure with the controller's power supply unit. Amber: LAN reset switch was pressed.
9	LAN-RST switch	Use only when instructed by Hitachi Support.
10	STATUS LED (for BKMF)	Green: charging of the battery in the backup module is complete. Red: backup module can be removed safely. Blink red one time: main battery failure. Blink red two times: backup battery failure. Blink red three times: both batteries failed or preventive maintenance replacement of batteries can be performed. Off: battery is not mounted, battery-mounting failure occurred, or firmware is being upgraded. Off is normal status for configurations with no batteries (for example, BKMF-10 and BKMF-20).

CBLM rear panel




Number	Item
1	Power supply unit
2	Front end module
3	Back end module
4	LAN blade

Controller interfaces

Controllers provide interfaces for connecting, powering, and configuring and managing the storage system. They also have LEDs to show the status of the storage system.


Front end module descriptions

8 Gbps Fibre Channel board LEDs and connectors




Number	Item	Description
1	Fibre Channel connectors	Connect to Fibre Channel cables.
2	STATUS LED	Green: front end module is in power-on state. Red: front end module can be removed safely.
3	PORT LED	Red: small form-factor pluggable can be removed safely. Blue: normal link status at 8 Gbps. Green: normal link status at 2 Gbps or 4 Gbps.

16 Gbps Fibre Channel board LEDs and connectors



Number	Item	Description
1	STATUS LED	Green: front end module is in the power-on state. Red: front end module can be removed safely.
2	PORT LED	Red: small form-factor pluggable can be removed safely. Blue: normal link status at 16 Gbps. Green: normal link status at 4 or 8 Gbps.
3	Fibre Channel connectors	Connect to Fibre Channel cables.


10 Gbps iSCSI board LEDs and connectors




Number	Item	Description
1	STATUS LED	Green: front end module is in the power-on state. Red: front end module can be removed safely.
2	PORT LED	Red: small form-factor pluggable can be removed safely. Blue: normal link status.

Number	Item	Description
		Blink blue: front end module is in communication status.
3	iSCSI connectors	Connect to Ethernet LAN cables.

Back end module LEDs and connectors




Number	Item	Description
1	PATH 1 connector	Connect to a drive tray.
2	PORT LED	Blue: normal link status.



Number	Item	Description
1	STATUS LED	Green: back end module is in the power-on state. Red: back end module can be removed safely.


Number	Item	Description
2	Port LED	Blue: link status is normal.
3	PATH 0 connector	Connect to a drive tray.
4	PATH 1 connector	Connects to a drive tray.

Power supply unit LEDs and connectors



Number	LED or connector	Description
1	Receptacle	Connect to the power cable supplied with the storage system.
2	AC IN LED	Blue: AC input is normal.
3	ALM/RDY LED	Red: power supply unit can be removed safely. Green: normal operation.

Power supply unit LEDs and connectors




Number	Item	Description
1	ALM/RDY LED	Red: power supply unit can be removed safely.
2	Receptacle	Connect to the power cable supplied with the storage system.
3	RDY LED	Green: normal operation.

Storage system drive trays

Drive trays contain drives, power supplies, fans, and status LEDs. They also provide interfaces for connecting to controllers and other drive trays.


Small form factor (SFF) drive tray

SFF with front panel bezel




Number	Item	Description
1	POWER LED	Green: Drive tray is powered on.
2	READY LED	Green: Drive tray is operational.
3	LOCATE LED	Amber: Nonfatal error. Storage system can remain operating. This LED can also go ON to identify the drive tray being added.
4	Lock	Locks and unlocks the front panel bezel using the supplied key.

SFF front panel without bezel



Number	Item	Description
1	ACT LED	Green: normal operation. Blink green: drive is being accessed.
2	ALM LED	Red: drive stopped due to a failure and can be removed safely.
3	POWER, READY, LOCATE LEDs	See previous table.
4	Small form factor drives	Twenty-four 2.5-inch small form factor drives oriented vertically. Slots are designated 0-23 ,moving from left to right.


SFF rear panel



Number	Item	Description
1	ENC	N/A
2	POWER LED	Green: ENC is in the power-on state.
3	LOCATE LED	Amber: Shows the ENC when adding drive trays.
4	ALARM LED	Red: ENC can be removed safely.
5	PATH (IN) LED	Blue: IN side port is linked up.
6	PATH (IN) connector	Connect to a controller or drive tray.
7	PATH (OUT) LED	Blue: OUT side port is linked up.
8	PATH (OUT) connector	Connect to a drive tray.
9	Console	This port is reserved.
10	Power supply unit	N/A
11	Receptacle	Connect to the power cable supplied with the storage system.
12	AC IN LED	Green: normal operation.
13	ALM LED	Red: power supply unit can be removed safely.
14	RDY LED	Green: normal operation.

Large form factor (LFF) drive tray


LFF with front panel bezel



Number	Item	Description
1	POWER LED	Green: Drive tray is powered on.


Number	Item	Description
2	READY LED	Green: Drive tray is operational.
3	LOCATE LED	Amber: Nonfatal error. Storage system can remain operating. This LED can also go ON to identify the drive tray being added.
4	Lock	Locks and unlocks the front panel bezel using the supplied key.

LFF front panel without bezel



Number	Item	Description
1	POWER, READY, LOCATE LEDs	See previous table.
2	ACT LED	Green: normal operation. Blink green: drive is being accessed.
3	ACT LED	Red: drive stopped due to a failure and can be removed safely.
4	Large Form Factor Drives	Twelve 3.5-inch large form factor drives stacked horizontally. Slots are designated the following way: <div style="display: flex; justify-content: space-around; margin-top: 10px;"> 891011 </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> 4567 </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> 0123 </div>


LFF rear panel



Number	Item	Description
1	ENC	N/A
2	POWER LED	Green: ENC is in the power-on state.
3	LOCATE LED	Amber: Shows the ENC when adding drive trays.
4	ALARM LED	Red: ENC can be removed safely.
5	PATH (IN) LED	Blue: IN side port is linked up.
6	PATH (IN) connector	Connect to a controller or drive tray.
7	PATH (OUT) LED	Blue: OUT side port is linked up.
8	PATH (OUT) connector	Connect to a drive tray.
9	Console	This port is reserved.
10	Power supply unit	N/A
11	Receptacle	Connect to the power cable supplied with the storage system.
12	AC IN LED	Green: normal operation.
13	ALM LED	Red: power supply unit can be removed safely.
14	RDY LED	Green: normal operation.


Flash module drive (FMD) tray

FMD with front panel bezel




Number	Item	Description
1	POWER LED	Green: Drive tray is powered on.
2	READY LED	Green: Drive tray is operational.
3	LOCATE LED	Amber: can be forced on using the maintenance utility when adding drive trays.
4	Lock	Locks and unlocks the front panel bezel using the supplied key.

FMD front panel without bezel



Number	Item	Description
1	ACT LED	Green: normal operation. Blink green: drive is being accessed.
2	ALM LED	Red: drive stopped due to a failure and can be removed safely.
3	POWER, READY, LOCATE LEDs	See previous table.
4	Flash module drives	Twelve flash module drives. Slots are designated the following way: 9, 10, 11 6, 7, 8 3, 4, 5 0, 1, 2

FMD rear panel




Number	Item	Description
1	ENC	N/A
2	POWER LED	Green: ENC is in the power-on state.
3	LOCATE LED	Amber: Shows the ENC when adding drive trays.
4	ALARM LED	Red: ENC can be removed safely.
5	PATH (IN) LED	Blue: IN side port is linked up.
6	PATH (IN) connector	Connect to a controller or drive tray.

Number	Item	Description
7	PATH (OUT) LED	Blue: OUT side port is linked up.
8	PATH (OUT) connector	Connect to a drive tray.
9	Console	This port is reserved.
10	Receptacle	Connect to the power cable supplied with the storage system.


Dense intermix drive tray

Dense intermix drive tray with front panel bezel



Number	Item	Description
1	POWER LED	Green: Drive tray is powered on.
2	READY LED	Green: Drive tray is operational.
3	LOCATE LED	Amber: Nonfatal error. Storage system can remain operating. This LED can also go ON to identify the drive tray being added.
4	Lock	Locks and unlocks the front panel bezel using the supplied key.

Dense intermix drive tray display LEDs




Number	Item	Description
1	ACT	Green: normal operation. Blink green: drive is being accessed.
2	ALM LED	Red: drive stopped due to a failure and can be removed safely.



Note: Drives are organized as follows, starting from the rear of the drive tray and moving left to right. In the above figure on the left, the rear of the drive tray is at the top.

- Rear of drive tray: 48 - 59
- 36 - 47
- 24 - 35
- 12 - 23
- Front of drive tray: 00 - 11

Dense intermix drive tray rear panel



Number	Item	Description
1	Power supply unit	N/A
2	RDY LED	Green: normal operation.
3	AC IN LED	Green: normal operation.
4	ALM LED	Red: power supply unit can be removed safely.
5	Receptacle	Connect to the power cable supplied with the storage system.
6	ENC	N/A
7	PATH (OUT) LED	Blue: OUT side port is linked up.
8	PATH (OUT) connector	Connect to a drive tray.
9	PATH (IN) LED	Blue: IN side port is linked up.
10	PATH (IN) connector	Connect to a controller or drive tray.
11	Console	This port is reserved.
12	ALARM LED	Red: ENC can be removed safely.
13	LOCATE LED	Amber: Shows the ENC when adding drive trays.
14	POWER LED	Green: ENC is in the power-on state.

Service Processor

Storage systems come with a separate, dedicated 1U service processor (SVP) on which element manager runs. The SVP (model number 3919435.P) operates independently from the storage system's CPU and operating system,

and provides out-of-band configuration and management of the storage system. It also collects performance data for key components of the storage system to enable diagnostic testing and analysis.



Note: This product is also designed for IT power distribution systems with phase-to-phase voltage.

The SVP runs Microsoft Windows Embedded Standard 7. This operating system provides the same look and feel and desktop environment as Microsoft Windows 7 Professional.

The SVP provides four RJ-45 ports:

- Two ports connect to the storage system controllers (one port for each controller).
- One port connects to the user's IP network.
- One port connects to a user-supplied management console PC.


Three of the four RJ-45 ports (the ones that connect to the controllers and the IP network) are configured as a bridge. The SVP can be addressed using the default IP address 192.168.0.15.

Users are responsible for adopting the appropriate security procedures with the SVP, including:

- Applying Windows security patches.
- Turning on automatic Windows updates or using the manual Windows update method.
- Installing antivirus software that has been tested and approved by Hitachi.
- Installing the latest SVP firmware releases from Hitachi.

SVP front panel

The SVP front panel has LEDs, a reset button, and a power button.




Number	Description
1	LEDs. From left to right, the LEDs are:

Number	Description
	<ul style="list-style-type: none"> BMC Heartbeat LAN card 2 LAN card 1 Hard drive System standby power
2	Reset button.
3	Power button. Applies power to or removes power from the SVP.

SVP rear panel

The only ports used on the rear panel of the SVP are the power socket and the four LAN ports.



Number	Description
1	Power socket. Attach the power cable supplied with the SVP.
2	<p>Four LAN ports arranged as follows:</p> <p>LAN3 LAN4</p> <p>LAN1 LAN2</p> <p>These ports connect to your IP network, the management console PC, and the user LAN port on each storage system controller.</p>

Replacing components

This chapter describes the steps to take before replacing a component. It also describes how to check that the system has recovered after replacing components.

- ☐ [Electrostatic discharge precautions](#)
- ☐ [Unpacking replacement components](#)
- ☐ [Follow appropriate power on and power off work procedures](#)
- ☐ [Safety considerations](#)
- ☐ [Guidelines to follow when replacing a component](#)
- ☐ [Guidelines to follow after replacing a component](#)
- ☐ [Starting the maintenance utility](#)
- ☐ [Replacement parts](#)
- ☐ [Removing and replacing the front bezel](#)
- ☐ [Checking recovery after replacing components](#)

Electrostatic discharge precautions

Static electricity can damage the storage system's static-sensitive components. To prevent damage, follow these precautions:

When performing the service procedures in this document, observe the following electrostatic discharge (ESD) precautions:

- Wear an antistatic wrist strap at all times when handling any field-replaceable unit (FRU). Clip the end of the wrist strap to exposed metal on frame. For convenience, a wrist strap is supplied with the storage system. Do not remove the wrist strap until the removal or replacement procedure has been completed.
- Before handling any FRU, discharge any static electricity by touching a grounded surface. Grounded surfaces include static-dissipating mats (already grounded) or grounded workstations.
- Remove all plastic, vinyl, and foam material from the work area.
- Do not remove a FRU from its antistatic protective bag until you are ready to install it.
- Handle any card FRU only by its edges and avoid touching the components or circuitry.
- Do not slide a FRU over any surface.
- Limit body movement (which builds up static electricity) during the removal and replacement of a FRU.
- To avoid electric shock when performing a "hot replacement" of a part, do not wear metallic accessories or a watch and avoid touching "live" parts of the storage system with a screwdriver or similar tools.

Unpacking replacement components

Unpack replacement components in a dry location that is not exposed to moisture, direct sunlight, dust, and temperature extremes. If the part to be added has been exposed to high or low temperature during transport, the part might not operate properly.

Follow appropriate power on and power off work procedures

If a replacement procedure requires power off and power on steps, follow the steps carefully to ensure the security of data.

After powering off the storage system, remove the power cables from the two power supply units on the storage system.

Safety considerations

Observe the following guidelines to ensure safety when replacing parts. Failure to follow these guidelines could result in bodily injury or damage to the chassis or components.

- Use the host to back up user data on the storage system before replacing components.
- When performing any installation, comply with all local health and safety requirements.
- Wear protective footwear when moving storage system hardware.
- Do not wear loose clothing that could get caught in the chassis or mounting hardware. Fasten ties and scarves and roll up sleeves.
- Wear safety glasses when working under conditions that are hazardous to your eyes.
- Keep walkways clear of tools, cables, and parts to prevent them from being stepped on or causing people to trip and fall.
- Do not work on the equipment or disconnect cables during a thunderstorm, when wearing a wool sweater or other heavy wool clothing, or when power is applied.
- Always turn off the storage system and unplug all data and power cables before lifting the storage system.
- Keep floors dry to prevent slips and falls.
- Do not use ungrounded power cables.
- Use only the power cables supplied with this product. Do not use power cables from other products. Otherwise, unexpected failures or accidents can occur.
- If you encounter unusual odors, heat generation, or smoke emission, shut off power to the equipment and inform the appropriate personnel. Leaving such conditions unattended can cause electric shock or fire.
- Keep the area clean and dust-free when replacing components.
- Do not block or cover the openings of the storage system hardware. Never place a unit near a radiator or heat register. Failure to follow these guidelines can cause overheating and affect the unit's reliability.
- After a component has been replaced, secure the chassis cover to the storage system. The chassis is designed to let cooling air flow effectively within it. An open chassis allows air leaks that might interrupt and redirect the flow of cooling air from internal components.
- Do not make mechanical or electrical modifications or repairs to the equipment. Such actions can cause an electric shock or cause the storage system to malfunction. Hitachi is not responsible for regulatory compliance of a modified Hitachi product.
- When removing cables, hold the cable connector and leave enough slack in the cables, so they do not bend to a diameter of less than 76 mm (3") or a

radius less than 38 mm (1.5") when extended and do not become pinched when retracted.

Guidelines to follow when replacing a component

Observe the following guidelines when replacing a component.

- Use only the replacement parts specified in this guide.
- Do not perform maintenance when the storage system is being started. Wait for the **READY** LED on the controller to go on before performing maintenance.
- If you replace a drive, controller, cache memory, front end module, backup module, back end module, ENC, fan, or power supply unit while the storage system power is turned on:
 - Wait at least 20 seconds after the failed part was removed before installing the new part.
 - Complete the replacement within 10 minutes. Otherwise, the system might power off due to an abnormal rise in temperature.

If a power supply unit and another component fail at the same time, replace the power supply unit first, and then replace the other failed component. Otherwise, the system might power off due to an abnormal rise in temperature.

- If a fan on the controller fails at the same time when another component fails, replace the fan first, and then replace the other failed component. Otherwise, the system might power off due to an abnormal rise in temperature.
- Insert replacement parts quickly. Otherwise, the recovery might fail.
- If only the main switch power is off, power is provided by the basic supply. Do not leave components removed from the storage system for long periods of time, as this can trigger a power supply alarm.
- If the replacement part has a cover over one or more connectors, replace the cover of the connector part that is going to be used.

Guidelines to follow after replacing a component

Observe the following guidelines after replacing a component in the Hitachi storage system.

- When restarting the storage system, wait for the amber **POWER** LED to go ON, and then turn off the main switch. Wait at least one minute before turning on the main switch.
- After you replace components, close all the external storage system covers.


Starting the maintenance utility

You can start the maintenance utility from Hitachi Command Suite or Hitachi Device Manager - Storage Navigator.

Starting the maintenance utility from Hitachi Command Suite


Procedure

1. Start Hitachi Command Suite.



2. In the **Hitachi Command Suite** main window, click the **Resources** tab, and then click **Storage Systems** from the tree view.
3. Expand the tree, and then right-click a storage system and click **Other Functions**.

4. In Hitachi Device Manager - Storage Navigator, click the **Maintenance Utility** menu, and then click **Hardware** to start the maintenance utility.



Starting the maintenance utility from Hitachi Device Manager - Storage Navigator

Procedure

1. Launch a web browser from the console PC connected to the SVP, and then start Device Manager - Storage Navigator.
2. Enter the following URL in the address field of your browser, and then press the Enter key: `http://[IP address of SVP]/module/sn2/0/index.do`
3. In the **Storage Device List** window, click the picture of the registered storage system.
4. Log in to Device Manager - Storage Navigator.

- On the **Maintenance Utility** menu, click **Hardware > Other hardware maintenance** to start the maintenance utility.

The screenshot shows the Hitachi Device Manager Storage Navigator interface. The 'Maintenance Utility' menu is open, showing options like 'Auto maintenance requiring CTL2 blockage', 'HUB reset for CTL1...', 'HUB reset for CTL2...', and 'Other hardware maintenance...'. The 'Allocation Summary' section displays a pie chart and a table of storage allocation details.

Physical Summary		Virtual Summary	
Physical Capacity	60.00 GB	Virtual Capacity	1.67 Tb
Used DP Pool	15.83 GB (26%)	DP Allocated	10.00 GB
Unused DP Pool	0.00 MB (0%)	DP Unallocated	10.00 GB
Other	4.16 GB (7%)	Other	0.00 MB
Available Space	60.00 GB (26%)	Virtual Total	20.00 GB
Free Space	1.53 Tb (92%)		



Note: If a message reports a problem with the website's security, click **Continue to this website (not recommended)**.

The screenshot shows the Maintenance Utility interface for a Hitachi storage system. The 'Storage System' section displays 'S/N: 400001' and 'CTL2'. The 'Hardware' section shows 'Controller Chassis' and 'Drive Box - 00', 'Drive Box - 01', 'Drive Box - 02', and 'Drive Box - 03'. The 'Administration' section shows 'Menu' with options like 'Initial Setup Wizard', 'Power Management', and 'System Management'. The 'Set up System Information' section displays system details like 'Storage System Name', 'Contact', 'Location', 'Storage System Type', 'Serial Number', 'Temperature', and 'Number of Drives'.

Set up System Information	
Storage System Name	StorageSystem
Contact	03-xxxx-xxxx
Location	Tokyoxxxx
Storage System Type	HM800M
Serial Number	400001
Temperature	25 degree C
Number of Drives	74
Spare	8
Free	9
Total	91

Replacement parts

The following table lists information about replacement parts for Hitachi Virtual Storage Platform storage systems. If a replacement part is valid for certain models only, those models are shown in parentheses.

Part name	Part number	Model	Status of host and storage system	
			I/O from the host	No I/O from the host
200-GB, MLC, 12-Gbps, 2.5-inch flash drive	5559263-A	DKC-F810I-200MEM	YES	YES
300-GB, 15kmin ⁻¹ , 6-Gbps, SAS, 2.5-inch (contains BNST)	5552785-A	DKC-F810I-300KCM	YES	YES
300-GB, 15kmin ⁻¹ , 6-Gbps, SAS, 2.5-inch	5552785-P	DKC-F810I-300KCMC	YES	YES
400-GB, MLC, 12-Gbps,, 2.5-inch flash drive	5559016-A	DKC-F810I-400MEM	YES	YES
600-GB, 10kmin ⁻¹ , 6-Gbps, SAS, 2.5-inch (contains BNST)	5552786-A	DKC-F810I-600JCM	YES	YES
600-GB, 10kmin ⁻¹ , 6-Gbps, SAS, 2.5-inch	5552786-P	DKC-F810I-600JCMC	YES	YES
600-GB, 15kmin ⁻¹ , 12-Gbps, SAS, 2.5-inch	5559498-A	DKC-F810I-600KGM	YES	YES
1.2-TB, 10kmin ⁻¹ , 6-Gbps, SAS, 2.5-inch (contains BNST)	5552789-A	DKC-F810I-1R2JCMC	YES	YES
1.2-TB, 10kmin ⁻¹ , 6-Gbps, SAS, 2.5-inch	5552789-P	DKC-F810I-1R2JCMC	YES	YES
400-GB, MLC, 12-Gbps, 3.5-inch flash drive	5559090-A	DKC-F810I-400M6M	YES	YES
1.2-TB, 10kmin ⁻¹ , 6-Gbps, SAS, 3.5-inch (contains BNST)	5559116-A	DKC-F810I-1R2J5M	YES	YES
1.2-TB, 10kmin ⁻¹ , 6-Gbps, SAS, 3.5-inch	5559116-P	DKC-F810I-1R2J5MC	YES	YES
4-TB, 7200min ⁻¹ , 6-Gbps, SAS7.2K, 3.5-inch (contains BNST)	5552784-A	DKC-F810I-4R0H3M	YES	YES
4-TB, 7200min ⁻¹ , 6-Gbps, SAS7.2K, 3.5-inch	5552784-P	DKC-F810I-4R0H3MC	YES	YES

Part name	Part number	Model	Status of host and storage system	
			I/O from the host	No I/O from the host
6-TB, 7200min ⁻¹ , 12-Gbps, SAS7.2K, 3.5-inch	5560075-A	DKC-F810I-6R0H9M	YES	YES
Battery (VSP G400, G600)				
CBLM and CBLH	3289081-A	DW-F800-BAT	YES	YES
Fan			YES	YES
CBSS and CBSL	3290738-A	N/A	YES	YES
Power Supply Unit				
CBSS and CBSL	3290737-A	N/A	YES	YES
CBLM and CBLH	3289056-A	N/A	YES	YES
DW-F800-DBS and DW-F800-DBL (contains BNST)	3290647-A	N/A	YES	YES
DW-F800-DBSC and DW-F800-DBLC	3290647-P			
FMD drive tray	3286659-A	N/A	YES	YES
Controller				
CBSS and CBSL	3290733-A	DW-F800-CTLS	YES	YES
CBLM	3289039-A	DW-F800-CTLM	YES	YES
Cache Memory				
8 GB	3290718-A	DKC-F810I-CM8G	YES	YES
16 GB	5552764-A	DKC-F810I-CM16G	YES	YES
Front End Modules				
8 Gbps Fibre Channel	3289046-A	DW-F800-4HF8	YES	YES
16 Gbps Fibre Channel	3289047-A	DW-F800-2HF16	YES	YES
10 Gbps SFP iSCSI	3289048-A	DW-F800-2HS10S	YES	YES
Small Form Factor Pluggable				
Optical module (8 Gbps LongWave)	5556750-A	DKC-F810I-1PL8	YES	YES
Optical module (8 Gbps ShortWave)	5557409-A	DKC-F810I-1PS8	YES	YES
Optical module (16 Gbps LongWave)	5552782-A	DKC-F810I-1PL16	YES	YES

Part name	Part number	Model	Status of host and storage system	
			I/O from the host	No I/O from the host
Optical module (16 Gbps ShortWave)	5552781-A	DKC-F810I-1PS16	YES	YES
Disk Board				
CBLM and CBLH	3289045-A	DW-F800-BS12G	YES	YES
	3289094-A	DW-F800-BS12GE	YES	YES
ENC				
SFF and LFF drive trays	3290646-A	N/A	YES	YES
FMD drive tray	3286658-A	N/A	YES	YES
SAS Cables				
1 m SAS cable including two omega clips	3290630-A	DW-F800-SCQ1	YES	YES
1.5 m SAS cable including two omega clips	3290631-A	DW-F800-SCQ1F	YES	YES
3 m SAS cable including two omega clips	3290632-A	DW-F800-SCQ3	YES	YES
5 m SAS cable including two omega clips	3290633-A	DW-F800-SCQ5	YES	YES
10 m SAS optical cable	3290666-A	DW-F800-SCQ10A	YES	YES
30 m SAS optical cable	3290667-A	DW-F800-SCQ30A	YES	YES
100 m SAS optical cable	3290723-A	DW-F800-SCQ1HA	YES	YES
Cache Flash Memory (CFM)				
CFM (VSP G200)	3290736-A	DW-F800-BM10	YES	YES
CFM	3289043-A	DW-F800-BM20	YES	YES
CFM	3289043-B	DW-F800-BM30	YES	YES
LAN Blade				
LAN Board (VSP G400, 600, and 800)	3289044-A	N/A	YES	YES
Backup Module (BKM)				
CBSS and CBSL	3290735-A	N/A	YES	YES
CBLM and CBLH	3289036-A	N/A	YES	YES
SVP				

Part name	Part number	Model	Status of host and storage system	
			I/O from the host	No I/O from the host
Service Processor	3919435.P	N/A	YES	YES

Removing and replacing the front bezel

To gain access to a storage system, remove the front bezel. After replacing the component, replace the front bezel.


Removing the front bezel from a DBS or DBL drive tray

Procedure

1. Use the supplied key to unlock the bezel.
2. Holding the lower right part of the bezel, gently pull the key toward you and disengage the right side of the bezel from the ball catch.



Note: When disengaging the front bezel, do not open the bezel more than 45 degrees; otherwise, you can damage the bezel.



3. Disengage the front bezel from the left tabs and then remove the bezel.


Replacing the front bezel for a CBSS or CBSL controller

To replace the front bezel:


Procedure

1. Use the supplied key to unlock the front bezel. Hold the key and the bottom of the bezel with both hands, so the front of the bezel is facing you.
2. Insert the tabs on the left-front side of the storage system into the tab holes on the front bezel.
3. Push the right side of the bezel until it engages with the ball catch on the front of the storage system to secure the bezel.

4. Use the supplied key to lock the front bezel.



Before turning the key, be sure it is inserted completely into the lock. Otherwise, you can damage the key.



When removing the key after locking the front bezel, align its groove with the positioning mark on the lock. Otherwise, you can damage the lock.

Removing the front bezel from SFF, LFF, and FMD drive trays


Procedure

1. Use the supplied key to unlock the bezel.

2. Holding the lower right part of the bezel, gently pull the key toward you and disengage the right side of the bezel from the ball catch.



Note: When disengaging the front bezel, do not open the bezel more than 45 degrees; otherwise, you can damage the bezel.



3. Disengage the front bezel from the left tabs and then remove the bezel.


Replacing the front bezel from a SFF, LFF, or FMD drive tray

To replace the front bezel:


Procedure

1. Use the supplied key to unlock the front bezel. Hold the key and the bottom of the bezel with both hands, so the front of the bezel is facing you.
2. Insert the tabs on the left-front side of the storage system into the tab holes on the front bezel.
3. Push the right side of the bezel until it engages with the ball catch on the front of the storage system to secure the bezel.

4. Use the supplied key to lock the front bezel.



Before turning the key, be sure it is inserted completely into the lock. Otherwise, you can damage the key.



When removing the key after locking the front bezel, align its groove with the positioning mark on the lock. Otherwise, you can damage the lock.

Remove the front bezel from a CBLM or CBLH controller


Procedure

1. Use the supplied key to unlock the bezel.

2. Holding the lower right part of the bezel, gently pull the key toward you and disengage the right side of the bezel from the ball catch.



Note: When disengaging the front bezel, do not open the bezel more than 45 degrees; otherwise, you can damage the bezel.



3. Disengage the front bezel from the left tabs and then remove the bezel.


Replacing the front bezel

To replace the front bezel:

Procedure

1. Use the supplied key to unlock the front bezel. Hold the bottom of the bezel with both hands, so the front of the bezel is facing you.
2. Insert the tabs on the left-front side of the storage system into the tab holes on the front bezel.
3. Push the right side of the bezel until it engages with the ball catch on the front of the storage system to secure the bezel.

4. Use the supplied key to lock the bezel.
Before turning the key, be sure it is inserted completely into the lock. Otherwise, you can damage the key.




When removing the key after locking the front bezel, align its groove with the positioning mark on the lock. Otherwise, you can damage the lock.

Attaching the front bezel to a dense intermix drive tray

Procedure

1. Use the supplied key to unlock the front bezel.
Hold the key and the bottom of the bezel with both hands, so the front of the bezel is facing you.
2. Insert the tabs on the left-front side of the storage system into the tab holes on the front bezel.
3. Push the right side of the bezel until it engages with the ball catch on the front of the storage system to secure the bezel.
4. Use the supplied key to lock the front bezel.
Before turning the key, verify that it is inserted completely into the lock. Otherwise, you can damage the key.
5. Remove the key from the lock.
Align the groove of the key with the positioning mark on the lock. Otherwise, you can damage the lock.



Removing the front bezel from a dense intermix drive tray

To prevent the rack from tipping when removing a dense intermix drive tray:

- Do not remove multiple dense intermix drive trays at one time.
- After removing the dense intermix drive tray, do not place objects on it or use it as working space.


To remove the front bezel from the dense intermix drive tray:

Procedure

1. Use the supplied key to unlock the bezel.
2. Holding the lower right part of the bezel, gently pull the key toward you and disengage the right side of the bezel from the ball catch.



Note: When disengaging the front bezel, do not open the bezel more than 45 degrees; otherwise, you can damage the bezel.



3. Disengage the front bezel from the left tabs and then remove the bezel.

Checking recovery after replacing components

After you replace one or more components, check to verify that the storage system has recovered.

Procedure

1. In the **Maintenance Utility** window, click **Refresh**.
2. Confirm that the status of the replaced components is `Normal`.

Replacing a drive


Before replacing a drive, read the precautions and understand the procedure for your drive type.

- ☐ [Checking a drive](#)
- ☐ [Blocking the drive](#)
- ☐ [Replacing a drive for a CBSS or SFF drive tray](#)
- ☐ [Replacing a drive for a CBSL or LFF drive tray](#)
- ☐ [Replacing a drive for a flash module drive tray](#)
- ☐ [Replacing a drive for the dense intermix drive tray](#)
- ☐ [Checking the drive status](#)

Checking a drive

Procedure

1. Start the maintenance utility.
2. Click **Hardware > Controller Chassis** or **Hardware > Drive Box**.
3. Click the **Drives** tab.
4. Confirm that the status of the drive to be replaced is Warning, Failed, Blocked, Copy incomplete, or Reserved.



5. Click **Refresh**.
6. If the red ALM LED on the failed drive is off:
 - In the **Drives** tab, check which drive is blocked, and then click **Block** in the **Block Drives** window.
 - When prompted about whether you want to perform sparing, click **Yes**.
 - Remove the front bezel and confirm the number of the slot in which the failed drive is installed.
 - Click **Close**.
 - Replace the drive.
7. If the red ALM LED on the failed drive is on:
 - Remove the front bezel and confirm the number of the slot in which the failed drive is installed.

- Replace the drive.


Blocking the drive

Prerequisites


Check the drive in the maintenance utility.

Procedure

1. Select the drive to be replaced, and then click **Block**.
2. When the **Block Drives** window appears, confirm that the drive shown in the window is the one to be replaced, and then click **Block**.



3. If the following warning appears, click **Yes**.



4. Confirm that the drive is blocked, and then click **Close**.

Replacing a drive for a CBSS or SFF drive tray

Facing the front of the chassis, drive numbering in a chassis is #0 to #23, from left to right.

Prerequisites


- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- The red **ALM** LED for the drive to be replaced is on.

Procedure

1. Remove the front bezel.
2. Pull up the stopper of the drive handle toward you to release the lock.
3. Open the handle toward you, and then gently remove the drive to be replaced.
Handle the drive with care.
4. Place the drive into the guide rail and slide it gently in the direction of the arrow.
5. Push the lower part of the drive until it reaches the position where the hook on the handle engages with the square hole on the frame.

6. Raise the stopper, which is tilted toward you, and then press the stopper to disengage the lock.

If the handle is raised so the hook of the handle cannot enter into each hole, the drive cannot be installed properly because it is blocked by the frame of the storage system.



7. Gently pull the handle of the drive toward you to make sure the drive is installed securely.
8. Confirm that the red **ALM** LED is off at the new drive.
9. In the maintenance utility, click **Hardware > Controller Chassis** or **Hardware > Drive Box**.
10. Click the **Drives** tab.
11. Confirm that the status of the drive to be replaced is **Normal**.
If necessary, click **Refresh** at the top-right of the window to update the status in the window.
12. Attach the front bezel.

Replacing a drive for a CBSL or LFF drive tray

Facing the front of the chassis, drive numbering in the chassis is #0 to #11, from the bottom left to the top right.

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.

- The red **ALM** LED for the drive to be replaced is on.


Procedure

1. Remove the front bezel.
2. Pull up the stopper of the drive handle toward you to release the lock.
3. Open the handle toward you, and then gently remove the drive to be replaced.

Handle the drive with care.

4. Place the drive into the guide rail and slide it gently in the direction of the arrow.
5. Push the lower part of the drive until it reaches the position where the hook on the handle engages with the square hole on the frame.
6. Pull the stopper lightly, close the handle, and then press the stopper to engage the lock.

If the hook of the handle cannot enter the square hole, the drive cannot be installed properly because it gets blocked by the frame of the storage system.



7. In the maintenance utility, click **Hardware > Controller Chassis** or **Hardware > Drive Box**.
8. Click the **Drives** tab.
9. Confirm that the status of the drive to be replaced is **Normal**.
If necessary, click **Refresh** at the top-right of the window to update the status in the window.
10. Confirm that the red **ALM** LED is off at the new drive.
11. Attach the front bezel.

Replacing a drive for a flash module drive tray

Drive replacement for this drive tray is not supported.

Replacing a drive for the dense intermix drive tray

Facing the front of the chassis, drive numbering is #0 to #59, from the bottom left to the top right.

When dealing with a dense intermix drive tray:

- Be mindful of other workers nearby.
- Exercise care when removing or storing the dense intermix drive tray.
- Do not pull out multiple dense intermix drive trays at one time because the rack can fall over.
- Do not put objects on a dense intermix drive tray you removed from the rack.
- Do not use the dense intermix drive tray as working space because the rack can fall over.


Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- The red **ALM** LED for the drive to be replaced is on.

Procedure

1. Remove the dense intermix drive tray from the rack and remove the top cover and bezel.
2. Pull up the stopper of the drive handle toward you to release the lock.
3. Open the handle toward you, and then gently remove the drive to be replaced.
Handle the drive with care.
4. Place the drive into the guide rail and slide it gently in the direction of the arrow.

5. Push the drive until a click indicates it has locked in place.



6. In the maintenance utility, click **Hardware > Controller Chassis** or **Hardware > Drive Box**.
7. Click the **Drives** tab.
8. Confirm that the status of the drive to be replaced is *Normal*.
If necessary, click **Refresh** at the top-right of the window to update the status in the window.
9. Confirm that the red *ALM* LED is off at the new drive.
10. Attach the front bezel, and then replace the dense intermix drive tray in the rack.

Checking the drive status

Procedure

1. In the maintenance utility, click **Hardware > Controller Chassis** or **Hardware > Drive Box**.
2. Click the **Drives** tab.
3. Confirm that the status of the replacement drive is **Normal**.
Observe the following guidelines:
 - If you replaced a drive without blocking it, click **Refresh** at the top-right of the **Maintenance Utility** window to update the window, and then check the status of the replaced drive.

- When replacing a drive after saving data to a spare drive, the drive status changes to **Normal** after performing the copy-back operation. This operation can take up to 12 hours to perform, depending on the configuration and drive capacity
- If the drive status is **Copy incomplete**, the correction-copy operation cannot be performed because a copy-processing operation is being performed in the parity group to which the target drive belongs. Complete the other copy-processing operation, and then replace the drive.
- If the drive status is **Reserved**, the copy-back operation cannot be performed because more than one copy-processing operation is being performed in the parity group to which the copy-back source drive of the target drive belongs. Complete the other copy-processing operation, and then replace the drive.
- If the copy-back operation is set to disabled, this operation will not be performed.

Replacing a battery

Hitachi Virtual Storage Platform G400, G600 systems have replaceable batteries. Before replacing a battery on these storage systems, read the precautions and understand the procedure for your battery.

- ☐ [Checking the battery](#)
- ☐ [Replacing the battery](#)

Checking the battery

Prerequisites

- Storage system power is turned on.
- The red **STATUS** LED for the backup module containing the battery to be replaced is blinking.
- The power supply is operating normally.

Procedure

1. Start the maintenance utility.
2. In the **Maintenance Utility** window, click **Hardware > Controller Chassis**.
3. In the **Controller Chassis** window, click the **BKMFs** tab.
4. Confirm that the status of the battery to be replaced is **Warning**.

The screenshot shows the Hitachi Maintenance Utility interface. The top bar includes 'Alert', 'System Locked', 'Logged in as user00', and 'Logout'. The left sidebar shows 'Storage System' (S/N: 400001, CTL2) and 'Controller Chassis' (Warning). The main area shows the 'Controller Chassis' window with the 'BKMFs' tab selected. The 'BKMFs' tab displays a table of battery statuses.

CTLs		BKMFs		CFMs		CHBs		DKBs		LANBs		PSs	
Block												Total: 8	
Location		BKMF Status	Battery(Basic)		Battery(Optional)								
Location		BKMF Status	Location		Status	Location	Status						
-	BKMF-10	Normal	-	Not Installed	-	Not Installed							
o	BKMF-11	Warning	BAT-B11	Normal	-	Not Installed							
o	BKMF-12	Normal	BAT-B12	Normal	-	Not Installed							
o	BKMF-13	Normal	BAT-B13	Normal	-	Not Installed							
-	BKMF-20	Normal	-	Not Installed	-	Not Installed							
o	BKMF-21	Normal	BAT-B21	Normal	-	Not Installed							
o	BKMF-22	Normal	BAT-B22	Normal	-	Not Installed							

Replacing the battery

The blink pattern of the red **STATUS** LED indicates which battery needs replacement.

- **One blink::** Replace the standard battery.

- **Two blinks::** Replace the optional battery.
- **Three blinks::** Replace both the standard and optional batteries.


Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- The red `STATUS` LED for the backup module containing the battery to be replaced is blinking.
- Use the maintenance utility to check the battery.

Procedure

1. Loosen the blue screw that secures the BKMF whose red `STATUS` LED is blinking.
2. Open the lever to pull out and remove the BKMF with both hands.
3. Find the BKMF whose red `STATUS` LED is blinking, and then loosen the blue screw that secures that BKMF.
4. Slide the top panel of the BKMF and remove it.
5. Hold the latch of the cable connector of the battery to be replaced and remove the connector from the socket.
6. Remove the battery to be replaced.
7. Install a new battery in the BKMF and route cables along the groove of the BKMF.
If replacing one battery, install the replacement battery at the front (fan) side of the system. The battery clicks into place when installed securely in the slot. Route cables with minimum bending.
8. Connect the cable connector to the socket. You will hear a click when the connection is secure.
9. Replace the BKMF top panel by sliding it and then attaching it.
10. Tighten the blue screw on the rear side of the BKMF.
11. With the lever of the BKMF opened, hold the BKMF with both hands and insert it straight into the slot.

12. Close the lever of the BKMF, and tighten the blue screw.



13. Check that the green `STATUS` LED on the BKMF is blinking.
14. In the **Maintenance Utility** window, click **Hardware > Controller Chassis**.
15. Click the **BKMF** tab.
16. Confirm that the status of the replacement battery is `Normal`.
17. Log out and close the **Maintenance Utility** window.

Replacing a fan


Before replacing a fan, read the precautions and understand the procedure for your fan.

- ☐ [Blocking the controller](#)
- ☐ [Replacing a fan](#)
- ☐ [Restoring a fan](#)

Blocking the controller

Procedure

1. Use the amber CTL WARN LED to identify the failed fan that needs to be replaced:
 - If the LED blinks 1 time, replace fan 0.
 - If the LED blinks 2 times, replace fan 1.
2. Start the maintenance utility.
3. Click **Hardware > Controller Chassis**.
4. In the **Controller Chassis** window, click the **CTLs** tab.
5. Confirm that the status of the controller to be replaced is **Warning**.




The screenshot shows the Hitachi Maintenance Utility interface. The left sidebar has a 'Storage System' section with 'S/N: 400001' and 'CTL2' status 'Ready'. Below it is a 'Hardware' section with 'Controller Chassis' selected. The main area is titled 'Controller Chassis' and shows a 'Last Updated' timestamp of '2014/08/03 03:57'. It includes a 'Front' and 'Back' view of the chassis. Below this is a 'CTLs' tab with a 'Replace' button. The table below shows the status of CTL1 and CTL2, including battery charge, cache memory, and fan status.


CTLs	CTL1	CTL2
CTL Status	Normal	Normal
Amount of Battery charge	90%	80%
Cache Memory	Total Cache Size: 32GB	CTL1 Status / Size: Normal / 8GB x 2
Fan Status	CTL1: FAN-10 (Warning), FAN-11 (Normal)	CTL2: FAN-20 (Normal), FAN-21 (Normal)
Shared Memory Function	Base: Installed	Extension1: Not Installed, Extension2: Not Installed

6. Click the **Replace** list, and select the controller that contains the cache memory you want to replace.

7. When the **Replace FANs** window appears, verify that the fan shown in the window is the one to be replaced, and then click **Block**.



8. Check that the controller is blocked and becomes ready for replacing. Leave the **Replace FANs** window open, but do not click the **Restore** button.



Replacing a fan



Caution: Storage system fans rotate at high speed. Exercise extreme caution to avoid getting anything caught in the fan and to prevent injury.



Caution: A short-circuit can cause a fire. Never insert metal or other objects into the cable connector; otherwise, a short-circuit can occur.

Prerequisites


- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- A fan is installed in the controller.
- Storage system power is turned on.
- The amber CTL WARN LED is blinking one or two times rapidly (one blink = replace fan 0, two blinks = replace fan 1).
- Use the maintenance utility to block the controller.



Note: Storage system fans rotate at high speed. Exercise extreme caution to avoid getting anything caught in the fan and to prevent injury.

Procedure

1. Remove all optical and SAS cables connected to the controller.
2. Loosen the blue screw that secures the controller, and then open the lever.
3. Hold the controller with both hands, and then pull it gently and remove it.
4. Loosen the blue screw that secures the fan.
5. Lift the fan and remove it from the connector.
6. Install the new fan into the connector of the controller.



7. Tighten the blue screw to secure the fan.
8. Check that the controller connector is in good condition (not deformed or damaged).
9. With the right and left controller levers open completely, insert the controller into the slot of the Controller.
10. Push the controller in all the way, and then close the right and left levers completely.
11. Tighten the blue screw to secure the controller.

12. Connect all the optical and SAS cables that you removed from the controller.

Postrequisites

- Use the maintenance utility to restore (unblock) the controller.


Restoring a fan

Procedure

1. In the **Replace FANs** window, click **Restore**.
A progress bar shows the replacement status.



Note: The restore operation can take up to 20 minutes to complete. If a message states that the recovery failed, go to the HDS Support Portal at <https://portal.hds.com>.



2. When the progress bar goes away and the completion message appears, click **Close**.
3. Confirm that the amber CTL WARN LED is off at the fan.
4. In the **BKMFs** tab, click **Refresh** at the top-right of the window and confirm that the fan status is `Normal`.

5. Log out and close the **Maintenance Utility** window.

Replacing a power supply

Before replacing a power supply, read the precautions and understand the procedure for your power supply.


The following topics are covered in this chapter:

- ☐ [Checking the power supply](#)
- ☐ [Replacing a power supply for a CBSS or CBSL](#)
- ☐ [Replacing a power supply for a CBLM or CBLH](#)
- ☐ [Replacing a power supply for SFF and LFF drive trays](#)
- ☐ [Replacing a power supply for a FMD drive tray](#)
- ☐ [Confirming the power supply unit status](#)

Checking the power supply

Procedure

1. Start the maintenance utility.
2. Click **Hardware > Controller Chassis** or **Hardware > Drive Box**.
3. In the **Controller Chassis** window, click the **PSs** tab.
4. Confirm that the status of the power supply to be replaced is **Warning**.



Replacing a power supply for a CBSS or CBSL



Caution: Be sure to replace the faulty power supply. If you replace the operational power supply, the system will go down.



Caution: A short-circuit can cause a fire. Never insert metal or other objects into the cable connector; otherwise, a short-circuit can occur.



Note: Power supply unit #1 and power supply unit #2 are installed in opposite directions.

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- The red ALM/RDY LED for the power supply to be replaced is on.




Note: If the red ALM/RDY LED is on at both power supplies, do not perform this procedure. Contact the HDS Support Portal at <https://portal.hds.com>.

Procedure

1. Disconnect the power cable from the power supply to be replaced. Remove the cable holder to disconnect the power cable from the power supply.
2. Hold up the latch on the cable holder of the power supply to release the lock, and then slide the cable holder forward.
3. Pull the lever open while pressing the latch on the power supply inward with right thumb.

When the lever is completely opened, the power supply moves forward.



4. Pull out and remove it while holding the body of the power supply with both hands.
5. Insert the new power supply into the slot.

6. Wait at least 20 seconds, and then push the power supply until the latch clicks. If the latch does not click, reorient the power supply, and then reinsert it into the slot.
7. Connect the power cable to the power supply, and then secure the cable with the cable holder.
8. Confirm that the red **ALM/RDY** LED is off at the power supply and the green **ALM/RDY** LED is on.

If the red **ALM/RDY** LED does not go off after more than 30 minutes following replacement of the power supply, remove the power supply, wait at least 30 seconds, and then reinstall it.

Replacing a power supply for a CBLM or CBLH



Caution: Be sure to replace the faulty power supply. If you replace the operational power supply, the system will go down.



Caution: A short-circuit can cause a fire. Never insert metal or other objects into the cable connector; otherwise, a short-circuit can occur.



Note: Power supply unit #1 and power supply unit #2 are installed in opposite directions.

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- The red **ALM** LED for the power supply unit to be replaced is on.




Note: If the red **ALM** LED is on at both power supplies, do not perform this procedure. Contact the HDS Support Portal at <https://portal.hds.com>.

Procedure

1. Disconnect the power cable from the power supply to be replaced. Remove the cable holder to disconnect the power cable from the power supply.
2. Using a Phillips screwdriver, loosen the blue screw that secures the power supply.
3. Open the lever to remove the power supply.
When the lever is completely opened, the power supply moves forward.

4. Hold the power supply with both hands, and then pull it gently and remove it.



5. Hold up the latch on the cable holder of the new power supply to release the lock, and then slide the cable holder forward.
6. With the lever opened completely, insert the new power supply into the slot. Wait at least 20 seconds, and then insert the power supply all the way into the slot. If the power supply does not install all the way into the slot, reorient the power supply, and then reinsert it into the slot.
7. Close the lever completely.
8. Using a Phillips screwdriver, tighten the blue screw to secure the power supply.
9. Connect the power cable to the power supply, and then secure the cable using the cable holder.
10. Confirm that the red **ALM** LED is off at the power supply and the green **RDY** LED is on.

If the red **ALM** LED does not go off after more than 30 minutes following replacement of the power supply, remove the power supply, wait at least 30 seconds, and then reinstall it.

Replacing a power supply for SFF and LFF drive trays



Caution: Be sure to replace the faulty power supply. If you replace the operational power supply, the system will go down.



Caution: A short-circuit can cause a fire. Never insert metal or other objects into the cable connector; otherwise, a short-circuit can occur.



Note: Power supply unit #1 and power supply unit #2 are installed in opposite directions.

Prerequisites


- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- The red **ALM** LED for the power supply unit to be replaced is on.



Note: If the red **ALM** LED is on at both power supplies, do not perform this procedure. Contact the HDS Support Portal at <https://portal.hds.com>.

Procedure

1. Disconnect the power cable from the power supply to be replaced. Remove the cable holder to disconnect the power cable from the power supply.
2. Pull the lever open while pressing the latch on the power supply inward with your right thumb. When the lever is completely opened, the power supply moves forward.



3. Hold the power supply with both hands, and then pull it gently and remove it.

4. With the lever opened completely, insert the new power supply into the slot.
Wait at least 20 seconds, and then insert the power supply all the way into the slot.
5. Close the lever completely and secure the power supply. If the lever cannot be moved, reorient the power supply, and then reinsert it into the slot.
6. Connect the power cable to the power supply, and then secure the cable using the cable holder.
7. Confirm that the red **ALM** LED is off at the power supply and the green **RDY** LED is on.
If the red **ALM** LED does not go off after more than 30 minutes following replacement of the power supply, remove the power supply, wait at least 30 seconds, and then reinstall it.

Replacing a power supply for a FMD drive tray



Caution: Be sure to replace the faulty power supply. If you replace the operational power supply, the system will go down.



Caution: A short-circuit can cause a fire. Never insert metal or other objects into the cable connector; otherwise, a short-circuit can occur.



Note: Power supply unit #1 and power supply unit #2 are installed in opposite directions.

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
 - Storage system power is turned on.
 - The red **ALM** LED for the power supply unit to be replaced is on.
-




Note: If the red **ALM** LED is on at both power supplies, do not perform this procedure. Contact the HDS Support Portal at <https://portal.hds.com>.

Procedure

1. Disconnect the power cable from the power supply to be replaced. Remove the cable holder to disconnect the power cable from the power supply.

2. Pull the lever open while pressing the latch on the power supply inward with your right thumb. When the lever is completely opened, the power supply moves forward.



3. Hold the power supply with both hands, and then pull it gently and remove it.
4. With the lever opened completely, insert the new power supply into the slot. Wait at least 20 seconds, and then insert the power supply all the way into the slot.
5. Close the lever completely and secure the power supply. If the lever cannot be moved, reorient the power supply, and then reinsert it into the slot.
6. Connect the power cable to the power supply, and then secure the cable using the cable holder.
7. Confirm that the red **ALM** LED is off at the power supply and the green **RDY** LED is on.

If the red **ALM** LED does not go off after more than 30 minutes following replacement of the power supply, remove the power supply, wait at least 30 seconds, and then reinstall it.

Confirming the power supply unit status

Procedure

1. Click **Hardware > Controller Chassis** or **Hardware > Drive Box**.
2. In the **Controller Chassis** window, click the **PSs** tab.
3. In the **PSs** tab in the **Maintenance Utility** window, confirm that the status of the power supply unit changed to **Normal**.

If necessary, click **Refresh** at the top-right of the window to update the status in the window.

4. Log out and close the **Maintenance Utility** window.

Replacing a controller

Before replacing a controller, read the precautions and understand the procedure for your controller.

The following topics are covered in this chapter:

- ☐ [Blocking the controller](#)
- ☐ [Replacing a controller for a CBSS or CBSL controller](#)
- ☐ [Replacing a CBLM or CBLH controller](#)
- ☐ [Restoring a controller](#)

Blocking the controller

Procedure


1. Start the maintenance utility.
2. Click **Hardware > Controller Chassis**.
3. In the **Controller Chassis** window, click the **CTLs** tab.
4. Confirm that the status of the controller to be replaced is **Warning**.

The screenshot shows the Hitachi Maintenance Utility interface. The left sidebar contains the 'Storage System' section with 'S/N: 400001' and 'CTL2' status 'Ready'. Below this is the 'Hardware' section with 'Controller Chassis' selected, showing 'Drive Box - 01', 'Drive Box - 02', and 'Drive Box - 03'. The 'Administration' and 'Menu' sections are also visible. The main area is titled 'Controller Chassis' and shows a 'Last Updated' timestamp of '2014/08/03 03:57'. It features a 'Front' and 'Back' view of the controller chassis. Below this is a table of controller status information.

CTLs			
Replace	Install	Remove	Reset HUB
CTL Status	CTL1	CTL2	Normal
Amount of Battery charge	CTL1	CTL2	90%
Cache Memory	Total Cache Size	32GB	
	CTL1 Status / Size	Normal / 8GB x 2	
	CTL2 Status / Size	Normal / 8GB x 2	
Fan Status	CTL1	FAN-10	Warning
		FAN-11	Normal
	CTL2	FAN-20	Normal
		FAN-21	Normal
Shared Memory Function	Base	Installed	
	Extension1	Not Installed	
	Extension2	Not Installed	


5. Click the **Replace** list, and select the controller that contains the cache memory you want to replace.

6. When the **Replace Controller Board** window appears, verify that the controller shown in the window is the one to be replaced, and then click **Block**.



7. If prompted that the target controller is in the normal status, click **OK** to proceed.

8. Check that the controller is blocked and becomes ready for replacing. Leave the **Replace Controller Board** window open, but do not click the **Restore** button.



Replacing a controller for a CBSS or CBSL controller

When you replace a CBSS or CBSL controller, you will have to install the following components on the new controller:

- Fan
- Cache memory
- Front end module
- Cache flash memory
- Backup module

Removing the controller



Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Use the maintenance utility to block the controller.
- Storage system power is turned on.

- The red CTL ALARM LED for the controller to be replaced is on.

Procedure

1. Remove all cables connected to the controller.
2. Loosen the blue screw that secures the controller, and then open the lever.



3. Hold the controller with both hands, and then pull it gently in a straight direction and remove it.
Keep the controller straight to avoid jostling the components above and below it.
4. Install the fan, cache memory, front end module, and CFM on the new controller.

Postrequisites

- Install the controller.
- Use the maintenance utility to restore (unblock) the controller.

Removing and installing the fan



Caution: Storage system fans rotate at high speed. Exercise extreme caution to avoid getting anything caught in the fan and to prevent injury.


Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- The controller must be removed from the storage system.

Procedure

1. Loosen the blue screw that secures the fan.
2. Lift the fan and remove it from the connector.
3. Install the fan into the connector of the new controller.


4. Tighten the blue screw to secure the fan.



Removing and installing cache memory

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.




Procedure

1. Press the button, and then slide the dual in-line memory module (DIMM) cover in the direction of the arrow and remove the DIMM cover from the hooks on either side.
2. Lift the DIMM cover gently to remove it.



Note: The DIMM cover has a band that can be damaged easily. Exercise care when removing the DIMM cover.




3. Pull the lever outward.

4. Hold both ends of the cache memory, and then gently pull out the cache memory from the socket.



Note: Do not exert pressure on the cache memory. Otherwise, you can damage the printed-circuit board.



5. Align the notch on the cache memory board with the projection inside the slot.
6. Holding both ends of the cache memory, insert it into the socket.
7. Confirm that the lever is securing the cache memory.
8. To install the DIMM cover, slide it in the direction of the arrow. Confirm that the DIMM cover is secured by the two hooks on either side.

Postrequisites

- Install the controller.
- Use the maintenance utility to restore (unblock) the controller.

Removing and installing a front end module

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Use the maintenance utility to block the controller.
- Remove the controller.

Procedure

1. Disconnect the optical cable from the front end module to be replaced.
2. Loosen the two blue screws that secure the front end module.

3. Using the blue screw, pull out the front end module in a straight direction and remove.
4. Connect the optical cable to the new front end module.
5. Insert the front end module into the slot of the new controller.
6. Push the front end module all the way into the slot.
7. Tighten the two blue screws to secure the front end module.


Removing and installing cache flash memory

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Use the maintenance utility to block the controller.
- The controller must be removed from the storage system.

Procedure

1. Loosen the blue screw that secures the cache flash memory (CFM).
2. Open the lever.
3. Using both hands, hold the body of the CFM and remove it.



4. With the lever opened completely, insert the CFM into the slot.
5. Push the CFM all the way into the slot.
6. Close the lever completely.

7. Tighten the blue screw to secure the CFM.

Postrequisites

- Once all parts are installed on the controller, install it in the storage system.
- Use the maintenance utility to restore (unblock) the controller.

Removing and installing the backup module

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- The controller must be removed from the storage system.

Procedure

1. Loosen the blue screw that secures the backup module.
2. Open the lever, and then use both hands to remove the backup module.
3. With the backup module lever opened, insert the backup module into the slot of the new controller.
4. Close the backup module lever and tighten the blue screw.

Installing a controller


Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Complete the installation of all components from the old controller.

Procedure

1. With the right and left levers of the new controller open completely, insert it into the slot of CBSS or CBSL.

2. Push the controller all the way into the slot until the right and left levers close completely.



3. Tighten the blue screw to secure the controller.
4. Confirm that the red `CTL ALM` LED on the controller is off.
5. Connect all the cables you removed.

Replacing a CBLM or CBLH controller

When you replace a CBLM or CBLH controller, you will have to install the following components on the new controller:

- Cache memory
- Cache flash memory
- Backup module

You must remove the backup module first, and then remove the controller.


Removing a CBLM or CBLH controller

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- Use the maintenance utility to block the controller.
- The red `CTL ALARM` LED for the controller to be replaced is on.


Procedure

1. Loosen the right and left blue screws on the lever of the controller in the front of the CBLM or CBLH controller, and then open the lever.
2. Loosen the blue screw securing the Backup Module (BKMF).
3. Pull out and remove the BKMF.



4. Remove all four BKMF modules installed in the controller.
5. Loosen the blue right and left screws on the lever of the controller, and then open the lever.

6. With the lever opened completely, hold the controller with both hands, and then pull it gently and remove it.
Keep the controller straight to avoid jostling the components above and below it.



Postrequisites

- Install the backup module (BKMF) in the new controller.
- Install the cache memory on the new controller.
- Install the cache flash memory on the new controller.
- Use the maintenance utility to restore (unblock) the controller.



Note: If the POWER/READY/WARNING/ALARM LED on the front of the CBLM/CBLH goes off after removing the controller, check the status of the storage system in the **Maintenance Utility** window, and then continue the replacement work. After restoring the controller (described later), confirm that the LED goes on.


Removing and installing cache memory

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- The controller is removed from the storage system.

Procedure

1. Open the air guide.





2. Pull the lever outward.

3. Holding both ends of the cache memory, pull out the cache memory from the socket.



Note: Do not exert pressure on the cache memory. Otherwise, you can damage the printed-circuit board.



Note: DIMMs are installed in sets of four. There are two groups of cache memory DIMM slots: CMG0 and CMG1. Populate the CMG0 slots first, and then populate the CMG1 slots if necessary.

4. Align the notch on the cache memory board with the projection inside the slot.
5. Holding both ends of the cache memory, insert it into the socket of the new controller.
6. Check that the lever is securing the cache memory.
7. Close the air guide.

Postrequisites

- Once all components are installed on the controller, install the controller in the storage system.
- Use the maintenance utility to restore (unblock) the controller.

Removing and installing cache flash memory for a CBLM or CBLH controller


Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- The controller must be removed from the storage system.

Procedure

1. Loosen the blue screw that secures the cache flash memory (CFM).
2. Open the lever.

3. Using both hands, hold the body of the CFM and remove it.



4. With the lever opened completely, insert the CFM into the slot.
5. Push the CFM all the way into the slot.
6. Tighten the blue screw to secure the CFM.

Postrequisites

- Once all parts are installed on the controller, install it in the storage system.
- Use the maintenance utility to restore (unblock) the controller.


Installing a controller in a CBLM or CBLH controller

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.


Procedure

1. With the right and left levers on the new controller opened completely, insert the controller into the slot of the CBLM or CBLH chassis. Hold the controller with both hands and move it in a straight direction.



2. With the lever closed on the BKMF you removed, tighten the blue screw to secure the BKMF.

3. Install the four BKMFs on the controller.



4. Push the controller in all the way.
The right and left covers close completely.
5. Tighten the blue screw to secure the controller.
6. Confirm that the red **CTL ALM** LED on the new controller is off.
7. Attach the front bezel.

Postrequisites

- Use the maintenance utility to restore (unblock) the controller.

Restoring a controller

Procedure

1. At the **Replace Controller Board** window, click **Restore**. A progress bar shows the replacement status.



Note: The restore operation can take up to 20 minutes to complete. If a message states that the recovery failed, go to the HDS Support Portal at <https://portal.hds.com>.

2. When the progress bar goes away and the completion message appears, click **Close**.
3. Click **CTLs** tab and confirm that the status of the new controller you replaced is `Normal`. If necessary, click **Refresh** at the top-right of the window to update the status in the window.
4. Log out and close the **Maintenance Utility** window.

Replacing cache memory

Before replacing cache memory, read the precautions and understand the procedure for your cache memory.

The following topics are covered in this chapter:

- ☐ [Checking cache memory](#)
- ☐ [Replacing cache memory for a CBLM or CBLH controller](#)
- ☐ [Replacing cache memory for a CBSS or CBSL controller](#)
- ☐ [Replacing cache memory for a CBLM or CBLH controller](#)
- ☐ [Restoring cache memory](#)

Checking cache memory

Procedure

1. Start the maintenance utility.
2. Click **Hardware > Controller Chassis**.

3. Click the **CTLs** tab.

Maintenance Utility HITACHI

Alert System Locked Logged in as user00 Logout ?

Storage System S/N: 400001 CTL2 **Ready**

Hardware

- Controller Chassis
- Drive Box - 01
- Drive Box - 02
- Drive Box - 03

Administration

Menu

- Initial Setup Wizard
- Power Management
- System Management

Controller Chassis Last Updated : 2014/08/05 03:12

Front Back

Chassis **CTLs** CHBs BKMs CFMs PSs

Replace Install Remove Reset HUB

CTL Status	CTL1	Normal
	CTL2	Normal
Amount of Battery Charge	CTL1	90%
	CTL2	80%
Cache Memory	Total Cache Size	32GB
	CTL1 Status / Size	Normal / 8GB x 2
	CTL2 Status / Size	Normal / 8GB x 2
Fan Status	CTL1 FAN-10	Normal
	FAN-11	Normal
	CTL2 FAN-20	Normal
	FAN-21	Normal
Shared Memory Function	Base	Installed
	Extension1	Not Installed
	Extension2	Not Installed

Maintenance Utility HITACHI

Alert System Locked Logged in as user00 Logout ?

Storage System S/N: 400001 CTL2 **Ready**

Hardware

- Controller Chassis
- Drive Box - 00
- Drive Box - 01
- Drive Box - 02
- Drive Box - 03

Administration

Menu

- Initial Setup Wizard
- Power Management
- System Management

Controller Chassis Last Updated : 2014/08/05 01:12

Front Back

CTLs BKMFs CFMs CHBs DKBs LANBs PSs

Replace Replace (Type Change) Install Remove


CTL Status	CTL1	Normal
	CTL2	Normal
Amount of Battery Charge	CTL1	90%
	CTL2	80%
Cache Memory	Total Cache Size	64GB
	CTL1 CMG0 Status / Size	Normal / 8GB x 4
	CMG1 Status / Size	Not equip
	CTL2 CMG0 Status / Size	Normal / 8GB x 4
	CMG1 Status / Size	Not equip
Shared Memory Function	Base	Installed
	Extension1	Not Installed
	Extension2	Not Installed
	Extension3	Not Installed
	Extension4	Not Installed

- Confirm that the status of the cache memory to be replaced is **Warning**.
- Click **Close**.


Replacing cache memory for a CBLM or CBLH controller

Procedure

1. Start the maintenance utility.
2. Click **Hardware > Controller Chassis**.
3. In the **Controller Chassis** window, click the **CTLs** tab.
4. Confirm that the component you want to replace has the status **Warning** or **Failed**.
5. Click the **Replace** list, and select the controller that contains the cache memory you want to replace.
6. Click **Block**.



7. Check that the controller is blocked and becomes ready for replacing. Leave the Replace Cache Memories window open, but do not click the **Restore** button.



Replacing cache memory for a CBSS or CBSL controller


Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Use the maintenance utility to block the controller.
- Storage system power is turned on.
- The red **CTL ALARM** LED for the controller containing the cache memory to be replaced is on.

Procedure

1. Remove all cables connected to the controller.
2. Loosen the blue screw that secures the controller and open the lever.

3. Hold the controller with both hands, and then gently remove it. Keep the controller straight to avoid touching the components above and below it.




4. Press the button near the dual in-line memory module (DIMM) cover, slide the cover in the direction of the arrow.


5. Lift and remove the DIMM cover from the hooks on either side.



Note: The DIMM cover has a band that can be damaged easily. Exercise care when removing the DIMM cover.



6. Note the cache memory locations.




7. Pull the lever outward.

8. Hold both ends of the cache memory by the fingers, and then gently remove the cache memory from the socket.



Note: Do not exert pressure on the cache memory. Otherwise, you can damage the printed-circuit board.




9. Align the notch on the cache memory board with the projection inside the slot.
10. Holding both ends of the cache memory, insert it into the socket of the new controller.
11. Check that the lever is securing the cache memory.
12. To install the DIMM cover, slide it in the direction of the arrow. Confirm that the DIMM cover is secured by the two hooks on either side.
13. Check that the connector of the controller is not damaged, deformed, or dusty.
14. With the right and left levers on the controller opened completely, insert it into the slot of CBSS or CBSL controller.
15. Push the controller in all the way. The right and left levers close completely.
16. Tighten the blue screw to secure the controller.
17. Connect all cables removed from the controller.
18. Confirm that the red CTL ALM LED on the controller in which the cache memory was installed goes off.

Postrequisites

- Use the maintenance utility to restore (unblock) the controller.

Replacing cache memory for a CBLM or CBLH controller

When replacing cache memory on a CBLM or CBLH controller, remove the backup module first, and then remove the controller. A single CBLM or CBLH controller weighs approximately 42 pounds (19 kg).



Note: DIMMs are installed in sets of four. There are two groups of cache memory DIMM slots: CMG0 and CMG1. Populate the CMG0 slots first, and then populate the CMG1 slots if necessary.


Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Use the maintenance utility to block the controller.
- Storage system power is turned on.
- The red CTL ALARM LED for the controller containing the cache memory to be replaced is on.

Procedure


1. Remove the front bezel.
2. Loosen the blue left and right screws on the lever of the controller to add the cache memory in the front of the CBLM or CBLH and open the lever.
3. Loosen the blue screw securing the backup module.

4. With the lever opened, pull out and remove the backup module.



5. Remove all four backup modules installed in the controller.
6. Loosen the blue right and left screws on the lever of the controller, and then open the lever.

7. Hold the controller with both hands and gently remove it. Keep the controller straight to avoid touching the components above and below it.




8. Open the air guide.
9. Pull the lever outward.

10. Hold both ends of the cache memory, and then gently pull out the cache memory from the socket.



Note: Do not exert pressure on the cache memory. Otherwise, you can damage the printed-circuit board.



11. Align the notch on the cache memory board with the projection inside the slot.
12. Holding both ends of the cache memory, insert it into the socket.
13. Confirm that the lever is securing the cache memory.
14. Close the air guide.
15. Confirm that the connector of the controller is not damaged, deformed, or dusty.
16. With the right and left levers of the controller opened completely, insert it into the slot of the controller.
17. Push the controller in all the way.
The right and left levers close completely.
18. Tighten the blue screw to secure the controller.
19. With the lever on the backup module open, insert the backup module into the slot.
20. With the backup module lever closed, tighten the blue screw to secure it.
21. Install the four backup modules on the controller.
22. Push the controller all the way into the slot until the right and left levers close completely.
23. Tighten the blue screw to secure the controller.
24. Confirm that the red **CTL ALM** LED on the controller in which the cache memory was installed goes off.

Postrequisites

- Use the maintenance utility to restore (unblock) the controller.

Restoring cache memory

Procedure

1. At the **Replace Cache Memories** window, click **Restore**.
A progress bar shows the replacement status.



Note: The restore operation can take up to 20 minutes to complete. If a message states that the recovery failed, go to the HDS Support Portal at <https://portal.hds.com>.

2. When the progress bar goes away and the completion message appears, click **Close**.
3. Click **CTLs** tab and confirm that all status conditions are `Normal`.
If necessary, click **Refresh** at the top-right of the window to update the status in the window.
4. Log out and close the **Maintenance Utility** window.

Replacing a front end module

Before replacing a front end module, read the precautions and understand the procedure for your front end module.

Controller 1 and Controller 2 must have the same number of front end modules installed. For example, if you install a second front end module to Controller 1, you must also install a new front end module to Controller 2. You cannot add a front end module to one controller without adding a front end module to the other controller.

- ☐ [Blocking a front end module](#)
- ☐ [Adding a front end module](#)
- ☐ [Restoring a front end module](#)

Blocking a front end module

Procedure


1. Start the maintenance utility.
2. In the **Maintenance Utility** window, click **Hardware > Controller Chassis**.
3. Click the **CHBs** tab.
4. Confirm that the status of the front end module to be replaced is Warning.

The screenshot shows the Hitachi Maintenance Utility interface. The left sidebar contains 'Storage System' (S/N: 400001, CTL2), 'Warning', 'Hardware' (selected), 'Administration', and 'Menu'. The main area is titled 'Controller Chassis' and shows 'Front' and 'Back' views of the chassis. Below these views is a tabbed interface with 'CHBs' selected. A table lists the status of various modules, with CHB-1A showing a 'Warning' status.

Location	Status	Type	SFP Status
CHB-1A	Warning	16G 2Port FC	Normal
CHB-1B	Normal	8G 4Port FC	Normal
CHB-1C	Normal	10G 2Port iSCSI(Optic)	Normal
CHB-1D	Normal	10G 2Port iSCSI(Optic)	Normal
CHB-2A	Normal	16G 2Port FC	Normal
CHB-2B	Normal	8G 4Port FC	Normal
CHB-2C	Normal	10G 2Port iSCSI(Optic)	Normal
CHB-2D	Normal	10G 2Port iSCSI(Optic)	Normal


5. Click the front end module to be replaced, and then click **Replace**.

6. Click **Block**.



7. Verify that the front end module is blocked and is ready for replacing.

8. Leave the **Replace Channel Board** window open, but do not click **Restore**.



Adding a front end module

Prerequisites


- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Use the maintenance utility to block the front end module.
- Storage system power is turned on.

Procedure

1. Disconnect the optical fiber cable from the front end module.
2. Loosen the two blue screws that secure the front end module.

3. Gently remove the front end module.


When removing the front end module, hold the blue screw and keep the front end module straight avoid jostling the components above and below it.



4. Orient the new front end module upside-down.

5. Connect the optical fiber cable to the new front end module.

6. Insert the new front end module into the slot, just before the "shield finger."



7. Gently push the front end module all the way into the slot.
8. Tighten the two blue screws to secure the front end module.
9. Confirm that the red `STATUS` LED on the front end module goes off.

Postrequisites

- Use the maintenance utility to restore (unblock) the front end module.

Restoring a front end module

Procedure

1. At the **Replace Channel Board** window, click **Restore**.
A progress bar shows the replacement status.



Note: It can take up to 20 minutes for the controller to recover. If a message states that the recovery failed, go to the HDS Support Portal at <https://portal.hds.com>.

2. When the progress bar goes away and the completion message appears, click **Close**.
3. Click the **CHBs** tab in the **Controller Chassis** window.
4. Confirm that the status of the new front end module is `Normal`.
If necessary, click **Refresh** at the top-right of the window to update the status in the window.
5. Log out and close the **Maintenance Utility** window.

Replacing a small form-factor pluggable (SFP)

Before replacing a small form-factor pluggable (SFP) port, read the precautions and understand the procedure for your SFP.



Note: SFP ports also have been referred to as a mini-GigaBit or (GBIC) ports. However, this term has been made obsolete by SFP.

☐ [Checking an SFP](#)

☐ [Replacing an SFP](#)

Checking an SFP

Procedure

1. Start the maintenance utility.
2. In the **Maintenance Utility** window, click **Hardware > Controller Chassis**.
3. In the **Controller Chassis** window, click the **CHBs** tab.
4. Confirm that the status of the SFP to be replaced is **Warning**.



5. In the **SFP Status** column, click the warning to display a pop-up window with SFP port ID, status, and type information.
6. Replace the SFP. Do not click **Close** at this time.

Replacing an SFP

Install the same type of SFP as the one being replaced. The color of the lever or the entire SFP identifies the SFP type:


- Shortwave SFPs are black.
- Longwave SFPs are blue.

Prerequisites


- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.

Procedure

1. Disconnect the optical cable from the SFP to be replaced.
2. Pull the SFP lever down toward you and pull out the SFP.
If you cannot remove the SFP, pull it out while pushing open the lever toward you.



3.



Wait at least 10 seconds, and then check the SFP insertion direction and insert the SFP into the port until it clicks.



Note: Replace the SFP with the same type being removed.

4. Connect the optical cable to the new SFP. Check that optical cable latch clicks and the cables are surely connected.
5. Confirm that the red **STATUS** LED on the front end module is off.
6. In the **Controller Chassis** window, confirm that the status of the replacement SFP is **Normal**.

If necessary, click **Refresh** at the top-right of the window to update the status in the window.

7. Log out and close the **Maintenance Utility** window.

Replacing an ENC


Before replacing an ENC, read the precautions and understand the procedure for your ENC.

- ☐ [Blocking an ENC](#)
- ☐ [Replacing the ENC for SFF and LFF drive trays](#)
- ☐ [Replacing the ENC for a FMD drive tray](#)
- ☐ [Restoring an ENC](#)


Blocking an ENC

Procedure

1. Start the maintenance utility.
2. Click **Hardware > Drive Box**.
3. In the **Drive Box** window, click the **ENCs** tab.
4. Confirm that the status of the ENC to be replaced is **Warning**.
5. Click the ENC to be replaced, and then click **Replace**.




6. When the **Replace ENC** window appears, confirm that the ENC shown in the window is the one to be replaced.



7. Click **Block**.
8. Verify that the ENC is blocked and is ready for replacing.

9. Leave the **Replace ENC** window open, but do not click the **Restore** button.



Replacing the ENC for SFF and LFF drive trays

Do not touch the ENC connector because it is fragile. Check that the ENC connector is in good shape and is not deformed, damaged, or dusty before installing the ENC.



Note: Be sure to replace the faulty ENC. If you replace the operational ENC, the system will go down.



Caution: A short-circuit can cause a fire. Never insert metal or other objects into the cable connector; otherwise, a short-circuit can occur.


Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- Use the maintenance utility to block the ENC.

- The red **ALARM** LED for the ENC to be replaced is on.

Procedure

1. Disconnect the SAS cable from the ENC to be replaced.
2. Open toward you the right and left levers that secure the ENC.
When the levers are completely opened, the ENC moves forward.
3. Hold the ENC with both hands, and then pull it gently and remove it.
4. Open completely the right and left levers of the new ENC.
5. Insert the ENC into the slot, and then push the right and left levers toward the ENC until the levers open slightly.



6. Confirm that the red **ALARM** LED on the new ENC is off.
7. Connect the SAS cable to the new ENC.

Postrequisites

- Use the maintenance utility to restore (unblock) the ENC.

Replacing the ENC for a FMD drive tray

Do not touch the ENC connector because it is fragile. Check that the ENC connector is in good shape and is not deformed, damaged, or dusty before installing the ENC.



Note: Be sure to replace the faulty ENC. If you replace the operational ENC, the system will go down.



Caution: A short-circuit can cause a fire. Never insert metal or other objects into the cable connector; otherwise, a short-circuit can occur.

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- Use the maintenance utility to block the ENC.
- The red **ALARM** LED for the ENC to be replaced is on.

Procedure

1. Disconnect the SAS cable from the ENC to be replaced.
2. Open toward you the right and left levers that secure the ENC.
When the levers are completely opened, the ENC moves forward.
3. Hold the ENC with both hands, and then pull it gently and remove it.
4. Open completely the right and left levers of the new ENC.
5. Insert the ENC into the slot, and then push the right and left levers toward the ENC until the levers open slightly.
6. Confirm that the red **ALARM** LED on the new ENC is off.
7. Connect the SAS cable to the new ENC.

Restoring an ENC



Procedure

1. At the **Replace ENC** window, click **Restore**.
A progress bar shows the replacement status.
2. When the progress bar goes away and the completion message appears, click **Close**.
3. Click the **ENCs** tab in the **Drive Box** window and confirm that the status of the new ENC is **Normal**.
If necessary, click **Refresh** at the top-right of the window to update the status of the window.
4. Log out and close the **Maintenance Utility** window.

Replacing a SAS cable

Before replacing a SAS cable, read the precautions and understand the procedure for your SAS cable.

SAS cables come in the following shapes:

Model Name	Shape
DW-F800-SCQ1 DW-F800-SCQ1F DW-F800-SCQ3 DW-F800-SCQ5	
DW-F800-SCQ10A DW-F800-SCQ30A DW-F800-SCQ1H	

- Block the connected chassis and replace the SAS cables.

- For SAS cable DW-F800-SCQ1HA, replace the SAS adapter first. If recovery fails even after replacing the SAS adapter, replace the cable.
- The cable thickness and connector shape depend on the model name of the SAS cable.

☐ [Replacing SAS cables connected to a CBSS or CBSL controller](#)

☐ [Replacing SAS cables connected to a CBLM or CBLH controller](#)


☐ [Replacing SAS cables on a drive tray](#)

Replacing SAS cables connected to a CBSS or CBSL controller


Replacing SAS cables for a CBSS or CBSL controller requires you to block a controller before replacing the cables.

Procedure

1. Start the maintenance utility.
2. In the **Maintenance Utility** window, **Hardware --> Controller Chassis**.
3. Click the **CTLs** tab. Check the status of the controller, and then click the **Replace** list and select the controller whose SAS cable you want to replace.
4. After checking that the appropriate controller has been selected, click **Block**.
5. When the **Replace Controller Board** window appears, verify that the controller shown in the window is the one whose SAS cables are to be replaced, and then click **Block**.




6. Check that the controller is blocked and becomes ready for replacing the SAS cables. Leave the **Replace Controller Board** window open, but do not click the **Restore** button.



7. Confirm that the red CTL ALM LED on the controller is on.
8. Release the routing of the SAS cable connected to the CBSS or CBSL.
9. Remove the SAS cable from the back end module on the CBSS or CBSL.
10. Remove the SAS cable from the ENC on the drive tray connected to the CBSS or CBSL.


- 11.** For SAS cable DW-F800-SCQ1HA:
- a.** Remove the cable from the SAS adapters you want to replace.
 - b.** Pull the latch of the cables and remove them from the SAS adapters.



12. Connect new SAS cables to the back end module on the CBSS or CBSL and to the ENC of the drive tray connected to the CBSS or CBSL.



Note: When connecting the SAS cable DW-F800-SCQ1HA to a SAS adapter, be sure the cable latch clicks and that the cables are connected securely to the SAS adapter.



13. Confirm that the red **STATUS** LED for the back end module is off.
14. Route the cables appropriately.



Note: When connecting the DW-F800-SCQ1HA SAS adapter, you do not have to route the SAS cable.

15. At the **Replace Controller Board** window, click **Restore**. A progress bar shows the replacement status.



Note: The restore operation can take up to 20 minutes to complete. If a message states that the recovery failed, go to the HDS Support Portal at <https://portal.hds.com>.


16. When the progress bar goes away and the completion message appears, click **Close**.
17. Click the **CTLs** tab, and then check that the controller whose SAS cable you replaced is **Normal**.
18. Log out and close the **Maintenance Utility** window.

Replacing SAS cables connected to a CBLM or CBLH controller


Replacing SAS cables for a CBLM or CBLH controller requires you to block a back end module before replacing the cables.

Procedure

1. Start the maintenance utility.
2. In the **Maintenance Utility** window, click **Hardware --> Controller Chassis**.
3. Click the **DKBs** tab. Check the status of the back end module, and then click the **Replace** list and select the back end module whose SAS cable you want to replace.
4. After checking that the appropriate back end module has been selected, click **Block**.
5. When the **Replace Disk Board** window appears, verify that the back end module shown in the window is the one whose SAS cables are to be replaced, and then click **Block**.



6. Leave the **Replace Disk Board** window open, but do not click the **Restore** button.




7. Confirm that the red **STATUS** LED on the back end module whose SAS cable you want to replace is on.
8. Unroute the SAS cable connected to the CBLM or CBLH.



Note: When replacing the SAS adapter for DW-F800-SCQ1HA, you do not have to release the routing of the SAS cable.


9. Remove the SAS cable from the back end module on the CBLM or CBLH.
10. Remove the SAS cable from the ENC on the drive tray connected to the CBLM or CBLH.

- 11.** For SAS cable DW-F800-SCQ1HA:
 - a.** Remove the cable from the SAS adapters you want to replace.
 - b.** Pull the latch of the cables and remove them from the SAS adapters.



- 12.** Connect new SAS cables to the back end module on the CBLM/CBLH and to the ENC of the drive tray connected to the CBLM/CBLH.
- 13.** Confirm that the red `STATUS` LED for the back end module is off.

14. Connect the new SAS cables to the back end module on the CBLM or CBLH and to the ENC of the drive tray connected to the CBLM or CBLH.



15. Connect the cables to the SAS adapters. When replacing the SAS adapter for SAS cable DW-F800-SCQ1HA, install the cable into a new SAS adapter, and then connect it to the ENC.



Note: When connecting the SAS cable DW-F800-SCQ1HA, be sure the cable latch clicks and the cables are connected securely to the SAS adapters.

16. Route the cables appropriately.
17. At the **Replace Disk Board** window, click **Restore**.
A progress bar shows the replacement status.
18. When the progress bar goes away and the completion message appears, click **Close**.
19. Click the **DKBs** tab, and then check that the back end module whose SAS cable to replaced is *Normal*.
20. Log out and close the **Maintenance Utility** window.


Replacing SAS cables on a drive tray

Replacing SAS cables for a drive tray requires you to block an ENC before replacing the cables.


The following procedure describes how to replace SAS cables connected to a drive tray. Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.

Procedure

1. Start the maintenance utility.
2. Click **Hardware > Drive Box**.
3. In the **Drive Box** window, click the **ENCs** tab.
4. Click the ENC whose SAS cable you want to replace, and then click **Replace**.




5. When the **Replace ENC** window appears, confirm that the ENC shown in the window is the one to be replaced.



6. Click **Block**.
7. Verify that the appropriate ENC is blocked.

8. Leave the **Replace ENC** window open, but do not click the **Restore** button.




9. Confirm that the red **ALARM** LED on the ENC whose SAS cable you want to replace is on.
10. Unroute the SAS cable connected to the drive tray.



Note: For SAS cable DW-F800-SCQ1HA, you do not have to unroute the cable.

11. Remove the SAS cable from the ENC on the drive tray and from the ENC on a drive tray connected to another drive tray.


- 12.** For SAS cable DW-F800-SCQ1HA:
- a.** Remove the cable from the SAS adapters you want to replace.
 - b.** Pull the latch of the cables and remove them from the SAS adapters.



13. Connect new SAS cables to the ENC on the drive tray(s).



Note: When connecting the SAS cable DW-F800-SCQ1HA, be sure the cable latch clicks and that the cables are connected securely to the SAS adapters.



14. Confirm that the red **ALARM** LED for the ENC is off.
15. Route the cables appropriately.
16. At the **Replace ENC** window, click **Restore**.
A progress bar shows the replacement status.
17. When the progress bar goes away and the completion message appears, click **Close**.
18. Click the **ENCs** tab, and then check that the ENC whose SAS cable to replaced is **Normal**.
19. Log out and close the **Maintenance Utility** window.

Replacing cache flash memory

Before replacing cache flash memory (CFM), read the precautions and understand the procedure for your CFM.

- ☐ [Blocking the CFM](#)
- ☐ [Replacing the CFM](#)
- ☐ [Restoring a CFM](#)

Blocking the CFM

Procedure


1. Start the maintenance utility.
2. Click **Hardware > Controller Chassis**.
3. In the **Controller Chassis** window, click the **CFMs** tab.
4. Confirm that the status of the CFM to be replaced is Warning.

The screenshot shows the Hitachi Maintenance Utility interface. The left sidebar contains the 'Storage System' section with 'S/N: 400001' and 'CTL2', a 'Ready' status bar, and a 'Hardware' section with 'Controller Chassis' selected. Below this is an 'Administration' section and a 'Menu' with options like 'Initial Setup Wizard', 'Power Management', and 'System Management'. The main area is titled 'Controller Chassis' and shows a rack layout with 'Front' and 'Back' views. Below the rack layout is a tabbed interface with 'CTLs', 'BKMFs', 'CFMs' (selected), 'CHBs', 'DKBs', 'LANBs', and 'PSs'. The 'CFMs' tab shows a 'Replace' button and a table of CFM components.

Location	Status	Type
CFM-10	Warning	BM20
CFM-20	Normal	BM20


5. Click the CFM to be replaced, and then click **Replace**.

6. When the **Replace Cache Flash Memory** window appears, confirm that the CFM shown in the window is the one to be replaced, and then click **Block**.



7. Click **Block**.
8. Verify that the CFM is blocked and is ready for replacing.

9. Leave the **Replace Cache Flash Memory** window open, but do not click the **Restore** button.



Replacing the CFM



Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- Use the maintenance utility to block the CFM.
- The red **STATUS** LED for the CFM to be replaced is on.
- The red **ALARM** LED (CBSS/CBSL) or **ALM** LED (CBLM/CBLH) on the cache flash memory (CFM) to be replaced is on.

Procedure

1. Loosen the blue screw securing the CFM.
2. Open the lever

3. Hold the CFM with both hands, and then pull it gently and remove it.



4. With the lever opened completely, insert the new CFM all the way into the slot.
5. Close the lever completely, and tighten the blue screw to secure the CFM.
6. Confirm that the red **ALARM** or **ALM** LED on the CFM is off.

Postrequisites

- Use the maintenance utility to restore (unblock) the CFM.

Restoring a CFM

In the maintenance utility:

Procedure

1. In the **Replace Cache Flash Memory** window, click **Restore**.
A progress bar shows the replacement status.
2. When the progress bar goes away and the completion message appears, click **Close**.
3. Click the **CFMs** tab in the **Controller Chassis** window.
4. Verify that the status of the new CFM is `Normal`.
If necessary, click **Refresh** at the top-right of the window to update the status of the window.
5. Log out and close the **Maintenance Utility** window.

Replacing a LAN blade


Before replacing a LAN blade, read the precautions and understand the procedure for your LAN blade.

- ☐ [Blocking the controller](#)
- ☐ [Replacing the LAN blade](#)
- ☐ [Restoring the LAN blade](#)

Blocking the controller


Procedure

1. Start the maintenance utility.
2. Click **Hardware > Controller Chassis**.
3. In the **Controller Chassis** window, click the **LANBs** tab.
4. Confirm that the status of the LAN blade to be replaced is **Warning**.




5. Click the **CTLs** tab.
6. Click the **Replace** list and select the controller that contains the LAN blade to be replaced.
7. When the **Replace Controller Board** window appears, confirm that the controller shown in the window is the one that contains the LAN blade to be replaced.

8. Click **Block**.



9. Confirm that the controller is blocked.

10. Leave the **Replace Controller Board** window open, but do not click the **Restore** button.



11. Confirm that the red CTL ALM LED on the controller is on.

Replacing the LAN blade


Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- Use the maintenance utility to block the LAN blade.
- The red CTL ALM LED on the CBLM or CBLH controller is on.


Procedure

1. Remove the LAN cable from the user LAN port.
2. Release the controller:
 - a. Loosen the blue right and left screws on the lever of the controller to be replaced.

- b.** Open the lever.
- 3.** Loosen the blue screw that secures the LAN blade.
- 4.** Using both hands, pull out and remove the LAN blade.
- 5.** Insert the new LAN blade into the slot, just before the "shield finger."



- 6.** Gently push the new LAN blade all the way into the slot.
- 7.** Tighten the blue screw to secure the LAN blade.



- 8.** Secure the controller.
 - a.** Push in the controller all the way until the right and left levers close completely.
 - b.** Tighten the blue screw and secure the controller.
- 9.** Confirm that the red CTL ALM LED on the controller is off.
- 10.** Connect the LAN cable you removed to the user LAN port.

Postrequisites

- Use the maintenance utility to restore (unblock) the LAN blade.

Restoring the LAN blade

In the maintenance utility:

Procedure

1. In the **Replace Controller Board** window, click **Restore**.
A progress bar shows the replacement status.



Note: The restore operation can take up to 20 minutes to complete. If a message states that the recovery failed, go to the HDS Support Portal at <https://portal.hds.com>.

2. When the progress bar goes away and the completion message appears, click **Close**.
3. Click the **LANBs** tab in the **Controller Chassis** window and confirm that the status of the new LAN blade is `Normal`.
If necessary, click **Refresh** at the top-right of the window to update the status in the window.
4. Confirm that the red `CTL ALM` LED is off at the controller that contains new LAN blade.
5. Log out and close the **Maintenance Utility** window.

Replacing a backup module

Before replacing a backup module, read the precautions and understand the procedure for the backup module.

- ☐ [Replacing a BKM](#)
- ☐ [Replacing a BKMF](#)

Replacing a BKM

The following sections describe how to replace a BKM backup module.


Checking the BKM backup module

Prerequisites

- A backup module is installed in the backup module enclosure.
- Storage system power is turned on.
- The red `STATUS` LED on the backup module to be replaced is on.
- Use the Detail Dump tool to collect the storage system information.

Procedure

1. Start the maintenance utility.
2. Click **Hardware > Controller Chassis**.
3. Click the **BKMs** tab.




4. Confirm that the status of the backup module to be replaced is `Warning`.

Replacing the BKM backup module

Use the following procedure to replace the BKM backup module.

Procedure

1. Loosen the blue screw that secures the BKM.
2. Open the lever forward.
3. Using both hands, hold the body of the BKM, and then pull out and remove the BKM.
4. With the lever of the BKM opened forward, insert the new BKM into the slot.



5. Push the BKM all the way into the slot.
6. Close the lever and tighten the blue screw to secure the BKM.
7. Confirm that the green `STATUS` LED on the BKM is blinking.
8. In the **BKMS** tab of the maintenance utility, check that the status of the BKM you replaced is `Normal`.
9. Log out and close the **Maintenance Utility** window

Replacing a BKMF

The following sections describe how to replace a BKMF backup module.


Blocking a BKMF

Prerequisites

- A backup module is installed in the backup module enclosure.
- Storage system power is turned on.
- The red `STATUS` LED on the backup module to be replaced is on.
- Use the Detail Dump tool to collect the storage system information.

Procedure

1. Start the maintenance utility.
2. Click **Hardware > Controller Chassis**.
3. Click the **BKMFs** tab.



4. Confirm that the status of the backup module to be replaced is **Warning**.

Replacing the BKMF backup module

Prerequisites

- Wear a wrist strap connected to the storage system to prevent part failures caused by static electricity. Do not remove the wrist strap until you finish the procedure.
- Storage system power is turned on.
- The red **STATUS** LED on the backup module to be replaced is on.
- Use the Detail Dump tool to collect the storage system information.
- Use the maintenance utility to verify the backup module status.

Procedure

1. Loosen the blue screw that secures the backup module.
2. Open the lever forward.
3. Open the lever.
4. Hold the backup module with both hands, and then pull it out and remove it.


5. Hold the latch of the cable connector of the battery to be installed in the backup module and remove the connector from the socket.
6. Remove all batteries that are installed.

A maximum of two batteries can be installed.

7. Loosen the blue screw on the rear side of the new backup module.
8. Slide the top panel of the new backup module and remove it.
9. In the new backup module, install all batteries you removed and route the cables along the groove of the backup module.

If you removed one battery, install the battery in the front (fan side) of the storage system. Route the cables to avoid bending the cables.

10. Connect the cable connector to the socket.
11. Slide the top panel of the backup module and attach it.
12. Tighten the blue screw on the rear panel of the backup module.
13. With the lever of the backup module opened forward, insert the new backup module into the slot.



14. Push all the way into the slot.
15. Close the lever and tighten the blue screw to secure the backup module.
16. Confirm that the green `STATUS` LED on the BKMF is blinking.

- 17.** In the **BKMFs** tab of the maintenance utility, check that the status of the backup module you replaced is `Normal`.
If necessary, click **Refresh** at the top-right of the window to update the status.
- 18.** Log out and close the **Maintenance Utility** window.

General maintenance

This chapter provides general maintenance procedures.

- ☐ [Periodic maintenance](#)
- ☐ [Cleaning the storage system](#)
- ☐ [Inspecting fans](#)
- ☐ [Replacing the battery](#)
- ☐ [Checking for loose or damaged cables or connectors](#)
- ☐ [Restarting the storage system](#)
- ☐ [Storing the storage system](#)

Periodic maintenance

The following table describes the periodic maintenance procedures you can perform to extend the life of your storage system. Inspect and clean the storage system regularly according to the operation environment.

Maintenance	Interval	Approximate time to perform procedure
Clean the storage system	Once a year	5 minutes
Inspect the fan	Once a year	5 minutes
Replace the battery	Every 3 years	10 minutes

Cleaning the storage system

When cleaning the storage system, check whether the system's air vents are clogged by dust. If they are clogged, remove the dust with a vacuum cleaner or wipe the dust using a dry cloth.

Keep the front bezel and rear panel clean. Otherwise, storage system ventilation deteriorates and the inside temperature might rise, causing a failure or fire.

Do not move the storage system during cleaning.

Procedure

1. Clean the outside of the front bezel.
2. Insert the key in the front bezel and turn in the direction shown by the arrow to unlatch the bezel.



Caution: Attach or remove the front bezel carefully to avoid pinching your fingers. Do not touch "live parts;" otherwise, you can receive an electric shock.

3. Remove the front bezel.
4. Clean the internal surfaces of the front bezel.
5. Attach the front bezel.
6. Turn the key in the direction shown by the allow to latch the front bezel.
7. Clean the external surfaces of the rack.

Inspecting fans

Inspect the fans when storage system power is turned on.



Caution: Storage system fans rotate at high speed. Exercise extreme caution to avoid getting anything caught in the fan and to prevent injury.

Procedure

1. Gain access to the inside of the rack.
2. Open the front bezel of the storage system.
3. Confirm that the storage system fans are rotating
4. Close the front bezel, and then close the rack.

Replacing the battery

Each controller contains a sealed battery that provides backup power to cache memory. You must replace the battery every three years.



Note: Do not disassemble the battery; otherwise, you could get burned or receive a shock.

If the storage system does not receive power for more than six months, the battery can become discharged and possibly damaged. To avoid this situation, charge the battery for more than three hours at least once every six months.

Checking for loose or damaged cables or connectors

It is good practice to check cables for damage on a periodic basis. Confirm that all cables and cable connectors are in good condition and connected securely to the appropriate interfaces.

Restarting the storage system

Before restarting the storage system, wait at least one minute with the main switch off (amber **POWER** LED is off).

Storing the storage system

If the storage system does not receive power for more than six months, the battery can become discharged and possibly damaged. To avoid this situation, charge the battery for more than three hours at least once every six months.



Note: Do not store the equipment in an environment with temperatures of 104°F (40°C) or higher because battery life will be shortened.

Troubleshooting

This chapter covers troubleshooting topics related to the replacement of components.

- ☐ [General troubleshooting](#)
- ☐ [Troubleshooting Hitachi Device Manager - Storage Navigator](#)
- ☐ [Dump tool](#)
- ☐ [Troubleshooting the maintenance utility](#)
- ☐ [Checking alerts](#)
- ☐ [Turning the storage system on or off using the maintenance utility](#)
- ☐ [Using LEDs to diagnose problems](#)

General troubleshooting

Correct values for the storage system IP address

Set appropriate value IP address, subnet mask, and default gateway settings for the storage system for the customer environment.

IPv4 default value

Controller 1:
Controller 2:
IP Address: 192.168.0.16
Subnet Mask: 255.255.255.0
Default gateway: 0.0.0.0
Controller board #2:
IP Address: 192.168.0.17
Subnet Mask: 255.255.255.0
Default gateway: 0.0.0.0

IPv6 default value

Controller 1:
IP Address: Auto
Controller 2:
IP Address: Auto

DHCPv4 configuration for storage systems

If the storage system is configured to use DHCPv4, connect with the IP address assigned by the DHCPv4 server. When using DHCPv4 server, configure the storage system to use a static IP address.

If the storage system does not receive an IP address from a DHCP server when it is configured for DHCP, Hitachi Device Manager - Storage Navigator cannot connect to the storage system. Contact your network administrator, and review the DHCPv4 server settings.

Default value

DHCPv4: Off (Static IP Address)

IP address being used by other storage systems or hosts

If the storage system is using the same IP address is used by other devices, Hitachi Device Manager - Storage Navigator cannot connect to the storage system. Assign an IP address to the storage system that is not used by another device.

IP address configuration for the host

Use Hitachi Device Manager - Storage Navigator to set the IP address, subnet mask, and default gateway that the host can use to communicate with the storage system.

TCP/UDP port filtering being performed on the network switch

The default TCP port number for Hitachi Device Manager - Storage Navigator is 2000. Set an appropriate value for the customer's environment.

```
[default port number]: 2000 (standard)
28355 (secure)
```

Change the port number in environments that use Cisco SIP Phones.

Search Storage system performed across the IPv6 routers

The Auto Search Storage system of IPv6 uses link-local scope multicast. The IPv6 router is unable to transfer this multicast to other local links, so the IPv6 router is unable to search storage systems across the IPv6 router. For different local links, register the storage system using a static IP address search.

Troubleshooting Hitachi Device Manager - Storage Navigator

Message ID	Description	Recovery Action
21542 005011	Clicking the Apply button in the Add System window caused the error, and the storage icon is not created.	The SVP does not have sufficient free space to create the storage icon. Make 20 GB or more of free space available in the installation directory of the drive.
21542 005019	Clicking Start Service caused the error, and the service cannot start.	Two or more services cannot be executed simultaneously. Stop the service that started before starting the other service.
21542 005026	Clicking Start Service caused the error and the service cannot start.	The SVP IP address is invalid. At the top-right of the screen of the Storage Device List window, click SVP IP Address. In the Change SVP IP Address window, set the IP address of the SVP, and then retry Start Service.
21542 005026	The status of the service changed to Error after rebooting the SVP with the Start-up service set to Auto . The Service Status window shows the error, and the Status field shows BASE .	The SVP IP address is invalid. At the top-right of the screen of the Storage Device List window, click SVP IP Address. In the Change SVP IP Address window, set the IP address of the SVP, and then retry Start Service.

Message ID	Description	Recovery Action
21041-006002	Clicking the storage system in the Storage Device List window caused the error, and Hitachi Device Manager - Storage Navigator cannot start.	The default browser is not defined. Specify your browser as the default browser (refer to the documentation for your browser) and retry.
21041-006005	Starting the Storage Device List caused the error, and the Storage Device List cannot start.	Failed to connect to the Supervisor service (DKCMan/MAPPAppServer/MAPPWebServer). Select Control Panel > Administrative Tools > Services in Windows, and confirm that the DKCMan, MAPPAppServer, and MAPPWebServer services started. Start the Storage Device List again. If the status of DKCMan, MAPPAppServer, and MAPPWebServer did not start, right-click the service and select Start, or reboot the SVP.

Dump tool

About the Dump tool

Use the Dump tool to collect Hitachi Device Manager - Storage Navigator configuration information.

You can use the collected dump files:

- Before deleting the storage management software.
- To collect the dump files from the SVP.
- To troubleshoot using Device Manager - Storage Navigator.
- To check the Device Manager - Storage Navigator configuration. In Device Manager - Storage Navigator, click File > Refresh All to update the configuration information, and then use the Dump tool to collect dump files.

The Dump tool has two files.

- `Dump_Normal.bat` collects dump files containing information about the SVP and minimum information about the storage system. Use this tool when there is no fatal error, such as a problem with accessing Device Manager - Storage Navigator.
- `Dump_Detail.bat` collects detailed dump files and contains comprehensive information about the storage system in addition to the contents of the normal dump file. Use this tool if you cannot start Device Manager - Storage Navigator or to check for problems with the storage system.

Using the Dump tool

Prerequisites

- The client PC must be connected to the SVP using the Remote Desktop Connection.
- No other user should be using the Dump tool.
- No maintenance operation is being performed.

Procedure

1. Close all Hitachi Device Manager - Storage Navigator sessions on the SVP.
2. On the SVP, exit to a Windows command prompt as Administrator.
3. Change to the directory where the Dump tool is located.
For example, `C:\Mapp\wk\83xxxxxxx\DKC200\mp\pc` where `83xxxxxxx` is the DKC serial number.
4. Specify the output folder for the dump file (for example, `C:\Mapp\wk\83xxxxxxx\DKC200\tmp`) as an output destination, and then execute `Dump_Normal.bat` OR `Dump_Detail.bat`.
5. When the completion message appears, close the command prompt.
6. Under the output destination folder, check that the following files are created.:
 - `hdcp.tgz` = dump file
 - `zSv_AutoDump.log` = dump tool log file. If the dump file was not created, give this log file to your administrator. Otherwise, delete the log file.
7. Exit the command prompt.

Collecting dump files manually

If you cannot use the Dump tool or the Dump tool fails, collect the following dump files manually.



Note: In the following list:

- `installDir` = the SVP installation directory (for example, `C:\Mapp`).
- `%USERPROFILE%` = the installation login user of the SVP (for example, `C:\Users\<user name>`).
- `%WINDIR%` = the Windows folder in the system drive (for example, `C:\Windows`).

```
<installDir>\wk\supervisor\dkcman\log\*.*
```

```
<installDir>\wk\supervisor\dkcman\cnf\*.*
```

```
<installDir>\wk\supervisor\rmiserver\log\*.*
```

```

<installDir>\wk\supervisor\rmiserver\cnf\*.*
<installDir>\wk\supervisor\sdlist\log\*.*
<installDir>\wk\supervisor\mappiniset\logs\MappIniSet\*.*
<installDir>\OSS\apache\logs\*.log
<installDir>\OSS\apache\logs\ssl\*.log
<installDir>\OSS\jetty\logs\*.log
%USERPROFILE%\AppData\LocalLow\Sun\Java\Deployment\log
%WINDIR%\system32\config\SysEvent.Evt
%WINDIR%\system32\config\SecEvent.Evt
%WINDIR%\system32\config\AppEvent.Evt
%WINDIR%\minidump\*.dmp
%WINDIR%\System32\Winevt\Logs\Application.evtx
%WINDIR%\System32\Winevt\Logs\Security.evtx
%WINDIR%\System32\Winevt\Logs\System.evtx
%WINDIR%\system32\drivers\etc\HOSTS*
%WINDIR%\system32\drivers\etc\services*
%WINDIR%\minidump\*.dmp
c:\SetupTrace\*.*

```

Troubleshooting the maintenance utility

JavaScript security

The **Maintenance Utility** window opens, but it is blank, even after one or more minutes elapse.

Use the following procedure to add the **Maintenance Utility** window to the trusted sites, and then open the **Maintenance Utility** window again.

Procedure

1. In Internet Explorer, select **Tools > Internet Options** and select the **Security** tab.
2. Click **Trusted Sites > Sites**.
3. Clear the **Require server verification (https:) for all sites in this zone** check box.

4. Enter the IP address of controller 1 to **Add this website to the zone** and click **Add**.
5. Add the IP address of controller 2 using the same method.
6. Click **Close**.
7. When returning to the **Internet Options** window, click **OK** to close the window.

Compatibility view

Contents displayed in the **Maintenance Utility** window may be corrupted. Exclude the maintenance utility from the compatibility view target. In Internet Explorer, check the Compatibility View on the address bar. In Internet Explorer versions 10 and earlier:

Procedure

1. Select **Tools > Compatibility View setting**.
2. Clear the **Display intranet sites in Compatibility View** and the **Display all websites in Compatibility View** check box.
3. Click **Close**.

Clearing the browser cache

In the unlikely event that the login to the **Maintenance Utility** window fails, or the **Maintenance Utility** window opens but is blank, even after one or more minutes elapse, clear the browser cache and open the **Maintenance Utility** window again.

Forcing browser refreshes of the Maintenance Utility window

If images in the **Maintenance Utility** window do not appear properly, refresh your web browser.

To refresh your web browser:

Procedure

1. If the maintenance utility is open, log out.
2. Press the **Ctrl** key and **F5** key at the same time to force a refresh.

Maintenance Utility window hangs

The maintenance utility provides a locking feature you can use in case the window freezes (or "hangs").

In the unlikely event that the **Maintenance Utility** window "hangs" during normal operation:

Procedure

1. Check the network connection between the SVP and the storage system.

2. Log out of the SVP, and then log in again.
3. When the `System Locked` message appears, click **System Locked** to unlock the system.


Checking alerts

If an alert, warning, or information item appears in the maintenance utility, but there is no service information message (SIM) associated with it, use the following procedure to obtain more information about the item.

Procedure

1. In the navigation area of the **Maintenance Utility** window, check the status of the storage system.

- In the header area, click **Alert**.
The **Alerts** tab appears.



Status	Description	Navigation area	Alert color
Failed	The storage system might be down.		Red
Warning	A part has a Blocked, Failed, or Warning status.		Amber
Information	Alert does not have a SIM defined for it.		Amber
Ready	All parts have a normal status.		Green
Power-on in progress	Power-on is in progress.		—
Power-off in progress	Power-off is in progress.		—

Status	Description	Navigation area	Alert color
Unknown	The storage system is in an unknown state prior to power on..	Unknown	—

3. In the **Alerts** tab, click **DKC** and **GUM**, and then check the alerts.

Maintenance Utility HITACHI

Alert System Unlocked Logged in as: Log Out ?

Storage System

S/N: 400001
CTL1

Warning

Hardware

Controller Chassis
Drive Box - 00

Administration

Menu

- Initial Setup Wizard
- Power Management
- System Management

Storage System Last Updated : 2014/07/29 14:38

Set up System Information

Storage System Name	StorageSystem	IPv4 Address	CTL1	192.168.0.16
Contact		CTL2	192.168.0.17	
Location		IPv6 Address	CTL1	::
Storage System Type		CTL2	::	
Serial Number	400001	Temperature	26 degree C	

Number of Drives	Data	Spare	Free	Total
Drive Capacity	8	0	0	8
	9.59 TB	0 B	0 B	9.59 TB


Chassis Drives **Alerts**

View Internal Alerts Total: 11 **DKC** **GUM**

Alert ID	Date and Time ▲	Reference Code	Error Level	Error Section	Error Detail
98	2014/08/29 19:25:14	aff101	Warning		
98	2014/08/29 19:25:14	aff101	Warning		
87	2014/08/29 16:33:34	aff100	Warning		
87	2014/08/29 16:33:34	aff100	Warning		
41	2014/08/29 03:17:09	fe0100	Normal		
41	2014/08/29 03:17:09	fe0100	Normal		
28	2014/08/29 02:06:21	af4003	Warning		
33	2014/08/29 02:06:21	af4007	Warning		
28	2014/08/29 02:06:21	af4003	Warning		
33	2014/08/29 02:06:21	af4007	Warning		
23	2014/08/29 02:06:07	627000	Warning		

- Under the **Alert ID** column, click an entry.
The **Alert Detail** window appears.

Alert Detail

Alert ID	98
Date and Time	2014/08/29 19:25:14
Reference Code	aff101
Error Level	 Warning
Error Section	
Error Detail	
Location	
Concerned Alert ID	99

Action Codes

Action Code	Possible Failure Parts	Location

Total: 0

Close

- To check the internal alert, click **Internal Alerts (DKC)** or **Internal Alerts (GUM)** from the **View Internal Alerts** list. Click an entry under **Alert ID**.

6. When the **Alert Detail** window appears, check the alert information:
- SSB shows high-priority error information.
 - SSBS = shows low-priority error information.

SSB Tab in the Internal Alerts (DKC) Window

Internal Alerts (DKC)

SSB

SSBS

← ← 1 /1138 → →

Alert ID	Date and Time ▲	F/M	Error Code
123456	2014/01/02 12:59:59	x7	6789
123463	2014/01/02 10:59:59	x4	0156
123452	2014/01/01 23:59:59	x3	2345
123459	2014/01/01 23:59:59	x0	9012
123460	2014/01/01 22:59:59	x1	9023
123461	2014/01/01 21:59:59	x2	9034
123462	2014/01/01 20:59:59	x3	9045
123457	2014/01/01 15:59:59	x8	7890
123453	2014/01/01 12:59:59	x4	2456

Total: 10240

Close

SSBs Tab in the Internal Alerts (DKC) Window

Internal Alerts (DKC)

SSB

SSBS

← ← 1 /1138 → →

Alert ID	Date and Time ▲	F/M	Error Code
123456	2014/01/02 12:59:59	x7	6789
123463	2014/01/02 10:59:59	x4	0156
123452	2014/01/01 23:59:59	x3	2345
123459	2014/01/01 23:59:59	x0	9012
123460	2014/01/01 22:59:59	x1	9023
123461	2014/01/01 21:59:59	x2	9034
123462	2014/01/01 20:59:59	x3	9045
123457	2014/01/01 15:59:59	x8	7890
123453	2014/01/01 12:59:59	x4	2456

Total: 10240

Close

Internal Alerts (GUM) Window

Internal Alerts (GUM)

SSB

← ← 1 /2276 → →

Alert ID	Date and Time ▲	F/M	Error Code
123456	2014/01/02 12:59:59	x7	6789
123463	2014/01/02 10:59:59	x4	0156
123452	2014/01/01 23:59:59	x3	2345
123459	2014/01/01 23:59:59	x0	9012
123460	2014/01/01 22:59:59	x1	9023
123461	2014/01/01 21:59:59	x2	9034
123462	2014/01/01 20:59:59	x3	9045
123457	2014/01/01 15:59:59	x8	7890
123453	2014/01/01 12:59:59	x4	2456

Total: 10240

Close

Turning the storage system on or off using the maintenance utility

In the unlikely event the SVP will not run or it cannot connect to the storage system, you can power on and off the storage system using the maintenance utility.

Prerequisites

- The breaker is turned on.
- The amber `POWER` LED on the storage system is on.

Procedure

1. Start the browser on the client PC.
2. In the browser address bar, enter the address of controller 1, and press **Enter**.
The login window opens.
3. Log in.
The **Maintenance Utility** window opens.
4. To power on the storage system, select **Power Management > Power on Storage System**. When the confirmation message appears, click **Submit**.
5. To power off the storage system, select **Power Management > Power off Storage System**. When the confirmation message appears, click **Submit**.

Using LEDs to diagnose problems

If the storage system used in a remote TrueCopy configuration restarts with the TrueCopy status of `enabled`, the following occur:

- The path used by TrueCopy becomes blocked. Notifications from the Hitachi Device Manager - Storage Navigator email alert function, SNMP Agent Support function, and TRAP occur when the path is blocked. Follow the instructions in the notification. The blocked path recovers automatically after restarting the storage system.
- If the TrueCopy pair status is `PAIR` or `COPY`, the pair changes to `PSUE`. In this case, suspend the pairs before restarting the storage system.

POWER LED does not go on

Procedure

1. Set the main switch to on.

2. Is the **POWER** LED on at the controller?
 - Yes: Go to step 10.
 - No: Power on the host computer.
3. Is the **POWER** LED on at the controller?
 - Yes: Go to step 10.
 - No: Set the main switch to off.
4. Check that the PDU on the rack is delivering power to the storage system.
5. Verify that the AC cable is correctly connected to the plug socket and the equipment.
6. Set the main switch to on.
7. Is the **POWER** LED on at the controller?
 - Yes: Go to step 10.
 - No: Set the main switch to off.
8. Contact your administrator. Go to step 10.
9. Is the **READY** LED on?
 - Yes: Continue to use the equipment, even if the green **READY** LED blinks fast.
 - No: See *READY LED does not go on or READY LED went on and then off*.
10. End of procedure.

POWER LED turned off

Procedure

1. Is AC power being supplied?
 - Yes: Go to step 2.
 - No: Supply AC power to the storage system and restart the storage system. Go to step 2.
2. Set the main switch to off.
3. Wait over a minute and then set the main switch to on.
4. Is the **POWER** LED on at the controller?
 - Yes: go to step 6.
 - No: set the main switch to off.
5. Contact your administrator. Go to step 7.
6. Is the **READY** LED on at the controller?
 - Yes: Use the equipment in its current operational state, even if the green **READY** LED blinks fast.
 - No: See *READY LED does not go on or READY LED when on and then off*.
7. End of procedure.

READY LED does not go on or READY LED went on and then off

Procedure

1. Is the controller **POWER** LED on?
 - Yes: Go to step 2.
 - No: Go to step 4 in *POWER LED does not go on*.
2. Is the **ALARM** LED on at the controller?
 - Yes: See *ALARM LED is on*.
 - No: Go to step 3.
3. Turn off the main switch.
4. Wait more than one minute and then set the main switch to on.
5. Is the **READY** LED on at the controller?
 - Yes: Continue to use the equipment. If the green **READY** LED blinks fast, the storage system is operational. Go to step 8.
 - No: Go to step 8.
6. Set the main switch to off.
7. Contact your system administrator.
8. End of procedure.

ALARM LED is on.

Procedure

1. Identify which components failed.
2. Contact your system administrator and do not disturb the equipment.

WARNING LED goes on or blinks.

Procedure

1. Does the amber **WARNING** LED on the controller blink fast?
 - Yes: Identify which components in the controller chassis failed using Hitachi Device Manager - Storage Navigator. Go to step 5.
 - No: Go to step 2.
2. Does the amber **WARNING** LED at the controller blink slowly?
 - Yes: At the controller, wait for the amber **WARNING** LED to go off and the green **READY** LED to go on.
 - No: Go to step 3.
3. Is the green **READY** LED at the controller on?
 - Yes: Go to step 5.
 - No: See *READY LED does not go on or READY LED went on and then off*.
4. Continue to use the equipment and contact your system administrator.
5. End of procedure.


Warning labels on the storage system

- ☐ [CBSS controller](#)
- ☐ [CBSL controller](#)
- ☐ [CBLM controller](#)
- ☐ [Small form factor drive tray](#)
- ☐ [Large form factor drive tray](#)
- ☐ [Flash module drive tray](#)
- ☐ [Dense intermix drive tray](#)
- ☐ [CBSS/CBSL controller](#)
- ☐ [CBLM controller](#)
- ☐ [Drive for a CBSS/small form factor drive tray](#)
- ☐ [Drive for a small form factor drive tray](#)
- ☐ [Drive for a CBSL/large form factor drive tray](#)
- ☐ [Drive for a large form factor drive tray](#)
- ☐ [Drive for a flash module drive tray](#)
- ☐ [Drive for a dense intermix drive tray](#)
- ☐ [CBSS/CBSL power unit](#)

- ☐ [CBLM power supply](#)
- ☐ [Power supply for small and large form factor drive trays](#)
- ☐ [Flash module drive tray power supply](#)
- ☐ [Dense intermix drive tray power supply](#)
- ☐ [Front end module \(Fibre Channel/iSCSI\)](#)
- ☐ [Back end module](#)
- ☐ [ENC for small and large form factor drive trays](#)
- ☐ [ENC for a dense intermix drive tray](#)
- ☐ [CMA \(used to secure dense intermix drive tray\)](#)
- ☐ [Battery](#)

CBSS controller

⚠ CAUTION Take care not to drop Dropping the array may cause injury, keep hands securely on array. Be aware of the red line marked on the array top - When sliding the array out of the rail terminal past this mark, keep a firm hold on the array.	⚠ 注意 落下注意 装置が落下してけがをする危険があります。装置上面の赤い線を越えて引き出す場合、装置を両手でしっかりと持ってください。	⚠ VORSICHT Nicht fallen lassen Beim Herunterfallen des Arrays können Personen verletzt werden. Halten Sie das Array stets sicher mit Ihren Händen fest. Beachten Sie die rote Linie, die oben des Arrays angebracht ist.	⚠ PRECAUCIÓN Tenga cuidado para evitar caídas Dejar caer la cabina puede causar lesiones. Mantenga las manos de forma segura en la cabina. Respete la línea roja marcada en la parte superior de la cabina.	⚠ ATTENTION Prenez garde de ne pas laisser tomber Le fait de laisser tomber le cadre peut occasionner des blessures. Tenez les mains fermement sur le cadre. Tenez compte de la ligne marquée en rouge sur le haut du cadre.
⚠ CAUTION Heavy Lifting the heavy array may cause injury in your arms or low back. Use lifting equipment or handle the array with two or more personnel. This array weighs approximately 46kg.	⚠ 注意 重量物注意 重量物を持ち上げると、腕や腰を痛めます。リフターを使用したり、2人以上で使ったりしてください。 装置重量は約46 kgです。	⚠ VORSICHT Hohes Gewicht Beim Anheben des schweren Arrays könnten Ihre Arme oder Ihr unterer Rücken verletzt werden. Verwenden Sie eine Hebevorrichtung oder transportieren Sie das Array mit mindestens zwei Personen. Dieses Array wiegt etwa 46kg.	⚠ PRECAUCIÓN Peso elevado Levantar una cabina pesada puede causar lesiones en los brazos o la región lumbar. Utilice un dispositivo de elevación o levante la cabina con la ayuda de dos o más personas. Este cabina posee un peso aproximado de 46kg.	⚠ ATTENTION Poids Le fait de soulever le cadre qui est lourd peut entraîner des lésions aux bras ou au bas du dos. Utilisez un équipement de levage ou manipulez le cadre à deux personnes ou plus. Ce cadre pèse environ 46kg.
NOTICE Avoid damage - do not carry the array by its front side. Lift or carry the array by its left, right, or rear sides. Avoid damage to the base - do not place the array directly on the floor or table while the base is attached. Remove the base as needed to prevent weight from being applied to the base. Avoid damage to the chassis - do not place anything on top of the array.	通知 運搬時は、装置前面を触らないでください。奥面および側面を持って、持ち上げたり運んだりしてください。装置にべんがらが付いた状態で、平置きしないでください。べんがらが脱落する恐れがありますので、べんがらを動作するか、べんがらに力がかからないように避けてください。シャーシが変形する恐れがあります。装置の上には何も置かないでください。	HINWEIS Vermeiden Sie Beschädigungen - tragen Sie das Array nicht an seiner Vorderseite. Heben oder tragen Sie das Array an seiner linken, rechten oder hinteren Seite. Beschädigen Sie nicht die Basis - legen Sie das Array nicht direkt auf den Boden oder einen Tisch, wenn die Basis angebracht ist. Entfernen Sie die Basis bei Bedarf, damit sie keine Gewicht unterstützen wird. Beschädigen Sie nicht das Gehäuse - stellen Sie keine Gegenstände oben auf das Array.	AVISO Evite daños: no transporte la cabina desde su lado frontal. Levante o transporte la cabina desde el lado izquierdo, derecho o trasero. Evite causar daños en el marco: no coloque la cabina directamente sobre el piso o mesa cuando el marco se encuentra colocado. Extraiga el marco según sea necesario para evitar que el peso quede apoyado sobre el marco. Evite causar daños al chasis: no coloque ningún objeto sobre la parte superior de la cabina.	AVIS Pour éviter les dégâts - ne portez pas le cadre par sa face avant. Soulevez ou transportez le cadre par ses côtés gauche, droit, ou arrière. Pour éviter d'endommager le porteur - ne posez pas le cadre directement au sol ou sur une table lorsque le porteur est attaché. Retirez le porteur du cadre à éviter que le poids ne s'appuie sur le porteur. Pour éviter d'endommager le châssis - ne posez rien sur le dessus du cadre.




CBSL controller

<p>⚠ CAUTION Take care not to drop</p> <p>Dropping the array may cause injury. keep hands securely on array. Be aware of the red line marked on the array top - When sliding the array out of the rail terminal past this mark, keep a firm hold on the array.</p>	<p>⚠ 注意 落下注意</p> <p>設置が落下してけがをする危険があります。設置上蓋の赤い線を離れて引き出す場合、設置を両手でしっかりと持ってください。</p>	<p>⚠ VORSICHT Nicht fallen lassen</p> <p>Beim Herunterfallen des Arrays können Personen verletzt werden. Halten Sie das Array stets sicher mit Ihren Händen fest. Beachten Sie die rote Linie, die oben des Arrays angebracht ist.</p>	<p>⚠ PRECAUCIÓN Tenga cuidado para evitar caídas</p> <p>Dejar caer la cabina puede causar lesiones. Mantenga las manos de forma segura en la cabina. Respete la línea roja marcada en la parte superior de la cabina.</p>	<p>⚠ ATTENTION Prenez garde de ne pas laisser tomber</p> <p>Le fait de laisser tomber le cadre peut occasionner des blessures. Tenez les mains fermement sur le cadre. Tenez compte de la ligne marquée en rouge sur le haut du cadre.</p>
<p>⚠ CAUTION Heavy</p> <p>Lifting the heavy array may cause injury in your arms or low back. Use lifting equipment or handle the array with two or more personnel. This array weighs approximately 46kg.</p>	<p>⚠ 注意 重量物注意</p> <p>重量物を持ち上げると、腕や腰を傷めます。リフターを使用したり、2人以上で持ったりしてください。設置重量は約46 kgです。</p>	<p>⚠ VORSICHT Hohes Gewicht</p> <p>Beim Anheben des schweren Arrays könnten Ihre Arme oder Ihr unterer Rücken verletzt werden. Verwenden Sie eine Hebevorrichtung oder transportieren Sie das Array mit mindestens zwei Personen. Dieses Array wiegt etwa 46kg.</p>	<p>⚠ PRECAUCIÓN Peso elevado</p> <p>Levantar una cabina pesada puede causar lesiones en los brazos o la región lumbar. Utilice un dispositivo de elevación o levante la cabina con la ayuda de dos o más personas. Esta cabina posee un peso aproximado de 46kg.</p>	<p>⚠ ATTENTION Poids</p> <p>Le fait de soulever le cadre qui est lourd peut entraîner des lésions aux bras ou au bas du dos. Utilisez un équipement de levage ou manipulez le cadre à deux personnes ou plus. Ce cadre pèse environ 46kg.</p>
<p>NOTICE</p> <p>Avoid damage - do not carry the array by its front side. Lift or carry the array by its left, right, or rear sides. Avoid damage to the bezel - do not place the array directly on the floor or table while the bezel is attached. Remove the bezel as needed to prevent weight from being applied to the bezel. Avoid damage to the chassis - do not place anything on top of the array.</p>	<p>通知</p> <p>運搬時は、設置前面を持たないでください。取組する恐れがあります。前面および後面を持って、持ち上げたり運んだりしてください。設置にベゼルが取り付けられた状態で、作業しないでください。ベゼルが破損する恐れがありますので、ベゼルを脱着するか、ベゼルに外力が加からないように置いてください。シャーシが破損する恐れがあります。設置の上面に何も置かないでください。</p>	<p>HINWEIS</p> <p>Vermeiden Sie Beschädigungen - tragen Sie das Array nicht an seiner Vorderen Seite. Heben oder tragen Sie das Array an seiner linken, rechten oder hinteren Seite. Beschädigen - legen Sie das Array nicht direkt auf den Boden oder einen Tisch, wenn die Binde angebracht ist. Entfernen Sie die Binde bei Bedarf, damit sie keine Beschädigung verursacht. Beschädigen Sie nicht das Gehäuse - stellen Sie keine Gegenstände oben auf das Array.</p>	<p>AVISO</p> <p>Evite daños: no transporte la cabina desde su lado frontal. Levante o transporte la cabina desde el lado izquierdo, derecho o trasero. Evite causar daños en el marco: no coloque la cabina directamente sobre el piso o una mesa cuando el marco se encuentra colocado. Extraiga el marco según sea necesario para evitar que el peso quede apoyado sobre el marco. Evite causar daños al chasis: no coloque ningún objeto sobre la parte superior de la cabina.</p>	<p>AVIS</p> <p>Pour éviter les dégâts - ne portez pas le cadre par sa face avant. Soulevez ou transportez le cadre par ses côtés gauche, droit, ou arrière. Pour éviter d'endommager le porteur - ne posez pas le cadre directement au sol ou sur une table lorsque le porteur est attaché. Retirez le porteur de sorte à éviter que le poids ne repose sur le porteur. Pour éviter d'endommager le châssis - ne posez rien sur le dessus du cadre.</p>


<p>通知</p> <p>この装置は、電源の電圧が変動する場合があります。電源が変動する場合は、電源を切断してください。</p>	<p>NOTICE</p> <p>The array has a dual power supply configuration. To remove electricity from the array, unplug the two power cables from the power source.</p>	<p>HINWEIS</p> <p>Das Array hat eine doppelte Energieversorgungsanordnung. Um die Elektrizität aus dem Array zu entfernen, ziehen Sie beide Kabel aus der Stromquelle.</p>	<p>AVISO</p> <p>Este controlador tiene una configuración dual de la fuente de alimentación. Al eliminar la electricidad del controlador, desconecte los cables de la fuente de alimentación.</p>	<p>AVIS</p> <p>Ce contrôleur est équipé d'un système de source d'alimentation dual. Afin de couper le courant du contrôleur, déconnectez les deux câbles de la source d'alimentation.</p>
---	---	---	---	--

CBLM controller




Small form factor drive tray

⚠ CAUTION Take care not to drop Dropping the array may cause injury. Keep hands securely on array. Be aware of the red line marked on the array top and sides - When sliding the array out of the rail terminal past this mark, keep a firm hold on the array.	⚠ 注意 落下注意 装置が落下してけがをする危険があります。装置上面および側面の赤い線を越えて引き出す場合、装置を両手でしっかりと持ってください。	⚠ VORSICHT Nicht fallen lassen Beim Herunterfallen des Arrays können Personen verletzt werden. Halten Sie das Array stets sicher mit Ihren Händen fest. Beachten Sie die rote Linie, die oben und an den Seiten des Arrays angebracht ist.	⚠ PRECAUCIÓN Tenga cuidado para evitar caídas Dejar caer la cabina puede causar lesiones. Mantenga las manos de forma segura en la cabina. Respete la línea roja marcada en la parte superior y lateral de la cabina.	⚠ ATTENTION Prenez garde de ne pas laisser tomber Le fait de laisser tomber le cadre peut occasionner des blessures. Tenez les mains fermement sur le cadre. Tenez compte de la ligne marquée en rouge sur le haut et sur les côtés du cadre.
⚠ CAUTION Heavy Lifting the heavy array may cause injury in your arms or low back. Use lifting equipment or handle the array with two or more personnel. This array weighs approximately 23kg.	⚠ 注意 重量物注意 重量物を持ち上げると、腕や腰を痛めます。リフターを使用したり、2人以上で渡ったりしてください。装置重量は約 23 kgです。	⚠ VORSICHT Hohes Gewicht Beim Anheben des schweren Arrays könnten Ihre Arme oder Ihr unterer Rücken verletzt werden. Verwenden Sie eine Hebevorrichtung oder transportieren Sie das Array mit mindestens zwei Personen. Dieses Array wiegt etwa 23kg.	⚠ PRECAUCIÓN Peso elevado Levantar una cabina pesada puede causar lesiones en los brazos o la región lumbar. Utilice un dispositivo de elevación o levante la cabina con la ayuda de dos o más personas. Esta cabina posee un peso aproximado de 23kg.	⚠ ATTENTION Poids Le fait de soulever le cadre qui est lourd peut entraîner des lésions aux bras ou au bas du dos. Utilisez un équipement de levage ou manipulez le cadre à deux personnes ou plus. Ce cadre pèse environ 23kg.
NOTICE Avoid damage - do not carry the array by its front side. Lift or carry the array by its left, right, or rear sides. Avoid damage to the base - do not place the array directly on the floor or table while the base is attached. Remove the base as needed to prevent weight from being applied to the base. Avoid damage to the chassis - do not place anything on top of the array.	通知 運搬時は、装置前面を触らないでください。装置前面を触ると、破損する恐れがあります。側面および後面を持って、持ち上げたり運んだりしてください。装置にべゼンが取り付けられている状態で、平置きしないでください。べゼンが破損する恐れがありますので、べゼンを取付するか、べゼンに外力が加わらないように置いてください。シャーシが変形する恐れがあります。装置の上面に何も置かないでください。	HINWEIS Vermeiden Sie Beschädigungen - tragen Sie das Array nicht an seiner Vorderseite. Heben oder tragen Sie das Array an seiner linken, rechten oder hinteren Seite. Beschädigen Sie die Basis, indem Sie das Array nicht auf den Boden oder eine Tischplatte direkt auflegen. Entfernen Sie die Basis bei Bedarf, damit sie keine Gewichtsmasse trägt. Vermeiden Sie Schäden am Gehäuse - stellen Sie keine Gegenstände auf das Array.	AVISO Evite daños: no transporte la cabina desde su lado frontal. Levante o transporte la cabina desde el lado izquierdo, derecho o trasero. Evite causar daños en el marco: no coloque la cabina directamente sobre el piso o mesa cuando el marco se encuentra instalado. Extraiga el marco según sea necesario para evitar que el peso quede apoyado sobre el marco. Evite causar daños al chasis: no coloque ningún objeto sobre la parte superior de la cabina.	AVIS Pour éviter les dégâts - ne portez pas le cadre par sa face avant. Soulevez ou transportez le cadre par ses côtés gauche, droit, ou arrière. Pour éviter d'endommager le porteur - ne posez pas le cadre directement au sol ou sur une table lorsque le porteur est attaché. Retirez le porteur de sorte à éviter que le poids ne s'exerce sur le porteur. Pour éviter d'endommager le châssis - ne posez rien sur le dessus du cadre.




通知 この装置は、電源ケーブルを電源に接続する必要があります。電源ケーブルを電源に接続するときは、必ず電源ケーブルの両端を電源にしっかりと接続してください。	NOTICE This array has a hot power supply configuration. To remove electricity from the array, unplug the two power cables from the power source.	HINWEIS Dieses Array ist mit einer Energieversorgungskonfiguration ausgestattet. Um die Elektrizität aus dem Array zu entfernen, ziehen Sie beide Kabel aus der Stromquelle.	AVISO Este sistema tiene una configuración dual de la fuente de alimentación. Al eliminar la electricidad del sistema, desenchufar los cables de la fuente de alimentación.	AVIS Ce système dispose d'un système de courant électrique dual. Afin d'éliminer le courant du système, déconnectez les deux câbles de la source d'alimentation.
--	--	--	---	--


Flash module drive tray




Dense intermix drive tray




CBSS/CBSL controller




CBLM controller




Drive for a CBSS/small form factor drive tray




Drive for a small form factor drive tray




Drive for a CBSL/large form factor drive tray




Drive for a large form factor drive tray




Drive for a flash module drive tray




Drive for a dense intermix drive tray




CBSS/CBSL power unit




CBLM power supply




Power supply for small and large form factor drive trays




Flash module drive tray power supply




Dense intermix drive tray power supply




Front end module (Fibre Channel/iSCSI)




Back end module




ENC for small and large form factor drive trays



ENC for a dense intermix drive tray



CMA (used to secure dense intermix drive tray)



Battery

Hitachi Data Systems

Corporate Headquarters

2845 Lafayette Street
Santa Clara, California 95050-2639
U.S.A.
www.hds.com

Regional Contact Information

Americas

+1 408 970 1000
info@hds.com

Europe, Middle East, and Africa

+44 (0) 1753 618000
info.emea@hds.com

Asia Pacific

+852 3189 7900
hds.marketing.apac@hds.com



FE-94HM8027-00