SVP SECTION

| REV.0 | Oct.2001 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|

Contents


| 1 How to Operate the SVP (PC) | SVP01-10 |
|---|------------|
| 1.1 How to use a touchpad | SVP01-10 |
| 1.2 Windows Screen Component Nomenclature | |
| 1.3 How to use Windows | |
| 1.4 Power On | SVP01-50 |
| 1.5 Power Off | SVP01-70 |
| 1.6 Mode | SVP01-80 |
| 1.7 Run | SVP01-90 |
| 1.8 How to reference the manual on CDR | SVP01-100 |
| 2 Function of the SVP | SVP02-10 |
| 2.1 TOD (Time Or Date) setting | SVP02-10 |
| 2.2 Log indication | SVP02-30 |
| 2.3 Log delete | SVP02-170 |
| 2.4 Monitoring | |
| 2.5 Online read margin (ORM) | |
| 2.6 SIM Reporting Specification | |
| 2.7 Management of drive threshold values | |
| 2.8 DUMP/LOG FD Copy | |
| 2.9 SIM Log Complete | |
| 2.10 Dump | |
| 2.11 Logical Device Maintenance | |
| 2.11.1 Logical Device | |
| 2.11.2 Open VOL | |
| 2.12 Pin Data indication | |
| 2.13 Multi PCB Replace | |
| 2.14 System Option | |
| 2.15 Blocking of Cluster | |
| 2.16 Recovering of Cluster | |
| 2.17 HDD Configuration | |
| 2.18 PCB Revision Display | |
| 2.19 Tuning Parameter | |
| 2.20 Change CM Module group size | |
| 2.21 Setting Battery Life | |
| 2.22 Switch SVPs | |
| 2.23 Transferring Configuration Data | SVP02-1340 |

| 3. | Activating and Terminating STATUS | SVP03-10 |
|----|---|------------|
| | 3.1 Activating STATUS | SVP03-10 |
| | 3.2 Terminating STATUS | SVP03-40 |
| | 3.3 Updating the STATUS display | .SVP03-40 |
| | 3.4 Main screen | SVP03-50 |
| | 3.5 DKC (Controller) | SVP03-70 |
| | 3.6 DKU (Disk) | SVP03-130 |
| | 3.7 Copy status | SVP03-160 |
| | 3.8 Logical device | SVP03-170 |
| | 3.9 Micro-program version | .SVP03-180 |
| | 3.10 LCP/HTP Path | SVP03-230 |
| | 3.11 Pin | .SVP03-250 |
| | 3.12 LUN Management | .SVP03-260 |
| | 3.13 OS Install Status | SVP03-340 |
| | 3.14 Error or Failure Status Action | SVP03-350 |
| 4 | Option Install | .SVP04-10 |
| | 4.1 Option install by one | SVP04-10 |
| | 4.2 Option install with together | SVP04-50 |
| | 4.3 Details for Screen | |
| 5 | Guidance Operation Screen | SVP05-10 |
| | 5.1 Operation Manual of Guidance Function | |
| | 5.2 Outline of Countermeasure By Guidance | |
| | 5.3 Object SIM RC for Guidance Function | |
| | 5.4 Guidance Change of Screen | |
| | 5.5 Operation of Guidance | |
| | 5.6 Detail of Screen | |
| | | SVP05-260 |

1 How to Operate the SVP (PC)

This manual describes how to operate the SVP (PC) with a touchpad.

1.1 How to use a touchpad



Trace this device to move the pointer to a desired position.


②: Button

Pressing this button selects an item on which the pointer is placed.

SVP01-20

1.2 Windows Screen Component Nomenclature

Either of the following windows is displayed.



Note 1: Each SVP screen on this maintenance manual is a sample, and it may not be the same as the actual screen.

Note 2: Raid Information Service Display shows a status of the service being done by the Web Console.

When Lock Status on this screen is Lock, you cannot perform maintenance from SVP. (You can change to Modify mode.)

Wait until Lock Status becomes Unlock. If you do not use Web Console from SVP or a remote machine, errors on this screen do not effect the operation. You can perform maintenance from SVP when Lock Status is Unlock.

(When an error occurs, retry process runs periodically, and Lock Status becomes Lock Status periodically.)

For farther details, refer to the section, "Web Console".

1.3 How to use Windows

(1) Notation

In this manual, "select" has the following three meanings, and (CL), (DC), or (DR) is added to the word for each meaning.

(CL) Click: Quickly press and release the button the touchpad.

(DC) Double-click: Click the button the touchpad twice in rapid succession.

(DR) Drag: To hold down the button above the touchpad while you trace the touchpad

to move the pointer to a desired position. Then release the button.

example)


Select (DC) the [Install] icon in the 'SVP' window.

Move the pointer to [Install] with the touchpad. Then click the button the touchpad twice in rapid succession.

(2) Close

"Close" means to close the aplication window.


(Double-click the control menu box of the window or click the close button for Windows 95.)



(3) Moving the Window


Move the pointer to the title bar with the trackball.

While pressing the button, move the window with the trackball or touchpad (DR) to a desired position and release the button.



(4) Changing the window size

Move the pointer to the window border (frame) (the pointer changes to the double-headed arrow). While pressing the button, move the border (the border changes to the broken line) until the window becomes a desired size, and release the button.



(5) Switching the screen (when two or more screens are opened)

While pressing the ALT key, press TAB (or ESC) until your desired window title is displayed, and release the ALT key.

| REV.0 | Oct.2001 | | | | |
|-------|----------|--|--|--|--|
|-------|----------|--|--|--|--|

1.4 Power On


Usually, SVP starts automatically at the breakers-ON.

If some problems occurred (and you must start SVP), follow the procedures below (to start SVP).

- (1) Power On SVP
- a. Press Power Switch on the SVP keyboard.
- b. Watch messages displayed on the SVP screen. If following messages are displayed, go to (2). If not, power off (press Power Switch) and on SVP to retry. (*1)

If no message appears after retrying twice, reinstall the SVP OS using the SVP image CD. Then install the latest micro code.

If it still does not recover, replace the SVP.



[Message]

Starting Windows... (Some other messages)

- (2) Windows Start (SVP Start)
- a. Wait a few minutes until Windows system starts.
- b. Read the messages displayed on the SVP screen. (Go to SVPMSG section)
 Otherwise, power off (press Power Switch) and on SVP to retry. (*1)
 If no message appears after retrying twice, replace SVP.
 [End of Power On]
 - *1: If you press only Power Switch on the SVP keyboard when SVP and Windows system are active, these systems will be frozen.

 You should be sure to press Power Switch to power off SVP.
 - *2: If Windows doesn't start, check the following items.
 - (1) Is the DKC "CE mode"?
 - (2) Are the two LEDs at the LAN cable socket always on?

If above two conditions are satisfied, pull out the LAN cable until Windows starts.


Blank Sheet

| REV.0 Oct. | 2001 | | | | |
|------------|------|--|--|--|--|
|------------|------|--|--|--|--|

1.5 Power Off

- (1) What is running?
- a. See what is displayed.If Windows is displayed, go to (2).
- (2) Exit Windows(Stop SVP)
- a. Select (CL) "Start" button.
- b. Select (CL) "Shut Down".
- c. Select (CL) "Shut Down the computer?", and Select (CL) [Yes].

[End of Power Off]



(3) Power Off SVP

a. Press Power Switch.[End of Power Off]

Note: Do not press only Power Switch key.

Since SVP does not stop perfectly, we do not guarantee the operation of SVP after repower on.

If only Power Switch key is pressed, please power off SVP.

1.6 Mode

(1) View Mode

In view mode, only referring the subsystem status is allowed.


Note: In view mode, pending SIMs (if exist) are reported to host.

| | View Mode | |
|-------------|-------------|--|
| Maintenance | Information | |
| Instell | Diagnosis | |
| FD Copy | HRC | |
| | HORC | |
| HMRCF | HOMRCF | |
| HIHSM | DUMP | |

(2) Modify Mode

In modify mode, referring and changing the subsystem status are allowed.

For example, log/pin data indication and status display on MAINTENANCE are available in any mode, but hardware replacement is available in only modify mode.



(3) Change Mode

If you push (CL) [View Mode] button, the mode changes from [View Mode] to [Modify Mode], and SVP changes to Modify Mode.

If you push (CL) [Modify Mode] button, the mode changes from [Modify Mode] to [View Mode], and SVP changes to View Mode.


| REV.1 | Oct.2001 Aug.2002 | | | |
|-------|-------------------|--|--|--|
|-------|-------------------|--|--|--|

1.7 Run

(1) <Select [Run]> Select (CL) [Run...] by selecting [Start] button for the pull down menu.



(2) <Input file name>
Input file name in 'Open' and select (CL)
[OK].



1.8 How to reference the manual on CDR

Preface

The Maintenance Manual is released by CDR.

The manual is provided in the PDF (Portable Document Format). To read this manual, you must have a special reader software program in SVP.

How to install Acrobat Reader

The CDR contains the setup program of Acrobat Reader. You can use this setup program to install Acrobat Reader into SVP. To install Acrobat Reader:

- (1) Insert the CDR into the drive of your PC.
- (2) Use Explorer to locate the CDR drive.
- (3) Double-click the "Acr\xxx.exe" to start the setup program.
- (4) Follow instruction messages to install Acrobat Reader.

How to reference the manual

To reference this manual:

- (1) Insert the CDR into the drive of your PC.
- (2) Use Explorer to locate the CDR drive.
- (3) Double-click a desired file.

The content of the selected file will be displayed on another window.

| Copy | /right | ©2001, | Hitachi, | Ltd. |
|------|--------|--------|----------|------|
| | | | | |

| REV.0 | Oct.2001 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|


2 Function of the SVP

2.1 TOD (Time Or Date) setting


(1) Change the mode to [Modify Mode] from [View Mode] (CL).

(2) Select (CL) [Install].

(3) Select (CL) [Set Subsystem Time] in the 'Install' window.



(4) Specify the date (year, month and day) and time (hour, minute and second) and select (CL) [OK].



(5) Close the 'Install' window.

Note: If you execute the performance measurement by Performance Monitor, don't push back the TOD.


2.2 Log indication

| [1] SSB Log | SVP02-40 |
|--|-----------|
| [2] SIM Log | SVP02-60 |
| [3] Detail Log | SVP02-80 |
| [4] Reset Log | SVP02-90 |
| [5] Power Event Log | SVP02-100 |
| [6] Incident Log | SVP02-110 |
| [7] LCP Log | SVP02-130 |
| [8] Diagnosis Log | |
| [9] Copy History Log | |
| [10] MP# - Location correspondence table | |


Prerequisite Operation:

(1) Select (CL) [Information].

(2) Select (CL) [Log...].




(3) 'Log' dialog box is displayed.



[1] SSB Log

(1) Select (CL) [SSB] in the 'Log'. Select (CL) [List].



(2) Select (CL) data to be indicated in the 'List-SSB' dialog box and select (CL) [Content...].

Note1: To sort and list items, select (CL) [Sort...] first.


Then select (CL) the desired item in the [Items] and [Order] options in the 'Sort' dialog box, and select (CL) [OK].


Note2: To search for the desired log, select (CL) [Search...]. Then set the log for which you want to search individual List in the 'SSB Search Condition' dialog box and select (CL) [OK].


Note3: In case of the log data exceeds 1000 cases

(Denominator of the total displays 1000 or more),
the log data can be displayed from new data to
1000 data out of the entry sequence on SVP.
The entry sequence sometimes differs from
occurrence order of the log.
Perform search function in order to check
occurrence order.


Note4: Please do not change an application's window until search function finish.








(3) The detailed data is displayed in the 'Content-SSB' dialog box. Select (CL) [Refer...] in the 'Content-SSB' dialog box to display the relative log.



(4) Select (CL) the log to be displayed in the 'Refer' dialog box. ([SIM] is selected in this example.)



(5) Display the log to be selected.('SIM Log' is displayed in this example.)See SIM LOG Section




(6) Close the relative log when it is referred to. Select (CL) [Close] in the 'Content-SSB' dialog box. Select (CL) [Close] in the 'List-SSB' dialog box. Close the 'Log' dialog box and close the 'Information' window.

[2] SIM Log

Note: When SIM log exists after SVP is started up, the 'SIM Message' window is displayed.

(1) Select (CL) [SIM] in the 'Log' dialog box. Select (CL) [List...].





(2) Select (CL) data to be indicated in the 'List-SIM' dialog box and select (CL) [Content...].

Note: To sort and list items, select (CL)

[Sort] first.

Then select (CL) the desired item in the [Items] and [Order] options in the 'Sort' dialog box, and select (CL) [OK].







(3) The 'Content-SIM' dialog box is displayed. Select (CL) [Refer...] in the 'Content-SIM' dialog box, when the relative log is displayed.

Note1: In WCHK1 dump and ABEND dump received SIM (RC = 3080X0, 3081X0), the system error code is indicated in the format [YYYY] as in Reference Code 3080X0[YYYY].


Note2: If Reference Code is 73XX00 or 1400X0, perform the recovery procedure for LAN error. (see TRBL05-60.)



(4) Select (CL) the log to be displayed in the 'Refer' dialog box. ([SSB] is selected in this example.)




(5) The selected log is displayed. ('Content-SSB' is displayed in this example.)



(6) Close the relative log when it is referred to. Select (CL) [Close] in the 'Content-SIM' dialog box. Select (CL) [Close] in the 'List-SIM' dialog box. Close the 'Log' dialog box and close the 'Information' window.

[3] Detail Log


(1) Select (CL) [Detail] in the 'Log' dialog box. Select (CL) [List...].




(2) Select (CL) data to be indicated in the 'List-Detail' dialog box and select (CL) [Content...]. Note:To sort and list items, select (CL)


[Sort] first.

Then select (CL) the desired item in the [Items] and [Order] options in the 'Sort' dialog box, and select (CL) [OK].





(3) The 'Content - Detail' dialog box is displayed.




(4) Select (CL) [Close] in the 'Content - Detail' dialog box. Select (CL) [Close] in the 'List-Detail' dialog box. Close the 'Log' dialog box and close the 'Information' window.

| REV.0 Oct.2001 | | | |
|----------------|--|--|--|
|----------------|--|--|--|


[4] Reset Log


(1) Select (CL) [Reset] in the 'Log' dialog box. Select (CL) [List...].




(2) Select (CL) data to be indicated in the 'List-Reset' dialog box and select (CL) [Content...].Note:To sort and list items, select (CL) [Sort] first.

Then select (CL) the desired item in the [Items] and [Order] options in the 'Reset Log Sort' dialog box, and select (CL) [OK].





(3) The 'Content-Reset' dialog box is displayed.




(4) Select (CL) [Close] in the 'Content-Reset' dialog box. Select (CL) [Close] in the 'List-Reset' dialog box. Close the 'Log' dialog box and close the 'Information' window.

| REV.0 Oct.2001 | | | |
|----------------|--|--|--|
|----------------|--|--|--|

[5] Power Event Log


(1) Select (CL) [Power Event] in the 'Log' dialog box. Select (CL) [List...].




(2) The 'List-Power Event' dialog box is displayed. Note: To sort and list items, select (CL)

[Sort] first.

Then select (CL) the desired item in the [Items] and [Order] options in the 'Sort' dialog box, and select (CL) [OK].






(3) Select (CL) [Close] in the 'List-Power Event' dialog box. Close the 'Log' dialog box and close the 'Information' window.

[6] Incident Log

(1) Select (CL) [Incident] in the 'Log' dialog box. Select (CL) [List...].





(2) Select (CL) data to be indicated in the 'List-Incident' dialog box and select (CL) [Content...].

Note:To sort and list items, select (CL)


[Sort] first.

Then select (CL) the desired item in the [Items] and [Order] options in the 'Sort' dialog box, and select (CL) [OK].






(3) The 'Content-Incident' dialog box is displayed.



(4) To display the relative log, select (CL) [Refer...] in the 'Content-Incident' dialog box.


Select (CL) the log type to be displayed in the 'Refer' dialog box and then select (CL) [OK].



(5) Select (CL) [Close] in the 'Content-Incident' dialog box. Select (CL) [Close] in the 'List-Incident' dialog box. Close the 'Log' dialog box and close the 'Information' window.


[7] LCP Log


(1) Select (CL) [LCP] in the 'Log' dialog box. Select (CL) [List...].




(2) Select (CL) data to be indicated in the 'List-LCP' dialog box and select (CL) [Content...]. Note: To sort and list items, select (CL) [Sort] first.

Then select (CL) the desired item in the [Items] and [Order] options in the 'Sort' dialog box, and select (CL) [OK].





(3) The 'Content-LCP' dialog box is displayed.




(4) Select (CL) [Close] in the 'Content-LCP' dialog box. Select (CL) [Close] in the 'List-LCP' dialog box. Close the 'Log' dialog box and close the 'Information' window.

| REV.0 Oct.200 | | | |
|---------------|--|--|--|
|---------------|--|--|--|

[8] Diagnosis Log

(1) Select (CL) [Diagnosis] in the 'Log' dialog box. Select (CL) [List...].




(2) Select (CL) data to be indicated in the 'List-Diagnosis'


dialog box and select (CL) [Content...].

Note:To sort and list items, select (CL)


[Sort] first.

Then select (CL) the desired item in the [Items] and [Order] options in the 'Sort' dialog box, and select (CL) [OK].





(3) The 'Content-Diagnosis' dialog box is displayed.




(4) Select (CL) [Close] in the 'Content-Diagnosis' dialog box. Select (CL) [Close] in the 'List-Diagnosis' dialog box. Close the 'Log' dialog box and close the 'Information' window.

| REV.0 | Oct.2001 | | | | |
|-------|----------|--|--|--|--|
|-------|----------|--|--|--|--|

[9] Copy History Log

(1) Select (CL) [Copy history] in the 'Log' dialog box. Select (CL) [List...].




(2) Select (CL) data to be indicated in the 'List-Copy history'


dialog box and select (CL) [Content...].

Note: To sort and list items, select (CL)

[Sort] first.

Then select (CL) the desired item in the [Items] and [Order] options in the 'Sort' dialog box, and select (CL) [OK].





(3) The 'Content-Copy History' dialog box is displayed.



(4) Select (CL) [Close] in the 'Content-Copy History' dialog box. Select (CL) [Close] in the 'List- Copy History' dialog box. Close the 'Log' dialog box and close the 'Information' window.

[10] MP# - Location correspondence table Multi Cabinet Model

| | Location | | MP# | | Lo | cation | | MP# | |
|-----|------------|--------|----------|----|-----|----------|--------|----------|----|
| | CHA-1P CHP | | CHP00-1P | 00 | | | DKA-1B | DKP80-1B | 20 |
| | | | CHP01-1P | 01 | | | | DKP81-1B | 21 |
| | | | CHP02-1P | 02 | | | | DKP82-1B | 22 |
| | | | CHP03-1P | 03 | | | | DKP83-1B | 23 |
| | | CHA-1Q | CHP10-1Q | 04 | 1 | | DKA-1C | DKP90-1C | 24 |
| | | | CHP11-1Q | 05 | | | | DKP91-1C | 25 |
| | | | CHP12-1Q | 06 | | | | DKP92-1C | 26 |
| | Cluster1 | | CHP13-1Q | 07 | | Cluster1 | | DKP93-1C | 27 |
| | | CHA-1R | CHP20-1R | 08 | 1 | | DKA-1D | DKPA0-1D | 28 |
| | | | CHP21-1R | 09 | 1 | | | DKPA1-1D | 29 |
| | | | CHP22-1R | 0a | | | | DKPA2-1D | 2a |
| | | | CHP23-1R | 0b | | | | DKPA3-1D | 2b |
| | | CHA-1S | CHP30-1S | 0c | | | DKA-1E | DKPB0-1E | 2c |
| | | | CHP31-1S | 0d | | | | DKPB1-1E | 2d |
| | | | CHP32-1S | 0e | | | | DKPB2-1E | 2e |
| CHA | | | CHP33-1S | Of | DKA | | | DKPB3-1E | 2f |
| | | CHA-2V | CHP40-2V | 10 | | | DKA-2H | DKPC0-2H | 30 |
| | | | CHP41-2V | 11 | | | | DKPC1-2H | 31 |
| | | | CHP42-2V | 12 | | | | DKPC2-2H | 32 |
| | | | CHP43-2V | 13 | | | | DKPC3-2H | 33 |
| | | CHA-2W | CHP50-2W | 14 | | | DKA-2J | DKPD0-2J | 34 |
| | | | CHP51-2W | 15 | | | | DKPD1-2J | 35 |
| | | | CHP52-2W | 16 | | | | DKPD2-2J | 36 |
| | Cluster2 | | CHP53-2W | 17 |] | Cluster2 | | DKPD3-2J | 37 |
| | | CHA-2X | CHP60-2X | 18 | | | DKA-2K | DKPE0-2K | 38 |
| | | | CHP61-2X | 19 | | | | DKPE1-2K | 39 |
| | | | CHP62-2X | 1a |] | | | DKPE2-2K | 3a |
| | | | CHP63-2X | 1b | | | | DKPE3-2K | 3b |
| | | CHA-2Y | CHP70-2Y | 1c | | | DKA-2L | DKPF0-2L | 3c |
| | | | CHP71-2Y | 1d | | | | DKPF1-2L | 3d |
| | | | CHP72-2Y | 1e | l | | | DKPF2-2L | 3e |
| | | | CHP73-2Y | 1f | | | | DKPF3-2L | 3f |

Single Cabinet Model


| | Location | | | | | 10 | cation | | MP# |
|-----|-----------------|--------|----------|-----------|-----|-----------|---------|----------|-----|
| | CHA-1C CHP00-1C | | | MP# 00 | | I | DKA-1B | DKA80-1B | 20 |
| | | CHA-1C | | | | | DIVA-16 | | 21 |
| | | | CHP01-1C | 01 | | | | DKA81-1B | |
| | | | CHP02-1C | 02 | | Observant | | DKA82-1B | 22 |
| | | | CHP03-1C | 03 | | Cluster1 | | DKA83-1B | 23 |
| | | CHA-1D | CHP10-1D | 04 | | | DKA-1F | DKA90-1F | 24 |
| | | | CHP11-1D | 05 | | | | DKA91-1F | 25 |
| | Cluster1 | | CHP12-1D | 06 | | | | DKA92-1F | 26 |
| | | | CHP13-1D | 07 | DKA | | | DKA93-1F | 27 |
| | | CHA-1F | CHP20-1F | 08 | | | DKA-2L | DKPC0-2L | 30 |
| | | | CHP21-1F | 09 | | | | DKPC1-2L | 31 |
| | | | CHP22-1F | 0a | | | • | DKPC2-2L | 32 |
| CHA | | | CHP23-1F | 0b | | Cluster2 | | DKPC3-2L | 33 |
| | | CHA-2G | CHP40-2G | 10 | | | DKA-2K | DKPD0-2K | 34 |
| | | | CHP41-2G | 11 | | | • | DKPD1-2K | 35 |
| | | | CHP42-2G | 12 | | | • | DKPD2-2K | 36 |
| | | | CHP43-2G | 13 | | | • | DKPD3-2K | 37 |
| | | CHA-2J | CHP50-2J | 14 | | | | | |
| | Cluster2 | | CHP51-2J | 15 | | | | | |
| | | | CHP52-2J | 16 | | | | | |
| | | | CHP53-2J | 17 | | | | | |
| | | CHA-2K | CHP60-2K | 18 | | | | | |
| | | | CHP61-2K | 19 | | | | | |
| | | | CHP62-2K | 1a | | | | | |
| | | | CHP63-2K | 1b | | | | | |

| REV.2 | Oct.2001 Feb.2002 | Jun.2002 | | | |
|-------|-------------------|----------|--|--|--|
|-------|-------------------|----------|--|--|--|

2.3 Log delete


- [1] SSB Log
- [2] SIM Log
- [3] Detail Log
- [4] Reset Log
- [5] Power Event Log
- [6] Incident Log
- [7] LCP/MCP Log
- [8] Diagnosis Log
- [9] Copy History Log
- (1) Select (CL) [Information] in 'SVP' window.

(2) Select (CL) [Log] in the 'Information' dialog box.




| REV.0 Oct.2001 |
|----------------|
|----------------|

(3) In the Log dialog box, select (CL) an item to be deleted. Select (CL) [Delete].



(4) Select (CL) [Yes] in the 'Delete' dialog box.




(5) Close the 'Log' dialog box and close the 'Information' window.

2.4 Monitoring

| [1] Displaying a graph for items | SVP02-200 |
|---|-----------|
| [2] Displaying the operation ratio of the processor | SVP02-220 |
| [3] Displaying the use ratio of the cache and the write pending data ratio in a tabular f | orm |
| | SVP02-240 |
| [4] Displaying the read hit ratio in a tabular form | SVP02-250 |
| [5] Displaying the use ratio of the Access Path in a tabular form | SVP02-260 |
| | |
| Prerequisite Operation | |


(1) Select (CL) [Information] in the 'SVP' window.

(2) Select (CL) [Monitor] in the 'Information' window



[1] Displaying a graph for items

(1) Select (CL) [Start...].



Interval: 💷

☐ Processor Operation☐ Cache Used

☐ <u>W</u>rite Pending Data
☐ Sidefile

☐ Read Hit Rate
☐ CHA SM Access Path

☐ Async Write Pending Data

DKA SM Access Path
 CHA CM Access Path

☐ DKA CM Access Path

OY. Cancel

(2) Select (CL) [Interval], [File Output], and [Item] in the 'Monitoring' dialog box and select (CL) [OK].

Note 1: "Interval" indicates a time interval from 5 to 3600 at which samples are taken.

Note 2: Up to three items can be selected in the "Item" list

box. The selectable values are:

Processor Operation : Operation ratio of the


processor

Cache Used : Use ratio of the cache
Write Pending Data : Write pending data ratio


Sidefile : Sidefile ratio of the subsystem
Async Write Pending Data : Async write pending data ratio
Read Hit Rate : Read hit ratio of the subsystem

CHA SM Access Path
 DKA SM Access Path
 Use ratio of the CHA - SM Access Path.
 Use ratio of the DKA - SM Access Path.
 Use ratio of the CHA - CM Access Path.
 Use ratio of the DKA - CM Access Path.


(3) After a few minutes, a graph is displayed for the item selected in step (2).



(4) When [Stop] is selected (CL) during the display of the graph, displaying is interrupted.If [OK] is selected (CL) in the 'Monitoring' dialog box, displaying is stopped.



(5) Select (CL) the [File] menu in the 'Monitor' dialog box and select (DR) [Exit].




(6) Close the 'Monitor' dialog box and close the 'Information' window.


- [2] Displaying the operation ratio of the processor
- (1) Display a graph (see steps listed above).

 Select (CL) [Processor Operation] in the "Item" list box.

If [Detail...] is selected (CL) in 'Monitor', 'Detail' will be displayed select (CL). [[Processor...] in 'Detail' and select (CL) [OK].



(2) Select (CL) [Part...] in the 'Processor' dialog box.




OK.

Cancel

(3) Select (DR) the contents of "Parts" in the 'Part' dialog box and select (CL) [OK].

Note: In the Parts list box, the following values



System Average : Average in the system
CHP (CHT) Average : Average for the CHP[CHT]
CHP (CHA) Average : Average for the CHP[CHA]
CHP (CHN) Average : Average for the CHP[CHN]

DKP (DKF) Average : Average for the DKP

CHP00-1P : Average for a particular processor


•



System Average

Part

(4) Select (CL) [Close] in the 'Processor' dialog box.




(5) Close the 'Monitor' dialog box and close the 'Information' window.


| REV.1 Oct.2001 | Feb.2002 | | | | |
|----------------|----------|--|--|--|--|
|----------------|----------|--|--|--|--|

- [3] Displaying the use ratio of the cache and the write pending data ratio in a tabular form.
- (1) Display a graph (see section [1] (SVP02-200) above).Select (CL) [Write Pending Data], [Cache Used] or [Sidefile] in the "Item" list box.

Select (CL) [Detail...] in the 'Monitor'. Select (CL) [Cache] in the 'Detail' and select (CL) [OK].




(2) Select (CL) [Close] in the 'Cache' dialog box.




(3) Close the 'Monitor' dialog box and close the 'Information' window.

- [4] Displaying the read hit ratio in a tabular form
- (1) Display a graph by executing steps (1) to (3) in "[1] Displaying a graph for items" in advance. In step (2), select (CL) [Read Hit Rate] in the "Item" list box.

Select (CL) [Detail...] in the 'Monitor'. Select (CL) [Read/Write] in the 'Detail' and select (CL) [OK].




(2) Select (CL) [Close] in the 'Read/Write' dialog box.




(3) Close the 'Monitor' window and close the 'Information' window.

- [5] Displaying the use ratio of the Access Path in a tabular form
- (1) Display a graph by executing steps (1) to (3) in "[1] Displaying a graph for items" in advance. Select (CL) [Detail...] in the 'Monitor'. Select (CL) [Access Path] in the 'Detail' and select (CL) [OK].



(2) Select (CL) [OK] in the 'Access Path' dialog box.




(3) Close the 'Monitor' window and close the 'Information' window.

2.5 Online read margin (ORM)

[Overview]

The on-line read margin test (ORM) function is a read diagnostic function provided for preventive maintenance of disk drives. The diagnostic is automatically executed in each drive. The DKC reads the diagnostic result at specified intervals and reports it to the SVP.

The SVP calculates the error ratio to the threshold value which is set in advance, and indicates it in the OVER RATE Display (see [1], (2)). When the Rate in the display exceeds 100%, it means the error count is exceeding the threshold, the SVP creates the warning SIM. It is, however, not reported to the Host. The disk drive reporting the SIM should be exchanged with higher priority than other normal drives.



The SVP classifies the errors into six types in the Over Rate Counter Display. They are Unrecovered Read Error, Recovered Read Error, Unrecovered Seek error, Recovered Seek Error, Not Ready and Other Errors. Each has three types of counters indicated as Today, 7 days and Total. Refer to [1], (4) for the Over Rate Counter Display. In the Over Rate Counter Display, the error ratio which has the largest number among those classified types is displayed for each drive to represent each error.

The warning SIMs to be reported in the ORM are shown below.

ORM SIM and Reference Code

| No | Error Type | Reference Code | Meaning |
|----|------------------------|------------------|-------------------|
| 1 | Unrecovered Read Error | 502X | Drive Media Error |
| 2 | Recovered Read Error | $(X = 0 \sim F)$ | |
| 3 | Unrecovered Seek Error | 501X | Drive Unit Error |
| 4 | Recovered Seek Error | $(X = 0 \sim F)$ | |
| 5 | Not Ready | | |
| 6 | Other Errors | | |

| REV.1 Oct.2 | 001 Oct.2003 | | | | |
|-------------|--------------|--|--|--|--|
|-------------|--------------|--|--|--|--|

| [1] Displaying an error count, thresholds, and log | - SVP02-290 |
|--|-------------|
| [2] Resetting an error count | - SVP02-340 |
| [3] Displaying thresholds | - SVP02-370 |
| [4] Altering a threshold | - SVP02-390 |
| [5] Displaying the ORM running status | - SVP02-410 |
| [6] Resetting thresholds | - SVP02-420 |


(1) Check SVP Mode.

The Following operation needs SVP Mode to be 'Modify'. (See SVP01-80)


- [2] Resetting an error count
- [4] Altering a threshold
- [6] Resetting thresholds

(2) Select (CL) the [Information] in the 'SVP' window.

(3) Select (CL) [Online Read Margin...] in the 'Information' window.



- [1] Displaying an error count, thresholds, and log
- (1) Select (CL) [Display Over Rate...] in the 'Online Read margin' window.



(2) Enter a number from 0 to 100 at "Rate" in the 'ORM Over Rate HDD# Display' dialog box. Select (CL) [Display].

Then only the HDDs which have the rate of equal to or greater than the input number at "Rate" will appear in the display.

Rate: ratio of the number of errors for the


threshold value. Grp# : the parity group.


SPARE : spare HDD

RSRVD: reserved HDD with sparing

* : spare HDD in use.


(Multi Cabinet Model)






(3) When more detailed information is needed for the particular drive, select (CL) the HDD from the "HDD Location" list box.
Select (CL) [Detail].

(Multi Cabinet Model)





(Single Cabinet Model)



(4) In the 'Over Rate Counter Display' dialog box, select (CL) the error for which detailed log is to be displayed from the "ID" list box. Select (CL) [ORM LOG].

(Multi Cabinet Model)





The errors detected in the ORM are classified into six types of error category. Each error has the following definition.

(a) Read Error [Unrecovered]

A disk media error was detected. After ten times retries, the error was judged that it might become a serious media error which could not be recovered with ECC or retries.

(b) Read Error [Recovered]

A disk media error was detected. After ten times retries, the error was judged that it was an intermittent read error and recoverable, and included in the error rate management for the preventive maintenance.

(c) Seek Error [Recovered]

A seek error was detected. After ten times retries, the error was judged to be recoverable.

(d) Seek Error [Unrecovered]

A seek error was detected. After ten times retries, the error was judged to be unrecoverable.

(e) Not Ready

Not Ready status of the drive was detected.

(f) Other Errors

Any error which does not belong to the above classification was detected.

They are also managed with different time periods. "Today" is for one day count and cleared at AM 0:00 every day. "7 days" is for the cumulative value in the latest 7 days. "Total" shows the total cumulative count.

In this Over Rate Counter Display, each error category indicates the Error Count and the Threshold value except for the Read Error [Recovered]. The "-" for the Threshold value means no threshold is set.

Only the Read Error [Recovered] has an error rate expression. It is not managed with error count per day, per 7 days or Total. The error rate of the Read Error [Recovered] is calculated in the following formula:

Error rate = Number of error sectors/Number of ORM scan bits

Note: Only the result from approximately the latest one volume scan in ORM is used for the calculation.


In the example display, "4.13e-011" means the error rate is "4.13 \times 10⁻¹¹". This is corresponding to the raw error count and scan bits shown as "00000001/2.422270e+010", where the error count is one sector and the scan bits is 2.422270×10^{10} .


| aoC | vriaht | ©2001. | Hitachi, | Ltd. |
|-----|--------|--------|----------|------|
| | | | | |

| REV.0 | Oct.2001 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|

(5) The nature of the error selected in step (4) is displayed.

(Multi Cabinet Model)






| Byte | Bit | Name | Explanation |
|-------|-------|-------------------------|--|
| 0 - 3 | · | UCT | Time when the diagnostic result was reported from the DKC to the SVP |
| 4 | 7 | Log Valid | When this bit is 1, it indicates that this log is valid. |
| | 6 | Address Valid | When this bit is 1, it indicates that the address information in bytes 8 to F is valid |
| | 5 - 4 | (Reserved) | Reserved |
| | 3 - 0 | Sense Key | Error sense key in the SCSI drive report. (*1) |
| 5 | | Additional | Additional sense code in the SCSI drive report .(*1) |
| | | Sense Code | |
| 6 | | Sense Code Qualifier | Additional sense code qualifier in the SCSI drive report. (*1) |
| 7 | | Seek Error | Number of seek errors within 10 seek error retries. |
| | | Count | |
| 8 - 9 | | CC | Address of the cylinder where the error occurred. |
| Α | | Н | Address of the head where the error occurred. |
| В | | S | Address of the sector where the error occurred. |
| C-F | | LBA | LBA where the error occurred. |

^{*1:} Definition and contents of the error codes are same as those of the SSB for ordinary DKU errors.

| REV.1 Oct.2001 Jun.2002 | | |
|-------------------------|--|--|
|-------------------------|--|--|

| (6) Select (CL) [Close] in the 'ORM Log Display' dialog box. |
|---|
| |
| |
| |
| |
| |
| |
| (7) Select (CL) [Close] in the 'Over Rate Counter Display' dialog box. |
| |
| |
| |
| |
| |
| |
| (8) Select (CL) [Close] in the 'ORM Over Rate HDD# Display' dialog box. |
| |
| |
| |
| |
| |
| |
| (9) Close the 'Information' window. |
| |
| |
| |

- [2] Resetting an error count
- (1) Select (CL) [Display Over Rate...] in the 'Online Read Margin' window.



(2) Enter a number from 0 to 100 at 'Rate' in the 'ORM Over Rate HDD# Display' dialog box. Select (CL) [Display].

Then only the HDDs which have the rate of equal to or greater than the input number at "Rate" will appear in the display.

Rate: ratio of the number of errors for the


threshold value. Grp#: the parity group.


SPARE: spare HDD

RSRVD: reserved HDD with sparing

* : spare HDD in use.


(Multi Cabinet Model)






(3) In the 'ORM Over Rate HDD# Display' dialog box, select (CL) the HDD for which an error count and thresholds are to be reset from the "HDD Location" list box. Select (CL) [Detail].

(Multi Cabinet Model)





(Single Cabinet Model)



(4) In the 'Over Rate Counter Display' dialog box, select (CL) [Reset] button.


(Multi Cabinet Model)





| REV.1 Oct.2 | 1 Jun.2002 | | | | |
|-------------|------------|--|--|--|--|
|-------------|------------|--|--|--|--|

(5) Select (CL) [OK] in the 'Threshold Counter Reset' dialog box.



(6) Select (CL) [Close] in the 'Over Rate Counter Display' dialog box.


(7) Select (CL) [Close] in the 'ORM Over Rate HDD# Display' dialog box.

(8) Close the 'Information' window.

| REV.0 | Oct.2001 | | | | |
|-------|----------|--|--|--|--|
|-------|----------|--|--|--|--|

[3] Displaying thresholds

(1) Select (CL) [Alter and Display] in the 'Online Read Margin' window.



(2) In the 'ORM Threshold Alter/Display' dialog box, select (CL) an HDD from the "HDD#" list box and select (CL) [Display]. In order to display threshold of another interval, select (CL) the interval from the "Type" list box.

Note: Multiple HDDs can be selected (CL) from the "HDD#" list box while the control key is being held down.
In this case, each "Threshold" field in the "Threshold Value" list box shows the threshold for the HDD that is highlighted in the "HDD#" list box.


Grp#: the parity group.

SPARE: spare HDD


RSRVD: reserved HDD with sparing

* : spare HDD in use.


(Multi Cabinet Model)



Multiple Selected (Multi Cabinet Model)



(Single Cabinet Model)



Multiple Selected (Single Cabinet Model)




(3) Select (CL) [Close] in the 'ORM Threshold Alter/Display' dialog box and close the 'Information' window.

| REV.0 Oct.2001 | | | | | |
|----------------|--|--|--|--|--|
|----------------|--|--|--|--|--|

[4] Altering a threshold

(1) Select (CL) [Alter and Display...] in the 'Online Read Margin' window.



(2) In the 'ORM Threshold Alter/Display' dialog box, select (CL) an HDD from the "HDD#" list box and select (CL) [Display]. In order to display threshold of another interval, select (CL) the interval from the "Type" list box.


Grp#: the parity group.


SPARE: spare HDD

RSRVD: reserved HDD with sparing

* : spare HDD in use.

(Multi Cabinet Model)







(3) In the 'ORM Threshold Alter/Display' dialog box, alter the threshold in the "Threshold" field in the "Threshold Value" list box. Then select (CL)[Alter].

Note: When multiple HDDs are selected in the "HDD#" list box, the thresholds of all HDDs are altered to the same value.

(Multi Cabinet Model)



(Single Cabinet Model)




(4) Select (CL) [OK] in the 'Alter Threshold Value' dialog box.



(5) Select (CL) [Close] in the 'ORM Threshold Alter/Display' dialog box and close the 'Information' window.

- [5] Displaying the ORM running status
- (1) Select (CL) [Running Status...].



(2) In the 'ORM Running Status Display' dialog box, the ORM running status is displayed as the number of sectors.

Note: The "HDD#" list box shows the location numbers of HDDs. "Scan" shows the number of scanned sectors.

"Total" shows the total number of sectors in the drive. "Times" shows the number of times the entire drive was scanned.


Grp#: shows the parity group.

SPARE: spare HDD


RSRVD: reserved HDD with sparing

* : spare HDD in use.

(Multi Cabinet Model)




(Single Cabinet Model)




(3) Select (CL) [Close] in the 'ORM Running Status Display' dialog box and close the 'Information' window.

- [6] Resetting thresholds
- (1) Select (CL) [File]-[Exit] in the 'Information' window.




(2) Select (CL) [Install] in the 'SVP'.

(3) Select (CL) [Initialize ORM Value] in the 'Install' window.




| REV.0 Oct.2 |
|-------------|
|-------------|

(4) Select (CL) [Yes] in the 'Initialize ORM Value' dialog box.




(5) Select (CL) [OK] in the 'Initialize ORM Value' dialog box.




2.6 SIM Reporting Specification

- [1] DKC SIM
- [2] Cache SIM
- [3] Media SIM
- [4] Device SIM
- (1) Select (CL) [Information].

(2) Select (CL) [Log...] in the 'Information window'.




(3) Select (DR) [SIM Report...] from the [Options] menu in the 'Log' dialog box.



(4) Select (CL) SIM report type from the 'Type' list box.

Type : DKC SIM Cache SIM Media SIM Device SIM



Select (CL) the level to be reported in the

'SIM Reporting Option' dialog box, and also select (CL) [OK].

SIM message report level are arranged as follows in order of the higher level.

Acute > Serious > Moderate > Service

Selecting level, means all higher levels are to be reported.

(5) Close the 'Log' dialog box and also close the 'Information' window.

2.7 Management of drive threshold values

| [1] Displaying threshold values | - SVP02-470 |
|---------------------------------|-------------|
| [2] Altering threshold value | · SVP02-490 |
| [3] Displaying an error count | · SVP02-510 |
| [4] Resetting an error count | SVP02-520 |


(1) Check SVP Mode.

The Following operation needs SVP Mode to be 'Modify'. (See SVP01-80)

- [2] Altering threshold value
- [4] Resetting an error count


(2) Select (CL) the [Information] window in the 'SVP' window.

(3) Select (CL) [Threshold Value...] in the 'Information' window.



[1] Displaying threshold values

(1) Select (CL) [Alter and Display...] in the 'Threshold Value' window.



(2) Select (CL) an HDD location from the "HDD#" list box in the 'Threshold Alter/Display' dialog box and select(CL) [Display].
In order to display threshold of another interval, select (CL) the interval from the "Type" list box.

Note: Multiple HDD locations can be selected (CL) from the "HDD#" list box while the control key being held down. The threshold value in the "Threshold Value" list box shows the threshold value for the HDD location that is highlighted in the "HDD#" list box. Recovered: Threshold of errors recoverable by retry.

Unrecd: Threshold of errors not recoverable by retry.


Grp#: the parity group.

SPARE: spare HDD


RSRVD: reserved HDD with sparing

: spare HDD in use.


(Multi Cabinet Model) Threshold Alter/Display




Multiple Selected (Multi Cabinet Model)



(Single Cabinet Model)
Threshold Alter/Display



Multiple Selected (Single Cabinet Model)




(3) Select (CL) [Close] in the 'Threshold Alter/Display' dialog box and close the 'Information' window.

| REV.0 | Oct.2001 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|

[2] Altering threshold value

(1) Select (CL) [Alter and Display...] in the 'Threshold Value' window.



(2) Select (CL) an HDD location from the "HDD#" list box in the 'Threshold Alter/Display' dialog box and select (CL) [Display]. In order to display threshold of another interval, select (CL) the interval from the "Type" list box.


Grp#: the parity group.

SPARE: spare HDD

RSRVD: reserved HDD with sparing

* : spare HDD in use.

(Multi Cabinet Model)




| Threshold Alter/Display | | | |
|-------------------------|-----------------|--|--|
| HDD# D Total | <u>D</u> isplay | Threshold Value HDD:HDD-000 Error Type R Mechanical error Media error Read / Write error Drive I/F error Controller hardware error | Aker ecovered Unrecd 150 6 0 15 150 30 150 6 150 6 |
| Selected HDD(s):1 | , | FC I/F error Port 0 FC I/F error Port 1 Port 0 error Port 1 error | 6 6 12 |
| | | | Close |

(3) Alter a threshold value in the "Threshold Value" list box in the 'Threshold Alter/Display' dialog box.


Then select (CL) [Alter].

Note: When multiple HDD locations are selected(CL) from the "HDD#" list box with the control key being hold down, the thresholds for all the selected HDDs are modified to the same value.

(Multi Cabinet Model)



(Single Cabinet Model)




(4) Select (CL) [OK] in the 'Alter Threshold Value' dialog box.



(5) Select (CL) [Close] in the 'Threshold Alter/Display' dialog box and close the 'Information' window.

- [3] Displaying an error count
- (1) Select (CL) [Display Error Count...] in the 'Threshold Value' Window.



(2) Select (CL) an HDD location from the "HDD Location" drop-down list in the 'Threshold Counter Display' dialog box to display the error count for the HDD.


Grp#: the parity group.

SPARE: spare HDD


RSRVD: reserved HDD with sparing

* : spare HDD in use.

(Multi Cabinet Model)




(Single Cabinet Model)



(3) Select (CL) [Close] in the 'Threshold Counter Display' dialog box and close the 'Information' window.

- [4] Resetting an error count
- (1) Select (CL) [Display Error Count...] in the 'Threshold Value' window.



(2) Select (CL) the HDD location, for which you want to reset the error count, from the "HDD Location" drop-down list in the 'Threshold Counter Display' dialog box and also select (CL) [Reset].


Grp#: the parity group.

SPARE: spare HDD


RSRVD: reserved HDD with sparing

* : spare HDD in use.

(Multi Cabinet Model)



(Single Cabinet Model)





(3) Select (CL) [OK] in the 'Threshold Counter Reset' dialog box.



(4) After confirming that the error count has been reset in the 'Threshold Counter Display' dialog box select (CL) [Close] and close the 'Information' window.

(Multi Cabinet Model)






| REV.1 Oct.2001 Jun.2002 | | | |
|-------------------------|--|--|--|
|-------------------------|--|--|--|

2.8 DUMP/LOG FD Copy

Prerequisite operation.

(1) Select (CL) [FD Copy].

If this function has been terminated abnormally (e.g, Ctrl + Alt + Delete), you should reboot SVP and retry again.




Copying the dump and log files to a floppy disk.

(1) Select (CL) [Start] in the 'FD Copy' dialog box.

(NAS PCB Not Equip)




*: When the "Additional NAS LOG" check box is not Checked at the time of NAS PCB equipment, NAS LOG is not gathered.



Close

Start

(2) The message "Please insert a DOS formatted FD (NO.1)" will be displayed in the 'FD SET' dialog box. In response to this message, insert a floppy disk and select (CL) [OK].




(3) If the floppy disk contains files, the message "FD contain these files. Do you want to delete them ?" is displayed.

If you want to delete these files, select (CL) [YES] and proceed to step (4).

If you don't want to delete these files, select (CL) [NO] and proceed to step (4).

If an error occurs, check the items indicated in the 'ACCESS ERROR!!' dialog box then select (CL) [Retry].

(The screen goes back to the beginning of step (4).)






(4) When a compressed file(FDCP.LZH) doesn't exist in HDD, proceed to step (5).


When a compressed file exists in HDD, "A compressed File(FDCP.LZH) already exists." is displayed.

If you want to start compressing again, select (CL) [Yes] and proceed to step (5).


If you want to start coping only, select (CL) [No] and "Do you want to copy the compressed file to the FD" is displayed.

Select (CL) [OK] and proceed to step (6).





(5) The message "Compressing files..." is displayed, and compressing is started.



(6) The message "Copying files to FD..." is displayed, and copying is started.

(If the capacity of the floppy disk becomes insufficient, go back to step (2) and replace the floppy disk with a new one.)



(7) The message "Delete DUMP files in HDD." is displayed in the 'DUMP DELETE' dialog box.

Select (CL) [OK] and delete DUMP files in HDD.




(8) Close the 'Fdcopy' dialog box.


2.9 SIM Log Complete

(1) Select (CL) [Information].


(2) Select (CL) [Log...] in the 'Information' dialog box.




(3) Select (CL) [SIM] and [List...] in the 'Log'.




(4) Select (CL) data to be completed in the 'List-SIM' dialog box and select (CL) [Complete].



(5) Select (CL) [Yes] in the 'Complete' dialog box.



(6) In the 'List-SIM' dialog box, make sure that "Completed" is displayed in the status.



(7) Select (CL) [Close] in the 'List-SIM' dialog box. Close the 'Log' dialog box and close the 'Information' window.

| REV.0 Oct.2 |
|-------------|
|-------------|

2.10 Dump


Auto Dump is a useful function to provide the user with free selection of the dump data type and the output media so that the user can collect dump information.

Note 1: Please use DUMP in order to select MP.


Note 2: You can use DUMP as usual.

- [1] Manual Dump
- (1) Select (CL) [Dump] in the 'SVP' window.

(2) Select (CL) "Location No." of the processor in the 'Dump' dialog box, and select (CL) [Dump]. When [All Adapters] is selected, dumps from all the processors are performed.





(3) A box indicating progress of the dump is displayed. When the dump terminates normally, go to step (5).



(4) When an error occurs, the following dialog box is displayed.

Perform the following procedure and retry the dump.





| REV.1 Oct.2001 | Feb.2002 | | | | |
|----------------|----------|--|--|--|--|
|----------------|----------|--|--|--|--|

(5) "Dump is received successfully" is displayed. Select (CL) [OK].




(6) When copying the dump file to on FD, execute "[1] Copying the dump file to floppy disk" in Section 2.8 "DUMP/LOG FD Copy".


[2] SSVP DUMP

(1) Push the SSVP DUMP switch. (Refer to LOCATION03-40, LOCATION03-60.)

(2) Open the Maintenance window (see SVP section). Check that the message "SSVP Dump is being performed (XXXX). Environment status can't be read." is displayed and select (CL) [OK].



If the message "Connection error occurred. SVP-SSVP" is displayed, check the wiring connection and select (CL) [OK] to start from step (1) again. If step (1) is performed three times and the same message "Connection error occurred. SVP-SSVP" is displayed, replace SSVP (see REP01-170).



(3) The SSVP ALARM lamp blinks after completion of dump. (For about 10 minutes after performing step (1))


(4) Copy the dump file to FD. Perform "2.8 DUMP/LOG FD Copy" on page SVP02-540.

(5) Push the SSVP Alarm Reset switch. (Refer to LOCATION03-40, LOCATION03-60.)

(6) Open the Maintenance window.

If the message "Connection error occurred .SVP-SSVP" is displayed, select (CL) [OK] to perform step (5) again.

If step (5) is performed three times and the same message "Connection error occurred. SVP- SSVP" is displayed, replace SSVP (see REP01-170).




| REV.1 Oct | .2001 Feb.2002 | | | | |
|-----------|----------------|--|--|--|--|
|-----------|----------------|--|--|--|--|

| (7) | If the message shown at step (6) is not displayed, the SSVP IMPL is completed. |
|-----|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

- [3] Auto Dump
- (1) Select (CL) [AutoDump] button

(2) Select one of three dump types and one of two media types and specify the FTP Transfer Detail, and select (CL) [OK] or [Only FTP Transfer].



<Dump Type>

(a)Rapid This dump type is to get log information, SVP operation history, or configuration information. SVP will compress these files automatically. The compressed files will be stored in a few FDs. This dump type will be used when the initial analysis of error is needed. In this case, you should gather the files used by this type and send it to the Center. After sending this files, you should gather dump data by selecting "Normal" type and send it to the Center to analyze more details.

(b)Normal This dump type is to get dump data (you can get DUMP information of all adapters) adding to the log files used by "Rapid" type. SVP will compress these dump files automatically. You should get dump data by using this dump type after sending the "Rapid" type of data to Center.

(c)Detail This type is to get monitor information adding to the dump files used by "Normal" type. This data will be needed when the performance of the DKC wants to be checked. If there is no order to get these data, you do not need to use this type.

REV.1

<Media>

(a)FDD SVP will store the compressed files to FD. If the data could not be stored in one FD, SVP will divide the compressed files into smaller files and store them into several FDs. If you cannot transfer the compressed files to your center from the SVP, you could use this media type to save files into several FDs and transfer them by using other PC which can connect to the center.

(b)HDD SVP will store the compressed files to HDD. The file name is "c:\dkc200\tmp\hdcp.lzh". If you can transfer the files to your center directly, this type will be useful. (Notice: When operating the maintenance, SVP will sometimes delete the files. Do not use the maintenance operation before sending the files to your center.)

(c)FTP SVP will store the compressed files to HDD. The file name is "c:\dkc200\tmp\hdcp.lzh". After the compression processing end, Transfer processing of compression data is performed to the transfer place directory of a specification server inputted into FTP Transfer Detail.

<FTP Transfer Detail>

(a)Host Name The host name of a FTP transfer place or an IP address is inputted.

(b)Transfer Path
(c)USER Name
(d)Password

The directory of a FTP transfer place is inputted.
The user name which login to a FTP server is inputted.
The password which login to a FTP server is inputted.

<[Only FTP Transfer] Button>

When FTP mode is selected, only transmission of the "c:\dkc200\tmp\hdcp.lzh" already compressed Performed to the transmission place directory of a specification server which inputted into FTP Transfer Detail without refreshing it.

(3-1) Executing Auto Dump

SVP will execute Auto Dump. Refer to the following section during the process.

2.9 DUMP/LOG FD Copy

2.11 DUMP


Go to (4)

(3-2) Select (CL) [OK] in response to the confirmation message


"Do you want to transfer the already gathered dumps, logs, history of SVP operation, and usage data to an FTP server without refreshing them?"



(4) Starting FTP Transfer
When [FTP] is selected as an [Media],
transfer processing of compression data
begins.



(5) Finish FTP Transfer
After finishing the FTP transfer function, SVP will
display the message "FTP transfer has ended
successfully.". Select (CL) [OK] to end this process.



| REV.0 Jun.2002 | | |
|----------------|--|--|
|----------------|--|--|

2.11 Logical Device Maintenance

2.11.1 Logical Device

| [1] Physical Device List | SVP02-690 |
|---|-----------|
| [2] FORMAT Logical Device | SVP02-700 |
| [3] Block Logical Device | SVP02-730 |
| [4] Restore the Logical Device | SVP02-760 |
| [5] Refer the system configuration data | SVP02-790 |
| [6] Verify Logical Device | SVP02-800 |
| [7] LDEV recovery for multiple PDEV failures | SVP02-840 |
| [8] Only a Blockade Logical Device FORMAT with together | SVP02-855 |
| | |


Prerequisite Operation: From [1] to [7]


(1) Select (CL) [Maintenance] in the 'SVP' window.

(2) Select (CL) [Logical Device] in the 'Maintenance' Window.

If the shredding process is running for some logical devices from Storage Navigator, go to (3). If the Shredding process is not running, go to (4).


(Multi Cabinet Model)






(3) "Shredding" is displayed.

If processing is finished. ----- Go to (4). If you want to close the Window, select (CL) [Close]. ----- Go to (2). If you want to interrupt this process, select (CL) [Stop]. Note: Confirm to user that the process is interrupted. ----- Go to (4).




(4) "Logical Device Status" is displayed.




Prerequisite Operation: [8]

(1) Change the mode to [MODIFY Mode], select (CL) [Install].

- [1] Physical Device List
- (1) Select (CL) an LDEV from the LDEV list box in the 'Logical Device Status' dialog box and select (CL) [Detail].



(2) 'Logical Device Status Detail' is displayed. And select (CL) [Close].



(Single Cabinet Model) Group 1-2 (RAID5(3D1P)) Close W <u>F</u>ormat Blockade <u>R</u>estore Renewal Open Vol

(3) Select (CL) [Close] in the 'Logical Device Status' dialog box. Close the 'General Status Display' window.

[2] FORMAT Logical Device

Notice

Executing this operation may cause a serious error such as a system down or a data loss. Accordingly, confirmation of the appropriateness of the operation and input of a password on the succeeding password input screen is required.

(1) Select (CL) ECC group from the LDEV list box in the 'Logical Device Status' dialog box.

Format by Ldev unit:


Select (CL) [Detail] ----- Go to (2-1)

Format by ECC group:

Select (CL) [Format]----- Go to (2-2)


(It can select multiple items at once)


Note: Execute Format Logical Device after you confirm the target Logical Device is blocked.



(2-1) Select (CL) LDEVs which you want to format from "Logical Device Status Detail", and select (CL) [Format]. Go to (2-2). (It can select multiple items at once.)


(Multi Cabinet Model)






(2-2) Select (CL) the corresponding LDEV from the LDEV ID list in the 'Logical Device' dialog box and select (CL) [OK].

If the target LDEV was not blocked, return to the 'Logical Device Status' dialog box.




(3) "Data in the specified logical device may be lost due to this operation. You need the password to continue." is displayed. Enter the password and select (CL) [OK].



Notice

This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss and requires an input of a password. Ask the technical support center about the appropriateness of the operation, and input the password after getting an approval of executing the operation.

(4) "Formatting the logical device..." is displayed.




Notice

When REFER CONFIG etc. is executed during LDEV FORMAT of open volume, there is the rare case that MAINTENANCE WINDOW may disappear. Then please reboot SVP and execute LDEV FORMAT again.

For your information, even while rebooting SVP, LDEV FORMAT is executed without intermission. When you open LDEV FORMAT WINDOW again, you can see the current status of LDEV FORMAT.

(5) Select (CL) [OK] in response to "Formatting was finished.".



(6) Select (CL) [Close] in the 'Logical Device Status' dialog box. Close the 'Maintenance' window.


[3] Block Logical Device

Notice

Executing this operation may cause a serious error such as a system down or a data loss. Accordingly, confirmation of the appropriateness of the operation and input of a password on the succeeding password input screen is required.

(1) Select (CL) ECC group from the LDEV list box in the 'Logical Device Status' dialog box.

Blockade by Ldev unit:
Select (CL) [Detail] Go to (2-1)
Blockade by ECC group:
Select (CL) [Blockade] Go to (2-2)
(It can select multiple items at once)





Notice

Execute Format Logical Device after you confirm the target Logical Device is blocked.

(2-1) Select (CL) LDEVs which you want to format from "Logical Device Status Detail", and select (CL) [Blockade]. Go to (2-2). (It can select multiple items at once.)









| REV.1 Oct.2001 | Jun.2002 | | | | |
|----------------|----------|--|--|--|--|
|----------------|----------|--|--|--|--|

(2-2) Select the corresponding LDEV from the LDEV ID list in the 'Logical Device' dialog box and select (CL) [OK].



(3) "Data in the specified logical device may be lost due to this operation. You need the password to continue." is displayed. Enter the password and select (CL) [OK].




Notice

This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss and requires an input of a password. Ask the technical support center about the appropriateness of the operation, and input the password after getting an approval of executing the operation.

(4) "Blocking the logical device..." is displayed.

(5) Select (CL) [OK] in response to "Blocking the logical device is completed.".



(6) Select (CL) [Close] in the 'Logical Device Status' dialog box. Close the 'Maintenance' window.

[4] Restore the Logical Device

Notice

Executing this operation may cause a serious error such as a system down or a data loss. Accordingly, confirmation of the appropriateness of the operation and input of a password on the succeeding password input screen is required.

(1) Select (CL) ECC group from the LDEV list box in the 'Logical Device Status' dialog box.

Restore by Ldev unit:


Select (CL) [Detail] ----- Go to (2-1)

Restore by ECC group:


Select (CL) [Restore] ----- Go to (2-2)


(It can select multiple items at once)


Note: Execute Restore Logical Device after you confirm the target Logical Device is blocked.



(2-1) Select (CL) LDEVs which you want to format from "Logical Device Status Detail", and select (CL) [Restore]. Go to (2-2). (It can select multiple items at once.)









(2-2) Select (CL) the corresponding LDEV from the LDEV ID list in the 'Logical Device' dialog box and select (CL) [OK].


If the target LDEV was not blocked, return to the 'Logical Device Status' dialog box.



(3) Select (CL) the corresponding item from the Restore Type in the 'Restore Logical Device' dialog box and select (CL) [OK].



If "Forcible Restoration" is selected, the message "Ask the TSC about the appropriateness of this operation, and enter the password." is displayed.
Enter the password and select (CL) [OK].




Notice

This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss and requires an input of a password. Ask the technical support center about the appropriateness of the operation, and input the password after getting an approval of executing the operation.


(4) "Restoring..." is displayed.

(5) Select (CL) [OK] in response to "Restoring the logical device is completed.".



(6) Select (CL) [Close] in the 'Logical Device Status' dialog box. Close the 'Maintenance' window.

- [5] Refer the system configuration data
- (1) Select (CL) [Renewal] in the 'Logical Device Status' dialog box.



(2) "Reading the subsystem configuration..." is displayed.

(3) Select (CL) [Close] in the 'Logical Device Status' dialog box.Close the 'Maintenance' window.

Copyright ©2001, Hitachi, Ltd.


| REV.0 | Oct.2001 | | | | |
|-------|----------|--|--|--|--|
|-------|----------|--|--|--|--|

[6] Verify Logical Device

Notice


Executing this operation may cause a serious error such as a system down or a data loss. Accordingly, confirmation of the appropriateness of the operation and input of a password on the succeeding password input screen is required.

(1) Select (CL) an LDEV from the LDEV list box in the 'Logical Device Maintenance List' dialog box and select (CL) [Verify...].




(2) Select (CL) the corresponding LDEV from the LDEV ID list in the 'Logical Device' dialog box and select (CL) [OK].

If the target LDEV was not Normal, return to the 'Logical Device Status' dialog box.




(3) Enter the password and select (CL) [OK].



Notice

This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss and requires an input of a password. Ask the technical support center about the appropriateness of the operation, and input the password after getting an approval of executing the operation.

Select (CL) 'Auto Correct' or input the value of Error Stop, and select (CL) [OK].




(4) "Verifying logical devices..." is displayed and the parity synchronization check is started.


When you want to interrupt the check, select (CL) the [Stop] button.

The routine goes to Step (5).

When the parity synchronization check is completed, if a PDEV that could not be checked exists, the routine goes to Step (6), or if an LDEV whose parity is not synchronized exist, the routine goes to Step (7), or if neither of the above exists, the routine goes to Step (13).




When the check is started on condition that a parity group or an HDEV is specified



When the check is started on condition that two or more parity groups are specified

(5) When you select (CL) the [Stop] button in the "Verify" window that shows progress of the check and select (CL) the [OK] button in response to a message, "The synchronization check of the logical device is interrupted," that asks whether or not to interrupt the check, the parity synchronization check is interrupted immediately.



When a PDEV that could not be checked exists, the routine goes to Step (6).


When an LDEV whose parity is not synchronized exist, the routine goes to Step (7). When neither of the above exists, the routine goes to Step (13).

(6) The PDEV that could not be checked is displayed. The PDEV concerned may have not been checked because it was detached or the synchronization check was interrupted. Check the status of the PDEV concerned after the synchronization check is terminated.

When you close the "Skip PDEV" window, select (CL) the [OK] button.


When an LDEV whose parity is not synchronized exists, if Step

- (9) is not displayed yet, the routine goes to Step (7), or if Step
- (9) has already been displayed, the routine goes to Step (9).




(7) "Do you want to output the result of Verify to a file?(MAX: ***) A result file is output and compressed when "FD Copy" or "Auto Dump" is performed." is displayed.

(Time required for processing is displayed on ***.)



If you want to output the result to a file, select (CL) [Yes] and go to (8). If you want to not output the result to a file, select (CL) [No] and go to (9).

(8) "Receiving the Verify result..." is displayed. "Compressing the Verify result..." is displayed. "The output of a result file was completed." is displayed.




(9) An LDEV having parity errors is displayed. Select (CL) an LDEV to be indicated in the 'Parity Error' dialog box and select (CL) [Detail...]. Go to (10).

If you want close the 'Parity Error' dialog box, select (CL) [Close]. When select (CL) [Yes] by (7), go to (13).

When select (CL) [No] by (7), go to (12).

If you want to output the result to a file, select (CL) [Dump] and go to (7).



When you want to display the "Skip PDEV" window again, select (CL) the [Skip PDEV] button. The routine is returned to Step (6).

(10) Detail of parity errors.

(When "No." exist more than 17, select (CL) [Next].)


Note: For OPEN-LDEV, only LBA's are


displayed. If LBA of the error slot can not be displayed, "----" is displayed in both CCHH and LBA columns.

As for "Logical Device:", LDEV#:"XXX" of the error slot and LDEV#:"(YYY)" at the head of extension LU are displayed.

But, the LDEV at the head of extension LU doesn't display "(YYY)".


(Multi Cabinet Model)





(11) Select (CL) [Close] in the 'Detail' dialog box. Go to (9).


(12) "The result of Verify is not outputted to a file. Are you sure you want to terminate processing? If you want to output the result to a file, select No, and then select Dump button." is displayed.




If you want to terminate processing, select (CL) [Yes] and go to (13). If you want to output the result to a file, select (CL) [No] and go to (9).

(13) When the parity synchronization check is not interrupted, a message, "Parity synchronization check was completed normally," is displayed.

When the parity synchronization check is interrupted, a message, "The SVP interrupted the synchronization check of the logical device," is displayed.





(14) Select (CL) [close] in the 'Logical Device Status' dialog box. Close the 'Maintenance' window.

[7] LDEV recovery for multiple PDEV failures

If this procedure is performed, the blockaded PDEV within a parity group will be restore and LDEV will be recovered in the collection access state. (It may be unable to restore depending on the contents of the obstacle of PDEV.)

Notice:

This function does not eliminate an obstacle factor. After data backup, PDEV replace and LDEV format may be required.

Please inform a technical support center and be sure to follow the directions for this judgment.

(1) Select (CL) ECC group from the LDEV list box in the 'Logical Device Status' dialog box.

Restore by Ldev unit:

Select (CL) [Detail] ----- Go to (2-1)

Restore by ECC group:


Select (CL) [Restore] ----- Go to (2-2)


(It can select multiple items at once)

Note: Execute Restore Logical Device after you confirm that the target Logical Device is blocked.

(2-1) Select (CL) LDEVs which you want to format from "Logical Device Status Detail", and select (CL) [Restore]. Go to (2-2). (It can select multiple items at once.)


(Multi Cabinet Model)





(2-2) Select (CL) the corresponding LDEV from the LDEV ID list in the 'Logical Device' dialog box and select (CL) [OK].

If the target LDEV was not blocked, return to the 'Logical Device Status' dialog box.




(3) "Restoring..." is displayed.
The recoverable PDEV is restored.

If "The replaced physical devices could not spin up." is displayed, this recovery procedure cannot be performed.

Execute the Work ID = RDK7 on page REP01-150.



(4) Select (CL) [OK] in response to "Restoring the logical devices is completed.".



(5) Please refer ECC group status.

If status is 'Blocked', execute the Work ID = RDK7 on page REP01-150.


Select (CL) [Close] in the 'Logical Device Status' dialog box. Close the 'Maintenance'.

[8] Only a Blockade Logical Device FORMAT with together


Notice

Executing this operation may cause a serious error such as a system down or a data loss. Accordingly, confirmation of the appropriateness of the operation and input of a password on the succeeding password input screen is required.

(1) Select (CL) [Logical Device Format].



(2) Select (CL) [Yes] in response to "This process will format blocked logical devices only. Are you sure you want to continue this process?".




(3) Select (CL) [OK] in response to "This process will format logical devices at low speed.

When you want to format all logical devices, change the current mode to INTIAL SETUP MODE, and then retry the "Logical Device Format" operation.".



(4) "Data in the specified device may be lost due to this operation. You need the password to continue." is displayed.


Enter the password and select (CL) [OK].




Notice

This is a special (exceptional) operation that can cause a serious failure such as a system down or a data loss and requires an input of a password. Ask the technical support center about the appropriateness of the operation, and input the password after getting an approval of executing the operation.

(5) "Formatting logical device..." is displayed.



(6) Select (CL) [OK] in response to "Formatting was finished.".



(7) Close the 'Install' window.

2.11.2 Open VOL


| [1] FORMAT Open VOL | SVP02-880 |
|-----------------------|-------------|
| | |
| [2] Block Open VOL | SVP02-900 |
| [3] Restore Open VOL | SVP02-920 |
| [5] Restore open (oz | 3 11 02 220 |


(1) Select (CL) the [Maintenance] in the 'SVP' window.

(2) Select (CL) [Open VOL] in the 'Maintenance' Window.

If the shredding process is running for some logical devices from Storage Navigator, go to (3). If the Shredding process is not running, go to (4).


(Multi Cabinet Model)






(3) "Shredding" is displayed.

If processing is finished. ----- Go to (4). If you want to close the Window, select (CL) [Close]. ----- Go to (2). If you want to interrupt this process, select (CL) [Stop]. Note: Confirm to user that the process is interrupted. ------ Go to (4).



(4) 'Open VOL' is displayed.




[1] FORMAT Open VOL


(1) Select (CL) Open VOL from the Open VOL list box in the 'Open VOL' window.

Format by LDEV unit: Select (CL) [Detail] ------Go to (2) Format by Open VOL: Select (CL) [Format] ------Go to (3) (It can select multiple items at once.)

Note: Execute Format Open VOL after you confirm that the target Open VOL is blocked.




(2) Select (CL) LDEVs which you want to format from 'Open VOL Detail' window, and select (CL) [Format]. Go to (3). (It can select multiple items at once.)




(3) "Data in the specified logical device may be lost due to this operation. You need the password to continue." is displayed. Enter the password and select (CL) [OK].

Password is needed for this operation. Please call Technical Support Center to obtain the password and authorization.



(4) "Formatting the logical device..." is displayed.



(5) Select (CL) [OK] in response to "Formatting was finished.".



(6) Select (CL) [Close] in the 'Open VOL' window. Close the 'Maintenance' window.


| REV.1 |
|-------|
|-------|

[2] Block Open VOL


(1) Select (CL) Open VOL from the Open VOL list box in the 'Open VOL' window.

Blocked by LDEV unit:
Select (CL) [Detail] ------Go to (2)
Blocked by Open VOL:
Select (CL) [Block]------Go to (3)
(It can select multiple items at once.)

Note: Execute Format Open VOL after you confirm that the target Open VOL is blocked.



(2) Select (CL) LDEVs which you want to block from the 'Open VOL Detail' window, and select (CL) [Blockade]. Go to (3). (It can select multiple items at once.)




(3) "Data in the specified logical device may be lost due to this operation. You need the password to continue." is displayed.

Enter the password and select (CL) [OK].


Password is needed for this operation.

Please call Technical Support Center to obtain the password and authorization.



(4) "Blocking the logical device..." is displayed.

(5) Select (CL) [OK] in response to "Blocking the logical device is completed.".



(6) Select (CL) [Close] in the 'Open VOL' window. Close the 'Maintenance' window.

Copyright ©2001, Hitachi, Ltd.

| REV.0 Oct.2001 |
|----------------|
|----------------|

- [3] Restore Open VOL
- (1) Select (CL) Open VOL from the Open VOL list box in the 'Open VOL' window.

Restore by LDEV unit:


Select (CL) [Detail] ------Go to (2)

Restore by Open VOL:


Select (CL) [Restore]------Go to (3)

(It can select multiple items at once.)


Note: Execute Restore Open VOL after you confirm that the target Open VOL is blocked.



(2) Select (CL) LDEVs which you want to restore from the 'Open VOL Detail' window, and select (CL) [Restore]. Go to (3). (It can select multiple items at once.)



(3) Select (CL) the corresponding item from the Restore Type in the 'Restore Logical Devices' window and select (CL) [OK].




If "Forcible Restoration" is selected, the message "Ask the TSC about the appropriateness of this operation, and enter the password." is displayed.

Enter the password and select (CL) [OK].

Password is needed for this operation.

Please call Technical Support Center to obtain the password and authorization.



(4) "Restoring..." is displayed.

(5) Select (CL) [OK] in response to "Restoring the logical device is completed.".



(6) Select (CL) [Close] in the 'Open VOL' window. Close the 'Maintenance' window.


| REV.0 Oct.200 |
|---------------|
|---------------|


2.12 Pin Data indication


Prerequisite operation

(1) Select (CL) [Maintenance].

(2) Select (CL) [PIN] in the 'Maintenance' dialog box.








(3) Display an LDEV with a pinned slot. Select (CL) the LDEV, details of which you want to display, in "Ldev" and select (CL) "Detail....".

-----Go to Step (4).

Note: When the pinned slot is gone, the LDEV, an occurrence of the pinned slot in which was reported by a SIM, is not displayed.

When you want to output pinned data to a file, select the [Archive] button.

-----Go to Step (5).



When you close the "Pinned Track" window, select (CL) the [Close] button.
------Go to Step (7).

(4) Display the detail of a Pin Slot.


If there are more than 17 Pin Slots, the [Next] button will display other Pin Slots.)

Note: If a Pin Slot has some recoverable trouble, the detail of the Pin Slot will not be displayed. In case of OPEN-LDEV, only LBA's Pin Slots are displayed. But, if the Pin Slot of LBA's can't be displayed, "----" is displayed in both CCHH and LBA columns.


When you want to close the 'Detail' windows, select (CL) [Close] button.

-----Go to Step (3).

(Multi Cabinet Model)



(Single Cabinet Model)



| (5) | "Do you want to output pinned data to a file? You can get the pinned data file by executing the FD Copy or Auto Dump," is displayed. When you want to output the result to a file, select (CL) [Yes]. |
|-----|--|
| (6) | "Output of the pinned data file was completed," is displayedGo to Step (3). |
| (7) | Select (CL) [Close] in the 'Detail' dialog box. Select (CL) [Close] in the 'Pin Volume' dialog box. Close the 'General Status' window. |

Copyright ©2002, Hitachi, Ltd.

| REV.0 | Dec.2002 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|

2.13 Multi PCB Replace

(1) <Set path offline> Set the path offline from HOST when replacing CHA.

(2) <Maintenance>

The 'Maintenance' window is displayed.


(Multi Cabinet Model)

In the 'Maintenance' window, check and select (CL) [Controller] to be replaced.


(Single Cabinet Model)

In the 'Maintenance' window, check and select (CL) [Controller] to be replaced.

(Multi Cabinet Model)



(Single Cabinet Model)



(3)

(Multi Cabinet Model)


<DKC window>

Select (CL) [Cluster-n] in the 'DKC'.

(Single Cabinet Model)


<Controller window>

Select (CL) [Cluster-n] in the 'Controller'.




(4) <Select Multi PCB Replace> Select (CL) [Multi PCB Replace]. Selecting (CL) [Close] returns you to step (3).


(Multi Cabinet Single Phase Model, Multi Cabinet 3 Phase Model [30A AC BOX])



(Multi Cabinet 3 Phase Model [Without 30A AC BOX])




(Single Cabinet Model)



(ex. Cluster-1)

(5) <Select CHA/DKA>
Select (CL) CHA/DKA PCB.
Select (CL) [Replace].




Notice:

When the subsystem is placed online, ask the customer to place it offline.

Notice:

When the screen prompting an operator to input a password in order to prevent multiple maintenance, contact the technical support center to ask for instructions.

(6) <Enter Password>
Enter the password in response to
[Password?] and select (CL) [OK].



Notice

Executing this operation may cause a serious error such as a system down or a data loss. Accordingly, confirmation of the appropriateness of the operation and input of a password on the succeeding password input screen is required.

(7) <Confirm Channel Path offline> Select (CL) [OK] in response to "Please confirm you have already varied off the concerned Channel paths. If OK, please press OK."

If a Fibre channel adapter is installed: After you confirm that you have stopped concerned SCSI Channel paths, select (CL) [Yes].

If a NAS adapter is installed: After you confirm that you have stopped concerned service, select (CL) [Yes].

CHA and CHA (SCSI) exist: After you confirm that you have stopped concerned Channel paths and SCSI channel paths, select (CL) [Yes].

CHA and CHA (NAS) exist: After you confirm that you have stopped concerned Channel paths and service, select

(CL) [Yes].


CHA (SCSI) and CHA (NAS) exist: After you confirm that you have stopped concerned SCSI Channel and service, select (CL) [Yes].

CHA, CHA (SCSI) and CHA (NAS) exist: After you confirm that you have stopped concerned Channel paths, SCSI Channel and service, select (CL) [Yes].

















(8) <Caution message for system down>



Notice

Select (CL) [Yes] in response to the message below.

"Automatic subsystem check for error prevention will be performed when blocking target the PCB.

Yes = Normal replacement

No = Forcible replacement

(Possible critical errors)"


- (9) <CHA/DKA blocking>
 - * For CHA
 - "The CHA-xx is being blocked... Usually, several minutes (maximum 15 minutes)"
 - * For DKA
 - "The DKA-xx is being blocked..."
- (10) < Check to see if shut down LED is lit>

Select (CL)

- * [Yes] if LED is on
- * [No] if LED is off

in response to "Is the LED of the target PCB(s) lit?". If [No] is selected:

Select in response to "Is the LED of the target PCB(s) lit?" again.



Notice

If the jumper is inserted in the wrong PCB, a system down may occur.

<Forcing shut down LED on>

If [No] is selected twice:

Insert a jumper in response to "Please insert jumper into the target PCB, then pull it out without considering the status of the LED".



For CHA (SERIAL) HARDWARE C (REP03-80)


For FIBRE HARDWARE D (REP03-110)

For DKA HARDWARE E (REP03-140)

(11) < Beginning of CHA / DKA Replacement>

"Please replace the PCB(s), and then select OK." is displayed.

Select (CL) [OK] after replacing the PCBs.



For CHA (Serial) Go to HARDWARE C (REP03-80) For FIBRE Go to HARDWARE D (REP03-110) For DKA Go to HARDWARE E (REP03-140)

(12)

Select (CL) [OK] in response to "Please replace the PCB(s). After replacement, please press OK."

"Waiting for Power Event... Usually, several minutes (maximum 10 minutes)" is displayed.

(13) < Check the recovery processing >


The following message is displayed:

- * For DKA
- "Restoring the DKA-xx..."
- "DKA-xx is being path recovered..."

Copyright ©2001, Hitachi, Ltd.

| REV.0 | Oct.2001 | | | | |
|-------|----------|--|--|--|--|
|-------|----------|--|--|--|--|

(14) <Check the end of CHA/DKA recovery> Select (CL) [OK] in response to "Replace finished.".



Notice

When one or more PCBs are replaced normally, "Replace finished." will be displayed. So please confirm PCBs' status.

(15) < Path on-line when CHA is replaced>

Whenever a CHA is replaced, set the path (from the host) on the replaced CHA to ONLINE by your customer.

(16) <SIM Complete>
Go to SVP02-580.

(17)

Close the 'Multi PCB Replace' window.

Close the 'Cluster-n' window.

Close the 'Maintenance' window.

| REV.0 Oct.2001 | |
|----------------|--|
|----------------|--|

2.14 System Option

[Overview]

Change the following system option when the system operates.

<1> Spare Disk Recovering - Select the performance density when data is copied to a spare disk. (correction copy and drive copy)

• Interleave : Everytime 4-slot copy is completed, copy job

sleeps for the time dependent on load of HOST

I/O.

• Offline : No sleep. (No considering HOST job)

NOTICE

Please do not use if no channel paths is varied offline.

<2> Disk Copy Pace ------ Specification of copy pace is supported with the "Interleave" mode at Spare Disk Recovering. Three modes are supported.

• Medium : Optimization mode. The copy time depends on

load of HOST I/O.

• Faster : Copy job is prior to HOST job.

• Slower : HOST job is prior to copy job.

<3> Copy Operation ----- • Dynamic Sparing : Copy automatically to a spare disk if disk

failure exceeded the threshold value.

• Correction Copy : Execute correction copy to a spare disk

automatically when one drive has

blocked.

<4> Read Configuration Data Mode

------ To change the method of adding S/N which DKC reports by the Read Configuration Data command.

• OFF : Compatible method

• ON : 4096 support method (default)

<5> PS Off Timer ----- Enters the Destage time. (25 [min])

• OFF : The Destage time is effectively.


• ON : The Destage time is ineffectively, and change the Destage time.

<6> AC Box -----Change the DKC and DKU AC Box configuration.


<7> Link Fail Threshold ----- Set up the threshold which notifies the link failure.

(1) Change the Mode from [View Mode] to [Modify Mode]. Select (CL) [Install].

(2) Select (CL) the [Change Configuration] menu in the 'Install' window and select (CL) [OK].




(3) Select (CL) the [System Option] menu in the 'Menu Dialog' window and select (CL) [OK].




(4) Select (CL) the desired item in the 'System Option' dialog box, and select (CL) [OK].

[AC Box...]: Set the DKC and DKU AC Box configuration. (Refer to step 4-1.)




(4-1) <Setting the AC Box configuration>
Set the DKC and DKU AC Box configuration, select
(CL) the [OK]. Return to step 4.



(5) "Loading configuration..." is displayed.

(6) "Change configuration was completed." is displayed. Select (CL) [OK].



(7) "Reading subsystem configuration data..." is displayed.


"Please insert the Config FD in the FDD." is displayed.

Insert the configuration FD into FDD, select (CL) [OK].




(8) When this procedure is completed, the message "Please remove the Config FD." is displayed.

Remove the FD, select (CL) [OK].



(9) Close the 'Install' window. Select (CL) [File]-[Exit].



(10) Change the Mode from [Modify Mode] to [View Mode].

2.15 Blocking of Cluster




This is a special operation. Ask the technical support center about the appropriateness of the operation.

The following is an example procedure for blocking of Cluster-1.


1. Select (CL) [Maintenance].

2. Select (CL) the [Maintenance] menu in the 'Maintenance' dialog box and select(DR) [Blockade].

(Multi Cabinet Model)




(Single Cabinet Model)




3. Select (DR) the [Cluster-n] to be blocked.

(Multi Cabinet Model)



(Single Cabinet Model)



4. Beginning of Blocking

• When only serial or parallel channels, or they are mixed.

Select [Yes] (CL) in response to "Please confirm you have already varied off the concerned channel path(s). Do you want to block xxxxx?".



• When SCSI channels and other kinds are mixed. Select [Yes] (CL) in response to "Please confirm you have already varied off the concerned channel path(s). Please confirm you have already shutdown concerned



connecting SCSI host(s) or switched to the alternate SCSI channel path(s). Do you want to block xxxxx?".

• When only SCSI channels are installed. Select [Yes] (CL) in response to "Please confirm you have already shutdown concerned connecting SCSI host(s) or switched to the alternate SCSI channel path(s). Do you want to block xxxxx?".




Valid xxxxx values are listed below.

- Cluster-1
- Cluster-2

5. Processing to Cluster block.

- "Reading configuration..."
- "Blocking cache memory..."
- "Blocking shared memory..."
- "Blocking CHA..."
- "Blocking CHP..."
- "Blocking DKA..."
- "Blocking DKP..."
- "Blocking CSW..."
- "Blocking Cluster failure report..."
- "Processing to disable the environment check..."



6. End of Cluster block
Select [OK] (CL) in response to "The blockade has finished. Cluster is blocked.".



7. Close the 'Maintenance' window.

| REV.0 | Oct.2001 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|

2.16 Recovering of Cluster


Note: Before recovering of Cluster, please reboot SVP.

The following is an example procedure for blocking of Cluster-1.


1. Select (CL) [Maintenance]

2. Select (CL) the [Maintenance] menu in the 'Maintenance' and select(DR) [Recover].

(Multi Cabinet Model)




(Single Cabinet Model)




3. Select (DR) [Cluster-n] to be recovered.

(Multi Cabinet Model)



(Single Cabinet Model)




4. Beginning of Recovery Select [Yes] (CL) in response to "Do you want to recover xxxx?".

Valid xxxx values are listed below.

- Cluster-1
- Cluster-2

If Cluster 1/2 is fail. Go to 5
If Cluster 1/2 is blockade. Go to 8
If Cluster 1/2 is normal. Go to 9



- 5. Confirm varied Off-line.
 - When only serial or parallel channels, or they are mixed. Select [OK] (CL) in response to "This operation will block xxxxx before recovery. Please confirm you have already varied off the concerned channel path(s). Do you want to continue?".



• When SCSI channels and other kinds are mixed.

Select [OK] (CL) in response to "This operation will block xxxxx before recovery. Please confirm following items.

- 1. Varied off the channel path(s).
- 2. Shutdown connecting SCSI host(s) or switched to the alternate SCSI channel path(s). Do you want to continue?".
- When only SCSI channels are installed. Select [OK] (CL) in response to "This operation will block xxxxx before recovery. Please confirm you have already shutdown concerned connecting SCSI host(s) or switched to the alternate SCSI channel path(s). Do you want to continue?".






- Valid xxxxx values are listed below. • Cluster-1
- Cluster-2

6. Processing to Cluster block.

- "Reading configuration..."
- "Checking status of Cluster..."
- "Blocking Cluster..."
- "Blocking cache memory..."
- "Blocking shared memory..."
- "Blocking CHA..."
- "Blocking CHP..."
- "Blocking DKA..."
- "Blocking DKP..."
- "Blocking CSW..."
- "Blocking Cluster failure report..."
- "Processing to disable the environment check..."



7.

A CAUTION

- In this section, operate only 5/3VPSxA and 5/3VPSxB in the appropriate cluster.
- Do not operate other PSs. Otherwise, a system down or a part failure way occur.
- This operation Lights up the SUBSYSTEM ALARM LED. Ignore the Light because it goes out with the operation of the LED TEST/CHK RST switch.

Select [OK] (CL) response to


- "Please perform the following operation.
- 1. Switch all 5/3VPSs in Cluster-X to DISABLE.
- 2. Switch all 5/3VPSs in Cluster-X to ENABLE.
- 3. Turn the LED TEST/CHK RST switch on DKC-PANEL to CHK RST.
- 4. Select OK.".

Valid X values are listed below.

- Cluster-1 --- 1
- Cluster-2 --- 2

| REV.1 Oct.2001 | Aug.2002 | | | | |
|----------------|----------|--|--|--|--|
|----------------|----------|--|--|--|--|

8. The SVP automatically checks the power supplies to determine if cluster is recoverable.



- "Reading configuration..."
- "Checking status of Cluster..."
- "Restoring Cluster..."
- "Checking Power on..."
- "Waiting for Power Event...

Usually, several minutes(maximum 15 minutes)"

- "Reading configuration..."
- "Restoring DKA (PDEV Spin up)..."
- "Restoring DKP Path..."
- "Restoring Cluster failure report..."
- "Setting C-Port register..."
- "Running INLINE CUDG..."
- "Running CSW Path test..."
- "Restoring shared memory..."
- "Restoring cache memory..."
- "Processing to enable the environment check..."

| OTHERS | |
|-----------------------|--|
| Reading configuration | |
| ' | |
| | |
| | |

| REV.0 Oct.2001 | | | | |
|----------------|--|--|--|--|
|----------------|--|--|--|--|

10. End of Cluster Recover


• When only serial or parallel channels, or they are mixed.

Select (CL) [OK] in response to "The restore has finished. Cluster is enabled. The concerned channel path(s) are available. Please vary the path(s) on.".




• When SCSI channels and other kinds are mixed. Select (CL) [OK] in response to "The restore has finished. Cluster is enabled. The concerned channel path(s) and SCSI channel

has finished. Cluster is enabled. The concerned channel path(s) and SCSI channel path(s) are available. Please vary the path(s) on.".



• When only SCSI channels are installed. Select (CL) [OK] in response to "The restore has finished. Cluster is enabled. The concerned SCSI channel path(s) are available.".




11. Close the 'Maintenance' window.


2.17 HDD Configuration

(1) Select (CL) [Install].


(2) Select (CL) [Change Configuration] on the 'Install' map screen in the 'Install' screen.



(3) Select (CL) [HDD Configuration] on the 'Menu Dialog' screen, and select (CL) [OK].




(4) Select (CL) [Yes] in response to the message "Are you sure you want to change HDD Configuration?".




| REV.0 | Oct.2001 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|

(5) The message "Loading Configuration..." is displayed.


(6) Select (CL) [OK] in response to the message "Change Configuration was completed." to terminate the processing.



(7) The message "Reading subsystem configuration data..." is displayed, and also the message "Please insert the Config FD in the FDD." is displayed. Insert Config FD into FDD and select (CL) [OK].



(8) After the completion of FD backup, the message "Please remove the Config FD." is displayed.Pull out FD from FDD and select (CL) [OK].




| REV.0 | Oct.2001 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|

2.18 PCB Revision Display

(1) Select (CL) [Install] in the 'SVP' window.


(2) Select (CL) [PCB Revision Display] in the 'Install' window.



(3) 'Reading or Writing PCB revision informations...' is displayed.

| REV.0 Oct.2001 | | | |
|----------------|--|--|--|
|----------------|--|--|--|

- (4) Select a PCB whose revision you want to display in the 'PCB Revision Display' window.
 - When [Write] is selected (CL) in the 'PCB Revision Display' window, the revision will be displayed again after the processing is completed.



(5) Select(CL) [Close] in the 'PCB Revision Display' dialog box.

(6) Close the 'Install' window.

| REV.0 Oct.2001 | | | |
|----------------|--|--|--|
|----------------|--|--|--|


2.19 Tuning Parameter

(1) Exchange threshold information. (See MICRO-FC08-10)


(2) Select (CL) [Install].

(3) Select (CL) the [Change Configuration] menu in the 'Install' window and select (CL) [OK].

(4) Select (CL) the [Tuning Parameter] menu in the 'Menu Dialog' window and select (CL) [OK].



(5) Select (CL) [Yes] for a message of confirming.




(6) Select (CL) [OK] for a message of finishing.




2.20 Change CM Module group size

1. Close the all SVP menu.

2. <Enter the password>
Press "Shift+Ctrl+C" in the 'SVP' window.
Enter the password, and select (CL) [OK].
(Please call Technical Support Center for asking it.)



3. <CM Replace Mode>
'CM Replace' is displayed.
Select (CL) [Maintenance].




4. <Maintenance window>

'Maintenance' window is displayed.


(Multi Cabinet Model) In the 'Maintenance' window, check and select (CL) [DKC] to be replaced.

(Single Cabinet Model)
In the 'Maintenance' window, check and select
(CL) [Controller] to be replaced.

(Multi Cabinet Model)



(Single Cabinet Model)



5.

(Multi Cabinet Model)


<DKC window>

Select (CL) [Cluster-n] in the 'DKC'.

(Single Cabinet Model)


<Controller window>

Select (CL) [Cluster-n] in the 'Controller'.




6. <Select Cache> Select (CL) part.

(Multi Cabinet Single Phase Model, Multi Cabinet 3 Phase Model [30A AC BOX])



(Multi Cabinet 3 Phase Model [Without 30A AC BOX])



(Single Cabinet Model)

| Cluster-1 | |
|-----------------------------------|-------------------------------|
| - Main Platter | _P/S |
| CACHE-1E Cache Side Status Normal | 5/3VPS1A Systatus Normal |
| CSW-1A | 3/12VPS1A 3/12VPS1B 3/12VPS1B |
| CHA-1C DKA-1B | |
| CHA-1D DYA-1F CHA-1F | 12VSUB Status |
| | SUBPS1 Normal |
| Multi PCB Replace | SVP-PS1 |
| Fan | |
| | Close (<) |


(ex. Cluster-1)

7. <Replace>

A CAUTION


When the screen appears prompting the operator to input a password to prevent multiple maintenance or for executing a pin check, contact the technical support center to ask for instructions.

Check status display. Select (CL) [Replace].



8. <Change the Cache Memory Module Size>
Select (CL) module size in the 'Cache
Memory Module Size Mode', and select (CL)
[OK].

"The CMG size will be changed. xxxxMB -> xxxxMB The shared memory will be blocked in this processing.", and select (CL) [OK]. xxxx is CMG of before and after size.



If any other message than the list is displayed, see the SVP Message Section (SVPMSG00-00).

9. <Check beginning of cache blocking> Select (CL) [Yes] after making sure that the package to be blocked is correct in response to:



"Are you sure you want to block the Shared

Memory and Cache Memory PCB? If you select [Yes], physically pulling off and putting in of PCB will be unavoidable."

10. < Cache blocking >


- "The Cache Memory PCB is being blocked." is displayed.
- "The Shared Memory PCB is being blocked..." is displayed.

11. <Check removal of cache>

Select (CL) [Yes] in response to:

- * For CACHE (with SM)
- "Do you want to pull out the Shared Memory and Cache Memory PCB now?"
- * For CACHE

"Do you want to pull out the Cache Memory PCB now?"



12. <Check shut down LED>


Select (CL)

- * [Yes] if LED is on
- * [No] if LED is off

in response to "Is the LED of the target PCB lit?".

When [No] is selected, the same message is displayed again.

Check the LED and then reply to a message.



<Forcing shut down LED on>



If the jumper is inserted in the wrong PCB, a system down may be caused.

If [No] is selected:

Insert a jumper in response to "Please insert jumper into the target PCB (CACHE-nn), then pull it out without considering the status of the LED".

(Refer REP03-50)




| REV.0 Sep.2003 | | | |
|----------------|--|--|--|
|----------------|--|--|--|

13. <Cache Replacement>

At this point refrain from pressing the [OK] button. "Replace the Cache Memory PCB. When you finish replacing the PCB, please select OK." is displayed.

Make sure of the installation location and size of the module to be added and insert the correct module in the correct location.

(Uninstalled module is displayed as looks depressed.)



14. <Replace cache PCB> Replace cache.

See HARDWARE B (REP03-50)

15. < Check the beginning of cache/SM recovery>




CAUTION

Selecting "No" stops the recovery and places the cache in the status being blocked for maintenance.

Select (CL) [Yes] in response to:


- * For CACHE (with SM)
- "Do you want to restore the Shared Memory and Cache Memory PCB now?"



16. <Restoring the Shared Memory> "Restoring the Shared Memory PCB..." is displayed.

17. <Restoring the Cache Memory>
"Restoring the Cache Memory PCB..." is displayed.

18. < Check the end of Cache/Shared Memory recovery> Select (CL) [OK] in response to "Replace finished.".



19.

Close 'CACHE-xx' window. Close 'Cluster-n' window. (If finishing in the Cluster-2 side, go to 21.)

20. <Change the Cache Memory module size in Cluster-2 side> Perform steps 5 to 19. Select [Cluster-2], [CACHE-2G] or [CACHE-2F].

21.

Close 'DKC' window.

Close 'Maintenance' window.

Change the mode to [View Mode].

Copyright ©2001,2003, Hitachi, Ltd.


| REV.2 | Oct.2001 | Aug.2002 | Sep.2003 | | | |
|-------|----------|----------|----------|--|--|--|
|-------|----------|----------|----------|--|--|--|

2.21 Setting Battery Life


Set the Battery Life warning SIM to prompt to prepare the periodical exchange maintenance of a battery before the lifetime of the battery (2.5 years) equipped in the Subsystem. Set the number of days remained until you generate [Battery Life Warning SIM] based on your maintenance plan.

1. Select (CL) the [Setting Battery Life] menu in the 'Install' window.

2. Select [Set...] applying the check to 'Battery Life Warning SIM'.



3. Select (CL) [OK] after inputting the remainder days until Warning SIM is reported.




- Note 1: After executing the periodical exchange of a battery, set 27 month (810 days).
- Note 2: Default value is 27 month (810 days), which is 3 month earlier than the lifetime of a battery (2.5 years).


Determine the number of days remained based on your maintenance plan.

4.

"Please insert the Config FD in the FDD." is displayed. Insert the configuration FD into FDD, select (CL) [OK].



5. When this procedure is completed, message "Please remove the Config FD." is displayed. Remove the FD, select (CL) [OK].



6. "Backup Configuration..." is displayed.



7. Close the 'Install' window.

2.22 Switch SVPs

This SVP function is valid if SVP High Reliability Kit is installed.

- [1] Operating Master SVP
- (1) <Initial screen>


(2) <Operation mode change>
Change the mode to [Modify Mode].
Select (CL) [Maintenance].

(3) <Maintenance window> The 'Maintenance' window is displayed.


> (Multi Cabinet Model) In the 'Maintenance' window, check and select (CL) [DKC] to be replaced.

> (Single Cabinet Model)
> In the 'Maintenance' window, check and select
> (CL) [Controller] to be replaced.

(Multi Cabinet Model)



(Single Cabinet Model)



(4)

(Multi Cabinet Model)


<DKC window>

Select (CL) [SVP] in the 'DKC'.


(Single Cabinet Model)

<Controller window>

Select (CL) [SVP] in the 'Controller'.




(5) <Replace window>
Select (CL) "Switch SVPs with Transfer
Config Data" in the 'Replace' window.
And select (CL) [Execute].



(6) <Execution> Select (CL) [Yes].

* The switching takes about 30 minutes.




(7) <Transfer status>

"Transferring subsystem configuration data..." in displayed.

Transferring subsystem configuration data...

Phase 1/3


(8) <Checking beginning of the SVP switching>
The message "Switching SVPs has started." is displayed.
The SVP is powered off automatically owing to the SVP switching. Make sure that the Standby SVP has started up.



- [2] Operating Standby SVP
- (1)

The Standby SVP restarts automatically again after the Standby SVP is powered on. Wait until restart is end.

(2) <Initial screen>
When the RAID Information window is displayed, the switching has been completed.



2.23 Transferring Configuration Data

This SVP function is valid if SVP High Reliability Kit is installed.


(1) Change the mode to [Modify Mode]. Select (CL) [Maintenance].

(2) The "Maintenance" window is displayed.


(Multi Cabinet Model)
In the 'Maintenance' window, check and select (CL)
[DKC] to be replaced.

(Single Cabinet Model)
In the "Maintenance' window, check and select (CL)
[Controller] to be replaced.

(Multi Cabinet Model)



(Single Cabinet Model)



(3)


(Multi Cabinet Model)

In the 'DKC' window, check and select (CL) [SVP] to be replaced.


(Single Cabinet Model)

In the 'Controller' window, check and select (CL) [SVP] to be replaced.


(Multi Cabinet Model)




(Single Cabinet Model)



(4) Select (CL) "Transfer Config Data only", and select (CL) [Execute].



(5) In response to a message "Do you want to transfer configuration data?", select (CL) [Yes].




(6) "Transferring subsystem configuration data..." is displayed.

Transferring subsystem configuration data...
Phase 1/3

(7) "Configuration data has been transferred." is displayed, when Configuration data has been transferred. Select (CL) [OK].

If error has occurred while transferring, correct that a replaced SVP has problem of connecting and/or setting.



(8)

(Multi Cabinet Model)

Close 'DKC' window.

Close 'Maintenance' window.

(Single Cabinet Model)

Close 'Controller' window.

Close 'Maintenance' window.

(9)

Change the SVP mode to [View Mode].

3 Activating and Terminating STATUS

3.1 Activating STATUS


(1) Select (CL) the [Maintenance] in the 'SVP' window.


(2) The 'Maintenance' window will appear, on which the message "Reading the Subsystem Configuration. Please wait..." is displayed. Upon completion of reading the system configuration information, go to step (3). If a read error occurs, go to step (4) or (5).

Reading the Subsystem Configuration.

Please wait ...

- *: Please do not change an application's window until SVP-DKC communication finishes.
- (3) The main screen on the right will appear the 'Maintenance' window, and the status activates.





(4) If an error occurs, the details of error is displayed.


"Cluster X is failed!"


X:1 or 2

Select (CL) [OK].

If the status is power supply fault (refer to step SVP03-70), see TROUBLE SHOOTING SECTION (refer to step 3.2.7 (TRBL03-180)).

If the status is normal power supply (refer to step SVP03-70), see SVP SECTION (refer to step 2.16 (SVP02-1110)).






- (5) If an error occurs, the details of the error is displayed.
 - "Connection error occurred. SVP-XXX" is displayed.

XXX: DKC or SSVP

- ② "Initializing SSVP (Phase X/16) Please Wait"
 - $X: 1 \sim 16$
- ③ "SSVP Dump is being performed (Phase X/15). Environment Status cannot be read."

X:1~15

Select (CL) [OK].




(6) The similar screen as in step (3) will appear, but "----" on the button shows that it has an error. Terminate the STATUS and remove the cause of the error, and then reactivate STATUS.


> Note: When a communication error occurred on either the SVP-DKC or the SVP-SSVP, the status that was taken through communication is displayed. The example on the right is the screen displayed when a communication error occurs in SVP-DKC and SVP-SSVP.

When a communication error occurred on either SVP-DKC or SVP-SSVP, refer to "5.3 Recovery Procedure for LAN Error (TRBL05-60)".

(Multi Cabinet Model) Maintenance File Renew Display Maintenance



(Single Cabinet Model)



3.2 Terminating STATUS

(1) Close the 'Maintenance' window. Select (CL) [File] - [Exit] in menu bar on 'Maintenance'. (Screen on the right.)

or

Select (DC) Control Box at the left on the title bar.

or

Select (CL) Control Box - [Close].



3.3 Updating the STATUS display

The STATUS display remains unchanged while the screen is displayed or being switched. To display the latest status, follow the procedure below.

(1) Select (CL) [Renew] - [Renew Status] in the menu bar on the main screen. (Screen on the right)



or

(2) Terminate STATUS and activate it again.

3.4 Main screen

After the STATUS is activated, the buttons on the 'Maintenance' window indicate each status as follows.

(Multi Cabinet Model)

DKC..... Status of the DKC (Details are displayed

on the lower layered screen.)
Valid button : Normal

Blinking button: Failure or under

maintenance

DKU-R1,R2,R3,L1,L2,L3

...... Status of the DKU (Details are displayed

on the lower layered screen.)

Valid button Normal

Blinking button: Failure or under maintenance or during a copy operation

Invalid button : Non-mounted

(Single Cabinet Model)

Controller..... Status of the Controller (Details are

displayed on the lower layered screen.)

Valid button : Normal

Blinking button: Failure or under

maintenance

Disk..... Status of the Disk (Details are displayed on

the lower layered screen.)

Valid button : Normal

Blinking button: Failure or under maintenance or during a copy operation

Invalid button : Non-mounted

Copy Status...... Status of copy operation

Blinking button: Copy operation is in progress. (Details are displayed on the

lower layered screen.)

Invalid button : Copy operation is not performed. (The lower layered screen

is not provided.)

Logical Device... Logical device information is displayed on the lower layered screen.

Valid button : Normal

Blinking button: Failure or vender maintenance.

(Multi Cabinet Model)

(Single Cabinet Model)


Copy Status... Logical Device...

CM/SM Path... OS Install Status...

Front View

- Back Viev

IMPL Status...



Version.......Version information on the micro-program is displayed on the lower layered

screen.

SCSI Path definition is displayed.

Pin......Pinned Track is displayed.

IMPL Status Each MP of IMPL Sequence codes are displayed.

Main Frame Path LCP Path and HTP Path information are displayed on the lower layered screen.

Valid button : Normal

Blinking button: Failure or vender maintenance.

No displayed : Non open volume

OS Install Status OS Install Status for CHN PCBs are displayed on the lower layered screen.

Valid button : Normal

Blinking button: Installing or uninstalled : Non-mounted CHN PCBs No displayed

The menus in the menu bar are explained below.

(Select (CL) [Renew] – [Renew Status].)

[Exit] to close the STATUS.

Display...... A menu to display 'Cluster' by selecting (CL) [PCBs Cluster1] or [PCBs

Cluster2] from the pull down menu.

3.5 DKC (Controller)

(1) Status of DKC (Controller)


Select (CL) [DKC] ([Controller]) on the main screen.

The 'DKC' ('Controller') window will appear.

DKCMN-1 Status of DKCMN-1 and

DKCMN-2 DKCMN-2

Valid button : Normal Blinking button : Failure



Cluster-1 Status of Cluster-1 and Cluster-2

Cluster-2 (Details are displayed on the lower layered screen.)

DKC PanelOnly part names are displayed.

EPO SW

SVP

SSVP/HUB

RS CON

PCI CON

SVPPS-BOX

Write Count...... Memory write Count of SSVP is displayed.

SVP-PS1 AC B0X-C1

5/3VPS18

SVP-PS1 BREAKER BOX-1

Close (X)

Close (⊻)

(Multi Cabinet Single Phase Model,

TH

Multi Cabinet 3 Phase Model

CACHE-1U

FAN

(Multi Cabinet 3 Phase Model

CSW-1A

FAN

[Without 30A AC BOX])

[30A AC BOX])

(2) Status of Cluster-1 and Cluster-2

Select (CL) [Cluster-1] or [Cluster-2] in the 'DKC' window.

The 'Cluster-1/2' window will appear.

3VPSnA Status of the power supplies Valid button : Normal

(3/12VPSnA)5V/3VPSnA

3VPSnB

Blinking button: Failure

Remark: Parenthetic PS installed ENABLER

(3/12VPSnB) 5V/3VPSnB 3VPSnC (3/12VPSnC)

3VPSnD (3/12VPSnD)

SUBPSn SVP-PSn

BREAKER BOX-n.. Only Breaker Box names are displayed.

AC BOX-Xn Only AC Box names are displayed.

5V Status Status of the 5 voltage


3V Status Status of the 3 voltage

12VSUB Status Status of the 12 voltage

Normal

• Warning (abnormal)

(Single Cabinet Model)



(ex. Cluster-1)

FLGFANn1 Status of the fans

FLGFANn2 Valid button : Normal RLGFANn1 Blinking button: Failure

RLGFANn2 RPSFANn1 RPSFANn2

THFn Status of the temperature THRn Valid button : Normal Blinking button: Abnormal

BATTERY-n0...... Status of the expanded power supplies

: Normal BATTERY-n1 Valid button BATTERY-n2 Blinking button: Abnormal

BAT-CTR-n0 BAT-CTR-n1

Cache Side Status..... Status of the Cache Side

- Normal
- Warning (abnormal)
- Failed (blocked due to a failure)
- Blocked (blocked for maintenance)

CACHE-nx..... Status of Cache (Details are displayed on the lower layered screen.)

Valid button : Normal

Blinking button: Failure or under maintenance

Invalid button : Non-mounted

CHA-nx..... Status of the CHA (Details are displayed on the lower layered screen.)

Valid button : Normal
Blinking button : Abnormal
Invalid button : Non-mounted

DKA-nx..... Status of the DKA (Details are displayed on the lower layered screen.)

Valid button : Normal
Blinking button : Abnormal
Invalid button : Non-mounted

n=1:Cluster1, n=2:Cluster2

Close (⊻)

Replace

<u>B</u>lockada

(3) Status of each PCB (Cache)
Select (CL) one of [Cache-nxx/nx] in the

'Cluster-1/2' window.

The window for the selected PCB will appear. The same configuration is used for all PCBs.

Cache Module Status of the cache

memory module

(Displayed for each module group)

Valid button : Normal

Blinking '*' in the button: Failure

'--' displayed in the button : Non-mounted

SM..... Status of the shared memory module

Valid button : Normal

Blinking '*' in the button: Failure or under maintenance

'i' displayed in the button: Non-mounted

PCB Status Status of this package

Valid button : Normal

Blinking button: Warning (abnormal)

: Blocked (blocked for maintenance)

: Failed (blocked due to a failure)

Normal

: Cache Access Error (PCB blocked and CMG

normal)

Logical Path Status... Status of PCB Logical Path

- Normal
- Warning (abnormal)
- Blocked (blocked for maintenance)
- Failed (blocked due to a failure)

| Copy | vriaht | ©2001. | Hitachi, | Ltd |
|------|--------|--------|----------|-----|
| | | | | |

| REV.0 Oct | 2001 | | | | |
|-----------|------|--|--|--|--|
|-----------|------|--|--|--|--|

CHP02-1P

UnKnown

FCP-1B

Logical Path Status

Close (≥)

Replace

Regtore

<u>B</u>lockade

(4) Status of the CHA

Select (CL) one of [CHA-nx] in the 'Cluster-1/2' window. The 'CHA' window will appear.

The CHA part location number is displayed in the

title.

CHPX-XX..... Status of program CHP in the **CHA**

> Valid button : Normal

CHP00-1P

Blinking button: Failure

LCPXX..... Status of program LCP in the LCM

Valid button : Normal Blinking button: Failure

Invalid button : Non-mounted

FCP XX..... Status of FCP

Valid button : Normal

Blinking button: Failed or Blocked (status displayed under FCP button) Invalid button : Non-mounted

HTP XX Status of program HTP

Valid button : Normal Blinking button: Failed

Invalid button : Non-mounted

NOP XX..... Status of program NOP

Valid button : Normal Blinking button: Failed

Invalid button : Non-mounted

IOP XX Status of program IOP

Valid button : Normal Blinking button: Failed

Invalid button : Non-mounted

PCB Status Status of the CHA package

- Normal
- Warning (abnormal)
- Blocked (blocked for maintenance)
- Failed (blocked due to a failure)

Logical Path Status... Status of PCB Logical Path

- Normal
- Warning (abnormal)
- Blocked (blocked for maintenance)
- Failed (blocked due to a failure)

Mode Mode of the CHA package

- Standard
- Switching to Standard
- Switching to High Speed
- High Speed
- Switching to High Speed (2 Port)
- High Speed (2 Port)

(5) Status of the DKA

Select (CL) one of [DKA-nx] in the 'Cluster-1/2' window. The 'DKA' window will appear.

Close (X) Replace DKP80-1B DKP81-1B DKP82-1B DKP83-1B Replace(Inline) Re⊵tore DRR80-1B DRR81-1B DRR82-1B DRR83-1B <u>B</u>lockade FCA-1B0 FCA-1B1 FCA-1B2 FCA-1B3 Logical Path Stat Normal Normal

DKPX-XX..... Status of programs DMP and DSP in the DKA

Valid button : Normal

Blinking button: Failure or under maintenance

DKA-1B

FCA-XXX..... Status of the FCA (No. $0 \sim 3$)

PCB Status Status of the DKA package

Normal

• Warning (abnormal)

• Blocked (blocked for maintenance)

• Failed (blocked due to a failure)

DRR-XX Status of DRR

Valid button : Normal Blinking button : Failure

Logical Path Status... Status of PCB Logical Path

- Normal
- Warning (abnormal)
- Blocked (blocked for maintenance)
- Failed (blocked due to a failure)

| REV.0 | Oct.2001 | | | | |
|-------|----------|--|--|--|--|
|-------|----------|--|--|--|--|

3.6 DKU (Disk)

(1) Status of the DKU (Disk)

Select (CL) [DKU-R1], [DKU-R2], [DKU-R3], [DKU-L1], [DKU-L2] or [DKU-L3] (Disk) in the main screen. The 'DKU' ('Disk') window will appear.

The DKU (Disk) part location number is displayed in the title.

HDU-XXn.....Status of the HDUs constituting the

HDU-n selected DKU (Disk)

(Details are displayed on the lower layered

screen.)

Valid button : Normal

Blinking button: Failure or under

maintenance or copy work

in progress

Invalid button : Non-mounted

DKUMN-XXF ... Status of DKU monitor


DKUMN-XXR Valid button: Normal DKUMN-n Blinking button: Failure

AC BOX-XXn....Only AC BOX names are displayed.


AC BOX-n

XX represents XX in DKU-XX: for example, R1 for DKU-R1 and L2 for DKU-L2.

(Multi Cabinet Model)



(Single Cabinet Model)



(2) Status of the HDU (Multi Cabinet Model)

Select (CL) one of [HDU-XXn] ([HDU-n]) in the 'DKU' ('Disk')window. The 'HDU' window will appear.

XXn.....Status of the HDDs constituting the HDU

nn (Details are displayed on the lower layer screen.)

Valid button : Normal

Blinking button : PDEV error, failure, or under

maintenance

(Single Cabinet Model) Blocked

port Copy work in progress

Invalid button : Non-mounted

"---- "button : No information due to

SVP-DKC error

MPS0..... Status of the HDU power supplies

MPS1 Valid button: Normal

Blinking button: Failure

"---- "button : No information

due to SVP-SSVP error

FAN-XX0..... Status of the fans in the HDU

FAN-n Valid button : Normal

Blinking button : Failure

"---- "button : No information

due to SVP-SSVP error

• Multi Cabinet Model Only Fibre switch names are

FSWXXn-Rn displayed.

FSWXXn-Ln "----"button : No

•Single Cabinet Model information due FSWn-Rn to SVP-SSVP error

FSWn-Ln

JMPXXn-Rn Status of the HDU JMP

JMPXXn-Ln Valid button : Normal JMPn-Rn Blinking button : Failure

JMPn-Ln "----"button : No information due to SVP-DKC error


12V Status Status of the 12 voltage

5V Status Status of the 5 voltage


• Normal

• Warning (abnormal)

YYY represents YYY in HDU-YYY: when HDU-R12 is selected, for example, YYY is R12.



(Multi Cabinet Model [DKU405])



(Single Cabinet Model)

| HDU-0 | | | | | | | | | | | | É | | | | | | | | |
|---------|------|------|-------|----|----|------|------|----|------------|--------------|-------------|-------------|----|----|------|----|---------|-----|------|----|
| - NDO-0 | | 1F 1 | ID 18 | 19 | 17 | 15 | 13 | 11 | | | | | 0F | 0Đ | 08 | 09 | 07 | 05 | 03 0 | л |
| MPS0 | MPS1 | Ji | HP0-I | .2 | | JidF | 20-L | 1 | FSW 042 | FSW 0-FI2 | FSW 0-L1 | FSW 0-R1 | Ĺ | MP |)-R: | 2 | J | MP |)-R1 | |
| | | 1E 1 | IC 1A | 19 | 16 | 14 | 12 | 10 | | | | | Œ | 00 | 04 | 08 | 06 | 04 | 02 0 | 00 |
| | | | _ | | | | | | P1 | P0 | P1 | P0 | | | | | | | | |
| Norm | | | | | | | | | | | | | | | | | <u></u> | Clo | se 🔀 | |

(3) Status of the HDD


Select (CL) one of [YYY0] to [YYYB] in the 'HDU' window. The 'HDD' window will appear.

The HDD part location number is displayed in the title.

Device Type Model name of the HDD

GroupNumber of the parity group to which the HDD belongs

LDEV Detail The involved logical devices are listed.



Device Status..... The status of the HDD and the work name are displayed.

- Normal
- Correction Copy (xx%)
- Copy Back (xx%)
- Drive Copy (xx%)
- Dynamic Sparing (xx%)
- Blocked (blocked for maintenance)
- Failed (blocked due to failure)
- Warning (Either Port is blocked.)
- Failed (Both Ports are blocked.)
- Free (available spare disk.)
- Reserved (unavailable spare disk. The spare disk is reserved.) During a copy operation, copy destination/copy source is displayed.
- to HDD-xx : Data are copied from this drive to HDD-xx.
- from HDD-xx: Data are copied from HDD-xx to this drive.

Port StatusPort status

- Normal
- Warning (Port 0 failed): port 0 is blocked.
- Warning (Port 1 failed): port 1 is blocked.
- Failed: Both ports are blocked.

| REV.1 | Oct.2001 | Aug.2002 | | | | |
|-------|----------|----------|--|--|--|--|
|-------|----------|----------|--|--|--|--|

3.7 Copy status

(1) Select (CL) [Copy Status] in the main screen. The 'Copy Status' window will appear.

Copy TaskThe operations of the drive copy currently running are listed.

Correction Copy to HDD-XXXX

Dynamic Sparing HDD-XXXX->HDD-XXXX

Copy Back

HDD-XXXX->HDD-XXXX

Drive Copy HDD-XXXX->HDD-XXXX

GroupThe number of the parity group to which the target drive belongs.

StartDate and time when the job started

Progress......Degree of job progress (indicated in percentage)

LDEV DetailSelect (CL) one job item from the list.

And select (CL) the Button. The following information on the selected LDEV ID will be displayed.

CU.....CU ID


LDEV ID.....Logical Device ID

Online DKU FC ...During Online micro exchange processing or discontinuation processing, the Button is Displayed.

On the selected (CL) the Button, OEM micro exchange progress screen will be displayed.


Renewal......Updating the STATUS. And the Status display.

(Multi Cabinet Model)



(Single Cabinet Model)






3.8 Logical device

(1) Select (CL) [Logical Device] in the main screen. The 'Logical Device Status' window will appear.

GrpGrp ID
CU:LDEVList of the mounted logical devices

RAIDRAID Level

Status Status of the logical device



Select (CL) a logical device from the list. And select (CL) [Detail] in the 'logical device status' screen. The following information on the selected logical device will be displayed:

Parity Group Parity group to which the Logical Device belongs


PDEV The number of the HDD including the Logical Device

PIN If an LDEV has PIN, SVP will indicate the PIN status as '*'.


'*': PIN occurred.

' ': Normal (PIN did not occur).

(Multi Cabinet Model)




(Single Cabinet Model)



3.9 Micro-program version

Select (CL) [Version] from the main screen. The message indicating that the version data of the currently running micro-program is being read is displayed, followed by the message indicating that the version data of the disk drive is read. Finally, the message indicating that the version data of the micro-program in the processor is being read is displayed. Then, the 'Version Information' dialog box is displayed.

* Do not change the application's window until SVP-DKC communication finishes.



DISK SUBSYSTEM area: Displays the version of the currently running micro-program.

- Representative version
- Version of each processor

SVP area: Displays the version of the micro-program saved in the SVP.

- Latest version in the SVP
- Old version in the SVP

DKU area

• Drive version

In the version display areas, a hyphen "-" indicates that micro-program is not installed. In the version display areas, a question mark "?" indicates that version data could not be obtained, and the letter "x" indicates that the obtained data is invalid.


If the version of the PCB which has already been installed is indicated as "x", exchange the microcode corresponding to "x" by micro FC (refer to MICRO-FC SECTION 4.4 Hard Disk Download (MICRO-FC04-160)).

To obtain new version data, select (CL) [RENEW]. The contents of the display will be updated accordingly.

To quit the version display, select (CL) [OK]. This will take you back to the main screen.

REV.4

[1] DISK SUBSYSTEM area



(1) Representative version and version for each processor


The Currently running Micro-program Version area displays the representative version of micro-program currently running.

The Stored Micro-program Version per Processor area displays the version of the currently running micro-program for each processor.

(This parameter specifies the kind of DKCMAIN micro program version.) If you select "Running", currently running DKCMAIN micro program version in SM is displayed. If you select "FM", DKCMAIN micro program version in FM is displayed.

A micro-program is divided into eight items: MAIN, LCP, HTP, LCDG, FCDG, PCDG, BOOT (RAM), BOOT (ROM). The version of MAIN is displayed in the form of VV-RR-NN-PP/nn. The other versions are displayed in the form of VV-RR-NN.

The representative version may be displayed in reverse video. This display indicates that there is a processor version that does not match the representative version. The processor displayed in reverse video in the Stored Micro-program Version per Processor area is the one that caused a mismatch. An asterisk "*" in front of a version number indicates the mismatching item in the mismatching processor.



(2) Patch status display

Select (DC) one line from the list in the Stored Micro-program Version per Processor area on the 'Version Information' dialog box

A 'Patch Map' dialog box will be displayed, showing the patch status for the target processor.

MP No Processor ID

All Map List of all maps. All maps in the FM and

SVP are displayed. When a match is not

found between a map in the FM and the corresponding map in the SVP, an asterisk "*" is displayed between them.

Difference Map.... Only the maps which do not provide a match between the FM and SVP in All Map.

The example on the right is processor CHP0-1E and shows the contents for patch ID numbers 00 and 02 are contained in the flash memory (FM) but not in the SVP.

To quit the patch status map display, select (CL) [OK].

(3) Drive version

The DKU area on the 'Version Information' dialog box lists drive versions as ROM Version-RAM Version. If types of drives are OEM drives, it lists version as RAM Version (xx-xx) only.


Type: Types of drives currently running (DKxxx). Current: Version of micro-program currently running.

SVP : New version of micro-program stored in SVP hard

disk. (00-00-RAM Version)

Backup: Old version of micro-program stored in SVP hard

disk. (00-00-RAM Version)



(4) Drive name display


Select (DC) one line from the list in the DKU area on the 'Version Information' dialog box. The 'DKU List' dialog box will be displayed, in which the drive identified by the version are listed.

Drive Type Types of drives identified by the selected version.

Version.....Selected version


DKU ID.....List of IDs of the drives identified by the selected version.

To quit 'Drive List', select (CL) [OK].



(Single Cabinet Model)


[DKU List 2]



Copyright ©2001,2002, Hitachi, Ltd.

| REV.1 Oct.2001 | Jun.2002 | | | | |
|----------------|----------|--|--|--|--|
|----------------|----------|--|--|--|--|

[2] SVP area



This area displays the versions of two generations (previous and most recent) of microprograms saved on the SVP hard disk. Each micro-program is divided into eleven items: MAIN, LCP, HTP, LCDG, FCDG, PCDG, CONFIG, BOOT (RAM), SVP, S-SVP, and CUDG4. The version of MAIN is displayed in the form of VV-RR-NN-PP/nn while that of SVP, CONFIG is displayed in the form of VV-RR-NN/nn. The other versions are displayed in the form of VV-RR-NN.

Program VersionThe latest version is displayed. Backup Program VersionThe old version is displayed.


3.10 LCP/HTP Path

Select (CL) [Main Frame Path] from the main screen. The message shown on the right is displayed while the SVP is reading path information from the DKC.

Wait...

Upon completion of reading the path information, the Main Frame Path screen is displayed for selecting the physical or logical path.


* Do not change window until SVP-DKC communication finishes.



(1) Physical Path

Select (CL) [Physical Path] in the screen. The 'Physical Path Status' window will appear.

LCPxx/RCPxx/HTPxx.. LCP/RCP/HTP mountposition



LINK ADDR

Self......LCP/RCP link address

Destination......Connection destination (host) link address

NODE ID (HOST)

STATUS Node ID obtainment status

TYPE/MODEL Connection destination type/model name

SEQNUMBER Connection destination production number

TAG Connection destination tag

World Wide Name (HOST)

N_Port_Name Connection destination N_Port name Node_Name Connection destination NODE name Speed Link bandwidth

To exit the display, press [Close].

Close

(2) Logical Path

Select (CL) [Logical Path] in the screen.

The 'Logical Path Status' window will appear.

PT# Path number

NODE.....LCPxx : LCP with the logical path.

RCPxx: RCP with the logical path. HTPxx: HTP with the logical path.

NU : Unused logical path

LINK.....Link address of the connected host

"NA" is displayed when the RCP is specified.

SW#, Area ID, Port ID are displayed when the HTP is specified.

PT# NODE LINK
178 NU
179 NU
17A NU
17B NU
17C NU
17C NU
17F NU
17F NU
180 LCP2J 01

LGCL.....Logical address of the connected host.

Since data can be displayed only in 16 rows within a screen, use the scroll bar to display data hidden from the screen.

To exit the display, press (CL) [Close].

CU#Control unit address:

Y: Connected

N: Not connected

[CU#:00-0F]....To CU#00-0F the display, press (CL) [CU#00-0F].


[CU#:10-1F]....To CU#10-1F the display, press (CL) [CU#10-1F].

3.11 Pin

(1) Select (CL) [Pin] in the main screen. The 'Pinned Track' windows will appear.

exists

CU ----- CU ID Ldev ----- Logical device number in which PIN



Select (CL) an Ldev from the list. And select (CL) [Detail] on the 'Pinned Track' screen. The following information concerning the selected Ldev will be displayed.

CCHH-----Number of cylinder and head in which PINs exist.

Slot -----Kind of Track in which PIN exists.

DATA: DATA Track
PRTY: Parity Track

Reason ---- Cause of Pin.

ELC/LRC error : See TRBL04-20. WRITE error : See TRBL04-30.


PDEV#----HDD number of Logical device

with PIN.


Stripe ----- The first and the last CCHH of parity stripes. The first and the last LBA of parity stripes.

Select (CL) [Next] to display the next PIN detailed information.

Select (CL) [Before] to display the previous PIN detailed information.



(Single Cabinet Model)



3.12 LUN Management

(1) Outline




Figure 1.1 Main Window

The Main window consists of the following elements.

Table 1.1 Outline of Main Window Elements

| # | Item | Description | | |
|-----|------------|--|--|--|
| ① | Menu | Menu of items operable by this function. | | |
| 2 | Tool bar | Part of the menu enabled to be operable by buttons. | | |
| 3 | Switch | When "Switch" displayed in the tree view is selected (Port), the status of the switch is selectable. The setting of the groups or LUN is selectable. | | |
| 4 | Tree | The structure that it is conscious of the hardware construction. (A port type is attached to a port.) | | |
| (5) | Upper list | Displays the details of an item selected from the tree. | | |
| 6 | Lower list | Displays the details of an item selected from the upper list, if any. | | |
| 7 | Status bar | Displays outlined function of each item on the menu and tool bar when the mouse is positioned on it. Also it displays the all of the LU figures and the LU figures with the pass definition. | | |

Menu items and their details are shown below.

Table 1.2 List of Menu Items

| Menu | Submenu | Description | Tool bar | |
|---------------|-------------------|--|--------------|--|
| File | Exit | Closes the window. | (Exit) | |
| Edit Copy | | Not selectable. | None | |
| | Paste | Not selectable. | None | |
| View | Toolbar | Makes the tool bar displayed or not. | None | |
| | Status Bar | Makes the status bar displayed or not. | None | |
| Group | New | Not selectable. | (New) | |
| | Change | Not selectable. | (Change) | |
| | Delete | Not selectable. | (Delete) | |
| WWN/ iSCSI | Add | Not selectable. | (Add) | |
| Name | Change | Not selectable. | (Change) | |
| | Delete | Not selectable. | (Delete) | |
| | Login List | The hosts identified by the following WWNs/iSCSI Names login to the DKC. | List" | |
| LUN | Add | Not selectable. | (Add) | |
| | Delete | Not selectable. | (Delete) | |
| | Command Device | Not selectable. | (Cmd) | |
| CHA | Change | Not selectable. | (CHA) | |
| Port | Parameter | Not selectable. | (Port) | |
| | Security Switch | Not selectable | رگا (Switch) | |
| Device | Command Device | Not selectable. | (Cmd) | |
| | Property | Refers to LUN information from LDEV. | None | |
| LUSE | LU Size Expansion | Activates the LU Size Expansion window. | te (LUSE) | |

(2) CHA Window




Figure 2.1 CHA Window

When "CHA" in the tree view is selected (CL), installed CHA PCB's supported by this function are displayed in the upper right list.

Table 2.1 Details of CHA Window

| Item | Description | | |
|------------|---|--|--|
| Upper list | Displays installed CHA PCB's supported by this function. Displayed items: PCB name, Host Interface Type, Operate mode (Standard mode: Standard / High Speed mode: High Speed / 2 Port High Speed mode: High Speed (2 Port)) In the case of the NAS or iSCSI, the PCB operation mode is displayed as "". | | |
| | Provided with a sorting function. | | |
| Lower list | Displays nothing. | | |

(3) Port Window




Figure 3.1 Port Window

When "CHA locations" in the tree view is selected (CL), installed ports information supported by this function are displayed in the upper right list.

Table 3.1 Details of Port Window

| Item | Description | | |
|------------|---|--|--|
| Upper list | Displays installed ports supported by this function. Displayed items: Port name, type (Initiator, RCU target, or none), AL-PA, Security Switch, fabric, connection type, and channel speed In the case of the NAS, only the Port name is displayed. In the case of the iSCSI, the Port name, type, information on the Security Switch, IP Address, Subnet Mask, Gateway, iSCSI Name, iSCSI Alias, Port Number, Keep Alive Timer, MAC Address, iSNS, iSNS Port Number and iSNS IP Address are displayed. Provided with a sorting function. | | |
| Lower list | Displays no item. | | |

(4) Group Window




Figure 4.1 Group Window

When "Port" in the tree view is selected, "Group" is set on the Display. Displays the group setting in the port that has been selected in the upper right list. In the lower right list, details of a group that has been selected from the upper right list are displayed.

Table 4.1 Details of Group Window

| Item Description | |
|------------------|--|
| Upper list | Displays groups connected with the port that has been selected from the tree. Displayed items: Group number, group name, and host mode(setting) |
| | Provided with a sorting function. |
| Lower list | Displays details of a group that has been selected from the upper list. Displayed items: WWN (16 hexadecimal digits) and nickname (up to eight characters) Besides, in the case of the iSCSI, an iSCSI Name and a nickname are displayed. (Displays nothing when no item to be selected exists in the upper list or more than one item has been selected.) Provided with a sorting function. |

(5) LUN Window





Figure 5.1 LUN Window

When "Port" in the tree view is selected, "LUN" is set on the Display. Displays the group setting in the port that has been selected in the upper right list. In the lower right list, details of a group that has been selected from the upper right list are displayed

Table 5.1 Details of LUN Window

| Item | Description |
|------------|---|
| Upper list | Displays groups connected with the port that has been selected from the tree. |
| | Displayed items: Group number, group name, and host mode(setting) |
| | Provided with a sorting function. |
| Lower list | Displays LUN's defined as being contained in the group that has been selected from the upper list. |
| | Displayed items: LUN (two hexadecimal digits), CU: LDEV number, emulation type (number of connectable in decimal), CVS (Defined: "*", Not defined: No indication), size (in Mbytes), Cmd.Dev., Cmd.Sec., and the attribute of LDEV guard. |
| | The symbol '+' added to CU:LDEV# denotes the existence of path setting as follow: '+' A LUN is set. |
| | '++'Multiple LUNs are set. |
| | (Displays nothing when no item to be selected exists in the upper list or more |
| | than one item has been selected.) |
| | Provided with a sorting function. |



(6) Logical Device Window

Figure 6.1 Logical Device Window

When "Logical Device" in the tree view is selected (CL), CU numbers of installed LDEV's supported by this function are displayed in the upper right list. In the lower right list, details of a CU selected from the upper right list are displayed.

 Item
 Description

 Upper list
 Displays CU numbers of installed LDEV's supported by this function.

 Displayed items: CU number (two hexadecimal digits)

 Provided with a sorting function.

 Lower list
 Displays details of a CU selected from the upper list.

 Displayed items: LDEV number (two hexadecimal digits), emulation type

Table 6.1 Details of Logical Device Window

| (number of connectable in decimal), CVS (Defined: "*", Not defined: No |
|--|
| indication), size (in Mbytes), Cmd.Dev., Cmd.Sec., definition of LUN |
| (Defined: "*", Not defined: No indication), and the attribute of LDEV guard. |
| (Displays nothing when no item to be selected exists in the upper list or more |
| than one item has been selected. |
| Provide with a sorting function. |
| |
| |




Figure 7.2 Login Host List Window

Select (DR) [Login List] form the [WWN/iSCSI Name] menu in the Main Window (Figure 7.1), Login Host List Window (Figure 7.2) is displayed.


When you select the 'WWN' or the 'iSCSI Name', the login WWNs or iSCSI Names are displayed respectively.

| o | | | |
|----------------|---------------------------------|--|--|
| Item | Description | | |
| Switch | WWN or iSCSI Name. | | |
| List | Displays a WWN/iSCSI Name list. | | |
| Delete button | Not selectable. | | |
| Refresh button | Not selectable. | | |
| Close button | Returns you the Main window. | | |

Table 7.1 Details Login WWN List window

3.13 OS Install Status

When the [OS Install Status] is selected (CL) in the main window, the "OS Install Status" window is displayed.



Location ----- Location name of the CHA

PCB Kind ----- Name of a PCB kind

OS Status ----- Installation status of the CHN OS

| Indication | Status | Icon color |
|-------------|----------------------------|------------|
| Installed | The OS has been installed. | Blue |
| Installing | The OS is being installed. | Yellow |
| Not Install | The OS is not installed. | Red |
| | Other than CHN PCB | Gray |

Close ----- To be used to close the window.

3.14 Error or Failure Status Action

When an error status of, Warning, Failure, or other is displayed on the screen and any action is required, locate the part in error and follow the instructions according to the action code (ACC). The ACC can be obtained by executing the SSB log or the SIM log displayed function of the SVP.

Copyright ©2002, Hitachi, Ltd.

| REV.0 | Dec.2002 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|


4 Option Install

4.1 Option install by one


(1) <Mode Change>
Change the mode from [View Mode] to [Modify Mode].

(2) Select Install Select (CL) [Install].


(3) Select Change Configuration
Select (CL) the [Change Configuration] menu in the 'Install' window.




(4) Select System Option
Select (CL) the [System Option] menu in the
'Menu Dialog' window and select (CL) [OK].



(5) Select Option
Select (CL) the [Option...] menu in the 'System Option' window.




(6) Change Option
Option Install
Select (CL) option item you want to install
from 'Option List' and select (CL) [Install...]
button. Go to (7).




Option De-install Select (CL) option item you want to de-install from the 'Option List' and select (CL) [De-install...] button. Go to (9).


Note: Change the option according to the device configuration worksheet (License Key sheet).




(7) Input Key Code Input the key code and select (CL) [OK].

Note: When the [Detail...] button is pressed, details of key code are displayed.






(8) Confirm option
Confirm option detail and select (CL) [Install].




- (9) Changing finish
 - Option Install
 Confirm that Status is changed to [Install].
 - Option De-install
 Confirm that Status is changed to [Not install].

Select (CL) [Close]




(10) Close System Option Select (CL) [OK].



(11) "Loading configuration..." is displayed.


(12) "Change configuration was completed." is displayed. Select (CL) [OK].



(13) "Reading subsystem configuration data..." is displayed.

"Please insert the Config FD in the FDD." is displayed.

Insert the configuration FD into FDD, and select (CL) [OK].




(14) When this procedure is completed, the message "Please remove

the Config FD." is displayed.

Remove the FD, and select (CL) [OK].



(15) In the 'Install' window, select (CL) [File]-[Exit].




(16) Change the Mode from [Modify Mode] to [View Mode].

4.2 Option install with together


(1) <Mode Change>
Change the mode from [View Mode] to [Modify Mode].

(2) Select Install Select (CL) [Install] in the 'SVP' window.


(3) Select Change Configuration Select (CL) the [Change Configuration] menu in the 'Install' window.




(4) Select System Option
Select (CL) the [System Option] menu in the
'Menu Dialog' window and select (CL) [OK].



(5) Select Option
Select (CL) the [Option...] menu in the 'System Option' window.




(6) Select Key File
Select (CL) the [Key File] button in the
'Option Product' dialog box.



(7) Select a License Key File Select the License key file, and select (CL) [Open].

Note: Select a License Key File according to the device configuration worksheet (License Key sheet).




(8) Select Option


Check the option you want to install, and select (CL) the [Install] button.

Note: P.P. information displays key information has already been installed.


Program Product Name, License Type, and License show information on license key files.



(9) Changing finishConfirm that Status is changed to [Install].Select (CL) [Close].




(10) Close System Option Select (CL) [OK].



(11) "Loading configuration..." is displayed.


(12) "Change configuration was completed." is displayed. Select (CL) [OK].



(13) "Reading subsystem configuration data..." is displayed.

"Please insert the Config FD in the FDD." is displayed.

Insert the configuration FD into FDD, and select (CL) [OK].



(14) When this procedure is completed, the message "Please remove

the Config FD." is displayed.

Remove the FD, and select (CL) [OK].



(15) In the 'Install' window, select [File] and then [Exit].

(16) Change the Mode from [Modify Mode] to [View Mode].

REV.3

4.3 Details for Screen

[1] The Option Product Panel




Figure 4.3.1 Option Product Panel

The Option Product panel has the following features:

- The **Option List** displays the available DKCMAIN options.
- The **Status** list shows the current status of each option (**Install** or **Not Install**).
- The **Key Kind** list displays the license type (**Temporary**, **Permanent**, **Emergency** or **Enterprise**) and the maximum licensed capacity of the PDEVs (physical devices). If **[Frame Unlimited**] is displayed, this indicates that the licensed capacity for that option is unlimited.
- The **Install...** button allows you to install the selected option.
- The **De-install...** button deinstalls the selected option.
- The **Key File...** button opens the Select a License Key File panel, which allows you to select one or more license key file(s) for the connected 9900 subsystem.
- The **Available...** button opens the Available Program Product Install panel (see Figure 4.3.5).
- The **Usable...** button opens the Option Product Capacity panel (see Figure 4.3.4), which displays the total capacity already used and the capacity licensed by specific options such as TrueCopy, ShadowImage, and Extended Remote Copy options.
- The **Close** button closes the Option Product panel.

REV.1

- Status Bar displays the following items.
 - Drive Capacity: The lowest license capacity needed it the disksubsystem is displayed.
 - Licensed Capacity: The license capacity of the DKC option installed in the disksubsystem is displayed. • Term of validity:
- The date when the License key (Temporary key, Emergency key) lapses is displayed.

- Note1: If you forcibly install an emergency key to an option that has already the permanent key, the license of that option will expire in 10 days. DKC holds the licensed capacity of the previously installed permanent key. After the Emergency key is installed, license capacity (Already Capacity) of the Permanent key is displayed in the Status Bar.
- Note2: Note on installation of the license key whose installed capacity is larger than the licensed capacity.
 - DKC accepts the license key input.
 - Through Status is [Not install], the license capacity is held.
 - Install the license key for [Existing Capacity (Base Capacity) + added capacity].
 - Optional functions (Usable Capacity) are excluded.
- Note3: When the license capacity is insufficient compared to the PDEV capacity after PDEV increase, the status becomes as follows.
 - Capacity Insufficient : The License capacity is insufficient.
 - Expired : License lapsed.

The License capacity is held.

The valid term of the license is 10 days from the Drive increase.

When the PDEV increase operation is interrupted after PDEV is compulsorily installed (SVPMSG ID: 3462), the state of License is changed.

Please change to the state of Install by Available Program Product Install Panel (Refer to SVP04-140).

Copyright ©2002,2003, Hitachi, Ltd.

| REV.2 Feb.2002 Dec.2002 | Oct.2003 | | | |
|-------------------------|----------|--|--|--|
|-------------------------|----------|--|--|--|

[2] The License Key File Panel




Figure 4.3.2 DKCMAIN License Key Panel




Figure 4.3.3 Examples of DKCMAIN License Key Installations

The License Key File panel has the following features:

- (1) On the License Key File panel, check the box(es) for the desired option(s).
- (2) Select **Install** to continue installation, or select **Cancel** to exit the License Key File panel.

| REV.0 Feb.2002 | | | | |
|----------------|--|--|--|--|
|----------------|--|--|--|--|

- (3) If an installation fails, the failed option(s) will be displayed in red. Select a failed option if you want to review the contents of the error message. Once you have reviewed the contents of the error message, select **Close** to exit the License Key File panel, and then retry the installation.
- (4) If the installation is complete successfully, the License Key File panel closes and you are returned to the Option Product panel. The displayed status of the selected options changes from **Not install**.
- Note1: You can install an emergency key to an option that has already been installed with the permanent key, by selecting the **Forcibly Install Emergency Keys** check box. However, the license of the forcibly installed option will expire in 10 days. DKC holds the licensed capacity of the previously installed permanent key.
- Note2: Note on installation of the license key whose installed capacity is larger than the licensed capacity.
 - DKC accepts the license key input.
 - Through Status is [Not install], the licensed capacity is held.
 - Install the license key for [Existing Capacity (Base Capacity) + added capacity].
 - Optional functions (Usable Capacity) are excluded.

| | Copyright | ©2002,2003, | Hitachi. | Ltd. |
|--|-----------|-------------|----------|------|
|--|-----------|-------------|----------|------|

| REV.1 | Feb.2002 | Oct.2003 | | | | |
|-------|----------|----------|--|--|--|--|
|-------|----------|----------|--|--|--|--|

[3] The Option Product Usable Capacity Panel

The Option Product Capacity panel (see Figure 4.3.4) displays the capacity already used and capacity licensed by each of the available options. To access the Option Product Capacity panel, select the **Usable...** button on the Option Product panel (see Figure 4.3.1).




Figure 4.3.4 Option Product Capacity Panel

The Option Product Capacity panel has the following features:

- The **Option List** displays the available DKCMAIN options*¹.
- The **Already Used** displays the total disk capacity that each option has already used.
- The **Licensed** displays the total disk capacity that the user is licensed to use.
- The Close button exits the Option Product Usable Capacity panel

Note: If the capacity already used has reached 80% of the capacity licensed, the option is highlighted in yellow. It is recommended that you add your licensed capacity for the options that are highlighted in yellow on the Option Product Capacity panel.

[4] Available Program Product Install Panel

To access the Available Program Product panel, select the **Available...** button on the Option Product panel (see Figure 4.3.1).

This panel is a function to install Program Product by which the License capacity becomes more than the PDEV capacity after PDEV De-Install is processed.




Figure 4.3.5 Available Program Product Panel

The Available Program Product panel has the following features:

- The **Available Program Product List** displays the available Program Product. Available Program Product List displays Program Product by which the License capacity becomes more than the PDEV capacity.
- The **Status** list shows the current status of each program product (**Install** or **Not Install** etc.).
- The **License Type** list displays the licensed capacity.
- The **Install** button allows you to install the selected option.

 On the Available Program Product panel, check the box(es) for the desired option(s).


 If an installation fails, the failed option(s) will be displayed in red. Select a failed option if you want to review the contents of the error message.
- The **Close** button closes the Available Program Product Install panel.

| REV.0 | Dec.2002 | | | | |
|-------|----------|--|--|--|--|
|-------|----------|--|--|--|--|


5 Guidance Operation Screen

5.1 Operation Manual of Guidance Function

Similar to Maintenance and Information, Guidance Function runs under the SVP launcher screen.



5.2 Outline Of Countermeasure By Guidance



| REV.0 | Oct.2001 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|

5.3 Object SIM RC for Guidance Function

When the following SIM RC occurred, Guidance function can be execute.

List of object SIM RC for Guidance function (1/2)


| SIM RC | Name of failure | trouble ID | Guidance function |
|--------|--|------------|---|
| BF4XXX | P/S warning error | 01 | Guidance function can be measured to |
| BF2XXX | Voltage alarm | 02 | counter these failure as well as |
| BFA1XX | Environment disagreement error | 03 | Troubleshoot in the maintenance |
| | | | manual. |
| DF6XXX | | | If a specific drive can be identified as a cause of failure, it is isolated and the |
| DF7XXX | Recovery procedure for common Fibre loop error | 04 | location is displayed. If a cause of failure cannot be specified, the troubleshooting |
| DF8XXX | | | in the maintenance manual is referred to. |
| | | | In case of replacement, you can use the |
| DF9XXX | | | Replace function in the Maintenance |
| | | | Window. |
| CF90XX | | | Guidance function can not cope with |
| EF9XXX | Recovery procedure for LDEV | 05 | these failure situation. Refer to the |
| DFAXXX | blocking | | troubleshooting and finish Guidance. |
| DFBXXX | | | |
| XXXXXX | Replace | 06 | In this case, troubleshooting depends on Replace procedure by maintenance |
| | | | screen. |
| 2180XX | RIO PATH closed | 07 | Guidance function can not cope with |
| 2190XX | AL_PA value conflict | 08 | these failure situation. Refer to the |
| 3993XX | Replace failure | 09 | troubleshooting and finish Guidance. |
| 3D93XX | | | _ |
| 399FXX | CHT PCB type inconsistency | 0a | |
| FFE3XX | Shared memory failure | 0b | TSC CALL message will be displayed |
| FFD3XX | | 0с | to finish Guidance. |
| FFDEXX | | 0d | Refer to the troubleshooting and finish |
| | | | Guidance. |

| REV.0 | Oct.2001 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|

List of object SIM RC for Guidance function (2/2)

| SIM RC | Name of failure | trouble ID | Guidance function |
|----------|-----------------------|------------|---------------------------------------|
| D40XXX ~ | HRC/HODM/HORC failure | 0e | Guidance function can not cope with |
| D45XXX, | | | these failure situation. Refer to the |
| D48XXX, | | | troubleshooting in the maintenance |
| D4DXXX ~ | | | manual. |
| D4FXXX, | | | |
| DB0XXX ~ | | | |
| DB5XXX, | | | |
| DBDXXX ~ | | | |
| DBFXXX | | | |
| 47DXXX | HMRCF/HOMRCF failure | Of | Guidance function can not cope with |
| | | | these failure situation. Refer to the |
| | | | troubleshooting in the maintenance |
| | | | manual. |
| 47FXXX | HIHSM failure | 10 | Guidance function can not cope with |
| | | | these failure situation. Refer to the |
| | | | troubleshooting in the maintenance |
| | | | manual. |


5.4 Guidance Change of Screen




| REV.0 Oct.2001 | | | |
|----------------|--|--|--|
|----------------|--|--|--|

5.5 Operation of Guidance

- [1] Start of Guidance
- (1) Select (CL) [Guidance] menu.



(2) SIM selection screen is displayed. (Initial screen of Guidance function)




[2] SIMLOG Detail Screen

(1) When the SIM RC (SIM status is available) is selected

When the Guidance function can be execute, the [Detail & Go] button is displayed. Select (CL) the [Guidance] button.


The SIMLOG detail dialog box is displayed.




(2) When the SIM RC (SIM status is not available) is selected


When the Guidance function is cannot be executed, (when the Guidance status is not available on the screen) the [Detail] button is displayed.

Since the Guidance function is disable, [Guidance] button is not displayed.







(3) When the Guidance function is running Select (DC) SIMLOG in the list box.




Since the Guidance function is running, [Guidance] button is not displayed.



- [3] Start troubleshooting
- (1) Select (CL) the [Guidance] button.



The Guidance frame screen is displayed.




| REV.0 | Oct.2001 | | | | | |
|-------|----------|--|--|--|--|--|
|-------|----------|--|--|--|--|--|


[4] History screen

(1) Start from initial screen. Select (CL) the [HISTORY] menu.





(2) Start from the SIMLOG detail screen. Select (CL) the [Flow Chart] button.




The [Up], [Down] and [Log Delete] buttons are not displayed.


| REV.0 Oct.2001 | | | |
|----------------|--|--|--|
|----------------|--|--|--|

[5] Delete history


(1) Select (CL) the [HISTORY] button.




(2) Select (CL) the [Log Delete] button.



(3) When the confirmation message is displayed, select (CL) the [Yes] button.




(4) All the logs are cleared.




[6] SIM Complete

(1) Select (CL) SIM RC in the list box, Select (CL) the [SIM Complete] menu.





(2) Select (CL) the [Yes] button.




| REV.0 Oct.2 |
|-------------|
|-------------|


- [7] Change of SIM selection screen
- (1) 'ACC' screen displayed when select (DR) [ACC] menu or icon.







(2) 'PRACTICE' screen displayed when select (DR) [Practice] menu or icon.







(3) 'Reference SSB' screen displayed when select (DR) [SSB] menu or icon.






(4) 'CONTENT' screen displayed when select (DR) [Content] menu or icon.






[8] End of Guidance

(1) Select (DR) [Exit] menu at display frame when you want to close screen.




(2) Select (DR) [Exit] menu at initial frame when you want to finish application.



| REV.0 Oct.2001 | | | |
|----------------|--|--|--|
|----------------|--|--|--|


5.6 Detail of Screen

- [1] Initial Frame
- (1) ICON



- **C** : Display content frame
- **A**: Display ACC frame
- **P**: Display practice frame
- **s** : Display reference frame
- **D** : Change display mode of complete SIM to display
- **D**: Change display mode of complete SIM to not display
- **B**: Display before data
- : Display next data
- ← : Scroll ACC data to left
- ⇒ : Scroll ACC data to right

(2) Status Bar



Disp Mode : Frame kind of SIM list display or guidance history display


Total SIM Cnt : SIM count

UnComp SIM Cnt: Un completed SIM count

Comp SIM : Display mode of complete SIM

Svp Mode : SVP mode

- (3) Display Data
- (a) SIM selection screen 1(SIM Contents Information)



C : item number

Date/Time : Time stamp of SIMLOG generated.

SIM RC : SIM RC (SSB22, 23, 13)

Fail : Display location Information by edited SIM RC.


Detail : Display contents of error by edited SIM RC.

Location : Display location Information by edited SIM RC.

(These contents are the same as Information screen.)

| REV.0 Oct.2001 | | | |
|----------------|--|--|--|
|----------------|--|--|--|

(b) SIM selection screen 2(SIM ACC Information)




P : item number

Date Time : Time stamp of generated SIMLOG.

SIM RC : SIM RC (SSB22, 23, 13) Action Code : Action Code in SIMLOG

| REV.0 Oct.2001 | | | | |
|----------------|--|--|--|--|
|----------------|--|--|--|--|

(c) SIM selection screen 3(SIM Practice Information)



P : item number

Date Time : Time stamp of generated SIMLOG.

SIM RC : SIM RC (SSB22, 23, 13)

Alert Level : SIM alert level (Acute, Serious, Moderate, Service)


SIM Status : SIM condition (Initial, Complete, Pending)

Maintenance Type: Kind of Maintenance (Guidance, Replace, Others, Nothing)

Guidance Status : Guidance condition (Available, Not Available, Not Supported, Completed)

| REV.0 Oct.2001 | | | |
|----------------|--|--|--|
|----------------|--|--|--|

(d) SIM selection screen 4 (Reference SSB Information)



P : item number

Date Time : Time stamp of generated SIMLOG.


SIM RC : SIM RC (SSB22, 23, 13)

F/M : Format / Message of SSB related to SIM

Error Code : Error Code of SSB related to SIM
Action Code : Action Code of SSB related to SIM

| REV.0 Oct.200 | | | |
|---------------|--|--|--|
|---------------|--|--|--|

(e) History screen1(Operation History)




Date/Time : Time stamp of executed guidance function.

Frame : Display troubleshoot ID.
Operation : Display result execution.

| REV.0 | Oct.2001 | | | | |
|-------|----------|--|--|--|--|
|-------|----------|--|--|--|--|

(f) History screen2(Guidance Information)




Date/Time : Time stamp of executed guidance function.

Gdnc id : Display troubleshoot ID.

FPC : Display ACC of Replace Part
Result : Display result execution.

| REV.0 Oct.2 |
|-------------|
|-------------|

[2] SIMLOG detail screen



(1) Display part

This part is the same as the Information screen.


(2) Operation part

Guidance : Executes a Guidance function.
Cancel : Returns to the previous screen.

Flow Chart: Displays flow chart for Guidance function.

| REV.0 Oct.2001 | | | |
|----------------|--|--|--|
|----------------|--|--|--|

[3] Guidance frame screen



Guidance ID : Displays trouble ID, flow ID on the current procedure.

Working Message : Displays contents of next procedure (or current procedure).

Yes/No button : Refers to Working Message for you to choose (CL) the [Yes]/[No]

button.

Location button : Displays replace part, location on the help screen linked to the Working

Message.

Help button : Displays additional information on the help screen.

Exit function button : When a Guidance function is finished, select (CL) the [Exit function]

button according to the Working Message.

BACK button : Back to the previous condition ID.

Restart/Force Exit button: Restart: Quits the procedure and restarts with initial procedure.

Force Exit: Forced end of guidance function.

Predictable FRU : Displays predicted FRU when the Guidance is executed.

Resulted status : Displays replaced part or Guidance resulted status.

SIM LOG : Displays object SIM LOG (Select (DC) SIM LOG so that you can

display the SIM detail screen).

: If the content of SIM LOG is abnormal, "SIM LOG is invalid." is displayed. When the Lnk SSB is invalid, Lnk SSB number is not

displayed. (Space)

SSB LOG : Displays SSB LOG linked SIM LOG. When the linked SSB or the

linked SIM is invalid, each number is not displayed. (Space)

Depending on the first SSB LOG, the following messages are displayed.

(The second or later SSB LOGs are not displayed.)

① Related SSB do not exist.: Linked SSB in the SIM LOG is invalid.

② Related SSB can not read. : In case of the related SSB can not read.

(Retry Restart Guidance) (Guidance can be continued. If you obtain the same result when you

make another attempt, it means that the related SSB does not exist.)

③ Related SSB is invalid. : SSB LOG content is abnormal.

| REV.1 Oct.2001 | Apr.2002 | | | | |
|----------------|----------|--|--|--|--|
|----------------|----------|--|--|--|--|

5.7 Message of T.S.C CALL

| MSG NO | ID NO | TRBL NO | Message |
|-----------|--------|------------|--|
| 01 | 0x0101 | 1 | The ACC in the SIM "BF4XXX" has data other than 3VPS, 5/3VPS, SUBPS, MPS. |
| 02 | 0x0102 | 2 | The wrong data exists on Byte13 of the SIM "BF2XYY". |
| 03 | 0x0103 | 2 | The wrong data exists on Byte23 of the SIM "BF2XYY". |
| 04 | 0x0104 | 2 | You can't measure error because of the failed cluster is now active. |
| 05 | 0x0105 | 2 | Measured the failed cluster, but the voltage alarm is still detected. |
| 06 | 0x0106 | 2 | You can't measure error because of the failed cluster is now active. |
| 07 | 0x0107 | 2 | You can't measure error because of the failed HDU is now active. |
| 80 | 0x0108 | 2 | Measured the failed HDU, but the voltage alarm is still detected. Pin5 and pin6 of Pxx-1 are short-circuit. Passed Flow-ID = 3E |
| 09 | 0x0109 | 2 | Measured the failed HDU, but the voltage alarm is still detected. pin7 and pin8 of Pxx-1 are short-circuit. Passed Flow-ID = 5A |
| 0A | 0x010A | 2 | Measured the failed HDD, but the voltage alarm is still detected. |
| 0B | 0x010B | 2 | Measured the failed DKUMN, but the voltage alarm is still detected. |
| 0C | 0x010C | 2 | Checked the PCB short-circuit of the failed cluster, but can't identify the |
| | | | cause of the failure. SIMRC byte13 ≠ 10 Passed Flow-ID = 87 |
| 0D | 0x010D | 2 | Checked the PCB short-circuit of the failed cluster, but can't identify the |
| | | | cause of the failure. SIMRC byte13 =10 Passed Flow-ID = 8E |
| 0E | 0x010E | 3 | Replaced PCB of the failed cluster, but the voltage alarm is still detected. |
| 0F | 0x010F | 3 | Replaced the failed DKCMN, but the environment monitors mismatch error is still detected. |
| 10 | 0x0110 | 3 | Replaced the failed DKCMN, DKC PANEL, but the environment monitors mismatch error is still detected. |
| 11 | 0x0111 | 3 | Can't identify the cause of the environment monitors mismatch error. DKCMN and DKUMN are not blinking. Passed Flow-ID = 41 |
| 12 | 0x0112 | 3 | Can't identify the cause of the environment monitors mismatch error. Replaced DKUMN, but DKUMN is blinking. Passed Flow-ID = 47 |
| 13 | 0x0113 | 3 | Can't identify the cause of the environment monitors mismatch error. Can't execute PSOFF. Passed Flow-ID = 5A |
| 14 | 0x0114 | 3 | Can't identify the cause of the environment monitors mismatch error. DKUMN is not blinking. Passed Flow-ID = 60 |
| 15 | 0x0115 | 3 | Replaced the failed DKUMN, but the environment monitors mismatch error is still detected. |
| 16 | 0x0116 | 3 | Can't identify the cause of the environment monitors mismatch error. Blinking either DKCMN or DKUMN. Passed Flow-ID = 76 |
| 17 | 0x0117 | 3 | Can't identify the cause of the environment monitors mismatch error. Blinking either DKCMN or DKUMN. Passed Flow-ID = 7C |
| 18 | 0x0118 | 3 | Replaced the failed DKC PANEL, but the environment monitors mismatch error is still detected. |
| 19 | 0x0119 | 3 | Can't identify the cause of the environment monitors mismatch error. Blinking DKCMN. Passed Flow-ID = 90 |

| REV.0 Oct.2001 | | | | |
|----------------|--|--|--|--|
|----------------|--|--|--|--|

| MSG NO | ID NO | TRBL NO | Message | | | | |
|-----------|--------|------------|---|--|--|--|--|
| 1A | 0x011A | 3 | Replaced the failed DKCPANEL, DKUMN, but the environment monitors mismatch error is still detected. | | | | |
| 1B | 0x011B | 5 | LDEV Blocking (SIM = CF90XX, DFAXXX, DFBXXX, EF9XXX) can't execut for Guidance. | | | | |
| 1C | 0x011C | 4 | Common Fiber Error (SIM = DF6XXX, DF7XXX, DF8XXX, DF9XXX) can't execute for Guidance. | | | | |
| 1D | 0x011D | 7 | RIO PATH Closed (SIM = 2180XX) can't execute for Guidance. | | | | |
| 1E | 0x011E | 8 | AL_PA value conflict (SIM = 2190XX) can't execute for Guidance. | | | | |
| 1F | 0x011F | 9 | Replace failure (SIM = 3993XX, 3D93XX) can't execute for Guidance. | | | | |
| 20 | 0x0120 | 0a | CHT PCB type inconsistency (SIM = 399FX0) can't execute for Guidance. | | | | |
| 21 | 0x0121 | 0b | Shared Memory (Real memory size inconsistent) failure (SIM = FFE3XX) can't execute for Guidance. | | | | |
| 22 | 0x0122 | 0c | Shared Memory failure (SIM = FFD3XX) can't execute for Guidance. | | | | |
| 23 | 0x0123 | 0d | Shared Memory (Loss of duplicated information) failure (SIM = FFDEXX) can't execute for Guidance. | | | | |
| 24 | 0x0124 | 0e | HRC/HODM/HORC failure can't execute for Guidance. | | | | |
| 25 | 0x0125 | Of | HMRCF/HOMRCF failure (SIM = 47DXXX) can't execute for Guidance. | | | | |
| 26 | 0x0126 | | The Guidance function was force finished for the FORCEEND button, after performed replace etc. | | | | |
| 27 | 0x0127 | 10 | HIHSM failure (SIM = 47FXXX) can't execute for Guidance. | | | | |

| REV.0 Oct.2001 | | | | |
|----------------|--|--|--|--|
|----------------|--|--|--|--|