

IBM System Storage TS3100 Tape Library and TS3200
Tape Library



Setup, Operator, and Service Guide

Machine Type 3573

IBM System Storage TS3100 Tape Library and TS3200
Tape Library



Setup, Operator, and Service Guide

Machine Type 3573

Note!

Before using this information and the product it supports, be sure to read the general information under “Notices” on page I-1 in the *IBM System Storage TS3100 and TS3200 Tape Library Setup, Operator, and Service Guide*.

To ensure that you have the latest publications, visit the web at <http://www.ibm.com/storage/>.

This edition applies to the *IBM System Storage TS3100 Tape Library and TS3200 Tape Library Setup, Operator, and Service Guide*, GA32-0545-07, and to the subsequent releases and modifications until otherwise indicated in new editions.

© Copyright International Business Machines Corporation 2005, 2008.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Read This First

Minimum Firmware Levels for Common Library Features

Table 1. Minimum Firmware Levels for common Library features

Feature	Minimum Firmware Level(s) Required
Dedicated Cleaning Slot removal	Library firmware level must be greater than 1.95.
Encryption	Library firmware level must be 4.0 or greater. Drive firmware level must be 74H4 or greater.
Key Path Diagnostics	Library firmware level must be greater than 6.3.
Path Failover (for one activation key for both Control Path Failover and Data Path Failover)	LTO 4 Tape Drives: No minimum level of firmware is required. LTO 3 Tape Drives: Drive firmware must be greater than 73P5. Library firmware must be greater than 1.95.
Secure Socket Layer (SSL) over Encryption Key Manager (EKM)	Library firmware must be 6.3 or higher

Accessing Online Technical Support

For online Technical Support for your Library, visit:
<http://www.ibm.com/support/>.

Registering for My Notification

My Notification registration provides email notification when firmware levels have been updated and are available for download and installation. To register for My Notification:

1. Visit the web at <http://www.ibm.com/us>.
2. Click **Get support**.
3. Click **My support**.

Note: Library firmware and tape drive firmware are verified and released together. When updating to the latest firmware, verify that all installed components such as tape drive(s), and library are at the latest levels noted on the Support web site. Mixing different levels of library and tape drive firmware is not supported and may cause unpredictable results.

Sending Us Your Comments

Your feedback is important in helping IBM provide accurate and useful information. If you have comments or suggestions for improving this publication, send your comments by:

- E-mailing IBM:
 - Internet or IBMLink™ from US: *starpubs@us.ibm.com*
 - IBMLink from Canada: *STARPUBS at TORIBM*

Include the following information in your e-mail:

- Exact publication title
- Form number (for example, GA32-1234-04) or part number (located on the back cover of the publication)
- Page number to which you are referring
- Using the Readers' Comments form at the back of this publication
- Mailing your comments to:

International Business Machines Corporation
Information Development
Department GZW
9000 South Rita Road
Tucson, AZ 85747-0001 USA

Contacting IBM Technical Support

In the USA: Call 1-800-IBM_SERV (1-800-426-7378).

Note: Before calling, complete all the steps in "Contacting IBM Technical Support" in chapter 9.

All other Countries/Regions: Visit <http://www.ibm.com>.

To open a Service Request online: Under **Support & downloads**, click on **Open a service request**.

Summary of Changes

The following information has been added to the GA32-0545-06 edition:

- SNMP Messaging: Management Information Base (MIB)
- Updated Remove/Replace Tape Drive Sled chapter
- Updated Drive Sense Data
- Updated and Additional Error Codes
- Accessibility Information

The following information has been added to the GA32-0545-07 edition:

- DNS addressing
- Save/Restore to library USB port using OCP
- Save/Restore file to computer using library web UI
- Revised Remove/Replace procedure for library enclosure
- Additional new information includes: - Save Service Dump

Contents

Read This First iii

Minimum Firmware Levels for Common Library	
Features	iii
Accessing Online Technical Support	iii
Registering for My Notification	iii
Sending Us Your Comments	iv
Contacting IBM Technical Support	iv
Summary of Changes	iv

Figures ix

Tables xiii

Safety and Environmental Notices . . . xv

Danger Notice	xv
Caution Notice	xv
Laser Safety and Compliance	xvii
Class I Laser Product	xvii
Performing the Safety Inspection Procedure	xvii
Rack Safety.	xviii
Product Recycling and Disposal	xx
Battery Return Program.	xxii
Cautions and Regulatory Compliance Statements for NEBS	xxiii

Preface xxv

Related Publications	xxv
--------------------------------	-----

Chapter 1. Product Description 1-1

Front Panel	1-1
Rear Panel	1-3
Bar Code Reader	1-4
Encryption	1-5
Supported Internet Protocols	1-5
SNMP Messaging	1-6
SNMP Traps	1-6
Maximum Library Storage Capacity and Data Transfer Rate	1-6
Ultrium Tape Drives	1-7
Speed Matching	1-8
Channel Calibration	1-9
Power Management	1-9
Media	1-9
Library Specifications	1-9
Product Environment	1-11
Supported Servers, Operating Systems, and Software	1-11
Supported Device Drivers	1-12

Chapter 2. User Interfaces 2-1

Operator Control Panel	2-1
Operator Control Panel Philosophy	2-1
Power-ON Display.	2-2
Note about the Front Panel LEDs	2-2

Input Modes	2-3
Power ON/OFF	2-4
Web User Interface.	2-4
Login	2-5
System Status	2-6
Web User Interface Help Pages	2-8
Logging out of the Web User Interface	2-8

Chapter 3. Installation Planning. . . . 3-1

Determining the Number of Logical Libraries.	3-1
Basic Guidelines	3-1
Library Sharing	3-1
Using Multiple Logical Libraries for Library Sharing	3-2
Using Multiple Control Paths	3-2
Using Multiple Control Paths for System i, iSeries, and AS/400 Attachment	3-2
Using Multiple Control Paths for Path Failover	3-2
Library Partitioning and Element Addressing.	3-3
Using Persistent Binding to Ensure SCSI ID Assignment	3-6
Logical Unit Number (LUN) Scanning	3-7
Host Interfaces	3-7
SCSI Interface	3-7
SAS Interface	3-9
Fibre Channel Interface	3-10

Chapter 4. Installation and Configuration 4-1

Using the Library Configuration Form	4-1
Installing Your Library	4-1
Choosing a Location	4-1
Unpacking the Library	4-2
Verifying the Shipment	4-3
Installing the Library Foot Pads (for Desktop Installation ONLY).	4-4
Removing and Storing the Shipping Lock	4-5
Rackmounting the Library (for Rack Installation ONLY).	4-6
Connecting the Host Interface Cable	4-12
Connecting a Power Cord	4-14
Configuring Your Library	4-15
Choosing Your Configuration Method	4-15
Using Factory Defaults as Your Configuration	4-16
Configuring Your Library using the Web User Interface.	4-16
Configuring Your Library using the Operator Control Panel	4-33
Preparing the Host	4-34
Verifying the Connection	4-34
Cartridge Magazines.	4-35
Populating the Library with Data Cartridges	4-38
Inserting the Cleaning Cartridge.	4-39
Registering for My Notification	4-40

Chapter 5. Operations 5-1

Operator Control Panel Navigation	5-8
Operator Control Panel Menu Tree	5-10
Monitor Menu	5-11
Control Menu	5-16
Configure Menu	5-18
Service Menu	5-28
Web User Interface Menus	5-30
Monitor Library Menu	5-31
Manage Library Menu	5-39
Configure Library Menu	5-41
Service Library Menu	5-53
Import and Export Media during Normal Library Operation	5-59
Configuring I/O Stations and Reserving Slots	5-60

Chapter 6. Using Ultrium Media 6-1

Data Cartridges	6-1
Cartridge Compatibility	6-2
Capacity Scaling	6-3
WORM (Write Once, Read Many).	6-3
WORM Media	6-3
Data Security on WORM Media	6-3
WORM Media Errors	6-4
Requirements for WORM Capability	6-4
Cleaning Cartridge.	6-4
Cartridge Memory Chip (LTO-CM)	6-4
Bar Code Label	6-5
Guidelines for Using Bar Code Labels	6-6
Write-Protect Switch	6-7
Handling the Cartridges	6-7
Provide Training	6-8
Ensure Proper Packaging	6-8
Provide Proper Acclimation and Environmental Conditions	6-9
Perform a Thorough Inspection	6-9
Handle the Cartridge Carefully	6-10
Examples of Cartridge Problems	6-10
Repositioning or Reattaching a Leader Pin	6-11
Repositioning a Leader Pin	6-11
Reattaching a Leader Pin	6-13
Environmental and Shipping Specifications for Tape Cartridges	6-17
Disposing of Tape Cartridges	6-18
Ordering Media Supplies	6-18
Ordering Bar Code Labels	6-20

Chapter 7. Troubleshooting 7-1

Installation Problems	7-6
Library Recovery Problem Determination	7-8
Procedures for Isolating CRU Problems	7-8
Isolating a Power Supply Problem	7-8
Isolating Drive Sled Problems.	7-10
Isolating a Library Controller Card vs. Accessor Enclosure Problem	7-12
Isolating Web User Interface Problems.	7-12
Isolating Accessor Scanner Problems	7-13
Isolating Host Attachment Interface Problems	7-13
Identifying a Suspect Cartridge	7-14

Chapter 8. Error Codes 8-1

Chapter 9. Service Procedures 9-1

Removing Cartridges from Magazine Slots.	9-1
Releasing the Magazines Manually	9-1
IBM TotalStorage Tape Diagnostic Tool (ITDT)	9-4
Contacting IBM Technical Support	9-5

Chapter 10. Check, Adjust, Remove, and Replace 10-1

Tools Required.	10-1
Electrostatic Discharge	10-1
Relocating Your Library.	10-1
Removing/Installing/Adding a Tape Drive Sled	10-3
Removing a Tape Drive Sled	10-4
Installing a Tape Drive Sled	10-6
Adding a Tape Drive Sled	10-9
Removing the Slot Blocker - 2U Library	10-10
Replacing a Power Supply	10-11
Replacing a Library Controller Card	10-12
Replacing Cartridge Magazines.	10-14
Replacing Magazine Fiducials	10-14
Replacing the Library Enclosure	10-15
Preparing the Defective Library for Replacement	10-15
Unpacking and Preparing the Replacement Library Enclosure	10-16
Installing Your Drive(s) in the Replacement Library Enclosure	10-18
Swapping Library Controller Cards	10-21
Swapping Cartridge Magazines.	10-23
Swapping Power Supplies	10-26
Installing the Replacement Library Enclosure	10-27
Completing the Installation of the Replacement Library Enclosure.	10-28
Returning the Defective Library	10-29

Chapter 11. Optional Features, Replacement Parts and Power Cords . 11-1

Appendix A. Information for Trained Service Personnel A-1

Internal View of Library.	A-1
Manual Cartridge Removal Procedure	A-2
Recommended Tools	A-2
Before You Begin	A-2
Beginning Procedure	A-3
Removing the Drive Brick from the Sled	A-3
Removing the Drive Cover.	A-6
Full-high Drive: Tape Spooled Off Supply Reel	A-7
Half-high Drive: Tape Spooled Off Supply Reel	A-8
Full-high Drive: Tape Pulled from or Broken near Leader Pin	A-9
Half-high Drive: Tape Pulled from or Broken near Leader Pin	A-11
Full-high Drive: Tape Broken in Mid-tape	A-13
Half-high Drive: Tape Broken in Mid-tape	A-14
Full-high Drive: Tape Tangled along Tape Path	A-15
Half-high Drive: Tape Tangled along Tape Path	A-18

Full-high Drive: No Apparent Failure or Damage to Tape	A-19		
Half-high Drive: No Apparent Failure or Damage to Tape	A-22		
Ending Procedure	A-25		
Writing a Drive Dump to Flash Memory	A-25		
Accessing the Library using Telnet	A-26		
Appendix B. SCSI Element Types, SCSI Addresses, and Physical Configurations	B-1		
2U Library I/O Slot, Storage Slots and Drive Slot Element Addresses and Physical Locations	B-1		
4U Library I/O Slots, Storage Slots, and Drive Slots Element Addresses and Physical Locations	B-2		
Library Partitioning and Element Addressing	B-2		
Appendix C. TapeAlert Flags	C-1		
TapeAlert Flags Supported by the Library	C-1		
TapeAlert Flags Supported by the Drive	C-3		
Appendix D. Sense Data	D-1		
Library Sense Data	D-1		
Drive Sense Data	D-6		
Appendix E. Message Retrieval at the Host	E-1		
Retrieving from an IBM System p or IBM Power System with AIX	E-1		
SCSI Sense Data Definition	E-2		
SCSI Sense Data - Library Error	E-2		
SCSI Sense Data - Drive Error	E-3		
Retrieving from a Sun System	E-4		
Retrieving from an HP-UX System	E-5		
Retrieving from an IBM System i or IBM Power System with IBM i OS	E-5		
		Appendix F. SNMP Status MIB Variables and Traps	F-1
		Appendix G. Library Configuration Form	G-1
		Appendix H. Accessibility	H-1
		Notices	I-1
		Trademarks	I-2
		Electronic Emission Notices	I-2
		Federal Communications Commission (FCC) Statement	I-2
		European Union (EU) Electromagnetic Compatibility Directive	I-3
		People's Republic of China Class A Electronic Emission Statement	I-3
		Taiwan Class A compliance statement	I-3
		Taiwan Contact Information	I-4
		Japan VCCI Class A ITE Electronic Emission Statement	I-4
		Industry Canada Compliance Statement	I-4
		Avis de conformité à la réglementation d'Industrie Canada	I-4
		Germany Electromagnetic Compatibility Directive	I-4
		Korean Class A Electronic Emission Statement	I-5
		Australia and New Zealand Class A Statement	I-5
		Glossary	J-1
		Index	X-1

Figures

1-1.	Front panel of a 2U library	1-1	4-21.	Example: The 4U library Configure Library: General screen	4-21
1-2.	Front panel of a 4U library	1-1	4-22.	The 4U library Configure Library: Logical Libraries page	4-22
1-3.	Rear panel of a 2U library with a SCSI drive	1-3	4-23.	The Configure Library: Path Failover Feature Activation screen.	4-22
1-4.	Rear panel of a 4U library with full high Fibre Channel drive and half high SCSI and SAS drives	1-3	4-24.	Feature Key verification screen.	4-23
1-5.	Rear panel of a 2U library with a full high dual port SAS drive.	1-3	4-25.	Feature Activation Key screen	4-24
1-6.	Library drive sled without ESD springs (SCSI sled shown)	1-8	4-26.	Configure Library: Encryption Activation screen	4-24
1-7.	Library drive sled with ESD springs [1] (SAS sled shown)	1-8	4-27.	The Configure Library: Drive screen	4-26
2-1.	Power-ON screens	2-2	4-28.	Configure Library: Network Page	4-27
2-2.	Web User Interface login page	2-6	4-29.	Warning Screen	4-27
2-3.	2U library System Status screen	2-6	4-30.	The Configure Library: User Access screen	4-29
2-4.	4U library System Status screen	2-6	4-31.	The Configure Library: Date and Time screen	4-30
2-5.	4U library System Status screen showing media attention status	2-7	4-32.	The Configure Library: Logs and Traces screen	4-31
2-6.	4U library System Status screen showing a power supply failure	2-7	4-33.	The Configure Library: Event Notification screen	4-31
3-1.	Configuration of a one - partition system	3-4	4-34.	Pound sign (#) shows accessible menus when access PIN is enabled but before it is entered.	4-33
3-2.	Configuration of a two - partition system	3-4	4-35.	2U library left magazine	4-35
3-3.	Configuration of a three - partition system	3-5	4-36.	2U library right magazine	4-36
3-4.	Configuration of a four - partition system	3-5	4-37.	2U library I/O Station in the left magazine	4-36
3-5.	Examples of SCSI element addressing	3-6	4-38.	4U library left magazines.	4-37
4-1.	Removing the plastic protective sheets from the library	4-3	4-39.	4U library right magazines	4-37
4-2.	Installing foot pads on the bottom of the library enclosure	4-4	4-40.	4U library I/O Station in the lower left magazine	4-38
4-3.	Shipping lock and label	4-5	4-41.	Finger Holes on back side of 4U Library I/O Station	4-38
4-4.	Removing the Shipping lock and label	4-6	5-1.	2U Library Control Keys	5-9
4-5.	Library shipping lock and label storage location on rear panel of library.	4-6	5-2.	4U Library Control Keys	5-9
4-6.	Rack Kit mounting hardware.	4-8	5-3.	Operator Control Panel Menu Tree	5-11
4-7.	Examples of EIA units for round hole and square hole installations	4-8	5-4.	Monitor: Library menu	5-12
4-8.	Rear view of a rack showing the narrow part of the rail.	4-9	5-5.	Monitor: Drive menu	5-14
4-9.	Front view of a rack showing the rails installed.	4-9	5-6.	Example of a 4U Monitor: Inventory menu	5-15
4-10.	2U library side screws to remove	4-10	5-7.	Overview of inventoried cartridges: Lower Left Magazine of a 4U Library	5-16
4-11.	2U library rack anchors and mounting brackets	4-10	5-8.	Detailed information on cartridges residing in a magazine	5-16
4-12.	Sliding the 2U library into the rack	4-11	5-9.	Control: I/O Station menu	5-17
4-13.	Sliding the 4U library into the rack	4-11	5-10.	Control: Move Cartridges menu	5-17
4-14.	Securing the 2U library to the rack	4-12	5-11.	Control: Magazine menu	5-18
4-15.	Securing the 4U library to the rack	4-12	5-12.	Control: Re-Inventory menu.	5-18
4-16.	Attaching SCSI ([1]), Fibre Channel ([4]), and SAS ([2]) cables to the 4U library	4-13	5-13.	Configure: Logical Libraries menu	5-19
4-17.	Interposer installation	4-14	5-14.	Configure: Library menu.	5-20
4-18.	Removing the protective label from the power receptacle	4-15	5-15.	Configure: Drive menu	5-23
4-19.	Log in screen on the Web User Interface	4-19	5-16.	Configure: Network menu	5-24
4-20.	The 2U library Configure Library: General screen	4-21	5-17.	Configure: Set Access PIN menu	5-25
			5-18.	Configure: Restore Defaults menu	5-25
			5-19.	Configure: Set Date and Time menu	5-27
			5-20.	Configure: Path Failover	5-28
			5-21.	Service: Library Verify menu	5-28
			5-22.	Service: Run Tests menu	5-29

5-23.	Service: Service menu	5-29	6-8.	Leader pin in the incorrect and correct positions	6-12
5-24.	Service: Display Contrast menu	5-30	6-9.	Placing the dislodged leader pin into the correct position	6-12
5-25.	The 4U library Monitor Library: Library Identity page.	5-32	6-10.	Rewinding the tape into the cartridge	6-13
5-26.	The 4U library Monitor Library: Drive Identity page showing one SAS (#1), one SCSI drive (#2), and one Fibre Channel drive (#3)	5-34	6-11.	Leader Pin Reattachment Kit	6-14
5-27.	The 4U library Monitor Library: Library Status page	5-35	6-12.	Attaching the leader pin attach tool to the cartridge	6-15
5-28.	The 4U library Monitor Library: Drive Status page	5-37	6-13.	Winding the tape out of the cartridge	6-16
5-29.	The 2U library Monitor Library: Inventory page	5-38	6-14.	Removing the C-clip from the leader pin	6-16
5-30.	The 4U library Monitor Library: Inventory page	5-39	6-15.	Attaching the leader pin to the tape	6-17
5-31.	Manage Library: Move Media page	5-40	7-1.	A 250w power supply with LEDs	7-9
5-32.	Manage Library: Perform Inventory page	5-40	7-2.	A 80w power supply without LEDs	7-9
5-33.	Manage Library: Release Magazine page	5-40	9-1.	Access holes for the left magazine	9-2
5-34.	The 4U library Configure Library: General and Extended page.	5-42	9-2.	Access holes for the right magazine	9-3
5-35.	The 4U library Configure Library: Logical Libraries page	5-43	9-3.	Left Magazine pulled out of the 2U Library	9-4
5-36.	The 4U library Configure Library: Path Failover page	5-43	9-4.	Left Magazines pulled out of the 4U Library	9-4
5-37.	Path Failover license verification page	5-43	10-1.	ESD label	10-1
5-38.	Feature Activation Key screen	5-44	10-2.	Shipping Lock and Label Storage Location	10-2
5-39.	Configure Library: Encryption Feature configuration screen	5-45	10-3.	Shipping Lock and Label.	10-2
5-40.	The Configure Library: Drive page for a 4U library.	5-47	10-4.	Library drive sled without ElectroStatic Discharge (ESD) springs (SCSI sled shown)	10-3
5-41.	Configure Library: Network Page	5-48	10-5.	Library drive sled with ESD springs [1] (SAS sled shown)	10-4
5-42.	Warning Screen	5-48	10-6.	Drive sled components (full-high fibre drive in top position, half-high SCSI drive in middle position, half-high SAS drive in bottom position) on back panel of a 4U library	10-5
5-43.	Configure Library: User Access page	5-50	10-7.	Pulling the drive sled out of the library (drive sled without ESD springs shown)	10-6
5-44.	The Configure Library: Date & Time page	5-51	10-8.	Pushing the drive sled into the library (drive sled without ESD springs shown)	10-7
5-45.	Configure Library: Logs & Traces page	5-51	10-9.	Diagrams for applying conductive tape for ESD protection to the back of a drive sled installed in a 2U or 4U library	10-8
5-46.	Configure Library: Event Notification page	5-52	10-10.	2U Magazine with Slot Blocker	10-10
5-47.	Configure Library: Restore Defaults page	5-53	10-11.	Popping the Slot Blocker out of the Cell	10-11
5-48.	Service Library: Clean Drive page	5-54	10-12.	A power supply being removed from a 2U library	10-12
5-49.	Service Library: View Logs page	5-55	10-13.	A Library Controller Card being removed from the library	10-13
5-50.	Service Library: View Drive Logs screen	5-55	10-14.	Magazine fiducial.	10-14
5-51.	Service: Save Drive Dump	5-56	10-15.	Removing the two mounting bracket screws anchoring the library to the rack (one screw on each side of the library)	10-16
5-52.	Service Library: Perform Diagnostics page	5-56	10-16.	Foot pads installed on the bottom of the library enclosure	10-17
5-53.	Service Library: Perform Key Path Diagnostics page	5-57	10-17.	Removing the shipping label and lock from the top of the library and storing on the rear panel	10-18
5-54.	The 2U library Service Library: Upgrade Firmware page	5-58	10-18.	Library shipping lock and label storage location on the rear panel of the library	10-18
5-55.	The 4U library Service Library: Upgrade Firmware page	5-58	10-19.	Removing a drive sled from the library (drive sled without ESD springs shown)	10-19
5-56.	Service Library: Reboot page	5-59	10-20.	Drive sled taping diagrams	10-20
6-1.	The IBM LTO Ultrium 800 GB Data Cartridge	6-1	10-21.	Removing a Library Controller Card from the library	10-22
6-2.	Ultrium WORM Tape Cartridge.	6-3	10-22.	Library front panel LEDs	10-23
6-3.	Sample bar code label on the LTO Ultrium 4 Tape Cartridge	6-6	10-23.	Access hole for the left magazine (facing rear of library)	10-24
6-4.	Setting the write-protect switch	6-7			
6-5.	Tape cartridges in a Turtlecase	6-8			
6-6.	Double-boxing tape cartridges for shipping	6-9			
6-7.	Checking for gaps in the seams of a cartridge	6-10			

10-24.	Access hole for the right magazine (facing rear of library)	10-25	A-10.	Leader Block Assembly (LBA)	A-11
10-25.	Left magazines pulled out of a 4U library (facing front of library)	10-26	A-11.	Drive with cover removed to reveal gear train.	A-12
10-26.	A power supply being removed from a library	10-27	A-12.	Leader Block Assembly (LBA)	A-13
10-27.	Mounting brackets and anchors for securing the library in a rack (one bracket and anchor on each side of the library).	10-28	A-13.	Using hex wrench to rewind tape into cartridge	A-14
10-28.	Front view of a rack showing the rails installed	10-28	A-14.	Rewinding tape into cartridge	A-15
10-29.	Proper placement of the Repair Identification (RID) Tag	10-29	A-15.	Using hex wrench to rewind tape into cartridge	A-16
11-1.	Types of Receptacles	11-7	A-16.	Drive with cover removed to reveal gear train.	A-17
A-1.	Internal view of the library	A-1	A-17.	Leader Block Assembly (LBA)	A-18
A-2.	Drive connection card showing screws and plastic cover	A-4	A-18.	Rewinding tape into cartridge	A-19
A-3.	Half high drive with the connection card moved to the side showing the screws	A-5	A-19.	Using hex wrench to rewind tape into cartridge	A-20
A-4.	The drive brick showing the cables to be unplugged.	A-5	A-20.	Drive with cover removed to reveal gear train.	A-21
A-5.	Removing the bezel and the cover from the 4U internal drive	A-6	A-21.	Leader Block Assembly (LBA)	A-22
A-6.	Removing the bezel and the cover from the half high internal drive	A-7	A-22.	Rewinding tape into cartridge	A-23
A-7.	Using hex wrench to rewind tape into cartridge	A-8	A-23.	Drive with cover removed to reveal gear train.	A-24
A-8.	Rewinding tape into cartridge	A-9	A-24.	Leader Block Assembly (LBA)	A-24
A-9.	Drive with cover removed to reveal gear train.	A-10	B-1.	Configuration of a one - partition system	B-3
			B-2.	Configuration of a two - partition system	B-4
			B-3.	Configuration of a three - partition system	B-4
			B-4.	Configuration of a four - partition system	B-4
			B-5.	Examples of SCSI element addressing	B-5
			E-1.	AIX ERRPT Library Error Log Example	E-3
			E-2.	AIX ERRPT Library Error Log Example	E-4

Tables

1.	Minimum Firmware Levels for common Library features	iii	6-2.	Bar code label requirements for Ultrium tape drives and libraries	6-5
2.	NEBS Compliance Statements	xxiv	6-3.	Cartridges and VOLSERs compatible with the Ultrium 3 and Ultrium 4 Tape Drive	6-5
1-1.	2U library and 4U library front panel descriptions	1-2	6-4.	Location of the write-protect switch	6-7
1-2.	2U library and 4U library rear panel descriptions	1-4	6-5.	Environment for operating, storing, and shipping the LTO Ultrium Tape Cartridge	6-18
1-3.	Tape drive model and host interface type	1-6	6-6.	Media supplies	6-19
1-4.	Library storage capacity and data transfer rate	1-7	6-7.	Authorized suppliers of custom bar code labels	6-21
1-5.	Physical Specifications	1-9	7-1.	Troubleshooting table	7-1
1-6.	Power Specifications	1-10	7-2.	Power Supply LED Meanings	7-9
1-7.	Operation Specifications: Ultrium 4	1-10	8-1.	Main Error Codes	8-2
1-8.	Operation Specifications: Ultrium 3	1-10	8-2.	Sub error codes	8-6
1-9.	Environmental Specifications	1-10	8-3.	Warning Events	8-10
3-1.	Host Drive Interface Support.	3-7	10-1.	Shipping Lock/Shipping Label.	10-2
3-2.	Maximum bus length between terminators	3-8	11-1.	Optional Features	11-1
3-3.	Recommended maximum quantity of drives per SCSI bus	3-8	11-2.	Replacement Parts	11-2
4-1.	Location criteria	4-1	11-3.	Power Cords	11-3
5-1.	Menu navigation shortcuts	5-1	A-1.	Internal view description	A-1
5-2.	Library Control Keys	5-9	B-1.	2U library SCSI Element Types and Element Addresses	B-1
5-3.	Detailed information on cartridges residing in a magazine	5-16	B-2.	4U library SCSI Element Types and Element Addresses	B-1
5-4.	Factory Default Settings	5-26	B-3.	2U library SCSI element addresses for storage slots and drive slot	B-1
5-5.	Web User Interface Menus	5-30	B-4.	4U library SCSI element addresses for storage slots and drive slot	B-2
5-6.	Library Identity page elements	5-32	C-1.	TapeAlert Flags Supported by the Ultrium Tape Drive.	C-3
5-7.	Drive Identity page elements	5-33	D-1.	Library Sense Keys, ASC and ASCQ	D-1
5-8.	Library Status page elements	5-34	D-2.	LTO Tape Drive Sense Data	D-6
5-9.	Drive Status page elements	5-35	E-1.	AIX ERRPT Library Sense Data	E-3
5-10.	Configure Library: General page elements	5-41	E-2.	AIX ERRPT Drive Sense Data	E-4
5-11.	Configure Library: Specific page elements	5-41	F-1.	SNMP Status Events	F-1
5-12.	Drive Identity page elements	5-46			
6-1.	Ultrium data and cleaning cartridge compatibility with Ultrium tape drive	6-2			

Safety and Environmental Notices

When using this product, observe the danger, caution, and attention notices that are contained in this guide. The notices are accompanied by symbols that represent the severity of the safety condition.

Most danger or caution notices contain a reference number (Dxxxx or Cxxxx). Use the reference number to check the translation in the *IBM Systems Safety Information* (G229-9054) publication included in your ship group.

The sections that follow define each type of safety notice and give examples.

Danger Notice



A danger notice calls attention to a situation that is potentially lethal or extremely hazardous to people. A lightning bolt symbol always accompanies a danger notice to represent a dangerous electrical condition.

Caution Notice

A caution notice calls attention to a situation that is potentially hazardous to people because of some existing condition. A caution notice can be accompanied by one of several symbols:

If the symbol is...	It means....
	A hazardous electrical condition with less severity than electrical danger.
	A generally hazardous condition not represented by other safety symbols.
 Class I	A hazardous condition due to the use of a laser in the product. Laser symbols are always accompanied by the classification of the laser as defined by the U. S. Department of Health and Human Services (for example, Class I, Class II, and so forth).
	A hazardous condition due to mechanical movement in or around the product.
 32-55 kg (70.5-121.2 lbs) svc00168	A hazardous condition due to the weight of the unit. Weight symbols are accompanied by an approximation of the product's weight.

If the symbol is... **It means....**



A hazardous condition due to the unit's susceptibility to electrostatic discharge.

Laser Safety and Compliance

Before using the library, review the following laser safety information.

Class I Laser Product

The library may contain a laser assembly that complies with the performance standards set by the U.S. Food and Drug Administration for a Class I laser product. Class I laser products do not emit hazardous laser radiation. The library has the necessary protective housing and scanning safeguards to ensure that laser radiation is inaccessible during operation or is within Class I limits. External safety agencies have reviewed the library and have obtained approvals to the latest standards as they apply.

Performing the Safety Inspection Procedure

Before you service the unit, perform the following safety inspection procedure:

1. Stop all the activities between the host and the library's tape drives.
2. Turn off the power to the library by pushing in on the **Power** button (1) shown in Figure 1-1 on Page 1-1 for 4 seconds.
3. If drives are SCSI attached, disconnect the SCSI cable and check the SCSI bus terminator for damage.
4. Unplug the library's power cord or cords from the electrical outlet and the library power supply.
5. Check the library's power cord for damage, such as a pinched, cut, or frayed cord.
6. If drives are SCSI attached, check the tape drive's SCSI bus (signal) cable for damage.
7. If drives are FC/SAS attached, check the tape drive's FC/SAS cable for damage.
8. Check the cover of the library for sharp edges, damage, or alterations that expose its internal parts.
9. Check the cover of the library for proper fit. It should be in place and secure.
10. Check the product label at the rear of the library to make sure that it matches the voltage at your outlet.

Rack Safety

The following general safety information should be used for all rack mounted devices.



DANGER

- Always lower the leveling pads on the rack cabinet.
- Always install stabilizer brackets on the rack cabinet.
- To avoid hazardous conditions due to uneven mechanical loading, always install the heaviest devices in the bottom of the rack cabinet. Always install servers and optional devices starting from the bottom of the rack cabinet.
- Rack mounted devices are not to be used as a shelf or work space. Do not place any object on top of rack mounted devices.
- Each rack cabinet might have more than one power cord. Ensure that all power cords in the rack cabinet are disconnected before servicing any device in the rack cabinet.
- Connect all devices installed in a rack cabinet to power devices installed in the same rack cabinet. Do not plug a power cord from a device installed in one rack cabinet into a power device installed in a different rack cabinet.
- An electrical outlet that is not correctly wired could place hazardous voltage on the metal parts of the system or the devices that attach to the system. It is the responsibility of the customer to ensure that the outlet is correctly wired and grounded to prevent an electrical shock.



CAUTION:

- Do not install a unit in a rack where the internal rack ambient temperatures **WILL** exceed the manufacturer's recommended ambient temperature for all your rack mounted devices.
- Do not install a unit in a rack where the air flow is compromised. Ensure that air flow is not blocked or reduced on any side of the unit.
- Connect the equipment to the supply circuit such that overloading of the circuits does not compromise the supply wiring or overcurrent protection. To provide the correct power connection to a rack, refer to the rating labels located on the equipment in the rack to determine the total power requirement of the supply circuit.
- *(For sliding drawers)* Do not pull out or install any drawer or feature if the rack stabilizer brackets are not attached to the rack. Do not pull out more than one drawer at a time. The rack may become unstable if you pull out more than one drawer at a time.
- *(For fixed drawers)* Do not move a fixed drawer. Attempting to move the drawer partially or completely out of the rack may cause the rack to become unstable or cause the drawer to fall out of the rack.

(R001)

**CAUTION:**

Removing components from the upper positions in the rack cabinet improves rack stability during relocation. Follow the general guidelines as listed below whenever you relocate a populated rack cabinet within a room or building:

- Reduce the weight of the rack cabinet by removing equipment starting at the top of the rack cabinet. When possible, restore the rack cabinet to the configuration of the rack cabinet as you received it. If this configuration is not known, you must do the following:
 - Remove all devices in the 32U position and above.
 - Ensure that the heaviest devices are installed in the bottom of the rack cabinet.
 - Ensure that there are no empty U-levels between devices installed in the rack cabinet below the 32U level.
- If the rack cabinet you are relocating is part of a suite of rack cabinets, detach the rack cabinet from the suite.
- Inspect the route that you plan to take to eliminate potential hazards.
- Verify the route that you choose can hold the weight of the loaded rack cabinet. Refer to the documentation that comes with your rack cabinet for the weight of a loaded rack cabinet.
- Verify that all door openings are at least 762 x 2032 mm (30 x 80 inches).
- Ensure that all devices, shelves, drawers, doors, and cables are secure.
- Ensure that the four leveling pads are raised to their highest position.
- Ensure that there is no stabilizer bracket installed on the rack cabinet during movement.
- Do not use a ramp inclined at more than ten degrees.
- Once the rack cabinet is in the new location, do the following:
 - Lower the four leveling pads.
 - Install stabilizer brackets on the rack cabinet.
 - If you remove any of the devices from the rack cabinet, repopulate the rack cabinet from the lowest position to the highest position.
- If a long distance relocation is required, restore the rack cabinet to the configuration of the rack cabinet as you received it. Pack the rack cabinet in the original packaging material, or equivalent. Also lower the leveling pads to raise the casters off of the pallet and bolt the rack cabinet to the pallet.

(R002)


Product Recycling and Disposal

This unit contains recyclable materials.

This unit must be recycled or discarded according to applicable local and national regulations. IBM® encourages owners of information technology (IT) equipment to responsibly recycle their equipment when it is no longer needed. IBM offers a variety of product return programs and services in several countries to assist equipment owners in recycling their IT products. Information on IBM product recycling offerings can be found on IBM's Internet sites at <http://www.ibm.com/ibm/recycle/us/index.shtml> and <http://www.ibm.com/ibm/environment/products/index.shtml>

Note: This paragraph is also translated into Spanish as follows:

Esta unidad debe reciclarse o desecharse de acuerdo con lo establecido en la normativa nacional o local aplicable. IBM recomienda a los propietarios de equipos de tecnología de la información (TI) que reciclen responsablemente sus equipos cuando éstos ya no les sean útiles. IBM dispone de una serie de programas y servicios de devolución de productos en varios países, a fin de ayudar a los propietarios de equipos a reciclar sus productos de TI. Se puede encontrar información sobre las ofertas de reciclado de productos de IBM en el sitio web de IBM <http://www.ibm.com/ibm/environment/products/index.shtml>



Notice: This mark applies only to countries within the European Union (EU) and Norway.

Appliances are labeled in accordance with European Directive 2002/96/EC concerning waste electrical and electronic equipment (WEEE). The Directive determines the framework for the return and recycling of used appliances as applicable throughout the European Union. This label is applied to various products to indicate that the product is not to be thrown away, but rather reclaimed upon end of life per this Directive.

Remarque : Cette marque s'applique uniquement aux pays de l'Union Européenne et à la Norvège.

L'étiquette du système respecte la Directive européenne 2002/96/EC en matière de Déchets des Equipements Electriques et Electroniques (DEEE), qui détermine les dispositions de retour et de recyclage applicables aux systèmes utilisés à travers l'Union européenne. Conformément à la directive, ladite étiquette précise que le produit sur lequel elle est apposée ne doit pas être jeté mais être récupéré en fin de vie.

注意: このマークは EU 諸国およびノルウェーにおいてのみ適用されます。

この機器には、EU 諸国に対する廃電気電子機器指令 2002/96/EC(WEEE) のラベルが貼られています。この指令は、EU 諸国に適用する使用済み機器の回収とリサイクルの骨子を定めています。このラベルは、使用済みになった時に指令に従って適正な処理をする必要があることを知らせるために種々の製品に貼られています。


In accordance with the European WEEE Directive, electrical and electronic equipment (EEE) is to be collected separately and to be reused, recycled, or recovered at end of life. Users of EEE with the WEEE marking per Annex IV of the WEEE Directive, as shown above, must not dispose of end of life EEE as unsorted municipal waste, but use the collection framework available to customers for the return, recycling and recovery of WEEE. Customer participation is important to minimize any potential effects of EEE on the environment and human health due to the potential presence of hazardous substances in EEE. For proper collection and treatment, contact your local IBM representative.

Battery Return Program

This product may contain sealed lead acid, nickel cadmium, nickel metal hydride, lithium, or a lithium ion battery. Consult your user manual or service manual for specific battery information. The battery must be recycled or disposed of properly. Recycling facilities may not be available in your area. For information on disposal of batteries outside the United States, go to <http://www.ibm.com/ibm/environment/products/index.shtml> or contact your local waste disposal facility.

In the United States, IBM has established a return process for reuse, recycling, or proper disposal of used IBM sealed lead acid, nickel cadmium, nickel metal hydride, and other battery packs from IBM Equipment. For information on proper disposal of these batteries, contact IBM at 1-800-426-4333. Please have the IBM part number listed on the battery available prior to your call.

For the European Union:



For Taiwan:



Please recycle batteries

廢電池請回收

Batteries or packaging for batteries are labeled in accordance with European Directive 2006/66/EC concerning batteries and accumulators and waste batteries

and accumulators. The Directive determines the framework for the return and recycling of used batteries and accumulators as applicable throughout the European Union. This label is applied to various batteries to indicate that the battery is not to be thrown away, but rather reclaimed upon end of life per this Directive.

Les batteries ou emballages pour batteries sont étiquetés conformément aux directives européennes 2006/66/EC, norme relative aux batteries et accumulateurs en usage et aux batteries et accumulateurs usés. Les directives déterminent la marche à suivre en vigueur dans l'Union Européenne pour le retour et le recyclage des batteries et accumulateurs usés. Cette étiquette est appliquée sur diverses batteries pour indiquer que la batterie ne doit pas être mise au rebut mais plutôt récupérée en fin de cycle de vie selon cette norme.

バッテリーあるいはバッテリー用のパッケージには、EU 諸国に対する廃電気電子機器指令 2006/66/EC のラベルが貼られています。この指令は、バッテリーと蓄電池、および廃棄バッテリーと蓄電池に関するものです。この指令は、使用済みバッテリーと蓄電池の回収とリサイクルの骨子を定めているもので、EU 諸国にわたって適用されます。このラベルは、使用済みになったときに指令に従って適正な処理をする必要があることを知らせるために種々のバッテリーに貼られています。

In accordance with the European Directive 2006/66/EC, batteries and accumulators are labeled to indicate that they are to be collected separately and recycled at end of life. The label on the battery may also include a chemical symbol for the metal concerned in the battery (Pb for lead, Hg for mercury and Cd for cadmium). Users of batteries and accumulators must not dispose of batteries and accumulators as unsorted municipal waste, but use the collection framework available to customers for the return, recycling and treatment of batteries and accumulators. Customer participation is important to minimize any potential effects of batteries and accumulators on the environment and human health due to the potential presence of hazardous substances. For proper collection and treatment, contact your local IBM representative.

Spain

This notice is provided in accordance with Royal Decree 106/2008 of Spain: The retail price of batteries, accumulators and power cells includes the cost of the environmental management of their waste.

Perchlorate Material - California

Special handling may apply. See <http://www.dtsc.ca.gov/hazardouswaste/perchlorate> for more information.

The foregoing notice is provided in accordance with California Code of Regulations Title 22, Division 4.5 Chapter 33. Best Management Practices for Perchlorate Materials. This product/part may include a lithium manganese dioxide battery which contains a perchlorate substance.

Cautions and Regulatory Compliance Statements for NEBS

This library is NEBS certified. This section includes the cautions and regulatory compliance statements for the Network Equipment-Building System (NEBS) certification from the Telcordia Electromagnetic Compatibility and Electrical Safety - Generic Criteria for Network Telecommunications Equipment (A Module of

LSSGR, FR-64; TSGR, FR-440; and NEBSFR, FR-2063) Telcordia Technologies Generic Requirements, GR-1089-CORE, Issue 4, June 2006.

Table 2. NEBS Compliance Statements

	Caution: To comply with the Telcordia GR-1089-CORE standard for electromagnetic compatibility and safety, for Ethernet RJ-45 ports, use only shielded Ethernet cables that are grounded on both ends. In a NEBS installation, all Ethernet ports are limited to intra-building wiring.
	Caution: The intra-building ports of the equipment or subassembly are only suitable for connection to intra-building or unexposed wiring or cabling. The intra-building ports of the equipment or subassembly MUST NOT be metalically connected to interfaces that connect to the OSP or its wiring. These interfaces are designed for use only as intra-building interfaces (Type 2 or Type 4 ports as described in GR-1089-CORE, Issue 4), and require isolation from the exposed OSP cabling. The addition of primary protectors is not sufficient protection in order to connect these interfaces metalically to OSP wiring.
	An external Surge Protective Device (SPD) is not required for operating this library.
	This product can be installed in a network telecommunication facility or location where the NEC applies.

Preface

This manual contains information and instructions necessary for the installation, operation, and service of the IBM System Storage™ TS3100 Tape Library and TS3200 Tape Library.

Note: The IBM System Storage™ TS3100 Tape Library and TS3200 Tape Library is a customer installed unit. The customer is responsible for the setup and maintenance of the tape library. The customer will be charged for service if a service contract is not in place.

Related Publications

Refer to the following publications for additional information. To ensure that you have the latest publications, visit the web at <http://www.ibm.com/storage/>.

- *IBM System Storage TS3100 Tape Library and TS3200 Tape Library Getting Started Guide* (GA32-0546) provides installation information.
- *IBM System Storage TS3100 Tape Library and TS3200 Tape Library SCSI Reference* (GA32-0547) provides supported SCSI commands and protocol governing the behavior of SCSI interface.
- *IBM Tape Device Driver Installation and User's Guide* (GC27-2130) provides instructions for attaching IBM-supported hardware to open-systems operating systems. It indicates what devices and levels of operating systems are supported. It also gives requirements for adapter cards, and tells how to configure hosts to use the device driver. All of the above are with the Ultrium family of devices.
- *IBM Tape Device Driver Programming Reference* (GA32-0566) supplies information to application owners who want to integrate their open-systems applications with IBM-supported Ultrium hardware. The reference contains information about the application programming interfaces (APIs) for each of the various supported operating-system environments.
- *IBM Encryption Key Manager component for the Java platform Quick Start Guide* (GA76-0420) gets you started with a basic configuration for encryption on LTO 4 tape drives.
- *IBM Encryption Key Manager component for the Java platform Introduction, Planning, and User's Guide* (GA76-0418) contains information to help you install, configure, and use the IBM Encryption Key Manager component for the Java platform.
- *IBM Tivoli® Key Lifecycle Manager V1.0* (English) publications may be downloaded from the following Web site: <http://www.ibm.com/software/tivoli/library>.
 - *IBM Tivoli Key Lifecycle Manager Quick Start Guide* (GI11-8738)
 - *IBM Tivoli Key Lifecycle Manager Installation and Configuration Guide* (SC23-9977)
- The IBM Publications Center: <http://www.ibm.com/shop/publications/order> The Publications Center is a worldwide central repository for IBM product publications and marketing material with a catalog of 70,000 items. Extensive search facilities are provided. Payment options for orders are via credit card (in the U.S.) or customer number for 20 countries. A large number of publications are available online in various file formats, and they can all be downloaded by all countries, free of charge.

Chapter 1. Product Description

The IBM System Storage™ TS3100 Tape Library (2U library) and the IBM System Storage TS3200 Tape Library (4U library) provide compact, high-capacity, low-cost solutions for simple, unattended data backup. The 4U library houses up to 48 tape cartridges (or 45 and an elective 3-slot I/O Station) in a compact 4U form factor with easy access to cartridges via four removable magazines. The 2U library houses up to 24 tape cartridges (or 23 and an elective 1-slot I/O Station) in a compact 2U form factor with easy access to cartridges via two removable magazines.

The fourth generation of the Ultrium series of products is available with interfaces to suit your needs: a Small Computer Systems Interface (SCSI), Fibre Channel interface (FC), or Serial Attached SCSI interface (SAS).

Front Panel




Figure 1-1. Front panel of a 2U library




Figure 1-2. Front panel of a 4U library

Table 1-1 on page 1-2 below contains front panel descriptions for both the 2U library in Figure 1-1 and the 4U library in Figure 1-2.

Table 1-1. 2U library and 4U library front panel descriptions

Number	Item	Description
1	Power button	Pressing this button powers ON the library. Pressing and holding this button for 4 seconds will power OFF the unit (soft power down). No power switch or button can be found on the back panel of the library.
2	Front panel LEDs (left to right)	• Ready/Activity (Green LED) - It is illuminated any time the unit is powered ON and able to function. It should blink whenever there is library or drive activity, or when the library is in the process of powering up. • Clean Drive (Amber LED) - It is illuminated when the drive needs to be cleaned. The LED will be turned OFF after the drive is cleaned successfully. • Attention (Amber LED) - It is illuminated when there has been a failure that indicates a piece of media is bad, marginal, or invalid. It will be cleared when all invalid cartridges have been exported from the library. The amber LED may also be lit because a power supply or a power supply fan is failing, or a drive sled is defective, missing, or has been replaced by a different drive type. • Error (Amber LED) - It is illuminated when there is an unrecoverable library or drive failure. A message is displayed at the same time on the Operator Control Panel display.
3	Cartridge magazines	• The 2U library contains two cartridge magazines. – The left magazine can hold up to 12 cartridges (or 11 data cartridges and the elective 1-slot I/O Station.) – The right magazine can hold up to 12 cartridges. • The 4U library contains four cartridge magazines. – The upper left magazine can hold up to 12 cartridges. – The lower left magazine can hold up to 12 cartridges (or 9 data cartridges and the elective 3-slot I/O Station.) – The upper right magazine can hold up to 12 cartridges. – The lower right magazine can hold up to 12 cartridges.
4	Air vents	These vents draw cooler air into the library enclosure and allow warm air to escape, which helps keep the library at a normal operating temperature.
5	Control keys	• UP (+) - The upper left button is used to scroll upward through menu items. • DOWN (-) - The lower left button is used to scroll downward through menu items. • CANCEL (X) - The upper right button is used to cancel a user action and return to the previous menu screen. • SELECT - The lower right button is used to display a sub-menu or force an accessor action.
6	Machine type, Model number, and Serial Number label	The machine type, model number and serial number of the library are located on this label. This serial number is the number that links the library to your warranty.
7	Operator Control Panel display	This component is a 128 X 64 monochrome graphic display.
8	I/O Station	The Input/Output (I/O) Station is used to import and export cartridges into and out of the library. • The 2U library has an elective 1-slot I/O Station. • The 4U library has an elective 3-slot I/O Station.

Rear Panel




Figure 1-3. Rear panel of a 2U library with a SCSI drive




Figure 1-4. Rear panel of a 4U library with full high Fibre Channel drive and half high SCSI and SAS drives.




Figure 1-5. Rear panel of a 2U library with a full high dual port SAS drive

Table 1-2. 2U library and 4U library rear panel descriptions

Number	Item	Description
1	Power connector(s)	Both libraries require a 110/220 volt AC power connection. - The 2U library has one power supply. - The 4U library has a minimum of one power supply, but has the capability of adding a redundant power supply.
2	Host interface connectors	The library has one or more of the following host interface connectors on the drive sled: - a 68-pin HD SCSI connector - a Fibre Channel connector - a SFF-8088 mini-SAS connector
3	Tape drive sled	This library supports the Ultrium 3 and Ultrium 4 tape drive. The tape drive in the library is packaged in a container called a drive sled. Drive sleds come in a full high or half high configuration. The drive sled is a customer replaceable unit (CRU), and is hot-pluggable, which is designed for easy removal and replacement.
4	Shipping lock and label storage location	The shipping lock, which secures the accessor during shipping, and associated label are stored on the rear panel of the library for future use. See “Removing and Storing the Shipping Lock” on page 4-5. Note: The shipping lock must be removed before powering ON the library to allow the accessor to function properly.
5	USB port	An alternative communication path to the library. For use by IBM Service Personnel.
6	Serial port	This port is used to communicate serially with the library using an RJ-11 connector. For use by IBM Service Personnel.
7	Ethernet port	This port is used to connect the library to a network.
8	Tape drive LED	This LED indicates the current status of the drive. When the LED is green, it indicates normal drive activity.
9	Machine type, Model number, and Serial Number pull-out label	The machine type, model number and serial number of the library are located on this pull-out label. This serial number is the number that links the library to your warranty.
10	Fan vents	These vents allow air to escape from the power supply and tape drive sled.
11	ESD label	The Electrostatic Discharge label is a reminder that some of the components of this library are susceptible to electrostatic discharge. See “Electrostatic Discharge” on page 10-1.

Bar Code Reader

The bar code reader is an integral part of the library accessor. The bar code reader provides inventory feedback to the host application, Operator Control Panel display, and Web User Interface by reading cartridge bar code labels. The library stores the customized inventory data in memory.

Library firmware supports a 6 or 8 character volume serial number (VOLSER) on the bar code label on the tape cartridge.

Encryption

The LTO Ultrium 4 Tape Drive supports host Application Managed Encryption (AME), Library Managed Encryption (LME), and System Managed Encryption (SME), using T10 encryption methods, for SAS and Fibre Channel drives only. Data encryption is supported with LTO Ultrium 4 Data Cartridges only. Encryption is also supported with library firmware version 4.0 or higher.

The encryption enabled drive contains the necessary hardware and firmware to encrypt and decrypt host tape application data. Encryption policy and encryption keys are provided by the host application or host server. A drive digital certificate is installed at manufacturing time. Each drive receives a unique serial number and certificate. The T10 application may validate each drive instance by checking the drive's digital certificate.

The LTO Ultrium 4 encryption environment is complex and requires knowledge beyond that of product trained Service Support Representatives (SSRs). The Encryption function on tape drives (desktop, stand alone and within libraries) is configured and managed by the customer. In some instances, SSRs are required to enable encryption at a hardware level when service access or service password controlled access is required. Customer setup support is by Field Technical Sales Support (FTSS), customer documentation, and software support for encryption software problems. Customer 'how to' support is also provided via support line contract.

The library firmware should always allow the user to select "None" or "Application Managed Encryption" from the Web User Interface, as long as there is at least one encryption capable drive in the logical library. If a valid Transparent Encryption license key has been previously entered, "System Managed Encryption" or "Library Managed Encryption" can be selected. The factory default is "None."

Note: The optional Transparent Encryption Key feature enabling System Managed Encryption and Library Managed Encryption is not available on TS3200 and TS3100 models purchased through High Volume (HVEC) channels.

Note: All encryption settings should be configured or re-verified in the drive after any library or drive reset. This is because a new drive may have been added or an existing drive may have been swapped with another drive.

For more details, see the IBM Tape Device Drivers documentation, and the IBM LTO Ultrium Tape Drive SCSI Reference documentation. See "Related Publications" in the Preface.

Supported Internet Protocols

The library supports the following Internet protocols:

- IPv4
- IPv6

To learn more about IPv4, visit <http://www.iana.org/>. To learn more about IPv6, visit <http://www.ipv6.org/>.

SNMP Messaging

Occasionally, the library may encounter a situation that you want to know about, such as an open magazine or a fault that causes the library to stop. The library provides a standard TCP/IP protocol called Simple Network Management Protocol (SNMP) to send alerts about conditions (such as need for operator intervention) over a TCP/IP LAN network to an SNMP monitoring station. These alerts are called SNMP traps. Using the information supplied in each SNMP trap, the monitoring station (together with customer-supplied software) can alert operations personnel of possible problems or operator interventions that occur.

SNMP Traps

SNMP traps are alerts or status messages that can be collected, monitored and used to proactively manage attached libraries using SNMP protocol with the host server(s). In summary, each trap provides the following information:

- **Product Identification** such as product name, description, manufacturer, model number, firmware level, and the URL that the trap is designated for.
- **Product Status** such as the severity of the trap, status (current and previous) and the time the trap occurred.
- **Library State** (physical device status) such as identification and status of devices that are monitored. In the case of the library, it would include enclosure, power supply, controller, magazine status, drive count, cartridge slot count, and I/O station count. Also included would be certain library statistics, and where appropriate, the fault FSC (fault symptom code) including the severity and description of that fault.
- **Drive Status** such as the identification of each drive in the library, firmware level, serial number and other address and status information.
- **Trap Definitions** such as library status change, open magazine, I/O accessed, hard fault information, drive cleaning requests, excessive retries and library returning to normal operations. For additional information, refer to Appendix G. "SNMP Status MIB Variables and Traps" on page G-1.
- **SNMP MIBs:** The library's Management Information Base (MIB) contains units of information that specifically describe an aspect of the system, such as the system name, hardware number or communications configuration. Status and error data is also gathered by MIBs and sent to one or more IP addresses defined during the SNMP configuration operation. Download the SNMP MIB file for this library from <http://www.ibm.com/storage/support>.

Maximum Library Storage Capacity and Data Transfer Rate

Maximum library storage capacity and maximum data transfer rates are as follows:

Table 1-3. Tape drive model and host interface type

Tape Drive Model	Host Interface
Ultrium 4 Full High drives	• Ultra160 SCSI LVD (depending on drive; single-ended (SE) is not recommended as it will severely degrade performance) • 4 Gb/s Fibre Channel • 3 Gb/s Serial Attached SCSI (SAS) - dual port
Ultrium 4 Half High drives	• 3 Gb/s SAS - single port

Table 1-3. Tape drive model and host interface type (continued)

Tape Drive Model	Host Interface
Ultrium 3 Full High drives	- Ultra160 SCSI LVD (depending on drive; single-ended (SE) is not recommended as it will severely degrade performance) 4 Gb/s Fibre Channel
Ultrium 3 Half High drives	- Ultra 160 SCSI LVD (depending on drive; single-ended (SE) is not recommended as it will severely degrade performance) 3 Gb/s SAS - single port

Table 1-4. Library storage capacity and data transfer rate

Characteristic	2U Library Specification	4U Library Specification
Maximum storage capacity - Ultrium 4 Data Cartridges	24 data cartridges - Native: 19.2 TB - Compressed: 38.4 TB (2:1 compression)	48 data cartridges - Native: 38.4 TB - Compressed: 75.2 TB (2:1 compression)
Maximum storage capacity - Ultrium 3 Data Cartridges	24 data cartridges - Native: 9.6 TB - Compressed: 19.2 TB (2:1 compression)	48 data cartridges - Native: 19.2 TB - Compressed: 38.4 TB (2:1 compression)
Sustained native data transfer rate	LTO 3 HH: 60 MBs, LTO 3 FH: 80 MBs LTO 4 HH and FH: 120 MBs	

Ultrium Tape Drives

This library supports the Ultrium 3 and Ultrium 4 Tape Drives. Each tape drive in the library is packaged in a container called a drive sled. The drive sled is a customer replaceable unit (CRU), and is designed for quick removal and replacement in the library.


The Ultrium 4 Full High Tape Drives support LVD Ultra160, Serial Attached SCSI (SAS), or Fibre Channel interfaces. It features two SFF-8088 SAS connectors, or one LC Fibre Channel connector. The Ultrium 4 Half High Tape Drive supports one SAS SFF-8088 connector.

The Ultrium 3 Full High Tape Drive supports LVD Ultra160, or Fibre Channel interfaces. It features two HD68 connectors or one LC Fibre Channel connector. The Ultrium 3 Half High Drive supports one SAS SFF-8088 connector or two HD68 SCSI connectors.



a77ug008

Figure 1-6. Library drive sled without ESD springs (SCSI sled shown)



a77ug202

Figure 1-7. Library drive sled with ESD springs [1] (SAS sled shown)

Note: Ultrium 3 and 4 SCSI, SAS, and Fibre Channel drives are allowed in the same physical and logical library.

Speed Matching

To improve system performance, the Ultrium 3 and Ultrium 4 Tape Drive uses a technique called *speed matching* to dynamically adjust its native (uncompressed) data rate to the slower data rate of the attached server.

Channel Calibration

The channel calibration feature of the Ultrium 3 and Ultrium 4 Tape Drive customizes each read/write data channel for optimum performance. The customization enables compensation for variations in the recording channel transfer function, media characteristics, and read/write head characteristics.

Power Management

The Ultrium 3 and Ultrium 4 Tape Drive's power management function controls the drive's electronics so that part of the electronics completely turn OFF when circuit functions are not needed for the drive's operation.

Media

The library uses Ultrium Tape Cartridges that provide up to 800 GB native capacity (up to 1600 GB with 2:1 hardware data compression) for LTO-4 tape drives, and up to 400 GB native capacity (up to 800 GB with 2:1 hardware data compression) for LTO-3 tape drives.

IBM Ultrium 4 tape drives can read and write LTO Ultrium 4 Data Cartridges. IBM Ultrium 4 tape drives can read and write LTO Ultrium 3 Data Cartridges at original Ultrium 3 capacities, and can also read LTO Ultrium 2 Data Cartridges with improved data rates. IBM Ultrium 3 Tape Drives can read and write LTO Ultrium 2 Data Cartridges at original Ultrium 2 capacities, and can also read LTO Ultrium 1 Data Cartridges with improved data rates of up to 20 MB/second native data transfer rate (40 MB/second with 2:1 compression). Ultrium 4 tape drives cannot read Ultrium 1 tapes.

Supported cartridges include:

- IBM LTO Ultrium 800 GB Data Cartridge (Ultrium 4)
- IBM LTO Ultrium 400 GB Data Cartridge (Ultrium 3)
- IBM Write-Once-Read-Many Data Cartridge (WORM; Ultrium 3 and Ultrium 4)
- IBM LTO Ultrium 200 GB Data Cartridge (Ultrium 2)
- IBM 100 GB Data Cartridge (Ultrium 1; read only)
- IBM LTO Ultrium Cleaning Cartridge

For additional information, see Chapter 6, "Using Ultrium Media," on page 6-1.

Library Specifications

Physical Specifications

Table 1-5. Physical Specifications

Specification	2U library	4U library
Height	Rack mount 87.6 mm (3.44 in), stand-alone 97.6 mm (3.84 in)	Rack mount 175.2 mm (6.9 in), stand-alone 185.2 mm (7.3 in)
Width	447.5 mm (17.6 in.)	447.5 mm (17.6 in.)
Depth	Rack mount 740 mm (29.13 in), stand-alone 810 mm (31.9 in)	Rack mount 740 mm (29.13 in), stand-alone 810 mm (31.9 in)
Weight with 1 drive and without media	15.59 kg (34.37 lbs.)	21.32 kg (47 lbs.)
Weight with media	20.67 kg (45.57 lbs.)	31.71 kg (69.9 lbs.)

Power Specifications

Table 1-6. Power Specifications

AC power voltage	100-127 VAC; 200-240 VAC (4 - 2 A)
Line frequency	50-60 Hz

Operation Specifications

Table 1-7. Operation Specifications: Ultrium 4

Library with Ultrium 4 drive(s)	2U Library	4U Library
Maximum storage capacity	Maximum number of data cartridges: 24 Native: 19.2 TB Compressed: 38.4 TB (2:1 compression)	Maximum number of data cartridges: 48 Native: 38.4 TB Compressed: 75.2 TB (2:1 compression)
Number of slots	24 (including I/O Station)	48 (Including 3 I/O station slots)
Sustained native data transfer rate	Ultrium 4 Full High Drive: 120 MB/s Ultrium 4 Half High Drive: 120 MB/s	
Drive types	Ultrium 4 Full High Drive SCSI, Fibre Channel, SAS Ultrium 4 Half High Drive: SAS	
Interfaces	Ultra160 SCSI LVD 4 Gb/s Fibre Channel 3 Gb/s SAS	
*Host Interface Drive Transfer Rates may vary depending on host usage and interface utilization.		

Table 1-8. Operation Specifications: Ultrium 3

Library with Ultrium 3 drive(s)	2U library	4U library
Maximum storage capacity	Maximum number of data cartridges: 24 Native: 9.6 TB Compressed: 19.2 TB (2:1 compression)	Maximum number of data cartridges: 48 Native: 19.2 TB Compressed: 38.4 TB (2:1 compression)
Number of slots	24 (including I/O Station)	48 (Including 3 I/O station slots.)
Sustained native data transfer rate	Ultrium 3 Full High Drive: 80 MB/s Ultrium 3 Half High Drive: 60 MB/s	
Drive types	Ultrium 3 Full High Drive: SCSI, Fibre Channel Ultrium 3 Half High Drive: SCSI, Serial Attached SCSI (SAS)	
Interfaces	Ultra160 SCSI LVD 4 Gb/s Fibre Channel 3 Gb/s SAS	

Environmental Specifications

Table 1-9. Environmental Specifications

Temperature	
Operating	10° to 35° C (50° to 95° F)
Storage, without cartridges	-30° to 60° C (-22° to 140° F)
Wet bulb, operating	26° C (79.0° F) maximum

Table 1-9. Environmental Specifications (continued)

Temperature shock immunity - maximum rate of change	10° C (18° F) per hour
Miscellaneous	
Dust concentration	less than 200 microgram/cubic meter
Altitude (operating)	2500 meters (8200 ft.) at 25°C ambient
Maximum acoustical noise sound power levels LwAd in bels	6.6/6.8
Humidity	
Operating	15% to 80% RH non-condensing
Storage, without cartridges	10% to 90% RH non-condensing

Product Environment

The library is designed to operate in a general business environment.

The library meets the acoustical requirements for general business area category 2D. Category 2D states that the library should be installed a minimum of 4 m (13 ft.) from a permanent work station.

To allow for service access, install the library a minimum of 0.9 m (3 ft.) from all obstacles.

The library is a precision computer peripheral. To ensure maximum longevity of your library, locate the library away from dust, dirt, and airborne particulates:

- Keep the library away from high-traffic areas, especially if the floor is carpeted. Carpeting harbors dust and people walking on the carpet can cause the carpet fibers and the dust to become airborne.
- Keep the library out of printer/copier rooms because of toner and paper dust. Additionally, do not store paper supplies next to the library.
- Keep the library away from moving air caused by doorways, open windows, fans, and air conditioners.

Ensure that the machine covers are always kept closed to minimize any contamination from airborne particles.

Supported Servers, Operating Systems, and Software

The library is supported by a wide variety of servers (hosts), operating systems, and adapters. These attachments can change throughout the life cycle of the product.

To determine the latest supported attachments:

1. Visit the web at <http://www.ibm.com/>.
2. Point cursor at **Support & downloads**, then **Support by product**, then point and click **System storage**.
3. Select the appropriate **Interoperability** link.

Supported Device Drivers

IBM maintains the latest levels of device drivers and driver documentation for the library on the Internet. You can use one of the following procedures to access this material. (**Note: If you do not have Internet access and you need information about device drivers, contact your Marketing Representative.**)

- Using a browser, type one of the following:
 - <http://www.ibm.com/storage/lto>
 - <ftp://ftp.software.ibm.com/storage/devdrv>
- Using File Transfer Protocol (FTP), enter the following specifications:
 - FTP site: [ftp.software.ibm.com](ftp://ftp.software.ibm.com)
 - IP Addr: 207.25.253.26
 - Userid: anonymous
 - Password: (use your current e-mail address)
 - Directory: /storage/devdrv

IBM provides Portable Document Format (.pdf) and Postscript (.ps) versions of its device driver documentation in the /storage/devdrv/Doc directory:

- IBM_tape_IUG.pdf and IBM_tape_IUG.ps contain the current version of the *IBM Tape Device Drivers Installation and User's Guide*.
- IBM_tape_PROGREF.pdf and IBM_tape_PROGREF.ps contain the current version of the *IBM Tape Device Drivers Programming Reference*.

A list of device drivers for each supported server appears at /storage/devdrv/.

Note: The device driver for System i servers is included in the OS/400 operating system.

Chapter 2. User Interfaces

This library has two user interfaces.

- Operator Control Panel - located on the front panel of the library
- “Web User Interface” on page 2-4 - accessed via a web browser

Operator Control Panel

The Operator Control Panel operates in two basic modes.

- **User Interaction mode** - This mode is employed when a user is pushing buttons on the Operator Control Panel.
- **System Driven mode** - This is the normal mode of operation. In this mode, the Operator Control Panel displays status associated with the actions that were caused from commands issued via the drive’s internal (drive to library) serial interface.

When an Operator Control Panel button is pressed and released, the Operator Control Panel automatically transitions to User Interaction mode. User Interaction mode will continue until 3 minutes after a user stops pushing buttons, or the requested accessor action stops - whichever is longer. At which time, the Operator Control Panel will return to System Driven mode.

If necessary, the Operator Control Panel automatically transitions to the System Driven mode. When this occurs, the library must remember the previous function before the display mode changed. Therefore the next button pressed only transitions the Operator Control Panel to the User Interaction mode from the System Driven mode.

In case of the activated user security feature, the User Interaction mode is restricted to **Login** and **Monitor** menu items, until a user logs in with a correct password.

Operator Control Panel Philosophy

Operator Control Panel operation must obey some basic rules. These rules of operation constitute a philosophy.

- Any operational conflict between commands received over the host interface or the Web User Interface and those entered via the Operator Control Panel will be avoided with a reservation mechanism on a first-come, first-served basis. Any reservation by the Operator Control Panel is canceled by an Operator Control Panel logout or a timeout, which cancels the User Interaction Mode.
- Library firmware will not allow a user to select an impossible request. Those situations will include, but are not limited to:
 - Moving a cartridge from any source to a full slot
 - Moving a cartridge from an empty slot
 - Loading a cartridge from any source to a full drive
 - Unloading a cartridge from an empty drive
- Any error detected by the library or drive controller and not recoverable through predetermined firmware algorithms will be considered as fatal. An error code will be displayed on the Operator Control Panel display and the error LED will

become illuminated. The error code remains on the Operator Control Panel until a push button is pressed, which causes the Operator Control Panel to return to the Home Screen.

- Numeric error codes are only used for unrecoverable, fatal errors, otherwise text status messages are displayed.

Power-ON Display

When the library powers ON or resets, it goes through several internally controlled processes that allow it to get initialized and running. These processes are called Power-On-Self-Test (POST). During the POST the Operator Control Panel displays information that may be meaningless until POST is complete. When the POST is finished, the library displays the Startup screen, then the Home screen.

The Startup screen is the first screen that appears after powering ON the library. It contains the following information:

- Firmware Rev: the current level of library firmware
- Drives: the total number of drives that the library can support
- Magazines: the total number of magazines in the library
- I/O Station: the current status of the I/O Station

The Home screen example below shows that the Accessor and Drives 1 through 3 are OK as shown by the check marks in the Home Screen, but that drive 4 either has a problem, or is missing. The exclamation mark (!), which shows that there is something wrong with drive 4 will not go away until the drive is either fixed, or is replaced. At that time, the explanation mark will become a check mark.




Figure 2-1. Power-ON screens

Note about the Front Panel LEDs

All LEDs are updated during power ON and reset sequences. Upon power ON or software reset, the library illuminates all LEDs as soon as POST allows. When initialization starts, all LEDs are extinguished and the Ready/Activity LED flashes at a rate of approximately one second per cycle. When the mechanical initialization is complete, the Ready/Activity LED will stop flashing and be constantly illuminated.

If a library failure occurs, the Ready/Activity LED will turn OFF and the Error LED illuminates. The Operator Control Panel will also display an appropriate error code to help identify the failure.

The following are additional operational details of LEDs:

- The **Ready/Activity** LED is illuminated any time the unit is powered ON and functional. The Ready/Activity LED blinks whenever there is library or drive activity. This LED will also blink when the unit is OFFLINE.
- The **Clean** LED is illuminated when either a cleaning requested or a cleaning required flag has been issued by the drive. The LED is turned off after a successful drive cleaning operation.
- The **Attention** LED indicates one of the following conditions.

Problem	Action Required
Bad media	1. Go to Monitor → Inventory to locate the defective cartridge. 2. Move the defective cartridge to the I/O Station. (Operator Control Panel: Control → Move Cartridges). 3. Open the I/O Station to remove the defective cartridge. (Operator Control Panel: Control → Open I/O).
Drive sled issues	Do one of the following: - Install a drive sled (see “Removing/Installing/Adding a Tape Drive Sled” on page 10-3). - Modify or resubmit Logical Library setting (Operator Control Panel: Configure → Logical Libraries or Web User Interface: Configure Library → Logical Libraries). - Restore defaults (Operator Control Panel: Configure → Restore Defaults or Web User Interface: Configure Library → Restore Defaults).
Redundant power supply failed	Complete the following steps: 1. Replace the failed power supply (see “Replacing a Power Supply” on page 10-11). 2. Cycle library power.
Power supply fan failure	Replace the power supply.

- The **Error** LED is illuminated when there is an unrecoverable (i.e. hard) drive or library failure. This will happen at the same time the hard error message is displayed on the screen and the LED will remain lit until the error state is resolved.

Note: From the Operator Control Panel, run **Service** → **Library Verify**. If Library Verify runs without error, the Error LED turns off. If the error persists, recycle power.

Input Modes

There are several ways to enter values in the different menu items. These values are selectable predefined values, toggle values (for example, ON/OFF) and numerical values like network addresses.

Selecting Predefined Values

1. To set the predefined values, press the SELECT button to select the menu item.
2. Using the UP and DOWN buttons, select one of the various predefined values for that item.
3. As soon as the Operator Control Panel display shows the correct value, press the SELECT button to apply the value.

Toggling Values

Toggle values are used to switch between two different states like *ON* and *OFF*.

1. After navigating to the menu item, press the SELECT button to select the menu item.
2. Using the UP and DOWN buttons, select one of the various predefined states for that item.
3. Press the SELECT button to apply the new state.

Entering Numerical Values

Numerical values are needed for network addresses, password entries and other configuration entries.

1. After navigating to the menu item, the current value is displayed and the cursor highlights the first digit of the value that can be changed.
2. For each digit to be changed in the value:
 - a. Use the UP and DOWN buttons to increment / decrement the digit.
 - b. Press the SELECT button to highlight the next editable digit.
3. Press the SELECT button at the last digit to apply the complete entry, or press the CANCEL button to cancel the whole edit process and maintain the original value.

Power ON/OFF

Part of the Operator Control Panel is the Power ON/OFF button. If the library is powered ON, pressing this button for 4 seconds will initiate a controlled power down of the library (soft landing). The following operations will take place before the library shuts down completely:

- The display indicates with an appropriate message that the shutdown is in progress.
- The library controller finishes all ongoing library and drive activities.
- The accessor is moved to its home position.
- The library controller switches OFF the power supply's secondary side.

Note: The shutdown process may be aborted by releasing the button before 4 seconds has passed.

Web User Interface

Many of the same operations performed from the Operator Control Panel can also be performed remotely using the Web User Interface.

The Web User Interface lets you monitor and control your library from any terminal connected to your network or through the World Wide Web (WWW). The Web User Interface hosts a dedicated, protected Internet site that displays a graphical representation of your library.

For static IP Addresses only: After establishing a connection to the library, open any HTML browser and enter the IP address of the library. To configure the Web User Interface, you must first set the IP address using the Operator Control Panel. Refer to "Configure: Network" on page 5-23 or "Configure Library: Network" on page 5-45.

Login

Important: Some options of the Web User Interface take the library OFFLINE. This inactive mode can interfere with host-based application software, causing data loss. Make sure the library is idle before attempting to perform any remote operations that will take the library OFFLINE.

To login, select the Role type and enter the correct password. There are four levels of access:

- User - Normal user level. The User only has access to Monitor Library menus.
- Superuser - The Superuser has access to the Monitor Library and Manage Library sections.
- Admin - Admin user level The Admin user has access to all menus except those restricted to Service only.
- Service - Service personnel user level - Access to this level is for Service personnel only. Service personnel have access to all menus.

Note: Passwords are case-sensitive.


Use the following password for logging in as an Admin user: **secure**

Each level affects which areas you have access to and what actions you can initiate from those areas.

For DHCP, use the Operator Control Panel to determine the IP Address assigned to your library. Navigate to **Monitor** → **Library** → **Identity**. Scroll down to **IP Address** and make note of the address. Enter the IP Address in your internet browser address field to access your library with the Web User Interface.

For IPv4 or Dual Stack IPv4 + IPv6, enter your library's static IP Address using the 0.0.0.0 format (four octets).

For IPv6, enter your library's static IP Address or Router Assigned IP Address using the following format: http://[0:0:0:0:0:0:0:0]. To determine your Router Assigned IP Address, navigate to **Monitor** → **Library** → **Network** on the Operator Control Panel. For the IPv6 Router Assigned Addresses to be displayed on the Operator Control Panel, the Network must be configured to IPv6 Only and the Stateless Autoconfig on the must be set to ON.



The login page features a title bar labeled 'Login'. Below it, there is a 'User ID:' label followed by a dropdown menu currently showing 'Admin'. Underneath is a 'Password:' label followed by a text input field. At the bottom left is a 'Log in' button. A vertical text label 'a77ug070' is positioned on the right side of the form.

Figure 2-2. Web User Interface login page

System Status

The **System Status** screen is always present after login giving current status of the library.



The 2U library System Status screen displays the following information:

System Status	
View Legend	
03/28/2007 15:59:24	
Library Name	BOSTON141
Status	✓ Ready
Drive 1 Status	✓ Ready
Slots (Empty/Total)	22/23
I/O Station	Disabled
Library Time	15:59:24

A vertical text label 'a77ug080' is positioned on the right side of the screen.

Figure 2-3. 2U library System Status screen



The 4U library System Status screen displays the following information:

System Status	
View Legend	
03/28/2007 15:27:45	
Library Name	ATLANTA162
Status	✓ Ready
Drive 1 Status	✓ Ready
Drive 2 Status	✓ Ready
Slots (Empty/Total)	42/44
I/O Station	Closed
Library Time	15:27:45
Auto Clean Status	Chk Media/Rsvd Slot?
Power Supply Status	✓ 2 Online

A vertical text label 'a77ug089' is positioned on the right side of the screen.

Figure 2-4. 4U library System Status screen

Status icons indicate the following conditions.

- The green check mark indicates that the library is fully operational and that no user intervention is required.
- The yellow exclamation point indicates that user intervention is necessary, but that the library is still capable of performing operations. This condition can be caused by a media, library, redundant power supply, power supply fan, or a drive sled problem. To determine which, view the System Status screen.
- The red X indicates that user intervention is required and that the library is not capable of performing operations.

- If Auto Clean is enabled and a cleaning cartridge is **not** present, or if a cleaning cartridge is present, but not in a reserved slot, Auto Clean status will show **Chk Media/Rsvd Slot?** and **Status** will show a green check mark and the words **Media Attention**.



Figure 2-5. 4U library System Status screen showing media attention status

- The Power Supply Status will only appear if redundant power is being utilized with a 4U library, and the library was manufactured after March 14, 2008. If a redundant power supply fails, the System Status screen will appear as shown in Figure 2-6.




Figure 2-6. 4U library System Status screen showing a power supply failure

Note: If your library has -04 level redundant power supplies (see label on top of power supply), it is normal for the one in "Standby" mode to turn its "Green" LED off. You can test this power supply by pulling the power connector from the other "Active" power supply. The power supply that was in "Standby" mode will now become "Active", and its "Green" LED should light. If it doesn't, replace it (refer to "Replacing a Power Supply" on page 10-11).

If your library has -05 level redundant power supplies, the "Green" LED will be ON on both power supplies. If both "Green" LEDs are not ON, replace the failed power supply (refer to "Replacing a Power Supply" on page 10-11).

Web User Interface Help Pages

Each screen on the Web User Interface has an associated Help page. To access a Help page, click on **Help** in the upper right corner of the screen. A new web page will open. Using the left navigation pane, select the desired Help page. To close the Help page, click the red **X** in the upper right corner of the screen.

Logging out of the Web User Interface

It is important to log out of the Web User Interface before using the Operator Control panel. To log out of the Web User Interface, click **Logout** in the upper right corner of the current screen.

Important: If you click the **X** in the upper right corner of your internet browser window, you will not log out of the Web User Interface.

Chapter 3. Installation Planning

Before installing your library, take time to review the following information.

Determining the Number of Logical Libraries

You can partition the library into as many logical libraries as there are drives in the library.

Basic Guidelines

- Each logical library must contain at least one drive.
- A library configuration of exactly one logical library equals the entire physical library.
- The library issues a warning to the user if media is moved across logical libraries.

Library Sharing

The library's default configuration allows a single application to operate the library through a single control path. Often, it is advantageous to be able to share a single library between heterogeneous (dissimilar) or homogeneous (similar) applications. Some applications (and some servers) do not allow for sharing a library between systems. Configurations can be created that enable the library to process commands from multiple heterogeneous applications (such as an IBM System p application and a Windows NT[®] application) and multiple homogeneous applications (for example, the same application run by several System p servers).

From the library's Web User Interface or Operator Control Panel, the following actions can be performed:

- Configure the library so that it is partitioned into separate logical libraries that independently communicate with separate applications through separate control paths. This configuration requires no special capabilities from the server or application. (For more information, see "Using Multiple Logical Libraries for Library Sharing" on page 3-2.)
- Configure any single logical library (including the entire physical library) so that it is shared by two or more servers that are running the same application. Depending on the capabilities of the server and application, there are several ways to set up this type of configuration. Three typical ways include:
 - Configuring one server (host) to communicate with the library through a single control path; all other servers send requests to that server through a network. This configuration is used by Tivoli[®] Storage Manager (TSM).
 - Configuring all of the servers to communicate with the library through a single, common control path. This configuration is used in high-availability environments such as IBM's High Availability Clustered Microprocessing (HACMP) and Microsoft's Systems Management Server (SMS) and Clustered Server Environments. Multi-initiator configurations are only supported by certain adapters and independent software vendors (ISVs). Check with your ISV.
 - Configuring a single logical library to communicate with multiple servers through multiple control paths. This configuration requires that control paths

be added (see “Using Multiple Control Paths”). It is used by Backup Recovery and Media Services (BRMS).

Library configuration is not limited to the examples given above. Many configurations are possible, and can be designed according to your business needs. For additional information, refer to your host application documentation.

Using Multiple Logical Libraries for Library Sharing

Multiple logical libraries are an effective way for the library to simultaneously back up and restore data from heterogeneous applications. For example, the library can be partitioned so that it processes:

- Commands from Application A (about Department X) in Logical Library 1
- Commands from Application B (about Department Y) in Logical Library 2

In this configuration, the storage slots and drives in each logical library are dedicated to that library and are not shared among other libraries. Commands issued by the applications travel to the library through two unique control paths. Thus, the data processing for:

- Department X is confined to the storage slots and drives in Logical Library 1
- Department Y is confined to the storage slots and drives in Logical Library 2

Using Multiple Control Paths

In addition to creating multiple logical libraries, any logical library can be configured to have more than one control path. When configuring additional control paths, additional library sharing configurations and availability options are made possible. Access to the logical library is on a first-come, first-served basis and each control path for a logical library can accept commands while the library is in use by another control path. By default, only the first drive in a logical library will be LUN-1 enabled.

Note: Microsoft Windows® 2000 and Microsoft Windows 2003 Removable Storage Manager (RSM) does not support multiple control paths within a logical library. It is recommended that RSM be disabled to use this feature.

For a particular logical library, you can enable as many control paths as there are drives in that logical library.

Using Multiple Control Paths for System i, iSeries, and AS/400 Attachment

The use of control paths for the System i, iSeries, and AS/400 servers is unique. In general, every iSeries adapter must recognize the control path that is associated with the drives to which it is connected. For the iSeries and AS/400 servers, one to six drives are supported by LVD and Fibre Channel adapters and the OS/400® 5.1, OS/400 5.2, or i5/OS 5.3 operating system.

Using Multiple Control Paths for Path Failover

Command failures and timeouts are costly. You want your library to run smoothly and efficiently. To ensure continued processing, the library offers an optional path failover feature that enables the host device driver to resend the command to an alternate control path for the same logical library. With control path failover installed, the alternate control path can include another HBA, SAN, or library control path drive. The device driver initiates error recovery and continues the

operation on the alternate control path without interrupting the application. AIX, HP-UX, Solaris, Linux and Windows 2003 hosts are currently supported for this feature.

The 2U library does not support Control Path Failover and Data Path Failover. As a result, there should be no license key entry for "Path Failover" on the 2U library. Path Failover is a combination of two previous features: Control Path Failover (key entered at the library user interface) and Data Path Failover (key entered at the device driver interface). A single activation key entered at the library user interface now activates both features unless the LTO-3 drive firmware level is equal to or lower than 73P5 and/or the library firmware is equal to or lower than 1.95. For either or both of these two cases, the device driver interface Data Path Failover key activation will still be required. The Path Failover feature is available for select LTO 4 tape drives. Path Failover is not supported for half high drives.

The Path Failover feature can be installed by the customer. For ordering information, see Chapter 11, "Optional Features, Replacement Parts and Power Cords," on page 11-1.

Note: The optional Path Failover feature is not available on TS3200 models purchased through High Volume (HVEC) channels.

For more information about using the path failover feature, see the *IBM Ultrium Device Drivers Installation and User's Guide*.

Library Partitioning and Element Addressing

Library 4U systems with firmware versions of 1.70 and higher, and containing at least 2 drives, have the ability to configure two logical libraries (create two partitions). This partitioning has been expanded with the new library firmware and half-high drive integration. Now it is possible to configure 1, 2, 3 or 4 partitions in the 4U library. Additionally the 2U library can now be configured into one or two partitions. Each library must contain at least one drive per logical library (partition).

Partitioning of 2U Libraries

When two half high drives are installed in a 2U library, the library firmware will support partitioning in the same way that the 4U supports partitioning with two full high drives today. The first partition will contain the first magazine and the first drive. The second partition will contain the second magazine and the second drive. The I/O station (if configured as I/O) will be shared, as is done with the partitioned 4U library.

One full high drive is "Drive 1". When using half high drives, the first half high drive position will be called "Drive 1", The second half high drive position will be called "Drive 2."

Partitioning of 4U Libraries

When one or more half high drives are added to a 4U library, the drive naming will change. Currently, the first full high drive is "Drive 1" and the second full high drive is "Drive 2". When you consider that each full high drive slot may contain one or two half high drives, there are four potential drives in the space that used to occupy two. As a result, the first half high drive position, or the first full-high drive position, will be called "Drive 1". The second half high drive

position will be called "Drive 2". The third half high drive position, or the second full high drive position, will be called "Drive 3". The fourth half high drive position will be called "Drive 4".

Mixing of Drives

The library supports a mix of full high and half high drives in the same physical library and the same logical library. They support a mix of Gen 3 and Gen 4 drives in the same physical library and the same logical library. They will also support a mix of SCSI, SAS, and Fibre Channel in the same physical library and the same logical library; however, mixing drive interface types in the same logical library is not recommended.

Configuration of a 1 - Partition System

A one partition system configured for a 4U library contains any and all drives present in any drive positions, and it will contain all four magazines.




Figure 3-1. Configuration of a one - partition system

Configuration of a 2 - Partition System

A two partition system must have at least two drives installed. One drive must be installed in either drive position 1 or drive position 2, and another drive must be installed in either drive position 3 or drive position 4. Partition 1 contains any drives in drive position 1 and drive position 2. Partition 1 will also contain magazine 1 and magazine 2. Partition 2 contains any drives in drive position 3 and drive position 4. Partition 2 will also contain magazine 3 and magazine 4.




Figure 3-2. Configuration of a two - partition system

Configuration of a 3 - Partition System

A three partition system must have at least three drives installed. A drive must be installed in drive position 1, another drive must be installed in drive position 2, and another drive must be installed in either drive position 3 or drive position 4. Partition 1 contains the first drive and the first magazine. Partition 2 contains the

second drive and the second magazine. Partition 3 contains any drives in drive position 3 and drive position 4. Partition 3 will also contain magazine 3 and magazine 4.




Figure 3-3. Configuration of a three - partition system

Configuration of a 4 - Partition System

A four partition system must have four drives. Each partition contains one drive and one magazine.




Figure 3-4. Configuration of a four - partition system

SCSI Element Addressing

Every logical library starts at the first drive slot with the current assigned element start address (default value 256). It will be incremented from the bottom to the top slots for every drive slot. There is one exception to this addressing scheme to accommodate libraries currently in the field. A 4U library containing only full high drives will continue to have the addresses assignments 256 and 257, thus causing no interruptions to their operation. Drive slots will still be incremented by 1 for each drive slot position.

Note: Exchanging drives with different form factors will result in the library needing to be reconfigured.

4U Unit with only FH drives
(1 logical library)

SCSI Element	Slot
257	4
	3
256	2
	1

4U Unit with FH and HH drives
(1 logical library)

SCSI Element	Slot
258	4
	3
257	2
256	1

a77ug165

Figure 3-5. Examples of SCSI element addressing

The SCSI specification does not allow gaps in the SCSI element addressing. Special handling is needed for empty drive slots to fulfill the specification. Also temporarily removed drives need to have their addresses preserved to not confuse the attached host and host application. Generally only drives which are currently physically available or temporarily removed are reported. Empty (unused) slots located at the bottom or the top should not be reported, with an exception in case of a “removed” condition. A drive slot which does not contain a drive, and has a position between used slots, needs to be reported as a SCSI element. To signal the host application that this slot is not usable, its ACCESS bit will be disabled.

Note: When reducing the number of drives in your library, update the Logical Library configuration. This will remove the Attention LED on the front panel and the exclamation mark on the Home screen indicating that a drive is missing.

Updating the Logical Library configuration will also update the drive element addressing and drive numbering. Replacing LTO half high drives with full high drives may require you to execute Restore Factory Defaults to correctly update the drive element addressing and drive numbering. See “Configure Library: Restore Defaults” on page 5-52.

Using Persistent Binding to Ensure SCSI ID Assignment

When a server is booted, devices are discovered and assigned SCSI target and LUN IDs. It is possible for these SCSI assignments to change between boots. Some operating systems do not guarantee that devices will always be allocated the same SCSI target ID after rebooting. Also, some software depends on this association, so you do not want it to change. The issue of SCSI ID assignment is addressed by persistent binding.

Persistent binding is an HBA function that allows a subset of discovered targets to be bound between a server and device. Implemented by a World Wide Node Name (WWNN) or World Wide Port Name (WWPN), persistent binding causes a tape drive’s WWNN to be bound to a specific SCSI target ID. After a configuration has been set, it survives reboots and any hardware configuration changes because the information is preserved. If a drive needs to be replaced, the new drive

assumes the WWNN of the old drive because the WWNN for the drive is location-dependent within the library. Because the WWNN does not change, persistent binding does not need to be changed thus preventing a potential outage.

Logical Unit Number (LUN) Scanning

The library uses a single SCSI or Loop ID per drive and dual LUNs to control the tape drive (LUN 0) and library accessor (LUN 1). The library requires a Host Bus Adapter (HBA) that supports LUN scanning. If it is not enabled, your host system will not scan beyond LUN 0 and will fail to discover the library. It will only see the tape drive.

Important: Some HBAs, such as RAID controllers, do not support LUN scanning.

Host Interfaces

The 2U library and the 4U library can be attached to servers using the following interfaces:

- SCSI (LVD Ultrium 160)
- Serial Attached SCSI (SAS)
- Fibre Channel

Table 3-1. Host Drive Interface Support

Drive	SCSI (LVD Ultra 160)	SAS	FC
Ultrium 3 FH	X		X
Ultrium 3 HH	X	X	
Ultrium 4 FH	X	X*	X
Ultrium 4 HH		X	
Note: * = Dual Port SAS			

SCSI Interface

Note: Although the LVD hardware in the library is capable of operating in single-ended (SE) mode, SE operation is not recommended.

The library supports SCSI LVD attachments by using SCSI cables with 68-pin, HD-connectors. SCSI adapters must be properly terminated.

Before installing the SCSI cables, inspect all cables for damage. Do not install a cable if it is damaged. Report the damage immediately by contacting your place of purchase.

The maximum allowable length of your bus cabling depends on the type of SCSI bus that you use (LVD).

- For a server with an LVD SCSI bus:
 - Use a maximum system-to-device cable length of 10 m (33 ft) when attaching to the host interface board (SCSI) and one or two daisy-chained drives.
 - Use a maximum system-to-device cable length of 5 m (17 ft) when attaching to the host interface board (SCSI) and three to six daisy-chained drives.

Note: For maximum performance, it is recommended to have a maximum of one drive per SCSI bus.

- Only use the maximum system-to-device cable length of 25 m (82 ft) when attaching directly to one device (a point to point interconnection).

Note: Daisy-chaining is NOT recommended due to potential issues with SCSI bus performance, SCSI cables/connectors, and host bus adapters.

Physical Characteristics of the SCSI Interface

The library operates as a set of SCSI-3 devices. The Ultrium Tape Drives attach to servers using an LVD Ultra160 SCSI interface. Each SCSI drive sled uses shielded, HD68-pin connectors, and can attach directly to a 2-byte-wide SCSI cable.

Any combination of up to two initiators (servers) and up to four targets (devices) is allowed on a single SCSI bus if the following conditions are met:

- The SCSI bus is terminated properly at each end
- Cable restrictions are followed according to the SCSI-3 specification

Under the SCSI-3 protocol, this type of attachment allows cable lengths of up to 25 m (81 ft) with the appropriate cable and terminator. The table below gives the maximum bus length between terminators for the LVD interface. For information about cable connectors, see “SCSI Connectors and Adapters” on page 3-9.

Table 3-2. Maximum bus length between terminators

Type of Interconnection	Maximum Bus Length Between Terminators (in meters)
Point-to-point (1 server and 1 drive)	25
Multi-drop/daisy-chain (1 server and multiple drives)	12 (LVD)
Note: The maximum bus lengths stated in this table include the internal length of the bus.	

For maximum performance, multiple SCSI buses may be required (see “Using Multiple SCSI Buses”), and IBM Ultrium Tape Drives must be the only target devices that are active on the bus.

Note: Daisy-chaining is NOT recommended due to potential issues with SCSI bus performance, SCSI cables/connectors, and host bus adapters.

Note: For maximum performance, the quantity of tape drives that you can attach to one SCSI bus is limited, and is based on the type of bus that you have and the amount of data compression achieved. Ultra160 SCSI buses have a bandwidth of 160 MB per second. The table below lists the types of SCSI buses and gives the recommended maximum quantity of drives that you can attach.

Table 3-3. Recommended maximum quantity of drives per SCSI bus

Type of Drive	Ultra 160 SCSI Bus
LVD Ultrium 3	1 drive at 2:1 compression

Using Multiple SCSI Buses

The library has two SCSI connectors for each tape drive in the library. Each drive can be daisy-chained using a SCSI bus jumper.

Note: Daisy-chaining is NOT recommended due to potential issues with SCSI bus performance, SCSI cables/connectors, and host bus adapters.

Removal of any jumpers will create a SCSI bus for each drive installed in your library for attachment to multiple servers or to multiple SCSI adapter cards on one server. Remember that each SCSI bus must be terminated. Multiple SCSI buses may be required for maximum performance, depending on the application and data compression ratio. Note, however, that library (Medium Changer) control is required on at least one SCSI bus.

The Medium Changer device is required to be addressed via LUN 1 of the lowest-numbered drive position of each logical library. The Medium Changer device may additionally be addressed via LUN 1 of other drives in any logical library.

Any bus containing a Medium Changer device via LUN 1 of a drive is referred to as a control and data path. Any other bus is referred to as a data path. For information about control paths, see “Using Multiple Control Paths” on page 3-2.

Terminating the Bus

The SCSI bus and all of the wires in the SCSI cable must be properly terminated according to the SCSI standard.

You can plug an external terminator into one of the SCSI connectors. A terminator must be installed on the last device on each end of a string of multiple devices. A terminator is included with each SCSI Ultrium Tape Drive.

SCSI Connectors and Adapters

The library is supported by a wide variety of servers (hosts), operating systems, and adapters. These attachments can change throughout the product’s life cycle. To determine the latest supported attachments, visit the web at <http://www.ibm.com/storage/>. Or, contact your IBM Sales Representative.

SCSI Differential - LVD

IBM LVD tape devices support a bus length of 25 meters (82 ft.) point-to-point, and 12 meters (39 ft.) using multi-drop interconnection (daisy-chaining). For each daisy-chained device, the maximum cable length must be reduced by 0.5 meters (1.6 ft).

Important: A faster bus does not imply that an attached device will support that data rate, but that multiple devices can operate on the bus at that maximum speed. For a detailed table of SCSI terms and related specifications, refer to the SCSI Trade Association Web site at <http://www.scsita.org/terms/scsiterms.html>. To ensure best performance, if possible, avoid daisy-chaining.

SAS Interface

A drive sled with a SAS (Serial Attached SCSI) interface can be linked directly to controllers. SAS is a performance improvement over traditional SCSI because SAS enables multiple devices (up to 128) of different sizes and types to be connected simultaneously with thinner and longer cables; its full-duplex signal transmission supports 3.0 Gb/s. Up to four Ultrium 3 or Ultrium 4 single port half high drives or two Ultrium 4 dual port drives can be attached. At the library end, each of four drive sleds or ports can be attached via a SFF-8088 cable to the interposer cable. In addition, SAS drives can be hot-plugged.

SAS drives will auto-negotiate speed. There are no configurable topologies thus no feature switches associated with SAS. The SAS Ultrium 3 and Ultrium 4 Half high drive sleds are single ported and can only be attached to one host. While the Ultrium 4 Full high drive is dual ported and can be attached to a maximum of two hosts, the intention of the second port is for redundancy for failover rather than sharing. Sharing between these two hosts is limited to active/passive cluster failover. LAN-free drive sharing is not supported. Ultrium 3 and Ultrium 4 SAS drive sleds use the SFF-8088 connection at the drive sled end and SFF-8088 or SFF-8470 at the host adapter end. Initially, only point-to-point connections are supported.

Fibre Channel Interface

Fibre Channel allows for an active intelligent interconnection scheme, called a Fabric, to connect devices. Everything between the ports on Fibre Channel is called the Fabric. The Fabric is most often a switch or series of switches that takes the responsibility for routing.

The library allows the selection of the following Fibre channel port behaviors:

- LN Port: (default setting) - an automatic configuration that tries arbitrated loop first, then switched fabric
- L Port - arbitrated loop
- N Port - point to point protocol in a switched fabric topology

Cables and Speeds

Ultrium 3 and Ultrium 4 Fibre Channel tape drives use LC duplex fiber optics cables.

The maximum distances that the library supports on a Fibre Channel link is determined by the link speed, the type of fiber (50-micron or 62.5-micron), and the device to which the library is attached.

If the library attaches to an HBA (Host Bus Adapter), refer to the distances that are supported by the HBA. If the library attaches to a switch, the supported distances are:

- For a 50-micron cable:
 - 1-Gbit link speed = up to 500 m (1640 ft)
 - 2-Gbit link speed = up to 300 m (984 ft)
 - 4-Gbit link speed = up to 150 m (492 ft)
- For a 62.5-micron cable:
 - 1-Gbit link speed = up to 175 m (574 ft)
 - 2-Gbit link speed = up to 150 m (492 ft)
 - 4-Gbit link speed = up to 70 m (230 ft)

Using Zoning to Isolate Devices and Enhance Security

For security reasons, it is important to limit the devices that a server or servers can recognize or access. Also, some performance configurations and SAN configurations can result in a device being seen multiple times from the same server. For example, if you have two HBAs from the same server connected to an Ultrium Tape Drive in the library, the drive will be detected and appear as two logical devices. That is, there will be two special files for one physical device. Zoning can address these issues.

Zoning allows you to partition your SAN into logical groupings of devices so that each group is isolated from the other and can only access the devices in its own group. Two types of zoning exist: hardware zoning and software zoning. Hardware zoning is based on physical fabric port number. Software zoning is defined with a World Wide Node Name (WWNN) or World Wide Port Name (WWPN). While zoning can be reconfigured without causing an outage, some zoning configurations can become complicated. The advantage of the library's WWNN implementation is that you can avoid the exposure of introducing zoning errors because you do not have to change the zoning configuration if a drive needs service or replacement.

Attention: It is recommended that tape storage devices be connected on a separate HBA from disk storage devices to avoid potential configuration incompatibilities.

Fibre Channel Host Environment

The library is supported by a wide variety of servers (hosts), operating systems, and adapters. These attachments can change throughout the product's life cycle. To determine the latest supported attachments, visit the web at <http://www.ibm.com/storage/>.

Sharing on a Storage Area Network

With Storage Area Network (SAN) components, the possibilities for connecting multiple systems and multiple drives have increased. Not all software and systems are designed to share drives. Before you install a drive that would allow two systems to share it, check that the systems and their software support sharing. If your software does not support sharing, note that Fibre Channel switches have a zoning capability to form a SAN partition. For systems that do not cooperate, use zoning to prevent the systems from sharing the same drive. You can remove zoned partitions as you upgrade software and system levels.

Chapter 4. Installation and Configuration

Note: Review the information in "Installation Planning" before installing your library.

The IBM TS3100 Tape Library and TS3200 Tape Library is a customer installed unit. The customer is responsible for the setup and maintenance of the tape library. Customers will be charged for service if a service contract is not in place.

To install a desktop or rack mounted 2U library or 4U library, perform the procedures in this chapter in the order they are presented.

Using the Library Configuration Form

Before beginning the installation and configuration of your library, make a copy of the Appendix G, "Library Configuration Form," on page G-1. Enter library information (such as serial numbers, types of drives, etc.) and configuration settings on the Library Configuration Form and store in a safe location for future reference. Be sure to update this form any time changes are made to your library hardware or configuration.

Installing Your Library

Complete these procedures to install your library hardware.

1. "Choosing a Location."
2. "Unpacking the Library" on page 4-2.
3. "Verifying the Shipment" on page 4-3.
4. "Installing the Library Foot Pads (for Desktop Installation ONLY)" on page 4-4.
5. "Removing and Storing the Shipping Lock" on page 4-5.
6. "Rackmounting the Library (for Rack Installation ONLY)" on page 4-6.
7. "Connecting the Host Interface Cable" on page 4-12.
8. "Connecting a Power Cord" on page 4-14.

Choosing a Location

Choose a location that meets the following criteria:

Table 4-1. Location criteria

Criteria	Definition
Room temperature	10° - 35° C (50° - 95° F) Note: If the temperature in the room where the library will be installed varies by 15° C (30° F) from the room where the library was stored, allow the library to acclimate to the surrounding environment for at least 12 hours before unpacking it from the shipping container.

Table 4-1. Location criteria (continued)

Criteria	Definition
Power source	- AC power voltage: 100-127 VAC; 200-240 VAC (4 - 2 A) Note: The 4U library requires two separate power sources to implement redundant power. - Line frequency: 50-60 Hz Place the library near an AC outlet. The AC power cord is the product's main AC disconnect device and must be easily accessible at all times. Two separate power sources must be available for redundant power.
Air quality	The library should be placed in an area with minimal sources of particulate contamination. Avoid areas near frequently used doors and walkways, stacks of supplies that collect dust, printers, and smoke-filled rooms. Excessive dust and debris can damage tapes and tape drives.
Humidity	15-80 % RH non-condensing
Clearance	- Back: Minimum of 15.4 cm (6 inches) - Front: Minimum of 30.8 cm (12 inches) - Sides: Minimum of 5.08 cm (2 inches)
Rack requirements	Standard 19-inch rack with: 2U (88.90 mm/3.5 in.) of clearance for a 2U library 4U (177.8 mm/7 in.) of clearance for a 4U library Rackmounting the library is optional.

Unpacking the Library

1. Clear a work surface to unpack the library.
2. Before opening and removing the library from the shipping container, inspect the container for shipping damage. If you notice any damage, report it to the shipping company immediately.
3. Open the shipping container and carefully remove the shipping materials from the top of the library. Remove the accessory package and set it aside.

Note: Once the drive is unpacked, **save and store** the packaging materials for future moves or shipping. If you discard the original packaging materials, you may need to purchase packaging materials if you wish to move or store your library. **Read Me** documentation may be found with the packaging material, containing updated and important unpacking instructions.

4. Lift the library out of the carton and remove the bag from the library. Remove the foam cushion from the back of the library. Save the packaging materials for future use.

Important: Do not place the library on the front panel or the rear panel as this may damage the library. The display should NOT be touched during the removal of the unit from the packaging.

5. Remove all clear plastic protective sheets from the library.



Figure 4-1. Removing the plastic protective sheets from the library

Verifying the Shipment

Verify that the following items are included in your library shipment:

- With every library:
 - Power cord
 - Foot pads (for desktop installation)
 - Documentation CD:
 - Setup, Operator, and Service Guide
 - Translated Safety Notices
 - Statement of Limited Warranty (in 29 languages)
 - IBM License Agreement for Machine Code
 - Installation Quick Reference
 - Warranty information (in 9 languages)
 - Quality Hotline card
- With every library containing a SCSI drive:
 - SCSI terminator (one per SCSI drive)
 - SCSI library-to-host cable (if ordered by customer)
 - SCSI Wrap tool (one for each library)
- With every library containing a Fibre Channel drive:
 - Fibre wrap tool (one per library)
 - Fibre Channel library-to-host/switch cable (if ordered by customer)
- With every library containing a SAS drive:
 - SAS library-to-host cable (if ordered by customer)
 - SAS Wrap tool (one for each library)
- Optional item that is included in your shipment, if ordered:
 - Rack Mount Kit

Important: If any of the contents of your shipment are damaged or missing, please call the appropriate number listed on the Quality Hotline card.

Installing the Library Foot Pads (for Desktop Installation ONLY)

If you intend to install your library in a rack, skip this step and proceed to “Removing and Storing the Shipping Lock” on page 4-5.

Important: Operating your library on a flat surface without foot pads may damage your library or cause it not to function properly.

Six foot pads must be installed on the bottom of the library before the library can be used as a desktop unit.

To install the library foot pads:

1. Being very careful, lay the library on its side.
2. Peel the adhesive from the back of each foot pad.
3. Install the foot pads on the bottom of the library enclosure by pressing each foot into one of the six areas (**1**) as shown in the figure below.




Figure 4-2. Installing foot pads on the bottom of the library enclosure

4. Carefully return the library to an upright position.

Important: Do not place any objects on top of the library.

Removing and Storing the Shipping Lock

Important: The shipping lock, which prevents the library accessor from moving during shipment, **must be removed before the library is powered ON.**

The shipping lock is held in place with a label and is located in the top center of the library. After the shipping lock is removed, it should be stored on the right side of the back panel of the library for future use.

To remove and store the shipping lock:

1. Remove the blue label (**2**) that is securing the lock (**1**) to the top of the library, then remove the lock (see Figure 4-3).



Figure 4-3. Shipping lock and label




Figure 4-4. Removing the Shipping lock and label

2. Store the lock (1) and label (2) on the rear panel of the library as shown in Figure 4-5.



Figure 4-5. Library shipping lock and label storage location on rear panel of library

Rackmounting the Library (for Rack Installation ONLY)

Attention: If you haven't removed the shipping lock, complete this first before rackmounting your library. See "Removing and Storing the Shipping Lock" on page 4-5.

The 2U library and the 4U library are easily installed into a standard 19-inch rack system. A standard 19-inch rack system contains multiple mounting locations

called EIA units as defined by the Electronics Industries Association. Each EIA unit contains three square or round holes used to mount rack designed equipment. These units are often referred to as "U"s, thus the 2U library requires 2 EIA units (or 6 holes) of space; the 4U library takes 4 EIA units (or 12 holes) of space. Each unit is separated by a very small space. See Figure 2-5 for an example of how to count EIA units. The 2U library requires 2U (3.5 in.) of space. The 4U library requires 4U (7 in.) of space.

Important: A 2U library weighs 15.59 kg (34.37 lbs.) with one drive and without media. A 4U library weighs 21.32 kg (47 lbs.) with one drive and without media.

To reduce the risk of personal injury or damage to the library:

1. observe local health and safety requirements and guidelines for manual material handling,
2. obtain adequate assistance to lift and stabilize the library during installation or removal, and
3. always remove all cartridges to reduce the overall weight of the library.

To install your library in a rack, perform the following steps.

1. Verify that your rack kit includes the following contents (see Figure 4-6 on page 4-8):

- Packaged in plastic material:

- Two (2) rails (not shown)
- Two (2) mounting brackets (**1**)

- Packaged in the small bag with no label:

- One (1) T10 Torx wrench (**5**)
- Two (2) anchors (**4**)
- Two (2) countersunk screws for securing the anchors (**6**)
- Two (2) smaller screws for securing the tops of the mounting brackets (**7**)
- Two (2) large screws to secure the mounting brackets to the rack (**8**)

- Packaged in the small bag with "Round Hole" on the label: Nine (9) screws to be used on racks with round holes. (**2**)

- Packaged in the small bag with "Square Hole" on the label: Nine (9) screws to be used on racks with square holes. (**3**)

Note: Eight (8) screws are needed for the installation. One additional screw is provided for security.




Figure 4-6. Rack Kit mounting hardware

2. Determine the location in your rack for your library to be installed and, using a pencil, mark the location on each vertical rail in your rack.

Note: A 2U library requires 2U (3.5 in.= two EIA) of rack space. A 4U library requires 4U (7 in. = four EIA) of rack space




Figure 4-7. Examples of EIA units for round hole and square hole installations

1	Two EIA units for round hole and square hole installation	3	Wide Gaps within the EIA unit
2		4	Narrow Gaps between EIA units

3. Remove the adhesive security tape on the backside of the rails. Using the screws for your rack type (round holes or square holes) and a #2 Phillips

screwdriver and ensuring that the flange on each rail points toward each other to form a shelf, secure one rail to each side of the rack in your chosen rack location. Secure both the front and back of each rail to the rack, then tighten all 8 screws. The narrow end of each rail goes to the rear of the rack. The rails extend to fit a variety of rack depths. Each rail requires 2 EIA units of rack space (**1** in Figure 4-8).




Figure 4-8. Rear view of a rack showing the narrow part of the rail




Figure 4-9. Front view of a rack showing the rails installed

4. Using the Torx wrench included in your shipment, remove the screws (**1**) as shown in Figure 4-10 on page 4-10. Screw locations on the 4U library are similar.




Figure 4-10. 2U library side screws to remove

5. Install the library rack anchors (**2**) as shown in Figure 4-11 on each side of your library using the longer counter-sunk screws included in the rack kit.




Figure 4-11. 2U library rack anchors and mounting brackets

6. Install the library mounting brackets (**1**) as shown on the 2U and 4U library on each side of the library using the screws removed from your library and additional short, counter-sunk screws included in the rack kit.
7. With library rack anchors and mounting brackets installed, slide the library onto the rails (as shown in Figure 4-12 on page 4-11 and Figure 4-13 on page 4-11). When the library stops, gently push the library to lock the anchors installed on each side of the library to the rails and until the mounting brackets are flush with the vertical rack rails.



Figure 4-12. Sliding the 2U library into the rack



Figure 4-13. Sliding the 4U library into the rack


8. Using thumbscrews, secure the library to the rack (see Figure 4-14 on page 4-12 for a 2U library; see Figure 4-15 on page 4-12 for a 4U library) by placing a screw in the center hole of each mounting bracket and tightening them (**1**).



1

a77ug112

Figure 4-14. Securing the 2U library to the rack



1

a77ug110

Figure 4-15. Securing the 4U library to the rack

Connecting the Host Interface Cable

To connect the host interface cables to the library:

1. It is recommended that you shut down and turn OFF the associated server. Turn OFF all attached devices. Remove the power cables from the server and all attached accessories.

Important: Failure to remove the power cords from these devices before connecting the host interface cable could result in damage to the library.

2. For a SCSI library, attach one end of the host interface cable to one of the connectors on the back panel of the library (**1**). For a Fibre Channel library, attach one end of the host interface cable to the connector on the back panel of the library (**4**). For a Serial Attached SCSI (SAS) connected library, attach the host end of the SAS cable to the SAS or Mini-SAS (SFF-8088) HBA (**2**). Full high drives will have dual SAS or Mini-SAS connectors. Half high drives will have one SAS connector. Unused SAS connectors do not need to be terminated.




Figure 4-16. Attaching SCSI ([1]), Fibre Channel ([4]), and SAS ([2]) cables to the 4U library.

3. Attach the other end of the host interface cable as follows:
 - For a SCSI library, connect the host interface cable to the connector on the SCSI host bus adapter or to the connector on the previous device on the SCSI bus. Attach the terminator (**3** in “Connecting the Host Interface Cable” on page 4-12) to the remaining SCSI connector on the back panel of the library, if the library is the last or only device on the SCSI bus. Otherwise, attach one end of a SCSI cable to the remaining port and the other end to the next device on the SCSI bus. Make sure that the last device on the SCSI bus is properly terminated.

Note: Cables and terminators supporting Ultra160 should be used.

Note: The host bus adapter should be LVD SCSI. A single-ended (SE) SCSI host bus adapter will work, but will severely degrade performance, and limit cable length. If there are any SE devices on the same SCSI bus, the entire SCSI bus will negotiate down to SE speed and severely degrade performance.

- For a Fibre Channel library, connect the host interface cable to the host or to a switch. If an SC-to-LC interposer is required, refer to “Installing a Fibre Channel Interposer (Feature Code 5096)” on page 4-14.
- For a SAS library, connect the drive using a host interface cable to the host HBA, or to an interposer as required. You can connect to either ports if you have a dual port configuration. Unused SAS connectors do not need termination.

4. Plug the network ethernet cable (**5** in “Connecting the Host Interface Cable” on page 4-12) into the ethernet port on the back panel of the library. If the ethernet connection is directly attached to a server or laptop, a crossover ethernet cable may be required.

Note: It is the customer’s responsibility to supply the crossover ethernet cable if one is required.

Installing a Fibre Channel Interposer (Feature Code 5096)

For a list of supported adapters and required interposers, go to the Technical Support section on the web at <http://www.ibm.com/storage/>.

To install the interposer, refer to the procedure below.




Figure 4-17. Interposer installation

1. Connect the host SC fibre cable to the matching side of the interposer.
2. Connect the drive LC fibre side of the interposer to the drive/library.

Connecting a Power Cord

Attention: This product can ONLY be used with an approved power cord for your specific geographic region. Use of an unapproved power cord may result in:

- not meeting individual country specific safety requirements;
- overheating with potential personal injury and/or property damage; and
- a fracture resulting in the internal contacts being exposed, which potentially could subject the user to a shock hazard.

For every power supply in the library, complete the following steps.

1. Remove the protective label from the power receptacle on your library.



Figure 4-18. Removing the protective label from the power receptacle

2. Plug one end of the power cord (4 in “Connecting the Host Interface Cable” on page 4-12) into each power supply connector on the back panel of the library.
3. Plug the other end of each power cord into the nearest properly grounded power outlet. Use separate power sources for each power supply for redundant power.
Attention: To disconnect all power from the library, remove the power cord from each outlet. The power button removes power from portions of the library and the drives, but the power supplies still have AC power at their inputs.
4. Remove the protective plastic on the exterior surfaces of the library.
5. Turn ON the library using the power button. Check the Operator Control Panel display to make sure the library is receiving power. If it is not, check the power connections and your power source. During the Power-On Self Test (POST), all four LEDs are illuminated briefly, followed by a flashing Ready LED. When the initialization sequence is complete, the Home screen (see “Power-ON Display” on page 2-2) will be displayed.

Configuring Your Library

Note: Review the information in “Installation Planning” before configuring your library.

The library can be configured using the Operator Control Panel and/or the Web User Interface. The recommended method for configuring your library is using the Web User Interface.

For complete detailed configuration information on all of the functions available on your library using both the Operator Control Panel and the Web User Interface, see Chapter 5, “Operations,” on page 5-1. For default library settings, see “Configure: Restore Defaults” on page 5-25

Choosing Your Configuration Method

If you choose to use the factory defaults for your library configuration, go to “Using Factory Defaults as Your Configuration” on page 4-16.

If you choose to use the Web User Interface for configuring your library, go to “Configuring Your Library using the Web User Interface” on page 4-16.

If you choose to use the Operator Control Panel for configuring your library, go to “Configuring Your Library using the Operator Control Panel” on page 4-33.

Using Factory Defaults as Your Configuration

The table below shows the main default library settings. If you wish to use the defaults, no other changes need to be made before using your library

Item	Default Setting
Logical Libraries	1
Active Slots	Maximum
I/O Slots	Enabled
DHCP	Enabled
Internet Protocol	IPv4 Only
Bar Code Label Length	8
Library Mode	Random
AutoClean	Disabled
Encryption	None
IPv6 Stateless Autoconfig	Off

For a full list of factory defaults, see “Configure: Restore Defaults” on page 5-25.

Configuring Your Library using the Web User Interface

To configure your library using the Web User Interface, complete the following procedures:

1. “Establishing Remote Access to Your Library” on page 4-17
2. “Logging on to the Web User Interface” on page 4-18
3. “Verifying/Updating Firmware” on page 4-19
4. “Choosing General Library Settings” on page 4-20
5. “Choosing the Number of Logical Libraries for Your Library” on page 4-21
6. “Entering Path Failover Feature Activation Key” on page 4-22
7. “Setting Up Encryption” on page 4-23
8. “Choosing Drive(s) Interface Identification/Settings” on page 4-25
9. “Entering Library Network Settings” on page 4-26
10. “Entering User Access Information using the Web User Interface” on page 4-29
11. “Entering Date and Time using the Web User Interface” on page 4-30
12. “Configuring Logs and Traces using the Web User Interface” on page 4-30
13. “Entering Event Notification Information using the Web User Interface” on page 4-31
14. “Running Key Path Diagnostic for Testing Encryption Configuration” on page 4-32
15. “Restoring Factory Default Settings using the Web User Interface” on page 4-32
16. “Logging out of the Web User Interface” on page 2-8
17. “Setting the Operator Control Panel Access PIN using the Operator Control Panel” on page 4-32

Establishing Remote Access to Your Library

Static library network settings must be entered using the Operator Control Panel before the library can be accessed remotely using the Web User Interface. If your system is serviced by DHCP (Dynamic Host Configuration Protocol) server, the network parameters will be automatically set. Once remote access has been established, you can complete the configuration of your library using the Web User Interface.

1. Access the **Configure** menu using the Operator Control Panel.
 - a. From the screen that shows the library logo (Home screen), press either the UP or DOWN button to get to the Main Menu.
 - b. Press the DOWN button to select **Configure**.
 - c. Press the SELECT button to display the **Configure** menu.
2. Press the DOWN button to highlight the **Network** menu.
3. Press the SELECT button to display the **Network** screen.
4. Select IP STACK to change Internet Protocols. Choose **IPv4 only**, **IPv6 only**, or **IPv4 & IPv6**.
5. If you do **not** want to select DHCP as your library network setting, skip this step and proceed to the next step. If you want to select DHCP as your library network setting, complete the following steps:
 - a. Press the SELECT button to highlight the **DHCP** field.
 - b. Press the DOWN button to select **ON**.
 - c. Press the SELECT button to apply your selection.
 - d. Skip to Step 7.
6. Press the DOWN button to select **IP Address**. For IPv4 only, enter only an IPv4 address. For IPv6 only, enter only an IPv6 address. For IPv4 & IPv6, enter an IPv4 address and an IPv6 address.
 - a. Press the SELECT button to highlight the **IP Address** field.
 - b. Press the UP or DOWN button to select the digit(s) of your library's IP Address.
 - c. Press the SELECT button to highlight the next digit(s) in your IP Address.
 - d. After entering the final digits, press the SELECT button to apply your entries.
7. Press the DOWN button to select **Netmask**. For IPv4, enter only an IPv4 Netmask address. For IPv6, enter only an IPv6 Netmask address. For IPv4 & IPv6, enter both IPv4 and IPv6 Netmask addresses.
 - a. Press the SELECT button to highlight the **Netmask** field.
 - b. Press the UP or DOWN button to select the digit(s) in your library's Netmask address.
 - c. Press the SELECT button to highlight the next digit(s) in your library's Netmask address.
 - d. After entering the final digit(s) in your Netmask address, press the SELECT button to apply your entries.
8. Press the DOWN button to select **Gateway**. For IPv4, enter only an IPv4 Gateway address. For IPv6, enter only an IPv6 Gateway address. For IPv4 & IPv6, enter a Gateway address for both IPv4 and IPv6.
 - a. Press the SELECT button to highlight the **Gateway** field.
 - b. Press the UP or DOWN button to select the digit(s) in your library's Gateway address.

- c. Press the SELECT button to apply your entries.
9. Press the DOWN button to select **Ethernet**.
 - a. Press the DOWN button to highlight the Ethernet field.
 - b. Press the SELECT button to change the Ethernet setting.
 - c. Press the DOWN button to select a new setting.
 - d. Press the SELECT button to apply the new setting.
 - e. Press the DOWN button and select one of the following:
 - **Save** - to apply your new configuration.
 - **Cancel** - to cancel all of your entries and leave the settings as they were.
10. Press the CANCEL button until the Home screen displays.
11. Press the CANCEL button to return to the home screen.
12. Power cycle the library to initialize your configuration.

Logging on to the Web User Interface

To complete the configuration of your library using the Web User Interface, follow the steps below.

1. Return to the Home screen on the Operator Control Panel.
2. On your host computer, open an Internet browser.
3. In the browser address field, enter your library's IP Address.
 - a. For DHCP, use the Operator Control Panel to determine the IP Address assigned to your library. Navigate to **Monitor** → **Library** → **Identity**. Scroll down to IP Address and make note of the address. Enter the IP Address in your internet browser address field to access your library with the Web User Interface.
 - b. For IPv4, enter your library's static IP Address using the 0.0.0.0 format (four octets).
 - c. For IPv6, enter your library's static IP Address or Router Assigned IP Address using the following format: http://[0:0:0:0:0:0:0:0]. To determine your Router Assigned IP Address, navigate to **Monitor** → **Library** → **Network** on the Operator Control Panel. For the IPv6 Router Assigned Addresses to be displayed on the Operator Control Panel, the Network must be configured to IPv6 Only and the Stateless Autoconfig on the must be set to ON.
 - d. For Dual Stack IPv4 + IPv6, enter your library's information for both IPv4 and IPv6.
4. When the login screen appears,
 - a. Select **admin** for a User ID.
 - b. Enter **secure** for a Password.




Figure 4-19. Log in screen on the Web User Interface

Verifying/Updating Firmware

It is important to run the latest level of firmware. To ensure that you are running the latest levels of library firmware, drive firmware, and SNMP MIB (Management Information Base) file, complete this procedure.

1. Verify the SNMP MIB file currently installed on your SNMP server. Verify the levels of library and drive firmware currently installed on your library by completing the following steps:
 - a. Expand **Monitor Library** in the left navigation pane of the Web User Interface.
 - b. Click **Library Identity** and make note of the Firmware revision.
 - c. Click **Drive Identity** and make note of the Firmware revision.
 - d. Log out of the Web User Interface.
2. Download the latest library firmware, drive firmware, and SNMP MIB (Management Information Base) file from the IBM web site.
 - a. Enter <http://www.ibm.com/storage/support/> in your internet browser address field and press **Enter** on your keyboard.
 - b. Select **Tape Systems** from the **Product Family** list, then select **TS3100 Tape Library** or **TS3200 Tape Library** from the **Product** list.
 - c. Click the **Download** tab, then click **Firmware**.
 - d. Click **TS3100 Tape Library Firmware** or **TS3200 Tape Library Firmware**.
 - e. Compare the firmware level available on the web to those that you made note of in step 1. If you are running the latest levels of library and drive firmware, proceed to the next step. If you are not running the latest levels of library and drive firmware, download the firmware that needs to be updated to your library host.
3. Update library and drive firmware on your library, if necessary.
 - a. Enter the IP Address of your library in your internet browser address field and press **Enter** on your keyboard.
 - b. Log in to your library's Web User Interface.
 - c. Expand **Service Library** in the left navigation pane of the Web User Interface.
 - d. Click **Upgrade Firmware**.
 - e. Browse to the new firmware level on your host, then click **Update**. Do this for both library and drive firmware, if necessary.
4. Install the MIB file on your SNMP server. Refer to your server application documentation for instructions.

Choosing General Library Settings

If your library contains only one drive or logical library, both general and specific settings will be combined into one table (see Figure 4-20 on page 4-21).

1. Expand **Configure Library** in the left navigation pane of the Web User Interface.
2. Click **General** and enter the following:
 - **Library Name** - Enter a name for your library.
 - **Library Mode** (select one of the following per logical library):
 - **Random:** In random mode, the library allows the server's (host's) application software to select any data cartridge in any order.
 - **Sequential:** In sequential mode, the library's firmware predefines the selection of the cartridges. After initialization, the firmware causes the library to select the first available cartridge found (counting from the I/O Station through the last slot in your library) for loading into the drive.

Important: If a Logical Library in Sequential Mode contains more than one drive, only the first drive in the Logical Library will be utilized.

- **Autoload:** Sequential mode with autoload mode ON loads the first available cartridge (slot with the lowest numerical value that contains a cartridge) automatically if the library powers ON with an empty drive.
- **Loop:** Sequential mode with loop mode ON loads the cartridge in the lowest numerical slot after the cartridge in the highest numerical slot has been filled and sent back to its home slot. This allows endless backup operations without user interaction.
- **Active Slots** - Select the number of active slots you would like to assign in your library. This item will affect the number of **Res. (Reserved) Slots** in your library. For more information refer to "Configuring I/O Stations and Reserving Slots" on page 5-60.

Note: Slots can be reserved so that they are invisible to the host. It may be necessary to reserve slots in order to match the number of available slots to the ISV software licensing. Slots will be reserved starting with the highest element address. If your library does not have a dedicated cleaning cartridge slot, and you desire to enable Auto Clean, you must designate a reserved slot which can be used to hold the cleaning cartridge.

- **I/O Station Enabled** - If checked, the I/O Station is enabled. If not, the first 3 slots (in a 4U library or the 1st slot in a 2U library) are configured as storage. See "Configure Library: General" on page 5-41.
- **Auto Clean Enabled** - Automatically cleans drive when drive requests cleaning **and** cleaning cartridge is present in a reserved slot or a dedicated cleaning slot. All cleaning cartridges must have **CLN** as part of the bar code. The Universal Cleaning Cartridge has the bar code label CLNUxxLx.
- **Bar Code Label Length Reported to Host** - Choose between 6 and 8. With 6, the first six characters of the cartridge VOLSER (Volume Serial Numbers) will be reported to the host. With 8, All characters in the VOLSER (first six characters plus the two character media type identifier) will be reported to the host. For more information on bar code labels, see "Bar Code Label" on page 6-5.
- Click one of the following:

- **Refresh** - Click this button to update the current screen.
- **Apply Selections** - Click this button to submit the changes made to the screen.

General	
Library Name	
Library Mode	☒ Random ☐ Sequential ☐ Autoload ☐ Loop
Active Slots	23 ▼
I/O Station Enabled	☒
Auto Clean Enabled	☐
Barcode Label Length Reported To Host	8 ▼

a77ug066

Figure 4-20. The 2U library Configure Library: General screen

General	
Library Name	
I/O Station Enabled	☒
Auto Clean Enabled	☒
Barcode Label Length Reported To Host	8 ▼

Extended Configuration for Logical Libraries	
Logical Library 1	
Library Mode	☒ Random ☐ Sequential ☐ Autoload ☐ Loop
Active Slots	21 ▼
Logical Library 2	
Library Mode	☒ Random ☐ Sequential ☐ Autoload ☐ Loop
Active Slots	23 ▼

a77ug094

Figure 4-21. Example: The 4U library Configure Library: General screen

3. If your library has more than one drive, proceed to “Choosing the Number of Logical Libraries for Your Library.” If your library has one drive, proceed to “Entering Path Failover Feature Activation Key” on page 4-22.

Choosing the Number of Logical Libraries for Your Library

Note: Review the information in “Determining the Number of Logical Libraries” on page 3-1 before completing the procedure in this section.

If you have a 2U or 4U library with only one drive, or do not wish to partition your library, proceed to the next section, “Entering Path Failover Feature Activation Key” on page 4-22.

One cartridge magazine cannot be assigned to two logical libraries. If you partition a multi-drive library, each of the magazines must be assigned to a logical library on a magazine boundary. The entire magazine must be part of one logical library only.

Note: If you have a 2U library with two drives, you have the capability to have two logical libraries.

In a fully populated 4U library with four half high drives and four logical libraries, resource assignments will be as follows:

- Logical Library 1 will contain Drive 1 and the lower left cartridge magazine.
- Logical Library 2 will contain Drive 2 and the upper left cartridge magazine.
- Logical Library 3 will contain Drive 3 and the lower right cartridge magazine.
- Logical Library 4 will contain Drive 4 and the upper right cartridge magazine.

Note: For more information about various configurations, see “Library Partitioning and Element Addressing” on page 3-3.

The I/O Station and slots reserved for cleaning cartridges, if any, are shared among all logical libraries.

1. Click **Logical Libraries** in the left navigation pane.




Figure 4-22. The 4U library Configure Library: Logical Libraries page

2. Select the number of logical libraries you would like to create in your library.
3. Click **Submit** to create the logical libraries.

Entering Path Failover Feature Activation Key

Path Failover is a combination of two previous features: Control Path Failover (key entered at the library user interface) and Data Path Failover (key entered at the device driver interface). The Path Failover feature is available for select LTO 4 tape drives. Path Failover is not supported for half high drives.

1. Click **Path Failover** in the left navigation pane.



Figure 4-23. The Configure Library: Path Failover Feature Activation screen

2. Enter the Control Path Failover 12-digit feature key in the spaces provided.

Note: A single activation key (available by purchasing Feature Code 1682) entered at the library user interface now activates both features unless the LTO-3 drive firmware level is equal to or lower than 73P5 and/or the

library firmware is equal to or lower than 1.95. For either or both of these two cases, the device driver interface Data Path Failover key activation will still be required.

3. Click **Activate** to save the feature key. The following screen will display if you have correctly entered the feature key.




Figure 4-24. Feature Key verification screen

Setting Up Encryption

Note: Application Managed Encryption (AME) does not require a key. Library Managed Encryption (LME) and System Managed Encryption (SME) require a license key which is available by purchasing Feature Code 5900.

Prerequisites for Application Managed Encryption:

- SAS and Fibre Channel LTO Ultrium 4 Tape Drive (Full High or Half High)
- Ultrium 4 Tape Cartridge
- Library firmware level 4.0 or higher
- Drive firmware level 74H4 or higher
- Encryption Key Manager application

Prerequisites for Library Managed Encryption and System Managed Encryption:

- Feature Code 5900 (Transparent LTO Encryption)
- SAS and Fibre Channel LTO Ultrium 4 Tape Drive (Full High or Half High)
- Ultrium 4 Tape Cartridge
- Library firmware level 4.0 or higher
- Drive firmware level 74H4 or higher
- Encryption Key Manager application

Setting a Drive's Method of Encryption

1. Click **Encryption (Configure Library → Encryption)** in the left navigation pane.

Encryption is not supported for this Logical Library!

Encryption		
Feature Activation Key		- -

a77ug199

Figure 4-25. Feature Activation Key screen

2. On the **Encryption** screen, enter the **Feature Activation Key** to make available the library managed and the system managed encryption options.
3. Click **Activate** to save the key and expand the screen for additional encryption settings.

Encryption		
Feature Activation Key	Encryption is currently licensed on this library.	
Enable SSL for EKM	☐	
Encryption Setting for Logical Library 1		
Encryption method	None ▼	
Encryption policy	Encrypt All ▼	
EKM Server Setting		
Primary IP address (IPv4)	0.0.0.0	IPv4 address or Host name and domain
Primary TCP port	3801	
Secondary IP address (IPv4)	0.0.0.0	IPv4 address or Host name and domain
Secondary TCP port	3801	
Advanced Encryption Settings (for Engineering Support use only)		
Encryption method	No Advanced Setting ▼	
Encryption policy	No Advanced Setting ▼	
Encryption density	No Advanced Setting ▼	
Encryption key path	No Advanced Setting ▼	

a77ug150

Figure 4-26. Configure Library: Encryption Activation screen

4. Select **Enable SSL for EKM** to enable Secure Sockets Layer for the Encryption Key Manager application.
5. Select an **Encryption method** for each logical library.
 - Without an encryption license key, select **None** or **Application Managed Encryption**.
 - With an encryption license key, select **Library Managed Encryption** or **System Managed Encryption**.
6. Select an **Encryption policy** for each logical library.
 - **Encrypt All**: This is the default policy. It encrypts all cartridges using the default data keys specified in the EKM. This setting applies to all drives in a 3573 logical library.
 - **Internal Label - Selective Encryption**: This policy is based on the internal volume label information. Currently, the only application that supports this

option is Symantec NetBackup. It only encrypts cartridges with pool identifiers between 1500 and 9999 (inclusive), using keys specific to each pool. Labels for these keys are generated by the tape drive based on the pool identifier; for instance, key label IL_NBU_1505 would be generated for a cartridge in pool 1505.

- **Internal Label - Encrypt All:** This policy is based on the internal volume label information. Currently, the only application that supports this option is Symantec NetBackup. It encrypts all cartridges. Cartridges with pool identifiers between 2000 and 65535 (inclusive) are encrypted with keys specific to each pool. Labels for these keys are generated by the tape drive based on the pool identifier; for instance, key label IL_NBU_2505 would be generated for a cartridge in pool 2505.
7. A primary and secondary EKM server can be set for each logical library. Each partition has its own Encryption and EKM settings. Maintaining primary and secondary EKM servers is desired for maximum availability of encrypted backup and recovery. These settings are required for Library Managed Encryption only. Enter the **EKM Server Setting** information.
 - **Primary IP address (IPv4 or IPv6):** Enter the IP address of the primary EKM server.
 - **Primary TCP port:** After entering the Primary IP address, the library will automatically set the value of the Primary TCP port.
 - **Secondary IP address (IPv4 or IPv6):** Enter the IP address of the secondary EKM server.
 - **Secondary TCP port:** After entering the **Secondary IP address**, the library will automatically set the value of the **Secondary TCP port**.

Note: The Default Port for TCP (SSL disabled) is **3801**. The Default Port for SSL is **443**. These values are the default values set by the library. They can be changed depending on the user configuration but the user has to make sure they match the EKM properties file.

Note: The Advanced Encryption Settings are for Engineering Support only.

8. Click **Activate** to apply the changes.
9. Record the Feature Activation Key (or apply one of the labels) on the Appendix G, "Library Configuration Form," on page G-1 for future reference. **It is important to save your extra Feature Activation Key labels in a secure location for future reference.**
10. Install the Encryption Key Manager (EKM) application on your host. Refer to the EKM documentation for detailed instructions (refer to the EKM documents listed in "Related Publications").

Choosing Drive(s) Interface Identification/Settings

1. Click **Drives** in the left navigation pane.

Drives	
Drive 1 (Logical Library 1)	☒ Power On ☒ Control Path Note: SAS drives do not require user configuration
Drive 2 (Logical Library 2)	☒ Power On ☒ Control Path
SCSI ID	6 ▼
Drive 3 (Logical Library 3)	☒ Power On ☒ Control Path
Port A Configuration	
Speed	Automatic ▼
Port Type	LN-Port ▼
Loop ID	6 ▼
Port B Configuration	Port not available

a77ug095

Figure 4-27. The Configure Library: Drive screen

2. Select the desired settings for each drive listed (either SCSI, SAS, or Fibre Channel). See Figure 4-27.
3. Click one of the following:
 - **Refresh** - to update the current screen
 - **Submit** - to apply the changes made to the screen

Note: If you have a Fiber Channel Drive connected to an AS/400 Host, direct attached to the Fiber HBA, set the Port Type to L-Port.

Entering Library Network Settings

This page shows the current network configuration of the library and allows modification to the configuration. When a change is requested, a pop-up box checks to confirm the changes.

1. Click **Network** in the left navigation pane, to display the **Network** page.

Network	
Protocol Stack	IPv4 only ▼
Host Name	LIB1006DD
Domain Name	
DNS Primary	0.0.0.0
DNS Secondary	0.0.0.0
Enable SSL For Web	☐
Ethernet Settings	Auto ▼
IPv4	
Enable DHCP	☐ On
Static Address	9.11.219.139
Network Mask	255.255.255.0
Gateway address	9.11.219.1
IPv6	
Enable DHCP	☐
Enable Stateless Auto Config	☐
Static Address	0:0:0:0:0:0:0:0
Prefix length	64
Gateway address	0:0:0:0:0:0:0:0
SNMP	
Enabled	☐
Target 1 - IP Address	0.0.0.0
	IPv4 address or Host name and domain
Version	SNMPv1 ▼
Target 2 - IP Address	0.0.0.0
	IPv4 address or Host name and domain
Version	SNMPv1 ▼
Target 3 - IP Address	0.0.0.0
	IPv4 address or Host name and domain
Version	SNMPv1 ▼
Community Name	public
Security User Name	initial
You will be required to login again if changes are made, except of changing snmp settings. If you change the IP address of the library then you will need to use the new IP address when you attempt to access the library again. Refresh Submit	

Figure 4-28. Configure Library: Network Page

2. Select a **Protocol Stack** - Choose **IPv4 only**, **IPv6 only**, or **Dual Stack IPv4 & IPv6**.

If you choose **Dual Stack IPv4 & IPv6**, you must be prepared to enter both IPv4 and IPv6 IP addresses. The sections below will gray out depending on the choices made here.

Note: When changes are made, the following Warning message will appear when the Submit button is clicked.

Warning: Changes Will Take Effect After A Reboot!

Figure 4-29. Warning Screen

The library must be rebooted or the changes will not take place.

3. Enter the **Host Name**.
4. Enter the **Domain Name**.
5. **DNS Primary** - Enter the IP address of your primary DNS server.
6. **DNS Secondary** - Enter the IP address of your secondary DNS server.
7. **Enable SSL for Web** - If you desire to have SSL (Secure Sockets Layer) enabled, place a check in this box.

Note: If you get a security certificate alert when logging in to the Web User Interface, you can install the certificate or allow an exception (depending on the internet browser you are using). SSL is enabled when the URL begins with **https://** and some browsers will show a lock.

8. **Ethernet Settings** - You can disable Ethernet settings, manually enable them, or let another machine enable them by using Dynamic Host Configuration Protocol (DHCP). You can also set a specific speed for the Ethernet port or specify the library to automatically negotiate the speed. Ethernet Settings choices are: **Auto** (the default), **10 Mbit/Half**, **10 Mbit/Full**, **100 Mbit/Half**, **100 Mbit/Full**.

9. **Enter IPv4 settings (if applicable).**

- a. **Enable DHCP** - Click this item ON to have the IP Address of your library automatically set by the DHCP server. If you are not using a DHCP server, leave unchecked and enter the appropriate information for the IP Address, Network Mask, and Gateway Address.
- b. **Static Address** - An identifier for a computer or device on a TCP/IP network. Networks using the TCP/IP protocol route messages based on the IP address of the destination. The format of an IP address is a 32-bit numeric address written as four numbers separated by periods. Each number can be zero to 255. For example, 1.160.10.240 could be an IP address.
- c. **Network Mask** - This address defines and limits users within a local network.
- d. **Gateway address** - This address allows access outside the local network.

10. **Enter IPv6 settings (if applicable).**

- a. **Enable DHCP** - Click this item ON to have the IP Address of your library automatically set by the DHCP server. If you are not using a DHCP server, leave unchecked and enter the appropriate information for the IP Address, Network Mask, and Gateway Address.
- b. **Enable Stateless Auto Config** - Click this item ON to have the IP Address of your library automatically set by the library host computer. Leave unchecked and enter the appropriate information for the static assigned IP Address, prefix length, and Gateway Address.
- c. **Static Address** - Enter the assigned IPv6 address. The format of an IPv6 IP address is a 128-bit numeric address written as 8 groups of four numbers separated by colons.
- d. **Prefix length** - The default prefix length is set to 64, but can be set to any length, depending upon the address used.
- e. **Gateway address** - This address allows access outside the local network.

11. **Enter SNMP settings.**

Note: For more information on SNMP, refer to "SNMP Messaging" on page 1-6 and Appendix F, "SNMP Status MIB Variables and Traps," on page F-1.

- a. **Enabled** - If you desire to have SNMP traps sent to an IP address of your choosing, place a check in this box.
- b. **Target 1-IP Address** - If SNMP traps are enabled, enter an IP address where SNMP traps are to be sent.
- c. **Target 2-IP Address** - Enter an optional 2nd IP address where SNMP traps are to be sent, or leave as 0.0.0.0.
- d. **Target 3-IP Address** - Enter an optional 3rd IP address where SNMP traps are to be sent, or leave as 0.0.0.0.
- e. **Version** - The library offers three versions of the SNMP protocol; v1, v2 and v3. Select a version for each Target IP Address.
- f. **Community Name** - An SNMP community name is a text string that acts as a password to authenticate messages sent between the SNMP remote management application and the library. Enter your preferred name, or leave as "public".
- g. **Security User Name** - In order to receive traps via SNMPv3 the SNMP client needs to be logged in properly. This is provided by this user name. Currently this field may not be changed.

Entering User Access Information using the Web User Interface

This function, other than the Access PIN, is not available on the Operator Control Panel.

1. Click **User Access** in the left navigation pane.

Figure 4-30. The Configure Library: User Access screen

2. Check the **Disable Superuser** checkbox to disable the Superuser role for this library. Check the **Disable User** checkbox to disable the User role for this library. Uncheck these boxes to allow these roles access to your library.
3. Choose a Role.
 - User (if enabled)
 - Superuser (if enabled)
 - Admin
 - Service

Note: Only one password can be set for each Role.

4. Enter the **New Password** (up to 10 alphanumeric characters).
5. In **Repeat Password**, enter the new password again.

6. In **Support Name**, enter the name of the person that will be able to offer the user help with the library.

Note: Only one support person can be configured for the entire tape library. The support person may or may not be one of the user, superuser, or admin account holders.

7. In **Support Phone**, enter the phone number of the person that will be able to offer the user help with the library.
8. In **Support Email**, enter the email address of the person that will be able to offer the user help with the library.
9. Click one of the following:
 - **Refresh** - to update the current screen.
 - **Submit** - to apply the changes made to the screen.

Entering Date and Time using the Web User Interface

1. Click **Date & Time** in the left navigation pane.

Date & Time						
Time (24H)	17	:	41	:	11	
Date	Month :	04	Day :	11	Year :	2006

Refresh Submit

a771ug061

Figure 4-31. The Configure Library: Date and Time screen

2. Enter the current **Time** using the HH:MM:SS 24-hour format.
3. Enter the current **Date** using the MMDDYYYY format.
4. Click one of the following:
 - **Refresh** - to update the current screen
 - **Submit** - to apply changes made to the current screen

Configuring Logs and Traces using the Web User Interface

This function is not available on the Operator Control Panel.

1. Click **Logs & Traces** in the left navigation pane.

Logs & Traces

Error Log Mode

☒ Continuous ☐ Stop Trace At First Error ☐ Stopped

Trace Level

☒ Cmd ☒ Response ☒ Event

☒ Trace Data ☒ Low Level Trace ☒ Recovered Error

☒ Hard Error

Trace Filter

☒ Main ☒ Drive ☒ CDB Interpreter

☒ Robotic ☒ Trace ☒ OCP Input

☒ OCP Output ☒ SCSI Module ☒ SDCI Module

a77ug071

Figure 4-32. The Configure Library: Logs and Traces screen

2. For Error Log Mode, select **Continuous** so all information for logs and traces will be captured.
3. Leave all options under **Trace Level** and **Trace Filters** selected. These options can be changed by Service personnel only.
4. Click **Submit** to apply any changes.

Entering Event Notification Information using the Web User Interface

This function is not available on the Operator Control Panel.

Use this menu item to set up email notification of library errors and warnings.

1. Click **Event Notification** in the left navigation pane.

Event Notification

Notify Errors ☒ On

Notify Warnings ☒ On

To Email Address

SMTP Server Address (IPv4 or IPv6)
Host name and domain

Domain Name

a77ug065

Figure 4-33. The Configure Library: Event Notification screen

2. If you would like to be notified when an error occurs, select **Notify Errors**.
3. If you would like to be notified when a warning occurs, select **Notify Warnings**.
4. In **To Email Address**, enter the email address to which the information will be sent.
5. In **SMTP Server Address (IPv4 or IPv6)**, enter the IP Address of the SMTP server associated with the email address.

6. Enter the **Domain Name** for your library. This field cannot be blank when using event notification.

Note: If you attempt to enter a blank value for the Domain Name, a warning message will appear. It will say **If you are using Event Notification then a value is required for the Domain Name.**

Running Key Path Diagnostic for Testing Encryption Configuration

If you have purchased an encryption activation key (Feature Code 5900: Transparent LTO Encryption) and any LTO 4 Fibre Channel or SAS drives in your library are configured for library managed encryption, run the Key Path Diagnostic to ensure that your encryption configuration is correct.

Important: Ensure that library firmware and drive firmware are up to date before running the Key Path Diagnostic. Library firmware level must be greater than 6.xx. See “Verifying/Updating Firmware” on page 4-19.

For information on running the diagnostic, refer to “Service Library: Perform Key Path Diagnostics” on page 5-56.

Restoring Factory Default Settings using the Web User Interface

If you would like to erase your current configuration and restore factory default settings (see Table 5-3 in “Configure: Restore Defaults” on page 5-25), do so by selecting **Restore Defaults** in the Configure Library menu.

This function is also available on the Operator Control Panel. If you do not have the capability of accessing your library using the Web User Interface, write down all library configuration settings on the Appendix G, “Library Configuration Form,” on page G-1 for future reference.

Logging out of the Web User Interface

It is important to log out of the Web User Interface before using the Operator Control panel. To log out of the Web User Interface, click **Logout** in the upper right corner of the current screen.

Important: If you click the X in the upper right corner of your internet browser window, you will not log out of the Web User Interface.

Setting the Operator Control Panel Access PIN using the Operator Control Panel

1. Navigate to **Configure** → **Set Access PIN**.
2. Press the SELECT button to highlight the first digit of the 4-digit Access PIN.
3. Use the UP and DOWN buttons to select each digit.
4. Press the SELECT button to move to the next digit.
5. Repeat these steps for repeating the Access PIN.
6. After entering the final digit, press the DOWN button and select one of the following:
 - **Save** - to apply your settings.
 - **Cancel** - to delete your settings.

Note: In Figure 4-34 on page 4-33, menus with the pound sign (#) are the only menus accessible when the Access PIN is enabled, but entered incorrectly

or before it is entered. To gain access to all menus, disable the Access PIN or enter the correct PIN number when requested.




Figure 4-34. Pound sign (#) shows accessible menus when access PIN is enabled but before it is entered

Configuring Your Library using the Operator Control Panel

If you choose to use the Operator Control Panel for configuring your library, go to “Configure Menu” on page 5-18 for information on configuring the following items:

- Logical Libraries
- Library Settings
- Drive(s)
- Network
- Set Access PIN
- Set Date and Time
- Path Failover

To complete the configuration of your library, the following items will have to be accessed from the Web User Interface:

- Encryption (see “Configure Library: Encryption” on page 5-43)
- User Access Information (see “Configure Library: User Access” on page 5-50)
- Logs and Traces (see “Configure Library: Logs & Traces” on page 5-51)
- Event Notification Information (see “Configure Library: Event Notification” on page 5-52)
- Key Path Diagnostic (see “Service Library: Perform Key Path Diagnostics” on page 5-56)
- Updating Firmware (see “Service Library: Upgrade Firmware” on page 5-57)

Preparing the Host

Follow these general guidelines:

1. Ensure that your backup application supports the SCSI, SAS, or Fibre Channel host bus adapter (HBA).
2. Ensure that all the required or latest available Operating System files and/or updates (dll's, PTF's, etc.) have been installed and applied.
3. If the host server is connected to a network, check with the system administrator before turning host power OFF.
4. Install a suitably rated HBA. Remember that if there are any single-ended (SE) devices on the same SCSI bus, the entire SCSI bus will negotiate down to SE speed and severely degrade performance and limit cable length.
5. Ensure that LUN scanning is enabled on the SCSI host adapter.
6. Ensure that Fibre Channel Tape Support is enabled on the Fibre Channel HBA if installing a library with a Fibre Channel drive.
7. Ensure that SAS support is enabled on the SAS HBA if installing a library with a SAS drive.
8. For library managed or system managed encryption capability, install the Encryption Key Manager (EKM) application on your host. Refer to the EKM documentation for detailed instructions. For a list of the EKM documents, see “Related Publications” in the Preface.

Verifying the Connection

1. Depending on the server configuration, you may need to change the SCSI ID or Fibre Channel Loop ID of the library, if the current ID is the same as another device on the bus.
2. When the host server is powered ON, install the software and/or driver(s) that are compatible with the library. Backup software packages may require additional software or licensing to communicate with the library accessor.
3. If this is a SCSI attachment, ensure the library is properly terminated. If the library is the only SCSI device, other than the SCSI host adapter on the selected SCSI bus, it must be terminated. Likewise, if the library is physically the last SCSI device on the SCSI bus, it must be terminated. Only the devices physically located at the beginning and end of the SCSI bus should be terminated.
4. Confirm that the host server operating system recognized the library. In Microsoft® Windows XP, Windows Server 2003, or in Windows 2000 you can verify this by going to: **Settings** → **Control Panel** → **System** → **Hardware** → **Device Manager** → **Tape Drive and/or Medium Changer** .

For more information on verifying the connection of SCSI devices, see the operating system documentation.

Cartridge Magazines

The library has removable magazines. Magazine access is password protected. For safety reasons, the accessor motion is stopped when a magazine is removed.

The magazines can be released using the Operator Control Panel or the Web User Interface. In case the Operator Control Panel or Web User Interface initiated process has failed or the library no longer has power, a manual emergency release is available.

Important: To manually release a magazine, see “Releasing the Magazines Manually” on page 9-1. This manual process should only be used if the magazine cannot be released using the Operator Control Panel or the Web User Interface.

2U Library Cartridge Magazines

The 2U library has two cartridge magazines. The left cartridge magazine (see Figure 4-35) has eleven storage slots and houses the elective 1-slot I/O Station. The right magazine (see Figure 4-36 on page 4-36) has twelve storage slots. For information about Element Addressing, see “2U Library I/O Slot, Storage Slots and Drive Slot Element Addresses and Physical Locations” on page B-1.

Note: On some 2U Libraries prior to Library Microcode Level 1.9, slot 11 may be labelled a “Not Used” slot which contained a “Slot Blocker”. With Library Microcode level 1.9 or higher, there is an option to remove the “Slot Blocker” and place that slot into use. See “Removing the Slot Blocker - 2U Library” on page 10-10.



Figure 4-35. 2U library left magazine




a77ug021

Figure 4-36. 2U library right magazine

2U Library I/O Station

The I/O (Input/Output) Station (see Figure 4-37) in a 2U library is part of the left magazine. To open the I/O Station, select **Control** → **Open I/O Station**. The I/O Station will pop open. To close the I/O Station, gently push it back into the left magazine.



a77ug022

Figure 4-37. 2U library I/O Station in the left magazine

4U Library Cartridge Magazines

The 4U library has four cartridge magazines, two on each side (see Figure 4-38 on page 4-37 and Figure 4-39 on page 4-37). The upper left magazine has twelve

storage slots. The lower left magazine has nine storage slots and houses the elective 3-slot I/O Station (**1** in Figure 4-38). The upper right magazine has twelve storage slots. The lower right magazine has twelve storage slots. For information on Element Addressing, see “4U Library I/O Slots, Storage Slots, and Drive Slots Element Addresses and Physical Locations” on page B-2.



Figure 4-38. 4U library left magazines



Figure 4-39. 4U library right magazines

4U Library I/O Station

The I/O Station in a 4U library (see Figure 4-40 on page 4-38) is part of the lower left magazine. To open the I/O Station, select **Control** → **Open I/O Station**. The I/O Station will pop open. To close the I/O Station, gently push it back into the lower left magazine.



Figure 4-40. 4U library I/O Station in the lower left magazine

There are finger holes on the back side of the I/O Station (see **1** in Figure 4-41) that allow the user to push the cartridges out of the I/O station.




Figure 4-41. Finger Holes on back side of 4U Library I/O Station

Populating the Library with Data Cartridges

For information on working with the cartridge magazines, see “Cartridge Magazines” on page 4-35.

1. Unlock the cartridge magazines.
 - Using the Operator Control Panel: **Control** → **Magazines**
 - Using the Web User Interface: **Manage Library** → **Release Magazine**

Note: The magazines will relock after 15 seconds if they have not been removed.

2. Remove all magazines from the library.
3. Insert cartridges in the left magazine(s). Do not store cartridges in the I/O Station or in the dedicated cleaning cartridge slot. See “2U Library I/O Slot, Storage Slots and Drive Slot Element Addresses and Physical Locations” on page B-1 or “4U Library I/O Slots, Storage Slots, and Drive Slots Element Addresses and Physical Locations” on page B-2 for determining slot location.
4. Insert cartridges in the right magazine(s).
5. Put all magazines back into the library. The library will automatically start up and perform an inventory check.

Inserting the Cleaning Cartridge

See the **Note** below for 4U libraries with a Dedicated Cleaning Slot (DCS).

The following criteria must be followed for **Auto Clean** to function:

1. The **Auto Clean** function must be configured “**On**” or “**Enabled**”.
 - Operator Control Panel: **Configure**→**Library Settings**→**Enabled**
 - Web User Interface: **Configure Library**→**General**→**Auto Clean**→**checkmark**

Note: Earlier versions of the 4U library contained a **Dedicated Cleaning Slot (DCS)**. This DCS can be retained and is supported by future library firmware updates. However, library firmware later than 1.95 will allow removal of the DCS, thus enabling this slot to be used as a storage slot. Once the DCS is removed, the Auto Clean cleaning cartridge slot must be configured as described below. If the DCS has been removed, it can only be reinstated by restoring factory default settings. To remove the DCS, perform the following procedure using the Operator Control Panel (OCP): **OCP**→**Configure**→**Library Settings**→**General**→**Remove DCS**→**No/Yes**→**Save**.

2. A storage slot must be reserved (Res or RSVD).
 - Reserving a slot is accomplished by reducing the **Active Slot** count in any particular logical library. A reserved slot (or slots) is always the last slot in the last magazine of any particular logical library. A cleaning cartridge that is in a reserved slot is available to any logical library drive even if the reserved slot is not in that particular logical library. If the library contains multiple logical libraries, typically, the last logical library is chosen to be the reserved slot containing the cleaning cartridge. As with a library with a single logical library, this slot is the last physical slot in the library (top right magazine, uppermost rear slot).
3. A cleaning cartridge (**CLNxxxLx**) must be placed or moved to a reserved slot.
 - A cleaning cartridge must be replaced after 50 uses. Click on the Web User Interface, **Monitor Library**→**Inventory**.
 - Find the magazine that contains the cleaning cartridge.
 - Click on the (+) located under that magazine presentation to expand the detail of resident cartridges.

- Observe the cleaning cartridge location displayed. The number of Media Loads represent how many times the cleaning cartridge has been used. The number 50, minus that Media Load number represents the number of uses left.
4. To install a cleaning cartridge in the 2U or 4U library:
 - a. Use the Operator Control Panel: **Control** → **Move Cartridge** or the Web User Interface: **Manage Library** → **Move Media** to insert the cleaning cartridge into the reserved slot or the DCS (if one exists, 4U only).
 - b. An alternate method is to use the Release Magazine option:
 - Operator Control Panel: **Control** → **Magazine (Left/Right)**
 - Web User Interface: **Manage Library** → **Release Magazines (Left/Right)**
 - c. Place a cleaning cartridge into the reserved slot or the DCS (if one exists, 4U only).

Registering for My Notification

My Notification registration provides email notification when firmware levels have been updated and are available for download and installation.

To register for My Notification:

1. Visit the web at <http://www.ibm.com/us/>.
2. Click **Get Support**.
3. Click **My support**.

Note: Library firmware and tape drive firmware are verified and released together. When updating to the latest firmware, verify that all installed components such as tape drive(s), and library are at the latest levels noted on the Support web site. Mixing different levels of library and tape drive firmware is not supported and may cause unpredictable results.

Chapter 5. Operations

The following table lists menu navigation shortcuts to activities that can be performed via the Operator Control Panel and/or the Web User Interface.

Before using the Operator Control Panel or the Web user Interface, please review the information in Chapter 3: **User Interfaces**.

Table 5-1. Menu navigation shortcuts

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Access PIN, create new	Configure → Set Access PIN	"Configure: Set Access PIN" on page 5-25	Configure Library → User Access	"Configure Library: User Access" on page 5-50
Access PIN, modify existing	Configure → Set Access PIN	"Configure: Set Access PIN" on page 5-25	Configure Library → User Access	"Configure Library: User Access" on page 5-50
Accessor, number of cartridge moves	Monitor → Library → Status → Cycles	"Monitor: Library" on page 5-11	Monitor Library → Library Status	"Monitor Library: Library Status" on page 5-34
Auto Clean, enable	Configure → Library Settings → Auto Clean	"Configure: Library" on page 5-20	Configure Library → General	"Configure Library: General" on page 5-41
Cartridge, currently active/moving	Monitor → Library → Status → Act. Cart	"Monitor: Library" on page 5-11	Monitor Library → Library Status	"Monitor Library: Library Status" on page 5-34
Cartridge, determine encryption	Not available with this interface		Monitor Library → Inventory	"Monitor Library: Inventory" on page 5-37
Cartridge, Inventory	Monitor → Inventory → Magazines	"Monitor: Inventory" on page 5-15	Manage Library → Perform Inventory	"Manage Library: Perform Inventory" on page 5-40
Cartridge, Move	Control → Move Cartridges	"Control: Move Cartridges" on page 5-17	Manage Library → Move Media	"Manage Library: Move Media" on page 5-39
Cartridge currently in drive (n), serial number	Monitor → Inventory → Drive (n)	"Monitor: Inventory" on page 5-15	Monitor Library → Drive Status	"Monitor Library: Drive Status" on page 5-35

Table 5-1. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Cartridge in drive (n), serial number	Monitor → Drive → Status → Drive (n)/Source	"Monitor: Drive" on page 5-13	Monitor Library → Drive Status	"Monitor Library: Drive Status" on page 5-35
Configuration, save and restore*	Configure → Restore Defaults	"Configure: Restore Defaults" on page 5-25	Configure Library → Restore Defaults	"Configure Library: Restore Defaults" on page 5-52
	* Note: From this location, you can not only restore factory defaults but save and restore your library configuration from the RMU or OCP.			
Control path, enable	Configure → Drive → Control Paths	"Configure: Drive" on page 5-23	Configure Library → Drive	"Configure Library: Drives" on page 5-46
Date and time, current setting	Monitor → Library → Identity → Date/Time	"Monitor: Library" on page 5-11	Monitor Library → Library Identity	"Monitor Library: Library Identity" on page 5-31
Date and time, set	Configure → Set Date and Time	"Configure: Set Date and Time" on page 5-27	Configure Library → Date & Time	"Configure Library: Date & Time" on page 5-51
Dedicated Cleaning slot, removing, reinstating	Configure → Library Settings	"Configure: Library" on page 5-20	Not available with this interface	
DHCP, current status	Monitor → Library → Network → DHCP	"Configure: Network" on page 5-24	Configure Library → Network	"Configure Library: Network" on page 5-47
DHCP, modify	Configure → Network → DHCP	"Configure: Network" on page 5-24	Configure Library → Network	"Configure Library: Network" on page 5-47
Diagnostics, run drive Head test	Service → Service → Drive Tests	"Service: Run Tests" on page 5-29	Service Library → Perform Diagnostics	"Service Library: Perform Diagnostics" on page 5-56
Diagnostics, run drive Media test	Service → Service → Drive Tests	"Service: Run Tests" on page 5-29	Service Library → Perform Diagnostics	"Service Library: Perform Diagnostics" on page 5-56
Diagnostics, run drive Normal Read/Write test	Service → Service → Drive Tests	"Service: Run Tests" on page 5-29	Service Library → Perform Diagnostics	"Service Library: Perform Diagnostics" on page 5-56
Diagnostics, run drive POST	Service → Service → Drive Tests	"Service: Run Tests" on page 5-29	Service Library → Perform Diagnostics	"Service Library: Perform Diagnostics" on page 5-56

Table 5-1. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Diagnostics, run drive wrap test	Service → Service → Drive Tests	“Service: Run Tests” on page 5-29	Service Library → Perform Diagnostics	“Service Library: Perform Diagnostics” on page 5-56
Diagnostics, run Key Path diagnostics	Not available with this interface		Service Library → Perform Key Path Diagnostics	“Service Library: Perform Key Path Diagnostics” on page 5-56
Diagnostics, run Library Verify test	Service → Library Verify	“Service: Library Verify” on page 5-28	Not available with this interface.	
Diagnostics, run Slot to Slot test	Service → Run Tests	“Service: Run Tests” on page 5-29	Service Library → Perform Diagnostics	“Service Library: Perform Diagnostics” on page 5-56
Diagnostics, run System Test	Service → Run Tests	“Service: Run Tests” on page 5-29	Service Library → Perform Diagnostics	“Service Library: Perform Diagnostics” on page 5-56
Display Contrast	Service → Display Contrast	“Service: Display Contrast” on page 5-30	Not available with this interface.	
DNS, modify settings	Not available with this interface.		Configure Library → Network	“Configure Library: Network” on page 5-47
Drive, change interface configuration	Configure → Drive → Drive Interface	“Configure: Drive” on page 5-23	Configure Library → Drives	“Configure Library: Drives” on page 5-46
Drive, change encryption	Not available with this interface		Configure Library → Encryption	“Configure Library: Encryption” on page 5-43
Drive, clean	Service → Service → Clean Drive	“Service: Service (Drives)” on page 5-29	Service Library → Clean Drive	“Service Library: Clean Drive” on page 5-53
Drive, current SCSI/Loop ID	Monitor → Drive → Identity	“Monitor: Drive” on page 5-13	Monitor Library → Drive Identity	“Monitor Library: Drive Identity” on page 5-32
Drive, current status	Monitor → Drive → Status	“Monitor: Drive” on page 5-13	Monitor Library → Drive Status	“Monitor Library: Drive Status” on page 5-35

Table 5-1. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Drive, data compression ON/OFF	Not available with this interface.		Monitor Library → Drive Identity → Data Compression	"Monitor Library: Drive Identity" on page 5-32
Drive, Fibre, Worldwide Node Name	Monitor → Drive → Identity → Drive (n)/WWNN	"Monitor: Drive" on page 5-13	Monitor Library → Drive Status	"Monitor Library: Drive Status" on page 5-35
Drive, Hashed SAS Address	Not available with this interface.		Monitor Library → Drive Status → Hashed SAS Address	"Monitor Library: Drive Status" on page 5-35
Drive, Interface type	Configure → Drive → Drive Interface	"Configure: Drive" on page 5-23	Configure Library → Drive	"Configure Library: Drives" on page 5-46
Drive, SCSI Inquiry string	Monitor → Drive → Identity → Drive (n)/Product ID	"Monitor: Drive" on page 5-13	Monitor Library → Drive Identity	"Monitor Library: Drive Identity" on page 5-32
Drive, turn power ON/OFF	Service → Service → Drive Power	"Service: Service (Drives)" on page 5-29	Configure Library → Drive	"Configure Library: Drives" on page 5-46
Drive activity, current	Monitor → Drive → Status → Drive (n)/Activity	"Monitor: Drive" on page 5-13	Monitor Library → Drive Status	"Monitor Library: Drive Status" on page 5-35
Drive fan, status	Monitor → Drive → Status → Drive (n)/Cooling	"Monitor: Drive" on page 5-13	Monitor Library → Drive Status	"Monitor Library: Drive Status" on page 5-35
Drive Dump, save	Not available with this interface.		Service Library → Save Drive Dump	"Service Library: Save Drive Dump" on page 5-55
Encryption, activate	Not available with this interface.		Configure Library → Encryption	"Configure Library: Encryption" on page 5-43
Encryption, configure	Not available with this interface.		Configure Library → Encryption	"Configure Library: Encryption" on page 5-43
Encryption, testing configuration	Not available with this interface.		Service Library → Perform Key Path Diagnostics	"Service Library: Perform Key Path Diagnostics" on page 5-56

Table 5-1. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Encryption, determine method, current method	Not available with this interface.		Monitor Library → Drive Status → Encryption method	"Monitor Library: Drive Status" on page 5-35
Ethernet settings	Configure → Drive → Ethernet		Configure Library → Ethernet	
Event notifications: add, modify, and delete	Not available with this interface.		Configure Library → Event Notification	"Configure Library: Event Notification" on page 5-52
Error log, view	Monitor → Library → Error log	"Monitor: Library" on page 5-11	Service Library → View logs	"Service Library: View Logs" on page 5-54
Error logs and traces, set mode	Not available with this interface		Configure Library → Logs & Traces	"Configure Library: Logs & Traces" on page 5-51
Factory Default settings, restore	Configure → Restore Default	"Configure: Restore Defaults" on page 5-25	Configure Library → Restore Defaults	"Configure Library: Restore Defaults" on page 5-52
Fibre Channel, speed	Monitor → Drive → Status → Drive (n)/Speed	"Monitor: Drive" on page 5-13	Monitor Library → Drive Status	"Monitor Library: Drive Status" on page 5-35
Fibre Channel, topology	Monitor → Drive → Status → Drive (n)/Topology	"Monitor: Drive" on page 5-13	Monitor Library → Drive Status	"Monitor Library: Drive Status" on page 5-35
Fibre Channel link, status	Monitor → Drive → Status → Drive (n)/Link	"Monitor: Drive" on page 5-13	Monitor Library → Drive Status	"Monitor Library: Drive Status" on page 5-35
Firmware, drive, current level	Monitor → Drive → Identity	"Monitor: Drive" on page 5-13	Monitor Library → Drive Identity	"Monitor Library: Drive Identity" on page 5-32
Firmware, library, identify current level	Monitor → Library → Identity	"Monitor: Library" on page 5-11	Monitor Library → Library Identity	"Monitor Library: Library Identity" on page 5-31
Firmware, library, update	Not available with this interface.		Service Library → Upgrade Firmware	"Service Library: Upgrade Firmware" on page 5-57
Gateway, current address	Monitor → Library → Network → Gateway	"Monitor: Library" on page 5-11	Configure Library → Network	"Configure Library: Network" on page 5-47

Table 5-1. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Gateway Address, modify	Configure → Network → Gateway	“Configure: Network” on page 5-24	Configure Library → Network	“Configure Library: Network” on page 5-47
Inventory, perform	Control → Re-Inventory	“Control: Re-Inventory” on page 5-18	Manage Library → Perform Inventory	“Manage Library: Perform Inventory” on page 5-40
I/O Station, configuring	Configure → Library Settings	“Configure: Library” on page 5-20	Configure Library → General	“Configure Library: General” on page 5-41
I/O Station, current status	Monitor → Library → Status	“Monitor: Library” on page 5-11	Monitor Library → Library Status	“Monitor Library: Library Status” on page 5-34
I/O Station, open	Control → Open I/O Station	“Control: Open I/O Station” on page 5-17	Not available with this interface	
IP Address, current	Monitor → Library → Identity	“Monitor: Library” on page 5-11	Monitor Library → Library Identity	“Monitor Library: Library Identity” on page 5-31
IP Address, modify	Configure → Network → IP Address	“Configure: Network” on page 5-24	Configure Library → Network	“Configure Library: Network” on page 5-47
Library, current status	Monitor → Library → Status	“Monitor: Library” on page 5-11	Monitor Library → Library Status	“Monitor Library: Library Status” on page 5-34
Logical libraries, configure	Configure → Logical Libraries	“Configure: Logical Libraries” on page 5-19	Configure Library → Logical Libraries	“Configure Library: Logical Libraries” on page 5-42
Logs, library, view	Monitor → Library → Error Log	“Monitor: Library” on page 5-11	Service Library → View Logs	“Service Library: View Logs” on page 5-54
Magazines, graphical representation	Monitor → Inventory → Magazines	“Monitor: Inventory” on page 5-15	Monitor Library → Inventory	“Monitor Library: Inventory” on page 5-37
Magazines, Unlock	Control → Magazines	“Control: Magazine” on page 5-17	Manage Library → Release Magazine	“Manage Library: Release Magazine” on page 5-40

Table 5-1. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Mode, library, change	Configure → Library Settings → Mode	“Configure: Library” on page 5-20	Configure Library → General	“Configure Library: General” on page 5-41
Mode, library, current	Monitor → Library → Identity	“Monitor: Library” on page 5-11	Monitor Library → Library Identity	“Monitor Library: Library Identity” on page 5-31
Netmask, current address	Monitor → Library → Network → Netmask	“Monitor: Library” on page 5-11	Configure Library → Network	“Configure Library: Network” on page 5-47
Netmask Address, modify	Configure → Network → Netmask	“Configure: Network” on page 5-24	Configure Library → Network	“Configure Library: Network” on page 5-47
Network configuration, change	Configure → Network	“Configure: Network” on page 5-24	Configure Library → Network	“Configure Library: Network” on page 5-47
Network configuration, view	Monitor → Library → Network	“Monitor: Library” on page 5-11	Configure Library → Network	“Configure Library: Network” on page 5-47
Path Failover, enter activation key	Configure → Path Failover	“Configure: Path Failover” on page 5-27	Configure Library → Path Failover	“Configure Library: Path Failover” on page 5-43
Power cycles	Monitor → Library → Status	“Monitor: Library” on page 5-11	Monitor Library → Library Status	“Monitor Library: Library Status” on page 5-34
Restart, library,	Not available with this interface.		Service Library → Reboot	“Service Library: Reboot” on page 5-59
SCSI Inquiry string, library	Monitor → Library → Identity	“Monitor: Library” on page 5-11	Monitor Library → Library Identity	“Monitor Library: Library Identity” on page 5-31
Serial Number, drive	Monitor → Drive → Identity	“Monitor: Drive” on page 5-13	Monitor Library → Drive Identity	“Monitor Library: Drive Identity” on page 5-32
Serial Number, library	Monitor → Library → Identity	“Monitor: Library” on page 5-11	Monitor Library → Library Identity	“Monitor Library: Library Identity” on page 5-31

Table 5-1. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Slots, number active	Monitor → Library → Identity → Active Slots	“Monitor: Library” on page 5-11	Monitor Library → Library Identity	“Monitor Library: Library Identity” on page 5-31
Slots, number empty	Monitor → Library → Status → Slots Empty	“Monitor: Library” on page 5-11	Monitor Library → Library Status	“Monitor Library: Library Status” on page 5-34
Slots, reassign number of active, reserving	Configure → Library Settings → Active Slots	“Configure: Library” on page 5-20	Configure Library → General	“Configure Library: General” on page 5-41
SNMP, modify settings	Not available with this interface.		Configure Library → Network	“Configure Library: Network” on page 5-47
Telnet Service Port, activate	Service → Telnet Service Port	“Service: Telnet Service Port” on page 5-30	Not available with this interface.	
Time elapsed since power ON	Monitor → Library → Status	“Monitor: Library” on page 5-11	Monitor Library → Library Status	“Monitor Library: Library Status” on page 5-34
Operator Control Panel, access PIN, enable/disable	Configure → Set Access PIN	“Configure: Set Access PIN” on page 5-25	Not available with this interface.	
Web User Interface, user access, create or modify	Not available with this interface.		Configure Library → User Access	“Configure Library: User Access” on page 5-50

Operator Control Panel Navigation

The four control keys on the front of a 2U or 4U library enable the user to navigate through the library settings and make changes as needed to configure the library.




Figure 5-1. 2U Library Control Keys




Figure 5-2. 4U Library Control Keys

Table 5-2. Library Control Keys

Control Keys	Description
1	UP (+) - Upper-left button Used to scroll upward through menu items.
2	CANCEL - Upper-right button Used to cancel a user action and return to the previous menu screen.
3	SELECT - Lower-right button Used to display a sub-menu or force an accessor action.

Table 5-2. Library Control Keys (continued)

Control Keys	Description
4	DOWN (-) - Lower-left button Used to scroll downward through menu items.

1. Press the UP (**1**) or DOWN(**4**) keys to enter Interaction Mode. The Main Selection Menu will appear. The Main Selection screen shows Monitor, Control, Configure, and Service.
2. Scroll to your selection, then press the SELECT (**3**) key. The sub-menu for the selected menu item will appear.
3. Use the UP (**1**) or DOWN(**4**) and SELECT (**3**) keys to scroll until you get to the area/screen you wish to configure.
4. Use the CANCEL (**2**) key if you wish to move backwards through the menu selections.

Operator Control Panel Menu Tree

The Operator Control Panel Main menu is made up of the following items:

- Monitor
- Control
- Configure
- Service

The table below shows each Main menu item and the associated sub menu items.




Figure 5-3. Operator Control Panel Menu Tree

Monitor Menu

The Monitor menu contains information about the following sub menu items:

- Library
- Drive
- Inventory

Monitor: Library

This menu item displays current library information and settings.




Figure 5-4. Monitor: Library menu

Under **Monitor** → **Library** are the following items:

- **Status**
- **Identity**
- **Error Log**
- **Network**

Under **Monitor** → **Library** → **Status** are the following items:

- Status - current status of the library

- Act. Cart - the serial number of the cartridge currently active in the library
- On Time - the amount of time the library has been powered ON
- Slots Empty - the number of empty slots in the library/total number of active slots in the library
- Cycles - the total number of cartridge moves carried out by the library accessor
- I/O Station - indicates whether the I/O Station is open or closed
- Date/Time - gives the current date and time set in the library

Under **Monitor** → **Library** → **Identity** are the following items:

- Serial Number - the serial number of the library
- Version - the current level of library firmware installed
- Vendor ID - IBM
- Product ID - library inquiry string
- IP Address - current library IP address
- Active Slots - number of active slots in each logical library
- WWNN - World Wide Node Name of the library
- Library Mode - current library mode (Random or Sequential)


Under **Monitor** → **Library** → **Error Log**, you will have a list of errors logged by the library. The errors will be displayed beginning with the most recent error.

Under **Monitor** → **Library** → **Network** are the following items:

- IP Stack - the internet protocol currently being used by the library
- DHCP - (Dynamic Host Configuration Protocol) - records whether DHCP is ON or OFF
- IP Addresses - the internet addresses of the library
- Netmask - the Network Mask Address of the library
- Gateway - the Gateway Address of the library
- Ethernet - the speed of the ethernet interface
- Stateless auto configuration - indicates whether or not stateless auto configuration is enabled
- Prefix Length - the length of the IP Address prefix
- Static IPv6 Address - the static IPv6 address of the library
- Link Local IPv6 Address - local link-only IPv6 address of the library
- Router assigned IPv6 Address - IPv6 address(es) discovered by the network router

Monitor: Drive

This menu item displays drive information and settings.



a77ug035

Figure 5-5. Monitor: Drive menu

Under **Status** and **Drive (n)** are the following items:

- **Status** - the current status of the drive
- **Activity** - the current action being performed by the drive


- Source - the serial number of the cartridge currently in the drive
- Encryption - indicates the type of data encryption currently set for the selected drive
- Topology - the topology chosen for a fibre library (see “Fibre Channel Interface” on page 3-10)
- Speed - indicates the speed of the fibre channel (fibre library)
- Link - indicates the status of the fibre channel (fibre library)
- Hashed Address - an address calculated from the WWID

Under **Identity** and **Drive (n)** are the following items:

- Firmware Rev - the current level of drive firmware
- Vendor ID - IBM
- Product ID - drive inquiry string
- Serial Number - the drive serial number
- SCSI ID - the unique identifier assigned to a SCSI drive
- WWNN - the fibre channel drive’s World Wide Node Name
- Topology - the topology chosen for the fibre channel drive
- Speed - indicates the speed of the fibre channel tape drive
- Loop ID - unique identifier assigned to a fibre channel tape drive
- PID - port identification

Monitor: Inventory

This menu item displays the current library inventory of a 4U library.



a77ug036

Figure 5-6. Example of a 4U Monitor: Inventory menu

Under **Magazine** choose one of the following to see a graphical representation of the cartridge magazine(s). Slots containing cartridges will be highlighted.

Magazines > Lower Left			
I/O 3	7	8	9
I/O 2	4	5	6
I/O 1	1	2	3
Idle Rand			

Figure 5-7. Overview of inventoried cartridges: Lower Left Magazine of a 4U Library

The black boxes are inventoried cartridges. Press the up and down keys to scroll. Note that this magazine has a 3-slot I/O Station. These slots can be changed to storage slots if needed. See “Configuring I/O Stations and Reserving Slots” on page 5-60.

Press **SELECT** to display all empty slots and cartridge serial numbers in the associated magazine.

Magazines > Lower Left			
1	2	DT0632L4	LTO4 EC
	3	3FB114L4	LTO4 ED
	4	Empty	
	5	Empty	
Idle Rand			

377ug236

Figure 5-8. Detailed information on cartridges residing in a magazine

Table 5-3. Detailed information on cartridges residing in a magazine

1	Magazine slot number	3	Media type (generation of cartridge)
2	Cartridge volume serial number or “Empty” (meaning no cartridge currently residing in slot)	4	Encryption abbreviation for LTO4 cartridges: • EC - encryption capable (The LTO 4 cartridge does not contain encrypted data). • ED- encrypted data (The LTO 4 cartridge does contain encrypted data).

Control Menu

The Control Menu contains the following items:

- Open I/O Station
- Move Cartridges
- Magazine
- Re-Inventory

Control: Open I/O Station

Use this menu item to open the I/O Station.




Figure 5-9. Control: I/O Station menu

Attention: After closing the I/O Station, you must wait for the library to complete its inventory before proceeding with normal library operations.

Control: Move Cartridges

Use this menu item to move cartridges in the library.




Figure 5-10. Control: Move Cartridges menu

To move a cartridge from point A to point B, you must make the following choices:

- Source Type - Drive, I/O station, magazine. Only the source type(s) that contain cartridges will be listed.
- Source - the choices start with the choice made in the preceding item and then advances through all available choices.

Note: If the Attention LED is ON due to a suspect cartridge, that cartridge will be identified by an exclamation point (!) when scrolling through the source cartridges.

- Volume Serial - the serial number of the cartridge
- Dest Type - the destination Drive, I/O station, magazine
- Dest - the choices start with the choice made in the preceding item and then advances through all available choices.

Control: Magazine

Use this menu item to unlock the cartridge magazines.




Figure 5-11. Control: Magazine menu

Choose "Left" or "Right" to unlock the corresponding cartridge magazine(s). The magazines can now be removed from the library by gently pulling each magazine out of the library. To replace a magazine, insert the back of the magazine into the front of the library and gently push the magazine into the library. The magazine will lock when inserted into the library.

Attention: After inserting the magazines into the library, you must wait for the library to complete its inventory before proceeding with normal library operations.

If the magazines are not pulled out of the library within 15 seconds after they are unlocked, the command will cancel and you will have to repeat the process to unlock the magazines.

Control: Re-Inventory

Use this menu item to initiate a scan of the cartridges currently in the library.




Figure 5-12. Control: Re-Inventory menu

Note: It may take up to five minutes to complete the library inventory.

Configure Menu

The Configure Menu is used during the initial setup of your library and when changes need to be made to your library's configuration. This menu contains the following items:

- Logical Libraries
- Library Settings
- Drive
- Network

- Set Access PIN
- Set Date and Time
- Path Failover
- Restore Defaults

Configure: Logical Libraries

Use this menu item to select the number of logical libraries.




Figure 5-13. Configure: Logical Libraries menu

Note: This menu is only available on libraries with multiple drives.

Note: Whenever there is a hardware configuration change such as drives being swapped with different form factors (i.e. HH to FH or FH to HH), a library configuration change is needed. Reconfiguring the library by reassigning the amount of logical libraries will clear this issue.

Configure: Library




Figure 5-14. Configure: Library menu

The following library configuration items are in this menu:

- **Mode:**
 - **Random:** In random mode, the library allows the server's (host's) application software to select any data cartridge in any order.

- **Sequential:** In sequential mode, the library's firmware predefines the selection of the cartridges. After initialization, the firmware causes the library to select the first available cartridge found (counting from the I/O Station through slot 23) for loading into the drive.

Important: If a Logical Library in Sequential Mode contains more than one drive, only the first drive in the Logical Library will be utilized.

- **Autoload:** Sequential mode with autoload mode ON loads the first available cartridge (slot with the lowest numerical value that contains a cartridge) automatically if the library powers ON with an empty drive.
- **Loop:** Sequential mode with loop mode ON loads the cartridge in the lowest numerical slot after the cartridge in the highest numerical slot has been filled and sent back to its home slot. This allows endless backup operations without user interaction.
- **Starting Sequential Mode**
 - Autoload Option:
 - If the Autoload option is set to **ON (Configure → Library → Autoload)**, the accessor will load the first cartridge (cartridge located in the slot with the lowest numeric value) found in the storage inventory area into the drive upon power ON of the library. If the library powers on with a cartridge already in the drive, sequential mode will start with that cartridge unless the host issues a rewind and unload command to the drive. In that case, the next cartridge in sequence will be loaded into the drive.
 - If the Autoload Option is **OFF**, sequential mode must be started by selecting the Move Cartridges option (**Control → Move Cartridges**) to load the first cartridge (or any cartridge) into the drive. Whatever cartridge is loaded into the drive, that is where the sequence starts from. For example, if a cartridge from the fifth lowest numeric storage slot containing a cartridge is loaded using the Move Cartridges option, after the host issues a rewind/unload command, the next cartridge loaded will be the cartridge from the next higher numeric slot. Cartridges need not be in contiguous slots.
 - Loop Option:

If the Loop option is set to **ON (Configure → Library → Loop)**, when the last cartridge (cartridge in the highest numeric slot) is unloaded and placed back into storage, the accessor will immediately start over again loading the first cartridge into the drive.
 - **Stopping Sequential Mode:** To stop sequential mode, use the Move Cartridges option from the Control menu (**Control → Move Cartridges**) to unload the drive. the next sequential cartridge will NOT be loaded. To restart sequential mode, use the same Control menu command to load a cartridge. The loading sequence will resume from that numeric slot in the cartridge inventory.

- **Active Slots** - the number of active slots in each logical library.

Note: Slots can be reserved so that they are invisible to the host. It may be necessary to set the number of **Active Slots** to match the number of slots that are available to the ISV software. Reserved slots are created by reducing the number of active slots.

- **Auto Clean** - Use this menu item to enable the Auto Clean function. All cleaning cartridges must have "CLNxxxLx" as part of the bar code.

The cleaning cartridge can be stored in any data cartridge slot.

Note: The universal cleaning cartridge has a bar code CLNUxxLx. This cleaning cartridge is used to clean all LTO generation tape drives.

For Auto Clean to function, the following criteria must be met:

- On 4U libraries with library firmware of 1.95 or lower that still contain a Dedicated Cleaning Slot (DCS), or 4U libraries with library firmware higher than 1.95 that chose to retain the DCS in their library, a CLN cartridge must be present in that slot.
- On libraries that don't have a DCS, a storage slot must be reserved (RSVD) by reducing the active slot count by one.
- A cleaning cartridge (CLNxxxLx) must be placed or moved to the reserved slot.
- Auto Clean must be enabled.

Note: Cleaning cartridges must be replaced after 50 cleanings. The Web User Interface inventory screen will show the number of times the media has been loaded, not the number of cleaning sessions remaining. Subtract this number from 50 to determine the number of cleanings remaining.

- **I/O Station(s) enabled** - The I/O Station(s) can be enabled (the default), or disabled so the stations can be utilized as storage slots.
- **Remove DCS** - If the DCS has been removed, it cannot be reinstated. This option will no longer appear in the Operator Control Panel.
- **Host Label Length** - The Host Label Length is related to the Bar Code Labels appearing on the media being used. The default value is 8, but 6 can also be chosen.

Configure: Drive




Figure 5-15. Configure: Drive menu

The following items are in this menu:

- **Drive Interface** - use this to assign a SCSI ID to a SCSI drive or to assign a Port Speed, Port Type, and Loop ID to a Fibre Channel drive. SAS drives do not require user configuration. For more information on drive interfaces, refer to “Host Interfaces” on page 3-7.
- **Control Paths** - use this to enable the drive as a control path drive. Each logical library must have a control path drive; however, all drives in a logical library can be designated as control path drives.

Configure: Network




Figure 5-16. Configure: Network menu

Use these menu items to change the current network settings which allow you to access the library remotely via a web browser.

- **IP Stack** - Choose **IPv4 only**, **IPv6 only**, or **IPv4 & IPv6**.
- **IPv6 Only** and **Dual Stack IPv4 & IPv6** - Choose **Enable** Stateless Auto Config Address (Web User Interface) or Stateless Autoconfig (Operator Control Panel) if router assigned IPv6 IP addresses are desired. To view the router assigned IPv6 addresses after enabling Stateless Auto Config Address, do the following:
 - **Operator Control Panel (IPv6 Only): Monitor → Library → Network**
 - **Web Interface (IPv6 Only and Dual Stack): Monitor Library → Library Identity**

If you choose **Dual Stack IPv4 & IPv6**, you must be prepared to enter both IPv4 and IPv6 IP addresses.

- **DHCP** - (Dynamic Host Configuration Protocol) If this is enabled, your library host will negotiate the connection with the library. If DHCP is disabled, the following information is necessary to establish the remote access.
- **IP Address** - the IP address of the library
- **Netmask** - the Network Mask address of the library
- **IP Stack** - the IP Stack manages static IP addresses
- **Stateless autoconfig** - allows IPv6 hosts to be configured automatically when connected to a routed IPv6 network
- **Prefix length** - the length of the IP address prefix
- **Static IPv6 address** - a static IPv6 address that has been assigned to the library
- **Link Local IPv6 address** - an IPv6 address having link-only scope that can be used to reach neighboring nodes attached to the same link
- **Router assigned IPv6 address** - an IPv6 address assigned by a router
- **Gateway** - the Gateway address of the library
- **Ethernet** - the current speed setting of the ethernet interface

Configure: Set Access PIN

Use this menu item to enable/disable, set or change the Access PIN (personal identification number) which is used to restrict access to the Control, Configure, and Service menus.

Note: Record the Access PIN and store this in a secure location for future reference. Library configuration files, saved with the Save Library Config menu, do not include the Access PIN.




Figure 5-17. Configure: Set Access PIN menu

Configure: Restore Defaults

Use this menu item to restore the factory default settings.




Figure 5-18. Configure: Restore Defaults menu

- **Restore Passwords** - This menu item restores the factory default RMU Admin user access password.

- **Restore all** - This menu item restores all factory default settings (refer to Table 5-4).
- **Restore Library Config** - This menu item restores your saved library configuration from a USB device. If you have more than one saved configuration file (.dbb) on your USB device, press **Select**, then use the up and down keys to move between the different files. When the correct configuration file is displayed, press **Select** again.
- **Save Library Config** - This menu item saves your library configuration to a USB device.

Note: Ensure the USB device is formatted for FAT12, FAT16, or FAT32 and does not use autorun files.

Note: Configuration files saved with one version of library firmware may not be compatible with other versions of firmware. It is recommended to save a configuration file each time the library firmware is upgraded. Restore the library using a configuration file that was saved with the same version of firmware currently installed in the library.

Important: Restoring factory defaults will wipe out all the previous configuration data.

Table 5-4. Factory Default Settings

Restored Item	Default Setting*	Comments
Autoclean	Disabled	
Logical Libraries	1	
Active Slots	Maximum number of slots in library minus I/O Station	
I/O Station	Enabled	2U library has 1-slot I/O Station. 4U library has 3-slot I/O Station.
Encryption	None	License Key is protected, if previously entered.
Ethernet Setting	Auto	
DHCP	Enabled	Note: DNS server addresses, if available, will be automatically assigned. If the DHCP server does not find any DNS server, the DNS fields will be set to "0.0.0.0".
Network IP Mode	IPv4 Only	
Bar Code Label Length Reported to Host	8	
SNMP	Disabled	
Event Notification	Disabled	
User Access		Restore from Operator Control Panel or Web User Interface
Admin	secure	(default)
Library Mode	Random	
Library Name	(Blank)	
Host Name		(Depends on MAC Address)
Logs & Traces Error Log Mode	Continuous	

Table 5-4. Factory Default Settings (continued)

Restored Item	Default Setting*	Comments
Path Failover Key	No change	License Key is protected, if previously entered.
OCP Access PIN	Disabled	If OCP Access PIN has been enabled the default PIN is "1234".
SSL for Web	Disabled	
Drives		
Power	Power On	(All drives)
Drive 1 SCSI-ID	4	SCSI Drives
Drive 2 SCSI-ID	5	SCSI Drives
Drive 3 SCSI-ID	6	SCSI Drives
Drive 4 SCSI-ID	8	SCSI Drives
Drive 1 Loop-ID	4	FC Drives Arbitrated Loop
Drive 2 Loop-ID	5	FC Drives Arbitrated Loop
Control Path Drive	Drive 1 only	
Speed	Auto	FC Drives (all)
Topology	LN-Port	FC Drives (all)
IPv6 Stateless Autoconfig	Off	
Note: * = all settings at library firmware level 4.xx and greater		

In some cases, (such as Library Mode), the entry of one option precludes any other options from being selected. In such cases, the details of the non-applicable options are not shown.

Configure: Set Date and Time

Use this menu item to set the current date and time in your library.




Figure 5-19. Configure: Set Date and Time menu

Configure: Path Failover

Use this menu item to enter the Path Failover Feature Activation key (4U library only).




Figure 5-20. Configure: Path Failover

Path Failover is a combination of two previous features: Control Path Failover (key entered at the library user interface) and Data Path Failover (key entered at the device driver interface). A single activation key entered at the library user interface now activates both features unless the LTO-3 drive firmware level is equal to or lower than 73P5 and/or the library firmware is equal to or lower than 1.95. For either or both of these two cases, the device driver interface Data Path Failover key activation will still be required. The Path Failover feature is available for select LTO 4 tape drives. Path Failover is not supported for half high drives.

Service Menu

The 2U/4U library is always online, except for when the user enters the Service Library area. A warning message appears stating that the library should be taken offline from the host before performing any Service functions. It is up to the operator to ensure that it is taken offline by phoning the host operator or other means of communication. Before performing any service functions, ensure the host is not performing any data writing or retrieval.

The **Service Menu** contains the following items:

- Library Verify - an overall library diagnostic
- Run Tests - other library diagnostics
- Service - diagnostics and procedures for servicing the drive
- Display Contrast - setting the display from light to dark

Service: Library Verify

This is an overall diagnostic that exercises all library components. To run the Library Verify test, complete the following procedure.




Figure 5-21. Service: Library Verify menu

1. On the Operator Control Panel, navigate to **Service** → **Library Verify** and start diagnostic.
2. When prompted by the Operator Control Panel display and the I/O Station opens, insert a blank or scratch data cartridge.
3. Close the I/O Station by pushing it back into the library.
4. While the test is running, the Operator Control Panel will display library status.
 - If the test PASSES, resume normal library operations.

- If the test FAILS, an error code will be displayed. Make note of the error, then refer to Chapter 7, "Troubleshooting," on page 7-1.
5. When prompted by the Operator Control Panel display and the I/O Station opens, remove the cartridge used in the test.
 6. Close the I/O Station by pushing it back into the library.
 7. Press **Cancel** to exit the **Library Verify** screen.

Service: Run Tests




Figure 5-22. Service: Run Tests menu

The following library diagnostics are available in this menu:

- **System Test** - this test exercises library components by moving customer data cartridges from slots to drives and back to slots. No data is written or read from the customer tapes. To run this test successfully, the library must contain at least one data cartridge for every drive present in the library.
- **Slot to Slot Test** - The Slot To Slot test will move each resident data cartridge from one slot to another, for each test cycle requested. When completing the Slot To Slot test, you will need to **Inventory** your library before placing it back online, since this test scrambles the cartridge slot locations.

Note: After running the System Test or the Slot to Slot Test, the library will need to be re-inventoried.

Service: Service (Drives)




Figure 5-23. Service: Service menu

The following drive diagnostics and service procedures are available in this menu:

- **Clean Drive** - The accessor takes the cleaning cartridge from the dedicated cleaning cartridge slot (DCS), or previously reserved slot if no DCS is available, and inserts it into the drive. After the cleaning is complete, the accessor removes the cleaning cartridge from the drive and returns it to the dedicated cleaning cartridge slot or reserved slot.

- **Drive Tests** - Power On Self Test (POST), Wrap Test, Normal Read/Write Test, Head Test, Media Test

Note: The Operator Control Panel will display "Wrap Test" for libraries containing SCSI and Fibre Channel tape drives. "Wrap A Test" and "Wrap B Test" will be displayed for libraries containing SAS tape drives. Run both wrap tests (A & B) on SAS full high tape drives to test both SAS ports. Run Wrap A test only on SAS half high tape drives as they only have one SAS port.

1. Navigate to the desired test (**Service** → **Service** → **Drive Tests**). Choose the drive if more than one is installed.
2. Follow the instructions displayed on the Operator Control Panel, and, if required, insert a blank or scratch cartridge into the I/O Station when requested. All wrap tests require a wrap tool to perform the diagnostic.
3. The test will execute.
 - If the test PASSES, resume normal library operations.
 - If the test FAILS, an error will be displayed. Make note of the error, then refer to "Isolating Drive Sled Problems" on page 7-10.
4. Remove the cartridge from the I/O Station, if needed, then close the I/O Station.
5. Press **Cancel** to exit the screen.

- **Drive Power** - use this item to turn drive power ON and OFF

Service: Display Contrast




Figure 5-24. Service: Display Contrast menu

The following display contrast settings are available in this menu:

- The numbers **1** through **10** will display, with **10** being the lightest shade and **1** being the brightest.

Service: Telnet Service Port

The Telnet Service Port menu item is to be used under the direction of the IBM Support Center. Refer to "Accessing the Library using Telnet" on page A-26.

Web User Interface Menus

The following menus are available on the Web User Interface.

Table 5-5. Web User Interface Menus

■ Monitor Library
Library Identity
Drives Identity
Library Status
Drives Status

Table 5-5. Web User Interface Menus (continued)

	Inventory
■	Manage Library
	Move Media
	Perform Inventory
	Release Magazine
■	Configure Library
	General
	Logical Libraries
	Path Failover
	Encryption
	Drives
	Network
	User Access
	Date & Time
	Logs & Traces
	Event Notification
	Restore Defaults
■	Service Library
	Clean Drive
	Advanced Diagnostics (for Service Personnel only)
	View Logs
	View Drive Logs
	Save Drive Dump
	Perform Diagnostics
	Key Path Diagnostics
	Upgrade Firmware
	Reboot

Monitor Library Menu

The **Monitor Library** menu contains the following sub-menu items.

- “Monitor Library: Library Identity”
- “Monitor Library: Drive Identity” on page 5-32
- “Monitor Library: Library Status” on page 5-34
- “Monitor Library: Drive Status” on page 5-35
- “Monitor Library: Inventory” on page 5-37

Monitor Library: Library Identity

This page provides access to the static information about the library. No changes can be made from this page. Table 5-6 on page 5-32 lists all available elements on the Library Identity page. An “X” indicates that the element displays for the specified library type.

Table 5-6. Library Identity page elements

Menu Item	Description	2U	4U
Serial Number	This is the unique identification number assigned by the manufacturer.	X	X
Product ID	This is the SCSI inquiry string of the library	X	X
Currently Installed Library Firmware	This is the current level of firmware installed on the library. To ensure you are running the latest version of firmware, visit http://www.ibm.com . For information on updating your firmware, refer to “Service Library: Upgrade Firmware” on page 5-57.	X	X
Bootcode Firmware Revision	This is the level of bootcode firmware currently installed on the library. Bootcode is the firmware that allows the library to begin initialization when it is powered ON.	X	X
IPv4 Address	This is the Internet Protocol v4 Address assigned to your library.	X	X
Link local IPv6 address	This is the local IPv6 address assigned to your library.	X	X
IPv6 static assigned address	This is your library’s IPv6 static assigned address.	X	X
Router discovery IPv6 address	This is the IPv6 router discovery address assigned to your library.	X	X
MAC Address	This is the machine’s access code assigned to your library.	X	X
WWide Node Name	This is the Worldwide Node Name assigned to your library.	X	X
Logical Library x Library Mode	The Extended Logical Libraries Information table displays information about the logical libraries currently assigned in your library. For each logical library in your library, either Random or Sequential Loop Autoload will be displayed.	X	X

Library Identity	
Serial Number	78B0368
Product ID	3573-TL
Currently Installed Library Firmware	7.AH / 2.70e
Bootcode Firmware Revision	0.50
IPv4 Address	9.11.219.162
Link local IPv6 address	FE80::20E:11FF:FE10:68B0
IPv6 static assigned address	2002:90B:E002:219:9:11:224:30
Router discovery IPv6 address	2002:90B:E002:219:20E:11FF:FE10:68B0
MAC Address	000E111068B0
WWide Node Name	2000000E111068B0

Extended Logical Library Informations	
Logical Library 1 Library Mode	Random
Logical Library 2 Library Mode	Sequential Loop Autoload
Logical Library 3 Library Mode	Random
Logical Library 4 Library Mode	Sequential Loop Autoload

Figure 5-25. The 4U library Monitor Library: Library Identity page

Monitor Library: Drive Identity

This page provides the following detailed information about the drive. No changes can be made from this page. The displayed information will vary depending on the library model and drive type (SCSI, SAS, or Fibre Channel). Table 5-7 on page 5-33

5-31 lists all available elements on the Drive Identity page. An "X" indicates that the element displays for the specified drive type.

Table 5-7. Drive Identity page elements

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
Vendor ID	This identifies the manufacturer of the tape drive.	X	X	X	X	X	X
Product ID	This is the SCSI inquiry string of the tape drive.	X	X	X	X	X	X
Serial Number	This is the unique identification number of the tape drive that was assigned by the manufacturer.	X	X	X	X	X	X
Firmware Revision	This is the current level of firmware installed on the drive. To ensure you are running the latest version of firmware, visit http://www.ibm.com . For information on updating your firmware, refer to "Service Library: Upgrade Firmware" on page 5-57.	X	X	X	X	X	X
SCSI ID	This is the unique identifier assigned to the SCSI drive to enable it to receive communications from the host computer.	X			X		
Element Address	This is the unique identifier assigned to the drive that allows the host to recognize and communicate with the drive.	X	X	X	X	X	X
Control Path Drive	If the drive communicates all messages from the host to the library, then it is considered the control path drive. If the drive is the control path drive, this element displays "Yes." If not, this element displays "No." All drives in a logical library may be a control path drive.	X	X	X	X	X	X
Data Compression	If the drive is compressing data, this element displays "Yes." If not, this element displays "No."	X	X	X	X	X	X
Interface Type	This identifies Fibre Channel drives.		X			X	
Node Name	This is the Worldwide node Name assigned to a Fibre drive.		X			X	
Worldwide ID	This is the Worldwide ID assigned to a SAS drive.			X			X
Port A	This port is always "enabled."		X	X		X	X
Port Name	This is the name assigned to Port A on the drive.		X	X		X	X
Topology	This is the type of connection to the host.		X			X	
FC-AL Loop ID	This is the Fibre Channel - Arbitrated Loop ID of the drive.		X			X	
Speed	This is the current speed setting of the drive. Choices are Auto (where the drive will automatically negotiate the speed of the drive to match that of the server), 1Gb/s, 2Gb/s or 4 Gb/s.		X			X	
Port B	This port is enabled for full high SAS drives only.			X			X

Drive Identity	1 (LUN)
Vendor ID	IBM
Product ID	ULTRIUM-HH4
Serial Number	1K10000195
Firmware Revision	7A31
World Wide ID - Port A	5000E111068B0002
World Wide ID - Port B	5000E111068B0003
Element Address	256
Control Path Drive	Yes
Data Compression	Yes
Interface Type	SAS

Drive Identity	2 (LUN)
Vendor ID	IBM
Product ID	ULTRIUM-HH3
Serial Number	1H00000683
Firmware Revision	73P9
SCSI ID	6
SCSI Element Address	256
Control Path Drive	Yes
Data Compression	Yes
Interface Type	SCSI

Drive Identity	3 (LUN)
Vendor ID	IBM
Product ID	ULT3580-TD4
Serial Number	1300000682
Firmware Revision	77B1
Element Address	256
Control Path Drive	Yes
Data Compression	Yes
Interface Type	Fibre Channel
Node Name	2007000E111068B0
Port A	Enabled
Port Name	2008000E111068B0
Topology	LN-Port
FC-AL Loop ID	06
Speed	Automatic
Port B	Disabled

a77ug091

Figure 5-26. The 4U library Monitor Library: Drive Identity page showing one SAS (#1), one SCSI drive (#2), and one Fibre Channel drive (#3)

Monitor Library: Library Status


This page displays the dynamic information about the library, such as the current status of the components. No changes can be made from this page. Table 5-8 lists all available elements on the Library Identity page. An "X" indicates that the element displays for the specified library type.

Table 5-8. Library Status page elements

Menu Item	Description	2U	4U
Status	Library status is displayed using icons with text. A checkmark with the word "Ready" indicates the library is functioning properly. An exclamation point with the word "Caution" indicates the library can function, but is experiencing a problems. An X with the word "Error" indicates the library is not functioning because of a serious problem.	X	X
Cartridge in Transport	This identifies a cartridge that is currently being moved by the accessor. "None" is displayed if no cartridge is being moved.	X	X

Table 5-8. Library Status page elements (continued)

Menu Item	Description	2U	4U
Number of Moves	This is the number of times the accessor has moved a cartridge from Point A to Point B (for example, from a storage slot to a drive).	X	X
Total Power On Time	This is the total amount of time that the library has been powered ON.	X	X
Accessor Status	This is the current status of the accessor.	X	X
Left Magazine	This displays whether the left magazine is "Present" or "Not Present".	X	
Right Magazine	This displays whether the right magazine is "Present" or "Not Present".	X	
1. Left Magazine	This displays whether the lower left magazine is "Present" or "Not Present".		X
1. Right Magazine	This displays whether the lower right magazine is "Present" or "Not Present".		X
2. Left Magazine	This displays whether the upper left magazine is "Present" or "Not Present".		X
2. Right Magazine	This displays whether the upper right magazine is "Present" or "Not Present".		X



a77ug092

Figure 5-27. The 4U library Monitor Library: Library Status page

Monitor Library: Drive Status

This page provides the following detailed dynamic information about the drive in the library. No changes can be made from this page. The displayed information will vary depending on the library model and drive type (SCSI, SAS, or Fibre Channel). Table 5-9 lists all available elements on the Drive Status page. An "X" indicates that the element displays for the specified drive type.

Table 5-9. Drive Status page elements

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
Status	This is the current status of the drive. A checkmark indicates that the drive is operating properly. An exclamation point indicates that the drive is operating but has a problem. An X indicates that the drive is not operational because of a serious problem.	X	X	X	X	X	X
Cartridge in Drive	This is the serial number of the cartridge currently in the drive. If the drive does not contain a cartridge, "None" is displayed.	X	X	X	X	X	X

Table 5-9. Drive Status page elements (continued)

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
Drive Error Code	If the drive has generated an error code, it is displayed here. If the drive has not generated an error, "No Error" will be displayed.	X	X	X	X	X	X
Drive Activity	This indicates whether or not the drive is operating.	X	X	X	X	X	X
Port A Status	This indicates whether Port A is logged on or out.		X	X		X	X
Port Name	This is the name assigned to Port A on the drive.		X			X	
Speed	This is the current speed setting of the drive. Choices are Auto (where the drive will automatically negotiate the speed of the drive to match that of the server), 1Gb/s, 2Gb/s, or 4Gb/s.		X			X	
Topology	This is the type of connection to the host. N-Port ID		X			X	
FC-AL Loop ID	This is the Fibre Channel - Arbitrated Loop ID of the drive.		X			X	
Hashed SAS Address	The Hashed SAS address is a value which is calculated from the WWID for use on the SAS interface			X			X
Encryption Status	This shows the status of any encryption that is enabled on the drive.	X	X	X	X	X	X
Encryption method	This is the type of encryption that is enabled on the drive.	X	X	X	X	X	X
Key path	This is the path used for transferring an encryption key. This setting is dependent upon the encryption method selected.	X	X	X	X	X	X
BOP policy	This indicates whether the Beginning of Partition (BOP) policy is enabled or disabled.	X	X	X	X	X	X
Density reporting	This setting determines whether the drive shows or masks encryption.	X	X	X	X	X	X

Drive 1 Status At 10:02:00 Library Time

Status	☒ Ready
Cartridge In Drive	None
Drive Error Code	No Error
Drive Activity	Ready

Drive 3 Status At 10:02:00 Library Time

Status	☒ Ready
Cartridge In Drive	None
Drive Error Code	No Error
Drive Activity	Ready
Port A Status	Not ready, not connected
Speed	-
Hashed SAS address	000000
Port B Status	Not ready, not connected
Speed	-
Hashed SAS address	000000
Encryption Status	
Encryption method	Library managed
Key path	Default by method
BOP policy	Int label select
Density reporting	Other

Refresh

a77ug093

Figure 5-28. The 4U library Monitor Library: Drive Status page

Monitor Library: Inventory

This page provides detailed information about the tape inventory in the library. A summary of each magazine is shown. To get detailed information about the cartridges that reside in a magazine, click on the + button. This will expand the display for the magazine. To determine whether a cartridge is encrypted, refer to the Comments column in the Cartridge Details screen.





Figure 5-29. The 2U library Monitor Library: Inventory page

Note: On some 2U Libraries prior to Library Microcode Level 1.90, slot 11 may be labelled a "Not Used" slot which contained a "Slot Blocker". With Library Microcode level 1.9 or higher, there is an option to remove the "Slot Blocker" and place that slot into use. See "Removing the Slot Blocker - 2U Library" on page 10-10.

10
11
12
13



Cartridge details for 2. Left Magazine

1. Right Magazine - Slot inventory

33	32	31	30	1. Right Magazine 
29	28	27	26	
25	24	23	22	

Cartridge details for 1. Right Magazine

2. Right Magazine - Slot inventory

CLNI07L1	45	44	43	42	2. Right Magazine 
41	3SR023L3	40	39	38	
37	36	35	34		

Cartridge details for 2. Right Magazine

Slot #	Attn	Status	In Drive	Label	Media Loads	Comment
I/O Station 1	Closed	Empty		-----		
I/O Station 2	Closed	Empty		-----		
I/O Station 3	Closed	Empty		-----		
1		Empty		-----		
2		Empty		-----		
3		Empty		-----		
4		Empty		-----		
5		Full, Gen. 4		3IR115L4	6773	Encrypted
6		Full, Gen. 4		3FR016L4		
7		Full, Gen. 4		3IR101L4	3505	Encrypted
8		Empty		-----		
9		Empty		-----		

a77ug099

Figure 5-30. The 4U library Monitor Library: Inventory page

Manage Library Menu

Manage Library: Move Media

This page allows the user to move tape cartridges within the library. The source and destination are selected and then the MOVE button in the center of the screen is clicked to activate the move.

Source			Destination		
	Element	Volume Serial		Element	Volume Serial
☐	Slot 15 (1)		☐	Drive 1 (1)	
☐	Slot 19 (1)	3TX370L3	☐	Drive 2 (2)	
			☐	I/O Station 1	
			☐	I/O Station 2	
			☐	I/O Station 3	
			☐	Slot 1 (1)	
			☐	Slot 2 (1)	
			☐	Slot 3 (1)	
			☐	Slot 4 (1)	
			☐	Slot 5 (1)	
			☐	Slot 6 (1)	
			☐	Slot 7 (1)	
			☐	Slot 8 (1)	
			☐	Dedicated cleaning slot	

Move >

Figure 5-31. Manage Library: Move Media page

The following elements appear in the **Source** and **Destination** screens.

Element

In the **Source** screen, this identifies the library element that contains a cartridge. In the **Destination** screen, this identifies the library element that is empty and can receive a cartridge.

Volume Serial

In the **Source** screen, this element displays the serial number of the cartridge. In the **Destination** screen, this element contains no information.

Manage Library: Perform Inventory

This page allows the library to be re-scanned to determine the current media inventory.

Perform Inventory

Rescan

Figure 5-32. Manage Library: Perform Inventory page

Manage Library: Release Magazine

This page allows the user to release the right or left magazine from the library.

Release Magazine

Magazine

Right

Release

Figure 5-33. Manage Library: Release Magazine page

Note: To manually release a magazine, see “Releasing the Magazines Manually” on page 9-1. However, this manual process should only be used if the magazine cannot be released using the Operator Control Panel or the Web User Interface.

Configure Library Menu

The **Configure Library** menu contains the following sub-menu items:

- “Configure Library: General”
- “Configure Library: Logical Libraries” on page 5-42
- “Configure Library: Path Failover” on page 5-43
- “Configure Library: Encryption” on page 5-43
- “Configure Library: Drives” on page 5-46
- “Configure Library: Network” on page 5-47
- “Configure Library: User Access” on page 5-50
- “Configure Library: Date & Time” on page 5-51
- “Configure Library: Logs & Traces” on page 5-51
- “Configure Library: Event Notification” on page 5-52
- “Configure Library: Restore Defaults” on page 5-52

Configure Library: General

This page allows you to make changes to general library configuration elements. As changes are made, they will only be applied after the **Apply Selections** or the **Submit** button is selected. After making the selection, a warning page will inform you of the impact of the proposed change. In some cases a pop-up screen will ask for confirmation. Many changes will also require a library reboot.

Table 5-10. Configure Library: General page elements

Menu Item	Description	2U	4U
Library Name	Enter the name of the library.	X	X
I/O Station Enabled	The I/O Station defaults to I/O Station Enabled . Choosing Disabled (no checkmark) adds one more storage slot to the 2U library, and 3 more storage slots to the 4U library. When the I/O Station is disabled, removing or adding media to the library must be performed by releasing the left and/or right magazine(s).	X	X
Auto Clean Enabled	Auto Clean defaults to Disabled . For Auto Clean to function, a cleaning cartridge (CLNxxxLx) must be resident in a reserved library slot and Auto Clean must be enabled (turned on).	X	X
Bar Code Label Length Reported To Host	The default bar code label length is 8, but can be set to 6. The bar code label length is a “reported” length. This setting will cause the host computer to only see the first 6 characters of the label or all 8 characters. This setting does not affect the bar code label that is shown on any of the library user interfaces (always shows all 8 characters).	X	X

Table 5-11. Configure Library: Specific page elements

Menu Item	Description	2U	4U
Library Mode	Choices are Random and Sequential. If you choose Sequential, you may also activate Autoload and/or Loop. If there is more than one logical library, there is a Library Mode entry for each logical library. Important: If a Logical Library in Sequential Mode contains more than one drive, only the first drive in the Logical Library will be utilized.	X	X
Active Slots	It may be necessary to modify the number of active slots to agree with the number of slots allowed by your host software. To modify the number of active slots in your library, click on the drop down list and select the number of slots you want active in your library. Also, the Auto Clean function requires the cleaning cartridge to be in a DCS or reserved slot. Reserved slots are created by reducing the number of active slots.	X	X

General	
Library Name	
I/O Station Enabled	☒
Auto Clean Enabled	☒
Barcode Label Length Reported To Host	8 v

Extended Configuration for Logical Libraries	
Logical Library 1	
Library Mode	☒ Random ☐ Sequential ☐ Autoload ☐ Loop
Active Slots	21 v
Logical Library 2	
Library Mode	☒ Random ☐ Sequential ☐ Autoload ☐ Loop
Active Slots	23 v

Figure 5-34. The 4U library Configure Library: General and Extended page

Configure Library: Logical Libraries

To partition your multi-drive library, select the number of logical libraries you would like to create in your library, then click **Submit**.

One cartridge magazine cannot be assigned to two logical libraries. If you partition a multi-drive library, each of the magazines must be assigned to a logical library on a magazine boundary. The entire magazine must be part of one logical library only. In a fully populated 4U library with four logical libraries, resource assignments will be as follows:

- Logical Library 1 will contain Drive 1 and the lower left cartridge magazines.
- Logical Library 2 will contain Drive 2 and the upper left cartridge magazines.
- Logical Library 3 will contain Drive 3 and the lower right cartridge magazine.
- Logical Library 4 will contain Drive 4 and the upper right cartridge magazine.

The I/O Station and the reserved slot (or dedicated cleaning slot (DCS) if one is assigned) are shared among all logical libraries.

Note: When reducing the number of drives in your library, update the Logical Library configuration. This will remove the Attention LED on the front panel and the exclamation mark on the Home screen indicating that a drive is missing.

Updating the Logical Library configuration will also update the drive element addressing and drive numbering. Replacing LTO half high drives with full high drives may require you to execute **Restore Factory Defaults** to correctly update the drive element addressing and drive numbering. See “Configure Library: Restore Defaults” on page 5-52.

Figure 5-35. The 4U library Configure Library: Logical Libraries page

Configure Library: Path Failover

This page allows the user to enter the Path Failover feature activation key. Path Failover is a combination of two previous features: Control Path Failover (key entered at the library user interface) and Data Path Failover (key entered at the device driver interface). A single activation key entered at the library user interface now activates both features unless the LTO-3 drive firmware level is equal to or lower than 73P5 and/or the library firmware is equal to or lower than 1.95. For either or both of these two cases, the device driver interface Data Path Failover key activation will still be required. The Path Failover feature is available for select LTO 4 tape drives. Path Failover is not supported for half high drives.

Figure 5-36. The 4U library Configure Library: Path Failover page

After clicking **Activate**, this page will display if you have entered the feature key correctly.

Figure 5-37. Path Failover license verification page

Configure Library: Encryption

Note: Application Managed Encryption (AME) does not require a license key. Library Managed Encryption (LME) and System Managed Encryption (SME) require a license key which is available by purchasing Feature Code 5900. In addition to the feature license key, SME and LME require the implementation of an external Encryption Key Manager (EKM), to provide and manage encryption keys. With AME, encryption key management is handled by the application.

Prerequisites for Application Managed Encryption:

- SAS and Fibre Channel LTO Ultrium 4 Tape Drive (Full High or Half High)
- Ultrium 4 Tape Cartridge
- Library firmware level 4.0 or higher
- Drive firmware level 74H4 or higher
- Application capable of managing encryption keys.

Note: At the publication of this manual, the only application with this capability is Tivoli Storage Manager.

Prerequisites for Library Managed Encryption and System Managed Encryption

- Feature Code 5900 (Transparent LTO Encryption)
- SAS and Fibre Channel LTO Ultrium 4 Tape Drive (Full High or Half High)
- Ultrium 4 Tape Cartridge
- Library firmware level 4.0 or higher
- Drive firmware level 74H4 or higher
- Encryption Key Manager application

EKM applications include the following:

- Encryption Key Manager (EKM)
- Tivoli Key Lifecycle Manager (TKLM)

Unless specifically stated otherwise, this manual will use the term "EKM" to infer the Encryption Key Manager or the Tivoli Key Lifecycle Manager.

Setting or Changing a Drive's Method of Encryption

1. Enter your library's IP Address in an internet browser address field and press ENTER.
2. Log in to the Web User Interface. Refer to "Login" on page 2-5.
3. Expand **Configure Library** in the left navigation pane.
4. Click **Encryption**.




Figure 5-38. Feature Activation Key screen

5. On the **Encryption** screen, enter the **Feature Activation Key** to make available the library managed and the system managed encryption options.
6. Click **Activate** to save the key and expand the screen for additional encryption settings.

Encryption	
Feature Activation Key	Encryption is currently licensed on this library.
Enable SSL for EKM	☐
Encryption Setting for Logical Library 1	
Encryption method	None
Encryption policy	Encrypt All
EKM Server Setting	
Primary IP address (IPv4)	0.0.0.0 IPv4 address or Host name and domain
Primary TCP port	3801
Secondary IP address (IPv4)	0.0.0.0 IPv4 address or Host name and domain
Secondary TCP port	3801
Advanced Encryption Settings (for Engineering Support use only)	
Encryption method	No Advanced Setting
Encryption policy	No Advanced Setting
Encryption density	No Advanced Setting
Encryption key path	No Advanced Setting
Refresh Submit	

a77ug150

Figure 5-39. Configure Library: Encryption Feature configuration screen

7. Select **Enable SSL for EKM** to enable Secure Sockets Layer for the Encryption Key Manager application.
8. Select an **Encryption method** for each logical library.
 - Without an encryption license key, select **None** or **Application Managed Encryption**.
 - With an encryption license key, select **Library Managed Encryption** or **System Managed Encryption**.
9. Select an **Encryption policy** for each logical library.
 - **Encrypt All**: This is the default policy. It encrypts all cartridges using the default data keys specified in the EKM. This setting applies to all drives in the 3573 logical library.
 - **Internal Label - Selective Encryption**: This policy is based on the internal volume label information. Currently, the only application that supports this option is Symantec NetBackup. Only encrypts cartridges with pool identifiers between 1500 and 9999 (inclusive), using keys specific to each pool. Labels for these keys are generated by the tape drive based on the pool identifier; for instance, key label IL_NBU_1505 would be generated for a cartridge in pool 1505.
 - **Internal Label - Encrypt All**: This policy is based on the internal volume label information. Currently, the only application that supports this option is Symantec NetBackup. Encrypts all cartridges. Cartridges with pool identifiers between 2000 and 65535 (inclusive) are encrypted with keys specific to each pool. Labels for these keys are generated by the tape drive based on the pool identifier; for instance, key label IL_NBU_2505 would be generated for a cartridge in pool 2505.
10. A primary and secondary EKM server can be set for each logical library. Each partition has its own Encryption and EKM settings. Maintaining primary and

secondary EKM servers is desired for maximum availability of encrypted backup and recovery. These settings are required for Library Managed Encryption only. Enter the **EKM Server Setting** information.

- **Primary IP address (IPv4 or IPv6):** Enter the IP address of the primary EKM server.
- **Primary TCP port:** After entering the Primary IP address, the library will automatically set the value of the Primary TCP port.
- **Secondary IP address (IPv4 or IPv6):** Enter the IP address of the secondary EKM server.
- **Secondary TCP port:** After entering the **Secondary IP address**, the library will automatically set the value of the **Secondary TCP port**.

Note: The Default Port for TCP (SSL disabled) is **3801**. The Default Port for SSL is **443**. These values are the default values set by the library. They can be changed depending on the user configuration but the user has to make sure they match the EKM properties file.

Note: The Advanced Encryption Settings are for Engineering Support only.

11. Click **Activate** to apply the changes.
12. Record the Feature Activation Key (or apply one of the labels) on the Appendix G, "Library Configuration Form," on page G-1 for future reference. **It is important to save your extra Feature Activation Key labels in a secure location for future reference.**
13. Install the Encryption Key Manager (EKM) application on your host. Refer to the EKM documentation for detailed instructions (refer to the EKM documents listed in "Related Publications").

Configure Library: Drives

This page allows you to modify the current ID assigned to a SCSI or Fibre Channel drive. This page allows any drive in the library to be powered off by de-selecting the check mark in the Power On box. The displayed information will vary depending on the library model and drive type (SCSI, SAS, or Fibre Channel). Table 5-12 lists all available elements on this page. An "X" indicates that the element displays for the specified drive type.

Table 5-12. Drive Identity page elements

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
SCSI ID	For each SCSI drive, click on the drop down list and select the number of the slot in which the drive is located.	X			X		
Power On	For each drive, click in the box to power ON the selected drive.	X	X	X	X	X	X
Control Path	The control path drive communicates messages from the host to the library. Select this option for each drive that you want to be a control path drive. At least one drive in each logical library must be designated as a control path drive.	X	X	X	X	X	X
Port A Configuration:							

Table 5-12. Drive Identity page elements (continued)

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
Speed	For each Fibre Channel drive, click on the drop down list and select Automatic, 1Gb/s, 2Gb/s, or 4 Gb/s. Selecting Automatic will allow library speed to automatically negotiate to the current server speed.		X			X	
Port Type	For each Fibre Channel drive, click LN-Port, L-Port, or N-Port.		X			X	
Loop ID	This is the loop position number if the drive is in an arbitrated loop configuration.		X			X	
Port B Configuration:							
	Port B is supported for SAS full high drives only.			X			X

Drives

Drive 1 (Logical Library 1) ☒ Power On ☒ Control Path
Note: SAS drives do not require user configuration

Drive 2 (Logical Library 2) ☒ Power On ☒ Control Path

SCSI ID 6

Drive 3 (Logical Library 3) ☒ Power On ☒ Control Path

Port A Configuration

Speed Automatic

Port Type LN-Port

Loop ID 6

Port B Configuration Port not available

Refresh Submit

Figure 5-40. The Configure Library: Drive page for a 4U library

Configure Library: Network

This page shows the current network configuration of the library and allows modification to the configuration. When a change is requested, a pop-up box checks to confirm the changes.

1. Click **Network** in the left navigation pane, to display the **Network** page.

Network	
Protocol Stack	IPv4 only ▼
Host Name	LIB1006DD
Domain Name	
DNS Primary	0.0.0.0
DNS Secondary	0.0.0.0
Enable SSL For Web	☐
Ethernet Settings	Auto ▼
IPv4	
Enable DHCP	☐ On
Static Address	9.11.219.139
Network Mask	255.255.255.0
Gateway address	9.11.219.1
IPv6	
Enable DHCP	☐
Enable Stateless Auto Config	☐
Static Address	0:0:0:0:0:0:0:0
Prefix length	64
Gateway address	0:0:0:0:0:0:0:0
SNMP	
Enabled	☐
Target 1 - IP Address	0.0.0.0 IPv4 address or Host name and domain
Version	SNMPv1 ▼
Target 2 - IP Address	0.0.0.0 IPv4 address or Host name and domain
Version	SNMPv1 ▼
Target 3 - IP Address	0.0.0.0 IPv4 address or Host name and domain
Version	SNMPv1 ▼
Community Name	public
Security User Name	initial
You will be required to login again if changes are made, except of changing snmp settings. If you change the IP address of the library then you will need to use the new IP address when you attempt to access the library again. Refresh Submit	

a77ug074

Figure 5-41. Configure Library: Network Page

2. Select a **Protocol Stack** - Choose **IPv4 only**, **IPv6 only**, or **Dual Stack IPv4 & IPv6**.

If you choose **Dual Stack IPv4 & IPv6**, you must be prepared to enter both IPv4 and IPv6 IP addresses. The sections below will gray out depending on the choices made here.

Note: When changes are made, the following Warning message will appear when the Submit button is clicked.

Warning: Changes Will Take Effect After A Reboot!

a77ug171

Figure 5-42. Warning Screen

The library must be rebooted or the changes will not take place.

3. Enter the **Host Name**.
4. Enter the **Domain Name**.
5. **DNS Primary** - Enter the IP address of your primary DNS server.
6. **DNS Secondary** - Enter the IP address of your secondary DNS server.
7. **Enable SSL for Web** - If you desire to have SSL (Secure Sockets Layer) enabled, place a check in this box.

Note: If you get a security certificate alert when logging in to the Web User Interface, you can install the certificate or allow an exception (depending on the internet browser you are using). SSL is enabled when the URL begins with **https://** and some browsers will show a lock.

8. **Ethernet Settings** - You can disable Ethernet settings, manually enable them, or let another machine enable them by using Dynamic Host Configuration Protocol (DHCP). You can also set a specific speed for the Ethernet port or specify the library to automatically negotiate the speed. Ethernet Settings choices are: **Auto** (the default), **10 Mbit/Half**, **10 Mbit/Full**, **100 Mbit/Half**, **100 Mbit/Full**.

9. **Enter IPv4 settings (if applicable).**

- a. **Enable DHCP** - Click this item ON to have the IP Address of your library automatically set by the DHCP server. If you are not using a DHCP server, leave unchecked and enter the appropriate information for the IP Address, Network Mask, and Gateway Address.
- b. **Static Address** - An identifier for a computer or device on a TCP/IP network. Networks using the TCP/IP protocol route messages based on the IP address of the destination. The format of an IP address is a 32-bit numeric address written as four numbers separated by periods. Each number can be zero to 255. For example, 1.160.10.240 could be an IP address.
- c. **Network Mask** - This address defines and limits users within a local network.
- d. **Gateway address** - This address allows access outside the local network.

10. **Enter IPv6 settings (if applicable).**

- a. **Enable DHCP** - Click this item ON to have the IP Address of your library automatically set by the DHCP server. If you are not using a DHCP server, leave unchecked and enter the appropriate information for the IP Address, Network Mask, and Gateway Address.
- b. **Enable Stateless Auto Config** - Click this item ON to have the IP Address of your library automatically set by the library host computer. Leave unchecked and enter the appropriate information for the static assigned IP Address, prefix length, and Gateway Address.
- c. **Static Address** - Enter the assigned IPv6 address. The format of an IPv6 IP address is a 128-bit numeric address written as 8 groups of four numbers separated by colons.
- d. **Prefix length** - The default prefix length is set to 64, but can be set to any length, depending upon the address used.
- e. **Gateway address** - This address allows access outside the local network.

11. **Enter SNMP settings.**

Note: For more information on SNMP, refer to "SNMP Messaging" on page 1-6 and Appendix F, "SNMP Status MIB Variables and Traps," on page F-1.

- a. **Enabled** - If you desire to have SNMP traps sent to an IP address of your choosing, place a check in this box.
- b. **Target 1-IP Address** - If SNMP traps are enabled, enter an IP address where SNMP traps are to be sent.
- c. **Target 2-IP Address** - Enter an optional 2nd IP address where SNMP traps are to be sent, or leave as 0.0.0.0.
- d. **Target 3-IP Address** - Enter an optional 3rd IP address where SNMP traps are to be sent, or leave as 0.0.0.0.
- e. **Version** - The library offers three versions of the SNMP protocol; v1, v2 and v3. Select a version for each Target IP Address.
- f. **Community Name** - An SNMP community name is a text string that acts as a password to authenticate messages sent between the SNMP remote management application and the library. Enter your preferred name, or leave as "public".
- g. **Security User Name** - In order to receive traps via SNMPv3 the SNMP client needs to be logged in properly. This is provided by this user name. Currently this field may not be changed.

Configure Library: User Access

This page allows the user to add and modify user accounts. See "Login" on page 2-5 for information on user types.

Figure 5-43. Configure Library: User Access page

The following elements are displayed on the **User Access** page.

Role The name associated with the chosen Access Level.

Check the **Disable Superuser** checkbox if you do not want **Superuser** to be listed on the Role listbox (i.e. prohibits Superuser login). Check the **Disable User** checkbox if you do not want **User** to be listed on the Role listbox (i.e. prohibits User login). Uncheck the checkbox(es) to allow **Superuser** or **User** login.

New Password

The password must be a maximum of ten characters .

Repeat Password

Enter the New Password again.

Support name

The name of the individual within your company to contact for Web User Interface or library support.

Note: Only one support person can be configured for the entire tape library. The support person may or may not be one of the user, superuser, or admin account holders.

Support phone

The phone number of the individual within your company to contact for Web User Interface or library support.

Support email

The email address of the individual within your company to contact for Web User Interface or library support.

Configure Library: Date & Time

This page allows the user to set the time and date, and how it will be displayed.

Figure 5-44. The Configure Library: Date & Time page

Time (24H)

Using a 24-hour format, enter the current hour, minutes, and seconds.

Date Enter the current month, day, and year.

Configure Library: Logs & Traces

This page allows service personnel to set the error log mode to **Continuous** or to **Stop trace at first error**.

Figure 5-45. Configure Library: Logs & Traces page

It is recommended that you select **Continuous** for the **Error Log Mode** so that all information for logs and traces will be captured.

Note: The trace level and trace filter selection options are only changeable by Service personnel.

Configure Library: Event Notification

This page allows the user to enter information for event notification. When set up correctly, **Event Notification** allows the library to send an email to a designated individual when the library is experiencing a problem.

Event Notification	
Notify Errors	☒ On
Notify Warnings	☒ On
To Email Address	xxxxx@us.ibm.com
SMTP Server Address (IPv4 or IPv6)	9.17.195.158 Host name and domain
Domain Name	

a77ug065

Figure 5-46. Configure Library: Event Notification page

The following elements are displayed on the **Event Notification** page.

Notify Errors

Select this item to be notified of library errors via email.

Notify Warnings

Select this item to be notified of library warnings via email.

To Email Address

Enter the email address of the individual you would like to receive the errors and/or warnings.

SMTP Server Address (IPv4 or IPv6)

Enter the address of the email server of the individual you would like to receive the errors and/or warnings. This can be an IPv4 or IPv6 address, or a host name and domain. If a host name and domain is listed, the IPv4 or IPv6 address will be resolved from the DNS using that name, and the address will be stored rather than the name. If the address changes, a new name or a new address will need to be entered.

Domain Name

Enter the Domain Name for your library. This field cannot be blank when using event notification.

Note: If you attempt to enter a blank value for the Domain Name, a warning message will appear. It will say **If you are using Event Notification then a value is required for the Domain Name.**

Configure Library: Restore Defaults

This page allows the library configuration to be reset to the factory defaults.

For information on factory default settings, see “Configure: Restore Defaults” on page 5-25. Be aware that when you restore your library to factory defaults, all configuration data in the library will be lost and will need to be reestablished.

Saving and restoring configuration data can be done using the Remote Management Unit (RMU) and/or the Operator Control Panel (OCP). The feature has been implemented on the RMU and on the OCP, but with slightly different functionality.

Note: Configuration files saved with one version of library firmware may not be compatible with other versions of firmware. It is recommended to save a configuration file each time the library firmware is upgraded. Restore the library using a configuration file that was saved with the same version of firmware currently installed in the library.

Since the RMU can be accessed remotely, its implementation will save/restore the configuration data to/from a file on the host site. When entering commands on the OCP, the unit is accessed directly. For this reason the OCP implementation will save/restore the configuration data to/from a USB memory stick that is inserted into the USB connector on the library controller.

The screenshot shows a web interface with two main sections. The top section, titled 'Restore Defaults', contains a sub-section 'Restore Factory Defaults' with a 'Restore' button. The bottom section, titled 'Save/Restore Configuration', contains two sub-sections: 'Save Configuration to File' with a 'Save' button, and 'Restore Configuration from File' with a text input field, a 'Browse...' button, and a 'Restore' button. A vertical label 'a77ug079' is visible on the right side of the bottom section.

Figure 5-47. Configure Library: Restore Defaults page

Service Library Menu

The 2U/4U library is always online, except for when the user enters the Service Library area. A warning message appears stating that the library should be taken offline from the host before performing any Service functions. It is up to the operator to ensure that it is taken offline by phoning the host operator or other means of communication. Before performing any service functions, ensure the host is not performing any data writing or retrieval.

Service Library: Clean Drive

This page allows the user to clean the tape drive. After the requested drive is cleaned, the screen will be greyed out. If you want to clean another drive, click on the Navigation bar "Service Library: Clean Drive" in the left column of your screen to activate the "Clean Drive" screen and select another drive. Click on "Clean".

Note: If Auto Clean is enabled and a cleaning cartridge is **not** present, or if a cleaning cartridge is present, but not in a reserved slot, Auto Clean status on the Web User Interface Status screen will show **Chk Media/Rsvd Slot?** and **Status** will show a green check mark and the words **Media Attention**.

Clean Drive	
Slot #	45
Drive	3
Clean	

Figure 5-48. Service Library: Clean Drive page

Service Library: Advanced Diagnostics (for Service Personnel Only)

This menu is for use by IBM Authorized Service Personnel only. Refer to “Writing a Drive Dump to Flash Memory” on page A-25.

Service Library: View Logs

This page allows the library logs to be viewed after entering the following:

- Log Type
 - **Error Trace:** Logs all the error messages
 - **Informational Trace:** Logs all the informational messages created as the library operates
 - **Warning Trace:** Logs all warning messages created by the library. Warning messages will not stop a library’s operation but does remind the user of issues that may become a problem. Example: Invalid Media.
 - **Configuration Change Trace:** Logs any configuration changes made, such as changing/adding partitions, changing SCSI addresses, removing a DCS, etc.
 - **Standard Trace:** Logs all library operations

Note: Ensure that all the pop-up facilities on the web browser are set to enable pop-up boxes to appear. For example, on Microsoft Internet Explorer, under **Tools**, ensure that the Pop-up Blocker is turned OFF and **Internet Options** → **Security** → **Custom Level** → **Downloads** → **Automatic Prompting** for file Downloads and **File Downloads** are both Enabled.

- Total Number of Entries
- Start Entry
- Number of Entries per Page
- View
- Clear Log - Clears the log you are viewing
- Dump Log - Dumps the log you are viewing
- Save Service Dump - Creates a DPA (Dump All) log output that can be viewed or saved to a file

View Logs	
Log Type	Error Trace
Total Number Of Entries	5
Start Entry	1
Number Of Entries Per Page	5
View Clear Log Dump Log Save Service Dump	

```

08.10.10 10:01:31.50 LIB/ERR <F4 98 > HE: drive load timeout
08.10.09 15:07:08.99 LIB/ERR <98 63 > HE: cartridge detection failed - Return status:
command failed
08.10.09 14:57:10.07 LIB/ERR <98 63 > HE: cartridge detection failed - Return status:
command failed
08.10.09 14:50:36.87 LIB/ERR <98 63 > HE: cartridge detection failed - Return status:
command failed
08.10.09 14:01:10.29 LIB/ERR <98 63 > HE: cartridge detection failed - Return status:
command failed

```

Figure 5-49. Service Library: View Logs page

Service Library: View Drive Logs

This menu item allows the user to view a drive log.

View Drive Logs	
Select Drive	1
Log Type	Error
Total Number Of Entries	0
Start Entry	1
Number Of Entries Per Page	5
View	

Figure 5-50. Service Library: View Drive Logs screen

Service Library: Save Drive Dump

This menu item allows a drive dump to be saved to the host computer. Once the **Save Drive Dump** button is clicked, the user will have the option of saving the drive dump to their hard drive. The progress status for the drive dump is shown on the System Status screen to the right of the main Web User Interface screen.

Note: Ensure that all the pop-up facilities on the web browser are set to enable pop-up boxes to appear. For example on the Microsoft Internet Explorer, under **Tools**, ensure that the Pop-up Blocker is turned OFF and **Internet Options -> Security -> Custom Level -> Downloads -> Automatic Prompting** for file Downloads and File Downloads are both Enabled.

Once saved on the hard drive, it can be e-mailed to Tech Support for analysis, if needed.

Note: The dump may take as long as 20 minutes to complete. The **System Status** portion of the screen shows "Drive Dump in Progress" with the number of

KBs transferred.



Figure 5-51. Service: Save Drive Dump

Service Library: Perform Diagnostics

Note: When running the “System Test”, the library must contain at least the same number of data cartridges as there are drives in that library. For example, if your library has 4 drives installed, you must have 4 or more data cartridges in the library prior to the start of the test. If there are fewer data cartridges than drives in the library, an error message “Slot Empty” will occur, and the test will not complete successfully.

This page provides the system administrator with general tests to verify the usability and reliability of the library. The “System Test” will use resident data cartridges to test the load and unload capability of the drives, and ensure that the library mechanics are working satisfactorily. No data will be written to the cartridges and the cartridges will be returned to their normal slot location. The “Slot To Slot” test will move each resident data cartridge from one slot to another, for each test cycle requested. When completing the “Slot To Slot” test, you will need to Inventory your library before placing it back online, since this test scrambles the cartridge slot locations.

The user selects the number of test cycles before starting the test from the EXECUTE button. To cancel the test before it completes the cycles, select the STOP button.

Note: The Web User Interface System Status screen will indicate progress and completion of the activity.



Figure 5-52. Service Library: Perform Diagnostics page

Service Library: Perform Key Path Diagnostics

Important: Ensure that library firmware and drive firmware are up to date before running the Key Path Diagnostic. Library firmware level must be greater than 6.xx. See “Verifying/Updating Firmware” on page 4-19.

The key path diagnostics test provides the ability to perform diagnostics on the encryption key path. Only drives that are set up for library managed encryption will be tested. All drives are listed in the test results, even if the drive is not enabled for library managed encryption.

The test consists of four parts:

- **Drive Test:** The library performs a drive communication test to confirm communication with the drive.
- **Ethernet Test:** For each EKM IP address, the library performs a ping test and records the results.
- **EKM Path Test:** For each EKM IP address that passed the ping test, the library performs an EKM communication test.
- **EKM Config Test:** This test confirms that a drive is correctly configured in the EKM to service key requests.

To run the Key Path Diagnostic, complete the following procedure.

1. Log on to the Web User Interface. Refer to “Login” on page 2-5.
2. Quiesce all drives, then unload all drives.
3. Click **Service**, then **Key Path Diagnostics**.

Drive	IP Address	Drive Test	Ethernet Test	EKM Path Test	EKM Config Test
1	9.11.221.224	Passed	Passed	Failed	N/A
	9.11.221.242	Passed	Passed	In Progress	
3	9.11.221.204	Passed	Passed	Failed	N/A
	9.11.221.224	Passed	Passed	In Progress	

Figure 5-53. Service Library: Perform Key Path Diagnostics page

4. Click **Start Tests**.

Note: If you have just enabled encryption on your library, wait for all LME drives to be displayed in the table and the **Start Tests** button to become active.

Each test will show a result of “Passed” or “Failed”. Test results will clear:

- When the test is rerun
- When the library is rebooted

The time and date of the last test will appear below the Key Path Diagnostics screen. If any of the tests fail, refer to Chapter 7, “Troubleshooting,” on page 7-1 for additional information.

Service Library: Upgrade Firmware

Note: The IBM System Storage™ TS3100 Tape Library and TS3200 Tape Library is a customer installed unit. The customer is responsible for the setup and maintenance of the tape library. The customer will be charged for service if a service contract is not in place.

Note: Library firmware and tape drive firmware are verified and released together. When updating to the latest firmware, verify that all installed components such as tape drive(s), and library are at the latest levels noted on the Support web site. Mixing different levels of library and tape drive firmware is not supported and may cause unpredictable results.

This page displays the current library and drive firmware versions. Firmware can be downloaded to the host then uploaded to the drive in the library by using this page.

In the first line you can see the actual loaded firmware revision or level installed on the drive. Click **Browse...** to choose the firmware file you have downloaded from the web site (the web site is <http://www.ibm.com/storage/support/>) on the first drive you want to update (You can not update 2 drives at the same time). Be sure you choose the correct firmware for your drive type. After pressing the **Update** button the file will be sent to the drive and the drive will be upgraded.

Note: During the update no host drive action is possible. The drive update takes approximately 5 minutes. The system status panel (in the right of the browser window) will change from "update" to "ready".

Upgrade Library Firmware	
Currently Installed Library Firmware	3.05
Library Firmware File	Browse...
	Update

Upgrade Drive 1 Firmware	
Drive Firmware Revision	73P0
Drive Firmware File	Browse...
	Update

a77ug081

Figure 5-54. The 2U library Service Library: Upgrade Firmware page

Upgrade Library Firmware	
Currently Installed Library Firmware	3.05
Library Firmware File	Browse...
	Update

Upgrade Drive 1 Firmware	
Drive Firmware Revision	73PA
Drive Firmware File	Browse...
	Update

Upgrade Drive 2 Firmware	
Drive Firmware Revision	73PA
Drive Firmware File	Browse...
	Update

a77ug097

Figure 5-55. The 4U library Service Library: Upgrade Firmware page

Service Library: Reboot

Important: Some options of the Web User Interface take the library OFFLINE. This inactive mode can interfere with host-based application software, causing data loss. Ensure that the library is idle before attempting to perform any remote operations that will take the library OFFLINE.

This page is used to perform a library reboot. There is a default time delay when the Web User Interface page refreshes itself. This time should be sufficient to reload the page. However, during a reboot, the connection to the library may be lost. If the connection is lost, the user will have to reload the page manually.




Figure 5-56. Service Library: Reboot page

Import and Export Media during Normal Library Operation

Import Media

Data cartridges can be inserted and taken out of a magazine while the library is in operation. If the library contains an I/O Station, and you wish to import media, follow these steps:

1. Go to **Main** → **Control** → **Open I/O Station**. The I/O Station will unlock itself.
2. Pull out the magazine and insert a data cartridge(s) into the I/O Station. On a 2U library, only 1 cartridge can be inserted at a time. On the 4U library, 3 cartridges can be inserted at one time.
3. Close the door of the I/O Station. The library will automatically start an inventory. The cartridges in the I/O Station will be counted but unassigned until they are moved into storage slots.
4. Go to **Main** → **Control** → **Move Cartridges** and move the data cartridges into the desired data slots. See “Control: Move Cartridges” on page 5-17 or “Manage Library: Move Media” on page 5-39 for more information.

If the library does not have an I/O Station (all slots are assigned to storage), and you wish to import media, you will need to release a magazine and insert the cartridges manually following these steps:

1. Go to **Main** → **Control** → **Magazine**. Choose the desired magazine to unlock/remove.
2. Pull out the magazine and insert a data cartridge(s) into the empty slots.
3. Push the magazine back into the library. The library will automatically start an inventory.
4. To move cartridges in the magazine once they are inserted, go to **Main** → **Control** → **Move Cartridges** and move the data cartridges into the desired slots. See “Control: Move Cartridges” on page 5-17 or “Manage Library: Move Media” on page 5-39 for more information.

Note: If you run a library configuration backup program on your host computer, use the program to run an audit of the library after new cartridges have been added to update the backup program.

Export Media

To remove cartridges from your library using your I/O Station, follow these steps:

1. Go to **Main** → **Control** → **Move Cartridges** and move the data cartridges into the I/O Station. See “Control: Move Cartridges” on page 5-17 or “Manage Library: Move Media” on page 5-39 for more information.
2. Go to **Main** → **Control** → **Open I/O Station**. The I/O Station will unlock itself
3. Pull out the magazine and take the data cartridge(s) out of the I/O Station
4. Push the magazine back into the library. The library will automatically start an inventory of the I/O station.

If you do not have an I/O Station (all slots are assigned to storage), and wish to export media, you will need to release a magazine and take out the cartridges manually following these steps:

1. Go to **Main** → **Control** → **Magazine**. Choose the magazine you wish to unlock/remove.
2. Pull out the magazine and remove the desired data cartridge(s).
3. Push the magazine back into the library. The library will automatically start an inventory.

Note: If you run a library configuration backup program on your host computer, use the program to run an audit of the library after cartridges have been removed to update the backup program.

Configuring I/O Stations and Reserving Slots

2U libraries usually have 1 slot for an I/O Station, while 4U libraries have 3 slots assigned as an I/O Station. These slots can be configured as storage if needed.

To configure the I/O Station using the Web User Interface, follow these steps.

- Go to **Configure Library->General**.
- To enable the I/O Station, place a check mark in the **I/O Station Enabled** box. If it is checked as enabled, the first 3 physical slots in the lower left magazine in a 4U or the first physical slot in the left magazine in a 2U is configured as an I/O station. If the I/O Station Enabled box is not checked, the slots are configured as storage.

Dedicated Cleaning Slot

Earlier versions of the 4U library contained a Dedicated Cleaning Slot (DCS). This DCS can be retained and is supported by future library firmware updates. Library firmware after 1.95 will allow removal of the DCS, thus enabling this slot to be used as a storage slot.

To remove the DCS, perform the following procedures using the Operator Control Panel (OCP).

1. Navigate to the Library Settings (Logical Library Settings) screen **Configure > Library Settings (or Logical Library Settings)**.
2. Select **General**.
3. Scroll down to **Remove DCS**.
4. Select **No** or **Yes**.
5. Select **Save** then press the **Enter** button.

Attention: If your library originally contained a Dedicated Cleaning Slot and was removed, it can only be reinstated by restoring factory default settings.

To enable automatic cleaning of the drives when needed, a slot must be reserved, a cleaning cartridge must be present in the reserved slot, and Auto Clean must be enabled.

Reserving Slots

Reserving a slot is accomplished by reducing the **Active Slot** count in any particular logical library. Slots are reserved beginning with the last available slot in the last magazine of the library. A cleaning cartridge in a reserved slot is available to any logical library drive even if the reserved slot is not in that logical library. Typically, if the library contains multiple logical libraries, the last logical library is chosen for the reserved slot containing the cleaning cartridge. As with a library with a single logical library, this slot is the last physical slot in the library (top right magazine, uppermost rear slot).

To reserve a cleaning slot, follow these steps.

- To reserve slots in your library, go to the Web User Interface at “Choosing General Library Settings” on page 4-20 or the Operator Control Panel at “Configure: Library” on page 5-20 to get directions on reducing the Active slot count.

Chapter 6. Using Ultrium Media

To ensure that your IBM Ultrium Tape Drive conforms to IBM's specifications for reliability, use only IBM LTO Ultrium tape cartridges. You may use other LTO-certified data cartridges, but they may not meet the standards of reliability that are established by IBM. Neither the IBM LTO Ultrium 400 GB Data Cartridge (Ultrium 3) nor the IBM LTO Ultrium 800 GB Data Cartridge can be interchanged with the media used in other IBM non-LTO Ultrium tape products.

Figure 6-1 shows the IBM LTO Ultrium 800 GB Data Cartridge and its components.




Figure 6-1. The IBM LTO Ultrium 800 GB Data Cartridge

- | | | | |
|----------|----------------------|----------|----------------------|
| 1 | LTO cartridge memory | 4 | Write-protect Switch |
| 2 | Cartridge door | 5 | Label area |
| 3 | Leader Pin | 6 | Insertion guide |

Data Cartridges

The different generations of IBM Ultrium data cartridges can be identified by color:

Type	Color
Ultrium 4	Green
Ultrium 4 WORM	Green and Silvery gray
Ultrium 3	Slate Blue
Ultrium 3 WORM	Slate Blue and Silvery gray
Ultrium 2	Purple
Ultrium 1	Black

All generations contain 1/2-inch, dual-coat, metal-particle tape.

You can order tape cartridges with the bar code labels included, or you can order custom labels. To obtain tape cartridges and bar code labels, see “Ordering Media Supplies” on page 6-18.

When processing tape in the cartridges, Ultrium Tape Drives use a linear, serpentine recording format. The native data capacity and recording format of Ultrium data cartridges is as follows:

Type	Native Data Capacity	Recording Format
Ultrium 4	800 GB (1600 GB at 2:1 compression)	Reads and writes data on 896 tracks, sixteen tracks at a time.
Ultrium 3	400 GB (800 GB at 2:1 compression)	Reads and writes data on 704 tracks, sixteen tracks at a time
Ultrium 2	200 GB (400 GB at 2:1 compression)	Reads and writes data on 512 tracks, eight tracks at a time
Ultrium 1	100 GB (200 GB at 2:1 compression)	Reads and writes data on 384 tracks, eight tracks at a time

The first set of tracks (sixteen for Ultrium 4 and 3; eight for Ultrium 2 and 1) is written from near the beginning of the tape to near the end of the tape. The head then repositions to the next set of tracks for the return pass. This process continues until all tracks are written and the cartridge is full, or until all data is written.

The cartridge door **2** protects the tape from contamination when the cartridge is out of the drive. The tape is attached to a leader pin **3**, behind the door. When the cartridge is inserted into the drive, a threading mechanism pulls the pin (and tape) out of the cartridge, across the drive head, and onto a non-removable take-up reel. The head can then read or write data from or to the tape.

The write-protect switch **4** prevents data from being written to the tape cartridge. For more information, see “Write-Protect Switch” on page 6-7.

The label area **5** provides a location to place a label. For more information, see “Bar Code Label” on page 6-5.

The insertion guide **6** is a large, notched area that prevents the cartridge from being inserted incorrectly.

Generation 3 and 4 of the LTO Ultrium Data Cartridge have a nominal cartridge life of 20,000 (20k) load and unload cycles. Generation 2 has a nominal cartridge life of 10,000 (10k) load and unload cycles. Generation 1 of the LTO Ultrium Data Cartridge has a nominal cartridge life of 5000 (5k) load and unload cycles.

Cartridge Compatibility

Table 6-1. Ultrium data and cleaning cartridge compatibility with Ultrium tape drive

IBM Ultrium Tape Drive	IBM LTO Ultrium Data Cartridges			
	800 GB (Ultrium 4)	400 GB (Ultrium 3)	200GB (Ultrium 2)	100GB (Ultrium 1)
Ultrium 4	Read/Write	Read/Write	Read only	
Ultrium 3		Read/Write	Read/Write	Read only
Ultrium 2			Read/Write	Read/Write

Table 6-1. Ultrium data and cleaning cartridge compatibility with Ultrium tape drive (continued)

IBM Ultrium Tape Drive	IBM LTO Ultrium Data Cartridges			
	800 GB (Ultrium 4)	400 GB (Ultrium 3)	200GB (Ultrium 2)	100GB (Ultrium 1)
Ultrium 1				Read/Write

Capacity Scaling

To control the capacity of the cartridge (for example, to obtain a faster seek time) issue the SCSI command SET CAPACITY. For information about this command, refer to the *IBM TotalStorage® Ultrium Tape Drive SCSI Reference*.

WORM (Write Once, Read Many)

Certain records retention and data security applications require a Write Once, Read Many (WORM) method for storing data on tape. The LTO Ultrium generation 4 drive enables WORM support when a WORM tape cartridge is loaded into the drive.

WORM Media

Because standard read/write media are incompatible with the WORM feature, a specially formatted WORM tape cartridge (see Figure 6-2) is required. Each WORM cartridge has a unique, worldwide cartridge identifier (WWCID), which comprises the unique CM chip serial number and the unique tape media serial number. Ultrium 4 WORM cartridges are two-tone green and silvery-gray. See “Ordering Media Supplies” on page 6-18 for information on how to choose and purchase the appropriate WORM tape cartridges for your library.




Figure 6-2. Ultrium WORM Tape Cartridge

Data Security on WORM Media

Certain built-in security measures help ensure that the data written on a WORM cartridge does not become compromised, for example:

- The format of an Ultrium 4 800 GB or Ultrium 3 400 GB WORM Tape Cartridge is unlike that of standard read/write media. This unique format prevents a drive that lacks WORM-capable firmware from writing on a WORM tape cartridge.
- When the drive senses a WORM cartridge, the firmware prohibits the changing or altering of user data already written on the tape. The firmware keeps track of the last appendable point on the tape.

WORM Media Errors

The following conditions cause WORM media errors to occur:

- Information in the servo manufacturer's word (SMW) on the tape must match information from the cartridge memory (CM) module in the cartridge. If it does not match, a media Error Code 7 will post on the drive's single-character display (SCD). An error will also be displayed on the Operator Control Panel.
- Inserting a WORM tape cartridge into a drive that is not WORM capable causes the cartridge to be treated as an unsupported medium. The drive will report a media Error Code 7. Upgrading the drive firmware to the correct code level will resolve the problem.

Requirements for WORM Capability

To add WORM capability to your LTO Ultrium generation 4 drive(s), you need to have the drive firmware to the correct code level, and use either Ultrium 4 800 GB WORM tape cartridges or Ultrium 3 400 GB WORM tape cartridges (see "Ordering Media Supplies" on page 6-18).

Cleaning Cartridge

With each library, a specially labeled IBM LTO Ultrium Cleaning Cartridge is supplied to clean the drive head. The drive itself determines when a head needs to be cleaned. It alerts you by lighting the "Clean Drive" (amber LED) above the library Operator Control Panel. To clean the head manually, insert a cleaning cartridge into the tape load compartment (see "Inserting the Cleaning Cartridge" on page 4-39). The drive performs the cleaning automatically. When the cleaning is finished, the drive ejects the cartridge, and the library turns the "Clean Drive" LED off. Some libraries have an Auto Clean function which, when enabled, will prompt the library to retrieve the cleaning cartridge that resides in the library, insert it in the drive that needs cleaning, clean the drive, then return the cleaning cartridge to its home slot.

Note: The drive will automatically eject an expired cleaning cartridge.

The IBM Cleaning Cartridges are valid for 50 uses. The cartridge's LTO-CM chip tracks the number of times that the cartridge is used.

Cartridge Memory Chip (LTO-CM)

All generations of the IBM LTO Ultrium Data Cartridges include a Linear Tape-Open Cartridge Memory (LTO-CM) chip (**1** in Figure 6-1 on page 6-1), that contains information about the cartridge and the tape (such as the name of the manufacturer that created the tape), as well as statistical information about the cartridge's use. The LTO-CM enhances the efficiency of the cartridge. For example, the LTO-CM stores the end-of-data location which, when the next time this cartridge is inserted and the Write command is issued, enables the drive to quickly locate the recording area and begin recording. The LTO-CM also aids in determining the reliability of the cartridge by storing data about its age, how many times it has been loaded, and how many errors it has accumulated. Whenever a tape cartridge is unloaded, the tape drive writes any pertinent information to the cartridge memory.

The storage capacity of the LTO Generation 4 LTO-CM is 8160 bytes. LTO Generations 1, 2, and 3 have an LTO-CM capacity of 4096 bytes.

Bar Code Label

A bar code label contains:

- A volume serial number (VOLSER) that is human-readable
- A bar code that the library can read

Note: The tape drive does not require bar code labels, but you may choose to use labels for tape cartridge identification purposes.

Table 6-2. Bar code label requirements for Ultrium tape drives and libraries

Ultrium Tape Drive/Library	Bar Code Label Requirements
3573	Required
3576	Required
3580	Not required
3581	Required with optional Bar Code Reader
3582	Required
3583	Required
3584	Required

When read by a library's bar code reader, the bar code identifies the cartridge's VOLSER to the library. The bar code also tells the library whether the cartridge is a data cartridge or cleaning cartridge. In addition, the bar code includes the two-character media-type identifier Lx, where x equals 1, 2, 3, or 4. L identifies the cartridge as an LTO cartridge and the number represents the generation of cartridge for that cartridge type. Figure 6-3 on page 6-6 shows a sample bar code label for the LTO Ultrium Tape Cartridge.

Tape cartridges can be ordered with the labels included or with custom labels. To order tape cartridges and bar code labels, see "Ordering Media Supplies" on page 6-18. The bar code for usage in LTO tape libraries must meet predefined specifications. They include (but are not limited to):

- Six or eight (the default) uppercase alphanumeric characters, where the last two characters must be L4, L3, L2, or L1
- Label and printing to be non-glossy
- Nominal narrow line or space width of 0.423 mm (0.017 in.)
- Wide to narrow ratio of 2.75:1
- Minimum bar length of 11.1 mm (0.44 in.)

Table 6-3. Cartridges and VOLSERs compatible with the Ultrium 3 and Ultrium 4 Tape Drive

Cartridges	VOLSER
Ultrium 4 Data Cartridge	xxxxxxL4
Ultrium 4 WORM Cartridge	xxxxxxLU
Ultrium 3 Data Cartridge	xxxxxxL3
Ultrium 3 WORM Cartridge	xxxxxxLT
Ultrium 2 Data Cartridge	xxxxxxL2
Ultrium 1 Data Cartridge (READ ONLY)	xxxxxxL1
IBM LTO Ultrium Cleaning Cartridge	CLNxxxLx

Table 6-3. Cartridges and VOLSERs compatible with the Ultrium 3 and Ultrium 4 Tape Drive (continued)

Cartridges	VOLSER
*An Ultrium 3 Tape Drive must have a minimum firmware level of 54xx for it to be compatible with the WORM cartridge.	

To determine the complete specifications of the bar code and the bar code label, visit the web at <http://www.ibm.com/storage/lto>, (select **LTO Support**), or contact your IBM Sales Representative.

When attaching a bar code label to a tape cartridge, place the label only in the recessed label area (see **4** in Figure 6-1 on page 6-1). A label that extends outside of the recessed area can cause loading problems in the drive.

Attention: Do not place any type of mark on the white space at either end of the bar code. A mark in this area may prevent the library from reading the label.




Figure 6-3. Sample bar code label on the LTO Ultrium 4 Tape Cartridge. The volume serial number (LTO123), cartridge type (L4), and bar code are printed on the label.

Guidelines for Using Bar Code Labels

Apply the following guidelines whenever using bar code labels:

- Use only IBM-approved bar code labels on cartridges to be used in an IBM tape library.
- Do not reuse a label or reapply a used label over an existing label.
- Before you apply a new label, remove the old label by slowly pulling it at a right angle to the cartridge case.
- Use peel-clean labels that do not leave a residue after being removed. If there is glue residue on the cartridge, remove it by gently rubbing it with your finger. Do not use a sharp object, water, or a chemical to clean the label area.
- Examine the label before applying it to the cartridge. Do not use the label if it has voids or smears in the printed characters or bar code (a library's inventory operation will take much longer if the bar code label is not readable).
- Remove the label from the label sheet carefully. Do not stretch the label or cause the edges to curl.
- Position the label within the recessed label area (see **5** in Figure 6-1 on page 6-1).
- With light finger pressure, smooth the label so that no wrinkles or bubbles exist on its surface.

- Verify that the label is smooth and parallel, and has no roll-up or roll-over. The label must be flat to within 0.5 mm (0.02 in.) over the length of the label and have no folds, missing pieces, or smudges.
- Do not place other machine-readable labels on other surfaces of the cartridge. They may interfere with the ability of the drive to load the cartridge.

Write-Protect Switch

The position of the write-protect switch on the tape cartridge (see **1**) determines whether you can write to the tape. If the switch is set to:

- The locked position  (solid red), data cannot be written to the tape.
- The unlocked position (black void), data can be written to the tape.

If possible, use your server’s application software to write-protect your cartridges (rather than manually setting the write-protect switch). This allows the server’s software to identify a cartridge that no longer contains current data and is eligible to become a scratch (blank) data cartridge. Do not write-protect scratch (blank) cartridges; the tape drive will not be able to write new data to them.

If you must manually set the write-protect switch, slide it left or right to the desired position.




Figure 6-4. Setting the write-protect switch

Table 6-4. Location of the write-protect switch

1	Write-Protect Switch
----------	----------------------

Handling the Cartridges

Attention: Do not insert a damaged tape cartridge into the drive. A damaged cartridge can interfere with the reliability of a drive and may void the warranties of the drive and the cartridge. Before inserting a tape cartridge, inspect the cartridge case, cartridge door, and write-protect switch for breaks.

Incorrect handling or an incorrect environment can damage cartridges or their magnetic tape. To avoid damage to your tape cartridges and to ensure the continued high reliability of your IBM LTO Ultrium Tape Drives, use the following guidelines:

Provide Training

- Post procedures that describe proper media handling in places where people gather.
- Ensure that anyone who handles tape has been properly trained in handling and shipping procedures. This includes operators, users, programmers, archival services, and shipping personnel.
- Ensure that any service or contract personnel who perform archiving are properly trained in media-handling procedures.
- Include media-handling procedures as part of any services contract.
- Define and make personnel aware of data recovery procedures.

Ensure Proper Packaging

- When shipping a cartridge, use the original or better packaging.
- Always ship or store a cartridge in a jewel case.
- Use only a recommended shipping container that securely holds the cartridge in its jewel case during transportation. Ultrium Turtlecases (by Perm-A-Store) have been tested and found to be satisfactory (see Figure 6-5). They are available at <http://www.turtlecase.com>.



Figure 6-5. Tape cartridges in a Turtlecase

- Never ship a cartridge in a commercial shipping envelope. Always place it in a box or package.
- If you ship the cartridge in a cardboard box or a box of a sturdy material, ensure the following:
 - Place the cartridge in polyethylene plastic wrap or bags to protect it from dust, moisture, and other contaminants.
 - Pack the cartridge snugly; do not allow it to move around.

- Double-box the cartridge (place it inside a box, then place that box inside the shipping box) and add padding between the two boxes (see Figure 6-6).



Figure 6-6. Double-boxing tape cartridges for shipping

Provide Proper Acclimation and Environmental Conditions

- Before you use a tape cartridge, acclimate it to the operating environment for 24 hours or the time necessary to prevent condensation in the drive (the time will vary, depending on the environmental extremes to which the cartridge was exposed).
- Ensure that all surfaces of a cartridge are dry before inserting it.
- Do not expose the cartridge to moisture or direct sunlight.
- Do not expose recorded or blank cartridges to stray magnetic fields of greater than 100 oersteds (for example, terminals, motors, video equipment, X-ray equipment, or fields that exist near high-current cables or power supplies). Such exposure can cause the loss of recorded data or make the blank cartridge unusable.
- Maintain the conditions that are described in “Environmental and Shipping Specifications for Tape Cartridges” on page 6-17.

Perform a Thorough Inspection

After purchasing a cartridge and before using it, perform the following steps:

- Inspect the cartridge’s packaging to determine potential rough handling.
- When inspecting a cartridge, open only the cartridge door. Do not open any other part of the cartridge case. The upper and lower parts of the case are held together with screws; separating them destroys the usefulness of the cartridge.
- Inspect the cartridge for damage before using or storing it.
- Inspect the rear of the cartridge (the part that loads first into the tape load compartment) and ensure that there are no gaps in the seam of the cartridge case (see **1** in Figure 6-7 on page 6-10 and **4** in Figure 6-9 on page 6-12). If there are gaps in the seam (see Figure 6-7 on page 6-10), the leader pin may be dislodged. Go to “Repositioning or Reattaching a Leader Pin” on page 6-11.




Figure 6-7. Checking for gaps in the seams of a cartridge

- Check that the leader pin is properly seated (see **2** in Figure 6-8 on page 6-12).
- If you suspect that the cartridge has been mishandled but it appears usable, copy any data onto a good cartridge immediately for possible data recovery. Discard the mishandled cartridge.
- Review handling and shipping procedures.

Handle the Cartridge Carefully

- Do not drop the cartridge. If the cartridge drops, slide the cartridge door back and ensure that the leader pin is properly seated in the pin-retaining spring clips (see **2** in Figure 6-8 on page 6-12). If the leader pin has become dislodged, go to “Repositioning or Reattaching a Leader Pin” on page 6-11.
- Do not handle tape that is outside the cartridge. Handling the tape can damage the tape’s surface or edges, which may interfere with read or write reliability. Pulling on tape that is outside the cartridge can damage the tape and the brake mechanism in the cartridge.
- Do not stack more than six cartridges.
- Do not degauss a cartridge that you intend to reuse. Degaussing makes the tape unusable.

Examples of Cartridge Problems

Example: Split Cartridge Case (see Figure 6-7)

The cartridge’s case is damaged. There is a high possibility of media damage and potential loss. Perform the following steps:

1. Look for cartridge mishandling.
2. Use the IBM Leader Pin Reattachment Kit (part number 08L9129) to correctly seat the pin (see “Repositioning or Reattaching a Leader Pin” on page 6-11). Then, immediately use data recovery procedures to minimize chances of data loss.

3. Review media-handling procedures.

Example: Improper Placement of Leader Pin (see Figure 6-8 on page 6-12)

The leader pin is misaligned. Perform the following steps:

1. Look for cartridge damage.
2. Use the IBM Leader Pin Reattachment Kit (part number 08L9129) to correctly seat the pin (see “Repositioning or Reattaching a Leader Pin”). Then, immediately use data recovery procedures to minimize chances of data loss.

Repositioning or Reattaching a Leader Pin

Attention: Use a repaired tape cartridge only to recover data and move it to another cartridge. Continued use of a repaired cartridge may void the warranties of the drive and the cartridge.

If the leader pin in your cartridge becomes dislodged from its pin-retaining spring clips or detaches from the tape, you must use the IBM Leader Pin Reattachment Kit (part number 08L9129) to reposition or reattach it. (Do not reattach the pin if you must remove more than seven meters (23 feet) of leader tape.) The sections that follow describe each procedure.

Attention: Use a repaired tape cartridge only to recover data and move it to another cartridge. Continued use of a repaired cartridge may void the warranties of the drive and the cartridge.

Repositioning a Leader Pin

A leader pin that is improperly seated inside a cartridge can interfere with the operation of the drive. Figure 6-8 on page 6-12 shows a leader pin in the incorrect **1** and correct **2** positions.

To place the leader pin in its proper position, you will need the following tools:

- Plastic or blunt-end tweezers
- Cartridge manual rewind tool (from Leader Pin Reattachment Kit, part number 08L9129)




Figure 6-8. Leader pin in the incorrect and correct positions. The cartridge door is open and the leader pin is visible inside the cartridge.

To reposition the leader pin, perform the following steps.

1. Slide open the cartridge door (**1** in Figure 6-9) and locate the leader pin (**2** (you may need to shake the cartridge gently to roll the pin toward the door).
2. With plastic or blunt-end tweezers, grasp the leader pin and position it in the pin-retaining spring clips (**3**).
3. Press the leader pin gently into the clips until it snaps into place and is firmly seated.
4. Close the cartridge door.




Figure 6-9. Placing the dislodged leader pin into the correct position. The cartridge door is open to show the leader pin.

5. To rewind the tape, insert the cartridge manual rewind tool (**1** in Figure 6-10) into the cartridge's hub (**2**) and turn it clockwise until the tape becomes taut.




Figure 6-10. Rewinding the tape into the cartridge

6. Remove the rewind tool by pulling it away from the cartridge.
7. If you suspect that the cartridge has been mishandled but it appears useable, copy any data onto a good cartridge immediately for possible data recovery. Discard the mishandled cartridge.

Reattaching a Leader Pin

The first meter of tape in a cartridge is leader tape. Once the leader tape has been removed there is a possibility of tape breakage. After reattaching the leader pin, transfer data from the defective tape cartridge. **Do not reuse the defective tape cartridge.**

The Leader Pin Reattachment Kit contains three parts:

- **Leader pin attach tool** (see **1** in Figure 6-11 on page 6-14). A plastic brace that holds the cartridge door open.
- **Cartridge manual rewind tool** (see **2** in Figure 6-11 on page 6-14). A device that fits into the cartridge's hub and lets you wind the tape into and out of the cartridge.
- **Pin supplies** (see **3** in Figure 6-11 on page 6-14). Leader pins and C-clips.

Attention:

- Use only the IBM Leader Pin Reattachment Kit to reattach the leader pin to the tape. Other methods of reattaching the pin will damage the tape, the drive, or both.
- Use this procedure on your tape cartridge only when the leader pin detaches from the magnetic tape and you must copy the cartridge's data onto another cartridge. Destroy the damaged cartridge after you copy the data. This procedure may affect the performance of the leader pin during threading and unloading operations.
- Touch only the end of the tape. Touching the tape in an area other than the end can damage the tape's surface or edges, which may interfere with read or write reliability.





Figure 6-11. Leader Pin Reattachment Kit

The following procedure describes how to reattach a leader pin.

To reattach a leader pin by using the IBM Leader Pin Reattachment Kit:

1. Attach the leader pin attach tool (1 in Figure 6-12 on page 6-15) to the cartridge (2) so that the tool's hook (3) latches into the cartridge's door (4). Pull the tool back to hold the door open, then slide the tool onto the cartridge. Open the tool's pivot arm (5).



A67E0033

Figure 6-12. Attaching the leader pin attach tool to the cartridge. To hold the cartridge door open, hook the tool into the door and pull the tool back.

2. To find the end of the tape inside the cartridge, attach the cartridge manual rewind tool (**1** in Figure 6-13 on page 6-16) to the cartridge's hub **2** by fitting the tool's teeth between the teeth of the hub. Turn the tool clockwise until you see the end of the tape inside the cartridge. Then, slowly turn the rewind tool counterclockwise to bring the tape edge toward the cartridge door **3**.
3. Continue to turn the rewind tool counterclockwise until approximately 13 cm (5 in.) of tape hangs from the cartridge door. If necessary, grasp the tape and pull gently to unwind it from the cartridge.
4. Remove the rewind tool by pulling it away from the cartridge. Set the tool and the cartridge aside.




Figure 6-13. Winding the tape out of the cartridge. Turn the cartridge manual rewind tool clockwise to see the end of the tape, then turn it counterclockwise to bring the tape to the cartridge door.

5. On the leader pin (**1** in Figure 6-14), locate the open side of the C-clip **2** . The C-clip is a small black part that secures the tape **3** to the pin.
6. Remove the C-clip from the leader pin by using your fingers to push the clip away from the pin. Set the pin aside and discard the clip.




Figure 6-14. Removing the C-clip from the leader pin. Use your fingers to push the C-clip from the leader pin.

7. Position the tape in the alignment groove of the leader pin attach tool (see **1** in Figure 6-15 on page 6-17).
 8. Place a new C-clip into the retention groove **2** (Figure 6-15 on page 6-17) on the leader pin attachment tool and make sure that the clip's open side faces up.
 9. Place the leader pin (from step 6) into the cavity **3** (Figure 6-15 on page 6-17) of the leader pin attach tool.
- Attention:** To prevent the leader pin from rolling into the cartridge, in the following step use care when folding the tape over the pin.
10. Fold the tape over the leader pin and hold it with your fingers (see Figure 6-15 on page 6-17).

Note: Use care to ensure that the tape is centered over the leader pin. Failure to properly center the tape on the pin will cause the repaired cartridge to fail. When the tape is properly centered, a 0.25-mm (0.01-in.) gap

exists on both sides of the pin.




Figure 6-15. Attaching the leader pin to the tape

11. Close the pivot arm **4** of the leader pin attach tool by swinging it over the leader pin so that the C-clip snaps onto the pin and the tape.
12. Swing the pivot arm open and trim the excess tape **5** so that it is flush with the reattached leader pin **6**.
13. Use your fingers to remove the leader pin from the cavity **3** in the leader pin attach tool.
14. Use the cartridge manual rewind tool to wind the tape back into the cartridge (wind the tape clockwise). Ensure that the leader pin is latched by the pin-retaining spring clips on each end of the leader pin.
15. Remove the rewind tool.
16. Remove the leader pin attach tool by lifting its end up and away from the cartridge.

Environmental and Shipping Specifications for Tape Cartridges

Before you use a tape cartridge, acclimate it to the operating environment for 24 hours or the time necessary to prevent condensation in the drive (the time will vary, depending on the environmental extremes to which the cartridge was exposed).

The best storage container for the cartridges (until they are opened) is the original shipping container. The plastic wrapping prevents dirt from accumulating on the cartridges and partially protects them from humidity changes.

When you ship a cartridge, place it in its jewel case or in a sealed, moisture-proof bag to protect it from moisture, contaminants, and physical damage. Ship the cartridge in a shipping container that has enough packing material to cushion the cartridge and prevent it from moving within the container.

Table 6-5 gives the environment for operating, storing, and shipping LTO Ultrium Tape Cartridges.

Table 6-5. Environment for operating, storing, and shipping the LTO Ultrium Tape Cartridge

Environmental Factor	Environmental Specifications			
	Operating	Operational Storage ¹	Archival Storage ²	Shipping
Temperature	10 to 45°C(50 to 113°F)	16 to 32°C(61 to 90°F)	16 to 25°C(61 to 77°F)	-23 to 49°C(-9 to 120°F)
Relative humidity (non-condensing)	10 to 80%	20 to 80%	20 to 50%	5 to 80%
Maximum wet bulb temperature	26°C(79°F)	26°C(79°F)	26°C(79°F)	26°C(79°F)
Note: 1. The short term or operational storage environment is for storage durations of up to six months. 2. The long term or archival storage environment is for durations of six months up to ten years.				

Disposing of Tape Cartridges

Under the current rules of the U.S. Environmental Protection Agency (EPA), regulation 40CFR261, the LTO Ultrium Tape Cartridge is classified as non-hazardous waste. As such, it may be disposed of in the same way as normal office trash. These regulations are amended from time to time, and you should review them at the time of disposal.

If your local, state, country (non-U.S.A.), or regional regulations are more restrictive than EPA 40CFR261, you must review them before you dispose of a cartridge. Contact your account representative for information about the materials that are in the cartridge.

If a tape cartridge must be disposed of in a secure manner, you can erase the data on the cartridge by using a high-energy ac degausser (use a minimum of 4000 oersted peak field over the entire space that the cartridge occupies). The tape should make two passes through the field at 90 degree orientation change for each pass to achieve complete erasure. Some commercial degaussers have two magnetic field regions offset 90 degrees from each other to accomplish complete erasure in one pass for higher throughput. Degaussing makes the cartridge unusable.

If you burn the cartridge and tape, ensure that the incineration complies with all applicable regulations.

Ordering Media Supplies

Table 6-6 on page 6-19 lists the cartridges and media supplies that you can order for the drive.

Table 6-6. Media supplies

Supply Item	Methods of Ordering
20-PACK IBM LTO Ultrium 800 GB Data Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 010. Specify the VOLSER characters that you want. Order as part number 95P4443 (color label) or 95P4445 (black and white label) through an IBM-authorized distributor. Specify the VOLSER characters that you want.
20-PACK IBM LTO Ultrium 800 GB Data Cartridge (without attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 011. Order as part number 95P4447 through an IBM-authorized distributor.
5-PACK IBM LTO Ultrium 800 GB Data Cartridge	Order as part number 95P4278 through an IBM-authorized distributor.
20-PACK IBM Ultrium 4 800 GB WORM Tape Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 032. Order as part number 95P4457 (color label) or 95P4459 (black and white label) through an IBM-authorized distributor. Specify the VOLSER characters that you want.
20-PACK IBM Ultrium 4 800 GB WORM Tape Cartridge (without attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 033. Order as part number 95P4461 through an IBM-authorized distributor. Specify the VOLSER characters that you want.
IBM LTO Ultrium 400 GB Data Cartridge Bar code labels are pre-applied to cartridges.	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 008. Specify the VOLSER characters that you want. Order as part number 96Pxxxx (color label) or 96Pxxxx (black and white label) through an IBM-authorized distributor. Specify the VOLSER characters that you want.
IBM LTO Ultrium 400 GB Data Cartridge Order VOLSER labels separately.	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 009. Order as part number 24Rxxxx through an IBM-authorized distributor. Specify the VOLSER characters that you want.
5-PACK IBM LTO Ultrium 400 GB Data Cartridge	Order as part number 95P2020 through an IBM-authorized distributor. Specify the VOLSER characters that you want.

Table 6-6. Media supplies (continued)

Supply Item	Methods of Ordering
IBM Ultrium 3 400 GB WORM Tape Cartridge (with attached labels) IBM TotalStorage 3589 Model 028/Feature Code 2820 is a 20-pack of WORM cartridges labeled with starting volume serial information and, optionally, packed in individual jewel cases. Attached labels have been preprinted with a Bar Code that ends with LT, where L stands for LTO, and T identifies the cartridge as a WORM cartridge. This media can be used with LTO 3 drives (read/write).	Order by Machine Type/Model and Feature Code through an IBM-authorized distributor.
IBM Ultrium 3 400 GB WORM Tape Cartridge (without attached labels) IBM TotalStorage 3589 Model 029/Feature Code 2920 is a 20-pack of WORM cartridges packed in individual jewel cases with unattached blank labels. This media can be used with LTO 3 drives (read/write).	Order by Machine Type/Model and Feature Code through an IBM-authorized distributor.
IBM LTO Ultrium 200 GB Data Cartridge Bar code labels are pre-applied to cartridges.	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 006. Specify VOLSER characters you want.
IBM LTO Ultrium 200 GB Data Cartridge Order VOLSER labels separately (see “Ordering Bar Code Labels”).	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 007.
IBM LTO Ultrium 100 GB Data Cartridge Order VOLSER labels separately (see “Ordering Bar Code Labels”).	Order as part number 08L9120 through an IBM-authorized distributor.
IBM LTO Ultrium Cleaning Cartridge (universal cleaning cartridge for use with Ultrium 1, Ultrium 2, and Ultrium 3 drives) VOLSER labels are included.	Order as part number 35L2086 through an IBM-authorized distributor.
Leader Pin Reattachment Kit	Order as part number 08L9129 through an IBM-authorized distributor.
Manual Rewind Tool	Order as part number 08L9130 through an IBM-authorized distributor.

To find the closest IBM-authorized distributor, visit the web at <http://www.ibm.com/storage/media> or call 1-888-IBM-MEDIA.

Ordering Bar Code Labels

The LTO Ultrium 3 and 4 Tape Drives do not require cartridge bar code labels. However, if you use your data cartridges or cleaning cartridges in an IBM tape library product, you may need cartridge bar code labels if your tape library product requires them (see Table 6-2 on page 6-5). You can order these labels separately from the IBM Data Cartridges and Cleaning Cartridges.

You can order bar code labels directly from the authorized label suppliers in Table 6-7.

Table 6-7. Authorized suppliers of custom bar code labels

In America	In Europe and Asia
EDP/Tri-Optic 6800 West 117th Avenue Broomfield, CO 80020 U. S. A. Telephone: 888-438-8362 http://www.tri-optic.com/	EDP Europe, Ltd. 43 Redhills Road South Woodham Ferrers Chelmsford, Essex CM3 5UL U. K. Telephone: 44 (0) 1245-322380 http://www.tri-optic.com/
Dataware P.O. Box 740947 Houston, TX 77274 U. S. A. Telephone: 800-426-4844 http://www.datawarelabels.com/	Dataware Labels Europe Heubergstrasse 9 D-83052 Bruckmuhl-Gotting Germany Telephone: 49 8062-9455 http://www.datawarelabels.com/
NetC P. O. Box 1067 Fairfield, CT 06825 U. S. A. Telephone: 203-372-6382 http://www.netc11c.com/	NetC Europe Ltd Town Farm Bungalow The Pavement North Curry TA3 6LX Somerset U. K. Telephone: 44 (0) 1823 49 1439 http://www.netclabels.co.uk
	NetC Asia Pacific Pty Ltd Locked Bag 1 Kenthurst NSW 2156 Australia Telephone: 61 (0) 2 4573 6556 http://www.netclabels.com.uk

Chapter 7. Troubleshooting

- The library consists of the following CRUs (Customer Replaceable Units):
 - Control Card (electronics, processor, memory, etc.)
 - Power Supply
 - Drive Sled (drive plus drive-to-library connectivity)
 - Library Enclosure (accessor, Operator Control Panel display, etc.)
 - Cartridge Magazines
- **Other possible Replacement Parts are:**
 - Data Cartridges
 - Cables/Terminator

Important: Before replacing any CRU and after finding the problem and performing any listed actions listed in the Troubleshooting Table below, be sure to review the “Procedures for Isolating CRU Problems” on page 7-8 to help confirm the failing CRU.

The following table is the starting point for all service issues. Find the reason which closest resembles the problem you are experiencing and perform the listed action. If you are unable to correct the problem, create a prioritized list of replacement parts required. Select only one CRU at a time starting with the most likely based on the “Procedures for Isolating CRU Problems” on page 7-8 and/or the error code listing. After exhausting all troubleshooting efforts, refer to “Contacting IBM Technical Support” on page 9-5.

After correcting the problem, run Library Verify (Operator Control Panel: **Service → Library Verify**) to ensure that all library components are functioning properly before resuming normal library operations.

Table 7-1. Troubleshooting table

Problem	Solution
INSTALLATION/CONFIGURATION	
Unable to configure 3 logical libraries with 3 drives (2 half high drives and 1 full high drive) installed.	The 2 half high drives must be in drive positions 1 and 2 (the lowest drive positions in the library) and the full high drive must be in the remaining drive position. For additional information, refer to Appendix B, “SCSI Element Types, SCSI Addresses, and Physical Configurations,” on page B-1.
Installation and Configuration	1. Refer to “Installation Problems” on page 7-6.
POWER	
Library does not power ON	1. Perform “Isolating a Power Supply Problem” on page 7-8.
The Operator Control Panel is blank or frozen	1. Power cycle the library. 2. If possible, log on to the Web User Interface and check the error log (Service Library → View Logs). Look up the error code and try to resolve (see Chapter 8, “Error Codes,” on page 8-1). 3. Upgrade/reinstall the latest library firmware. To download the latest library firmware, visit http://www.ibm.com/support. • If the problem is corrected, run Library Verify before resuming normal library operations. Refer to “Service: Library Verify” on page 5-28. • If the problem persists, refer to “Contacting IBM Technical Support” on page 9-5.

Table 7-1. Troubleshooting table (continued)

Problem	Solution
ENCRYPTION	
Encryption Error: Displayed when the drive detects an error associated with an encryption operation - if the problem occurred while the tape drive was writing data to, or reading data from, tape	1. Check the host application to ensure the Encryption Key Manager (EKM) application is providing the correct encryption key. • Refer to the IBM Tape Device Drivers Installation and Users Guide and the “Drive Sense Data” on page D-6 returned for an encryption operation. • Retry the encryption operation after the EKM application problems have been resolved. 2. Check the operation of the tape drive by resetting the drive (Operator Control Panel: Service → Service → Drive Power) and running POST. • Refer to the error code displayed on the Operator Control Panel if the drive resets and POST fails. • Retry the encryption operation if the drive reset and POST complete without errors. 3. Check the media. • Ensure the correct media is being used. Data encryption is supported with LTO Ultrium 4 Data Cartridges only. • Retry the encryption operation with the tape cartridge in another encryption enabled drive. Replace the media if the problem repeats with the same tape cartridge in multiple drives. If the problem occurred while the tape drive was running POST or diagnostics, replace the drive. The error code clears with the first attempted write/read after the encryption key is changed, or when the drive is placed in maintenance mode.
Encryption-related error is posted	Check the EKM application’s error logs, device driver logs, tape library error logs, and tape drive error logs for entries that are related to encryption. See “Service Library: View Logs” on page 5-54, “Service Library: View Drive Logs” on page 5-55, Chapter 8, “Error Codes,” on page 8-1, and “Drive Sense Data” on page D-6.
Connection problem with the Encryption Key Manager (EKM)	If you are using library-managed encryption, perform the Key Path Diagnostic (see “Service Library: Perform Key Path Diagnostics” on page 5-56) . If the test fails, a problem could exist with the IP address, the Ethernet cable, or the EKM server. Perform the following: 1. Check the Ethernet connection between the library and the EKM server. 2. Check the TCP/IP configuration of the library and the server. 3. Check that the EKM is correctly installed and configured, and that the EKM application is properly started (refer to your EKM documentation). 4. Ensure that the tape drive is registered in the EKM (refer to your EKM documentation). 5. Ensure that a default key label is defined in the EKM (refer to your EKM documentation). If you are using application-managed encryption or system-managed encryption, check your key proxy server’s documentation for a similar test.
Lost Encryption Feature Activation Key	Refer to “Contacting IBM Technical Support” on page 9-5.
Changed drive type or position in library	Resubmit encryption settings under Configure Library → Encryption even if the settings do not change.
LME capable drive does not exercise Key Path Diagnostics	
ERROR CODES	

Table 7-1. Troubleshooting table (continued)

Problem	Solution
There is an error code in the error log.	Most library or drive errors will result in an error code or error message on the Operator Control Panel display. An error code history is maintained in the library or drive error log. See "Service Library: View Drive Logs" on page 5-55 for how to get the error log over the Operator Control Panel and "Service Library: View Logs" on page 5-54 to view logs using the Web User Interface. Look up the error code and try to resolve (see Chapter 8, "Error Codes," on page 8-1 and/or Appendix D, "Sense Data," on page D-1).
FRONT PANEL LEDs	
Attention LED	To determine why the Attention LED is turned ON, log in to the Web User Interface and select Service Library → View Logs → Warning Log. Drive Sled Issues: • Refer to "Isolating Drive Sled Problems" on page 7-10. • Whenever there is a hardware configuration change such as drives being swapped with different form factors (i.e. HH to FH or FH to HH), a library configuration change is needed. Reconfiguring the library by reassigning the amount of logical libraries will clear this issue. Navigate to the Web User Interface Configure Library → Logical Libraries or to the Operator Control Panel's Configure → Library section and reassign the logical libraries. If you do not want to change your logical library configuration, resubmit your current settings. • Restore factory defaults (Operator Control Panel: Configure → Restore Defaults or Web User Interface: Configure Library → Restore Defaults). Media Issues: • Avoid contamination by ensuring that the library is installed in a clean, contamination-free environment. Continue cleaning the tape drive as needed. Refer to "Choosing a Location" on page 4-1. • A cartridge should be acclimated for at least 24 hours before being used, particularly if it has been stored at a substantially different temperature or level of humidity than the library. Refer to "Provide Proper Acclimation and Environmental Conditions" on page 6-9. • Any cartridge that is suspected of being defective or contaminated should NOT be reused, in any drive. Power Supply or Fan Issues: Check the power supply (or redundant power supply) for failure, and also check any power supply fans. Replace any defective units. Refer to "System Status" on page 2-6 for a redundant power supply failure on a 4U library and "Isolating a Power Supply Problem" on page 7-8.
Clean Drive LED	• Ensure that you are using an Ultrium universal cleaning cartridge (see "Cleaning Cartridge" on page 6-4). • Ensure that the cleaning cartridge has not expired. A drive will automatically eject an expired cleaning cartridge. A cleaning cartridge is good for 50 cleans. If your cleaning cartridge has expired, refer to "Ordering Media Supplies" on page 6-18 for information on ordering a new cleaning cartridge. • If the problem still exists, refer to "Contacting IBM Technical Support" on page 9-5.

Table 7-1. Troubleshooting table (continued)

Problem	Solution
Error LED	If the Error LED remains ON after completing any user action listed for the error code in Chapter 8, "Error Codes," on page 8-1, run Library verify (Operator Control Panel: Service → Library Verify). • If the test passes, the Error LED will turn OFF. • If the test fails, cycle library power to turn the Error LED OFF. To check the library error log, log on to the Web User Interface and click Service Library, then View Logs. If the Operator Control Panel displays WARNING: Unit Busy, click OK to turn the error LED OFF.
FIRMWARE	
Determining current firmware levels	Many problems can be resolved by a firmware upgrade. Ensure that both the library and drive firmware are at the latest levels available. Compare the firmware levels on the Operator Control Panel with the latest levels on the web site http://www.ibm.com/storage/. • Library firmware: Monitor → Library → Identity → Version • Drive firmware: Monitor → Drives → Identity (select a drive) → Firmware Rev
Update library firmware	Refer to "Service Library: Upgrade Firmware" on page 5-57.
Update drive firmware	Refer to "Service: Service (Drives)" on page 5-29 or "Service Library: Upgrade Firmware" on page 5-57.
CARTRIDGE MOVEMENT PROBLEMS	
Cartridge placement problems	Magazine slot prism fiducials NOT seated properly can result in gripper or slider error codes due to the fiducial interfering with the back edge of the cartridge. Release and pull magazines out of the library for inspection. To release the magazines using the Operator Control Panel, navigate to Control → Magazine. To release the magazines using the Web User Interface, navigate to Manage Library → Release Magazines. Inspect the light pipe fiducials on each slot of the magazine for proper seating. See "Replacing Magazine Fiducials" on page 10-14.
Cartridge will not eject from drive	1. Power cycle the library, allow it to complete initialization, which can take up to 1 hour depending on the type of cartridge (LTO 4, LTO 3, etc.) and how much of the tape has been spooled out of the cartridge. Retry unloading the cartridge using the library Operator Control Panel. Refer to "Control: Move Cartridges" on page 5-17. 2. Allow the drive to complete all operations. This may take as long as 1 hour if you reset or cycle power on the library while the cartridge is positioned at the physical end of the media. 3. Ensure that the backup software is not reserving the slot or preventing the drive from ejecting the cartridge. The backup software needs to cancel the reservation and any hold it has on the drive. Temporarily disconnecting the library from the host server and power cycling eliminates the host and its software as a problem source. 4. If the problem still exists, refer to "Contacting IBM Technical Support" on page 9-5.
Cartridge can not be removed from storage slot	See "Removing Cartridges from Magazine Slots" on page 9-1.

Table 7-1. Troubleshooting table (continued)

Problem	Solution
Extended library recovery time	1. Release both left and right magazines (Operator Control Panel: Control → Magazine; Web User Interface: Manage Library → Release Magazine) and inspect for both the presence and conditions of the cell prism fiducials. Each cell should contain a correctly installed prism with no visible damage. Replace any missing or damaged prism fiducials. Refer to “Replacing Magazine Fiducials” on page 10-14. 2. An error code that will often surface after completing an inventory request or a diagnostic request such as the system Test will be 9B 37....Sled position sensor not found. The OCP Error LED will be lit and the Library Status on the web interface will show a Robotic Failure. During the extended recovery process, by viewing the Standard Trace under the web interface Service Library → View Logs, the same Robotic Failure entries into this log can be viewed as the library enters recovery mode for failure to sense a particular fiducial. Proceed to the next step for failure isolation suggestions. 3. If there are no prism integrity issues and the library continues to post extended recovery time, refer to “Library Recovery Problem Determination” on page 7-8 and “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 7-12.
Slot Blocker blocking a storage slot	See “Removing the Slot Blocker - 2U Library” on page 10-10
MEDIA	
Cleaning or data cartridge incompatible with drive.	Ensure that you are using data and cleaning cartridges that are compatible with the drive and model of your library. The library automatically unloads incompatible cartridges and the Media Attention LED flashes. Export the media in order to clear the state. Refer to “Cartridge Compatibility” on page 6-2.
Cannot write to or read from tape.	1. Ensure that the cartridge write-protect switch is in the write enabled position (see “Write-Protect Switch” on page 6-7). 2. Ensure that you have the appropriate data cartridge for your library model (see “Cartridge Compatibility” on page 6-2). 3. Ensure that you are using an Ultrium cartridge that has <u>not</u> been degaussed. Do not degauss Ultrium cartridges. 4. Ensure that the cartridge has not been exposed to harsh environmental or electrical conditions and is not physically damaged in any way. Refer to “Provide Proper Acclimation and Environmental Conditions” on page 6-9 and “Perform a Thorough Inspection” on page 6-9. 5. Many backup applications do not read or write to cartridges that were created using a different backup application. In this case, you may have to perform an erase, reformat, or label replacement operation on the cartridge. 6. Ensure that you understand any data protection or overwrite protection schemes that your backup application may be using, which could prevent you from writing to a given cartridge. 7. Retry the operation with a different, known good cartridge. 8. Clean the drive. See “Service Library: Clean Drive” on page 5-53.
Cartridge VOLSER is reported as “unknown”	Probable cause: cartridge with no label or damaged label. Ensure that cartridge is properly labelled. If cartridge is properly labelled, unload the cartridge from drive and perform an inventory (Manage Library → Perform Inventory). If VOLSER is again reported as “Unknown”, run Library Verify (Service → Library Verify).
DRIVE ID (SCSI, SAS, OR FIBRE CHANNEL LOOP)	

Table 7-1. Troubleshooting table (continued)

Problem	Solution
Changed drive ID, but the host server does not recognize the new ID	1. Ensure that all devices on the same bus/network have unique ID numbers. 2. Ensure that you cycle power on the library after changing the ID. 3. Reboot the host server.
Tape library performance: The library is not efficiently backing up data	1. Check the network bandwidth from the host computer. If you are backing up data over a network, consider comparing to a local-only backup. 2. Ensure that the library and tape drive are on their own SCSI bus and not daisy-chained to another tape drive or to the hard drive being backed up. 3. Ensure that the library is connected to a LVDS SCSI bus and there are no single-ended (SE) devices on the same bus, because this will cause the entire bus to negotiate down to SE speed. 4. Use an Ultra160 SCSI bus and high-quality cabling with the library.
CUSTOMER REPLACEABLE UNITS (CRU)	
Drive Sled	See "Isolating Drive Sled Problems" on page 7-10.
Power Supply	See "System Status" on page 2-6 and "Isolating a Power Supply Problem" on page 7-8.
Library Controller Card	See "Isolating a Library Controller Card vs. Accessor Enclosure Problem" on page 7-12.
Library Enclosure	See "Isolating a Library Controller Card vs. Accessor Enclosure Problem" on page 7-12.
ITDT	
Performance Test duration varies	Items affecting the duration of the test are: • The level of adapter device driver • Your adapter model and type
OTHER PROBLEMS	
Web User Interface problems	See "Isolating Web User Interface Problems" on page 7-12.
Bar code scanner problems	See "Isolating Accessor Scanner Problems" on page 7-13.
Host Attachment Interface problems	See "Isolating Host Attachment Interface Problems" on page 7-13
Need help with a library password	Refer to "Contacting IBM Technical Support" on page 9-5.
Key path diagnostic not working	This diagnostic is available with library firmware level greater than 6.xx. Refer to "Verifying/Updating Firmware" on page 4-19 to determine the level of firmware on your library. If necessary, visit http://www.ibm.com to download the latest levels of firmware for your library.
Auto Clean status displayed as "Chk Media/Rsvd Slot?" on the Web User Interface System Status screen.	If Auto Clean is enabled and a cleaning cartridge is not present, or if a cleaning cartridge is present but not in the reserved slot, Auto Clean status will show "Chk Media/Rsvd Slot?" and Status will show a green check mark and the words "Media Attention."

Installation Problems

Problems encountered during the installation of the library are usually caused by improper SCSI bus configuration, application software configuration errors, or an incorrectly configured operating system. If the application software that you are using is not communicating with the library after installation, check the following:

- **Accessor Ship Lock Key:**

Ensure that the Accessor Ship Lock Key on the top cover has been removed **before** powering on the library. Refer to “Removing and Storing the Shipping Lock” on page 4-5.

- **Drive SCSI or Loop ID:**

Ensure that the SCSI ID of the Drive (or Fibre Channel Loop ID) is correct and not the same as other devices that may be on the same bus or loop. To determine the SCSI or Loop ID for each SCSI or Fibre Channel drive in your library, navigate to:

- Operator Control Panel: **Monitor** → **Drive** → **Identity**
- Web User Interface: **Monitor Library** → **Drive** → **Identity**

To change a drive’s ID, navigate to:

- Operator Control Panel: **Configure** → **Drive** → **Drive Interface**
- Web User Interface: **Configure** → **Drive** → **Drives**

- **Host Bus Adapter (HBA) Compatibility:**

Ensure that the library is compatible with the HBA. For best performance, the HBA used for this library should be SCSI-3 LVDS. Pay particular attention to any steps describing settings of various jumpers and/or switches. Refer to .

- **HBA LUN 0/1 Support:**

A single ID will address both drive and library since the drive is LUN 0 and the library is LUN 1. These models require an HBA that supports LUN scanning which must be enabled at the HBA. Refer to “Logical Unit Number (LUN) Scanning” on page 3-7 and “Supported Servers, Operating Systems, and Software” on page 1-11.

- **Cable Connections:**

Ensure that there are no bent pins on cables and that all connections are securely fastened.

- **Fibre Channel Tape Support:**

Ensure that Fibre Channel Tape Support is enabled on the HBA if you are installing a library with a Fibre Channel drive.

- **SCSI Cable Length:**

Ensure that the maximum cable length is not over 25 meters (82 ft.) for a single device on the bus or 12 meters (40 ft.) for multiple devices. Internal SCSI length within the library accounts for 2 ft.

- **SCSI Termination:**

Verify proper termination on both ends of the SCSI bus. Refer to “Connecting the Host Interface Cable” on page 4-12.

- **SAS Cables and Interposers**

Ensure that SAS Cables and Interposers (if any) are properly attached. Refer to “Connecting the Host Interface Cable” on page 4-12.

- **Backup Application Installation:**

Refer to the documentation included with your backup application software for instructions on how to verify proper installation.

- **Device Driver Installation:**

Ensure that the proper device driver, if applicable, is installed for the library.

Note: Many backup applications use their own drivers for the library and drive. Before installing a driver, make sure it will not be in conflict with the software. Contact your Backup Application vendor for this information.

Library Recovery Problem Determination

The 2U and 4U library firmware will generally retry failed operations up to three times before posting a failure to complete the operation, or, in some situations, proceeding with an operation that can be completed in an alternative manner. Of course, if the operation is successful within the allotted retry count, the appropriate retry counter is updated and recorded in the retry log and the next library operation will commence.

For example, failure to pick or place a cartridge from or to a designated cell or drive location after exhausting the retry count will result in a failed operation with the appropriate error code. However, failure to detect a particular cell location by sensing the prism fiducial located on the cell shelf because it is missing or damaged will eventually result in the cell location being located by the gripper, bar code reader and positional emitter pulse count after the prism detection retry count is exhausted. If several prisms are missing or damaged or if the accessor prism sensor/emitter is inoperable, initialization and/or inventory functions can take a prolonged amount of time to complete due to the lengthy retry recovery procedure.

If the library is taking an extended amount of time to initialize, to perform an inventory or even move a cartridge within the library, the magazines prism integrity should be verified prior to exchanging a library component. This situation can be noted by the ACTIVITY line on the Operator Panel posting Recovery. Prism integrity verification can be done by releasing the magazines and inspecting the cell prisms. Normal initialization or inventory time for a 2U library once the picker mechanism starts its operation should be approximately 1 to 2 minutes. For a 4U library, 2 to 3 minutes. A single missing or damaged prism can add 1 to 2 minutes. If the accessor tray sensor/emitter is inoperable, or several prisms are missing or damaged, initialization or inventory could exceed 30 minutes or longer. Refer to Troubleshooting table "Cartridge Movement Problems".

Procedures for Isolating CRU Problems

Isolating a Power Supply Problem

- | **Note:** Not all power supplies have LEDs. The original power supply for the 2U
- | library did not have LEDs though any power supplies replaced will likely
- | have LEDs. The 4U library has power supplies with LEDs.




Figure 7-1. A 250w power supply with LEDs




Figure 7-2. A 80w power supply without LEDs

Table 7-2. Power Supply LED Meanings

1	If the blue LED is lit, AC voltage is available.
2	If the amber LED is lit, there is a possible fan problem or other power supply issue. The power supply will need replacement.
3	If the green LED is lit, DC power is OK and active.
4	Cooling Fan Grill
5	Thumb Screws
6	Power Receptacle

If the Library does not power on:

1. With library power OFF and the power cord unplugged, loosen the three thumb screws (**5**), grasp two of the thumb screws, pull the power supply out half way, reseal the power supply, and tighten the three thumb screws.
2. Ensure the power cord is plugged in at the power supply (**6**) and at the electrical outlet, then turn library power ON.
 - a. For power supplies with LED's, the "Blue" LED will be lit if AC power is good.
 - b. If your power supply does not have LED's, feel for air flowing out of the cooling fan grill on the rear of the library (**4**). AC is good if air is flowing from the cooling fan grill.
3. If power appears to be missing
 - a. Plug the power cord into another electrical outlet.
 - b. If power is still missing, plug another device into the outlet to test.
 - c. If the outlet tests OK, try another power cord with the library.
4. For power supplies with LED's, if the "Amber" LED is lit, replace the power supply (refer to "Replacing a Power Supply" on page 10-11).
5. If your power supply has no LED's, and you have verified that the electrical outlet works properly, but the power supply is still failing, replace it (refer to "Replacing a Power Supply" on page 10-11).
6. If the power supply seems to be delivering power to the library (Operator Control Panel and front panel LED's may be functioning); however, air does not flow from the power supply cooling fan grill on the rear of the library, replace the power supply (refer to "Replacing a Power Supply" on page 10-11).
7. If the power supply seems to be delivering power to the library (Operator Control Panel and front panel LED's may be functioning), and air is flowing from the power supply cooling fan grill on the rear of the library, observe the "Green" LED (lowest of the three). If it is lit, the power supply is OK.

Note: If your library has -04 level redundant power supplies (see label on top of power supply), it is normal for the one in "Standby" mode to turn its "Green" LED off. You can test this power supply by pulling the power connector from the other "Active" power supply. The power supply that was in "Standby" mode will now become "Active", and its "Green" LED should light. If it doesn't, replace it (refer to "Replacing a Power Supply" on page 10-11).

If your library has -05 level redundant power supplies, the "Green" LED will be ON on both power supplies. If both "Green" LEDs are not ON, replace the failed power supply (refer to "Replacing a Power Supply" on page 10-11).

8. If the "Green" LED is not lit, and it is the only one in the Library, replace it (refer to "Replacing a Power Supply" on page 10-11).

Isolating Drive Sled Problems

Prior to replacing a drive sled CRU, verify that the following activities have been performed:

1. BEFORE POWERING OFF THE LIBRARY, write the drive dump to flash. It is important to preserve the drive dump on the drive for analysis by IBM Technical Support. For instructions, refer to “Writing a Drive Dump to Flash Memory” on page A-25.

Note: If you are instructed by IBM Technical Support to copy the drive dump to your host computer, use one of the following methods:

- Web User Interface: Refer to “Service Library: Save Drive Dump” on page 5-55.
 - ITDT: Refer to “IBM TotalStorage Tape Diagnostic Tool (ITDT)” on page 9-4.
2. Ensure that the drive firmware is at the latest level (visit <http://www.ibm.com/storage/>). To determine current library and drive firmware levels using the Operator Control Panel:
 - Library firmware: **Monitor** → **Library** → **Identity** → **Version**
 - Drive firmware: **Monitor** → **Drives** → **Identity (select a drive)** → **Firmware Rev**
 3. Try reseating the drive sled.

Note: The drive sled is hot-pluggable so it is not necessary to power off the library. See “Removing/Installing/Adding a Tape Drive Sled” on page 10-3.

4. Cycle power to the library.
5. If air does not flow from the drive sled cooling fan grill on the rear of the library, replace the drive sled CRU. Several library error codes also point to cooling problems. See “Removing/Installing/Adding a Tape Drive Sled” on page 10-3.
6. If the drive is experiencing permanent or temporary errors or if the amber Clean LED is lit on the front panel of the library, select Clean Drive from the Operator Control Panel Service Menu and clean the drive. Use only an approved cleaning cartridge (see “Cleaning Cartridge” on page 6-4).
7. Run the **Library Verify Diagnostic** which includes a drive performance Read/Write test (other drive diagnostics are also available) available on the Operator Control Panel or Web User Interface. Be sure to use a known good scratch or blank data cartridge.
 - If the drive test fails, replace the drive sled CRU (refer to “Removing/Installing/Adding a Tape Drive Sled” on page 10-3).
 - If the drive diagnostic(s) pass, run the drive wrap test **Service** → **Service (Drives)** → **Drive Tests** on the Operator Control Panel. If the wrap test fails, verify that you are using a wrap tool and not a terminator. If you are using the correct wrap tool, replace the drive sled CRU (refer to “Removing/Installing/Adding a Tape Drive Sled” on page 10-3).

Note: On a Half high SAS drive, run SAS wrap test A.

Note: If a SCSI drive wrap test fails, run the test again, with a different SCSI terminator prior to exchanging the drive sled.

8. Using the host interface test tool, ITDT, run the Scan function(s) to verify that the host application interface (SCSI, SAS, or Fibre Channel) can detect the drive (LUN 0) and the library (LUN 1). To further test the interface communication path, run the Test Device function (t), if available, after selecting the drive. This function will write/read data across the interface as well as sending a command to the drive to run the internal performance Read/Write test.

9. If the host tool, ITDT, cannot detect the drive or library, look for problems with the host interface cabling, the HBA, the device driver or the backup application software.

Isolating a Library Controller Card vs. Accessor Enclosure Problem

1. If possible, ensure that the library firmware is at the latest level, check the current library firmware level using the Operator Control Panel (**Monitor** → **Library** → **Identity** → **Version**) or the Web User Interface (**Monitor Library** → **Library Identity**), then (visit <http://www.ibm.com/storage/>).
2. With library power OFF, loosen the two thumb screws which secure the controller card to the library enclosure and slide it out.
 - Inspect the card for any broken components or other anomalies.
 - If the card appears to have no abnormalities, reseal the card back in the library, tighten the thumb screws, and turn library power ON.
3. If both the Operator Control Panel and Web User interfaces are inoperable or frozen and the latest firmware has been installed, the controller card CRU electronics is the most likely failure. If only the Web User Interface has failed, please see “Isolating Web User Interface Problems” before replacing any CRUs.
4. If a control card error code has been obtained and reseating, power cycling, and updating the library firmware did not fix the problem, the controller card CRU is the most likely failing CRU (refer to “Replacing a Library Controller Card” on page 10-12).
5. If the error code indicates an accessor type error (slider, elevator, sled, etc.), release and remove both magazines (see “Control: Magazine” on page 5-17, “Manage Library: Release Magazine” on page 5-40, or “Releasing the Magazines Manually” on page 9-1) and observe the accessor path for any obvious obstruction or problems. Resolve any observed problem if possible. Otherwise, replace the library enclosure CRU (refer to “Replacing the Library Enclosure” on page 10-15).
6. If the problem is intermittent or if a particular electronic or mechanical function of the library is not working properly as evidenced through observation or by error code, the library enclosure CRU is the most likely failing component (refer to “Replacing the Library Enclosure” on page 10-15).
7. If the library is taking an extended amount of time in recovery to complete initialization, perform an inventory, or executing a cartridge movement within the library, and, after finding the magazine cell fiducials to be present with no visible damage and correctly installed, suspect the sensor/emitter on the accessor mechanism to be inoperable. See .

Isolating Web User Interface Problems

If the Web User Interface is not functioning at all or if it is intermittently functioning, review the following steps to ensure that it is properly configured, or, to help determine which CRU or part needs to be replaced. The complete Web User Interface electronics reside on the library controller card CRU.

1. Ensure that the ethernet cable is securely plugged in the rear of the library at the ethernet port. See **7** on the “Rear Panel” on page 1-3.
2. Ensure that the correct IP, Netmask, and Gateway addresses are keyed into the network parameters. From the Operator Control Panel, navigate to **Configure** → **Network**.

3. Ensure that the correct IP address is being used on the web browser. If you get a security certificate alert when logging in to the Web User Interface, you can install the certificate or allow an exception (depending on the internet browser you are using). Even though with some browsers you will still receive a security certificate warning/error each time you log in to the Web User Interface, your transmission is secure. SSL is enabled when the URL to your library begins with **https://** and some browsers will show a lock.
4. If the ethernet connection is a direct connection between the PC and the library, a special "crossover" ethernet cable needs to be used.

Note: On newer PCs, either straight through or crossover ethernet cables may be used since the crossover requirement is provided internally.

5. Check the ethernet cable carefully (or try another cable) and, if the cable is connected to a network hub or switch, try a different port.
6. If the Web User Interface is still malfunctioning, replace the Library Controller Card CRU (refer to "Replacing a Library Controller Card" on page 10-12).

Isolating Accessor Scanner Problems

If the server has reported inventory problems relating to inability to read bar code labels, or, if some or all of the cartridge labels are not being displayed on the Web User Interface, use the following procedure to determine if the scanner (library enclosure CRU) needs to be replaced.

1. Ensure that a supported bar code label (or labels) are being used. Also, check for damaged labels (see "Bar Code Label" on page 6-5).
2. With library power OFF, reseal the library controller card CRU (refer to "Replacing a Library Controller Card" on page 10-12), and then switch library power ON.
3. Perform a re-inventory via the Operator Control Panel (**Control** → **Re-Inventory**) and view the inventory via the Web User Interface (**Monitor Library** → **Inventory**) to determine if the labels are now being read.
4. If the labels are still not being read properly, replace the library enclosure CRU (refer to "Replacing the Library Enclosure" on page 10-15).

Isolating Host Attachment Interface Problems

After successfully exercising "Isolating Drive Sled Problems", and more specifically the "Library Verify" diagnostic on the Operator Control Panel (**Service** → **Library Verify**) which includes a drive (or drives) read/write diagnostic, the following procedures are suggested to help isolate the failure to properly establish connectivity to the Host Bus Adapter (HBA).

1. If not already performed, exercise the drive interface wrap test on the Operator Control Panel (**Service** → **Service** → **Drive Tests**). The test will require that a proper Wrap Tool be installed at some point during the test procedure. If the wrap test fails, replace the drive sled (refer to "Removing/Installing/Adding a Tape Drive Sled" on page 10-3), and skip steps 2 and 3. Proceed to step 2 if the wrap test passes.

Note: If a SCSI wrap test fails, run the test one more time with a different SCSI terminator prior to replacing the drive sled.

2. Use the utility, ITDT, to evaluate connectivity from the HBA through the cabling to the drive (or drives). ITDT does not require separate device drivers, thus the Operating System has the ability to scan and find all the LTO devices that are attached. If ITDT cannot successfully locate the LTO drive, suspect

cabling or HBA problems, and skip step 3. If ITDT successfully located the LTO drive, proceed to step 3. See “IBM TotalStorage Tape Diagnostic Tool (ITDT)” on page 9-4 for a brief description of ITDT and instructions on how to download the tool from the web.

3. If ITDT successfully locates the LTO device(s), verify that the correct application device drivers and backup application software is properly installed.
4. Ensure that all the required or latest available Operating System files and/or updates (dll's, PTF's, etc.) have been installed and applied.

Identifying a Suspect Cartridge

The amber **Attention** LED will be lit on the front panel of the library when there has been a failure that indicates a piece of media is bad, marginal, or invalid. It will be cleared when all invalid cartridges have been exported from the library.

Note: The amber LED may also be lit because a power supply, or a power supply fan is failing. Refer to “Isolating a Power Supply Problem” on page 7-8.

1. Navigate to **Move Cartridges** using the Operator Control Panel (**Control** → **Move Cartridges**).
2. Select **Source**.
3. Scroll through the different slots containing cartridges, and look for an exclamation point (!). The exclamation point indicates that the cartridge is bad or was rejected due to wrong format, write protected, etc..
4. Select the marked cartridge as the **Source** and the I/O Station as the **Destination (Dest)**.
5. Select **Move**.
6. Open the I/O Station (**Control** → **I/O Station**).
7. Remove the marked cartridge from the I/O Station and dispose of properly.
8. Close the I/O Station. If the amber LED was lit because of bad media, the **Attention** LED will turn OFF. If the amber LED is still on, check the power supply or the power supply fans. See “Isolating a Power Supply Problem” on page 7-8.

Chapter 8. Error Codes

If an error occurs during operation of the library, the library stops the current operation and displays an error code on the LCD screen. Unless otherwise noted in “Error Codes” on page 8-2, try to resolve the error by cycling power to the library and retrying the last operation. If the error persists, contact technical support.

Example Error Code

EVENT -6

8D 07

Where:

- -6 indicates the position in sequence list, 0 being the most recent.
- 8D 07 indicates the error. (code 8D = sled blocked,).

The event log with the library also includes a date stamp for each event. Press SELECT to display the associated time stamp in the following format:

yy.mm.dd hh:mm:ss:HH

Where:

- yy is the year
- mm is the month
- dd is the current day
- hh is hours
- mm is minutes
- ss is seconds
- HH is 1/100 second

The time stamp is set to zero at system start.

A description of each error code and possible solution is provided in “Error Codes” on page 8-2.

Preparing to Resolve an Error Code

1. Record the error information that is displayed on the Operator Control Panel display or Web User Interface screen.
2. If possible, cycle library power and retry operation.
 - If the error reoccurs, refer to “Error Codes” on page 8-2 for information on resolving the error.
 - If the error does not reoccur, run Library Verify before continuing with normal library operation.

Complete the steps in “Preparing to Resolve an Error Code” before completing the User Action listed in “Error Codes” on page 8-2.

Error Codes

Errors described in this section are hard errors. If such an error occurs the library stops all operations and the Error LED starts blinking. An appropriate message will be posted on the Operator Control Panel and the Web User Interface. These errors are also reported via email notification, if enabled. To enable email notifications, refer to “Configure Library: Event Notification” on page 5-52.

Table 8-1. Main Error Codes

Error Code	Description	User Action
80	Bar code reader Error, cannot initialize BCR	Refer to “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 7-12. Possible Replacement CRUs: • Primary: Library Enclosure • Secondary: Library Controller Card
81	Bar code reader Error, no response from BCR	
82	EEPROM (Electrically Erasable Programmable Read-Only Memory) Error, no response from EEPROM (located on accessor controller)	
83	Accessor controller generic problem	
84	Setting of gripper motor parameters failed	
85	Setting of slider motor parameters failed	
86	Setting of elevator motor parameters failed	
87	Setting of rotation motor parameters failed	
88	Setting of sled motor parameters failed	1. If this is the first time the library has been powered ON or if it has been moved to a new location, ensure that the shipping lock has been removed. The lock is located on the top of the library (see “Removing and Storing the Shipping Lock” on page 4-5). 2. Refer to “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 7-12. Possible Replacement CRUs: • Primary: Library Enclosure • Secondary: Library Controller Card
89	Gripper blocked	
8A	Slider blocked	
8B	Elevator blocked	
8C	Rotation blocked	
8D	Sled blocked	

Table 8-1. Main Error Codes (continued)

Error Code	Description	User Action
8E	Cannot find gripper block within the expected range	Refer to “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 7-12. Possible Replacement CRUs: • Primary: Library Enclosure • Secondary: Library Controller Card
8F	Cannot find slider block within the expected range	
90	Cannot find elevator block within the expected range	
91	Cannot find rotation block within the expected range	
92	Cannot find sled block within the expected range	
93	Gripper outside range, Gripper has reached a position beyond the expected range	
94	Slider outside range, Slider has reached a position beyond the expected range	
95	Elevator outside range, Elevator has reached a position beyond the expected range	
96	Rotation outside range, Rotation has reached a position beyond the expected range	
97	Sled outside range, Sled has reached a position beyond the expected range	
98	Cartridge present sensor not found	
99	Slider home sensor not found	
9A	Rotation home sensor not found	
9B	Sled position sensor (fiducial sensor) not found	
9C	Gripper range out of specification	
9D	Slider range out of specification	
9E	Elevator range out of specification	
9F	Rotation range out of specification	
A0	Sled range out of specification	
A1	Open I/O Station (Import/Export Element) failed	
B0	Robotic controller response timeout. A command did not complete in the required amount of time.	
B1	NACK (not acknowledged) received from robotic controller	
B2	Accessor controller communication failed	

Table 8-1. Main Error Codes (continued)

Error Code	Description	User Action
B3	Accessor controller urgent stop due to a released magazine	1. Verify that the left and right magazines are completely inserted, then retry operation. 2. Refer to “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 7-12. Possible Replacement CRUs: • Primary: Library Enclosure • Secondary: Library Controller Card
B4	Cartridge did not transport completely	
B5	Accessor controller does not respond on command	
C0	Network initialization failed	1. Refer to “Isolating Web User Interface Problems” on page 7-12. 2. If the error recurs, refer to “Contacting IBM Technical Support” on page 9-5.
C1	Telnet Interface initialization failed	
C2	Webserver initialization failed	
C6	Ping command did not reach target	
C7	Cannot Upgrade from USB	Not supported
D0	ROM error. ROM checksum incorrect	Refer to “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 7-12. Possible Replacement CRUs: • Primary: Library Controller Card • Secondary: Library Enclosure *D7 - Fatal System error can occur due to an over-temperature condition. Ensure the environment meets the Environmental Specifications (refer to “Environmental Specifications” on page 1-10). **If you receive a D8 error while restoring your library configuration from the OCP or Web UI, verify that your file extension is .dbb. If the extension is correct, your file may have been corrupted during the save. Reconfigure, then save your library configuration. Note: Configuration files saved with one version of library firmware may not be compatible with other versions of firmware. It is recommended to save a configuration file each time the library firmware is upgraded. Restore the library using a configuration file that was saved with the same version of firmware currently installed in the library.
D1	RAM error. Power on Self Test (POST) has failed,	
D2	NVRAM (Non-Volatile Random Access Memory) error. Read/Write operation to NVRAM has failed	
D3	CTC (Channel to Channel) Error. Timer unit has failed during POST.	
D4	UART (Universal Asynchronous Receiver Transmitter) Error. Frame overrun or Parity Error on serial Interface.	
D5	Display Error Communication to display failed	
D6	Memory Error, Stack and heap overflow.	
D7	Fatal system error*	
D8	Data base error**	
D9	No SCSI IC detected	
DA	While running the Library Verify Test, the bar code reader read different bar code data for the same customer-supplied scratch cartridge label.	1. Refer to “Isolating Accessor Scanner Problems” on page 7-13. 2. If the error recurs, refer to “Contacting IBM Technical Support” on page 9-5.
E0	Incompatible magazine detected	1. Remove magazine from library. 2. Insert magazine in library. If error recurs, refer to “Contacting IBM Technical Support” on page 9-5.
F0	Drive Over temperature Condition The subcode indicates which drive is affected. <u>Example:</u> Subcode 02: drive #2	1. Check the ambient temperature conditions, and check all fans. 2. Refer to “Isolating Drive Sled Problems” on page 7-10.

Table 8-1. Main Error Codes (continued)

Error Code	Description	User Action
F1	Drive Communication Error Library controller has lost communication to drive The subcode indicates which drive is affected. <u>Example:</u> Subcode 02: drive #2	Refer to “Isolating Drive Sled Problems” on page 7-10.
F2	Drive Sled not present The subcode indicates which drive sled is affected. <u>Example:</u> Subcode 02: drive sled #2	
F3	Drive Hardware Error The subcode indicates which drive is affected. <u>Example:</u> F3 xy Where x refers to the hardware drive error code (single character display) and Y refers to the drive position in the library. x values: • 4: firmware or hardware error • 5: hardware error • 6: hardware or media error • A: recoverable hardware error	
F4	Drive Load Timeout Drive has run in a timeout while loading a tape. The subcode indicates which drive is affected. <u>Example:</u> Subcode 02: drive #2	
F5	Drive Unload Timeout Drive has run in a timeout while unloading a tape The subcode indicates which drive is affected. <u>Example:</u> subcode 02: drive #2	

Table 8-1. Main Error Codes (continued)

Error Code	Description	User Action
F6	No drive installed. A drive has never been installed	Refer to “Isolating Drive Sled Problems” on page 7-10.
F7	Support ticket download from drive not possible	
F8	Invalid drive command	
F9	Invalid drive parameter	
FA	SDCI microcode error	
FB	Drive logged out	
FC	Internal SCSI command failed with check condition	
FD	Internal SCSI command timeout	

Sub Error Codes

Table 8-2. Sub error codes

Error Code	Description
Robotics	
00	No sub error code
01	Mechanical initialization failure
02	Connection to slave robotic failed
03	Error motor initialization
04	Error during gripper close
05	Error slider home positioning
06	Error elevator home movement
07	Error during sled movement to rotation position
08	Error during rotation initialization, get range failed
09	Error elevator init
0A	Error during rotation to far position
0B	Error first sled init, move to sensor failed
0C	Error during sled movement to rotation position
0D	Error during rotation to drive position
0E	Error slider init, get range failed
0F	Error during slider forward movement

Table 8-2. Sub error codes (continued)

10	Error gripper init, get range failed
11	Error during slider home movement
12	Error during rotation to FAR position
13	Error sled init, move to sensor failed
14	Error during sled movement; check shipping lock
20	Error Inventory scan
21	Error during gripper close
22	Error slider home movement
23	Error during move gripper to scan pos
24	Error reading barcode label
25	Error during move sled to scan position
26	Error during move elevator to scan position
27	Error during sled preposition movement
28	Error Extra inventory scan
29	Error during closing gripper
2A	Error slider preposition movement
2B	Error during opening gripper
2C	Error during sled movement up to sensor
2D	Error slider preposition backwards movement
30	Error slot preposition
31	Error during sled movement in FLMoveRotation function
32	Command sending to robotic failed
33	Error during elevator movement in FLMoveRotation function
34	Error during rotation in FLMoveRotation function
35	Error during elevator movement in FLMoveSled function
36	Error during sled movement in FLMoveSled function
37	Error during sled positioning to sensor in FLMoveSled function

Table 8-2. Sub error codes (continued)

38	Error during sled positioning to mail slot in FLMoveSled function
39	Error during sled positioning without sensor
3A	Error during elevator movement without sensor
3B	Error slot position sensor not found
40	Movement to/from slot failed
41	Error during first slider movement
42	Error during first gripper movement
43	Error during second slider movement
44	Error during second gripper movement, get range failed
45	Error during third slider movement, move home failed
50	Preposition to drive failed
51	Elevator movement to home sensor failed.
52	Sled movement to home sensor failed.
53	Error during sled movement to drive position.
54	Error during rotation to drive position.
55	Error during elevator movement in drive position.
56	Error during sled movement to rotation position.
57	Error during rotation to end position.
60	Move from/to drive failed.
61	Error during first slider movement.
62	Error during first gripper movement.
63	Error during second slider movement.
64	Error during second gripper movement, get range failed.
65	Error during third slider movement, move home failed.
70	Release magazine failed.
71	Error during sled movement to rotation position.
72	Error during rotation to unlock position.
73	Error during move sled to block.
80	Opening I/O slot failed.
81	Error during movement to I/O slot open position.
82	Error during moving back - sensor was found.
90	Movement to home position failed.
91	Elevator movement to home position failed.
92	Error during sled movement to rotation position.
93	Error during rotation to home or far position.
94	Sled movement to home sensor position failed.

Table 8-2. Sub error codes (continued)

95	Sled movement to transport position failed.
A0	Movement of I/O slot failed.
A1	Sled movement to sensor failed.
A2	Sled movement to rotation position failed.
A3	Elevator movement to home position failed.
A4	Error during rotation to far position.
A5	Sled movement to I/O slot position failed.
A6	Error during elevator movement to position
B0	EEPROM on robotics controller not accessible or error during Read/Write operation
LIBRARY	
81	Drive wake up failed
88	Error accessing slot status
90	Accessor load not reached Cartridge Present sensor
91	No activity after Load command
92	Timeout while loading tape
93	No activity after load command
94	Timeout drive Unload
95	Drive terminated unsuccessfully
96	Tape not ejected at robot unload
97	Slot not free at robot unload
98	Cartridge not seated in load phase

Warning Events

Warning events described in this section are reported via email notification. The Attention LED will blink when warning events for the following occur:

- Media
- Fan
- Redundant power supply

An appropriate message will be posted on the Operator Control Panel and the Web User Interface.

Table 8-3. Warning Events

30	SCSI: transport element full	Refer to your host application documentation for problem determination information.
31	SCSI: all slots empty	
32	SCSI: invalid opcode	
33	SCSI: invalid element address	
34	SCSI: invalid field in CDB	
35	SCSI: Invalid drive specified	
36	SCSI: SEND DIAGNOSTIC command: invalid test number	
37	SCSI: invalid LUN	
38	SCSI: parameter list length error	
39	SCSI: parameter list error: invalid field	
3A	SCSI: parameter list error: parameter not supported	
3B	SCSI: parameter value invalid	
3C	SCSI: saving parameters not supported	
3D	SCSI: invalid ID message	
3E	SCSI: destination element full	
3F	SCSI: source slot or drive empty	
40	SCSI: wrong checksum	
41	SCSI: command sequence error	
42	SCSI: drive disabled	Check your configuration settings.
43	SCSI: I/O Station disabled	
44	SCSI: flash image does not fit bootcode	Refer to your host application documentation for problem determination information.
45	SCSI: media removal prevented by drive	
46	SCSI: media removal prevented by library	
47	SCSI: flash image does not fit personality	Check the version of firmware used for the upgrade.
48	SCSI: drive type not supported in this library	Check whether a version of firmware is available which supports this drive type. For a list of supported drives, refer to "Ultrium Tape Drives" on page 1-7.
49	SCSI: incompatible magazine, magazine not accessible	Check your configuration settings.
4A	SCSI: source not ready	Complete move process and retry operation.
4B	SCSI: destination source not ready	
4C	SCSI: library controller busy	Complete process and retry operation.
4D	SCSI: cannot make reservation	Refer to your host application documentation for problem determination information.
4E	SCSI: invalid slave robotic controller request	
4F	SCSI: robotic axes/motors aren't initialized	Check robotics status. Refer to "Isolating a Library Controller Card vs. Accessor Enclosure Problem" on page 7-12.
50	SCSI: cartridge belongs to another partition	Refer to your host application documentation for problem determination information.

Table 8-3. Warning Events (continued)

54	SCSI: failure in LME interface	1. Check your Encryption configuration. 2. Run Key Path Diagnostics. 3. Refer to your EKM server documentation.
55	SCSI: invalid license key entered	Re-enter license key. If problem persists, refer to "Contacting IBM Technical Support" on page 9-5.
58	Recovered Error: SCSI parity error	No user action is required.
59	Recovered Error: Error log overflow	
5A	Illegal request, downgrade prohibited	Disable encryption for firmware downgrade.
5B	Incompatible medium generation	Replace incorrect cartridge(s).
5C	Illegal request, downgrade prohibited because of incompatible network stack	Change network settings to IPv4 only before downgrading firmware.
5D	Illegal request, wrong drive FW for drive	Obtain correct drive firmware image.
60	Cleaning cartridge installed	Complete the cleaning process and retry the operation.
61	Cleaning failure. Cleaning process could not be performed	1. Verify that autoclean is enabled. 2. Check for an expired cleaning cartridge and replace if necessary. 3. Refer to "Configuring I/O Stations and Reserving Slots" on page 5-60.
62	Cleaning cartridge expired	Replace cleaning cartridge.
63	Invalid cartridge. Drive has rejected the data cartridge as invalid	1. Verify that the correct cartridge is being used. Refer to "Cartridge Compatibility" on page 6-2. 2. Refer to "Identifying a Suspect Cartridge" on page 7-14.
64	Invalid cleaning cartridge. Drive has rejected the cleaning cartridge as invalid	
65	Invalid upgrade cartridge. Drive has rejected the upgrade cartridge as invalid	Not supported
66	Medium error; diagnostic tape write protected	Ensure diagnostic tape is not write protected.
67	Medium error, incompatible medium for write operation	Replace incorrect cartridge(s).
70	Currently not used	
71	Currently not used	
72	Currently not used	
73	SCSI: overlapped command attempt	Refer to your host application documentation for problem determination information.
74	SCSI: echo buffer overwritten	
DB	External cooling fan error (fan motion has stopped). The subcode indicates which drive sled fan is affected Subcode 01: drive sled #1(bottom) Subcode 02: drive sled #2	Refer to "Isolating Drive Sled Problems" on page 7-10.

Table 8-3. Warning Events (continued)

DC	I ² C Bus Failure	Refer to “Isolating a Power Supply Problem” on page 7-8.
DD	Power Supply x fan has failed, Redundancy may be at risk The subcode indicates which power supply fan is affected Subcode 01: 1st PS fan from bottom Subcode 02: 2nd PS fan from bottom	
DF	Power Good signal changed from 2 to 1 Power Supplies	

Chapter 9. Service Procedures

Removing Cartridges from Magazine Slots

In the event of a severe mechanical problem with the library or if circumstances require you to remove tape cartridges, do the following. If the Operator Control Panel or the Web User Interface is still operational:

1. Move the tapes from the drive(s) to the magazines using the **Manage Library** → **Move Media** command (Web User Interface) or **Control** → **Move Cartridges** command (Operator Control Panel). See “Manage Library: Move Media” on page 5-39 or “Control: Move Cartridges” on page 5-17.

Note: Refer to “Contacting IBM Technical Support” on page 9-5. if a cartridge will not eject from the drive.

2. Use the magazine removal process to release the magazine and remove it from the library. To use the Operator Control Panel, see “Control: Magazine” on page 5-17. To use the Web User Interface, see “Manage Library: Release Magazine” on page 5-40. If neither one of these processes works, see “Releasing the Magazines Manually.”


Releasing the Magazines Manually

If the directions in steps 1 and 2 above do not allow you to remove the tapes, do the following:

1. Unplug the power cord from the library.
2. Find the access holes for the right and left magazines.



Figure 9-1. Access holes for the left magazine



a77ug024

Figure 9-2. Access holes for the right magazine

3. To manually release the magazines, push the end of a straightened paper clip into the access hole for each magazine at the back of the library. While holding the paper clip, have a second person pull the magazine out of the front of the unit. DO NOT push the paper clip in more than 1/2 inch.



a77ug023

Figure 9-3. Left Magazine pulled out of the 2U Library



a77ug102

Figure 9-4. Left Magazines pulled out of the 4U Library

4. If there are additional tapes still in the library, or if you were unable to manually remove the magazines and drive, refer to “Contacting IBM Technical Support” on page 9-5 for further instructions.

IBM TotalStorage Tape Diagnostic Tool (ITDT)

The IBM TotalStorage Tape Diagnostic Tool (ITDT):

- Runs quick or extended diagnostics on tape drives. If the library is online to the server/host where the tool resides, ITDT will communicate with the drive through the library to load and unload a test cartridge thereby exercising some library functions.
- Retrieves firmware dumps from tape drives and libraries.
- Performs a firmware update on tape drives or libraries.
- Tests the performance of the environment by completely writing a cartridge and measuring performance.
- Retrieves and displays cartridge information.
- Verifies the encryption environment.
- Does not require special device drivers.
- Is available for most major platforms.
- Scans the host interface and will find and display for selection all IBM LTO devices. The tool will not display non-IBM devices.

The IBM TotalStorage Tape Diagnostic Tool (ITDT) v2.1 is available as a command line utility and a graphical user interface (GUI) version.

- The **IBM TotalStorage Tape Diagnostic Tool (ITDT) v2.1** tool is a command line utility. Invoke it by entering the executable from the directory where the tool is located. The Help feature gives a brief explanation of each function and shows the required syntax.
- The **IBM TotalStorage Tape Diagnostic Tool (ITDT) v2.1** tool is a GUI version for Microsoft Windows. Microsoft Windows XP and Microsoft Windows Server 2003 (IX86, 32-bit) are only supported.

Note: Before using ITDT, verify that your library host operating system is at the latest released level. This will ensure optimum read/write operations for diagnostics.

Note: The legacy Tape Products (3580 GEN1 and GEN2, 3581, 3582, and 3583 Products) are not supported with this version of ITDT but are still supported with the older version of ITDT v1.2.

To download the ITDT tool and instructions for using the tool, visit <http://www-03.ibm.com/servers/storage/support/>.

Contacting IBM Technical Support

Note: The IBM System Storage™ TS3100 Tape Library and TS3200 Tape Library is a customer installed unit. The customer is responsible for the setup and maintenance of the tape library. The customer will be charged for service if a service contract is not in place.

Note: Where instructions refer you to the web, visit <http://www-03.ibm.com/servers/storage/support/lto/>.

1. Verify that you have exhausted all of the following troubleshooting options:
 - a. Perform all recommended diagnostic procedures.
 - b. Verify that the library's and drive's firmware is at the most recent level. To determine the latest release of firmware, visit the web.
 - c. Verify that your device drivers are at the most recent level (see your server (host) manual for instructions).
 - For the latest release of IBM device drivers, visit the web.

- For the latest release of device drivers by Independent Software Vendors (ISVs), visit the appropriate third-party web site.
 - d. Verify whether your hardware and software configuration is supported. To determine the latest supported attachments, visit the web
 - e. Ensure that cables and connectors are not damaged.
 - f. Review all documentation carefully. (Experience has demonstrated that most questions are answered in your documentation.)
2. Follow these steps to take full advantage of your call:
- a. Be prepared to explain whether the software or hardware has worked properly at anytime in the past. Have you changed anything recently?
 - b. Pinpoint the exact location of your problem, if possible. Note the steps that led to the problem. Can you duplicate the problem or is it a one-time occurrence?
 - c. Note any error messages displayed on your PC monitor or file server. Write down the exact error message.
 - d. If at all possible, call while at your computer, with the library installed and turned on.
 - e. If running on a network, have all relevant information available (that is, type, version number, network hardware, and so on).
 - f. Having this information available when you call for customer assistance will enable support personnel to resolve your problem in the most efficient manner possible.
 - Library Machine type and Model name(s)
 - Serial number of the library (front of the library on the label underneath the power button)
 - Library and drive firmware levels currently installed
 - Device driver information
 - Host application name and version
 - Type of host, operating system version, clock speed, RAM, network type, network version, and any special boards installed
3. The IBM Support Center will assist with problem determination and initiate shipment of a replacement part, if needed, to your location. To contact IBM Technical Support:
- In the USA: 1-800-IBM_SERV (1-800-426-7378).
 - All other Countries/Regions: <http://www.ibm.com/planetwide/>.
 - To open a Service Request online: Under **Support & downloads**, click **Open a Service Request**.

Chapter 10. Check, Adjust, Remove, and Replace

Tools Required

To service a library you may need one or more of the following tools:

- #2 Phillips screwdriver
- Ground strap (recommended, if available)

Electrostatic Discharge

Important: A discharge of static electricity can damage static-sensitive devices or microcircuitry. Proper packaging and grounding techniques are necessary precautions to prevent damage.



Figure 10-1. ESD label

To prevent electrostatic damage, observe the following precautions:

- Transport products in static-safe containers such as conductive tubes, bags, or boxes.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Cover the unit with approved static-dissipating material. If available, provide a ground strap connected to the work surface and properly grounded tools and equipment. If a ground strap is not available, touch a metal surface to discharge any static electricity in your body.
- Keep the work area free of nonconducting materials, such as ordinary plastic assembly aids and foam packing.
- Make sure you are always properly grounded when touching a static-sensitive component or assembly.
- Avoid touching pins, leads, or circuitry.
- Use conductive field service tools.

Relocating Your Library

When moving or shipping your library, it is important that the shipping lock be in place to prevent the accessor from moving and to protect the library from possible damage. Before relocating your library, complete the following procedure.

1. Remove all cartridges from inside the library.
2. Power OFF the library. This will align the robot with the shipping lock slot.
3. Remove any cables and terminators connected to the library.
4. Remove the library from the rack, if necessary.
5. Remove the shipping label (**2**) and lock (**1**) from the rear panel of the library.



Figure 10-2. Shipping Lock and Label Storage Location

6. Insert the shipping lock (**1**) into the slot located on the center of the top of the library and secure with the shipping label (**2**).



Figure 10-3. Shipping Lock and Label

7. Pack the library in its original packaging materials (or equivalent packaging) for moving or shipping.

Table 10-1. Shipping Lock/Shipping Label

1	Shipping Lock
2	Shipping Label

Removing/Installing/Adding a Tape Drive Sled

There are two types of drive sleds in a TS3100 library (2U library) and a TS3200 library (4U library). The contents of the ship groups are specific to the type of drive sled.

- Drive sled without ElectroStatic Discharge (ESD) springs (see Figure 10-4) ship group:
 - Drive sled without ESD springs
 - Packet of conductive tape to be applied to the drive sled for ESD protection
- Drive sled with ESD springs (see Figure 10-5 on page 10-4) ship group:
 - Drive sled with ESD springs



Figure 10-4. Library drive sled without ElectroStatic Discharge (ESD) springs (SCSI sled shown)




Figure 10-5. Library drive sled with ESD springs [1] (SAS sled shown)

Removing a Tape Drive Sled

1. IT IS IMPORTANT TO PRESERVE A DRIVE DUMP FOR IBM ANALYSIS IF ALL OF THE FOLLOWING CONDITIONS EXIST:

- Library Error LED is ON.
- Operator Control Panel is displaying a drive error message.
- Web User Interface System Status screen is indicating that a drive has failed.

For instructions on preserving the drive dump, refer to “Writing a Drive Dump to Flash Memory” on page A-25.

IF NONE OF THE CONDITIONS LISTED ABOVE EXIST, PROCEED TO THE NEXT STEP.

2. Power OFF the library before removing and/or installing a SCSI drive sled. Fibre Channel and SAS drive sleds are hot pluggable and may be removed and installed while the library is powered ON.
3. If necessary, unload the tape cartridge from the drive to be removed.
 - Using the Operator Control Panel: **Control** → **Move Cartridges**
 - Using the Web User Interface: **Manage Library** → **Move Media**
4. Remove the host interface cable (**1** , **2** , or **4** in Figure 10-6 on page 10-5) and terminator (**3** for SCSI drive sled only).




Figure 10-6. Drive sled components (full-high fibre drive in top position, half-high SCSI drive in middle position, half-high SAS drive in bottom position) on back panel of a 4U library

1	SCSI cable
2	SAS cable
3	SCSI terminator
4	Fibre Channel cable
5	Ethernet cable
6	Power cords
7	Drive sled blue captive thumbscrews
8	Black pull-out tab
9	Drive sled
10	Drive sled handle

5. If present, remove the conductive tape from the drive sled (refer to Figure 10-9 on page 10-8).
6. Loosen the blue captive thumbscrews (**7** in Figure 10-6) on the drive sled.
7. Pull straight back on the drive sled handle (**10**) to remove it from the library (see Figure 10-7 on page 10-6).
8. If you are replacing the tape drive sled, proceed to Installing a Tape Drive Sled for instructions. If you are not replacing the tape drive sled immediately, you will need to perform the following procedures:
 - a. Install a drive cover plate to protect your library from dust and debris.
 - b. To remove the "Missing drive" indicators on the Operator Control Panel (Attention LED) and the Web User Interface (System Status screen), modify or resubmit logical library setting (Operator Control Panel: **Configure** → **Logical Libraries** or Web User Interface: **Configure Library** → **Logical Libraries**).




Figure 10-7. Pulling the drive sled out of the library (drive sled without ESD springs shown)

Installing a Tape Drive Sled

Note: Power OFF the library before installing a SCSI drive sled. Fibre Channel and SAS drive sleds are hot pluggable and may be removed and installed while the library is powered ON.

1. Before installing the new drive sled, inspect all connectors on the drive sled. Ensure that the connectors are intact, free of any foreign objects, and have no cracks, deformed, or bent contacts.
2. Extend the black pull-out tab (**8** in Figure 10-6 on page 10-5) located underneath the library near the lower right corner of the drive sled.
3. Slowly insert the new drive sled into the drive slot, and align the connectors on the library while supporting the bottom of the drive sled (see Figure 10-8 on page 10-7). Ensure that the black tab remains extended (**8** in Figure 10-6 on page 10-5).

Important: Push in on the drive sled handle (**10** in Figure 10-6 on page 10-5) while supporting the bottom of the drive sled until it is properly seated. Damage to the connector pins may occur if this procedure is not followed.

4. Push the drive sled slowly into the drive slot until the sled seats itself against the back of the library.






Figure 10-8. Pushing the drive sled into the library (drive sled without ESD springs shown)

5. Tighten the captive thumbscrews (**7** in Figure 10-6 on page 10-5) until the drive sled is secure.
6. If you are installing a drive sled without ESD springs (see Figure 10-4 on page 10-3), apply conductive tape to the sled as shown in Figure 10-9 on page 10-8.

2U Library



4U Library



a77ug203

Figure 10-9. Diagrams for applying conductive tape for ESD protection to the back of a drive sled installed in a 2U or 4U library

Note: The small gray markers show where conductive tape should be placed to provide ESD protection.

7. Push the black tab (**8** in Figure 10-6 on page 10-5) back underneath the library. When inserted properly, only the handle of the tab will be visible.
8. Upgrade library firmware and drive firmware to the latest version.
Refer to “Configure Library: Drives” on page 5-46 to configure the drive if it is a SCSI or FC drive. Connect the drive host interface cable to the host or FC switch.

Note: Go to <http://www.ibm.com/storage/support/> to download the latest firmware for your library and tape drive(s).

9. Run the Library Verify test. (Operator Control Panel: **Service** → **Library Verify**). This test requires the use of a scratch (blank) cartridge.
 - If the test passes:
 - When prompted by the Operator Control Panel display and the I/O Station opens, remove the cartridge used in the test.
 - Close the I/O Station by pushing it back into the library.
 - Press **Cancel** to exit the Library Verify screen.
 - Resume normal library operations.
 - If the test fails, an error code will be displayed. Make note of the error, then refer to the Troubleshooting chapter in this document for additional instructions.
10. Package the failed drive sled in the same packaging in which the new sled was shipped to you and return to IBM. Fill out the Warranty Redemption form and return it in the package with the drive sled.

Important: If the failed drive was configured for encryption, to ensure the replacement drive receives the proper encryption parameters, resubmit the encryption choices listed on **Configure Library → Encryption** for that particular drive or logical library even if the encryption settings did not change.

Adding a Tape Drive Sled

Use these instructions to add a new tape drive to your 2U or 4U Tape Library. Refer to Appendix B, “SCSI Element Types, SCSI Addresses, and Physical Configurations,” on page B-1 for more information.

Note: Power OFF the library before installing a SCSI drive sled. Fibre Channel and SAS drive sleds are hot pluggable and may be removed and installed while the library is powered ON.

Complete the following procedure to add a new tape drive to your library.

1. Before installing the new drive sled, inspect all connectors on the drive sled. Ensure that the connectors are intact, free of any foreign objects, and have no cracks, deformed, or bent contacts.
2. Slowly insert the new drive sled into the drive slot, and align the connectors on the library while supporting the bottom of the drive sled (see Figure 10-8 on page 10-7). If necessary, ensure that the black tab remains extended (**8** in Figure 10-6 on page 10-5). Push in on the drive sled handle (**10** in Figure 10-6 on page 10-5) while supporting the bottom of the drive sled until it is properly seated.

Important: Damage to the connector pins may occur if this procedure is not followed.

3. Tighten the captive thumbscrews (**7** in Figure 10-6 on page 10-5) until the drive sled is secure.
4. If you are installing a drive sled without ESD springs (see Figure 10-4 on page 10-3), apply conductive tape to the sled as shown in Figure 10-9 on page 10-8.

Note: The small gray markers show where conductive tape should be placed to provide ESD protection.

5. Install cover plates on any open drive slots in the library.
6. Power ON the library.
7. Run the Library Verify test. (Operator Control Panel: **Service** → **Library Verify**). This test requires the use of a scratch (blank) cartridge.
 - If the test passes:
 - When prompted by the Operator Control Panel display and the I/O Station opens, remove the cartridge used in the test.
 - Press **Cancel** to exit the Library Verify screen.
 - Proceed to “Configuring the Tape Drive.”
 - If the test fails, an error code will be displayed. Make note of the error, then refer to the Troubleshooting chapter in the *IBM System Storage TS3100 Tape Library and TS3200 Tape Library Setup, Operator and Service Guide* (GA32-0545) for additional instructions.

Configuring the Tape Drive

1. Log on to the Web User Interface.

2. Verify that you are running the latest version of Library firmware and drive firmware (library firmware: **Monitor Library** → **Library Identity**; drive firmware: **Monitor Library** → **Drive Identity**). Upgrade, if necessary (**Service Library** → **Upgrade Firmware**).
3. Restore defaults (**Configure Library** → **Restore Defaults**). Refer to Table 5-4 on page 5-26 for a list of factory default settings.
4. Reconfigure your library using the OCP to configure your network settings, then using the Web UI to complete your library configuration.
5. Save your library configuration to your host computer or to a USB device.
6. Update your Library Configuration Form with the new drive and configuration information.
7. Resume normal library operations.

Removing the Slot Blocker - 2U Library

Earlier versions of the 2U library may have a "slot blocker" in the upper right cell of the left magazine. A slot blocker is used to close off/restrict a data cell so a data cartridge cannot be placed there. For 2U libraries using library firmware of 1.90 or higher, this blocker can be removed by following the procedure below:



Figure 10-10. 2U Magazine with Slot Blocker

Completely remove the magazine from the library. The power does not have to be turned off.

1. In the upper right cell, locate the slot blocker (**1**).
2. Remove the slot blocker.
 - a. From behind the magazine, push a screwdriver or a pen through the hole.
 - b. Pop the slot blocker out of the cell.




Figure 10-11. Popping the Slot Blocker out of the Cell

3. Slide the magazine back into the rack.
4. After the accessor runs through the inspection, a REMOVE SLOT RESTRICTION? message will appear on the main menu screen.
5. Choose the YES option. You can replace the empty cell with a data cartridge.

Replacing a Power Supply

1. Power OFF the library by pressing and holding down the power button for 4 seconds.
2. Disconnect the power cord from the electrical source, then from the library.
3. Loosen the three blue captive thumbscrews on the power supply located on the back panel of the library.
4. Pull on two of the thumbscrews to pull the unit away from the rear panel of the library, then grasp the top and bottom edge of the power supply and pull it out of the library.



Figure 10-12. A power supply being removed from a 2U library

5. Remove the packaging from the replacement power supply.
6. Grasp the top and bottom edge of the power supply and push it into the library.
7. Tighten the three blue captive thumbscrews on the power supply located on the back panel of the library.
8. Connect the power cord to the library, then to the electrical source.
9. Power ON the library using the power button on the front panel.
10. Run the Library Verify test (refer to "Service: Library Verify" on page 5-28).
11. Package the failed power supply in the same packaging in which the new power supply was shipped to you and return to IBM. Fill out the Warranty Redemption form and return it in the package with the power supply.

Replacing a Library Controller Card

Read Me before Continuing

The Library Controller Card contains a copy of the vital product data (VPD) for your library. The VPD contains your current library configuration. A backup copy of this VPD is contained within the electronics of the Library Enclosure. When the Library Controller Card is replaced, the new replacement card should contain zeros (0's) in key VPD locations. Upon detection of these zeros, the library will automatically attempt to write VPD data to the new Library Controller Card from the backup copy of the VPD contained in the Library Enclosure. In rare occurrences, the new Library Controller Card may contain valid (non-zero) VPD data left over from having been installed previously in another library. If this occurs, the library, which is expecting to see zeros in the VPD area, will instead detect valid VPD data, and will not know which copy of the VPD is the correct one. It will detect a "VPD Mismatch" and display on the Operator Control Panel a screen entitled "VPD Selection", where it is asking you to determine which copy of VPD should be written to the new Library Controller Card.

If the message "VPD Selection" is displayed at the Operator Control Panel, carefully highlight the "VPD from Enclosure" option to copy that version of the VPD to the new Library Controller Card. Then continue with the procedure.

Removal and Replacement

1. Power OFF the library by pressing and holding the power button at the front of the library for 4 seconds.
2. Disconnect the power cord from the electrical source, then from the power supply or supplies at the back of the library.
3. Loosen the two blue captive thumbscrews on the Library Controller Card.
4. Grasp the two thumbscrews and pull the defective Library Controller Card out of the library.



Figure 10-13. A Library Controller Card being removed from the library

5. Remove the packaging from the replacement Library Controller Card.
6. Grasp the two thumbscrews and push the replacement Library Controller Card into the library.
7. Tighten the two blue captive thumbscrews on the Library Controller Card.
8. Connect the power cord to the power supply or supplies at the back of the library, then to the electrical source.
9. Power ON the library using the power button on the front panel.
10. After power is restored to the Library Controller Card, the library will automatically restore the VPD on the new Library Controller Card from the Library Enclosure. If a "VPD Selection" message is displayed in the Operator Control Panel, see the "Read Me before Continuing" section earlier in this procedure to determine how to respond to the message.
11. Upgrade library firmware and drive firmware to the latest version. See "Service Library: Upgrade Firmware" on page 5-57.
12. Run the Library Verify test (refer to "Service: Library Verify" on page 5-28).

Note: Use care when selecting the appropriate VPD to restore from/to. An error in selection here could cause a long downtime.

13. Package the failed Library Controller Card in the same packaging in which the new control board was shipped to you and return to IBM. Fill out the Warranty Redemption form and return it in the package with the Library Controller Card.

Replacing Cartridge Magazines

To replace a cartridge magazine, refer to one of the following procedures:

- Using the Web User Interface, refer to “Manage Library: Release Magazine” on page 5-40.
- Using the Operator Control Panel, refer to “Control: Magazine” on page 5-17.
- If your library can not be powered ON, refer to “Releasing the Magazines Manually” on page 9-1.

Replacing Magazine Fiducials

Magazine fiducials are location sensors utilized by the library accessor. Extra magazine fiducials are included in your original library shipment.




Figure 10-14. Magazine fiducial

1. Remove the cartridge magazine that requires a replacement fiducial (refer to “Cartridge Magazines” on page 4-35).

2. Remove the damaged fiducial by pushing on the fiducial tab (**3**) and pulling the fiducial (**1**) out of the slot in the magazine (**2**).
3. Slide the replacement fiducial (**1**) into the correct magazine slot (**2**) being sure that the fiducial tab (**6**) on each side of the fiducial is underneath the magazine slot at **5** and above the magazine slot at **4** . Ensure that the fiducial is not installed in the magazine slot as indicated by **7** .
4. Slide the cartridge magazine into the library and resume normal library operation.

Replacing the Library Enclosure

This procedure is necessary when the library accessor or display fails. These components are contained within the replacement library enclosure.

The replacement library enclosure includes cartridge magazines, a power supply, a Library Controller Card, and a packet of library foot pads. These items are included with the replacement library enclosure due to safety agency requirements. These unused parts will be removed from the replacement library enclosure and sent back to IBM installed in the defective library. The old parts currently in your defective library will be removed, and installed into the replacement library enclosure.

Note: To reduce the risk of personal injury or damage to equipment:

- observe local health and safety requirements and guidelines for manual material handling
- obtain adequate assistance to lift and stabilize the library during installation or removal

Minimum Installation Time: 1 hr.

Minimum Number of Persons Required: 2

Recommended Tools: #2 Phillips screw driver, paper clip, blank (or scratch) data cartridge

Preparing the Defective Library for Replacement

1. If possible, use the Operator Control Panel to unload any drives that contain a cartridge (**Control** → **Move Cartridges**).
2. Power OFF the defective library.
3. Disconnect all cables from the rear panel of the defective library.
4. If the defective library is rack mounted, remove the two screws (**1** in Figure 10-15 on page 10-16) from the front of the defective library anchoring the mounting brackets on the library to the rack. With assistance, remove the defective library from the rack.



Figure 10-15. Removing the two mounting bracket screws anchoring the library to the rack (one screw on each side of the library)

5. Place the defective library on a clean and sturdy work surface.
6. Proceed to “Unpacking and Preparing the Replacement Library Enclosure.”

Unpacking and Preparing the Replacement Library Enclosure

Before installing the replacement library enclosure, it is important to verify that the enclosure is functioning properly.

1. Unpack the replacement library enclosure and place it on a sturdy and clean work surface near the defective library. Save all packaging materials for returning the failing part(s) to IBM.
2. Choose one of the options below for installing the foot pads.

Important: Operating your library on a flat surface without foot pads may damage your library or cause it not to function properly.

- a. For a rack mounted library:
 - 1) Lift the replacement library enclosure slightly above the work surface, have another person place a foot pad under each corner of the library and on each side of the library halfway between the front and back.
 - 2) Gently set the replacement library enclosure on top of the feet. Adjust foot pad placement as necessary to stabilize the library. Do not permanently attach the foot pads to the library.
- b. For a desktop library:
 - 1) Carefully, lay the library on its side.
 - 2) Peel the adhesive from the back of each of the six foot pads.
 - 3) Install the foot pads on the bottom of the library enclosure by pressing each foot into one of the six areas (**1**) as shown in Figure 10-16 on page 10-17.




Figure 10-16. Foot pads installed on the bottom of the library enclosure

3. Carefully return the library to an upright position.
4. Remove the shipping lock from the top of the replacement library enclosure (see Figure 10-17 on page 10-18).




Figure 10-17. Removing the shipping label and lock from the top of the library and storing on the rear panel

5. Store the lock and label on the back panel of the replacement library enclosure (see Figure 10-18).



Figure 10-18. Library shipping lock and label storage location on the rear panel of the library

6. Proceed to “Installing Your Drive(s) in the Replacement Library Enclosure.”

Installing Your Drive(s) in the Replacement Library Enclosure

Note: It is important to install the drives from the defective library into the same positions in the replacement library enclosure in order to maintain your current library configuration.

1. Remove all drives from the defective library (see Figure 10-19) and install them in the same positions in the replacement library enclosure.





Figure 10-19. Removing a drive sled from the library (drive sled without ESD springs shown)

- a. On the rear of the defective library, loosen the blue captive thumbscrews on the drive.
- b. If necessary, remove the conductive tape from the drive sled.
- c. Pull straight back on the tape drive handle to remove it from the library.
- d. On the rear of the replacement library enclosure, extend the black pull-out tab located underneath the lower right corner of the lowest drive sled position.
- e. Slowly insert each tape drive into the replacement library enclosure in the same drive slot as it was positioned in the defective library. Align with the connectors on the library while supporting the drive assembly. Ensure that the black pull-out tab remains extended when inserting a drive sled in the lowest drive position in the library.
- f. Push in on the tape drive handle while supporting the bottom of the tape drive until it is properly seated.

Important: Damage to the connector pins may occur if this procedure is not followed.

- g. Push the tape drive slowly into the drive slot until the drive is seated against the back of the library.
- h. Tighten the captive thumbscrews until the drive is secure.
- i. If installing a drive sled without ESD springs (see Figure 10-19), apply conductive tape as shown in Figure 10-20 on page 10-20.

2U Library



4U Library




Figure 10-20. Drive sled taping diagrams

Note: The gray markers show where conductive tape should be placed.

- j. Push the black tab back underneath the drive sled. When inserted properly, only the handle of the tab will be visible.
2. Power ON the replacement library enclosure.
 - a. If power ON is successful:
 - 1) After power up, the Ready/Activity LED (**1** in Figure 10-22 on page 10-23) will turn ON.
 - a) If the following message is displayed after the library powers ON, follow the instructions in Step 1. If the message is NOT displayed skip Step 1 and proceed to Step 2.
 [New library detected.]
 [1. Perform Library Verify]
 [2. Power Off and insert LCC]
 [from old library]
 [ok]
 - b) The system will initialize completely.
 - c) After confirming the pop-up, you should be able to use the interfaces.
 - d) Run the Library Verify test (Operator Control Panel: **Service** → **Library Verify**). This diagnostic requires a blank or scratch data cartridge
 - 2) Power OFF the replacement library enclosure.
 - 3) You must power down, remove the CRU LCC and replace it with the original LCC to have VPD transferred from the original LCC to the new chassis.
 - 4) Proceed to “Swapping Library Controller Cards” on page 10-21.
 - b. If power ON is not successful:

- 1) The Error LED (**4** in Figure 10-22 on page 10-23) will turn ON.
- 2) Power OFF the replacement library enclosure.
- 3) Contact IBM Technical Support for further instructions.

Swapping Library Controller Cards

IMPORTANT - READ ME BEFORE CONTINUING

The Library Enclosure contains a copy of the vital product data (VPD) for your library. The VPD contains your current library configuration. A primary copy of this VPD is contained within the Library Controller Card. A backup copy of this VPD is maintained on the accessor in the enclosure (or chassis). When the Library Enclosure is replaced, the new enclosure electronics should contain zeros (0's) in key VPD locations. Upon detection of these zeros, the library will automatically write VPD data to the replacement library enclosure from the primary copy of the VPD contained in the Library Controller Card. In rare occurrences, the replacement library enclosure may contain valid (non-zero) VPD data left over from having been installed previously in another library. If this occurs, the library firmware, which is expecting to see zeros in the VPD area, will instead detect valid VPD data, and will not know which copy of the VPD is the correct one. It will detect this VPD mismatch and display a message entitled "VPD Selection" on the Operator Control Panel. The library will need your input to determine which copy of VPD to write to the replacement library enclosure. If you are replacing both the Library enclosure and the Library Controller Card, transfer VPD after installing one part before installing the other.

If the message "VPD Selection" is displayed at the Operator Control Panel, carefully highlight the "VPD from Controller" option to copy VPD from the controller to the replacement library enclosure before selecting OK. Then continue with the procedure.

1. Swap the Library Controller Card in the defective library with the Library Controller Card in the replacement library enclosure.
 - a. Remove the Library Controller Card (see Figure 10-21 on page 10-22) in the defective library and in the replacement library enclosure. To remove a Library Controller Card:
 - 1) Loosen the two blue captive thumbscrews on the Library Controller Card.
 - 2) Grasp the thumbscrews and pull the card out of the library.
 - b. Install the Library Controller Card from the defective library in the replacement library enclosure. Install the Library Controller Card from the replacement library enclosure in the defective library to return to IBM. To install a Library Controller Card:
 - 1) Grasp the two blue captive thumbscrews and push the Library Controller Card into the library.
 - 2) Tighten the thumbscrews.

Note: You will hear a snap when the Library Controller Card is fully engaged and installed properly.



Figure 10-21. Removing a Library Controller Card from the library

Note: If you power on the replacement library without first swapping the Library Controller Card from the original (defective) library enclosure, the following message will appear on the Operator Control Panel shortly after applying power: **"New library detected. Please remove library power and insert Library Controller Card from old Library"**. The library requires the library serial number and other library attributes from the original library which is located in the VPD on the original Library Controller Card in order to continue library initialization. See **Important - Read Me Before Continuing** message listed above.

As a further Note, if the replacement library does **not** complete library initialization successfully after swapping in the original Library Controller Card, be sure to retain the original Library Controller Card so it can be swapped into the "new" replacement library enclosure which will have to be ordered.

2. Plug one end of the power cord (removed earlier from the defective library) into the rear panel of the replacement library enclosure and plug the other end into a power source.
3. Power ON the replacement library enclosure.
 - a. If power ON is successful:
 - 1) The Ready/Activity LED (**1**) will turn ON indicating that all components are functioning properly.
 - 2) After power is restored to the replacement library enclosure, the library will automatically restore the VPD on the replacement library enclosure from the Library Controller Card. If a "VPD Selection" message is displayed in the Operator Control Panel, see the "Read Me before Continuing" section earlier in this procedure to determine how to respond to the message.
 - 3) Power OFF the replacement library enclosure.
 - 4) Proceed to "Swapping Cartridge Magazines" on page 10-23.
 - b. If power ON is not successful:

- 1) The Error LED (**4** in Figure 10-22) will turn ON. This indicates that the Library Controller Card from the defective library is not functioning properly.
- 2) Power OFF the replacement library enclosure.
- 3) Refer to IBM Technical Support for further instructions.

I




Figure 10-22. Library front panel LEDs

1	Ready/Activity LED (green)	3	Attention LED (amber)
2	Clean Drive LED (amber)	4	Error LED (amber)

Swapping Cartridge Magazines

1. Manually release and remove all magazines from the defective library and from the replacement library enclosure. To release and remove a cartridge magazine:
 - a. Find the access holes for the right and left magazines (see Figure 10-23 on page 10-24 and Figure 10-24 on page 10-25).



Figure 10-23. Access hole for the left magazine (facing rear of library)




Figure 10-24. Access hole for the right magazine (facing rear of library)

- b. Push the end of a straightened paper clip into the access hole for each magazine at the back of the library. **DO NOT push the paper clip in more than $\frac{1}{2}$ inch.** While holding the paper clip, have a second person pull the magazine out of the front of the unit.

Note: Do not remove the other components from the defective library at this time.



Figure 10-25. Left magazines pulled out of a 4U library (facing front of library)

2. Insert the cartridge magazines removed from the defective library into the same positions in the replacement library enclosure.
3. Insert the cartridge magazines removed from the replacement library enclosure into the same positions in the defective library to return to IBM.
4. Wait for inventory of the magazines to complete.
 - a. If inventory is successful:
 - 1) The replacement library enclosure will complete with the Ready/Activity LED (**1** in Figure 10-22 on page 10-23) ON.
 - 2) Power OFF the replacement library enclosure.
 - 3) Proceed to “Swapping Power Supplies.”
 - b. If inventory is not successful:
 - 1) The Error LED (**4** in Figure 10-22 on page 10-23) will turn ON.
 - 2) Power OFF the enclosure.
 - 3) Contact IBM Technical Support for further instructions.

Swapping Power Supplies

1. Unplug the power cord from the power source then from the replacement library enclosure.
2. Swap the Power Supply in the defective library with the Power Supply in the replacement library enclosure.
 - a. Remove the power supply from the defective library and from the replacement library enclosure. To remove a power supply from a library:
 - 1) Loosen the three blue captive thumbscrews on the power supply.
 - 2) Pull on two of the thumbscrews to pull the unit away from the rear panel of the library.
 - 3) Grasp the top and bottom edges of the power supply and pull it out of the library.
 - b. Install the power supply removed from the defective library in the replacement library enclosure. Install the power supply removed from the replacement library enclosure in the defective library to return to IBM. To install a power supply:

- 1) Grasp two of the thumbscrews and push the power supply into the library.
- 2) Tighten the thumbscrews.



Figure 10-26. A power supply being removed from a library

3. Plug the power cord into the replacement library enclosure then into a power source.
4. Power ON the replacement library enclosure.
 - a. If power ON is successful:
 - 1) The replacement library enclosure will power up with the Ready/Activity LED (**1** in Figure 10-22 on page 10-23) ON.
 - 2) Power OFF the replacement library enclosure.
 - 3) Unplug the power cord from the power source then from the library.
 - 4) Proceed to "Installing the Replacement Library Enclosure."
 - b. If power ON is not successful, contact IBM Technical Support for further instructions.

Installing the Replacement Library Enclosure

Refer to the appropriate procedure in this section (rack or desktop) for installing the replacement library enclosure.

Note: If you are shipping the replacement library enclosure to a remote location, install the shipping lock and label before shipment.

Rack Installation:

1. Remove the mounting brackets (**1** in Figure 10-27 on page 10-28) and anchors (**2**) from each side of the defective library and install them on the replacement library enclosure.




Figure 10-27. Mounting brackets and anchors for securing the library in a rack (one bracket and anchor on each side of the library)

2. With assistance, slide the replacement library enclosure onto the metal rails that are already in position in the rack (see Figure 10-28).




Figure 10-28. Front view of a rack showing the rails installed

3. Tighten the mounting bracket screws (**1** in Figure 10-15 on page 10-16) to anchor the replacement library enclosure to the rack.
4. Proceed to “Completing the Installation of the Replacement Library Enclosure.”

Desktop Installation:

1. Place the library in its permanent location.
2. Proceed to “Completing the Installation of the Replacement Library Enclosure.”

Completing the Installation of the Replacement Library Enclosure

1. Connect all cables to the replacement library enclosure.
2. Power ON the replacement library enclosure.
3. Upgrade library firmware and drive firmware to the latest version.

- a. Visit <http://www.ibm.com/storage/support/> to download the latest levels of library and drive firmware.
- b. Using the Web User Interface (**Service Library** → **Upgrade Firmware**), upgrade library and drive firmware.
4. Run the Library Verify test (Operator Control Panel: **Service** → **Library Verify**). This diagnostic requires a blank or scratch data cartridge.
5. Properly fill out the Repair Identification (RID) Tag.
 - a. Copy the serial number of the defective library onto the RID tag.
 - b. Apply the tag to the front of the replacement library enclosure (as shown in Figure 10-29)




Figure 10-29. Proper placement of the Repair Identification (RID) Tag

6. Proceed to “Returning the Defective Library.”

Returning the Defective Library

1. Remove the shipping label (**2** in Figure 10-18 on page 10-18) and lock (**1**) from the rear panel of the defective library, place the lock in the slot located in the top center of the library, and secure with the shipping lock label. This will secure the library accessor for shipping.
2. Fill out the Warranty Redemption card that was included with the replacement library enclosure.
3. Using the replacement library enclosure packaging materials, securely package the defective library (including the left and right magazines, Library Controller Card, and power supply removed from the replacement library enclosure) and return it, along with the Warranty Redemption Card, to IBM.

Important: Failure to return all of these components to IBM will result in you being charged for any missing components.

Chapter 11. Optional Features, Replacement Parts and Power Cords

For information on ordering tape cartridges, refer to “Ordering Media Supplies” on page 6-18. For information on ordering bar code labels, refer to “Ordering Bar Code Labels” on page 6-20

Optional Features

Table 11-1. Optional Features

Feature Code	Description
1682	Path Failover (4U)
1901	Additional Power Supply (4U)
5096	LC-SC Fibre Cable Interposer
5400	SAS/Mini-SAS 4x Interposer
5402	2 m SAS/Mini-SAS 1x Cable
5406	5.5 m SAS/Mini-SAS 1x Cable
5500	Mini-SAS/Mini-SAS 4x Interposer
5502	2 m Mini-SAS/Mini-SAS 1x Cable
5506	5.5 m Mini-SAS/Mini-SAS 1x Cable
5602	2.5 m VHDCI/HD68 SCSI Cable
5604	4.5 m VHDCI/HD68 SCSI Cable
5610	10 m VHDCI/HD68 SCSI Cable
5900	Transparent LTO Encryption
6005	5 m LC/LC Fibre Cable
6013	13 m LC/LC Fibre Cable
6025	25 m LC/LC Fibre Cable
7002	Rack Mount Kit
8002	Cleaning Cartridge L1 UCC
8043	Ultrium 3 LVD SCSI Tape Drive Sled
8044	Ultrium 3 4Gb/s Fibre Channel Tape Drive Sled
8046	Ultrium 3 Half-High SCSI Tape Drive Sled
8047	Ultrium 3 Half-High SAS Tape Drive Sled
8106	Right Side Magazine
8107	Left upper 4U Magazine
8108	Left lower 4U Magazine
8109	Left side 4U Magazine
8143	Ultrium 4 SCSI Tape Drive Sled
8144	Ultrium 4 Fibre Tape Drive Sled
8145	Ultrium 4 SAS Tape Drive Sled
8147	Ultrium 4 Half-High SAS Tape Drive Sled
8305	Data Cart (GEN3) 5-Pack

Table 11-1. Optional Features (continued)

Feature Code	Description
8405	Ultrium 4 Data Cartridges (5 pack)
9848	Rack Power Distribution Unit (PDU) Line Cord
9900	Encryption Configuration

Replacement Parts

Note: This library has Tier 1 and Tier 2 CRUs (customer replaceable units). (Tier 1: No tools needed Tier 2: Tools needed) These CRUs are parts of the library that should be added, removed, and replaced by the customer. If a customer chooses to have the CRU added or removed/replaced by an IBM Service Representative, there will be a charge for the service.

Table 11-2. Replacement Parts

Part Number	Description
95P5855	Ultrium 4 Full High LVD SCSI Tape Drive Sled
95P5856	Ultrium 4 Full High Fibre Channel Tape Drive Sled
95P5857	Ultrium 4 Full High SAS Tape Drive Sled
45E2695	Ultrium 4 Half High SAS Tape Drive Sled
95P5218	Ultrium 3 Full High LVD SCSI Tape Drive Sled
95P5219	Ultrium 3 Full High Fibre Channel Tape Drive Sled
95P5858	Ultrium 3 Half High LVD SCSI Tape Drive Sled
95P5859	Ultrium 3 Half High SAS Tape Drive Sled
45E0657	Library Controller Card
95P6037	250 W Power Supply (can be used in both 2U and 4U libraries; is a replacement for an 2U library 80w power supply)
23R7170	Foot Pads
23R5841	SCSI Terminator
23R5840	SCSI Wrap Tool
12R9314	Fibre Channel Wrap Tool
23R3841	2.5 m VHDCI/HD68 SCSI Cable
23R3594	4.5 m VHDCI/HD68 SCSI Cable
23R3593	10 m VHDCI/HD68 SCSI Cable
95P4587	2 m SAS/Mini-SAS 1x Cable
39M5700	5 m LC-LC Fibre Channel Cable
12R9559	13 m LC-LC Fibre Channel Cable
39M5701	25 m LC-LC Fibre Channel Cable
95P4588	5.5 m SAS/Mini-SAS 1x Cable
95P4488	2 m Mini-SAS/Mini-SAS 1x Cable
95P4494	5.5 m Mini-SAS/Mini-SAS 1x Cable
95P5933	SAS/Mini-SAS 4x Interposer
95P5177	Mini-SAS/Mini-SAS 4x Interposer
95P6566	SAS Wrap Tool

Table 11-2. Replacement Parts (continued)

Part Number	Description
23R9679	Library Enclosure (2U)*
23R9629	Library Enclosure (4U)*
23R6471	Left Cartridge Magazine (2U)
23R6452	Right Cartridge Magazine (2U/4U)
23R7175	Lower Left Cartridge Magazine (4U)
23R7174	Upper Left Cartridge Magazine (4U)
23R7172	Block Out Panel, Power Supply (4U)
23R7173	Block Out Panel, Full High Drive Bay (4U)
95P6720	Half High Drive Filler Plate (2U/4U)
45E2709	Half High Drive Blockout Back Plate
* Tier 2 CRUs	

Power Cords



To avoid electrical shock, a power cord with a grounded attachment plug has been provided. Use only properly grounded outlets.

Table 11-3 lists the power cord part number, feature code, the country or region where the power cord can be used, and the plug's standard reference. The last column in the table contains an index number that you can match to a specific receptacle type in Figure 11-1 on page 11-7.

All power cords use an appliance coupler that complies with the International Electrotechnical Commission (IEC) Standard 320, Sheet C13.

If the power cord that you receive does not match your receptacle, contact your local dealer.

Power cords used in the United States and Canada are listed by Underwriter's Laboratories (UL), are certified by the Canadian Standards Association (CSA), and comply with the plug standards of the National Electrical Manufacturers Association (NEMA). For other worldwide geographies, plug standards are listed in Table 11-3.

Table 11-3. Power Cords

Description, Feature Code (FC), and Part Number (PN)	Plug Standard Reference	Country or Region	Index Number in Figure 11-1 on page 11-7
US/Canada • 2.8 m, 125V • FC 9800 • PN 39M5081	NEMA 5-15P	Aruba, Bahamas, Barbados, Bermuda, Bolivia, Brazil, Canada, Cayman Islands, Colombia, Costa Rica, Curacao, Dominican Republic, Ecuador, El Salvador, Guatemala, Guyana, Haiti, Honduras, Jamaica, Japan, Liberia, Mexico, Netherlands Antilles, Nicaragua, Panama, Peru, Philippines, Saudi Arabia, South Korea, Suriname, Taiwan, Trinidad Tobago, Venezuela, US	1

Table 11-3. Power Cords (continued)

Description, Feature Code (FC), and Part Number (PN)	Plug Standard Reference	Country or Region	Index Number in Figure 11-1 on page 11-7
Chicago • 1.8 m, 125 V • FC 9986 • PN 39M5080	NEMA 5-15P	Chicago, U.S.A.	1
US/Canada • 2.8 m, 250 V • FC 9833 • PN 39M5095	NEMA 6-15P	Aruba, Bahamas, Barbados, Bermuda, Bolivia, Brazil, Canada, Cayman Islands, Costa Rica, Curacao, Dominican Republic, Ecuador, El Salvador, Guatemala, Guyana, Haiti, Honduras, Jamaica, Japan, Liberia, Netherlands Antilles, Nicaragua, Panama, Peru, Philippines, Suriname, Taiwan, Thailand, Trinidad Tobago, Venezuela, US	2
Australia • 2.8 m, 250V • FC 9831 • PN 39M5102	AS 3112 NZS 198	Argentina, Australia, China, Colombia, New Zealand, Papua New Guinea, Paraguay, Uruguay, Western Samoa	3
France, Germany • 2.8 m, 250V • FC 9820 • PN 39M5123	CEE 7 - VII	Afghanistan, Algeria, Andorra, Angola, Aruba, Austria, Belgium, Benin, Brazil, Bulgaria, Burkina Faso, Burundi, Cameroon, Central African Republic, Chad, Congo-Brazzaville, Curacao, Czech Republic, Democratic Republic of Congo, Denmark, Egypt, Finland, France, French Guiana, Germany, Greece, Guinea, Hungary, Iceland, Indonesia, Iran, Ivory Coast, Jordan, Kenya, Korea, Lebanon, Luxembourg, Macau, Malagasy, Mali, Martinique, Mauritania, Mauritius, Monaco, Morocco, Mozambique, Netherlands, Netherlands Antilles, New Caledonia, Niger, Norway, Poland, Portugal, Romania, Russia, Saudi Arabia, Senegal, Spain, Sweden, Sudan, Syria, Togo, Tunisia, Turkey, Yugoslavia, Zaire, Zimbabwe, Vietnam	4

Table 11-3. Power Cords (continued)

Description, Feature Code (FC), and Part Number (PN)	Plug Standard Reference	Country or Region	Index Number in Figure 11-1 on page 11-7
Denmark • 2.8 m, 250V • FC 9821 • PN 39M5130	DK2-5A	Denmark	5
South Africa • 2.8 m, 250V • FC 9829 • PN 39M5144	SABS 164	Bangladesh, Burma, Pakistan, South Africa, Sri Lanka	6
United Kingdom • 2.8 m, 250V • FC 9825 • PN 39M5151	BS 1363	Antigua, Bahrain, Bermuda, Brunei, Channel Islands, China (Hong Kong S.A.R.), Cyprus, Fiji, Ghana, Guyana, India, Iraq, Ireland, Jordan, Kenya, Kuwait, Malaysia, Malawi, Malta, Nepal, Nigeria, Oman, Polynesia, Qatar, Sierra Leone, Singapore, Tanzania, Uganda, UK, United Arab Emirate (Dubai), Yemen, Zambia	7
Switzerland • 2.8 m, 250V • FC 9828 • PN 39M5158	SEV SN 416534	Liechtenstein, Switzerland	8
Italy • 2.8 m, 250V • FC 9830 • PN 39M5165	CEI 23- 16	Chile, Ethiopia, Italy, Libya, Somalia	9
Israel • 2.8 m, 250V • FC 9827 • PN 39M5172	S11-32-1971	Israel	10
Argentina • 2.8 m, 250V • FC 9834 • PN 39M5068	IEC 83-A5	Argentina, Brazil, Colombia, Paraguay, Trinidad Tobago, Uruguay	11
China • 2.8 m, 250V • FC 9840 • PN 39M5206	CCEE	People's Republic of China	12
Taiwan LV* • 2.8 m, 125V • FC 9835 • PN 39M5247	CNS 10917-3	Taiwan	13

Table 11-3. Power Cords (continued)

Description, Feature Code (FC), and Part Number (PN)	Plug Standard Reference	Country or Region	Index Number in Figure 11-1 on page 11-7
Taiwan HV** • 2.8 m, 250V • FC 9841 • PN 39M5254	CNS 10917-3	Taiwan	14
Japan LV* • 2.8 m, 125V • FC 9842 • PN 39M5199	JIS C8303, C8306	Japan	15
Japan HV** • 2.8 m, 250V • FC 9843 • PN 39M5186	JIS C8303, C8306	Japan	16
Korea HV** • 2.8 m, 250V • FC 9844 • PN 39M5219	KS C8305, K60884-1	Korea	17
India HV** • 2.8 m, 250V • FC 9845 • PN 39M5226	IS 6538	India	18
Brazil LV* • 2.8 m, 125V • FC 9846 • PN 39M5233	InMetro NBR 6147	Brazil	19
Brazil HV** • 2.8 m, 250V • FC 9847 • PN 39M5240	InMetro NBR 14136	Brazil	20
* Low Voltage ** High Voltage			

Types of Receptacles

Figure 11-1 on page 11-7 shows the plugs that are used by the power cords in Table 11-3 on page 11-3. Match the index number that is beside each plug to the index number in the table.




Figure 11-1. Types of Receptacles

Appendix A. Information for Trained Service Personnel

Internal View of Library

Important: FOR REFERENCE ONLY. The customer is not authorized to remove the top cover of the library. No customer serviceable components are inside the library.




Figure A-1. Internal view of the library

Table A-1. Internal view description

Number	Item	Description
1	Right cartridge magazine(s)	• In a 2U library, the right magazine can hold up to 12 cartridges. • In a 4U library, the right magazines can hold up to 24 cartridges.
2	Left cartridge magazine(s)	• In a 2U library, the left magazine can hold up to 11 cartridges and houses the elective 1-slot I/O Station. • In a 4U library, the left magazines can hold up to 21 cartridges and houses the elective 3-slot I/O Station.
3	Accessor	This component contains the library robot and bar code reader. The accessor moves cartridges to/from the following: • I/O Station • storage slots • tape drive(s)
4	Library Controller Card	This component is a customer replaceable unit (CRU) and stores the user configuration information or vital product data (VPD).

Table A-1. Internal view description (continued)

Number	Item	Description
5	Tape drive sled	Both libraries support the Ultrium 3 and Ultrium 4 Tape Drive. Each tape drive in the library is packaged in a container called a drive sled. The drive sled is a customer replaceable unit (CRU), and is designed for easy removal and replacement. • The 2U library houses one full high tape drive sled or up to two half high tape drive sleds. • The 4U library houses up to two full high tape drive sleds or up to four half high tape drive sleds. Combinations of full high and half high drive sleds are allowed.
6	Power supply	The power supply is a customer replaceable unit (CRU) and the sole source of power for the library. The 2U has one power supply. The 4U has one or can have an optional second power supply for redundancy.

Manual Cartridge Removal Procedure

Attention

- It is strongly recommended that the drive and tape be returned to IBM for removal and recovery.
- If the cartridge in the drive is an INPUT tape containing ACTIVE or 'ONLY COPY' data (i.e., there is no backup), eject commands issued at the host fail to unload the tape, and power-cycling the drive fails to eject the cartridge, make no further attempts to unload this tape. Call Technical Support and open a PMR if one isn't already open, to initiate the process of sending the drive with the loaded cartridge in for recovery.
- These procedures must be performed only by a trained IBM service provider. SSRs should claim their time against service code 33 ECA 013 when performing this procedure.
- Inform the customer the following procedure has high risk of damaging the drive and high risk of not being able to recover the data.

Recommended Tools

- #1 Phillips screwdriver
- ESD Kit
- Flashlight (optional)
- #1 Flathead screwdriver (optional)

Before You Begin

1. If you have not already done so, attempt to remove the cartridge with the device power ON and using library manager, a host application, or the unload button. When using the Unload button, press and hold the button for 12 seconds. This will cause the drive to eject the cartridge when it has completed the midtape recovery
2. If you have not already done so, ensure the operator has issued the appropriate application commands to perform a rewind and unload of the cartridge. This is to ensure that the stuck cartridge is not due to a hang condition in the application
3. If you have not already done so, attempt to remove the cartridge by power cycling the drive. Look for the drive to attempt a midtape recovery.

Note: It can take 5 minutes to 1 hour (depending on cartridge type (LTO4, LTO 3, etc.) and how much of the tape is spooled out of the cartridge) for the cartridge to rewind and unload.

4. If the cartridge unloads, inform the operator that the cartridge is unloaded. If the cartridge does not unload, repeat steps 2 and 3 once before continuing with this procedure.

Note: If the cartridge in the drive is an INPUT tape containing ACTIVE or 'ONLY COPY' data (i.e., there is no backup), eject commands issued at the host fail to unload the tape, and power-cycling the drive fails to eject the cartridge, make **no further attempts** to unload this tape. Call Technical Support and open a PMR if one isn't already open, to initiate the process of sending the drive with the loaded cartridge in for recovery.

Beginning Procedure

Note: If the cartridge in the drive is an INPUT tape containing ACTIVE or 'ONLY COPY' data (i.e., there is no backup), eject commands issued at the host fail to unload the tape, and power-cycling the drive fails to eject the cartridge, make **no further attempts** to unload this tape. Call Technical Support and open a PMR if one isn't already open, to initiate the process of sending the drive with the loaded cartridge in for recovery.

Removing the Drive Brick from the Sled

1. Remove the tape drive sled from the library. See "Removing a Tape Drive Sled" on page 10-4.
2. Place the sled on a clean, sturdy work surface.
3. If necessary, perform the following steps to remove the sled connection card to provide access to the two screws securing the sled to the drive brick:




Figure A-2. Drive connection card showing screws and plastic cover

1	Connection card screws
2	Plastic cover
3	Connection card
4	Screws that hold the drive brick to the sled (2 on each side)
5	Signal cable
6	Power cable
7	RS-422 cable

- a. Remove the three screws (**1**) securing the connection card (**3**) to the sled.
- b. Remove the plastic cover (**2**) from the connection card.
- c. Carefully move the connection card to one side. DO NOT UNPLUG ANY CABLES CONNECTED TO THE CARD.
4. Remove the drive brick from the sled by performing the following steps:
 - a. Remove the four screws (two on each side of the sled **4**) that secure the sled to the drive brick.




Figure A-3. Half high drive with the connection card moved to the side showing the screws

- b. Carefully pull the drive brick out of the front of the sled far enough to unplug the signal cable (SCSI, Fibre Channel or SAS **5**).




Figure A-4. The drive brick showing the cables to be unplugged

- c. With the signal cable unplugged, carefully pull the drive brick out so that the power cable (**6**) and the RS-422 cable (**7**) can be accessed and unplugged.

Note: The SAS signal cable also contains the power cable.

Note: The RS-422 cable is very delicate. Use your fingernails to work the cable loose before unplugging it.

- d. Remove the drive brick from the sled.

Removing the Drive Cover

1. Ground yourself to the drive by using an ESD Kit.
2. Remove the cover of the full high drive by performing the following steps:
 - a. Using a Phillips screwdriver, remove the three screws and washers (see **1** in Figure A-5) that secure the bezel **2** to the internal drive, then remove the bezel.
 - b. Remove the cover of the internal drive by performing the following steps:
 - 1) Remove the four cover-mounting screws and washers **3**.
 - 2) Remove the cover by lifting it up.




Figure A-5. Removing the bezel and the cover from the 4U internal drive

3. Remove the cover of the half high drive by performing the following steps:
 - a. To remove the drive bezel, pull the right side of the bezel (**1**) from the front of the drive, then pull the left side of the bezel out of the frame of the drive.
 - b. Remove the cover of the internal drive by performing the following steps:
 - 1) Remove the four cover-mounting screws (**2**). Two screws are located on each side of the drive.
 - 2) Remove the cover by lifting it up.




Figure A-6. Removing the bezel and the cover from the half high internal drive

4. Inspect the drive to decide which of the following conditions most closely matches the symptom on the drive:
 - **Tape spooled off the supply reel** - All the tape appears to be on the take up reel and no tape is on the supply reel (inside the cartridge). Test the drive after the procedure is completed.
 - **Tape pulled from leader pin (or broken at the front end)** - All the tape appears to be on the supply reel (inside the cartridge) and very little or no tape appears to be on the take up reel. The leader block is positioned in the take up reel. Return the drive after the procedure is completed.
 - **Tape broken in mid-tape** - Tape appears to be on both the supply reel (inside the cartridge) and take up reel. Test the drive after the procedure is completed.
 - **Tape tangled along tape path** - Tape appears to be tangled and damaged but intact. Return the drive after the procedure is completed.
- OR --
- No damage to tape (or no apparent failure)** - There appears to be no damage or slack to the tape. Return the drive after the procedure is completed.

Full-high Drive: Tape Spooled Off Supply Reel

Note: If the cartridge in the drive is an INPUT tape containing ACTIVE or 'ONLY COPY' data (i.e., there is no backup), eject commands issued at the host fail to unload the tape, and power-cycling the drive fails to eject the cartridge, make **no further attempts** to unload this tape. Call Technical Support and open a PMR if one isn't already open, to initiate the process of sending the drive with the loaded cartridge in for recovery.

1. With the front of the drive facing you, pull an arm's length of tape out of the take up reel from the left side of the drive.
2. From the take up reel, thread tape around the rear of the tape path and over the head and rollers on the left side of the drive.
3. Set the drive on its left side with the head and tape path facing up.
4. Moisten a cotton swab with water and wet approximately 13 mm (0.5 in.) of the tape end and feed it onto the supply reel (inside the cartridge).
5. From the bottom of the drive, insert a 2.5 mm offset hex wrench through the bottom cover access hole and into the reel motor axle.




Figure A-7. Using hex wrench to rewind tape into cartridge

6. Turn the supply reel clockwise, allowing the moistened tape to adhere to the hub as it winds around the supply reel (inside the cartridge).
7. Continue spooling into the cartridge until the tape is taut and remains within the flanges of the tape guiding rollers. Ensure that you do not stretch the tape.
8. Go to "Ending Procedure" on page A-25.

Half-high Drive: Tape Spooled Off Supply Reel

ATTENTION: DO NOT TOUCH THE OUTER GUIDE RAIL (2). THIS RAIL IS VERY DELICATE AND EASILY DAMAGED.

Note: If the cartridge in the drive is an INPUT tape containing ACTIVE or 'ONLY COPY' data (i.e., there is no backup), eject commands issued at the host fail to unload the tape, and power-cycling the drive fails to eject the cartridge, make **no further attempts** to unload this tape. Call Technical Support and

open a PMR if one isn't already open, to initiate the process of sending the drive with the loaded cartridge in for recovery.

1. From the takeup reel, pull an arm's length of tape around the rear of the tape path and over the head and rollers on the left side of the drive.
2. Set the drive on its left side with the head and tape path facing up.
3. Ensure that the tape is not twisted. Untwist the tape if required.
4. Moisten a cotton swab with water and wet approximately 13 mm (0.5 in.) of the tape end and feed it onto the supply reel (inside the cartridge).
5. Turn the supply reel (**4**) clockwise, allowing the moistened tape to adhere to the hub as it winds around the supply reel (inside the cartridge).





Figure A-8. Rewinding tape into cartridge

- | | | | |
|----------|---|----------|-------------------|
| 1 | Loader motor worm gear | 3 | Takeup reel motor |
| 2 | Outer guide rail
(WARNING: Do Not Touch) | 4 | Supply reel motor |

6. Continue spooling into the cartridge until the tape is taut and remains within the flanges of the tape guiding rollers. Turn the supply reel (**4**) 10 additional turns. Ensure that you do not stretch the tape.
7. Go to "Ending Procedure" on page A-25.

Full-high Drive: Tape Pulled from or Broken near Leader Pin



a82ru009

Figure A-9. Drive with cover removed to reveal gear train.

1	Loader motor worm gear	6	Threader mechanism gear
2	Cartridge loader tray guide bearing	7	Lever
3	Rotator stub	8	Loader mechanism gear
4	Threader motor worm gear		
5	Threader intermediate gear		

1. From the left side of the drive, pull out tape from the take up reel.

Note: If there is more than approximately 0.6 m (2 ft.) of tape on the take up reel, go to “Full-high Drive: Tape Broken in Mid-tape” on page A-13.

2. If there is less than approximately 0.6 m (2 ft.) of tape on the take up reel, cut off the excess tape as close to the leader pin, as possible.
3. Locate the threader motor worm gear (**4**) the rear of the drive. Use your finger to rotate the threader motor worm gear and slowly rotate the threader mechanism gear (**6**) clockwise. This rotates the threader motor worm gear (**4**) clockwise, drawing the tape leader block assembly (LBA) into the cartridge.
4. As the LBA is secured in the cartridge, you should hear the LBA retention spring clips click into place. If you do not hear the click, continue rolling until the threader motor worm gear (**4**) stops. The LBA is in the correct position.

Note: Be sure to keep tension on the tape as the LBA is drawn into the cartridge by using a hex wrench as shown in Figure A-7 on page A-8.

5. Notice the following:

- a. Loader mechanism gear (**8**) nearest the front of the drive that actuates the cartridge loader mechanism
 - b. Position of the rotator stub (**3**).
 - c. Front loader motor worm gear (**1**). Rotating this gear allows the loader mechanism gear (**8**) to turn.
6. Rotate the loader motor worm gear (**1**) to turn the loader mechanism gear (**6**) counterclockwise. Continue turning until the rotator stub (**3**) loses contact with the lever (**7**). This releases the LBA leader pin.
 7. Rotate the threader motor worm gear (**4**) to turn the threader mechanism gear (**6**) counterclockwise. This moves the LBA out of the cartridge and past the read/write head. Stop this rotation when the LBA is near the tape guide roller nearest the rear of the drive (**1**).




Figure A-10. Leader Block Assembly (LBA)

8. Continue rotating the loader motor worm gear (**1**) until the rotate stub (**3**) is positioned as shown. Notice that the rotator stub (**3**) is nearly aligned with the cartridge loader tray guide bearing (**2**).
9. Remove the cartridge from the cartridge loader tray.
10. Go to "Ending Procedure" on page A-25.

Half-high Drive: Tape Pulled from or Broken near Leader Pin




Figure A-11. Drive with cover removed to reveal gear train.

- | | | | | | |
|----------|-------------------------------|----------|----------------------------|----------|---------------------------|
| 1 | Threader
intermediate gear | 2 | Threader mechanism
gear | 3 | Loader motor worm
gear |
|----------|-------------------------------|----------|----------------------------|----------|---------------------------|

1. Pull out tape from the takeup reel.

Note: If there is more than approximately 0.6 m (2 ft.) of tape on the takeup reel, go to “Half-high Drive: Tape Broken in Mid-tape” on page A-14

2. If there is less than approximately 0.6 m (2 ft.) of tape on the takeup reel, cut off the excess tape as close to the leader pin, as possible.
3. Reattach the leader pin to the remaining tape.
4. Locate the threader intermediate gear (**1**) near the rear of the drive. You can use your finger to rotate the threader intermediate gear (**1**) and slowly rotate the threader mechanism gear (**2**) clockwise. This draws the tape leader block assembly (LBA) into the cartridge.
5. As the leader pin is secured in the cartridge, you should hear the leader pin retention spring clips click into place. If you do not hear the click, continue rolling until the threader intermediate gear (**1**) stops. The LBA is in the correct position.
6. Rotate the loader motor worm gear (**3**) clockwise as viewed from the front of the drive until it stops. This releases the LBA leader pin.
7. Rotate the threader intermediate gear (**1**) counterclockwise until the leader block is in front of the Read/Write head. This moves the LBA out of the cartridge.




Figure A-12. Leader Block Assembly (LBA)

1 Loader motor worm gear **2** Leader block assembly (LBA)

8. Rotate the loader motor worm gear (**3**) counterclockwise as viewed from the front of the drive until it stops.
9. Remove the cartridge from the cartridge loader tray.
10. Go to "Ending Procedure" on page A-25.

Full-high Drive: Tape Broken in Mid-tape

1. With the front of the drive facing you, pull an arm's length of tape out of the take up reel from the left side of the drive.

Note: If there is less than approximately 5 cm (2 in.) of tape on the take up reel, go to "Full-high Drive: Tape Pulled from or Broken near Leader Pin" on page A-9.

2. From the supply reel inside the cartridge, pull approximately 0.3 m (1 ft.) of tape.
3. From the take up reel, thread tape around the rear of the tape path and over the head rollers on the left side of the drive.
4. Moisten a cotton swab with water, and wet approximately 13 mm (0.5 in.) of the tape end. Overlap the tape ends, loosely mending them together.
5. Set the drive on its left side with the head and tape path facing up.
6. From the bottom of the drive, locate the access hole (**1** in Figure A-13 on page A-14) in the bottom cover. Insert a 2.5 mm offset hex wrench through the bottom cover access hole and into the reel motor axle. begin spooling tape back into the cartridge by turning the hex wrench clockwise.




Figure A-13. Using hex wrench to rewind tape into cartridge

7. Turn the supply reel clockwise, carefully guiding the mended portion of the tape to wind around the hub of the supply reel located inside the cartridge. Continue spooling into the cartridge until the tape is taut. The tape must remain within the flanges of the tape guiding rollers. Ensure that you do not stretch the tape.
8. Go to "Ending Procedure" on page A-25.

Half-high Drive: Tape Broken in Mid-tape

1. With the front of the drive facing you, pull an arm's length of tape out of the takeup reel. From the takeup reel, thread tape around the rear of the tape path and over the head rollers on the left side of the drive.

Note: If there is less than approximately 5 cm (2 in.) of tape on the takeup reel, go to "Half-high Drive: Tape Pulled from or Broken near Leader Pin" on page A-11.

2. From the supply reel inside the cartridge, pull approximately 0.3 m (1 ft.) of tape.
3. Ensure that the tape is not twisted. Untwist the tape if required
4. Moisten a cotton swab with water, and wet approximately 13 mm (0.5 in.) of the tape end. Overlap the tape ends, loosely mending them together.
5. Set the drive on its left side with the head and tape path facing up
6. Turn the supply reel (**4**) clockwise, carefully guiding the mended portion of the tape to wind around the hub of the supply reel located inside the cartridge. Continue spooling into the cartridge until the tape is taut. The tape must remain within the flanges of the tape guiding rollers. Turn the supply reel (**4**)

10 additional turns. Ensure that you do not stretch the tape.




Figure A-14. Rewinding tape into cartridge

- | | | | |
|----------|---|----------|-------------------|
| 1 | Loader motor worm gear | 3 | Takeup reel motor |
| 2 | Outer guide rail
(WARNING: Do Not Touch) | 4 | Supply reel motor |

7. Go to “Ending Procedure” on page A-25.

Full-high Drive: Tape Tangled along Tape Path

Note: If the cartridge in the drive is an INPUT tape containing ACTIVE or ‘ONLY COPY’ data (i.e., there is no backup), eject commands issued at the host fail to unload the tape, and power-cycling the drive fails to eject the cartridge, make **no further attempts** to unload this tape. Call Technical Support and open a PMR if one isn’t already open, to initiate the process of sending the drive with the loaded cartridge in for recovery.

1. Carefully pull out excess tape and untangle.

Note: If you find the tape to be broken, go to one of the following appropriate procedures:

- “Full-high Drive: Tape Spooled Off Supply Reel” on page A-7
- “Full-high Drive: Tape Pulled from or Broken near Leader Pin” on page A-9

--OR--

“Full-high Drive: Tape Broken in Mid-tape” on page A-13

2. Set the drive on its left side with the head and tape path facing up.





Figure A-15. Using hex wrench to rewind tape into cartridge

3. From the bottom of the drive, locate the access hole (**1** in Figure A-15).
4. Insert a 2.5 mm offset hex wrench through the bottom cover access hole and into the reel motor axle. Begin spooling the tape back into the cartridge by turning the hex wrench clockwise.
5. Continue spooling into the cartridge until the tape is taut and remains within the flanges of the tape guiding rollers. Ensure that you do not stretch the tape.
6. Locate the threader motor worm gear (**4** in Figure A-16 on page A-17) on the rear of the drive. Use your finger to rotate the threader motor worm gear and slowly rotate the threader mechanism gear (**6** in Figure A-16 on page A-17) clockwise. This rotates the threader motor worm gear (**4** in Figure A-16 on page A-17) clockwise, drawing the LBA into the cartridge.



a82ru009

Figure A-16. Drive with cover removed to reveal gear train.

- | | | | |
|----------|-------------------------------------|----------|-------------------------|
| 1 | Loader motor worm gear | 6 | Threader mechanism gear |
| 2 | Cartridge loader tray guide bearing | 7 | Lever |
| 3 | Rotator stub | 8 | Loader mechanism gear |
| 4 | Threader motor worm gear | | |
| 5 | Threader intermediate gear | | |

7. As the tape leader block assembly (LBA) is secured in the cartridge, you should hear the LBA retention spring clips click into place. If you do not hear the click, continue rolling until the threader motor worm gear (**4** in Figure A-16) stops. The LBA is in the correct position.

Note: Be sure to keep tension on the tape as the LBA is drawn into the cartridge by using a hex wrench as shown in Figure A-15 on page A-16.

8. Notice the:
 - a. Loader mechanism gear (**6** in Figure A-16) nearest the front of the drive that actuates the cartridge loader mechanism.
 - b. Position of the rotate stub (**3** in Figure A-16).
 - c. Front loader motor worm gear (**1** in Figure A-16). Rotating this gear allows the loader mechanism gear (**8** in Figure A-16) to turn.
9. Rotate the loader motor worm gear (**1** in Figure A-16) to turn the threader mechanism gear (**6** in Figure A-16) counterclockwise. Continue turning until the rotator stub (**3** in Figure A-16) loses contact with the lever (**7** in Figure A-16). This releases the LBA leader pin.

10. Rotate the threader motor worm gear (**4** in Figure A-16 on page A-17) to turn the threader mechanism gear (**6** in Figure A-16 on page A-17) counterclockwise. This moves the LBA out of the cartridge and past the read/write head. Stop this rotation when the LBA is near the tape guide roller nearest the rear of the drive shown as **1** Figure A-17.




Figure A-17. Leader Block Assembly (LBA)

11. Continue rotating the loader motor worm gear (**1** in Figure A-16 on page A-17) until the rotator stub (**3** in Figure A-16 on page A-17) is positioned as shown. Notice that the rotator stub (**3** in Figure A-16 on page A-17) is nearly aligned with the cartridge loader tray guide bearing (**2** in Figure A-16 on page A-17).
12. Remove the cartridge from the cartridge loader tray.
13. Go to “Ending Procedure” on page A-25.

Half-high Drive: Tape Tangled along Tape Path

Note: If the cartridge in the drive is an INPUT tape containing ACTIVE or ‘ONLY COPY’ data (i.e., there is no backup), eject commands issued at the host fail to unload the tape, and power-cycling the drive fails to eject the cartridge, make **no further attempts** to unload this tape. Call Technical Support and open a PMR if one isn’t already open, to initiate the process of sending the drive with the loaded cartridge in for recovery.

1. Carefully pull out excess tape and untangle.

Note: If you find the tape to be broken, go to one of the following appropriate procedures:

- “Half-high Drive: Tape Spooled Off Supply Reel” on page A-8
- “Half-high Drive: Tape Pulled from or Broken near Leader Pin” on page A-11

–OR–

- “Half-high Drive: Tape Broken in Mid-tape” on page A-14

2. Set the drive on its left side with the head and tape path facing up.




Figure A-18. Rewinding tape into cartridge

- | | | | |
|----------|---|----------|-------------------|
| 1 | Loader motor worm gear | 3 | Takeup reel motor |
| 2 | Outer guide rail
(WARNING: Do Not Touch) | 4 | Supply reel motor |

3. Turn the supply reel (**4**) clockwise.
4. Continue spooling into the cartridge until the tape is taut and remains within the flanges of the tape guiding rollers. Turn the supply reel (**4**) 10 turns. Ensure that you do not stretch the tape.
5. Go to "Ending Procedure" on page A-25.

Full-high Drive: No Apparent Failure or Damage to Tape

Note: If the cartridge in the drive is an INPUT tape containing ACTIVE or 'ONLY COPY' data (i.e., there is no backup), eject commands issued at the host fail to unload the tape, and power-cycling the drive fails to eject the cartridge, make **no further attempts** to unload this tape. Call Technical Support and open a PMR if one isn't already open, to initiate the process of sending the drive with the loaded cartridge in for recovery.

1. Set the drive on its left side with the head and tape path facing up.





Figure A-19. Using hex wrench to rewind tape into cartridge

2. From the bottom of the drive, locate the access hole (**1** in Figure A-19).
3. Insert a 2.5 mm offset hex wrench through the bottom cover access hole and into the reel motor axle. Begin spooling the tape back into the cartridge by turning the hex wrench clockwise.
4. Continue spooling into the cartridge until the tape is taut and remains within the flanges of the tape guiding rollers. Ensure that you do not stretch the tape.
5. Locate the threader motor worm gear (**4** in Figure A-20 on page A-21) on the rear of the drive. Use your finger to rotate the threader motor worm gear and slowly rotate the threader mechanism gear (**6** in Figure A-20 on page A-21) clockwise. This rotates the threader motor worm gear (**4** in Figure A-20 on page A-21) clockwise, drawing the LBA into the cartridge.



a82ru009

Figure A-20. Drive with cover removed to reveal gear train.

- | | | | |
|----------|-------------------------------------|----------|-------------------------|
| 1 | Loader motor worm gear | 6 | Threader mechanism gear |
| 2 | Cartridge loader tray guide bearing | 7 | Lever |
| 3 | Rotator stub | 8 | Loader mechanism gear |
| 4 | Threader motor worm gear | | |
| 5 | Threader intermediate gear | | |

6. As the tape leader block assembly (LBA) is secured in the cartridge, you should hear the LBA retention spring clips click into place. If you do not hear the click, continue rolling until the threader motor worm gear (**4** in Figure A-20) stops. The LBA is in the correct position.

Note: Be sure to keep tension on the tape as the LBA is drawn into the cartridge by using a hex wrench as shown in Figure A-19 on page A-20.

7. Notice the:
 - a. Loader mechanism gear (**6** in Figure A-20) nearest the front of the drive that actuates the cartridge loader mechanism.
 - b. Position of the rotate stub (**3** in Figure A-20).
 - c. Front loader motor worm gear (**1** in Figure A-20). Rotating this gear allows the loader mechanism gear (**8** in Figure A-20) to turn.
8. Rotate the loader motor worm gear (**1** in Figure A-20) to turn the loader mechanism gear (**6** in Figure A-20) counterclockwise. Continue turning until the rotator stub (**3** in Figure A-20) loses contact with the lever (**7** in Figure A-20). This releases the LBA leader pin.

9. Rotate the threader motor worm gear (**4** in Figure A-20 on page A-21) to turn the threader mechanism gear (**6** in Figure A-20 on page A-21) counterclockwise. This moves the LBA out of the cartridge and past the read/write head. Stop this rotation when the LBA is near the tape guide roller nearest the rear of the drive shown as **1** Figure A-21.




Figure A-21. Leader Block Assembly (LBA)

10. Continue rotating the loader motor worm gear (**1** in Figure A-20 on page A-21) until the rotator stub (**3** in Figure A-20 on page A-21) is positioned as shown. Notice that the rotator stub (**3** in Figure A-20 on page A-21) is nearly aligned with the cartridge loader tray guide bearing (**2** in Figure A-20 on page A-21).
11. Remove the cartridge from the cartridge loader tray.
12. Go to “Ending Procedure” on page A-25.

Half-high Drive: No Apparent Failure or Damage to Tape

Note: If the cartridge in the drive is an INPUT tape containing ACTIVE or ‘ONLY COPY’ data (i.e., there is no backup), eject commands issued at the host fail to unload the tape, and power-cycling the drive fails to eject the cartridge, make **no further attempts** to unload this tape. Call Technical Support and open a PMR if one isn’t already open, to initiate the process of sending the drive with the loaded cartridge in for recovery.

1. Set the drive on its left side with the head and tape path facing up.




Figure A-22. Rewinding tape into cartridge

- | | | | |
|----------|---|----------|-------------------|
| 1 | Loader motor worm gear | 3 | Takeup reel motor |
| 2 | Outer guide rail
(WARNING: Do Not Touch) | 4 | Supply reel motor |

2. Begin spooling the tape back into the cartridge by turning the supply reel motor (**4**) clockwise.
3. Continue spooling into the cartridge until the tape is taut and remains within the flanges of the tape guiding rollers. Ensure that you do not stretch the tape. Continue spooling until all tape is removed from the takeup reel (**3**).
4. Locate the threader intermediate gear (**1**) near the rear of the drive. You can use your finger to rotate the threader intermediate gear (**1**) and slowly rotate the threader mechanism gear (**2**) clockwise. This draws the tape leader block assembly (LBA) into the cartridge.




Figure A-23. Drive with cover removed to reveal gear train.

- | | | | | | |
|----------|-------------------------------|----------|----------------------------|----------|---------------------------|
| 1 | Threader
intermediate gear | 2 | Threader mechanism
gear | 3 | Loader motor worm
gear |
|----------|-------------------------------|----------|----------------------------|----------|---------------------------|

5. As the leader pin is secured in the cartridge, you should hear the leader pin retention spring clips click into place. If you do not hear the click, continue rolling until the threader intermediate gear (**1**) stops. The LBA is in the correct position.

Note: Be sure to keep tension on the tape as the LBA is drawn into the cartridge.

6. Rotate the loader intermediate gear (**1**) clockwise as viewed from the front of the drive until it stops. This releases the LBA leader pin.
7. Rotate the threader motor worm gear (**3**) counterclockwise until the leader block is in front of the Read/Write head. This moves the LBA out of the cartridge.




Figure A-24. Leader Block Assembly (LBA)

- | | | | |
|----------|------------------------|----------|-----------------------------|
| 1 | Loader motor worm gear | 2 | Leader block assembly (LBA) |
|----------|------------------------|----------|-----------------------------|

8. Rotate the loader motor worm gear (**3**) counterclockwise as viewed from the front of the drive until it stops.

9. Remove the cartridge from the cartridge loader tray.
10. Go to “Ending Procedure”.

Ending Procedure

1. Reassemble the drive brick by reversing the steps in “Removing the Drive Cover” on page A-6.
2. Reassemble the drive sled by performing the following steps:
 - a. Reinstall the drive brick into the sled by performing the following steps:
 - Plug in the RS-422 cable, the power cable (if applicable), and the signal cable.
 - Push the drive brick fully into the sled.
 - Align the two screws holes on each side of the sled with the screw holes on each side of the drive brick. **DO NOT TIGHTEN THE SCREWS COMPLETELY.**
 - After verifying that the drive and sled are properly aligned, fully tighten the screws.
 - b. If necessary, perform the following steps to reinstall the connection card and protective plastic cover on the sled.
 - Place the card and the protective plastic cover on top of spacers aligning the three screw holes. **DO NOT TIGHTEN THE SCREWS COMPLETELY.**
 - After verifying that the connection card and protective plastic cover are properly aligned, fully tighten the three screws.
3. Install the tape drive sled in the library. Refer to “Installing a Tape Drive Sled” on page 10-6.
4. Power ON the library and wait for the library to finish POST (power on self test), inventory and mid-tape recovery (this can take up to 1 hour).
5. If the cartridge does not eject from the drive, move the cartridge from the drive to the I/O Station (Operator Control Panel: **Control** → **Move Cartridges**; Web User Interface: **Manage Library** → **Move Media**), then discard the cartridge.
6. Run Library Verify before resuming normal library operations. Refer to “Service: Library Verify” on page 5-28.
7. If necessary, return the failed drive sled to IBM.

Writing a Drive Dump to Flash Memory

When a tape drive error is reported by the library, the drive produces a dump and saves it in RAM. If the library is powered OFF, this information will be lost. To preserve this information for analysis by IBM Technical Support, the drive dump must be copied to the drive’s flash memory. Complete the following steps to write a drive dump to flash memory.

1. Log in to the Web User Interface.
 - a. Username: Service
 - b. Password: [contact IBM Technical Support for the Service password]
2. Expand **Service Library** and click **Advance Diagnostic**.
3. Select the drive that has failed, then select **Write Drive Dump to Flash**. To determine which drive has failed, refer to the Web User Interface System Status screen.
4. Click **Execute** to write the drive dump to flash memory.

Accessing the Library using Telnet

To access a customer's library using telnet, complete the following procedure:

1. Ask the library administrator to enable the serial port (Operator Control Panel: **Service** → **Telnet Service Port**).
2. Open a Command Prompt screen.
3. Enter **telnet [library IP address]** then press the **Enter** key.
4. **FLMON>** will display.
5. Enter **h** then press the **Enter** key for the limited command menu.
6. Enter **lgi** then press the **Enter** key.
7. Enter **service** as your Username, then press the **Enter** key.
8. Enter the service Password, then press the **Enter** key. Contact your next level of support for the password.
9. Enter **help** then press the **Enter** key for the expanded command menu.
10. To end the telnet session, enter **lgo** then press the **Enter** key to log out of the library.
11. Enter **exit** then press the **Enter** key to disconnect from the library.
12. Inform the library administrator that your telnet session has ended and instruct the administrator to reboot his library to disable telnet capabilities to the library.

Appendix B. SCSI Element Types, SCSI Addresses, and Physical Configurations

For an overview of library partitioning and element addressing, see “Library Partitioning and Element Addressing” on page B-2.

The following tables contain element addresses for the 2U library and the 4U library.

Table B-1. 2U library SCSI Element Types and Element Addresses

Element Type	Element Address Range
Media Transport (Accessor) Element (MTE)	1 (0x01)
I/O Station Element (IEE)	16 (0x10)
Data Transfer (Drive) Element (DTE)	256 (0x100), 257 (0x101)
Storage Elements (STE)	4096 (0x1000) - 4117 (0x1015)

Table B-2. 4U library SCSI Element Types and Element Addresses

Element Type	Element Address Range
Media Transport (Accessor) Element (MTE)	1 (0x01)
I/O Station Elements (IEE)	16 (0x10), 17 (0x11), 18 (0x12)
Data Transfer (Drives) Elements (DTE)	256 (0x100), 257 (0x101), 258 (0x102), 259 (0x103)
Storage Elements (STE)	4096 (0x1000) - 4139 (0x102B)

2U Library I/O Slot, Storage Slots and Drive Slot Element Addresses and Physical Locations

For an overview of library partitioning and element addressing, see “Library Partitioning and Element Addressing” on page B-2.

The following table contains the physical location and SCSI element address (decimal and hexadecimal) of the I/O slot, storage slots, and drive slot in the 2U library containing only one drive. If a second drive were installed, it would be located at address 257 (0x101).

Table B-3. 2U library SCSI element addresses for storage slots and drive slot

Left Magazine ⇐ Front of 2U library				Library Rear Panel	Right Magazine Front of 2U library ⇒			
Slot 8 4103 (0x1007)	Slot 9 4104 (0x1008)	Slot 10 4105 (0x1009)	Slot 11 4106 (0x100A)	Drive 1 256 (0x100)	Slot 23 4118 (0x1016)	Slot 22 4117 (0x1015)	Slot 21 4116 (0x1014)	Slot 20 4115 (0x1013)
Slot 4 4099 (0x1003)	Slot 5 4100 (0x1004)	Slot 6 4101 (0x1005)	Slot 7 4102 (0x1006)		Slot 19 4114 (0x1012)	Slot 18 4113 (0x1011)	Slot 17 4112 (0x1010)	Slot 16 4111 (0x100F)
I/O slot 16 (0x10)	Slot 1 4096 (0x1000)	Slot 2 4097 (0x1001)	Slot 3 4098 (0x1002)		Slot 15 4110 (0x100E)	Slot 14 4109 (0x100D)	Slot 13 4108 (0x100C)	Slot 12 4107 (0x100B)

4U Library I/O Slots, Storage Slots, and Drive Slots Element Addresses and Physical Locations

For an overview of library partitioning and element addressing, see “Library Partitioning and Element Addressing.”

The following table contains the physical location (Slot x) and SCSI element address in decimal (4xxx) and in hexadecimal (0x10xx) of the I/O slots, storage slots, and drive slots in the 4U library containing only two drive sleds.

In older 4U libraries where the Dedicated Cleaning Slot (DCS) is in a fixed location (slot 9) and elected to be retained as a DCS (option to delete DCS is available in library firmware greater than 1.95), the above slot numbering and element address changes starting with slot 10. In 4U libraries with a DCS, the information shown in slot 9 below moves to slot 10 and so forth through the remaining magazine slots. The final slot is slot 44 instead of slot 45 for libraries without a DCS. See “Configuring I/O Stations and Reserving Slots” on page 5-60 for information on how to delete the dedicated cleaning slot. Once the DCS is deleted, you cannot get it back. You will have to create a reserved slot if you want to clean the drive(s).

Table B-4. 4U library SCSI element addresses for storage slots and drive slot

Upper Left Magazine ⇐Front of 4U library				Library Rear Panel	Upper Right Magazine Front of 4U library⇒			
Slot 18 4113 (0x1011)	Slot 19 4114 (0x1012)	Slot 20 4115 (0x1013)	Slot 21 4116 (0x1014)	Drive 2 257 (0x101)	Slot 45 4140 (0x102C)	Slot 44 4139 (0x102B)	Slot 43 4138 (0x102A)	Slot 42 4137 (0x1029)
Slot 14 4109 (0x100D)	Slot 15 4110 (0x100E)	Slot 16 4111 (0x100F)	Slot 17 4112 (0x1010)		Slot 41 4136 (0x1028)	Slot 40 4135 (0x1027)	Slot 39 4134 (0x1026)	Slot 38 4133 (0x1025)
Slot 10 4105 (0x1009)	Slot 11 4106 (0x100A)	Slot 12 4107 (0x100B)	Slot 13 4108 (0x100C)		Slot 37 4132 (0x1024)	Slot 36 4131 (0x1023)	Slot 35 4130 (0x1022)	Slot 34 4129 (0x1021)
Lower Left Magazine				Drive 1 256 (0x100)	Lower Right Magazine			
I/O Slot 3 18 (0x12)	Slot 7 4102 (0x1006)	Slot 8 4103 (0x1007)	Slot 9 4104 (0x1008)		Slot 33 4128 (0x1020)	Slot 32 4127 (0x101F)	Slot 31 4126 (0x101E)	Slot 30 4125 (0x101D)
I/O Slot 2 17 (0x11)	Slot 4 4099 (0x1003)	Slot 5 4100 (0x1004)	Slot 6 4101 (0x1005)		Slot 29 4124 (0x101C)	Slot 28 4123 (0x101B)	Slot 27 4122 (0x101A)	Slot 26 4121 (0x1019)
I/O Slot 1 16 (0x10)	Slot 1 4096 (0x1000)	Slot 2 4097 (0x1001)	Slot 3 4098 (0x1002)		Slot 25 4120 (0x1018)	Slot 24 4119 (0x1017)	Slot 23 4118 (0x1016)	Slot 22 4117 (0x1015)

Library Partitioning and Element Addressing

Library 4U systems with firmware versions of 1.70 and higher, and containing at least 2 drives, have the ability to configure two logical libraries (create two partitions). This partitioning has been expanded with the new library firmware and half-high drive integration. Now it is possible to configure 1, 2, 3 or 4 partitions in the 4U library. Additionally the 2U library can now be configured into one or two partitions. Each library must contain at least one drive per logical library (partition).

Partitioning of 2U Libraries

When two half high drives are installed in a 2U library, the library firmware will support partitioning in the same way that the 4U supports partitioning with two full high drives today. The first partition will contain the first magazine and the first drive. The second partition will contain the second magazine and the second drive. The I/O station (if configured as I/O) will be shared, as is done with the partitioned 4U library.

One full high drive is "Drive 1". When using half high drives, the first half high drive position will be called "Drive 1", The second half high drive position will be called "Drive 2."

Partitioning of 4U Libraries

When one or more half high drives are added to a 4U library, the drive naming will change. Currently, the first full high drive is "Drive 1" and the second full high drive is "Drive 2". When you consider that each full high drive slot may contain one or two half high drives, there are four potential drives in the space that used to occupy two. As a result, the first half high drive position, or the first full-high drive position, will be called "Drive 1". The second half high drive position will be called "Drive 2". The third half high drive position, or the second full high drive position, will be called "Drive 3". The fourth half high drive position will be called "Drive 4".

Mixing of Drives

The library will support a mix of full high and half high drives in the same physical library and the same logical library. They will support a mix of Gen 3 and Gen 4 drives in the same physical library and the same logical library. They will also support a mix of SCSI, SAS, and Fibre Channel in the same physical library and the same logical library; however, mixing drive interface types in the same logical library is not recommended.

Configuration of a 1 - Partition System

A one partition system configured for a 4U library contains any and all drives present in any drive positions, and it will contain all four magazines.




Figure B-1. Configuration of a one - partition system

Configuration of a 2 - Partition System

A two partition system must have at least two drives installed. One drive must be installed in either drive position 1 or drive position 2, and another drive must be installed in either drive position 3 or drive position 4. Partition 1 will contain any

drives in drive position 1 and drive position 2. Partition 1 will also contain magazine 1 and magazine 2. Partition 2 will contain any drives in drive position 3 and drive position 4. Partition 2 will also contain magazine 3 and magazine 4.




Figure B-2. Configuration of a two - partition system

Configuration of a 3 - Partition System

A three partition system must have at least three drives installed. A drive must be installed in drive position 1, another drive must be installed in drive position 2, and another drive must be installed in either drive position 3 or drive position 4. Partition 1 will contain the first drive and the first magazine. Partition 2 will contain the second drive and the second magazine. Partition 3 will contain any drives in drive position 3 and drive position 4. Partition 3 will also contain magazine 3 and magazine 4.




Figure B-3. Configuration of a three - partition system

Configuration of a 4 - Partition System

A four partition system must have four drives. Each partition will contain one drive and one magazine.




Figure B-4. Configuration of a four - partition system

SCSI Element Addressing

Every logical library starts at the first drive slot with the current assigned element start address (default value 256). It will be incremented from the bottom to the top slots for every drive slot. There is one exception to this addressing scheme to accommodate libraries currently in the field. A 4U library which contains only full high drives will continue to have the addresses assignments 256 and 257, thus causing no interruptions to their operation. Drive slots will still be incremented by 1 for each drive slot position.

Note: Exchanging drives with different form factors will result in the library needing to be reconfigured.




Figure B-5. Examples of SCSI element addressing

The SCSI specification does not allow gaps in the SCSI element addressing. Special handling is needed for empty drive slots to fulfill the specification. Also temporarily removed drives need to have their addresses preserved to not confuse the attached host and host application. Generally only drives which are currently physically available or temporarily removed are reported. Empty (unused) slots located at the bottom or the top should not be reported, with an exception in case of a “removed” condition. A drive slot which does not contain a drive, and has a position between used slots, needs to be reported as a SCSI element. To signal the host application that this slot is not usable, its ACCESS bit will be disabled.

Note: When reducing the number of drives in your library, update the Logical Library configuration. This will remove the Attention LED on the front panel and the exclamation mark on the Home screen indicating that a drive is missing.

Updating the Logical Library configuration will also update the drive element addressing and drive numbering. Replacing LTO half high drives with full high drives may require you to execute Restore Factory Defaults to correctly update the drive element addressing and drive numbering. See “Configure Library: Restore Defaults” on page 5-52.

Appendix C. TapeAlert Flags

This appendix is intended to provide additional information to the reader about the tape drive. All error code and diagnostic information contained in this chapter can be accessed from the Operator Control Panel of the Library. The drive portion of the Operator Control Panel Display will contain any drive error codes. Therefore there is no need to open the Library to access the buttons on the drive as described in this chapter. See the Setup, Operator and Service Guide for a complete description of the Operator Control Panel functions and Displays.

TapeAlert is a standard that defines status conditions and problems experienced by devices such as tape drives, autoloaders, and libraries. The standard enables a server to read TapeAlert messages (called *flags*) from a tape drive via the SCSI bus. The server reads the flags from Log Sense Page 0x2E.

This library is compatible with TapeAlert technology, which provides error and diagnostic information about the drives and the library to the server. Because library and drive firmware may change periodically, the SNMP interface in the library does not require code changes if devices add additional TapeAlerts that are not supported today. However, should this occur the Management Information Block (MIB) is written to minimize impact to the SNMP monitoring station. At the time of this writing, the TapeAlert flags in this appendix correctly represent TapeAlerts that will be sent. The MIB file should not be taken to mean that all traps that are defined in the MIB (refer to Appendix F, “SNMP Status MIB Variables and Traps,” on page F-1) will be sent by the library or that they will be sent in the future.

This appendix lists TapeAlert flags that are supported by the Ultrium 3 and Ultrium 4 Tape Drives.

TapeAlert Flags Supported by the Library

Parameter Code (d=decimal)	Flag name	Type	Action Required
01d	Library Hardware A	C	The media changer mechanism is having difficulty communicating with the drive. Power cycle the library and try the operation again. • If the problem is corrected, run Library Verify before resuming normal library operations. Refer to “Service: Library Verify” on page 5-28. • If the problem persists, go to “Contacting IBM Technical Support” on page 9-5.
02d	Library Hardware B	W	There is a problem with the media changer mechanism. Power cycle the library and try the operation again. • If the problem is corrected, run Library Verify before resuming normal library operations. Refer to “Service: Library Verify” on page 5-28. • If the problem persists, go to “Contacting IBM Technical Support” on page 9-5.

03d	Library Hardware C	C	The media changer has a hardware fault: • Ensure that the media changer and drives are not being used by any host, then reset the library from the front panel. • If the problem persists, go to “Contacting IBM Technical Support” on page 9-5.
04d	Library Hardware D	C	• Ensure that the media changer and drives are not being used by any host, then reset the library from the front panel. • If the problem persists, go to “Contacting IBM Technical Support” on page 9-5.
13d	Library Pick Retry	W	There is a potential problem with the cartridge loader picking a cartridge from a drive or slot. • No action needs to be taken at this time. • If the problem persists, go to “Contacting IBM Technical Support” on page 9-5. This flag is cleared when the next move command is received.
14d	Library Place Retry	W	There is a potential problem with the cartridge loader placing a cartridge into a slot. • No action needs to be taken at this time. • If the problem persists, go to “Contacting IBM Technical Support” on page 9-5. This flag is cleared when the next move command is received.
15d	Drive Load Retry	W	There is a potential problem with the cartridge loader or drive when placing a cartridge into a drive. • No action needs to be taken at this time. • If the problem persists, go to “Contacting IBM Technical Support” on page 9-5. This flag is cleared when the next move command is received.
17d	Library I/O Station	C	There is a mechanical problem with the library media I/O Station.
18d	Media Changer	C	It is set when a magazine is removed from the changer.
19d	Library Security	W	Library security has been compromised. The door was opened then closed during operation.
21d	Media Changer	I	It is set when the changer is set offline.
24d	Library Inventory	C	The library has detected an inconsistency in its inventory. • Redo the library inventory to correct inconsistency. • Restart the operation. Check the applications users manual or the hardware users manual for specific instructions on redoing the library inventory.
25d	Media Changer	W	It is set when it receives unsupported SCSI opcodes.
27d	Cooling FAN Failure	W	One or more fans inside the library have failed. This flag is cleared when all fans are working again.
32d	Unreadable Bar Code Labels	I	The library was unable to read the barcode on a cartridge.

- D = Decimal
- I = Informational suggestion to user
- W = Warning. Remedial action is advised. Performance of data may be at risk.
- C = Critical immediate remedial action is required.

TapeAlert Flags Supported by the Drive

Table C-1. TapeAlert Flags Supported by the Ultrium Tape Drive

Flag Number	Flag	Description	Action Required
3	Hard error	Set for any unrecoverable read, write, or positioning error. (This flag is set in conjunction with flags 4, 5, or 6.)	See the Action Required column for Flag Number 4, 5, or 6 in this table.
4	Media	Set for any unrecoverable read, write, or positioning error that is due to a faulty tape cartridge.	Replace the tape cartridge.
5	Read failure	Set for any unrecoverable read error where isolation is uncertain and failure could be due to a faulty tape cartridge or to faulty drive hardware.	If Flag 4 is also set, the cartridge is defective. Replace the tape cartridge.
6	Write failure	Set for any unrecoverable write or positioning error where isolation is uncertain and failure could be due to a faulty tape cartridge or to faulty drive hardware.	If Flag Number 9 is also set, make sure that the write-protect switch is set so that data can be written to the tape (see "Write-Protect Switch" on page 6-7)). If Flag Number 4 is also set, the cartridge is defective. Replace the tape cartridge.
7	Media life	Set when the tape cartridge reaches its end of life (EOL).	1. Copy the data to another tape cartridge. 2. Discard the old (EOL) tape.
8	Not data grade	Set when the cartridge is not data-grade. Any data that you write to the tape is at risk.	Replace the tape with a data-grade tape.
9	Write protect	Set when the tape drive detects that the tape cartridge is write-protected.	Ensure that the cartridge's write-protect switch is set so that the tape drive can write data to the tape (see "Write-Protect Switch" on page 6-7).
10	No removal	Set when the tape drive receives an UNLOAD command after the server prevented the tape cartridge from being removed.	Refer to the documentation for your server's operating system.
11	Cleaning media	Set when you load a cleaning cartridge into the drive.	No action required.
12	Unsupported format	Set when you load an unsupported cartridge type into the drive or when the cartridge format has been corrupted.	Use a supported tape cartridge.
15	Cartridge memory chip failure	Set when a cartridge memory (CM) failure is detected on the loaded tape cartridge.	Replace the tape cartridge.

Table C-1. TapeAlert Flags Supported by the Ultrium Tape Drive (continued)

Flag Number	Flag	Description	Action Required
16	Forced eject	Set when you manually unload the tape cartridge while the drive was reading or writing.	No action required.
17	Media loaded is Read-only format	Set when a cartridge marked as read only is loaded into the drive. The flag is cleared when the cartridge is ejected.	No action required.
18	Tape directory corrupted in the cartridge memory	Set when the drive detects that the tape directory in the cartridge memory has been corrupted.	Re-read all data from the tape to rebuild the tape directory.
19	Nearing media life	Set when the tape cartridge is nearing its specified end of life. The flag is cleared when the cartridge is removed from the drive.	1. Copy the data to another tape cartridge. 2. Replace the tape cartridge.
20	Clean now	Set when the tape drive detects that it needs cleaning.	Clean the tape drive.
21	Clean periodic	Set when the drive detects that it needs routine cleaning.	Clean the tape drive as soon as possible. The drive can continue to operate, but you should clean the drive soon.
22	Expired clean	Set when the tape drive detects a cleaning cartridge that has expired.	Replace the cleaning cartridge.
23	Invalid cleaning tape	Set when the drive expects a cleaning cartridge and the loaded cartridge is not a cleaning cartridge.	Use a valid cleaning cartridge.
30	Hardware A	Set when a hardware failure occurs that requires that you reset the tape drive to recover.	Go to "Contacting IBM Technical Support" on page 9-5.
31	Hardware B	Set when the tape drive fails its internal Power-On Self Tests.	Note the error code on the single-character display, then go to "Contacting IBM Technical Support" on page 9-5.
32	Interface	Set when the tape drive detects a problem with the host interface.	Go to "Contacting IBM Technical Support" on page 9-5.
33	Eject media	Set when a failure occurs that requires you to unload the cartridge from the drive.	Unload the tape cartridge, then reinsert it and restart the operation.
34	Download fail	Set when an FMR image is unsuccessfully downloaded to the tape drive through the host interface.	Ensure that it is the correct FMR image. Download the FMR image again.
37	Drive voltage	Set when the drive detects that the externally supplied voltages are either approaching the specified voltage limits or are outside the voltage limits.	Go to "Contacting IBM Technical Support" on page 9-5.
38	Predictive failure of drive hardware	Set when a hardware failure of the tape drive is predicted.	Go to "Contacting IBM Technical Support" on page 9-5.
39	Diagnostics required	Set when the drive detects a failure that requires diagnostics for isolation.	Go to "Contacting IBM Technical Support" on page 9-5.

Table C-1. TapeAlert Flags Supported by the Ultrium Tape Drive (continued)

Flag Number	Flag	Description	Action Required
51	Tape directory invalid at unload	Set when the tape directory on the tape cartridge that was previously unloaded is corrupted. The file-search performance is degraded.	Use your backup software to rebuild the tape directory by reading all the data.
52	Tape system area write failure	Set when the tape cartridge that was previously unloaded could not write its system area successfully.	Copy the data to another tape cartridge, then discard the old cartridge.
53	Tape system area read failure	Set when the tape system area could not be read successfully at load time.	Copy the data to another tape cartridge, then discard the old cartridge.
55	Loading Failure	When loading a tape into a drive, a hardware malfunction can prevent the tape from being loaded into the drive, or the tape may actually get stuck in the drive.	Take this action if the tape cartridge will not load in the drive: 1. Remove the tape cartridge from the library and inspect it for damage. If damaged, discard it. 2. Try another cartridge in that tape drive. If it still fails, replace the drive sled. See “Removing/Installing/Adding a Tape Drive Sled” on page 10-3. Take this action if the tape is stuck in the drive: 1. Attempt to unload the tape from the drive using the host backup application that is currently using the drive, or using the remote or local UI. 2. If the cartridge will not unload, go to “Contacting IBM Technical Support” on page 9-5.
56	Unload Failure	When attempting to unload a tape cartridge, a drive hardware malfunction can prevent the tape from being ejected. The tape may actually be stuck in the drive.	1. Unload the cartridge from the drive using the Operator Control Panel (Control → Move Cartridge) or the Web User Interface (Manage Library → Move Media). 2. Cycle drive power using the Operator Control Panel (Service → Service → Drive Power) or the Web User Interface (Configure Library → Drives). 3. Try unloading the cartridge from the drive again using the Operator Control Panel (Control → Move Cartridge) or the Web User Interface (Manage Library → Move Media). 4. If the cartridge will not unload from the drive, go to “Contacting IBM Technical Support” on page 9-5.

Table C-1. TapeAlert Flags Supported by the Ultrium Tape Drive (continued)

Flag Number	Flag	Description	Action Required
59	WORM Medium – integrity check failed	Set when the drive determines that the data on tape is suspect from a WORM point of view.	1. Copy the data to another WORM tape cartridge. 2. Discard the old WORM tape.
60	WORM Medium – Overwrite attempted	Set when the drive rejects a write operation because the rules for allowing WORM writes have not been met. Data can only be appended to WORM media. Overwrites to WORM media are not allowed.	Append the information on a WORM tape cartridge or write the data to a non-WORM cartridge.

Appendix D. Sense Data

When a drive encounters an error, it makes sense data available. You can use IBM device drivers to examine the sense data and determine errors. Instructions for downloading, installing, and properly configuring the IBM device drivers are available in the *IBM Ultrium Device Drivers Installation and User's Guide*. The IBM device drivers may conflict with some commercial software applications unless properly configured. To avoid conflicts on Windows operating systems, refer to your device driver's procedures for setting the driver to manual startup mode. For applications that use Open Systems device drivers that are provided by IBM (for example, AIX®, Sun Solaris, HP-UX, Windows 2000, Linux®, and Windows 2003), the *Ultrium Device Drivers Installation and User's Guide* contains information about how to obtain sense data after an error has occurred.

If your application uses other device drivers, see the appropriate documentation for those drivers to obtain the sense data.

Raw sense data (as returned from the drive) is documented in the *IBM LTO Ultrium Tape Drive SCSI Reference*.

In addition to device drivers, other methods exist for obtaining sense data and error information. The sections that follow describe alternatives for gathering such information from the IBM System i™, and System p™ servers.

Library Sense Data

The following table lists the Additional Sense Codes (ASC) and Additional Sense Code Qualifiers (ASCQ) associated with the reported Sense Keys.

A sense key of 00h (no sense) has no ASC/ASCQ associated with it. A few ASC/ASCQs can be associated with more than one sense key. The sense keys that can give a particular ASC/ASCQ are indicated within the Sense Key column. ASC/ASCQs that can indicate an abnormal element state as part of element descriptor.

Table D-1. Library Sense Keys, ASC and ASCQ

Sense Key	ASC	ASCQ	Description
Recovered Error (01)	0Ah	00h	Error log overflow
	47h	00h	SCSI parity error

Table D-1. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Not Ready (02)	00h	17h	Drive cleaning requested
	04h	00h	Cause not reportable
	04h	01h	In progress becoming ready, scanning magazines, etc.
	04h	02h	Initializing command required
	04h	03h	Manual intervention required
	04h	07h	Operation in progress
	04h	12h	Offline
	04h	83h	Door open
	04h	85h	Firmware upgrade in progress
	04h	87h	The drive is not enabled
	04h	88h	The drive is busy
	04h	89h	The drive is not empty
	04h	9Ah	Drive fibre down
	04h	8Eh	The media changer is in sequential mode
	30h	03h	Cleaning in progress
	3Bh	12h	Magazine removed
Medium Error (03)	30h	00h	Incompatible media installed
	30h	03h	Cleaning tape installed
	30h	07h	Cleaning failure

Table D-1. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Hardware Error (04)	81h	80h	Cannot initialize bar code reader
	81h	81h	No response from bar code reader
	81h	82h	No response from EEPROM
	81h	83h	Slave robotic generic problem
	81h	84h	Setting of gripper pic value failed
	81h	85h	Setting of slider pic value failed
	81h	86h	Setting of elevator pic value failed
	81h	87h	Setting of rotation pic value failed
	81h	88h	Setting of sled pic value failed
	81h	89h	Gripper blocked
	81h	8Ah	Slider blocked
	81h	8Bh	Elevator blocked
	81h	8Ch	Rotation blocked
	81h	8Dh	Sled blocked
	81h	8Eh	Cannot find gripper block
	81h	8Fh	Cannot find slider block
	81h	90h	Cannot find elevator block
	81h	91h	Cannot find rotation block
	81h	92h	Cannot find sled block
	81h	93h	Gripper outside range
	81h	94h	Slider outside range
	81h	95h	Elevator outside range
	81h	96h	Rotation outside range
	81h	97h	Sled outside range
	81h	98h	No cartridge present sensor found
	81h	99h	No slider home sensor found
	81h	9Ah	No rotation home sensor found
	81h	9Bh	No sled position sensor found
	81h	9Ch	The range of gripper is wrong
	81h	9Dh	The range of slider is wrong
	81h	9Eh	The range of elevator is wrong
	81h	9Fh	The range of rotation is wrong
	81h	A0h	The range of sled is wrong
	81h	A1h	Open import/export element failed
	81h	A2h	Locking failed
	81h	A3h	SE2 Block
	81h	A4h	SE2 No Block
	81h	A5h	No Sled2 Home Sensor
	81h	A6h	No Elev Home Sensor

Table D-1. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Hardware Error (04) (continued)	81h	B0h	Slave robotic controller response timeout
	81h	B1h	NACK received from slave robotic controller
	81h	B2h	Slave robotic controller communication failed
	81h	B3h	Slave robotic controller urgent stop
	81h	B4h	Cartridge did not transport completely
	81h	B5h	Slave robotic controller does not respond on command
	80h	C0h	Network init
	80h	C1h	Telnet interface
	80h	C2h	Webserver
	80h	C3h	EEPROM parameter
	80h	C4h	Cannot init LAN card
	80h	C5h	Write to EEPROM failed
	80h	C6h	Ping command did not reach target
	80h	C7h	Cannot upgrade from USB
	80h	D0h	ROM error
	80h	D1h	RAM error
	80h	D2h	NVRAM error
	80h	D3h	CTC error
	80h	D4h	UART error
	80h	D5h	Display error
	80h	D6h	Memory error
	80h	D7h	Fatal system error
	80h	D8h	dBase error
	80h	D9h	No SCSI IC detected
	80h	DAh	Different bar code labels
	80h	DBh	External cooling fan failure
	80h	DCh	Internal I2C bus error
	80h	DFh	Power Good failed
	80h	E0h	Incompatible Magazine
	82h	F0h	Over temperature problem
	82h	F1h	Drive communication error
	82h	F2h	Drive sled not present
	82h	F3h	Drive broken: needs repair
	82h	F4h	Drive load timeout
	82h	F5h	Drive unload timeout
	82h	F6h	Drive never present
	82h	F7h	Drive support ticket error

Table D-1. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Illegal Request (05h)	1Ah	00h	Parameter length error
	20h	00h	Invalid command operation code
	21h	01h	Invalid element address
	24h	00h	Invalid field CDB
	3Dh	00h	SCSI invalid ID message
	25h	00h	Invalid LUN
	2Ch	00h	Command sequence error
	26h	00h	Invalid field in parameter list
	26h	01h	Parameter list error: parameter not supported
	26h	02h	Parameter value invalid
	26h	90h	Wrong firmware image, does not fit boot code
	26h	91h	Wrong personality firmware image
	26h	93h	Wrong firmware image, checksum error
	39h	00h	Saving parameters not supported
	3Bh	0Dh	Medium destination element full
	3Bh	0Eh	Medium source element empty
	3Bh	11h	Medium magazine not accessible
	3Bh	81h	Cartridge of other partition
	3Bh	A0h	Medium transfer element full
	53h	02h	Library media removal prevented state set
	53h	03h	Drive media removal prevented state set
	44h	80h	Bad status library controller
	44h	81h	Source not ready
	44h	82h	Destination not ready
	44h	83h	Cannot make reservation
	44h	84h	Wrong drive type
	44h	85h	Invalid slave robotic controller request
	44h	86h	Accessor not initialized
Unit Attention (06h)	28h	00h	Not ready to ready transition
	28h	01h	Import/export element accessed
	29h	01h	Power on occurred
	29h	02h	SCSI Bus reset occurred
	29h	05h	Bus type changed to Single Ended (SE)
	29h	06h	Bus type changed to Low Voltage Differential (LVD)
	2Ah	01h	Mode parameters changed
	2Ah	10h	Time stamp changed
	3Bh	13h	Medium magazine inserted
	3Fh	01h	Microcode has changed
	53h	02h	Media removal prevented

Table D-1. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Command Aborted (0Bh)	3Fh	0Fh	ECHO buffer overwritten
	43h	00h	SCSI message error
	47h	00h	SCSI parity error
	49h	00h	SCSI invalid message
	4Eh	00h	Overlapped command attempt

Drive Sense Data

LTO Ultrium 4 drives contain hardware which performs user data write encryption and read decryption, protecting all user data written to the medium from unauthorized use, provided it is integrated into a secure system design.

Table D-2. LTO Tape Drive Sense Data

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
0	Address valid When set to 1, the info byte field contains a valid logical block address.	Error Code						
1	Segment Number (0)							
2	Filemark	EOM (end of medium)	ILI (Incorrect length indicator)	Reserved	Sense Key Description 0 - No sense 1 - Recovered error 2 - Not ready 3 - Media error 4 - Hardware error 5 - Illegal request 6 - Unit attention 7 - Data protect 8 - Blank Check 9 - Reserved A - Reserved B - Aborted command C - Reserved D - Volume overflow E - Reserved F - Reserved			
3	Information byte (most significant byte)							
4	Information byte							
5	Information byte							
6	Information byte (least significant byte)							
7	Additional Sense Length							
8-11	Command specific information							

Table D-2. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
12-13	Additional Sense Code (ASC) Additional Sense Code Qualifier (ASCQ) Byte 12 Byte 13 ASC ASCQ							
	00	00	00 - No additional sense - The flags in the sense data indicate the reason for the command failure					
	00	01	01 - Filemark detected - A Read or Space command terminated early due to an FM The FM flag is set.					
	00	02	02 - EOM - A Write or Write File Marks command failed because the physical end of tape was encountered, or a Read or Space command encountered EOM The EOM flag is set					
	00	04	04 - BOM - A space command ended at Beginning of Tape The EOM bit is also set					
	00	05	05 - EOD - Read or Space command terminated early because End of Data was encountered					
	00	16	16 - Operation in Progress					
	04	00	00 - Cause not reportable - A cartridge is present in the drive, but it is in the process of being unloaded					
	04	01	01 - Becoming Ready - A media access command was received during a front panel initiated load or an immediate reported load command					
	04	02	02 - Initializing Command Required - A cartridge is present in the drive, but is not logically loaded. A Load command is required					
	04	03	03 - Manual Intervention Required - A cartridge is present in the drive but could not be loaded or unloaded without manual intervention					
	04	10	10 - Logical unit not ready, auxiliary memory not accessible					
	04	12	12 - Logical unit not ready, offline					
	08	01	01 - Logical unit communication failure					
	09	00	00 - Track following error (servo)					
	0C	00	00 - Write Error - A Write operation has failed. This is probably due to bad media, but may be hardware related					
	11	00	00 - Unrecovered Read Error - A Read operation failed. This is probably due to bad media, but may be hardware related					
	11	12	12 - Auxiliary memory read error. The drive reported that it is unable to read the Auxiliary Memory in a WORM cartridge.					
	14	00	00 - Recorded Entity Not Found - A space or Locate command failed because a format violation prevented the target from being found.					
	14	03	03 - End Of Data not found - A Read type operation failed because a format violation related to a missing EOD data set					
	14	10	10 - Not Ready - Auxiliary memory not accessible. The drive is not able to become ready because it is unable to access the Auxiliary Memory in a WORM cartridge.					
	17	01	01 - Recovered data with retries					
	1A	00	00 - Parameter list length error - The amount of parameter data sent is incorrect					
	20	00	00 - Invalid Command Operation Code - The Operation Code in the command was not a valid Operation Code					
	24	00	00 - Invalid field in CDB - An invalid field has been detected in a Command Descriptor Block					
	25	00	00 - LUN not supported - The command was addressed to a non-existent logical unit number					
	26	00	00 - Invalid Field in Parameter List - An invalid field has been detected in the data sent during the data phase					

Table D-2. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
12-13	Additional Sense Code (ASC) - Additional Sense Code Qualifier (ASCQ) (Continued) Byte 12 Byte 13 ASC ASCQ							
27	00	Write Protect - A Write type operation has been requested on a cartridge which has been write protected						
28	00	Not Ready to Ready Transition - A cartridge has been loaded successfully into the drive and is now ready to be accessed						
28	01	Import or export element accessed						
29	00	Reset - The drive has powered on, received a reset signal or a bus device reset signal since the initiator last accessed it						
29	04	Device internal reset						
2A	01	Mode Parameters Changed - The Mode parameters for the drive have been changed by an initiator other than the one issuing the command						
2C	00	Command sequence error						
2C	0B	Not reserved - The OIR bit of the sequential access device page is set and the I-T nexus attempting to communicate with the drive does not hold a reservation.						
2F	00	Commands cleared by another initiator						
30	00	Incompatible Media Installed - A write type operation could not be executed because it is not supported on the cartridge type that is loaded.						
30	01	Unknown Format - An operation could not be carried out because the cartridge in the drive is of a format not supported by the drive						
30	02	Incompatible Format - An operation could not be completed because the Logical Format is not correct						
30	03	Cleaning Cartridge Installed - An operation could not be carried out because the cartridge in the drive is a cleaning cartridge						
30	05	Cannot write medium, incompatible format						
30	07	Cleaning Failure - A cleaning operation was attempted, but could not be completed for some reason						
30	0C	Data Protect - WORM overwrite attempted. The drive rejected a write operation because it would have resulted in an overwrite. Overwrite is not allowed on WORM media.						
30	0D	Medium Error - WORM integrity check. The drive rejected a Read or Write operation because the cartridge is a suspicious WORM cartridge.						
31	00	Media format corrupted - Data could not be read because the format on tape is not valid, but is a known format. A failure occurred attempting to write the FID						
37	00	Rounded parameter - A Mode Select command parameter has been rounded because the drive can not store it with the accuracy of the command.						
3A	00	Media Not Present - A media access command has been received when there is no cartridge loaded						
3B	00	Sequential Positioning Error - A command has failed and left the logical position at an unexpected location						
3B	0C	Position past beginning of medium						
3D	00	Invalid bits in identify Message - An illegal Identify Message has been received at the drive at the start of a command						
3E	00	Logical Unit has not Self-Configured - The drive has just powered on and has not completed its self test sequence and can not process commands						
3F	01	Code Download - The firmware in the drive has just been changed by a Write Buffer command						
3F	03	Inquiry data has changed						
3F	0E	Reported LUNs data has changed						
3F	0F	Echo buffer overwritten						
40	xx	Diagnostic failure - A diagnostic test has failed. The xx (ASCQ) is a vendor specific code indicating the failing component.						

Table D-2. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
12-13	Additional Sense Code (ASC) - Additional Sense Code Qualifier (ASCQ) (Continued) Byte 12 Byte 13 ASC ASCQ 41 00 - Data path failure 43 00 - Message Error - A message could not be sent or received due to excessive transmission errors 44 00 - Internal target failure - A hardware failure has been detected in the drive that has caused the command to fail 45 00 - Select/Reset Failure - An attempt to reselect an initiator in order to complete the command has failed 48 00 - Initiator detected error message received 49 00 - Invalid message error 4A 00 - Command phase error 4B 00 - Data Phase Error - A command could not be completed because too many parity errors occurred during the Data phase 4E 00 - Overlapped Commands - An initiator selected the drive even though it already had a command outstanding in the drive 50 00 - Write Append Error - A write type command failed because the point at which to append data was unreadable 51 00 - Erase failure - An Erase command failed to erase the required area on the media 52 00 - Cartridge fault - A command could not be completed due to a fault in the tape cartridge 53 00 - Media Load/Eject Failed - (Sense Key 03) An attempt to load or eject the cartridge failed due to a problem with the cartridge. 53 00 - Media Load/Eject Failed - (Sense Key 04) An attempt to load or eject the cartridge failed due to a problem with the drive 53 02 - Media Removal Prevented - An Unload command has failed to eject the cartridge because media removal has been prevented 5A 01 - Operator medium removal request 5D 00 - Failure Prediction Threshold - Failure Prediction thresholds have been exceeded indicating that a failure may occur soon 5D FF - Failure Prediction False - A Mode Select command has been used to test for Failure Prediction system. 82 82 - Drive requires cleaning - The drive has detected that a cleaning operation is required to maintain good operation 82 83 - Bad Code Detected - The data transferred to the drive during a firmware upgrade is corrupt or incompatible with drive hardware							

Table D-2. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
12-13	Additional Sense Code (ASC) - Additional Sense Code Qualifier (ASCQ) (Continued) Byte 12 Byte 13 ASC ASCQ Sense Key 0 (No Sense) EE 13 - Encryption - Key Translate EF 13 - Encryption - Key Translate EKM Sense Key 3 (Medium Error) 30 02 - Encryption - Encryption feature is not enabled so format/processing is not supported EE 60 - Encryption - Proxy Command Error EE D0 - Encryption - Data Read Decryption Failure EE D1 - Encryption - Data Read after Write Decryption Failure EE E0 - Encryption - Key Translation Failure EE E1 - Encryption - Key Translation Ambiguous EE F0 - Encryption - Decryption Fenced (Read) EE F1 - Encryption - Encryption Fenced (Write) Sense Key 4 (Hardware Error) EE 0E - Encryption - Key Service Timeout EE 0F - Encryption - Key Service Failure 40 00 - Encryption - Failure Hardware, POST or Module Failure Sense Key 5 (Illegal Request) EE 00 - Encryption - Key Service Not Enabled EE 01 - Encryption - Key Service Not Configured EE 02 - Encryption - Key Service Not Available EE 10 - Encryption - Key Required EE 20 - Encryption - Key Count Exceeded EE 21 - Encryption - Key Alias Exceeded EE 22 - Encryption - Key Reserved EE 23 - Encryption - Key Conflict EE 24 - Encryption - Key Method Change EE 25 - Encryption - Key Format Not Supported EE 26 - Encryption - Unauthorized Request - dAK EE 27 - Encryption - Unauthorized Request - dSK EE 28 - Encryption - Unauthorized Request - eAK EE 29 - Encryption - Authentication Failure EE 2A - Encryption - Invalid RDKi EE 2B - Encryption - Key Incorrect EE 2C - Encryption - Key Wrapping Failure EE 2D - Encryption - Sequencing Failure EE 2E - Encryption - Unsupported Type EE 2F - Encryption - New Key Encrypted Write Pending EE 30 - Encryption - Prohibited Request EE 31 - Encryption - Key Unknown EE 32 - Encryption - Keystore Related Problem EE 42 - Encryption - EKM Challenge Pending EE E2 - Encryption - Key Translation Disallowed EE FF - Encryption - Security Prohibited Function EF 01 - Encryption - Key Service Not Configured 26 11 - Encryption - Incomplete Key - Associate Data Set 26 12 - Encryption (T10) - Vendor Specific Reference Key Not Found 55 08 - Encryption (T10) - Maximum Number of Supplemental Keys Exceeded							

Table D-2. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name								
	7	6	5	4	3	2	1	0	
12-13	Sense Key 6 (Unit Attention)								
	EE	12 - Encryption - Key Change Detected							
	EE	18 - Encryption - Changed (Read)							
	EE	19 - Encryption - Changed (Write)							
	EE	40 - Encryption - EKM Identifier Changed							
	EE	41 - Encryption - EKM Challenge Changed							
	EE	50 - Encryption - Initiator Identifier Changed							
	EE	51 - Encryption - Initiator Response Changed							
	2A	11 - Encryption - Data Encryption Parameters Changed by Another I_T Nexus							
	2A	12 - Encryption - Data Encryption Parameters Changed by Vendor Specific Event							
	Sense Key 7 (Data Protect)								
	EF	10 - Encryption - Key Required							
	EF	11 - Encryption - Key Generation							
	EF	13 - Encryption - Key Translate							
	EF	1A - Encryption - Key Optional							
	EF	C0 - Encryption - No Operation							
	26	10 - Encryption - Data Decryption Key Fail Limit							
	2A	13 - Encryption - Data Encryption Key Instance Counter Has Changed							
	74	00 - Security Error							
	74	01 - Encryption - Unable to Decrypt Data							
	74	02 - Encryption - Unencrypted Data Encountered While Decrypting							
	74	03 - Encryption - Incorrect Data Encryption Key							
	74	04 - Encryption - Cryptographic Integrity Validation Failed							
	74	05 - Encryption - Error Decrypting Data							
	14	FRU code							
	15	SKSV	C/D	Reserved		BPV	Bit pointer		
					When set to 1, the bit pointer is valid.				
16 -17	SKSV = 0: First Error Fault Symptom Code (FSC). SKSV = 1: Field Pointer								
18-19	First Error Flag Data								
20	Reserved (0)								
21					CLN	Reserved	Reserved	VolValid	
22-28	Volume Label								
29	Current Wrap								
30-33	Relative LPOS								
34	SCSI Address								
35	Frame number				Drive number				

Table D-2. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
36-39	Port Identifier (Relative Target Port Address) Reporting Sense (This is the port address of the drive port through which sense is being reported. On Fibre Channel drives, it is the Fibre Channel Fabric Port Address [for example, 011E13 or 000026] with byte 36 being reserved. On SAS drives, it is the Hashed SAS Address of the drive port [for example, F32A94] with byte 36 being reserved. On SCSI, bytes 36 through 38 are reserved, and byte 39 is set to the port’s SCSI address [i.e., byte 39 = byte 34].)							
40	Tape Directory Valid	Reserved	Reserved	Reserved	Reserved	Relative Tgt Port Reporting Sense 0: Reserved 1: Relative Tgt Port 1 (Port 0) 2: Relative Tgt Port 2 (Port 1) 3: Relative Tgt Port 3 (Library Port)		
41	Host Command (SCSI Opcode)							
42	Density Type 0: No media present 1: Gen1 (384 track) 2: Gen2 (512 track) 3: Gen3 (704 track)				Media Type (Vendor Reserved)			
43	Volume Label Cartridge Type							
44								
45-48	Logical Block Number (Current LBA that would be reported in Read Position command)							
49-52	Data set Number							
53	1st Error FSC							
54								
55	1st Error Flag Data							
56								
57	2nd Error FSC							
58								
59	2nd Error Flag Data							
60								
61	Next-to-Last Error FSC							
62								
63	Next-to-Last Error Flag Data							
64								

Table D-2. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
65	Last Error FSC							
66								
67	Last Error Flag Data							
68								
69	LPOS Region							
70-85	ERP Summary Information							
86-89	Product Revision Level: YMDV (as defined in Standard Inquiry; this is also known as the Code Level)							
90-95	Reserved (0)							

The descriptions below serve only as an overview of sense reporting in the tape drive. This tape drive conforms to all sense field reporting as specified in the SCSI standards.

Note:

1. The Error Code field (Byte 0) is set to 70h to indicate a current error, that is one associated with the most recently received command. It is set to 71h to indicate a deferred error which is not associated with the current command.
2. The segment number (Byte 1) is zero since the Copy, Compare, and Copy and Verify commands are not supported.
3. The File Mark flag (Byte 2, bit 7) is set if a Space, Read, or Verify command did not complete because a file mark was read.
4. The End of Media (EOM) flag (Byte 2, bit 6) is set if a Write or Write File Marks command completed in the early warning area. Spacing into BOM also causes this flag to be set. It is also set on an attempt to read or space past EOD, or if an attempt is made to space into Beginning of Media.
5. The Illegal Length Indicator (ILI) flag (Byte 2, bit 5) is set if a Read or Verify ended because a block was read from tape that did not have the block length requested in the command.
6. The Information Bytes (Bytes 3-5) are only valid if the Valid flag is set. This occurs only for current errors and not for deferred errors.
7. The Field Replaceable Unit field (Byte 14) is set to either zero or to a non-zero, vendor-specific code indicating which part of the drive is suspected of causing the failure.
8. The Clean (CLN) flag (Byte 21, bit 3) is set if the drive needs cleaning and clear otherwise.
9. The Volume Label Fields Valid (VolValid) bit (Byte 21, bit 0) is set if the Volume Label being reported is valid.
10. The Volume Label field (Bytes 22-28) reports the volume label if a cartridge is loaded in the drive and Volume Label Fields Valid is set.
11. The Current Wrap field (Byte 29) reports the physical wrap of the tape. The least significant bit reflects the current physical direction. A 0

means that the current direction is away from the physical beginning of the tape. A 1 means that the current direction is towards the physical beginning of the tape.

12. Relative LPOS fields (Bytes 30-33) reports the current physical position on the tape.
13. SCSI Address field (Byte 34) reports the SCSI Bus Address for the drive. Values returned range from 00h to 0Fh.
14. This field (Byte 35) contains the frame and drive number, passed across the RS-422 serial interface.

Appendix E. Message Retrieval at the Host

Retrieving messages from different hosts are discussed in this appendix.

Obtaining Error Information from the Host

How error information is obtained from the host depends on the type of device driver being utilized. Refer to the table below for instructions specific to your type of device driver.

If you are...	Then
Using an IBM device driver	Refer to the <i>IBM Tape Device Drivers Installation and User's Guide</i> (GC27-2130) for problem determination information specific to your host operation system. Visit ftp://ftp.software.ibm.com/storage/devdrv/Doc/ to download the latest version of the manual.
Using a non-IBM device driver	Refer to "IBM TotalStorage Tape Diagnostic Tool (ITDT)" on page 9-4. Visit http://www-1.ibm.com/support/docview.wss?uid=ssg1S4000662 to download the diagnostic tool.

Retrieving from an IBM System p™ or IBM Power System with AIX

IBM device drivers for the System p system logs error information when an error occurs on a tape drive or library.

The error information includes the following:

1. Device VPD
2. SCSI command parameters
3. SCSI sense data (if available)

The AIX Tape and Media Changer Device Driver for the System p provides logging to the system error log for a variety of errors. You can view the error log by following this procedure.

1. At the AIX command line, type **errpt lpg** to display a summary report, or type **errpt -a lpg** to display a detailed report. Press **[Enter]**.

Note: In most cases you will use the summary report to find the date and time of any errors related to library devices, then use the detail report to obtain the sense data needed to identify the cause of the error.

2. Press **[Enter]** to scroll through the error log.
3. Type **q** and press **[Enter]**, to quit the error log at any time.

To correct a problem you noticed in the **errpt** report, determine the type of error by using the examples that follow:

- For library errors [Resource Name = **smcn** (for example, smc0) and Resource Type = 3573-TL]), refer to “SCSI Sense Data Definition” and Sense Data in Appendix C.
- For drive errors [Resource Name = **rmtn** (for example, rmt0) and Resource Type = LTO], refer to “SCSI Sense Data Definition” and Sense Data in Appendix C.
- For fibre channel errors (not fibre channel adapter errors), determine which host adapter and device are affected, and go to that host documentation to resolve any fibre channel problems. If unsuccessful, call for IBM support.
- For fibre channel adapter errors (not fibre channel bus errors), use the maintenance package for the host.

Note: See Appendix D, “Sense Data,” on page D-1 for further details on sense data.

SCSI Sense Data Definition

Following is an example of a tape drive communication failure while attached to an Open Systems host through a fibre channel link, using SCSI protocol. When the host detected the failure, it built the following SCSI Sense Data record. An explanation of the SCSI Sense Data breakout in this example follows.

SENSE DATA

aabb xxxx ccdd eeee eeee eeee eeee eeee ffgg hhxx ssss ssss ssss ssss ssss

```

0600 0000 1200 0000 0000 0000 0000 0000 0200 0300 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000

```

Note: The bold area above represents the SCSI Sense Data presented by the host. The regular font data (in this case many bytes of ‘zero’), designated by ‘sss’ would normally contain device sense data, but with the kind of failure in this example (COMMAND TIMEOUT), the host could not collect valid device sense data, so zeros are the result and should be ignored. If the host had been able to collect valid sense data from the drive, the first byte ‘ss’ would be ‘70’, ‘71’, ‘F0’ or ‘F1’, and valid device sense data would be listed.

DETAIL DATA

aabb xxxx ccdd eeee eeee eeee eeee eeee ffgg hhxx ssss ssss ssss ssss ssss

aa Length of the Command Descriptor Block (CDB) sent by the host. In this case, '06' bytes.
bb SCSI target address. In this example, SCSI address '00'.
xx Unused or reserved
cc Start of CDB, cc is the operation code (byte 0). In this case, '12' which was an "Inquiry".

SCSI Sense Data - Library Error

The following example of SCSI Sense Data was received from an RS/6000 Open System host and shows a Tape Drive Failure and what the sense data would look like. Unlike the previous situation with “SCSI Sense Data Definition”, this data contains valid sense data as defined by the hex ‘70’ in the first sense byte position. Therefore, instead of all zeros as in the previous example, we have valid data to rely on. While the data shows that this is a TAPE_ERR2, it could also be caused by a library failure. As described above, the resource name is smc0 indicating a library error. The ASC/ASCQ points to a “Mechanical Positioning Error” while attempting a “Move Medium” command (‘A5’). For more information about Sense Data,

consult your “IBM System Storage TS3100 Tape Library and TS3200 Tape Library SCSI Reference” document.

```
LABEL:      TAPE_ERR2
IDENTIFIER:  476B351D

Date/Time:   Fri May 04 42:26 DFT
Sequence Number: 1665
Machine ID:  0046083B4C00
Node ID:     risc4
Error Class:  H
Error Type:   PERM
Resource Name: smc0
Resource Class: tape
Resource Type: 3573
Location:     P1.1-I3/Q1-W5003013D38321011-L1000000000000
VPD:
  Manufacturer.....IBM
  Machine Type and Model.....3573-TL
  Serial Number.....X2U78B0384
  Device Specific . (FW) .....4.09  (Firmware Level)

Description
TAPE DRIVE FAILURE

Probable Causes
TAPE DRIVE

Failure Causes
TAPE
TAPE DRIVE
  Recommended Actions
  PERFORM PROBLEM DETERMINATION PROCEDURES

Detail Data

aabb xxxx ccdd eeee eeee eeee eeee ffgg  hhxx ssss  ssss  ssss  ssss  ssss ...

aa Length of the Command Descriptor Block (CDB) sent by the host. In this case, '0C' bytes.
bb SCSI target address. In this example, SCSI address '00'.
xx Unused or reserved
cc Start of CDB, cc is the operation code (byte 0). In this case, 'A5' which was a "Move Medium".

SENSE DATA
0C00 0000 A500 0000 10F 1010 0000 0000 0102 0000 7000 0400 0000 000A 0000 0000
818F 0000 BE00 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
```

Figure E-1. AIX ERRPT Library Error Log Example

Table E-1. AIX ERRPT Library Sense Data

Hex	Description
A5	SCSI Command (in this case Move Medium)
70	Byte 0 of Library Sense Data (Valid Data)
04	Sense Key (in this case Hardware Error)
818F	ASC/ASCQ (additional sense code/additional sense code qualifier), in this case a “Cannot Find Slider Block” error.

SCSI Sense Data - Drive Error

The following example of SCSI Sense Data was received from a RS/6000 Open System host and shows a Tape Drive Failure and what the sense data would look like. Like the SCSI Sense Data in Example 1, this Sense Data example contains

valid sense data as defined by the hex '71' in the first sense byte position. Therefore, we have valid data to rely on. While the data shows that this example is a TAPE_ERR2, it could also be caused by a library failure. Further review of the ASC/ASCQ, (Media load or eject failed), points more to a problem with the media or the drive. Also note that the FSC listed was F402 which is a timeout while attempting to load drive 2. For more information about the Sense Key and ASC/ASCQ fields, refer to the "IBM System Storage TS3100 Tape Library and TS3200 Tape Library SCSI Reference" document.

```

LABEL:      TAPE_ERR2
IDENTIFIER:  476B351D

Date/Time:   Wed May 09 07:51:42 DFT
Sequence Number: 1669
Machine ID:  0046083B4C00
Node ID:     risc4
Error Class:  H
Error Type:   PERM
Resource Name: rmt0
Resource Class: tape
Resource Type: LTO
Location:     P1.1-I3/Q1-W5003013D38321011-L0
VPD:
    Manufacturer.....IBM
    Machine Type and Model.....ULT3573-TD4
    Serial Number.....1300000680
    Device Specific . (FW) .....74H4   (Firmware Level)
    Loadable Microcode Level....A1700D5C

Description
TAPE DRIVE FAILURE

Probable Causes
TAPE DRIVE

Failure Causes
TAPE
TAPE DRIVE
    Recommended Actions
    PERFORM PROBLEM DETERMINATION PROCEDURES

Detail Data
SENSE DATA
0600 0000 0000 0000 0000 0000 0000 0000 0102 0000 7100 0400 0000 0058 0000 0000
5300 0702 F402 0000 0001 0110 0001 0000 0000 0000 0200 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 2800 01E0 0000 0000 0000 4133 3820
2020 2000 0000 0000 0000 0000 0000 8000 0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000

```

Figure E-2. AIX ERRPT Library Error Log Example

Table E-2. AIX ERRPT Drive Sense Data

Hex	Description
71	Valid Sense Data Follows
04	Sense Key (Hardware Problem)
5300	ASC/ASCQ (additional sense code/additional sense code qualifier)
F401	FSC (fault symptom code) in this case, Drive Load Timeout. Likely a drive problem.

Retrieving from a Sun System

The Sun System provides information when an error occurs on a tape drive or library in system-errollog /var/adm/messages. When you have located the error information, go to Chapter 7, "Troubleshooting," on page 7-1.

Retrieving from an HP-UX System

The HP-UX system provides information when an error occurs on a tape drive or library in syslog /var/adm/syslog.log. When you have located the error information, go to Chapter 7, “Troubleshooting,” on page 7-1.

Retrieving from an IBM System i™ or IBM Power System with IBM i OS

IBM device drivers for the System i system logs error information when an error occurs on a tape drive or library.

The error information includes the following:

1. Device VPD
2. SCSI command parameters
3. SCSI sense data (if available)

To gain access to the System i problem logs and error logs, sign on at any available workstation using the QSRV logon and its security password (QSRV). After signing on, the proper access authorizations will be granted and the System i MAIN MENU displays.

1. Type STRSST (Start System Service Tools) command on the command entry line on the System i Main Menu, and press **[Enter]**.
2. On the “System Service Tool (SST)” screen, select **Start a service tool**, and press **[Enter]**.
3. On the “Start a Service Tool” screen, select **Product activity log**, and press **[Enter]**.
4. On the “Product activity log” screen, select **Analyze log**, and press **[Enter]**.
5. On the “Select Subsystem Data” screen, select **Magnetic media**, enter the From and To time period for searching the error log, and press **[Enter]**.
6. On the “Select Analysis Report Options” screen, select the following, and press **[Enter]**.
 - a. Report type. 1
 - b. Optional entries to include
 - 1) Informational YES
 - 2) Statistic NO
 - c. Reference code selection
 - 1) Option 1
 - 2) Reference codes. *ALL
 - d. Device selection
 - 1) Option 1
 - 2) Device type or resource names . . *ALL
7. On the “Log Analysis Report” screen, enter a **5** on an error line that has a resource type of 3583 (library) or 3580 (drive), and press **[Enter]**.
8. On the “Display Detail Report for Resource” screen, press:
 - F4=Additional Information.
Pressing F4 will display the machine type and serial number of the device. It also will display SCSI sense data, if available.
 - F6=Hexadecimal report.
Pressing F6 will display the device hexadecimal data (for support use).

- F9=Address Information.
Pressing F9 will display the SCSI address information.

System i Product Activity Log

```
Product Activity Log Page . . . : 1
RMLPAR1 08/26/05 10:28:40
Invocation . . . . . : Product Activity Log
Title . . . . . : Log ID Report
System type . . . . . : 9406
System model . . . . . : 825
System release . . . . . : V5R3M0
System name . . . . . : RMLPAR1
System serial
number . . . . . : 10-F321B
Log ID . . . . . : 09020145
Include hexadecimal
data . . . . . : Y Y=YES
N=NO
Product Activity Log Page . . . : 2
RMLPAR1 08/26/05 10:28:40
Detail Report for Resource
Serial Resource
Name Type Model Number Name
TAPMLB19 3580 001 00-1004538
Log ID . . . . . : 09020145 Sequence . . . . . : 211510
Date . . . . . : 04/21/05 Time . . . . . : 10:40:11
Reference code . . . . : 9350 Secondary code . . : 00000000
Table ID . . . . . : 63A00001 IPL source/state . . : B / 3
Class . . . . . : Permanent
System ref code . . . . : 63A09350
Tape unit detected a read or write error on tape medium
Physical location:
Frame ID . . . . . :
Card position . . . . :
Device position . . . . :
Logical address:
PCI bus: Library:
System bus . . . . . : 36 I/O adapter . . . . . : 2
System board . . . . . : 0 I/O bus . . . . . : 1
System card . . . . . : 32 Library: 20
Controller . . . . . : 4
Device . . . . . : 0
SENSE DATA FOLLOWS. . . . :
DATA OFFSET 0 1 2 3 4 5 6 7 8 9 A B C D E F
00000000 71000300 0000001C 00000000 53000600
00000010 31190601 00020000 00000000 00000000
00000020 00000301
00000000 0000 C5D3F0F5 00000180 00E00180 8983EBC2 489D8001 00033A36 20E00902 01450000 *EL05...h....ic.B.....*
00000000 0040 F3F8F2F8 F4F4F6F3 C1F00002 00240000 00200000 00050001 00140004 00000002 *38284463A0.....*
00000000 0060 00000000 00000000 00000000 40404040 40404040 40400000 00000000 00000000 *.....*
00000000 0080 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000 *.....TA*
00000000 00A0 D7D4D3C2 F1F94040 00000000 00000000 00000000 00000000 40404040 40404040 *PMLB19 .....*
00000000 00C0 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 *
00000000 00E0 F6F3C1F0 F0F0F0F1 0000E2D3 C9C3C9D6 4040C5F5 D9F3D4F0 40400000 00000000 *63A00001..SLICIO V5R3M0 .....*
00000000 0100 01030000 00000000 00000141 00000000 00000000 01950000 00000000 00000197 *.....n.....p*
00000000 0120 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000 *.....*
00000000 0140 E3C1D7F2 F7404040 40404040 40404040 40404040 40404040 00070001 *TAP27 ....*
00000000 0160 00000000 10200003 00000000 00000000 00000000 00000000 0009001E 00000188 *.....h*
00000000 0180 F8007000 20440001 00002600 21104000 63A00001 93500100 45381202 05D00000 *B.....t&.....Q..*
00000000 01A0 00000000 00004624 00000000 00000000 00040000 00003580 0001A170 02903435 *.....*
Product Activity Log Page . . . : 3
RMLPAR1 08/26/05 10:28:40
00000000 01C0 36310040 00007100 03000000 001C0000 00005300 06003119 06010002 00000000 *... ..*
00000000 01E0 00000000 00000000 03010000 00000000 00000000 00000000 00000000 00000000 *.....*
00000000 0200 00000000 000009C5 D8400000 D9E2000C 02000000 0000E2C3 E2C91202 00180000 *.....REQ ..RS.....SCSI.....*
00000000 0220 00000000 0000C509 D940C3C8 C3020444 050209E2 0000E2C3 E2C91202 00180300 *.....ERR CMCK..e.RS..SCSI.....*
00000000 0240 00000000 0000E2D5 E2C47100 03000000 001C0000 0000C509 D7C11202 05D00000 *.....SNSD.....ERPA...Q..*
00000000 0260 00171202 050809C5 E2D70000 00171202 050809E2 00000000 D4C5C4C9 C1000C3 *.....QRESP.....QRS....MEDIA..C*
00000000 0280 D7D7F1F2 F5C50004 E3C1D7C3 D30500C3 D7D7F6F4 F0F000E4 C6C9F0F0 F8F7F1C3 *PP125E.MTAPCLN.CPP6400.UFI00871C*
00000000 02A0 D7D7F1F8 F5C60005 00000000 00000000 00000000 00000000 00000000 *PP185F.N.....*
00000000 02C0 00000000 00000000 00000000 00000000 00000000 00000000 C3D7D7F6 F3F0C3D5 *.....CPP630CN*
00000000 02E0 F6F3C1F0 F9F3F5F0 F0F0F0F0 F0F0F0F0 F0F0F0F0 F0F1F9F7 F8F0F0F7 0000E8D5 *63A0935000000000000001978007..YN*
00000000 0300 00000000 00000000 40404040 40404040 40404040 40404040 40404040 *.....*
*****END OF COMPUTER PRINTOUT*****
```

Appendix F. SNMP Status MIB Variables and Traps

Note: For additional information, refer to “SNMP Messaging” on page 1-6.

Table F-1. SNMP Status Events

Event	Trap ID	Definition
Status Change	1	Library status has changed.
Door Open	2	Library door has been opened.
Mail Slot Accessed	3	Library I/O Station has been accessed.
Fault Posted	4	Library has posted a hard fault/error.
Request Drive Clean	5	Drive has requested a clean.
Drive Error	6	Drive has reported an error.
Loader Retries Excessive	7	Library has reported excessive load retries.
Loader OK	8	Library has resumed normal operations.

Appendix G. Library Configuration Form

Use this form when planning your library configuration. Keep this document in a secure location and update it when changes are made to the library configuration.

General Information				
Library type	TS3100		TS3200	
Library Serial Number				
Library name				
I/O Station	Enabled		Disabled	
AutoClean	Enabled		Disabled	
Library Network Settings				
DHCP	Enabled		Disabled	
IP Address				
Netmask Address				
Gateway Address				
DNS Servers IP Addresses				
EKM Servers IP Addresses				
Encryption Settings				
Logical Libraries				
Number in library	1	2	3	4
Mode	Random: ON/OFF Sequential: ON/OFF Autoload: ON/OFF Loop: ON/OFF	Random: ON/OFF Sequential: ON/OFF Autoload: ON/OFF Loop: ON/OFF	Random: ON/OFF Sequential: ON/OFF Autoload: ON/OFF Loop: ON/OFF	Random: ON/OFF Sequential: ON/OFF Autoload: ON/OFF Loop: ON/OFF
Magazine Assignment	☐ Upper Left ☐ Lower Left ☐ Upper Right ☐ Lower Right	☐ Upper Left ☐ Lower Left ☐ Upper Right ☐ Lower Right	☐ Upper Left ☐ Lower Left ☐ Upper Right ☐ Lower Right	☐ Upper Left ☐ Lower Left ☐ Upper Right ☐ Lower Right
Number of Active Slots				
Drive Serial Numbers	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:

Drive types	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4: 4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4:4U Position 3:2U/4U Position 2:2U/4U Position 1:
Fibre Channel Drive settings	Logical Library: Position: Speed: Port type: Loop ID:	Logical Library: Position: Speed: Port type: Loop ID:	Logical Library: Position: Speed: Port type: Loop ID:	Logical Library: Position: Speed: Port type: Loop ID:
SAS Drive settings	Logical Library: Position: ID:	Logical Library: Position: ID:	Logical Library: Position: ID:	Logical Library: Position: ID:
SCSI Drive settings	Logical Library: Position: ID:	Logical Library: Position: ID:	Logical Library: Position: ID:	Logical Library: Position: ID:
User Accounts				
Role: Password:				
Role: Password:				
Role: Password:				
Role: Password:				

Activation Key Labels

Encryption Key

[Adhere one of the activation key labels here for future reference.]

Path Failover Key

[Adhere one of the activation key labels here for future reference.]

Appendix H. Accessibility

Accessibility features help a user who has a physical disability, such as restricted mobility or limited vision, to use the HTML version of the customer documentation successfully.

Features

These are the major accessibility features for the HTML version of this document:

- You can use screen-reader software and a digital speech synthesizer to hear what is displayed on the screen. The following screen readers have been tested: WebKing and Window-Eyes.
- You can operate all features using the keyboard instead of the mouse.

Navigating by keyboard

You can use keys or key combinations to perform operations and initiate many menu actions that can also be done through mouse actions. You can navigate the HTML version of the IBM System Storage TS3100 Tape Library and TS3200 Tape Library Setup, Operator, and Service Guide help system from the keyboard by using the following key combinations:

- To traverse to the next link, button, or topic, press Tab inside a frame (page).
- To move to the previous topic node, press ^ or Shift+Tab.
- To scroll all the way up or down, press Home or End, respectively.
- To print the current page or active frame, press Ctrl+P.
- To select, press Enter.

Accessing the publications

You can view the publications for this library in Adobe Portable Document Format (PDF) using the Adobe Acrobat Reader. The PDFs are provided at the following Web site:

<http://www.ibm.com/storage/support/>.

Notices

This information was developed for products and services offered in the U.S.A. IBM may not offer the products, services, or features discussed in this document in other countries (or regions). Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A.

The following paragraph does not apply to the United Kingdom or any other country (or region) where such provisions are inconsistent with local law:
INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states (or regions) do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM web sites are provided for convenience only and do not in any manner serve as an endorsement of those web sites. The materials at those web sites are not part of the materials for this IBM product and use of those web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

Trademarks

The following are trademarks of International Business Machines Corporation in the United States, or other countries (or regions), or both:

AIX	System p
System i	xSeries
IBM	Tivoli
iSeries	TotalStorage
pSeries	zSeries
System x	System Storage
i5/OS	System z

The following are U.S. trademarks of Hewlett-Packard Company, International Business Machines Corporation, and Certance.

Linear Tape-Open
LTO
Ultrium

Intel is a registered trademark of Intel Corporation in the United States, or other countries (or regions), or both.

Microsoft, Windows, Windows NT, Windows 2000, and the Windows logo are registered trademarks of Microsoft Corporation in the United States, or other countries (or regions), or both.

Solaris and Sun are registered trademarks of Sun Microsystems Incorporated.

Unix is a trademark of The Open Group in the United States, or other countries or regions, or both.

Other company, product, or service names may be the trademarks or service marks of others.

Electronic Emission Notices

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, might cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors, or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device might not cause harmful interference, and (2) this device must accept any interference received, including interference that might cause undesired operation.

European Union (EU) Electromagnetic Compatibility Directive

This product is in conformity with the protection requirements of EU Council Directive 2004/108/EC, on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of non-IBM option cards.

This product has been tested and found to comply with the limits for Class A Information Technology Equipment according to European Standard EN 55022. The limits for Class A equipment were derived for commercial and industrial environments to provide reasonable protection against interference with licensed communication equipment.

Attention: This is a Class A product. In a domestic environment this product might cause radio interference in which case the user might be required to take adequate measures.

European Community contact:

IBM Technical Regulations
Pascalstr. 100, Stuttgart, Germany 70569
Tele: 0049 (0)711 785 1176
Fax: 0049 (0)711 785 1283
e-mail: tjahn@de.ibm.com

People's Republic of China Class A Electronic Emission Statement

中华人民共和国“A类”警告声明

声明

此为A级产品，在生活环境中，该产品可能会造成无线电干扰。在这种情况下，可能需要用户对其干扰采取切实可行的措施。

Taiwan Class A compliance statement

警告使用者：

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

lateml

Taiwan Contact Information

IBM Taiwan Product Service Contact Info:
IBM Taiwan Corporation
3F, No 7, Song Ren Rd., Taipei Taiwan
Tel: 0800-016-888

台灣IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路7號3樓
電話：0800-016-888

Japan VCCI Class A ITE Electronic Emission Statement

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づきクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

vcci

Industry Canada Compliance Statement

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Avis de conformité à la réglementation d'Industrie Canada

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Germany Electromagnetic Compatibility Directive

Deutschsprachiger EU Hinweis:

Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit. Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2004/108/EG zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022 Klasse A ein.

Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung der IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung der IBM gesteckt/eingebaut werden.

EN 55022 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden:
"Warnung: Dieses ist eine Einrichtung der Klasse A. Diese Einrichtung kann im

Wohnbereich Funk-Störungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen zu ergreifen und dafür aufzukommen."

Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten. Dieses Produkt entspricht dem "Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG)". Dies ist die Umsetzung der EU-Richtlinie 2004/108/EG in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) (bzw. der EMC EG Richtlinie 2004/108/EG) für Geräte der Klasse A.

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Konformitätserklärung des EMVG ist die IBM Deutschland GmbH, 70548 Stuttgart.

Generelle Informationen:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 Klasse A.

Korean Class A Electronic Emission Statement

이 기기는 업무용으로 전자파 적합등록을 받은 기기 이오니, 판매자 또는 사용자는 이점을 주의하시기 바라며, 만약 잘못 구입하셨을 때에는 구입한 곳에서 비업무용으로 교환하시기 바랍니다.

Australia and New Zealand Class A Statement

Attention: This is a Class A product. In a domestic environment this product might cause radio interference in which case the user might be required to take adequate measures.

Glossary

This glossary defines the special terms, abbreviations, and acronyms that are used in this publication. If you do not find the term you are looking for, refer to the index or to the *Dictionary of Computing*, 1994.

Numbers

2:1 compression. The relationship between the quantity of data that can be stored with compression as compared to the quantity of data that can be stored without compression. In 2:1 compression, twice as much data can be stored with compression as can be stored without compression.

A

A. Ampere.

ac. Alternating current.

access method. A technique for moving data between main storage and input or output devices.

accessor. This component contains the library robot and bar code reader. The accessor moves cartridges to and from the I/O Station, storage slots, and tape drives.

adapter card. A circuit board that adds function to a computer.

adj. Adjustment.

AH. The Authentication Header (AH) is intended to guarantee connectionless integrity and data origin authentication of IP datagrams. Further, it can optionally protect against replay attacks by using the sliding window technique and discarding old packets.

AIX. Advanced Interactive Executive. IBM's implementation of the UNIX® operating system. The System p system, among others, uses AIX as its operating system.

alphanumeric. Pertaining to a character set that contains letters, numerals, and usually other characters, such as punctuation marks.

alter. To change.

ambient temperature. The temperature of air or other media in a designated area, particularly the area surrounding equipment.

AME. Application Managed Encryption

ampere (A). A unit of measure for electric current that is equivalent to a flow of one coulomb per second, or to the current produced by one volt applied across a resistance of one ohm.

ANSI. American National Standards Institute.

archive. To collect and store files in a designated place.

ASCII. American National Standard Code for Information Interchange. A 7 bit coded character set (8 bits including parity check) that consists of control characters and graphic characters.

assigning a device. The establishing of the relationship of a device to a running task, process, job, or program.

assignment. The naming of a specific device to perform a function.

asynchronous. Pertaining to two or more processes that do not depend upon the occurrence of specific events such as common timing signals.

attention (notice). A word for calling attention to the possibility of danger to a program, device, or system, or to data. Contrast with *caution* and *danger*.

ATTN. Attention.

B

backup. To make additional copies of documents or software for safekeeping.

bar code. A code representing characters by sets of parallel bars of varying thickness and separation which are read optically by transverse scanning.

bar code label. Paper bearing a bar code and having an adhesive backing. The bar code label must be affixed to a tape cartridge to enable the library to identify the cartridge and its volume serial number.

bar code reader. A laser device specialized for scanning and reading bar codes and converting them into either the ASCII or EBCDIC digital character code.

Beginning of Partition. See *BOP*.

bezel. Decorative and safety cover.

bicolored. Having two colors.

bit. Either of the digits 0 or 1 when used in the binary numbering system.

BOM or bill of materials. A list of specific types and amounts of direct materials expected to be used to produce a given job or quantity of output.

BOP. BOP (Beginning of Partition) is a SCSI term, which in a single partition format is the same as beginning of tape. It means that policy is determined on writes at LB (logical block) zero (the first block in the partition). Appending to a tape [or overwriting at a non-zero LB] does not change the policy already in use for that tape.

Border Gateway Protocol (BGP). BGP is the core routing protocol of the Internet. It works by maintaining a table of IP networks or 'prefixes', which designate network reachability among autonomous systems (AS).

browser. A client program that initiates requests to a Web server and displays the information that the server returns.

buffer. A routine or storage used to compensate for a difference in rate of flow of data or time of occurrence of events, when transferring data from one device to another.

bus. A facility for transferring data between several devices located between two end points, only one device being able to transmit at a given moment.

byte. A string consisting of a certain number of bits (usually 8) that are treated as a unit and represent a character. A fundamental data unit.

C

capacity. The amount of data that can be contained on storage media and expressed in bytes of data.

cartridge manual rewind tool. A device that can be fitted into the reel of a cartridge and used to rewind tape into or out of the cartridge.

cartridge storage slot. Individual slot located within a magazine that is used to house tape cartridges.

caution (notice). A word to call attention to possible personal harm to people. Contrast with *attention* and *danger*.

CE. Customer engineer; field engineer; service representative.

centimeter (cm). One one-hundredth of a meter (0.01 m). Approximately 0.39 inch.

channel command. An instruction that directs a data channel, control unit, or device to perform an operation or set of operations.

char. Character.

CHK. Check.

cleaning cartridge. A tape cartridge that is used to clean the heads of a tape drive. Contrast with *data cartridge*.

command. A control signal that initiates an action or the start of a sequence of actions.

compact disc (CD). A disc, usually 4.75 inches in diameter, from which data is read optically by means of a laser.

compression. The process of eliminating gaps, empty fields, redundancies, and unnecessary data to shorten the length of records or blocks.

concurrent. Refers to diagnostic procedures that can be run on one control unit while the rest of the subsystem remains available for customer applications.

contingent connection. A connection between a channel path and a drive caused when a unit check occurs during an I/O operation.

controller. A device that provides the interface between a system and one or more tape drives.

control path drive. A drive that communicates messages from the host computer to the library in which the drive is installed.

CP. Circuit protector.

ctrl. Control.

CU. Control unit.

D

danger (notice). A word to call attention to possible lethal harm to people. Contrast with *attention* and *caution*.

data. Any representations such as characters or analog quantities to which meaning is or might be assigned.

data buffer. The storage buffer in the control unit. This buffer is used to increase the data transfer rate between the control unit and the channel.

data cartridge. A tape cartridge dedicated to storing data. Contrast with *cleaning cartridge*.

data check. A synchronous or asynchronous indication of a condition caused by invalid data or incorrect positioning of data.

dc. Direct current.

DCS. Designated Cleaning Slot

degauss. To make a magnetic tape nonmagnetic by means of electrical coils carrying currents that neutralize the magnetism of the tape.

degausser. A device that makes magnetic tape nonmagnetic.

degradation. A decrease in quality of output or throughput or an increase in machine error rate.

degraded. Decreased in quality of output or throughput or increased machine error rate.

Density reporting. This setting determines whether the drive shows or masks encryption. This settings affects host reporting of density and is included to support legacy needs for transparency. The default of not masking encrypted densities means that the host can see a different density code for encrypted vs non-encrypted tapes (x72 [enc] as opposed to x52 [non-enc]). This feature masks this so the drive reports the primary density only. Normally this is set to the drive default (which is to show encr density). If a legacy setup will not work with a new density code being reported [for whatever software reason] this will allow transparent encryption to still be used.

deserialize. To change from serial-by-bit to parallel-by-byte.

detented. A part being held in position with a catch or lever.

device. Any hardware component or peripheral, such as a tape drive or tape library, that can receive and send data.

device driver. A file that contains the code needed to use an attached device.

DHCPv6. The Dynamic Host Configuration Protocol for IPv6. Although IPv6's stateless address autoconfiguration removes the primary motivation for DHCP in IPv4, DHCPv6 can still be used to statefully assign addresses if the network administrator desires more control over addressing.

DIAG. Diagnostic section of maintenance information manual.

differential. See *High Voltage Differential (HVD)*.

direct access storage. A storage device in which the access time is independent of the location of the data.

display contrast. On the Operator Control Panel (OCP), the brightness of the display can be set by setting the contrast from 1 (the brightest) to 10 (the lightest).

dll. Dynamic link library: Microsoft's implementation of the shared library concept. These libraries usually

have the file extension DLL, OCX (for libraries containing ActiveX controls), or DRV (for legacy system drivers).

| **DNS Server.** A **DNS server** is any computer
| registered to join the *Domain Name System*. A DNS
| server runs special-purpose networking software,
| features a public IP address, and contains a database of
| network names and addresses for other Internet hosts.
| Your ISP also maintains DNS servers as part of your
| Internet connection setup.

| **Domain Name System (DNS).** The **Domain Name
| System (DNS)** is a standard technology for managing
| the names of Web sites and other Internet domains.
| DNS technology allows you to type names into your
| Web browser like *compnetworking.about.com* and your
| computer to automatically find that address on the
| Internet. A key element of the DNS is a worldwide
| collection of *DNS servers*.

download. (1) To transfer programs or data from a computer to a connected device, typically a personal computer. (2) To transfer data from a computer to a connected device, such as a workstation or microcomputer.

DRAM. Dynamic random-access memory.

drive, magnetic tape. A mechanism for moving magnetic tape and controlling its movement.

Drive Not Configured. This message occurs during the first boot after a factory settings restore is executed. This is not a real issue since it takes the library a while to configure.

DRV. Drive.

DSE. Data security erase.

DSP. Digital signal processor.

E

EBCDIC. Extended binary-coded decimal interchange code.

EC. Edge connector. Engineering change. Encryption capable.

ECC. Error correction code.

ED. Encrypted data. This term will appear on the Operator Control Panel (OCP) when encrypted data is contained on a LTO4 cartridge.

EEPROM. Electrically erasable programmable read-only memory.

EIA. Electronics Industries Association.

EIA unit. A unit of measure, established by the Electronic Industries Association, equal to 44.45 millimeters (1.75 inches).

eject. To remove or force out from within.

EKM. The Encryption Key Manager application

EKM Server Settings. Maintaining primary and secondary EKM servers is desired for maximum availability of encrypted backup and recovery. These settings are required for Library Managed Encryption only.

electronic mail. Correspondence in the form of messages transmitted between user terminals over a computer network.

email. See *electronic mail*.

encryption. To alter (a file, for example) using a secret code so as to be unintelligible to unauthorized parties. An encryption enabled drive contains the necessary hardware and firmware to encrypt and decrypt host tape application data. Encryption policy and encryption keys are provided by the host application or host server.

EPO. Emergency power off.

EPROM. Erasable programmable read only memory.

EQC. Equipment check.

equipment check. An asynchronous indication of a malfunction.

Error log. A dataset or file in a product or system where error information is stored for later access.

ESD. Electrostatic discharge.

ESP. The Encapsulating Security Payload (ESP) protocol provides origin authenticity, integrity, and confidentiality protection of a packet. ESP also supports encryption-only and authentication-only configurations, but using encryption without authentication is strongly discouraged because it is insecure.

F

fault symptom code (FSC). A hexadecimal code generated by the drive or the control unit microcode in response to a detected subsystem error.

FC. Feature code.

FCC. Federal communications commission.

FE. Field engineer, customer engineer, or service representative.

fiducial. A target used for teaching a physical location to a robot.

field replaceable unit (FRU). An assembly that is replaced in its entirety when any one of its components fails.

file. A named set of records stored or processed as a unit. Also referred to as a dataset.

file protection. The processes and procedures established in an information system that are designed to inhibit unauthorized access to, contamination of, or deletion of a file.

file transfer protocol (FTP). In the Internet suite of protocols, an application layer protocol that uses TCP and Telnet services to transfer bulk-data files between machines or hosts.

firmware. Proprietary code that is usually delivered as microcode as part of an operating system. Firmware is more efficient than software loaded from an alterable medium and more adaptable to change than pure hardware circuitry. An example of firmware is the Basic Input/Output System (BIOS) in read-only memory (ROM) on a PC motherboard.

FLASH EEPROM. An electrically erasable programmable read-only memory (EEPROM) that can be updated.

FMR. Field microcode replacement.

format. The arrangement or layout of data on a data medium.

formatter. Part of a magnetic tape subsystem that performs data conversion, speed matching, encoding, first level error recovery, and interfaces to one or more tape drives.

FP. File protect.

frayed. Damaged as if by an abrasive substance.

FRU. Field replaceable unit.

FSC. Fault symptom code.

FSI. Fault symptom index.

FTSS. Field Technical Sales Support

functional microcode. Microcode that is resident in the machine during normal customer operation.

G

g. Gram.

GB. gigabyte.

GBIC. Gigabit Interface Converter.

Gbi. gigabit

gigabit (Gbit). 1 000 000 000 bits.

gigabyte (GB). 1 000 000 000 bytes.

Gigabit Interface Converter (GBIC). Converts copper interface to optic interface.

gnd. Ground.

H

hertz (Hz). Unit of frequency. One hertz equals one cycle per second.

hex. Hexadecimal.

High Voltage Differential (HVD). A logic signaling system that enables data communication between a supported host and the library. HVD signaling uses a paired plus and minus signal level to reduce the effects of noise on the SCSI bus. Any noise injected into the signal is present in both a plus and minus state, and is thereby canceled. Synonymous with *differential*.

HVD. SCSI Bus High Voltage Differential

Hz. Hertz (cycles per second).

I

IBM Ultrium Tape Drive. Located within the library, a data-storage device that controls the movement of the magnetic tape in an IBM LTO Ultrium Tape Cartridge. The drive houses the mechanism (drive head) that reads and writes data to the tape.

ID. Identifier.

identifier (ID). (1) In programming languages, a lexical unit that names a language object; for example, the names of variables, arrays, records, labels, or procedures. An identifier usually consists of a letter optionally followed by letters, digits, or other characters. (2) One or more characters used to identify or name data element and possibly to indicate certain properties of that data element. (3) A sequence of bits or characters that identifies a program, device, or system to another program, device, or system.

IML. Initial microprogram load.

Incomp. Mag.. Incompatible Magazine: This message appears on the Operator Control Panel during library initializing. It occurs during factory restore or VPD. This is not a real issue since it takes the library a while to configure.

initial microprogram load (IML). The action of loading a microprogram from an external storage to writable control storage.

initiator. The component that executes a command. The initiator can be the host system or the tape control unit.

INST. Installation.

interface. A shared boundary. An interface might be a hardware component to link two devices or it might be a portion of storage or registers accessed by two or more computer programs.

Internet Protocol version 4 (IPv4). A network layer protocol for packet-switched internetworks. IPv4 supports 2^{32} (about 4.3 billion) addresses.

Internet Protocol version 6 (IPv6). A network layer protocol for packet-switched internetworks. It is designated as the successor of IPv4, the current version of the Internet Protocol, for general use on the Internet. The main improvement brought by IPv6 is the increase in the number of addresses available for networked devices, allowing, for example, each mobile phone and mobile electronic device to have its own address.

interposer. The part used to convert a 68-pin connector to a 50-pin D-shell connector.

intervention required. Manual action is needed.

INTRO. Introduction.

I/O. Input/output.

IOP. Input/output processor.

IP address. An identifier for a computer or device on a TCP/IP network. Networks using the TCP/IP protocol route messages based on the IP address of the destination. The format of an IP address is a 32-bit numeric address written as four numbers separated by periods. Each number can be zero to 255. For example, 1.160.10.240 could be an IP address.

IPL. Initial program load.

IPsec. IPsec (or Internet Protocol Security) provides an additional level of security for IPv6 users.

IP Stack. The IP Stack manages static IP addresses.

IPv4. A network layer protocol for packet-switched internetworks. IPv4 supports 2^{32} (about 4.3 billion) addresses.

IPv6. A network layer protocol for packet-switched internetworks. It is designated as the successor of IPv4, the current version of the Internet Protocol, for general use on the Internet. IPv6 supports approximately 5×10^{28} addresses for each of the roughly 6.5 billion people alive today.

ISV. Independent software vendor.

ITST. Idle-time self-test.

K

Key Path. This is the path used for transferring an encryption key. This setting is dependent upon the encryption method selected.

kilogram (kg). One thousand grams (approximately 2.2 pounds).

km. kilometer. 1000 Meters, Approximately 5/8 mile.

L

LAN. Local area network. A computer network within a limited area.

LCD. See *liquid crystal display*.

LED. Light-emitting diode.

Library recovery. The 2U and 4U library firmware will generally retry failed operations up to three times before posting a failure to complete the operation, or, in some situations, proceeding with an operation that can be completed in an alternative manner.

Linear Tape-Open (LTO). A type of tape storage technology developed by the IBM Corporation, Hewlett-Packard, and Certance. LTO technology is an "open format" technology, which means that its users will have multiple sources of product and media. The "open" nature of LTO technology enables compatibility between different vendors' offerings by ensuring that vendors comply with verification standards. The LTO technology is implemented in two formats: the Accelis format focuses on fast access; the Ultrium format focuses on high capacity. The Ultrium format is the preferred format when capacity (rather than fast access) is the key storage consideration. An Ultrium cartridge has a compressed data capacity of up to 800 GB (2:1 compression) and a native data capacity of up to 400 GB.

Link-local address. An address having link-only scope that can be used to reach neighboring nodes attached to the same link. All interfaces have a link-local unicast address.

| **Linux.** A Unix-like computer operating system using a Linux kernel.

liquid crystal display (LCD). A low-power display technology used in computers and other I/O devices.

loadable. Having the ability to be loaded.

LME. Library Managed Encryption

LTO cartridge memory (LTO-CM). Within each LTO Ultrium data cartridge, an embedded electronics and interface module that can store and retrieve a cartridge's historical usage and other information.

| **LUN.** Logical Unit Number: The number assigned to a "logical unit", a SCSI protocol.

LVD. SCSI Bus Low Voltage Differential

M

MAC Address. The Media Access Control address of a computer networking device.

magnetic tape. A tape with a magnetical surface layer on which data can be stored by magnetic recording.

MAP. Maintenance analysis procedure.

mask. A pattern of characters that controls the retention or elimination of portions of another pattern of characters. To use a pattern of characters to control the retention or elimination of portions of another pattern of characters.

master file. A file used as an authority in a given job and that is relatively permanent, even though its contents may change. Synonymous with main file.

Maximum Transmission Unit (MTU). The size of the largest packet that a network protocol can transmit.

MB. Mega Byte (usually expressed as data rate in MB/s or MB/second).

media capacity. The amount of data that can be contained on a storage medium, expressed in bytes of data.

| **media-type identifier.** Pertaining to the bar code on the bar code label of the IBM Ultrium Tape Cartridge, a 2-character code, L1, that represents information about the cartridge. L identifies the cartridge as one that can be read by devices utilizing LTO technology; 1 indicates that it is the first generation of its type.

mega. One million of.

meter. In the Metric System, the basic unit of length; equal to approximately 39.37 inches.

MIB file. Management Information Block

micro. One millionth of.

microcode. (1) One or more micro instructions. (2) A code, representing the instructions of an instruction set, implemented in a part of storage that is not program-addressable. (3) To design, write, and test one or more micro instructions. (4) See also *microprogram*.

microdiagnostic routine. A program that runs under the control of a supervisor, usually to identify field replaceable units.

microdiagnostic utility. A program that is run by the customer engineer to test the machine.

microinstruction. A basic or elementary machine instruction.

microprogram. A group of microinstructions that when executed performs a preplanned function.

The term microprogram represents a dynamic arrangement or selection of one or more groups of microinstructions for execution to perform a particular function. The term microcode represents microinstructions used in a product as an alternative to hard-wired circuitry to implement certain functions of a processor or other system component.

MIM. Media information message.

mm. Millimeter.

modifier. That which changes the meaning.

mount a device. To assign an I/O device with a request to the operator.

MP. Microprocessor.

ms. Millisecond.

MSG. Message.

multipath. Pertaining to using more than one path.

N

N/A. Not applicable.

Network Address Translation (NAT). NAT involves rewriting the source and/or destination addresses of IP packets as they pass through a Router or firewall. Most systems using NAT do so in order to enable multiple hosts on a private network to access the Internet using a single public IP address.

node. In a network, a point at which one or more functional units connect channels or data circuits.

NVS. Nonvolatile storage. A storage device whose contents are not lost when power is cut off.

O

| **OCP.** Operator Control Panel.

oersted. The unit of magnetic field strength in the unrationalized centimeter-gram-second (cgs) electromagnetic system. The oersted is the magnetic field strength in the interior of an elongated, uniformly wound solenoid that is excited with a linear current density in its winding of one abampere per 4π centimeters of axial length.

offline. Pertaining to the operation of a functional unit without the continual control of a computer. Contrast with *online*.

online. Pertaining to the operation of a functional unit that is under the continual control of a computer. Contrast with *offline*.

OPER. Operation.

ov. Over voltage.

overrun. Loss of data because a receiving device is unable to accept data at the rate it is transmitted.

overtightening. To tighten too much.

P

parameter. A variable that is given a constant value for a specified application and that may denote the application.

p bit. Parity bit.

PC. Parity check.

PCC. Power control compartment.

PDF. Portable Document Format.

PE. Parity error. Product engineer.

pick. Pertaining to the library, to remove, by means of a robotic device, a tape cartridge from a storage slot or drive.

picker. See *Accessor*.

PM. Preventive maintenance.

POR. Power-on reset.

port. A physical connection for communication between the drive/library and the host processor.

Portable Document Format (PDF). A standard specified by Adobe Systems, Incorporated, for the electronic distribution of documents. PDF files are compact, can be distributed globally (via e-mail, the Web, intranets, or CD-ROM), and can be viewed with the Acrobat Reader, which is software from Adobe Systems that can be downloaded at no cost from the Adobe Systems home page.

PROM. Programmable read only memory.

PS. Power supply.

PTF. Program temporary fix: a single bugfix or group of bugfixes distributed in a form ready to install for customers.

PWR. Power.

Q

Quiesce. Stop all commands to the library drives.

R

rack. A unit that houses the components of a storage subsystem, such as the library.

rackmount kit. A packaged collection of articles used to install the rack mounted version of the library.

RAM. Random access memory.

Random access memory. A storage device into which data is entered and from which data is retrieved in a nonsequential manner.

RAS. Reliability, availability, and serviceability.

record. A collection of related data or words, treated as a unit.

recording density. The number of bits in a single linear track measured per unit of length of the recording medium.

recoverable error. An error condition that allows continued execution of a program.

ref. Reference.

reg. Register.

re-inventory. To inventory again.

retention. The process or function of tightening the tape onto the cartridge, if it is sensed that the tape has a loose wrap on the cartridge.

RFC (Request for Comments). Request for Comments (RFC) documents are a series of memoranda encompassing new research, innovations, and methodologies applicable to Internet technologies.

RH. Relative humidity.

| **RMU.** Remote Management Unit. An Ethernet
| interface that allows remote administration. The RMU
| performs many of the same functions as the front panel
| interface. These functions include moving tapes, system
| operations options, networking options, security
| options, running diagnostic tests, and performing
| system updates.

robot. Accessor.

robotics. Accessor assembly.

Router Assigned IPv6 Address. IPv6 addresses created by the network router and assigned to the library (similar to DHCP).

RPQ. Request for price quotation.

R/W. Read/write.

S

s. Seconds of time.

SAC. Service Action Code. Code developed to indicate possible FRU or FRU's to replace to repair the hardware.

scratch cartridge. A data cartridge that contains no useful data, but can be written to with new data.

SCSI. Small computer system interface.

SE. Single-ended.

Secure Socket Layer. See *SSL*.

segment. A part.

sel. Select.

Serial Attached SCSI (SAS). A drive sled with a SAS interface can be linked directly to controllers. SAS is a performance improvement over traditional SCSI because SAS enables multiple devices (up to 128) of different sizes and types to be connected simultaneously with thinner and longer cables; its full-duplex signal transmission supports 3.0 Gb/s. In addition, SAS drives can be hot-plugged.

serialize. To change from parallel-by-byte to serial-by-bit.

serializer. A device that converts a space distribution of simultaneous states representing data into a corresponding time sequence of states.

servo, servos. An adjective for use in qualifying some part or aspect of a servomechanism.

servomechanism. A feedback control system in which at least one of the system signals represents mechanical motion.

Simple Network Management Protocol. SNMP, a standard TCP/IP protocol to send alerts about conditions (such as need for operator intervention) over a TCP/IP LAN network to an SNMP monitoring station.

Slot Blocker. A slot blocker is used to restrict/close off a data cell so a data cartridge cannot be placed there. This blocker can easily be removed.

Small Computer Systems Interface (SCSI). A standard used by computer manufacturers for attaching peripheral devices (such as tape drives, hard disks, CD-ROM players, printers, and scanners) to computers (servers). Pronounced "scuzzy". Variations of the SCSI

interface provide for faster data transmission rates than standard serial and parallel ports (up to 160 megabytes per second). The variations include:

- **Fast/Wide SCSI:** Uses a 16-bit bus, and supports data rates of up to 20 MBps.
- **SCSI-1:** Uses an 8-bit bus, and supports data rates of 4 MBps.
- **SCSI-2:** Same as SCSI-1, but uses a 50-pin connector instead of a 25-pin connector, and supports multiple devices.
- **Ultra SCSI:** Uses an 8- or 16-bit bus, and supports data rates of 20 or 40 MBps.
- **Ultra2 SCSI:** Uses an 8- or 16-bit bus and supports data rates of 40 or 80 MBps.
- **Ultra3 SCSI:** Uses a 16-bit bus and supports data rates of 80 or 160 MBps.
- **Ultra160 SCSI:** Uses a 16-bit bus and supports data rates of 80 or 160 MBps.

SME. System Managed Encryption

SNMP. Simple Network Management Protocol, a standard TCP/IP protocol to send alerts about conditions (such as need for operator intervention) over a TCP/IP LAN network to an SNMP monitoring station.

SNS. Sense.

special feature. A feature that can be ordered to enhance the capability, storage capacity, or performance of a product, but is not essential for its basic work.

SR. Service representative, see also *CE*.

SRAM. Static random access memory.

SS. Status store.

SSL. SSL, or Secure Socket Layer is a cryptographic protocol that provide secure communications on the Internet for such things as web browsing, EKM communication, Internet faxing, instant messaging and other data transfers. This protocol allows applications to communicate across a network in a way designed to prevent eavesdropping, tampering, and message forgery.

ST. Store.

standard feature. The significant design elements of a product that are included as part of the fundamental product.

START. Start maintenance.

subsystem. A secondary or subordinate system, usually capable of operating independently of, or asynchronously with, a controlling system.

SUPP. Support.

sync. Synchronous, synchronize. Occurring with a regular or predictable time relationship.

T

tachometer, tach. A device that emits pulses that are used to measure/check speed or distance.

tape cartridge. A container holding magnetic tape that can be processed without separating it from the container.

tape void. An area in the tape in which no signal can be detected.

TCP/IP. Transmission Control Protocol/Internet Protocol.

TCU. Tape control unit.

Telnet. See *Telnet Service Port*.

Telnet Service Port. A network protocol used by service personnel, under direction by support personnel, to access the library. TELNET clients are used, often when diagnosing problems, to manually "talk" to other services without specialized client software.

TH. Thermal.

thread/load operation. A procedure that places tape along the tape path.

TM. Tapemark.

U

UART. Universal asynchronous receiver/transmitter.

unload. Prepare the tape cartridge for removal from the drive.

| **USB.** Universal Serial Bus. A serial bus standard to
| interface devices to a host computer. USB was designed
| to allow many peripherals to be connected using a
| single standardized interface socket and to improve the
| plug-and-play capabilities by allowing hot swapping,
| that is, by allowing devices to be connected and
| disconnected without rebooting the computer or
| turning off the device. Other convenient features
| include providing power to low-consumption devices
| without the need for an external power supply and
| allowing many devices to be used without requiring
| manufacturer specific, individual device drivers to be
| installed.

utilities. Utility programs.

utility programs. A computer program in general support of the processes of a computer; for instance, a diagnostic program.

uv. Under voltage.

V

VOLSER. Volume serial number.

volume. A certain portion of data, together with its data carrier, that can be handled conveniently as a unit.

VPD. Vital product data. The information contained within the tape drive that requires nonvolatile storage used by functional areas of the drive, and information required for manufacturing, RAS, and engineering.

W

word. A character string that is convenient for some purpose to consider as an entity.

World Wide Node Name (WWNN). In a fibre channel connected library, the Drive ID as listed in the Web User Interface.

Write. Write command.

WT. world trade.

X

XR. External register.

XRA. External register address register.

Index

A

- Access PIN, Operator Control
 - Panel 4-32
- accessibility
 - keyboard H-1
 - repeat rate of up and down buttons H-1
 - shortcut keys H-1
- accessor 1-4
- Accessor A-1
- accessory package 4-2
- active slots 5-20, 5-41
- Active Slots 4-20
- air quality 4-1
- air vents, front panel 1-1
- AME 5-43
- Application Managed Encryption (AME) 4-23
- ASC D-1
- ASCQ D-1
- auto clean 5-20, 5-41
- Auto Clean 4-20

B

- Bar code labels
 - ordering 6-20
- Bar Code Labels 6-5
 - guidelines for using 6-6
- bar code reader 1-4
- bootcode firmware, current level 5-31
- BOP 5-35
- Border Gateway Protocol (BGP) 1-5

C

- cable, host interface 4-12
- Cartridge 1-9, 6-1
 - capacity scaling 6-1, 6-3
 - cleaning 6-4
 - compatibility 6-2
 - data 6-1
 - disposal of 6-18
 - leader pin 6-11
 - memory chip 6-4
 - ordering 6-18
 - proper handling 6-7
 - specifications 6-17
 - Write-Protect Switch 6-7
- cartridge magazines 1-1, 4-35, A-1
- Cartridge, environment 6-9
- cartridge, suspect 2-2
- cartridges
 - inserting in library 4-38
 - populating library 4-38
- Cartridges, insert and remove 5-59
- Cartridges, repairing A-2
- channel calibration 1-9
- choosing a location 4-1
- clean drive 5-53

- cleaning slot 5-60
- clearance 4-1
- Configure menu
 - network settings 4-17
- configuring library using Web User Interface 4-16
- configuring the library 4-15
- control keys 5-8
- control path drive 5-32, 5-46
- control path failover 3-2, 5-43
- control paths 5-23
 - multiple 3-2
 - multiple paths for iSeries and as/400 3-2
 - using multiple for control path failover 3-2

D

- daisy-chaining 3-9
- Data Cartridge 5-59
- data transfer rate 1-6
- DCS 5-60
- dedicated cleaning slot B-2
- default settings 5-25
- description 1-1
- desktop installation 4-1
- Device drivers supported 1-12
- DHCP 4-17, 4-26, 5-24, 5-47
- Diagnostics 5-56
- display contrast 5-30
- dll 4-34, 7-13
- Drive
 - channel calibration 1-9
 - power management 1-9
 - speed matching 1-8
- drive configuration 5-46
- Drive Density 5-35
- Drive Diagnostics 5-29, 5-56
- drive dump, saving to host 5-55
- drive firmware, current version 5-32
- drive interface 5-23
- Drive Log 5-55
- drive serial number 5-32
- drive sled
 - description 1-7
- drive status 5-35
- drive, clean 5-53

E

- EC 5-15
- ED 5-15
- EKM 4-23
- EKM Server Setting 4-23
- element addresses 3-3, B-2, B-3
- element addressing B-1
- element types B-1
- Encryption 1-5, 4-23
- environment 1-11

- environment (*continued*)
 - operating 1-11
 - particulates 1-11
- environmental specifications 1-9
- Error Codes 8-1
- Error LEDs 7-8
- Error log 8-1
- errors
 - obtaining from library and drives E-1
 - System p E-1
- errpt command, using E-1
- Ethernet Port 1-3
- Export Media 4-38, 5-17, 5-39, 5-59, 9-1

F

- factory default settings 5-25
- fan vents 1-3
- feature activation key 5-43
- features
 - optional
 - drives 1-7
- Fibre Channel 3-7
- Fibre Channel interface
 - cables and speeds 3-10
 - connectors and adapters 3-11
 - persistent binding 3-6
 - sharing on a SAN 3-11
 - zoning 3-10
- fibre channel interposer 4-14
- Fibre Channel ports 3-10
- Firmware
 - updating
 - using ITDT Tool 9-4
- firmware, upgrade 5-57
- foot pads, installing 4-4
- front panel components 1-1

G

- Gateway address 4-17
- Gateway Address 4-26, 5-24, 5-47
- glossary J-1

H

- Host Attachment 7-13
- host bus adapter 3-7
- host connection, verifying 4-34
- host interface cable 4-12
- host interface connectors 1-3
- host interfaces 3-7
- host preparation 4-34
- hp-ux system error information E-5
- humidity 4-1

I

- I/O Station 1-1, 4-35, 5-59
- I/O Station, configuring 5-60
- I/O Station, open and close 5-60
- identifying a suspect cartridge 1-1, 2-2
- Import Media 4-38, 5-17, 5-39, 5-59
- installation 4-1
- Interface 7-13
- interfaces 3-7
- interfaces, supported 1-7
- internal view of library A-1
- Internet Protocol version 4 1-5
- Internet Protocol version 6 1-5
- interposer, fibre channel 4-14
- Inventory 5-15, 5-40
- IP address 4-17, 5-31
- IP Address 4-26, 5-24, 5-47
- IP Stack 5-24
- IPv4 1-5
- IPv6 1-5
- ITDT Tool 9-4

K

- Key Path 5-35
- Key Path Diagnostics 5-56
- keyboard H-1

L

- Labels
 - bar code 6-5
 - guidelines for using 6-6
 - ordering 6-20
- LED, amber 7-14
- LEDs 2-2, 7-8
- LEDs, front panel 1-1
- library configuration form G-1
- Library Controller Board A-1
- library firmware, current level 5-31
- library logs 5-54
- library mode 4-20, 5-20, 5-31, 5-41
- library name 5-41
- library network configuration 4-26, 5-47
- library recovery 7-8
- library status 5-34
- Library Verify 5-28
- library weight 1-9
- license activation key 4-22, 4-23, 5-27
- Link-local IPv6 address 5-11
- LME 5-43
- locating the library 4-1
- logical libraries 4-21, 5-19, 5-42
 - determining number 3-1
 - basic guidelines 3-1
 - using multiple for sharing 3-2
- logical libraries, assigning 4-21
- logs 5-54
- low voltage differential (LVD) SCSI interface 1-7
- low-power mode 1-9
- LUN 3-7
- LUN scanning 3-7
- LVD SCSI interface 1-7

M

- MAC Address 1-5
- magazines 1-1, 4-35, A-1
- Maximum Transmission Unit (MTU) 1-5
- media 1-9
- Media 6-1
- media capacity 1-1
- menu shortcuts 5-1
- menu tree
 - Operator Control Panel 5-10
- Menus
 - Configure
 - network settings 4-17
- MIB 1-6, C-1
- Monitor menu
 - Drive 5-13
 - Library 5-11
- Move Media 4-38, 5-17, 5-39
- Multiple control paths 3-2

N

- Navigation 5-8
- Netmask 4-17
- Network Address Translation (NAT) 1-5
- network configuration 5-24
- Network Mask 4-26, 5-24, 5-47
- network settings 5-24

O

- OCP 4-33
- ON/OFF power button 2-4
- operating systems supported 1-11
- operation specifications 1-9
- Operator Control Panel
 - Access PIN 4-32
 - Configure: Restore Defaults 5-25
 - control keys on front panel 1-1
 - display 1-1
 - menu tree 5-10
- Monitor menu
 - Drive 5-13
 - Library 5-11
 - power ON display 2-2
- Operator Control Panel menus
 - Configure: Drive 5-23
 - Configure: Library 5-20

P

- packaging materials 4-2
- partitioning 3-3, 4-21, B-3
- partitioning your 4U library 5-42
- path failover 4-22, 5-27
- physical specifications 1-9
- power button 1-1, 2-4
- power connector 1-3
- power management 1-9
- power ON display 2-2
- power source 4-1
- power specifications 1-9
- power supply A-1
- Power Supply Problem 7-8
- product ID 5-31

- PTF 4-34, 7-13

Q

- Quiesce 5-56

R

- rack installation 4-1, 4-6
- rack mounting the library 4-6
- rack requirements 4-1
- RAID controllers 3-7
- Read/Write capability 6-2
- rear panel of library 1-3
- Remove/replace procedures 10-1
- reserve slot, active slot 5-60
- Reserved Slots 4-20
- RFC (Request for Comments) 1-5
- Router assigned IPv6 address 5-11

S

- Safety inspection procedure xvii
- SAS interface 3-9
- screens displayed at power ON 2-2
- SCSI interface 3-7
 - bus termination 3-9
 - connectors and adapters 3-9
 - description 1-7
 - multiple buses 3-8
 - physical characteristics 3-8
- SCSI LVD 3-7, 3-9
- SCSI Trade Association Web site 3-9
- Sense data
 - using D-1
- sense data, library D-1
- sequential mode, starting 5-20
- sequential mode, stopping 5-20
- serial number 5-31
- serial number, drive 5-32
- Serial Port 1-3
- server attachment
 - SCSI interface 3-7
- servers supported 1-11
- Sharing the library 3-1
- shipment verification 4-3
- shipping container 4-2
- shipping label, removing and storing 4-5
- shipping lock and label storage location 1-3
- shipping lock, removing and storing 4-5
- shortcut keys H-1
- Simple Network Management Protocol 1-6
- sled, description of tape drive 1-7
- Slot Blocker 10-10
- slot physical locations B-2
- SME 5-43
- SNMP 1-6, 5-47, C-1, F-1
- software supported 1-11
- specifications 1-9
 - environmental 1-9
 - operation 1-9
 - physical 1-9
 - power 1-9

- Specifications
 - cartridges 6-17
 - speed matching 1-8
 - SSL 4-26, 5-47
 - storage capacity 1-6
- System p
 - error information E-1

- write-protect switch
 - Write Protect Switch Setting C-3
- Write-Protect Switch
 - setting 6-7
- WWNN 5-31

T

- tape cartridge 1-9
- tape drive sled 1-3, A-1
- Tape drives
 - channel calibration 1-9
 - power management 1-9
 - quantity in library 1-7
 - speed matching 1-8
- TapeAlert Flags
 - for drives C-3
- TapeAlert Flags, library C-1
- technical support 9-5
- Telnet A-26
- Telnet Service Port 5-30
- Traps F-1
- troubleshooting 7-1

U

- Ultra160 1-6
- Ultra320 1-6
- Ultrium Tape Drives 1-7
- unpacking the library 4-2
- Updating firmware
 - using ITDT Tool 9-4
- upgrade firmware 5-57
- USB port 1-3

V

- verifying the shipment 4-3
- View Drive Logs 5-55

W

- Web User Interface
 - Configure Library: Event Notification 5-52
 - Configure Library: Restore Defaults 5-52
 - configuring library 4-16
 - date and time 4-30
 - drive information 4-25
 - event notification 4-31
 - general library information 4-20
 - logging on 4-18
 - logs and traces 4-30
 - user access information 4-29
- Web User Interface menus
 - Configure Library: User Access 5-50
- World Wide Node Name (WWNN) 3-6
- World Wide Port Name (WWPN) 3-6
- worldwide node name 5-31
- WORM (Write Once, Read Many) 6-3
- Write Once, Read Many (see WORM) 6-3

Readers' Comments — We'd Like to Hear from You

IBM System Storage TS3100 Tape Library and TS3200 Tape Library
Setup, Operator, and Service Guide
Machine Type 3573

Publication No. GA32-0545-07

We appreciate your comments about this publication. Please comment on specific errors or omissions, accuracy, organization, subject matter, or completeness of this book. The comments you send should pertain to only the information in this manual or product and the way in which the information is presented.

For technical questions and information about products and prices, please contact your IBM branch office, your IBM business partner, or your authorized remarketer.

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute your comments in any way it believes appropriate without incurring any obligation to you. IBM or any other organizations will only use the personal information that you supply to contact you about the issues that you state on this form.

Comments:

Thank you for your support.

Send your comments to the address on the reverse side of this form.

If you would like a response from IBM, please fill in the following information:

Name

Address

Company or Organization

Phone No.

E-mail address

Readers' Comments — We'd Like to Hear from You
GA32-0545-07



Cut or Fold
Along Line

Fold and Tape

Please do not staple

Fold and Tape




NO POSTAGE
NECESSARY
IF MAILED IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 40 ARMONK, NEW YORK

POSTAGE WILL BE PAID BY ADDRESSEE

International Business Machines Corporation
Information Development
Department GZW
9000 South Rita Road
Tucson, Arizona U.S.A. 85775-4401



Fold and Tape

Please do not staple

Fold and Tape



Part Number: 45E6627

Printed in USA

GA32-0545-07



(1P) P/N: 45E6627



Spine information:



IBM System Storage TS3100 Tape
Library and TS3200 Tape Library

TS3100 Tape Library and TS3200 Tape Library Setup,
Operator, and Service Guide

Machine Type 3573