

# Core MW Management Guide

## Core Middleware

---

### USER GUIDE

**Copyright**

© Ericsson AB 2015–2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Prerequisites	1
<b>2</b>	<b>Core MW Command Overview</b>	<b>3</b>
2.1	Deprecated Commands	6
<b>3</b>	<b>Administrative Operations</b>	<b>9</b>
3.1	Reboot Cluster	9
3.2	Reboot Node	10
3.3	Lock Node	10
3.4	Unlock Node	11
3.5	Verify System Status	11
3.6	Save IMM Data	15
3.7	Get AMF Node of Given Hostname	15
3.8	Get Hostname of Given AMF Node	15
3.9	Configure IMM Access Control	16
3.10	Enable or Disable Core MW Features	16
3.11	Set Time-Out for Core MW Scaling Feature	25
3.12	Clear Alarm Issued by AMF	25
<b>4</b>	<b>Core MW Partial Backup and Partial Restore – Deprecated</b>	<b>27</b>
4.1	Create Core MW Partial Backup – Deprecated	27
4.2	List Core MW Partial Backups – Deprecated	28
4.3	Delete Core MW Partial Backup – Deprecated	28
4.4	Restore Using Core MW Partial Backup – Deprecated	28
<b>5</b>	<b>Software Management</b>	<b>31</b>
5.1	Import Software Bundles and Campaigns	31
5.2	Delete Software Bundles and Campaigns	32
5.3	Read from Software Inventory	32
5.4	Use SMF Campaigns	34
5.5	Configure ECIM SWM	39
5.6	Use CLI for Upgrade Package/CSP	41
5.7	Configure ISP Events for Cluster Restarts	47



5.8	Configure Reboot Behavior of Single-Step Procedures	48
5.9	Configure Remote Fencing Parameters	49
<b>6</b>	<b>Performance Management</b>	<b>51</b>
6.1	Create ECIM PM Job	51
6.2	Start ECIM PM Job	55
6.3	Stop ECIM PM Job	56
6.4	Delete ECIM PM Job	56
6.5	Report Status of ECIM PM Job	57
6.6	List ECIM PM Jobs	58
6.7	Modify ECIM PM Job	60
6.8	Display Active PM Values for an Instance	63
<b>7</b>	<b>OpenSAF Tools</b>	<b>65</b>
7.1	OpenSAF Tools Wrapper	65
<b>8</b>	<b>Backup and Restore Framework</b>	<b>69</b>



# 1 Introduction

This document describes how to manage the Core Middleware (MW) component.

## 1.1 Prerequisites

This section describes the prerequisites, which must be fulfilled before using these procedures.

### 1.1.1 Conditions

The following conditions must apply:

- The system is ready to accept logon attempts from users.
- Commands are run as root user or prefixed with `sudo` and run by users belonging to group `system-adm`. The sudo configuration enforces the user to provide the password before execution of the command. Any exceptions to this are detailed in the relevant sections.





## 2 Core MW Command Overview

After successful logon the commands shown in Table 1 are available to root user or to user belonging to group `system-adm` and prefixed by `sudo`.

**Note:** The exact output from any command can differ depending on the release. Command completions can be used.

Command argument completion can be used if the OS supports it and bash shell is used.

In addition to what is listed in Table 1, all commands have a `--help` attribute.

Core MW has introduced interference checks and locking between a number of commands to minimize the risk that parallel execution disrupts the system. The following areas are included:

- Campaign execution
- Backup
- Resize of Core MW

The interference locking assures that it is only possible to execute one of these commands at the same time.

*Table 1 Core MW Command Overview*

Core MW Command	Description
<code>cmw-alarm-clear [-v] &lt;alarm-type&gt; &lt;managed-object&gt;</code>	Clear alarm issued by AMF. See Section 3.12 Clear Alarm Issued by AMF on page 25.
<code>cmw-amfnode-get &lt;hostname&gt;</code>	Get AMF node of given hostname. See Section 3.7 Get AMF Node of Given Hostname on page 15.
<code>cmw-campaign-commit &lt;campaign-name&gt;</code>	Commit campaign. See Section 5.4.1 Execute an SMF Campaign on page 35.
<code>cmw-campaign-rollback &lt;campaign-name&gt;</code>	Rollback campaign. See Section 5.4.2 Roll Back a Campaign on page 37.



Table 1 Core MW Command Overview

Core MW Command	Description
<code>cmw-campaign-start [--disable-backup] &lt;campaign-name&gt;</code>	Start campaign. See Section 5.4.1 Execute an SMF Campaign on page 35. If more than one campaign is executed in sequence, <code>--disable-backup</code> can be used to inhibit backups during campaign execution, except for the first campaign where a backup is recommended.
<code>cmw-campaign-status &lt;campaign-name&gt;</code>	View campaign status. See Section 5.4.1 Execute an SMF Campaign on page 35.
<code>cmw-campaign-stop &lt;campaign-name&gt;</code>	Suspend campaign. See Section 5.4.2 Roll Back a Campaign on page 37.
<code>cmw-campaign-verify &lt;campaign-name&gt;</code>	Verify campaign. See Section 5.4.6 Initiate SMF Verification on page 39.
<code>cmw-cluster-reboot [--no-rapid-reboot] [--yes]</code>	Reboot cluster. See Section 3.1 Reboot Cluster on page 9.
<code>cmw-hostname-get &lt;amfnode&gt;</code>	Get hostname of given AMF node. See Section 3.8 Get Hostname of Given AMF Node on page 15.
<code>cmw-node-lock &lt;hostname&gt; [-t &lt;timeout&gt;   --timeout &lt;timeout&gt;]</code>	Lock node. See Section 3.3 Lock Node on page 10.
<code>cmw-node-unlock &lt;hostname&gt; [-t &lt;timeout&gt;   --timeout &lt;timeout&gt;]</code>	Unlock node. See Section 3.4 Unlock Node on page 11.
<code>cmw-node-reboot [&lt;hostname&gt;]</code>	Reboot single node. See Section 3.2 Reboot Node on page 10.
<code>cmw-pmjob-create &lt;job-name&gt; &lt;option&gt; [&lt;option&gt;...]</code>	Create an ECIM PM Job. See Section 6.1 Create ECIM PM Job on page 51.
<code>cmw-pmjob-start &lt;job-name&gt;</code>	Start an ECIM PM Job. See Section 6.2 Start ECIM PM Job on page 55.
<code>cmw-pmjob-stop &lt;job-name&gt;</code>	Stop an ECIM PM Job. See Section 6.3 Stop ECIM PM Job on page 56.
<code>cmw-pmjob-delete &lt;job-name&gt;</code>	Delete an ECIM PM Job. See Section 6.4 Delete ECIM PM Job on page 56.
<code>cmw-pmjob-modify &lt;job-name&gt; &lt;option&gt; [&lt;option&gt;...]</code>	Modify an ECIM PM Job. See Section 6.7 Modify ECIM PM Job on page 60.
<code>cmw-pm-show-counters [-v] &lt;option&gt; [&lt;option&gt;...]</code>	Display active PM values for a specified instance. See Section 6.8 Display Active PM Values for an Instance on page 63.
<code>cmw-pmjob-status [-v] &lt;job-name&gt;</code>	View ECIM PM Job status. See Section 6.5 Report Status of ECIM PM Job on page 57.



Table 1 Core MW Command Overview

Core MW Command	Description
<code>cmw-pmjob-list [&lt;option&gt;...]</code>	List all defined ECIM PM Jobs. See Section 6.6 List ECIM PM Jobs on page 58.
<code>cmw-repository-list [--campaign] [--node] [&lt;hostname&gt;...]</code>	List imported software bundles and campaigns. See Section 5.3 Read from Software Inventory on page 32.
<code>cmw-sdp-import &lt;file&gt; [&lt;file&gt;...]</code>	Import software bundles and campaigns. See Section 5.1 Import Software Bundles and Campaigns on page 31.
<code>cmw-sdp-remove &lt;name&gt; [&lt;name&gt;...]</code>	Delete software bundles and campaigns. See Section 5.2 Delete Software Bundles and Campaigns on page 32.
<code>cmw-status [-v] &lt;class-name&gt; [&lt;class-name&gt;...]</code>	View system status. Only failing items are printed unless flag <code>-v</code> is specified. See Section 3.5 Verify System Status on page 11.
<code>cmw-swm</code>	Consume a UP/CSP. See Section 5.6 Use CLI for Upgrade Package/CSP on page 41.
<code>cmw-ait-install</code>	Consume a CSP. Used by AIT to consume a package that could not be consumed by ECIM SWM because of multiple campaigns generated based on the CBA System Model (CSM) model contained in the CSP. See Section 5.6 Use CLI for Upgrade Package/CSP on page 41.
<code>cmw-swm-config-set &lt;option&gt; [&lt;option&gt;...]</code>	Set the installation-dependent attributes in the ECIM SWM object. See Section 5.5 Configure ECIM SWM on page 39.
<code>cmw-imm-policy-set &lt;option&gt;</code>	Configure IMM access control. See Section 3.9 Configure IMM Access Control on page 16.
<code>cmw-node-alarm-timeout</code>	Set Core MW node alarm time-out. This is the time before an alarm is raised when contact with a node is lost. It is also used to determine the time when housekeeping must have finished. The housekeeping is performed after a restore when scaling is enabled (equal to the time that the system can have a faulty state after a restore).



Table 1 Core MW Command Overview

Core MW Command	Description
<code>cmw-configuration &lt;option&gt;</code>	Enable or disable Core MW features. See Section 3.10 Enable or Disable Core MW Features on page 16.
<code>cmw-timeout-configuration</code>	Set time-out for scaling batch, node join, and parallel shutdown of Core MW scaling features. See Section 3.11 Set Time-Out for Core MW Scaling Feature on page 25.
<code>cmw-utility [-h   --help] &lt;immfind / immlist / immcfg / immadm / amfadm&gt; [&lt;options&gt;]</code>	Core MW wrapper command for OpenSAF tools. See Section 7.1 OpenSAF Tools Wrapper on page 65.

## 2.1 Deprecated Commands

The deprecated commands are listed in Table 2.

Table 2 Deprecated Commands

Core MW Command	Description
<code>cmw-immSave</code>	<p>This command is deprecated and cannot be used. Using this command only result in the logging of a warning message.</p> <p>The IMM data is, starting with Core MW R2A, persistently saved automatically.</p>
<code>cmw-partial-backup-create [--verbose] &lt;label&gt;</code>	<p>This command is deprecated since Core MW R6A.</p> <p>Create Core MW partial backup. See Section 4.1 Create Core MW Partial Backup – Deprecated on page 27.</p>
<code>cmw-partial-backup-remove [--verbose] &lt;label&gt;</code>	<p>This command is deprecated since Core MW R6A.</p> <p>Delete Core MW partial backup. See Section 4.3 Delete Core MW Partial Backup – Deprecated on page 28.</p>



Table 2 Depreciated Commands

Core MW Command	Description
<code>cmw-partial-backup-restore</code> <code>[--verbose] &lt;label&gt;</code>	This command is deprecated since Core MW R6A.  Restore Core MW from partial backup. See Section 4.4 Restore Using Core MW Partial Backup – Deprecated on page 28.
<code>cmw-partial-backup-list</code>	This command is deprecated since Core MW R6A.  List Core MW partial backups. See Section 4.2 List Core MW Partial Backups – Deprecated on page 28.

Deprecated command options are listed in Table 3.

Table 3 Depreciated Command Options

Core MW Command Option	Description
<code>cmw-configuration &lt;--enable / --disable / --status&gt; ONE_STEP_UPGRADE</code>	This command option is deprecated since Core MW R3A. To configure upgrade execution method, refer to Section <i>Configure Upgrade Execution Method of the Upgrade Package</i> in <i>Core MW Software Management</i> .  Enable, disable, or check status of One Step Upgrade feature. See Section 3.10.5 One Step Upgrade Feature – Deprecated on page 20.





## 3 Administrative Operations

All commands in this section are to be run as root user.

All commands except those for “Configuring IMM Access Control” can be prefixed with `sudo` and run by users belonging group `system-adm`.

This section describes the following administrative operations:

- Rebooting cluster
- Rebooting node
- Locking node
- Unlocking node
- Verifying system status
- Saving IMM data
- Getting AMF node of given hostname
- Getting hostname of given AMF node
- Configuring IMM Access Control
- Enabling or disabling Core MW features
- Setting time-out for Core MW scaling feature
- Clearing alarm issued by AMF

### 3.1 Reboot Cluster

To reboot the cluster in an ordered way, use the following command:

```
cmw-cluster-reboot [--no-rapid-reboot] [--yes]
```

If `--no-rapid-reboot` is specified, the cluster reboots using a regular mechanism instead of using `kexec` to facilitate fast rebooting as usual.

If `--yes` is specified, the command does not require confirmation.



```
SC-1:~ # cmw-cluster-reboot
Really want to reboot the entire cluster (yes/no)? yes
Rebooting all nodes
Stopping DHCP daemon on node 2 (SC-2)
Stopping DHCP daemon ..done
Stopping DHCP daemon on node 1 (SC-1)
Stopping DHCP daemon ..done
Rebooting node 4 (PL-4)
Rebooting node 3 (PL-3)
Waiting for payload nodes to shut down
Payload nodes have shut down
Rebooting node 2 (SC-2)
Rebooting node 1 (SC-1)

Broadcast message from root (pts/0) (Mon Jul  5 13:07:36 2010):

The system is going down for reboot NOW!
SC-1:~ #
```

*Example 1 Rebooting Cluster with Interactive Confirmation*

## 3.2 Reboot Node

To reboot a single node, use the following command:

```
cmw-node-reboot [<hostname>]
```

If no hostname is specified, the current node is rebooted.

**Note:** This command is normally not used, but can be necessary to recover from transient error situations on a node that cannot be resolved using procedures with less system impact.

```
SC-1:~ # cmw-node-reboot PL-4
Rebooting node 4 (PL-4)
SC-1:~ #
```

*Example 2 Rebooting Remote Node*

## 3.3 Lock Node

To lock an AMF node, that is, to set its administrative state to `LOCKED`, use the following command:

```
cmw-node-lock <hostname> [-t <timeout> | --timeout  
<timeout>]
```

All Service Units (SUs) hosted on the node are prohibited from providing service.



To set the time-out in seconds, use the utility `timeout` command:

```
-t, --timeout <seconds>
```

If time-out is not specified, the default time-out of 900 seconds is used.

**Note:** The affected workload is redistributed according to the AMF redundancy model of the application.

```
SC-1:~ # cmw-node-lock PL-4
SC-1:~ #
```

*Example 3 Locking Node*

## 3.4 Unlock Node

To unlock an AMF node, that is, to set its administrative state to `UNLOCKED`, use the following command:

```
cmw-node-unlock <hostname> [-t <timeout> | --timeout
<timeout>]
```

All SUs hosted on the node are administratively allowed to provide service.

To set the time-out in seconds, use the utility `timeout` command:

```
-t, --timeout <seconds>
```

If time-out is not specified, the default time-out of 900 seconds is used.

```
SC-1:~ # cmw-node-unlock PL-4
SC-1:~ #
```

*Example 4 Unlocking Node*

## 3.5 Verify System Status

To verify that the system status is normal, check the status of the following system items with the following command:

```
cmw-status [-v] <class-name> [<class-name>...]
```

Here `v` is verbose and `class-name` is one of the following:

<b>app</b>	Application has an administrative state that must be verified. In a “normal” system state, the application must be in an unlocked state.
------------	--



<b>csiass</b>	<p>The Component Service Instance (CSI) has a High Availability (HA) state that must be verified. No CSI must be in <code>quiescing</code> or <code>quiesced</code> state when the system status is normal.</p>
<b>comp</b>	<p>An AMF component has a HA state that must be verified. No component must be in <code>quiescing</code> or <code>quiesced</code> state when the system status is normal. The <code>operationalState</code> of <code>comp</code> must be <code>ENABLED</code>.</p>
<b>node</b>	<p>An executing instance of the host OS connected to the cluster. A node can be a Virtual Machine.</p>
<b>pm</b>	<p>Performance Management (PM) reports overall Ericsson Common Information Model (ECIM) PM status. If all ECIM PM Jobs are in <code>Active</code> state, PM returns <code>Status OK</code>. Otherwise PM provides details about ECIM PM Jobs that are in <code>Stopped</code> or <code>Faulty</code> state.</p> <p>The command has a short and verbose format. The short format lists only the ECIM PM Job name and state for <code>Stopped</code> or <code>Faulty</code> Jobs. The verbose format lists all ECIM PM Jobs, including those in <code>Active</code> states.</p>
<b>sg</b>	<p>A Service Group (SG) is a logical entity that groups one or more SUs to provide service availability for a particular set of SIs. The redundancy model defines how the SUs in the SG are used to provide service availability. Supported redundancy models are as follows:</p> <ul style="list-style-type: none"><li>• <code>2N</code> – In this redundancy model one SU is active for all SIs, and one SU is standby for all SIs.</li><li>• <code>N+M</code> – Flexible redundancy with possibility to control the number of active and standbys. A common use of this redundancy model is the <code>N+1</code> redundancy in which a single SU is standby for <code>N</code> active SUs.</li><li>• <code>N-Way</code> – In this redundancy model, it is possible for an SU to have active HA state for some SIs and at the same time have standby HA state for some other SIs.</li><li>• <code>N-WayActive</code> – This is a load-sharing redundancy model with only active SUs.</li><li>• <code>No Redundancy</code> – This redundancy model is typically used with non-critical components when the failure of a component does not cause any severe impact on the overall system and a restart is good enough.</li></ul>



<b>si</b>	As components are aggregated into SUs, the AMF supports the aggregation of CSIs into a logical entity called a Service Instance (SI). An SI represents a single workload assigned to the entire SU. AMF assigns HA state to the SU on behalf of one or more of SIs.
<b>siass</b>	Defines the SUs assigned to an SI. All SUs of the same type can be assigned Service Instances (SIs) derived from the same set of service types.
<b>su</b>	<p>A Service Unit (SU) is a logical entity that aggregates a set of components combining their individual functionalities to provide a higher-level service. It is the unit of redundancy in the sense that it is the smallest logical entity that can be instantiated in a redundant manner. Each SU always executes on only one node, that is, it cannot be distributed over several nodes.</p> <p>The components that constitute an SU can be developed in isolation, and a component developer can be unaware of which components constitute an SU, as they are defined at deployment time.</p>

When the system is in normal status, the output can look as shown in Example 5.

```
SC-1:~ # cmw-status node comp su
Status OK
SC-1:~ #
```

#### *Example 5 System in Normal Status*

When verifying system status the primary class names to specify are `su`, `node`, and `comp`. If the `si` class name is specified, `PARTIALLY_ASSIGNED` can be returned even if there is no fault in the system.

On a single node cluster (1 + 0 configuration), the output can look as shown in Example 6.

```
SC-1:~ # cmw-status si
Status OK
SC-1:~ #
```

#### *Example 6 Single Node System with Normal SI Status*

In verbose mode on a single node cluster (1 + 0 configuration) the output can look as shown in Example 7.



```
SC-1:~ # cmw-status -v si
safSi=SC-2N,safApp=OpenSAF
AdminState=UNLOCKED(1)
AssignmentState=PARTIALLY_ASSIGNED(3)
safSi=SC-2N,safApp=ERIC-CoreMW
AdminState=UNLOCKED(1)
AssignmentState=PARTIALLY_ASSIGNED(3)
SC-1:~ #
```

**Example 7** *Single Node System with Normal Verbose SI Status*

```
SC-1:~ # cmw-status node
safAmfNode=PL-3,safAmfCluster=myAmfCluster
AdminState=LOCKED-INSTANTIATION(3)
OperState=ENABLED(1)
SC-1:~ #
```

**Example 8** *System with One Node Locked*

```
SC-1:~ # cmw-status -v node
safAmfNode=SC-2,safAmfCluster=myAmfCluster
AdminState=UNLOCKED(1)
OperState=ENABLED(1)
safAmfNode=SC-1,safAmfCluster=myAmfCluster
AdminState=UNLOCKED(1)
OperState=ENABLED(1)
safAmfNode=PL-4,safAmfCluster=myAmfCluster
AdminState=UNLOCKED(1)
OperState=ENABLED(1)
safAmfNode=PL-3,safAmfCluster=myAmfCluster
AdminState=UNLOCKED(1)
OperState=ENABLED(1)
SC-1:~ #
```

**Example 9** *Verifying System Using Verbose Mode*

```
SC-1:~ # cmw-status pm
pmJobId=TC-CMW-PM-CMD-STATUS-1, Stopped
SC-1:~ #
```

**Example 10** *Verifying PM Job Status with One Job in State Stopped*



```

SC-1:~ # cmw-status -v pm
Name                                     Value(s)
=====
pmJobId                                TC-CMW-PM-CMD-STATUS-1
jobType                                Measurement(0x1)
granularityPeriod                       1 minute(0x3)
reportingPeriod                         1 minute(0x3)
jobPriority                             High(0x3)
requestedJobState                       Stopped(0x2)
currentJobState                         Stopped(0x2)
Overall Job State                       Stopped(0x2)
Name                                     Value(s)
=====
pmJobId                                TC-CMW-PM-CMD-STATUS-2
jobType                                Threshold(0x2)
granularityPeriod                       5 minutes(0x4)
reportingPeriod                         15 minutes(0x5)
jobPriority                             Medium(0x2)
requestedJobState                       Active(0x1)
currentJobState                         Active(0x1)
Overall Job State                       Active(0x1)
SC-1:~ #

```

*Example 11 Verifying PM Job Status Using Verbose Mode*

## 3.6 Save IMM Data

The IMM data is automatically persisted incrementally for every Configuration Change Bundle (CCB) and persistent runtime object create/update/delete operation. During campaign execution, the persistency is disabled and then enabled again when the campaign reaches the completed state, that is, before commit is done.

## 3.7 Get AMF Node of Given Hostname

To get the AMF node of a given hostname, use the following command:

```
cmw-amfnode-get <hostname>
```

```

SC-1:~ # cmw-amfnode-get SC-1
SC-1
SC-1:~ #

```

*Example 12 Getting AMF Node of Given Hostname*

## 3.8 Get Hostname of Given AMF Node

To get the hostname of a given AMF node, use the following command:



```
cmw-hostname-get <amfnode>
```

```
SC-1:~ # cmw-hostname-get SC-1  
SC-1  
SC-1:~ #
```

*Example 13 Getting Hostname of Given AMF Node*

## 3.9 Configure IMM Access Control

To configure IMM Access Control, use the following command:

```
cmw-imm-policy-set <enforced / disabled / permissive>
```

For compatibility reasons, the default setting of IMM Access Control is DISABLED.

By setting IMM Access Control to ENFORCED, the IMM users wanting to access IMM must belong to the `cmw-imm-users` group. For more information, refer to Section *Information Model Management Service in Core MW System Architecture Description*.

**Note:** PERMISSIVE logs all violations to system logs without enforcing access control. Must be used with caution, as it can introduce unwanted spam in the system logs.

## 3.10 Enable or Disable Core MW Features

To enable, disable, or check status of Core MW features, use the following command:

```
cmw-configuration <--enable / --disable / --status> <feature>  
[--reboot]
```

The parameters are as follows:

- `--enable` – Enable *<feature>* on all nodes.
- `--disable` – Disable *<feature>* on all nodes.
- `--status` – Check status of *<feature>* (enable/disable).
- `--reboot` – Force cluster reboot immediately to enable or disable *<feature>* on all nodes. A cluster reboot is needed to enable or disable some features. Information about this can be found in the description of each feature.

The FENCING feature supports the following additional parameters:

- `--test` – Test specified Fencing plug-in and parameters.
- `--plugin <plug-in name>` – Specify plug-in for the FENCING feature.



- `--set <amfNodeName>` – Set `amfNodeName` for the FENCING feature.
- `--list` – List available plug-ins for the FENCING feature.

The following features are supported:

- TIPC\_MULTICAST
- SC\_ABSENCE\_ALLOWED
- SCALING
- ISP\_REPORT
- ONE\_STEP\_UPGRADE – Deprecated
- PM\_REPORTALWAYS
- ME\_NAME
- FENCING

### 3.10.1 TIPC Multicast Feature

The Message Distribution Service (MDS) broadcasts are implemented using `unicast`, which adds load and does not scale on larger clusters. The Transparent Inter-Process Communication (TIPC) multicast feature solves this issue, deleting these performance impacts.

Before enabling the TIPC Multicast feature in Core MW, the user must verify that the current TIPC driver fully supports that feature.

**Note:** A cluster reboot is required for this action to take effect. An immediate cluster reboot can be triggered with parameter `--reboot`.

If the TIPC Multicast feature is already enabled, then after a Core MW upgrade it stays enabled and if it is disabled, it stays disabled.

How to enable the TIPC Multicast feature is shown in Example 14 with forced reboot, and in Example 15 without forced reboot.

```
SC-1:~ # cmw-configuration --enable TIPC_MULTICAST --reboot
Rebooting cluster ...
```

*Example 14 Enabling TIPC Multicast with Forced Reboot*

```
SC-1:~ # cmw-configuration --enable TIPC_MULTICAST
Cluster reboot is required for change to take effect
```

*Example 15 Enabling TIPC Multicast without Forced Reboot*

If the TIPC Multicast feature is already enabled, the output is as shown in Example 16.



```
SC-1:~ # cmw-configuration --enable TIPC_MULTICAST --reboot
Already enable
```

*Example 16 Enabling TIPC Multicast When Already Enabled*

```
SC-1:~ # cmw-configuration --status TIPC_MULTICAST
Enable
```

*Example 17 Checking TIPC Multicast Status*

### 3.10.2 SC Absence Feature

The System Controller (SC) Absence feature ensures that the cluster does not reboot while both SC nodes are down, allowing the payload to work with limited service. If the time taken for the SC nodes to recover exceeds a `timeout` value, all payload nodes shut down (current behavior).

Before enabling the SC Absence feature in Core MW, the user must verify that the system fully supports this feature.

**Note:** A cluster reboot is required for this action to take effect. An immediate cluster reboot can be triggered with parameter `--reboot`.

`timeout` is an optional argument for the `cmw-configuration` command. By default, `timeout` has the same value as the maximum `timeout` (900 seconds).

If the SC Absence feature is already enabled, then after a Core MW upgrade it stays enabled and if it is disabled, it stays disabled.

Example 18 and Example 19 are common examples to provide more information.

```
SC-1:~ # cmw-configuration --enable SC_ABSENCE_ALLOWED 300 --reboot
Rebooting cluster ...
```

*Example 18 Enabling SC Absence with Time-Out of 300 Seconds and Forced Reboot*

```
SC-1:~ # cmw-configuration --disable SC_ABSENCE_ALLOWED
Cluster reboot is required for change to take effect
```

*Example 19 Disabling SC Absence without Forced Reboot*

When the status of the SC Absence feature is checked, the `timeout` value is also shown. The result of checking the feature is shown in Example 20.

```
SC-1:~ # cmw-configuration --status SC_ABSENCE_ALLOWED
WARNING: Configuration has been changed but cluster reboot isn't called
Enable
Current timeout is 300
```

*Example 20 Checking Status of SC Absence (After Change without Reboot)*



### 3.10.3 Scaling Feature

When scaling is enabled, the system can automatically be expanded with newly detected nodes, using a default scaling profile. The Compute Resource Management (CRM) Northbound Interface (NBI) model allows the deletion of scalable nodes, which triggers a resize of the system. The scaling feature is enabled in runtime and does not require a reboot.

```
SC-1:~ # cmw-configuration --enable SCALING
```

#### *Example 21 Enabling Scaling*

Example 22 shows how to check the status of the scaling feature if it is already enabled.

```
SC-1:~ # cmw-configuration --status SCALING
Enable
```

#### *Example 22 Checking Status of Scaling*

```
SC-1:~ # cmw-configuration --disable SCALING
```

#### *Example 23 Disabling Scaling*

For more details about the scaling feature, refer to *Core MW Cluster Manager Description*.

### 3.10.4 In-Service Performance Report Feature

The ISP functionality collects ISP information that has been generated by Core MW and other components/applications (following the ISP API description, refer to *ISP API Interface Description 1.1.0*) and produces an XML file as output for processing by the ISP tool.

The support is as follows:

- Partial Outage reporting: partial outage events can be reported by applications or components following the specification in the ISP API. Reporting is done using the Log service.
- Network Element (NE) configuration change reporting: an upgrade/update event can be reported following the specification in the ISP API. Reporting is done using the Log service.
- ISP delivers the needed security rules to make ISP Log files visible over the NBI. These are accessed by the Automated Data Collection (ADC) tool to fetch and deliver them to the ISP tool.
- The ISP functionality keeps the XML report files for six months. Core MW automatically cleans the old ISP reports. This activity occurs once per month at the time of creation of output XML files.

Enabling/disabling the ISP report feature does not require reboot.



```
SC-2-1:~ # cmw-configuration --enable ISP_REPORT
```

*Example 24 Enabling ISP\_REPORT*

```
SC-2-1:~ # cmw-configuration --status ISP_REPORT
```

*Example 25 Checking Status of ISP\_REPORT*

```
SC-2-1:~ # cmw-configuration --disable ISP_REPORT
```

*Example 26 Disabling ISP\_REPORT*

**Note:** It is highly recommended to enable ISP events for cluster restarts in the system, see Section 5.7 Configure ISP Events for Cluster Restarts on page 47. Otherwise cluster restart events are not visible in the ISP logs, not even on individual blade level.

### 3.10.5 One Step Upgrade Feature – Deprecated

The Software Management Framework (SMF) normally executes the procedures in a campaign in execution level order. When the One Step Upgrade feature is enabled, the SMF collects all actions calculated to be made by the originally written procedures into a new internal single-step procedure, which executes all upgrade actions in a single step. The originally written procedures in the campaign are not executed.

```
SC-1:~ # cmw-configuration --enable ONE_STEP_UPGRADE
```

*Example 27 Enabling ONE\_STEP\_UPGRADE*

Example 28 shows how to check the status of the One Step Upgrade feature if it is already enabled.

```
SC-1:~ # cmw-configuration --status ONE_STEP_UPGRADE
Enable
```

*Example 28 Checking Status of ONE\_STEP\_UPGRADE*

```
SC-1:~ # cmw-configuration --disable ONE_STEP_UPGRADE
```

*Example 29 Disabling ONE\_STEP\_UPGRADE*

### 3.10.6 PM\_REPORTALWAYS Feature

The `PM_REPORTALWAYS` feature allows runtime configuration of the report file content generated for active PM Measurement jobs. It affects both existing and later created PM jobs. If the feature is enabled, report content is always generated in `MISSING_MOIDS` manner, independent of the `reportContentGeneration` attribute value of each PM job. If the feature is disabled, report content is generated according to the `reportContentGeneration` attribute value of each PM job.

This feature is disabled by default.



```
SC-1:~ # cmw-configuration --enable PM_REPORTALWAYS
```

*Example 30 Enabling PM\_REPORTALWAYS*

```
SC-1:~ # cmw-configuration --disable PM_REPORTALWAYS
```

*Example 31 Disabling PM\_REPORTALWAYS*

Example 32 shows how to check the status of the PM\_REPORTALWAYS feature if it is already enabled.

```
SC-1:~ # cmw-configuration --status PM_REPORTALWAYS
Enable
```

*Example 32 Checking Status of PM\_REPORTALWAYS*

### 3.10.7

#### Managed Element Network Name Feature

The ME\_NAME feature allows the user to set a network name on the Managed Element (ME).

This feature is disabled by default.

```
SC-1:~ # cmw-configuration --enable ME_NAME Network1
```

*Example 33 Enabling ME\_NAME*

```
SC-1:~ # cmw-configuration --disable ME_NAME
```

*Example 34 Disabling ME\_NAME*

Example 35 shows how to check the status of the ME\_NAME feature if it is already enabled.

```
DSC-1:~ # cmw-configuration --status ME_NAME
Disable
```

*Example 35 Checking Status of ME\_NAME*

### 3.10.8

#### Fencing Feature

Remote Fencing (RF) allows components, applications, and integrators to substitute the generic remote fencing logic within Core MW with a remote fencing solution more suitable to the target cluster.

Before enabling this feature, the user must verify that the system fully supports the features implemented in the RF plug-in.

To view the status of the Fencing feature, use parameter `--status` as shown in Example 36 and Example 37.



```
SC-2-1:~ # cmw-configuration --status FENCING
Fencing : Disabled
```

#### *Example 36 Fencing Feature Disabled*

```
SC-2-1:~ # cmw-configuration --status FENCING
Fencing : Enabled
Plugin Name : FENCING_STONITH-CXP9010009_1
Plugin Version : R3A20
Plugin Parameter: SC-2 SC-1
```

#### *Example 37 Fencing Feature Enabled*

To view the available RF plug-ins that have been installed on the system, use parameter `--list` as shown in Example 38 and Example 39.

```
SC-2-1:~ # cmw-configuration --status FENCING --list
Fencing : Disabled
Plugin List :
FENCING_IPMI-CXP9010010_1
```

#### *Example 38 Available RF Plug-ins Installed on System*

Example 39 shows the available RF plug-ins installed on the system and that the RF plug-in is enabled but a cluster reboot is required before configuration takes effect.

```
SC-2-1:~ # cmw-configuration --status FENCING --list
WARNING: Configuration has been changed but cluster reboot isn't called
Fencing : Enabled
Plugin Name : FENCING_STONITH-CXP9010009_1
Plugin Version : R3A20
Plugin Parameter: SC-1 SC-2
Plugin List :
FENCING_IPMI-CXP9010010_1
FENCING_STONITH-CXP9010009_1
```

#### *Example 39 Available RF Plug-ins Installed on System – RF Plug-in Enabled*

To configure and enable an RF plug-in for SC-1 and SC-2, use parameters `--enable`, `--plugin`, and `--set`, as shown in Example 40 and Example 41.

**Note:** A cluster reboot is required for this action to take effect if the RF plug-in contains any OpenSAF variable configuration. Core MW detects this automatically and informs the user that reboot is required.

```
SC-2-1:~ # cmw-configuration --enable FENCING --reboot --plugin =>
FENCING_IPMICXP9010010_1 --set SC-1 --set SC-2
Rebooting cluster ...
```

#### *Example 40 Enabling RF Plug-in and Rebooting System*

Example 41 shows how to enable an RF plug-in with the user warned that cluster reboot is required for changes to take effect.



```

SC-2-1:~ # cmw-configuration --enable FENCING --plugin =>
FENCING_STONITH-CXP9010009_1 --set SC-1 --set SC-2
setlocale: No such file or directory
1075 FT-REG-70-SC-1 running
1076 FT-REG-70-PL-4 running
1077 FT-REG-70-PL-5 running
1078 FT-REG-70-PL-3 running
1079 FT-REG-70-SC-2 running
- FT-REG-70-gwhost701 shut off
setlocale: No such file or directory
1075 FT-REG-70-SC-1 running
1076 FT-REG-70-PL-4 running
1077 FT-REG-70-PL-5 running
1078 FT-REG-70-PL-3 running
1079 FT-REG-70-SC-2 running
- FT-REG-70-gwhost701 shut off
setlocale: No such file or directory
1075 FT-REG-70-SC-1 running
1076 FT-REG-70-PL-4 running
1077 FT-REG-70-PL-5 running
1078 FT-REG-70-PL-3 running
1079 FT-REG-70-SC-2 running
- FT-REG-70-gwhost701 shut off
setlocale: No such file or directory
1075 FT-REG-70-SC-1 running
1076 FT-REG-70-PL-4 running
1077 FT-REG-70-PL-5 running
1078 FT-REG-70-PL-3 running
1079 FT-REG-70-SC-2 running
- FT-REG-70-gwhost701 shut off
WARNING: Cluster reboot is required for change to take effect

```

#### *Example 41 Enabling RF Plug-in and Rebooting System – Reboot Warning*

Core MW performs checks on the RF plug-in before enabling it by calling the “verify” functionality of the plug-in. If any errors are detected in the RF plug-in itself, or the configured data for it, the user is alerted and further information can be found in the system logs. Example 42, Example 43, and Example 44 show some typical error use cases.



```

SC-2-1:~ # cmw-configuration --enable FENCING --reboot --plugin FENCING_IPMICXP9010010_1 =>
--set SC-1 --set SC-2
CMW: ERROR (cmw-configuration): Fencing Enable failed to verify (1)
SC-2-1:~ # less /var/log/messages
Oct 21 19:54:20 SC-2-1 FENCING IPMI-CXP9010010_1: ERROR
(/storage/system/config/coremw/fencing/rf.FENCING_IPMI-CXP9010010_1): RFP_IPADDR,
RFP_USERID or RFP_PASSWD missing; check configuration
Oct 21 19:54:20 SC-2-1 FENCING IPMI-CXP9010010_1: ERROR
(/storage/system/config/coremw/fencing/rf.FENCING_IPMI-CXP9010010_1): error executing
ipmitool:
Oct 21 19:54:20 SC-2-1 FENCING IPMI-CXP9010010_1: ERROR
(/storage/system/config/coremw/fencing/rf.FENCING_IPMI-CXP9010010_1): Verify of
connection to IPMI failed
Oct 21 19:54:20 SC-2-1 CMW: Fencing plugin failed (1) on SC-1
Oct 21 19:54:20 SC-2-1 CMW: ERROR (cmw-configuration): Fencing Enable failed to
verify (1)

```

#### Example 42 Incorrect RF Plug-in Configuration Data

```

SC-2-1:~ # cmw-configuration --enable FENCING --reboot --plugin FENCING_STONITHCXP9010009_1 =>
--set SC-1 --set SC-2
CMW: ERROR (cmw-configuration): Fencing Enable failed to verify (1)
SC-2-1:~ # less /var/log/messages
Oct 21 20:02:56 SC-2-1 FENCING STONITH-CXP9010009_1: ERROR
(/storage/system/config/coremw/fencing/rf.FENCING_STONITH-CXP9010009_1):
TARGET_PLUGIN (/cluster/home/fencingtest/target.FENCING_STONITH-CXP9010009_1-R3A20)
not readable
Oct 21 20:02:56 SC-2-1 CMW: Fencing plugin failed (1) on SC-1
Oct 21 20:02:56 SC-2-1 CMW: ERROR (cmw-configuration): Fencing Enable failed to
verify (1)

```

#### Example 43 RF Plug-in TARGET\_PLUGIN Not Found

```

SC-2-1:~ # cmw-configuration --enable FENCING --plugin FENCING_STONITH-CXP9010009_1 =>
--set SC-1 --set SC-2
CMW: ERROR (cmw-configuration): Fencing Enable failed to verify (1)
SC-2-1:~ # less /var/log/messages
Oct 21 20:07:20 SC-2-1 external/libvirt[14655]: ERROR: Failed to get status for
qemu+tcp://172.16.83.51?name=qemu:///system
Oct 21 20:07:20 SC-2-1 external/libvirt[14655]: ERROR: setlocale: No such file or
directory#012error: unexpected data 'version'
Oct 21 20:07:21 SC-2-1 stonith: external status: 'libvirt status' failed with rc 1
Oct 21 20:07:21 SC-2-1 stonith: external/libvirt device not accessible.
Oct 21 20:07:21 SC-2-1 FENCING_STONITH-CXP9010009_1: ERROR
(/storage/system/config/coremw/fencing/rf.FENCING_STONITH-CXP9010009_1): Verify of
stonith and libvirt via stonith failed, rc: 1
Oct 21 20:07:21 SC-2-1 CMW: Fencing plugin failed (1) on SC-1
Oct 21 20:07:21 SC-2-1 CMW: ERROR (cmw-configuration): Fencing Enable failed to
verify (1)

```

#### Example 44 RF Plug-in Enable Failed Because of Connection Issue to Hypervisor Management System

The user can invoke the “verify” functionality of an RF plug-in (irrespective of whether enabled or not) by entering the `cmw-configuration` command with parameter `--test`, as shown in Example 45.

```

SC-2-1:~ # cmw-configuration --test FENCING --plugin FENCING_STONITH-CXP9010009_1 --set SC-1
setlocale: No such file or directory
1075 FT-REG-70-SC-1 running
1076 FT-REG-70-PL-4 running
1077 FT-REG-70-PL-5 running
1078 FT-REG-70-PL-3 running
1079 FT-REG-70-SC-2 running
- FT-REG-70-gwghost701 shut off
SC-2-1:~ # echo $?
0

```

#### Example 45 Testing RF Plug-in on SC-1 – Result Is Successful



### 3.11 Set Time-Out for Core MW Scaling Feature

To set time-out for scaling batch, node join, and parallel shutdown of Core MW scaling features, use the following command:

```
cmw-timeout-configuration [--list | --set <timeout>
<value>]
```

The parameters are as follows:

- `--list` – View the value of these time-outs.
- `--set` – Set a value to these time-outs through arguments `SCALING_BATCH`, `SCALING_JOIN`, and `SCALING_SHUTDOWN`.

```
SC-1:~ # cmw-timeout-configuration --set SCALING_JOIN 120
```

*Example 46 Setting Time-Out Value for Node Join Cluster*

### 3.12 Clear Alarm Issued by AMF

To clear an alarm issued by AMF, use the following command:

```
cmw-alarm-clear [-v] <alarm-type> <managed-object>
```

Here `v` is verbose, `managed-object` is the Distinguished Name (DN) of the alarming object, and `alarm-type` is one of the following:

<b>cleanup</b>	To clear an alarm of type “AMF Component Cleanup Failed” that was raised when AMF did not successfully clean up a software component.
<b>instantiation</b>	To clear an alarm of type “AMF Component Instantiation Failed” that was raised when AMF did not successfully instantiate a software component.
<b>model_error</b>	To clear an alarm of type “MDF Detected Model Error” that was raised when Core MW MDF detected an error during model delivery.
<b>proxy</b>	To clear an alarm of type “Proxy Status of a Component Changed to Unproxied” that was raised when a component, that was previously being proxied, had currently no proxy component mediating for it.
<b>unassign</b>	To clear an alarm of type “AMF SI Unassigned” that was raised when an SI had no active assignments to any SU.



```
SC-1:~ # cmw-alarm-clear instantiation ManagedElement=1,=>  
SaAmfApplication.safApp=ERIC-CoreMW,SaAmfSG.safSg=2N,=>  
SaAmfSU.safSu=SC-1,SaAmfComp.safComp=EcimSwm
```

*Example 47    Clearing Alarm*



## 4 Core MW Partial Backup and Partial Restore – Deprecated

**Note:** This section and all its subsections contain information that is deprecated since Core MW R6A.

When the scaling feature is enabled, all the following mentioned Core MW partial backup commands are disabled.

This section describes the following partial backup and partial restore operations:

- Creating Core MW partial backup
- Listing Core MW partial backups
- Deleting Core MW partial backup
- Restoring using Core MW partial backup

A Core MW partial backup contains a snapshot of files for Core MW, which represents the system state of Core MW. The scope of a Core MW partial backup can be extended if application programs register application-specific backup commands. The partial backup mainly acts as a driver of backup where the OS and the applications keep their backup files on their own.

The Core MW partial backup can usually be used to restore a system, but as it does not contain all files it cannot be used for restoring the system after a catastrophic event.

Core MW supports integration of custom backup manager frameworks. If a custom backup manager is registered, the responsibility for backup and restore is transferred to the backup manager. The `cmw-partial-backup-create` and `cmw-partial-backup-register` commands are disabled and returns non-zero error codes when executed.

### 4.1 Create Core MW Partial Backup – Deprecated

To create a Core MW partial backup, use the following command:

```
cmw-partial-backup-create [--verbose] <label>
```

A partial backup with the specified label is created.

The label can be a maximum of 128 characters and can only contain characters that are valid in a Linux<sup>®</sup> filename.



The partial backup is physically divided in multiple archives files. The partial backup covers the following areas:

- Host OS
- Core MW
- Software bundles and campaigns imported to Core MW repository
- Data provided by registered application backup commands

```
SC-1:~ # cmw-partial-backup-create mgmtug-example
Snapshot starting (/cluster/snapshot/.cmwea-snapshot-mgmtug-example.tar.gz)
Snapshot completed
SC-1:~ #
```

*Example 48 Creating Core MW Partial Backup*

## 4.2 List Core MW Partial Backups – Deprecated

To list the labels of the created partial backups, use the following command:

**cmw-partial-backup-list**

Only the labels of the complete partial backups are listed. For incomplete labels of partial backups, a warning message is printed.

```
SC-1:~ # cmw-partial-backup-list
1st-CMW
mgmtug-example
SMF-BACKUP_2010-07-05T12:48:08
SMF-BACKUP_2010-07-05T12:58:56
SC-1:~ #
```

*Example 49 Listing Core MW Partial Backup Labels*

## 4.3 Delete Core MW Partial Backup – Deprecated

To delete a previously created partial backup, use the following command:

**cmw-partial-backup-remove [--verbose] <label>**

```
SC-1:~ # cmw-partial-backup-remove mgmtug-example
SC-1:~ #
```

*Example 50 Deleting Core MW Partial Backup*

## 4.4 Restore Using Core MW Partial Backup – Deprecated

To restore the system from a previously created partial backup, use the following commands:



```
cmw-partial-backup-restore [--verbose] <label>
```

```
cmw-cluster-reboot --yes
```

The partial backup must be activated by rebooting the cluster, see Section 3.1 Reboot Cluster on page 9.

```
SC-1 # cmw-partial-backup-restore mgmtug-example
Restore the Host OS ...
Snapshot restore starting (/cluster/snapshot/cmwea-snapshot-mgmtug-example.tar.gz)
Snapshot restore completed
Starting RPM synchronization of node 1
Synchronizing linux-control-R1A03-PRE1.x86_64.rpm
Synchronizing =>
COREMW_COMMON-R1A-72.x86_64.716a0b126ae0b34d2f841e5cd3c539e3.rpm
Synchronizing =>
coremw-opensaf-4.0-R1A01.x86_64.09ade38a707f803470fdcf58d92f5434.rpm
Synchronizing =>
opensaf-amf-libs-4.0.RC1-R1A01.1580.4.x86_64.a8774057970069565b178c62002b893f.rpm
Synchronizing =>
opensaf-amf-nodedirector-4.0.RC1-R1A01.1580.4.x86_64.a772b062ed3638ac48a59e8bfd30e2db.rpm
Synchronizing =>
opensaf-ckpt-libs-4.0.RC1-R1A01.1580.4.x86_64.b40335b7cfa2f3592f08246fad13844c.rpm
Synchronizing =>
opensaf-ckpt-nodedirector-4.0.RC1-R1A01.1580.4.x86_64.14866c4e3fbe964cda83e97d673b7447.rpm
Synchronizing =>
opensaf-clm-libs-4.0.RC1-R1A01.1580.4.x86_64.1574c1c5e29562731573eb045d45d520.rpm
Synchronizing =>
opensaf-clm-nodeagent-4.0.RC1-R1A01.1580.4.x86_64.b7c8544f5dd86d7d33e5b8575ae3fe00.rpm
Synchronizing =>
opensaf-imm-libs-4.0.RC1-R1A01.1580.4.x86_64.59f8198c1ccbcd5ef6f21e464e19b4a9.rpm
Synchronizing =>
opensaf-imm-nodedirector-4.0.RC1-R1A01.1580.4.x86_64.769e124e417a0711c4dd4771a48a3c26.rpm
Synchronizing =>
opensaf-libs-4.0.RC1-R1A01.1580.4.x86_64.e23173b8021f50927f1328a299f793f4.rpm
Synchronizing =>
opensaf-log-libs-4.0.RC1-R1A01.1580.4.x86_64.2fbc9be1867d7c307351aeb5ebba9425.rpm
Synchronizing =>
opensaf-ntf-libs-4.0.RC1-R1A01.1580.4.x86_64.ded91cefd458156125bed888782afe73.rpm
Synchronizing =>
opensaf-smf-libs-4.0.RC1-R1A01.1580.4.x86_64.11a6b0cad1300999bf9dfa8ce4bef3d6.rpm
Synchronizing =>
opensaf-smf-nodedirector-4.0.RC1-R1A01.1580.4.x86_64.cf8cce9975734cf5d0324a24c1565ff1.rpm
Synchronizing =>
opensaf-4.0.RC1-R1A01.1580.4.x86_64.77e4dc0c1c15c20cac63097935f54cfd.rpm
Synchronizing =>
opensaf-amf-director-4.0.RC1-R1A01.1580.4.x86_64.a79972ce3e15bf7c307526459e00349f.rpm
Synchronizing =>
opensaf-ckpt-director-4.0.RC1-R1A01.1580.4.x86_64.6f6c5eaf5f6b413b4c4b88fbb65ef9b4.rpm
Synchronizing =>
opensaf-clm-server-4.0.RC1-R1A01.1580.4.x86_64.fa5baf4a1fa773e50037bb7afc5c679f.rpm
Synchronizing =>
opensaf-controller-4.0.RC1-R1A01.1580.4.x86_64.ba49b887419f2c4753f4fda58024f758.rpm
Synchronizing =>
opensaf-imm-director-4.0.RC1-R1A01.1580.4.x86_64.41b0fb79df6fd3fa25076aa43b291fce.rpm
Synchronizing =>
opensaf-log-server-4.0.RC1-R1A01.1580.4.x86_64.308b7372726cb676e9e51da7d4dbca45.rpm
Synchronizing =>
opensaf-ntf-server-4.0.RC1-R1A01.1580.4.x86_64.932bfbc668a973b6941054e99416988f.rpm
Synchronizing =>
opensaf-smf-director-4.0.RC1-R1A01.1580.4.x86_64.50ec99d3b2b0a6a3fafdbec9257d5b43.rpm
Synchronizing =>
COREMW_SC-R1A-53.x86_64.679a7116d9d5a9758c0c8f081c99ed5b.rpm
Completed RPM synchronization of node 1
.....
Completed RPM synchronization of node 9
Unpack the Core MW backup ...
Restore application data [backup-ERIC-Vip-CXP9013048_4-R1A03] ...
SC-1 # cmw-cluster-reboot --yes
```

### Example 51 Restoring Using Core MW Partial Backup





## 5 Software Management

This section describes the following software management tasks:

- Importing software bundles and campaigns
- Deleting software bundles and campaigns
- Reading from software inventory
- Using SMF campaigns
- Configuring ECIM SWM
- Using CLI for upgrade package/CSP
- Configuring ISP events for cluster restarts
- Configuring reboot behavior of single-step procedures
- Configuring remote fencing parameters

Commands are to be run as root user or prefixed with `sudo` and run by a user belonging to the `system-adm` group.

### 5.1 Import Software Bundles and Campaigns

To import software bundles or campaigns to the repository, use the following command:

```
cmw-sdp-import <file> [<file>...]
```

The possible formats are the following:

- Bundle Software Delivery Package (SDP)
- Campaign SDP
- Bundle RPM

**Note:** Different file formats can be mixed in the command.

The names of successfully imported software bundles and campaigns are printed.

```
# cmw-sdp-import /home/MyApp/incoming/TestApp.sdp =>  
/home/MyApp/incoming/TestAppInstall.sdp  
ERIC-TestApp-CXP12345-R1A01 imported (type=Bundle)  
ERIC-InstallTestApp imported (type=Campaign)  
#
```

*Example 52 Importing Bundle SDP*



A third party product (3PP) software import in bundle RPM format is shown in Example 53.

```
# cmw-sdp-import MySQL-server-community-5.1.61-1.sles11.x86_64.rpm
3PP-MySQL-server-community-5.1.61-1.sles11 imported (type=Bundle)
#
```

*Example 53 Importing Bundle RPM*

## 5.2 Delete Software Bundles and Campaigns

To delete software bundles and campaigns from the repository, use the following command:

```
cmw-sdp-remove <name> [<name>...]
```

The possible formats are the following:

- Bundle SDP
- Campaign SDP
- Bundle RPM

**Note:** Different formats can be mixed in the command.

```
# cmw-sdp-remove ERIC-TestApp-CXP12345-R1A01 ERIC-InstallTestApp
Bundle SDP removed [ERIC-TestApp-CXP12345-R1A01]
Campaign SDP removed [ERIC-InstallTestApp]
#
```

*Example 54 Deleting Bundle SDP*

**Note:** Deleting already deleted software bundles or campaign SDPs is not considered an error.

```
sc-1:~ # cmw-sdp-remove 3PP-MySQL-server-community-5.1.61-1.sles11
Bundle SDP removed [3PP-MySQL-server-community-5.1.61-1.sles11]
sc-1:~ #
```

*Example 55 Deleting Bundle RPM*

## 5.3 Read from Software Inventory

To list the imported campaigns, use the following command:

```
cmw-repository-list --campaign
```



```
SC-1 # cmw-repository-list --campaign
ERIC-InstallTestApp
SC-1 #
```

#### *Example 56 Listing Imported Campaigns*

To list the imported software bundles and if they are used or not in the system, use the following command:

**cmw-repository-list**

A list of imported software bundles and if they are used or not in the system is shown in Example 57.

```
sc-1:~ # cmw-repository-list
ERIC-COREMW_COMMON-CXP9017566_1-P1A34      Used
ERIC-COREMW_SC-CXP9017565_1-P1A31          Used
ERIC-COREMW_OPENSAP-CXP9017656_1-P1A26      Used
3PP-MySQL-server-community-5.1.61-1.sles11  Used
sc-1:~ #
```

#### *Example 57 Reading from Software Inventory*

The first column shows the name of the software bundle and the second column states whether the software bundle is used, without specifying the node.

To list all software bundles installed per node, use the following command:

**cmw-repository-list --node [<hostname>...]**

If *hostname* is not used, the output looks as in Example 58.

```
SC-1:~ # cmw-repository-list --node
PL-3 ERIC-COREMW_COMMON-CXP9017566_1-P1C72
PL-3 ERIC-COREMW_OPENSAP-CXP9017656_1-R1A01
PL-4 ERIC-COREMW_COMMON-CXP9017566_1-P1C72
PL-4 ERIC-COREMW_OPENSAP-CXP9017656_1-R1A01
SC-1 ERIC-COREMW_COMMON-CXP9017566_1-P1C72
SC-1 ERIC-COREMW_OPENSAP-CXP9017656_1-R1A01
SC-1 ERIC-COREMW_SC-CXP9017565_1-P1C53
SC-1 3PP-MySQL-server-community-5.1.61-1.sles11
SC-2 ERIC-COREMW_COMMON-CXP9017566_1-P1C72
SC-2 ERIC-COREMW_OPENSAP-CXP9017656_1-R1A01
SC-2 ERIC-COREMW_SC-CXP9017565_1-P1C53
SC-2 3PP-MySQL-server-community-5.1.61-1.sles11
SC-1:~ #
```

#### *Example 58 Reading from Software Inventory Using Variable Node*



## 5.4 Use SMF Campaigns

All kinds of software reconfiguration such as installation, upgrade, and deletion are done with a campaign.

A campaign is contained and delivered in an SDP. To make the campaign available to Core MW, the campaign SDP is imported using the `cmw-sdp-import` command. For more information about this command, see Section 5.1 Import Software Bundles and Campaigns on page 31.

To list imported campaigns, use the following command:

```
cmw-repository-list --campaign
```

For more information about the command, see Section 5.3 Read from Software Inventory on page 32.

The software reconfiguration specified in a `campaign.xml` file is executed by SMF. SMF implements a state machine that interprets the XML file and executes the software reconfiguration.

The transitions between SMF states depending on Core MW commands are shown in Figure 1.




Figure 1 SMF State Diagram

### 5.4.1 Execute an SMF Campaign

Ensure that the units (node, SU, component, and so on) are affected by the campaign and that they are free of faults before executing.

To execute a campaign:

1. Get a list of the installed campaigns:

```
cmw-repository-list --campaign
```

2. Start an SMF campaign:

```
cmw-campaign-start <campaign-name>
```



If the SMF campaign is a template, the first step performed is that the campaign is updated with information fetched from the system. Any error that occurs during campaign update and validation results in an error message and the campaign execution is not started. If this occurs, a new campaign SDP must be provided, but no other measures are needed.

If more than one campaign is executed in sequence, the optional parameter `--disable-backup` can be used to inhibit backups during campaign execution. However, when the first campaign is started, a backup is recommended and the optional parameter must not be used.

**Note:** Execution of a new campaign cannot be started until the previous campaign is committed.

3. Verify that the campaign status has state `COMPLETED`:

```
cmw-campaign-status <campaign-name>
```

If SMF detects that a campaign cannot be initiated, the initial transition is `Cannot_initiate` and the state remains `Initial`. The `Cannot_initiate` transition can be caused by an invalid campaign file, or a campaign that executes already. Once executing, the campaign can either be successful or it can fail.

**Note:** As one of the first steps of campaign execution a backup is taken. A failed campaign requires that the system is restored from a backup, during which there is a service outage.

The backup is labeled according to the following syntax:

```
SMF-BACKUP_YYYY-MM-DDTHH:MM:SS
```

Examples:

```
SMF-BACKUP_2010-07-05T12:48:08
SMF-BACKUP_2010-07-05T12:58:56
```

Depending on the state, take different actions, as follows:

State	Action
INITIAL without error	Retry status command.
INITIAL with error	Contact the campaign provider.
EXECUTING	Retry status command.
ERROR_DETECTED	Retry status command.
SUSPENDED_BY_ERROR_DETECTED	Start or rollback.



State	Action
COMPLETED	Proceed with commit step.
FAILED	Initiate a fallback by restoring and restarting the cluster, see Section 4.4 Restore Using Core MW Partial Backup – Deprecated on page 28.

4. Verify the status of the cluster, see Section 3.5 Verify System Status on page 11.

If the status is OK, continue with the next step, otherwise repeat the status check.

5. Commit the campaign, if it executed successfully:

```
cmw-campaign-commit <campaign-name>
```

6. Verify that the campaign status is COMMITTED:

```
cmw-campaign-status <campaign-name>
```

It can take some time before the campaign is committed. Repeat the command until the campaign status is COMMITTED.

## 5.4.2 Roll Back a Campaign

To roll back a campaign:

1. Stop the executing campaign, if the campaign is executing:

```
cmw-campaign-stop <campaign-name>
```

2. Roll back the campaign:

```
cmw-campaign-rollback <campaign-name>
```

3. Verify that the campaign status is ROLLBACK COMPLETED:

```
cmw-campaign-status <campaign-name>
```

If the campaign status is ROLLBACK COMPLETED, continue with the next step.

If the campaign status is ROLLBACK FAILED, initiate a fallback by restoring and restarting the cluster, see Section 4.4 Restore Using Core MW Partial Backup – Deprecated on page 28.

4. Commit the campaign, if it rolled back successfully:

```
cmw-campaign-commit <campaign-name>
```

5. Verify that the campaign status is ROLLBACK\_COMMITTED:



```
cmw-campaign-status <campaign-name>
```

It can take some time before the campaign is committed. Repeat the command until the campaign status is `ROLLBACK_COMMITTED`.

### 5.4.3 Add Software

Applications are installed using a campaign. The application is contained in one or more software bundles and the installation campaign in an SDP. The installation campaign is target system size specific.

To install an application using a campaign:

1. Copy the installation campaign SDP and the software bundles to a location at the target system, for example:

```
/home/MyApp1/incoming
```

2. Import all campaign SDPs and software bundles:

```
cmw-sdp-import /home/MyApp/incoming/<installation-campaign-filename>
```

```
cmw-sdp-import /home/MyApp/incoming/<application-filename>
```

3. Execute the installation campaign, see Section 5.4.1 Execute an SMF Campaign on page 35.
4. Delete the installation campaign SDP:

```
cmw-sdp-remove <installation-campaign>
```

### 5.4.4 Upgrade Software

Any software delivered as a software bundle is upgraded using a campaign. The new version of the software is contained in a software bundle and the upgrade campaign in a campaign SDP.

To upgrade software using a campaign:

1. Copy the campaign SDP and the software bundles to a location at the target system, for example:

```
/home/MyApp1/incoming
```

2. Import all campaign SDPs and software bundles:

```
cmw-sdp-import /home/MyApp/incoming/<upgrade-campaign-filename>
```

```
cmw-sdp-import /home/MyApp/incoming/<new-software-filename>
```



3. Execute the upgrade software campaign, see Section 5.4.1 Execute an SMF Campaign on page 35.
4. Delete the campaign SDP and the old application software bundles:

```
cmw-sdp-remove <upgrade-campaign> <old-software-bundle-name>...
```

### 5.4.5 Delete Software

Software is deleted using a campaign. The removal campaign is contained in an SDP and target system specific.

To delete software using a campaign:

1. Import the removal campaign:

```
cmw-sdp-import /home/MyApp/incoming/<removal-campaign-sdp-filename>
```

2. Execute the removal campaign, see Section 5.4.1 Execute an SMF Campaign on page 35.
3. Delete the removal campaign SDP and the software bundles:

```
cmw-sdp-remove <removal-campaign> <software-bundle-name>...
```

### 5.4.6 Initiate SMF Verification

An application can provision itself with the ability to influence the progress of an SMF campaign by registering a callback function during application startup. Once the callback is registered, it is called whenever a campaign is initiated, see Section 5.4.1 Execute an SMF Campaign on page 35.

To initiate campaign verification manually and hence execute all currently registered callbacks, use the following command:

```
cmw-campaign-verify <campaign-name>
```

The command returns exit code 0 on success, otherwise exit code 1.

Verification can also be initiated through ECIM SWM `verify()`, which makes use of `cmw-campaign-verify`.

## 5.5 Configure ECIM SWM

If ECIM for SWM is to be used, the installation-dependent attributes in the ECIM SWM object must be set. These attributes are described in Table 4.

For more information about these attributes, refer to *Core MW Software Management and Managed Object Model cmw\_SwM*.



All these attributes can be set using the following command:

```
cmw-swm-config-set <option> [<option>...]
```

Except for `localFileStorePath` and `subType`, all attributes in Table 4 can also be configured using the NBI.

The command takes the options described in Table 4.

Table 4 Command Options

Option	Description
-l, --localFileStorePath	<p><code>localFileStorePath</code> is used when creating <i>UpgradePackage</i> Managed Objects (MOs) using action <i>createUpgradePackageLocal</i>. Each local Upgrade Package (UP) to be represented by an <i>UpgradePackage</i> MO must be put in a unique directory directly under <code>localFileStorePath</code>.</p> <p>For more details, refer to action <i>createUpgradePackageLocal</i> in <i>Managed Object Model cmw_SwM</i>.</p> <p>Expectations on the file store path are as follows:</p> <ul style="list-style-type: none"><li>• The specified directory must exist before setting <code>localFileStorePath</code>.</li><li>• The directory must be accessible by both controllers.</li><li>• The directory must be writable to delete the packages as part of action <i>removeUpgradePackage</i> in <i>Managed Object Model cmw_SwM</i>.</li></ul> <p>As no default setting exists, this attribute must be assigned if action <i>createUpgradePackageLocal</i> is used.</p>
-t, --tmpStorePath	<p><code>tmpStorePath</code> is the path to the temporary storage to be used by ECIM SWM during the upgrade process. If <code>tmpStorePath</code> is not set, ECIM SWM uses the <code>/tmp</code> directory as the default temporary storage.</p> <p>Expectations on the temporary storage are as follows:</p> <ul style="list-style-type: none"><li>• The directory structure must be created before using <code>cmw-swm-config-set</code>.</li><li>• The directory must be writable to ECIM SWM.</li></ul>



Table 4 Command Options

Option	Description
-s, --subType	subType is the name of the node type. The subType describes the Managed Element, for example, "smallSystem" or "mergedSystem". This attribute is used to select the correct campaign to apply from a UP.  For more details about how it works, refer to Section <i>Element MESubtype</i> in <i>Core MW Software Management</i> .
-b, --automaticBackup	Set automaticBackup to 1 (true) if ECIM SWM is to take an automatic backup at activation, otherwise use 0 (false).  Defaults to 1 (automatic restore enabled).
-r, --automaticRestore	automaticRestore is set to 1 (true) in order for ECIM SWM to perform automatic restore at failure.
-f, --fallbackTimer	fallbackTimer specifies the maximum number of seconds ECIM SWM waits for user action before fallback. Defaults to 1200.
-a, --alarmBeforeTimeout	alarmBeforeTimeout specifies the time in seconds that an alarm is issued before a fallback occurs. Defaults to 180.

```
cmw-swm-config-set --automaticBackup 1 -s smallCluster -l =>
/home/my/package/repository
```

#### Example 59 Configuring ECIM SWM

The command activates automatic backup, sets subType to "smallCluster", and the local file store path to /home/my/package/repository.

## 5.6 Use CLI for Upgrade Package/CSP

Core MW can consume a UP/CBA Software Package (CSP) by using the command `cmw-swm`. This command allows users not using the COM component to create a UP/CSP and upgrade a CBA system using the produced package. It also allows components and applications to use the same upgrade scenario with a limited CBA stack deployed. The command takes the options described in Table 5.

Table 5 Command Options

Option	Description	Example
--up-list	View a list ID of UPs or CSPs in the system. The number following the UP ID is the action ID of the Create action that created the UP.	<pre>\$ cmw-swm --up-list</pre> Output: ERIC-Test-UP1509221 23955-P1A01 1



Table 5 Command Options

Option	Description	Example
--up-create	<p>Create a new UP/CSP instance from URI – points to the directory where the UP/CSP content is located. The URI is local (for example file:///data/dir/subdir, /storage/system/.../UP.tgz) or a remote (for example sftp://hostname/dir/subdir).</p> <p>A UP is active when it has been created but not deleted or confirmed. No other UPs can be created if another UP is active. If the user tries to do that, error messages similar to the following are displayed:</p> <ul style="list-style-type: none"><li>• CMW: error-string: @ComNbi@SwM::createUpgradePackage UpgradePackage=ERIC-Test-UP150922123955-P1A01 is still active</li><li>• CMW: error - saImmOmAdminOperationInvoke_2 admin-op RETURNED: SA_AIS_ERR_BUSY (10)</li><li>• CMW: ERROR (cmw-swm): Failed to execute create UP/CSP command for uri: file:///SoftwareManagement/cmw-csp-KQJd-UP2.tgz</li></ul> <p>The result of a successful execution of this action is an action ID. The user can use the action ID together with output of command <code>cmw-swm --up-list</code> to identify the UP ID, which is uniquely associated with each UP/CSP.</p>	<ul style="list-style-type: none"><li>• Create UP from local file path: \$ <code>cmw-swm --up-create /home/UP.tgz</code></li><li>• Create UP from remote location, protected with password: \$ <code>cmw-swm --up-create sftp://user@hostname/dir/UP_dir pa55w0rd</code></li></ul>
--up-prepare	Prepare the ME for activation of the UP/CSP.	\$ <code>cmw-swm --up-prepare ERIC-Test-UP150922123955-P1A01</code>



Table 5 Command Options

Option	Description	Example
--up-activate	Activate UP/CSP step by step or all at once.	<code>\$ cmw-swm --up-activate ERIC-Test-UP150922123955-P1A01</code>
--up-confirm	Confirm the upgrade procedure on the ME.	<code>\$ cmw-swm --up-confirm ERIC-Test-UP150922123955-P1A01</code>
--up-cancel	Cancel the upgrade procedure before confirmation or cancel Activate action at breakpoints between steps. This option can also be used to cancel long running actions such as Prepare or Activate.	<code>\$ cmw-swm --up-cancel ERIC-Test-UP150922123955-P1A01</code>
--up-remove	Delete a UP/CSP from the ME.	<code>\$ cmw-swm --up-remove ERIC-Test-UP150922123955-P1A01</code>
--up-status	<p>Get state of specific UP/CSP ID, track the progress and result of actions.</p> <p>Output format:            Action: &lt;action-name&gt; - &lt;action-state&gt;            Result: &lt;final-result-of-the-action&gt;            State: &lt;UP-state&gt;</p> <p>The last line is only displayed when a UP ID is specified in the command.</p>	<ul style="list-style-type: none"> <li>• Status of the last Create or Remove action. In this case, as UP is not created or deleted, no UP ID can be specified. <code>\$ cmw-swm --up-status</code>            Output:            Action: CreateUpgradePackage - FINISHED            Result: SUCCESS</li> <li>• Status of a UP after other actions:  <code>\$ cmw-swm --up-status ERIC-Test-UP150922123955-P1A01</code>            Output:            Action: Prepare - RUNNING            Result: NOT_AVAILABLE            State: PREPARE_IN_PROGRESS</li> </ul>



Table 5 Command Options

Option	Description	Example
<code>--default-execmethod</code>	<p>View or set the default upgrade execution method.</p> <p>Output format for view:  <code>execMethod: &lt;execution-method&gt;</code></p> <p>The following lines are only displayed when default has been configured for BALANCED execution method:  <code>roleId: &lt;ECIM_CrMRole-MO&gt;</code>  <code>minSizeOfRole: &lt;minimum-number-of-nodes-in-role&gt;</code>  <code>minRemainingCapacity: &lt;minimum-remaining-capacity&gt;</code>  <code>numberOfSteps: &lt;Empty&gt;</code></p> <p><code>numberOfSteps</code> is not calculated for default.</p>	<ul style="list-style-type: none"> <li>View default <code>execMethod</code>: \$ <b><code>cmw-swm --default-execmethod</code></b>  Output:  <code>execMethod: ROLLING</code></li> <li>Set default <code>execMethod</code> to ROLLING: \$ <b><code>cmw-swm --default-execmethod rolling</code></b></li> <li>Set default <code>execMethod</code> to ONE-STEP: \$ <b><code>cmw-swm --default-execmethod one-step</code></b></li> </ul>
<code>--up-execmethod</code>	<p>View or set the upgrade execution method of a UP/CSP.</p> <p>Output format for view:  <code>execMethod: &lt;execution-method&gt;</code></p> <p>The following lines are only displayed when the UP has been configured for BALANCED execution method):  <code>roleId: &lt;ECIM_CrMRole-MO&gt;</code>  <code>minSizeOfRole: &lt;minimum-number-of-nodes-in-role&gt;</code>  <code>minRemainingCapacity: &lt;minimum-remaining-capacity&gt;</code>  <code>numberOfSteps: &lt;calculate-d-number-of-steps&gt;</code></p>	<ul style="list-style-type: none"> <li>View UP <code>execMethod</code>: \$ <b><code>cmw-swm --up-execmethod ERIC-Test-UP150922123955-P1A01</code></b>  Output:  <code>execMethod: BALANCED</code>  <code>roleId: roleId=ScalableRole,ECIM_CrMcrMid=1</code>  <code>minSizeOfRole: 2</code>  <code>minRemainingCapacity: 35</code>  <code>numberOfSteps: 5</code></li> <li>Set UP <code>execMethod</code> to ROLLING: \$ <b><code>cmw-swm --up-execmethod ERIC-Test-UP150922123955-P1A01 rolling</code></b></li> <li>Set UP <code>execMethod</code> to BALANCED using Role: \$ <b><code>cmw-swm --up-execmethod ERIC-Test-UP150922123955-P1A01 roleId=ScalableRole,ECIM_CrMcrMid=1 8 45</code></b>  (Minimum 8 nodes and minimum 45% remaining capacity.)</li> </ul>



Example of upgrading software using `cmw-swm`:

1. Create a UP/CSP from the file argument:

```
cmw-swm --up-create /storage/system/software/coremw/repository/UP/ERIC-ActivateCommand_UP/ERIC-ActivateCommand_UP.tgz
```

The UP/CSP can be created from `file://`, `sftp://`, or path of file.

2. Verify that the UP/CSP was created and to get the `<UP-ID>` of the UP/CSP:

```
cmw-cwm --up-list
```

3. View the progress and result of the command in the previous step:

```
cmw-swm --up-status
```

4. View the UP status:

```
cmw-swm --up-status <UP-ID>
```

5. Verify that the UP has state `INITIALIZED`.

6. Set the UP/CSP upgrade execution method to `ONE-STEP`, `ROLLING`, or `BALANCED`:

```
cmw-swm --up-execmethod <UP_ID> one-step | rolling | <role-name> <min-size-of-role> <min-remaining-capacity>
```

Command `cmw-swm --up-execmethod <UP-ID>` (without execution method arguments) can also be used to view the upgrade execution method configured for the UP/CSP.

7. Prepare the ME for the activation of the UP/CSP with `<UP-ID>`:

```
cmw-swm --up-prepare <UP-ID>
```

The prerequisite of this action is that the state of the UP/CSP is `INITIALIZED`. This step is considered completed when the state of the UP/CSP is `PREPARE_COMPLETED`.

8. Activate the UP/CSP step by step or all at once:

```
cmw-swm --up-activate <UP-ID>
```

If the UP/CSP is designed with more than one step and `ignoreBreakpoints` is set to `false`, action `Activate` is called several times.

9. Verify that the upgrade procedure is completed:

```
cmw-swm --up-confirm <UP-ID>
```



The expected state is `COMMIT_COMPLETED`.

10. Delete the UP/CSP MO given as action parameter:

```
cmw-swm --up-remove <UP-ID>
```

This command also deletes all files temporarily stored in the ME and associated with the UP/CSP.

During consuming of the CSP 1.2 or above where the campaign is generated automatically, multiple campaigns are sometimes generated. If this occurs, the preparation of the CSP fails with the following status:

```
Action: Prepare - FINISHED  
Result: FAILURE - Unsupport multiple tcg campaigns yet  
State: INITIALIZED
```

ECIM SwM does not support multiple campaigns, so the `cmw-ait-install` command is provided for the Automatic Installation Tool (AIT) to continue consuming this package at installation time:

```
cmw-ait-install [--status] | [--disable-backup]  
<CSP-package>
```

```
cmw-ait-install [--status] | [--disable-backup] <CSP-ID>
```

**Note:** This command is only to be executed to the CSP that has just failed the prepare phase with the above status.



Table 6 Command Options

Option	Description	Example
<code>--disable-backup</code>	By default, a backup is automatically created before consuming the package. This option is to disable the backup creation.	<p>Check the CSP status: \$  <b>cmw-swm --up-status cba.test-CXP123456-1.0.0</b>  Output:  Action: Prepare -  FINISHED  Result: FAILURE -  Unsupport multiple tcg campaigns yet  State: INITIALIZED</p> <p>Continue the CSP: \$  <b>cmw-ait-install --disable-backup cba.test-CXP123456-1.0.0</b></p>
<code>--status</code>	<p>Get state of specific CSP ID, track the progress and result of actions.</p> <p>Output format:  State: &lt;CSP-state&gt;  Action: &lt;action-name&gt;  Additional Info:  [Additional information of the current state, if applicable]  Result: &lt;action-result&gt;  Result Info:  [Information about result, if applicable]</p>	<p>Check the AIT installation status: \$  <b>cmw-ait-install --status cba.test-CXP123456-1.0.0</b>  Output:  State: RUNNING  Action: PREPARING  Additional Info:  Generating campaigns from CSM model  Result: NOT_AVAILABLE  Result Info:</p>

## 5.7 Configure ISP Events for Cluster Restarts

ISP events for cluster restarts are disabled by default.

This feature can be enabled or disabled during AIT installation of Core MW. For more information, see Section *Automatically Installing Core MW by Using AIT in Core MW SW Installation*.

ISP events for cluster restarts can be enabled in runtime with the `cmw-utility` command as follows:



```
cmw-utility immcfg --attribute ispClusterRebootLogEnabled=
1 CmwMonitorIspId=1,CmwMonitorId=1,CmwSysConfigId=1
```

ISP events for cluster restarts can be enabled within a campaign by setting attribute `ispClusterRebootLogEnabled` of object with class type `CmwMonitorIsp` to 1.

An example of a campaign Init section that enables ISP events for cluster restarts by setting attribute `ispClusterRebootLogEnabled` to 1 is shown in Example 60.

```
<campInitAction>
  <immCCB ccbFlags="0">
    <modify objectDN="CMW_GETDN(^CmwMonitorIspId=1,CmwMonitorId=1,⇒
CmwSysConfigId=1$)" operation="SA_IMM_ATTR_VALUES_MODIFY">
      <attribute name="ispClusterRebootLogEnabled" type="SA_IMM_ATTR_SAUINT32T">
        <value>1</value>
      </attribute>
    </modify>
  </immCCB>
</campInitAction>
```

**Example 60** *ISP Events for Cluster Restarts*

**Note:** In order for cluster restart events to be visible in the ISP report, the Core MW `ISP_REPORT` feature must also be enabled, as described in Section 3.10.4 In-Service Performance Report Feature on page 19.

## 5.8 Configure Reboot Behavior of Single-Step Procedures

SMF single-step procedures are typically used for installation (or removal) of components/applications where a component/application is not in-service upgradeable. If a single-step upgrade procedure contains software bundles, which require a reboot to install or remove, SMF can either perform a cluster reboot or perform nodewise reboot of only the affected nodes.

The default SMF behavior is to perform nodewise reboot during single-step upgrade procedures.

To define the affected nodes for nodewise reboot, the `campaign.xml` file must specify them in the `<singleStepUpgrade>` section, as shown in Example 61.

```
<singleStepUpgrade>
  <upgradeScope>
    <forAddRemove>
      <deactivationUnit>
        <actedOn>
          <byName objectDN="safAmfNode=SC-2,safAmfCluster=myAmfCluster"/>
        </actedOn>
      </deactivationUnit>
      <activationUnit>
        <actedOn>
          <byName objectDN="safAmfNode=SC-2,safAmfCluster=myAmfCluster"/>
        </actedOn>
      </activationUnit>
    </forAddRemove>
  </upgradeScope>
</singleStepUpgrade>
```

**Example 61** *Campaign Defining Affected Nodes for Single-Step Upgrade Procedures*

Attribute `smfSSAffectedNodesEnable` of the SMF configuration controls the nodewise reboot feature and defaults to 1. To change SMF behavior to reboot



all nodes in the cluster during a single-step upgrade procedure, a campaign must disable nodewise reboot, as shown in Example 62.

```
<campWrapupAction>
  <immCCB ccbFlags="0">
    <modify operation="SA_IMM_ATTR_VALUES_REPLACE" objectDN="smfConfig=1,safApp=safSmfService">
      <attribute name="smfSSAffectedNodesEnable" type="SA_IMM_ATTR_SAUINT32T">
        <value>0</value>
      </attribute>
    </modify>
  </immCCB>
</campWrapupAction>
```

**Example 62** Campaign Disabling Nodewise Reboot Feature

## 5.9 Configure Remote Fencing Parameters

All RF parameters are configured within the RF plug-in. For more information on RF plug-ins, refer to Section *Remote Fencing in Core MW Programmer's Guide*.

### 5.9.1 OpenSAF Parameters

Table 7 describes the OpenSAF fencing parameters.

**Table 7** OpenSAF Fencing Parameters

Parameter	Description	Example
FMS_NODE_ISOLATION_TIMEOUT	Enable self-fencing set value to non-zero value. Unit in milliseconds.	Export FMS_NODE_ISOLATION_TIMEOUT=10
FMS_PROMOTE_ACTIVE_TIMER	The Promote active timer is set to delay the Standby controllers reboot request, as the Active controller also requests reboot of the standby. The resolution is in 10 ms units.	Export FMS_PROMOTE_ACTIVE_TIMER=300
FMS_USE_REMOTE_FENCING	Enable remote fencing.	Export FMS_USE_REMOTE_FENCING=1
FMS_FENCE_CMD	Fencing command.	Export FMS_FENCE_CMD="stonith"
FMS_DEVICE_TYPE	Fencing device type.	Export FMS_DEVICE_TYPE="external/libvirt"
FMS_HYPERVISOR_URI	Connection URI to hypervisor host machine.	Export FMS_HYPERVISOR_URI="qemu+tcp://192.168.122.1/system"
FMS_FENCE_ACTION	Fence action.	Export FMS_FENCE_ACTION="reset"



## 5.9.2 Core MW Parameters

Table 8 describes the Core MW RF parameters.

*Table 8 Core MW RF Parameters*

Parameter	Description	Example
FMS_USE_REMOTE_FENCING	Enable remote fencing.	Export FMS_USE_REMOTE_FENCING=1
RF_NAME	Remote fencing plug-in name.	Export RF_NAME="FENCING_STONITH-CXP9010009_1"
RF_VERSION	Remote fencing plug-in version.	Export RF_VERSION="R1A01"
TARGET_PLUGIN	Full path location to target.<plugin> file.	Export TARGET_PLUGIN="/cluster/home/fencingtest/target.FENCING_STONITH-CXP9010009_1-R1A01"



## 6 Performance Management

PM jobs can be created, modified, deleted, started, and stopped programmatically using the IMM Object Management (OM) API.

This section describes the following shell command support for managing ECIM PM Jobs:

- Creating an ECIM PM Job
- Starting an ECIM PM Job
- Stopping an ECIM PM Job
- Deleting an ECIM PM Job
- Reporting status of an ECIM PM Job
- Listing ECIM PM Jobs
- Modifying an ECIM PM Job

This section also describes the following PM operation:

- Displaying active PM values for an instance

Commands are to be run as root user or prefixed with `sudo` and run by a user belonging to the `system-adm` group.

### 6.1 Create ECIM PM Job

To create an ECIM PM Job, use the `cmw-pmjob-create` command.

The command syntax is as follows:

```
cmw-pmjob-create <job-name>
                  (-u <pmgroup-id>
                  [-M <meas-reader>]
                  [-R <variation-rate>]
                  [-d <threshold-direction>]
                  [(-I <mo-instance>...)]
                  [-m <meas-type>]
                  [-T <threshold-id>
                  -H <threshold-high>
                  -L <threshold-low>
                  -S <severity>]
                  ) ...
                  [-t <job-type>]
```



```

[-r <reporting-period>]
[-g <granularity-period>]
[-p <job-priority>]
[-q <requested-state>]
[-c <job-control>]

```

The syntax is interpreted as follows:

- `job-name` is attribute `pmJobId` in the `PmJob` MO.
- `pmgroup-id` is the MO class (`moClass`) name of the Measurement Type (MT).
- `meas-type` is the MT.
- The part within ( ) can occur multiple times, as indicated with three dots.

The command supports any number of Measurement Readers (MRs) and Measurement Specifications (MSs).

For threshold jobs, up to four thresholds object are supported.

The MS can use a direct reference to an MT or use an indirect reference by referring to a `moClass`.

A direct reference to an MT occurs when the `moClass` (option `-u`) and the MT (option `-m`) are specified for the MR.

An indirect reference to a group occurs when only the `moClass` (option `-u`) is specified for the MR. However, indirect references are only valid for measurement jobs (`-t 1`), not for threshold jobs (`-t 2`).

The optional parameters for threshold jobs are as follows:

- `-T <threshold-id>`
  - `-H <threshold-high>`
  - `-L <threshold-low>`
  - `-S <severity>`
    - 3 – CRITICAL
    - 4 – MAJOR
    - 5 – MINOR (default value)
    - 6 – WARNING
- `-R <variation-rate>`
  - 0 – PER\_SECOND (default value)
  - 1 – PER\_GP

**Note:** Only used for Cumulative Counter (CC) collection method.

- `-d <threshold-direction>`
  - 1 – INCREASING



- 2 – DECREASING

The optional Job parameters are as follows:

- `-i <mo-instance>`

A specific MT instance to be referenced. If not specified, all MT instances are referenced. It supports any number of instance parameters. The format is as follows: `-i <instance1> -i <instance2> -i <instance3>`.

- `-t <job-type>`
  - 1 – MEASUREMENTJOB (default value)
  - 2 – THRESHOLDJOB
- `-r <reporting-period>`
  - 3 – 1 minute
  - 4 – 5 minutes
  - 5 – 15 minutes (default value)
  - 6 – 30 minutes
  - 7 – 1 hour
  - 8 – 12 hours
  - 9 – 24 hours
- `-g <granularity-period>`
  - 3 – 1 minute
  - 4 – 5 minutes
  - 5 – 15 minutes (default value)
  - 6 – 30 minutes
  - 7 – 1 hour
  - 8 – 12 hours
  - 9 – 24 hours
- `-p <job-priority>`
  - 1 – LOW
  - 2 – MEDIUM (default value)
  - 3 – HIGH
- `-q <requested-state>`
  - 1 – ACTIVE (default value)
  - 2 – STOPPED
- `-c <job-control>`
  - 0 – FULL (default value)
  - 1 – STARTSTOP
  - 2 – VIEWONLY
- `-G <job-group>`
- `-x <compression-type>`



– 0 – GZIP

The creation of an ECIM PM Job named `job3`, which directly references MT `rxOctets` in `moClass mocRx` is shown in Example 63.

```
SC-1:~ # cmw-pmjob-create job3 -u mocRx -m rxOctets
PM job job3 created
SC-1:~ #
```

**Example 63** *Creating an ECIM PM Job*

The command returns exit code 0 on success, otherwise exit code 1.

Attempting to create an ECIM PM Job without first defining the MT or `moClass` results in failure, as shown in Example 64.

```
SC-1:~ # cmw-pmjob-create job4 -u mocTx -m txOctets
Creating job job4...
Failed to apply object creations 21
CMW: ERROR (cmw-pmjob-create): Job creation from command line failed.
SC-1:~ #
```

**Example 64** *Failed Attempt to Create an ECIM PM Job*

How to create an ECIM PM Job that references an MT indirectly by the `moClass mocRxRate` (by not specifying option `-m`) is shown in Example 65.

```
SC-1:~ # cmw-pmjob-create job4 -u mocRxRate
PM job job4 created.
SC-1:~ #
```

**Example 65** *Creating an ECIM PM Job That Indirectly References an MT*

Multiple MT references can be applied to the same job, as shown in Example 66.

```
SC-1:~ # cmw-pmjob-create job5 -u mocRx
                                -m rxDiscFr
                                -T rxDiscAlm
                                -H 300 -L 250 -S 3
                                -u mocRxRate
                                -m rxRate
                                -T rxRateOversub
                                -H 600 -L 550 -S 3
                                -T rxRateHigh
                                -H 400 -L 350 -S 4
                                -T rxRateBusy
                                -H 200 -L 150 -S 6
                                -t 2

PM job job5 created.
SC-1:~ #
```

**Example 66** *Creating an ECIM PM Job with Multiple MTs*



job5 is defined as a threshold type job (flag -t is set to 2), as shown in Example 66.

job5 contains two MR references that can be described as follows:

- The first MR directly references an MT named `rxDiscFr` in `moClass mocRx`. It defines a `PmThresholdMonitoring` threshold named `rxDiscAlm` of severity class 3 (CRITICAL). The high threshold is set to 300 and the low threshold is set to 250.
- The second MR directly references an MT named `rxRate` in the `moClass mocRxRate`. It defines three `PmThresholdMonitoring` thresholds (`rxRateOversub`, `rxRateHigh`, and `rxRateBusy`), each with an assigned severity and threshold levels.

Attribute `job-control` is optional. Defaults to `FULL`, which means that the job can be started, stopped, or deleted.

PMJob2 in Example 67 is defined as a measurement job, which has `job-control` as 1 (`STARTJOB`).

```
SC-1:~ # cmw-pmjob-create PMJob2 -u PMGroup-1
                                     -t 1 -r 3 -g 3
                                     -p 3 -q 2 -c 1
SC-1:~ #
```

*Example 67 Creating an ECIM PM Job with Start Stop Control*

## 6.2 Start ECIM PM Job

To start an ECIM PM Job, use the `cmw-pmjob-start` command.

**Note:** The precondition is that `job-control` is `FULL` or `STARTSTOP`.

The command syntax is as follows:

```
cmw-pmjob-start <job-name>
```

The syntax is interpreted as follows:

- `job-name` is attribute `pmJobId` in the `PmJob MO`.

```
SC-1:~ # cmw-pmjob-start TC-CMW-PM-JOB-CMD-START
PM Job TC-CMW-PM-JOB-CMD-START Started.
SC-1:~ #
```

*Example 68 Starting an ECIM PM Job*

The command returns exit code 0 on success, otherwise exit code 1.

A failure to start an ECIM PM Job whose `job-name` does not exist is shown in Example 69.



```
SC-1:~ # cmw-pmjob-start TC-CMW-PM-JOB-CMD-START_non-exist
CMW: ERROR (cmw-pmjob-start): PM Job =>
TC-CMW-PM-JOB-CMD-START_non-exist does not exist
SC-1:~ #
```

#### *Example 69 Starting a Non-Existing ECIM PM Job*

Attempting to start an already started ECIM PM Job results in exit code 0 with the following message:

```
Warning: PM Job <job-name> is already Active
```

## 6.3 Stop ECIM PM Job

To stop an ECIM PM Job, use the **cmw-pmjob-stop** command.

**Note:** The precondition is that `job-control` is `FULL` or `STARTSTOP`.

The command syntax is as follows:

```
cmw-pmjob-stop <job-name>
```

The syntax is interpreted as follows:

- `job-name` is attribute `pmJobId` in the `PmJob` MO.

```
SC-1:~ # cmw-pmjob-stop TC-CMW-PM-JOB-CMD-STOP
PM job TC-CMW-PM-JOB-CMD-STOP stopped.
SC-1:~ #
```

#### *Example 70 Stopping an ECIM PM Job*

The command returns exit code 0 on success, otherwise exit code 1.

Attempting to stop an already stopped ECIM PM Job results in exit code 0 with the following message:

```
Warning: PM Job <job-name> is already Stopped
```

## 6.4 Delete ECIM PM Job

To delete a stopped ECIM PM Job, use the **cmw-pmjob-delete** command.

**Note:** The precondition is that `job-control` is `FULL`.

The command syntax is as follows:

```
cmw-pmjob-delete <job-name>
```



The syntax is interpreted as follows:

- `job-name` is attribute `pmJobId` in the `PmJob` MO.

```
SC-1:~ # cmw-pmjob-delete TC-CMW-PM-JOB-CMD-CC-ECIM-001
PM job TC-CMW-PM-JOB-CMD-CC-ECIM-001 deleted.
SC-1:~ #
```

#### *Example 71 Deleting an ECIM PM Job*

The command returns exit code 0 on success, otherwise exit code 1.

Attempting to delete an ACTIVE ECIM PM Job results in exit code 1 with the following message:

```
CMW: ERROR (cmw-pmjob-delete): PM Job <job-name> is
Active - can not be deleted
```

Attempting to delete a non-existent ECIM PM Job results in exit code 1 with the following message:

```
CMW: ERROR (cmw-pmjob-delete): PM Job <job-nam
e> does not exist
```

## 6.5 Report Status of ECIM PM Job

To report the status of an ECIM PM Job, use the `cmw-pmjob-status [-v] <job-name>` command.

The command syntax is as follows:

```
cmw-pmjob-status [-v] <job-name>
```

The syntax is interpreted as follows:

- `job-name` is attribute `pmJobId` in the `PmJob` MO.
- The optional `-v` flag produces a verbose output. Omitting the `-v` flag only produces the job name and status.

```
SC-1:~ # cmw-pmjob-status TC-CMW-PM-JOB-CMD-STATUS-2
PM job TC-CMW-PM-JOB-CMD-STATUS-2 is active
SC-1:~ #
```

#### *Example 72 Reporting Status of an ECIM PM Job*



```
SC-1:~ # cmw-pmjob-status -v TC-CMW-PM-JOB-CMD-STATUS-2
Name                                     Value(s)
=====
pmJobId                                TC-CMW-PM-JOB-CMD-STATUS-2
jobType                                Measurement(0x1)
granularityPeriod                       1 minute(0x3)
reportingPeriod                         1 minute(0x3)
jobPriority                             High(0x3)
requestedJobState                       Active(0x1)
currentJobState                         Active(0x1)
Overall Job State                       Active(0x1)
SC-1:~ #
```

*Example 73 Reporting Status of an ECIM PM Job Using Verbose Mode*

If the job does not exist or if the status cannot be shown, the command returns exit code 1 and logs the following message:

```
CMW: ERROR (cmw-pmjob-status): Could not show the
status for PM Job <job-name>
```

Otherwise the command returns exit code 0.

## 6.6 List ECIM PM Jobs

To list ECIM PM Jobs, use the `cmw-pmjob-list` command.

The command syntax is as follows:

```
cmw-pmjob-list [<options>]
```

The possible options are as follows (<N> is a numeral):

- `-v` – Use long format for each job.
- `-h` | `--help` – Display this help and exit.
- `-f` – List only jobs with problems (faulty).
- `-r <N>` – List only jobs with this reporting period.
- `-t <N>` – List only jobs with this job type.
- `-p <N>` – List only jobs with this job priority.
- `-g <N>` – List only jobs with this granularity period.
- `-q <N>` – List only jobs with this requested job state.
- `-s <N>` – List only jobs with this current job state.

Using the command without any options results in a short listing, showing each ECIM PM Job name, requested job state, and current job state, as shown in Example 74.



```
SC-1:~ # cmw-pmjob-list
pmJobId=TCPMJCA_0, requestedJobState=Stopped(0x2), currentJobState=Stopped(0x2)
pmJobId=TCPMJCA_1, requestedJobState=Active(0x1), currentJobState=Active(0x1)
pmJobId=TCPMJCA_2, requestedJobState=Stopped(0x2), currentJobState=Stopped(0x2)
pmJobId=TCPMJCA_3, requestedJobState=Active(0x1), currentJobState=Active(0x1)
pmJobId=TCPMJCA_4, requestedJobState=Stopped(0x2), currentJobState=Stopped(0x2)
SC-1:~ #
```

#### Example 74 Listing ECIM PM Jobs

The command contains a `-v` flag for verbose (long format). The output contains detailed information about each ECIM PM Job, as shown in Example 75.

```
SC-1:~ # cmw-pmjob-list -v
Name                               Value(s)
=====
pmJobId                            Job1
jobType                            Measurement(0x1)
granularityPeriod                   15 minutes(0x5)
reportingPeriod                     5 minutes(0x4)
jobPriority                         Medium(0x2)
requestedJobState                   Active(0x1)
currentJobState                    Active(0x1)
Overall Job State                  Active(0x1)
Name                               Value(s)
=====
pmJobId                            Job2
jobType                            Threshold(0x2)
granularityPeriod                   15 minutes(0x5)
reportingPeriod                     1 minute(0x3)
jobPriority                         Medium(0x2)
requestedJobState                   Active(0x1)
currentJobState                    Active(0x1)
Overall Job State                  Active(0x1)
Name                               Value(s)
=====
pmJobId                            Job3
jobType                            Threshold(0x2)
granularityPeriod                   15 minutes(0x5)
reportingPeriod                     1 hour(0x7)
jobPriority                         Medium(0x2)
requestedJobState                   Active(0x1)
currentJobState                    Active(0x1)
Overall Job State                  Active(0x1)
SC-1:~ #
```

#### Example 75 Listing ECIM PM Jobs Using Verbose Mode

Multiple options can be combined in one command to **OR** the result. For example, using multiple options on the same job list as in Example 75, jobs with `reportingPeriod` equal to 1 minute and `jobType` equal to `Measurement` can be shown. A filtered list using multiple options is shown in Example 76.



```

SC-1:~ # cmw-pmjob-list -v -r 3 -t 1
Name                               Value(s)
=====
pmJobId                            Job1
jobType                            Measurement(0x1)
granularityPeriod                   15 minutes(0x5)
reportingPeriod                     5 minutes(0x4)
jobPriority                         Medium(0x2)
requestedJobState                   Active(0x1)
currentJobState                     Active(0x1)
Overall Job State                   Active(0x1)
Name                               Value(s)
=====
pmJobId                            Job2
jobType                            Threshold(0x2)
granularityPeriod                   15 minutes(0x5)
reportingPeriod                     1 minute(0x3)
jobPriority                         Medium(0x2)
requestedJobState                   Active(0x1)
currentJobState                     Active(0x1)
Overall Job State                   Active(0x1)
SC-1:~ #

```

**Example 76** Listing ECIM PM Jobs Using Multiple Options

Multiple options can be used in short format (without flag -v), as shown in Example 77.

```

SC-1:~ # cmw-pmjob-list -r 3 -t 1 -g 5
pmJobId=Job2, requestedJobState=Active(0x1), =>
currentJobState=Active(0x1), reportingPeriod=3
pmJobId=Job1, requestedJobState=Active(0x1), =>
currentJobState=Active(0x1), jobType=1
pmJobId=Job1, requestedJobState=Active(0x1), =>
currentJobState=Active(0x1), granularityPeriod=5
pmJobId=Job2, requestedJobState=Active(0x1), =>
currentJobState=Active(0x1), granularityPeriod=5
pmJobId=Job3, requestedJobState=Active(0x1), =>
currentJobState=Active(0x1), granularityPeriod=5
SC-1:~ #

```

**Example 77** Listing ECIM PM Jobs in Short Format with Multiple Flags

## 6.7 Modify ECIM PM Job

To modify a stopped ECIM PM Job, use the `cmw-pmjob-modify` command.

The command syntax is as follows:

```

cmw-pmjob-modify <job-name> <added-MOs> / <deleted-MOs> |
<modified-attributes>

```



Syntax when adding MeasurementReader MOs:

```
cmw-pmjob-modify <job-name>
    [ (-C
        [-M <meas-reader>]
        [-R <threshold-rate-of-variation>]
        [-d <threshold-direction>]
        [(-i <mo-instance>...)]
        -u <pmgroup-id>
        [-m <meas-type>]
    ) ...]
```

Syntax when adding PmThresholdMonitoring MOs:

```
cmw-pmjob-modify <job-name>
    [ (-C
        [-M <meas-reader>]
        (-T <threshold-id>
            -H <threshold-high>
            -L <threshold-low>
            -S <severity>)
    ) ...]
```

Syntax when adding both MeasurementReader and PmThresholdMonitoring MOs:

```
cmw-pmjob-modify <job-name>
    [ (-C
        [-M <meas-reader>]
        [-R <threshold-rate-of-variation>]
        [-d <threshold-direction>]
        [(-i <mo-instance>...)]
        -u <pmgroup-id>
        -m <meas-type>
        (-T <threshold-id>
            -H <threshold-high>
            -L <threshold-low>
            -S <severity>)
    ) ...]
```

Syntax when deleting MOs:

```
cmw-pmjob-modify <job-name>
    [ (-D
        -M <meas-reader>
        [-T <threshold-id>]
    ) ...]
```

Syntax when modifying attributes:

```
cmw-pmjob-modify <job-name>
    [-r <reporting-period>]
```



```

[-g <granularity-period>]
[-p <job-priority>]
[-G <job-group>]
[-x <compression-type>]

```

This command requires `-C` to indicate child MO creation, and `-D` to indicate child MO deletion. All the other options have the same meanings as with the `cmw-pmjob-create` command, see Section 6.1 Create ECIM PM Job on page 51. The parts within `()` can occur multiple times.

The addition of a `MeasurementReader` MO to an existing job named `job3` is shown in Example 78.

```

SC-1:~ # cmw-pmjob-modify job3 -C -u mocRx -m rxOctets
Modifying job job3...
PM job job3 modified.
SC-1:~ #

```

**Example 78** Adding a `MeasurementReader` MO to an Existing ECIM PM Job

The command returns exit code 0 on success, otherwise exit code 1.

The addition of both a `MeasurementReader` MO and its child `PmThresholdMonitoring` MO to an existing threshold job named `job5` is shown in Example 79.

```

SC-1:~ # cmw-pmjob-modify job5 -C -M mrRxRate -u mocRxRate -m rxRate =>
-T rxRateOversub -H 50 -L 45 -S 3
Modifying job job5...
PM job job5 modified.
SC-1:~ #

```

**Example 79** Adding a `MeasurementReader` MO and its Child `PmThresholdMonitoring` MO to an Existing ECIM PM Job

The addition of a `PmThresholdMonitoring` MO to an existing `MeasurementReader` MO of an existing job named `job5` is shown in Example 80. As the `PmThresholdMonitoring` MO is a child of a `MeasurementReader` MO, parameter `-M` must be specified.

```

SC-1:~ # cmw-pmjob-modify job5 -C -M mrRxRate -T rxRateOversub -H 50 =>
-L 45 -S 3
Modifying job job5...
PM job job5 modified.
SC-1:~ #

```

**Example 80** Adding a `PmThresholdMonitoring` MO to an Existing `MeasurementReader` MO

The deletion of a `MeasurementReader` MO from an existing job named `job3` is shown in Example 81.



```
SC-1:~ # cmw-pmjob-modify job3 -D -M mrRxRate
Modifying job job3...
PM job job3 modified.
SC-1:~ #
```

**Example 81** *Deleting a MeasurementReader MO from an Existing ECIM PM Job*

The deletion of a `PmThresholdMonitoring` MO from an existing threshold job named `job5` is shown in Example 82. Parameter `-M` must be specified.

```
SC-1:~ # cmw-pmjob-modify job5 -D -M mrRxRate -T rxRateOversub
Modifying job job5...
PM job job5 modified.
SC-1:~ #
```

**Example 82** *Deleting a PmThresholdMonitoring MO from an Existing ECIM PM Job*

Modifying one or more ECIM PM Job attributes for an existing job named `job3` is shown in Example 83.

```
SC-1:~ # cmw-pmjob-modify job3 -p 2 -x 0 -G group1
Modifying job job3...
PM job job3 modified.
SC-1:~ #
```

**Example 83** *Modifying Attributes for an Existing ECIM PM Job*

## 6.8 Display Active PM Values for an Instance

To display active PM values for a specified instance, use the command `cmw-pm-show-counters`. The command displays the current value of all MTs associated with a specified instance.

**Note:** The precondition is that the instance is associated with the MTs that are measured by an active ECIM PM Job.

The command syntax is as follows:

```
cmw-pm-show-counters [-v] <instance>
                        [-t <timeout>]
                        [-j <job-name> [<job-name>...]]
                        [-m <meas-type> [<meas-type>...]]
```

The syntax is interpreted as follows:

- `-v` | `--verbose` is verbose.
- `-t` | `--timeout` <seconds> is the time-out. Defaults to 6 seconds.
- `job-name` is attribute `pmJobId` of an active `PmJob` MO. If job names are specified, only instance values from the specified jobs are displayed.



- `meas-type` is attribute `measurementTypeId` of a `MeasurementType` MO. If MTs are specified, only instance values associated with the specified MTs are displayed.

The command returns exit code 0 on success, otherwise exit code 1.

```
cmw-pm-show-counters MeasObj=1
    intCounterActive=123 SUSPECT
    multivalueIntCounter=12,14,16
```

*Example 84 Displaying Current Instance Values*

```
cmw-pm-show-counters -v MeasObj=1
    intCounterActive=123 PmJob=1 Gp=5 min SUSPECT
    multivalueIntCounter=12,14,16 PmJob=1 Gp=5 min
```

*Example 85 Displaying Verbose Current Instance Values*



## 7 OpenSAF Tools

### 7.1 OpenSAF Tools Wrapper

The `cmw-utility` command can be used to run the following OpenSAF tools:

- `immfind`
- `immlist`
- `immcfg`
- `immadm`
- `amfadm`
- `runasroot`

The command syntax is as follows:

```
cmw-utility [-h | --help] <immfind | immlist | immcfg |  
immadm | amfadm | runasroot> [<options>]
```

The syntax is interpreted as follows:

- `-h | --help` – Print help menu.
- `options` – See the following sections for the individual OpenSAF tools.

#### 7.1.1 **immfind**

`immfind` is used for searching for IMM objects.

The command syntax is as follows:

```
cmw-utility immfind [path...] [<options>]
```

The options are as follows:

- `-c | --class <name>` – Only search for objects of the specified class.
- `-t | --timeout <timeout>` – Utility time-out in seconds.

```
cmw-utility immfind --class SaAmfCluster
```

*Example 86 Searching for IMM Objects*

### 7.1.2 immlist

`immlist` is used for listing IMM objects.

The command syntax is as follows:

```
cmw-utility immlist [<options>] <object-name> [<object-name>...]
```

```
cmw-utility immlist [<options>] <class-name>
```

The options are as follows:

- `-a | --attribute <name>` – Attribute name to print.
- `-c | --class <name>` – Class definition to print.
- `-t | --timeout <timeout>` – Utility time-out in seconds.

```
cmw-utility immlist safAmfCluster=myAmfCluster
cmw-utility immlist --attribute SaImmAttrClassName =>
CmwMonitorId=1,CmwSysConfigId=1
cmw-utility immlist --class CmwMonitor
```

*Example 87 Listing IMM Objects*

### 7.1.3 immcfg

`immcfg` is for creating, deleting, or modifying IMM objects.

The command syntax is as follows:

```
cmw-utility immcfg ([<options>] [<object-name>])...
```

The options are as follows:

- `-a | --attribute <name>[+|-]=<value>` – Change attribute.
- `-c | --create-object <class-name>` – Create an object of the specified class.
- `-d | --delete-object [<object-name>]...` – Delete objects.
- `-m | --modify-object [<object name>]...` – Modify objects.
- `-u | --unsafe` – The CCBs generated by `immcfg` have `SA_IMM_CCB_REGISTERED_OI` set to false, allowing CCB commit when Object Implementers (OIs) are missing.
- `-t | --timeout <timeout>` – Utility time-out in seconds.



```
cmw-utility immcfg --create-object CmwPmPmJob =>
pmJobId=CmwUtilityTestJobObj, CmwPmpmId=1
```

#### *Example 88 Creating IMM Objects*

```
cmw-utility immcfg --attribute requestedJobState=2 =>
CmwPmPmJob pmJobId=CmwUtilityTestJobObj, CmwPmpmId=1
```

#### *Example 89 Changing IMM Objects*

```
cmw-utility immcfg --delete-object =>
pmJobId=CmwUtilityTestJobObj, CmwPmpmId=1
```

#### *Example 90 Deleting IMM Objects*

### 7.1.4

#### **immadm**

immadm is used for performing an IMM admin operation.

The command syntax is as follows:

```
cmw-utility immadm [<options>] [<object-name>...]
```

The options are as follows:

- `--disable-tryagain` – Disable try again handling. Defaults to no.
- `-o | --operation-id <id>` – Numerical operation ID.
- `-p | --parameter=<p>` – Parameter/parameters to admin operation.

Parameter syntax: `<name>:<type>:<value>`

Value types according to `imm.xsd`: `SA_INT32_T`, `SA_UINT32_T`, `SA_INT64_T`, `SA_UINT64_T`, `SA_TIME_T`, `SA_NAME_T`, `SA_FLOAT_T`, `SA_DOUBLE_T`, `SA_STRING_T`.

- `-t | --timeout <timeout>` – Utility time-out in seconds.

```
cmw-utility immadm --operation-id 1 =>
safJob=CmwUtilityTestJobObj, safPm=1
```

#### *Example 91 Performing an IMM Admin Operation*

### 7.1.5

#### **amfadm**

amfadm is used for performing an AMF admin operation.

The command syntax is as follows:

```
cmw-utility amfadm [<options>] <command> <object-name>
```



The options are as follows:

- `-s | --su` – Specified object DN is checked to be an SU before performing AMF admin operation.
- `-t | --timeout <timeout>` – Utility time-out in seconds.
- `<command>` – **lock, unlock, lock-in, unlock-in, shutdown, restart, si-swap, sg-adjust, repaired, eam-start, eam-stop.**

```
cmw-utility amfadm --su lock safSu=SC-1,safSg=2N,⇒  
safApp=ERIC-CoreMW  
cmw-utility amfadm unlock safSu=SC-1,safSg=2N,⇒  
safApp=ERIC-CoreMW
```

*Example 92 Performing ADM Admin Operations*

## 7.1.6

### runasroot

`runasroot` is used for running a command with root privileges. It only supports the SMF service and must be called through SMF callbacks.

The command syntax is as follows:

```
cmw-utility runasroot <command>
```

For an example, refer to Section *Built-in SMF API Callback Receiver* in *Core MW Software Management*.



## 8 Backup and Restore Framework

For information about the Backup and Restore Framework, refer to *BRF-C Management Guide*.