

Storage Engine, Backup Fault In PLDB

Ericsson Centralized User Database

Operating Instructions

Copyright

© Ericsson AB 2016, 2018. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document *Trademark Information*.

Contents

1	Introduction	1
1.1	Alarm Description	1
1.2	Prerequisites	2
2	Procedure	3
	Glossary	4





1 Introduction

This instruction concerns alarm handling for the Storage Engine, Backup Fault In PLDB alarm.

1.1 Alarm Description

This alarm is issued when a backup procedure fails in a Processing Layer Data base (PLDB) Storage Engine during an Ericsson Centralized User Database (CUDB) system backup process or a PLDB backup process. For further information about the backup procedures, refer to [CUDB Backup and Restore Procedures](#).

The possible alarm causes and the corresponding fault reasons, fault locations, and impacts are described in [Table 1](#).

Table 1 Alarm Causes

Alarm Cause	Description	Fault Reason	Fault Location	Impact
Backup procedure fails.	A backup procedure fails in a PLDB Storage Engine during a CUDB system backup process or a PLDB backup process.	No connection to the PL cluster.	PL cluster.	No recent backup is available.
		Not possible to recover local information data from the PL cluster.		
		Not possible to generate data backup for a single cluster due to insufficient space.		
		No connection to the remote CUDB node where the local backup is generated or operated.		

The alarm attributes are listed and explained in [Table 2](#):

Table 2 Alarm Attributes

Attribute Name	Attribute Value
Auto Cease	No
Module	STORAGE-ENGINE
Error Code	5
Timestamp First	Date and time when the alarm was raised for the first time.
Repeated Counter	Number which indicates how many times the alarm was raised.
Timestamp Last	Date and time of the most recent alarm raised.
Resource ID	.1.3.6.1.4.1.193.169.1.1.5. <ND>
Alarm Model Description	Backup fault, Storage Engine.
Alarm Active Description	Storage Engine (PLDB): backup failed in node # <ND> .



Attribute Name	Attribute Value
ITU Alarm Event Type	processingErrorAlarm (4)
ITU Alarm Probable Cause	softwareProgramError (546)
ITU Alarm Perceived Severity	(4) - Major
Originating Source IP	Node IP where the alarm was raised.
Sequence Number	Number which indicates the order in which alarms were raised.

In [Table 2](#), the indicated variables are as follows:

- <ND> is the CUDB Node Identifier within the system.

For further information about attribute descriptions, refer to CUDB Node Fault Management Configuration Guide.

1.2 Prerequisites

This section provides information on the documents, tools and conditions that apply to the procedure.

1.2.1 Documents

This instruction references the following documents:

- CUDB Backup and Restore Procedures
- CUDB Node Fault Management Configuration Guide
- Operating System, Disk Usage Too High
- CUDB System Administrator Guide

1.2.2 Tools

Not applicable.

1.2.3 Conditions

Not applicable.



2 Procedure

If the alarm is raised, perform the following steps:

Steps

1. Check connections in the system.
2. Check the disk storage space in /home in the System Controllers (SCs). If there is not enough space, remove previous backups. If not possible, in this situation the Operating System, Disk Usage Too High alarm may be raised, so follow the instructions provided in Operating System, Disk Usage Too High.
3. Clear the alarm manually as described in CUDB Node Fault Management Configuration Guide.
4. Run the backup again. For further information, refer to CUDB Backup and Restore Procedures.
5. If the alarm is raised again, consult the next level of maintenance support. Further actions are outside the scope of this Operating Instruction.
6. If the alarm does not cease, contact the next level of maintenance support. Further actions are outside the scope of this Operating Instruction.



Glossary

For the terms, definitions, acronyms and abbreviations used in this document, refer to CUDB Glossary of Terms and Acronyms