

Change Administrator Account

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2015, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Change Administrator Account	1



Change Administrator Account



1 Description

This instruction describes how to change attributes in the specific Administrator account that is used for initial and recovery scenarios when authentication to regular Operation and Maintenance (O&M) accounts is inaccessible.

2 Procedure

2.1 Change Administrator Account

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - The user has sufficient access rights to perform the task, for example, the user has System Security Administrator role.
 - The user is familiar with the security policy of the organization.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.
 - The PasswordPolicy Managed Object (MO) is known.

Steps

1. Navigate to the AdministratorAccount MO, for example:

```
>dn ManagedElement=NODE06ST, SystemFunctions=1, SecM=1, UserManagement=1, LocalAuthenticationMethod=1, AdministratorAccount=la-admin
```

2. Enter Config mode:

```
(AdministratorAccount=la-admin)>configure
```

3. Set the AdministratorAccount attributes according to operators password policy, for example:

```
(config-AdministratorAccount=la-admin)>passwordMaxFailure=5
```



4. Commit the settings:

```
(config-AdministratorAccount=la-admin)>commit
```

5. Verify the settings:

```
(AdministratorAccount=la-admin)>show -v
```

The following is an example output:

```
AdministratorAccount=la-admin
administratorAccountId="la-admin"
lastLoginTime="" <read-only>
passwordChangedTime="" <read-only>
passwordFailureCountInterval=86400 <default>
passwordFailureTimes <read-only>
""

passwordHistoryLength=12 <read-only>
passwordMaxFailure=5
passwordMinLength=12 <read-only>
passwordQuality="ManagedElement=NODE06ST,⇒
SystemFunctions=1,SecM=1,UserManagement=1,⇒
LocalAuthenticationMethod=1,PasswordQuality=1"
```