

Add Active-Standby Geographical Redundancy to a Live SAPC

Ericsson Service-Aware Policy Controller

OPERATING INSTRUCTION

Copyright

© Ericsson España, S.A. 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.



Contents

1	Add Active-Standby Geographical Redundancy Description	1
1.1	Add Active-Standby Geographical Redundancy Prerequisites	1
2	Add Geographical Redundancy Procedure	3
2.1	Procedure in Mated SAPC (SAPC2)	3
2.2	Procedure in Live SAPC (SAPC1)	3
2.3	Start Mated SAPC (SAPC2) as Standby SAPC	5





1 Add Active-Standby Geographical Redundancy Description

This document describes how to add Active-Standby Geographical Redundancy to a live SAPC, that is, how to add a second cluster to a standalone system. It also describes how to make the introduction of the second cluster transparent from a network point of view. The second cluster can be installed on the same site where the standalone system is running, or it can be installed on a different site; this document assumes that a different location is used.

This document is valid for both PNF and VNF deployments. Any different depending on the type of deployment is explicit in the procedure.

1.1 Add Active-Standby Geographical Redundancy Prerequisites

The following sections describe the documents, conditions, and tools required before the procedure.

Documents

Before starting this procedure, ensure that you have read the following documents:

- Personal Health and Safety Information
- System Safety Information
- Application-specific documents describing the configuration to be used in the new SAPC.
- Active-Standby Geographical Redundancy Network Configuration Guide. This document describes the infrastructure requirements.

Check also the following documents:

- Active-Standby Geographical Redundancy User Guide

For the installation of the new cluster (required only on the new site, site 2):

- SAPC PNF Deployment Instruction, SAPC VNF Deployment Instruction for CEE, or SAPC VNF Deployment Instruction for VMware, respectively.





2 Add Geographical Redundancy Procedure

This section describes the installation procedure step-by-step. Some steps must be coordinated between the two clusters while others can be performed independently. If coordination is required, it is clearly stated in the relevant step.

2.1 Procedure in Mated SAPC (SAPC2)

1. Follow the installation instructions for the SAPC2 cluster contained in *SAPC PNF Deployment Instruction*, *SAPC VNF Deployment Instruction for CEE*, or *SAPC VNF Deployment Instruction for VMware*, respectively, to configure the Mated SAPC as non-preferred because live SAPC has to be configured as preferred.

Once the configuration is applied, the SAPC2 is in Initial State. That means that it is ready to be the Standby SAPC in a Active-Standby Geographical Redundancy, after the live SAPC has been configured as Active SAPC.

2.2 Procedure in Live SAPC (SAPC1)

1. For **PNF** deployments, add the replication template in BSP, following the **BSP 8100 Configuration** section in *SAPC PNF Deployment Instruction*.

2. Access to the <OAM-VIP> and then the SC-1.

```
InstallationServer:# ssh root@<OAM-VIP>
```

```
SC-<X>:# ssh root@SC-1
```

3. Copy the following file:

```
SC-1:# cp /cluster/storage/no-backup/adapt/adapt_cluster.cfg.pr  
ocessed /cluster/storage/no-backup/adapt/adapt_cluster.cfg
```

4. Update write permissions:

```
SC-1:# chmod u+w /cluster/storage/no-backup/adapt/adapt_clust  
er.cfg
```

5. Modify the **adapt_cluster.cfg** as follows:

- a. If provisioning VIP is not configured, add it in the **[Network]** section:

[Network]

PROV_IP =VIP-Provisioning VIP address for provisioning shared between the SAPC clusters. For further information, refer to



Active-Standby Geographical Redundancy Network Configuration Guide.

- b. If a new **ALB** is going to be used for replication, add the corresponding values in the **[Network]** section. For further details, refer to **Adapt Cluster Tool**.

Caution!

The creation of a new **ALB** for replication is only supported in **PNF** deployments.

- c. Add **[GeoRed]** section:

[GeoRed]

LOCAL_REP_VIP = VIP-Replication SAPC1. VIP address for data replication in the local cluster. For further information, refer to **Active-Standby Geographical Redundancy Network Configuration Guide**.

PEER_REP_IP = VIP-Replication SAPC2. VIP address for data replication in the remote cluster. For further information, refer to **Active-Standby Geographical Redundancy Network Configuration Guide**.

PREFERRED = 1 <This SAPC has to be configured as preferred>.

Note: The SAPC configured as preferred maintains the database to resolve some fault situations where is not possible to know which of the SAPC clusters holds the most up-to-date database.

6. Execute the customizing tool command.

— SC-1: # **adapt_cluster -f /cluster/storage/no-backup/adapt/adapt_cluster.cfg geored**

Once the tool finishes, the Geographical Redundancy configuration is applied.

7. To check that everything has been successful, the following file must contain the same info as **adapt_cluster.cfg**

— SC-1: # **cat /cluster/storage/no-backup/adapt/adapt_cluster.cfg.processed_expansion**

8. Once the configuration is applied, the SAPC1 is ready to become the Active SAPC in a Active-Standby Geographical Redundancy. Consider that SAPC1 arises several alarms (Policy Control, Geographical Redundancy Unable To



Reach Peer, DBS, NR, Synchronization Needed and DBS, NR, Connection Lost) until the SAPC2 becomes the Standby SAPC.

2.3 Start Mated SAPC (SAPC2) as Standby SAPC

1. To configure SAPC2 as Standby SAPC, follow the Start Active-Standby Geographical Redundancy procedure.