

# MtasLicenses, SIP Trunking AS Base License Absent

MTAS

OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2017, 2018. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Alarm Description</b>	<b>1</b>
<b>2</b>	<b>Procedure</b>	<b>2</b>
2.1	Handle MtasLicenses, SIP Trunking AS Base License Absent	2



MtasLicenses, SIP Trunking AS Base License Absent



# 1 Alarm Description

The alarm is raised when the SIP Trunking Basic services are enabled through the `mtasStAdministrativeState` attribute, but the license allowing use of the services is not available in the Network License Server (NeLS).

The alarm is cleared when a valid license is installed or when the `mtasStAdministrativeState` attribute is disabled.

For more information about licenses, refer to [License Management and MTAS Licenses](#).

Table 1 MtasLicenses, SIP Trunking AS Base License Absent Alarm Causes

Alarm Cause	Description	Fault Reason	Fault Location	Impact
The SIP Trunking AS Base license is not present.	MTAS is unable to get the license details from NeLS.	The NeLS server is unreachable, or the relevant license is unavailable, has expired, or is corrupted.	NeLS server	MTAS cannot handle SIP Trunking Basic services.
			TLS <sup>(1)</sup> configuration in the ME <sup>(2)</sup>	
			Possible IP network issue	
			DNS <sup>(3)</sup> server	
			Network interface	

(1) Transport Layer Security (TLS)

(2) Managed Element (ME)

(3) Domain Name System (DNS)

Table 2 MtasLicenses, SIP Trunking AS Base License Absent Alarm Attributes

Attribute Name	Attribute Value
Major Type	193
Minor Type	6619241
Managed Object Class	MtasLicenses
Managed Object Instance	MtasFunction.applicationName=MtasFunction,MtasLicenses.mtasLicenses=0
Specific Problem	MtasLicenses, SIP Trunking AS Base License Absent
Event Type	communicationsAlarm (2)
Probable Cause	m3100Unavailable(14)
Additional Text	No License found or License Server Not reachable or License expired or License Server in LOCKED mode
Perceived Severity	critical (3)
Additional Info	-



For more information about the alarm information, refer to [Handling Alarms](#).

## 2 Procedure

### 2.1 Handle MtasLicenses, SIP Trunking AS Base License Absent

#### Prerequisites

- This instruction references the following documents:
  - [Check Alarm Status](#)
  - [Data Collection Guideline for MTAS](#)
  - [License Management, Autonomous Mode Activated](#)
  - [License Management, Key File Fault](#)
  - [View License Information](#)
- No tools are required.
- The following conditions must apply:
  - The alarm is raised.
  - No ongoing maintenance activities are affecting the network or network elements.
  - The user has proper authority to handle configuration management of the network elements.
  - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

#### Steps

1. If there is a network-related alarm on the ME, act on it first.
2. If there is a [License Management, Autonomous Mode Activated](#) alarm on the ME, act on it.
3. If there is a [License Management, Key File Fault](#) alarm on the ME, act on it.
4. Check if a valid `vMtasSTBaseCapacity` license (CXC4012234) is installed. For more information, refer to [View License Information](#).



5. If no license is present, or if the granted status of the license is false, and expiration shows an already elapsed date, proceed with Step 8.
6. Check the alarm status, refer to [Check Alarm Status](#). Is the alarm still active?  
  
Yes: Continue with the next step.  
  
No: Proceed with Step 9.
7. Perform data collection using Data Collection Tool with a Full profile. For more information, refer to [Data Collection Guideline for MTAS](#).
8. Consult the next level of maintenance support. Further actions are outside the scope of this instruction.
9. Job is completed.