

# MtasMmt, Business Line AS Base License Absent

MTAS

OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2017, 2018. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Alarm Description</b>	<b>1</b>
<b>2</b>	<b>Procedure</b>	<b>2</b>
2.1	Handle MtasMmt, Business Line AS Base License Absent	2



MtasMmt, Business Line AS Base License Absent



# 1 Alarm Description

The alarm is raised when a valid Business Line (BL) voice base license is not available in the Network License Server (NeLS) and the following conditions apply:

- The MMTel-AS is configured to serve business users (attribute `mtasMmtServeSubscriberType` is set to `BUSINESS` or `BUSINESS_AND_CONSUMER`).
- The basic MMTel services are enabled through the `mtasMmtAdministrativeState` attribute.

The alarm is cleared when at least one of the following conditions apply:

- A valid `vMtasBLVoiceBase` license is installed.
- Attribute `mtasMmtAdministrativeState` is locked.

For more information about licenses, refer to [License Management and MTAS Licenses](#).

Table 1 MtasMmt, Business Line AS Base License Absent Alarm Causes

Alarm Cause	Description	Fault Reason	Fault Location	Impact
The Business Line AS Base license is not present.	MTAS is unable to get license details from NeLS.	The NeLS server is unreachable, or the license is unavailable, has expired, or is corrupted.	NeLS server	MTAS cannot handle Business Line AS Base services.
			TLS <sup>(1)</sup> configuration in the ME <sup>(2)</sup>	
			Possible IP network issue	
			DNS <sup>(3)</sup> server	
			Network interface	

(1) Transport Layer Security (TLS)

(2) Managed Element (ME)

(3) Domain Name System (DNS)

Table 2 MtasMmt, Business Line AS Base License Absent Alarm Attributes

Attribute Name	Attribute Value
Major Type	193
Minor Type	6619223
Managed Object Class	MtasMmt
Managed Object Instance	MtasFunction.applicationName=MtasFunction,MtasLicenses.mtasLicenses=0
Specific Problem	MtasMmt, Business Line AS Base License Absent
Event Type	communicationsAlarm (2)



Table 2 MtasMmt, Business Line AS Base License Absent Alarm Attributes

Attribute Name	Attribute Value
Probable Cause	Unavailable(14)
Additional Text	No License found or License Server Not reachable or License expired or License Server in LOCKED mode
Perceived Severity	critical (3)
Additional Info	-

For more information about the alarm information, refer to [Handling Alarms](#).

## 2 Procedure

### 2.1 Handle MtasMmt, Business Line AS Base License Absent

#### Prerequisites

- This instruction references the following documents:
  - [Check Alarm Status](#)
  - [Data Collection Guideline for MTAS](#)
  - [License Management, Autonomous Mode Activated](#)
  - [License Management, Key File Fault](#)
  - [View License Information](#)
- No tools are required.
- The following conditions must apply:
  - The alarm is raised.
  - No ongoing maintenance activities are affecting the network or network elements.
  - The user has proper authority to handle configuration management of the network elements.
  - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

#### Steps



1. If there is any network-related alarm on the ME, act on it first.
2. If there is a License Management, Autonomous Mode Activated alarm on the ME, act on it.
3. If there is a License Management, Key File Fault alarm on the ME, act on it.
4. Check if a valid vMtasBLVoiceBase license (CXC4012166) is installed. For more information, refer to [View License Information](#).
5. If no license is present, or if the granted status of the license is false, and expiration shows an already elapsed date, proceed with Step 8.
6. Check the alarm status, refer to [Check Alarm Status](#). Is the alarm still active?  
  
Yes: Continue with the next step.  
  
No: Proceed with Step 9.
7. Perform data collection using Data Collection Tool with a Full profile. For more information, refer to [Data Collection Guideline for MTAS](#).
8. Consult the next level of maintenance support. Further actions are outside the scope of this instruction.
9. Job is completed.