

Certificate Management, Automatic Enrollment Failed

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2014–2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Alarm Description	1
2	Procedure	1
2.1	Handle Alarm Certificate Management, Automatic Enrollment Failed	1





1 Alarm Description

The alarm is raised when automatic certificate enrollment or renewal failed to execute because of local misconfiguration or remote enrollment service denial.

Note: The alarm is raised only if the `renewalMode` in a `NodeCredential Managed Object (MO)` is set to `AUTOMATIC`.

Table 1 Certificate Management, Automatic Enrollment Failed Alarm Causes

Alarm Cause	Description	Fault Reason	Fault Location	Impact
Automatic certificate enrollment or renewal has failed	Automatic enrollment or renewal failed to execute because of local misconfiguration or break in remote enrollment service	Configuration or customization error This can be for one of the following reasons: <ul style="list-style-type: none">• Local misconfiguration• Failure in remote enrollment service	Node credential	Certificate is not renewed, which causes certificate expiration Expired certificate can cause secured service failure, for example, Internet Protocol Security connection authenticated by non-existing or expired certificate can fail

2 Procedure

2.1 Handle Alarm Certificate Management, Automatic Enrollment Failed

Prerequisites

— This instruction references the following documents:

- Change Enrollment Server
- Configure Enrollment Authority
- Configure Enrollment Server Group Together with Enrollment Servers



- Configure Renewal Mode of Node Credential
 - Data Collection Guideline
 - Install Node Credential Online
 - Renew Node Credential Online
- No tools are required.
- The following conditions must apply:
- The alarm is raised.
 - The user has the System Security Administrator role.
 - The user is familiar with the security policy and environment of the organization. The user knows what mechanism is appropriate to use to install and renew node credentials online.
 - For the online renewal of node credentials, the correct configuration information for enrollment server groups and enrollment authorities is obtained from the IT or security administrator.
 - No ongoing maintenance activities are affecting the network or network elements.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Navigate to the `NodeCredential` Managed Object (MO) given in the alarm, for example:

```
>ManagedElement=NODE06ST, SystemFunctions=1, SecM=1, CertM=1, NodeCredential=1
```

2. Compare if the existing configuration information for the `NodeCredential` MO matches with the information received from the IT or security administrator.

The values of attributes `enrollmentServerGroup` and `enrollmentAuthority` can be checked in the `NodeCredential` MO with the following command:

```
(NodeCredential=1)>show
```

3. Change the attribute `renewalMode` to `MANUAL`.

For information on how to change attribute `renewalMode`, refer to [Configure Renewal Mode of Node Credential](#).

Note: When `renewalMode` is set to `MANUAL`, the alarm is cleared but the problem remains.



4. Select the appropriate action based on the result in Step 2:
 - There is a mismatch with the `NodeCredential` MO configuration information – Continue with Step 5.
 - There is no mismatch with the `NodeCredential` MO configuration information – Continue with Step 6.
5. Select the appropriate action based on the result in Step 2:
 - If the `EnrollmentServerGroup` MO or the `EnrollmentServer` MO needs to be reconfigured, follow the instruction `Configure Enrollment Server Group Together with Enrollment Servers`, then continue with the next step.
 - If the `EnrollmentServer` MO needs to be changed, follow the instruction `Change Enrollment Server`, then continue with the next step.
 - If the `EnrollmentAuthority` MO needs to be changed, follow the instruction `Configure Enrollment Authority`, then continue with the next step.
 - If some of the `NodeCredential` MO attribute values are wrong, correct the faulty attribute values using the values in `Install Node Credential Online`.
6. Renew the certificate.

For information on how to renew the certificate, refer to `Renew Node Credential Online`.
7. Was the `Renew Node Credential Online` procedure successful?

Yes: Continue with the next step.

No: Proceed with Step 9.

Note: The cause of the failure is shown in `resultinfo` of the attribute `nodeCredentialId`.
8. Change the attribute `renewalMode` back to `AUTOMATIC`.

For information on how to change the attribute `renewalMode`, refer to `Configure Renewal Mode of Node Credential`.
9. Is the alarm cleared?

Yes: Proceed with Step 12.

No: Continue with the next step.
10. Perform data collection, refer to `Data Collection Guideline`.
11. Consult the next level of maintenance support. Further actions are outside the scope of this instruction.
12. Job is completed.