

# Configure Own Node

---

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2015, 2016. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Prerequisites	1
<b>2</b>	<b>Procedure</b>	<b>3</b>





# 1 Introduction

This document describes how to configure the Diameter own node, acting either as a client, as a server, or as an agent.

The Diameter Base Protocol allows the establishment of direct connections between a generic Diameter node (called the own node) and one or more Diameter peer nodes. Diameter messages can be transferred over the Transmission Control Protocol (TCP) or the Stream Control Transmission Protocol (SCTP), over IPv4 or IPv6.

## 1.1 Prerequisites

This section describes the prerequisites, which must be fulfilled before using the procedure.

### 1.1.1 Conditions

The following conditions must apply:

- The following mandatory attributes are known:
  - The unique node identifier, formatted as a case-insensitive Fully Qualified Domain Name (FQDN).
  - The name of the Diameter product running on the own node, set to the default value `Ericsson Diameter Stack`.
  - The unique own node realm, formatted as a case-insensitive FQDN, used for Domain Name System (DNS) message routing.
  - The identifiers of all vendors whose Attribute-Value Pairs (AVPs) are supported by the own node, in a list.
- The desired optional attributes are known.
- An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.





## 2 Procedure

### Configure the Node

To configure the own node:

1. Navigate to the *DIA-CFG-OwnNodeConfig* Managed Object (MO), for example:

```
>dn ManagedElement=NODE06ST,XYZFunction=xyz,DIA-CFG-App
lication=DIA,DIA-CFG-StackContainer=abc,DIA-CFG-OwnNod
eConfig=abc
```

2. Enter Config mode:

```
(DIA-CFG-OwnNodeConfig=abc) >configure
```

3. Set string attribute `hostId` to the node identifier of the own node, for example:

```
(config-DIA-CFG-OwnNodeConfig=abc) >hostId="dia.node"
```

4. Set string attribute `productName` to the name of the Diameter product running on the own node, for example:

```
(config-DIA-CFG-OwnNodeConfig=abc) >productName="Eric
son Diameter Stack"
```

5. Set string attribute `realm` to the name of the node realm, for example:

```
(config-DIA-CFG-OwnNodeConfig=abc) >realm="ericsson.com"
```

6. Set string attribute `supportedVendorsIds` to the vendor IDs, for example:

```
(config-DIA-CFG-OwnNodeConfig=abc) >supportedVendorsI
ds="193"
```

7. Set attributes `transportLayerType` and `ipAddressesList` of the *DIA-CFG-OwnNodeConfig* MO, for example.

```
(config-DIA-CFG-OwnNodeConfig=abc) >transportLayerType=1
```

```
(config-DIA-CFG-OwnNodeConfig=abc) >ipAddressesList="0:
10.1.137.2"
```

```
(config-DIA-CFG-OwnNodeConfig=abc) >ipAddressesList="1:
2dea::66:2"
```

8. Commit the settings:



```
(config-DIA-CFG-OwnNodeConfig=abc) >commit -s
```

9. Verify the own node configuration result:

```
(DIA-CFG-OwnNodeConfig=abc) >show
```

The following is an example output:

```
allowConnectFromUnknownNode=false
enabled=false
firmwareRevision="0"
hostId="dia.node"
ipAddressesList
  "0:10.1.137.2"
  "1:2dea::66:2"
loadRegulationEnabled=false
productName="Ericsson Diameter Stack"
realm="ericsson.com"
sctpHandlerLogLevel="DEFAULT"
sendErrorAtOverload=false
supportedVendorsIds
  "193"
traceSctpHandler="DEFAULT"
transportLayerType="1"
```

### Enable or Disable the Node

10. Enable the own node:

```
(config-DIA-CFG-OwnNodeConfig=abc) >enabled=true
```

**Note:** To disable the own node, set enabled to false.

11. Commit the settings:

```
(config-DIA-CFG-OwnNodeConfig=abc) >commit
```

12. Verify the own node configuration result:

```
(DIA-CFG-OwnNodeConfig=abc) >show enabled
```

The following is an example output:

```
enabled=true
```