

LOTC Ethernet Bonding

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document LDE Trademark Information.



Contents

1	Alarm Description	1
2	Procedure	1
2.1	Handle Alarm LOTC Ethernet Bonding	1





1 Alarm Description

The alarm is raised when one or more Ethernet interfaces belonging to a bonded interface fail.

Table 1 LOTC Ethernet Bonding Alarm Causes

Alarm Cause	Description	Fault Reason	Fault Location	Impact
Failed Ethernet interface on <code>bond0</code>	The physical link state of one or both Ethernet interfaces is down	Faulty physical Ethernet interface	Physical Ethernet interface	If one Ethernet interface is down, there is a loss in resilience. If both Ethernet interfaces are down, then internal cluster services such as booting and logging are affected.
		Faulty external device (that is, Ethernet switch)	External device (that is, Ethernet switch)	
Failed Ethernet interface on <code>bond1</code>	The physical link state of one or both Ethernet interfaces is down	Faulty physical Ethernet interface	Physical Ethernet interface	If one Ethernet interface is down, there is a loss in resilience. If both Ethernet interfaces are down, then external network traffic is down.
		Faulty external device (that is, Ethernet switch)	External device (that is, Ethernet switch)	

Note: This alarm can appear as a result of a maintenance activity.

2 Procedure

2.1 Handle Alarm LOTC Ethernet Bonding

Prerequisites

- This instruction references the following document:



- *Data Collection Guideline*
- No tools are required.
- The following conditions must apply:
 - The alarm is raised.
 - It is known how to map the `HostName` (part of alarm attribute `Source`), to the physical address (slot) in the Blade Server Platform (BSP).
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Is the alarm present on multiple blades, that is, are there at least two LOTG Ethernet Bonding alarms with different values of alarm attribute `Source`?

Yes: Proceed with Step 8.

No: Continue with the next step.

2. Is the alarm severity `critical`?

Yes: Continue with the next step.

No: Proceed with Step 11.

3. Log on to the BSP to access a Linux shell, for example:

```
ssh <user>@<hostname> -p 7022
```

The hostname is part of alarm attribute `Source`.

4. Collect the kernel messages:

```
dmesg > $(hostname) - $(date +%d-%m-%y_%H-%M-%S).dmesg.log
```

If there is no network connectivity to a blade, gather kernel information using a serial console using copy and paste.

The following is an example output:



```
[ 0.000000] Initializing cgroup subsys cpuset
[ 0.000000] Initializing cgroup subsys cpu
[ 0.000000] Linux version 3.0.80-0.7.1.5895.4.PTF-default (geeko@buildhost) (gcc version =>
4.3.4 [gcc-4_3-branch revision 152973] (SUSE Linux) ) #1 SMP Mon Aug 26 13:53:40 UTC 2013 ()
[ 0.000000] Command line: panic=10 console=tty0 cluster=(type=control,disk_cache=0,=>
clean_rootfs=0)
[ 0.000000] BIOS-provided physical RAM map:
[ 0.000000] BIOS-e820: 0000000000000000 - 0000000000009fc00 (usable)
[ 0.000000] BIOS-e820: 0000000000009fc00 - 000000000000a0000 (reserved)
[ 0.000000] BIOS-e820: 000000000000f0000 - 00000000000100000 (reserved)
[ 0.000000] BIOS-e820: 00000000000100000 - 0000000003fff0000 (usable)
[ 0.000000] BIOS-e820: 0000000003fff0000 - 00000000040000000 (ACPI data)
[ 0.000000] BIOS-e820: 00000000040000000 - 00000000100000000 (reserved)
[...]
```

5. Using the ECLI on the BSP, reset the blade:

```
>ManagedElement=<hw_ME_name>,Equipment=1,Shelf=<shelf>,Slot=<slot>,Blade=1,reset --resetType HARD
--gracefulReset FALSE
```

For example, when the issue is on shelf 2 and slot 3:

```
>ManagedElement=BSP04ST,Equipment=1,Shelf=2,Slot=3,Blade=1,reset --resetType HARD --gracefulReset FALSE
```

6. Wait 5 minutes.

7. Is the alarm cleared?

Yes: Proceed with Step 13.

No: Proceed with Step 11.

8. Are the alarms reporting from the same bond from all blades, for example, bond0 or bond1?

Yes: With high probability, the fault is in the BSP. Continue with the next step.

No: Proceed with Step 11.

9. Is the BSP switch alive and functioning properly?

Yes: Proceed with Step 11.

No: Troubleshoot the BSP switch.

10. Once the switch problem is solved, is the alarm cleared?

Yes: Proceed with Step 13.

No: Continue with the next step.

11. Perform data collection, refer to *Data Collection Guideline*.

Note: The status of the bounded interfaces must be collected.



12. Consult next level of support. Further actions are outside the scope of this instruction.
13. Job is completed.