

Configure SNMP Master Agent with engineId

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Configure SNMP Master Agent with engineId	1





1 Description

This instruction describes how to configure the SNMP Master Agent with engineId.

2 Procedure

2.1 Configure SNMP Master Agent with engineId

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - An Ericsson Command-Line Interface (ECLI) in exec mode is in progress.

Steps

1. Navigate to the `Snm` Managed Object (MO), for example:

```
>dn ManagedElement=1,SystemFunctions=1,SysM=1,Snm=1
```
2. Enter Config mode:

```
(Snm=1)>configure
```
3. Configure the SNMP Master Agent with an engineId which can be a string, for example:

```
(config-Snm=1)>engineId="1234567890"
```
4. Commit the settings:

```
(config-Snm=1)>commit
```
5. Verify the settings:

```
(Snm=1)>show -v
```

The following is an example output:



```
Snmp=1
  administrativeState=UNLOCKED <default>
  enableSourceCheckForV1V2C=false <default>
  engineId="1234567890"
  nodeCredential="ManagedElement=1, SystemFunctions=1, ⇒
SecM=1, CertM=1, NodeCredential=nc1"
  operationalState=ENABLED <read-only>
  port=161 <default>
  portDtls=10161 <default>
  snmpId="1"
  trustCategory="ManagedElement=1, SystemFunctions=1, ⇒
SecM=1, CertM=1, TrustCategory=tc1"
  agentAddress[@1]
    host="127.0.0.1"
    port=161
  agentAddressDtls[@1]
    host="127.0.0.1"
    port=10161
```

Note: If SNMP stack cannot support setting the engineId, then the applied value is ignored, keeping the current empty value.

The engineId attribute is optional. If not set by NBI user, then a random engineId, generated by netSNMP library, is used.