

Delete Inactive Software Version

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Delete Inactive Software Version	1





1 Description

This instruction describes how to delete an inactive software version from the managed element. This operation can be used to save disk space when an inactive software version, which is no longer needed, has not been deleted automatically by the latest software upgrade.

2 Procedure

2.1 Delete Inactive Software Version

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Navigate to the **SwM** managed object, for example:

```
>dn ManagedElement=NODE06ST,SystemFunctions=1,SwM=1
```

2. Identify the inactive software version to delete:

```
(SwM=1)>show -v ManagedElement=NODE06ST,SystemFunctions=1,SwInventory=1
```

The following example output shows that two software versions are present. The software version with revision R7F01 is explicitly indicated as active. The other software version with revision R7E01 is inactive because it is not indicated as active. It is therefore possible to delete R7E01.

```
SwInventory=1
  active <read-only>
    "ManagedElement=1,SystemFunctions=1,SwInventory=1,SwVersion=ERIC-COREMW_RUNTIME-CXP9020355_1-R7E01
[...]
```

3. Delete the inactive software version, for example:



```
(SwM=1)>removeSoftwareVersion ManagedElement=N0DE06ST,SystemFunctions=1,SwInventory=1,SwVersion=ERIC-COREMW_RUNTIME-CXP9020355_1-R7E01
```

The system returns output true or false.

4. Verify that the software version is deleted:

```
(SwM=1)>show -v ManagedElement=N0DE06ST,SystemFunctions=1,SwInventory=1
```

The following is an example output showing the final result.

```
SwInventory=1
  active <read-only>
    "ManagedElement=1,SystemFunctions=1,SwInventory=1,SwVersion=ERIC-COREMW_RUNTIME-CXP9020355_1-R7F01"
[...]
```

```
SwVersion=ERIC-COREMW_RUNTIME-CXP9020355_1-R7F01
```

```
[...]
```