

Scale in VMware VNF Using VNF-LCM

Call Session Control Function

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2018, 2019. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	2
2.1	Scale in a VNF	2
2.2	Troubleshooting	5






1 Description

This instruction describes how to scale in a Virtual Network Function (VNF) in the Virtual Network Function Life Cycle Management (VNF-LCM).

The Call Session Control Function (CSCF) workflow software package contains more files than are described in this instruction. These unmentioned files are only used in special deployment scenarios that are outside the scope of this instruction. Only use the files that are explicitly mentioned in the instruction.

The VNF-LCM procedures use workflow instances. The following figure shows an example of a workflow instance, where workflow progress can be tracked in the **Workflow Diagram** view. The boxes in the **Workflow Diagram** only represent the stages of the various procedures; operations are performed in the **Task** view.





2 Procedure

2.1 Scale in a VNF

Prerequisites

— The following virtual and physical hardware and software are required:

- The VNF is scaled out using the VNF-LCM.
- VNF-LCM is available, using either Operations Support System for Radio and Core (OSS-RC) or Ericsson Network Manager (ENM).
- The VIM is configured in VNF-LCM:

The VIM configuration in VNF-LCM can be checked with the `vnflcm vim list` command. For more information on VIM configuration, see VNF Lifecycle Manager System Administrator Guide, 1543-APR 901 0578 Uen.

— This instruction references the following documents:

- [CSCF Troubleshooting Guideline](#)
- [VNF Lifecycle Manager System Administrator Guide, 1543-APR 901 0578 Uen](#)

— No tools are required.

— The following condition must apply:

- The VNF-LCM is available using either the Operations Support System for Radio and Core (OSS-RC) or the Ericsson Network Manager (ENM).



Attention!

Risk of system malfunction or traffic disturbance.

Scaling in SC-1, SC-2, PL-3, and PL-4 is not possible. Hence, the CSCF cluster configuration is a 2 + 2 configuration or larger.

Steps

1. In the VNF-LCM, click **Start a Workflow**, and select **Scale VNF**, and then click **Start a New Instance**.



Ericsson OSS / Workflows

VNF LifeCycle Management

Workflows 5

Table Settings

Name	Instances with User Tasks	Active Instances	Description
Heal VNF			vIMS workflow to heal a VNF instance
Instantiate VNF			vIMS workflow to instantiate a VNF
NR-Upgrade VNF			vIMS workflow to upgrade a VNF with a redundant network
Scale VNF			vIMS workflow to scale a VNF instance
Terminate VNF			vIMS workflow to terminate a VNF instance

- In the **Start a Workflow** view, fill out the **Instance Name** field, and then click **Submit**.
- Select the newly created workflow from the **Instance Activity** panel.
- On the **Workflow Instance** screen, select the VNF to be scaled in, select **Scale In** for scaling type, specify the number of Virtual Machines (VMs) to be deleted from the VNF, and then click **Submit**.

Task

Collect user data for Scale

Scale VNF instance

Scale Data

Select VNF instance*

vCSCF__1.8.0

Select scaling type*

Scale In

Number of VMs to scale*

1

Submit

Reset

The following step is optional. If none of these parameters are needed, leave the fields blank.

- In the **Collect extra parameters** view, specify the needed parameters, and then click **Submit**.



The VNF instance is scaled in and the specified number of VMs is deleted from the cluster.

Optional scale-in parameters:

- Specific VMs to be scaled-in
- Scale-in type (**Graceful** or **Forceful**)
- VM Universal Unique Identifiers (UUIDs) to scale in.

Task

Collect extra parameters

Input additional parameters for workflow

Optional: List of VM UUIDs to scale-in

Scale-in type

GRACEFUL



GRACEFUL

FORCEFUL

Submit

Reset

Note: If any UUID is specified, the VMs with the specified UUIDs are removed.



Attention!

Risk of system malfunction or traffic disturbance.

During the scaling, the optional user input **Cancel LCM Hook** is available. Do not click **Submit**. This is not supported in the current release.



Task

OPTIONAL: Override User Input

OPTIONAL: Cancel LCM hook

This user form is a possibility to gracefully or forcefully cancel LCM hook in case of unexpectedly long execution time, faulty initial inputs or other cases. It is not mandatory, and the execution may complete without it being submitted. To keep track of progress, please use the refresh button occasionally.

Select cancellation method:

Gracefully cancel executi... ▼

Submit

Reset

2.2 Troubleshooting

If the workflow execution fails, inspect the relevant logs to identify the cause of the failure.

Steps

1. Increase the log level from INFO to DEBUG. For information on how to change log level, see VNF Lifecycle Manager System Administrator Guide, 1543-APR 901 0578.
2. Inspect the following logs to identify the cause of the failure:
 - Jboss Server log: /ericsson/3pp/jboss/standalone/log/server.log
 - System log: /var/log/messages
 - Workflow log: the **Workflow Log** view in the VNF-LCM
3. If the **Workflow Log** view reports Authentication failed, repair the Secure Shell (SSH) key between the VNF-LCM and the CSCF. For more information, see Section Check SSH Key for Authentication in [CSCF Troubleshooting Guideline](#).
4. If a problem cannot be solved, consult the next level of maintenance support and provide the logs. Further actions are outside the scope of this instruction.