

Change Alarm Type Severity

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Change Alarm Type Severity	1





1 Description

This instruction describes how to change the alarm type severity. The user can experience that the designed alarm severity does not match the actual perceived severity in the network solution and can change its value.

2 Procedure

2.1 Change Alarm Type Severity

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - The alarm type and the new alarm type severity are known.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Navigate to the *FmAlarmType* managed object, for example:

```
>dn ManagedElement=NODE06ST, SystemFunctions=1, Fm=1, FmAlarmModel=SwM, FmAlarmType=FallbackOperationStartingSoon
```

2. Show the alarm severity:

```
(FmAlarmType=FallbackOperationStartingSoon) >show defaultSeverity
```

```
defaultSeverity= []
```

3. Enter Config mode:

```
(FmAlarmType=FallbackOperationStartingSoon) >configure
```

4. Change the alarm type severity, for example:



```
(config-FmAlarmType=FallbackOperationStartingSoon) >configuredSeverity=MINOR
```

5. Commit the change:

```
(config-FmAlarmType=FallbackOperationStartingSoon) >commit
```

6. Verify the change:

```
(FmAlarmType=FallbackOperationStartingSoon) >show configuredSeverity
```

```
configuredSeverity=MINOR
```