

Enable Automatic Deletion of Manual Backups

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Enable Automatic Deletion of Manual Backups	1





1 Description

This instruction describes how to enable automatic deletion of manual system backups in the managed element.

Enabling automatic deletion of manual system backups when the maximum number of manual system backups is below the existing number of stored manual system backups results in immediate deletion of one or more stored manual system backups to match the maximum number.

For information on how to modify the maximum number of manual system backups, refer to *Change Maximum Number of Manual Backups*.

2 Procedure

2.1 Enable Automatic Deletion of Manual Backups

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - The existing value of attribute `autoDelete` is `DISABLED`.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

If the number of backups is already over the value of attribute `maxStoredManualBackups`, this operation deletes one or more existing backups. Consider to export important backups before enabling this operation.



Attention!

Risk of data loss or data corruption.

1. Navigate to the *BrmBackupHousekeeping* managed object, for example:

```
>dn ManagedElement=NODE06ST,SystemFunctions=1,BrM=1,Br  
mBackupManager=SYSTEM_DATA,BrmBackupHousekeeping=SYS  
TEM_DATA.
```

2. Enter Config mode:

```
(BrmBackupHousekeeping=SYSTEM_DATA) >configure
```

3. Enable automatic deletion of manual backups:

```
(config-BrmBackupHousekeeping=SYSTEM_DATA) >autoDelete  
=ENABLED
```



Attention!

Risk of data loss or data corruption.

Depending on the number of stored manual backups and the value of the maximum number of manual backups, commit of this change can result in immediate deletion of stored manual system backups.

Note: The value of the `autoDelete` attribute cannot be cleared by the `no autoDelete` ECLI command.

4. Commit the change:

```
(config-BrmBackupHousekeeping=SYSTEM_DATA) >commit
```

5. Verify the change:

```
(BrmBackupHousekeeping=SYSTEM_DATA) >show -v
```

The following is an example output:

```
BrmBackupHousekeeping=SYSTEM_DATA  
  autoDelete=ENABLED <default>  
[...]
```