

# Enable Automatic Deletion of Manual Backups

---

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Prerequisites	1
<b>2</b>	<b>Procedure</b>	<b>3</b>



Enable Automatic Deletion of Manual Backups



# 1 Introduction

This document describes how to enable automatic deletion of manual user backups in the managed element.

Enabling automatic deletion of manual user backups when the maximum number of manual user backups is below the existing number of stored manual user backups results in immediate deletion of one or more stored manual user backups to match the maximum number.

For information on how to modify the maximum number of manual user backups, refer to *Change Maximum Number of Manual Backups*.

## 1.1 Prerequisites

This section describes the prerequisites, which must be fulfilled before using the procedure.

### 1.1.1 Conditions

The following conditions must apply:

- The existing value of attribute `autoDelete` is `DISABLED`.
- An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.





## 2 Procedure



### Attention!

Risk of data loss or data corruption.

If the number of backups is already over the value of attribute `maxStoredManualBackups`, this operation deletes one or more existing backups. Consider to export important backups before enabling this operation.

To enable automatic deletion of manual backups:

1. Navigate to the *BrmBackupHousekeeping* managed object, for example:

```
>dn ManagedElement=<Node Name>,SystemFunctions=1,BrM=1,BrmBackupManager=USER_DATA,BrmBackupHousekeeping=USER_DATA.
```

2. Enter Config mode:

```
(BrmBackupHousekeeping=USER_DATA) >configure
```

3. Enable automatic deletion of manual backups:

```
(config-BrmBackupHousekeeping=USER_DATA) >autoDelete=ENABLED
```



### Attention!

Risk of data loss or data corruption.

Depending on the number of stored manual backups and the value of the maximum number of manual backups, commit of this change can result in immediate deletion of stored manual backups.

**Note:** The value of the `autoDelete` attribute cannot be cleared by the `no autoDelete` ECLI command.

4. Commit the change:



```
(config-BrmBackupHousekeeping=USER_DATA) >commit
```

5. Verify the change:

```
(BrmBackupHousekeeping=USER_DATA) >show -v
```

The following is an example output:

```
BrmBackupHousekeeping=USER_DATA  
  autoDelete=ENABLED <default>  
[...]
```