

Compute Host Failed

Cloud Execution Environment

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Introduction	1
1.1	Alarm Description	1
1.2	Prerequisites	2
2	Procedure	2
2.1	Actions	3
3	Additional Information	4



Compute Host Failed



1 Introduction

This instruction concerns alarm handling.

1.1 Alarm Description

The alarm is issued by the Managed Object (MO) `Node` when the periodic supervision algorithm detects that the compute host has failed the availability test three consecutive times, and, after that, remains unavailable for more than five minutes.

The severity of the alarm is `MINOR` or `CLEARED`.

The possible alarm causes and fault locations are explained in Table 1.

Table 1 Alarm Causes

Alarm Cause	Description	Fault Reason	Fault Location	Impact
Compute node is down	The compute node fails the availability test three consecutive times, and, after that, remains unavailable for more than five minutes.	Compute node malfunction	Compute node	The compute node becomes permanently unavailable.

The following is the consequence for the node if the alarm is not solved:

- The compute node remains unavailable.

The alarm attributes are listed in Table 2.

Table 2 Alarm Attributes

Attribute Name	Attribute Value
Major Type	193
Minor Type	2031678
Managed Object Class	Node
Managed Object Instance	Region=<name_of_the_region>, CeeFunction=1, Node=<hostname_of_the_node>
Specific Problem	Compute Host Failed
Event Type	other (1)



Attribute Name	Attribute Value
Probable Cause	m3100ReplaceableUnitProblem(69)
Additional Text	;uuid=<HW_UUID_of_failed_server> ⁽¹⁾
Severity	MINOR (5) or CLEARED

(1) The format of this field is expected to change in CEE R6.

Note: The alarm does not specify which Virtual Machines (VMs) are affected. Separate VM Unavailable alarms are issued for each.

For more information about the VM Unavailable alarm, refer to *VM Unavailable*.

1.2 Prerequisites

This section provides information on the documents, tools, and conditions that apply to the procedure.

1.2.1 Documents

Not applicable.

1.2.2 Tools

No tools are required.

1.2.3 Conditions

Before starting this procedure, ensure that the following condition is met:

- Information about how to connect and use the out-of-band management is available.

2 Procedure

This section describes the procedure to follow when this alarm is received.



2.1 Actions

Perform the following:

1. Use the unqualified part of the hostname to find out the number of the corresponding shelf and server.

The unqualified hostname is displayed in the following format:

```
compute-<shelf_id>-<blade_id>
```

The first value reflects the number of the shelf, while the second value reflects the number of the server.

2. Restart the server in question by using corresponding out-of-band management.
3. The following scenarios are possible:
 - The reboot of the server solved the problem, and the alarm ceases.
If the alarm ceases, exit this procedure.
 - Or the reboot of the server did not solve the problem.
In this case, proceed to Step 4.
4. Replace the server as described in *Server Replacement*.
5. The following scenarios are possible:
 - The replacement process was successful, the server became online, and the alarm ceases.
If the alarm ceases, exit this procedure.
 - Or the replacement process did not solve the problem.
In this case, proceed to Step 6.
6. Collect troubleshooting data as described in the *Data Collection Guideline*. For alarm-specific logs, refer to the Table *Data Collection for Alarms and Alerts* in the *Data Collection Guideline*.
7. Contact the next level of maintenance support.
Further actions are outside the scope of this instruction.
8. The job is completed.



3 Additional Information

The alarm is ceased for a compute host when the compute host passes the availability test.

As fencing is done by CM-HA through out-of-band management, in case fencing is turned on, there is a valid scenario when the compute host is switched off before evacuation, and only powered on at a later time.