



# **Commissioning the IBBU of UltraSite EDGE BTS**

The information in this document is subject to change without notice and describes only the product defined in the introduction of this documentation. This document is intended for the use of Nokia's customers only for the purposes of the agreement under which the document is submitted, and no part of it may be reproduced or transmitted in any form or means without the prior written permission of Nokia. The document has been prepared to be used by professional and properly trained personnel, and the customer assumes full responsibility when using it. Nokia welcomes customer comments as part of the process of continuous development and improvement of the documentation.

The information or statements given in this document concerning the suitability, capacity, or performance of the mentioned hardware or software products cannot be considered binding but shall be defined in the agreement made between Nokia and the customer. However, Nokia has made all reasonable efforts to ensure that the instructions contained in the document are adequate and free of material errors and omissions. Nokia will, if necessary, explain issues which may not be covered by the document.

Nokia's liability for any errors in the document is limited to the documentary correction of errors. NOKIA WILL NOT BE RESPONSIBLE IN ANY EVENT FOR ERRORS IN THIS DOCUMENT OR FOR ANY DAMAGES, INCIDENTAL OR CONSEQUENTIAL (INCLUDING MONETARY LOSSES), that might arise from the use of this document or the information in it.

This document and the product it describes are considered protected by copyright according to the applicable laws.

NOKIA logo is a registered trademark of Nokia Corporation.

Other product names mentioned in this document may be trademarks of their respective companies, and they are mentioned for identification purposes only.

Copyright © Nokia Corporation 2004. All rights reserved.

## Contents

**Contents 3**

<b>1</b>	<b>Statutory Information 5</b>
1.1	CE Marking 5
1.2	FCC Statement 5
<b>2</b>	<b>Software description for UltraSite EDGE with IBBU 7</b>
2.1	Nokia PSM software 7
<b>3</b>	<b>Preparing to commission the IBBU of UltraSite EDGE BTS 11</b>
3.1	Connecting LMP cable for commissioning UltraSite EDGE BTS 11
3.2	Powering ON UltraSite EDGE BTS 13
3.3	Installing Nokia PSM Manager 14
<b>4</b>	<b>Commissioning UltraSite EDGE BTS IBBU with Nokia PSM Node Manager Commissioning Wizard 19</b>
4.1	Overview of Commissioning UltraSite EDGE BTS with IBBU 19
4.2	Checking the BIOS of UltraSite EDGE BTS with IBBU 21
4.3	Upgrading the BIOS of UltraSite EDGE BTS with IBBU 22
4.4	Upgrading CCUA software of UltraSite EDGE BTS with IBBU 24
4.5	Preparing to commission UltraSite EDGE BTS with IBBU using Nokia PSM Node Manager 26
4.6	Connecting Remotely to Nokia PSM Node Manager 27
4.7	Connecting locally to a PSM Node Manager 28
4.8	Entering System Type and Setup details of UltraSite EDGE BTS with IBBU 30
4.9	Entering Product Code, Serialisation and Configuration details for SiSS Node of UltraSite EDGE BTS with IBBU 31
4.10	Entering Documentation, Site Details and Cabinet Mechanics details of UltraSite EDGE BTS with IBBU 31
4.11	Entering Product Code and Serialisation details for Batteries of UltraSite EDGE BTS with IBBU 32
4.12	Entering Product Code and Serialisation details for Climatic Control Unit of UltraSite EDGE BTS with IBBU 33
4.13	Checking the Configuration and completing commissioning of UltraSite EDGE BTS with IBBU 33
4.14	Printing a commissioning report of UltraSite EDGE BTS with IBBU 34
<b>5</b>	<b>Checking setting of UltraSite EDGE BTS IBBU 37</b>
5.1	Checking Power Management settings of UltraSite EDGE BTS with IBBU 37
5.2	Checking Climatic Control settings of UltraSite EDGE BTS with IBBU 38
5.3	Checking System settings of UltraSite EDGE BTS with IBBU 39
5.4	Checking Identifications of UltraSite EDGE BTS with IBBU 39
<b>6</b>	<b>Nokia PSMMan commissioning windows 41</b>
6.1	Commissioning procedure overview 41
6.2	Welcome window of PSM Manager installation wizard 42

6.3	Pre-requisites window of PSM Manager installation wizard	43
6.4	License Agreement window of PSM Manager installation wizard	44
6.5	Setup Type window of PSM Manager installation wizard	45
6.6	Start Copying Files window of PSM Manager installation wizard	46
6.7	Setup Status window of PSM Manager installation wizard	47
6.8	Installation complete window of PSM Manager installation wizard	48
6.9	Choose Target window of PSMMan Software Download Wizard	49
6.10	Select File window of PSMMan Software Download Wizard	50
6.11	Start Download window of PSMMan Software Download Wizard	51
6.12	Switch Software window of PSMMan Software Download Wizard	52
6.13	Welcome and User Details window of PSMMan Commissioning Wizard	53
6.14	System Type and Setup Page window of PSMMan Commissioning Wizard	54
6.15	Product Code and Serialisation Page [SiSS Node] & Configuration window of PSMMan Wizard	55
6.16	Documentation, Site Details & Cabinet Mechanics [CRM] Identification window of PSMMan Commissioning Wizard	56
6.17	Product Code and Serialisation Page [Batteries] window of PSMMan Commissioning Wizard	57
6.18	Product Code and Serialisation Page [Climatic Control Unit] window of PSMMan Commissioning Wizard	58
6.19	Configuration Summary & Commission window of PSMMan Commissioning Wizard	59
6.20	SiSS Commissioning Report Page window of PSMMan Commissioning Wizard	60
6.21	Power Management (Settings) window of PSMMan	61
6.22	Climatic Control (Settings) window of PSMMan	62
6.23	System Settings window of PSMMan	63
6.24	Identifications window of PSMMan	64
<b>7</b>	<b>Glossary</b>	<b>65</b>
7.1	Glossary for UltraSite EDGE BTS	65
7.1.1	Abbreviations and acronyms	65
7.1.2	Terms	81

## **Related Topics 91**

# 1 Statutory Information

## 1.1 CE Marking

Standard	Description
C € 0168 ⓘ	Hereby, Nokia Corporation, declares that this Nokia UltraSite EDGE Base Station is in compliance with the essential requirements and other relevant provisions of Directive: 1999/5/EC.

## 1.2 FCC Statement

Standard	Description
FCC Statement	<p>Hereby, Nokia Corporation declares that this Nokia UltraSite EDGE Base Station is in compliance with the essential requirements and other relevant provisions of Directive: 1999/5/EC.</p> <p>The product is marked with the CE marking and Notified Body number according to the Directive 1999/5/EC.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful</p>

Standard	Description
	interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

# 2

## Software description for UltraSite EDGE with IBBU

### 2.1 Nokia PSM software

The node manager software (SW), designated PSMMan, controls the PSM nodes. The node manager SW can be used in three ways as follows:

- It can be used at the site for commissioning and maintaining the Nokia UltraSite with IBBU. This is carried out by connecting a PC (running the software) to the LMP on the CCUA module. Since there are no security levels with this interface, the site user has limited access. For example the user may be able to read information but not alter it. When a site is commissioned, the engineer will run a commissioning wizard that will set all parameters to the default values required by the user.

---

#### Note

The user is required to have access rights.

---

- Another mode of operation for the PSMMan is when it is used from the NMS to monitor nodes and to make alterations to the nodes. The operator at the NMS can look at the node by using its address and make alterations such as changing the battery temperature compensation, should this be required. The operator can also read data from the site, such as the results of the last battery test.
- A third mode of operation is remotely via a telephone connection to the NMS. This allows an engineer to dial into the NMS via a modem link.

The PSMMan has a graphical user interface (GUI) and runs on a Windows 95, Windows 98, Windows 2000 or Windows NT4 operating system. However, the PSMMan must use Windows NT4 at the NMS as this is a requirement of the NMS. Several copies of the PSMMan can be used simultaneously to monitor more than one node at a time.

Nodes may be monitored via the alarm window, which displays the alarms from the nodes. Alarms may be filtered for their level of urgency.

When viewing a node, the PSMMan provides an equipment view feature. By clicking on various parts of this view, you can find data that is of interest about the item. For example, clicking on the battery will bring up the data for the batteries in that node.






Figure 1. UltraSite EDGE BTS with IBBU site overview



# 3

## Preparing to commission the IBBU of UltraSite EDGE BTS

### 3.1 Connecting LMP cable for commissioning UltraSite EDGE BTS

#### Before you start

Review the *Overview of commissioning UltraSite EDGE BTS*. Pay careful attention to all Warnings and Cautions.

#### Summary

The LMP cable connects the PC running BTS Manager SW to the BOI unit in the BTS.




Figure 2. LMP cable

Table 1. LMP cable connector pin order

BTS end, D9 male, pin number	PC end, D9 female, pin number	PC end, D25 female, pin number
2, LMP in	3, transmitted data	2, transmitted data
3, LMP out	2, received data	3, received data
5, ground	5, ground	7, ground

**Steps**

1. **Remove the protective cover from the LMP port on the BOIx for GSM/EDGE connection.**

Alternatively, remove the protective cover from the BTS master WAM unit for WCDMA connection.

2. **Connect the D9 female connector to the PC.**

3. **Connect the D9 male connector to the LMP port on the BOIx for GSM/EDGE connection.**

Alternatively, connect the D25 female connector to the BTS master WAM unit for WCDMA connection.

## 3.2 Powering ON UltraSite EDGE BTS

**Before you start**

Review the *Overview of commissioning UltraSite EDGE BTS*. Pay careful attention to all Warnings and Cautions.

Ensure all internal BTS components are properly installed.

**Summary**

---

**Warning**

**Be aware of the risk of lethal voltages and electric shock.**

---

**Steps**

1. *If Mains power has been switched OFF,*

*Then*

**Check the ADUx circuit breakers.**

Verify all ADUx unit circuit breakers are switched OFF.

2. *If BTS power supplies are switched ON,*

*Then*

**Switch the power supplies OFF.**

- 3. Switch Mains breaker ON.**
- 4. Switch ADUx unit breakers ON.**
- 5. Switch BTS Power supplies ON.**
- 6. Check BTS units for power.**

Observe the LED lights of the units in the BTS and ensure power is supplied. If LED lights are not illuminated, troubleshoot the affected units as directed in *Overview of checking UltraSite EDGE BTS GSM/EDGE LEDs* or *Overview of checking UltraSite EDGE BTS WCDMA LEDs*.

## 3.3 Installing Nokia PSM Manager

### Before you start

Review the *Overview of commissioning UltraSite EDGE BTS*. Pay careful attention to all Warnings and Cautions.

Table 2. System requirements for PSM

Installation type	System requirements
PC	<ul style="list-style-type: none"><li>• Pentium II 300 MHz processor</li><li>• Microsoft Windows 2000, Microsoft Windows NT 4.0 (service Pack 3 or later) or Microsoft Windows 98 (release OS2 or above)</li><li>• Windows 2000 Server edition for 3G with running Q1Agent</li><li>• Windows NT for WTS in NMS200 environment (required for server)</li><li>• Q1CS Version 4.2; for 2G, Q1CS 4.1 is sufficient</li><li>• Citrix NTC WinCenter client software</li></ul>
Remote connection PC	<ul style="list-style-type: none"><li>• Pentium II 300 MHz processor</li><li>• Microsoft Windows 2000, Microsoft Windows NT 4.0 (service Pack 3 or later) or Microsoft Windows 98 (release OS2 or above)</li><li>• Windows 2000 Server edition for 3G with running Q1Agent</li><li>• Windows NT for WTS in NMS200 environment</li><li>• 128 MB RAM</li></ul>

Table 2. System requirements for PSM (cont.)

Installation type	System requirements
	<ul style="list-style-type: none"> <li>• 200 MB free hard drive space</li> <li>• 16X CD - ROM</li> <li>• 1.44 MB 3.5" floppy</li> <li>• 56.6k modem and data-capable telephone line</li> <li>• 8 MB video card</li> <li>• 1024 x 800-resolution, 256-colour display</li> <li>• 115 200 bps serial port</li> <li>• GCS 4.1 (or later)</li> </ul> <hr/> <p><b>Note</b></p> <p>To connect remotely to NMS/2000, include the PSMMan application in NMS/2000. Edit the file, \$OMCCONFPATH/osi/ouorapmx.cf, to include the Q1 Node Manager PSMMan OSI application.</p> <hr/> <p><b>Note</b></p> <p>To connect remotely to PSM in a NetAct 3.1 environment, GCS 4.2 must be installed on the same PC as PSMMan.</p> <hr/>
NMS/2000 desktop	<ul style="list-style-type: none"> <li>• NMS/2000 must run GCS 4.1 (or later)</li> <li>• The node manager server must be set up with Citrix MetaFrame 1.8 or later</li> <li>• The node manager server must be set up with UIS (NTC WinCenter UNIX integration services version 1.0). UIS will enable support of UNIX connections to the NT4TSE / MetaFrame server.</li> <li>• Citrix Client software must be installed on the NMS/2000 terminal / PC</li> <li>• Citrix Client should be configured to log on to the server (NMS/10 Node Manager). Alternatively, if more than one type of application is to be launched, use a generic Node Manager Server icon.</li> </ul> <hr/> <p><b>Tip</b></p> <p>If PSMMan is the only node manager application, configure the Client Software to launch PSMMan. Name the icon <b>PSMMan</b>.</p> <hr/>

Table 2. System requirements for PSM (cont.)

Installation type	System requirements
	<ul style="list-style-type: none"> <li data-bbox="375 461 1329 521">• The Create Action application in NMS/2000 must be used to create an NMS/10 icon, if the node manager server is running NMS/10.</li> </ul> <hr/> <p data-bbox="451 584 518 613"><b>Note</b></p> <p data-bbox="451 656 1329 741">Choose a meaningful graphic for the NMS/10 icon. Give the icon a meaningful name, such as NMS/10_Server. It should also be given a meaningful icon, such as one depicting a PC.</p> <hr/> <ul style="list-style-type: none"> <li data-bbox="375 826 1268 855">• Link the icon with the path of the shell script to launch the Citrix Client software.</li> </ul> <hr/> <p data-bbox="451 918 518 947"><b>Note</b></p> <p data-bbox="451 990 1187 1019">A good place to put the shell script is the Citrix MetaFrame directory.</p> <hr/> <p data-bbox="451 1158 518 1187"><b>Note</b></p> <p data-bbox="451 1229 1085 1258">Pay particular attention to the warning contained in this file.</p> <hr/> <ul style="list-style-type: none"> <li data-bbox="375 1344 1329 1404">• A shell script may be needed in the NMS/2000 to point to the directory where Citrix Client is installed in the NMS/2000. This can be generated using <code>dterm</code> in NMS/2000.</li> </ul> <hr/> <p data-bbox="451 1467 518 1496"><b>Note</b></p> <p data-bbox="451 1538 1318 1599">In NMS/2000, <code>dterm</code> means a terminal window. The file is created with an editor like <code>vi</code> (console) or <code>dtpad</code> (graphical).</p> <hr/> <p data-bbox="413 1680 1075 1709">An example of this script, called <code>citrix.sh</code>, is shown below.</p> <p data-bbox="643 1742 788 1771" style="text-align: center;">Example 1.</p> <p data-bbox="643 1816 858 1845" style="text-align: center;">Citrix Shell Script</p>



Table 2. System requirements for PSM (cont.)

Installation type	System requirements
	<pre data-bbox="718 459 1300 627">#!/bin/sh  export ICAROOT="opt/lib/ICAClient"  exec \$ICAROOT/wfica</pre> <ul data-bbox="451 638 1372 694" style="list-style-type: none"> <li>• When configuring Citrix Client, it is recommended that you select a window size of 1024/768 pixels and select 256 colours.</li> </ul> <hr data-bbox="526 734 1404 739"/> <p data-bbox="526 761 598 795"><b>Note</b></p> <p data-bbox="526 828 1404 974">If NMS/2000 is running with GCS 4.1, PSMMan uses NMS/10 User Groups to determine access privileges. The administrator of the server must generate an NMS/10 user group in order to determine individual user privileges. Even if NMS/10 is not used, the administrator of the server must generate an NMS/10 user group in order to determine individual user privileges.</p> <hr data-bbox="526 1012 1404 1016"/>
Local connection (laptop PC)	<ul data-bbox="451 1086 1404 1545" style="list-style-type: none"> <li>• Pentium II 300 MHz processor</li> <li>• Microsoft Windows 2000, Microsoft Windows NT 4.0 (service Pack 3 or later), Microsoft Windows 98 (release OS2 or above) or Microsoft Windows 95 (release OS2 or above)</li> <li>• 128 MB RAM</li> <li>• 200 MB free hard drive space</li> <li>• 16X CD - ROM</li> <li>• floppy 3.5" 1.44 MB</li> <li>• 56.6k modem</li> <li>• video card 8 MB</li> <li>• 1024 x 800 resolution, 256 colour display</li> <li>• serial port 115 200 bps</li> <li>• Q1CS Version 4.2; for 2G, Q1CS 4.1 is sufficient</li> <li>• Citrix NTC WinCenter client software</li> </ul>

### Summary

The Power System Management (PSM) software package includes PSM Manager (PSMMan).



### Steps

#### 1. Start PSM Manager installation.

Double click `setup.exe`, in the PSM CD, to start the PSM Manager installation.

The *PSM Manager installation wizard* window displays.

2. **Proceed to view the pre-requisites from the PSM Manager installation wizard welcome window .**

Click the *Next* button. The *PSM Manager pre-requisites* window displays.

3. **Ensure that the system requirements in the PSM Manager pre-requisites window are met.**

After reviewing the pre-requisites, click the *Next* button. The *PSM Manager license agreement* window displays.

4. **Accept the license agreement in the PSM Manager license agreement window.**

Click *Yes* to accept the agreement. The *PSM Manager setup type* window displays.

5. **Select setup type in the PSM Manager setup type window .**

Select *Full Setup* and click the *Next* button. The *PSM Manager start copying files* window displays.

6. **Review settings in the PSM Manager start copying files window .**

Click the *Next* button. The *PSM Manager setup status* window displays.

7. **Observe the installation progress in the PSM Manager setup status window.**

When the installation is 100% complete, the *PSM Manager installation complete* window displays.

8. **Exit the installation wizard in the PSM Manager installation complete window .**

Select the option to restart the computer immediately or restart later and click the *Finish* button to exit the wizard.

# 4

## Commissioning UltraSite EDGE BTS IBBU with Nokia PSM Node Manager Commissioning Wizard

### 4.1 Overview of Commissioning UltraSite EDGE BTS with IBBU

#### Before you start

Before commissioning, the physical installation of the BTS (units, cabling, antennas and radios) must be complete.

#### Summary

---



#### Caution

Nokia recommends that only properly trained and authorised personnel perform commissioning operations on any Nokia BTS.

---

The Nokia PSM and PSMMAN software is used when commissioning on site the Nokia UltraSite EDGE IBBU.

The PSM Commissioning Wizard in the PSMMAN SW guides you through the tasks to establish the necessary criteria for configuring the IBBU equipment.

The Wizard ensures that:

- Tasks are carried out in an ordered manner
- Tasks are automated where possible
- A Commissioning Report is produced

## Note

It is assumed here that you know how to operate the basic functions of the Windows based operating system that you are using, and that the PSMMan software and other associated software components are installed correctly.




Figure 3. Welcome window



## Steps

1. **Connect the LMP cable.**
2. **Power on the UltraSite EDGE BTS.**
3. **Install BTS Manager.**
4. **Install BTS Hub Manager.**

**5. Install PSM Manager.****6. Commission the UltraSite EDGE BTS with IBBU.**

- a. *Check the BIOS.*
- b. *Upgrade the BIOS.*
- c. *Upgrade CCUA software.*
- d. *Prepare to commission with PSM Node Manager.*
- e. *Connect to PSM Node Manager remotely.*
- f. *Connect to PSM Node Manager locally.*
- g. *Enter system type and set up details.*
- h. *Enter product code, serialisation and configuration details for SiSS node.*
- i. *Enter documentation, site details and cabinet mechanics details.*
- j. *Enter product code and serialisation details for rectifiers.*
- k. *Enter product code and serialisation details for batteries.*
- l. *Enter product code and serialisation details for climatic control unit.*
- m. *Check the configuration and complete commissioning.*
- n. *Print a commissioning report.*
- o. *Check power management settings.*
- p. *Check climatic control settings.*
- q. *Check system settings.*
- r. *Check identifications.*

## 4.2 Checking the BIOS of UltraSite EDGE BTS with IBBU

**Before you start**

Before the BIOS file is upgraded it is necessary to check the version of the BIOS file that is currently installed.

---

**Note**

The instructions below are for general reference. Refer to the applicable Release Notes for specific instructions.

---

**Steps**

1. **Ensure the UltraSite EDGE BTS has power applied and is switched ON.**

2. **Connect locally or remotely to Nokia PSM Node Manager.**

See *Connecting locally to Nokia PSM Node Manager* and *Connecting remotely to a Nokia PSM Manager.*

3. **Select *Configure* / *Identifications* / *Q1* on the menu toolbar.**

4. **Ensure the Identifications window is displayed.**

5. **Compare BIOS versions.**

Compare the version of the BIOS file installed against the version supplied on the CD-ROM that contains the PSMMAN software. If the installed version is an earlier version, then the BIOS file has to be upgraded. See *Upgrading the BIOS of UltraSite EDGE BTS IBBU*.

6. **Select *Cancel* to exit.**

## 4.3 Upgrading the BIOS of UltraSite EDGE BTS with IBBU

**Before you start**

When the CCUA software is upgraded it may also be necessary to upgrade the CCUA BIOS. You can use the PSMMAN Software Download Wizard to download the BIOS software. Special instructions may be issued for a BIOS upgrade.

**Summary****Caution**

Great care should be taken when upgrading the BIOS because, unlike the software, where two versions may be stored in separate banks, it is only possible to have one copy of the BIOS.

---



### Caution

The procedure for upgrading must be strictly adhered to as an incorrect software or BIOS upgrade can cause the CCUA to become disconnected from the network and, in the case of BIOS corruption, require returning to the factory.

### Note

The instructions below are for general reference. Refer to the applicable Release Notes for specific instructions.



### Steps

1. **Ensure that the UltraSite EDGE BTS has power applied and is switched ON.**

2. **Connect locally or remotely to Nokia PSM Node Manager.**

See *Connecting locally to Nokia PSM Node Manager* and *Connecting remotely to a Nokia PSM Manager.*

3. **Select *Maintenance* / *Software* / *Download* on the menu toolbar.**



Figure 4. Selecting the *Download* option in PSMMan Node Manager

4. **Ensure that the *Software Download Wizard Step 1 of 4 - Choose Target* window is displayed.**
5. **Make sure *Download to BIOS (Q1A or Ultrasite Family SiSS Controller)* is selected in the *BIOS* field.**

6. Click **Next >**.
  7. Make sure the **Software Download Wizard Step 2 of 4 - Select File** window is displayed.
  8. Ensure that the correct version of **CCUAbxxxx.swd** file is selected in the **Filename** box. Use **Browse...** to select the correct BIOS file.
  9. Click **Next >**.
  10. When PSMMan informs you about the change in data structure, click **OK**.
  11. Make sure the **Software Download Wizard Step 3 of 4 - Start Download** window is displayed.
  12. Ensure that the file details are correct.
  13. Click the **Start...** button.
- 

#### Note

After the BIOS file has been upgraded the Nokia PSM Node Manager will disconnect automatically from the CCUA.

---

14. Download the CCUA software file.

## 4.4 Upgrading CCUA software of UltraSite EDGE BTS with IBBU

### Before you start

---

#### Note

The instructions below are for general reference. Refer to the applicable Release Notes for specific instructions.

---



### Steps



1. **Ensure the UltraSite EDGE BTS IBBU has power applied and is switched ON.**
2. **Connect locally or remotely to Nokia PSM Node Manager.**

See *Connecting locally to Nokia PSM Node Manager* and *Connecting remotely to a Nokia PSM Manager..*

3. **Select *Maintenance* / *Software* / *Download* on the menu toolbar.**



Figure 5. Selecting the Download option in PSMMan Node Manager

4. **Make sure the Software Download Wizard Step 2 of 4 - Select File window is displayed.**

## Note

By checking the Automatically switch banks after download successfully completes box, the CCUA automatically switches to the upgraded software version upon completion of download.

5. **Make sure the correct version of CCUAxxxx.swd file is selected in the *Filename* box. Use *Browse...* to select the correct CCUA file.**
6. **Click *Next >*.**
7. **When PSMMan informs you about the change in data structures, click *OK*.**
8. **Make sure the *Software Download Wizard Step 3 of 4 - Start Download* window is displayed.**
9. **Ensure the file details are correct.**

10. Click the *Start...* button.
  11. Make sure the *Software Download Wizard Step 4 of 4 - Switch Software* window is displayed.
  12. Click the *Switch Now* button to switch banks to the new software.
- 

#### Note

Click the *Switch Later* button to continue running the current software and NOT switch banks. Generally, the *Switch Later* function is only used in special cases.

---

13. Click *Finish*.
14. Make sure that the *PSMMan Commissioning Wizard* is launched and the *Welcome and User details (Page 1 of 9)* window is displayed.

## 4.5 Preparing to commission UltraSite EDGE BTS with IBBU using Nokia PSM Node Manager

### Before you start

---

#### Note

The instructions below are for general reference. Refer to the applicable Release Notes for specific instructions.

---



### Steps

1. Ensure the UltraSite EDGE BTS IBBU has power supplied and is switched ON.
2. Connect locally or remotely to Nokia PSM Node Manager.

See *Connecting locally to Nokia PSM Node Manager* and *Connecting remotely to a Nokia PSM Manager*.

3. Select *Manage | Commissioning Wizard* on the menu toolbar.

4. At the **Welcome** screen, type in your **User Name** and any information that is specific to this node.

*Welcome and User Details Window of PSMMan Commissioning Wizard*

5. Click **Next>**.

## 4.6

## Connecting Remotely to Nokia PSM Node Manager



### Steps

1. Launch PSMMan
2. Select the **Manage, Connect** menu to launch the Nokia connection tool
3. In the **Connect to Node** window, select the the node connection name from the pull-down menu
4. Enter a valid Q1 address in the Node Parameters **Q1 Address** box

---

### Note

The Q1 address can be any valid address. It is recommended to use 4084 (and 4085 for IBBUs).

---




Figure 6. Setting node managers and connecting in PSMMan

5. Click **Connect**

## 4.7 Connecting locally to a PSM Node Manager

### Before you start

To use PSMMan locally and make changes to the power system via Q1IA, you will need to use a Q1IA LMP cable to connect your PSMMan laptop to the Local Management Port (LMP) of the Q1IA.

---

## Note

The Q1IA LMP is *NOT* the same as the MMI cable for CCUA. The Q1IA LMP is configured PIN 2 - 2, PIN 3 - 3 and PIN 5 - 5 (GND).

---

## Summary

The local connection procedure depends upon the type of power system you are connecting to.



## Steps

1. **Ensure that your PC is connected directly to the Q1IA LMP port.**



Figure 7. LMP Connection

2. **On the PC, launch the PSMMan Node Manager application from the Windows Task Bar.**
3. **Use the *Manage, Connect Locally* menu to connect to the Q1IA.**
4. **Click *Connect*.**

You have now established a connection and can continue with the commissioning procedures.

5. **Set the parameters (or comms port) as required.**

The NE Address can be set manually, and is 4084 by default. The Q1 Address for Q11A is 4084.

## 4.8 Entering System Type and Setup details of UltraSite EDGE BTS with IBBU



### Steps

1. **Make sure the *System Type and Setup Page (Page 2 of 9)* window is displayed.**

*System Type and Setup Page Window of PSMMan Commissioning Wizard*

2. **Select the correct configuration from the drop-down options for each field below:**

- *System Type*
- 

### Note

The *System Type* should be detected automatically. If the displayed system type is not correct, select the correct one from the drop-down list.

---

- *Q1 Bus / Polling Equipment*
- 

### Note

Do not select *Enable Auto-Baud Rate Detection*.

---

- *Batteries & Rectifiers*
- 

### Note

*Number of Batteries* works in multiples of 4. It does not refer to the number of battery strings.

---

- *Number of Rectifiers*
- *Rectifier Capacity (W)*

---

### Note

The rectifier power is the power output of an individual rectifier.

---

3. Click **Next>**.

## 4.9 Entering Product Code, Serialisation and Configuration details for SiSS Node of UltraSite EDGE BTS with IBBU



### Steps

1. Make sure the **Product Code and Serialisation Page (SiSS Node) & Configuration (Page 3 of 9)** window is displayed.

*Product Code and Serialisation Page [SiSS Node] & Configuration window of PSMMan Commissioning Wizard*

2. Make sure the details are correct in the **SiSS Details** field.
3. Select either **Indoor** or **Outdoor** in the **SiSS Indoor / Outdoor System** field.  
  
The selection depends on whether you have a Nokia UltraSite Support indoor or outdoor cabinet.
4. Select whether or not an external cabinet is fitted.
5. Select where the batteries are located.
6. Click **Next>**.

## 4.10 Entering Documentation, Site Details and Cabinet Mechanics details of UltraSite EDGE BTS with IBBU



### Steps

1. Make sure the **Documentation, Site Details & Cabinet Mechanics (CRM) Identification (Page 4 of 9)** window is displayed.

*Documentation, Site Details & Cabinet Mechanics (CRM) Identification window of PSMMan Commissioning Wizard*

2. **Ensure the details displayed in this window are correct. Make any required changes in this window, or click < Back until the applicable window in which to apply the corrections is displayed.**

---

#### Note

In the Cabinet Mechanics (CRM) Identification field, the details under cabinet number 1 must be completed, details for external cabinet accessed from pull down menu.

---

3. **Click Next.**

## 4.11 Entering Product Code and Serialisation details for Batteries of UltraSite EDGE BTS with IBBU



#### Steps

1. **Make sure the *Product Code and Serialisation Page (Climatic Control Unit) (Page 7 of 9)* window is displayed.**

*Product Code and Serialisation Page (Climatic Control Unit) of PSMMan Commissioning Wizard*

2. **Where applicable in the *CPU Serialisation (5th generation systems)* field, enter the *Serial Number* and the *Test Time Stamp*.**

---

#### Note

If an ADU is installed, enter the *Serial Number* and the *Test Time Stamp* (where applicable) in the *ADU Serialisation (5th generation systems)* field.

---

3. **Click Next.**



## 4.12 Entering Product Code and Serialisation details for Climatic Control Unit of UltraSite EDGE BTS with IBBU



### Steps

1. Make sure the *Configuration Summary & Commissioning (Page 8 of 9)* window is displayed.

*Configuration Summary & Commission window of PSMMan Commissioning Wizard*

2. Make sure the configuration information is correct.
3. Click *Commission*.
4. When the commissioning process is completed successfully, click *Next*.
5. PSMMan displays a *Commissioning Report*, that is saved automatically to the folder NOKIAMGR/PSM\_MGR/Configuration.

*SiSS Commissioning Report Page window of PSMMan Commissioning Wizard*

6. Click *Finish*.

---

### Note

The message *Commissioning Completed Successfully* does not mean that the IBBU system is fully functional. It indicates that all the commands that will enable it to function correctly have been accepted.

---

## 4.13 Checking the Configuration and completing commissioning of UltraSite EDGE BTS with IBBU



### Steps

1. Make sure the *Configuration Summary & Commissioning (Page 8 of 9)* window is displayed.

*Configuration Summary & Commission window of PSMMan  
Commissioning Wizard*

2. **Make sure the configuration information is correct.**
3. **Click *Commission*.**
4. **When the commissioning process is completed successfully, click *Next*.**
5. **PSMMan displays a Commissioning Report, that is saved automatically to the folder NOKIAMGR/PSM\_MGR/Configuration.**

*SiSS Commissioning Report Page window of PSMMan Commissioning  
Wizard*

6. **Click *Finish*.**

---

**Note**

The message Commissioning Completed Successfully does not mean that the IBBU system is fully functional. It indicates that all the commands that will enable it to function correctly have been accepted.

---

## 4.14 Printing a commissioning report of UltraSite EDGE BTS with IBBU

### Summary

Commissioning reports can be opened and printed out using PSMMan. When the commissioning process is complete, PSMMan displays a Commissioning Report, which you can save and print out. The reports are encrypted so they cannot be changed. If you do not have the correct level of user security, you can print them using the procedure below.



### Steps

1. **On the PC, launch the PSMMan application from the windows task bar.**
2. **Select *File / Open* on the menu tool bar.**

3. In the configuration folder open the file to be printed.
4. Select *File / Print*.




Figure 8. Select *File / Print*

### Note

NE 408420030708072124 (Translated NE = Network entity, 4084 = Q1 node address year month date time).

5. Print the commissioning report.



# 5

## Checking setting of UltraSite EDGE BTS IBBU

### 5.1

### Checking Power Management settings of UltraSite EDGE BTS with IBBU



#### Steps

1. **Make sure the UltraSite EDGE Support has power applied and is switched ON.**
2. **Connect locally or remotely to Nokia PSM Node Manager.**  
*See Connecting locally to Nokia PSM Node Manager and Connecting remotely to a Nokia PSM Manager..*
3. **On the menu toolbar, select *Configure | Power Management | Settings*.**  
*Power Management (Settings) window of PSMMMan*
4. **Select the tab applicable to the settings that have to be checked.**
5. **Make sure the settings are applicable to the site being setup.**  
  
Where the settings require changes, type the correction and then click *Send* after each modification.
6. **Where other settings require checking, select the applicable tab and check the settings.**
7. **Repeat where applicable.**
8. **When all checks have been made for the settings of this window, close the window.**

## 5.2 Checking Climatic Control settings of UltraSite EDGE BTS with IBBU

### Summary

This feature is available on all UltraSite systems but only available on some Talk-Family systems (it is currently available on ExtraTalk II systems) and it is controlled via the PDU (CSM software).

An example of the measurements that can be made are:

- the cabinet and battery temperatures.



### Steps

1. **Make sure the UltraSite EDGE Support has power applied and is switched ON.**

2. **Connect locally or remotely to Nokia PSM Node Manager.**

See *Connecting locally to Nokia PSM Node Manager* and *Connecting remotely to a Nokia PSM Manager*.

3. **On the menu toolbar, select *Configure | Climatic Control | Settings*.**

*Climatic Control (Settings) window of PSMMan*

4. **Select the tab applicable to the settings that have to be checked.**

5. **Make sure the settings are applicable to the site being setup.**

Where the settings require changes, type the correction and then click *Send* after each modification.

6. **Where other settings require checking, select the applicable tab and check the settings.**

7. **Repeat where applicable.**

8. **When all checks have been made for the settings of this window, close the window.**

## 5.3 Checking System settings of UltraSite EDGE BTS with IBBU



### Steps

1. **Make sure the UltraSite EDGE Support has power applied and is switched ON.**
2. **Connect locally or remotely to Nokia PSM Node Manager.**

*See Connecting locally to Nokia PSM Node Manager and Connecting remotely to a Nokia PSM Manager..*

3. **On the menu toolbar, select *Configure / System Settings*.**

*System Settings Window of PSMMan*

4. **Select the tab applicable to the settings that have to be checked.**
5. **Make sure the settings are applicable to the site being setup.**

Where the settings require changes, type the correction and then click *Send* after each modification.

6. **Where other settings require checking, select the applicable tab and check the settings.**
7. **Repeat where applicable.**
8. **When all checks have been made for the settings of this window, close the window.**

## 5.4 Checking Identifications of UltraSite EDGE BTS with IBBU



### Steps

1. **Make sure the UltraSite EDGE Support has power and is switched on.**
2. **Connect locally or remotely to Nokia PSM Node Manager.**

*See Connecting locally to Nokia PSM Node Manager and Connecting remotely to a Nokia PSM Manager..*

3. On the menu toolbar select *Configure / Identifications*.
4. The *Identifications* window will be displayed.

*Identifications window of PSMMan*

5. When all checks are made, close the window.



# 6 Nokia PSMMan commissioning windows

## 6.1 Commissioning procedure overview




Figure 9. Commissioning procedure overview

## 6.2 Welcome window of PSM Manager installation wizard




Figure 10. PSM Manager installation welcome

## 6.3 Pre-requisites window of PSM Manager installation wizard




Figure 11. PSM Manager installation pre-requisites

## 6.4 License Agreement window of PSM Manager installation wizard




Figure 12. PSM Manager installation license agreement

## 6.5 Setup Type window of PSM Manager installation wizard




Figure 13. PSM Manager installation setup type

## 6.6 Start Copying Files window of PSM Manager installation wizard




Figure 14. PSM Manager installation start copying files

## 6.7 Setup Status window of PSM Manager installation wizard




Figure 15. PSM Manager installation setup status

## 6.8 Installation complete window of PSM Manager installation wizard




Figure 16. PSM Manager installation complete



## 6.9 Choose Target window of PSMMAN Software Download Wizard




Figure 17. Software Download Wizard Step 1 of 4 - Choose Target

## 6.10 Select File window of PSMMan Software Download Wizard




Figure 18. Software Download Wizard Step 2 of 4 - Select File

## 6.11 Start Download window of PSMMAN Software Download Wizard



Figure 19. Software Download Wizard Step 3 of 4 - Start Download

## 6.12 Switch Software window of PSMMan Software Download Wizard




Figure 20. Software Download Wizard Step 4 of 4 - Switch Software

## 6.13 Welcome and User Details window of PSMMan Commissioning Wizard





Figure 21. Welcome and User Details (Page 1 of 9)

## 6.14 System Type and Setup Page window of PSMMan Commissioning Wizard



**System Type and Setup Page (Page 2 of 9)**

**System Type**  
The site support system is already configured with system type as indicated below. Click 'Next' if you wish to reconfigure the site support system with the detected system type, or otherwise select the required system type.

System Type: Nokia UltraSite IBBU

**Auto-Baud Detection**  
Enable Auto-Baud rate detection (if applicable): ☒

**Batteries & Rectifiers**  
Please select the number of individual batteries (or 'blocks'), the number of rectifiers fitted to the system and the default rectifier capacity. (Choose the lowest capacity if a mix of rectifiers are fitted).

Number of Batteries: 4

Number of Rectifiers: 12 Rectifier Capacity (W): 1300

< Back **Next >** Cancel Help

Figure 22. System Type and Setup Page (Page 2 of 9)



## 6.15 Product Code and Serialisation Page [SiSS Node] & Configuration window of PSMMan Wizard

Product Code and Serialisation Page [SiSS Node] & Configuration (Page 3 of 9)

Please confirm/supply the following site support system details:

**SiSS Details**

Serial Number: 12345678

Equipment Type: PSM SiSS

Equipment Name: Nokia UltraSite IBBU

Family Type: Nokia UltraSite

**SiSS Indoor / Outdoor System**

Is the SiSS an: ☒ Indoor System ☐ Outdoor System

**SiSS External Cabinet Configuration**

Please indicate where batteries are located. WARNING: your selection will determine which temperature sensors are used for battery management.

Main Cabinet: ☒ External Cabinet 3: ☐

External Cabinet 1: ☐ External Cabinet 4: ☐

External Cabinet 2: ☐

< Back Next > Cancel Help

Figure 23. Product Code and Serialisation Page [SiSS Node] & Configuration (Page 3 of 9)

## 6.16 Documentation, Site Details & Cabinet Mechanics [CRM] Identification window of PSMMan Commissioning Wizard

Documentation, Site Details & Cabinet Mechanics [CRM] Identification (Page 4 of 9)

Please confirm/supply the following documentation, site & CRM details.

Documentation Details:

User Guide Code: 1.1.0 User Guide Version: 1.1.0

Site Details:

Site Name: Customer Settings

Group Name: Customer Settings

Site Location: Customer Settings

Cabinet Mechanics [CRM] Identification:


	Main (SiSS) Cabinet	External Cabinet
Serial Number:	XXXXXXXXXX	XXXXXXXXXX
Hardware Version:	CS71501.03	CS71550.03
ID & Firmware Version:	TBD	TBD
Manufacturer Name:	Scanfil	Scanfil

< Back Next > Cancel Help

Figure 24. Documentation, Site Details & Cabinet Mechanics [CRM] Identification (Page 4 of 9)



## 6.17 Product Code and Serialisation Page [Batteries] window of PSMMan Commissioning Wizard



Product Code and Serialisation Page [Batteries] (Page 6 of 9)

Please confirm/supply the serialisation for the site support system's batteries (i.e.: individual batteries or 'blocks').

Serialisation

Battery Number: 1

Serial Number: XXXXXXXXXX

Hardware Version: CS71366.14

Id & Firmware Version: TBD

Manufacturer Name: Hawker

< Back Next > Cancel Help

Figure 25. Product Code and Serialisation Page [Batteries] (Page 6 of 9)

## 6.18 Product Code and Serialisation Page [Climatic Control Unit] window of PSMMan Commissioning Wizard

Product Code and Serialisation Page (Climatic Control Unit) (Page 7 of 9)

Please confirm/supply the product codes, versions and serial numbers for the system's climatic control unit(s).

CCU Serialisation (3rd generation systems)

Product Code:

Product Version:

Serial Number:

CCU Serialisation (5th generation systems)

Serial Number:

Test Time Stamp:

ADU/PDU Serialisation (5th generation systems)

Serial Number:

Test Time Stamp:

< Back   Next >   Cancel   Help

Figure 26. Product Code and Serialisation Page (Climatic Control Unit) (Page 7 of 9)

## 6.19 Configuration Summary & Commission window of PSMMan Commissioning Wizard




Figure 27. Configuration Summary & Commission (Page 8 of 9)

## 6.20 SiSS Commissioning Report Page window of PSMMan Commissioning Wizard




Figure 28. SiSS Commissioning Report Page (9 of 9)

## 6.21 Power Management (Settings) window of PSMMan

**Power Management [Settings]**

Batteries | Rectifiers | Charging | Boost | Alarms

Details

Number of Batteries: 4

Number of Strings: 1

Battery String Capacity (Ah): 40

Disconnect/Reconnect

High Voltage Disconnect (V):

High Voltage Reconnect (V):

Low Voltage Disconnect (V): 39.0

Low Voltage Reconnect (V): 50.0

☐ Auto-refresh Refresh Send Cancel Help

Figure 29. Power Management (Settings)

## 6.22 Climatic Control (Settings) window of PSMMan




Figure 30. Climatic Control (Settings)

## 6.23 System Settings window of PSMMAN




Figure 31. System Settings

## 6.24 Identifications window of PSMMan

Identifications

SiSS Instal Q1 CCU BATA LTE Battery CRM ADU

Standard Identification Information

Equipment Type: PSM SiSS

Equipment Name: Nokia UltraSite IBBU

Family Type: Nokia Ultrasite

Site Name: Customer Settings

Group Name: Customer Settings

Site Location: Customer Settings

User Guide

User Guide Code: 1.1.0 User Guide Version: 1.1.0

☐ Auto-refresh Refresh Send Cancel Help

Figure 32. Identifications



# 7

## Glossary

### 7.1 Glossary for UltraSite EDGE BTS

#### 7.1.1 Abbreviations and acronyms

This section lists abbreviations and acronyms used throughout Nokia UltraSite EDGE Solution documentation.

AC	Alternating Current
ACFU	AC Filter Unit
A/D	Analog/Digital
ADC	Analog to Digital Converter
ADUA	AC/DC control and distribution unit for Integrated Battery Backup (IBBU)
AGC	Automatic Gain Control
ALS	Automatic Laser Shutdown
AMR	Adaptive Multi-Rate coding
ANSI	American National Standards Institute
ANT	Antenna connector
ARFN	Absolute Radio Frequency Channel Number
ASIC	Application Specific Integrated Circuit
ATM	Asynchronous Transfer Mode

AWG	American Wire Gauge
AXC	ATM cross-connect
AXU	ATM cross-connect unit
BAPT	Bundesamt für Post und Telekommunikation Telecommunications advisory agency of Federal Republic of Germany
BATx	Rectifier for battery backup
BBAG	12 V battery for Integrated Battery Backup (IBBU)
BB2x	Transceiver Baseband unit <ul style="list-style-type: none"> <li>• BB2A for GSM</li> <li>• BB2E for GSM/EDGE</li> </ul>
BCCH	Broadcast Control Channel
BCF	Base Control Function
BER	Bit Error Ratio  The ratio of the number of bit errors to the total number of bits transmitted in a given time interval.
BIST	Built-In Self Test  A technique that provides a circuit the capability to carry out an implicit test of itself.
BOIx	Base Operations and Interfaces unit
BPxN	Bias Tee without VSWR monitoring <ul style="list-style-type: none"> <li>• BPDN for GSM 900/1800/1900</li> <li>• BPxV Bias Tee with VSWR monitoring</li> <li>• BPGV for GSM 900</li> <li>• BPDV for GSM 1800/1900</li> </ul>
BS	British Standards
BSC	Base Station Controller

BSS	Base Station Subsystem
BTS	Base Transceiver Station (Base Station)
CC	Cross-Connection
CCCH	Common Control Channel
CCITT	Comité Consultatif International Télégraphique et Téléphonique  International Telegraph and Telephone Consultative Committee (Telecommunications advisory agency of France)
CCUA	Cabinet Control Unit
CDMA	Code Division Multiple Access  A technique in which the radio transmissions using the same frequency band are coded in a way that a signal from a certain transmitter can be received only by certain receivers
CE	Cable Entry; Consumer Electronics; Conformit Européen (European Conformity) CH Channel
CHDSP	Channel Digital Signal Processor
CN	Change Note  A short trouble management document in a specified form sent to a customer about a modification in a product
CRC	Cyclic Redundancy Check  A method for detecting errors in data transmission.
CRMx	Core Mechanics for Nokia UltraSite EDGE Base Station Indoor and Outdoor cabinet <ul style="list-style-type: none"><li>• CRMA for Indoor and Outdoor cabinets</li><li>• CRMB for Site Support cabinets</li><li>• CRMC for Midi Indoor and Outdoor cabinets</li></ul>
CSC	Customer Services Centre
D/A	Digital/Analog

DC	Direct Current
DCS	Digital Cellular System
DDS	Direct Digital Synthesis
	The frequency synthesis in which logic and memory are used to digitally construct the desired output signal, and a digital-to-analogue converter is used.
DL	(Downlink)
	The direction of transmission in which the BTS is the transmitting facility and the mobile station is the receiving facility.
DIP	Dual In-line Package
DRAM	Dynamic Random Access Memory
DRX	Discontinuous Reception
DSP	Digital Signal Processor
DTX	Discontinuous Transmission
DU2A	Dual Band Diplex Filter unit for GSM 900/1800
DVxx	Dual Variable Gain Duplex Filter unit <ul style="list-style-type: none"> <li>• DVTB for GSM/EDGE 800</li> <li>• DVTC for GSM/EDGE 800 co-siting</li> <li>• DVGA for GSM/EDGE 900</li> <li>• DVHA for GSM/EDGE 900 customer-specific H band</li> <li>• DVJA for GSM/EDGE 900 customer-specific J band</li> <li>• DVDC for GSM/EDGE 1800</li> <li>• DVDA for GSM/EDGE 1800 A band</li> <li>• DVDB for GSM/EDGE 1800 B band</li> <li>• DVPA for GSM/EDGE 1900</li> </ul>
E1	European Digital Transmission Format Standard (2.048 Mbit/s)
EAC	External Alarms and Control

EC	European Community
EDGE	Enhanced Data rates for Global Evolution
EEC	European Economic Community
EEPROM	Electrically Erasable Programmable Read Only Memory
EMC	Electromagnetic Compatibility
EMI	Electromagnetic Interference
EMP	Electromagnetic Pulse
EN	European Norm
EQDSP	Equaliser Digital Signal Processor
ESD	Electrostatic Discharge
ET	Exchange Terminal
ETSI	European Telecommunications Standards Institute
Ext.	External
FACCH	Fast Associated Control Channel
FACH	Forward Access Channel
FCC	Federal Communications Commission  The United States federal agency responsible for the regulation of interstate and international communications by radio, television, wire, satellite, and cable.
FC E1/T1	Wireline transmission unit (75 [ohm] E1, 120 [ohm] E1, or 100 [ohm] T1) of Nokia UltraSite EDGE Base Station without cross-connection capability.
FCLK	Frame Clock
FET	Field Effect Transistor
FHS	Frequency Hopping Synthesiser

FIFP	Forwarded Intermediate Frequency Power
FIKA	+24 VDC Installation Kit
FPGA	Field Programmable Gate Array
FXC E1	Wireline transmission unit (75 [ohm] E1) with four line interfaces to the 2 Mbit/s (E1) transmission line; cross-connection capability at 8 kbit/s level.
FXC E1/T1	Wireline transmission unit (120 [ohm] E1 or 100 [ohm] T1) with four line interfaces to the 2 Mbit/s (E1) or 1.5 Mbit/s (T1) transmission line; cross-connection capability at 8 kbit/s level.
FXC RRI	Radio link transmission unit (radio indoor unit) with cross-connection capability at 8 kbit/s level.  Used with MetroHopper Radio and FlexiHopper Microwave Radio.
Gb	Interface between RNC and SGSN
GMSK	Gaussian Minimum Shift Keying
GND	Ground; Grounding (protective earthing).  See Grounding and PE.
GPRS	General Packet Radio Service
GSM	Global System for Mobile communications <ul style="list-style-type: none"><li>• GSM 800 GSM 800 MHz frequency band</li><li>• GSM 900 GSM 900 MHz frequency band</li><li>• GSM 1800 GSM 1800 MHz frequency band</li><li>• GSM 1900 GSM 1900 MHz frequency band</li></ul>
GUI	Graphical User Interface
HDLC	High-level Data Link Control
HETA	Base station cabinet heater
HO	Handover

	The action of switching a call in progress from one radio channel to another, to secure the continuity of the established call
HSCSD	High-Speed Circuit Switched Data
HV	High Voltage
HW	Hardware
	Specifically, electronic equipment supporting data transmission and processing tasks, and the electrical and mechanical devices related to their operation
IAKx	Indoor Application Kit for Nokia UltraSite EDGE Base Station <ul style="list-style-type: none"><li>• IAKA for UltraSite Indoor cabinet</li><li>• IAKC for UltraSite Midi Indoor cabinet</li></ul>
IBBU	Integrated Battery Backup
IC	Integrated Cell
ICE	Intelligent Coverage Enhancement
ID	Identification; Identifier IE Information Element
	The basic unit of a transaction capabilities application part (TCAP) message.
IEC	International Electrotechnical Commission
IEEE	Institute of Electrical and Electronics Engineers, Inc.
IF	Intermediate Frequency
IFM	Interface Module
IFU	Interface unit
ILKA	Indoor Lock Kit
ILMT	Integrated Local Management Tool

IMA	Inverse Multiplexed ATM
IP	Ingress Protection
IRPA	International Radiation Protection Association
ISDN	Integrated Services Digital Network
ISHO	Inter-system handover  The handover from one system to another.
ISO	International Organization for Standardization
ITU	International Telecommunication Union
L2	AC Phase 2
L3	AC Phase 3
Iu	The interconnection point between the RNC and the Core Network
Iub	Interface between the RNC and node B
Iubis	Interface between the RNC and the BTS
Iur	The logical interface for the interconnection of two radio network controller (RNC) components of the UMTS terrestrial radio access network (UTRAN) system
JIS	Japanese Industrial Standard
LAN	Local Area Network  A data transmission network covering a small area.
LAPD	Link Access Protocol on D-channel between the BSC and BTS
LED	Light Emitting Diode
LMB	Local Management Bus
LMP	Local Management Port



LNA	Low-Noise Amplifier
LO	Local Oscillator
LTE	Line Terminal Equipment
LV	Low Voltage
LVD	Low Voltage Disconnect
LVDS	Low Voltage Differential Signalling
LVTTL	Low Voltage Transistor Transistor Logic
M2xA	2-way Receiver Multicoupler unit <ul style="list-style-type: none"><li>• M2LA for GSM/EDGE 800/900</li><li>• M2HA for GSM/EDGE 1800/1900</li><li>• M6xA 6-way Receiver Multicoupler unit</li><li>• M6LA for GSM/EDGE 800/900</li><li>• M6HA for GSM/EDGE 1800/1900</li></ul>
MAC	Medium Access Control function, handles the channel allocation and multiplexing, that is, the use of physical layer functions.
MCLG	Master Clock Generator
MDF	Main Distribution Frame
MHA	Masthead Amplifier
MMI	Man-Machine Interface
MML	Man-Machine Language <p>A text-based command language with a standardised structure, designed to facilitate direct user control of a system.</p>
MNxx	Masthead Amplifier specific to Nokia UltraSite EDGE Base Station <ul style="list-style-type: none"><li>• MNGA for GSM/EDGE 800/900</li><li>• MNDA for GSM/EDGE 1800 A band</li><li>• MNDB for GSM/EDGE 1800 B band</li></ul>

	<ul style="list-style-type: none"> <li>• MNPA for GSM/EDGE 1900 A band</li> <li>• MNPB for GSM/EDGE 1900 B band</li> <li>• MNPC for GSM/EDGE 1900 C band</li> </ul>
MPT	<p>Ministry of Posts and Telecommunications</p> <p>Telecommunications regulatory agency of Great Britain.</p>
MS	<p>Mobile Station</p> <p>User equipment which uses a radio connection, and which can be used in motion or at unspecified points. This is usually a mobile phone.</p>
MSC	<p>Mobile Switching Centre</p> <p>The mobile network element which performs the switching functions in its area of operation, and controls cooperation with other networks.</p>
MTBF	Mean Time Between Failure
NCRP	National Council on Radiation Protection and Measurements
NCU	Node Control Unit
NEBS	Network Equipment Building Systems
NED	Nokia Electronic Documentation
NMS	Network Management System
O&M	Operation and Maintenance
OAKB	Cable entry kit for BTS co-siting
OAKx	<p>Outdoor Application Kit for Nokia UltraSite EDGE Base Station</p> <ul style="list-style-type: none"> <li>• OAKA for UltraSite Outdoor cabinet</li> <li>• OAKC for UltraSite Midi Outdoor cabinet</li> <li>• OAKD for UltraSite Midi Outdoor to Talk-family Co-siting</li> </ul>
OBKA	Outdoor Bridge Kit

OCXO	Oven Controlled Crystal Oscillator  An oscillator in which the crystal and critical circuits are temperature-controlled by an oven.
OEKA	Outdoor (cable) Entry Kit
OFKA	Outdoor Air Filter Kit
OFKC	MIDI Outdoor Air Filter Kit
OMU	Operation and Maintenance Unit
OMUSIG	OMU Signalling
OVP	Over-Voltage Protection
PC	Personal Computer
PCB	Printed Circuit Board
PCM	Pulse Code Modulation
PE	Protective earthing (grounding)  See GND and Grounding.
PFC	Power Factor Correction
PLL	Phase-Locked Loop
Point-to-point	Transmission between two fixed points
PSM	Power System Management
PWM	Pulse Width Modulation
PWSx	AC/DC Power Supply unit <ul style="list-style-type: none"><li>• PWSA for 230 VAC input</li><li>• PWSB for -48 VDC input</li><li>• PWSC for +24 VDC input</li></ul>
Q1	Nokia proprietary transmission management protocol

RACH	Random Access Channel
RAKE	A receiver capable of receiving and combining multipath signals
RAM	Random Access Memory
RAN	Radio Access Network
	A third generation network that provides mobile access to a number of core networks of both mobile and fixed origin.
RCD	Residual Current Device
RF	Radio Frequency
RFF	Radio Frequency Fingerprinting
RIFP	Reflected Intermediate Frequency Power
RLE	Radio Link Equipment
RNC	Radio Network Controller
	The network element in a radio access network which is in charge of the use and the integrity of radio resources.
ROM	Read Only Memory
RRI	Radio Relay Interface
RSSI	Received Signal Strength Indicator
RTC	Remote Tune Combining
RTxx	Remote Tune Combiner
	<ul style="list-style-type: none"> <li>• RTGA for GSM/EDGE 900</li> <li>• RTHA for GSM/EDGE 900 H band</li> <li>• RTJA for GSM/EDGE 900 J band</li> <li>• RTDC for GSM/EDGE 1800</li> <li>• RTDA for GSM/EDGE 1800 A band</li> <li>• RTDB for GSM/EDGE 1800 B band</li> <li>• RTPA for GSM/EDGE 1900</li> </ul>

RTN	Return
RX	Receiver; Receive
SCF	Site Configuration File
SCT	Site Configuration Tool
SDCCH	Stand-alone Dedicated Control Channel
SDH	Synchronous Digital Hierarchy
SMB	Sub-Miniature B Connector
SMS	Short Message Service
SSS	Site Support System
STM	Synchronous Transport Module
STM-1	Synchronous Transport Module (155 Mbit/s)
SW	Software
Sync	Synchronization  The process of adjusting corresponding significant instances of signals, in order to obtain the desired phase relationship between these instances.
T1	North American Digital Transmission Format Standard (1.544 Mbit/s)
TC	Transcoder
TCH	Traffic Channel  The logical radio channel that is assigned to a base transceiver station and is primarily intended for conversation.
TCP/IP	Transport Control Protocol/Internet Protocol
TCS	Temperature Control System
TDMA	Time Division Multiple Access

TE	Terminal Equipment
	Equipment that provides the functions necessary for user operation of the access protocols.
TMS	Transmission Management System
	The network system for managing equipment settings, and for centralised retrieval of statistics and alarm information from transmission equipment connected to the system.
TS	Time Slot
	A cyclic time interval that can be recognised and given a unique definition.
TRE	Transmission Equipment
TRX	Transceiver
TRXSIG	TRX Signalling
TS	Time Slot
TSxx	Transceiver (RF unit), specific to Nokia UltraSite EDGE Base Station
	<ul style="list-style-type: none"> <li>• TSTB for GSM/EDGE 800</li> <li>• TSGA for GSM 900</li> <li>• TSGB for GSM/EDGE 900</li> <li>• TSDA for GSM 1800</li> <li>• TSDB for GSM/EDGE 1800</li> <li>• TSPA for GSM 1900</li> <li>• TSPB for GSM/EDGE 1900</li> </ul>
TTL	Transistor Transistor Logic
TX	Transmitter; Transmit
UC	Unit Controller
UI	User Interface
UL	Underwriters Laboratories

UL (Uplink)	<p>The direction of transmission in which the mobile station is the transmitting facility and the BTS is the receiving facility.</p> <ul style="list-style-type: none"><li>• 2-way uplink diversity - The function by which a BTS uses two antennas and two receivers simultaneously on a single channel to obtain improved overall BTS receiver sensitivity in an environment that is subject to random multipath fading.</li><li>• 4-way uplink diversity - The function by which a BTS uses four antennas and four receivers simultaneously on a single channel to obtain improved overall BTS receiver sensitivity in an environment that is subject to random multipath fading.</li></ul>
UMTS	Universal Mobile Telecommunications System
UTRAN / UMTS	<p>Terrestrial Radio Access Network</p> <p>A radio access network (RAN) consisting of radio network controllers (RNCs) and base transceiver stations (BTSs). It is located between the Iu interface and the wideband code division multiple access (WCDMA) radio interface.</p>
UPS	Uninterruptible Power Supply
VC	Virtual Channel
VCO	<p>Voltage Controlled Oscillator</p> <p>An oscillator for which a change in tuning voltage results in a predetermined change in output frequency.</p>
VLL	Line-to-Line Voltage
VP	<p>Virtual Path</p> <p>The unidirectional transport of ATM cells belonging to virtual channels that are associated by a common identifier value.</p>
VPCI	<p>Virtual Path Connection Identifier</p> <p>An identifier which identifies the virtual path connection between two B-ISDN ATM exchanges, or between a B-ISDN ATM exchange and a B-ISDN user.</p>

VPI	Virtual Path Identifier
	An identifier which identifies a group of virtual channel links at a given reference point that share the same virtual path connection.
VSWR	Voltage Standing Wave Ratio
	The ratio of maximum to minimum voltage in the standing wave pattern that appears along a transmission line. It is used as a measure of impedance mismatch between the transmission line and its load.
VXxx	Transmission unit, specific to Nokia UltraSite EDGE Base Station
	<ul style="list-style-type: none"> <li>• VXEa for FC E1/T1</li> <li>• VXRA for FC RRI</li> <li>• VXRb for Fxc RRI</li> <li>• VXTa for Fxc E1</li> <li>• VXTb for Fxc E1/T1</li> </ul>
WAF	Wideband Antenna Filter unit
WAM	Wideband Application Manager unit
WBC	Wideband Combining unit
WCC	Wideband Cabinet Core
WCDMA	Wide band Code Division Multiple Access
	A spread spectrum CDMA technique used to increase the capacity and coverage of wireless communication networks.
WCH	Wideband Cabinet Heater
WCxA	Wideband Combiner, specific to Nokia UltraSite EDGE Base Station
	<ul style="list-style-type: none"> <li>• WCGA for GSM/EDGE 800/900</li> <li>• WCDA for GSM/EDGE 1800</li> <li>• WCPA for GSM/EDGE 1900</li> </ul>



WEK	Wideband Extension Kit
WFA	Wideband Fan
WHX	Wideband Heat Exchanger
WIC	Wideband Input Combiner
WIK	Wideband Indoor Kit
WOC	Wideband Output Combiner
WOK	Wideband Outdoor Kit
WPA	Wideband Power Amplifier unit
WPS	Wideband Power Supply unit
WSC	Wideband System Clock
WSM	Wideband Summing and Multiplexing unit
WSP	Wideband Signal Processor unit
WTR	Wideband Transmitter and Receiver

### 7.1.2 Terms

This section provides definitions for terms used throughout Nokia UltraSite Solution documentation.

**Abis Interface**      Interface between a Base Transceiver Station (BTS) and the Base Station Controller (BSC) and between two BTSs.

**Absolute radio frequency channel number**  
See absolute radio frequency number.

**Absolute radio frequency number; absolute radio frequency channel number; ARFN; ARFCN**  
Radio frequency used in connection with, for example, mobile originating and terminating test calls.

**Adaptive multi-rate speech codec; AMR speech codec; AMR codec; AMR**  
Speech codec which adapts its operation optimally according to the prevailing channel conditions.

Air Interface	Interface between MS and BTS.
Alarm	Announcement given to the operating personnel about abnormal functioning of the system or about a failure, or an indication of the degradation of the service level or reliability.
Alarm Status	Classification of the severity of an alarm, such as Critical, Major, Minor, and Information.
Alternating current; AC	A periodic current having a mean value zero.
Analogue-to-digital converter; Analog-to-digital converter /US/; A/D converter; ADC	A device which converts an analogue input signal to a digital output signal carrying equivalent information.
Application-specific integrated circuit; custom circuit; custom IC; ASIC	Integrated circuit which is designed for a specific application and a specific customer and which is not available to other customers.
ATM connection control; connection control; CC	Function that keeps track of connection resources and based on those handles the operations related to different kind of cross-connections.
ATM inverse multiplexing	See inverse multiplexing for ATM.
Backplane	Connector board at the back of Nokia UltraSite cabinets to which plug-in units are directly connected. See also BATA backplane and RFU backplane.
Base station	See base transceiver station.
Base station controller; BSC	Network element in the public land mobile network (PLMN) for controlling one or more base transceiver stations (BTS) in the call set-up functions, in signalling, in the use of radio channels and in various maintenance tasks.
Base station system; BSS	System of base stations (BSs) and base station controllers which is viewed by the mobile services switching centre (MSC) through a single interface.

Base transceiver station; base station; BTS; BS	Network element in a mobile network responsible for radio transmission and reception to or from the mobile station.
BATA backplane	Additional backplane required in a Site Support cabinet when using 12 rectifiers.
Bias Tee	Unit that provides DC power for an associated MHA unit.
Cabinet Control Unit	Module of the ADUA or ADUB that manages battery control, climatic control, alarm reporting, and serial and version number reporting for the IBBU or Nokia UltraSite Support cabinet. The CCU connects to the BOIx with Q1-bus.
Cell	Coverage area of a given BTS where transmission is acceptably received.
Cell breathing	Variation of the cell coverage area; depends on the interference and power requirements.
Cellular Network	Two or more base stations connected together to provide an area of coverage for Mobile Stations (MS).
CENELEC	Comité Européen de Normalisation ELECTrotechnique. European Committee for Electrotechnical Standardization.
Chain Connection	Transmission solution in which the BTSs are interconnected through a chain, and the first BTS in the chain is connected to the BSC. See Loop Connection, Multidrop Connection, and Star Connection.
Chip	Signal element.
Chip rate	Number of chips transmitted in one second.
Commissioning	Tasks performed to enable the BTS to be connected to the network. Includes operational tests and configuring of the transmission equipment.
Coverage Area	See Cell.

Cross-connection	Connection between input and output ports of a network element.
Cross-connection bank	Information base that defines the cross-connections of a network element. The network element contains two or more banks, one of which is always active.
Custom circuit	See application-specific integrated circuit.
Custom IC	See application-specific integrated circuit.
D-bus	Bus used for traffic communication between the transmission units and BB2x units (D1-bus) and for internal O&M communication with the BOIx, BB2x, and RTxx units (D2-bus).
Despreading	The received wideband signal is modulated with the spreading code to get a narrowband signal after the multipath propagation in spread spectrum systems.
Digital signal processor; DSP	A processor designed for signal handling, resembling an ordinary microprocessor.
Discontinuous reception; DRX	Means of saving battery power (for example in hand-portable units) by periodically and automatically switching the mobile station receiver on and off.
Discontinuous transmission; DTX	Feature which enables saving battery power (for example in hand-portable units) and reducing interference by automatically switching the transmitter off when no speech or data are to be sent.
Downlink Diversity	See Frequency Hopping.
Earthing	See Grounding.
F-bus	Frequency Hopping bus. See Frequency Hopping.
Finger; rake finger; RAKE finger	Receiver unit that despreads one multipath signal.

Four-way uplink diversity; 4-way uplink diversity	Function by which a base transceiver station (BTS) uses four antennas and four receivers simultaneously on a single channel to obtain improved overall BTS receiver sensitivity in an environment that is subject to random multipath fading.
Forward link	See downlink.
Flash memory	Nonvolatile, electronically writable memory, similar to EEPROM in function, but which must be erased in blocks.
Flexbus	Bidirectional coaxial cable that carries up to 16 x 2 Mbit/s signals and power between transmission equipment, such as a radio outdoor and indoor unit.
Frequency-change oscillator	See local oscillator.
Frequency Hopping	Function in which a BTS swaps two transmitters on a single channel to obtain improved overall MS receiver sensitivity in a system that is subject to random fading.
Gain	Signal amplification, expressed in dBi—decibels over a theoretic, isotropic, and uniformly radiating antenna.
Grounding	Protecting the equipment and the users against lightning and surges through the external connections.
I <sup>2</sup> C-bus	Integrated Inter Cell communication bus used for polling, autodetection, version and serial number management, temperature polling, and alarm collection in units without a microprocessor.
Handover	The handover occurs between two cells; the signal goes through one base station or base station sector at a time.
Human-machine interface; man-machine interface; HMI; MMI	A subsystem or function which provides user interface functions in a man-machine language.
Installation	Tasks performed to enable the BTS to be mounted at the site.
Integration	Tasks performed to make the BTS functional in the cellular network. Includes making test calls.

**Inter-frequency handover**

Handover where the new carrier frequency is different from the current one.

**Inter-system handover**

Handover from one system to another, e.g. between a 3rd generation system and GSM.

**Inverse multiplexing for ATM; ATM inverse multiplexing; inverse multiplexing; IMA**

The transmission method in which ATM cells in a cell stream are divided across several physical E1 links on a cell-by-cell basis, and then reassembled at the receiving end without affecting the original cell order.

**Loop connection**

Transmission solution in which BTSs are interconnected in a loop. For example, the first and last BTSs are connected to the BSC. See Chain Connection, Multidrop Connection, and Star Connection.

**Macrocellular**

Application that covers large areas with a cell radius of 1 to 10 km (0.6 to 6 miles). The coverage area is achieved when the antenna is installed high and off the ground.

**Maximum ratio combining**

A signal combining technique in which each signal is multiplied by a weight factor that is proportional to the signal amplitude: the strong signals are further amplified, while the weak signals are attenuated.

**Microcellular**

Application that typically covers areas with a cell radius of 100 m to 1 km (327 feet to 0.6 miles). The antennas are installed below rooftop level.

**Microwave radio**

Radio equipment for establishing an aligned and fixed radio connection between two points.

**Midi**

Indoor or Outdoor cabinet with up to six TRXs.

**Multidrop Connection**

Transmission solution in which one or more BTS chains are connected to one BTS that is connected to the BSC. See Chain Connection, Loop Connection, and Star Connection.

**Network Element**

Any equipment that can be managed, monitored, or controlled in a telecommunications network.

**Network Topology**

Method of transmission between the cells of a network. Examples of transmission solutions are chain, loop, multidrop, and star connections.

**Node Manager**

A feature of Power System Management (PSM), the Node Manager software called PSMMan is used to control network elements, or nodes, of the Site Support System.

**Nokia FlexiHopper**

Nokia family of Flexbus-compatible microwave radios for the 13, 15, 18, 23, 26, and 38 GHz frequency bands, in which the radio transmission capacity can be selected using software. The radio transmission capacity of Nokia FlexiHopper can be 2 x 2, 4 x 2, 8 x 2, or 16 x 2 Mbit/s.

Nokia FlexiHopper outdoor unit can be used with different indoor units: FIU 19, RRIC, FC RRI, and FXC RRI.

**Nokia Hopper Manager**

PC software application used for controlling and monitoring Nokia FlexiHopper and Nokia MetroHopper radios connected to FIU19 or RRIC indoor units.

**Nokia MetroHopper**

Nokia Flexbus-compatible radio for the 58 GHz frequency band that does not require coordinated frequency planning. The main use of Nokia MetroHopper is to provide 4 x 2 Mbit/s, point-to-point wireless access for Nokia MetroSite BTS and Nokia MetroHub.

Nokia MetroHopper outdoor unit can be used with different indoor units: FIU 19, RRIC, FC RRI, and FXC RRI.

**Nokia MetroHub**

Nokia's compact transmission node with cross-connection and grooming functions, such as FXC RRI. Nokia MetroHub contains up to five transmission units.

**Nokia MetroSite GSM BTS**

Nokia's compact four-TRX GSM base station for Nokia MetroSite capacity solution. Nokia MetroSite GSM BTS can contain one transmission unit.

Nokia Q1 Connection Tool	Program that makes connection and node definitions for identifying objects on a Nokia Q1 managed network. See Q1.
Nokia UltraSite	Multimedia coverage and capacity macrocellular base station.
Omnidirectional Cell	Cell with a 360° sector; also known as standard cell.
Operator	Telecommunications company running telecommunications services in a specific geographical area.
PCM time slot	1.5 Mbit/s PCM circuit is divided into twenty-four 64 kbit/s time slots.  2 Mbit/s PCM circuit is divided into thirty-two 64 kbit/s time slots.
Peltier elements	Elements that absorb or emit heat when an electric current passes across a junction between two materials. Used for heating and cooling IP20 protection class equipment.
Point-to-point	Transmission between two fixed points.
Q1-bus	Bus in Nokia UltraSite EDGE BTS, used for local transmission management (Q1int) and for extending the management to external equipment.
Radio interface; air interface; AI	The interface between the mobile station (MS) and the radio equipment in the network. This is defined by functional characteristics, common radio (physical) interconnection characteristics, and other characteristics as appropriate.
Radio Relay	Microwave radio unit that replaces a fixed cable with a microwave radio link in the Abis Interface.
Rectifier	Device for converting alternating current to direct current. See BATx.
RFU backplane	Backplane in Nokia UltraSite EDGE BTS cabinet to which RF units are attached.
Sectored BTS Site	A site with multiple cells positioned to supply the desired radiation.



Sectorized Cell	A cell with a conical coverage area achieved by means of a directional aerial.
Single Sector	A part of the BTS's physical equipment that serves a single cell in the network radio topology.
Site	<p>Location where telecommunication equipment has been installed. For example, a site can contain a base station and transmission equipment with an equipment shelter and antenna tower.</p> <p>Several network elements can be located at a site.</p>
Soft handover	Handover where the signal goes through two base stations or base station sectors at a time.
Softer handover	Handover where the signal goes through two sectors in one base station area at a time.
Software Package	Software collection consisting of the components of the BTS operating system.
Spreading	A process in which the signal is modulated with the pseudo noise code to get a wideband signal for multipath propagation in spread spectrum systems.
Spreading code	A code that is used to despread a signal in spread spectrum communications.
Star Connection	Transmission solution in which three branches with one BTS in each are connected to a common node. See Chain Connection, Loop Connection, and Multidrop Connection.
Synchronisation (Sync)	Process of adjusting the corresponding significant instances of signals (between adjacent and serving cells) to obtain the desired phase relationship between these instances.

**Uplink** Direction of transmission in which the mobile station is the transmitting facility and the BTS is the receiving facility.

**Uplink Diversity**

2-way uplink diversity – Function in which a BTS uses two antennas and two receivers simultaneously on a single channel to obtain improved overall BTS receiver sensitivity in an environment that is subject to random multipath fading.

4-way uplink diversity – Function in which a BTS uses four antennas and four receivers simultaneously on a single channel to obtain improved overall BTS receiver sensitivity in an environment that is subject to random multipath fading.

See Frequency Hopping.

## Related Topics

### Nokia PSM software

#### References

Choose Target Window of PSMMan Software Download Wizard

Select File Window of PSMMan Software Download Wizard

Start Download Window of PSMMan Software Download Wizard

Switch Software Window of PSMMan Software Download Wizard

Welcome and User Details Window of PSMMan Commissioning Wizard

System Type and Setup Page Window of PSMMan Commissioning Wizard

Product Code and Serialisation Page [SiSS Node] & Configuration Window of PSMMan Commissioning Wizard

Documentation, Site Details & Cabinet Mechanics [CRM] Identification Window of PSMMan Commissioning Wizard

Product Code and Serialisation Page [Rectifiers] Window of PSMMan Commissioning Wizard

Product Code and Serialisation Page [Batteries] of PSMMan Commissioning Wizard

Product Code and Serialisation Page [Climatic Control Unit] of PSMMan Commissioning Wizard

Configuration Summary and Commissioning Window of PSMMan Commissioning Wizard

SiSS Commissioning Report Page Window of PSMMan Commissioning Wizard

Power Management (Settings) Window of PSMMan

Climatic Control (Settings) Window of PSMMan

System Settings Window of PSMMan

Identifications Window of PSMMan

## **Overview of Commissioning UltraSite EDGE BTS with IBBU**

### Descriptions

Nokia Sitewizard

## **Connecting locally to a PSM Node Manager**

### Reference

Connecting Locally to CCUA-based PSM