

TM8100 Mobile Radios TM8200 Mobile Radios

Installation Guide

MMA-00028-05 · Issue 5 · November 2012

Contact Information

Tait Communications Corporate Head Office

Tait Limited
P.O. Box 1645
Christchurch
New Zealand

For the address and telephone number of regional offices, refer to our website: www.taitradio.com

NZ577009, NZ579051, NZ579364, NZ580361,
AU2003281447, AU2004216984, AU2005267973,
AU11677/2008, AU13745/2008,
CN200930004200.4, CN200930009301.0,
CN1031871, CN1070368, EU000915475-0001,
EU000915475-0002, GB2386010, GB23865476,
GB2413249, GB2413445, US5745840, US7411461,
US7649893, US10/523952, US10/546696, US10/
546697, US10/547964, US10/597339, US11/572700,
US29/306491, US61/218015, US61/236663, US61/
238769, US61/251372.

Copyright and Trademarks

All information contained in this document is the property of Tait Limited. All rights reserved.
This document may not, in whole or in part, be copied, photocopied, reproduced, translated, stored, or reduced to any electronic medium or machine-readable form, without prior written permission from Tait Limited.

The word TAIT and the TAIT logo are trademarks of Tait Limited.

All trade names referenced are the service mark, trademark or registered trademark of the respective manufacturers.

Disclaimer

There are no warranties extended or granted by this document. Tait Limited accepts no responsibility for damage arising from use of the information contained in the document or of the equipment and software it describes. It is the responsibility of the user to ensure that use of such information, equipment and software complies with the laws, rules and regulations of the applicable jurisdictions.

Enquiries and Comments

If you have any enquiries regarding this document, or any comments, suggestions and notifications of errors, please contact your regional Tait office.

Updates of Manual and Equipment

In the interests of improving the performance, reliability or servicing of the equipment, Tait Limited reserves the right to update the equipment or this document or both without prior notice.

Intellectual Property Rights

This product may be protected by one or more patents or designs of Tait Limited together with their international equivalents, pending patent or design applications, and registered trade marks: NZ409837, NZ409838, NZ508806, NZ508807, NZ509242, NZ509640, NZ509959, NZ510496, NZ511155, NZ511421, NZ516280/NZ519742, NZ520650/NZ537902, NZ521450, NZ522236, NZ524369, NZ524378, NZ524509, NZ524537, NZ524630, NZ530819, NZ534475, NZ534692, NZ535471, NZ537434, NZ546295, NZ547713, NZ569985,

Environmental Responsibilities



Tait Limited is an environmentally responsible company which supports waste minimization, material recovery and restrictions in the use of hazardous materials.

The European Union's Waste Electrical and Electronic Equipment (WEEE) Directive requires that this product be disposed of separately from the general waste stream when its service life is over. For more information about how to dispose of your unwanted Tait product, visit the Tait WEEE website at www.taitradio.com/weee. Please be environmentally responsible and dispose through the original supplier, or contact Tait Limited.

Tait Limited also complies with the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS) Directive in the European Union.

In China, we comply with the Measures for Administration of the Pollution Control of Electronic Information Products. We will comply with environmental requirements in other markets as they are introduced.

Contents

Preface	5
Scope of Manual	5
Associated Documentation	5
Publication Record	6
Document Conventions	7
1 Safety and Regulatory Warnings	8
1.1 RF Exposure Hazard	8
1.2 Vehicle Manufacturer's Installation Instructions	8
1.3 MPT 1362 Code of Practice	8
1.4 Safe Radio Mounting	9
1.5 Interference with Vehicular Electronics	9
1.6 Preparation when Drilling Holes	9
1.7 Radio Installation in Gas or Fuel Tankers	9
1.8 Vehicles Powered by Liquefied Petroleum Gas	10
1.9 Non-standard Radio Installations	10
1.10 Negative Earth Supply	10
2 Preparing the U-Bracket Installation	11
2.1 Installation Tools	11
2.2 Checking the Equipment for Completeness	11
2.3 Power Source and Ignition Control	13
3 Installing the Radio	14
3.1 Mounting and Removing the Control Head	14
3.2 Selecting the Mounting Position	16
3.3 Mounting the U-Bracket	17
3.4 Installing the Antenna	18
3.5 Connecting the Power Cable to the Power Source	19
3.6 Connecting a Remote Speaker	21
3.7 Connecting to the Auxiliary Connector (Ignition Signal, Emergency Switch, External Alert Devices)	22
3.8 Installing the Radio	27
3.9 Installing the Microphone	28
3.10 Checking the Installation	29
3.11 Blank Control Head	30
3.12 RJ45 Control Head	31
4 Installation Options	32
4.1 Radio Body	33
4.2 Remote Control Head	34
4.3 Dual Control Heads	35
4.4 Hand-Held Control Head	37

4.5	Dual-Radio System.	39
4.6	Desktop Power Supply	41
	Tait Software License Agreement	42

Preface

Scope of Manual

This manual describes the installation of the TM8100/TM8200 mobile radio using the U-bracket, and how to install and connect the microphone, antenna, emergency switch, and external alert device.

The radio can also be installed in many other ways, using different combinations of components and accessories. For information on:

- radio body installation
- remote control head installation
- dual control head installation
- hand-held control head installation
- dual-radio system
- desktop installation

refer to ["Installation Options" on page 32](#), the installation instructions provided with the equipment, and the relevant sections in the service manual.

Some installation options may not be suitable for some models of radio. Consult your nearest Tait Dealer or Customer Service Organization for more information.

For information on installations with two bodies and one control head refer to the TM8260 Installation and Programming Guide (MMA-00041-**xx**).

Associated Documentation

The following associated documentation is available for this product:

- MTA-00011-**xx** Safety and Compliance Information
- MMA-00002-**xx** TM8100 User's Guide
- MMA-00051-**xx** TM8235 User's Guide
- MMA-00003-**xx** TM8250/TM8255 User's Guide
- MMA-00040-**xx** TM8260 User's Guide
- MMA-00041-**xx** TM8260 Installation and Programming Guide
- MMA-00005-**xx** TM8100/TM8200 Service Manual

The characters **xx** represent the issue number of the documentation.

This publication is also available in French (MMA-00044-**xx**), Spanish (MMA-00045-**xx**), and Chinese (MMA-00048-**xx**).

Technical notes are published from time to time to describe applications for Tait products, to provide technical details not included in manuals, and to offer solutions for any problems that arise.

All available TM8100/TM8200 product documentation is provided on the CD supplied with the service kit¹. Updates may also be published on the Tait support website.

Publication Record

Issue	Publication Date	Description
01	August 2005	First release
02	July 2006	Auxiliary connector information updated TM8235 and TM8260 information added
03	March 2008	References to hand-held control head, remote installations, and multi-head/multi-body installations added. Product codes for trigger-base bodies added. Information on antenna gain for 800MHz radios added. Part numbers for fuses corrected. Instructions on avoiding connection to centre tap of two 12V batteries added. Rating for 24V-to-12V converter added.
04	November 2009	Installation Options section added. Minor corrections and additions.
05	November 2012	New Tait logo

1. Technical notes are only available in PDF format from the Tait support website. Consult your nearest Tait Dealer.

Document Conventions

Please follow exactly any instruction that appears in the text as an 'alert'. An alert provides necessary safety information as well as instruction in the proper use of the product. This manual uses the following types of alert:.



Warning This alert is used when there is a hazardous situation which, if not avoided, could result in death or serious injury.



Caution This alert is used when there is a hazardous situation which, if not avoided, could result in minor or moderate injury.

Notice This alert is used to highlight information that is required to ensure procedures are performed correctly. Incorrectly performed procedures could result in equipment damage or malfunction.



This icon is used to draw your attention to information that may improve your understanding of the equipment or procedure.

Within this manual, the following symbols are used to highlight differences between radios with a transmit power of more than 25 W and radios with a transmit power of 25 W:



This symbol highlights information that is relevant to radios with a transmit power >25 W.



This symbol highlights information that is relevant to radios with a transmit power of 25 W.

1 Safety and Regulatory Warnings

This section contains important information on the safe installation of the radio. You must read this information before starting the installation.

You must also read and observe the safety information on radio operation provided in the safety and compliance information and the user's guide.

1.1 RF Exposure Hazard

To comply with FCC RF exposure limits:



For radios with a transmit power >25 W:

- VHF radios must be installed using an antenna mounted centrally on the vehicle roof, with a gain of 2.15 dBi or 5.15 dBi.
- UHF and 800MHz radios must be installed using an antenna mounted either centrally on the roof with a gain of 2.15 dBi or 5.65 dBi, or centrally mounted on the trunk with a gain of 5.65 dBi.



For radios with a transmit power of 25 W:

- The radio must be installed using an externally mounted antenna with a gain of either 2.15 dBi or 5.15 dBi.

In all cases, the antenna must not be mounted at a location such that any person or persons can come closer than 35 inches (0.9m) to the antenna.

1.2 Vehicle Manufacturer's Installation Instructions

Installation of this product in a vehicle must be performed according to the instructions provided by the vehicle manufacturer. For more information, refer to the vehicle manufacturer's website or contact the vehicle manufacturer's dealer.

1.3 MPT 1362 Code of Practice

Mobile radios should be installed in accordance with the MPT 1362 Code of Practice.

1.4 Safe Radio Mounting



Warning Mount the radio securely so that it will not break loose in the event of a collision. An unsecured radio is dangerous to the vehicle occupants.

- Mount the radio and the microphone where they will not interfere with:
 - the deployment of passenger airbags
 - the vehicle operator controls
 - the vehicle operator's view
- Do not mount the radio vertically, with the control head facing down. This will violate compliance with the standards UL/CSA/EN 60950, Safety of Information Technology Equipment.

1.5 Interference with Vehicular Electronics



Warning Some vehicular electronic devices may be prone to malfunction due to the lack of protection from RF energy when your radio is transmitting.

Examples of vehicular electronic devices that may be affected by RF energy are:

- electronic fuel injection systems
- electronic anti-skid braking systems
- electronic cruise control systems
- indicators

If the vehicle contains such equipment, consult the vehicle manufacturer or dealer to determine whether these electronic circuits will perform normally when the radio is transmitting.

1.6 Preparation when Drilling Holes



Warning When drilling holes in the vehicle, check that drilling at the selected points will not damage existing wiring, fuel tanks, fuel and brake lines, or battery cables.

1.7 Radio Installation in Gas or Fuel Tankers

Special conditions must be observed when installing a radio on gas and fuel tankers. Consult your radio provider or Tait-accredited service center for more details.

1.8 Vehicles Powered by Liquefied Petroleum Gas



Warning Radio installation in vehicles powered by LPG (liquefied petroleum gas) with the LPG container in a sealed-off space within the interior of the vehicle must conform to the National Fire Protection Association Standard NFPA 58.

This standard states that the radio equipment installation must meet the following requirements:


- The space containing the radio equipment shall be isolated by a seal from the space containing the LPG container and its fitting.
- Outside filling connections shall be used for the LPG container and its fittings.
- The LPG container space shall be vented to the outside of the vehicle.

1.9 Non-standard Radio Installations

The installation U-bracket described in this guide has been designed so that there is enough airflow around the radio to provide cooling.

If a non-standard installation method is used, care must be taken that sufficient heat can be dissipated from the heatsink fins and the ridged bottom surface of the radio.

For this to be achieved, there must be a gap of more than 3/8 inch (10 mm) between the bottom surface of the radio chassis and the mounting surface. This is illustrated in the following diagram (TM8200 radio shown):



1.10 Negative Earth Supply

The radios are designed to operate only in a negative earth system.

2 Preparing the U-Bracket Installation

This section contains the following information:

- installation tools
- checking the equipment for completeness
- choosing an installation configuration

2.1 Installation Tools

The following tools are required to install the radio:

- drill and drill bits
- Pozidriv screwdriver
- 5/16 inch (8mm) socket
- RF connector crimp tool
- fuse crimp tool
- in-line RF power meter capable of measuring forward and reflected power at the operating frequency of the radio

2.2 Checking the Equipment for Completeness

Unpack the radio and check that you have the following:



1. A radio body with one of the following product codes:
TM8100:
 - TMAB12 standard 25 W radio
 - TMAB13 trigger-base 25 W radio
 - TMAB14 standard >25 W radio**TM8200:**
 - TMAB22 standard 25 W radio
 - TMAB23 trigger-base 25 W radio
 - TMAB24 standard >25 W radio
2. A control head with one of the following product codes:
TM8100:
 - TMAC10 blank control head (TM8105 radio)
 - TMAC20 2-digit display control head (TM8115 radio)
 - TMAC50 1-digit-display control head (TM8110 radio)**TM8200:**
 - TMAC30 RJ45 control head (TM8252 radio)
 - TMAC40 or TMAC42 graphical-display control head (TM8250 and TM8255 radios)

- TMAC60 3-digit-display control head (TM8235 radio)
- TMAC70 hand-held control head (TM8254 radio), with TMAC34 remote control head, and TMAA10-06 remote speaker (>25 W radio) or TMAA10-03 remote speaker (25 W radio)



The TMAC31, TMAC32 and TMAC34 remote interfaces are similar in appearance to the TMAC30 RJ45 control head of the telemetry radio. However, their electrical characteristics and signals are different. For more information, refer to the installation instructions provided with the remote kits.

3. TMAA02-01 microphone, TMAA02-08 keypad microphone including microphone clip and screws (not required for the TM8105, TM8252 or TM8254 radio)



4. A TMAA03-17 installation kit (>25 W radio) or TMAA03-01 installation kit (25 W radio), consisting of the following items:

- U-bracket
- thumbscrews
- self-drilling screws and washers
- power cable with DC connector
- fuses
- in-line fuse holders
- receptacles for a remote speaker (remote speaker not included)
- antenna connector

Refer to "[Installation Kit Options](#)" below.



Warning Danger of fire! The radio's protection mechanisms rely on the correct fuses on both the negative and positive power supply leads being present. Failure to fit the correct fuses may result in fire or damage to the radio.

The correct fuse types are:



- >25 W radios: 20 A fuses (Tait IPN 265-00010-81)
- 25 W radios: 10 A fuses (Tait IPN 265-00010-80)

Installation Kit Options

Installation kits are also available without the U-bracket included and with other antenna connector options. Consult your nearest Tait Dealer or Customer Service Organization for more information.

2.3 Power Source and Ignition Control

The radio allows for different installation configurations for vehicles with respect to ignition signal and standby current. The installation configurations described below are based on the following hardware link configuration:

- hardware link 1 (+13.8V battery power sense): fitted
- hardware link 2 (ignition sense): fitted

For more information on the hardware links, refer to Table 3.4 on page 24 and to the service manual.

Direct Connection to the Power Source



The radio's power cable must always be connected directly to the power source (battery).

Notice Although it is possible to connect the radio in line with the vehicle ignition, this is not recommended, as it may draw too much current and damage the vehicle wiring and steering column or ignition switch. This may also cause the supply voltage of the radio to drop below the specified level.

The radio can always be turned on and off using the on/off button, independent of the ignition signal.

Installation without Ignition Signal

Connect the power cable directly to the power source as described in ["Connecting the Power Cable to the Power Source" on page 19](#).


-  If hardware link 1 is fitted (factory default) and the ignition signal is not used, the standby current is approximately 50mA. To reduce the standby current to <3mA either:
 - remove hardware link 1, or
 - connect pin 4 (AUX GPI3) to pin 15 (AGND) of the auxiliary connector
-  With the above two options, the radio always stays off when power is first applied. The radio can only be turned on with the on/off button.

Installation with Ignition Signal

Connect the power cable directly to the power source as described in ["Connecting the Power Cable to the Power Source" on page 19](#).

Connect pin 4 (AUX GPI3) of the auxiliary connector to the ignition signal as described in ["Connecting to the Auxiliary Connector \(Ignition Signal, Emergency Switch, External Alert Devices\)" on page 22](#).

The AUX GPI3 line must be programmed to 'Power Sense (Ignition)' and active to 'High'. For more information, refer to the online help of the programming application.

-  The TMAA04-05 ignition sense kit provides a suitable mating plug for the radio's auxiliary connector. The plug includes wiring for the the ignition signal and analog ground.

3 Installing the Radio

This section contains the following information:

- mounting and removing the control head
- selecting the mounting position
- mounting the U-bracket
- installing the antenna
- connecting the power cable to the power source
- connecting a remote speaker
- connecting to the auxiliary connector (ignition signal, emergency switch, external alert devices)
- installing the radio
- installing the microphone
- checking the installation
- blank control head
- RJ45 control head

For information on other types of installation, refer to ["Installation Options" on page 32](#), the installation instructions provided with the equipment, and the relevant sections in the service manual.

3.1 Mounting and Removing the Control Head

Notice The control head contains devices which can be damaged by static discharges. Always install or remove the control head in a static-safe environment. For information on antistatic precautions, go to the Electrostatic Discharge Association (ESD) website, <http://www.esda.org>.


Mounting the Control Head

The control head and its connection loom are delivered separately from the radio body. Before installing the radio, the control head should be mounted on the radio body.

The orientation of the radio body determines which way up the control head is mounted on the radio body.

Notice It may be necessary to mount the radio upside down to maintain a gap of more than 3/8 inch (10 mm) for air circulation between the underside of the radio body and the mounting surface.

Figure 3.1 Mounting the control head




1. Plug the control-head loom onto the control-head connector.
2. Place one edge of the control head on either the top or bottom pair of snap features on the front of the radio body, then rotate to snap the opposite edge into place.

Removing the Control Head

Notice During this procedure, take care that the control-head seal is not damaged. Damage to this seal reduces environmental protection.

Figure 3.2 Removing the control head



On the underside of the radio, two lever points are indicated on the radio body by a dot-dash-dot pattern (○ — ○). The lever point is between the control-head seal and the control head.

1. At either of the lever points, insert a 3/16 inch (5 mm) flat-bladed screwdriver between the control head and the control-head seal.
2. Use the screwdriver to lift the control head off the snap feature, then repeat in the other position. The control head can now be removed from the radio body.

3.2 Selecting the Mounting Position

Requirements for Safe and Convenient Installation

Ensure the mounting position complies with the following safety warnings:



Warning Safe radio mounting!

- Mount the radio securely so that it will not break loose in the event of a collision. An unsecured radio is dangerous to the vehicle occupants.
- Mount the radio and the microphone where they will not interfere with the deployment of airbags, the vehicle operator controls, the vehicle operator's view.



Caution The bottom surface of the radio and the heatsink fins can become hot during prolonged operation. When installing the radio, position the radio so that it is not possible for the radio user to touch the bottom surface of the radio and the heatsink fins.

Gap Between Radio Body and Mounting Surface

Notice It may be necessary to mount the radio upside down to maintain a gap of more than 3/8 inch (10 mm) between the bottom surface of the radio body and the mounting surface.

Inspect the vehicle and determine the safest and most convenient position for mounting the radio. Make sure that there is sufficient clearance behind the radio for the heatsink and cables.

IP54 Protection Class Considerations

The radio fulfils the requirements of the IP54 protection class.

Notice However, do not mount the radio in areas where it can be temporarily submerged from an accumulation of water or other liquids (e.g. when using a high-pressure cleaning device).

The IP54 protection class does not apply when:

- the control head is removed from the radio body
- the bungs are removed from the auxiliary connector or the cavity for the external options connector (fitting an auxiliary connector or external options connector will not restore the IP54 protection class)
- the programming connector cover seal is not installed (blank control head)
- the RJ45 connector bungs are not installed (RJ45 control head)
- the grommet of the microphone or hand-held control head is not installed
- an accessory is added which is not rated to IP54 (e.g. control-head interface box or hand-held control head remote interface box)

3.3 Mounting the U-Bracket

The U-bracket can be used to install the radio on the dashboard or on any sufficiently flat surface (e.g. cabin floor or trunk). The U-bracket can be mounted using the self-drilling screws and washers provided in the installation kit, or nuts and bolts (not included).



Caution Although an industrial-strength recloseable fastening system can be used to support the installation, for safety reasons Tait does not recommend this as a mounting option.

Notice When mounting the radio on a surface, check whether the mounting screws will screw into material providing sufficient strength. Reinforce the mounting surface, if required.

1. If the U-bracket is being mounted over a curved surface, bend the tabs at the bottom of the U-bracket slightly to match the surface shape.
2. Hold the U-bracket in the position chosen for the radio and use the mounting holes as a template to mark the mounting locations. Use at least four screws to install the U-bracket.




The screws provided are self-drilling. For more precise positioning, pre-drill $\varnothing 1/8$ inch (3 mm) pilot holes for self-drilling screws. Reduce the hole size in metal that is less than $1/32$ inch (1 mm) thick.

Notice Ensure that drilling at the selected points will not damage existing wiring.

3. Drill any holes required for cables and install suitable grommets or bushings in the holes.
4. Screw the U-bracket in the chosen mounting position using the self-drilling screws and washers provided. When tightening the screws, ensure that this does not distort the U-bracket.

Figure 3.3 Mounting the U-bracket



3.4 Installing the Antenna

This section provides information on installing an external antenna within the RF exposure limits.

Install the external antenna according to the antenna manufacturer's instructions. Good quality 50 Ω coaxial cable must be used, such as RG58 or UR76.

Notice Route the cable in a manner that minimizes:

- coupling into the electronic control systems of the vehicle
- coupling of electric vehicle systems, such as alternators, into the radio

Avoid sharp bends in the cable. These distort the cable and alter its electrical characteristics.



Warning RF exposure hazard!

To comply with FCC RF exposure limits, mount the antenna at a location such that no person or persons can come closer than 35 inches (0.9m) to the antenna.



For >25 W radios:

- VHF radios must be installed using an antenna mounted centrally on the vehicle roof, with a gain of 2.15 dBi or 5.15 dBi.
- UHF and 800MHz radios must be installed using an antenna mounted either centrally on the roof with a gain of 2.15 dBi or 5.65 dBi, or centrally mounted on the trunk with a gain of 5.65 dBi.




For 25 W radios:

- The radio must be installed using an externally mounted antenna with a gain of either 2.15 dBi or 5.15 dBi.

Terminating the Antenna Cable

1. Run the free end of the coaxial cable to the radio's mounting position and cut it to length, allowing approximately 8 inches (200mm) excess at the radio end.
2. Terminate the free end of the antenna cable with the mini-UHF plug or BNC plug (supplied) as shown in [Figure 3.4](#).


Figure 3.4 Terminating the antenna cable



3.5 Connecting the Power Cable to the Power Source



This section provides information on connecting the power cable to the power source.

Power Connector



The power connector is the interface to the vehicle battery and an optional external remote speaker. Connecting a remote speaker is described in ["Connecting a Remote Speaker" on page 21](#).

Table 3.1 Power connector (radio) - pins and signals

Pinout	Pin	Signal name	Description	Signal type
>25W radio  rear view 25W radio  rear view	1	AGND	Earth return for radio body power source	Ground
	2	SPK–	External speaker output. Balanced load configuration	Analog
	3	SPK+	External speaker output. Balanced load configuration	Analog
	4	13V8 BATT	DC power input for radio body and control head	Power

Notice This radio is designed to operate from a nominal 12V negative ground supply and may draw up to 15A of current. The radio will tolerate a supply voltage range of 10.8V to 16.0V at the radio.

Selecting the Power Source

In passenger vehicles, the radio is always connected directly to the battery using the power cable provided.

Notice Do not connect the radio to the center tap of two 12V batteries! This may result in damage to the radio due to earth loops, in particular when the negative lead is disconnected from the vehicle battery. It may also result in overcharging or undercharging of the batteries, reducing their service life.

In trucks, where direct connection to the battery is often not possible, the radio can be connected to a suitable terminal inside the fuse box that is connected directly to the battery.

24V-to-12V Converter



In vehicles with a supply voltage larger than 16.0V, such as many trucks, it is essential to provide a 24V-to-12V converter with a minimum rating of 15A for radios >25 W and 10A for the 25 W radio. This will isolate the radio from excessive battery voltage and provide the correct DC operating conditions. Note that most 24V-to-12V converters already fitted are not rated sufficiently.

Standby Current

When connecting the radio to the battery without using the ignition signal as described [on page 25](#), the standby current is approximately 50mA.

When using the ignition signal to turn off the radio, the standby current is reduced to <3mA.



To reduce the standby current from 50mA to <3 mA without using the ignition signal, connect pin 4 (AUX GPI3) and pin 15 (GND) of the auxiliary connector.

Connecting the Power Cable

Notice Although it is possible to connect the radio in line with the vehicle ignition, this is not recommended, as it may draw too much current and damage the vehicle wiring and steering column or ignition switch. This may also cause the supply voltage of the radio to drop below the specified level.

Notice Disconnecting the vehicle's battery may cause problems with some electronic equipment, such as vehicle alarms, engine management systems, and in-vehicle entertainment systems. Check that the vehicle owner has the necessary information to make all electronic equipment function correctly after battery reconnection.

Notice If the battery is not disconnected, exercise extreme caution during the installation and install the fuses only when the installation is ready to be checked. For more information, refer to "[Checking the Installation](#)" on page 29.

1. Disconnect the vehicle's battery unless specifically prohibited from doing so by the customer, vehicle manufacturer, agent, or supplier.

Notice Route the cable in a manner that minimizes coupling of electric vehicle systems such as alternators into the radio.

Notice Protect the power cable from engine heat, sharp edges and from being pinched or crushed.

2. Run the power cable between the radio's mounting position and the power source and cut it to length, allowing approximately 8 inches (200 mm) excess at the radio end.
3. Plug the power cable into the power connector of the radio.



Warning Danger of fire! The radio's protection mechanisms rely on the correct fuses on both the negative and positive power supply leads being present. Failure to fit the correct fuses may result in fire or damage to the radio.

The correct fuse types are:



- >25 W radios: 20 A fuses (Tait IPN 265-00010-81)
- 25 W radios: 10 A fuses (Tait IPN 265-00010-80)

4. Cut the negative and the positive wires where the in-line fuse holders will be placed (as close to the power source as possible).

Notice Do not install the fuses until the installation is ready to be checked. For more information, refer to ["Checking the Installation" on page 29](#).

5. Insert each end of the negative wire into each of the fuse crimp-terminals and crimp them to force the metal contacts onto the wires.
6. Push the two crimp-terminals into the clear plastic fuse cover. Close the cover while the next steps are completed.
7. Repeat steps 5 and 6 for the positive wire.
8. Connect the negative wire to the battery ground terminal.
9. Connect the positive wire to the battery positive terminal.

Notice Do not install the fuses until the installation is ready to be checked. For more information, refer to ["Checking the Installation" on page 29](#).

3.6 Connecting a Remote Speaker



If a high-power remote speaker is required, Tait recommends using:

- TMAA10-06 high-power remote speaker for >25 W radios
- TMAA10-03 high-power remote speaker for 25 W radios

The remote speaker is installed in parallel with the radio's existing internal speaker. It can be installed at some distance from the radio, or it can be used to increase the volume of the audio from the radio's existing internal speaker.



If a different speaker is used, receptacles for the speaker pins of the power connector are provided with the installation kit.

- Connect the speaker to pins 2 (SPK-) and 3 (SPK+) of the power connector described [on page 19](#).


For more information, refer to the installation instructions provided with the speaker, or to the relevant section of the service manual.

3.7 Connecting to the Auxiliary Connector (Ignition Signal, Emergency Switch, External Alert Devices)

The auxiliary connector can be used to connect external devices and signals that are typically connected to a radio. These devices and signals include:

- the ignition signal to power up and power down the radio
- an emergency switch to power up the radio (if required) and then enter emergency mode
- external alert devices

Auxiliary Connector The radio's auxiliary connector is a 15-way standard-density D-range socket.

 The space for a mating plug is limited to 1 5/8 inch (41 mm) in width and 11/16 inch (18 mm) in height. Although most plugs will fit this space, it is recommended that you test the plug to be used before manufacturing a cable.

Some input levels of the auxiliary connector depend on how the internal hardware links are fitted (refer to [Table 3.3](#)). For more information on hardware links refer to "[Hardware Links and Power-Sense Options](#)" on [page 24](#).

Table 3.2 Auxiliary connector (radio) - pins and signals


Pinout	Pin	Signal name	Description	Signal type
 rear view	12	AUX GPI1	General purpose digital input.	Digital, 3.3V CMOS.
	5	AUX GPI2	Programmable function	
	4	AUX GPI3	General purpose input (ignition sense)	3.3V levels. Protected for +13.8V (refer to Table 3.3).
	10	AUX GPIO4	Programmable function and direction Pads available to fit a higher power driver transistor on GPIO4 line	Digital, 3.3V CMOS input; open collector output with pullup
	2	AUX GPIO5		
	9	AUX GPIO6		
	1	AUX GPIO7		
	11	AUX TXD	Asynchronous serial port - Transmit data	Digital, 3.3V CMOS
	3	AUX RXD	Asynchronous serial port - Receive data	Digital, 3.3V CMOS
	7	AUD TAP IN	Programmable tap point into the Rx or Tx audio chain. DC-coupled	Analog
	13	AUD TAP OUT	Programmable tap point out of the Rx or Tx audio chain. DC-coupled	Analog
	14	AUX MIC AUD	Auxiliary microphone input. Electret microphone biasing provided. Dynamic microphones are not supported	Analog
	6	RSSI	Analog RSSI output	Analog
	8	+13V8 SW	Switched 13.8V supply. Supply is switched off when radio body is switched off	Power
	15	AGND	Analog ground	Ground

Table 3.3 Auxiliary connector - input levels

Parameter	Voltage ¹			Test method and conditions	Comments
	min.	max.	units		
Input low level: All inputs AUX_GPI2		0.7 $V_s - 4$	V V	No hardware links fitted ² . LK3 fitted.	Includes AUX_GPI3 with LK1/2 fitted. Configured as emergency power sense input.
Input high level: All inputs AUX_GPI2	1.7 $V_s - 1.5$		V V	No hardware links fitted ² . LK3 fitted.	Configured as emergency power sense input.
AUX_GPI3	2.6		V	LK1 and/or 2 fitted.	Configured as power sense input.
Safe DC input limits: AUX_GPI1-3 AUX_GPIO4-7 AUX_RXD AUX_TXD ³	-0.5 -0.5 -25V -10	$V_s + 0.5$ $V_s + 0.5$ $V_s + 0.5$ $V_s + 0.5$	V V V V		The input current must not exceed $\pm 50\text{mA}$. This is the rating of the clamping diodes.

1. The radio will tolerate a supply voltage range of 10.8V to 16.0V at the radio.

2. For more information on hardware links refer to Table 3.4 on page 24 and to the service manual.

3. This output is protected against accidental input to the limits specified.

Hardware Links and Power-Sense Options

The radio provides four hardware links (LK1 to LK4) on the top-side of the main board which can be configured to attain different power-sense options.

Table 3.4 shows the configuration of the hardware links LK1, LK2 and LK4 for the individual power-sense options. It also lists the dependence of the power-sense options with respect to the GPI lines, which can or cannot be used.

Hardware link LK3 is used for ‘emergency power sense’.

Table 3.4 Configuration of hardware links for power-sense options

Power-sense option	Links required	Configuration of remaining links and use of AUX GPI3 and IOP GPIO7	Voltages required
13.8V battery power sense	LK1 in LK4 out	LK2 in: AUX GPI3 must be left floating. LK2 out: AUX GPI3 can be used as GPI ¹ . IOP GPIO7 can be used as GPIO.	10.8V ≤ supply ≤ 16V
auxiliary power sense (ignition sense)	LK2 in LK4 out	LK1 in: Input line must sink > 1mA from AUX GPI3 (which is pulled to 13.8V by a 33kΩ resistor). The impedance between the vehicle ignition signal and ground must be ≤ 1kΩ. LK1 out: Input line must be active high ² . IOP GPIO7 can be used as GPIO.	AUX GPI3 ≤ 0.7V off AUX GPI3 ≥ 2.6V high (active) ignition-sense tolerant to 3.3V, 5V and 12V
internal power sense	LK1 out LK2 out LK4 in	AUX GPI3 can be used as GPI. With LK4 in, the input line must be active high ³ .	IOP GPIO7 ≤ 0.7V off IOP GPIO7 ≥ 2.6V high (active) ignition-sense tolerant to 3.3V and 5V only
no power sense	LK1 out LK2 out LK4 out	AUX GPI3 can be used as GPI. IOP GPIO7 can be used as GPIO.	10.8V ≤ supply ≤ 16V


1. If LK2 is out and AUX GPIO is not used, R775 (33kΩ) should be placed to ensure that AUX GPI3 does not float (R775 is not placed by factory default).
2. If LK1 is out and R775 is placed, AUX GPI3 should be driven low as well.
3. If LK 4 is in and R723 is placed, IOP GPIO7 should be driven low as well. (R723 is placed by factory default.)

For more information on hardware links and power-sense options refer to the service manual.

Shielding

If the auxiliary cable is longer than 4 feet (1 m) it is recommended that the cable and connector backshell are shielded. [Figure 3.5](#) shows the recommended shielding arrangement. The earth braid wire (bare copper) and aluminum foil should only be earthed at the radio end of the cable.

Figure 3.5 Auxiliary cable and connector shielding




Ignition Signal

The ignition signal can be used to power up and power down the radio. This will turn the radio off when the ignition key is off to avoid flattening the battery, and will turn the radio on or return to its previous state (as programmed) when the ignition key is on.



A TMAA04-05 ignition sense kit is available. The kit comprises a mating plug for the radio's auxiliary connector and a 13 foot (4m) length of cable to connect to the vehicle's ignition signal. Refer to the installation instructions supplied in the kit for full details.



Notice The AUX GPI3 line **must** be programmed to 'Power Sense (Ignition)' and active to 'High'. For more information, refer to the online help of the programming application.

- Connect the ignition signal to pin 4 (AUX GPI3) of the auxiliary connector.

Notice The logic thresholds for AUX GPI3 are based on 3V3 levels. However, AUX GPI3 can be connected directly to a +13.8V ignition signal (for input levels, refer to [Table 3.3 on page 23](#)).

Emergency Switch

The radio allows for connection of an emergency switch to any input line to enter the emergency mode. If connected to the AUX GPI2 input line, the radio can also use 'emergency power sense' to power up the radio to enter the emergency mode.

The selected input line must be programmed to 'Enter Emergency Mode' and active to 'Low'. To use 'emergency power sense', hardware link LK3 must be fitted (factory default), and AUX GPI2 must be used. For more information, refer to ["Hardware Links and Power-Sense Options" on page 24](#), the service manual and the online help of the programming application.

- Connect a normally open switch between the pin of the input line (pin 5 for AUX GPI2) and pin 15 (AGND) of the auxiliary connector.

External Alert Device

The radio allows for output to external alert devices using the digital GPIO lines of the auxiliary connector and the internal options connector.

AUX GPIO4 can be fitted with a power MOSFET (Q707) to directly connect external alert devices (e.g. flashing light, buzzer, horn relay) to the radio. Also, resistor R768 must be removed.

Notice While the MOSFET is rated at 12 A (with heat sink), the maximum allowable current of the connector and radio's earthing system is 2 A. Therefore, a horn must not be connected directly to the radio. A horn relay must be used.

The selected output line must be programmed to 'External Alert 1 or 2', active to 'Low', and signal state to 'Momentary'.


- Connect the external alert device to the pin of the output line (pin 10 for AUX GPIO4) and pin 8 (+13V8 SW) of the auxiliary connector (or a different positive battery connection).

This means that the negative side of the alert device must be connected to AUX GPIO4 and the positive side to pin 8 (+13V8 SW). The external alert device must be capable of accepting a voltage of between 10V and 18V.

3.8 Installing the Radio

1. Connect the antenna cable, power cable, and (if applicable) the auxiliary cable to the rear of the radio.
2. Position the radio in the U-bracket so that the holes in the U-bracket line up with the holes in the radio chassis.
3. Screw the radio into position using the four thumb screws provided, but without fully tightening the screws.
4. Adjust the position of the radio in the U-bracket for the best viewing angle, then tighten the thumb screws.

Figure 3.6 Installing the radio in the U-bracket



3.9 Installing the Microphone

This section describes the radio's microphone connector and the information required to connect the microphone and install the microphone clip.


Notice The microphone grommet must be installed whenever the microphone is plugged into the microphone socket:

- to prevent damage to the microphone socket when there is movement of the microphone cord, and
- to ensure that the control head is sealed against water, dust and other environmental hazards

Connecting the Microphone

1. Plug the microphone into the microphone socket.
2. Slide the grommet along the microphone cord and push two adjacent corners of the grommet into the microphone socket cavity.
3. Squeeze the grommet and push the remaining corners into position.
4. Check that the grommet is seated correctly in the cavity.

Figure 3.7 Correct remote cable grommet seating



Installing the Microphone Clip



Warning Safe radio mounting! Mount the microphone where it will not interfere with:

- the deployment of passenger airbags
- the vehicle operator controls
- the vehicle operator's view

Notice Only install the microphone clip provided. If a non-standard microphone clip is used, the correct operation of the microphone hook-switch cannot be guaranteed.

Install the microphone clip in the most convenient location using the screws provided. The microphone must be within reach of the user but in such a position that the PTT (press-to-talk) key cannot be inadvertently activated or jammed.

3.10 Checking the Installation



Warning Danger of fire! The radio's protection mechanisms rely on the correct fuses on both the negative and positive power supply leads being present. Failure to fit the correct fuses may result in fire or damage to the radio.



The >25 W radios use 20 A fuses; the 25 W radios use 10 A fuses. For part numbers of the fuses, refer to ["Checking the Equipment for Completeness"](#) on page 11.

1. Insert the fuses into the power leads.
2. Switch on the radio to confirm that it is operational, but do not transmit.
3. Connect an in-line power meter between the radio and the antenna.
4. Transmit and measure the forward and reflected power levels. Less than 4% of the forward power should be reflected. If this is not achieved, check the installation, including the antenna length.
5. Start reducing the length of the antenna in steps of 0.1 inches to 0.2 inches (2 to 5 mm). Measure the power levels at each step.

Notice Some antennas are pre-tuned and must not be cut. Check with the manufacturers' instructions.

6. Once the reflected power levels are within tolerance, make a call to another party on the radio.

3.11 Blank Control Head

The blank control head on the TM8105 radio has a 9-way D-range plug on the control head for programming (using the TMAA20-02 RJ45 to 9-way D-range adaptor).


Notice When the programming connector is not in use, the connector seal must be installed. This ensures that the control head is sealed against water, dust and other environmental hazards.

Figure 3.8 TM8105 radio with the blank control head



The pin allocations for the programming connector are explained in the following table.

Table 3.5 Programming connector for the blank control head - pins and signals

Pinout	Pin	Signal name	Description
 front view	1	RX AUD	Receive audio output (after volume control)
	2	TXD	Asynchronous serial port: transmit data
	3	MIC AUD	Microphone audio input
	4	RXD	Asynchronous serial port: receive data
	5	ON/OFF	Hardware power on/software power off input (active low)
	6	+13.8V	Unswitched 13.8V power supply
	7	PTT	PTT input
	8	AGND	Analogue ground
	9	DGND	Digital ground

3.12 RJ45 Control Head

The RJ45 control head on the TM8252 telemetry radio has one RJ45 socket installed and a cavity where another RJ45 can be installed. The control head also has a power on/off LED.


Notice When a connector is not in use, the RJ45 bung for the connector must be installed. This ensures that the control head is sealed against water, dust and other environmental hazards.

Figure 3.9 TM8252 telemetry radio



The pin allocations for the RJ45 programming connector are explained in the following table.

Table 3.6 Programming connector for the RJ45 control head - pins and signals

Pinout	Pin	Signal name	Description
 front view	1	RX AUD	Receive audio output (after volume control)
	2	+13.8V	Unswitched 13.8V power supply
	3	TXD	Asynchronous serial port: transmit data
	4	PTT	PTT input
	5	MIC AUD	Microphone audio input
	6	AGND	Analogue ground
	7	RXD	Asynchronous serial port: receive data
	8	ON/OFF	Hardware power on/software power off input (active low)

4 Installation Options

This section provides an overview of the accessory kits that are currently available for installing the following components:

- radio body
- remote control head
- dual control heads
- hand-held control head
- dual-radio system
- desktop power supply.


Some installation options may not be suitable for some models of radio. Consult your nearest Tait Dealer or Customer Service Organization for more information.

4.1 Radio Body

U-Bracket


The U-bracket is supplied as standard for mounting a radio fitted with either a local control head or a remote interface (for a remote mounted control head).

For full details on mounting the U-bracket and radio, refer to ["Mounting the U-Bracket" on page 17](#) and ["Installing the Radio" on page 27](#).



Security Bracket


The TMAA03-02 security bracket can be used in place of the standard U-bracket in locations where you want to stop opportunistic removal of the radio by a third party, or where you want to have a quick release setup that allows you to swap over radios (e.g. leasing situation). The security bracket also provides electrical isolation to the radio. Refer to the TMAA03-02 Security Bracket Installation Instructions (402-00014-xx) for full details.



Cradle




The TMAA03-18/TMAA03-39 cradle provides a means of mounting the radio in a wrap-around protective enclosure. The radio slides into the cradle and locks in place. It can only be removed by inserting a plastic key. The cradle is not suitable for >25 W radios or radios with a local graphical-display control head. Refer to the TMAA03-18/TMAA03-39 Cradle Installation Instructions (MMA-00019-xx) for full details.



4.2 Remote Control Head


Remote Control Head

A remote kit can be used to install the control head of a graphical-display radio remotely from the radio body. The diagram below shows the additional parts used for this installation. Refer to the Instructions for Installing a Remote Control Head (402-00020-xx) for full details.



Extended Remote Control Head

An extended remote kit can be used when extended distances are required between a TM8250 or TM8255 radio body and its graphical-display control head. This enables the control head to be installed up to 1 km away from the radio body. The items named or shown in **bold** below are part of the upgrade kit. Refer to the TMAA11-06 Extended Single Head Upgrade Kit Installation Instructions (402-00047-xx) for full details.




4.3 Dual Control Heads

In a dual-head radio system, elements of the user interface (such as display content, internal speaker audio, and LEDs) are duplicated on both control heads. This enables multiple users to share the same radio.


Dual Control Heads

The TMAA11-02/03/04 or TMAA11-10/11/12 upgrade kits can be used to convert a TM8250 or TM8255 mobile radio (single radio body and graphical-display control head) to a dual-head radio system. The following diagram summarizes how the components are installed. Items named or shown in **bold** are part of the upgrade kits. Refer to the TM8200 Dual Head Upgrade Kits Installation Instructions (402-00050-xx) for full details.



Extended Dual Control Heads


The TMAA11-07 or TMAA11-08 upgrade kits can be used to convert a TM8250 or TM8255 mobile radio (single radio body and graphical-display control head) to a dual-head radio system. The upgrade kits allow one or both control heads to be installed away from the radio body in difficult or isolated locations, up to a maximum of 1 km. The following diagram summarizes how the components are installed. Items named or shown in **bold** are part of the upgrade kits. Refer to the TMAA11-07 and TMAA11-08 Extended Dual Head Upgrade Kits Installation Instructions (402-00052-xx) for full details.



4.4 Hand-Held Control Head


Hand-Held Control Head

The TMAC70 is a hand-held control head for mobile radios that enables the user to operate the radio at a distance from the radio body. The hand-held control head plugs into one of the RJ45 sockets on the appropriate remote control head. A remote speaker is required when a hand-held control head is installed. Refer to the TMAC70 Hand-Held Control Head Installation Instructions (402-00042-xx) for full details.



Remote Hand-Held Control Head

The TMAA03-32 is an installation kit for remotely mounting the TMAC70 hand-held control head. The following diagram summarizes how the components are installed. The items named or shown in **bold** below are part of the kit. Refer to the TMAA03-32 Hand-Held Control Head Remote Interface Kit Installation Instructions (402-00044-xx) for full details.



Hand-Held Control Head Extension

The TMAA04-14/15/16/17 kits can be used to extend the distance between a hand-held control head and the radio body or remote interface box by between 5 ft (1.5m) and 30 ft (9.2m), depending on the kit. A housing unit and gasket enclose the extension cable socket, and provide additional strain relief and some protection from water and dust ingress. Refer to the


TMAA04-14/15/16/17 Hand-Held Control Head Extension Kits Installation Instructions (402-00067-xx) for full details.



4.5 Dual-Radio System


Dual Radio Bodies

In a dual-radio system one control head is connected to two radio bodies. A dual-radio system can operate as a crossband repeater, where transmissions received on one radio can automatically be transmitted on the other. It can also allow the user to receive and transmit simultaneously on two separate frequency bands without the need for manual switching. The following diagram summarizes how the components are installed. The items shown in **bold** are part of a typical dual-radio system. Other equipment listed may need to be obtained or ordered separately. Refer to the TM8260 Mobile Installation and Programming Guide (MMA-00041-xx) for full details.




Dual Control Heads

The TMAA11-09 upgrade kit can be used to convert a TM8260 dual-body mobile radio to a TM8260 dual-body dual-head radio system. The following diagram summarizes how the components are installed. Items named or shown in **bold** are part of the upgrade kit. Refer to the TMAA11-09 TM8260 Dual Head Upgrade Kit Installation Instructions (402-00043-xx) for full details.




4.6 Desktop Power Supply



The TMAA13 power supply enables you to use a TM8000 mobile radio as a desktop radio. The TMAA13 operates on an input voltage of 100–130 VAC or 200–250 VAC, depending on the model, and can be used with both >25 W (high power) and 25 W (standard power) radios. The mobile radio can be installed at a distance from the power supply, or it can be mounted on top of the power supply using a plinth or U-bracket. The following diagram shows the components included in each kit. Refer to the TMAA13 Power Supplies User's Guide (MMZ-00002-xx) for full details.

Notice Radios fitted with a graphical control head do not fit the U-bracket and must use the plinth.



Tait Software License Agreement

This Software License Agreement ("Agreement") is between you ("Licensee") and Tait Limited ("Tait").

By using any of the Software items embedded and pre-loaded in the related Tait Designated Product, included on CD, downloaded from the Tait website, or provided in any other form, you agree to be bound by the terms of this Agreement. If you do not agree to the terms of this Agreement, do not install or use any of the Software. If you install or use any of the Software, that will be deemed to be acceptance of the terms of this Agreement.

For good and valuable consideration, the parties agree as follows:

Section 1 DEFINITIONS

"Confidential Information" means all or any information supplied to or received by Licensee from Tait, whether before or after installation or use and whether directly or indirectly pertaining to the Software and Documentation supplied by Tait, including without limitation all information relating to the Designated Products, hardware, software; copyright, design registrations, trademarks; operations, processes, and related business affairs of Tait; and including any other goods or property supplied by Tait to Licensee pursuant to the terms of this Agreement.

"Designated Products" means products provided by Tait to Licensee with which or for which the Software and Documentation is licensed for use.

"Documentation" means product and software documentation that specifies technical and performance features and capabilities; user, operation, and training manuals for the Software; and all physical or electronic media upon which such information is provided.

"Executable Code" means Software in a form that can be run in a computer and typically refers to machine language, which is comprised of native instructions the computer carries out in hardware. Executable code may also refer to programs written in interpreted languages that require additional software to actually execute.

"Intellectual Property Rights" and **"Intellectual Property"** mean the following or their substantial equivalents or counterparts, recognized by or through action before any governmental authority in any jurisdiction throughout the world and including, but not limited to all rights in patents, patent applications, inventions, copyrights, trademarks, trade secrets, trade names, and other proprietary rights in or relating to the Software and Documentation; including any adaptations, corrections, de-compilations, disassemblies, emulations, enhancements, fixes, modifications, translations and updates to or derivative works

from, the Software or Documentation, whether made by Tait or another party, or any improvements that result from Tait processes or, provision of information services.

"Licensee" means any individual or entity that has accepted the terms of this License.

"Open Source Software" means software with freely obtainable source code and license for modification, or permission for free distribution.

"Open Source Software License" means the terms or conditions under which the Open Source Software is licensed.

"Person" means any individual, partnership, corporation, association, joint stock company, trust, joint venture, limited liability company, governmental authority, sole proprietorship, or other form of legal entity recognized by a governmental authority.

"Security Vulnerability" means any flaw or weakness in system security procedures, design, implementation, or internal controls that if exercised (accidentally triggered or intentionally exploited) could result in a security breach such that data is compromised, manipulated, or stolen, or a system is damaged.

"Software" (i) means proprietary software in executable code format, and adaptations, translations, de-compilations, disassemblies, emulations, or derivative works of such software; (ii) means any modifications, enhancements, new versions and new releases of the software provided by Tait; and (iii) may contain one or more items of software owned by a third-party supplier. The term "Software" does not include any third-party software provided under separate license or not licensable under the terms of this Agreement.

"Source Code" means software expressed in human readable language necessary for understanding, maintaining, modifying, correcting, and enhancing any software referred to in this Agreement and includes all states of that software prior to its compilation into an executable programme.

"Tait" means Tait Limited and includes its Affiliates.

Section 2 SCOPE

This Agreement contains the terms and conditions of the license Tait is providing to Licensee, and of Licensee's use of the Software and Documentation. Tait and Licensee enter into this Agreement in connection with Tait delivery of certain proprietary Software and/or products containing embedded or pre-loaded proprietary Software.

Section 3 GRANT OF LICENSE

3.1. Subject to the provisions of this Agreement and the payment of applicable license fees, Tait grants to Licensee a personal, limited, non-transferable (except as permitted in Section 7),

and non-exclusive license to use the Software in executable code form, and the Documentation, solely in connection with Licensee's use of the Designated Products for the useful life of the Designated Products. This Agreement does not grant any rights to source code.

3.2. If the Software licensed under this Agreement contains or is derived from Open Source Software, the terms and conditions governing the use of such Open Source Software are in the Open Source Software Licenses of the copyright owner and not in this Agreement. If there is a conflict between the terms and conditions of this Agreement and the terms and conditions of the any applicable Open Source Software Licenses, the terms and conditions of the Open Source Software Licenses will take precedence. For information about Open Source Components contained in Tait products and the related Open Source licenses, see:

<http://support.taitradio.com/go/opensource>

Section 4 LIMITATIONS ON USE

4.1. Licensee may use the Software only for Licensee's internal business purposes and only in accordance with the Documentation. Any other use of the Software is strictly prohibited. Without limiting the general nature of these restrictions, Licensee will not make the Software available for use by third parties on a "time sharing," "application service provider," "service bureau" basis, or for any other similar commercial rental or sharing arrangement.

4.2. Licensee will not, and will not directly or indirectly allow or enable any third party to: (i) reverse engineer, disassemble, extract components, decompile, reprogram, or otherwise reduce the Software or any portion thereof to a human perceptible form or otherwise attempt to recreate the source code; (ii) modify, adapt, create derivative works of, or merge the Software; (iii) copy, reproduce, distribute, lend, or lease the Software or Documentation to any third party; (iv) grant any sublicense or other rights in the Software or Documentation to any third party; (v) take any action that would cause the Software or Documentation to be placed in the public domain; (vi) remove, or in any way alter or obscure any copyright notice or other notice of Tait or third-party licensor's proprietary rights; (vii) provide, copy, transmit, disclose, divulge or make the Software or Documentation available to, or permit the use of the Software by, any third party or on any machine except as expressly authorized by this Agreement; or (viii) use, or permit the use of, the Software in a manner that would result in the production of a copy of the Software by any means whatsoever other than what is permitted in this Agreement. Licensee may make one copy of the Software to be used solely for archival, back-up, or disaster recovery purposes; provided that Licensee may not operate that copy of the Software at the same time as the original Software is being operated. Licensee may make as many copies of the Documentation as it may reasonably require for the internal use of the Software.

4.3. Unless otherwise authorized by Tait in writing, Licensee will not, and will not enable or allow any third party to: (i) install a copy of the Software on more than one unit of a Designated Product; or (ii) copy or transfer Software installed on one unit of a Designated Product to any other device. Licensee may temporarily transfer Software installed on a Designated Product to another device if the Designated Product is inoperable or malfunctioning. Temporary transfer of the Software to another device must be discontinued when the original Designated Product is returned to operation and the Software must be removed from the other device.

4.4. Licensee will maintain, during the term of this Agreement and for a period of two years thereafter, accurate records relating to this license grant to verify compliance with this Agreement. Tait, or a third party nominated by Tait, may inspect Licensee's premises, books and records, upon reasonable prior notice to Licensee, during Licensee's normal business hours and subject to Licensee's facility and security regulations. Tait is responsible for the payment of all expenses and costs of the inspection, provided that Licensee shall indemnify Tait for all costs (including audit costs and legal costs on a solicitor client basis) if Licensee has breached the terms of this Agreement. Any information obtained by Tait during the course of the inspection will be kept in strict confidence by Tait and used solely for the purpose of verifying Licensee's compliance with the terms of this Agreement.

Section 5 OWNERSHIP AND TITLE

Tait, its licensors, and its suppliers retain all of their Intellectual Property Rights in and to the Software and Documentation, in any form. No rights are granted to Licensee under this Agreement by implication, estoppel or otherwise, except for those rights which are expressly granted to Licensee in this Agreement. All Intellectual Property developed, originated, or prepared by Tait in connection with providing the Software, Designated Products, Documentation, or related services, remains vested exclusively in Tait, and Licensee will not have any shared development or other Intellectual Property Rights.

Section 6 LIMITED WARRANTY; DISCLAIMER OF WARRANTY

6.1. The commencement date and the term of the Software warranty will be a period of one (1) year from Tait shipment of the Software. If Licensee is not in breach of any obligations under this Agreement, Tait warrants that the unmodified Software, when used properly and in accordance with the Documentation and this Agreement, will be free from a reproducible defect that eliminates the functionality or successful operation of a feature critical to the primary functionality or successful operation of the Software. Whether a defect has occurred will be determined solely by Tait. Tait does not warrant that Licensee's use of the Software or

the Designated Products will be uninterrupted, error-free, completely free of Security Vulnerabilities, or that the Software or the Designated Products will meet Licensee's particular requirements. Tait makes no representations or warranties with respect to any third-party software included in the Software.

6.2 Tait sole obligation to Licensee, and Licensee's exclusive remedy under this warranty, is to use reasonable efforts to remedy any material Software defect covered by this warranty. These efforts will involve either replacing the media or attempting to correct significant, demonstrable program or documentation errors or Security Vulnerabilities. If Tait cannot correct the defect within a reasonable time, then at Tait option, Tait will replace the defective Software with functionally equivalent Software, license to Licensee substitute Software which will accomplish the same objective, or terminate the license and refund Licensee's paid license fee. If Tait investigation of the perceived defect reveals that no such defect in fact exists, Tait may recover its costs in respect of such investigation from Licensee.

6.3. Tait disclaims any and all other warranties relating to the Software or Documentation other than the express warranties set forth in this Section 6. Warranties in Section 6 are in lieu of all other warranties whether express or implied, oral or written, and including without limitation any and all implied warranties of condition, title, non-infringement, merchantability, or fitness for a particular purpose or use by Licensee (whether Tait knows, has reason to know, has been advised of, or is otherwise aware of any such purpose or use), whether arising by law, by reason of custom or usage of trade, or by course of dealing. In addition, Tait disclaims any warranty to any person other than Licensee with respect to the Software or Documentation.

Section 7 TRANSFERS

7.1. Licensee will not transfer the Software or Documentation to any third party without specific prior written consent from Tait. Tait may withhold such consent or at its own discretion make the consent conditional upon the transferee paying applicable license fees and agreeing to be bound by this Agreement.

7.2. In the case of a value-added reseller or distributor of Tait Designated Products, the consent referred to in Section 7.1 may be contained in a Tait Reseller or Tait Distributor Agreement.

7.3. If the Designated Products are Tait vehicle-mounted mobile products or hand-carried portable radio products and Licensee transfers ownership of the Tait mobile or portable radio products to a third party, Licensee may assign its right to use the Software which is embedded in or furnished for use with the radio products and the related Documentation; provided that Licensee transfers all copies of the Software and Documentation to the transferee.

7.4. For the avoidance of any doubt, Section 7.3 excludes TaitNet Infrastructure, or the

products listed at any time under network products at: <http://www.taitradio.com>.

7.5. If Licensee, as a contractor or subcontractor (integrator), is purchasing Tait Designated Products and licensing Software not for its own internal use but for end use only by a Customer, the Licensee may transfer such Software, but only if a) Licensee transfers all copies of such Software and the related Documentation to the transferee and b) Licensee has first obtained from its Customer (and, if Licensee is acting as a subcontractor, from the interim transferee(s) and from the ultimate end user sub license) an enforceable sublicense agreement that prohibits any other transfer and that contains restrictions substantially identical to the terms set forth in this Software License Agreement. Except as stated in the foregoing, Licensee and any transferee(s) authorised by this Section may not otherwise transfer or make available any Tait Software to any third party nor permit any party to do so. Licensee will, on request, make available evidence reasonably satisfactory to Tait demonstrating compliance with all the foregoing.

Section 8 TERM AND TERMINATION

8.1. Licensee's right to use the Software and Documentation will commence when the Designated Products are supplied by Tait to Licensee and will continue for the life of the Designated Products with which or for which the Software and Documentation are supplied, unless Licensee breaches this Agreement, in which case this Agreement and Licensee's right to use the Software and Documentation may be terminated immediately upon notice by Tait.

8.2. Within thirty (30) days after termination of this Agreement, Licensee must certify in writing to Tait that all copies of the Software have been removed or deleted from the Designated Products and that all copies of the Software and Documentation have been returned to Tait or destroyed by Licensee and are no longer in use by Licensee.

8.3. Licensee acknowledges that Tait made a considerable investment of resources in the development, marketing, and distribution of the Software and Documentation and that Licensee's breach of this Agreement will result in irreparable harm to Tait for which monetary damages would be inadequate. If Licensee breaches this Agreement, Tait may terminate this Agreement and be entitled to all available remedies at law or in equity including immediate injunctive relief and repossession of all non-embedded Software and associated Documentation. Licensee shall pay all Tait costs (on an indemnity basis) for the enforcement of the terms of this Agreement.

Section 9 CONFIDENTIALITY

Licensee acknowledges that the Software and Documentation contain proprietary and Confidential Information valuable to Tait and are Tait trade secrets, and Licensee agrees to respect the confidentiality of the information con-

tained in the Software and Documentation.

Section 10 LIMITATION OF LIABILITY

10.1. In no circumstances shall Tait be under any liability to Licensee, or any other person whatsoever, whether in Tort (including negligence), Contract (except as expressly provided in this Agreement), Equity, under any Statute, or otherwise at law for any losses or damages whether general, special, exemplary, punitive, direct, indirect, or consequential arising out of or in connection with any use or inability of using the Software.

10.2. Licensee's sole remedy against Tait will be limited to breach of contract and Tait sole and total liability for any such claim shall be limited at the option of Tait to the repair or replacement of the Software or the refund of the purchase price of the Software.

Section 11 GENERAL

11.1. COPYRIGHT NOTICES. The existence of a copyright notice on the Software will not be construed as an admission or presumption of publication of the Software or public disclosure of any trade secrets associated with the Software.

11.2. COMPLIANCE WITH LAWS. Licensee acknowledges that the Software may be subject to the laws and regulations of the jurisdiction covering the supply of the Designated Products and will comply with all applicable laws and regulations, including export laws and regulations, of that country.

11.3. ASSIGNMENTS AND SUBCONTRACTING. Tait may assign its rights or subcontract its obligations under this Agreement, or encumber or sell its rights in any Software, without prior notice to, or consent of, Licensee.

11.4. GOVERNING LAW. This Agreement shall be subject to and construed in accordance with New Zealand law and disputes between the parties concerning the provisions hereof shall be determined by the New Zealand Courts of Law. Provided however Tait may at its election bring proceedings for breach of the terms hereof or for the enforcement of any judgment in relation to a breach of the terms hereof in any jurisdiction Tait considers fit for the purpose of ensuring compliance with the terms hereof or obtaining relief for breach of the terms hereof.

11.5. THIRD-PARTY BENEFICIARIES. This Agreement is entered into solely for the benefit of Tait and Licensee. No third party has the right to make any claim or assert any right under this Agreement, and no third party is deemed a beneficiary of this Agreement. Notwithstanding the foregoing, any licensor or supplier of third-party software included in the Software will be a direct and intended third-party beneficiary of this Agreement.

11.6. SURVIVAL. Sections 4, 5, 6.3, 7, 8, 9, 10, and 11 survive the termination of this Agreement.

11.7. ORDER OF PRECEDENCE. In the event of inconsistencies between this Agree-

ment and any other Agreement between the parties, the parties agree that, with respect to the specific subject matter of this Agreement, this Agreement prevails.

11.8. SECURITY. Tait uses reasonable means in the design and writing of its own Software and the acquisition of third-party Software in order to limit Security Vulnerabilities. While no software can be guaranteed to be free from Security Vulnerabilities, if a Security Vulnerability is discovered, Tait will take the steps specified in Section 6 of this Agreement.

11.9. EXPORT. Licensee will not transfer, directly or indirectly, any Designated Product, Documentation or Software furnished hereunder or the direct product of such Documentation or Software to any country for which New Zealand or any other applicable country requires an export license or other governmental approval without first obtaining such license or approval.


11.10. SEVERABILITY. In the event that any part or parts of this Agreement shall be held illegal or null and void by any court or administrative body of competent jurisdiction, such determination shall not affect the remaining terms which shall remain in full force and effect as if such part or parts held to be illegal or void had not been included in this Agreement. Tait may replace the invalid or unenforceable provision with a valid and enforceable provision that achieves the original intent and economic effect of this Agreement.

11.11. CONSUMER GUARANTEES. Licensee acknowledges that the licenses supplied in terms of this agreement are supplied to Licensee in business, and that the guarantees and other provisions of prevailing consumer protection legislation shall not apply.

11.12. WHOLE AGREEMENT. Licensee acknowledges that it has read this Agreement, understands it and agrees to be bound by its terms and conditions. Licensee also agrees that, subject only to the express terms of any other agreement between Tait and Licensee to the contrary, this is the complete and exclusive statement of the Agreement between it and Tait in relation to the Software. This Agreement supersedes any proposal or prior agreement, oral or written, and any other communications between Licensee and Tait relating to the Software and the Designated Products.


Cable Connections

Terminating the Antenna Cable



For more information, refer to ["Installing the Antenna" on page 18](#).


Power and Remote Speaker Connections



Pin	Signal	Function
1	AGND	Earth return
2	SPK-	External speaker -
3	SPK+	External speaker +
4	+13V8 BATT	DC power input (10.8V to 16.0V)

For more information, refer to ["Connecting the Power Cable to the Power Source"](#) and ["Connecting a Remote Speaker" on page 21](#).

Ignition Sense, Emergency Switch, and External Alert Device Connections



Pin	Signal	Function
4	AUX GPI3	Ignition sense
5	AUX GPI2	Emergency switch +
8	+13V8 SW	External alert device +
10	AUX GPIO4	External alert device -
15	AGND	Emergency switch -

For more information, refer to ["Connecting to the Auxiliary Connector \(Ignition Signal, Emergency Switch, External Alert Devices\)" on page 22](#).

