


# A18-05775-XX

## ORDER WIRE CONTROL AND SPEAKER MONITOR PANEL



### Table of Contents

|                                |    |
|--------------------------------|----|
| Ordering Information .....     | 2  |
| General Description .....      | 2  |
| Circuit Description .....      | 3  |
| Installation .....             | 5  |
| Operation .....                | 9  |
| Technical Specifications ..... | 9  |
| Warranty .....                 | 10 |

#### About this Practice:

- This is a new document.

**Reissued Practices:** Updated and new content can be identified by a banner in the right margin.

**Issue date:** July 1998

UPDATED

### CAUTION

- Install or remove modules from the shelf only when the power is off. If you install a module in the shelf with the power on, the internal circuitry may suffer damage and the product warranty will be void.
- Remove and install circuit boards only in a static-safe environment (use antistatic wrist straps, smocks, footwear, etc.).
- Keep circuit boards in their antistatic bags when they are not in use.
- Do not ship or store circuit boards near strong electrostatic, electromagnetic, magnetic, or radioactive fields.
- For more complete information on electrostatic discharge safety precautions, refer to Bellcore™ Technical Reference # TR-NWT-000870.

# ORDERING INFORMATION

**NOTE:** This section lists the different options available for this product. To order any of the available options, contact Dantel Inside Sales through our toll-free number, 1-800-432-6835.

| OPTION NUMBER | FEATURES                   |
|---------------|----------------------------|
| A18-05775-00  | Speaker Monitor Panel only |

# GENERAL DESCRIPTION

The Dantel 41096 Order Wire Control and Speaker Monitor Panel (41096 Panel) provides centralized monitoring facilities for up to three selective signaling order-wire terminals. The panel can also be used to originate a call or answer an incoming call on an individual order wire channel.

The 41096 is mounted on a hinged bracket. The 41096 Panel occupies 3½" (2 rack units) in a 19" or 23" rack and operates on -21 to -56 VDC.

The 41096 Panel consists of a monitor section and a control section. The monitor section includes:

- ◆ A push-button channel selector
- ◆ A speaker with amplifier
- ◆ Two volume controls
- ◆ A fuse
- ◆ A fuse alarm LED

The control section includes:

- ◆ A push-button channel selector
- ◆ DTMF dial
- ◆ Handset
- ◆ Handset cradle
- ◆ Headset jacks

# CIRCUIT DESCRIPTION

Fig. 1 shows the 05775 Order Wire and Speaker Monitor Panel functional schematic.

The 05775 Panel monitoring section monitors all associated order wire channels over the speaker. Incoming calls couple to the speaker through transformers, operational amplifiers, and a volume control potentiometer.





The push-button speaker monitor channel selector monitors any one or two channels through an additional volume control potentiometer. This option allows the selected channel(s) to be monitored at a louder level. The unselected channels are still available for monitoring at a quieter level.

A fuse and fuse alarm indicator LED are located on the front panel. When the fuse blows, the alarm indicator LED lights up.

The control section is used to originate a call or answer an incoming call on an individual order wire channel. Pressing the channel button connects the handset to the respective order wire channel. A headset may be used instead of the handset.

# CIRCUIT DESCRIPTION

Fig. 1 - 05775 FUNCTIONAL SCHEMATIC



# INSTALLATION

The 05775 Order Wire Control and Speaker Monitor can be installed with existing DTSS3A Order Wire terminals.


## 1. Set the straps.

Refer to Table A and Fig. 2.

TABLE A - STRAP OPTIONS

| STRAP  | POSITION                          |
|--|-----------------------------------|
| <b>CONTROL LIMIT BYPASS</b>                            |                                   |
| ALL CHAN<br>Control Limit In<br>Control Limit Bypassed | CTL LMT A IN *<br>CTL LMT A OUT   |
| <b>CHAN SELECT</b>                                     |                                   |
| Control Limit In<br>Control Limit Bypassed             | CTRL LMT B IN *<br>CTRL LMT B OUT |
| * Default Setting                                      |                                   |

FIG.2 - FRONT PANEL AND STRAP OPTION LOCATIONS



CONTINUED . . .

# INSTALLATION

When a 05775 Panel is being installed with existing DTSS3A order wire terminal(s), the terminal(s) may be mounted behind the panel or near it. To mount the terminal(s) behind the panel, mount them to the panel before completing the rack mounting and wiring.


## 2. Remove mounting brackets.

Remove the mounting brackets from the order wire terminal(s) and replace them with the mounting brackets supplied with the 05775 panel. Install the brackets in the flush-mount position on the front of the order wire terminal(s).

## 3. Position 41096 Panel mounting brackets.

Position 05775 Panel mounting brackets for the desired mounting (5" projection or flush, for 19" or 23" width). Refer to Fig. 3.

FIG. 3 - MOUNTING BRACKET (ATTACH ANGLE) POSITIONS



CONTINUED . . .

# INSTALLATION

## 4. Install the inter-panel wiring for each channel.

Refer to Table B, Fig. 4 and Fig. 5. Dress the wiring across the rear of the 05775 Panel and through the wire-passage notches in the mounting brackets. Leave enough slack for the panel to open freely.

**TABLE B - INTER-PANEL WIRING**

| POWER                       |               |               |               |  |
|-----------------------------|---------------|---------------|---------------|--|
| -Battery                    |               | TB1-1         |               |  |
| Ground                      |               | TB1-3         |               |  |
| Chassis Ground              |               | TB1-2         |               |  |
| SIGNAL AND LAMP CONNECTIONS | CHANNEL       | CHANNEL       | CHANNEL       |  |
|                             | 1             | 2             | 3             |  |
| RCV Ring                    | RJ1-6 or C-3  | RJ2-6 or C-7  | RJ3-6 or C-11 |  |
| XMT Tip                     | RJ1-4 or C-29 | RJ2-4 or C-33 | RJ3-4 or C-37 |  |
| +Lamp                       | RJ1-7 or C-2  | RJ2-7 or C-6  | RJ3-7 or C-10 |  |
| RCV Tip                     | RJ1-3 or C-28 | RJ2-3 or C-32 | RJ3-3 or C-36 |  |
| XMT Ring                    | RJ1-5 or C-4  | RJ2-5 or C-8  | RJ3-5 or C-12 |  |
| -Lamp                       | RJ1-2 or C-27 | RJ2-2 or C-31 | RJ3-2 or C-35 |  |
| External Speaker            | RJ1-1 or C-26 | RJ2-1 or C-30 | RJ3-1 or C-34 |  |
| Speaker Ground              | RJ1-8 or C-1  | RJ2-8 or C-5  | RJ3-8 or C-9  |  |


**FIG 4 - 05775 REAR VIEW**



CONTINUED . . .

# INSTALLATION

FIG 5 - WIRING DIAGRAM



**5. Install the assembled unit into the rack.**

**6. Connect supply leads.**

**7. Connect input and/or output ports.**

Connect the appropriate input and/or output ports on each order wire (see the 00330 DTSS3A and subassembly documentation.)

# OPERATION

Initiate a call to the VNET (Off-Net) assembly by pressing the desired channel push-button, lifting the handset (or plugging in a headset) and dialing the desired station code. Answer an incoming call by pressing the channel push-button below the CALL LAMP LED and lifting the handset (or plugging in a headset).

To call another station, remove the handset from its cradle and call the desired site by speaking the site name into the handset.

Monitor all three order wire channels by turning the ALL CHAN SPEAKER VOLUME CONTROL clockwise until a sufficient level is heard.

Monitor a single channel by pressing the desired SPEAKER MONITOR CHAN SELECT push-button and turning the CHAN SELECT SPEAKER VOLUME CONTROL clockwise until a sufficient level is heard.

Reduce the level of other channel traffic by turning down the ALL CHAN SPEAKER VOLUME CONTROL. A limit resistor prevents other channel traffic from being completely turned off. This limit resistor can be bypassed with a bypass strap.

Monitor two channels at once by pressing two SPEAKER MONITOR CHANNEL SELECT push-buttons. When channel monitoring is no longer desired, return to all-channel monitoring by pressing and releasing the SPEAKER MONITOR CHANNEL SELECT push-button(s).

# TECHNICAL SPECIFICATIONS

| DESCRIPTION                 | VALUE   |
|-----------------------------|---|
| Input Voltage Range         | -21 to -56 VDC  |
| Input Current               |   |
| Idle                        | 75 mA @ -56 VDC   |
| Maximum                     | 250 mA @ -56 VDC  |
| Heat Dissipation            |   |
| Idle                        | 14.3 BTU/Hr. @ -56 VDC  |
| Maximum                     | 47.7 BTU/Hr. @ -56 VDC  |
| Weight                      |   |
| Option -00                  | 4 lb., 2 oz.  |
| Physical Dimensions         | 17 1/4"W (plus mounting hardware) x 3 1/2"H x 6"D<br>Handset projects 2 1/2" in front of panel. |
| Mounting Projection         | 5" or flush for 19" or 23" rack   |
| Operation Temperature Range | 0° to 55° C.  |
| Output Power                | 1 Watt  |
| Maximum Input Level         | -10 dBm   |
| Frequency Response          | 300 hz. to 3.6 KHz $\pm$ 1 dB @ 1 Watt (measured w/ 8 ohm resistor)                             |
| Input Impedance             | Low Impedance   |

# WARRANTY

## LIMITED WARRANTY

The Seller warrants that the standard hardware products sold will be free from defects in material and workmanship and perform to the Seller's applicable published specifications for a period of 18 months for hardware, and 3 months for software, from the date of the original invoice. The liability of the Seller hereunder shall be limited to replacing or repairing, at its option, any defective products which are returned F.O.B. to the Seller's plant, (or, at the Seller's option, refunding the purchase price of such products). In no case are products to be returned without first obtaining permission and a customer return authorization number from the Seller. In no event shall the Seller be liable for any consequential or incidental damages.

Equipment or parts which have been subject to abuse, misuse, accident, alteration, neglect, unauthorized repair or installation are not covered by warranty. The Seller shall make the final determination as to the existence and cause of any alleged defect. No warranty is made with respect to custom equipment or products produced to the Buyer's specifications except as specifically stated in writing by the Seller in the contract for such custom equipment.

This warranty is the only warranty made by the Seller with respect to the goods delivered hereunder, and may be modified or amended only by a written instrument signed by a duly authorized officer of the Seller and accepted by the Buyer.

Warranty and remedies on products not manufactured by the Seller are in accordance with warranty of the respective manufacturer. **THE SELLER MAKES NO OTHER WARRANTY OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED; AND ALL IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE WHICH EXCEEDS THE AFORESAID OBLIGATIONS IS HEREBY DISCLAIMED BY THE SELLER.**

## IN CASE OF DIFFICULTY

If you experience difficulty with this equipment, check the following, as appropriate:

- 1. Switch settings**
- 2. Signal levels**
- 3. Software configuration**
- 4. Connections between Dantel's equipment and your equipment.**

If there is still a problem, substitute equipment that is known to be good. For additional assistance, call Dantel's Technical Field Service Department weekdays, 6 A.M. to 5 P.M. pacific time:

**1-800-4DANTEL (1-800-432-6835).**

If a thorough checkout shows a piece of equipment has malfunctioned, you may return it to the factory. For repairs and emergency replacements, obtain a Return Material Authorization (RMA) number from the Customer Service Representative at **1-800-4DANTEL (1-800-432-6835)**.

To ensure expedient processing of your order, provide a purchase order number and shipping and billing information when requesting an RMA number. Also, when the units are returned to Dantel, include a description of the failure symptoms for each unit returned. Send defective equipment to:

**Dantel, Inc. • 2991 North Argyle Avenue • Fresno, California 93727-1388**



P.O. Box 55013 • Fresno, CA 93747-5013 Phone (209) 292-1111 Fax (209) 292-9355 <http://www.dantel.com>