



***Galaxy Power System 4848/100***  
***with 595 Series Rectifiers S1:3 and later***  
***(GPS 4848/100)***  
***H569-434***

Note: Refer to User's Guide Issue 8 for  
595 Series Rectifiers prior to S1:3.

User's Guide  
Select Code 167-792-155  
Comcode 107933384  
Issue 10  
February 2008



***User's Guide***  
***Select Code 167-792-155***  
***Comcode 107933384***  
***Issue 10***  
***February 2008***

***Galaxy Power System 4848/100***  
***with 595 Series Rectifiers S1:3 and later***  
***(GPS 4848/100)***  
***H569-434***

**Notice:**

The information, specifications, and procedures in this manual are subject to change without notice. Lineage Power assumes no responsibility for any errors that may appear in this document.



# ***Table of Contents***

## ***1 Introduction***

<i>GPS 4848/100</i>	<i>1-1</i>
<i>Overview</i>	<i>1-1</i>
<i>Illustration</i>	<i>1-2</i>
<i>Safety</i>	<i>1-3</i>
<i>Electromagnetic Compliance</i>	<i>1-3</i>
<i>CE Marking</i>	<i>1-3</i>
<i>Telcordia</i>	<i>1-3</i>
<i>Customer Service Contacts</i>	<i>1-4</i>
<i>Customer Service, Technical Support, Product</i>	
<i>Repair and Return, and Warranty Service</i>	<i>1-4</i>
<i>Customer Training</i>	<i>1-4</i>
<i>Downloads and Software</i>	<i>1-4</i>

## ***2 System Description***

<i>Overview</i>	<i>2-1</i>
<i>Block Diagram</i>	<i>2-1</i>
<i>System Components</i>	<i>2-2</i>
<i>Architecture</i>	<i>2-2</i>
<i>Introduction</i>	<i>2-2</i>
<i>Distributed</i>	<i>2-3</i>
<i>Centralized</i>	<i>2-5</i>
<i>Standard</i>	<i>2-7</i>
<i>Non-Traditional</i>	<i>2-7</i>

## ***3 Galaxy Millennium Controller***

<i>Overview</i>	<i>3-1</i>
<i>Mounting Location</i>	<i>3-1</i>
<i>Circuit Boards</i>	<i>3-1</i>
<i>Reference Material</i>	<i>3-1</i>
<i>Controller Product Manual</i>	<i>3-1</i>
<i>RPM System Product Manual</i>	<i>3-1</i>
<i>User Interface and Display</i>	<i>3-2</i>
<i>Front Panel</i>	<i>3-2</i>
<i>Default Display</i>	<i>3-2</i>
<i>LEDs</i>	<i>3-3</i>
<i>Pushbutton Controls</i>	<i>3-3</i>
<i>Test Jacks</i>	<i>3-3</i>

## **4 Rectifiers**

<i>595 Series</i>	4-1
<i>Overview</i>	4-1
<i>Front Panel Display</i>	4-2
<i>Power Switch</i>	4-2
<i>Status Indicators</i>	4-2
<i>Current Display</i>	4-2
<i>Lamp Test</i>	4-2
<i>Illustration</i>	4-2
<i>Features</i>	4-3
<i>Output Voltage Adjustment</i>	4-3
<i>Output Current “Walk-in”</i>	4-3
<i>Electronic Current Limit</i>	4-3
<i>Selective High Voltage Shutdown (SHVSD)</i>	4-3
<i>Backup High Voltage Shutdown (BHVSD)</i>	4-3
<i>Restart</i>	4-3
<i>Output Circuit Breaker</i>	4-3
<i>Fan Alarm and Control</i>	4-3
<i>Thermal Alarm</i>	4-4
<i>Controller Communications Alarm</i>	4-4
<i>Autonomous Operation of the Rectifier</i>	4-4
<i>Connectorized</i>	4-4
<i>“Forced” Load Sharing</i>	4-4

## **5 AC Input Panels**

<i>Overview</i>	5-1
<i>AC Service</i>	5-1

## **6 Battery Connection Panels**

<i>Overview</i>	6-1
<i>Introduction</i>	6-1
<i>Distributed Architecture</i>	6-1
<i>Centralized Architecture</i>	6-1
<i>Illustrations</i>	6-1

## **7 DC Distribution Panels**

<i>Overview</i>	7-1
<i>Function</i>	7-1

## **8 Circuit Boards**

<i>Overview</i>	8-1
<i>Function</i>	8-1
<i>Terminal Boards</i>	8-1
<i>Alarm Boards</i>	8-1
<i>Alarm/Terminal Boards</i>	8-1
<i>BLJ Terminal Board</i>	8-1
<i>Bay Interface Card</i>	8-2
<i>Contact Control Board</i>	8-2

## **9 Specifications**

<i>GPS 4848/100</i>	9-1
<i>Rectifiers</i>	9-4
<i>AC Input Panels</i>	9-7
<i>Battery Connection Panels</i>	9-7
<i>DC Distribution Panels</i>	9-8

## **10 Safety**

## **11 Maintenance and Replacement**

<i>Requirements</i>	11-1
<i>System</i>	11-1
<i>Batteries</i>	11-1
<i>Controller</i>	11-1
<i>Rectifier</i>	11-2
<i>Vacant Rectifier Positions</i>	11-2
<i>Rectifier Fan Assembly</i>	11-2
<i>Replacement Procedures</i>	11-3
<i>Installing or Replacing a Rectifier</i>	11-3
<i>Removing a Rectifier</i>	11-7
<i>Replacing the Rectifier Fan Assemblies</i>	11-9
<i>Testing</i>	11-11
<i>Testing Additional Alarms After Replacing Rectifiers</i>	11-11
<i>Testing Rectifiers and Load Share in Bay Expansions</i>	11-11
<i>Replacement Parts</i>	11-12
<i>System</i>	11-12
<i>Millennium Controller Circuit Boards</i>	11-13
<i>Additional Ordering Information</i>	11-13
<i>Documentation</i>	11-13
<i>Software</i>	11-13

## **12 Troubleshooting Preparations**

<i>Preliminary</i>	12-1
<i>Introduction</i>	12-1
<i>Safety</i>	12-1
<i>Tools</i>	12-1
<i>Troubleshooting Procedure</i>	12-2
<i>Purpose</i>	12-2
<i>Cabinet Alarm</i>	12-2
<i>System Status</i>	12-3
<i>Alarms Menu</i>	12-3
<i>Troubleshooting Tables</i>	12-3
<i>Identifying Problems</i>	12-3
<i>Reference Figures</i>	12-4
<i>Figure Numbers and Titles</i>	12-4
<i>Millennium Controller</i>	12-4
<i>Rectifier</i>	12-6
<i>Low Voltage Battery Disconnect</i>	12-7
<i>AC Input</i>	12-8
<i>DC Distribution</i>	12-9
<i>Low Voltage Load Disconnect</i>	12-10

## **13 Troubleshooting Millennium Systems**

<i>Introduction</i>	13-1
<i>In This Section</i>	13-1
<i>Preparation</i>	13-1
<i>Technical Assistance</i>	13-1
<i>Troubleshooting Tables</i>	13-2
<i>Organization</i>	13-2
<i>Table Reference</i>	13-2
<i>Rectifier Display Messages and LEDs</i>	13-2
<i>Millennium Controller Display</i>	13-3
<i>AC Alarm LED</i>	13-3
<i>BATT Alarm LED</i>	13-4
<i>CTRL Alarm LED</i>	13-5
<i>DIST Alarm LED</i>	13-9
<i>RECT Alarm LED</i>	13-10
<i>BD and RM Alarm LEDs, or No LED</i>	13-15

## **14 Product Warranty**

## *List of Figures*

<i>Figure 1-1: GPS 4848/100 With Millennium Controller</i>	<i>1-2</i>
<i>Figure 2-1: Block Diagram of the GPS 4848/100</i>	<i>2-1</i>
<i>Figure 2-2: Distributed Architecture</i>	<i>2-3</i>
<i>Figure 2-3: Distributed Architecture Initial and Growth Cabinets</i>	<i>2-4</i>
<i>Figure 2-4: Centralized Architecture</i>	<i>2-5</i>
<i>Figure 2-5: Centralized Architecture Initial and Growth Cabinets</i>	<i>2-6</i>
<i>Figure 2-6: Non-Traditional Cabling Arrangements</i>	<i>2-7</i>
<i>Figure 3-1: Galaxy Millennium Controller Front Panel</i>	<i>3-2</i>
<i>Figure 4-1: Rectifier Front Panel</i>	<i>4-2</i>
<i>Figure 5-1: H569-434 G20/220/320 (ED83142-30 G3) 208/240V AC Input Circuit Breaker Panel</i>	<i>5-1</i>
<i>Figure 5-2: H569-434 G21/23 (ED83142-30 G4) 208/240/480V AC Input Circuit Breaker Panel</i>	<i>5-2</i>
<i>Figure 5-3: H569-434 G22 (ED83142-30 G2) 480V AC Input Circuit Breaker Panel</i>	<i>5-2</i>
<i>Figure 5-4: H569-434 G24/25/26/27/128/129/130/131/224/226 (ED83142-30 G5) 208/240/480V AC input Terminal Strip Panel</i>	<i>5-3</i>
<i>Figure 5-5: H569-434 G70 (ED83142-30 G10) 480V 65kAIC AC Input Circuit Breaker Panel</i>	<i>5-3</i>
<i>Figure 5-6: H569-434 G71 (ED83142-30 G11) 480V 65kAIC AC Input Circuit Breaker Panel</i>	<i>5-4</i>
<i>Figure 6-1: H569-434 G30 (ED83143-31 G32) Battery Connection Panel</i>	<i>6-2</i>
<i>Figure 6-2: H569-434 G31 (ED83143-31 G31) Battery Connection Panel</i>	<i>6-2</i>

<i>Figure 6-3: H569-434 G32 (ED83143-31 G30) Battery Connection Panel</i>	<i>6-3</i>
<i>Figure 6-4: H569-434 G34 (ED83143-31 G41) Battery Connection Panel</i>	<i>6-3</i>
<i>Figure 6-5: H569-434 G35 (ED83143-31 G42) Battery Connection Panel</i>	<i>6-4</i>
<i>Figure 6-6: H569-434 G37/38 (ED83143-31 G60/61) Battery (OLE) Connection Panel</i>	<i>6-4</i>
<i>Figure 6-7: H569-434 G80/81/82 (ED83143-31 G31/43) Battery Connection Panel</i>	<i>6-5</i>
<i>Figure 6-8: H569-434 G86/87 (ED83143-31 G63/64) Battery Connection Panel</i>	<i>6-6</i>
<i>Figure 7-1: H569-434 G40/45/50/55 (ED83143-31 G11) 400A DC Distribution Panel</i>	<i>7-1</i>
<i>Figure 7-2: H569-434 G41/46/51/56 (ED83143-31 G12) 400A DC Distribution Panel</i>	<i>7-2</i>
<i>Figure 7-3: H569-434 G42/47 (ED83143-31 G2) 600A DC Distribution Panel</i>	<i>7-2</i>
<i>Figure 7-4: H569-434 G43 (ED83143-31 G1) 1200A DC Distribution Panel</i>	<i>7-3</i>
<i>Figure 7-5: H569-434 G48 (ED83143-31 G5) 1000A DC Distribution Panel</i>	<i>7-3</i>
<i>Figure 7-6: H569-434 G52 (ED83143-31 G53) 600A DC Distribution Panel</i>	<i>7-4</i>
<i>Figure 7-7: H569-434 G53/57 (ED83143-31 G55) 1000A DC Distribution Panel</i>	<i>7-4</i>
<i>Figure 7-8: HH569-434 G59 (ED83143-31 G56) 2-Position Fuse Distribution Panel</i>	<i>7-5</i>
<i>Figure 7-9: H569-434 G60/61/65/66 (ED83143-31 G71) 600A DC Distribution Panel</i>	<i>7-5</i>
<i>Figure 7-10: H569-434 G67 (ED83143-31 G22) 600A DC Distribution Panel</i>	<i>7-6</i>
<i>Figure 7-11: H569-434 G68 (ED83143-31 G21) 1200A DC Distribution Panel</i>	<i>7-6</i>

<i>Figure 7-12: H569-434 G96 (ED83143-31 G15) 510A DC Distribution Panel</i>	<i>7-7</i>
<i>Figure 7-13: H569-434 G97 (ED83143-31 G16) 14-Position, and H569-434 G98 (ED83143-31 G17) 22-Position DC Distribution Panel</i>	<i>7-7</i>
<i>Figure 7-14: H569-434 G54 (ED83143-31 G54) 5-Position DC Distribution Panel</i>	<i>7-8</i>
<i>Figure 7-15: H569-434 G58 (ED83143-31 G58) 6-Position GMT DC Distribution Panel</i>	<i>7-8</i>
<i>Figure 11-1: Installing a Rectifier in a Rectifier Shelf</i>	<i>11-5</i>
<i>Figure 11-2: Fan Replacement</i>	<i>11-9</i>
<i>Figure 12-1: Location of Cabinet Alarm Light and Controller</i>	<i>12-2</i>
<i>Figure 12-2: Millennium Controller Display</i>	<i>12-5</i>
<i>Figure 12-3: Millennium Controller Fuses and Circuit Boards</i>	<i>12-5</i>
<i>Figure 12-4: Rectifier Display</i>	<i>12-6</i>
<i>Figure 12-5: Low Voltage Battery Disconnect Contactor Control Switches</i>	<i>12-7</i>
<i>Figure 12-6: AC Input Panel and Rectifier Connection</i>	<i>12-8</i>
<i>Figure 12-7: DC Distribution Panel</i>	<i>12-9</i>
<i>Figure 12-8: Low Voltage Load Disconnect Contactor Control Switches</i>	<i>12-10</i>



## ***List of Tables***

<i>Table 9-A: Galaxy Power System 4848/100 Specifications</i>	<i>9-1</i>
<i>Table 9-B: 595 Series Rectifier Specifications - S1:3 and later</i>	<i>9-4</i>
<i>Table 9-C: Rectifier Display Messages and LEDs</i>	<i>9-6</i>
<i>Table 9-D: AC Panels</i>	<i>9-7</i>
<i>Table 9-E: Battery Connection Panels</i>	<i>9-7</i>
<i>Table 9-F: DC Distribution Panels</i>	<i>9-8</i>
<i>Table 11-A: GPS 4848/100 Replacement Parts</i>	<i>11-12</i>
<i>Table 11-B: Galaxy Millennium Controller Circuit Boards</i>	<i>11-13</i>
<i>Table 11-C: Product Documentation</i>	<i>11-13</i>
<i>Table 13-A: AC Alarms</i>	<i>13-3</i>
<i>Table 13-B: Battery Alarms</i>	<i>13-4</i>
<i>Table 13-C: Controller Alarms</i>	<i>13-5</i>
<i>Table 13-D: Distribution Alarms</i>	<i>13-9</i>
<i>Table 13-E: Rectifier Related Alarms</i>	<i>13-10</i>
<i>Table 13-F: Miscellaneous Alarms</i>	<i>13-15</i>



# ***1 Introduction***

## ***GPS 4848/100***

### ***Overview***

The Galaxy Power System (GPS) 4848/100 was developed to support -48 volt telecommunications powering solutions in worldwide markets. The GPS 4848/100 combines 200-ampere, fan-cooled, switchmode rectifiers, microprocessor control technologies, battery and load disconnect/reconnect options, and a comprehensive line of fuse and circuit breaker dc distribution options in a modular front-access design. This modularity ensures easy access, simplified installation and maintenance, and allows the system to expand in capacity and features as power needs grow.

With 10,000-ampere maximum capacity, distribution flexibility, and universal ac input capability, the GPS 4848/100 supports switching, transmission, and wireless applications in central office locations and environmentally controlled remote sites (huts or vaults). For centralized architecture, bus bars are available to 10,000A.

***Notes*** The Galaxy SCF Controller is no longer available in the GPS 4848/100. For information about systems with SCF controllers, see Issue 5 of this manual.


GPS 4848/100 supports 595LT series rectifiers, one per shelf. See GPS 4848/100 with Dual Rectifier Shelf User's Guide for Specifications of 595LT series rectifiers.

This document includes 595 series rectifiers S1:3 and later. For information about systems with 595 Series Rectifiers prior to S1:3, see Issue 8 of this manual.

## ***GPS 4848/100, continued***

***Illustration***

Figure 1-1 is an isometric view of the GPS 4848/100 with a Millennium Controller.



***Figure 1-1: GPS 4848/100 With Millennium Controller***

## ***GPS 4848/100, continued***

### ***Safety***

- UL<sup>1</sup> Listed (US and Canada): UL Subject 1801 with applicable sections of UL1950/CSA<sup>2</sup> 950)
- VDE Licensed to VDE 0805/IEC950/EN60950

### ***Electromagnetic Compliance***

- Emission:
  - FCC Part 15 Class B
  - EN55022 (CISPR 22) Radiated/Conducted Emission, Class B
- Immunity
  - IEC/EN 61000-4-2 ESD level 3 and 4
  - IEC/EN 61000-4-3 Radiated Immunity, 10V/m
  - IEC/EN 61000-4-4 Electrical Fast transients/Burst, level 4
  - IEC/EN 61000-4-5 Lightning Surge, level 4

### ***CE Marking***

- CE marked per European Union Council Directives:
  - Low-Voltage Directive (73/23/EEC) and
  - EMC Directive (89/336/EEC) as amended by CE Marking Directive (93/68/EEC)

### ***Telcordia***

- GR-63 and GR-1089 NEBS (including Level 3 testing)
- Report by an independent test house

---

1.UL is a registered trademark of Underwriters Laboratories, Inc.  
2.CSA is a registered trademark of Canadian Standards Association.

## ***Customer Service Contacts***

### ***Customer Service, Technical Support, Product Repair and Return, and Warranty Service***

For customers in the United States, Canada, Puerto Rico, and the US Virgin Islands, call 1-800-THE-1PWR (1-800-843-1797). This number is staffed from 7:00 am to 5:00 pm Central Time (zone 6), Monday through Friday, on normal business days. At other times this number is still available, but for emergencies only. Services provided through this contact include initiating the spare parts procurement process, ordering documents, product warranty administration, and providing other product and service information.

For other customers worldwide the 800 number may be accessed after first dialing the AT&T Direct country code for the country where the call is originating, or you may contact your local field support center or your sales representative to discuss your specific needs.

### ***Customer Training***

Lineage Power offers customer training on many Power Systems products. For information call 1-972-284-2163. This number is answered from 8:00 a.m. until 4:30 p.m., Central Time Zone (Zone 6), Monday through Friday.

### ***Downloads and Software***

To download the latest product information, product software and software upgrades, visit our web site at <http://www.lineagepower.com>

## 2 System Description

### Overview

#### Block Diagram

Figure 2-1 shows a basic block diagram of the Galaxy Power System 4848/100. It illustrates the arrangement and interconnections of the system components from the ac input to the dc output.




Figure 2-1: Block Diagram of the GPS 4848/100

## ***Overview, continued***

### ***System Components***

The power system accepts alternating current from the commercial utility or a standby ac power source and rectifies it to produce dc power for the using equipment. The system's control and alarm functions interact with the rectifiers and the office. In addition, the system provides overcurrent protection and charge, discharge, and distribution facilities. Battery reserve automatically provides a source of dc power if the commercial or standby ac fails. Battery reserve can be engineered to supply dc power for a specific period of time. In normal practice, battery capacity is sized to provide 3 to 8 hours of reserve time.

**AC Input** connects the commercial and/or standby ac power sources to the rectifiers within the system and provides overcurrent protection. In some applications the ac service is wired directly to the rectifiers and overcurrent protection is provided at the service panel.

**Rectifiers** convert an ac source voltage into the dc voltage level required to charge and float the batteries and to power the using equipment.

**Controller** provides the local and remote control, monitoring, and diagnostic functions required to administer the power system.

**Batteries** provide energy storage for an uninterrupted power feed to the using equipment during loss of ac input or rectifier failure.

**DC Distribution Panel** provides overcurrent protection, connection points for the using equipment, and bus bars used to interconnect the rectifiers, batteries, and dc distribution.

**Battery Connection Panel** provides connection points for the battery strings through battery disconnect fuse, contactors, current monitoring shunts, and equalize converters.

## ***Architecture***

### ***Introduction***

For the GPS 4848/100 system, the basic system components, i.e., ac input panels, battery connection panels, dc distribution panels, rectifiers, and controller, can be configured to form two distinct system architectures: a distributed architecture or a centralized architecture.


***Distributed***

In this system each cabinet contains ac distribution, dc distribution panels, battery connection panels, rectifiers, termination points for load circuits, and a battery shunt. The initial cabinet also contains the system controller and, as such, it can function as a stand-alone system. The rectifier output buses are interconnected to permit cabinets to share current and ensure common voltage references for all system rectifiers. Because each cabinet is basically a self-contained system, the overall system capacity can be increased by simply adding cabinet/battery entities. However, growing the system requires a distinct, dedicated floor plan.

During normal operation, the readings from the battery shunts are summed and subtracted from the rectifier current to obtain the system current. While the batteries are providing the system load power, the individual shunt may be monitored to determine the status of the individual battery sections.


Cabinets can be equipped with load and/or battery disconnect/reconnect contactors. Battery contactors prevent battery damage during deep discharges by disconnecting batteries. Load contactors can extend the time critical loads operate on battery discharge by disconnecting non-critical loads during discharge.

Figure 2-2 shows an example of GPS 4848/100 components configured in a distributed architecture; Figure 2-3 gives a front view of the distributed initial and growth cabinets.



***Figure 2-2: Distributed Architecture***

## ***Architecture, continued***



Initial Cabinet

Growth Cabinet


***Figure 2-3: Distributed Architecture Initial and Growth Cabinets***

## Architecture, continued

### Centralized


Figure 2-4 shows GPS 4848/100 components configured in a centralized architecture; Figure 2-5 provides a view of the centralized architecture initial and growth cabinets. Rectifiers, dc distribution panels, and batteries are cabled to external busbars where a single system shunt is provided to measure total system current. The initial cabinet contains ac distribution, rectifiers, the controller, and termination points for the system interconnect cables. Growth cabinets contain ac distribution, rectifiers, and cable termination points. A separate cabinet provides load distribution and protection facilities and may include load disconnect/reconnect contactors.

This architecture requires extensive up-front planning to determine the ultimate system capacity and engineering to size the external busbars appropriately; however, the system plan is not constrained to dedicated layouts as required for distributed architecture systems.



**Figure 2-4: Centralized Architecture**

## *Architecture, continued*



***Figure 2-5: Centralized Architecture Initial and Growth Cabinets***

## Cabinet Cabling Options

### Standard


Standard cabinets are designed so that ac, battery, and dc load cables are run through the top of the cabinet.

### Non-Traditional

Any of the battery panels and dc load panels (shown in Sections 6 and 7) may be used in cabinets that have non-traditional cabling orientations. However, only G20, G22, G24, G26, and G70 ac panels (shown in Section 5) are available for these cabinets (see Figure 2-6). Suffixes of the ac panels indicate the cabling arrangements listed below:

AC Panel Suffix	Cabling Arrangement	
	AC	Battery and DC Load
A	Through bottom of cabinet	Through bottom of cabinet
B	Through bottom of cabinet	Through top of cabinet
C	Through top of cabinet	Through bottom of cabinet

**Note:** Check H569-434 for availability.



**Figure 2-6: Non-Traditional Cabling Arrangements**



## **3**                      ***Galaxy Millennium Controller***

### ***Overview***

***Mounting Location***        The Galaxy Millennium Controller mounts inside the front door with the display viewed from the outside.

***Circuit Boards***            The Galaxy Millennium Controller is equipped with a Basic control board for basic operations and an optional Intelligent control board that provides advanced local and remote monitoring and data acquisition features. These control boards monitor each other's status and issue appropriate alarms in the event a failure occurs. Circuit packs are accessed by opening the hinged cover from the left side.

### ***Reference Material***

***Controller Product Manual***        A Galaxy Millennium Controller, Select Code 167-792-180, is furnished with every GPS 4848/100. Refer to the manual for information regarding configuration and operation.


***RPM System Product Manual***        Refer to the Galaxy Remote Peripheral Monitoring System product manual (Select Code 167-790-063) for additional information regarding module operation.

## User Interface and Display

### Front Panel

The control panel displays alarm and status indicators and provides test jacks to monitor the system output. Keys are provided for interacting with various menus that configure and monitor the system. The controller menus can be viewed in either English or Spanish.

The user's primary interface with the controller is a panel that includes a backlit LCD front panel display, two rows of LEDs, test jacks, and an array of simple pushbutton controls. See Figure 3-1.



**Figure 3-1: Galaxy Millennium Controller Front Panel**

### Default Display

The default display shows basic plant status. The controller returns to this display three minutes after the last time a key is pressed. The default screen display is similar to the following: The first line shows the number of alarms (0) and warnings (0) present in the system, the date and time. The next two lines show the plant voltage and the plant load. The last line shows the plant mode, which can be FLOAT, BOOST, STC (Slope Thermal Compensation), BTP (Battery Thermal Protection, a boost mode that offers protection against thermal runaway), or BATT TEST mode.

The information on the screen is updated automatically approximately every two seconds.

## ***User Interface and Display, continued***

### ***LEDs***

Two rows of LEDs show the source and severity of various alarms. An alarm may light two LEDs: one alarm LED and one status LED. More than one alarm LED may be on at the same time. In this case, the status LED will be that of the most severe active alarm.

The first row of seven LEDs indicates the source of the alarm: BD, battery on discharge; BATT, battery; DIST, distribution; RECT, rectifier; AC, ac power supply; RM, remote monitoring; and CTRL, controller.

The second row includes five LEDs. The first four LEDs indicate the severity of the reported alarms: CRIT, critical; MAJ, major; MIN, minor; and NORM, normal. Another LED, labeled COM, will be illuminated when the internal modem is in use.

A pushbutton labeled LAMP TEST tests the controller's circuit pack LEDs and front panel LEDs. It will also test the indicators of serially connected rectifiers.

### ***Pushbutton Controls***

A group of pushbutton keys beneath the backlit LCD display provides the primary user interface with the controller. These keys are used singly or in combination to navigate through the controller's menus. The following is the general description of these keys.

- Up arrow key: Use to navigate the menu; press the key to move the cursor up one line.
- Down arrow key: Use to navigate the menu; press the key to move the cursor down one line.
- Left arrow key: Use to navigate the menu; press the key to move the cursor left one field.
- Right arrow key: Use to navigate the menu; press the key to move the cursor right one field.
- MENU key: Press this key any time to view the MAIN menu.
- HELP key: Press this key to display limited on-line help information.
- ENTER key: Use this key to select a menu item.
- ESCAPE key: Use this key to return to the immediately higher level menu.

### ***Test Jacks***

A pair of test jacks allows direct measurement of the dc bus sense voltage being monitored.



# **4**                      ***Rectifiers***

## ***595 Series***

### ***Overview***

Two 200-ampere rectifiers are available for the GPS 4848/100 system: 595A Series and 595B Series. The 595A Series operates from 3-phase ac service with a phase-to-phase voltage within the range of 320-530Vac. The 595B Series operates from 3-phase ac service with a phase-to-phase voltage within the range of 170-260Vac.

The rectifiers are shipped separately from the cabinets for quick and straightforward installation into rectifier shelves at the site. Interconnections to ac input, dc output, and control signals occur automatically during insertion. The rectifiers are keyed to prevent installation of a rectifier with incompatible ac input. No operational settings or adjustments to potentiometers are necessary. The installer must set the rectifier's ID using the ON/STBY switch to allow the controller to learn the rectifier's physical location for alarm reporting.

## Front Panel Display

### Power Switch

This three-position switch has two active states:

- It controls the on/standby state of the rectifier.
- It is used to set the rectifier ID.

### Status Indicators

In addition to the ON and STBY LEDs, four other LEDs on the rectifier's faceplate indicate the rectifier's condition.

- The **ALM** LED is red and lights when a thermal alarm occurs or a rectifier fail condition occurs. This LED blinks when communication with the plant controller is not active.
- The **LIM** LED is yellow and lights when the unit is in current limit.
- The **FAN ALM** LED is red and lights when the fan inside the rectifier is not functioning properly.
- The **EQL** LED is yellow and lights when the rectifier is in equalize mode.


### Current Display

This display indicates the current of the rectifier. Upon specific no-power conditions, the 3-digit display will show informative messages.

### Lamp Test

To test the LEDs on the rectifier front panel, press the Lamp Test button on the controller.

### Illustration



**Figure 4-1: Rectifier Front Panel**

## ***Features***

### ***Output Voltage Adjustment***

This feature allows the rectifier output voltage to be set through the controller.

### ***Output Current “Walk-in”***

This feature controls the time (up to eight seconds) required for the rectifier to reach normal operating conditions after it is turned on. This feature minimizes the starting surge on the customer's power source.

### ***Electronic Current Limit***

When the output current tends to increase above the current limit set point (30% to 110% of rated output), the current limit circuit overrides the voltage regulating signal and safely limits the output current of the rectifier, thus preventing damage to itself, the battery, or the load.

### ***Selective High Voltage Shutdown (SHVSD)***

This feature allows the rectifier to respond and shut down at the output high voltage threshold set through the Galaxy controller.

### ***Backup High Voltage Shutdown (BHVSD)***

This is a hardwired feature independent of the rectifier's microcontroller. This feature is always active and will operate whether communicating with the controller or not and whether the rectifier's microcontroller is active or failed.

### ***Restart***

Upon shutdown, the rectifier will attempt to restart. The rectifier will try to restart three times before issuing a rectifier fail alarm to the controller. The rectifier will also accept a restart command from the controller for a remote restart.

### ***Output Circuit Breaker***

The output circuit breaker located on the front panel protects the power system from rectifier malfunction and may be used to disconnect the rectifier from the system output bus.

### ***Fan Alarm and Control***

The rectifier contains three cooling fans whose speed is based on ambient temperature and output power level. The fan's speed is lowered during low-load and low-temperature conditions to minimize audible noise and maximize fan life.

## ***Features, continued***

### ***Thermal Alarm***

The rectifier senses the internal operating temperature and will issue a thermal alarm if the internal temperature exceeds a safe operating level. Ambient temperatures above the maximum rating will result in a rectifier shutdown and the issuing of a thermal alarm (TA).

### ***Controller Communications Alarm***

When communications between the rectifier and controller are interrupted, the rectifier continues to operate and the red **ALM** LED on the rectifier blinks.

### ***Autonomous Operation of the Rectifier***

If communication with the Galaxy controller is lost, the rectifier will continue to operate and deliver regulated power to the system load.

### ***Connectorized***

The rectifiers provide the controller with a full complement of status and alarm messages. The rectifier status and alarm signals, ac input, and dc output are all connectorized for easy installation and maintenance. All connections automatically occur as the rectifier is physically mated to its shelf.

### ***“Forced” Load Sharing***

The controller forces rectifiers to load share by sending messages to them. In the event communication to the controller is lost or the controller malfunctions, load share balance is maintained while ac or dc power is applied to the rectifiers.

## **5**                      ***AC Input Panels***


### ***Overview***

#### ***AC Service***


The ac input panel provides the facility to terminate the 3-phase ac service to the GPS 4848/100. Depending upon the option ordered, the panel will connect 3-wire delta or 3-wire wye service to provide the phase-to-phase ac voltage required for the rectifiers.

In some systems, circuit breakers are provided in the AC Input Panel to protect the conductors providing ac service to the individual rectifiers. In other systems, the circuit breakers protecting these conductors are located in the building's ac service panel. In either case, conductors to each rectifier are protected by a dedicated circuit breaker.


Note: All wire sizes were based on the US National Electric Code.




***Figure 5-1: H569-434 G20/220/320 (ED83142-30 G3)  
208/240V AC Input Circuit Breaker Panel***




***Figure 5-2: H569-434 G21/23 (ED83142-30 G4)  
208/240/480V AC Input Circuit Breaker Panel***




***Figure 5-3: H569-434 G22 (ED83142-30 G2)  
480V AC Input Circuit Breaker Panel***



***Figure 5-4: H569-434 G24/25/26/27/128/129/130/131/224/226  
(ED83142-30 G5) 208/240/480V AC Input Terminal Strip Panel***



***Figure 5-5: H569-434 G70 (ED83142-30 G10)  
480V 65kAIC AC Input Circuit Breaker Panel***



***Figure 5-6: H569-434 G71 (ED83142-30 G11)  
480V 65kAIC AC Input Circuit Breaker Panel***

## **6**                      ***Battery Connection Panels***

### ***Overview***

#### ***Introduction***

Batteries are connected to the GPS 4848/100 cabinets based on the system architecture.

#### ***Distributed Architecture***

For distributed power architecture, the batteries are terminated on battery connection panels with shunts that monitor the battery charge / discharge current through circuits on the cabinet BIC (Bay Interface Card). These battery connection panels are located either in the very top of the cabinet (shunt-only panels) or directly below the ac input panel.

As options, these panels may also include fuses or low battery voltage disconnect/reconnect (LVBD/R) contactors. When equipped with contactor(s), contactor control card(s) provide local/manual control of the contactor(s) and communications with the controller for configured/remote control.

Off Line Equalize (OLE) battery connection panels additionally provide means to manually equalize single battery sections. A plug-in dc to dc converter provides up to 65V to fully charge battery section cells, equalizing cell float voltages. This restores fully charged cell capacity to each cell in the section. A timer terminates the manually initiated equalize operation.


#### ***Centralized Architecture***

For systems with centralized architecture, the batteries are connected between the system charge and charge return buses. In turn, these buses are connected to rectifier termination buses located behind the ac input panel.


#### ***Illustrations***

The battery connection panels are illustrated in Figures 6-1 through 6-8.


Note: Battery connection panels are blue; dc distribution panels are white.




**Figure 6-1: H569-434 G30 (ED83143-31 G32)  
Battery Connection Panel**




**Figure 6-2: H569-434 G31 (ED83143-31 G31)  
Battery Connection Panel**




**Figure 6-3: H569-434 G32 (ED83143-31 G30)  
Battery Connection Panel**




**Figure 6-4: H569-434 G34 (ED83143-31 G41)  
Battery Connection Panel**




**Figure 6-5: H569-434 G35 (ED83143-31 G42)  
Battery Connection Panel**



**Figure 6-6: H569-434 G37/38 (ED83143-31 G60/61)  
Battery (OLE) Connection Panel**



**Figure 6-7: H569-434 G80/81/82 (ED83143-31 G31/43)  
Battery Connection Panel**



**Figure 6-8: H569-434 G86/87 (ED83143-31 G63/64)  
Battery Connection Panel**


# 7 *DC Distribution Panels*

## *Overview*


### *Function*

A variety of dc distribution panels are available featuring large or small fuses and circuit breakers of both domestic and European design. All panels are equipped with an alarm card. When a fuse operates or a circuit breaker trips, a red LED on the alarm card lights, the cabinet alarm lights, and the alarm is transmitted to the controller. Replacement fuses and plug-in circuit breakers are listed in the *Replacement Parts* section.


Note: DC distribution panels are white; battery connection panels are blue.




**Figure 7-1: H569-434 G40/45/50/55 (ED83143-31 G11)  
400A DC Distribution Panel**




**Figure 7-2: H569-434 G41/46/51/56 (ED83143-31 G12)  
400A DC Distribution Panel**




**Figure 7-3: H569-434 G42/47 (ED83143-31 G2)  
600A DC Distribution Panel**




**Figure 7-4: H569-434 G43 (ED83143-31 G1)  
1200A DC Distribution Panel**




**Figure 7-5: H569-434 G48 (ED83143-31 G5)  
1000A DC Distribution Panel**




**Figure 7-6: H569-434 G52 (ED83143-31 G53)  
600A DC Distribution Panel**




**Figure 7-7: H569-434 G53/57 (ED83143-31 G55)  
1000A DC Distribution Panel**




**Figure 7-8: HH569-434 G59 (ED83143-31 G56)  
2-Position Fuse Distribution Panel**




**Figure 7-9: H569-434 G60/61/65/66 (ED83143-31 G71)  
600A DC Distribution Panel**




**Figure 7-10: H569-434 G67 (ED83143-31 G22)  
600A DC Distribution Panel**




**Figure 7-11: H569-434 G68 (ED83143-31 G21)  
1200A DC Distribution Panel**




**Figure 7-12: H569-434 G96 (ED83143-31 G15) 510A DC Distribution Panel**



**Figure 7-13: H569-434 G97 (ED83143-31 G16) 14-Position, and H569-434 G98 (ED83143-31 G17) 22-Position DC Distribution Panel**



**Figure 7-14: H569-434 G54 (ED83143-31 G54) 5-Position DC Distribution Panel**



**Figure 7-15: H569-434 G58 (ED83143-31 G58) 6-Position GMT DC Distribution Panel**

## **8**                      ***Circuit Boards***

### ***Overview***

#### ***Function***

Circuit boards (sometimes referred to as “cards” or “circuit packs”) are included in bays, battery connection panels, and dc distribution panels to provide data required by the controller and to control devices such as contactors and lamps.

#### ***Terminal Boards***

Terminal boards are used to provide shunt voltage data to the controller, where it is used to calculate current. Data from the terminal boards located on the battery connection panels are used to calculate battery current; data from terminal boards located on the dc distribution panels are used to calculate load currents.

#### ***Alarm Boards***

Alarm boards perform two functions:

- monitor panel functions and activate local indicators when faults occur on the panel;
- provide alarm data to the controller.

#### ***Alarm/Terminal Boards***

Alarm/terminal boards combine the functions of alarm boards and terminal boards.

#### ***BLJ Terminal Board***

The BLJ terminal board is located inside the cabinet door. The BLJ is the termination point for all signal cables in each cabinet and between cabinets.

## ***Overview, continued***

***Bay Interface Card*** Each cabinet has a Bay Interface Card (BIC) that attaches to the cabinet's terminal board (BLJ). The BIC provides controller access to alarm monitoring, battery voltages, battery currents, and temperature probes in the cabinet through the serial rectifier bus. The BIC also provides connection of the system serial rectifier bus to the bay rectifiers. See Figure 1-1.

***Contactor Control Board*** Contactor control boards provide four functions:

- Monitor and report shunt voltage to the controller
- Monitor and report contactor status to the controller
- Operate the contactor based on controller commands
- Operate or block the contactor based on maintenance switch settings

# 9 Specifications

## GPS 4848/100

**Table 9-A: Galaxy Power System 4848/100 Specifications**

Electrical	
Nominal output voltage	-48Vdc
Operating Voltage Range (Float or Boost)	-44Vdc to -58Vdc
Output Current (System Maximum)	10,000A <sup>1</sup> <sup>1</sup> Centralized bus bars available to 5,200A
Nominal Input Voltage (595A3 Rectifier)	380-480Vac, 3-wire plus ground
Nominal Input Voltage (595B3 Rectifier)	200-240Vac, 3-wire plus ground
Input Voltage Range per phase (595A3 Rectifier)	320Vac - 530Vac
Input Voltage Range per phase (595B3 Rectifier)	176Vac - 254Vac
Input Frequency Range	47 Hz - 63 Hz
System Efficiency (including ac and dc cables)	>88%
Regulation (line and load range with controller)	± 0.5%
AC Ripple	<100mVrms
Output Noise	<2mV psophometric
Electromagnetic Immunity	10V/meter over 20 MHz - 2000 MHz

**Table 9-A: Galaxy Power System 4848/100 Specifications (Continued)**

<b>Physical</b>																				
Width, Depth	600 mm, 600 mm (23.6 in. x 23.6 in.)																			
Weight (approximate, per cabinet)	250 kg (551 lbs.)																			
Height (cabinet only)	2134 mm (84.0 in.)																			
Height (cabinet with link bus bar)	2274 mm (89.5 in.)																			
<b>Environmental</b>																				
Maximum Input Current, per cabinet	120 amperes per phase, 3-wire																			
Heat Release, per cabinet (54Vdc 24A dc)	<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;"></th> <th style="width: 35%; text-align: center;">595A/LTA</th> <th style="width: 35%; text-align: center;">595B/LTB</th> </tr> </thead> <tbody> <tr> <td style="padding-left: 20px;">Per Rectifier</td> <td style="text-align: center;">1,030W (3,520 BTU/hr)</td> <td style="text-align: center;">1,180W (4,050 BTU/hr)</td> </tr> <tr> <td style="padding-left: 20px;">4 Rectifiers</td> <td style="text-align: center;">4,120W (14,100 BTU/hr)</td> <td style="text-align: center;">4,720W (16,120 BTU/hr)</td> </tr> <tr> <td style="padding-left: 20px;">6 Rectifiers</td> <td style="text-align: center;">6,180W (21,100 BTU/hr)</td> <td style="text-align: center;">7,080W (24,170 BTU/hr)</td> </tr> <tr> <td style="padding-left: 20px;">7 Rectifiers</td> <td style="text-align: center;">7,210W (24,600 BTU/hr)</td> <td style="text-align: center;">8,260W (28,200 BTU/hr)</td> </tr> <tr> <td style="padding-left: 20px;">8 Rectifiers</td> <td style="text-align: center;">8,240W (28,100 BTU/hr)</td> <td style="text-align: center;">9,440W (32,200 BTU/hr)</td> </tr> </tbody> </table>			595A/LTA	595B/LTB	Per Rectifier	1,030W (3,520 BTU/hr)	1,180W (4,050 BTU/hr)	4 Rectifiers	4,120W (14,100 BTU/hr)	4,720W (16,120 BTU/hr)	6 Rectifiers	6,180W (21,100 BTU/hr)	7,080W (24,170 BTU/hr)	7 Rectifiers	7,210W (24,600 BTU/hr)	8,260W (28,200 BTU/hr)	8 Rectifiers	8,240W (28,100 BTU/hr)	9,440W (32,200 BTU/hr)
	595A/LTA	595B/LTB																		
Per Rectifier	1,030W (3,520 BTU/hr)	1,180W (4,050 BTU/hr)																		
4 Rectifiers	4,120W (14,100 BTU/hr)	4,720W (16,120 BTU/hr)																		
6 Rectifiers	6,180W (21,100 BTU/hr)	7,080W (24,170 BTU/hr)																		
7 Rectifiers	7,210W (24,600 BTU/hr)	8,260W (28,200 BTU/hr)																		
8 Rectifiers	8,240W (28,100 BTU/hr)	9,440W (32,200 BTU/hr)																		
Operating Temperature	0°C to 40°C																			
Operating Relative Humidity	5% - 95%																			
<b>Units Per Initial Cabinet</b>																				
Rectifiers	0 - 6																			
Controller	1																			
Battery Disconnect Modules	1 - 3																			
DC Distribution	1 - 6 (maximum of 5 with battery disconnect)																			
<b>Units Per Growth Cabinet</b>																				
Rectifiers	0 - 6																			
Battery Disconnect Modules	0 - 1																			
DC Distribution	1 - 6 (maximum of 5 with battery disconnect)																			

**Table 9-A: Galaxy Power System 4848/100 Specifications (Continued)**

<b>Standards Compliance</b>	
Safety	<ul style="list-style-type: none"> <li>• UL<sup>3</sup> Listed (US and Canada): UL Subject 1801 with applicable sections of UL1950/CSA<sup>4</sup>950)</li> <li>• VDE Licensed to VDE 0805/IEC950/EN60950</li> </ul> <p><sup>3</sup>UL is a registered trademark of Underwriters Laboratories, Inc.</p> <p><sup>4</sup>CSA is a registered trademark of Canadian Standards Association.</p>
Electromagnetic Compliance	<ul style="list-style-type: none"> <li>• Emission:                             <ul style="list-style-type: none"> <li>– FCC Part 15 Class B</li> <li>– EN55022 (CISPR 22) Radiated/Conducted Emission, Class B</li> </ul> </li> <li>• Immunity                             <ul style="list-style-type: none"> <li>– IEC/EN 61000-4-2 ESD levels 3 and 4</li> <li>– IEC/EN 61000-4-3 Radiated Immunity, 10V/m</li> <li>– IEC/EN 61000-4-4 Electrical Fast Transients/Burst, level 4</li> <li>– IEC/EN 61000-4-5 Lightning Surge, level 4</li> </ul> </li> </ul>
CE Marking	<ul style="list-style-type: none"> <li>• CE marked per European Union Council Directives:                             <ul style="list-style-type: none"> <li>– Low-Voltage Directive (73/23/EEC)</li> <li>– EMC Directive (89/336/EEC)</li> </ul>                             as amended by CE Marking Directive (93/68/EEC)                         </li> </ul>
Telcordia	<ul style="list-style-type: none"> <li>• GR-63 and GR-1089 NEBS (including Level 3 testing)</li> <li>• Report by an independent test house</li> </ul>

## Rectifiers

**Table 9-B: 595 Series Rectifier Specifications - S1:3 and later**  
See Issue 8 for pre S1:3 specifications.

<b>Electrical</b>		
Output Voltage	52Vdc typical	
Equalize Voltage	65Vdc typical	
Output Voltage Adjustment	44-58Vdc float/boost 58-65Vdc equalize mode	
Regulation (with controller)	±0.5%	
High Voltage Shutdown (selected by controller)	Float/boost 44-60Vdc (56Vdc default) Equalize 44-67Vdc (65Vdc default)	
Backup High Voltage Shutdown	Float/boost 59-60Vdc (59.5Vdc nominal) Equalize 65.5-66.5Vdc (66Vdc nominal)	
Thermal Alarm	595A3 105°C <sup>I</sup> 595B3 103°C <sup>I</sup> <sup>I</sup> Internal rectifier component temperature	
Ripple	100mVrms	
Noise	<2mV psophometric	
Permanent Overload	220A <sub>dc</sub>	
Current Limit Set Point	60A <sub>dc</sub> - 220A <sub>dc</sub> (60A <sub>dc</sub> - 100A <sub>dc</sub> in equalize)	
Nominal Input Voltage 595A3 Rectifier	380-480Vac, 3-wire plus ground	
Nominal Input Voltage 595B3 Rectifier	200-240Vac, 3-wire plus ground	
Input Voltage Range	<b>595A3 Rectifier</b> 320Vac - 530Vac <b>595B3 Rectifier</b> 176Vac - 254Vac	
Input Current	<b>595A3 Rectifier</b> 20A at 480Vac 25A at 380Vac	<b>595B3 Rectifier</b> 40A at 208Vac 35A at 240Vac
Specified	30A	50A
Rated Maximum	23.7A at 320Vac 16.2A at 480Vac 20.4A at 380Vac	44.1A at 176Vac 38.8A at 200Vac 37.3A at 208Vac 32.3A at 240Vac
Typical Maximum	24.9A at 320Vac 16.6A at 480Vac 21.0A at 380Vac	45.3A at 176Vac 39.9A at 200Vac 38.3A at 208Vac 33.2A at 240Vac
Typical Maximum Rectifiers A3 / B3 S1:2 and prior		
Frequency Range	47 - 63 Hz	
Power Factor	>0.98 @ 50% to 100% load	
Total Harmonic Distortion	<5% @ 50% to 100% load	

**Table 9-B: 595 Series Rectifier Specifications - S1:3 and later**  
**See Issue 8 for pre S1:3 specifications. (Continued)**

<b>AC Surge Protection:</b> It is important that ac surges reaching rectifiers do not exceed the capacity of the rectifier internal surge protection. Protection must be provided external to the GPS system, if necessary, to limit surge energy reaching the rectifiers. Site surge protection must be coordinated with rectifier internal surge protection and must clamp at a lower voltage than the rectifier internal protection. The internal protection voltage and current characteristics of the rectifiers are as follows:	
<b>595A3</b>	
Phase to Phase	MOV Conduction
<u>Voltage</u>	<u>Current</u>
625 Vac (RMS)	0 A
940 Vpeak	1 mA
1650 Vpeak	100 A
<b>595B3</b>	
Phase to Phase	MOV Conduction
<u>Voltage</u>	<u>Current</u>
320 Vac (RMS)	0 A
462 Vpeak	1 mA
810 Vpeak	100 A
<b>Physical</b>	
Width	445 mm (17.5 in) rear of unit
Height	210 mm (8.25 in) rear of unit
Depth	470 mm (18.2 in) overall, less connector
Weight	27 kg (<59 lbs)
<b>Environmental</b>	
Efficiency	> 92% @ 100A <sub>dc</sub> - 220A <sub>dc</sub> output current
Storage Temperature	-40°C - +85°C
Storage Relative Humidity	5% - 90%
Altitude	-50 to 4000 meters ( <b>Note: For altitudes above 1500 meters, derate the temperature by 0.656° Celsius per 100 meters.</b> )
Audible Noise	< 60dBA at room temperature, mounted in cabinet
Heat Release:	Per Rectifier
54V <sub>dc</sub> , 160A	854W [2915 BTU/hr]
54V <sub>dc</sub> , 200A	1068W [3645.7 BTU/hr]

**Table 9-B: 595 Series Rectifier Specifications - S1:3 and later**  
**See Issue 8 for pre S1:3 specifications. (Continued)**

<b>Standards Compliance</b>	
Safety	<ul style="list-style-type: none"> <li>• UL Recognized (US and Canada) and VDE</li> <li>• UL1950, EN60950/IEC950, and CSA 234/950 (tested for SELV output)</li> </ul>
Electromagnetic Compliance: Emission and Immunity	<ul style="list-style-type: none"> <li>• EN55022 (CISPR22) Radiated/conducted emission, Class B meets FCC Part 15 Class B</li> <li>• IEC/EN 61000-4-2 ESD levels 3 and 4</li> <li>• IEC/EN61000-4-3 Radiated Immunity, 10Vm</li> <li>• IEC/EN61000-4-4 Electrical Fast Transients/Burst, level 4</li> <li>• IEC/EN 61000-4-5 Lightning Surge, level 4</li> </ul>
CE Marking	CE marked per European Union Council directives: Low-voltage Directive (73/23/EEC) as amended by CE Marking Directive (93/68/EEC)

**Table 9-C: Rectifier Display Messages and LEDs**

<b>State</b>	<b>Display Message</b>	<b>LED Illuminated</b>
Normal	Current	ON
Output Limited	Current	LIM
Manual Standby	Blank	STBY
Remote Standby (Shutdown)	tr	STBY
Output Breaker Open	CB	ALM
Interlock Open	ILC	ALM
AC Fail	ACF	None
Phase Fail	PF	None
Over Temperature Shutdown	tA	ALM
Output Under Voltage Shutdown	LO	ALM
High Voltage Shutdown	HO	ALM
Internal Failure	LS ICS IP5 IP6 IP7 SEN FSE InF	ALM

## AC Input Panels

**Table 9-D: AC Panels**

	Vac	AC Feeds	Rectifiers	ED83142-30	H569-434GPS4848/100
<b>AC Circuit Breaker Panels - 595 Rectifiers</b>					
	208/240	2	4	3	20, 220
	208/240	2	6	4	21
	480	1	4	2	22
	480	2	6	4	23
65KIC	480	2	4	10	70, 270
65KIC	480	2	6	11	71
<b>AC Terminal Strip Panels- 595 Rectifiers</b>					
	208/240	4	4	5	24, 224
	208/240	6	6	5	25
	208/240	8	8	18	129, 131
	480	4	4	5	26, 226
	480	6	6	5	27
	480	8	8	18	128, 130
<b>Distribution Only Panels, no ac</b>					
		-		None	28
		-		None	29

## Battery Connection Panels

**Table 9-E: Battery Connection Panels**

Fuse or Circuit Breaker	LVBD	Shunt	ED83143-31	H569-434 GPS4848/100
<b>No Battery Panel</b>				
			None	33
<b>Panels without Fuses or Circuit Breakers</b>				
		1,500A	30	32
	2,000A	3,000A	36	39
	1,200A	1,500A	31	31
	2 x 500A	2 x 600A	32	30
<b>Panels with Fuses or Circuit Breakers</b>				
2 x NH3 fuse		2 x 600A	41	34
1 x NH3 fuse		600A	42	35
2 x NH3 fuse	1,200A	2 x 600A	43 with 31	80
4 x NH3 fuse	1,200A	4 x 600A	2 x 43 with 31	81
6 x NH3 fuse	1,200A	6 x 600A	3 x 43 with 31	82
6 x breaker poles			63	86
6 x breaker poles	800A		64	87
<b>Off Line Equalize Panels</b>				
	1,200A	3 x 1,000A	60	37
		3 x 1,000A	61	38

## DC Distribution Panels

**Table 9-F: DC Distribution Panels**

Fuse or CB	Pos	Height (in.)	LVLD	Shunt	ED83143-31 Group <sup>1</sup>	H569-434 GPS 4848/100 Group <sup>1</sup>
CB Clip-on / Fuse Small - TPA	14	6			11	40, 40A, 50, 50A
CB Clip-on / Fuse Small - TPA	14	6	Y		11	45, 45A, 55, 55A
CB Clip-on / Fuse Small - TPA	22	9			12	41, 41A, 51, 51A
CB Clip-on / Fuse Small - TPA	22	9	Y		12	46, 46A, 56, 56A
CB Large – Bolt-in	3	6		CB size, 25mV	2	42, 42A, 106, 106A, 107, 107A, 108, 108A, 109, 109A
CB Large – Bolt-in	3	6	Y	CB size, 25mV	2	47, 47A
CB Large – Bolt-in	5	9		CB size, 25mV	5	48, 48A, 110, 110A, 111, 111A, 112, 112A, 113, 113A
CB Large – Bolt-in	5	9	Y	CB size, 25mV	5	48B, 48C
CB Large – Bolt-in	6	12		CB size, 25mV	1	43, 43A, 101, 101A, 102, 102A, 103, 103A, 104, 104A
CB Large – Bolt-in	6	12	Y	CB size, 25mV	1	43B, 43C
CB Bullet	10	6			15	96, 96A
CB Bullet	10	6	Y		15	96B, 96C
CB Bullet	14	6			16	97, 97A
CB Bullet	14	6	Y		16	97B, 97C
CB Bullet	22	9			17	98, 98A
CB Bullet	22	9	Y		17	98B, 98C
Fuse Medium - TPS	10	6			53	52, 52A
Fuse Medium - TPS	10	6	Y		53	52B, 52C
Fuse Large - TPL	2	9		600A, 50mV 1 / fuse	55	53, 53A
Fuse Large - TPL	2	9	Y	600A, 50mV 1 / fuse	55	57, 57A
Fuse Large - TPL-B	5	9		300A, 50mV 1 / fuse	54	54, 54A
Fuse Large - TPL-B	5	9	Y	300A, 50mV 1 / fuse	54	54B, 54C
CB DIN Small	14	6			71/171	60, 60A
CB DIN Small	14	6	Y		71/171	60B, 60C
CB DIN Large	10	6			71/171	61, 61A
CB DIN Large	10	6	Y		71/171	61B, 61C
Fuse DIN 10 x 38mm	14	6			71/171	65, 65A
Fuse DIN 10 x 38mm	14	6	Y		71/171	65B, 65C
Fuse DIN 14 x 51mm	10	6			71/171	66, 66A
Fuse DIN 14 x 51mm	10	6	Y		71/171	66B, 66C
Fuse DIN NH00	8	6			22	67, 67A
Fuse DIN NH00	8	6	Y		22	67B, 67C
Fuse DIN NH2	2	6			21	68, 68A
Fuse DIN NH2	2	6	Y		21	68B, 68C
Small Fuse, 6-GMT	6	0			58	58
Blank Panel	-	3			JD	93
Blank Panel	-	6			JA	90
Blank Panel	-	9			JB	91
Blank Panel	-	12			JC	92

1. Groups with B suffix or no suffix include return bus.

Groups with A or C suffix and Blank Panels do not include return bus.

# ***10***

# ***Safety***

Please read and follow all safety instructions and warnings before servicing the GPS 4848/100. Reference the Safety section of the GPS Installation Guide and individual module product manuals for safety statements specific to the modules.



# ***11 Maintenance and Replacement***

## ***Requirements***

### ***System***

With the exception of the battery, periodic maintenance specific to the power system is not required. The ac service for the building must be maintained with ANSI specified limits. The temperature and humidity within the power room must be maintained within the limits specified in Section 9 of this product manual.

Refer to Table 11-A for system replacement parts.

### ***Batteries***

The batteries must be maintained as directed by the battery manufacturer's requirements.

### ***Controller***

For replacement circuit packs for the Galaxy Millennium Controller, refer to Table 11-B.

## ***Requirements, continued***

### ***Rectifier***

With the exception of a fan failure, rectifiers are repaired by replacement.

Refer to “Installing or Replacing a Rectifier” and “Removing a Rectifier” in this section.

### ***Vacant Rectifier Positions***

Vacant rectifier positions in a cabinet below the top installed rectifier may cause excessive temperature in the remaining rectifiers. If a rectifier below the top rectifier is removed, it must be replaced immediately or the vacated position must be occupied by a Rectifier Shelf Cover (848680211).

If a spare rectifier or Rectifier Shelf Cover is not available, a rectifier from the top position must be relocated to occupy the vacant position.

### ***Rectifier Fan Assembly***

The expected life of the rectifier fans at 25°C (77°F) is approximately seven years. The fans in the rectifiers may be replaced in the field.

Two approaches can be taken to fan maintenance:

- The first approach is to replace the fans on a routine basis every six to seven years; this ensures that the fans do not fail in the field under normal operating conditions. This approach is appropriate when there are no remote alarm facilities at the site.
- The second approach, assuming one has remote alarm capability, is to wait until the fans fail. The rectifier will safely shut down and issue both a fail alarm and a thermal alarm. The fans can then be replaced. Since it is likely that all the rectifiers in that installation are of roughly the same age, all rectifier fans at that site should be replaced at that time.


The approach used depends on the location and manning of the site as well as the monitoring of alarms used at the site.

Refer to “Replacing the Rectifier Fan Assemblies” in this section.

## Replacement Procedures


 **Installing or Replacing a Rectifier**

**Stop!**  **Be sure rectifier is set to STBY and ac breakers on cabinet are OFF!**

Installing or Replacing a Rectifier	
Step	Action
1	Unpack the rectifier from shipping container.  <b>Caution</b> <b>Rectifier is heavy (59 pounds). Use two people to lift and move rectifiers.</b>
2	Remove rectifier by lifting the unit in a vertical direction from the packing container. See figure below.  <b>Caution</b> <b>Do not rest rectifier on faceplate or rear chassis; damage to faceplate and/or rear busbars will occur, rendering the unit unusable.</b>
	
<i>Continued on next page.</i>	

## ***Replacement Procedures, continued***

<b>Installing or Replacing a Rectifier, continued</b>	
<b>Step</b>	<b>Action</b>
3	Turn ac circuit breaker OFF.
4	Place rectifier power switch in STBY.
5	Verify that rectifier matches the ac input voltage of the system.   <b>DO NOT INSTALL 595B RECTIFIERS INTO 380/400/480Vac systems; they will will be damaged.</b>
<i>Continued on next page.</i>	

<b>Installing or Replacing a Rectifier, continued</b>	
<b>Step</b>	<b>Action</b>
6	<p>Install the rectifier. See Figure 11-1.</p> <p>a.  Verify that the output circuit breaker is OFF and that the rectifier power switch is in the “Standby” position.</p> <p>b. Slide the unit slowly onto the shelf until it contacts the rear connector.</p> <p>Note: Install rectifiers, starting at the bottom position and working upward.</p> <p>c. Remove the label over the locking screw access window. Using a 5mm (3/16") Allen-head “T” wrench, turn the locking screw clockwise to secure the rectifier to the shelf.</p> <p style="text-align: center;"> <b>Caution</b></p> <p><b>Verify that the rectifier chassis slides rearward evenly on the left and right sides as the locking screw is turned. DO NOT USE EXCESSIVE FORCE DURING THIS PROCEDURE! If the rectifier-to-shelf mating process appears to bind, back the unit out and start over. Avoid stripping the threads of the locking screw by stopping when the rearward progress of the rectifier ceases.</b></p>
	
<p><b>Figure 11-1: Installing a Rectifier in a Rectifier Shelf</b></p>	
<p><i>Continued on next page.</i></p>	

## Replacement Procedures, continued

Installing or Replacing a Rectifier, continued	
Step	Action
7	Turn ON output circuit breaker.
8	Turn ON ac circuit breaker.
9	Turn rectifier power switch to ON position.
10	Verify: <ul style="list-style-type: none"> <li>• Green LED is illuminated.</li> <li>• No alarms are illuminated.</li> </ul>
11	<p>Set rectifier ID number (choose appropriate procedure):</p> <p><b>For 595A2, 595A3, 595B2, and 595B3:</b></p> <p>Note: If the rectifier ID goes above 24, then it is a 595A2/A3 or 595B2/B3 rectifier. Otherwise, it is a 595A or 595B.</p> <ol style="list-style-type: none"> <li>a. Depress rectifier power switch in UP position; rectifier ID is displayed.</li> <li>b. Hold rectifier power switch in UP position for 5 seconds; the display number will begin to blink.</li> <li>c. Release the switch.</li> <li>d. Depress and hold the switch for 3 seconds to rapidly advance the ID.</li> <li>e. Depress and release repeatedly until the desired ID is reached.</li> <li>f. Leave switch un-pressed for 10 seconds to save the ID number.</li> </ol> <p><b>For 595A and 595B rectifiers:</b></p> <ol style="list-style-type: none"> <li>a. Depress and hold rectifier power switch in UP position for 5 seconds; the displayed number will begin to blink.</li> <li>b. Depress and release switch until desired number is reached.</li> <li>c. When the desired number is reached, continue to hold switch until display stops blinking. The new ID number is now set. Note: Abandoning this process before the display stops blinking will default the rectifier to the last number set.</li> </ol>
12	Follow Steps 3-6 to install remaining rectifiers. Follow Steps 7-11 to set remaining ID numbers.
13	Verify that the system voltage reads 52.08V or desired float voltage.
14	Test replaced rectifiers using the “Testing Additional Alarms After Replacement of Rectifiers” procedure in this section.

## Replacement Procedures, continued

### Removing a Rectifier


<b>Removing a Rectifier</b>	
<b>Step</b>	<b>Action</b>
1	Set power switch to STBY.
2	Turn OFF ac circuit breakers.
3	Turn OFF output circuit breaker on rectifier.
4	 Wait 5 minutes to allow capacitors to discharge.
5	Using a 5mm Allen-head “T” wrench, slowly turn the locking screw counterclockwise to release the rectifier from the shelf.
6	<p>Slowly slide rectifier from shelf.</p> <p style="text-align: center;"> <b>Caution</b></p> <p><b>Rectifier is heavy (59 pounds). Use two people to lift and move rectifiers.</b></p> <p><b>Do not rest rectifier on faceplate or rear chassis; damage to faceplate and/or rear busbars will occur, rendering the unit unusable.</b></p>
7	<p>If the rectifier is not going to be replaced immediately, retire the active CMA (Communications Fail - Minor) against that rectifier ID by using the following path on the Configuration menu on the front display of the plant controller:</p> <p>Menu -&gt; CONFIG -&gt; RECT MNGR (Basic Controller)</p> <p>or</p> <p>Menu -&gt; CONFIG -&gt; RECT MNGR -&gt; RECT OPER (Intel Controller)</p> <p>Move to the Field RMOVE RECT and use the (+) key to input the Rectifier ID of the removed rectifier. Press Enter to clear the alarm.</p>
<i>Continued on next page.</i>	

## ***Replacement Procedures, continued***

<b>Removing a Rectifier, continued</b>	
<b>Step</b>	<b>Action</b>
8	<p>If the removed rectifier is below the top rectifier in its cabinet, it must be replaced immediately or the vacated position must be occupied by a Rectifier Shelf Cover 848680211.</p> <p>If a spare rectifier or Rectifier Shelf Cover is not available, a rectifier from the top position must be relocated to occupy the vacant position.</p> <p>Temporarily relocated rectifiers retain their rectifier ID and require no configuration changes for alarm free operation.</p> <p>Follow rectifier removal and installation procedures to relocate a rectifier.</p>

## Replacement Procedures, continued

**⚠ Replacing the Rectifier Fan Assemblies**

<b>Replacing the Rectifier Fan Assemblies</b>	
<b>Step</b>	<b>Action</b>
1	Follow instructions in the “Removing a Rectifier” procedure in this section. Refer to Figure 11-1.
2	Place rectifier on a flat surface at a comfortable working height.
3	<p>Loosen the front cover (white) by removing 6 screws (2 top, 4 bottom).</p> <p style="text-align: center;"><b>⚠ Caution</b></p> <p><b>Allow the front end of the rectifier to <i>overhang</i> the working surface. To remove bottom screws, turn the rectifier on its side, or work below the table surface.</b></p> <p><b><i>Never tilt the front of the unit to gain access to the bottom screws. This will result in damage to the rear connector.</i></b></p>
	
<p><b>Figure 11-2: Fan Replacement</b></p> <p style="text-align: right;"><i>Continued on next page.</i></p>	

## ***Replacement Procedures, continued***

<b>Replacing the Rectifier Fan Assemblies, continued</b>	
<b>Step</b>	<b>Action</b>
4	Remove the 4 fan screws attaching the fan to be replaced to the chassis, and carefully unplug the fan connector. The fan connector is keyed and can be loosened by inserting a screwdriver into the slotted side of the connector and gently prying the fan-side connector loose.
5	Place the new fan in position and torque screws to 10 in-lb.
6	Replace the front cover.
7	Install the rectifier following the “Installing or Replacing a Rectifier” procedure in this section.
8	Test replaced rectifiers using the “Testing Additional Alarms After Replacement of Rectifiers” procedure in this section.

## Testing

Note: Consult the GPS Installation Guide for complete testing guidelines for new installations.

### *Testing Additional Alarms After Replacing Rectifiers*

Alarm operation may be verified while the system operates at float voltage.

<b>Testing Additional Alarms After Replacing Rectifiers</b>	
<b>Step</b>	<b>Action</b>
1	Turn OFF the ac circuit breaker of replaced rectifier. Verify that the AC and MIN alarm LEDs illuminate, the rectifier displays ACF, and the controller alarms screen indicates RECTIFIER FAIL : Gmm.
2	Turn ON the ac circuit breaker of the replaced rectifier. Verify that the rectifier starts and the alarms retire.
3	OPTIONAL: Simulate a load circuit breaker alarm by shorting the alarm contacts on the circuit breakers or inserting an operated alarm fuse. For ED83143-31 G1, G2, or G5 add a jumper from the hot bus to the FAJ input signal on the associated BNL1 (P4-1) or BNL7 (P5-6) alarm card. Verify that the DIST and MAJ alarm LEDs illuminate and the controller alarms screen indicates EXTERNAL FUSE MAJOR.

### *Testing Rectifiers and Load Share in Bay Expansions*

<b>Testing Rectifiers and Load Share in Bay Expansions</b>	
<b>Step</b>	<b>Action</b>
1	Turn all rectifiers to STBY.
2	Connect a resistive load box (proper voltage) to the system's positive and negative bus bars.
3	Verify that the system load is less than 50 amperes.
4	Increase the system load to 200 amperes.
5	Turn ON all the rectifiers; after approximately 60 seconds, verify that the load is divided equally among all the rectifiers (within 2 amperes).
6	Reduce the system load. Verify that the rectifiers continue to share the load.
7	Remove system load.

## Replacement Parts

### System

Table 11-A provides a list of replacement parts for GPS 4848/100.

**Table 11-A: GPS 4848/100 Replacement Parts**

Ordering Comcode	Description
<b>Cabinet</b>	
406204230	3 ampere alarm fuse
402328926	.18 ampere alarm fuse
406530725	1-1/3 ampere alarm fuse
405673161	1/2 ampere panel alarm fuse (WP90247 L3)
406420273	GMT fuse puller tool
848262622	BLJ3 terminal board
408229318	Wire insertion tool
108588625	BIC8 bay interface card
107900169	EBV2 load disconnect board
107604076	BJN1 battery disconnect board
407226786	Lens cover, red
407227172	Cabinet alarm lamp, 48V
<b>Rectifier and Rectifier Shelf</b>	
108972238	595LTA, 220 ampere rectifier
108979246	595LTB, 220 ampere rectifier
848693586	Fan
901181834	Insulated Allen-head wrench
<b>Distribution</b>	
405673161	1/2 ampere alarm fuse
<b>Galaxy Millennium Controller</b>	
406677880	Battery TL5101 for BSJ
406530725	1-1/3 ampere fuse (GMT)
406204230	3 ampere fuse (GMT)

## Replacement Parts, continued

### Millennium Controller Circuit Boards

Table 11-B lists the spare parts of the Galaxy Millennium Controller.

**Table 11-B: Galaxy Millennium Controller Circuit Boards**

Ordering Comcode	Description
108029679	Display board (BSK1)
108029687	Alarm wire wrap board (BSL1)
848194551	Insulation displacement alarm board (BSL2)
108029653	Basic control board (BSH1)
847950912	LCD module assembly display board
108029661	Intelligent control board (BSJ1)
108851338	Modem board (BSM5)
108163601	Data switch board (BSW1)
108340100	Gateway board (EBW1)

## Additional Ordering Information

### Documentation

Table 11-C lists documentation associated with the GPS 4848/100.

**Table 11-C: Product Documentation**

Document Number	Description
H569-434	GPS 4848/100 Ordering Guide
167-792-157	GPS Installation Guide
167-792-180	Galaxy Millennium Controller Product Manual
167-790-063	Remote Peripheral Monitoring System Product Manual
193-104-105	EasyView Software Product Manual
193-104-106	Galaxy Gateway Product Manual

### Software

EasyView software is a Windows-compatible communications package designed specifically for use with Galaxy controllers. To download from our web site, go to <http://www.lineagepower.com>, click “Downloads” and click on the appropriate EasyView download button.



# **12                      *Troubleshooting Preparations***

## ***Preliminary***

### ***Introduction***

This section provides information needed in preparation for locating and interpreting visual indicators to help identify problems.

When replacing a part does not correct the problem or visual indicators do not identify a defective part, notify Lineage Power Technical Support.

### ***Safety***

Review all safety instructions and warnings in the Safety section of the GPS Installation Guide before troubleshooting the GPS 4848/100.

### **Warning**

Hazardous ac and dc voltages and/or energy are present. Caution should be exercised. Tools must be insulated to help prevent accidental contact with live surfaces.

Coordinate all troubleshooting activities with other personnel that may be working on the system.

### ***Tools***

The following tools are necessary in order to troubleshoot the GPS 4848/100:

- 3/16-inch (5 mm) Allen-head wrench
- Insulated hand tools
- Calibrated digital voltmeter (DVM)  
(0.05% accuracy on dc scale)
- ESD wrist strap

## ***Troubleshooting Procedure***


### ***Purpose***

The troubleshooting procedure described below is used when a trouble condition has been identified and a technician has been dispatched to the system location as a first and fundamental step in diagnosing and correcting the problem.

For all trouble conditions, proceed as follows:

### ***Cabinet Alarm***

1. Locate the system controller. The controller is typically located in the cabinet identified as BAY ONE. Because a trouble condition exists, the red alarm on the top of the cabinet will be illuminated. See Figure 12-1.).



***Figure 12-1: Location of Cabinet Alarm Light and Controller***

## ***Troubleshooting Procedure, continued***

### ***System Status***

2. Determine the system status. For most problems, one or more alarm and status LEDs will be illuminated. The controller default screen indicates system voltage and current, the system mode (i.e., FLOAT or EQUALIZE), and the number of alarms and/or warnings present.

If the screen is blank, but alarm and status LEDs are illuminated, call technical support.

If the entire panel is blank, check the F3 basic power fuse (Figure 12-3). Verify that the controller is getting power. If not, replace fuse. If the display is still blank, call technical support.

### ***Alarms Menu***

3. If the default screen appears normal, press the MENU button. The main menu appears with “Alarms” blinking. Press ENTER to obtain the Alarms menu. Additional data appears that will help to identify the problem.

### ***Troubleshooting Tables***

4. Based on the information presented by the alarm LEDs, select the appropriate table from the list below:

<b>Section 13, Troubleshooting Millennium Systems</b>	
<b>Alarm LED</b>	<b>Table</b>
AC	13-A, AC Alarms
BATT	13-B, Battery Alarms
BD	13-F, Miscellaneous Alarms
CTRL	13-C, Controller Alarms
DIST	13-D, Distribution Alarms
RECT	13-E, Rectifier Related Alarms
No LED*	13-F, Miscellaneous Alarms
*If an alarm condition exists, but no alarm LED is lit, refer to Table 13-F.	

### ***Identifying Problems***

5. Once the appropriate table is identified, use the status LEDs and the alarm menu data to identify the specific problem that is causing the alarm.

## Reference Figures

### Figure Numbers and Titles

The following figures are provided for reference while performing the troubleshooting procedure:

Figure No.	Title
12-1	Location of Cabinet Alarm Light and Controller
12-2	Millennium Controller Display
12-3	Millennium Controller Fuses and Circuit Boards
12-4	Rectifier Display
12-5	Low Voltage Battery Disconnect Contactor Control Switches
12-6	AC Input Panel and Rectifier Connection
12-7	DC Distribution Panel
12-8	Low Voltage Load Disconnect Contactor Control Switches

### Millennium Controller

#### Basic Controller

**BSH (microprocessor board):** After power up, or after a reset, the green and yellow LEDs will both be lit while self diagnostics are in progress (which will take about 10 seconds). If all diagnostics pass, the yellow LED will extinguish and the green LED will remain lit. If a failure is detected during diagnostics, the green LED will extinguish and the yellow LED will remain lit.

If a failure occurs during normal operation, the green LED will extinguish and the yellow LED will light.

#### Intelligent Controller

**BSJ (microprocessor board):** After power up, or after a reset, the green and yellow LEDs will both be lit while self diagnostics are in progress (which will take about 30 seconds). If all diagnostics pass, the yellow LED will extinguish and the green LED will remain lit. If a failure is detected during diagnostics, the green LED will extinguish and the yellow LED will remain lit. If a terminal is attached to the local port during diagnostics, the diagnostic messages will show which test failed.

If a failure occurs during normal operation, the green LED will extinguish and the yellow LED will light.

## Reference Figures, continued

### Millennium Controller, continued




Figure 12-2: Millennium Controller Display




Figure 12-3: Millennium Controller Fuses and Circuit Boards

## Reference Figures, continued

### Rectifier

During normal operation, the rectifier's green ON LED will be lit and the display will show the rectifier's output current.





Figure 12-4: Rectifier Display

## Reference Figures, continued

### Low Voltage Battery Disconnect


The low voltage battery disconnect (LVBD) feature consists of a contactor, circuitry on the BJD board, and associated wiring. Control of the contactor is dictated by the BJD contactor control board and the controller.



**Figure 12-5: Low Voltage Battery Disconnect Contactor Control Switches**

## Reference Figures, continued


### AC Input



**Figure 12-6: AC Input Panel and Rectifier Connection**

## Reference Figures, continued

### DC Distribution




**Figure 12-7: DC Distribution Panel**

## Reference Figures, continued

### Low Voltage Load Disconnect

The EBV low voltage load disconnect (LVLD) contactor control board is mounted on the right side of the cabinet, as shown in Figure 12-8.

The manual contactor control switch (SW300) is not meant to be used to permanently override the LVLD function. It is only to be used temporarily while servicing or testing the equipment.



**Figure 12-8: Low Voltage Load Disconnect Contactor Control Switches**

# **13**                      ***Troubleshooting Millennium Systems***

## ***Introduction***

***In This Section***                      This section provides information for locating and interpreting visual indicators to help identify problems.

***Preparation***                              Read Section 12, *Troubleshooting Preparations*, thoroughly before proceeding.

***Technical Assistance***                      When visual indicators do not identify a defective part, notify Lineage Power Technical Support.

## Troubleshooting Tables

**Organization** The tables in this section are organized alphabetically by Alarm LED, then grouped according to the status of the alarm: Critical (CRIT), Major (MAJ), or Minor (MIN).

**Table Reference** Use the reference below to locate the Alarm LED and corresponding table.

Controller Alarm LED	Table
AC	13-A, AC Alarms
BATT	13-B, Battery Alarms
BD	13-F, Miscellaneous Alarms
CTRL	13-C, Controller Alarms
DIST	13-D, Distribution Alarms
RECT	13-E, Rectifier Related Alarms
RM	13-F, Miscellaneous Alarms
No LED*	13-F, Miscellaneous Alarms


\*If an alarm condition exists, but no alarm LED is lit, refer to Table 13-F.

### Rectifier Display Messages and LEDs

State	Display Message	LED Illuminated
Normal	Current	ON
Output Limited	Current	LIM
Manual Standby	Blank	STBY
Remote Standby (Shutdown)	tr	STBY
Output Breaker Open	CB	ALM
Interlock Open	ILC	ALM
AC Fail	ACF	None
Phase Fail	PF	None
Over Temperature Shutdown	tA	ALM
Output Under Voltage Shutdown	LO	ALM
High Voltage Shutdown	HO	ALM
Internal Failure	LS, CS, IP5, IP6, IP7, SEN, FSE, InF	ALM

**Millennium  
Controller Display**

The Millennium display is illustrated below.



**AC Alarm LED**

**Table 13-A: AC Alarms**  
(See Figure 12-6)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
AC	MIN	AC Fail	ACF on rectifier display	Rectifier is not receiving ac power: <ul style="list-style-type: none"> <li>•AC input circuit breaker has operated.</li> <li>•AC input voltage is out of range.</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that ac circuit breaker is closed; close circuit breaker if operated.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>
AC	MIN	Engine Transfer Timeout	Engine may have alarm.	Remote engine or connection to engine has failed.	Call technical support.
AC	MIN	Phase Alarm	PF on rectifier display	Phase failure: <ul style="list-style-type: none"> <li>•Rectifier high voltage shutdown</li> <li>•External phase imbalance or failure</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>

**BATT Alarm LED**

**Table 13-B: Battery Alarms**  
(See Figure 12-5)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
BATT	CRIT	Very Low Voltage	--	Occurs in an operating system following an extended commercial ac power outage, during which the batteries are providing power for the system and the system voltage is approaching the user-defined low limit.	<ol style="list-style-type: none"> <li>1. If commercial ac power is present but the system voltage remains low, call technical support.</li> <li>2. Investigate other alarms that may be present (rectifier-related alarms and the AC Fail alarm may also occur during the fault condition).</li> </ol>
BATT* *Alarm must be configured to turn on the BATT LED; not a factory default.	MAJ	Contactors 1 Open	Red LED on contactor drive board is lit.	Contactor is open: <ul style="list-style-type: none"> <li>•Open has been initiated by controller.</li> <li>•Open has been initiated manually.</li> </ul>	<ol style="list-style-type: none"> <li>1. Follow instructions on the label adjacent to the contactor drive board (see Figure 12-5).</li> <li>2. If the problem is not corrected, call technical support.</li> </ol>
BATT* *Alarm must be configured to turn on the BATT LED; not a factory default.	MAJ	Contactors 1 Fail	--	Contactors or drive board has failed.	Call technical support.
BATT	MIN	Open String	Alarm LED on battery fuse panel is lit.	Battery fuse has operated.	Replace the operated fuse.
BATT	MIN	Low Reserve Time	--	Controller has calculated that batteries are low.	Call technical support.

**CTRL Alarm LED**

**Table 13-C: Controller Alarms**  
(See Figures 12-2 and 12-3)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
CTRL	MAJ	Controller Fail	--	<ul style="list-style-type: none"> <li>•<b>BSH failure</b>→</li> <li>•BSJ failure</li> <li>•Option board failure</li> <li>•Display failure</li> <li>•BIC failure</li> </ul>	<p>Check the BSH board to see if the green LED is extinguished and the yellow LED is lit. If so, perform the following steps:</p> <ol style="list-style-type: none"> <li>1. Press the SW200 reset switch on the top of the BSH board. If all diagnostics pass, it is possible that some type of “one time” abnormality occurred to cause the failure.</li> <li>2. If the diagnostics did not pass, or if the problem recurs, unplug all the optional circuit board cables, then press the reset switch on the top of the BSH board again. If all the diagnostics pass, install optional circuit board cables one at a time, verifying operation after each.</li> <li>3. If the diagnostics did not pass, replace the BSH board and verify the failure is resolved. If so, reinstall the optional circuit boards and cables one at a time.</li> <li>4. If the problem is not corrected, call technical support.</li> </ol>

**Table 13-C: Controller Alarms (Continued)**  
 (See Figures 12-2 and 12-3)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
CTRL	MAJ	Controller Fail	--	<ul style="list-style-type: none"> <li>•BSH failure</li> <li>•BSJ failure→</li> <li>•Option board failure</li> <li>•Display failure</li> <li>•BIC failure</li> </ul>	<p>Check the BSJ board to see if the green LED is extinguished and the yellow LED is lit. If so, perform the following steps:</p> <ol style="list-style-type: none"> <li>1. Press the SW201 reset switch on the top of the BSJ board. (This circuit has an automatic restart, which will try three times to restart the microprocessor.)</li> <li>2. If the diagnostics did not pass, or if the problem recurs, remove all the optional circuit board cables, then press the reset switch on the top of the BSJ board again. If all the diagnostics pass, install optional circuit board cables one at a time, verifying operation after each.</li> <li>3. If the diagnostics did not pass, replace the BSJ board and verify the failure is resolved. If so, reinstall the optional circuit boards and cables one at a time.</li> <li>4. If the problem is not corrected, call technical support.</li> </ol>

**Table 13-C: Controller Alarms (Continued)**  
(See Figures 12-2 and 12-3)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
CTRL	MAJ	Controller Fail	--	<ul style="list-style-type: none"> <li>•BSH failure</li> <li>•BSJ failure</li> <li>•<b>Option board failure</b>→</li> <li>•Display failure</li> <li>•BIC failure</li> </ul>	<p>Check the option boards (modem and data switch) to see if the green LED is extinguished and the yellow LED is lit. If so, perform the following steps:</p> <ol style="list-style-type: none"> <li>1. Press the SW201 reset switch on the top of the BSJ board. (This circuit has an automatic restart, which will try three times to restart the microprocessor.) If the BSJ is not present, press the reset switch on the top of the BSH board.</li> <li>2. If the diagnostics did not pass, or if the problem recurs, replace the failed option board.</li> </ol>
CTRL	MAJ	Controller Fail	--	<ul style="list-style-type: none"> <li>•BSH failure</li> <li>•BSJ failure</li> <li>•Option board failure</li> <li>•<b>Display failure</b>→</li> <li>•BIC failure</li> </ul>	<p>If the front panel LCD module, LEDs, or switches fail, perform the following steps:</p> <ol style="list-style-type: none"> <li>1. Verify that the ribbon cable from the BSH board to the display is not cut, abraded, or otherwise mangled. Replace the cable if damaged.</li> <li>2. Press SW200 to reset the BSH board.</li> <li>3. If the LCD module is still not operating, replace the LCD module; if the switches and LEDs are still not operating, replace the BSH board.</li> </ol>

**Table 13-C: Controller Alarms (Continued)**  
(See Figures 12-2 and 12-3)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
CTRL	MAJ	Controller Fail	--	<ul style="list-style-type: none"> <li>•BSH failure</li> <li>•BSJ failure</li> <li>•Option board failure</li> <li>•Display failure</li> <li>•BIC failure→</li> </ul>	<ol style="list-style-type: none"> <li>1. Strap K1, K2, K3 on BLJ from “C” to “R” prior to replacing BIC. See Figure 8-2.</li> <li>2. Replace BIC.</li> </ol>
CTRL	MAJ	Circuit Pack Fail	--	See “Controller Fail”.	See “Controller Fail”.
CTRL	MAJ	Controller Fuse	--	Fuse has operated.	Replace the controller fuse labeled F2 (intelligent power).
CTRL	MAJ	Alarm Battery Supply Fuse	--	Fuse has operated.	Replace the controller fuse labeled F5 (alarm battery supply).
CTRL	MAJ	Remote Peripheral Fuse	--	Fuse has operated.	Replace the controller fuse labeled F1 (option power).
CTRL	MAJ	Sense/Control Fuse	--	Fuse has operated.	Replace the controller fuse labeled F4 (voltage sense).
CTRL	MAJ	Bay Interface ID Conflict	--	Two or more bay interface cards (BICs) have the same ID number.	Following instructions printed on the label over the BIC, adjust the DIP switches to change the ID number.
CTRL	MAJ	Major Communication Fail Alarm	Blinking ALM LED on rectifiers or red LED on BIC	Loss of communication with controller: <ul style="list-style-type: none"> <li>•Defective interface from BIC or multiple rectifiers to controller</li> <li>•Internal failure of controller, BIC, or multiple rectifiers</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that the controller is powered and operating correctly.</li> <li>2. If there are no controller alarms, replace the equipment that has lost communication.</li> <li>3. If the problem is not corrected, call technical support.</li> </ol>

**Table 13-C: Controller Alarms (Continued)**  
(See Figures 12-2 and 12-3)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
CTRL	MIN	Minor Communication Fail Alarm	Blinking ALM LED on rectifier	Loss of communication with controller: <ul style="list-style-type: none"> <li>•Defective interface from rectifier to controller</li> <li>•Internal controller or rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that the controller is powered and operating correctly.</li> <li>2. If there are no controller alarms, replace the equipment that has lost communication.</li> <li>3. If the problem is not corrected, call technical support.</li> </ol>
CTRL	MIN	Self Fail Test	--	See "Controller Fail".	See "Controller Fail".
CTRL	MIN	Thermal Probe Failure	--	Battery thermal probe has failed.	Call technical support.

***DIST Alarm LED***

**Table 13-D: Distribution Alarms**  
(See Figures 12-7 and 12-8)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
DIST	MAJ	External Fuse Major	Alarm LED on dc distribution panel is lit.	DC load fuse or circuit breaker has operated.	Replace fuse or reset circuit breaker.
DIST* *Alarm must be configured to turn on the DIST LED; not a factory default.	MAJ	Contactors 2 (or 3) Open	Red LED on contactor drive board is lit.	Contactors are open: <ul style="list-style-type: none"> <li>•Open has been initiated by controller.</li> <li>•Open has been initiated manually.</li> </ul>	<ol style="list-style-type: none"> <li>1. Follow instructions on the label adjacent to the contactor drive board (see Figure 12-8).</li> <li>2. If the problem is not corrected, call technical support.</li> </ol>
DIST* *Alarm must be configured to turn on the DIST LED; not a factory default.	MAJ	Contactors 2 (or 3) Fail	--	Contactors or drive board has failed.	Call technical support.

**RECT Alarm LED****Table 13-E: Rectifier Related Alarms**

(See Figures 12-4 and 12-6)

Controller LED	Controller Alarm Status	Millennium Controller Display	Rectifier LED	Rectifier Display	Possible Problem(s)	Possible Solution(s)
RECT	MAJ	ID Not Configured	None	None	Rectifier ID number has not been set.	Set rectifier ID using procedure in Section 11, "Installing or Replacing a Rectifier."
RECT	MAJ	ID Conflict	None	None	Two or more rectifiers have the same ID number.	See above.
RECT	MAJ	Multiple Rectifier Fail	ALM	None	More than one rectifier has an ALM LED lit.	See alarms listed below.
RECT	MAJ	High Voltage Alarm	ALM	HO	<ul style="list-style-type: none"> <li>•Lightning has struck system.</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	Rectifier Fail	ALM	HO	<p>High output voltage:</p> <ul style="list-style-type: none"> <li>•Rectifier high voltage shutdown</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify the configurable HV thresholds in the controller.</li> <li>2. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>3. If the problem is not corrected, replace the rectifier.</li> </ol>

**Table 13-E: Rectifier Related Alarms (Continued)**  
(See Figures 12-4 and 12-6)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Rectifier LED</b>	<b>Rectifier Display</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
RECT	MIN	Rectifier Fail	ALM	TA	Thermal alarm: •Excessive ambient temperature •Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Verify that there is no obstruction of the fan inlet.</li> <li>2. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>3. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	Rectifier Fail	ALM	CB	Circuit breaker alarm: •DC output circuit breaker open •Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position; toggle the DC output circuit breaker into the OFF position and then into the ON position. Return the ON/STBY switch to the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>

**Table 13-E: Rectifier Related Alarms (Continued)**  
 (See Figures 12-4 and 12-6)

Controller LED	Controller Alarm Status	Millennium Controller Display	Rectifier LED	Rectifier Display	Possible Problem(s)	Possible Solution(s)
RECT	MIN	Rectifier Fail	ALM	ICS IP5 IP6 IP7 InF FSE LS	Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Place the ac circuit breaker for the rectifier in the OFF position.</li> <li>2. Remove the rectifier from the shelf.</li> <li>3. Wait for 30 seconds or until all front panel display LEDs have extinguished.</li> <li>4. Replace the rectifier.</li> <li>5. Return the ac breaker to the ON position.</li> <li>6. Place the rectifier ON/STBY switch into the ON position.</li> <li>7. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	Rectifier Fail	ALM	LO	Low output voltage: <ul style="list-style-type: none"> <li>•Excessive output current</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>

**Table 13-E: Rectifier Related Alarms (Continued)**  
(See Figures 12-4 and 12-6)

Controller LED	Controller Alarm Status	Millennium Controller Display	Rectifier LED	Rectifier Display	Possible Problem(s)	Possible Solution(s)
RECT	MIN	Rectifier Fail	ALM	SEN	Thermal sensor failure: •Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Place the ac circuit breaker for the rectifier in the OFF position.</li> <li>2. Remove the rectifier from the shelf.</li> <li>3. Wait for 30 seconds or until all front panel display LEDs have extinguished.</li> <li>4. Replace the rectifier.</li> <li>5. Return the ac breaker to the ON position.</li> <li>6. Place the rectifier ON/STBY switch into the ON position.</li> <li>7. If the problem is not corrected, replace the rectifier with a new one.</li> </ol>
RECT	MIN	Rectifier Fail	FAN ALM	None	Fan failure	Replace the fan in the rectifier.
RECT	MIN	Manual Off	STBY	Blank	Rectifier has been manually turned off.	Turn rectifier on.
RECT	MIN	External Transfer Shutdown	STBY	TR	System is operating on external engine.	No action required.
RECT	MIN	High Float Voltage	None	None	Configuration problem	Call technical support.
RECT	MIN	Excess Rectifier Drain	None	None	Internal rectifier fault	Replace rectifier.

**Table 13-E: Rectifier Related Alarms (Continued)**  
 (See Figures 12-4 and 12-6)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Rectifier LED</b>	<b>Rectifier Display</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
RECT	MIN	Excess System Drain	None	None	System load exceeds shunt rating.	Call technical support.
RECT	MIN	Limited Recharge	None	None	Rectifier capacity has been exceeded.	Install more rectifiers.
RECT	MIN	Rectifier Fail	ALM	ILC	Rectifier not fully seated.	<ol style="list-style-type: none"> <li>1. Place the ac circuit breaker for the rectifier in the OFF position.</li> <li>2. Remove the rectifier from the shelf.</li> <li>3. Wait for 30 seconds or until all front panel display LEDs have extinguished.</li> <li>4. Replace the rectifier.</li> <li>5. Return the ac breaker to the ON position.</li> <li>6. Place the rectifier ON/STBY switch into the ON position.</li> <li>7. If the problem is not corrected, replace the rectifier with a new one.</li> </ol>

**BD and RM Alarm LEDs, or No LED****Table 13-F: Miscellaneous Alarms**

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
BD	MAJ	Battery on Discharge	Rectifiers may say ACF.	Temporary condition that may be associated with other alarms	Call technical support.
RM	MIN	Module Failure	Green LED on RPM will not blink.	Remote Peripheral Module has failed.	Call technical support.
RM	MIN	Measurement Out of Range	--	<ul style="list-style-type: none"> <li>•Data being sensed exceeds remote peripheral module's capability.</li> <li>•Remote peripheral module has failed.</li> </ul>	Call technical support.
None	MAJ	Auxiliary Major	Auxiliary equipment may have alarm.	Problem with operation of auxiliary equipment	Call technical support.
None	MIN	Auxiliary Minor	Auxiliary equipment may have alarm.	Problem with operation of auxiliary equipment	Call technical support.
None	None	None	<ul style="list-style-type: none"> <li>•STBY LED on rectifier is lit.</li> <li>•TR on rectifier display</li> </ul>	Remote transfer: <ul style="list-style-type: none"> <li>•Rectifier is in STBY.</li> </ul>	Remove the remote standby command issued by the controller.
None	None	None	Red LED is lit on some battery contactor drive boards, while green LED is lit on others.	If a green LED is lit despite a contactor open command issued by the controller, the drive card or the contactor has failed.	Call technical support.



# 14

## Product Warranty

- A. Seller warrants to Customer only, that:
1. As of the date title to Products passes, Seller will have the right to sell, transfer, and assign such Products and the title conveyed by Seller shall be good;
  2. During the warranty period stated in Sub-Article B below, Seller's Manufactured Products (products manufactured by Seller), which have been paid for by Customer, will conform to industry standards and Seller's specifications and shall be free from material defects;
  3. With respect to Vendor items (items not manufactured by Seller), Seller warrants that such Vendor items, which have been paid for by Customer, will be free from material defects for a period of sixty (60) days commencing from the date of shipment from Seller's facility.
- B. The Warranty Period listed below is applicable to Seller's Manufactured Products furnished pursuant to this Agreement, commencing from date of shipment from Seller's facility, unless otherwise agreed to in writing:

**Warranty Period**

<b>Product Type</b>	<b>New Product</b>	<b>Repaired Product*</b>
Central Office Power Equipment	24 Months	6 Months

*\*The Warranty Period for a repaired Product or part thereof is six (6) months or, the remainder of the unexpired term of the new Product Warranty Period, whichever is longer.*

- C. If, under normal and proper use during the applicable Warranty Period, a defect or nonconformity is identified in a Product and Customer notifies Seller in writing of such defect or nonconformity promptly after Customer discovers such defect or nonconformity, and follows Seller's instructions regarding return of defective or nonconforming Products, Seller shall, at its option attempt first to repair or replace such Product without charge at its facility or, if not feasible, provide a refund or credit based on the original purchase price and installation charges if installed by Seller. Where Seller has elected to repair a Seller's Manufactured Product (other than Cable and Wire Products) which has been installed by Seller and Seller ascertains that the Product is not readily returnable for repair, Seller will repair the Product at Customer's site.

With respect to Cable and Wire Products manufactured by Seller which Seller elects to repair but which are not readily returnable for repair, whether or not installed by Seller, Seller at its option, may repair the cable and Wire Products at Customer's site.

- D. If Seller has elected to repair or replace a defective Product, Customer shall have the option of removing and reinstalling or having Seller remove and reinstall the defective or nonconforming Product. The cost of the removal and the reinstallation shall be borne by Customer. With respect to Cable and Wire Products, Customer has the further responsibility, at its expense, to make the Cable and Wire Products accessible for repair or replacement and to restore the site. Products returned for repair or replacement will be accepted by Seller only in accordance with its instructions and procedures for such returns. The transportation expense associated with returning such Product to Seller shall be borne by Customer. Seller shall pay the cost of transportation of the repaired or replacing Product to the destination designated by Customer.
- E. Except for batteries, the defective or nonconforming Products or parts which are replaced shall become Seller's property. Customer shall be solely responsible for the disposition of any batteries.
- F. If Seller determines that a Product for which warranty service is claimed is not defective or nonconforming, Customer shall pay Seller all costs of handling, inspecting, testing, and transportation and, if applicable, traveling and related expenses.
- G. Seller makes no warranty with respect to defective conditions or nonconformities resulting from actions of anyone other than Seller or its subcontractors, caused by any of the following: modifications, misuse, neglect, accident, or abuse; improper wiring, repairing, splicing, alteration, installation, storage, or maintenance; use in a manner not in accordance with Seller's or Vendor's specifications or operating instructions, or failure of Customer to apply previously applicable Seller modifications and corrections. In addition, Seller makes no warranty with respect to Products which have had their serial numbers or month and year of manufacture removed, altered, or experimental products or prototypes or with respect to expendable items, including, without limitation, fuses, light bulbs, motor brushes, and the like. Seller's warranty does not extend to any system into which the Product is incorporated. This warranty applies to Customer only and may not be assigned or extended by Customer to any of its customers or other users of the Product.

THE FOREGOING WARRANTIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. CUSTOMER'S SOLE AND EXCLUSIVE REMEDY SHALL BE SELLER'S OBLIGATION TO REPAIR, REPLACE, CREDIT, OR REFUND AS SET FORTH ABOVE IN THIS WARRANTY.