

**Lucent Technologies**  
Bell Labs Innovations



***Galaxy Power System 4812***  
***(GPS 4812)***  
***H569-436***

User's Guide  
Select Code 167-792-161  
Comcode 108313057  
Issue 5  
June 2000  
© 2000 Lucent Technologies



*User's Guide*  
*Select Code 167-792-161*  
*Comcode 108313057*  
*Issue 5*  
*June 2000*

*Lucent Technologies*  
*Galaxy Power System 4812*  
*(GPS 4812)*  
*H569-436*

**Notice:**

Every effort was made to ensure that the information in this document was complete and accurate at the time of printing. However, information is subject to change.



# ***Table of Contents***

## ***1 Introduction***

<i>GPS 4812</i>	<i>1 - 1</i>
<i>Overview</i>	<i>1 - 1</i>
<i>Illustrations</i>	<i>1 - 1</i>
<i>Customer Assistance Contacts</i>	<i>1 - 4</i>
<i>Customer Training</i>	<i>1 - 4</i>
<i>Customer Service</i>	<i>1 - 4</i>
<i>Technical Support</i>	<i>1 - 4</i>
<i>Product Repair and Return</i>	<i>1 - 4</i>
<i>Warranty Service</i>	<i>1 - 5</i>
<i>On-Line Power Systems Product Manuals</i>	<i>1 - 5</i>
<i>On-Line Power Systems Software Upgrades</i>	<i>1 - 5</i>

## ***2 System Description***

<i>Overview</i>	<i>2 - 1</i>
<i>Block Diagram</i>	<i>2 - 1</i>
<i>System Components</i>	<i>2 - 2</i>
<i>Architecture</i>	<i>2 - 3</i>
<i>Configurations</i>	<i>2 - 3</i>
<i>Illustrations</i>	<i>2 - 3</i>

## ***3 Galaxy Controllers***

<i>Overview</i>	<i>3 - 1</i>
<i>Introduction</i>	<i>3 - 1</i>
<i>Galaxy Millennium Controller</i>	<i>3 - 2</i>
<i>Design</i>	<i>3 - 2</i>
<i>User Interface and Display</i>	<i>3 - 2</i>
<i>Default Display</i>	<i>3 - 2</i>
<i>LEDs</i>	<i>3 - 3</i>
<i>Test Jacks</i>	<i>3 - 3</i>
<i>Pushbutton Keys</i>	<i>3 - 4</i>
<i>Galaxy Vector Controller</i>	<i>3 - 5</i>
<i>Design</i>	<i>3 - 5</i>
<i>User Interface and Display</i>	<i>3 - 5</i>
<i>Default Display</i>	<i>3 - 5</i>
<i>LEDs</i>	<i>3 - 6</i>
<i>Test Jacks</i>	<i>3 - 6</i>
<i>Pushbutton Keys</i>	<i>3 - 7</i>

<i>Reference Material</i>	3 - 8
<i>Controller Product Manuals</i>	3 - 8
<i>RPM System Product Manual</i>	3 - 8
<b>4 Rectifiers</b>	
596A	4 - 1
<i>Overview</i>	4 - 1
<i>Front Panel Display</i>	4 - 2
<i>Power Switch</i>	4 - 2
<i>Status Indicators</i>	4 - 2
<i>Current Display</i>	4 - 2
<i>Lamp Test</i>	4 - 2
<i>Illustration</i>	4 - 3
<i>Features</i>	4 - 4
<i>Output Current “Walk-in”</i>	4 - 4
<i>Output Protection</i>	4 - 4
<i>Electronic Current Limit</i>	4 - 4
<i>High Voltage Shutdown (HVSD)</i>	4 - 4
<i>Restart</i>	4 - 4
<i>Fan Alarm and Control</i>	4 - 4
<i>Thermal Alarm</i>	4 - 4
<i>Autonomous Operation</i>	4 - 4
<i>Controller Communications Alarm</i>	4 - 4
<i>Connectorized</i>	4 - 5
<i>“Forced” Load Sharing</i>	4 - 5
<b>5 AC Input Panels</b>	
<i>Overview</i>	5 - 1
<i>AC Service</i>	5 - 1
<i>Cross Reference of Cabinets and Panels</i>	5 - 2
<i>Illustrations</i>	5 - 2
<b>6 Battery Connection Panels</b>	
<i>Overview</i>	6 - 1
<i>Function</i>	6 - 1
<i>Illustrations</i>	6 - 1
<b>7 DC Distribution Panels</b>	
<i>Overview</i>	7 - 1
<i>Function</i>	7 - 1
<i>Illustrations</i>	7 - 1

## **8 Circuit Boards**

<i>Overview</i>	8 - 1
<i>Function</i>	8 - 1
<i>Terminal Boards</i>	8 - 1
<i>Alarm Boards</i>	8 - 1
<i>Alarm/Terminal Boards</i>	8 - 1
<i>BLJ Terminal Board</i>	8 - 2
<i>Millennium Systems</i>	8 - 2
<i>Vector Systems</i>	8 - 2
<i>Bay Interface Card</i>	8 - 2
<i>Millennium Systems</i>	8 - 2
<i>Vector Systems</i>	8 - 2
<i>Illustrations</i>	8 - 3
<i>BLJ and BIC Locations</i>	8 - 3
<i>Replacing a BIC</i>	8 - 3

## **9 Specifications**

<i>GPS 4812</i>	9 - 1
<i>Rectifier</i>	9 - 3
<i>AC Input Panels</i>	9 - 5
<i>Battery Connection Panels</i>	9 - 6
<i>DC Distribution Panels</i>	9 - 7

## **10 Safety**

<i>Safety Statements</i>	10 - 1
<i>Warning Statements and Safety Symbols</i>	10 - 2
<i>Precautions</i>	10 - 4

## **11 Maintenance and Replacement**

<i>Requirements</i>	11 - 1
<i>System</i>	11 - 1
<i>Batteries</i>	11 - 1
<i>Rectifiers</i>	11 - 1
<i>Rectifier Fan Assembly</i>	11 - 2
<i>Replacement Procedures</i>	11 - 3
<i>Installing or Replacing a Rectifier</i>	11 - 3
<i>Replacing a Rectifier Fan Assembly</i>	11 - 5
<i>Replacement Parts</i>	11 - 6
<i>System</i>	11 - 6
<i>Millennium Controller Circuit Boards</i>	11 - 7
<i>Vector Controller Circuit Boards</i>	11 - 7
<i>Documentation</i>	11 - 8
<i>Software</i>	11 - 8

## **12 Troubleshooting Preparations**

<i>Preliminary</i>	12 - 1
<i>Introduction</i>	12 - 1
<i>Safety</i>	12 - 1
<i>Tools</i>	12 - 1
<i>Troubleshooting Procedure</i>	12 - 2
<i>Purpose</i>	12 - 2
<i>Cabinet Alarm</i>	12 - 2
<i>System Status</i>	12 - 3
<i>Alarms Menu</i>	12 - 3
<i>Troubleshooting Tables</i>	12 - 4
<i>Identifying Problems</i>	12 - 4
<i>Reference Figures</i>	12 - 5
<i>Figure Numbers and Titles</i>	12 - 5
<i>Millennium Controller</i>	12 - 6
<i>Vector Controller</i>	12 - 8
<i>Rectifiers</i>	12 - 9
<i>Low Voltage Battery Disconnect</i>	12 - 10
<i>AC Input</i>	12 - 11
<i>DC Distribution</i>	12 - 12
<i>Low Voltage Load Disconnect</i>	12 - 13

## **13 Troubleshooting Millennium Systems**

<i>Introduction</i>	13 - 1
<i>In This Section</i>	13 - 1
<i>Preparation</i>	13 - 1
<i>Technical Assistance</i>	13 - 1
<i>Troubleshooting Tables</i>	13 - 2
<i>Organization</i>	13 - 2
<i>Table Reference</i>	13 - 2
<i>Millennium Display Reference</i>	13 - 2
<i>AC Alarm LED</i>	13 - 3
<i>BATT Alarm LED</i>	13 - 4
<i>CTRL Alarm LED</i>	13 - 6
<i>DIST Alarm LED</i>	13 - 11
<i>RECT Alarm LED</i>	13 - 12
<i>BD and RM Alarm LEDs, or No LED</i>	13 - 17

## **14 Troubleshooting Vector Systems**

<i>Introduction</i>	14 - 1
<i>In This Section</i>	14 - 1
<i>Preparation</i>	14 - 1
<i>Technical Assistance</i>	14 - 1
<i>Troubleshooting Tables</i>	14 - 2

<i>Organization</i>	14 - 2
<i>Table Reference</i>	14 - 2
<i>Vector Display Reference</i>	14 - 2
<i>AC Alarm LED</i>	14 - 3
<i>BATT Alarm LED</i>	14 - 4
<i>CTRL Alarm LED</i>	14 - 5
<i>DIST Alarm LED</i>	14 - 6
<i>RECT Alarm LED</i>	14 - 7
<i>BD Alarm LED or No LED</i>	14 - 12

## **15 Product Warranty**



## *List of Figures*

<i>Figure 1-1: GPS 4812 Half Height Cabinet (with Battery Stand)</i>	<i>1 - 2</i>
<i>Figure 1-2: GPS 4812 Full Height Cabinet</i>	<i>1 - 3</i>
<i>Figure 2-1: Block Diagram of the GPS 4812</i>	<i>2 - 1</i>
<i>Figure 2-2: Schematic of Half Height Cabinet</i>	<i>2 - 4</i>
<i>Figure 2-3: Schematic of Full Height Cabinet</i>	<i>2 - 5</i>
<i>Figure 2-4: Schematic of Two-cabinet System Architecture</i>	<i>2 - 6</i>
<i>Figure 2-5: Half Height GPS 4812 with Door Open</i>	<i>2 - 7</i>
<i>Figure 2-6: Full Height GPS 4812 with Door Open</i>	<i>2 - 8</i>
<i>Figure 3-1: Galaxy Millennium Controller Front Panel</i>	<i>3 - 2</i>
<i>Figure 3-2: Galaxy Vector Controller Front Panel</i>	<i>3 - 5</i>
<i>Figure 4-1: Rectifier Front Panel</i>	<i>4 - 3</i>
<i>Figure 5-1: H569-436 G73F/71H (ED83142-30 G6) H569-436 G74F/74H (ED83142-30 G6M) AC Input Circuit Breaker Panel</i>	<i>5 - 3</i>
<i>Figure 5-2: H569-436 G72F (ED83142-30 G7) AC Input Circuit Breaker Panel</i>	<i>5 - 3</i>
<i>Figure 5-3: H569-436 G79F/76H (ED83142-30 G8) AC Input Terminal Strip Panel</i>	<i>5 - 4</i>
<i>Figure 5-4: H569-436 G77F/78F (ED83142-30 G9) AC Input Terminal Strip Panel</i>	<i>5 - 4</i>
<i>Figure 6-1: H569-436 G30 (ED83143-30 G32) Battery Connection Panel</i>	<i>6 - 2</i>
<i>Figure 6-2: H569-436 G31 (ED83143-30 G31) Battery Connection Panel</i>	<i>6 - 2</i>
<i>Figure 6-3: H569-436 G34 (ED83143-30 G41) Battery Connection Panel</i>	<i>6 - 3</i>

<i>Figure 6-4: H569-435 G35 (ED83143-30 G42) Battery Connection Panel</i>	<i>6 - 3</i>
<i>Figure 6-5: H569-436 G36H (ED83143-30 G33) Battery Connection Panel</i>	<i>6 - 4</i>
<i>Figure 6-6: H569-436 G37F/38F (ED83143-30 G60/61) Battery (OLE) Connection Panel</i>	<i>6 - 4</i>
<i>Figure 6-7: H569-436 G80/81/82 (ED83143-30 G31/43) Battery Connection Panel</i>	<i>6 - 5</i>
<i>Figure 6-8: H569-436 G84H (ED83143-30 G34) Battery Connection Panel</i>	<i>6 - 6</i>
<i>Figure 6-9: H569-436 G85F (ED83143-30 G35) Battery Connection Panel</i>	<i>6 - 6</i>
<i>Figure 7-1: H569-436 G40/50 (ED83143-30 G11/13) DC Distribution Panel</i>	<i>7 - 2</i>
<i>Figure 7-2: H569-436 G41/51 (ED83143-30 G12/14) DC Distribution Panel</i>	<i>7 - 2</i>
<i>Figure 7-3: H569-436 G42 (ED83143-30 G2/3) DC Distribution Panel</i>	<i>7 - 3</i>
<i>Figure 7-4: H569-436 G43 (ED83143-30 G1/4) DC Distribution Panel</i>	<i>7 - 3</i>
<i>Figure 7-5: H569-436 G44 (ED83143-30 G5/6) DC Distribution Panel</i>	<i>7 - 4</i>
<i>Figure 7-6: H569-436 G45 (ED83143-30 G15/16) DC Distribution Panel</i>	<i>7 - 4</i>
<i>Figure 7-7: H569-436 G52 (ED83143-30 G53) DC Distribution Panel</i>	<i>7 - 5</i>
<i>Figure 7-8: H569-436 G53 (ED83143-30 G51/52) DC Distribution Panel</i>	<i>7 - 5</i>
<i>Figure 7-9: H569-436 G60 (ED83143-30 G20/26) DC Distribution Panel</i>	<i>7 - 6</i>
<i>Figure 7-10: H569-436 G61 (ED83143-30 G25/29) DC Distribution Panel</i>	<i>7 - 6</i>
<i>Figure 7-11: H569-436 G65 (ED83143-30 G24/28) DC Distribution Panel</i>	<i>7 - 7</i>

<i>Figure 7-12: H569-436 G66 (ED83143-30 G23/27) DC Distribution Panel</i>	<i>7 - 7</i>
<i>Figure 7-13: H569-436 G67 (ED83143-30 G22) DC Distribution Panel</i>	<i>7 - 8</i>
<i>Figure 7-14: H569-436 G68 (ED83143-30 G21) DC Distribution Panel</i>	<i>7 - 8</i>
<i>Figure 8-1: Location of BLJ Terminal Board and Bay Interface Card</i>	<i>8 - 3</i>
<i>Figure 8-2: Required Straps Prior to Replacing a Bay Interface Card (BIC)</i>	<i>8 - 3</i>
<i>Figure 11-1: Detail of Rectifier Position</i>	<i>11 - 3</i>
<i>Figure 12-1: Location of Cabinet Alarm</i>	<i>12 - 2</i>
<i>Figure 12-2: Millennium Controller Display</i>	<i>12 - 7</i>
<i>Figure 12-3: Location of Millennium Controller Fuses and Boards</i>	<i>12 - 7</i>
<i>Figure 12-4: Vector Controller Display</i>	<i>12 - 8</i>
<i>Figure 12-5: Location of Vector Controller Fuses and Boards</i>	<i>12 - 8</i>
<i>Figure 12-6: Rectifier Display</i>	<i>12 - 9</i>
<i>Figure 12-7: Low Voltage Battery Disconnect Contactor Control Switches</i>	<i>12 - 10</i>
<i>Figure 12-8: Detail of AC Input Panel and Rectifier Shelf</i>	<i>12 - 11</i>
<i>Figure 12-9: Detail of DC Distribution Panel</i>	<i>12 - 12</i>
<i>Figure 12-10: Low Voltage Load Disconnect Contactor Control Switches</i>	<i>12 - 13</i>



## *List of Tables*

<i>Table 5-A: AC Input Panels</i>	<i>5 - 2</i>
<i>Table 9-A: Galaxy Power System 4812 Specifications</i>	<i>9 - 1</i>
<i>Table 9-B: 596A Rectifier Specifications</i>	<i>9 - 3</i>
<i>Table 9-C: AC Input Panels</i>	<i>9 - 5</i>
<i>Table 9-D: Battery Connection Panels</i>	<i>9 - 6</i>
<i>Table 9-E: DC Distribution Panels</i>	<i>9 - 7</i>
<i>Table 11-A: GPS 4812 System Replacement Parts</i>	<i>11 - 6</i>
<i>Table 11-B: Galaxy Millennium Controller Circuit Boards</i>	<i>11 - 7</i>
<i>Table 11-C: Galaxy Vector Controller Circuit Boards and Temperature Module</i>	<i>11 - 7</i>
<i>Table 11-D: Product Documentation</i>	<i>11 - 8</i>
<i>Table 11-E: Software</i>	<i>11 - 8</i>
<i>Table 13-A: AC Alarms</i>	<i>13 - 3</i>
<i>Table 13-B: Battery Alarms</i>	<i>13 - 4</i>
<i>Table 13-C: Controller Alarms</i>	<i>13 - 6</i>
<i>Table 13-D: Distribution Alarms</i>	<i>13 - 11</i>
<i>Table 13-E: Rectifier Related Alarms</i>	<i>13 - 12</i>
<i>Table 13-F: Miscellaneous Alarms</i>	<i>13 - 17</i>
<i>Table 14-A: AC Alarms</i>	<i>14 - 3</i>
<i>Table 14-B: Battery Alarms</i>	<i>14 - 4</i>
<i>Table 14-C: Controller Alarms</i>	<i>14 - 5</i>
<i>Table 14-D: Distribution Alarms</i>	<i>14 - 6</i>
<i>Table 14-E: Rectifier Related Alarms</i>	<i>14 - 7</i>
<i>Table 14-F: Miscellaneous Alarms</i>	<i>14 - 12</i>



# ***1 Introduction***

## ***GPS 4812***

### ***Overview***


Lucent Technologies developed the Galaxy Power System (GPS) 4812 to support -48 volt telecommunications powering solutions in worldwide markets. The GPS 4812 combines 50-ampere, fan-cooled, switchmode rectifiers, microprocessor control technologies, battery and load disconnect/reconnect options, and a comprehensive line of fuse and circuit breaker dc distribution options in a modular front-access design. This modularity ensures easy access, simplified installation and maintenance, and allows the system to expand in capacity and features as power needs grow.

With 1200-ampere maximum capacity, distribution flexibility, and universal ac input capability, the GPS 4812 supports switching, transmission, and wireless applications in central office locations and environmentally controlled remote sites (huts or vaults).


The main emphasis of this manual is to provide a general product description that will familiarize the user with the main components of the system and to provide guidelines for the basic maintenance of this Galaxy Power System.

### ***Illustrations***

Figures 1-1 and 1-2 illustrate the GPS 4812 half height and full height cabinets.



**Figure 1-1: GPS 4812 Half Height Cabinet (with Battery Stand)**



**Figure 1-2: GPS 4812 Full Height Cabinet**

## ***Customer Assistance Contacts***

***Customer Training*** Lucent Technologies offers customer training on many Power Systems products. For information call 1-972-284-2163. This number is answered from 8:00 a.m. until 4:30 p.m., Central Time Zone (Zone 6), Monday through Friday.

***Customer Service*** For customers in the United States, Canada, Puerto Rico, and the US Virgin Islands, call 1-800-THE-1PWR (1-800-843-1797). Services provided through this contact include initiating the spare parts procurement process for out of service emergencies, ordering Lucent Technologies documents, and providing other product and service information.

For other customers worldwide, call 001-972-840-0382. This number is answered from 8:00 a.m. until 4:30 p.m., Central Time Zone (Zone 6), Monday through Friday.

***Technical Support*** Technical support for Lucent Technologies customers is available around the world during the normal product warranty period and also while specific contractual agreements extend this service.

For customers in the United States, Canada, Puerto Rico, and the US Virgin Islands, call 1-800-CAL-RTAC (1-800-225-7822) to contact a product specialist to answer your technical questions and assist in troubleshooting problems.

For other customers worldwide, contact your local field support center or your sales representative to discuss your specific needs.

***Product Repair and Return*** Repair and return service is provided for Lucent Technologies customers around the world.

For customers in the United States, Canada, Puerto Rico, and the US Virgin Islands, call 1-800-255-1402 for information on returning of products for repair.

For other customers worldwide, contact your sales representative to discuss your particular circumstances.

## ***Customer Assistance Contacts, continued***

- Warranty Service*** For domestic warranty service, contact your Warranty Service Manager (WSM). For international warranty service, contact your sales representative.
- On-Line Power Systems Product Manuals*** For Lucent Technologies users logging in from inside the corporate firewall, the address of the “Power Systems On-Line Product Manuals” page is <http://www.cic.lucent.com/lineage.html>.
- For customers logging in from outside the firewall, the address is <http://www.lucent8.com/lineage.html>. The annual subscription fee for access to this site is \$25. To obtain a password, follow the instructions on-line or call 1-888-Lucent8 (1-888-582-3688). When prompted for an order number, enter or say “167-790-010.”
- On-Line Power Systems Software Upgrades*** EasyView software upgrades are on-line at <http://www.lucent.com/networks/power/software.html>.



## 2 System Description

### Overview

#### Block Diagram

A basic block diagram of the Galaxy Power System 4812 is shown in Figure 2-1. It illustrates the arrangement and interconnections of the system components from the ac input to the dc output.




Figure 2-1: Block Diagram of the GPS 4812

## *Overview, continued*

### *System Components*

The power system accepts alternating current from the commercial utility or a standby ac power source and rectifies it to produce dc power for the using equipment. The system's control and alarm functions interact with the rectifiers and the office. In addition, the system provides overcurrent protection and charge, discharge, and distribution facilities. Battery reserve automatically provides a source of dc power if the commercial or standby ac fails. Battery reserve can be engineered to supply dc power for a specific period of time. In normal practice, battery capacity is sized to provide 3 to 8 hours of reserve time.

**AC Input** connects the commercial and/or standby ac power sources to the rectifiers within the system and provides overcurrent protection. In some applications the ac service is wired directly to the rectifiers and overcurrent protection is provided at the service panel.

**Rectifiers** convert an ac source voltage into the dc voltage level required to charge and float the batteries and to power the using equipment.

**Controller** provides the local and remote control, monitoring, and diagnostic functions required to administer the power system.

**Batteries** provide energy storage for an uninterrupted power feed to the using equipment during loss of ac input or rectifier failure.

**DC Distribution Panel** provides overcurrent protection, connection points for the using equipment, and bus bars used to interconnect the rectifiers, batteries, and dc distribution.

**Battery Connection Panel** provides connection points for the battery strings through battery disconnect fuses or contactors and current monitoring shunts.

## ***Architecture***

### ***Configurations***

The GPS 4812 is available in two configurations:

- The half height cabinet, shown in Figures 1-1 and 2-2, mounts on top of a battery stand and can provide up to 400 amperes of dc power.
- The full height (7-foot) cabinet, shown in Figures 1-2 and 2-3, can provide up to 800 amperes of dc power.

Each cabinet contains ac distribution, dc distribution panels, a battery connection panel, rectifiers, termination points for load circuits, and a system controller.

### ***Illustrations***

Figure 2-4 shows how a supplemental full-height cabinet may be added to grow the system to 1200 amperes. The rectifier output buses are interconnected to permit the two cabinets to share current and ensure common voltage references for all system rectifiers.

Figures 2-5 and 2-6 show open-door views of the half height and full height cabinets.




Figure 2-2: Schematic of Half Height Cabinet








Figure 2-4: Schematic of Two-cabinet System Architecture



*Figure 2-5: Half Height GPS 4812 with Door Open*



**Figure 2-6: Full Height GPS 4812 with Door Open**

## **3**                      ***Galaxy Controllers***

### ***Overview***

#### ***Introduction***

The GPS 4812 is available with either the Galaxy Millennium Controller or the Galaxy Vector Controller.

This section describes the operation of each controller. It also provides detailed information about the features of their front panel keys, LEDs, and displays.

## Galaxy Millennium Controller


### Design

The Galaxy Millennium Controller is equipped with a **Basic** control board for basic operations and an optional **Intelligent** control board that provides advanced local and remote monitoring and data acquisition features. These CPU control boards monitor each other's status and issue appropriate alarms in the event a failure occurs.

Each cabinet used with the Galaxy Millennium Controller requires a bay interface card (BIC). The BIC acts as an interface to the cabinet control and alarm signals.

### User Interface and Display

The Millennium's primary user interface is a panel that includes a backlit LCD front panel display that can be viewed in English or Spanish, two rows of LEDs, an array of pushbutton keys, and a pair of test jacks. Figure 3-1 illustrates the Millennium's front panel.



**Figure 3-1: Galaxy Millennium Controller Front Panel**

### Default Display

The default display shows basic system status. The controller returns to this display approximately three minutes after the last time a key is pressed. The information on the screen is updated automatically approximately every two seconds.

The default screen display is similar to the following: The first line shows the number of alarms (0) and warnings (0) present in the system, the date, and the time. The next two lines show the system voltage and the system load. The last line shows the system mode, which can be:

- FLOAT
- BOOST
- STC (Slope Thermal Compensation)
- BATT TEST

## ***Galaxy Millennium Controller, continued***

### ***LEDs***

Two rows of LEDs show the source and severity of various alarms. An alarm lights one status LED and one or more alarm LEDs. If more than one alarm LED lights, the status LED that lights will indicate the most severe active alarm.

- The first row of seven LEDs, labeled ALARMS, indicates the *source* of the alarm:

BD - battery on discharge

BATT - battery

DIST - distribution

RECT - rectifier

AC - ac power supply

RM - remote monitoring

CTRL - controller

- The second row includes four LEDs, labeled STATUS. They indicate the *severity* of the reported alarm:

CRIT - critical

MAJ - major

MIN - minor

NORM - normal

- The COM LED illuminates when the internal modem is in use.

### ***Test Jacks***

A pair of test jacks allows direct measurement of the dc bus sense voltage being monitored by the controller.

## ***Galaxy Millennium Controller, continued***

### ***Pushbutton Keys***

A group of pushbutton keys to the right of the backlit LCD display provides the primary user interface with the controller. These keys are used singly or in combination to navigate through the controller's menus.

The following is a general description of the pushbutton keys:

- MENU: View the MAIN menu.
- ENTER: Select a menu item.
- HELP: Displays limited on-line help information.
- ESCAPE: Return to the immediate higher level menu.
- Up arrow: Moves the cursor up one line.
- Down arrow: Moves the cursor down one line.
- Left arrow: Moves the cursor left one field.
- Right arrow: Moves the cursor right one field.
- ADJUST + and -: Increase or decrease parameter values.
- LAMP TEST: Test the controller's circuit board LEDs and front panel LEDs. It will also test the indicators of serially connected rectifiers.

## Galaxy Vector Controller

### Design

The Galaxy Vector Controller consists of an electronics board and a terminal connection board. The Vector provides a wide range of control and monitoring features and issues appropriate alarms in the event a failure occurs.

### User Interface and Display

The Vector's primary user interface is a panel that includes an alpha-numeric LED display, rows of LEDs, an array of pushbutton keys, and a pair of test jacks. Figure 3-2 illustrates the Vector's front panel.




Figure 3-2: Galaxy Vector Controller Front Panel

### Default Display

The default display shows the system voltage. Toggle the VOLTS/AMPS switch to view system voltage or current. Press the VIEW ACTIVE ALARMS button to view the code for any active alarm. The controller returns to the default display approximately 30 seconds after the last time a key is pressed.

## ***Galaxy Vector Controller, continued***

### ***LEDs***

LEDs show the source and severity of various alarms. An alarm lights one status LED and one or more alarm LEDs. If more than one alarm LED lights, the status LED that lights will indicate the most severe active alarm.

- The ALARMS row of six LEDs indicates the *source* of the alarm:
  - BD - battery on discharge
  - BATT - battery
  - DIST - distribution
  - RECT - rectifier
  - CTRL - controller
  - AC - ac input power
- The STATUS row of three LEDs indicates the *severity* of the reported alarm:
  - MAJ - major
  - MIN - minor
  - NORM - normal
- THERMAL COMPENSATION: Lights when the system voltage has been adjusted by the Thermal Compensation feature.

### ***Test Jacks***

A pair of test jacks allows direct measurement of the dc bus sense voltage being monitored by the controller.

## *Galaxy Vector Controller, continued*

### *Pushbutton Keys*

Pushbutton keys around the backlit LCD display provide the primary user interface with the controller. These keys are used singly or in combination to navigate through the controller's menus.

The following is a general description of the pushbutton keys:

- VOLTS or AMPS: Select either volts or amps for viewing.
- BOOST or FLOAT: Select one of these system modes.
- BATTERY TEST: Start/stop discharge test.
- ACO: Switch between Alarm Cut Off and On. The LED lights when audible Alarm Cutoff is active.
- VIEW ACTIVE ALARMS: Display active alarms. Use the arrow keys to page through multiple alarms. The LED lights when this option is selected. **Note: View Active Alarms and Configure cannot be active simultaneously.**
- CONFIGURE: Enter Configuration Mode. The LED lights when this option is selected. **Note: Configure and View Active Alarms cannot be active simultaneously.**
- ENTER: Select a menu item.
- DEFAULT: In Configure mode, change a parameter to default value.
- ESCAPE: Return to the immediate higher level menu.
- Up arrow: Moves the cursor up one line.
- Down arrow: Moves the cursor down one line.
- Left arrow: Moves the cursor left one field.
- Right arrow: Moves the cursor right one field.
- ADJUST + and -: Increase or decrease parameter values.
- LAMP TEST: Tests the controller's circuit board LEDs and front panel LEDs. It will also test the indicators of serially connected rectifiers.

## ***Reference Material***

### ***Controller Product Manuals***

Either a Galaxy Millennium Controller product manual (Select Code 167-792-180) or Galaxy Vector Controller product manual (Select Code 167-792-112) is furnished with every GPS 4812. Refer to this manual for information regarding configuration and operation.

### ***RPM System Product Manual***

Refer to the Galaxy Remote Peripheral Monitoring System product manual (Select Code 167-790-063) for additional information regarding module operation.

## 4 *Rectifiers*

### 596A

#### *Overview*

The 596A 50-ampere rectifier operates from single-phase ac service with a phase-to-phase voltage within the range of 176-264Vac.

The rectifiers are shipped separately from the cabinets for quick and straightforward installation into rectifier shelves at the site. Interconnections to ac input, dc output, and control signals occur automatically during insertion. The rectifier is keyed to prevent installation of the wrong rectifier. No settings or adjustments to potentiometers are necessary. The installer must set the rectifier's ID using the ON/STBY switch to allow the controller to learn the rectifier's physical location.

The 596A rectifier is **UL Recognized** for both the U. S. and Canada, complies with UL1950 (Information Technology Equipment), and meets EN60950 requirements.

## ***Front Panel Display***

### ***Power Switch***

This three-position switch has two active states:

- It controls the on/standby state of the rectifier.
- It is used to set the rectifier ID.

### ***Status Indicators***

In addition to the ON and STBY LEDs, four other LEDs on the rectifier's faceplate indicate the rectifier's condition.

- The **ALM** LED is red and lights whenever the rectifier fails.
- The **LIM** LED is yellow and lights when the unit is in current limit.
- The **FAN ALM** LED is red and lights when the fan inside the rectifier is not functioning properly.
- The **BST** LED is yellow and lights when the rectifier is in boost mode.

### ***Current Display***

This display indicates the current of the rectifier. Upon specific no-power conditions, the 3-digit display will show informative messages.


### ***Lamp Test***

To test the LEDs on the rectifier front panel, press the Lamp Test button on the controller.

## ***Front Panel Display, continued***

***Illustration***

Figure 4-1 shows the rectifier's front panel.



***Figure 4-1: Rectifier Front Panel***

## ***Features***

### ***Output Current “Walk-in”***

This circuit controls the time (up to eight seconds) required for the rectifier to reach normal operating conditions after it is turned on. This feature minimizes the starting surge on the customer's power source.

### ***Output Protection***

Rectifier is equipped with an internal fuse for plant protection if a fault occurs in a rectifier.

### ***Electronic Current Limit***

When the output current tends to increase above the current limit set point, the current limit circuit overrides the voltage regulating signal and safely limits the output current of the rectifier, thus preventing damage to itself or the load.

### ***High Voltage Shutdown (HVSD)***

The rectifier senses the voltage at its output terminals. If this voltage is too high, the rectifier will shut down to prevent the high voltage from damaging itself or the load.

### ***Restart***

Upon shutdown, the rectifier will attempt to restart. The rectifier will also accept a restart command from the controller for a remote restart. The rectifier will attempt to restart three times before issuing a rectifier fail alarm to the controller.

### ***Fan Alarm and Control***

The rectifier contains a cooling fan. The fan's speed, which is based on ambient temperature and output power level, is lowered during low-load and low-temperature conditions to minimize audible noise and maximize fan life.

### ***Thermal Alarm***

The rectifier senses the internal operating temperature and will issue a thermal alarm if the internal temperature exceeds a safe operating level. Ambient temperatures above the maximum rating will result in a rectifier shutdown and the issuing of a thermal alarm (TA).

### ***Autonomous Operation***

Rectifiers will continue to power the load if the controller fails or if communication is lost.

### ***Controller Communications Alarm***

When communications between the rectifier and controller are interrupted, the rectifier continues to operate and the red **ALM** LED on the rectifier blinks.

## ***Features, continued***

### ***Connectorized***

The rectifiers provide the controller with a full complement of status and alarm signals. The rectifier status and alarm signals, ac input, and dc output are all connectorized for easy installation and maintenance. System connections are made when the rectifier is plugged into the shelf. No additional connections are required.

### ***“Forced” Load Sharing***

Internal rectifier circuitry will allow multiple rectifiers to share load in the event communication to the controller is lost or the controller malfunctions.



## **5**                      ***AC Input Panels***

### ***Overview***

#### ***AC Service***

The ac input panel provides the facility to terminate 3-phase ac service to the GPS 4812 system or to distribute individual 1-phase ac supplies to each of the system rectifier positions. Depending upon the option ordered, the panel will connect 3-wire (three phases), 4-wire (three phases + neutral), or individual 2-wire (single phase, either 2 hot leads or 1 hot lead and neutral) input ac service.

In some systems, circuit breakers are provided to protect the conductor providing ac service to the individual rectifiers. In other systems, the system's ac input panel contains a terminal strip and the conductors are protected by circuit breakers located in the building's ac service panel.

Note: All wire sizes were based on the US National Electric Code.


## Overview, continued

**Cross Reference of Cabinets and Panels** Table 5-A identifies which cabinet uses each of the panels.


**Table 5-A: AC Input Panels**

<b>Panel</b>	<b>Cabinet</b>	<b>Figure</b>
H569-436 G73F (ED83142-30 G6)	Full-height cabinet with two shelves of rectifiers that are connected phase to phase	Figure 5-1
H569-436 G71H (ED83142-30 G6)	Half-height cabinet with two shelves of rectifiers that are connected phase to phase	Figure 5-1
H569-436 G74F (ED83142-30 G6M)	Full-height cabinet with two shelves of rectifiers that are connected phase to neutral	Figure 5-1
H569-436 G74H (ED83142-30 G6M)	Half-height cabinet with two shelves of rectifiers that are connected phase to neutral	Figure 5-1
H569-436 G72F (ED83142-30 G7)	Full-height cabinet with three shelves of rectifiers that are connected phase to phase	Figure 5-2
H569-436 G79F (ED83142-30 G8)	Full-height cabinet with two shelves of rectifiers that are connected phase to phase or phase to neutral	Figure 5-3
H569-436 G76H (ED83142-30 G8)	Half-height cabinet with two shelves of rectifiers that are connected phase to phase or phase to neutral	Figure 5-3
H569-436 G77F (ED83142-30 G9)	Full-height cabinet with three shelves of rectifiers that are connected phase to phase or phase to neutral	Figure 5-4
H569-436 G78F (ED83142-30 G9)	Full-height cabinet with four shelves of rectifiers that are connected phase to phase or phase to neutral	Figure 5-4


**Illustrations** Circuit breaker panels are shown in Figures 5-1 and 5-2; terminal strip panels are shown in Figures 5-3 and 5-4.




**Figure 5-1: H569-436 G73F/71H (ED83142-30 G6)  
H569-436 G74F/74H (ED83142-30 G6M)  
AC Input Circuit Breaker Panel**



**Figure 5-2: H569-436 G72F (ED83142-30 G7)  
AC Input Circuit Breaker Panel**



**Figure 5-3: H569-436 G79F/76H (ED83142-30 G8)  
AC Input Terminal Strip Panel**



**Figure 5-4: H569-436 G77F/78F (ED83142-30 G9)  
AC Input Terminal Strip Panel**

## **6**                      ***Battery Connection Panels***

### ***Overview***

#### ***Function***


Batteries are connected to the GPS 4812 cabinets on battery connection panels located in the cabinet directly below or behind the ac input panel. All panels include the battery shunts and an alarm card that communicates with the controller to provide battery current and status information. As options, the panels may include fuses or low voltage battery disconnect/reconnect (LVBD/R) contactors. When equipped with contactors, a contactor control card provides local/manual control of the contactors.

Note: If no battery panel is needed (for full height supplemental cabinets only), H569-436 G33F is selected as a placeholder in the order.


#### ***Illustrations***

The battery connection panels are shown in Figures 6-1 through 6-9.


Note: Battery connection panels are blue; dc distribution panels are white.




**Figure 6-1: H569-436 G30 (ED83143-30 G32)  
Battery Connection Panel**




**Figure 6-2: H569-436 G31 (ED83143-30 G31)  
Battery Connection Panel**




**Figure 6-3: H569-436 G34 (ED83143-30 G41)  
Battery Connection Panel**




**Figure 6-4: H569-435 G35 (ED83143-30 G42)  
Battery Connection Panel**



**Figure 6-5: H569-436 G36H (ED83143-30 G33)  
Battery Connection Panel**




**Figure 6-6: H569-436 G37F/38F (ED83143-30 G60/61)  
Battery (OLE) Connection Panel**




\*H569-436 Battery Module

Group #	Includes:
G80	1 G31 1 G43
G81	1 G31 2 G43
G82	1 G31 3 G43 (shown)

**Figure 6-7: H569-436 G80/81/82 (ED83143-30 G31/43) Battery Connection Panel**



**Figure 6-8: H569-436 G84H (ED83143-30 G34)  
Battery Connection Panel**



**Figure 6-9: H569-436 G85F (ED83143-30 G35)  
Battery Connection Panel**

# **7**                      ***DC Distribution Panels***

## ***Overview***


### ***Function***

A variety of dc distribution panels is available for the GPS 4812 system, including DIN standard fuse holders and circuit breakers and U. S. standard fuse holders and circuit breakers. All panels are equipped with an alarm card. When a fuse operates or a circuit breaker trips, a red LED on the alarm card lights, the cabinet alarm lights, and the alarm is transmitted to the controller. Most panels are also available with contactors to provide low voltage load disconnect.


### ***Illustrations***

The dc distribution panels are illustrated in Figures 7-1 through 7-14.


Note: DC distribution panels are white; battery connection panels are blue.




**Figure 7-1: H569-436 G40/50 (ED83143-30 G11/13)  
DC Distribution Panel**




**Figure 7-2: H569-436 G41/51 (ED83143-30 G12/14)  
DC Distribution Panel**




**Figure 7-3: H569-436 G42 (ED83143-30 G2/3)  
DC Distribution Panel**




**Figure 7-4: H569-436 G43 (ED83143-30 G1/4)  
DC Distribution Panel**




**Figure 7-5: H569-436 G44 (ED83143-30 G5/6)  
DC Distribution Panel**




**Figure 7-6: H569-436 G45 (ED83143-30 G15/16)  
DC Distribution Panel**




**Figure 7-7: H569-436 G52 (ED83143-30 G53)  
DC Distribution Panel**




**Figure 7-8: H569-436 G53 (ED83143-30 G51/52)  
DC Distribution Panel**




**Figure 7-9: H569-436 G60 (ED83143-30 G20/26)  
DC Distribution Panel**




**Figure 7-10: H569-436 G61 (ED83143-30 G25/29)  
DC Distribution Panel**




**Figure 7-11: H569-436 G65 (ED83143-30 G24/28)  
DC Distribution Panel**



**Figure 7-12: H569-436 G66 (ED83143-30 G23/27)  
DC Distribution Panel**



**Figure 7-13: H569-436 G67 (ED83143-30 G22)  
DC Distribution Panel**



**Figure 7-14: H569-436 G68 (ED83143-30 G21)  
DC Distribution Panel**

# 8 *Circuit Boards*

## *Overview*

### *Function*

Circuit boards (sometimes referred to as “cards”) are included in the battery connection and dc distribution panels to provide data required by the controller.

### *Terminal Boards*

Terminal boards are used to provide shunt voltage data to the controller, where it is used to calculate current. Terminal boards located on the battery connection panels provide data that is used to calculate battery current; data from terminal boards located on the dc distribution panels is used to calculate load current.

### *Alarm Boards*

Alarm boards perform two functions:

- monitor panel functions and activate local indicators when faults occur on the panel
- provide alarm data to the controller

### *Alarm/Terminal Boards*

Alarm/terminal boards combine the functions of alarm boards and terminal boards.

## ***BLJ Terminal Board***

### ***Millennium Systems***

A BLJ terminal board is located inside the door of each initial and supplemental cabinet of a Millennium system. The BLJ is the termination point for distribution alarms in each cabinet. It uses the rectifier serial bus to communicate with the controller.

### ***Vector Systems***

The Vector controller, which is installed in the initial cabinet, contains a BLJ terminal connection board. This board is daisy-chained to a BLJ board in each supplemental cabinet.

## ***Bay Interface Card***

### ***Millennium Systems***

Each initial and supplemental cabinet in a Millennium system has a BIC that attaches to the cabinet's terminal board (BLJ). The BIC provides controller access to alarm monitoring, battery voltages, battery currents, and temperature probes in the cabinet through the serial rectifier bus.


### ***Vector Systems***

The initial cabinet contains the Vector controller, which consists of a BIC3 control board and a BLJ terminal connection board. Supplemental cabinets do not require a BIC.

## Illustrations

### ***BLJ and BIC Locations***


Figure 8-1 shows the location of the BLJ Terminal Board and Bay Interface Card (BIC).



**Figure 8-1: Location of BLJ Terminal Board and Bay Interface Card**

### ***Replacing a BIC***

Figure 8-2 shows the straps required prior to replacing a Bay Interface Card (BIC). (See “BIC Failure” in Table 13-C.) Straps are backups to ensure continuous operation of LVBD and LVDL contactors.



**Figure 8-2: Required Straps Prior to Replacing a Bay Interface Card (BIC)**



# 9 Specifications

## GPS 4812

**Table 9-A: Galaxy Power System 4812 Specifications**

<b>Electrical</b>		
<b>AC Input</b>		
Input Distribution	125A circuit breaker (2-shelf system) or 150A circuit breaker (3-shelf system) feed into each cabinet or 25A circuit breaker per rectifier for individual feeds	
Wire Size	Minimum 2 gauge/35 mm <sup>2</sup> (2-shelf system) or 1/0 gauge/50 mm <sup>2</sup> (3-shelf system) cable to each cabinet or 8 gauge/8 mm <sup>2</sup> (2-shelf system) or 8 gauge/8 mm <sup>2</sup> (3-shelf system) for individual feeds	
<b>System Output</b>		
	<b>Full Height</b>	<b>Half Height</b>
System Voltage	-48	-48
Output Current	50 - 1200 amperes	50 - 400 amperes
<b>Mechanical</b>		
<b>Cabinet</b>		
	<b>Full Height</b>	<b>Half Height</b>
Nominal Cabinet Dimensions (H x W x D)	2100 H x 600 W x 500 D mm (82.6 H x 23.6 W x 19.7 in.)	1080 H x 600 W x 500 D mm (42.5 H x 23.6 W x 19.7 D in)

**Table 9-A: Galaxy Power System 4812 Specifications**

<b>Units Per Initial Cabinet</b>		
	<b>Full Height</b>	<b>Half Height</b>
Rectifiers	1 - 12 or 1 - 16	1 - 8
Controller	1	
Battery Disconnect Modules	0 - 1	
DC Distribution	1 - 6	1 - 3
<b>Units Per Supplemental Cabinet</b>		
Rectifiers	1 - 12 or 1 - 8	N/A
Battery Disconnect Modules	0 - 1	N/A
DC Distribution	1 - 6	N/A
<b>Environmental</b>		
Operating Ambient Temperature	0°C to 45°C	
Altitude	-50 to 4000 meters <b>Note: For altitudes between 1500 and 4000 meters, derate the maximum temperature by 0.656°C per 100 meters.</b>	
Humidity	5% to 90% non-condensing	
Radiated and Conducted Emissions	EN50082-1, EN50082-2, EN50081, EN61000	
Electromagnetic Immunity	Level B	
Earthquake Rating	Zone 4, upper floors	
<b>Standards Compliance</b>		
Agency Approvals	CE Marked, UL Underwriters Laboratories (UL) Listed per Subject Letter 1801, DC Power Distribution Centers for Telecommunications Equipment	

# Rectifier

**Table 9-B: 596A Rectifier Specifications**

<b>Electrical</b>	
<b>Input</b>	
Voltage Range	176-264Vac, 2-wire, single phase
Frequency Range	47 - 63 Hz
Power Factor	> 0.98 for loads > 50%
High Voltage Shutdown	
Internal Selective High Voltage Shutdown (ISHVSD)	596A Float 56.0Vdc Nom. <sup>1, 2</sup> 596A Boost 56.0Vdc Nom. <sup>1, 2</sup> 596A Equalize 56.0Vdc Nom. <sup>1, 2</sup>
Backup High Voltage Shutdown (BUHVSD)	596A Float/Boost 59.52Vdc <sup>3</sup> 596A Equalize 66.0Vdc <sup>3</sup>
<sup>1</sup> Selectable/programmable through Galaxy Controller	
<sup>2</sup> Factory default settings – actual range is 44 - 60Vdc	
<sup>3</sup> Factory default settings – Float/Boost range is 58.51 - 60.53Vdc, Equalize range is 65.2 - 67.0Vdc	
<b>Rated Service Entrance Surge Protector:</b> It is important that the service entrance surge protector (if provided) be coordinated with the internal surge protection and that it clamps at a lower voltage than the internal protection. The internal protection of the 596A has the following voltage and current characteristics:	
<u>Phase to Phase Voltage</u>	<u>MOV Conduction Current</u>
320Vac (RMS)	0A
620V maximum clamping	1mA (DC test current)
810Vpeak	100A peak (8 x 20µs)
<b>Output</b>	
Output Current	50 amperes
Float/Boost Voltage	44-58Vdc
Total Harmonic Distortion	10% at Nom. Line V
Regulation	±0.5%
Ripple	100 mVrms
Noise	< 2mV psophometric
Permanent Overload	55A dc maximum
Current Limit Set Point	15A-55A <b>Note: When using the maximum 16 rectifiers in a cabinet, do not exceed 50 amperes current limit per rectifier at 65°C.</b>

**Table 9-B: 596A Rectifier Specifications**

<b>Mechanical</b>	
Width	5.25 in. (133.35 mm)
Height	8 in. (203.2 mm)
Depth	19.75 in. (501.65 mm)
Weight	20 lbs. (9 kg)
<b>Environmental</b>	
Efficiency	> 90% typical
Operating Temperature	-40°C to +65°C
Operating Relative Humidity	5% to 90%
Heat Release	Per rectifier:
52Vdc, 40A	231W [788.9 BTU/hr]
52Vdc, 50A	288W [983 BTU/hr]
Short Term Operating Relative Humidity	5% to 90%
Storage Temperature	-45°C to 85°C
Storage Relative Humidity	5% to 90%
Altitude	-50 to 4000 meters Note: For altitudes above 1500 meters, derate the temperature by 0.656° Celsius per 100 meters.
Audible Noise	< 52dBA
EMC	EN 50022, level B, conducted and radiated (CISPR 22)
<b>Standards Compliance</b>	
Safety Standard	EN 60950 (IEC950)
Certification Marks	UL, VDE, CE Rectifiers are individually UL Recognized and/or CSA Certified to UL1950 and CSA C22.2 No 234/950. Rectifiers are also approved to IEC-950/EN60950 by an EC Notified Body and have outputs classified as SELV.

## AC Input Panels

**Table 9-C: AC Input Panels**

Description	H569-436 Group No.	ED83142-30 Group No.
AC Input Circuit Breaker Panel Full-height cabinet with two shelves of rectifiers that are connected phase to phase	G73F	G6
AC Input Circuit Breaker Panel Half-height cabinet with two shelves of rectifiers that are connected phase to phase	G71H	G6
AC Input Circuit Breaker Panel Full-height cabinet with two shelves of rectifiers that are connected phase to neutral	G74F	G6M
AC Input Circuit Breaker Panel Half-height cabinet with two shelves of rectifiers that are connected phase to neutral	G74H	G6M
AC Input Circuit Breaker Panel Full-height cabinet with three shelves of rectifiers that are connected phase to phase	G72F	G7
AC Input Terminal Strip Panel Full-height cabinet with two shelves of rectifiers that are connected phase to phase or phase to neutral	G79F	G8
AC Input Terminal Strip Panel Half-height with two shelves of rectifiers that are connected phase to phase or phase to neutral	G76H	G8
AC Input Terminal Strip Panel Full-height cabinet with three shelves of rectifiers that are connected phase to phase or phase to neutral	G77F	G9
AC Input Terminal Strip Panel Full-height cabinet with four shelves of rectifiers that are connected phase to phase or phase to neutral	G78F	G9

## Battery Connection Panels

**Table 9-D: Battery Connection Panels**

<b>Description</b>	<b>H569-436 Group No.</b>	<b>ED83143-30 Group No.</b>
LVBD: (2) 500A contactors with 1000A shunts	G30	G32
LVBD: 1200A contactor with 1500A shunt	G31	G31
(2) fuse holders for 315-630A NH3 DIN fuses with 600A shunts	G34	G41
Fuse holder for 315-630A NH3 DIN fuse with 600A shunt	G35	G42
LVBD: 800A contactor with 600A shunt	G36H	G33
Off-Line Equalize (OLE) with (3) 600A fuse holders (US style), (3) 1000A shunts, and (1) 1200A contactor	G37F	G60
Off-Line Equalize (OLE) with (3) 600A fuse holders (US style) and (3) 1000A shunts	G38F	G61
LVBD: 1200A contactor, (2) NH3 DIN fuses and (2) 600A shunts	G80	G31 and (1) G43
LVBD: 1200A contactor, (4) NH3 DIN fuses and (4) 600A shunts	G81	G31 and (2) G43
LVBD: 1200A contactor, (6) NH3 DIN fuses and (6) 600A shunts	G82	G31 and (3) G43
600A shunt	G84H	G34
1000A shunt	G85F	G35

## DC Distribution Panels

**Table 9-E: DC Distribution Panels**

<b>Description</b>	<b>H569-436 Group No.</b>	<b>ED83143-30 Group No.</b>
13 positions for 0-100A plug-in fuse holders or circuit breakers	G40, G50	G11, G13
21 positions for 0-100A plug-in fuse holders or circuit breakers	G41, G51	G12, G14
3 positions for 125-600A circuit breakers	G42	G2, G3
6 positions for 125-600A circuit breakers	G43	G1, G4
5 positions for 125-600A circuit breakers	G44	G5, G6
10 positions for 0-150A plug-in (bullet style) circuit breakers	G45	G15, G16
10 fuse holders for 1-60A fuses	G52	G53
2 fuse holders for 100-600A fuses	G53	G51, G52
14 positions for 1-63A DIN circuit breakers	G60	G20, G26
10 positions for 80-125A DIN circuit breakers	G61	G25, G29
14 fuse holders for 1-32A DIN fuses	G65	G24, G28
10 fuse holders for 1-50A DIN fuses	G66	G23, G27
8 fuse holders for 4-160A DIN NH00 fuses	G67	G22
2 fuse holders for 32-400A DIN NH2 fuses	G68	G21



# ***10***                      ***Safety***

Please read and follow all safety instructions and warnings before servicing the Galaxy Power System. Reference the GPS Installation Guide and individual module product manuals for additional safety statements specific to the modules.



# ***11 Maintenance and Replacement***

## ***Requirements***

### ***System***

With the exception of the batteries, periodic maintenance specific to the power system is not required. The ac service for the building must be maintained with ANSI specified limits. The temperature and humidity within the power room must be maintained within the limits specified in Section 9 of this product manual.

Refer to Table 11-A for system replacement parts.

### ***Batteries***

The batteries must be maintained as directed by the battery manufacturer's requirements.

### ***Rectifiers***

With the exception of a fan failure, rectifiers are repaired by replacement. Refer to "Installing or Replacing a Rectifier" in this section.

## ***Requirements, continued***

### ***Rectifier Fan Assembly***

The expected life of the rectifier fans at 25 °C (77°F) is approximately eight years. The fans in the rectifiers may be replaced in the field.


Two approaches can be taken to fan maintenance.

- The first approach is to replace the fan on a routine basis every seven to eight years; this ensures that the fan does not fail in the field under normal operating conditions. This approach is appropriate when there are no remote alarm facilities at the site.
- The second approach, assuming one has remote alarm capability, is to wait until the fan fails. The rectifier will safely shut down and issue both a fail alarm and a thermal alarm. The fan can then be replaced. Since it is likely that all the rectifiers in that installation are of roughly the same age, all rectifier fans at that site should be replaced at that time.

The approach used depends on the location and manning of the site as well as the monitoring of alarms used at the site. Refer to “Replacing a Rectifier Fan Assembly” in this section.

## Replacement Procedures

**⚠ Installing or Replacing a Rectifier**

Installing or Replacing a Rectifier	
Step	Action
1	Locate and turn off the ac service feeding the rectifier. Note: Do not turn off ac service to the entire system, only to the rectifier that has failed.
2	Turn the rectifier's ON/STBY switch to STBY.  <b>⚠ Caution</b> <b>Rear portion of the rectifier that is in operation is HOT to the touch. Use appropriate precautions.</b>
3	(Steps 3 and 4 for replacement only. For a new installation, proceed to Step 5.)  Locate the Allen-head bolt in the center of the rectifier front panel. Using the Allen wrench provided, rotate the bolt counterclockwise to release the rectifier for removal.
4	<b>⚠ Caution</b> <b>Handle the rectifier using two hands, one hand supporting the rear of the unit, the other hand on the front handle.</b>  Grasp the front handle and slide/pull the rectifier from the shelf assembly. Support the rear of the unit as it slides from the shelf.
	
<p><b>Figure 11-1: Detail of Rectifier Position</b></p> <p><i>Continued on next page.</i></p>	

## ***Replacement Procedures, continued.***

<b>Installing or Replacing a Rectifier, continued</b>	
<b>Step</b>	<b>Action</b>
5	Slowly slide new rectifier onto the shelf until it contacts the rear connector.
6	Using the Allen wrench, turn the Allen-head bolt clockwise to pull the rectifier into the shelf.
7	Once the rectifier has been installed, set the rectifier ID. Follow the directions for the “ID Not Configured” alarm in Table 13-E (Millennium) or “rid” in Table 14-E (Vector).  Note: The red LED on the rectifier will blink until the rectifier establishes communication with the controller. After communication is established, the controller will issue a RECT MAJ alarm until the rectifier ID is set.
8	Turn the ac service back on.
9	Turn the rectifier’s ON/STBY switch to ON.

## Replacement Procedures, continued

**⚠ Replacing a Rectifier Fan Assembly**

**⚠ Stop!** Review the “Installing or Replacing a Rectifier” procedure in this section before proceeding.

<b>Replacing a Rectifier Fan Assembly</b>	
<b>Step</b>	<b>Action</b>
1	Remove the rectifier from the system. See the “Installing or Replacing a Rectifier” procedure in this section for the procedure.
2	WAIT five minutes for capacitors to discharge.
3	Loosen the white front cover by removing 14 screws (5 top, 5 bottom, 2 on each side). Before fully removing the cover, disconnect the ribbon cable from the display circuit pack.
4	Remove the screws attaching the old fans to the chassis and carefully unplug the fan connector. The fan connector is keyed and can be loosened by inserting a screwdriver into the slotted side of the connector and gently prying the fan-side connector loose.
5	Replace the new fans.
6	Reconnect the ribbon cable removed in Step 3.
7	Attach the front cover.
8	Install the rectifier, following instructions in the “Installing or Replacing a Rectifier” procedure in this section.

## Replacement Parts

### System

Table 11-A provides a list of replacement parts for GPS 4812.

**Table 11-A: GPS 4812 System Replacement Parts**

Ordering Code	Description
<b>Cabinet</b>	
402328926	0.18 ampere alarm fuse
405673161	0.5 ampere alarm fuse
406530725	1-1/3 ampere alarm fuse
406421032	2 ampere alarm fuse
406420273	GMT fuse puller tool
848262622	BLJ3 terminal board
408229318	Wire insertion tool
108588625	BIC8 bay interface card (Millennium controller only)
107900169	EBV2 load disconnect card
107604076	BJN1 battery disconnect card
407226786	Lens cover, red
407227172	Cabinet alarm lamp, 48V
<b>Rectifier</b>	
107598120	596A, 50A rectifier
407840792	Fan assembly
901181834	Insulated Allen-head wrench
<b>Distribution</b>	
405673161	1/2A alarm fuse
<b>Millennium Controller</b>	
406530725	1-1/3 ampere fuse (GMT)
406204230	3 ampere fuse (GMT)
406677880	Battery TL5101 for CP BSJ

## Replacement Parts, continued

### **Millennium Controller Circuit Boards**

Table 11-B lists the spare parts available for the Galaxy Millennium Controller.

**Table 11-B: Galaxy Millennium Controller Circuit Boards**

<b>Ordering Code</b>	<b>Description</b>
108029679	Display board (BSK1)
108029687	Alarm wire wrap board (BSL1)
848194551	Insulation displacement alarm board (BSL2)
108029653	Basic control board (BSH1)
847950912	LCD module assembly display board
108029661	Intelligent control board (BSJ1)
108029695	Modem board (BSM1)
108163601	Data switch board (BSW1)
108340100	Gateway board (EBW1)

### **Vector Controller Circuit Boards**

Table 11-C lists the spare parts available for the Galaxy Vector Controller.

**Table 11-C: Galaxy Vector Controller  
Circuit Boards and Temperature Module**

<b>Ordering Code</b>	<b>Description</b>
107789513	Thermal probe multiplexer (210E)
108402017	VC control panel (BMW3)
108259615	48V VC control board (BIC3)

## ***Replacement Parts, continued***

### ***Documentation***

Table 11-D lists other documentation associated with the GPS 4812.

**Table 11-D: Product Documentation**

<b>Document Number</b>	<b>Description</b>
H569-436	GPS 4812 Ordering Guide
167-792-157	GPS Installation Guide
167-792-180	Galaxy Millennium Controller Product Manual
167-792-112	Galaxy Vector Controller Product Manual
167-790-063	Remote Peripheral Monitoring System Product Manual

### ***Software***

EasyView software is a Windows-compatible communications package designed specifically for use with Galaxy controllers.

**Table 11-E: Software**

<b>Ordering Code</b>	<b>Description</b>
847473774	EasyView Software Package

# 12 *Troubleshooting Preparations*

## *Preliminary*

### *Introduction*

This section provides information needed in preparation for locating and interpreting visual indicators to help identify problems.

When replacing a part does not correct the problem or visual indicators do not identify a defective part, notify the local Regional Technical Assistance Center (RTAC) at 1-800-CAL-RTAC (1-800-225-7822).

### *Safety*

Review all safety instructions and warnings in Section 10 before troubleshooting the GPS 4812.

### **Warnings**

- |   |
|---|
| <ul style="list-style-type: none"><li>• Hazardous ac and dc voltages and/or energy are present. Caution should be exercised. Tools must be insulated to help prevent accidental contact with live surfaces.</li><li>• Coordinate all troubleshooting activities with other personnel that may be working on the system.</li></ul> |
|---|

### *Tools*

The following tools are necessary in order to troubleshoot the GPS 4812:

- 3/16-inch (5mm) Allen-head wrench
- Insulated hand tools
- Calibrated digital voltmeter (DVM) (0.05% accuracy on dc scale)
- ESD wrist strap

## Troubleshooting Procedure


### *Purpose*

The troubleshooting procedure described below is used when a trouble condition has been identified and a technician has been dispatched to the system location as a first and fundamental step in diagnosing and correcting the problem.

For all trouble conditions, proceed as follows:

### *Cabinet Alarm*

1. Locate the system Galaxy controller. The controller is typically located in the cabinet identified as BAY ONE. Because a trouble condition exists, the red alarm on the top of the cabinet will be illuminated. See Figure 12-1.



**Figure 12-1: Location of Cabinet Alarm**

## ***Troubleshooting Procedure, continued***

### ***System Status***

2. Determine the system status. For most problems, one or more alarm and status LEDs will be illuminated. Depending on the controller type, the following will be displayed:
  - system voltage (all)
  - system current (Millennium)
  - system mode (Millennium)
  - system number of alarm/warnings (Millennium)

If the screen is blank, but alarm and status LEDs are illuminated, call your RTAC representative.

If the entire panel is blank, check the controller fuse (F3 basic power for the Millennium; F1 on the BLJ board for the Vector). See Figures 12-3 and 12-5. Verify that the controller is getting power. If not, replace fuse. If the display is still blank, call your RTAC representative.)

### ***Alarms Menu***

3. To view the Alarms Menu:

- **Millennium controller:**

If the default screen appears normal, press the MENU button. The main menu appears with “Alarms” blinking. Press ENTER to obtain the Alarms menu. Additional data appears that will help to identify the problem.

- **Vector controller:**

Press the View Active Alarms button and use the displayed message code to help identify the problem.

## Troubleshooting Procedure, continued

### **Troubleshooting Tables**

- Based on the information presented by the alarm LEDs, select the appropriate table from the lists below:

<b>Section 13, Troubleshooting Millennium Systems</b>	
<b>Alarm LED</b>	<b>Table</b>
AC	13-A, AC Alarms
BATT	13-B, Battery Alarms
BD	13-F, Miscellaneous Alarms
CTRL	13-C, Controller Alarms
DIST	13-D, Distribution Alarms
RECT	13-E, Rectifier Related Alarms
No LED*	13-F, Miscellaneous Alarms
*If an alarm condition exists, but no alarm LED is lit, refer to Table 13-F.	

<b>Section 14, Troubleshooting Vector Systems</b>	
<b>Alarm LED</b>	<b>Table</b>
AC	14-A, AC Alarms
BATT	14-B, Battery Alarms
BD	14-F, Miscellaneous Alarms
CTRL	14-C, Controller Alarms
DIST	14-D, Distribution Alarms
RECT	14-E, Rectifier Related Alarms
No LED*	14-F, Miscellaneous Alarms
*If an alarm condition exists, but no alarm LED is lit, refer to Table 14-F.	

### **Identifying Problems**

- Once the appropriate table is identified, use the status LEDs and the alarm menu data to identify the specific problem that is causing the alarm.

## Reference Figures

### *Figure Numbers and Titles*

The following figures are provided for reference while performing the troubleshooting procedure:

#### **Troubleshooting Reference Figures**

<b>Figure No.</b>	<b>Title</b>
12-1	Location of Cabinet Alarm
12-2	Millennium Controller Display
12-3	Location of Millennium Controller Fuses and Boards
12-4	Vector Controller Display
12-5	Location of Vector Controller Fuses and Boards
12-6	Rectifier Display
12-7	Low Voltage Battery Disconnect Contactor Control Switches
12-8	Detail of AC Input Panel and Rectifier Shelf
12-9	Detail of DC Distribution Panel
12-10	Low Voltage Load Disconnect Contactor Control Switches

## *Reference Figures, continued*

### *Millennium Controller*

#### **Basic Controller**

**BSH (microprocessor board):** After power up, or after a reset, the green and yellow LEDs will both be lit while self diagnostics are in progress (which will take about 10 seconds). If all diagnostics pass, the yellow LED will extinguish and the green LED will remain lit. If a failure is detected during diagnostics, the green LED will extinguish and the yellow LED will remain lit.


If a failure occurs during normal operation, the green LED will extinguish and the yellow LED will light.

#### **Intelligent Controller**


**BSJ (microprocessor board):** After power up, or after a reset, the green and yellow LEDs will both be lit while self diagnostics are in progress (which will take about 30 seconds). If all diagnostics pass, the yellow LED will extinguish and the green LED will remain lit. If a failure is detected during diagnostics, the green LED will extinguish and the yellow LED will remain lit. If a terminal is attached to the local port during diagnostics, the diagnostic messages will show which test failed.

If a failure occurs during normal operation, the green LED will extinguish and the yellow LED will light.

**Reference Figures, continued**



**Figure 12-2: Millennium Controller Display**



**Figure 12-3: Location of Millennium Controller Fuses and Boards**

## Reference Figures, continued

### Vector Controller

The Control Board is mounted on top of the BLJ terminal connection board. The controller issues alarms off the BLJ board. There is a mnemonic abbreviation for each alarm, which is shown on the controller display, along with associated alarm LEDs. These mnemonics and related alarms are described in the Galaxy Vector Controller product manual.




Figure 12-4: Vector Controller Display




Figure 12-5: Location of Vector Controller Fuses and Boards

## Reference Figures, continued

### Rectifiers

During normal operation, the rectifier's green ON LED will be lit and the display will show the rectifier's output current.





Figure 12-6: Rectifier Display

## Reference Figures, continued

### Low Voltage Battery Disconnect

The low voltage battery disconnect (LVBD) feature consists of a contactor, circuitry on the BJN board, and associated wiring. Control of the contactor is dictated by the BJN contactor control board and the controller.

Figure 12-7 shows the location of the contactor control board in the GPS cabinet.



**Figure 12-7: Low Voltage Battery Disconnect Contactor Control Switches**

## Reference Figures, continued

### AC Input




Figure 12-8: Detail of AC Input Panel and Rectifier Shelf

## Reference Figures, continued

### DC Distribution





Figure 12-9: Detail of DC Distribution Panel

## Reference Figures, continued

### Low Voltage Load Disconnect

The EBV low voltage load disconnect (LVLD) contactor control board is mounted on the right side of the cabinet, as shown in Figure 12-10.

The manual contactor control switch (SW300) is not meant to be used to permanently override the LVLD function. It is only to be used temporarily while servicing or testing the equipment.



**Figure 12-10: Low Voltage Load Disconnect Contactor Control Switches**



# **13**                      ***Troubleshooting Millennium Systems***

## ***Introduction***

***In This Section***                      This section provides information for locating and interpreting visual indicators to help identify problems in Galaxy Power Systems equipped with the Millennium controller.

***Preparation***                              Read Section 12, *Troubleshooting Preparations*, thoroughly before proceeding.

***Technical Assistance***                      When visual indicators do not identify a defective part, notify the local Regional Technical Assistance Center (RTAC) at 1-800-CAL-RTAC (1-800-225-7822).

## Troubleshooting Tables

### Organization

The tables in this section are organized alphabetically by Alarm LED, then grouped according to the status of the alarm: Critical (CRIT), Major (MAJ), or Minor (MIN).

### Table Reference


Use the reference below to locate the Alarm LED and corresponding table.

Alarm LED	Table
AC	13-A, AC Alarms
BATT	13-B, Battery Alarms
BD	13-F, Miscellaneous Alarms
CTRL	13-C, Controller Alarms
DIST	13-D, Distribution Alarms
RECT	13-E, Rectifier Related Alarms
RM	13-F, Miscellaneous Alarms
No LED*	13-F, Miscellaneous Alarms

\*If an alarm condition exists, but no alarm LED is lit, refer to Table 13-F.

### Millennium Display Reference

The Millennium display is illustrated below for quick reference while using the troubleshooting tables.



**AC Alarm LED**

**Table 13-A: AC Alarms**  
(See Figure 12-8)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
AC	MIN	AC Fail	ACF on rectifier display	Rectifier is not receiving ac power: <ul style="list-style-type: none"> <li>•AC input circuit breaker has operated.</li> <li>•AC input voltage is out of range.</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that ac circuit breaker is closed; close circuit breaker if operated.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>
AC	MIN	Engine Transfer Timeout	Engine may have alarm.	Remote engine or connection to engine has failed.	Call your local RTAC representative.
AC	MIN	Phase Alarm	PF on rectifier display	Phase failure: <ul style="list-style-type: none"> <li>•Rectifier high voltage shutdown</li> <li>•External phase imbalance or failure</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>

**BATT Alarm LED**

**Table 13-B: Battery Alarms**  
(See Figure 12-7)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
BATT	CRIT	Very Low Voltage	--	Occurs in an operating system following an extended commercial ac power outage, during which the batteries are providing power for the system and the system voltage is approaching the user-defined low limit.	<ol style="list-style-type: none"> <li>1. If commercial ac power is present but the system voltage remains low, call your local RTAC representative.</li> <li>2. Investigate other alarms that may be present (rectifier-related alarms and the AC Fail alarm may also occur during the fault condition).</li> </ol>
BATT* *Alarm must be configured to turn on the BATT LED; not a factory default.	MAJ	Contactora 1 Open	Red LED on contactora drive board is lit.	Contactora is open: •Open has been initiated by controller. •Open has been initiated manually.	<ol style="list-style-type: none"> <li>1. Follow instructions on the label adjacent to the contactora drive board (see Figure 12-7).</li> <li>2. If the problem is not corrected, call your local RTAC representative.</li> </ol>
BATT* *Alarm must be configured to turn on the BATT LED; not a factory default.	MAJ	Contactora 1 Fail	--	Contactora or drive board has failed.	Call your local RTAC representative.
BATT	MIN	Open String	Alarm LED on battery fuse panel is lit.	Battery fuse has operated or bat string switch has opened..	Replace the operated fuse.
BATT	MIN	Low Reserve Time	--	Controller has calculated that battery reserve time is below the alarm threshold level.	Call your local RTAC representative.

**Table 13-B: Battery Alarms**  
(See Figure 12-7)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
BATT	MIN	Battery Thermal Alarm	Alarm on 210E unit, if equipped	Batteries have exceeded temp threshold	<ul style="list-style-type: none"><li>•Check room ambient temperature against battery temperature threshold</li><li>•Call your local RTAC representative</li></ul>

**CTRL Alarm LED**

**Table 13-C: Controller Alarms**  
(See Figures 12-2 and 12-3)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
CTRL	MAJ	Controller Fail	--	<ul style="list-style-type: none"> <li>•<b>BSH failure</b>→</li> <li>•BSJ failure</li> <li>•Option board failure</li> <li>•Display failure</li> <li>•BIC failure</li> </ul>	<p>Check the BSH board to see if the green LED is extinguished and the yellow LED is lit. If so, perform the following steps:</p> <ol style="list-style-type: none"> <li>1. Press the SW200 reset switch on the top of the BSH board. If all diagnostics pass, it is possible that some type of “one time” abnormality occurred to cause the failure.</li> <li>2. If the diagnostics did not pass, or if the problem recurs, unplug all the optional circuit board cables, then press the reset switch on the top of the BSH board again. If all the diagnostics pass, install optional circuit board cables one at a time, verifying operation after each.</li> <li>3. If the diagnostics did not pass, Replace the BSH board and verify the failure is resolved. If so, reinstall the optional circuit boards and cables one at a time.</li> <li>4. If the problem is not corrected, call your local RTAC representative.</li> </ol>

**Table 13-C: Controller Alarms**  
(See Figures 12-2 and 12-3)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
CTRL	MAJ	Controller Fail	--	<ul style="list-style-type: none"> <li>•BSH failure</li> <li>•<b>BSJ failure</b>→</li> <li>•Option board failure</li> <li>•Display failure</li> <li>•BIC failure</li> </ul>	<p>Check the BSJ board to see if the green LED is extinguished and the yellow LED is lit. If so, perform the following steps:</p> <ol style="list-style-type: none"> <li>1. Press the SW201 reset switch on the top of the BSJ board. (This circuit has an automatic restart which will try three times to restart the microprocessor.)</li> <li>2. If the diagnostics did not pass, or if the problem recurs, remove all the optional circuit board cables, then press the reset switch on the top of the BSJ board again. If all the diagnostics pass, install optional circuit board cables one at a time, verifying operation after each.</li> <li>3. If the diagnostics did not pass, replace the BSJ board and verify the failure is resolved. If so, reinstall the optional circuit boards and cables one at a time.</li> <li>4. If the problem is not corrected, call your local RTAC representative.</li> </ol>

**Table 13-C: Controller Alarms**  
(See Figures 12-2 and 12-3)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
CTRL	MAJ	Controller Fail	--	<ul style="list-style-type: none"> <li>•BSH failure</li> <li>•BSJ failure</li> <li>•<b>Option board failure</b>→</li> <li>•Display failure</li> <li>•BIC failure</li> </ul>	<p>Check the option boards (modem and data switch) to see if the green LED is extinguished and the yellow LED is lit. If so, perform the following steps:</p> <ol style="list-style-type: none"> <li>1. Press the SW201 reset switch on the top of the BSJ board. (This circuit has an automatic restart which will try three times to restart the microprocessor.) If the BSJ is not present, press the reset switch on the top of the BSH board.</li> <li>2. If the diagnostics did not pass, or if the problem recurs, replace the failed option board.</li> </ol>
CTRL	MAJ	Controller Fail	--	<ul style="list-style-type: none"> <li>•BSH failure</li> <li>•BSJ failure</li> <li>•Option board failure</li> <li>•<b>Display failure</b>→</li> <li>•BIC failure</li> </ul>	<p>If the front panel LCD module, LEDs, or switches fail, perform the following steps:</p> <ol style="list-style-type: none"> <li>1. Verify that the ribbon cable from the BSH board to the display is not cut, abraded, or otherwise mangled. Replace the cable if damaged.</li> <li>2. Press SW200 to reset the BSH board.</li> <li>3. If the LCD module is still not operating, replace the LCD module; if the switches and LEDs are still not operating, replace the BSH board.</li> </ol>

**Table 13-C: Controller Alarms**  
(See Figures 12-2 and 12-3)

Controller LED	Controller Alarm Status	Millennium Controller Display	Other Indication(s)	Possible Problem(s)	Possible Solution(s)
CTRL	MAJ	Controller Fail	--	<ul style="list-style-type: none"> <li>•BSH failure</li> <li>•BSJ failure</li> <li>•Option board failure</li> <li>•Display failure</li> <li>•<b>BIC failure</b>→</li> </ul>	<ol style="list-style-type: none"> <li>1. Strap K1, K2, K3 on BLJ3 from "C" to "R" prior to replacing BIC. See Figure 8-2.</li> <li>2. Replace BIC.</li> </ol>
CTRL	MAJ	Circuit Pack Fail	--	See "Controller Fail".	See "Controller Fail".
CTRL	MAJ	Controller Fuse	--	Fuse has operated.	Replace the controller fuse labeled F2 (intelligent power).
CTRL	MAJ	Alarm Battery Supply Fuse	--	Fuse has operated.	Replace the controller fuse labeled F5 (alarm battery supply).
CTRL	MAJ	Remote Peripheral Fuse	--	Fuse has operated.	Replace the controller fuse labeled F1 (option power).
CTRL	MAJ	Sense/Control Fuse	--	Fuse has operated.	Replace the controller fuse labeled F4 (voltage sense).
CTRL	MAJ	Bay Interface ID Conflict	--	Two or more bay interface cards (BICs) have the same ID number.	Following instructions printed on the label over the BIC, adjust the DIP switches to change the ID number.
CTRL	MAJ	Major Communication Fail Alarm	Blinking ALM LED on rectifiers or red LED on BIC	Loss of communication with controller: <ul style="list-style-type: none"> <li>•Defective interface from BIC or multiple rectifiers to controller</li> <li>•Internal failure of controller, BIC, or multiple rectifiers</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that the controller is powered and operating correctly.</li> <li>2. If there are no controller alarms, replace the equipment that has lost communication.</li> </ol> <ul style="list-style-type: none"> <li>•If the problem is not corrected, call your local RTAC representative.</li> </ul>

**Table 13-C: Controller Alarms**  
 (See Figures 12-2 and 12-3)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
CTRL	MIN	Minor Communication Fail Alarm	Blinking ALM LED on rectifier	Loss of communication with controller: <ul style="list-style-type: none"> <li>•Defective interface from rectifier to controller</li> <li>•Internal controller or rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that the controller is powered and operating correctly.</li> <li>2. If there are no controller alarms, replace the equipment that has lost communication.</li> </ol> <ul style="list-style-type: none"> <li>•If the problem is not corrected, call your local RTAC representative.</li> </ul>
CTRL	MIN	Self Fail Test	--	See "Controller Fail".	See "Controller Fail".
CTRL	MIN	Thermal Probe Failure	--	Battery thermal probe has failed.	Call your local RTAC representative.

***DIST Alarm LED***

**Table 13-D: Distribution Alarms**  
(See Figures 12-9 and 12-10)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
DIST	MAJ	External Fuse Major	Alarm LED on dc distribution panel is lit.	DC load fuse or circuit breaker has operated.	Replace fuse or reset circuit breaker.
DIST* *Alarm must be configured to turn on the DIST LED; not a factory default.	MAJ	Contactors 2 (or 3) Open	Red LED on contactor drive board is lit.	Contactors are open: •Open has been initiated by controller. •Open has been initiated manually.	1. Follow instructions on the label adjacent to the contactor drive board (see Figure 12-10). 2. If the problem is not corrected, call your local RTAC representative.
DIST* *Alarm must be configured to turn on the DIST LED; not a factory default.	MAJ	Contactors 2 (or 3) Fail	--	Contactors or drive board has failed.	Call your local RTAC representative.

**RECT Alarm LED**

**Table 13-E: Rectifier Related Alarms**  
(See Figures 12-6 and 12-8)

Controller LED	Controller Alarm Status	Millennium Controller Display	Rectifier LED	Rectifier Display	Possible Problem(s)	Possible Solution(s)
RECT	MAJ	ID Not Configured	None	None	Rectifier ID number has not been set.	<ol style="list-style-type: none"> <li>1. Press ON/STBY switch up and hold for five seconds until display starts blinking "0".</li> <li>2. Release switch; display should continue to blink.</li> <li>3. Depress switch and release. Display will increment up one number on each release of the switch, but will remain flashing.</li> <li>4. Once the desired ID number appears, depress and hold the switch for five seconds. The display will cease to blink, and then revert to the rectifier current.</li> </ol>
RECT	MAJ	ID Conflict	None	None	Two or more rectifiers have the same ID number.	See above.
RECT	MAJ	Multiple Rectifier Fail	ALM	None	More than one rectifier has an ALM LED lit.	See alarms listed below.
RECT	MAJ	High Voltage Alarm	ALM	HO	<ul style="list-style-type: none"> <li>•Lightning has struck system.</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>

**Table 13-E: Rectifier Related Alarms**  
(See Figures 12-6 and 12-8)

Controller LED	Controller Alarm Status	Millennium Controller Display	Rectifier LED	Rectifier Display	Possible Problem(s)	Possible Solution(s)
RECT	MIN	Rectifier Fail	ALM	HO	High output voltage: <ul style="list-style-type: none"> <li>•Rectifier high voltage shutdown</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify the configurable HV thresholds in the controller.</li> <li>2. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>3. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	Rectifier Fail	ALM	TA	Thermal alarm: <ul style="list-style-type: none"> <li>•Excessive ambient temperature</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that there is no obstruction of the fan inlet.</li> <li>2. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>3. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	Rectifier Fail	ALM	CB	Circuit breaker alarm: <ul style="list-style-type: none"> <li>•DC output circuit breaker open</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position; toggle the DC output circuit breaker into the OFF position and then into the ON position. Return the ON/STBY switch to the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>

**Table 13-E: Rectifier Related Alarms**  
(See Figures 12-6 and 12-8)

Controller LED	Controller Alarm Status	Millennium Controller Display	Rectifier LED	Rectifier Display	Possible Problem(s)	Possible Solution(s)
RECT	MIN	Rectifier Fail	ALM	ICS IP5 IP6 IP7	Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Place the ac circuit breaker for the rectifier in the OFF position.</li> <li>2. Remove the rectifier from the shelf.</li> <li>3. Wait for 30 seconds or until all front panel display LEDs have extinguished.</li> <li>4. Replace the rectifier.</li> <li>5. Return the ac breaker to the ON position.</li> <li>6. Place the rectifier ON/STBY switch into the ON position.</li> <li>7. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	Rectifier Fail	ALM	FSE	Fuse alarm: •DC fuse open •Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	Rectifier Fail	ALM	LO	Low output voltage: •Excessive output current •Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>

**Table 13-E: Rectifier Related Alarms**  
(See Figures 12-6 and 12-8)

Controller LED	Controller Alarm Status	Millennium Controller Display	Rectifier LED	Rectifier Display	Possible Problem(s)	Possible Solution(s)
RECT	MIN	Rectifier Fail	ALM	SEN	Thermal sensor failure: •Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Place the ac circuit breaker for the rectifier in the OFF position.</li> <li>2. Remove the rectifier from the shelf.</li> <li>3. Wait for 30 seconds or until all front panel display LEDs have extinguished.</li> <li>4. Replace the rectifier.</li> <li>5. Return the ac breaker to the ON position.</li> <li>6. Place the rectifier ON/STBY switch into the ON position.</li> <li>7. If the problem is not corrected, replace the rectifier with a new one.</li> </ol>
RECT	MIN	Rectifier Fail	FAN ALM	None	Fan failure	Replace the fan in the rectifier.
RECT	MIN	Manual Off	STBY	Blank	Rectifier has been manually turned off.	Turn rectifier on.
RECT	MIN	External Transfer Shutdown	STBY	TR	System is operating on external engine.	No action required.
RECT	MIN	High Float Voltage	None	None	Configuration problem	Call your local RTAC representative.
RECT	MIN	Excess Rectifier Drain	None	None	Internal rectifier fault	Replace rectifier.
RECT	MIN	Excess System Drain	None	None	System load exceeds shunt rating.	Call your local RTAC representative.

**Table 13-E: Rectifier Related Alarms**  
(See Figures 12-6 and 12-8)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Rectifier LED</b>	<b>Rectifier Display</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
RECT	MIN	Limited Recharge	None	None	Rectifier capacity has been exceeded.	Install more rectifiers.
RECT	MIN	External Transfer Shutdown	STBY	TR	System is operating on external engine.	No action required.

**BD and RM Alarm LEDs, or No LED**

**Table 13-F: Miscellaneous Alarms**

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Millennium Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
BD	MAJ	Battery on Discharge	Rectifiers may say ACF.	Temporary condition that may be associated with other alarms	Call your local RTAC representative.
RM	MIN	Module Failure	Green LED on RPM will not blink.	Remote Peripheral Module has failed.	Call your local RTAC representative.
RM	MIN	Measurement Out of Range	--	<ul style="list-style-type: none"> <li>•Data being sensed exceeds remote peripheral module's capability.</li> <li>•Remote peripheral module has failed.</li> </ul>	Call your local RTAC representative.
None	MAJ	Auxiliary Major	Auxiliary equipment may have alarm.	Problem with operation of auxiliary equipment	Call your local RTAC representative.
None	MIN	Auxiliary Minor	Auxiliary equipment may have alarm.	Problem with operation of auxiliary equipment	Call your local RTAC representative.
None	None	None	<ul style="list-style-type: none"> <li>•STBY LED on rectifier is lit.</li> <li>•TR on rectifier display</li> </ul>	Remote transfer: <ul style="list-style-type: none"> <li>•Rectifier is in STBY.</li> </ul>	Remove the remote standby command issued by the controller.
None	None	None	Red LED is lit on some battery contactor drive boards, while green LED is lit on others.	If a green LED is lit despite a contactor open command issued by the controller, the drive card or the contactor has failed.	Call your local RTAC representative.



# ***14 Troubleshooting Vector Systems***

## ***Introduction***

***In This Section*** This section provides information for locating and interpreting visual indicators to help identify problems in Galaxy Power Systems equipped with the Vector controller.

***Preparation*** Read Section 12, *Troubleshooting Preparations*, thoroughly before proceeding.

***Technical Assistance*** When visual indicators do not identify a defective part, notify the local Regional Technical Assistance Center (RTAC) at 1-800-CAL-RTAC (1-800-225-7822).

## Troubleshooting Tables

### Organization

The tables in this section are organized alphabetically by Alarm LED, then grouped according to the status of the alarm, Major (MAJ) or Minor (MIN).


### Table Reference

Use the reference below to locate the Alarm LED and corresponding table.

Alarm LED	Table
AC	14-A, AC Alarms
BATT	14-B, Battery Alarms
BD	14-F, Miscellaneous Alarms
CTRL	14-C, Controller Alarms
DIST	14-D, Distribution Alarms
RECT	14-E, Rectifier Related Alarms
No LED*	14-F, Miscellaneous Alarms
*If an alarm condition exists, but no alarm LED is lit, refer to Table 14-F.	

### Vector Display Reference

The Vector front display is shown below for quick reference while using the troubleshooting tables.



**AC Alarm LED**

**Table 14-A: AC Alarms**  
(See Figure 12-8)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Vector Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
AC	MAJ	nACF	ACF on rectifier display	Rectifier(s) not receiving ac power: <ul style="list-style-type: none"> <li>•AC input circuit breaker has operated.</li> <li>•AC input voltage is out of range.</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that ac circuit breaker is closed; close circuit breaker if operated.</li> <li>2. If the problem is not corrected, replace the rectifier(s).</li> </ol>
AC	MIN	ACF	ACF on rectifier display	Rectifier not receiving ac power: <ul style="list-style-type: none"> <li>•AC input circuit breaker has operated.</li> <li>•AC input voltage is out of range.</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that ac circuit breaker is closed; close circuit breaker if operated.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>
AC	MIN	ACF	PF on rectifier display	Phase failure: <ul style="list-style-type: none"> <li>•Rectifier high voltage shutdown</li> <li>•External phase imbalance or failure</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>

**BATT Alarm LED**

**Table 14-B: Battery Alarms**  
(See Figure 12-7)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Vector Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
BATT	MAJ	LLO	--	Occurs in an operating system following an extended commercial ac power outage, during which the batteries are providing power for the system and the system voltage is approaching the user-defined low limit.	<ol style="list-style-type: none"> <li>1. If commercial ac power is present but the system voltage remains low, call your local RTAC representative.</li> <li>2. Investigate other alarms that may be present (rectifier-related alarms and the AC Fail alarm may also occur during the fault condition).</li> </ol>
BATT	MAJ	C1O	Red LED on contactor drive board is lit.	Contactor is open: <ul style="list-style-type: none"> <li>•Open has been initiated by controller.</li> <li>•Open has been initiated manually.</li> </ul>	<ol style="list-style-type: none"> <li>1. Follow instructions on the label adjacent to the contactor drive board (see Figure 12-7).</li> <li>2. If the problem is not corrected, call your local RTAC representative.</li> </ol>
BATT	MAJ	C1F	--	Contactor or drive board has failed.	Call your local RTAC representative.
BATT	MAJ	bta	Alarm on 210E unit, if equipped	Batteries have exceeded temperature threshold.	Call your local RTAC representative.

**CTRL Alarm LED**

**Table 14-C: Controller Alarms**  
(See Figures 12-4 and 12-5)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Vector Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
CTRL	MAJ	None	--	•Controller failure	Check controller to see if the green LED is extinguished and the red LED is lit. If so, perform the following steps:  <ol style="list-style-type: none"> <li>1. Remove and reset the controller circuit board. If all diagnostics pass, it is possible that some type of “one time” abnormality occurred to cause the failure.</li> <li>2. If the diagnostics did not pass, Replace the controller circuit board and verify the failure is resolved.</li> <li>3. If the problem is not corrected, call your local RTAC representative.</li> </ol>
CTRL	MAJ	None	--	•Controller failure •Display failure	If the front panel LED module, LEDs, or switches fail, perform the following steps:  <ol style="list-style-type: none"> <li>1. Verify that the ribbon cable from the controller board to the BMW display is not cut, abraded, or otherwise mangled. Replace the cable if damaged.</li> <li>2. Reset the controller board.</li> <li>3. If the display is still not operating, replace the display module.</li> </ol>
CTRL	MIN	tPA	--	Battery thermal probe has failed.	Call your local RTAC representative.

***DIST Alarm LED***

**Table 14-D: Distribution Alarms**  
(See Figures 12-9 and 12-10)

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Vector Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
DIST	MAJ	C2O	Red LED on contactor drive board is lit.	Contactor is open: <ul style="list-style-type: none"> <li>•Open has been initiated by controller.</li> <li>•Open has been initiated manually.</li> </ul>	<ol style="list-style-type: none"> <li>1. Follow instructions on the label adjacent to the contactor drive board (see Figure 12-10).</li> <li>2. If the problem is not corrected, call your local RTAC representative.</li> </ol>
DIST	MAJ	C2F	--	Contactor or drive board has failed.	Call your local RTAC representative.
DIST	MAJ	FAJ	Alarm LED on dc distribution panel is lit.	DC load fuse or circuit breaker has operated.	Replace fuse or reset circuit breaker.
DIST	MAJ	FAJ	--	Fuse has operated.	Replace the controller fuse labeled F2 (alarm battery supply).

**RECT Alarm LED**

**Table 14-E: Rectifier Related Alarms**

<b>Rectifier Related Alarms</b> (See Figures 12-6 and 12-8)						
<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Vector Controller Display</b>	<b>Rectifier LED</b>	<b>Rectifier Display</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
RECT	MAJ	rid	None	None	Rectifier ID number has not been set.	<ol style="list-style-type: none"> <li>1. Press ON/STBY switch up and hold for five seconds until display starts blinking "0".</li> <li>2. Release switch; display should continue to blink.</li> <li>3. Depress switch and release. Display will increment up one number on each release of the switch, but will remain flashing.</li> <li>4. Once the desired ID number appears, depress and hold the switch for five seconds. The display will cease to blink, and then revert to the rectifier current.</li> </ol>
RECT	MAJ	rid	None	None	Two or more rectifiers have the same ID number.	See above.
RECT	MAJ	nrFA	ALM	None	More than one rectifier has an ALM LED lit.	See rectifier alarms listed below.

**Table 14-E: Rectifier Related Alarms**

<b>Rectifier Related Alarms</b> (See Figures 12-6 and 12-8)						
<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Vector Controller Display</b>	<b>Rectifier LED</b>	<b>Rectifier Display</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
RECT	MAJ	nrFA	--	--	Loss of communication with controller: <ul style="list-style-type: none"> <li>•Defective interface from multiple rectifiers to controller</li> <li>•Internal failure of controller or multiple rectifiers</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that the controller is powered and operating correctly.</li> <li>2. If there are no controller alarms, replace rectifiers that have lost communication.</li> <li>3. If the problem is not solved, call your local RTAC representative.</li> </ol>
RECT	MAJ	HO	ALM	HO	<ul style="list-style-type: none"> <li>•Lightning has struck system.</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	rFA	Blinking ALMLED on rectifier	--	Loss of communication with controller: <ul style="list-style-type: none"> <li>•Defective interface from rectifier to controller</li> <li>•Internal controller or rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Verify that the controller is powered and operating correctly.</li> <li>2. If there are no controller alarms, replace the rectifier.</li> <li>3. If the problem is not corrected, call your local RTAC representative.</li> </ol>

**Table 14-E: Rectifier Related Alarms**

<b>Rectifier Related Alarms</b> (See Figures 12-6 and 12-8)						
<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Vector Controller Display</b>	<b>Rectifier LED</b>	<b>Rectifier Display</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
RECT	MIN	rFA	ALM	HO	High output voltage: •Rectifier high voltage shutdown •Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Verify the configurable HV thresholds in the controller.</li> <li>2. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>3. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	rFA	ALM	TA	Thermal alarm: •Excessive ambient temperature •Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Verify that there is no obstruction of the fan inlet.</li> <li>2. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>3. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	rFA	ALM	FSE	Fuse alarm: •DC fuse open •Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>

**Table 14-E: Rectifier Related Alarms**

<b>Rectifier Related Alarms</b> (See Figures 12-6 and 12-8)						
<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Vector Controller Display</b>	<b>Rectifier LED</b>	<b>Rectifier Display</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
RECT	MIN	rFA	ALM	LO	Low output voltage: <ul style="list-style-type: none"> <li>•Excessive output current</li> <li>•Internal rectifier failure</li> </ul>	<ol style="list-style-type: none"> <li>1. Toggle the ON/STBY switch into the STBY position and then back into the ON position.</li> <li>2. If the problem is not corrected, replace the rectifier.</li> </ol>
RECT	MIN	rFA	ALM	ICS IP5 IP6 IP7	Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Place the ac circuit breaker for the rectifier in the OFF position.</li> <li>2. Remove the rectifier from the shelf.</li> <li>3. Wait for 30 seconds or until all front panel display LEDs have extinguished.</li> <li>4. Replace the rectifier.</li> <li>5. Return the ac breaker to the ON position.</li> <li>6. Place the rectifier ON/STBY switch into the ON position.</li> <li>7. If the problem is not corrected, replace the rectifier.</li> </ol>

**Table 14-E: Rectifier Related Alarms**

<b>Rectifier Related Alarms</b> (See Figures 12-6 and 12-8)						
<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Vector Controller Display</b>	<b>Rectifier LED</b>	<b>Rectifier Display</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
RECT	MIN	rFA	ALM	SEN	Thermal sensor failure: •Internal rectifier failure	<ol style="list-style-type: none"> <li>1. Place the ac circuit breaker for the rectifier in the OFF position.</li> <li>2. Remove the rectifier from the shelf.</li> <li>3. Wait for 30 seconds or until all front panel display LEDs have extinguished.</li> <li>4. Replace the rectifier.</li> <li>5. Return the ac breaker to the ON position.</li> <li>6. Place the rectifier ON/STBY switch into the ON position.</li> <li>7. If the problem is not corrected, replace the rectifier with a new one.</li> </ol>
RECT	MIN	rFA	FAN ALM	None	Fan failure	Replace the fan in the rectifier.
RECT	MIN	rOFF	STBY	Blank	Rectifier has been manually turned off.	Turn rectifier on.
RECT	MIN	HFO	None	None	Configuration problem	Call your local RTAC representative.

***BD Alarm LED or  
No LED***

**Table 14-F: Miscellaneous Alarms**

<b>Controller LED</b>	<b>Controller Alarm Status</b>	<b>Vector Controller Display</b>	<b>Other Indication(s)</b>	<b>Possible Problem(s)</b>	<b>Possible Solution(s)</b>
BD	MAJ	bod	Rectifiers may say ACF.	Temporary condition that may be associated with other alarms	Call your local RTAC representative.
None	MAJ	AUJ	Auxiliary equipment may have alarm.	Problem with operation of auxiliary equipment	Call your local RTAC representative.
None	None	None	Red LED is lit on some battery contactor drive boards, while green LED is lit on others.	If a green LED is lit despite a contactor open command issued by the controller, the drive card or the contactor has failed.	Call your local RTAC representative.
None	None	None	--	Fuse has operated.	Replace the controller fuse labeled F1 (power).

# ***15 Product Warranty***

A. Seller warrants to Customer only, that:

1. As of the date title to Products passes, Seller will have the right to sell, transfer, and assign such Products and the title conveyed by Seller shall be good;
2. Upon shipment, Seller's Manufactured Products will be free from defects in material and workmanship, and will conform to Seller's specifications or any other agreed-upon specification referenced in the order for such Product;
3. With respect to Vendor items, Seller, to the extent permitted, does hereby assign to Customer the warranties given to Seller by its Vendor of such Vendor Items, such assignment to be effective upon Customer's acceptance of such Vendor Items. With respect to Vendor items recommended by Seller in its specifications for which the Vendor's warranty cannot be assigned to Customer, or if assigned, less than Sixty (60) days remain of the Vendor's warranty or warranty period when the Vendor's items are shipped to Customer or when Seller submits its notice of completion of installation if installed by Seller, Seller warrants that such Vendor's items will be free from defects in material and workmanship on the date of shipment to Customer. In such an event, the applicable Warranty Period will be sixty (60) days.

B. The Warranty Period listed below is applicable to Seller's Manufactured Products furnished pursuant to this Agreement, unless otherwise stated:

**Warranty Period**

<b>Product Type</b>	<b>New Product</b>	<b>Repaired Product or Part*</b>
Central Office Power Equipment**	24 Months	6 Months

\*The Warranty Period for a repaired Product or part thereof is as listed or, in the case of Products under Warranty, is the period listed or the unexpired term of the new Product Warranty Period, whichever is longer.

\*\*The Warranty Period for Products ordered for Use in Systems or Equipment Manufactured by and furnished by Seller is that of the initial Systems or equipment.

- C. If, under normal and proper use during the applicable Warranty Period, a defect or nonconformity is identified in a Product and Customer notifies Seller in writing of such defect or nonconformity promptly after Customer discovers such defect or nonconformity, and follows Seller's instructions regarding return of defective or nonconforming Products, Seller shall, at its option attempt first to repair or replace such Product without charge at its facility or, if not feasible, provide a refund or credit based on the original purchase price and installation charges if installed by Seller. Where Seller has elected to repair a Seller's Manufactured Product (other than Cable and Wire Products) which has been installed by Seller and Seller ascertains that the Product is not readily returnable for repair, Seller will repair the Product at Customer's site.

With respect to Cable and Wire Products manufactured by Seller which Seller elects to repair but which are not readily returnable for repair, whether or not installed by Seller, Seller at its option, may repair the cable and Wire Products at Customer's site.

- D. If Seller has elected to repair or replace a defective Product, Customer shall have the option of removing and reinstalling or having Seller remove and reinstall the defective or nonconforming Product. The cost of the removal and the reinstallation shall be borne by Customer. With respect to Cable and Wire Products, Customer has the further responsibility, at its expense, to make the Cable and Wire Products accessible for repair or replacement and to restore the site. Products returned for repair or replacement will be accepted by Seller only in accordance with its instructions and procedures for such returns. The transportation expense associated with returning such Product to Seller shall be borne by Customer.

Seller shall pay the cost of transportation of the repair or replacing Product to the destination designated by Customer within the Territory.

- E. The defective or nonconforming Products or parts which are replaced shall become Seller's property.
- F. If Seller determines that a Product for which warranty service is claimed is not defective or nonconforming, Customer shall pay Seller all costs of handling, inspecting, testing, and transportation and, if applicable, traveling and related expenses.
- G. Seller makes no warranty with respect to defective conditions or nonconformities resulting from actions of anyone other than Seller or its subcontractors, caused by any of the following: modifications, misuse, neglect, accident, or abuse; improper wiring, repairing, splicing, alteration, installation, storage, or maintenance; use in a manner not in accordance with Seller's or Vendor's specifications or operating instructions, or failure of Customer to apply previously applicable Seller modifications and corrections. In addition, Seller makes no warranty with respect to Products which have had their serial numbers or month and year of manufacture removed, altered, or with respect to expendable items, including, without limitation, fuses, light bulbs, motor brushes, and the like.

THE FOREGOING WARRANTIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. CUSTOMER'S SOLE AND EXCLUSIVE REMEDY SHALL BE SELLER'S OBLIGATION TO REPAIR, REPLACE, CREDIT, OR REFUND AS SET FORTH ABOVE IN THIS WARRANTY.

© 2000 Lucent Technologies  
All Rights Reserved  
Printed in U.S.A.

