
E2A TELEMETRY SWITCHING CONTROL CENTER CENTRAL AND REMOTE MAINTENANCE

This section provides the maintenance procedures for the E2A telemetry equipment used in Switching Control Center Systems (SCCS). This issue contains maintenance information for the No. 1 Electronic Switching System (No. 1 ESS), No. 2B/3 ESS, No. 2 ESS/Automatic Intercept System (No. 2 ESS/AIS), the Traffic Service Position System (TSPS), and the No. 1A ESS. The procedures include tests for the critical indicator (CI) central, the command and display (C&D) central, the telemetry computer translator (TCT), and the E2A remotes at the central offices.

This section is reissued to include information on the TCT and the No. 1A ESS. Since this is a general revision, arrows ordinarily used to indicate changes have been omitted.

When a step-procedure chart refers to a table, ensure that the table referred to is for the system being maintained. See Table A for a list of the systems being maintained by this section and the associated table.

CHART	PAGE
1—CI Central Testing and Maintenance (A and B Cabinets)	1
2—C&D Central Group Report Command Troubleshooting	5
3—C&D Central Relay Output Command Troubleshooting	10
4—TCT Replacement	14
5—Remote Status Point Maintenance	15
6—Remote Relay Output Maintenance	18

CHART 1

CI CENTRAL TESTING AND MAINTENANCE (A and B Cabinets)

Maintenance of the CI central (J92621-D) is accomplished through the use of the E-telemetry station test set and the critical indicator panels (CIPs) at the SCC. Chart 1 presents a step-procedure method of performing the maintenance of the CI central (A and B cabinets). This test assumes that the CIPs and the wiring from the CI central to the CIPs are in proper operating condition. Before starting the test, check all lamps on each CIP by operating the lamp test switch located on the

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement

CHART 1 (Contd)

bottom of each CIP. Operate only one switch at a time, then reset before operating next panel. ***If this is not done, a fuse may blow.*** If any lamps do not light, replace before proceeding.

APPARATUS:

- E-telemetry station test set (KS-20937, L1)
 - General purpose plug-in (KS-20937, L4)
 - E2A test cable (KS-20937, L6)
 - Volt-ohm-milliammeter (KS-14510, L1), or equivalent
-

STEP**PROCEDURE**

Note: Before any testing of the central unit is begun, set all switches in the SCC equipment to the audible off position. Ensure that the +5, +15, and -15 Vdc power sources are being supplied to the unit on the TSA terminal strip.

Caution: *Remove power before removing or replacing any circuit pack.*

- 1 On the 202T data set, depress and hold the LT (local test) key for approximately 15 seconds.

Requirement: The MR, RS, CS, CO, and TM lamps will light and remain lighted for the duration of time that the LT key is depressed. If the TM lamp goes off during the 15-second period, repeat this step four additional times. If the TM lamp continues to go off, replace the data set and repeat the test.

- 2 Once the original data set or the new data set has met the requirement in Step 1, ensure that the following options in the data set are set as indicated and as listed in the associated applications schematic.

CHART 1 (Contd)

STEP	PROCEDURE																											
	<table border="0"> <thead> <tr> <th></th> <th>FEATURE OPTION</th> <th>SETTING*</th> </tr> </thead> <tbody> <tr> <td>1.</td> <td>4-wire operation</td> <td>(FF)</td> </tr> <tr> <td>2.</td> <td>Soft turnoff and squelch intervals</td> <td>O, O</td> </tr> <tr> <td>3.</td> <td>Fast-carrier detection—in</td> <td>(FF)</td> </tr> <tr> <td>4.</td> <td>Clear-to-send interval—8 ms</td> <td>(FF)</td> </tr> <tr> <td>5.</td> <td>Clamp—in</td> <td>(FF)</td> </tr> <tr> <td>6.</td> <td>Carrier detection—in</td> <td></td> </tr> <tr> <td>7.</td> <td>Continuous carrier—out</td> <td>(FF)</td> </tr> <tr> <td>8.</td> <td>Grounding option—signal ground not connected to frame ground</td> <td></td> </tr> </tbody> </table> <p>* (FF) indicates factory furnished</p>		FEATURE OPTION	SETTING*	1.	4-wire operation	(FF)	2.	Soft turnoff and squelch intervals	O, O	3.	Fast-carrier detection—in	(FF)	4.	Clear-to-send interval—8 ms	(FF)	5.	Clamp—in	(FF)	6.	Carrier detection—in		7.	Continuous carrier—out	(FF)	8.	Grounding option—signal ground not connected to frame ground	
	FEATURE OPTION	SETTING*																										
1.	4-wire operation	(FF)																										
2.	Soft turnoff and squelch intervals	O, O																										
3.	Fast-carrier detection—in	(FF)																										
4.	Clear-to-send interval—8 ms	(FF)																										
5.	Clamp—in	(FF)																										
6.	Carrier detection—in																											
7.	Continuous carrier—out	(FF)																										
8.	Grounding option—signal ground not connected to frame ground																											
	<table border="0"> <tbody> <tr> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> <td>7</td> <td>8</td> <td>9</td> <td>0</td> </tr> <tr> <td>0</td> <td>0</td> <td>x</td> <td>x</td> <td>0</td> <td>0</td> <td>0</td> <td>x</td> <td>x</td> <td>x</td> </tr> </tbody> </table>	1	2	3	4	5	6	7	8	9	0	0	0	x	x	0	0	0	x	x	x							
1	2	3	4	5	6	7	8	9	0																			
0	0	x	x	0	0	0	x	x	x																			

3 Once the requirement in Step 1 is met and the proper options are set, there is reasonable assurance that the data set is in proper working condition. Additional problems are probably within the remote circuitry. Steps 4 through 14 isolate the central circuit problems with the data set disconnected.

4 Insert and connect the general purpose plug-in unit into the E-telemetry station test set.

5 Operate the ACO switch on E2A CP 48 to the down position to prevent a local office alarm.

6 Locate and remove plug P1 from the 202T data set at the CI central unit.

CHART 1 (Contd)

STEP	PROCEDURE
	To determine the defective CP(s), replace the original CP(s) back in the central unit one at a time, repeating Step 10 after each replacement, until the unit malfunctions. The last originally installed CP is defective and will be replaced with a spare.
11	Observe the CIP and move switch number 3 in WORD 1, on the general purpose plug-in unit, to the 1 (up) position.
	Requirement: The CRITICAL lamps will light in sequential order on all the CIPs. If the requirement is not met, replace CP 17 and CP 18 and repeat the step.
12	Depress the ALM REL key on the central office select unit (COSJU). This step is only required for latching alarms (see Tables C through I).
13	Return switch number 3 in WORD 1 to the 0 (down) position.
	Requirement: All CRITICAL lamps will go off. If the requirement is not met, replace CP 17 and CP 18 and repeat the step.
14	Repeat the procedures used in Steps 11 through 13 for each remaining switch (4-17) in the appropriate table (Table C, D, E, F, G, H, or I), depending on the system.
	Requirement: The corresponding CIP lamp will light as shown in Table C, D, E, F, G, H, or I. If any part of the above requirement fails, replace CP 17 and CP 18 and repeat the step. Determine the defective CP(s) by replacing the original CP(s) back in the central, one at a time, until the unit malfunctions. The last CP replaced is defective and will be replaced with a spare.
15	Remove the test set, and connect plug P1 to the 202T data set.
16	Operate the ACO switch to the reset position and release.

CHART 2
C&D CENTRAL GROUP REPORT COMMAND TROUBLESHOOTING

The C&D central (J92621-C,P) unit is located within the SCC console [SCC control console type J1C016()]. To check the C&D central unit, it is necessary to ensure that the keys, lamps, and interface to the C&D central unit are in proper operating condition.

Before any tests are initiated, turn the console power switch on, depress the LOC LAMP TEST pushbutton switch, and note any lamps or keys which do not light. Replace defective lamps before proceeding.

CHART 2 (Contd)

Chart 2 describes in detail the equipment needed and the procedure for troubleshooting the group report commands sent by the C&D central unit.

APPARATUS:

- E-telemetry station test set (KS-20937, L1)
 - General purpose plug-in (KS-20937, L4)
 - E2A test cable (KS-20937, L6)
 - Volt-ohm-milliammeter (KS-14510, L1), or equivalent
-

STEP

PROCEDURE

Note: Before starting the step-procedure testing of the central, a preliminary test should be performed as follows: Turn off power to the console. Remove the cover from the console; turn the console power switch to on; and check that the +5, +15, and -15 Vdc power sources are supplied to the C&D central unit on terminal strip TSA. If all the voltages are present, proceed with Step 1. If any voltages are not present, repair or replace the power supply as necessary.

Caution: *Remove power before removing or replacing any circuit pack.*

- 1 On the 202T data set, depress and hold the LT key for approximately 15 seconds.

Requirement: The MR, RS, CS, CO, and TM lamps will light and remain lighted for the duration of time that the LT key is depressed. If the TM lamp goes off during the 15-second period, repeat this step four additional times. If the TM lamp continues to go off, replace the data set and repeat the test.

- 2 Once the original data set or the new data set has met the requirement in Step 1, ensure that the following options in the data set are set as indicated and as listed in the associated applications schematic.

CHART 2 (Contd)

STEP	PROCEDURE
------	-----------

FEATURE OPTION	SETTING*
1. 4-wire operation	(FF)
2. Soft turnoff and squelch intervals	O, O
3. Fast-carrier detection—in	(FF)
4. Clear-to-send interval—8 ms	(FF)
5. Clamp—in	(FF)
6. Carrier detection—in	
7. Continuous carrier—out	(FF)
8. Grounding option—signal ground not connected to frame ground	

* (FF) indicates factory furnished

1	2	3	4	5	6	7	8	9	0
0	0	x	x	0	0	0	x	x	x

- 3 Once the requirement in Step 1 is met and the proper options are set, there is reasonable assurance that the data set is in proper working condition. Additional problems are probably within the remote circuitry. Steps 4 through 16 isolate the central circuit problems with the data set disconnected.
- 4 Set the SCC console POWER switch to the OFF position.
- 5 Insert and connect the general purpose plug-in unit into the E-telemetry station test set.
- 6 Replace the data set card with a good spare card.
- 7 Locate and remove plug P1 from the 202T data set at the central unit.

CHART 2 (Contd)

STEP

PROCEDURE

8 Mate the female pin connector of the E2A test cable to the P1 plug removed in Step 7. Connect the other end of the test cable to the J2 connector on the E-telemetry station test set.

9 Set the controls on the E-telemetry station test set as follows:

SWITCH	POSITION
SYSTEM	E2A
PARITY	B
BIT RATE	1200
MODE	ANSWER
ENABLE	NORMAL
DISPLAY ERROR WORD	OFF
DISPLAY WORD SELECT	1
POWER	OFF
RCU	OFF
MESSAGE LENGTH	16
WORD 1 through WORD 4	1000000000000000

10 Depress the SCC console power switch on.

Requirement 1: The CSL PWR ON lamp will light.

Requirement 2: The TELEMETRY, CENT, and REM lamps may light. If this happens, depress the TLM ALM RLS key. Note, these lamps will relight if the test set has not been turned on.

11 Move the POWER switch on the E-telemetry station test set to the ON (up) position.

12 Depress, in order, the MASTER CLEAR and START pushbuttons.

Requirement: The TMT, RCV, VALID WORD, and WORD 1 through WORD 4 lamps on the E-telemetry station test set will blink; lamps 17, 16, and 13 of the information word will display 000, 001, 010, 100 (17, 16, 13 through 17, 16, 13) in a sequential and cyclic order.

Note: 1—lighted lamp, 0—off lamp.

CHART 2 (Contd)

STEP**PROCEDURE**

If the requirement is not met, replace all of the following circuit packs:

CP 1
CP 2
CP 3
CP 13 or 36
CP 14
CP 15
CP 16

Inspect CP 8 for proper strapping connections per Note 104 of SD-1C540-01-D1. After all of the listed CPs are replaced, determine the defective CP(s) by inserting the original CP(s) back in the central unit one by one. Repeat Step 12 after each replacement until the unit malfunctions. The last originally installed CP is defective and will be replaced with a spare.

- 13 Depress the TLM ALM RLS key. The CENT and REM TELEMETRY lights will go out.
- 14 On the E-telemetry station test set, set switch 2 of WORD 1 to the 1 (up) position.

Requirement: The console lamps designated per Table J, K, or L (depending on system) will light. If no lamp lights, replace CP 18 and repeat the step. If any part of the requirement is not met, replace CP 17 in the location(s) specified by the appropriate table for the unlighted lamp(s).

- 15 Return switch 2 of WORD 1 to the 0 (down) position.

Requirement: The console lamps designated per Table J, K, or L (depending on system) will go off. If the requirement is not met, replace CP 17 in the location specified by the appropriate table and repeat the step.

- 16 Repeat the procedures used in Steps 14 and 15 for each switch (2-17) in WORD 1 through WORD 4 per Table J, K, or L (depending on system).

CHART 3

C&D CENTRAL RELAY OUTPUT COMMAND TROUBLESHOOTING

Chart 3 describes in detail the equipment needed and the procedure for troubleshooting the relay output commands from the C&D central unit.

APPARATUS:

- E-telemetry station test set (KS-20937, L1)
 - General purpose plug-in (KS-20937, L4)
 - E2A test cable (KS-20937, L6)
 - Volt-ohm-milliammeter (KS-14510, L1), or equivalent
-

STEP

PROCEDURE

Note: Before starting the step-procedure testing of the central, a preliminary test should be performed as follows: Remove the cover from the console, turn the console power switch to ON, and check that the +5, +15, and -15 Vdc power sources are supplied to the C&D central unit on terminal strip TSA. If all the voltages are present, proceed with Step 1. If any voltage is not present, repair or replace the power supply as necessary.

Caution: *Remove power before removing or replacing any circuit pack.*

- 1 On the 202T data set, depress and hold the LT key for approximately 15 seconds.

Requirement: The MR, RS, CS, CO, and TM lamps will light and remain lighted for the duration of time that the LT key is depressed. If the TM lamp goes off during the 15-second period, repeat this step four additional times. If the TM lamp continues to go off, replace the data set and repeat the test.

- 2 Once the original data set or the new data set has met the requirement in Step 1, ensure that the following options in the data set are set as indicated and as listed in the associated applications schematic.

CHART 3 (Contd)

STEP	PROCEDURE																		
	<table border="0"> <thead> <tr> <th data-bbox="721 470 911 491">FEATURE OPTION</th> <th data-bbox="1133 470 1240 491">SETTING*</th> </tr> </thead> <tr> <td data-bbox="561 531 805 552">1. 4-wire operation</td> <td data-bbox="1143 531 1198 552">(FF)</td> </tr> <tr> <td data-bbox="561 594 1016 615">2. Soft turnoff and squelch intervals</td> <td data-bbox="1143 594 1198 615">O, O</td> </tr> <tr> <td data-bbox="561 657 911 678">3. Fast-carrier detection—in</td> <td data-bbox="1143 657 1198 678">(FF)</td> </tr> <tr> <td data-bbox="561 720 943 741">4. Clear-to-send interval—8 ms</td> <td data-bbox="1143 720 1198 741">(FF)</td> </tr> <tr> <td data-bbox="561 783 724 804">5. Clamp—in</td> <td data-bbox="1143 783 1198 804">(FF)</td> </tr> <tr> <td data-bbox="561 846 854 867">6. Carrier detection—in</td> <td></td> </tr> <tr> <td data-bbox="561 909 894 930">7. Continuous carrier—out</td> <td data-bbox="1143 909 1198 930">(FF)</td> </tr> <tr> <td data-bbox="561 972 1065 1035">8. Grounding option—signal ground not connected to frame ground</td> <td></td> </tr> </table>	FEATURE OPTION	SETTING*	1. 4-wire operation	(FF)	2. Soft turnoff and squelch intervals	O, O	3. Fast-carrier detection—in	(FF)	4. Clear-to-send interval—8 ms	(FF)	5. Clamp—in	(FF)	6. Carrier detection—in		7. Continuous carrier—out	(FF)	8. Grounding option—signal ground not connected to frame ground	
FEATURE OPTION	SETTING*																		
1. 4-wire operation	(FF)																		
2. Soft turnoff and squelch intervals	O, O																		
3. Fast-carrier detection—in	(FF)																		
4. Clear-to-send interval—8 ms	(FF)																		
5. Clamp—in	(FF)																		
6. Carrier detection—in																			
7. Continuous carrier—out	(FF)																		
8. Grounding option—signal ground not connected to frame ground																			

* (FF) indicates factory furnished

1	2	3	4	5	6	7	8	9	0
0	0	x	x	0	0	0	x	x	x

3	Once the requirement in Step 1 is met and the proper options are set, there is reasonable assurance that the data set is in proper working condition. Additional problems are probably within the remote circuitry. Steps 4 through 14 isolate the central circuit problems with the data set disconnected.
4	Insert and connect the general purpose plug-in unit into the E-telemetry station test set.
5	Locate and remove plug P1 from the 202T data set at the central unit.
6	Mate the female pin connector of the E2A test cable to the P1 plug removed in Step 5. Connect the other end of the test cable into the J2 connector on the E-telemetry station test set.

CHART 3 (Contd)

STEP	PROCEDURE
------	-----------

7 Set the controls on the E-telemetry station test set as follows:

SWITCH	POSITION
SYSTEM	E2A
PARITY	B
BIT RATE	1200
MODE	ANSWER
ENABLE	NORMAL
DISPLAY ERROR WORD	OFF
DISPLAY WORD SELECT	3
POWER	OFF
RCU	OFF
MESSAGE LENGTH	16
WORD 1 through WORD 4	100000000000000000

8 Turn the SCC console unit power switch on.

9 Move the station test set POWER switch to the ON (up) position.

10 Depress, in order, the MASTER CLEAR and START pushbuttons.

Requirement: The TMT, RCV, VALID WORD, ERROR WORD and WORD 1 through WORD 4 lamps will blink. If the requirement is not met, repeat the step. If the requirement is still not met, replace all of the following CPs:

CP 1
 CP 2
 CP 3
 CP 13
 CP 14
 CP 15
 CP 16

Inspect CP 8 for proper strapping connections per Note 104 of SD-1C540-01-D1. Determine the defective CP(s) by inserting the original CP(s) back in the central unit, one at a time. Repeat Step 10 after each replacement until the unit malfunctions. The last original CP installed is defective and will be replaced with a spare.

CHART 3 (Contd)

STEP	PROCEDURE
11	Depress the TLM ALM RLS key. Requirement: All console lamps will go off except CLS PWR ON (TELE REM and SYSTEM ON LINE for No. 2 console only).
12	Depress each switch on the SCC console per Table M, N, or O (depending on system). Requirement: The INFORMATION lamps on the E-telemetry station test set will light momentarily as indicated in Table M, N, or O. A lighted lamp is indicated by a "1," and an off lamp is indicated by a "0." If the requirement is not met, replace CP 21 in the location specified by the appropriate table. If the lamps indicated do not light after replacing CP 21, depress a few other switches and note whether they operate properly. If no switch operates properly, replace CPs 19 and 20 and repeat the step.
13	Depress and hold the RLS-OVRD key and at the same time depress any of the locking keys that are off. Requirement: INFORMATION lamp 2 (bit 2) will go off and remain off, indicating a release command has been forced.
14	On the E-telemetry station test set, set WORD 2, switches 2 through 17, to position 1 (up). Set WORD 3, switches 2 through 13, to position 1 (up). For No. 2 console only, set WORD 4, switches 2, 3, 4, and 9 to position 1. Remove AR761 (CP 3) for TSPS. Requirement: All LOCKING KEY lamps, all PROGRAM CONTROL keys, and EA DIS T-OUT key are lighted.
15	With the locking keys lighted, depress and release each switch on the SCC console per Table M, N, or O and observe INFORMATION lamp 2. Requirement: INFORMATION lamp 2 should remain off.
16	Depress and hold the OPR OVRD key and at the same time depress any of the locking keys which are lighted. Requirement: INFORMATION lamp 2 lights momentarily indicating an operate command has been forced.
17	On the test set, return all switches to 0 except bit 1 of WORD 1 through WORD 4, and reinsert circuit pack.
18	Depress each switch listed in Table P, Q, or R (depending on system) and release. Requirement: The INFORMATION lamps on the E-telemetry station test set will light per Table P, Q, or R with lamp 2 momentarily lighting when depressed and going out when the switch is released. If the requirement is not met, replace CP 21 in the location

CHART 3 (Contd)

STEP	PROCEDURE
-------------	------------------

specified by the appropriate table. If the lamps indicated do not light after replacing CP 21, depress a few other switches and note whether they operate properly. If no switch operates properly, replace CPs 19 and 20 and repeat the step.

CHART 4

TCT REPLACEMENT

A spare TCT (J92621-E) is provided at the SCC central for maintenance purposes. If a TCT is determined to be faulty, through the use of the system tests, it is replaced with the spare as set forth in Chart 4. The defective TCT is then returned to a Western Electric Service Center for repair. Once the TCT has been replaced, verify proper operation through the use of the system test.

APPARATUS:

None.

STEP	PROCEDURE
-------------	------------------

- 1 Notify the control console operator that the TCT is about to be replaced.
- 2 Disconnect the power cord and the three connectorized cables from connectors J1, J2, and J3 located on the back of the TCT.
- 3 Slide the defective TCT out of the control console 1A cabinet and replace it with the spare.
- 4 Reconnect the cables and power cord removed in Step 2.
- 5 Notify the control console operator that the defective TCT has been replaced.

CHART 5
REMOTE STATUS POINT MAINTENANCE

Charts 5 and 6 describe in detail the equipment needed and the procedure for troubleshooting the SCC E2A remote units (J92621-B, -AD, -AE, -M, and -AH).

APPARATUS:

E-telemetry station test set (KS-20937, L1)
 General purpose plug-in (KS-20937, L4)
 E2A test cable (KS-20937, L6)
 Volt-ohm-milliammeter (KS-14510, L1), or equivalent

STEP**PROCEDURE**

Note: Before starting the step-procedure testing of the E2A remote unit, a preliminary test should be performed to ensure that the +5, +15, and -15 Vdc power sources are supplied to the remote. For remote J92621-B, -AD, -AE, or -M, check for the voltages on terminal strips TSA and TSB and if any of the power sources are absent, replace CP 12 in location CA for J92621-B or CP 12 in location EC for J92621-AD, -AE, and -M. Verify J92621-AH remote voltages as follows:

VOLTAGE	POWER MODULE	CONNECTOR TERMINAL	VOLTAGE NOT PRESENT—REPLACE
+15	LPM	5	LPM—CP 12
-15	LPM	9	LPM—CP 12
+5	LPM	201	LPM—CP 12
+5	RPM	201	RPM—CP 12

(LPM + RPM = left and right power module as viewed from the rear.)

Caution: Remove power before removing or replacing any circuit pack.

Note: For J92621-AH remotes only, proceed to Step 4.

- 1 On the 202T data set, depress and hold the LT key for approximately 15 seconds.

Requirement: The MR, RS, CS, CO, and TM lamps will light and remain lighted for the duration of time that the LT key is depressed. If the TM lamp goes off during the

CHART 5 (Contd)

STEP	PROCEDURE
------	-----------

15-second period, repeat this step four additional times. If the TM lamp continues to go off, replace the data set and repeat the test.

- 2 Once the original data set or the new data set has met the requirement in Step 1, ensure that the following options in the data set are set as indicated and as listed in the associated applications schematic.

FEATURE OPTION	SETTING*
1. 4-wire operation	(FF)
2. Soft turnoff and squelch intervals	O, O
3. Fast-carrier detection—in	(FF)
4. Clear-to-send interval—8 ms	(FF)
5. Clamp—in	(FF)
6. Carrier detection—in	
7. Continuous carrier—out	(FF)
8. Grounding option—signal ground not connected to frame ground	

* (FF) indicates factory furnished

1	2	3	4	5	6	7	8	9	0
0	0	x	x	0	0	0	x	x	x

- 3 Once the requirement in Step 1 is met and the proper options are set, there is reasonable assurance that the data set is in proper working condition. Additional problems are probably within the remote circuitry. Steps 4 through 12 isolate the remote circuit problems with the data set disconnected.

- 4 Insert and connect the general purpose plug-in unit into the E-telemetry station test set.

- 5 Locate and remove plug P1 of the remote unit 202T data set.

 CHART 5 (Contd)

STEP	PROCEDURE
6	Mate the female pin connector of the E2A test cable to the P1 plug removed from the data set in Step 5. Plug the other end of the test cable into the J2 connector on the E-telemetry station test set.

- 7 Set the controls on the E-telemetry station test set as follows:

SWITCH	POSITION
SYSTEM	E2A
PARITY	B
BIT RATE	1200
MODE	CONT
ENABLE	NORMAL
DISPLAY ERROR WORD	OFF
DISPLAY WORD SELECT	1
POWER	OFF
RCU	OFF
MESSAGE LENGTH	1
WORD 1	01011111111000000
WORD 2 through WORD 4	00000000000000000

- 8 Move the POWER switch to the ON (up) position.
- 9 Depress, in order, the MASTER CLEAR and START pushbutton switches.

Requirement: The TMT, RCV, and VALID WORD lamps will blink. If the requirement is not met, repeat Step 9. If the requirement is still not met, replace **all** of the following CPs:

CP 1
 CP 2
 CP 3
 CP 48
 CP 5

CHART 5 (Contd)

STEP**PROCEDURE**

Inspect CP 34 for proper connections per Note 104 of SD-1C539-01-D1 for J92621-B; SD-2P021-01-D1 for J92621-AD, -AE, and -M; or SD-2P023-01-D1 for J92621-AH. Determine the defective CP(s) by inserting the original CP(s) back in the remote unit, one at a time. Repeat Step 9 after each replacement until the unit malfunctions. The last original CP installed is defective and will be replaced with a spare. Continue with this procedure until all CPs have been checked.

- 10 Hold the TEST switch, on CP 34, in the 1 (up) position.

Requirement: INFORMATION lamps 1 through 17 will light. If the requirement is not met, replace the CP in location AA (see Table S, T, U, V, or W [depending on system]).

- 11 Hold the TEST switch on CP 34 in the 0 (down) position.

Requirement: INFORMATION lamp 1 will remain lighted, and lamps 2 through 17 will go off. If the requirement is not met, replace the CP in location AA (see Table S, T, U, V, or W).

- 12 Repeat the procedures used in Steps 10 and 11 for each set of switch settings (WORD 1, switches 13 through 17, and the DISPLAY WORD SELECT switch) as shown in Table S, T, U, V, or W.

Requirement: The INFORMATION lamps will light as set forth in the requirements for Steps 10 and 11. If the requirements are not met, replace the associated CP (see Table S, T, U, V, or W) and repeat the test.

CHART 6**REMOTE RELAY OUTPUT MAINTENANCE****APPARATUS:**

E-telemetry station test set (KS-20937, L1)

General purpose plug-in (KS-20937, L4)

E2A test cable (KS-20937, L6)

E2A K1-1 extender board (KS-20937, L9)

E2A K1-4 lamp board (KS-20937, L12)

E2A K1-5 lamp board (KS-20937, L13)

CHART 6 (Contd)

APPARATUS (Contd)

Volt-ohm-milliammeter (KS-14510, L1), or equivalent

STEP

PROCEDURE

Note: Before starting the step-procedure testing of the E2A remote unit, a preliminary test should be performed to ensure that the +5, +15, and -15 Vdc power sources are supplied to the remote. For remote J92621-B, -AD, -AE, or -M, check for the voltages on terminal strips TSA and TSB. If any of the power sources are absent, replace CP 12 in location CA for J92621-B or CP 12 in location EC for J92621-AD, -AE, and -M. Verify J92621-AH remote voltages as follows:

VOLTAGE	POWER MODULE	CONNECTOR TERMINAL	VOLTAGE NOT PRESENT—REPLACE
+15	LPM	5	LPM—CP 12
-15	LPM	9	LPM—CP 12
+5	LPM	201	LPM—CP 12
+5	RPM	201	RPM—CP 12

(LPM + RPM = left and right power modules as viewed from the rear.)

Caution: Remove power before removing or replacing any circuit pack.

Note: For J92621-AH remotes only, proceed to Step 4.

- 1 On the 202T data set, depress and hold the LT key for approximately 15 seconds.

Requirement: The MR, RS, CS, CO, and TM lamps will light and remain lighted for the duration of time that the LT key is depressed. If the TM lamp goes off during the 15-second period, repeat this step four additional times. If the TM lamp continues to go off, replace the data set and repeat the test.

- 2 Once the original data set or the new data set has met the requirement in Step 1, ensure that the following options in the data set are set as indicated and as listed in the associated applications schematic.

CHART 6 (Contd)

STEP	PROCEDURE																		
	<table border="0"> <thead> <tr> <th data-bbox="678 480 870 506">FEATURE OPTION</th> <th data-bbox="1089 480 1198 506">SETTING*</th> </tr> </thead> <tr> <td data-bbox="516 537 764 562">1. 4-wire operation</td> <td data-bbox="1097 537 1159 562">(FF)</td> </tr> <tr> <td data-bbox="516 600 976 625">2. Soft turnoff and squelch intervals</td> <td data-bbox="1097 600 1159 625">O, O</td> </tr> <tr> <td data-bbox="516 663 870 688">3. Fast-carrier detection—in</td> <td data-bbox="1097 663 1159 688">(FF)</td> </tr> <tr> <td data-bbox="516 726 902 751">4. Clear-to-send interval—8 ms</td> <td data-bbox="1097 726 1159 751">(FF)</td> </tr> <tr> <td data-bbox="516 789 683 814">5. Clamp—in</td> <td data-bbox="1097 789 1159 814">(FF)</td> </tr> <tr> <td data-bbox="516 852 813 877">6. Carrier-detection—in</td> <td></td> </tr> <tr> <td data-bbox="516 915 854 940">7. Continuous carrier—out</td> <td data-bbox="1097 915 1159 940">(FF)</td> </tr> <tr> <td data-bbox="516 978 1016 1037">8. Grounding option—signal ground not connected to frame ground</td> <td></td> </tr> </table>	FEATURE OPTION	SETTING*	1. 4-wire operation	(FF)	2. Soft turnoff and squelch intervals	O, O	3. Fast-carrier detection—in	(FF)	4. Clear-to-send interval—8 ms	(FF)	5. Clamp—in	(FF)	6. Carrier-detection—in		7. Continuous carrier—out	(FF)	8. Grounding option—signal ground not connected to frame ground	
FEATURE OPTION	SETTING*																		
1. 4-wire operation	(FF)																		
2. Soft turnoff and squelch intervals	O, O																		
3. Fast-carrier detection—in	(FF)																		
4. Clear-to-send interval—8 ms	(FF)																		
5. Clamp—in	(FF)																		
6. Carrier-detection—in																			
7. Continuous carrier—out	(FF)																		
8. Grounding option—signal ground not connected to frame ground																			

* (FF) indicates factory furnished

1	2	3	4	5	6	7	8	9	0
0	0	x	x	0	0	0	x	x	x

- 3 Once the requirement in Step 1 is met and the proper options are set, there is reasonable assurance that the data set is in proper working condition. Additional problems are probably within the remote circuitry. Steps 4 through 27 isolate the remote circuit problems with the data set disconnected.
- 4 Insert and connect the general purpose plug-in unit into the E-telemetry station test set.
- 5 Locate and remove the plug P1 from the 202T data set at the remote unit.
- 6 Mate the female pin connector of the E2A test cable to the P1 plug removed from the data set in Step 5. Plug the other end of the test cable into the J2 connector on the E-telemetry station test set.

CHART 6 (Contd)

STEP

PROCEDURE

- 7 Set the controls on the E-telemetry station test set as follow:

SWITCH	POSITION
POWER	OFF
SYSTEM	E2A
PARITY	B
BIT RATE	1200
MODE	CONT
ENABLE	NORMAL
DISPLAY ERROR WORD	OFF
DISPLAY WORD SELECT	1
RCU	OFF
MESSAGE LENGTH	3
WORD 1	01001111111011111
WORD 2	10011111111001111
WORD 3	10000000000000000
WORD 4	00000000000000000

- 8 Move the POWER switch to the ON position.
- 9 Depress, in order, the MASTER CLEAR and START pushbuttons.
- Requirement:** RECEIVE lamps 1 and 12 will light. If this requirement is not met, perform Chart 5 test (Remote Status Point Maintenance).
- 10 Remove power from the remote.
- 11 Remove CP 6 or CP 37 from location AA and insert the List 9 extender board in its place.
- 12 Plug the removed CP 6 or CP 37 card into the end of the extender board.
- 13 Plug the List 12 lamp board into the List 9 extender board.
- 14 Return power to the remote.
- 15 Set WORD 3, switch 2, on the test set to the 1 (up) position.
- 16 Depress, in order, the MASTER CLEAR and START pushbuttons.

CHART 6 (Contd)

STEP	PROCEDURE
	Requirement: Lamp 1, on the List 12 lamp board, will light. If the requirement is not met, replace the associated CP 6 or CP 37 and repeat the step.
17	Set WORD 3, switch 2, on the test set to the 0 (down) position.
	Requirement: Lamp 1, on the List 12 lamp board, will go off. If the requirement is not met, replace the associated CP 6 or CP 37 and repeat the step.
18	Repeat the procedures used in Steps 15 through 17 for all remaining WORD 3 switch settings listed in Table X, Y, Z, AA, or AB (depending on the system) for the CP under test.
	Note: Remove power from E2A unit when circuit packs are being removed and inserted. If a CP 6 or CP 37 is replaced while performing Step 18, repeat the test starting at Step 15.
19	Repeat the procedures used in Steps 16 through 19 for all remaining CP 6s or CP 37s listed in Table X, Y, Z, AA, or AB.
20	Remove power from E2A remote.
21	Remove the last CP 6 or CP 37 tested, the List 12 lamp board, and the extender board. Reinsert the CP 6 or CP 37 in the module.
22	Remove the first CP 11 listed in Table AC, AD, AE, or AF (depending on system), and insert the List 9 extender board in its place.
23	Plug the CP 11 card into the end of the extender board.
24	Plug the List 13 lamp board into the K-1 extender board.
25	Set WORD 3, switch 2, on the test set to the 1 (up) position.
26	Depress, in order, the MASTER CLEAR and START pushbuttons.
	Requirement: Lamp 1, on the List 13 lamp board, will light. If the requirement is not met, replace CP 11 and repeat the step.
27	Set WORD 3, switch 2, on the test set to the 0 (down) position.
	Requirement: Lamp 1, on the List 13 lamp board, will go off. If the requirement is not met, replace CP 11 and repeat the step.
28	Repeat the procedures used in Steps 25 through 27 for all remaining WORD 3 switch settings listed in Table AC, AD, AE, or AF for the CP under test.

CHART 6 (Contd)

STEP**PROCEDURE**

Note: If a CP 11 is replaced while performing Step 17, repeat the test starting at Step 24.

- 29 Repeat the procedures used in Steps 25 through 28 for all remaining CP 11s listed in Table AC, AD, AE, or AF.
-

6. REFERENCES

- 6.01** The following is a list of Bell System Practices, schematic diagrams, and circuit descriptions which refer to or contain information on the E2A telemetry equipment used in switching control centers.

SECTION	TITLE
190-110-110	No. 2 Switching Control Center System—Common Application—Description
190-110-302	No. 2 Switching Control Center System—Common Application—Hardware Check Procedure
190-110-310	No. 2 Switching Control Center System—Common Application—Hardware Operation and Reconfiguration
190-110-314	No. 2 Switching Control Center System—Common Equipment—Troubleshooting Procedures
190-110-321	No. 1 and No. 2 Switching Control Center Systems—Common Application—System Acceptance Test and Periodic Evaluation Procedures
201-653-102	E2A Telemetry—Switching Control Center System—Description
592-031-100	Data Set 202T—Description and Operation
592-031-300	Data Set 202T—Maintenance
592-031-500	Data Set 202T—Transmitter-Receiver—Test Procedures

DOCUMENT**DESCRIPTION**

1C533-01	E2A Telemetry System—Remote Circuit Modules
1C534-01	E2A Telemetry System—Central Circuit Modules
1C535-01	E2A Telemetry System—Telemetry Computer Translator
1C539-01	No. 1 ESS Remote Application Schematic

SECTION 201-653-502

DOCUMENT	DESCRIPTION
1C540-01	SCC C&D Console Central Application Schematic
1C541-01	SCC CI Central Application Schematic
1D243-01	202T Data Set Schematic
2P021-01	SCC Remote Application Schematic
2P023-01	E2A Telemetry System—1A Processor SCC Remote Application Schematic

TABLE A

SYSTEMS AND ASSOCIATED TABLES

SYSTEM	ASSOCIATED TABLE
NO. 1 ESS — CRITICAL INDICATORS	C
NO. 2B ESS — CRITICAL INDICATORS	D
NO. 3 ESS — CRITICAL INDICATORS	E
NO. 2 ESS — CRITICAL INDICATORS	F
AIS — CRITICAL INDICATORS	G
TSPS — CRITICAL INDICATORS	H
NO. 1A ESS — CRITICAL INDICATORS	I
NO. 1 ESS — C&D CENTRAL GROUP REPORT COMMANDS	J
NO. 2 ESS/AIS — C&D CENTRAL GROUP REPORT COMMANDS	K
TSPS — C&D CENTRAL GROUP REPORT COMMANDS	L
NO. 1 ESS — C&D CENTRAL RELAY OUTPUT COMMANDS (LOCKING KEYS)	M
TSPS — C&D CENTRAL RELAY OUTPUT COMMANDS (LOCKING KEYS)	N
NO. 2 ESS/AIS — C&D CENTRAL RELAY OUTPUT COMMANDS (LOCKING KEYS)	O
NO. 1 ESS — C&D CENTRAL RELAY OUTPUT COMMANDS (NONLOCKING KEYS)	P
NO. 2 ESS/AIS — C&D CENTRAL RELAY OUTPUT COMMANDS (NONLOCKING KEYS)	Q
TSPS — C&D CENTRAL RELAY OUTPUT COMMANDS (NONLOCKING KEYS)	R
NO. 1 ESS — REMOTE STATUS POINTS	S
NO. 2 ESS/AIS — REMOTE STATUS POINTS	T
NO 2B ESS — REMOTE STATUS POINTS	U
TSPS — REMOTE STATUS POINTS	V
NO. 1A ESS — REMOTE STATUS POINTS	W
NO. 1 ESS — REMOTE RELAY OUTPUT MAINTENANCE	X
NO. 2 ESS/AIS — REMOTE RELAY OUTPUT MAINTENANCE	Y
NO. 2B/3 ESS — REMOTE RELAY OUTPUT MAINTENANCE	Z
TSPS — REMOTE RELAY OUTPUT MAINTENANCE	AA
NO. 1A ESS — REMOTE RELAY OUTPUT MAINTENANCE	AB
NO. 1 ESS — REMOTE RELAY OUTPUT MAINTENANCE	AC
NO. 2 ESS/AIS — REMOTE RELAY OUTPUT MAINTENANCE	AD
TSPS — REMOTE RELAY OUTPUT MAINTENANCE	AE
NO. 1A ESS — REMOTE RELAY OUTPUT MAINTENANCE	AF

TABLE B

STATION ADDRESS LAMPS

4	5	6	7
0	0	0	0
1	0	0	0
0	1	0	0
1	1	0	0
0	0	1	0
1	0	1	0
0	1	1	0
1	1	1	0
0	0	0	1
1	0	0	1
0	1	0	1
1	1	0	1
0	0	1	1
1	0	1	1
0	1	1	1
1	1	1	1

Legend:

- 1 — Lamp lighted
- 0 — Lamp off

TABLE C

NO. 1 ESS — CRITICAL INDICATORS

WORD 1 SWITCH NUMBER	CORRESPONDING CIP LAMP LIGHTED
2	CKT LIM
3	CRITICAL*
4	MAJOR**
5	MINOR**
6	SYS EMER**
7	CC
8	SP
9	PS
10	CS
11	PERIPH A
12	PERIPH B
13	BLDG/PWR
14	FORCED
15	BLDG INH
16	TRAFFIC
17	—

* Latching alarms

** May be latching (option of SCC)

TABLE D

NO. 2B ESS – CRITICAL INDICATORS

WORD 1 SWITCH NUMBER	CORRESPONDING CIP LAMP LIGHTED
2	CKT LIM
3	CRITICAL*
4	MAJOR**
5	MINOR**
6	SYS EMER**
7	CU
8	NET
9	SCAN
10	AMA
11	MAS
12	MISC
13	BLDG/PWR
14	FORCED
15	BLDG INH
16	TRAFFIC
17	—

* Latching alarms

** May be latching (option of SCC)

TABLE E

NO. 3 ESS – CRITICAL INDICATORS

WORD 1 SWITCH NUMBER	CORRESPONDING CIP LAMP LIGHTED
2	CKT LIM
3	CRITICAL*
4	MAJOR**
5	MINOR**
6	SYS EMER**
7	SYC
8	RT
9	AMA
10	—
11	PERIPH A
12	PERIPH B
13	BLDG/PWR
14	FORCED
15	BLDG INH
16	TRAFFIC
17	—

* Latching alarms

** May be latching (option of SCC)

TABLE F

NO. 2 ESS – CRITICAL INDICATORS

WORD 1 SWITCH NUMBER	CORRESPONDING CIP LAMP LIGHTED
2	CKT LIM
3	CRITICAL *
4	MAJOR**
5	MINOR**
6	SYS EMER**
7	INT DIS
8	NET
9	SCAN
10	AMA
11	—
12	MISC
13	BLDG/PWR
14	FORCED
15	BLDG INH
16	TRAFFIC
17	—

* Latching alarms

** May be latching (option of SCC)

TABLE G

AIS – CRITICAL INDICATORS

WORD 1 SWITCH NUMBER	CORRESPONDING CIP LAMP LIGHTED
2	CKT LIM
3	CRITICAL*
4	MAJOR**
5	MINOR**
6	SYS EMER**
7	INT DIS
8	FI
9	CN
10	AN
11	PERIPH A
12	PERIPH B
13	BLDG/PWR
14	FORCED
15	BLDG INH
16	TRAFFIC
17	—

* Latching alarms

** May be latching (option of SCC)

TABLE H

TSPS – CRITICAL INDICATORS

WORD 1 SWITCH NUMBER	CORRESPONDING CIP LAMP LIGHTED
2	CKT LIM
3	CRITICAL*
4	MAJOR**
5	MINOR**
6	SYS EMER**
7	PROC
8	STORE
9	SPC PU
10	BASE PU
11	PSS/RTA
12	—
13	BLDG/PWR
14	FORCED
15	BLDG/INH
16	TRAFFIC
17	—

* Latching alarms

** May be latching (option of SCC)

TABLE I

NO. 1A ESS – CRITICAL INDICATORS

WORD 1 SWITCH NUMBER	CORRESPONDING CIP LAMP LIGHTED
2	CKT LIM
3	CRITICAL*
4	MAJOR**
5	MINOR**
6	SYS EMER**
7	CC
8	FS
9	PS
10	CS
11	PERIPH A
12	PERIPH B
12	BLDG/PWR
14	FORCED
15	BLDG INH
16	TRAFFIC
17	—

* Latching alarms

** May be latching (option of SCC)

TABLE J

NO. 1 ESS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION	
1	2	SYSTEM ALARMS – DT DEL ALM	BG	
		PROCESSOR STATUS – SIGNAL PROC 0 – ACT	BE	
	3	CRITICAL	BD	
		SYSTEM ALARMS – MCC PWR ALM	BG	
			PROCESSOR STATUS – SIGNAL PROC 1 – ACT	BE
	4	MAJOR	BD	
		SYSTEM ALARMS – COML PWR	BG	
			PROCESSOR STATUS – CENTRAL CONTROL 0 – STOP	BE
	5	MINOR	BD	
		SYSTEM STATUS – RPTD T OUT	BG	
			PROCESSOR STATUS – CENTRAL CONTROL 0 – CLK	BE
			HARDWARE CONFIGURATION – RPTD T OUT	BG
	6		SYSTEM STATUS – EA PH IN PROG	BG
		PROCESSOR STATUS – CENTRAL CONTROL 1 – STOP	BE	
		PROGRAM INTERRUPT CONTROL – EA PH IN PROG	BG	
7		SYSTEM STATUS – MISC TBL	BG	
		PROCESSOR STATUS – CENTRAL CONTROL 1 – CLK	BE	
8		SYSTEM ALARMS – 4A TMR PWR ALM	BG	
		PROCESSOR STATUS – CENTRAL CONTROL 0 – SEND 0	BE	
9		SYSTEM STATUS – TRK MB OVFL	BG	
		PROCESSOR STATUS – CENTRAL CONTROL 0 – PS BUS – RCV 0	BE	
10		SYSTEM STATUS – DIAGS IN PROG	BG	
		PROCESSOR STATUS – CENTRAL CONTROL 1 – PS BUS – SEND 0	BE	
11		SYSTEM STATUS – OFF NOR	BG	
		PROCESSOR STATUS – CENTRAL CONTROL 1 – PS BUS – RCV 0	BE	
12		PROCESSOR STATUS – CENTRAL CONTROL 0 – PS BUS – SEND 1	BE	
		HARDWARE CONFIGURATION – INVD	BG	
13		SYSTEM STATUS – CO ALM INH	BG	
		PROCESSOR STATUS – CENTRAL CONTROL 0 – PS BUS – RCV 1	BE	

TABLE J (Contd)

NO. 1 ESS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
1	14	PROCESSOR STATUS – CENTRAL CONTROL 1 – PS BUS – SEND 1 SYSTEM INDICATORS – L SRV REQ HPR UNLD RT – MIN	BE BG
	15	PROCESSOR STATUS – CENTRAL CONTROL 1 – PS BUS – RCV 1 SYSTEM INDICATORS – L SRV REQ HPR UNLD RT – MID	BE BG
	16	PROCESSOR STATUS – CENTRAL CONTROL 0 – CS BUS – SEND 0 SYSTEM INDICATORS – L SRV REQ HPR UNLD RT – MAX	BE BG
	17	PROCESSOR STATUS – CENTRAL CONTROL 0 – CS BUS – RCV 0	BE
2	2*	PERIPHERAL STATUS – LINE SWITCH P	BG
		PROCESSOR STATUS – CENTRAL CONTROL 1 – CS BUS – SEND 0	BE
		PROGRAM DISPLAY – 8	BJ
		HARDWARE CONFIGURATION – EA DIS T OUT	BC
	3	PERIPHERAL STATUS – LINE SWITCH S	BG
		PROCESSOR STATUS – CENTRAL CONTROL 1 – CS BUS – RCV 0 PROGRAM DISPLAY – 9 TRAFFIC CONTROL – ENAB	BE BJ BC
4	PERIPHERAL STATUS – JUNCTOR SWITCH P	BG	
	PROCESSOR STATUS – CENTRAL CONTROL 0 – CS BUS – SEND 1 PROGRAM DISPLAY – 10 TRAFFIC CONTROL – EMER MAN SRV (KEY)	BE BJ BC	
5	PERIPHERAL STATUS – JUNCTOR SWITCH S	BG	
	PROCESSOR STATUS – CENTRAL CONTROL 0 – CS BUS – RCV 1 PROGRAM DISPLAY – 11 PROGRAM CONTROL – BLK	BE BJ BC	
6	PERIPHERAL STATUS – SLN & TRK SW P	BG	
	PROCESSOR STATUS – CENTRAL CONTROL 1 – CS BUS – SEND 1 PROGRAM DISPLAY – 12 PROGRAM CONTROL – 0	BE BJ BC	

* CRITICAL, MAJOR, and MINOR lamps will flash at hardware consoles equipped with the AR-761 circuit jack.

TABLE J (Contd)

NO. 1 ESS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
2	7	PERIPHERAL STATUS – SLN & TRK SW S	BG
		PROCESSOR STATUS – CENTRAL CONTROL 1 – CS BUS – RCV 1	BE
		PROGRAM DISPLAY – 13	BJ
		PROGRAM CONTROL – 1	BC
	8	SYSTEM STATUS – DISJN	BE
		PERIPHERAL STATUS – JUNCTOR P	BG
		PROGRAM DISPLAY – 14	BJ
PROGRAM CONTROL – 2		BC	
9	SYSTEM STATUS – MULT TBL	BE	
	PERIPHERAL STATUS – JUNCTOR S	BG	
	PROGRAM DISPLAY – 15	BJ	
	PROGRAM CONTROL – 3	BC	
10	SYSTEM ALARMS – MISCELLANEOUS – A	BE	
	PERIPHERAL STATUS – TRUNKS P	BG	
	PROGRAM DISPLAY – 16	BJ	
	PROGRAM CONTROL – 4	BC	
11	SYSTEM ALARMS – MISCELLANEOUS – B	BE	
	PERIPHERAL STATUS – TRUNKS S	BG	
	PROGRAM DISPLAY – 17	BJ	
	PROGRAM CONTROL – 5	BC	
12	SYSTEM ALARMS – MISCELLANEOUS – C	BE	
	PERIPHERAL STATUS – MASTER SCAN P	BG	
	PROGRAM DISPLAY – 18	BJ	
	PROGRAM CONTROL – 6	BC	
13	SYSTEM ALARMS – MISCELLANEOUS – D	BE	
	PERIPHERAL STATUS – MASTER SCAN S	BG	
	PROGRAM DISPLAY – 19	BJ	
	PROGRAM CONTROL – 7	BC	

TABLE J (Contd)

NO. 1 ESS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP-17 LOCATION
2	14	SYSTEM ALARMS – MISCELLANEOUS – E	BE
		PERIPHERAL STATUS – CPD P	BG
		PROGRAM DISPLAY – 20	BJ
		PROGRAM CONTROL – 8	BC
15	15	SYSTEM ALARMS – MISCELLANEOUS – F	BE
		PERIPHERAL STATUS – CPD S	BG
		PROGRAM DISPLAY – 21	BJ
16*	16*	PROGRAM CONTROL – 9	BC
		PERIPHERAL STATUS – RING & TONE P	BG
		PROGRAM DISPLAY – 22	BJ
		PROGRAM CONTROL – 10	BC
17*	17*	PERIPHERAL STATUS – RING & TONE S	BG
		PROGRAM DISPLAY – 23	BJ
		PROGRAM CONTROL – 11	BC
3	2	SYSTEM STATUS – EMER MAN SRV (INDICATOR)	BJ
		PROCESSOR STATUS – CENTRAL CONTROL 0 – OFF LINE	BF
		SYSTEM INDICATORS – QUEUES ACTIVE – RECEIVERS – CTT	BH
3	3	TRAFFIC CONTROL – EMER MAN SRV	BJ
		PROGRAM CONTROL – 12	BC
		SYSTEM STATUS – OG LOAD CONT	BJ
3	3	PROCESSOR STATUS – CENTRAL CONTROL 0 – PWR	BF
		SYSTEM INDICATORS – QUEUES ACTIVE – RECEIVERS – CDP	BH
		PROGRAM CONTROL – 13	BC
4	4	PROCESSOR STATUS – CENTRAL CONTROL 0 – TBL	BF
		SYSTEM INDICATORS – CC OVLD	BJ
		SYSTEM INDICATORS – QUEUES ACTIVE – RECEIVERS – MF	BH
		PROGRAM CONTROL – 14	BC

* CRITICAL, MAJOR, and MINOR lamps will flash at hardware consoles equipped with the AR-761 circuit jack.

TABLE J (Contd)

NO. 1 ESS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
3	5	PROCESSOR STATUS – CENTRAL CONTROL 0 – ACT	BF
		SYSTEM INDICATORS – RCVR OVLD	BJ
		SYSTEM INDICATORS – QUEUES ACTIVE – RECEIVERS – RP	BH
		HARDWARE CONFIGURATION – CO ACT	BF
		PROGRAM CONTROL – 15	BC
	6	PROCESSOR STATUS – CENTRAL CONTROL 1 – OFF LINE	BF
	SYSTEM INDICATORS – LLC ENAB	BJ	
	SYSTEM INDICATORS – QUEUES ACTIVE – RECEIVERS – TDP	BH	
	PROGRAM CONTROL – 16	BC	
7	7	PROCESSOR STATUS – CENTRAL CONTROL 1 – PWR	BF
		SYSTEM INDICATORS – DT DEL	BJ
		SYSTEM INDICATORS – QUEUES ACTIVE – TRANSMITTERS – MF	BH
		PROGRAM CONTROL – 17	BC
	8	SYSTEM STATUS – INC LOAD CONT	BJ
	PROCESSOR STATUS – CENTRAL CONTROL 1 – TBL	BF	
	SYSTEM INDICATORS – QUEUES ACTIVE – TRANSMITTERS – DP	BH	
	PROGRAM CONTROL – 18	BC	
9	9	PROCESSOR STATUS – CC BUS POWER – PS BUS 0	BJ
		PROCESSOR STATUS – CENTRAL CONTROL 1 – ACT	BF
		SYSTEM INDICATORS – QUEUES ACTIVE – TRANSMITTERS – RP	BH
		HARDWARE CONFIGURATION – PS0 PWR ON	BJ
		HARDWARE CONFIGURATION – CC1 ACT	BF
	PROGRAM CONTROL – 19	BC	
10	10	PROCESSOR STATUS – SIGNAL PROC 0 – TBL	BF
		PROCESSOR STATUS – CC BUS POWER – PS BUS 1	BJ
		SYSTEM INDICATORS – QUEUES ACTIVE – REGISTERS – ORIG	BH
		HARDWARE CONFIGURATION – PSB1 PWR ON	BJ
		PROGRAM CONTROL – 20	BC

TABLE J (Contd)

NO. 1 ESS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
3	11	PROCESSOR STATUS – SIGNAL PROC 0 – PWR	BF
		PROCESSOR STATUS – CC BUS POWER – CS BUS 0	BJ
		SYSTEM INDICATORS – QUEUES ACTIVE – REGISTERS – RING	BH
		HARDWARE CONFIGURATION – CSB0 PWR ON	BJ
		PROGRAM CONTROL – 21	BC
	12	PROCESSOR STATUS – SIGNAL PROC 0 – STOP	BF
		PROCESSOR STATUS – CC BUS POWER – CS BUS 1	BJ
SYSTEM INDICATORS – QUEUES ACTIVE – REGISTERS – DISC		BH	
13	SYSTEM ALARMS – TTY – LOC	BJ	
	PROCESSOR STATUS – SIGNAL PROC 1 – TBL	BF	
14	SYSTEM INDICATORS – QUEUES ACTIVE – REGISTERS – AMA	BH	
	SYSTEM ALARMS – TTY – REM	BJ	
15	PROCESSOR STATUS – SIGNAL PROC 1 – PWR	BF	
	SYSTEM INDICATORS – JOBS OMITTED DUE TO OVLD – RVFY	BH	
	PROGRAM CONTROL – 22	BC	
15	PROCESSOR STATUS – SIGNAL PROC 1 – STOP	BF	
	SYSTEM INDICATORS – JOBS OMITTED DUE TO OVLD – FCG	BH	
	HARDWARE CONFIGURATION – SP1 STOP	BF	
16	PROGRAM INTERRUPT CONTROL – ENAB	BC	
	SYSTEM INDICATORS – JOBS OMITTED DUE TO OVLD – BLK RTY	BH	
16	PROGRAM INTERRUPT CONTROL – BOTH	BF	
	HARDWARE CONFIGURATION – CC0 SEL ACT	BC	
	TELEMETRY – REM PWR OFF	BH	
17	HARDWARE CONFIGURATION – CC1 SEL ACT	BC	
	FUNC DATA	BF	
4	2	PROCESSOR STATUS – CALL STORES – CC P	BF
		SYSTEM INDICATORS – E-E RATE KC/15 MIN – 30+	BH
		PROGRAM INTERRUPT CONTROL – A	BD

TABLE J (Contd)

NO. 1 ESS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION	
4	3	PROCESSOR STATUS – CALL STORES – CC S	BF	
		SYSTEM INDICATORS – E-E RATE KC/15 MIN – 15-30	BH	
		PROGRAM INTERRUPT CONTROL – B	BD	
	4	4	PROCESSOR STATUS – CALL STORES – SP P	BF
			SYSTEM INDICATORS – E-E RATE KC/15 MIN – 7.5-15	BH
	5	5	PROGRAM INTERRUPT CONTROL – C	BD
			PROCESSOR STATUS – CALL STORES – SP S	BF
	6	6	SYSTEM INDICATORS – E-E RATE KC/15 MIN – 3.8-7.5	BH
PROGRAM INTERRUPT CONTROL – D			BD	
7	6	PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 0	BF	
		SYSTEM INDICATORS – E-E RATE KC/15 MIN – 1.9-3.8	BH	
8	7	PROGRAM INTERRUPT CONTROL – E	BD	
		PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 1	BF	
9	8	SYSTEM INDICATORS – E-E RATE KC/15 MIN – .94-1.9	BH	
		PROGRAM INTERRUPT CONTROL – F	BD	
10	9	PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 2	BF	
		SYSTEM INDICATORS – E-E RATE KC/15 MIN – .47-.94	BH	
10	10	PROGRAM INTERRUPT CONTROL – CLR EX	BD	
		PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 3	BF	
10	10	SYSTEM INDICATORS – E-E RATE KC/15 MIN – .47	BH	
		HARDWARE CONFIGURATION – STOP SP 0	BD	
10	10	PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 4	BF	
		PROGRAM DISPLAY – 0	BH	
		HARDWARE CONFIGURATION – STOP SP 1	BD	

TABLE J (Contd)

NO. 1 ESS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
4	11	PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 5 PROGRAM DISPLAY – 1 HARDWARE CONFIGURATION – PSB 0 OFF	BF BH BD
	12	PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 6 PROGRAM DISPLAY – 2 HARDWARE CONFIGURATION – PSB 1 OFF	BF BH BD
	13	PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 7 PROGRAM DISPLAY – 3 HARDWARE CONFIGURATION – CSB 0 OFF	BF BH BD
	14	PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 8 PROGRAM DISPLAY – 4 HARDWARE CONFIGURATION – CSB 1 OFF	BF BH BD
	15	PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 9 PROGRAM DISPLAY – 5 HARDWARE CONFIGURATION – SET MAN	BF BH BD
	16	PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 10 PROGRAM DISPLAY – 6 CO ALM RLS (KEY)	BF BH BD
	17	PROCESSOR STATUS – PROGRAM STORES MARKED IN TROUBLE – 11 PROGRAM DISPLAY – 7	BF BH

TABLE K

NO. 2 ESS/AIS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
1	2	SYSTEM STATUS – SERVICE LOSS	CF
		MISCELLANEOUS – COML PWR	CJ
	3	CRITICAL	CD
		MISCELLANEOUS – A	CJ
	4	MAJOR	CD
		SYSTEM STATUS – AUTO TEST INHIBIT	CG
		MISCELLANEOUS – B	CJ
	5	MINOR	CD
		SYSTEM STATUS – ALARM TRANSFERRED	CG
		MISCELLANEOUS – C	CJ
	6	SYSTEM STATUS – FUSE ALARM	CG
		MISCELLANEOUS – D	CJ
	7	SYSTEM STATUS – MAINTENANCE CENTER – INTERRUPT DISABLE	CD
		STORE MARGIN TEST – PROGRAM STORE	CG
		MISCELLANEOUS – E	CJ
	8	STORE MARGIN TEST – CALL STORE	CG
		MISCELLANEOUS – F	CJ
9	POWER CONTROL – TEST MODE REVERSAL ENABLE	CG	
10	POWER CONTROL – CONTROL UNIT SWITCH INHIBIT	CG	
11	SYSTEM STATUS – CONTROL UNIT 0 – STANDBY	CG	
12	SYSTEM STATUS – CONTROL UNIT 0 – OUT OF SERVICE	CG	
14	SYSTEM STATUS – MAINTENANCE CENTER – OUT OF SERVICE	CG	
15	SYSTEM STATUS – MAINTENANCE CENTER – MANUAL	CG	
	SYSTEM STATUS – MTCE FORCED	CJ	
16	SYSTEM STATUS – CONTROL UNIT 1 – OUT OF SERVICE	CG	
	SYSTEM STATUS – SCCS FORCED	CJ	
17	SYSTEM STATUS – CONTROL UNIT 1 – STANDBY	CG	
	SYSTEM STATUS – SERVICE LOSS	CJ	

TABLE K (Contd)

NO. 2 ESS/AIS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
2	2	COMPARATOR INPUT SWITCHES – 0 SYSTEM STATUS – NET/FI	CD CG
	3	COMPARATOR INPUT SWITCHES – 1 DISPLAY BUFFER – CLEAR* SYSTEM STATUS – SCAN/MS	CD CF CG
	4	COMPARATOR INPUT SWITCHES – 2 MAINTENANCE CENTER FUNCTIONS – SYS RESER & CLR* SYSTEM STATUS – AMA/CN	CD CF CG
	5	COMPARATOR – INPUT SWITCHES – 3 TEST STATUS – PF (INDICATOR PASS ALSO) SYSTEM STATUS – MISC/MP	CD CF CG
	6	COMPARATOR INPUT SWITCHES – 4 MAINTENANCE CENTER MODE – MAN.* SYSTEM STATUS – BLDG/AN	CD CF CG
	7	COMPARATOR INPUT SWITCHES – 5 MAINTENANCE CENTER MODE – NORM* SYSTEM STATUS – CKT LIM/TK	CD CF CG
	8	COMPARATOR INPUT SWITCHES – 6 AUXILIARY FUNCTIONS – PROG EXEC* SYSTEM STATUS – TRAFFIC/TQ	CD CF CG
	9	COMPARATOR INPUT SWITCHES – 7 AUXILIARY FUNCTIONS – INHIBIT AUTO DISPLAY* SYSTEM STATUS – DSP	CD CF CG
	10	COMPARATOR INPUT SWITCHES – 8 EMERGENCY ACTION – READY SYSTEM STATUS – TOLL NET/MI	CD CF CG
	11	COMPARATOR INPUT SWITCHES – 9 EMERGENCY ACTION – GO SYSTEM STATUS – OVLD	CD CF CG

*Will light both key and indicator

TABLE K (Contd)

NO. 2 ESS/AIS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
2	12	COMPARATOR INPUT SWITCHES – 10	CD
		EMERGENCY ACTION – TTY INIT	CF
		SYSTEM STATUS – XOS	CG
	13	COMPARATOR INPUT SWITCHES – 11	CD
		SYSTEM STATUS – XPER	CG
	14	COMPARATOR INPUT SWITCHES – 12	CD
		SYSTEM STATUS – XAMB	CG
SYSTEM STATUS – CONTROL UNIT 0 – ACTIVE		CJ	
15	COMPARATOR INPUT SWITCHES – 13	CD	
	DISPLAY BUFFER – 0	CG	
	SYSTEM STATUS – CONTROL UNIT 1 – ACTIVE	CJ	
16	COMPARATOR INPUT SWITCHES – 14	CD	
	AUXILIARY FUNCTIONS – LAMP PWR	CJ	
17	COMPARATOR INPUT SWITCHES – 15	CD	
	AUXILIARY FUNCTIONS – LAMP TEST	CJ	
3	2	COMPARATOR INPUT SWITCHES – 16	CE
		SYSTEM STATUS – SERVICE LOSS	CF
		DISPLAY BUFFER – 1	CH
	3	COMPARATOR INPUT SWITCHES – 17	CE
		TELEMETRY – REM PWR OFF	CF
		DISPLAY BUFFER – 2	CH
	4	COMPARATOR INPUT SWITCHES – 18	CE
		DISPLAY BUFFER – 3	CH
	5	EMERGENCY ACTION – POWER	
		COMPARATOR INPUT SWITCHES – 19	CE
MAINTENANCE CENTER FUNCTIONS – COMPARE PA-CIS*		CF	
6	DISPLAY BUFFER – 4	CH	
	COMPARATOR INPUT SWITCHES – 20	CE	
6	MAINTENANCE CENTER FUNCTIONS – COMPARE CSA-CIS*	CF	
	DISPLAY BUFFER – 5	CH	

*Will light both key and indicator

TABLE K (Contd)

NO. 2 ESS/AIS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION	
3	7	COMPARATOR INPUT SWITCHES – 21	CE	
		MAINTENANCE CENTER FUNCTIONS – DYN PS READ*	CF	
		DISPLAY BUFFER – 6	CH	
	8	EMERGENCY ACTION – ENABLE	MAINTENANCE CENTER FUNCTIONS – DYN CS READ*	CE
			DISPLAY BUFFER – 7	CF
	9	EMERGENCY ACTION – STABLE	SYSTEM STATUS – LOCK CU 0 ACT*	CH
			DISPLAY BUFFER – 8	CE
				CF
	10	EMERGENCY ACTION – REC CHG/TAPE	SYSTEM STATUS – LOCK CU 1 ACT*	CH
			DISPLAY BUFFER – 9	CE
	11	EMERGENCY ACTION – LINE TRFR	DISPLAY BUFFER – 10	CH
				CE
	12	DISPLAY BUFFER – 11	CH	
	13	DISPLAY BUFFER – 12	SYSTEM STATUS – CONTROL UNIT 0 – RUN	CH
			CK	
14	DISPLAY BUFFER – 13	SYSTEM STATUS – CONTROL UNIT 1 – RUN	CH	
			CK	
15	DISPLAY BUFFER – 14	TTY CONTROL STATUS – PWR OFF – TA	CH	
			CK	
16	DISPLAY BUFFER – 15	TTY CONTROL STATUS – PWR OFF – TB	CH	
			CK	
17	DISPLAY BUFFER – 16	TTY CONTROL STATUS – DATA SET DISCONNECT – D2	CH	
			CK	
4	2	TTY CONTROL STATUS – DATA SET DISCONNECT – TRI ON*	CE	
		DISPLAY BUFFER – 17	CH	
	3	TTY CONTROL STATUS – DATA SET DISCONNECT – REM MTCE*	DISPLAY BUFFER – 18	CE
			TTY CONTROL STATUS – DATA SET DISCONNECT – D3	CH
		CK		

*Will light both key and indicator

TABLE K (Contd)

NO. 2 ESS/AIS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
4	4	TTY CONTROL – LOC MTCE*	CE
		DISPLAY BUFFER – 19	CH
	5	TTY CONTROL STATUS – DATA SET DISCONNECT – D4	CK
		DISPLAY BUFFER – 20	CH
	6	TTY CONTROL STATUS – DATA SET DISCONNECT – D5	CK
		DISPLAY BUFFER – 21	CH
	7	TTY CONTROL STATUS – DATA SET DISCONNECT – D6	CK
		MAINTENANCE CENTER FUNCTIONS – COMPARE PSB – CIS	CH
	8	TTY CONTROL STATUS – DATA SET DISCONNECT – D7	CK
		MAINTENANCE CENTER FUNCTIONS – REPEAT EXECUTE ONE WORD	CH
	9	TTY CONTROL STATUS – TTY DISCONNECT – T2	CK
		MAINTENANCE CENTER MODE – ON-LINE INTERRUPT*	CE
	10	MAINTENANCE CENTER MODE – ON-LINE INIT*	CE
MAINTENANCE CENTER FUNCTIONS – EXECUTE ONE WORD NO ADV		CH	
11	TTY CONTROL STATUS – TTY DISCONNECT – T3	CK	
	TELEMETRY – ALL LAMPS ON	CE	
12	MAINTENANCE CENTER FUNCTIONS – EXECUTE ONE WORD & ADV	CH	
	TTY CONTROL STATUS – TTY DISCONNECT – T4	CK	
13	TELEMETRY – ALL LAMPS OFF	CE	
	MAINTENANCE CENTER FUNCTIONS – COMPARE EXT – CIS	CH	
14	TTY CONTROL STATUS – TTY DISCONNECT – T5	CK	
	POWER CONTROL – CU 0 ACT	CE	
15	OFF-LINE LOAD & DISPLAY – LOAD	CH	
	TTY CONTROL STATUS – TTY DISCONNECT – T6	CK	
16	POWER CONTROL – CU 1 ACT	CE	
	OFF-LINE LOAD & DISPLAY – DISPLAY	CH	
		TTY CONTROL STATUS – TTY DISCONNECT – T7*	CK

*Will light both key and indicator

TABLE K (Contd)

NO. 2 ESS/AIS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
4	14	TTY CONTROL – RESET	CE
		TEST STATUS – FAIL	CH
		POWER CONTROL – MTCE CENTER CIRCUIT	CK
	15	MAINTENANCE CENTER MODE – OFF-LINE STOP	CH
		POWER CONTROL – OFF-LINE CONTROL UNIT	CK
16		AUXILIARY FUNCTIONS – OFF-LINE STOPPED MANUAL	CH
		POWER CONTROL – SEQUENCE FAILURE – BUS A	CK
17		SYSTEM STATUS – SERVICE LOSS	CH
		POWER CONTROL – SEQUENCE FAILURE – BUS B	CK

TABLE L

TSPS — C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
1	2	EMERGENCY RECOVERY — PROCESSOR 0 — 13	CJ
	3	CRITICAL MISCELLANEOUS — COML PWR EMERGENCY RECOVERY — PROCESSOR 0 — 12	CD CG CJ
	4	MAJOR SYSTEM STATUS — DISJOIN EMERGENCY RECOVERY — PROCESSOR 0 — 11 HARDWARE CONFIGURATION — DISJOIN	CD CG CJ CG
	5	MINOR EMERGENCY RECOVERY — PROCESSOR 0 — 10 PROGRAM CONTROL — FUNC DATA	CD CJ CG
	6	TTY — LOC EMERGENCY RECOVERY — PROCESSOR 0 — 9	CG CJ
	7	TTY — REM EMERGENCY RECOVERY — PROCESSOR 0 — 8	CG CJ
	8	MISCELLANEOUS — A EMERGENCY RECOVERY — PROCESSOR 0 — 7	CG CJ
	9	MISCELLANEOUS — B EMERGENCY RECOVERY — PROCESSOR 0 — 6	CG CJ
	10	MISCELLANEOUS — C EMERGENCY RECOVERY — PROCESSOR 0 — 5	CG CJ
	11	MISCELLANEOUS — D EMERGENCY RECOVERY — PROCESSOR 0 — 4	CG CJ
	12	MISCELLANEOUS — E EMERGENCY RECOVERY — PROCESSOR 0 — 3	CG CJ
	13	MISCELLANEOUS — F EMERGENCY RECOVERY — PROCESSOR 0 — 2	CG CJ
	14	SYSTEM STATUS — RPTD T OUT EMERGENCY RECOVERY — PROCESSOR 0 — 1	CG CJ

TABLE L (Contd)

TPSP – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
1	15	SYSTEM STATUS – MULT TBL	CG
		EMERGENCY RECOVERY – PROCESSOR 0 – 0	CJ
	16	SYSTEM STATUS – SYSTEM MONITOR	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 19	CJ
17	EMERGENCY RECOVERY – PROCESSOR 1 – 18	CJ	
	TELEMETRY – REM PWR OFF	CG	
2	2	SYSTEM STATUS – DIAGS IN PROG	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 17	CJ
		SUBSYSTEM STATUS – 6	CL
		HARDWARE CONFIGURATION – EA DIS T OUT	CD
	3	SYSTEM STATUS – CD OFF NORM	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 16	CJ
4	SUBSYSTEM STATUS – 7	CL	
	HARDWARE CONFIGURATION – BUS 0 – 4	CF	
	PROGRAM CONTROL – BLK	CD	
	SYSTEM STATUS – CO ALM INHB	CG	
5	EMERGENCY RECOVERY – PROCESSOR 1 – 15	CJ	
	SUBSYSTEM STATUS – 8	CL	
	HARDWARE CONFIGURATION – BUS 0 – 5	CF	
	PROGRAM CONTROL – 0	CD	
	SPC STATUS – PROCESSOR 0 – STOP	CG	
6	EMERGENCY RECOVERY – PROCESSOR 1 – 14	CJ	
	SUBSYSTEM STATUS – 9	CL	
	HARDWARE CONFIGURATION – BUS 0 – 6	CF	
	PROGRAM CONTROL – 1	CD	
	SPC STATUS – PROCESSOR – CLK	CG	
7	EMERGENCY RECOVERY – PROCESSOR 1 – 13	CJ	
	SUBSYSTEM STATUS – 10	CL	
	HARDWARE CONFIGURATION – BUS 0 – 7	CF	
	PROGRAM CONTROL – 2	CD	

TABLE L (Contd)

TSPS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
2	7	SPC STATUS – PROCESSOR 0 – TBL	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 12	CJ
		SUBSYSTEM STATUS – 11	CL
		HARDWARE CONFIGURATION – BUS 1 – 0	CF
		PROGRAM CONTROL – 3	CD
		8	SPC STATUS – PROCESSOR 0 – OFF LINE
EMERGENCY RECOVERY – PROCESSOR 1 – 11	CJ		
SUBSYSTEM STATUS – 12	CL		
HARDWARE CONFIGURATION – BUS 1 – 1	CF		
PROGRAM CONTROL – 4	CD		
9	9	SPC STATUS – PROCESSOR 0 – ACT	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 10	CJ
		SUBSYSTEM STATUS – 13	CL
		HARDWARE CONFIGURATION – BUS 1 – 2	CF
		PROGRAM CONTROL – 5	CD
10	10	SPC STATUS – PROCESSOR 0 – PWR	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 9	CJ
		SUBSYSTEM STATUS – 14	CL
		HARDWARE CONFIGURATION – BUS 1 – 3	CF
		PROGRAM CONTROL – 6	CD
11	11	SPC STATUS – PROCESSOR 0 – STORE BUS – SEND 0	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 8	CJ
		OFF NORMAL MAJOR – PST SET	CL
		HARDWARE CONFIGURATION – BUS 1 – 4	CF
		PROGRAM CONTROL – 7	CD
12	12	SPC STATUS – PROCESSOR 0 – STORE BUS – RCV 0	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 7	CJ
		OFF NORMAL MAJOR – MNT OFF	CL
		HARDWARE CONFIGURATION – BUS 1 – 5	CF
		PROGRAM CONTROL – 8	CD

TABLE L (Contd)

TSPS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
2	13	SPC STATUS – PROCESSOR 0 – STORE BUS – SEND 1	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 6	CJ
		OFF NORMAL MAJOR – FR OFF	CL
		HARDWARE CONFIGURATION – BUS 1 – 6	CF
		PROGRAM CONTROL – 9	CD
	14	SPC STATUS – PROCESSOR 0 – STORE BUS – RCV 1	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 5	CJ
		OFF NORMAL MAJOR – CLK OFF	CL
		HARDWARE CONFIGURATION – BUS 1 – 7	CF
		PROGRAM CONTROL – 10	CD
	15	SPC STATUS – PROCESSOR 1 – STOP	CG
		EMERGENCY RECOVERY – PROCESSOR 1 – 4	CJ
		OFF NORMAL MAJOR – INIT RESP	CL
		HARDWARE CONFIGURATION – STATE CONT	CF
		PROGRAM CONTROL – 11	CD
	16	CRITICAL – MAJOR – MINOR MUST FLASH	
		EMERGENCY RECOVERY – PROCESSOR 1 – 3	CJ
		OFF NORMAL MINOR – PRT INH	CL
		HARDWARE CONFIGURATION – SET MANUAL	CF
		PROGRAM CONTROL – 12	CD
	17	CIRITICAL – MAJOR – MINOR MUST FLASH	
		EMERGENCY RECOVERY – PROCESSOR 1 – 2	CJ
		OFF NORMAL MINOR – ABN TASK	CL
		HARDWARE CONFIGURATION – SC ANS BUS 0 SELECT	CF
		PROGRAM CONTROL – 13	CD
3	2	EMERGENCY RECOVERY – PROCESSOR 1 – 1	CK
		SPC STATUS – PROCESSOR 1 – CLK	CH
		OFF NORMAL MINOR – AMA SMP	CL
		HARDWARE CONFIGURATION – SC ANS BUS 1 SELECT	CF
		PROGRAM CONTROL – 14	CE

TABLE L (Contd)

TSPS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
3	3	SPC STATUS – PROCESSOR 1 – TBL	CH
		EMERGENCY RECOVERY – PROCESSOR 1 – 0	CK
		OFF NORMAL MINOR – TFC GEN	CL
		HARDWARE CONFIGURATION – INH ERROR DET	CF
		PROGRAM CONTROL – 15	CE
4	4	SPC STATUS – PROCESSOR 1 – OFF LINE	CH
		TSPS PERIPHERAL STATUS – TRUNK LINE – 0	CK
		OFF NORMAL MINOR – GROW ACT	CL
		PROGRAM CONTROL – 16	CE
		CD LAMP TEST	CF
5	5	SPC STATUS – PROCESSOR 1 – ACT	CH
		TSPS PERIPHERAL STATUS – TRUNK LINK – S	CK
		PROGRAM DISPLAY – PTD	CL
		PROGRAM CONTROL – 17	CE
		HARDWARE CONFIGURATION – PROC 1 ACTIVE	
6	6	SPC STATUS – PROCESSOR 1 – PWR	CH
		TSPS PERIPHERAL STATUS – POSITION LINK – P	CK
		PROGRAM DISPLAY – 19	CL
		PROCESSOR POWER – PROC 0 – POWER OFF	CF
		PROGRAM CONTROL – 18	CE
7	7	SPC STATUS – PROCESSOR 1 – STORE BUS – SEND 0	CH
		TSPS PERIPHERAL STATUS – POSITION LINK – S	CK
		PROGRAM DISPLAY – 18	CL
		PROCESSOR POWER – PROC 0 – 005	CF
		PROGRAM CONTROL – 19	CE
8	8	SPC STATUS – PROCESSOR 1 – STORE BUS – RCV 0	CH
		TSPS PERIPHERAL STATUS – MASTER SCAN – P	CK
		PROGRAM DISPLAY – 17	CL
		PROCESSOR POWER – PROC 0 – OFF NORMAL	CF

TABLE L (Contd)

TSPS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
3	9	SPC STATUS – PROCESSOR 1 – STORE BUS – SEND 1 TSPS PERIPHERAL STATUS – MASTER SCAN – S PROGRAM DISPLAY – 16 PROCESSOR POWER – PROC 1 – POWER OFF	CH CK CL CF
	10	SPC STATUS – PROCESSOR 1 – STORE BUS – RCV 1 TSPS PERIPHERAL STATUS – COMM BUS TRNSL – A PROGRAM DISPLAY – 15 PROCESSOR POWER – PROC 1 – 005 PROCESSOR POWER – PROC 0 – POWER OFF	CH CK CL CF CE
	11	SPC STATUS – STORE – P TSPS PERIPHERAL STATUS – COMM BUS TRNSL – B PROGRAM DISPLAY – 14 PROCESSOR POWER – PROC 1 – OFF NORMAL PROCESSOR POWER – PROC 0 – POWER ON	CH CK CL CF CE
	12	SYSTEM STATUS – CALL PROC RECOV SPC STATUS – STORE – S TSPS PERIPHERAL STATUS – AMA – A PROGRAM DISPLAY – 13 EMERGENCY ACTION – CALL PROC RECOV PROCESSOR POWER – PROC 1 – POWER OFF	CH CK CL CF CE
	13	SPC STATUS – CPD BUS PWR – 0 TSPS PERIPHERAL STATUS – AMA – B PROGRAM DISPLAY – 12 PROCESSOR POWER – PROC 1 – POWER ON	CH CK CL CE
	14	SPC STATUS – CPD BUS PWR – 1 TSPS PERIPHERAL STATUS – TIME OF DAY – A PROGRAM DISPLAY – 11 EMERGENCY ACTION – ENAB	CH CK CL CE

CH

TABLE L (Contd)

TSPS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
3	15	SPC STATUS – CPD – P TSPS PERIPHERAL STATUS – TIME OF DAY – B PROGRAM DISPLAY – 10 EMERGENCY ACTION – MNA HARDWARE CONFIGURATION – INV	CH CK CL CE CF
	16	SPC STATUS – CPD – S TSPS PERIPHERAL STATUS – UNIV TRUNK – P PROGRAM DISPLAY – 9 EMERGENCY ACTION – MJA HARDWARE CONFIGURATION – BUS 0 ACTIVE	CH CK CL CE CF
	17	SPC STATUS – STORE BUS PWR – 0 TSPS PERIPHERAL STATUS – UNIV TRUNK – S PROGRAM DISPLAY – 8 EMERGENCY ACTION – SIA HARDWARE CONFIGURATION – BUS 1 ACTIVE	CH CK CL CE CF
4	2	SPC STATUS – STORE BUS PWR – 1 TSPS PERIPHERAL STATUS – SOG – A PROGRAM DISPLAY – 7 EMERGENCY ACTION – SIB	CH CK CM CE
	3	SPC STATUS – SCAN ANS BUS ACT – 0 TSPS PERIPHERAL STATUS – SOG – B PROGRAM DISPLAY – 6 EMERGENCY ACTION – AA HARDWARE COMFIGURATION – SC ANS BUS 0 ACTIVE	CH CK CM CE CH
	4	SPC STATUS – SCAN ANS BUS ACT – 1 TSPS PERIPHERAL STATUS – MISC – P PROGRAM DISPLAY – 5 EMERGENCY ACTION – AB HARDWARE CONFIGURATION – SC ANS BUS 1 ACTIVE	CH CK CM CE CH

TABLE L (Contd)

TSPS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
4	5	SPC STATUS – MSC – 0 – P	CH
		TSPS PERIPHERAL STATUS – MISC – S	CK
		PROGRAM DISPLAY – 4	CM
		EMERGENCY ACTION – AC	CE
	6	SPC STATUS – MSC – 0 – S	CH
		CIRCUIT STATUS – UNIV TRKS	CK
		PROGRAM DISPLAY – 3	CM
		EMERGENCY ACTION – AD	CE
7	SPC STATUS – PTU – P	CH	
	CIRCUIT STATUS – SRV CKTS	CK	
	PROGRAM DISPLAY – 2	CM	
	EMERGENCY ACTION – AE	CE	
8	SPC STATUS – PUA BUS POWER – 0	CH	
	CIRCUIT STATUS – SPL TRKS	CK	
	PROGRAM DISPLAY – 1	CM	
	EMERGENCY ACTION – CLEAR EXEC	CE	
9	SPC STATUS – PUA BUS POWER – 1	CH	
	TRAFFIC STATUS – OVLD	CK	
	PROGRAM DISPLAY – 0	CM	
	HARDWARE CONFIGURATION – PROC 0 SELECT	CE	
10	SPC STATUS – MSD – P	CH	
	CIRCUIT STATUS – POS	CM	
	TRAFFIC STATUS – POS Q OVF	CK	
	HARDWARE CONFIGURATION – PROC 1 SELECT	CE	
11	SPC STATUS – MSD – S	CH	
	SUBSYSTEM STATUS – M	CK	
	HARDWARE CONFIGURATION – BUS 0 SELECT	CE	
12	EMERGENCY RECOVERY – PROCESSOR 0 – 19	CH	
	SUBSYSTEM STATUS – 0	CK	
	HARDWARE CONFIGURATION – BUS 1 SELECT	CE	

TABLE L (Contd)

TSPS – C&D CENTRAL GROUP REPORT COMMANDS

WORD	SWITCH	CONSOLE LAMPS AND KEYS LIGHTED	CP 17 LOCATION
4	13	EMERGENCY RECOVERY – PROCESSOR 0 – 18 SUBSYSTEM STATUS – 1 HARDWARE CONFIGURATION – BUS 0 – 0	CH CK CE
	14	EMERGENCY RECOVERY – PROCESSOR 0 – 17 SUBSYSTEM STATUS – 2 HARDWARE CONFIGURATION – BUS 0 – 1	CH CK CE
	15	EMERGENCY RECOVERY – PROCESSOR 0 – 16 SUBSYSTEM STATUS – 3 HARDWARE CONFIGURATION – BUS 0 – 2	CH CK CE
	16	EMERGENCY RECOVERY – PROCESSOR 0 – 15 SUBSYSTEM STATUS – 4 HARDWARE CONFIGURATION – BUS 0 – 3	CH CK CE
	17	CRITICAL – MAJOR – MINOR MUST FLASH EMERGENCY RECOVERY – PROCESSOR 0 – 14 SUBSYSTEM STATUS – 5	CH CK

TABLE M

NO. 1 ESS – C&D CENTRAL RELAY OUTPUT COMMANDS (LOCKING KEYS)

SWITCH NAME	E-TELEMETRY STATION TEST SET				INFORMATION LAMP STATUS				CP 21 LOCATION									
	1	2	3	4	5	6	7	8		9	10	11	12	13	14	15	16	17
HARDWARE CONFIGURATION – EA DIS T OUT	1	*	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	BA
TRAFFIC CONTROL – ENAB	1	*	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	BA
EMER MAN SRV	1	*	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	BA
PROGRAM CONTROL – BLK	1	*	0	0	0	1	1	0	0	0	0	0	0	0	0	0	0	BA
0	1	*	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0	BA
1	1	*	0	0	0	1	0	1	0	0	0	0	0	0	0	0	0	BA
2	1	*	0	0	0	0	1	1	0	0	0	0	0	0	0	0	0	BA
3	1	*	0	0	0	1	1	1	0	0	0	0	0	0	0	0	0	BA
4	1	*	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	BA
5	1	*	0	0	0	1	0	0	1	0	0	0	0	0	0	0	0	BA
6	1	*	0	0	0	0	1	0	1	0	0	0	0	0	0	0	0	BA
7	1	*	0	0	0	1	1	0	1	0	0	0	0	0	0	0	0	BA
8	1	*	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0	BA
9	1	*	0	0	0	1	0	1	1	0	0	0	0	0	0	0	0	BA
10	1	*	0	0	0	0	1	1	1	0	0	0	0	0	0	0	0	BA
11	1	*	0	0	0	1	1	1	1	0	0	0	0	0	0	0	0	BA
12	1	*	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	BA
13	1	*	0	0	0	1	0	0	0	1	0	0	0	0	0	0	0	BA
14	1	*	0	0	0	0	1	0	0	1	0	0	0	0	0	0	0	BA
15	1	*	0	0	0	1	1	0	0	1	0	0	0	0	0	0	0	BA
16	1	*	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0	BA

Legend:

1 – Lamp lighted

0 – Lamp off

* – Lamp lighted for operate or off for release

TABLE M (Contd)

NO. 1 ESS – C&D CENTRAL RELAY OUTPUT COMMANDS (LOCKING KEYS)

SWITCH NAME	E-TELEMETRY STATION TEST SET INFORMATION LAMP STATUS																CP 21 LOCATION	
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		17
17	1	*	0	0	0	1	0	1	0	1	0	0	0	0	0	0	0	BA
18	1	*	0	0	0	0	1	1	0	1	0	0	0	0	0	0	0	BA
19	1	*	0	0	0	1	1	1	0	1	0	0	0	0	0	0	0	BA
20	1	*	0	0	0	0	0	0	1	1	0	0	0	0	0	0	0	BA
21	1	*	0	0	0	1	0	0	1	1	0	0	0	0	0	0	0	BA
22	1	*	0	0	0	0	1	0	1	1	0	0	0	0	0	0	0	BA

Legend:

1 – Lamp lighted

0 – Lamp off

* – Lamp lighted for operate or off for release

TABLE N

TSPS – C&D CENTRAL RELAY OUTPUT COMMANDS (LOCKING KEYS)

SWITCH (KEY) NAME	E-TELEMETRY STATION TEST SET INFORMATION LAMP STATUS																CP 21 LOCATION	
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		17
EA DIS T OUT	1	*	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	CA
BLK	1	*	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	CA
0	1	*	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	CA
1	1	*	0	0	0	1	1	0	0	0	0	0	0	0	0	0	0	CA
2	1	*	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0	CA
3	1	*	0	0	0	1	0	1	0	0	0	0	0	0	0	0	0	CA
4	1	*	0	0	0	0	1	1	0	0	0	0	0	0	0	0	0	CA
5	1	*	0	0	0	1	1	1	0	0	0	0	0	0	0	0	0	CA
6	1	*	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	CA
7	1	*	0	0	0	1	0	0	1	0	0	0	0	0	0	0	0	CA
8	1	*	0	0	0	0	1	0	1	0	0	0	0	0	0	0	0	CA
9	1	*	0	0	0	1	1	0	1	0	0	0	0	0	0	0	0	CA
10	1	*	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0	CA
11	1	*	0	0	0	1	0	1	1	0	0	0	0	0	0	0	0	CA
12	1	*	0	0	0	0	1	1	1	0	0	0	0	0	0	0	0	CA
13	1	*	0	0	0	1	1	1	1	0	0	0	0	0	0	0	0	CA
14	1	*	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	CA
15	1	*	0	0	0	1	0	0	0	1	0	0	0	0	0	0	0	CA
16	1	*	0	0	0	0	1	0	0	1	0	0	0	0	0	0	0	CA
17	1	*	0	0	0	1	1	0	0	1	0	0	0	0	0	0	0	CA
18	1	*	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0	CA
19	1	*	0	0	0	1	0	1	0	1	0	0	0	0	0	0	0	CA

Legend:

1 – Lamp lighted

0 – Lamp off

* – Lamp lighted for operate or off for release as specified by test

TABLE O

NO. 2 ESS/AIS – C&D CENTRAL RELAY OUTPUT COMMANDS (LOCKING KEYS)

SWITCH (KEY) NAME	E-TELEMETRY STATION TEST SET				INFORMATION LAMP STATUS				CP-21 LOCATION									
	1	2	3	4	5	6	7	8		9	10	11	12	13	14	15	16	17
COMP. INPUT SWITCHES 0	1	*	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	CA
1	1	*	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	CA
2	1	*	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	CA
3	1	*	0	0	0	1	1	0	0	0	0	0	0	0	0	0	0	CA
4	1	*	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0	CA
5	1	*	0	0	0	1	0	1	0	0	0	0	0	0	0	0	0	CA
6	1	*	0	0	0	0	1	1	0	0	0	0	0	0	0	0	0	CA
7	1	*	0	0	0	1	1	1	0	0	0	0	0	0	0	0	0	CA
8	1	*	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	CA
9	1	*	0	0	0	1	0	0	1	0	0	0	0	0	0	0	0	CA
10	1	*	0	0	0	0	1	0	1	0	0	0	0	0	0	0	0	CA
11	1	*	0	0	0	1	1	0	1	0	0	0	0	0	0	0	0	CA
12	1	*	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0	CA
13	1	*	0	0	0	1	0	1	1	0	0	0	0	0	0	0	0	CA
14	1	*	0	0	0	0	1	1	1	0	0	0	0	0	0	0	0	CA
15	1	*	0	0	0	1	1	1	1	0	0	0	0	0	0	0	0	CA
16	1	*	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	CA
17	1	*	0	0	0	1	0	0	0	1	0	0	0	0	0	0	0	CA
18	1	*	0	0	0	0	1	0	0	1	0	0	0	0	0	0	0	CA
19	1	*	0	0	0	1	1	0	0	1	0	0	0	0	0	0	0	CA
20	1	*	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0	CA
21	1	*	0	0	0	1	0	1	0	1	0	0	0	0	0	0	0	CA

Legend:

1 – Lamp lighted

0 – Lamp off

* – Lamp lighted for operate or off for release as specified by test

TABLE O (Contd)

NO. 2 ESS/AIS – C&D CENTRAL RELAY OUTPUT COMMANDS (LOCKING KEYS)

SWTCH (KEY) NAME	E-TELEMETRY STATION TEST SET				INFORMATION LAMP STATUS				CP 21 LOCATION									
	1	2	3	4	5	6	7	8		9	10	11	12	13	14	15	16	17
EMERGENCY ACTION ENABLE	1	*	0	0	0	0	1	1	0	1	0	0	0	0	0	0	0	CA
STABLE	1	*	0	0	0	1	1	1	0	1	0	0	0	0	0	0	0	CA
REC CHG TAPE	1	*	0	0	0	0	0	0	1	1	0	0	0	0	0	0	0	CA
LINE TRFR	1	*	0	0	0	1	0	0	1	1	0	0	0	0	0	0	0	CA
POWER	1	*	0	0	0	0	1	0	1	1	0	0	0	0	0	0	0	CA
LOCK CU 0 ACT	1	*	0	0	0	1	1	0	1	1	0	0	0	0	0	0	0	CA
LOCK CU 1 ACT	1	*	0	0	0	0	0	1	1	1	0	0	0	0	0	0	0	CA
TRI ON	1	*	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	CB
REM MTCE	1	*	0	0	0	1	0	0	0	0	1	0	0	0	0	0	0	CB
LOC MTCE	1	*	0	0	0	0	1	0	0	0	1	0	0	0	0	0	0	CB
CMPR PA – CIS	1	*	0	0	0	1	1	0	0	0	1	0	0	0	0	0	0	CB
CMPR CSA – CIS	1	*	0	0	0	0	0	1	0	0	1	0	0	0	0	0	0	CB
DYN PS READ	1	*	0	0	0	1	0	1	0	0	1	0	0	0	0	0	0	CB
DYN CS READ	1	*	0	0	0	0	1	1	0	0	1	0	0	0	0	0	0	CB
ON LINE INIT	1	*	0	0	0	1	1	1	0	0	1	0	0	0	0	0	0	CB

Legend:

1 – Lamp lighted

0 – Lamp off

* – Lamp lighted for operate or off for release as specified by test

TABLE P

NO. 1 ESS - C&D CENTRAL RELAY OUTPUT COMMANDS (NONLOCKING KEYS)

SWITCH NAME	E-TELEMETRY STATION TEST SET				INFORMATION LAMP STATUS				CP 21 LOCATION									
	1	2	3	4	5	6	7	8		9	10	11	12	13	14	15	16	17
ALL LAMPS OFF	1	*	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	BA
ALL LAMPS ON	1	*	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	BA
PROGRAM INTERRUPT CONTROL -ENAB	1	*	0	0	0	0	1	0	1	1	1	0	0	0	0	0	0	BA
HARDWARE CONFIGURATION -CC 0 SEL ACT	1	*	0	0	0	0	0	1	1	1	1	1	0	0	0	0	0	BA
-CC 1 SEL ACT	1	*	0	0	0	0	1	1	1	1	1	1	0	0	0	0	0	BA
PROGRAM INTERRUPT CONTROL -A	1	*	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	BB
-B	1	*	0	0	0	0	1	0	0	0	0	0	1	0	0	0	0	BB
-C	1	*	0	0	0	0	0	1	0	0	0	0	1	0	0	0	0	BB
-D	1	*	0	0	0	0	1	1	0	0	0	0	1	0	0	0	0	BB
-E	1	*	0	0	0	0	0	0	1	0	0	0	1	0	0	0	0	BB
-F	1	*	0	0	0	0	1	0	1	0	0	0	1	0	0	0	0	BB
-CLR EX	1	*	0	0	0	0	0	1	1	0	0	0	1	0	0	0	0	BB
HARDWARE CONFIGURATION - STOP SPO	1	*	0	0	0	0	1	1	1	0	0	0	1	0	0	0	0	BB
-STOP SP1	1	*	0	0	0	0	0	0	0	1	0	0	1	0	0	0	0	BB
-PSB0 PWR OFF	1	*	0	0	0	0	1	0	0	1	0	0	1	0	0	0	0	BB
-PSB1 PWR OFF	1	*	0	0	0	0	0	1	0	1	0	0	1	0	0	0	0	BB
-CSB0 PWR OFF	1	*	0	0	0	0	1	1	0	1	0	0	1	0	0	0	0	BB
-CSB1 PWR OFF	1	*	0	0	0	0	0	0	1	1	0	0	1	0	0	0	0	BB
-SET MAN	1	*	0	0	0	0	1	0	1	1	0	0	1	0	0	0	0	BB
CO ALM RLS	1	*	0	0	0	0	0	1	1	1	0	0	1	0	0	0	0	BB

Legend:

1 - Lamp lighted

0 - Lamp off

* - Lamp lighted for operate or off for release

TABLE Q

NO. 2 ESS/AIS – C&D CENTRAL RELAY OUTPUT COMMANDS (NONLOCKING KEYS)

SWITCH (KEY) NAME	E-TELEMETRY STATION TEST SET				INFORMATION LAMP STATUS				CP 21 LOCATION									
	1	2	3	4	5	6	7	8		9	10	11	12	13	14	15	16	17
ALL LAMPS OFF	1	*	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	CB
ALL LAMPS ON	1	*	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	CB
CU 0 ACT	1	*	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0	CB
CU 1 ACT	1	*	0	0	0	0	1	1	0	1	0	0	0	0	0	0	0	CB
RESET	1	*	0	0	0	0	0	0	1	1	0	0	0	0	0	0	0	CB
CLEAR BUFFER	1	*	0	0	0	0	1	0	0	0	1	1	0	0	0	0	0	CB
SYSTEM RESET & CLEAR	1	*	0	0	0	0	0	1	0	0	1	1	0	0	0	0	0	CB
PF	1	*	0	0	0	0	1	1	0	0	1	1	0	0	0	0	0	CB
MAN.	1	*	0	0	0	0	0	0	1	0	1	1	0	0	0	0	0	CB
NORM	1	*	0	0	0	0	1	0	1	0	1	1	0	0	0	0	0	CB
PROG EXEC	1	*	0	0	0	0	0	1	1	0	1	1	0	0	0	0	0	CB
INHIBIT AUTO DISPLAY	1	*	0	0	0	0	1	1	1	0	1	1	0	0	0	0	0	CB
READY	1	*	0	0	0	0	0	0	0	1	1	1	0	0	0	0	0	CB
GO	1	*	0	0	0	0	1	0	0	1	1	1	0	0	0	0	0	CB
TTY INIT	1	*	0	0	0	0	0	1	0	1	1	1	0	0	0	0	0	CB

Legend:

1 – Lamp lighted

0 – Lamp off

* – Lamp lighted for operate or off for release

TABLE R

TSPS – C&D CENTRAL RELAY OUTPUT COMMANDS (NONLOCKING KEYS)

SWITCH (KEY) NAME	E-TELEMETRY STATION TEST SET				INFORMATION LAMP STATUS				CP 21 LOCATION									
	1	2	3	4	5	6	7	8		9	10	11	12	13	14	15	16	17
ALL LAMPS OFF	1	*	0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	CA
ALL LAMPS ON	1	*	0	0	0	1	1	1	1	1	1	1	1	1	1	1	1	CA
PROC 0 POWER OFF	1	*	0	0	0	0	0	0	1	1	0	0	0	0	0	0	0	CA
PROC 0 POWER ON	1	*	0	0	0	1	0	0	1	1	0	0	0	0	0	0	0	CA
PROC 1 POWER OFF	1	*	0	0	0	0	1	0	1	1	0	0	0	0	0	0	0	CA
PROC 1 POWER ON	1	*	0	0	0	1	1	0	1	1	0	0	0	0	0	0	0	CA
ENAB	1	*	0	0	0	0	0	1	1	1	0	0	0	0	0	0	0	CA
MNA	1	*	0	0	0	1	0	1	1	1	0	0	0	0	0	0	0	CA
MJA	1	*	0	0	0	0	1	1	1	1	0	0	0	0	0	0	0	CA
SIA	1	*	0	0	0	1	1	1	1	1	0	0	0	0	0	0	0	CA
SIB	1	*	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	CB
AA	1	*	0	0	0	1	0	0	0	0	1	0	0	0	0	0	0	CB
AB	1	*	0	0	0	0	1	0	0	0	1	0	0	0	0	0	0	CB
AC	1	*	0	0	0	1	1	0	0	0	1	0	0	0	0	0	0	CB
AD	1	*	0	0	0	0	0	1	0	0	1	0	0	0	0	0	0	CB
AE	1	*	0	0	0	1	0	1	0	0	1	0	0	0	0	0	0	CB
CLEAR EXEC	1	*	0	0	0	0	1	1	0	0	1	0	0	0	0	0	0	CB
PROC 0 SELECT	1	*	0	0	0	1	1	1	0	0	1	0	0	0	0	0	0	CB
PROC 1 SELECT	1	*	0	0	0	0	0	0	1	0	1	0	0	0	0	0	0	CB
BUS 0 SELECT	1	*	0	0	0	1	0	0	1	0	1	0	0	0	0	0	0	CB
BUS 1 SELECT	1	*	0	0	0	0	1	0	1	0	1	0	0	0	0	0	0	CB
BUS 0 0	1	*	0	0	0	1	1	0	1	0	1	0	0	0	0	0	0	CB
BUS 0 1	1	*	0	0	0	0	0	1	1	0	1	0	0	0	0	0	0	CB

Legend:

1 – Lamp lighted

0 – Lamp off

* – Lamp lighted for operate or off for release

TABLE R (Contd)

TSPS – C&D CENTRAL RELAY OUTPUT COMMANDS (NONLOCKING KEYS)

SWITCH (KEY) NAME	E-TELEMETRY STATION TEST SET INFORMATION LAMP STATUS																CP 21 LOCATION	
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		17
BUS 0 2	1	*	0	0	0	1	0	1	1	0	1	0	0	0	0	0	0	CB
BUS 0 3	1	*	0	0	0	0	1	1	1	0	1	0	0	0	0	0	0	CB
BUS 0 4	1	*	0	0	0	1	0	0	0	1	1	0	0	0	0	0	0	CB
BUS 0 5	1	*	0	0	0	0	1	0	0	1	1	0	0	0	0	0	0	CB
BUS 0 6	1	*	0	0	0	1	1	0	0	1	1	0	0	0	0	0	0	CB
BUS 0 7	1	*	0	0	0	0	0	1	0	1	1	0	0	0	0	0	0	CB
BUS 1 0	1	*	0	0	0	1	0	1	0	1	1	0	0	0	0	0	0	CB
BUS 1 1	1	*	0	0	0	0	1	1	0	1	1	0	0	0	0	0	0	CB
BUS 1 2	1	*	0	0	0	1	1	1	0	1	1	0	0	0	0	0	0	CB
BUS 1 3	1	*	0	0	0	0	0	0	1	1	1	0	0	0	0	0	0	CB
BUS 1 4	1	*	0	0	0	1	0	0	1	1	1	0	0	0	0	0	0	CB
BUS 1 5	1	*	0	0	0	0	1	0	1	1	1	0	0	0	0	0	0	CB
BUS 1 6	1	*	0	0	0	1	1	0	1	1	1	0	0	0	0	0	0	CB
BUS 1 7	1	*	0	0	0	0	0	1	1	1	1	0	0	0	0	0	0	CB
STATE CONT	1	*	0	0	0	1	0	1	1	1	1	0	0	0	0	0	0	CB
SET MANUAL	1	*	0	0	0	0	1	1	1	1	1	0	0	0	0	0	0	CB
SC ANS BUS 0 SELECT	1	*	0	0	0	1	1	1	1	1	1	0	0	0	0	0	0	CB
SC ANS BUS 1 SELECT	1	*	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	CC
INH ERROR DET	1	*	0	0	0	1	0	0	0	0	0	1	0	0	0	0	0	CC
CD LAMP REST	1	*	0	0	0	0	1	0	0	0	0	1	0	0	0	0	0	CC
ALARM RESET	1	*	0	0	0	1	1	0	0	0	0	1	0	0	0	0	0	CC

Legend:

1 – Lamp lighted

0 – Lamp off

* – Lamp lighted for operate or off for release

TABLE S

NO. 1 ESS – REMOTE STATUS POINTS

E-TELEMETRY STATION TEST SET WORD 1 SWITCH SETTINGS					DISPLAY WORD SELECT SWITCH POSITION	ASSOCIATED CPs	
SWITCH NUMBER						CP NO.	CP LOCATION
13	14	15	16	17			
0	0	0	0	0	1	6	AA
0	0	0	0	0	2	6	AB
0	0	0	0	0	3	6	AC
0	0	0	0	0	4	6	AD
0	0	0	0	1	1	10*	CC
0	0	0	0	1	2	10*	CD
0	0	0	0	1	3	9*	CE
0	0	0	0	1	4	9*	CE
0	0	0	1	0	1	9*	CF
0	0	0	1	0	2	9*	CF
0	0	0	1	0	3	9*	CG
0	0	0	1	0	4	9*	CG
0	0	0	1	0	5	9*	CH
0	0	0	1	0	6	9*	CH
0	0	0	0	0	5	9	GC
0	0	0	0	0	6	9	GC
0	0	0	1	0	7	9	GD
0	0	0	1	0	8	9	GD

* In addition to CP 9 or CP 10, replace CP 7 in location AH. Determine the defective CP as described in Step 10.

TABLE T

NO. 2 ESS/AIS – REMOTE STATUS POINTS

E-TELEMETRY STATION TEST SET WORD 1 SWITCH SETTINGS					DISPLAY WORD SELECT SWITCH POSITION	ASSOCIATED CPs	
SWITCH NUMBER						CP NO.	CP LOCATION
13	14	15	16	17			
0	0	0	0	0	1	6	AA
0	0	0	0	0	2	6	AB
0	0	0	0	0	3	6	AC
0	0	0	0	0	4	6	AD
0	0	0	0	0	5	9	FA
0	0	0	0	0	6	9	FA
0	0	0	0	1	1	9	EA
0	0	0	0	1	2	9	EA
0	0	0	0	1	3	53	EB
0	0	0	0	1	4	53	EB
0	0	0	1	0	1	9	FB
0	0	0	1	0	2	9	FB
0	0	0	1	0	3	9	FC
0	0	0	1	0	4	9	FC
0	0	0	1	1	1	6	AA

TABLE U

NO. 2B/3 ESS -- REMOTE STATUS POINTS

E-TELEMETRY STATION TEST SET WORD 1 SWITCH SETTINGS					DISPLAY WORD SELECT SWITCH POSITION	ASSOCIATED CPs	
SWITCH NUMBER						CP NO.	CO LOCATION
13	14	15	16	17			
0	0	0	0	0	1	37	AA
0	0	0	0	0	2	37	AB
0	0	0	0	0	3	37	AC
0	0	0	0	0	4	37	AD
0	0	0	0	0	5	9	FA
0	0	0	0	0	6	9	FA
0	0	0	0	1	1	35	EA
0	0	0	0	1	2	35	EA
0	0	0	0	1	3	35	EB
0	0	0	0	1	4	35	EB
0	0	0	1	1	1	37	AA

TABLE V

TSPS – REMOTE STATUS POINTS

E-TELEMETRY STATION TEST SET WORD 1 SWITCH SETTINGS					DISPLAY WORD SELECT SWITCH POSITION	ASSOCIATED CPs	
SWITCH NUMBER						CP NO.	CP LOCATION
13	14	15	16	17			
0	0	0	0	0	1	6	AA
0	0	0	0	0	2	6	AB
0	0	0	0	0	3	6	AC
0	0	0	0	0	4	6	AD
0	0	0	0	0	5	9	FA
0	0	0	0	0	6	9	FA
0	0	0	0	1	1	9	EA
0	0	0	0	1	2	9	EA
0	0	0	0	1	3	9	EB
0	0	0	0	1	4	9	EB
0	0	0	1	0	1	9	FB
0	0	0	1	0	2	9	FB
0	0	0	1	0	3	9	FC
0	0	0	1	0	4	9	FC
0	0	0	1	0	5	9	FD
0	0	0	1	0	6	9	FD
0	0	0	1	0	7	9	FE
0	0	0	1	0	8	9	FE
0	0	0	1	1	1	9	AA

TABLE W

NO. 1A ESS – REMOTE STATUS POINTS

E-TELEMETRY STATION TEST SET WORD 1 SWITCH SETTINGS					DISPLAY WORD SELECT SWITCH POSITION	ASSOCIATED CPs		
SWITCH NUMBER						CP NO.	CP LOCATION	MODULE*
13	14	15	16	17				
0	0	0	0	0	1	37	AA	BRM
0	0	0	0	0	2	37	AB	BRM
0	0	0	0	0	3	37	AC	BRM
0	0	0	0	0	4	37	AD	BRM
0	0	0	0	0	5	35	BA	2nd Exp
0	0	0	0	0	6	35	BA	2nd Exp
0	0	0	0	0	7	35	BB	2nd Exp
0	0	0	0	0	8	35	BB	2nd Exp
0	0	0	0	0	9	35	BC	2nd Exp
0	0	0	0	0	10	35	BC	2nd Exp
0	0	0	0	1	1	35	BD	2nd Exp
0	0	0	0	1	2	35	BD	2nd Exp
0	0	0	0	1	3	35	BE	2nd Exp
0	0	0	0	1	4	35	BE	2nd Exp
0	0	0	0	1	5	35	BF	2nd Exp
0	0	0	0	1	6	35	BF	2nd Exp
0	0	0	0	1	7	35	BG	2nd Exp
0	0	0	0	1	8	35	BG	2nd Exp
0	0	0	1	0	1	35	BA	3rd Exp
0	0	0	1	0	2	35	BA	3rd Exp

*BRM = Basic remote module (located lower right)
 2nd Exp = Second expander module 1 (located upper left)
 3rd Exp = Third expander module 1 (located upper right)

TABLE W (Contd)

NO. 1A ESS – REMOTE STATUS POINTS

E-TELEMETRY STATION TEST SET WORD 1 SWITCH SETTINGS					DISPLAY WORD SELECT SWITCH POSITION	ASSOCIATED CPs		
SWITCH NUMBER						CP NO.	CP LOCATION	MODULE*
13	14	15	16	17				
0	0	0	1	0	3	35	BB	3rd Exp
0	0	0	1	0	4	35	BB	3rd Exp
0	0	0	1	0	5	35	BC	3rd Exp
0	0	0	1	0	6	35	BC	3rd Exp
0	0	0	1	0	7	35	BD	3rd Exp
0	0	0	1	0	8	35	BD	3rd Exp
0	0	0	1	1	1	37	AA	BRM

*BRM = Basic remote module (located lower right)

3rd Exp = Third expander module 1 (located upper right)

TABLE X

NO. 1 ESS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING		INSERT PLUG-IN	SET WORD 3 SWITCHES						LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	
6	AA	LIST 12	0	0	0	0	0	0	1
6			1	0	0	0	0	0	2
6			0	1	0	0	0	0	3
6			1	1	0	0	0	0	4
6	AA	LIST 12	0	0	1	0	0	0	5
6			1	0	1	0	0	0	6
6			0	1	1	0	0	0	7
6			1	1	1	0	0	0	8
6	AB	LIST 12	0	0	0	1	0	0	1
6			1	0	0	1	0	0	2
6			0	1	0	1	0	0	3
6			1	1	0	1	0	0	4
6	AB	LIST 12	0	0	1	1	0	0	5
6			1	0	1	1	0	0	6
6			0	1	1	1	0	0	7
6			1	1	1	1	0	0	8
6	AC	LIST 12	0	0	0	0	1	0	1
6			1	0	0	0	1	0	2
6			0	1	0	0	1	0	3
6			1	1	0	0	1	0	4
6	AC	LIST 12	0	0	1	0	1	0	5
6			1	0	1	0	1	0	6
6			0	1	1	0	1	0	7
6			1	1	1	0	1	0	8
6	AD	LIST 12	0	0	0	1	1	0	1
6			1	0	0	1	1	0	2
6			0	1	0	1	1	0	3
6			1	1	0	1	1	0	4
6	AD	LIST 12	0	0	1	1	1	0	5
6			1	0	1	1	1	0	6
6			0	1	1	1	1	0	7
6			1	1	1	1	1	0	8

TABLE Y

NO. 2 ESS/AIS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING		INSERT PLUG-IN	SET WORD 3 SWITCHES						LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	
6	AA	LIST 12	0	0	0	0	0	0	1
			1	0	0	0	0	0	2
			0	1	0	0	0	0	3
			1	1	0	0	0	0	4
6	AA	LIST 12	0	0	1	0	0	0	5
			1	0	1	0	0	0	6
			0	1	1	0	0	0	7
			1	1	1	0	0	0	8
6	AB	LIST 12	0	0	0	1	0	0	1
			1	0	0	1	0	0	2
			0	1	0	1	0	0	3
			1	1	0	1	0	0	4
6	AB	LIST 12	0	0	1	1	0	0	5
			1	0	1	1	0	0	6
			0	1	1	1	0	0	7
			1	1	1	1	0	0	8
6	AC	LIST 12	0	0	0	0	1	0	1
			1	0	0	0	1	0	2
			0	1	0	0	1	0	3
			1	1	0	0	1	0	4
6	AC	LIST 12	0	0	1	0	1	0	5
			1	0	1	0	1	0	6
			0	1	1	0	1	0	7
			1	1	1	0	1	0	8
6	AD	LIST 12	0	0	0	1	1	0	1
			1	0	0	1	1	0	2
			0	1	0	1	1	0	3
			1	1	0	1	1	0	4
6	AD	LIST 12	0	0	1	1	1	0	5
			1	0	1	1	1	0	6
			0	1	1	1	1	0	7
			1	1	1	1	1	0	8

TABLE Z

NO. 2B/3 ESS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING		INSERT PLUG-IN	SET WORD 3 SWITCHES						LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	
37	AA	LIST 12	0	0	0	0	0	0	1
			1	0	0	0	0	0	2
			0	1	0	0	0	0	3
			1	1	0	0	0	0	4
37	AA	LIST 12	0	0	1	0	0	0	5
			1	0	1	0	0	0	6
			0	1	1	0	0	0	7
			1	1	1	0	0	0	8
37	AB	LIST 12	0	0	0	1	0	0	1
			1	0	0	1	0	0	2
			0	1	0	1	0	0	3
			1	1	0	1	0	0	4
37	AB	LIST 12	0	0	1	1	0	0	5
			1	0	1	1	0	0	6
			0	1	1	1	0	0	7
			1	1	1	1	0	0	8
37	AC	LIST 12	0	0	0	0	1	0	1
			1	0	0	0	1	0	2
			0	1	0	0	1	0	3
			1	1	0	0	1	0	4
37	AC	LIST 12	0	0	1	0	1	0	5
			1	0	1	0	1	0	6
			0	1	1	0	1	0	7
			1	1	1	0	1	0	8
37	AD	LIST 12	0	0	0	1	1	0	1
			1	0	0	1	1	0	2
			0	1	0	1	1	0	3
			1	1	0	1	1	0	4
37	AD	LIST 12	0	0	1	1	1	0	1
			1	0	1	1	1	0	2
			0	1	1	1	1	0	3
			1	1	1	1	1	0	4

TABLE AA

TSPS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING		INSERT PLUG-IN	SET WORD 3 SWITCHES						LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	
6	AA	LIST 12	0	0	0	0	0	0	1
			1	0	0	0	0	0	2
			0	1	0	0	0	0	3
			1	1	0	0	0	0	4
6	AA	LIST 12	0	0	1	0	0	0	5
			1	0	1	0	0	0	6
			0	1	1	0	0	0	7
			1	1	1	0	0	0	8
6	AB	LIST 12	0	0	0	1	0	0	1
			1	0	0	1	0	0	2
			0	1	0	1	0	0	3
			1	1	0	1	0	0	4
6	AB	LIST 12	0	0	1	1	0	0	5
			1	0	1	1	0	0	6
			0	1	1	1	0	0	7
			1	1	1	1	0	0	8
6	AC	LIST 12	0	0	0	0	1	0	1
			1	0	0	0	1	0	2
			0	1	0	0	1	0	3
			1	1	0	0	1	0	4
6	AC	LIST 12	0	0	1	0	1	0	5
			1	0	1	0	1	0	6
			0	1	1	0	1	0	7
			1	1	1	0	1	0	8
6	AD	LIST 12	0	0	0	1	1	0	1
			1	0	0	1	1	0	2
			0	1	0	1	1	0	3
			1	1	0	1	1	0	4
6	AD	LIST 12	0	0	1	1	1	0	5
			1	0	1	1	1	0	6
			0	1	1	1	1	0	7
			1	1	1	1	1	0	8

TABLE AB

NO. 1 ESS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING BRM		INSERT PLUG-IN	SET WORD 3 SWITCHES										LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	12	13	14		
37	AA	LIST 12	0	0	0	0	0	0	0	0	0	0	1 2 3 4
			1	0	0	0	0	0	0	0	0	0	
			0	1	0	0	0	0	0	0	0	0	
			1	1	0	0	0	0	0	0	0	0	
37	AA	LIST 12	0	0	1	0	0	0	0	0	0	0	5 6 7 8
			1	0	1	0	0	0	0	0	0	0	
			0	1	1	0	0	0	0	0	0	0	
			1	1	1	0	0	0	0	0	0	0	
37	AB	LIST 12	0	0	0	1	0	0	0	0	0	0	1 2 3 4
			1	0	0	1	0	0	0	0	0	0	
			0	1	0	1	0	0	0	0	0	0	
			1	1	0	1	0	0	0	0	0	0	
37	AB	LIST 12	0	0	1	1	0	0	0	0	0	0	5 6 7 8
			1	0	1	1	0	0	0	0	0	0	
			0	1	1	1	0	0	0	0	0	0	
			1	1	1	1	0	0	0	0	0	0	
37	AC	LIST 12	0	0	0	0	1	0	0	0	0	0	1 2 3 4
			1	0	0	0	1	0	0	0	0	0	
			0	1	0	0	1	0	0	0	0	0	
			1	1	0	0	1	0	0	0	0	0	
37	AC	LIST 12	0	0	1	0	1	0	0	0	0	0	5 6 7 8
			1	0	1	0	1	0	0	0	0	0	
			0	1	1	0	1	0	0	0	0	0	
			1	1	1	0	1	0	0	0	0	0	
37	AD	LIST 12	0	0	0	1	1	0	0	0	0	0	1 2 3 4
			1	0	0	1	1	0	0	0	0	0	
			0	1	0	1	1	0	0	0	0	0	
			1	1	0	1	1	0	0	0	0	0	
37	AD	LIST 12	0	0	1	1	1	0	0	0	0	0	5 6 7 8
			1	0	1	1	1	0	0	0	0	0	
			0	1	1	1	1	0	0	0	0	0	
			1	1	1	1	1	0	0	0	0	0	

TABLE AC

NO. 1 ESS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING		INSERT PLUG-IN	SET WORD 3 SWITCHES							LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	12	
11	CB	K1-5	0	0	0	0	0	1	0	1
11			1	0	0	0	0	1	0	2
11			0	1	0	0	0	1	0	3
11			1	1	0	0	0	1	0	4
11	CB	K1-5	0	0	1	0	0	1	0	5
11			1	0	1	0	0	1	0	6
11			0	1	1	0	0	1	0	7
11			1	1	1	0	0	1	0	8
11	CB	K1-5	0	0	0	1	0	1	0	9
11			1	0	0	1	0	1	0	10
11			0	1	0	1	0	1	0	11
11			1	1	0	1	0	1	0	12
11	CB	K1-5	0	0	1	1	0	1	0	13
11			1	0	1	1	0	1	0	14
11			0	1	1	1	0	1	0	15
11			1	1	1	1	0	1	0	16
11	GA	K1-5	0	0	0	0	1	1	0	1
11			1	0	0	0	1	1	0	2
11			0	1	0	0	1	1	0	3
11			1	1	0	0	1	1	0	4
11	GA	K1-5	0	0	1	0	1	1	0	5
11			1	0	1	0	1	1	0	6
11			0	1	1	0	1	1	0	7
11			1	1	1	0	1	1	0	8
11	GA	K1-5	0	0	0	1	1	1	0	9
11			1	0	0	1	1	1	0	10
11			0	1	0	1	1	1	0	11
11			1	1	0	1	1	1	0	12

TABLE AC (Contd)

NO. 1 ESS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING		INSERT PLUG-IN	SET WORD 3 SWITCHES							LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	12	
11	GA	K1-5	0	0	1	1	1	1	0	13
11			1	0	1	1	1	1	0	14
11			0	1	1	1	1	1	0	15
11			1	1	1	1	1	1	0	16
11	GB	K1-5	0	0	0	0	0	0	1	1
11			1	0	0	0	0	0	1	2
11			0	1	0	0	0	0	1	3
11			1	1	0	0	0	0	1	4
11	GB	K1-5	0	0	1	0	0	0	1	5
11			1	0	1	0	0	0	1	6
11			0	1	1	0	0	0	1	7
11			1	1	1	0	0	0	1	8
11	GB	K1-5	0	0	0	1	0	0	1	9
11			1	0	0	1	0	0	1	10
11			0	1	0	1	0	0	1	11
11			1	1	0	1	0	0	1	12
11	GB	K1-5	0	0	1	1	0	0	1	13
11			1	0	1	1	0	0	1	14
11			0	1	1	1	0	0	1	15
11			1	1	1	1	0	0	1	16

TABLE AD

NO. 2 ESS/AIS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING		INSERT PLUG-IN	SET WORD 3 SWITCHES						LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	
11	FG	LIST 13	0	0	0	0	0	1	1
			1	0	0	0	0	1	2
			0	1	0	0	0	1	3
			1	1	0	0	0	1	4
11	FG	LIST 13	0	0	1	0	0	1	5
			1	0	1	0	0	1	6
			0	1	1	0	0	1	7
			1	1	1	0	0	1	8
11	FG	LIST 13	0	0	0	1	0	1	9
			1	0	0	1	0	1	10
			0	1	0	1	0	1	11
			1	1	0	1	0	1	12
11	FG	LIST 13	0	0	1	1	0	1	13
			1	0	1	1	0	1	14
			0	1	1	1	0	1	15
			1	1	1	1	0	1	16
11	FH	LIST 13	0	0	0	0	1	1	1
			1	0	0	0	1	1	2
			0	1	0	0	1	1	3
			1	1	0	0	1	1	4
11	FH	LIST 13	0	0	1	0	1	1	5
			1	0	1	0	1	1	6
			0	1	1	0	1	1	7
			1	1	1	0	1	1	8
11	FH	LIST 13	0	0	0	1	1	1	9
			1	0	0	1	1	1	10
			0	1	0	1	1	1	11
			1	1	0	1	1	1	12
11	FH	LIST 13	0	0	1	1	1	1	13
			1	0	1	1	1	1	14
			0	1	1	1	1	1	15
			1	1	1	1	1	1	16

TABLE AE

TSPS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING		INSERT PLUG-IN	SET WORD 3 SWITCHES						LAMP ON PLUG-IN	
CP	LOC		6	7	8	9	10	11		12
11	FG	LIST 13	0	0	0	0	0	1	0	1 2 3 4
			1	0	0	0	0	1	0	
			0	1	0	0	0	1	0	
			1	1	0	0	0	1	0	
11	FG	LIST 13	0	0	1	0	0	1	0	5 6 7 8
			1	0	1	0	0	1	0	
			0	1	1	0	0	1	0	
			1	1	1	0	0	1	0	
11	FG	LIST 13	0	0	0	1	0	1	0	9 10 11 12
			1	0	0	1	0	1	0	
			0	1	0	1	0	1	0	
			1	1	0	1	0	1	0	
11	FG	LIST 13	0	0	1	1	0	1	0	13 14 15 16
			1	0	1	1	0	1	0	
			0	1	1	1	0	1	0	
			1	1	1	1	0	1	0	
11	FH	LIST 13	0	0	0	0	1	1	0	1 2 3 4
			1	0	0	0	1	1	0	
			0	1	0	0	1	1	0	
			1	1	0	0	1	1	0	
11	FH	LIST 13	0	0	1	0	1	1	0	5 6 7 8
			1	0	1	0	1	1	0	
			0	1	1	0	1	1	0	
			1	1	1	0	1	1	0	
11	FH	LIST 13	0	0	0	1	1	1	0	9 10 11 12
			1	0	0	1	1	1	0	
			0	1	0	1	1	1	0	
			1	1	0	1	1	1	0	
11	FH	LIST 13	0	0	1	1	1	1	0	13 14 15 16
			1	0	1	1	1	1	0	
			0	1	1	1	1	1	0	
			1	1	1	1	1	1	0	
11	FJ	LIST 13	0	0	0	0	0	0	1	1 2 3 4
			1	0	0	0	0	0	1	
			0	1	0	0	0	0	1	
			1	1	0	0	0	0	1	

TABLE AE (Contd)

TSPS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING		INSERT PLUG-IN	SET WORD 3 SWITCHES							LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	12	
11	FJ	LIST 13	0	0	1	0	0	0	1	5
			1	0	1	0	0	0	1	6
			0	1	1	0	0	0	1	7
			1	1	1	0	0	0	1	8
11	FJ	LIST 13	0	0	0	1	0	0	1	9
			1	0	0	1	0	0	1	10
			0	1	0	1	0	0	1	11
			1	1	0	1	0	0	1	12
11	FJ	LIST 13	0	0	1	1	0	0	1	13
			1	0	1	1	0	0	1	14
			0	1	1	1	0	0	1	15
			1	1	1	1	0	0	1	16

TABLE AF

NO. 1A ESS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING 1ST EXP MOD		INSERT PLUG-IN	SET WORD 3 SWITCHES										LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	12	13	14		
11	BA	LIST 13	0	0	0	0	0	1	0	0	0	1 2 3 4	
			1	0	0	0	0	1	0	0	0		
			0	1	0	0	0	1	0	0	0		
			1	1	0	0	0	1	0	0	0		
11	BA	LIST 13	0	0	1	0	0	1	0	0	0	5 6 7 8	
			1	0	1	0	0	1	0	0	0		
			0	1	1	0	0	1	0	0	0		
			1	1	1	0	0	1	0	0	0		
11	BA	LIST 13	0	0	0	1	0	1	0	0	0	9 10 11 12	
			1	0	0	1	0	1	0	0	0		
			0	1	0	1	0	1	0	0	0		
			1	1	0	1	0	1	0	0	0		
11	BA	LIST 13	0	0	1	1	0	1	0	0	0	13 14 15 16	
			1	0	1	1	0	1	0	0	0		
			0	1	1	1	0	1	0	0	0		
			1	1	1	1	0	1	0	0	0		
11	BB	LIST 13	0	0	0	0	1	1	0	0	0	1 2 3 4	
			1	0	0	0	1	1	0	0	0		
			0	1	0	0	1	1	0	0	0		
			1	1	0	0	1	1	0	0	0		
11	BB	LIST 13	0	0	1	0	1	1	0	0	0	5 6 7 8	
			1	0	1	0	1	1	0	0	0		
			0	1	1	0	1	1	0	0	0		
			1	1	1	0	1	1	0	0	0		
11	BB	LIST 13	0	0	0	1	1	1	0	0	0	9 10 11 12	
			1	0	0	1	1	1	0	0	0		
			0	1	0	1	1	1	0	0	0		
			1	1	0	1	1	1	0	0	0		
11	BB	LIST 13	0	0	1	1	1	1	0	0	0	13 14 15 16	
			1	0	1	1	1	1	0	0	0		
			0	1	1	1	1	1	0	0	0		
			1	1	1	1	1	1	0	0	0		
11	BC	LIST 13	0	0	0	0	0	0	1	0	0	1 2 3 4	
			1	0	0	0	0	0	1	0	0		
			0	1	0	0	0	0	1	0	0		
			1	1	0	0	0	0	1	0	0		

TABLE AF (Contd)

NO. 1A ESS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING 1ST EXP MOD		INSERT PLUG-IN	SET WORD 3 SWITCHES									LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	12	13	14	
11	BC	LIST 13	0	0	1	0	0	0	1	0	0	5 6 7 8
			1	0	1	0	0	0	1	0	0	
			0	1	1	0	0	0	1	0	0	
			1	1	1	0	0	0	1	0	0	
11	BC	LIST 13	0	0	0	1	0	0	1	0	0	9 10 11 12
			1	0	0	1	0	0	1	0	0	
			0	1	0	1	0	0	1	0	0	
			1	1	0	1	0	0	1	0	0	
11	BC	LIST 13	0	0	1	1	0	0	1	0	0	13 14 15 16
			1	0	1	1	0	0	1	0	0	
			0	1	1	1	0	0	1	0	0	
			1	1	1	1	0	0	1	0	0	
11	BD	LIST 13	0	0	0	0	1	0	1	0	0	1 2 3 4
			1	0	0	0	1	0	1	0	0	
			0	1	0	0	1	0	1	0	0	
			1	1	0	0	1	0	1	0	0	
11	BD	LIST 13	0	0	1	0	1	0	1	0	0	5 6 7 8
			1	0	1	0	1	0	1	0	0	
			0	1	1	0	1	0	1	0	0	
			1	1	1	0	1	0	1	0	0	
11	BD	LIST 13	0	0	0	1	1	0	1	0	0	9 10 11 12
			1	0	0	1	1	0	1	0	0	
			0	1	0	1	1	0	1	0	0	
			1	1	0	1	1	0	1	0	0	
11	BD	LIST 13	0	0	1	1	1	0	1	0	0	13 14 15 16
			1	0	1	1	1	0	1	0	0	
			0	1	1	1	1	0	1	0	0	
			1	1	1	1	1	0	1	0	0	
11	BE	LIST 13	0	0	0	0	0	1	1	0	0	1 2 3 4
			1	0	0	0	0	1	1	0	0	
			0	1	0	0	0	1	1	0	0	
			1	1	0	0	0	1	1	0	0	
11	BE	LIST 13	0	0	1	0	0	1	1	0	0	5 6 7 8
			1	0	1	0	0	1	1	0	0	
			0	1	1	0	0	1	1	0	0	
			1	1	1	0	0	1	1	0	0	

TABLE AF (Contd)

NO. 1A ESS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING 1ST EXP MOD		INSERT PLUG-IN	SET WORD 3 SWITCHES									LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	12	13	14	
11	BE	LIST 13	0	0	0	1	0	1	1	0	0	9 10 11 12
			1	0	0	1	0	1	1	0	0	
			0	1	0	1	0	1	1	0	0	
			1	1	0	1	0	1	1	0	0	
11	BE	LIST 13	0	0	1	1	0	1	1	0	0	13 14 15 16
			1	0	1	1	0	1	1	0	0	
			0	1	1	1	0	1	1	0	0	
			1	1	1	1	0	1	1	0	0	
11	BF	LIST 13	0	0	0	0	1	1	1	0	0	1 2 3 4
			1	0	0	0	1	1	1	0	0	
			0	1	0	0	1	1	1	0	0	
			1	1	0	0	1	1	1	0	0	
11	BF	LIST 13	0	0	1	0	1	1	1	0	0	5 6 7 8
			1	0	1	0	1	1	1	0	0	
			0	1	1	0	1	1	1	0	0	
			1	1	1	0	1	1	1	0	0	
11	BF	LIST 13	0	0	0	1	1	1	1	0	0	9 10 11 12
			1	0	0	1	1	1	1	0	0	
			0	1	0	1	1	1	1	0	0	
			1	1	0	1	1	1	1	0	0	
11	BF	LIST 13	0	0	1	1	1	1	1	0	0	13 14 15 16
			1	0	1	1	1	1	1	0	0	
			0	1	1	1	1	1	1	0	0	
			1	1	1	1	1	1	1	0	0	
11	BG	LIST 13	0	0	0	0	0	0	0	1	0	1 2 3 4
			1	0	0	0	0	0	0	1	0	
			0	1	0	0	0	0	0	1	0	
			1	1	0	0	0	0	0	1	0	
11	BG	LIST 13	0	0	1	0	0	0	0	1	0	5 6 7 8
			1	0	1	0	0	0	0	1	0	
			0	1	1	0	0	0	0	1	0	
			1	1	1	0	0	0	0	1	0	
11	BG	LIST 13	0	0	0	1	0	0	0	1	0	9 10 11 12
			1	0	0	1	0	0	0	1	0	
			0	1	0	1	0	0	0	1	0	
			1	1	0	1	0	0	0	1	0	

TABLE AF (Contd)

NO. 1A ESS – REMOTE RELAY OUTPUT MAINTENANCE

TESTING 1ST EXP MOD		INSERT PLUG-IN	SET WORD 3 SWITCHES										LAMP ON PLUG-IN
CP	LOC		6	7	8	9	10	11	12	13	14		
11	BG		0	0	1	1	0	0	0	1	0	13 14 15 16	
		1	0	1	1	0	0	0	1	0			
		0	1	1	1	0	0	0	1	0			
		1	1	1	1	0	0	0	1	0			