

Part No. 209564-B
September 2002

4655 Great America Parkway
Santa Clara, CA 95054

Using the 8683POSM Module

Passport 8000 Series Switch
Software Release 3.3



NORTEL
NETWORKS™

Copyright © 2002 Nortel Networks

All rights reserved. September 2002.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks NA Inc.

Trademarks

Nortel Networks, the Nortel Networks logo, the Globemark, Unified Networks, Passport, and Alteon are trademarks of Nortel Networks.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation.

Adobe and Acrobat Reader are trademarks of Adobe Systems Incorporated.

SSH is a registered trademark and SSH Secure Shell is a registered trademark of SSH Communications Security Corp (www.ssh.com). The use of these trademarks is permitted to describe a product that conforms to the SSH standard and protocol.

The asterisk after a name denotes a trademarked item.

Statement of conditions

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks Inc. reserves the right to make changes to the products described in this document without notice.

Nortel Networks Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

International regulatory statements of conformity

This is to certify that the Nortel Networks 8000 Series chassis and components installed within the chassis were evaluated to the international regulatory standards for electromagnetic compliance (EMC) and safety and were found to have met the requirements for the following international standards:

- EMC - Electromagnetic Emissions – CISPR 22, Class A
- EMC - Electromagnetic Immunity – CISPR 24
- Electrical Safety – IEC 60950, with CB member national deviations

Further, the equipment has been certified as compliant with the national standards as detailed below.

National electromagnetic compliance (EMC) statements of compliance

FCC statement (USA only)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy. If it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to take whatever measures may be necessary to correct the interference at their own expense.

ICES statement (Canada only)

Canadian Department of Communications Radio Interference Regulations

This digital apparatus (8000 Series chassis and installed components) does not exceed the Class A limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Règlement sur le brouillage radioélectrique du ministère des Communications

Cet appareil numérique (8000 Series chassis) respecte les limites de bruits radioélectriques visant les appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique du ministère des Communications du Canada.

CE marking statement (Europe only)

EN 55 022 statements

This is to certify that the Nortel Networks 8000 Series chassis and components installed within the chassis are shielded against the generation of radio interference in accordance with the application of Council Directive 89/336/EEC. Conformity is declared by the application of EN 55 022 Class A (CISPR 22).

Warning: This is a Class A product. In a domestic environment, this product may cause radio interference, in which case, the user may be required to take appropriate measures.

Achtung: Dieses ist ein Gerät der Funkstörgrenzwertklasse A. In Wohnbereichen können bei Betrieb dieses Gerätes Rundfunkstörungen auftreten, in welchen Fällen der Benutzer für entsprechende Gegenmaßnahmen verantwortlich ist.

Attention: Ceci est un produit de Classe A. Dans un environnement domestique, ce produit risque de créer des interférences radioélectriques, il appartiendra alors à l'utilisateur de prendre les mesures spécifiques appropriées.

EN 55 024 statement

This is to certify that the Nortel Networks 8000 Series chassis is shielded against the susceptibility to radio interference in accordance with the application of Council Directive 89/336/EEC. Conformity is declared by the application of EN 55 024 (CISPR 24).

EC Declaration of Conformity

This product conforms to the provisions of the R&TTE Directive 1999/5/EC.

VCCI statement (Japan/Nippon only)

This is a Class A product based on the standard of the Voluntary Control Council for Interference (VCCI) for information technology equipment. If this equipment is used in a domestic environment, radio disturbance may arise. When such trouble occurs, the user may be required to take corrective actions.

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

BSMI statement (Taiwan only)

This is a Class A product based on the standard of the Bureau of Standards, Metrology and Inspection (BSMI) CNS 13438, Class A.

警告使用者：

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

MIC notice (Republic of Korea only)

This device has been approved for use in Business applications only per the Class A requirements of the Republic of Korea Ministry of Information and Communications (MIC). This device may not be sold for use in a non-business application.



명 칭 (모델명) : Switch (Passport 8600)
 인 증 번 호 : E-E011-02-0015 (A)
 인증받은자의상호 : Nortel Networks Ltd.
 제 조 일 : 별도표기
 제 조 자(제 조 국) : Nortel Networks Ltd.(미국)

National safety statements of compliance

CE marking statement (Europe only)

EN 60 950 statement

This is to certify that the Nortel Networks 8000 Series chassis and components installed within the chassis are in compliance with the requirements of EN 60 950 in accordance with the Low Voltage Directive. Additional national differences for all European Union countries have been evaluated for compliance. Some components installed within the 8000 Series chassis may use a nickel-metal hydride (NiMH) and/or lithium-ion battery. The NiMH and lithium-ion batteries are long-life batteries, and it is very possible that you will never need to replace them. However, should you need to replace them, refer to the individual component manual for directions on replacement and disposal of the battery.

NOM statement (Mexico only)

The following information is provided on the devices described in this document in compliance with the safety requirements of the Norma Oficial Mexicana (NOM):

Exporter:	Nortel Networks, Inc. 4655 Great America Parkway Santa Clara CA 95054 USA
Importer:	Nortel Networks de México, S.A. de C.V. Avenida Insurgentes Sur #1605 Piso 30, Oficina Col. San Jose Insurgentes Deleg-Benito Juarez México D.F. 03900 Tel: 52 5 480 2100 Fax: 52 5 480 2199
Input:	100 to 240 VAC, 50 to 60 Hz, 12 A max. per power supply -48 to -60 VDC, 29 A max. per power supply single supply, two supply or two + one redundant supply configurations

Información NOM (unicamente para México)

La información siguiente se proporciona en el dispositivo o en los dispositivos descritos en este documento, en cumplimiento con los requisitos de la Norma Oficial Mexicana (NOM):

Exportador:	Nortel Networks, Inc. 4655 Great America Parkway Santa Clara, CA 95054 USA
Importador:	Nortel Networks de México, S.A. de C.V. Avenida Insurgentes Sur #1605 Piso 30, Oficina Col. San Jose Insurgentes Deleg-Benito Juarez México D.F. 03900 Tel: 52 5 480 2100 Fax: 52 5 480 2199
Embarcar a:	100 to 240 V CA, 50 to 60 Hz, 12 A max. por fuente de poder -48 to -60 V CD, 29 A max. por fuente de poder una fuente, dos fuentes o dos + configuraciones de una fuente redundante

Nortel Networks Inc. software license agreement

This Software License Agreement (“License Agreement”) is between you, the end-user (“Customer”) and Nortel Networks Corporation and its subsidiaries and affiliates (“Nortel Networks”). PLEASE READ THE FOLLOWING CAREFULLY. YOU MUST ACCEPT THESE LICENSE TERMS IN ORDER TO DOWNLOAD AND/OR USE THE SOFTWARE. USE OF THE SOFTWARE CONSTITUTES YOUR ACCEPTANCE OF THIS LICENSE AGREEMENT. If you do not accept these terms and conditions, return the Software, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

“Software” is owned or licensed by Nortel Networks, its parent or one of its subsidiaries or affiliates, and is copyrighted and licensed, not sold. Software consists of machine-readable instructions, its components, data, audio-visual content (such as images, text, recordings or pictures) and related licensed materials including all whole or partial copies. Nortel Networks grants you a license to use the Software only in the country where you acquired the Software. You obtain no rights other than those granted to you under this License Agreement. You are responsible for the selection of the Software and for the installation of, use of, and results obtained from the Software.

1. Licensed Use of Software. Nortel Networks grants Customer a nonexclusive license to use a copy of the Software on only one machine at any one time or to the extent of the activation or authorized usage level, whichever is applicable. To the extent Software is furnished for use with designated hardware or Customer furnished equipment (“CFE”), Customer is granted a nonexclusive license to use Software only on such hardware or CFE, as applicable. Software contains trade secrets and Customer agrees to treat Software as confidential information using the same care and discretion Customer uses with its own similar information that it does not wish to disclose, publish or disseminate. Customer will ensure that anyone who uses the Software does so only in compliance with the terms of this Agreement. Customer shall not a) use, copy, modify, transfer or distribute the Software except as expressly authorized; b) reverse assemble, reverse compile, reverse engineer or otherwise translate the Software; c) create derivative works or modifications unless expressly authorized; or d) sublicense, rent or lease the Software. Licensors of intellectual property to Nortel Networks are beneficiaries of this provision. Upon termination or breach of the license by Customer or in the event designated hardware or CFE is no longer in use, Customer will promptly return the Software to Nortel Networks or certify its destruction. Nortel Networks may audit by remote polling or other reasonable means to determine Customer’s Software activation or usage levels. If suppliers of third party software included in Software require Nortel Networks to include additional or different terms, Customer agrees to abide by such terms provided by Nortel Networks with respect to such third party software.

2. Warranty. Except as may be otherwise expressly agreed to in writing between Nortel Networks and Customer, Software is provided “AS IS” without any warranties (conditions) of any kind. NORTEL NETWORKS DISCLAIMS ALL WARRANTIES (CONDITIONS) FOR THE SOFTWARE, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTY OF NON-INFRINGEMENT. Nortel Networks is not obligated to provide support of any kind for the Software. Some jurisdictions do not allow exclusion of implied warranties, and, in such event, the above exclusions may not apply.

3. Limitation of Remedies. IN NO EVENT SHALL NORTEL NETWORKS OR ITS AGENTS OR SUPPLIERS BE LIABLE FOR ANY OF THE FOLLOWING: a) DAMAGES BASED ON ANY THIRD PARTY CLAIM; b) LOSS OF, OR DAMAGE TO, CUSTOMER’S RECORDS, FILES OR DATA; OR c) DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), WHETHER IN CONTRACT, TORT OR OTHERWISE (INCLUDING NEGLIGENCE) ARISING OUT OF YOUR USE OF THE SOFTWARE, EVEN IF NORTEL NETWORKS, ITS AGENTS OR SUPPLIERS HAVE BEEN ADVISED OF THEIR POSSIBILITY. The forgoing limitations of remedies also apply to any developer and/or supplier of the Software. Such developer and/or supplier is an intended beneficiary of this Section. Some jurisdictions do not allow these limitations or exclusions and, in such event, they may not apply.

4. General

- a. If Customer is the United States Government, the following paragraph shall apply: All Nortel Networks Software available under this License Agreement is commercial computer software and commercial computer software documentation and, in the event Software is licensed for or on behalf of the United States Government, the respective rights to the software and software documentation are governed by Nortel Networks standard commercial license in accordance with U.S. Federal Regulations at 48 C.F.R. Sections 12.212 (for non-DoD entities) and 48 C.F.R. 227.7202 (for DoD entities).
- b. Customer may terminate the license at any time. Nortel Networks may terminate the license if Customer fails to comply with the terms and conditions of this license. In either event, upon termination, Customer must either return the Software to Nortel Networks or certify its destruction.
- c. Customer is responsible for payment of any taxes, including personal property taxes, resulting from Customer’s use of the Software. Customer agrees to comply with all applicable laws including all applicable export and import laws and regulations.
- d. Neither party may bring an action, regardless of form, more than two years after the cause of the action arose.
- e. The terms and conditions of this License Agreement form the complete and exclusive agreement between Customer and Nortel Networks.
- f. This License Agreement is governed by the laws of the country in which Customer acquires the Software. If the Software is acquired in the United States, then this License Agreement is governed by the laws of the state of New York.

Contents

Preface	17
Before you begin	17
Text conventions	18
Hard-copy technical manuals	19
How to get help	20
Chapter 1	
8683POSM Modules concepts	21
Features	22
Switch fabric console port	23
SONET transmission	24
SONET terms and acronyms	24
SONET/SDH transmission rates	25
Point-to-Point Protocol	25
Establishing the PPP link	26
Negotiating network layer protocols	27
Packet-over-SONET	28
PPP over SONET	28
Physical layer requirements	28
Interface format	29
Transmission rate	29
Control signals	29
Frame format	29
Configuration details	31
PPP Bridging Control Protocol (BCP)	31
Spanning tree group feature	32

Chapter 2	
Configuration considerations and limitations.	33
Device Manager access and passwords	33
Port numbering	34
IPX encapsulation method	35
Rebooting a terminal connected to the diagnostic port	35
Severely Errored Seconds	35
Chapter 3	
Configuring the 8683POSM Module Using Device Manager	37
Configuring and managing POS	38
Default 8683POSM configuration	38
Changing default settings	39
Resetting the 8683POSM Module	43
Viewing MDA information	45
Enabling or disabling a port	46
Configuring SONET parameters	47
Configuring bridging	50
Configuring routing	50
Configuring IP routing	50
Configuring IPX routing	54
Configuring the SONET trap feature	57
Viewing the Trap Log	60
SONET loopback test feature	61
Viewing 8683POSM statistics	62
Viewing POS statistics	64
Viewing PPP Link statistics	65
Viewing PPP Link Quality Reporting statistics	66
Viewing Section statistics	68
Viewing Line statistics	69
Viewing FE Line statistics	70
Viewing Path statistics	71
Viewing FE Path statistics	72

Chapter 4	
Using the CLI	75
Configuring and managing POS	75
Default 8683POSM configuration	76
Using the config poscard commands	76
Using the config pos port commands	77
config pos command	77
config pos ip	78
config pos ppp	79
Using the config pos info command	81
Using the config pos sonet command	82
Using the config pos stg command	83
Configuring routing	83
Configuring IP routing	84
Configuring IPX routing	84
Using the show commands	85
show ports info pos	85
show ports info pos all	86
show ports stats pos activealarms	90
show ports stats pos felinecurrent	92
show ports stats pos felineinterval	93
show ports stats pos fepathcurrent	95
show ports stats pos fepathinterval	96
show ports stats pos linecurrent	98
show ports stats pos lineinterval	99
show ports stats pos linkstatus	100
show ports stats pos lqrstatus	101
show ports stats pos pathcurrent	102
show ports stats pos pathinterval	104
show ports stats pos pppiftbl	105
show ports stats pos sectioncurrent	107
show ports stats pos sectioninterval	108
show ports stats pos sonetmediumtbl	110
Using the monitor commands	111
Using the test commands	112

test hardware	112
test led	113
test loopback	114
Chapter 5	
Web management	115
Statistics	127
Appendix A	
Technical Specifications	129
Index	133

Figures

Figure 1	PPP HDLC frame structure	30
Figure 2	Port dialog box — Interface tab	40
Figure 3	Card tab	43
Figure 4	POS tab	44
Figure 5	MDA dialog box	45
Figure 6	Port dialog box — POS SONET tab	48
Figure 7	Port dialog box — POS PPP tab	51
Figure 8	Port dialog box — IP Address tab	53
Figure 9	Port, Insert IP Address dialog box	54
Figure 10	VLAN dialog box — Basic tab	55
Figure 11	Chassis dialog box — System tab	58
Figure 12	Chassis dialog box — Trap Receivers tab	58
Figure 13	Chassis, Insert Trap Receiver dialog box	59
Figure 14	Trap Log dialog box	60
Figure 15	Port dialog box — Test tab	61
Figure 16	graphSonetPort dialog box — POS tab	64
Figure 17	graphSonetPort dialog box — PPP Link tab	65
Figure 18	graphSonetPort dialog box — PPP LQR tab	67
Figure 19	graphSonetPort dialog box — Section tab	68
Figure 20	graphSonetPort dialog box — Line tab	70
Figure 21	graphSonetPort dialog box — FE Line tab	71
Figure 22	graphSonetPort dialog box — Path tab	72
Figure 23	graphSonetPort dialog box — FE Path tab	73
Figure 24	config pos info command sample output	81
Figure 25	show ports info pos all command output	87
Figure 26	show ports info pos all command output (continued)	88
Figure 27	show ports stats pos activealarms command output	91
Figure 28	show ports stats pos felinecurrent command output	92
Figure 29	show ports stats pos felineinterval command output	94
Figure 30	show ports stats pos fepathcurrent command output	95

Figure 31	show ports stats pos fepathinterval command output	97
Figure 32	show ports stats pos linecurrent command output	98
Figure 33	show ports stats pos lineinterval command output	100
Figure 34	show ports stats pos linkstatus command output	101
Figure 35	show ports stats pos lqrstatus command output	102
Figure 36	show ports stats pos pathcurrent command output	103
Figure 37	show ports stats pos pathinterval command output	104
Figure 38	show ports stats pos pppiftbl command output	106
Figure 39	show ports stats pos sectioncurrent command output	107
Figure 40	show ports stats pos sectioninterval command output	109
Figure 41	show ports stats pos sonetmediumtbl command output	110
Figure 42	test hardware command output	113
Figure 43	test loopback command output	114
Figure 44	System page	116
Figure 45	System page showing the POS menu	118
Figure 46	SONET page	119
Figure 47	Link page	120
Figure 48	Bridge page	121
Figure 49	IP page	122
Figure 50	IPX page	123
Figure 51	Lqr page	124
Figure 52	Line page	125
Figure 53	SONET Medium page	126
Figure 54	Sonet options	127
Figure 55	PPP Link statistics page	128

Tables

Table 1	8683POSM Module access levels	33
Table 2	Value of x for available Bit Rates	35
Table 3	8683POSM Module default settings	38
Table 4	Interface tab fields	41
Table 5	Card tab fields	44
Table 6	POS tab fields	45
Table 7	MDA dialog box fields	46
Table 8	POS SONET tab fields	48
Table 9	POS PPP tab fields	52
Table 10	IP Address tab fields	53
Table 11	Insert IP Address dialog box fields	54
Table 12	Basic tab fields	55
Table 13	Trap Receivers tab fields	59
Table 14	Insert Trap Receiver dialog box fields	59
Table 15	Trap Log dialog box fields	60
Table 16	Test tab fields	62
Table 17	Types of statistics	63
Table 18	POS tab fields	64
Table 19	PPP Link tab fields	66
Table 20	PPP LQR tab fields	67
Table 21	Section tab fields	69
Table 22	Line tab fields	70
Table 23	FE Line tab fields	71
Table 24	Path tab fields	72
Table 25	FE Path tab fields	73
Table 26	config poscard command parameters and variables	77
Table 27	config pos command parameters and variables	78
Table 28	config pos ip command parameters and variables	79
Table 29	config pos ppp command parameters and variables	79

Table 30	config pos sonet command parameters and variables	82
Table 31	config pos stg command parameters and variables	83
Table 32	show ports info pos all command parameters	89
Table 33	show ports stats pos activealarms command parameters	91
Table 34	8683POSM Module alarms	91
Table 35	show ports stats pos felinecurrent command parameters	93
Table 36	show ports stats pos felineinterval command parameters	95
Table 37	show ports stats pos fepathcurrent command parameters	96
Table 38	show ports stats pos fepathinterval command parameters	97
Table 39	show ports stats pos linecurrent command parameters	99
Table 40	show ports stats pos lineinterval command parameters	100
Table 41	show ports stats pos linkstatus command parameters	101
Table 42	show ports stats pos lqrstatus command parameters	102
Table 43	show ports stats pos pathcurrent command parameters	104
Table 44	show ports stats pos pathinterval command parameters	105
Table 45	show ports stats pos pppiftbl command parameters	106
Table 46	show ports stats pos sectioncurrent command parameters	108
Table 47	show ports stats pos sectioninterval command parameters	109
Table 48	show ports stats pos sonetmediumtbl command parameters	111
Table 49	test led command parameters and variables	113
Table 50	System page fields	117
Table 51	SONET page fields	119
Table 52	Link page fields	120
Table 53	Bridge page fields	121
Table 54	IP page	122
Table 55	IPX page fields	123
Table 56	Lqr page fields	124
Table 57	Line page fields	125
Table 58	SONET Medium page fields	126

Preface

The 8683POSM Module is part of the Nortel Networks* 8000 Series line of communications products. This module is the Packet over SONET (POS) module for the 8000 chassis. This guide describes the features and operations of the 8683POSM Module and provides instructions for installing and managing the module.

For a complete list of the documentation related to the Passport 8000 Switch Series Software Release 3.3, refer to the release notes for that release, or to the documentation CD provided with your software. Note that the *Network Design Guidelines* is a Web-posted document and will not be provided on your CD.

Before you begin

This guide is intended for network installers and system administrators who are responsible for installing, configuring, or maintaining networks. This guide assumes that you have the following background:

- Understanding of the transmission and management protocols used on your network
- Experience with windowing systems or graphical user interfaces (GUIs)

Text conventions

This guide uses the following text conventions:

- | | |
|--------------------------|--|
| angle brackets (< >) | Indicate that you choose the text to enter based on the description inside the brackets. Do not type the brackets when entering the command.
Example: If the command syntax is <code>ping <ip_address></code> , you enter <code>ping 192.32.10.12</code> |
| bold Courier text | Indicates command names and options and text that you need to enter.
Example: Use the dinfo command.
Example: Enter show ip {alerts routes} . |
| braces ({}) | Indicate required elements in syntax descriptions where there is more than one option. You must choose only one of the options. Do not type the braces when entering the command.
Example: If the command syntax is <code>show ip {alerts routes}</code> , you must enter either <code>show ip alerts</code> or <code>show ip routes</code> , but not both. |
| brackets ([]) | Indicate optional elements in syntax descriptions. Do not type the brackets when entering the command.
Example: If the command syntax is <code>show ip interfaces [-alerts]</code> , you can enter either <code>show ip interfaces</code> or <code>show ip interfaces -alerts</code> . |
| ellipsis points (. . .) | Indicate that you repeat the last element of the command as needed.
Example: If the command syntax is <code>ethernet/2/1 [<parameter> <value>] . . .</code> , you enter <code>ethernet/2/1</code> and as many parameter-value pairs as needed. |

<i>italic text</i>	Indicates new terms, book titles, and variables in command syntax descriptions. Where a variable is two or more words, the words are connected by an underscore. Example: If the command syntax is <code>show at <valid_route></code> , <code>valid_route</code> is one variable and you substitute one value for it.
plain Courier text	Indicates command syntax and system output, for example, prompts and system messages. Example: <code>Set Trap Monitor Filters</code>
separator (>)	Shows menu paths. Example: <code>Protocols > IP</code> identifies the IP command on the Protocols menu.
vertical line ()	Separates choices for command keywords and arguments. Enter only one of the choices. Do not type the vertical line when entering the command. Example: If the command syntax is <code>show ip {alerts routes}</code> , you enter either <code>show ip alerts</code> or <code>show ip routes</code> , but not both.

Hard-copy technical manuals

You can print selected technical manuals and release notes free, directly from the Internet. Go to the www.nortelnetworks.com/documentation URL. Find the product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Use Adobe* Acrobat Reader* to open the manuals and release notes, search for the sections you need, and print them on most standard printers. Go to Adobe Systems at the www.adobe.com URL to download a free copy of the Adobe Acrobat Reader.

You can purchase printed books and documentation sets from Vervante. To order printed documentation, go to Vervante at the www.vervante.com/nortel URL.

How to get help

If you purchased a service contract for your Nortel Networks product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel Networks service program, contact one of the following Nortel Networks Technical Solutions Centers:

Technical Solutions Center	Telephone
Europe, Middle East, and Africa	(33) (4) 92-966-968
North America	(800) 4NORTEL or (800) 466-7835
Asia Pacific	(61) (2) 9927-8800
China	(800) 810-5000

Additional information about the Nortel Networks Technical Solutions Centers is available from the www.nortelnetworks.com/help/contact/global URL.

An Express Routing Code (ERC) is available for many Nortel Networks products and services. When you use an ERC, your call is routed to a technical support person who specializes in supporting that product or service. To locate an ERC for your product or service, go to the <http://www.nortelnetworks.com/help/contact/erc/index.html> URL.

Chapter 1

8683POSM Modules concepts

The 8683POSM Module is a 128K records module which allows support for large layer 2 and layer 3 configurations. This module only operates with 8000 Series software release 3.3 and later. For 128K record support the following configurations are required:

- The chassis must include the 8691SF CPU module.
- All modules installed in the chassis must support 128K records running 3.3 and later software.
- MMode (128K records mode) must be enabled. For instructions on enabling MMode (not a POS-specific command), see *Platform and System Management*.

The 8683POSM Module for the 8000 series routing switches provides WAN support to the 8000 Series product line by allowing access to SONET services in the metropolitan area. Where multiple campuses exist in a single metropolitan area, you can connect these campuses without compromising performance or increasing complexity.

The 8683POSM Module is a baseboard with slots for three of the following two optional media dependent adapters (MDAs):

- 1-port OC-12c/STM-4: single-mode fiber (SMF) or multimode fiber (MMF) using SONET/SDH
- 2-port OC-3c/STM-1: SMF or MMF using SONET/SDH

The 8683POSM Module supports up to six input/output (I/O) OC-3c/STM-1 lines and up to three I/O OC-12 lines. You can mix these MDAs on a single 8683POSM Module. For example, you can put an OC-12 MDA into the first slot and OC-3 MDAs into the two remaining slots.

You can put more than one 8683POSM Module in the 8000 series chassis, except slots 5 and 6, which are reserved for the 8691SF (Switch Fabric) modules. The maximum number of modules on a chassis is four.

One 8691SF module acts as the CPU for the chassis, and the other module is the standby CPU, taking over in case of failure. If a CPU failover occurs, all traffic on the chassis stops momentarily while the standby CPU reinitializes all input/output modules.

For a complete discussion on the hardware specifics of your 8683POSM module, or on how to install you module, see *Installing 8600 Switch Modules* or the installation manual specific to your chassis.

Features

The 8683POSM Module has the following features:

- SONET and SDH compliant, supporting OC-3c/STM-1 and OC-12c/STM-4 framing
- Front-panel LEDs to monitor port activity and module operation
- Ability to remove and install a module (hot-swap) without resetting the switch
- MTBF of 150,000 hours
- Internal and external loopback support on all ports for testing purposes
- Hardware diagnostics
- Brouter port configuration
- Bridging support: RFC 1638-compliant
- Routing support for both unicast and multicast IP and IPX routing
- Support for both single-mode fiber (SMF) and multimode fiber (MMF) cabling
- Support for DVMRP
- Support for IGMP
- Support for MultiLink Trunking (MLT)
- Support for the following VLAN features currently implemented in the 8000 Series switch including:
 - Port-based VLAN

- Policy-based VLANs (protocol-based, IP subnet-based VLANs)
- IEEE 802.1Q tagged VLANs
- Support for the following RFCs:
 - PPP over SONET: RFC 2615
 - SONET/SDH: RFC 2558
 - PPP: RFC 1471, RFC 1473, RFC 1474, and RFC 1661
 - LQM: RFC 1989
 - SNMP: RFC 1213
 - IPCP: RFC 1332
 - IPXCP: RFC1552
 - BCP: RFC 1638_
- Multiple spanning tree groups - bridge mode only
- Manageable through the CLI or Device Manager, the SNMP-based graphical user interface
- Monitored through a World Wide Web browser from anywhere on the network

Switch fabric console port

Use the Console port on the switch fabric CPU (8691SF Module) to establish a local CLI or Device Manager session for the 8683POSM Module. For information on connecting to the Console port, refer to the appropriate installation manual for your 8000 Series chassis.

The Diag port on the 8683POSM Module is used *only* by Nortel Networks personnel for debugging purposes. You can see diagnostic messages but you cannot input any text.

The Diag port on the module is an RJ-45 port that allows out-of-band management by Nortel Networks personnel.

A typical application consists of a single 8683POSM Module in an 8000 series switch, but multiple modules are also supported.

A typical network application of the 8683POSM Module is a direct connection between one 8000 series switch with a 8683POSM Module in one campus to an identical module in another 8000 series switch at another campus connected over a SONET ring. Using this connection, you achieve an intercampus link through packet over SONET (POS) technology.

SONET transmission

You can connect the 8683POSM Module through a Synchronous Optical Network (SONET) termination multiplexor to extend the range of the wide area network (WAN) connections. Or, you can connect the 8683POSM Module, using fiber, directly to a POS interface on another 8000 Series routing switch or on a traditional router.

The SONET frames received from the WAN contain IP packets encapsulated in Point-to-Point Protocol (PPP) that are converted by the 8683POSM Module into an Ethernet format. Similarly, the 8683POSM Module receives Ethernet frames and converts them into PPP packets for transmission over SONET.

SONET terms and acronyms

This section provides a brief listing of common Synchronous Optical Network (SONET) terms. SONET is a medium for transmitting data that uses fiber-optic cables.

The following terms and acronyms are frequently used with SONET information:

- **SONET:** Synchronous Optical Network. SONET is a family of fiber optic transmission rates that provides the flexibility to transport many digital signals with different capacities. This ANSI standard provides for transmission from OC-1 to OC-48 and greater.
- **SDH:** Synchronous Digital Hierarchy. SDH is a standard technology for optical fiber-based synchronous data transmission. SDH is the international equivalent of SONET.
- **OC-3c/STM-1:** Optical Carrier-level 3 concatenation. OC-3c/STM-1 is an optical fiber transmission system that carries STS-3c/STM-1 frame structures at 155 Mb/s. Concatenation refers to the fact that there is only one logical data stream (rather than supporting a channelized structure).

- OC-12c/STM-4: Optical Carrier-level 12 concatenation. OC-12c/STM-4 is an optical fiber transmission system that carries STS-12c/STM-4 frame structures at 622 Mb/s. Concatenation refers to the fact that there is only one logical data stream (rather than supporting a channelized structure).
- POS: Packet over SONET.
- PPP: Point-to-Point Protocol. PPP encapsulates common network-layer protocols in specialized Network Control protocol packets, such as IP over PPP (IPCP) and IPX over PPP (IPXCP), and BCP. Thus, it enables sending multiprotocol data over point-to-point links.

SONET/SDH transmission rates

The following transmission rates are commonly used with SONET:

- OC-3c/STM-1: 155.52 Mb/s
- OC-12c/STM-4: 622.08 Mb/s

The SONET specification defines optical both as:

- Single-mode fiber (SMF)
- Multimode fiber (MMF).



Note: The estimated maximum transmission distance for OC-3c SMF is 20 kilometers (km); for OC-3c MMF is 2 km; for OC-12c SMF is 15 km; for OC-12c MMF is 500 m.

Point-to-Point Protocol

The PPP family of protocols is divided into three categories:

- Control protocols control operation and maintenance of the PPP link.
- Network protocols describe the encapsulation methods needed to move multiprotocol network traffic over the PPP interface.
- Network control protocols are used to configure, manage, and control the operation of the network protocols. The 8683POSM Module uses the Link Control Protocol (LCP) and the Link Quality Report to monitor the link.

PPP goes through the following basic initialization phases when bringing up links:

- Link establishment
- Network layer protocol

Establishing the PPP link

The Link Control Protocol (LCP) of the PPP helps establish a link. LCP generates three types of packets:

- Link configuration packets, including configure-request, configure-ACK, configure-NAK, and configure-reject packets
- Link termination packets, including terminate-request and terminate-ACK packets
- Link maintenance packets, including code-reject, protocol-reject, echo-request, and echo-reply packets

When two devices initialize a PPP dialog, each sends a configure-request packet to the other. Each configure-request packet contains a list of LCP options and corresponding values that the sending device uses to define its end of the link.

For example, a configure-request packet may specify the link's maximum transmission unit (MTU) size. The configure-request packet contains the user-configured values, which the sending device and the receiving device may need to negotiate.

When the receiving device gets a configure-request packet from the sending device, the receiving device responds with one of the following three types of packets:

- configure-ACK (that is, configure acknowledgment),
- configure-reject, or
- configure-NAK (that is, configure negative acknowledgment).

When the receiving device accepts the proposed LCP options, it responds with a configure-ACK packet. When the devices on each side of the link send and receive configure-ACK packets, the LCP advances to an open state, which means that the PPP interface can advance to the next phase. The devices converge.

When the configure-request packet from the sending device contains options that the receiving device is not willing to negotiate, the receiving device sends back a configure-reject packet specifying the nonnegotiable options. From that point on, configure-request packets from the sending device should eliminate the unacceptable options. When the sending device eliminates the offending options, the devices converge.

When the receiving device disagrees with some or all of the values of the proposed options in the configure-request packet, it responds with a configure-NAK packet. The configure-NAK packet notes the values that the receiving device disagrees with, and it includes the corresponding values that the receiving device would like to see in subsequent configure-request packets.

LCP negotiations between sending and receiving devices continue until either:

- Both devices converge (reach an agreement regarding the configure-request).
- The receiving device transmits a specified number of configure-NAK packets before sending a configure-reject packet.
- The convergence timer expires.

Negotiating network layer protocols

PPP uses various network control protocols to determine the values of parameters during network layer negotiations, which is the final phase of PPP initialization. Similar to the LCP, each network control protocol allows the devices to negotiate various network options over the data link by transmitting configure-request, configure-ACK, configure-NAK, and configure-reject packets.

Networks options include which network addresses to use and which media types to bridge. Once both devices agree upon networks options, the network control protocol reaches the open state. The devices then begin transmitting user data packets for upper-layer protocols over the link.

Packet-over-SONET

Packet-over-SONET (POS) is a transport system that carries IP packets directly over a SONET/SDH network without any data link facility, such as ATM, in between. POS transmits information at the highest rates possible, because SONET has a smaller packet header overhead than ATM (28 bytes out of an 810-byte frame compared with 5 out of a 53-byte ATM cell).

On a 8683POSM Module, the following features and protocols are supported:

- Three types of VLANs are supported:
 - Port-based VLANs
 - Protocol-based VLANs
 - 802.1q VLANs
- The Spanning Tree Protocol (STP) and FastStart are supported. The Bridge Protocol Data Unit (BPDU) format is enabled by default on the 8683POSM Module. It must be disabled if support for spanning tree groups is required.
- MultiLink Trunking (MLT)
- Internet Group Management Protocol (IGMP)
- Distance Vector Multicast Routing Protocol (DVMRP)
- Point-to-Point Protocol (PPP)

PPP over SONET

Point-to-point protocol connections over SONET are supported. Because the PPP encapsulation has relatively low overhead, higher throughput can be attained compared to other SONET/SDH payload mapping, at a lower cost for line termination equipment.

Since SONET/SDH is by definition a point-to-point circuit, PPP is appropriate to use over these connections.

Physical layer requirements

PPP treats SONET/SDH transport as octet-oriented synchronous links. SONET/SDH links are full-duplex mode by definition.

Interface format

PPP presents an octet interface to the physical layer. There is no provision for suboctets to be supplied or accepted.

The octet stream is mapped into the SONET/SDH Synchronous Payload Envelope (SPE), with the octet boundaries aligned with the SPE octet boundaries.

No scrambling is needed during insertion into the SPE. The Path Signal Label (C2) is intended to indicate the contents of the SPE. The experimental value of 207 is used to indicate PPP.

The Multiframe Indicator (H4) is currently unused, and must be zero.

Transmission rate


The basic rate for PPP over SONET/SDH is that of STS-3c/STM-1 at 155.520 Mb/s. The available information bandwidth is 149.760 Mb/s, which is the STS-3c/STM-1 SPE with section, line, and path overhead removed.

Control signals

PPP does not require the use of control signals. When available, using such signals can allow greater functionality and performance.

Frame format

[Figure 1](#) presents a summary of the PPP HDLC frame structure. It does not include start/stop bits (for asynchronous links), nor any bits or octets inserted for transparency. The fields are transmitted from left to right.

Figure 1 PPP HDLC frame structure

10178EA

Flag Sequence

The Flag Sequence indicates the beginning or end of a frame and always consists of the binary sequence 01111110 (hexadecimal 0x7e).

The Flag Sequence is a frame separator. Only one Flag Sequence is required between two frames. Two consecutive Flag Sequences constitute an empty frame, which is ignored and not counted as an FCS error.

Address field

The Address field is a single octet and contains the binary sequence 11111111 (hexadecimal 0xff), the All-Stations address. PPP does not assign individual station addresses. The All-Stations address must always be recognized and received. The use of other address lengths and values may be defined at a later time or by prior agreement. Frames with unrecognized addresses should be silently discarded.

Control field

The Control field is a single octet and contains the binary sequence 00000011 (hexadecimal 0x03), the Unnumbered Information (UI) command with the P/F bit set to zero. The use of other Control field values may be defined at a later time or by prior agreement. Frames with unrecognized Control field values should be silently discarded.

Frame Check Sequence (FCS) field

The Frame Check Sequence field is normally 16 bits (two octets). The use of other FCS lengths may be defined at a later time or by prior agreement. The FCS is transmitted with the coefficient of the highest term first.

The FCS field is calculated over all bits of the Address, Control, Protocol, Information and Padding fields, not including any start and stop bits (asynchronous) nor any bits (synchronous) or octets (asynchronous or synchronous) inserted for transparency. This field also does not include the Flag Sequences nor the FCS field itself.



Note: When octets are received and flagged in the Async- Control-Character-Map, they are discarded before calculating the FCS.

Configuration details

The standard LCP sync configuration defaults apply to SONET/SDH links.

The following configuration options are recommended:

- Magic Number
- No Address and Control Field Compression
- No Protocol Field Compression
- 32-bit FCS

PPP Bridging Control Protocol (BCP)

The PPP BCP is supported. This protocol allows BPDUs to be transmitted over the POS link. When multiple spanning tree groups are used, the STP feature is disabled and BPDUs are bridged using the bridged coding.

Spanning tree group feature

The BPDU (Bridge Protocol Data Unit) format specified in RFC 1638 is enabled by default on the 8683POSM Module. If support for multiple spanning tree groups is required, the BPDU default format must first be disabled. For information on changing the STG format, see [“config pos ppp” on page 79](#).

Chapter 2

Configuration considerations and limitations

This chapter describes configuration limitations and considerations and interoperability issues that you should consider when configuring your 8683POSM Module.

Device Manager access and passwords

[Table 1](#) shows the security access levels for the 8683POSM Module.

Table 1 8683POSM Module access levels

Level of Access	8683POSM Module feature
Level 1 (read/write)	SONET parameters
Level 2 (read/write)	All PPP bridging and Spanning Tree parameters
Level 3 (read/write)	All IP and IPX routing parameters

Port numbering

You must insert an MDA into the 8683POSM Module in order to have connectivity. The module contains three slots for MDAs, and you can mix and match from among the following MDAs, which are available (SMF and MMF):

- 1-port OC-12c/STM-4
- 2-port OC-3c/STM-1

The management system identifies an interface by its slot number in the 8000 series chassis and its port number, using the syntax slot number/port number (s/p). Because the 8683POSM Module can have up to six ports with three 2-port MDAs inserted, port numbers 1 and 2 are reserved for the MDA in the left slot regardless of the actual physical number of ports. Port numbers 3 and 4 apply to the MDA in the middle slot regardless of the actual physical number of ports; and port numbers 5 and 6 apply to the MDA in the right slot regardless of the physical number of ports.

For example, a 8683POSM Module in the second slot of the 8000 series chassis with an OC-12c/STM-4 MDA in the left slot, an OC-3c/STM-1 MDA in the middle, and an OC-12c/STM-4 MDA in the right slot has the following port numbers for management and configuration:

- 2/1: OC-12c/STM-4
- 2/3: OC-3c/STM-1, left port
- 2/4: OC-3c/STM-1, right port
- 2/5: OC-12c/STM-4

As another example of port numbering, an 8683POSM Module in the second slot of the chassis with an OC-3c/STM-1 MDA in the left slot, the middle slot blank, and an OC-12c/STM-4 installed in the right slot has the following port numbers:

- 2/1: OC-3c/STM-1, left port
- 2/2: OC-3c/STM-1, right port
- 2/5: OC-12c/STM-4

A 8683POSM Module with three OC-3c/STM-1 MDAs installed has ports numbered consecutively 1 through 6, from left to right.

IPX encapsulation method

When a POS port is configured for IPXCP (IPX routed link), the only encapsulation method that you can use is Ethernet II. For more information, see [“Configuring IPX routing” on page 54](#).

Rebooting a terminal connected to the diagnostic port

Rebooting a terminal connected to the Diagnostic port on the Passport 8683POS module may cause the module to reset. This port is intended only for debugging operations and should not be used during normal operation.

Severely Errored Seconds

In a statistics display, a Severely Errored Second (SES) is a second where x or more Coding Violations occur. The value of x is dependent on the bit rate as follows:

[Table 2](#) shows the value of x for the available Bit Rates

Table 2 Value of x for available Bit Rates

Bit Rate	x value for Coding Violations
OC-3	155
OC-12	616

Chapter 3

Configuring the 8683POSM Module Using Device Manager

Two management tools enable you to configure the 8683POSM Module: Device Manager and command line interface (CLI). You can also use the embedded web-based management feature to monitor the 8683POSM Module. See [Chapter 5, “Web management,” on page 115](#) for information on using the web-based management feature.

Device Manager is an SNMP-based graphical user interface tool designed to manage single devices. In order to use Device Manager, you must have network connectivity to a management station running Device Manager on one of the supported platforms. This section describes Device Manager features that are specific to the 8683POSM Module.

For detailed information on all aspects of installing and running Device Manager, refer to *Getting Started with the 8000 Series Management Software*.

This chapter describes the following topics:

Topic	Page
Configuring and managing POS	38
Configuring the SONET trap feature	57
Viewing the Trap Log	60
SONET loopback test feature	61
Viewing 8683POSM statistics	62

Configuring and managing POS

This section describes how to use Device Manager to configure and manage POS, and includes the following topics:

- [“Default 8683POSM configuration, next](#)
- [“Changing default settings” on page 39,” next](#)
- [“Resetting the 8683POSM Module” on page 43”](#)
- [“Viewing MDA information” on page 45”](#)
- [“Enabling or disabling a port” on page 46”](#)
- [“Configuring SONET parameters” on page 47”](#)
- [“Configuring bridging” on page 50”](#)
- [“Configuring routing” on page 50”](#)

You can configure the 8683POSM Module in two basic modes:

- **Bridging:** Bridging mode is enabled by default. Bridging is configured for connections between two 8683POSM Modules and between 8683POSM Modules and other devices that support PPP bridging.
- **Routing:** You select routing mode for connections between your 8683POSM Module and other POS-capable routers for IP and IPX routing.

Default 8683POSM configuration

[Table 3](#) describes the default 8683POSM Module configuration.

Table 3 8683POSM Module default settings

Parameter	Default
Bridge Admin State (BCP)	Open
IP Admin State (IPCP)	Close
IPX Admin State (IPXCP)	Close
Clock source	Line
FCS size	32
Debug	Disabled
Framing	SONET

Table 3 8683POSM Module default settings (continued)

Parameter	Default
Priority	Low
Lock	False
Lqr interval	100
Lqr status	Enabled
Lqr threshold	95
Magic number	True
Oversize frame	Disabled
Perform tagging	Disabled
Scramble	Enabled
Signal-Label (C2)	0x16
Section trace (J0)	1 (0x01)
STP RFC 1638	Enabled
Tagged frame discard	Disabled
Unknown MAC discard	Disabled
Untagged frame discard	Disabled
Device Manager interval	10 seconds

Changing default settings

To change the default settings on the 8683POSM Module or to perform any configuration tasks in Device Manager, select the port you want to configure and open the Interface tab.

To open the Interface tab:

➔ Do one of the following:

- Right-click on the port. A shortcut menu opens. Choose Edit.
- Double-click on the port.

The Port dialog box opens with the Interface tab displayed ([Figure 2](#)).

Figure 2 Port dialog box — Interface tab

The screenshot shows a window titled "10.10.42.21 - Port 2/4" with a close button in the top right corner. The window contains a tabbed interface with the following tabs: ARP, DHCP, DVMRP, IGMP, OSPF, RIP, PIM, PGM, Router Discovery, IPX BRouter, Interface (selected), POS SONET, POS PPP, VLAN, STG, MAC Learning, Test, and IP Address. The main content area is divided into several sections:

- General Information:**
 - Index: 131
 - Name:
 - Descr: OC-3c(SM) Port 2/4
 - Type: rcOc3cPosSM
 - Mtu: 0
 - PhysAddress: 00:80:2d:b7:ac:49
 - VendorDescr:
- Status and Link:**
 - AdminStatus: up down testing
 - OperStatus: down
 - LastChange: none
 - LinkTrap: enabled disabled
- Speed and Duplex:**
 - AutoNegotiate: true false
 - AdminDuplex: half full
 - OperDuplex: full
 - AdminSpeed: mbps10 mbps100
 - OperSpeed: 0
- QoS and DiffServ:**
 - QosLevel: level0 level1 level2 level3 level4 level5 level6 level7
 - DiffServEnable
 - DiffServType: none access core
- Multimedia and Telephony:**
 - MultimediaPlatformAndDevice: ...
 - TelephonyAndMultimediaFilterEnable
- Miscellaneous:**
 - MitId: 0

At the bottom of the window, there are four buttons: Apply, Refresh (highlighted with a dashed border), Close, and Help...

Table 4 describes the Interface tab fields.

Table 4 Interface tab fields

Fields	Description
Index	Unique value assigned to each interface. The value ranges between 16 and 255.
Name	Displays the name of this port. To assign or change a name to the port, highlight the field and enter alphanumeric characters.
Descr	Type of interface, either: <ul style="list-style-type: none"> • OC-3c MMF or SMF • OC-12c MMF or SMF
Type	Media type of this interface. This will be ppp for a port on the 8683POSM Module.
Mtu	Size (in octets) of the largest packet that can be sent or received on the interface. For IPCP and IPXCP, the maximum is 1936. When BCP is enabled, however, the maximum is 1934. Check which NCP is enabled before configuring the Mtu on a connecting device. Note: The Bridge Control Protocol (BCP) is enabled on the 8683POSM Module by default.
PhysAddress	MAC address assigned to a particular interface.
VendorDescr	Vendor description.
AdminStatus	Sets the port to one of the following states: <ul style="list-style-type: none"> • up • down • testing When a managed system initializes, all interfaces start with AdminStatus in the down state. As a result of either management or configuration action, the AdminStatus is changed to the up state (or remains in the down state). The testing state indicates that no operational packets can be passed.

Table 4 Interface tab fields (continued)

Fields	Description
OperStatus	Operational state of the interface, one of the following: <ul style="list-style-type: none"> • up • down • testing The testing state indicates that no operational packets can be passed. If AdminStatus is down, then OperStatus should be down. If AdminStatus is changed to up, then OperStatus should change to up if the interface is ready to transmit and receive network traffic. It should remain in the down state if and only if there is a fault that prevents it from going to the up state.
LastChange	Value of sysUpTime at the time the interface entered its current operational state. If the current state was entered prior to the last reinitialization of the local network management subsystem, the value is zero.
LinkTrap	Sets whether or not link Up/link Down traps should be generated for this interface. <ul style="list-style-type: none"> • enabled—sends traps for link up or down • disabled—does not send traps for link up or down
OperDuplex	Current operational duplex of the port (half or full). This will always be full duplex on a POS port.
OperSpeed	Current operating speed of the port. It can be either 155 or 622 Mb/s depending on the type of interface installed.
MultiMediaPlatformAndDevice	Opens a dialog box that allows you to select the platform and device for multimedia.
TelephonyAndMultiMediaFilterEnable	Enables IP telephony and multimedia filters.
MltId	Multi-Link Trunk to which the port is assigned (if any).
Locked	Displays whether or not the port is locked. When locked, the port configuration cannot be changed. To lock or unlock a port, select Edit > Security > Port Lock.
Action	Sets one of the following port-related actions: <ul style="list-style-type: none"> • none • flushMacFdb—flush MAC forwarding table for port • flushArp—flush ARP table for port • flushIp—flush IP route table for port • flushAll—flush all tables for port • triggerRipUpdate—manually update the RIP table
Result	Displays results from the last system action.

From the Interface tab, select other POS-specific tabs to configure the port or change current or default configurations.

Resetting the 8683POSM Module

To reset 8683POSM module:

- 1 Highlight the card.
- 2 Choose Edit > Card.

The Card dialog box opens with the Card tab displayed (Figure 3).

Figure 3 Card tab




Table 5 describes the fields in the Card tab.

Table 5 Card tab fields

Field	Description
FrontType	Card type.
FrontDescription	Packet Over Sonet.
FrontAdminStatus	The administrative status of the card.
FrontOperStatus	The operational status of the card.
FrontSerialNum	Serial number of card.
FrontHwVersion	Hardware version.
FrontPartNumer	Part number.
FrontDateCode	Date code.
FrontDeviations	Deviations.
BackType	Card back type.
BackDescription	Description.
BackSerialNum	Serial Number.
BackHwVersion	Hardware version.
BackPartNumer	Part number.
BackDateCode	Date code.
BackDeviations	Deviations.

3 Click the POS tab.

The POS tab opens (Figure 4).

Figure 4 POS tab

Table 6 describes the fields in the POS tab

Table 6 POS tab fields

Field	Description
Action: reset	Resets the card.
ImageFileName	Name of the image file which downloads at initialization.

- 4 Click reset.
- 5 Click Apply.

Viewing MDA information

To view information on the MDA you are using:

- 1 Highlight the MDA.
- 2 Select Edit > Mda.

The MDA dialog box opens ([Figure 5](#)).


Figure 5 MDA dialog box

Table 7 describes the fields in the MDA dialog box.

Table 7 MDA dialog box fields

Field	Description
Type	Media type: <ul style="list-style-type: none">• OC-3c SMF MDA• OC-3c MMF MDA• OC-12c SMF MDA• OC-12c MMF MDA
Description	MDA description: <ul style="list-style-type: none">• OC-3c SMF MDA—Dual port OC-3c SMF• OC-3c MMF MDA—Dual port OC-3c MMF• OC-12c SMF MDA — Single Port OC-12c SMF• OC-12c MMF MDA —Single Port OC-12c MMF

Enabling or disabling a port



Note: When you change configurations in Device Manager, and click the Apply button, the system will disable and re-enable the port automatically.

You can enable or disable a port by two methods. To enable or disable a port through the Device Manager menu bar:

- 1 Highlight the port.
- 2 From the Device Manager menu bar, choose Edit > Port.
The Port dialog box opens with the Interface tab displayed ([Figure 2 on page 40](#)).
- 3 In AdminStatus area, click up to enable the port, or click down to disable the port.
- 4 Click Apply.

To enable or disable a port using a shortcut menu:

- 1 Right-click on the port.
A shortcut menu opens.
- 2 Choose Enable or Disable.

Configuring SONET parameters

To change the default parameters, you configure the values for the Synchronous Optical Network (SONET) media in the POS SONET tab. These values must be configured before you configure POS PPP, VLAN, or any other parameters.

See [Table 3 on page 38](#) for the default SONET parameters.

To change the configuration of the SONET parameters:

- 1 Highlight the port.
- 2 Choose Edit > Port.
The Port dialog box opens with the Interface tab displayed ([Figure 2 on page 40](#)).
- 3 Disable the port as described in [“Enabling or disabling a port” on page 46](#).
- 4 In the Interface tab, click the POS SONET tab.
The POS SONET tab opens ([Figure 6](#)).

Figure 6 Port dialog box — POS SONET tab

[Table 8](#) describes the fields in the POS SONET tab.

Table 8 POS SONET tab fields

Field	Description
SonetFraming	Sets the framing for the port to: <ul style="list-style-type: none"> SONET—Synchronous Optical Network format; standard format used in North America (default) SDH—Synchronous Digital Hierarchy clock format; standard format used in Europe.
SonetOperStatusFraming	Operational value of SONET framing.
SonetSectionTrace	Sets the integer that the section trace flag (j0) is set to, that is an integer between 1 and 255.
SonetOperStatusSectionTrace	Operational value of SonetSectionTrace.
SonetOperStatusPathSignalLabel	Operational value of Path Signal Label.
SonetClockSource	Sets the Clock Source to either line or internal.

Table 8 POS SONET tab fields (continued)

Field	Description
SonetOperStatusClockSource	Operational value of ClockSource.
SonetScramble	Parameter that enables or disables the scrambling option.
SonetOperStatusScramble	Operational value of SonetScramble.
SonetMedium	
MediumType	Identifies whether a SONET or a SDH signal is used across this interface.
MediumTimeElapsed	Number of seconds, including partial seconds, that have elapsed since the beginning of the current measurement period. If, for some reason, such as an adjustment in the system's time-of-day clock, the current interval exceeds the maximum value, the agent will return the maximum value.
MediumValidIntervals	Number of previous 15-minute intervals for which data was collected.
MediumLineCoding	Line coding for this interface. The Non-Return to Zero (NRZ) line coding is used for optical SONET/SDH signals.
MediumLineType	Line type for this interface. The line types are single mode fiber or multimode fiber interfaces.
MediumCircuitIdentifier	Transmission vendor's circuit identifier, for the purpose of facilitating troubleshooting. Note that the circuit identifier, if available, is also represented by <code>ifPhysAddress</code> .

5 Select the `SonetClockSource`, either line or internal.

If two POSM Modules are operating directly (that is, connected back to back, without any intervening Sonet equipment), one port must provide the clock source. Set the clock source of one port to internal, and the opposite port must be set to line.

6 Select other SONET parameters.

7 Click Apply.

8 Re-enable the port as described in [“Enabling or disabling a port” on page 46](#).

Configuring bridging

The 8683POSM Module is configured for bridging by default. The configuration is set for bridging between two 8683POSM Modules with one default VLAN. The Bridge Control Protocol (BCP) is enabled on the 8683POSM Module by default.



Note: When the POS link is enabled after a parameter change or a chassis reset, some superfluous traffic may initially be sent out of POS ports before any LCP packets go out. This is normal.

You can also configure bridging for the 8683POSM Module for connection to other POS-capable devices.

Configuring routing

A POS port configured for IPCP and/or IPXCP encapsulation must be the sole member of the VLAN. You cannot add any other port to a VLAN which already has a POS port with IPCP and/or IPXCP encapsulation enabled. You cannot add a POS port which is configured for IPCP and/or IPXCP encapsulation to a VLAN which already has other ports as members.



Note: When the 8600 switch is interoperating with a Juniper router, the POS port must have the Juniper IP address configured in the remote IP field. This is necessary because the Juniper routers do not provide their local IP address during PPP negotiation. The 8600 switch requires the Juniper address for IPCP operations.

Note also that for the IP address assigned to the POS port, 30-bit subnet masks may be required for certain JUNOS releases.

Configuring IP routing

To configure the 8683POSM Module for IP routing using Device Manager:

- 1 Highlight the port.
- 2 Choose Edit > port.

The Port dialog box opens with the Interface tab displayed (Figure 2 on page 40).

3 Click the POS PPP tab.

The POS PPP tab opens (Figure 7).

Figure 7 Port dialog box — POS PPP tab



The screenshot shows the 'Port dialog box' for '10.125.200.45 - Port 2/3'. The 'POS PPP' tab is selected. The configuration is organized into sections: Link, Bridge, Ip, Ipx, and Lqr. Each section contains various status indicators and configuration fields with radio buttons or text boxes.

Section	Parameter	Value
- Link	LinkConfigMagicNumber	<input checked="" type="radio"/> false <input checked="" type="radio"/> true
	OperStatusLinkMagicNumber	2
	LinkConfigFcsSize	32 (0..128, only 16/32 supported)
	LinkStatusTransmitFcsSize	32
- Bridge	BridgeConfigAdminStatus	<input checked="" type="radio"/> open <input type="radio"/> close
	BridgeOperStatus	not-opened
	LineConfigPppStp	<input checked="" type="radio"/> enable <input type="radio"/> disable
	OperStatusLinePppStp	enable
- Ip	IpConfigAdminStatus	<input type="radio"/> open <input checked="" type="radio"/> close
	IpOperStatus	not-opened
	LineConfigRemotIpAddr	0.0.0.0
	LineStatusRemotIpAddr	0.0.0.0
- Ipx	IpxcpAdminStatus	<input type="radio"/> open <input checked="" type="radio"/> close
	IpxOperStatus	down
	RoutingProtocol	<input type="radio"/> none <input checked="" type="radio"/> rip
	LineStatusIpxRoutingProtocol	0
- Lqr	LqrConfigStatus	<input checked="" type="radio"/> disabled <input type="radio"/> enabled
	OperStatusLqrStatus	1
	LqrConfigPeriod	100 (0..2147483647)
	LineStatusLocalPeriod	0
	LineConfigLqrThreshold	95 (1..100)
OperStatusLineLqrThreshold	95	

Buttons at the bottom: Apply, Refresh, Close, Help...

Table 9 describes the POS PPP tab fields.

Table 9 POS PPP tab fields

Area	Field	Description
Link	LinkConfigMagicNumber	If set to enable, selects a random number (“magic number”) used in loopback detection. Enable detects loopback; disable does not detect loopback.
	OperStatusLinkMagicNumber	Operational value of LinkConfigMagicNumber.
	LinkConfigFcsSize	Configures the size (in bits) of cyclic redundancy check field used in PPP frame.
	LinkStatusTransmitFcsSize	Operational value of LinkConfigFcsSize.
Bridge	BridgeAdminConfigStatus	This parameter enables or disables bridged traffic with in PPP.
	BridgeOperStatus	Operational value of BridgeAdminConfigStatus.
	LineConfigPppStp	Enables BPDUs to be received or transmitted with BPDU specific encapsulation. When disabled encapsulated within Ethernet frames.
	OperStatusLinePppStp	Operational value of LineConfigPppStp.
IP	IpConfigAdminStatus	Enables or disables the IP traffic (link) with in PPP.
	IpOperStatus	Operational value of IP link.
	LineConfigRemoteIPAddr	Configured value of remote end IP address.
	LineStatusRemoteIPAddr	Negotiated value of the remote end IP address.
IPX	IpxcpAdminStatus	Enables or disables the IPX traffic (link) with in PPP.
	IpxOperStatus	Operational value of IPX link.
	RoutingProtocol	Sets the IPX Routing Protocol to none or RIP.
	LineStatusIpxRoutingProtocol	Negotiated value of RoutingProtocol.
LQR	LqrConfigStatus	Sets the link quality reporting to enabled or disabled.
	OperStatusLqrStatus	Negotiated value of LqrConfigStatus.
	LqrConfigPeriod	Sets the link quality-reporting interval in 100th of a second.
	LineStatusLocalPeriod	Negotiated value of LqrConfigPeriod.
	LineConfigLqrThreshold	Sets input quality threshold in percent.
	OperStatusLqrThreshold	Operational value of LineConfigLqrThreshold.

4 In the BridgeConfigAdminStatus section, click close to disable bridging.

- 5 To enable IP routing, in the IpConfigAdminStatus field, click open.
- 6 To configure an IP address for the port:
 - a Highlight the port.
 - b Choose Edit > Port.

The Port dialog box opens with the Interface tab displayed (Figure 2 on page 40).

- c Click the IP Address tab.

The IP address tab opens (Figure 8).

Figure 8 Port dialog box — IP Address tab




Table 10 describes the fields in the IP Address tab.


Table 10 IP Address tab fields

Field	Description
IpAddress	IP address to which the entry's addressing information pertains.
NetMask	The subnet mask associated with the IP address of the entry.
BcastAddrFormat	The IP broadcast address format used on this interface.
ReasmMaxSize	The size of the largest IP datagram which this entity can re-assemble from incoming IP fragmented datagrams received on this interface.
VlanId	Unique VLAN identifier.
BrouterPort	indicates whether this entry corresponds to a brouter port (as opposed to a routable VLAN). This value cannot be changed after the row is created.

- d Click Insert.

The Port, Insert IP Address dialog box opens ([Figure 9](#)).

Figure 9 Port, Insert IP Address dialog box



[Table 11](#) describes the Port, Insert IP Address dialog box fields.

Table 11 Insert IP Address dialog box fields

Fields	Description
Ip Address	IP address to which the entry's addressing information pertains.
Net Mask	The subnet mask associated with the IP address of the entry.
VlanId	Unique VLAN identifier.

- e Type the IP address and click Insert.

The IP address displays in the table in the IP Address tab ([Figure 8](#)).

- 7 Click Apply.
- 8 To enable the port on the 8683POSM Module, click the Interface tab and, in the AdminStatus field, click up.
- 9 Click Apply.

Configuring IPX routing

When you use IPXCP encapsulation, you must select Ethernet II as the MAC encapsulation for the protocol-based VLANs. IPXCP supports only the Ethernet II format.

To configure the 8683POSM Modules for IPX routing using Device Manager, you must configure an Ethernet II protocol-based VLAN.

- 1 Highlight the port.
- 2 Choose Edit > port.

The Port dialog box opens with the Interface tab displayed (Figure 2 on page 40).

- 3 Disable the port as described in “Enabling or disabling a port” on page 46.
- 4 To configure the VLAN as an IPX protocol-based VLAN and assign the port to the VLAN:

- a From the Device Manager menu bar, choose VLAN > VLAN.

The VLAN dialog box opens with the Basic tab displayed (Figure 10).

Figure 10 VLAN dialog box — Basic tab




Table 12 describes the fields in the Basic tab.

Table 12 Basic tab fields

Field	Description
Id	Unique VLAN identifier.
Name	An administratively-assigned name for this VLAN.
ColorIdentifier	An administratively-assigned color code for this VLAN. The value of this object is used by the VLAN Manager GUI tool to select a color when it draws this VLAN on the screen.
Type	Type of VLAN, distinguished according to the policy used to define its port membership.
Stgld	Spanning Tree Group (STG) used by the VLAN to determine the state of its ports. If the VLAN is not associated with any STG, this value should be set to zero.

Table 12 Basic tab fields (continued)

Field	Description
PortMembers	Set of ports that are members (static or dynamic) of this VLAN.
ActiveMembers	Set of ports that are currently active in this VLAN. Active ports include all static ports and any dynamic ports where the VLAN policy was met.
StaticMembers	Set of ports that are static members of this VLAN. A static member of a VLAN is always active and is never aged out.
NotAllowedtoJoin	Set of ports that are not allowed to become members of this VLAN.
ProtocolId	Protocol identifier of this VLAN. This value is meaningful only if rcVlanType is equal to byProtocolId(3). For other VLAN types it should have the value none(0).
SubnetAddr	IP subnet address of this VLAN. This value is meaningful only if rcVlanType is equal to byIpSubnet(2). For other VLAN types it should have the value 0.0.0.0.
SubnetMask	IP subnet mask of this VLAN. This value is meaningful only if rcVlanType is equal to byIpSubnet(2). For other VLAN types it should have the value 0.0.0.0.

- b** To assign the POS ports to the VLAN as static members, enter the ports in the StaticMembers column.
 - c** To assign all other ports to the VLAN as active members, enter the ports in the ActiveMembers column.
 - d** Click Apply.
- 5** To disable bridging:
- a** Click the POS PPP tab.
 - b** In the Bridge area, BridgeConfigAdminStatus field, click Close.
- 6** To enable IPX routing on each selected port:
- a** Click the POS PPP tab.
 - b** In the IPX area, IpxcpAdminStatus field, click Open.
- 7** To enable the port on the 8683POSM Module:
- a** Click the Interface tab.
 - b** In the AdminStatus field, click Up.

- 8 Click Apply.

Configuring the SONET trap feature

The 8600 chassis with a functioning 8683POSM Module automatically transmits SONET-specific traps.


To configure the device for SONET-specific traps:

- 1 In Device Manager, select the chassis.

The frame of the chassis is highlighted.

- 2 Choose Edit > Chassis.

The Chassis dialog box opens with the System tab displayed ([Figure 11](#)).

Figure 11 Chassis dialog box — System tab

3 Click the Trap Receivers tab.

The Trap Receivers tab opens ([Figure 12](#)).


Figure 12 Chassis dialog box — Trap Receivers tab

Table 13 describes the fields in the Trap Receivers tab.

Table 13 Trap Receivers tab fields

Field	Description
IpAddress	IP address of the device used to capture traps.
Community	Community string used for trap messages to this trap receiver.
Version	Version

4 Click Insert.

The Chassis, Insert Trap Receivers dialog box opens (Figure 13).

Figure 13 Chassis, Insert Trap Receiver dialog box




Table 14 describes the fields in the Insert Trap Receiver dialog box.

Table 14 Insert Trap Receiver dialog box fields

Field	Description
IpAddress	IP address of the device used to capture traps.
Community	Community string used for trap messages to this trap receiver
Version	Version

5 Enter the IP address of the device where traps are to be sent and click Insert.

The dialog box closes and the Trap Receivers tab is redisplayed.

6 Click Apply.


Viewing the Trap Log

To view the Trap Log that contains SONET-specific traps:

➔ Click the bell icon on the toolbar.

The Trap dialog box opens (Figure 14).

Figure 14 Trap Log dialog box



Node	Time	Type	Description
10.125.200.45	2001/01/25-13:15:03	linkDown.0	ifIndex.0=2/3 ifAdminStatus.0=down ifOperStatus....
10.125.200.45	2001/01/25-13:15:45	linkUp.0	ifIndex.0=2/3 ifAdminStatus.0=up ifOperStatus.0=u...
10.125.200.45	2001/01/25-13:16:14	rcStpTopologyChang...	rcStgld.0=1 rcPortIndex.0=2/3
10.125.200.45	2001/01/25-13:17:20	rcSonetTrap.0	rcPortIndex.0=2/3 rcPosSonetTrapType.0=sectionAl...
10.125.200.45	2001/01/25-13:17:21	linkDown.0	ifIndex.0=2/3 ifAdminStatus.0=up ifOperStatus.0=d...
10.125.200.45	2001/01/25-13:17:41	rcSonetTrap.0	rcPortIndex.0=2/3 rcPosSonetTrapType.0=sectionAl...
10.125.200.45	2001/01/25-13:17:41	rcSonetTrap.0	rcPortIndex.0=2/3 rcPosSonetTrapType.0=pathAlar...
10.125.200.45	2001/01/25-13:17:41	rcSonetTrap.0	rcPortIndex.0=2/3 rcPosSonetTrapType.0=pathAlar...
10.125.200.45	2001/01/25-13:17:45	linkUp.0	ifIndex.0=2/3 ifAdminStatus.0=up ifOperStatus.0=u...
10.125.200.45	2001/01/25-13:18:14	rcStpTopologyChang...	rcStgld.0=1 rcPortIndex.0=2/3

Buttons: Export... Clear ▼ Close

Table 15 describes the fields in the Trap Log dialog box.

Table 15 Trap Log dialog box fields

Field	Description
Node	IP address of the device sending SONET trap.
Time	Timestamp in the trap.
Type	Type of SONET trap: Section/Line/Path alarm.
Description	Description of the alarm: LOS, LOF, and so forth.

SONET loopback test feature

This section describes the loopback test features in Device Manager available for the 8683POSM Module. For information on the CLI test commands, see [“Using the test commands” on page 112](#)




Note: All ports must be in test mode to conduct any testing.

To test for loopback:

- 1 Highlight the port.
- 2 Choose Edit > port.
The Port dialog box opens with the Interface tab displayed ([Figure 2 on page 40](#)).
- 3 In the AdminStatus field, click testing.
- 4 Click Apply.
- 5 Click the Test tab.

The Test tab opens ([Figure 15](#)).

Figure 15 Port dialog box — Test tab



[Table 16](#) describes the Test tab fields.

Table 16 Test tab fields

Field	Description
Result	Result of the test.
Code	Code used for test.
PassCount	Number of events which passed the test.
FailCount	Number of events which failed the test.

- 6** Click Ext. Loopback to test the external loopback or click Int. Loopback to test the internal loopback.

A dialog box displays the test results.

- 7** Click Stop to cease testing.
- 8** Click Close.
- 9** Click the Interface tab.
- 10** In the AdminStatus field, click up.
- 11** Click Apply.



Note: To run the external loopback test, you need a loopback cable on that port.

The test statistics are available only when the test has finished, unlike Ethernet ports where the test statistics can be viewed during testing.

Viewing 8683POSM statistics

Device Manager allows you to graph and display certain read-only statistics for the 8683POSM Module.

The 8683POSM Module provides the following read-only statistics tabs:

- [“Viewing POS statistics,”](#) next
- [“Viewing PPP Link statistics”](#) on page 65
- [“Viewing PPP Link Quality Reporting statistics”](#) on page 66

- “Viewing Section statistics” on page 68
- “Viewing Line statistics” on page 69
- “Viewing FE Line statistics” on page 70
- “Viewing Path statistics” on page 71
- “Viewing FE Path statistics” on page 72

Refer to *Reference for the 8000 Series Management Software Switching Operations, Release 3.1* for complete details on graphing statistics.

The values for the POS, PPP Link, and PPP LQR tabs are displayed for absolute, cumulative, average, minimum, maximum, and last values.

The values for the POS, PPP Link, and PPP LQR tabs are updated based on the poll interval.

For information on how to set the poll interval, refer to *System and Platform Management*.

Table 17 describes these values.

Table 17 Types of statistics

Field	Description
AbsoluteValue	The total count since the last reset of counters. A system reboot resets all counters.
Cumulative	The total count since the statistics tab was first opened. The elapsed time for the cumulative counter is displayed at the bottom of the statistics window.
Average	The cumulative count divided by the cumulative elapsed time.
Minimum	The minimum average for the counter for a given polling interval over the cumulative elapsed time.
Maximum	The maximum average for the counter for a given polling interval over the cumulative elapsed time.
LastValue	The average for the counter over the last polling period.

Viewing POS statistics

To display statistics POS statistics:

- 1 On the device view, right-click the port.
- 2 Choose Graph POS.

The graphSonetPort dialog box opens with the POS tab displayed (Figure 16).

Figure 16 graphSonetPort dialog box — POS tab

POS	PPP Link	PPP LQR	Section	Line	FE Line	Path	FE Path	AbsoluteValue	Cumulative	Average/sec	Minimum/sec	Maximum/sec	LastVal/sec
InErrors								225	0	0	0	0	0
InUnknownProtos								0	0	0	0	0	0
OutErrors								0	0	0	0	0	0
HCInOctets								303,570	0	0	0	0	0
HCInUcastPkts								4,348	0	0	0	0	0
HCInDiscards								0	0	0	0	0	0
HCOctets								810,967	0	0	0	0	0
HCOOutUcastPkts								15,149	0	0	0	0	0
HCOOutDiscards								0	0	0	0	0	0

Table 18 describes the fields in the POS tab.

Table 18 POS tab fields

Field	Description
InErrors	Number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.
InUnknownProtos	Number of packets received via the interface which were discarded because of an unknown or unsupported protocol.
OutErrors	Number of outbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.
HCInOctets	The total number of octets received on the interface, including framing characters.

Table 18 POS tab fields (continued)

Field	Description
HCIInUcastPkts	Number of packets delivered by this sub-layer to a higher (sub-)layer, which were not addressed to a multicast or broadcast address at this sub-layer.
HCIInDiscards	Number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol.
HCOOutOctets	The total number of octets transmitted out of the interface, including framing characters.
HCOOutUcastPkts	Number of packets that higher-level protocols requested be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.
HCOOutDiscards	Number of outbound packets which were chosen to be discarded.

Viewing PPP Link statistics

To display PPP Link statistics:

- 1 On the device view, right-click the port.
- 2 Choose Graph Port.

The graphSonetPort dialog box opens with the POS statistics tab displayed (Figure 16).

- 3 Click the PPP Link tab.

The PPP Link tab opens (Figure 17).

Figure 17 graphSonetPort dialog box — PPP Link tab

POS	PPP Link	PPP LQR	Section	Line	FE Line	Path	FE Path
		AbsoluteValue	Cumulative	Average/sec	Minimum/sec	Maximum/sec	LastVal/sec
	BadAddresses	0	0	0	0	0	0
	BadControls	2	0	0	0	0	0
	BadFCSs	1,936	0	0	0	0	0
	LocalMRU	1,936					
	PacketTooLongs	225	0	0	0	0	0

Table 19 describes the fields in the PPP Link tab.

Table 19 PPP Link tab fields

Field	Description
BadAddresses	Number of packets received with an Incorrect Address Field. This counter is a Component of the ifInErrors variable that is associated with the interface that represents this PPP Link.
BadControls	Number of packets received on this link with an incorrect Control Field. This counter is a component of the ifInErrors variable that is associated with the interface that represents this PPP Link.
BadFCSs	The number of received packets that have been discarded due to having an incorrect FCS.
LocalMRU	This is the current value of the MRU (Maximum Receive Unit) that the remote entity is using when sending packets to the local PPP entity.
PacketTooLongs	Number of received packets that have been discarded because their length exceeded the MRU. This counter is a component of the ifInErrors variable that is associated with the interface that represents this PPP Link. NOTE: packets which are longer than the MRU but which are successfully received and processed are NOT included in this count.

Viewing PPP Link Quality Reporting statistics

To display PPP Link Quality Reporting (LQR) statistics:

- 1 On the device view, right-click the port.

2 Choose Graph Port.

The graphSonetPort dialog box opens with the POS statistics tab displayed (Figure 16).

3 Click the PPP LQR tab.

The PPP LQR tab opens (Figure 18).

Figure 18 graphSonetPort dialog box — PPP LQR tab

	AbsoluteValue	Cumulative	Average/sec	Minimum/sec	Maximum/sec	LastVal/sec
Quality	0					
InGoodOctets	0	0.0	0.0	0.0	0.0	0.0
LocalPeriod	0					
RemotePeriod	0					
OutLQRs	0	0.0	0.0	0.0	0.0	0.0
InLQRs	0	0.0	0.0	0.0	0.0	0.0

Table 20 describes the fields in the PPP LQR tab.

Table 20 PPP LQR tab fields

Field	Description
Quality	This is the current quality of the link. It reflects the quality measurements with respect to the quality threshold.
InGoodOctets	Number of good octets received on the interface.
LocalPeriod	Time interval in 100th of a second between link quality reporting from local end.
RemotePeriod	Time interval in 100th of a second between link quality reporting from remote end.
OutLQRs	The number of Link Quality Reports transmitted by this node.
InLQRs	The number of Link Quality Reports received by this node.

Viewing Section statistics

To display Section statistics:


- 1 On the device view, right-click the port.
- 2 Choose Graph Port.

The graphSonetPort dialog box opens with the POS statistics tab displayed (Figure 16 on page 64).

- 3 Click the Section tab.

The Section tab opens (Figure 19).

Figure 19 graphSonetPort dialog box — Section tab



[Table 21](#) describes the fields in the Section tab.

Table 21 Section tab fields

Field	Description
ESs	Errored Second (ES) is a second with one or more Coding Violations or one or more incoming defects, for example, SEF, LOS, AIS, LOP.
SESSs	Severely Errored Second (SES) is a second with x or more CVs, or a second during which at least one or more incoming defects.
SEFSs	Severely Errored Framing Second (SEFS) is a second containing one or more SEF events.
CVs	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.

Viewing Line statistics


To display Line statistics:

- 1 On the device view, right-click the port.
- 2 Choose Graph Port.

The graphSonetPort dialog box opens with the POS statistics tab displayed ([Figure 16 on page 64](#)).

- 3 Click the Line tab.

The Line tab opens ([Figure 20](#)).

Figure 20 graphSonetPort dialog box — Line tab

[Table 22](#) describes the fields in the Line tab.

Table 22 Line tab fields

Field	Description
ESs	Errored Second (ES) is a second with one or more Coding Violations or one or more incoming defects, for example, SEF, LOS, AIS, or LOP.
SESs	Severely Errored Second (SES) is a second with x or more CVs, or a second during which at least one or more incoming defects.
CVs	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UASs	Number of seconds that the interface is unavailable.

Viewing FE Line statistics


To display FE Line statistics:

- 1 On the device view, right-click the port.
- 2 Choose Graph Port.

The graphSonetPort dialog box opens with the POS statistics tab displayed ([Figure 16 on page 64](#)).

- 3 Click the FE Line tab.

The FE Line tab opens ([Figure 21](#)).

Figure 21 graphSonetPort dialog box — FE Line tab

[Table 23](#) describes the fields in the FE Line tab.

Table 23 FE Line tab fields

Field	Description
ESs	Errored Second (ES) is a second with one or more Coding Violations or one or more incoming defects, for example, SEF, LOS, AIS, or LOP.
SESs	Severely Errored Second (SES) is a second with x or more CVs, or a second during which at least one or more incoming defects.
CVs	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UASs	Number of seconds that the interface is unavailable.

Viewing Path statistics

To display Path statistics:

- 1 On the device view, right-click the port.
- 2 Choose Graph Port.

The graphSonetPort dialog box opens with the POS statistics tab displayed ([Figure 16 on page 64](#)).

- 3 Click the Path tab.

The Path tab opens ([Figure 22](#)).


Figure 22 graphSonetPort dialog box — Path tab

Table 24 describes the fields in the Path tab.

Table 24 Path tab fields

Field	Description
ESs	Errored Second (ES) is a second with one or more Coding Violations or one or more incoming defects, for example, SEF, LOS, AIS, or LOP.
SESs	Severely Errored Second (SES) is a second with x or more CVs, or a second during which at least one or more incoming defects.
CVs	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UASs	Number of seconds that the interface is unavailable.

Viewing FE Path statistics


To display Path statistics:

- 1 On the device view, right-click the port.
- 2 Choose Graph Port.

The graphSonetPort dialog box opens with the POS statistics tab displayed (Figure 16 on page 64).

- 3 Click the FE Path tab.

The FE Path tab opens (Figure 23).

Figure 23 graphSonetPort dialog box — FE Path tab

[Table 25](#) describes the fields in the FE Path tab.

Table 25 FE Path tab fields

Field	Description
ESs	Errored Second (ES) is a second with one or more Coding Violations or one or more incoming defects, for example, SEF, LOS, AIS, or LOP.
SESs	Severely Errored Second (SES) is a second with x or more CVs, or a second during which at least one or more incoming defects.
CVs	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UASs	Number of seconds that the interface is unavailable.

Chapter 4

Using the CLI

Two management tools enable you to manage the 8683POSM Module: Device Manager and command line interface (CLI). You can also use the embedded web-based management feature to monitor the 8683POSM Module. See [Chapter 5, “Web management,” on page 115](#) for information on using the web-based management feature.

This chapter describes how to use the CLI to configure POS-specific features, and contains the following topics:

Topic	Page
Configuring and managing POS	75
Using the show commands	85
Using the monitor commands	111
Using the test commands	112

Configuring and managing POS

You can configure the 8683POSM Module in two basic modes:

- **Bridging:** Bridging mode is enabled by default. Bridging is configured for connections between two 8683POSM Modules and between 8683POSM Modules and other devices that support PPP bridging.
- **Routing:** You select routing mode for connections between your 8683POSM Module and other POS-capable routers for IP and IPX routing.

This section describes how to use Device Manager to configure and manage POS, and includes the following topics:

- “Default 8683POSM configuration” on page 76”
- “Using the config poscard commands” on page 76”
- “Using the config pos port commands” on page 77”
- “Using the config pos info command” on page 81”
- “Using the config pos sonet command” on page 82
- “Using the config pos stg command” on page 83
- “Configuring routing” on page 83”

Default 8683POSM configuration

[Table 3 on page 38](#) describes the default 8683POSM module configuration.

Using the config poscard commands

The `config poscard` command allows you to:

- Reset the module
- Enable trace messages
- Display the image filename for the 8683POSM Module

The syntax is:

```
config poscard <posslot number>
```

where <posslot number> is the slot number of the module in the 8600 chassis.

Table 26 describes the parameters and variables for the `config poscard` command.

Table 26 config poscard command parameters and variables

Parameters and variables	Description
card-reset	Resets the card.
debug <enable disable>	Enables or disables trace messages on the module to be displayed on the console of the switch.
info	Displays the image filename and debug mode for the module.
pos-console <enable disable>	Prints the trace message POSM card. This is a priv command. When the pos-console is enabled (on the host), POS prints trace messages on the POS console. You can also use this command to query information on the POSM card or port. To use this command, you must be in <code>priv</code> mode. The syntax to enter priv mode is: <code>config/poscard/<port number>/priv</code>

Using the config pos port commands

The port commands allow you to perform general configuration on the 8683POSM Module. The syntax for the `port config` commands is:

- `config pos <ports>`
- `config pos <ports> ip`
- `config pos <ports> ppp`
- `config pos <ports> sonet`
- `config pos <ports> stg`
- `config pos <ports> info`

The port commands, variables and parameters and sub-commands are described in the following sections.

config pos command

[Table 27](#) describes the parameters and variables for the `config pos <ports>` command.

Table 27 config pos command parameters and variables

Parameters and variables	Description
default-vlan-id <vid>	Directs the switch to send the untagged frames to a default VLAN if received on a tagged port. <vid> is the VLAN ID of the default VLAN to which the discarded frames are sent.
info	Shows the last saved port settings and the next-level CLI commands. Note that this does not show the current settings, but the last saved settings.
linktrap <enable disable>	Enables or disables the link up or down trap for a port.
lock <true false>	Locks a port for exclusive use if the port lock feature is globally enabled with the command <code>config sys set portlock on</code>
name <name>	Assign or set a name.
perform-tagging <enable disable>	Enables or disables the IEEE 802.1Q tagging on the port.
state <enable disable test>	Sets the state to enable, disable, or test.
tagged-frames-discard <enable disable>	Sets a port with tagging disabled to discard tagging frames.
untagged-frames-discard <enable disable>	Sets a port with tagging enabled to discard untagged frames.

config pos ip

Use the `config pos ip` command to configure IP parameters on the 8683POSM Module.



Note: When the 8600 switch is interoperating with a Juniper router, the POS port must have the Juniper IP address configured in the remote IP field. This is necessary because the Juniper routers do not provide their local IP address during PPP negotiation. The 8600 switch requires the Juniper address for IPCP operations.

Note also that for the IP address assigned to the POS port, 30-bit subnet masks may be required for certain JUNOS releases.

Table 28 describes the parameters and variables for the `config pos ip` command.

Table 28 config pos ip command parameters and variables

Parameters and variables	Description
create <ipaddr/mask> <vid> [mac_offset <value>]	Creates an IP address and assigns it to a VLAN, with the VLAN ID.
delete <ipaddr>	Deletes the IP address.
info	Shows the last saved port settings and the next-level CLI commands. Note that this does not show the current settings, but the last saved settings.

config pos ppp

Use the `config pos ppp` command to configure Point-to-Point Protocol (PPP) parameters on the 8683POSM Module.

[Table 29](#) describes the parameters and variables for the `config pos ppp` command.

Table 29 config pos ppp command parameters and variables

Parameters and variables	Description
bridge-admin-status <open close>	Enables or disables the bridge control protocol.
fcs-size<32 16>	Sets the length of the redundancy check (fcs) to either 32 or 16.
info	Shows the last saved port settings and the next-level CLI commands. Note that this does not show the current settings, but the last saved settings.
ip-admin-status <open close>	Enables or disables the IP control protocol.
ipx-admin-status <open close>	Enables or disables the IPX control protocol.
ipx-route-protocol <none rip>	Sets the protocol for IPX routing.
lqr-period <interval>	Sets the link quality reporting interval. Enter time in ms.
lqr-status <enable disable>	Enables or disables link quality reporting.
lqr-threshold <threshold>	Sets the link quality reporting threshold. Enter %.
magic-number <true false>	Sets a random number ("magic number") used in loopback detection. True detects loopback; false does not detect loopback.

ppp-stpmode <enable disable>	Encapsulates spanning tree BPDU packets as PPP. When enabled the BPDUs are encapsulated as in RFC 1638. When disabled, the BPDUs travel as bridged data (assuming bridge-admin-status is enabled).
remote-ip<ipaddr>	Sets the remote IP address.

Using the config pos info command

The `config pos info` command shows the current state of the port.

[Figure 24](#) shows a sample of the output from the `config pos info` command.

Figure 24 config pos info command sample output

```
8610:5/config# pos 10/5 info
Port 10/5 :
                lock : false
                name :
unknown-mac-discard : disable
  default-vlan-id : 1
  perform-tagging : disable
tagged-frames-discard : disable
untagged-frames-discard : disable
                state : up
                linktrap : enable
                port-type : OC3-MMF

8610:5/config#
```

Using the config pos sonet command

Use the `config pos sonet` command to configure SONET parameters on the 8683POSM Module.

[Table 30](#) describes the parameters and variables for the `config pos sonet` command.

Table 30 config pos sonet command parameters and variables

Parameters and variables	Description
clock-source <internal line>	Sets the clock source to: <ul style="list-style-type: none"> • <internal>, which means clocking is derived from on-board clock. • <line>, which means clocking is derived from line. Note that if you have two connected modules, you must set both to internal or one to line and one to internal; do not set both to line.
framing <sonet sdh>	Sets the framing to: <ul style="list-style-type: none"> • <sonet>, which means the Synchronous Optical Network format, the standard format used in North America. • <sdh>, which means the Synchronous Digital Hierarchy clock format, the standard format used in Europe.
info	Shows the last saved port settings and the next-level CLI commands. Note that this does not show the current settings, but the last saved settings.
signal label	Operational value of Path Signal Label (C2). The signal label value is reset when the scramble value is changed.
scramble <enable disable>	Enables or disables scrambling.
section-trace <sectiontrace>	Sets the integer that the section trace flag (j0) is set to (1...255).
z0-increment	Enables or disables z0 when the framing mode is set to SONET. This is a priv command - to use this command, you must be in privilege mode. The syntax to enter priv mode is: <code>config/pos/<port number>/sonet priv</code>

Using the config pos stg command

Use the `config pos stg` command to configure STG parameters on the 8683POSM Module.

[Table 31](#) describes the parameters and variables for the `config pos stg` command.

Table 31 config pos stg command parameters and variables

Parameters and variables	Description
faststart <enable disable>	Enables or disables the fast start flag.
info	Shows the last saved port settings and the next-level CLI commands. Note that this does not show the current settings, but the last saved settings.
pathcost <intval>	Sets the contribution of this port to the path cost.
priority <intval>	Sets the priority of this port.
stg <enable disable>	Enables or disables spanning tree protocol.

Configuring routing

A POS port configured for IPCP and/or IPXCP encapsulation must be the sole member of the VLAN. You cannot add any other port to a VLAN which already has a POS port with IPCP and/or IPXCP encapsulation enabled. You cannot add a POS port which is configured for IPCP and/or IPXCP encapsulation to a VLAN which already has other ports as members.



Note: When the 8600 switch is interoperating with a Juniper router, the POS port must have the Juniper IP address configured in the remote IP field. This is necessary because the Juniper routers do not provide their local IP address during PPP negotiation. The 8600 switch requires the Juniper address for IPCP operations.

Note also that for the IP address assigned to the POS port, 30-bit subnet masks may be required for certain JUNOS releases.

Configuring IP routing

To configure the 8683POSM Modules for IP routing using the CLI:

- 1 To disable the selected port on the 8683POSM Module, enter:

```
config pos <ports> state disable
```
- 2 To disable bridging, enter:

```
config pos <ports> bridge-admin-status close
```
- 3 To configure IP routing, enter:

```
config pos <ports>> ppp ip-admin-status open
```
- 4 To configure an IP address on the selected port on the 8683POSM Module, enter:

```
config pos <ports> ip create <ipaddr/mask> <vid>
```
- 5 To enable the selected port on the 8683POSM Module, enter:

```
config pos <ports> state enable
```

Configuring IPX routing

To configure the 8683POSM Modules for IPX routing using the CLI:

- 1 Configure a protocol-based VLAN and assign the port to the VLAN as a static member and ensure that no other ports are allowed to join.
- 2 To disable the selected port on the 8683POSM Module, enter:

```
config pos <ports> state disable
```
- 3 To disable bridging, enter:

```
config pos <ports> bridge-admin-status close.
```
- 4 To configure IPX routing, enter:

```
config pos <ports> ppp ipx-admin-status open.
```

- 5 To enable the selected port on the 8683POSM Module, enter:

```
config pos <ports> state enable
```

Using the show commands

This section describes the show commands available with the 8683POSM Module. These commands allow you to view information about the module:

```
show ports info pos [<ports>]
show ports stats pos activealarms [<ports>]
show ports stats pos felinecurrent [<ports>]
show ports stats pos felineinterval <intervalid> [<ports>]
show ports stats pos fepathcurrent [<ports>]
show ports stats pos fepathinterval <intervalid> [<ports>]
show ports stats pos linecurrent [<ports>]
show ports stats pos lineinterval <intervalid> [<ports>]
show ports stats pos linkstatus [<ports>]
show ports stats pos lqrstatus [<ports>]
show ports stats pos pathcurrent [<ports>]
show ports stats pos pathinterval <intervalid> [<ports>>]
show ports stats pos pppiftbl [<ports>]
show ports stats pos sectioncurrent [<ports>]
show ports stats pos sectioninterval <intervalid> [<ports>]
show ports stats pos sonetmediumtbl [<ports>]
```

For a complete list of CLI commands, see the documentation associated with your software release on the Web at <http://www.nortelnetworks.com/documentation>.

show ports info pos

The `show ports info pos` command displays information (Figure 25) about the configuration for a specified port on the 8683POSM Module.

The command uses the syntax: `show ports info pos [<ports>]` and options: `all`, `ppp`, `sonet` in the following syntax:

```
show ports info pos all
show ports info pos ppp
show ports info pos sonet
```

show ports info pos all

Figure 25 shows sample output for the `show ports info pos all` command, which includes information for the PPP and SONET parameters.

Figure 25 show ports info pos all command output

```

8610:5/show/ports/info/pos# all
=====
                                SONET Config Info
=====
PORT  FRAMING  CLOCK      SECTION   SIGNAL
NUM   MODE     SOURCE     TRACE     LABEL  SCRAMBLE
-----
10/1  sonet     line 1     0x16     enable
10/3  sonet     internal 1  0x16     enable
=====
                                SONET Local Operational Info
=====
PORT  FRAMING  CLOCK      SECTION   SIGNAL
NUM   MODE     SOURCE     TRACE     LABEL  SCRAMBLE
-----
10/1  sonet     line       1         0x16   enable
10/3  sonet     internal 1         0x16   enable
=====
                                PPP Config Info
=====
PORT  ADMIN      BRIDGE     IP         IPX        MAGIC PPP
NUM   STATUS     ADMIN      ADMIN      ADMIN      NUMBERSTP  LQSTATUS
-----
10/1  up         open       close      close      false enable enable
10/3  up         open       close      close      false enable enable

PORT          FCS  IPX ROUTE  LQR-QUAL  LQR-QUAL
NUM   SPEED  MRU   SIZE  PROTOCOL  THRESHOLD  PERIOD  REMOTE  IP
-----
10/1  OC3-MMF 1936 32  rip          95         100     0.0.0.0 -M
10/3  OC3-MMF 1936 32  rip          95         100     0.0.0.0 -M

PORT  IPX NET
NUM   ADDR
-----
10/1  0000000
10/3  0000000
=====
                                PPP Local Operational Info
=====
PORT  STATUS      LCP        BRIDGE     IP         IPX        MAGIC
NUM   OPERATE     STATUS     STATUS     STATUS     STATUS     NUMBER  STPMODE
-----
10/1  up          up         down       up         down       false  enable
10/3  up          up         down       up         down       false  enable

```

Figure 26 show ports info pos all command output (continued)

```

PORT  PPP
NUM  LQSTATUS  MRU    FCS  IPX ROUTE  LQR-QUAL  LQR-QUAL
-----
10/1  enable    1936   32   none      95         100      10.32.6.14
10/3  enable    1936   32   none      95         100      10.32.6.10

PORT  IPX NET
NUM  ADDR
-----
10/1  00000000
10/3  00000000
=====
                                Other Info
=====
PORT  POS S/W  PLD    FRAMER  CARD
NUM  VERSION VERSION VERSION VERSION
-----
10/1  51      7      2      POS  7

8610:5/show/ports/info/pos# all

```

[Table 32](#) describes the fields for output of the `show ports info pos all` command

Table 32 show ports info pos all command parameters

Field	Description
PORT NUM	Port number.
FRAMING MODE	Indicates whether the framing mode is either: <ul style="list-style-type: none"> • sonet • sdh
CLOCK SOURCE	Indicates whether the clock source is either: <ul style="list-style-type: none"> • line • internal
SECTION TRACE	Indicates the integer that the section trace flag (j0) is set to.
SIGNAL LABEL	Operational value of Path Signal Label (C2). The signal label value is reset when the scramble value is changed.
SCRAMBLE	Enables or disables the scrambling option.
ADMIN STATUS	Sets the port to one of the following states: <ul style="list-style-type: none"> • up • down • testing
BRIDGE ADMIN	This parameter indicates bridged traffic within PPP.
IP ADMIN	This parameter indicates the IP traffic (link) within PPP.
IPX ADMIN	This parameter indicates the IPX traffic (link) within PPP.
MAGIC NUMBER	If set to enable, selects a random number ("magic number") used in loopback detection. enable detects loopback; disable does not detect loopback.
STPMODE	Spanning Tree Protocol mode - This parameter enables BPDUs to be received or transmitted with BPDU specific encapsulation. When disabled, encapsulated within Ethernet frames.
PPP LQSTATUS	Sets the link quality reporting interval.
SPEED	Displays the current operating speed of the port. It can be either 155 or 622 Mb/s depending on the type of interface installed.
MRU	Size (in octets) of the largest packet that can be sent or received on the interface. For IPCP and IPXCP, the maximum is 1936. When BCP is enabled, however, the maximum is 1934. Check which NCP is enabled before configuring the Mru. Note: The Bridge Control Protocol (BCP) is enabled on the 8683POSM Module by default.

Table 32 show ports info pos all command parameters (continued)

Field	Description
FCS SIZE	Sets the length of the redundancy check (fcs) to either 32 or 16.
IPX ROUTE PROTOCOL	Sets the protocol for IPX routing.
LQR-QUAL THRESHOLD	Indicates the link quality reporting threshold.
LQR-QUAL PERIOD	Indicates the link quality reporting interval.
REMOTE IP	Indicates the remote iP address.
IPX NET ADDR	Indicates the IPX net address.
STATUS OPERATE	Operational status.
LCP STATUS	Link Control Protocol status.
BRIDGE STATUS	Bridging status.
IP STATUS	Routing (IP) status.
IPX STATUS	Routing (IPX) status
PPP LQSTATUS	Point-to-Point status

show ports stats pos activealarms

This command displays active alarms on the 8683POSM Module port. The command uses the syntax:

```
show ports stats pos activealarms [<ports>]
```

Figure 27 shows output for the show ports stats pos activealarms command.

Figure 27 show ports stats pos activealarms command output

```

8610:5/show/ports# stats pos activealarms
=====
                        Active Alarms
=====
PORT
NUM      ACTIVE ALARM
-----
10/5     No Defect
10/6     LOS

8610:5/show/ports/stats/pos#

```

[Table 33](#) describes the information fields for output for the `show ports stats pos activealarms` command.

Table 33 show ports stats pos activealarms command parameters

Field	Description
PORT NUM	Port number.
ACTIVE ALARM	Displays active alarms on the port.

[Table 34](#) lists the alarms that are specific to the 8683POSM Module. The alarms are listed in order of priority.

Table 34 8683POSM Module alarms

Name	Description
Section alarms	
LOS	Loss of signal - not enough Rx power or fiber disconnected.
LOF	Loss of frame - unable to frame the signal correctly, possibly due to improper timing setup.
Line Alarms	
L-AIS	Alarm Indication Signal - sent out when a port is disabled or indicates another line failure.
L-RDI	Remote Defect Indication - the result of a L-AIS or LOS/LOF at the remote end.

Table 34 8683POSM Module alarms (continued)

Name	Description
Path Alarms	
P-AIS	Path Alarm Indication Signal - indicates a propagation upstream of a downstream L-AIS alarm or another path failure.
P-LOP	Path Loss of Pointer - the pointer to the Sonet SPE is not correct; sometimes due to dirty fiber, or timing slips.
P-RDI	Path Remote Indicator - the result of a P-AIS alarm at the remote end.
P-SLM	Path Signal Label Mismatch - path labels do not match, in particular the C2 label is mismatched. (The C2 label is used to indicate scrambling according to RFC 2615.)
P-UNEQ	Unequipped Path Alarm - the path does not have a valid sender.

show ports stats pos felinecurrent

This command displays current statistics on the far end line, which is at the receiving end. The command uses the syntax:

```
show ports stats pos felinecurrent [<ports>]
```

Figure 28 shows sample output for the show ports stats pos felinecurrent command.

Figure 28 show ports stats pos felinecurrent command output

```
8610:5/show/ports/stats/pos# felinecurrent
=====
                        POS Far End Line Current Stats
=====
PORT      ERRORED SECONDS   SEVERELY ERRORED   CODE VIOLATION UNAVAILABLE
NUM      COUNT (ES)        COUNT (SES)        COUNT (CV-L) SECONDS(UAS)
-----
10/5     0                  0                  0                0
10/6     0                  0                  0                0

8610:5/show/ports/stats/pos#
```

[Table 35](#) describes the `show ports stats pos felinecurrent` command parameters.

Table 35 `show ports stats pos felinecurrent` command parameters

Field	Description
PORT NUM	Port number.
ERRORED SECONDS COUNT (ES)	Errored Second (ES) is a second with one or more Coding Violations (CV) or one or more incoming defects (for example, SEF, LOS, AIS, LOP).
SEVERELY ERRORED COUNT (SES)	Severely Errored Second (SES) is a second with x or more CVs, or one or more incoming defects.
CODE VIOLATION COUNT (CV-L)	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UNAVAILABLE SECONDS	Number of seconds that the interface is unavailable.

show ports stats pos felineinterval

This command displays statistics ([Figure 29](#)) on the far end line over a 15-minute interval. You specify which interval, or span of intervals, to display for the command. The command uses the syntax:

```
show ports stats pos felineinterval <intervalid> [<ports> ]
```

Figure 29 show ports stats pos felineinterval command output

```
8610:5/show/ports/stats/pos# felineinterval 4
=====
                POS Far End Line Interval Stats
=====
PORT      ERRORED SECONDS   SEVERELY ERRORED   CODE VIOLATION UNAVAILABLE
NUM      COUNT (ES)        COUNT (SES)        COUNT (CV-L) SECONDS(UAS)
-----
10/5     0                  0                  0                0
10/6     0                  0                  0                0

INTERVAL ID = 4
8610:5/show/ports/stats/pos#
```

[Table 36](#) describes the show ports stats pos felineinterval command

Table 36 show ports stats pos felineinterval command parameters

Field	Description
PORT NUM	Port number.
ERRORED SECONDS COUNT (ES)	Errored Second (ES) is a second with one or more Coding Violations (CV) or one or more incoming defects (for example, SEF, LOS, AIS, LOP).
SEVERELY ERRORED COUNT (SES)	Severely Errored Second (SES) is a second with x or more CVs, or one or more incoming defects.
CODE VIOLATION COUNT (CV-L)	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UNAVAILABLE SECONDS (UAS)	Number of seconds that the interface is unavailable.
INTERVAL ID	Specified interval.

show ports stats pos fepathcurrent

This command displays current statistics ([Figure 30](#)) for the far end path, which is at the receiving end. The command uses the syntax:

```
show ports stats pos fepathcurrent [<ports>]
```

Figure 30 show ports stats pos fepathcurrent command output

```
8610:5/show/ports/stats/pos# fepathcurrent
=====
                POS Far End Path Current Stats
=====
PORT      ERRORED SECONDS   SEVERELY ERRORED   CODE VIOLATION   UNAVAILABLE
NUM      COUNT (ES)       COUNT (SES)        COUNT (CV-P)     SECONDS(UAS)
-----
10/1      0                 0                  0                0
10/3      0                 0                  0                527

8610:5/show/ports/stats/pos#
```

[Table 37](#) describes the `show ports stats pos fepathcurrent` command parameters.

Table 37 `show ports stats pos fepathcurrent` command parameters

Field	Description
PORT NUM	Port number.
ERRORED SECONDS COUNT (ES)	Errored Second (ES) is a second with one or more Coding Violations (CV) or one or more incoming defects (for example, SEF, LOS, AIS, LOP).
SEVERELY ERRORED COUNT (SES)	Severely Errored Second (SES) is a second with x or more CVs, or one or more incoming defects.
CODE VIOLATION COUNT (CV-P)	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UNAVAILABLE SECONDS (UAS)	Number of seconds that the interface is unavailable.

show ports stats pos fepathinterval

This command displays statistics ([Figure 31](#)) on the far end path over a 15-minute interval. You specify the interval or span of intervals to display. The command uses the syntax:

```
show ports stats pos fepathinterval <intervalid> [<ports>]
```

Figure 31 show ports stats pos fepathinterval command output

```

8610:5/show/ports/stats/pos# fepathinterval 1

=====
                        POS Far End Path Interval Stats
=====
PORT      ERRORED SECONDS   SEVERELY ERRORED   CODE VIOLATION     UNAVAILABLE
NUM      COUNT (ES)       COUNT (SES)        COUNT (CV-P)       SECONDS(UAS)
-----
10/1      0                 0                  0                  0
10/3      0                 0                  0                  900

INTERVAL ID = 1
8610:5/show/ports/stats/pos#

```

[Table 38](#) describes the show ports stats pos fepathinterval command parameters.

Table 38 show ports stats pos fepathinterval command parameters

Field	Description
PORT NUM	Port number.
ERRORED SECONDS COUNT (ES)	Errored Second (ES) is a second with one or more Coding Violations (CV) or one or more incoming defects (for example, SEF, LOS, AIS, LOP).
SEVERELY ERRORED COUNT (SES)	Severely Errored Second (SES) is a second with x or more CVs, or one or more incoming defects.
CODE VIOLATION COUNT (CV-P)	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UNAVAILABLE SECONDS (UAS)	Number of seconds that the interface is unavailable.
INTERVAL ID	Specified interval.

show ports stats pos linecurrent

This command displays current statistics (Figure 32) for the line. The command uses the syntax:

```
show ports stats pos linecurrent [<ports>]
```

Figure 32 show ports stats pos linecurrent command output

```
8610:5/show/ports/stats/pos# linecurrent
```

```
=====
                          POS Line Current Stats
=====
PORT  ERRORED SECONDS  SEVERELY ERRORED  CODE VIOLATION  UNAVAILABLE
NUM   COUNT (ES)      COUNT (SES)       COUNT (CV-L)    SECONDS (UAS)  STATUS
-----
10/1   0                0                 0                277            No Defect
10/3   0                0                 0                787            Line AIS
```

```
8610:5/show/ports/stats/pos#
```

[Table 39](#) describes the show ports stats pos linecurrent command parameters.

Table 39 show ports stats pos linecurrent command parameters

Field	Description
PORT NUM	Port number.
ERRORED SECONDS COUNT (ES)	Errored Second (ES) is a second with one or more Coding Violations (CV) or one or more incoming defects (for example, SEF, LOS, AIS, LOP).
SEVERELY ERRORED COUNT (SES)	Severely Errored Second (SES) is a second with x or more CVs, or one or more incoming defects.
CODE VIOLATION COUNT (CV-P)	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UNAVAILABLE SECONDS (UAS)	Number of seconds that the interface is unavailable.
STATUS	Status of defects.

show ports stats pos lineinterval

This command displays statistics ([Figure 33](#)) for the line over a 15-minute interval. You can specify any interval or span of intervals. The command uses the syntax:

```
show ports stats pos lineinterval <intervalid> [<ports>]
```

Figure 33 show ports stats pos lineinterval command output

```

8610:5/show/ports# stats pos lineinterval 1

=====
                                POS Line Interval Stats
=====
PORT      ERRORED SECONDS   SEVERELY ERRORED   CODE VIOLATION     UNAVAILABLE
NUM       COUNT (ES)       COUNT (SES)        COUNT (CV-L)       SECONDS (UAS)
-----
3/5       0                 0                  0                  0
3/6       0                 0                  0                  0
INTERVAL ID = 1
8610:5/show/ports#

```

[Table 40](#) describes the show ports stats pos lineinterval command parameters

Table 40 show ports stats pos lineinterval command parameters

Field	Description
PORT NUM	Port number.
ERRORED SECONDS COUNT (ES)	Errored Second (ES) is a second with one or more Coding Violations (CV) or one or more incoming defects (for example, SEF, LOS, AIS, LOP).
SEVERELY ERRORED COUNT (SES)	Severely Errored Second (SES) is a second with x or more CVs, or one or more incoming defects.
CODE VIOLATION COUNT (CV-P)	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UNAVAILABLE SECONDS (UAS)	Number of seconds that the interface is unavailable.
STATUS	Indicates status of defects.

show ports stats pos linkstatus

This command displays current statistics ([Figure 34](#)) on the frames coming across the PPP link. The command uses the syntax:

```
show ports stats pos linkstatus [<ports>]
```

Figure 34 show ports stats pos linkstatus command output

```
8610:5/show/ports/stats/pos# linkstatus

=====
                                POS Link Stats
=====
PORT    BAD ADDR   BAD CNTL   TOO LONG   BAD FCS
NUM     FRAMES     FRAMES     FRAMES     FRAMES     MRU
-----
10/1    0           0           0           1936  1936
10/3    0           0           0           0       0

8610:5/show/ports/stats/pos#
```

[Table 41](#) describes the show ports stats pos linkstatus command parameters.

Table 41 show ports stats pos linkstatus command parameters

Field	Description
PORT NUM	Port number.
BAD ADDR FRAMES	Number of packets received with an Incorrect Address Field. This counter is a Component of the ifInErrors variable that is associated with the interface that represents this PPP Link.
BAD CNTL FRAMES	Number of packets received on this link with an incorrect address field.
TOO LONG FRAMES	Number of packets received and discarded because their length exceeded the MRU.
BAD FCS FRAMES	Number of packets received with an incorrect FCS size.
MRU	Maximum Receive Unit

show ports stats pos lqrstatus

This command displays current statistics ([Figure 35](#)) on the link quality reporting. The command uses the syntax:

```
show ports stats pos lqrstatus [<ports>]
```

Figure 35 show ports stats pos lqrstatus command output

```

8610:5/show/ports/stats/pos# lqrstatus
=====
                        POS Link Quality Stats
=====
PORT
NUM      QUALITY   IN GOOD OCTs   LOCAL PERIOD   REMOTE PERIOD  OUTLQRs  INLQRs
-----
10/5     100         4793094       100            100            40665   40666
10/6     0           0             0              0              0       0
8610:5/show/ports/stats/pos#

```

[Table 42](#) describes the show ports stats pos lqrstatus command parameters.

Table 42 show ports stats pos lqrstatus command parameters

Field	Description
PORT NUM	Port number.
QUALITY	This is the current quality of the link. It reflects the quality measurements with respect to the quality threshold.
IN GOOD OCTs	Number of good octets received at the port.
LOCAL PERIOD	Time interval in 100th of a second between link quality reporting from the local end.
REMOTE PERIOD	Time interval in 100th of a second between link quality reporting from the remote end.
OUT LQRs	The number of Link Quality Reports transmitted by this node.
INLQRs	The number of Link Quality Reports received by this node.

show ports stats pos pathcurrent

This command displays current statistics ([Figure 36](#)) on the path, on the transmitting end. The command uses the syntax:

```
show ports stats pos pathcurrent [<ports>]
```

Figure 36 show ports stats pos pathcurrent command output

```

8610:5/show/ports/stats/pos# pathcurrent

=====
                        POS Path Current Stats
=====
PORT  ERRED SECS  SEVERELY ERRED CODE VIOLATION  UNAVAILABLE
NUM   COUNT (ES)  COUNT (SES)   COUNT (CV-P)  SECONDS (UAS)  STATUS WIDTH
-----
10/5   0      0           0             0              0          No Defect   2
10/6   0      0           0             0             302        Path AIS    2
8610:5/show/ports/stats/pos#

```

[Table 43](#) describes the show ports stats pos pathcurrent command parameters.

Table 43 show ports stats pos pathcurrent command parameters

Field	Description
PORT NUM	Port number.
ERRED SECS COUNT (ES)	Errored Second (ES) is a second with one or more Coding Violations (CV) or one or more incoming defects (for example, SEF, LOS, AIS, LOP).
SEVERELY ERRED COUNT (SES)	Severely Errored Second (SES) is a second with x or more CVs, or one or more incoming defects.
CODE VIOLATION COUNT (CV-P)	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UNAVAILABLE SECONDS (UAS)	Number of seconds that the interface is unavailable.
STATUSWIDTH	Indicates status and number of defects.

show ports stats pos pathinterval

This command displays statistics ([Figure 37](#)) on the path for a 15-minute interval. You specify the interval or span of intervals to display. The command uses the syntax:

```
show ports stats pos pathinterval <intervalid> [<ports>]
```

Figure 37 show ports stats pos pathinterval command output

```
8610:5/show/ports/stats/pos# pathinterval 4

=====
                        POS Path Interval Stats
=====
PORT      ERRORED SECONDS   SEVERELY ERRORED   CODE VIOLATION   UNAVAILABLE
NUM       COUNT (ES)       COUNT (SES)        COUNT (CV-P)    SECONDS(UAS)
-----
10/1      0                 0                  0                0
10/3      0                 0                  0                900

INTERVAL ID = 4
8610:5/show/ports/stats/pos#
```

Table 44 describes the `show ports stats pos pathinterval` command.

Table 44 `show ports stats pos pathinterval` command parameters

Field	Description
PORT NUM	Port number.
ERRORED SECONDS COUNT (ES)	Errored Second (ES) is a second with one or more Coding Violations (CV) or one or more incoming defects (for example, SEF, LOS, AIS, LOP).
SEVERELY ERRORED COUNT (SES)	Severely Errored Second (SES) is a second with x or more CVs, or one or more incoming defects.
CODE VIOLATION COUNT (CV-P)	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
UNAVAILABLE SECONDS (UAS)	Number of seconds that the interface is unavailable.
INTERVAL ID	Specified interval.

show ports stats pos pppiftbl

This command displays statistics (Figure 38) on the PPP link. The command uses the syntax:

```
show ports stats pos pppiftbl [<ports>]
```

Figure 38 show ports stats pos pppiftbl command output

```

8610:5/show/ports/stats/pos# pppiftbl

=====
                        PPP IF Table Contents
=====
PORT      OCTETS      PACKETS      DROPPED      ERRORED      UNKNOWN
NUM      RECEIVED    RECEIVED    RX PACKETS  RX PACKETS  PROTOCOLS
-----
10/1  4637499      65449       0            0            0
10/3  0              0           0            0            0

PORT      OCTETS      PACKETS      DROPPED      ERRORED
NUM      TRANSMITTED TRANSMITTED TX PACKETS  TX PACKETS
-----
10/1      2769051532 4610831      0            0
10/3      20          1            0            0

8610:5/show/ports/stats/pos#

```

[Table 45](#) describes the show ports stats pos pppiftbl command parameters.

Table 45 show ports stats pos pppiftbl command parameters

Field	Description
PORT NUM	Port number.
OCTETS RECEIVED	Number of octets received at the port.
PACKETS RECEIVED	Number of packets received at the port.
DROPPED RX PACKETS	Number of RX packets dropped at the port.
ERRORED RX PACKETS	Number of RX packet errors at the port.
UNKNOWN PROTOCOLS	Number of unknown protocols.
OCTETS TRANSMITTED	Number of octets transmitted.
PACKETS TRANSMITTED	Number of packets transmitted.
DROPPED TX PACKETS	Number of TX packets dropped at the port.
ERRORED TX PACKETS	Number of TX packet errors at the port.

show ports stats pos sectioncurrent

This command displays the current statistics (Figure 39) on the section. The command uses the syntax:

```
show ports stats pos sectioncurrent [<ports>]
```

Figure 39 show ports stats pos sectioncurrent command output

```
8610:5/show/ports/stats/pos# sectioncurrent
=====
                        POS Section Current Stats
=====
PORT   ERRORED SECONDS SEVERELY ERRORED CODE VIOLATION SEVERELY ERRORED
NUM    COUNT (ES)      COUNT (SES)      COUNT (CV-S)     FRAMES (SEF) STATUS
-----
10/1      0           0           0           0           No Defect
10/3     620         620           0           0           LOS
8610:5/show/ports/stats/pos#
```

Table 46 describes the show ports stats pos sectioncurrent command parameters.

Table 46 show ports stats pos sectioncurrent command parameters

Field	Description
PORT NUM	Port number.
ERRORED SECONDS COUNT (ES)	Errored Second (ES) is a second with one or more Coding Violations (CV) or one or more incoming defects (for example, SEF, LOS, AIS, LOP).
SEVERELY ERRORED COUNT (SES)	Severely Errored Second (SES) is a second with x or more CVs, or one or more incoming defects.
CODE VIOLATION COUNT (CV-S)	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
SEVERELY ERRORED FRAMES (SEF)	Number of seconds that the interface is unavailable.
STATUS	Indicates status of defects.

show ports stats pos sectioninterval

This command displays statistics ([Figure 40](#)) on the section over a 15-minute interval. You specify the interval or span of intervals to display. The command uses the syntax:

```
show ports stats pos sectioninterval <intervalid> [<ports>]
```

Figure 40 show ports stats pos sectioninterval command output

```

8610:5/show/ports/stats/pos# sectioninterval 3

=====
                        POS Section Interval Stats
=====
PORT      ERRORED SECONDS   SEVERELY ERRORED   CODE VIOLATION SEVERELY ERRORED
NUM       COUNT (ES)       COUNT (SES)        COUNT (CV-S)   FRAMES (SEF)
-----
10/1      0                0                  0              0
10/3      900              900                0              0

INTERVAL ID = 10
8610:5/show/ports/stats/pos#

```

[Table 47](#) describes the show ports stats pos sectioninterval command parameters.

Table 47 show ports stats pos sectioninterval command parameters

Field	Description
PORT NUM	Port number.
ERRORED SECONDS COUNT (ES)	Errored Second (ES) is a second with one or more Coding Violations (CV) or one or more incoming defects (for example, SEF, LOS, AIS, LOP).
SEVERELY ERRORED COUNT (SES)	Severely Errored Second (SES) is a second with x or more CVs, or one or more incoming defects.
CODE VIOLATION COUNT (CV-S)	Coding Violations (CV) are Bit Interleaved Parity (BIP) errors that are detected in the incoming signal. CV counters are incremented for each BIP error detected.
SEVERELY ERRORED FRAMES (SEF)	Severely Errored Framing Second (SEFs) is a second containing one or more SEF events.
INTERVAL ID	Specified interval.

show ports stats pos sonetmediumtbl

This command displays statistics (Figure 41) on the SONET medium. The command uses the syntax:

```
show ports stats pos sonetmediumtbl [<ports>]
```

Figure 41 show ports stats pos sonetmediumtbl command output

```
-8610:5/show/ports/stats/pos# sonetmediumtbl
```

```
=====
                        POS SONET Medium Table
=====
PORT      MEDIUM   TIME      VALID      LINE      LINE      CIRCUIT
NUM       TYPE     ELAPSED   INTERVALS  CODING    TYPE     ID
-----
10/1      1        816      45         4         4         52689832
10/3      1        816      45         4         4         52689832
```

Table 48 describes the show ports stats pos sonetmediumtbl command parameters.

Table 48 show ports stats pos sonetmediumtbl command parameters

Field	Description
PORT NUM	Port number.
MEDIUM TYPE	Identifies whether a sonet or sdh signal is used across the interface.
TIME ELAPSED	Number of seconds, including partial seconds, that have elapsed since the beginning of the current measurement period. If the current interval exceeds the maximum value, the agent will return the maximum value.
VALID INTERVALS	Number of previous 15-minute intervals for which data was collected.
LINE CODING	Line coding for this interface. The B3ZS and CMI are used for electrical SONET/SDH signals (STS-1 and STS-3). The Non-Return to Zero (NZR) and the Return to Zero are used for optical SONET/SDH signals.
LINE TYPE	Line type for this interface. The line types are Single Mode fiber or Multi-Mode fiber interfaces.
CIRCUIT ID	Transmission vendor's circuit identifier, to facilitate troubleshooting.

Using the monitor commands

This section describes the monitor commands available with the 8683POSM Module. The monitor commands are self-updating show commands, set from the CLI for duration and interval. These commands allow you to view constantly updating information about the module. The monitor commands use the following syntax:

```
monitor ports stats pos activealarms [<ports>]
monitor ports stats pos felinecurrent [<ports>]
monitor ports stats pos felineinterval <intervalid>
 [<ports>]
monitor ports stats pos fepathcurrent [<ports>]
monitor ports stats pos fepathinterval <intervalid>
 [<ports>]
monitor ports stats pos linecurrent [<ports>]
monitor ports stats pos lineinterval <intervalid> [<ports>]
monitor ports stats pos linkstatus [<ports>]
```

```
monitor ports stats pos lqrstatus [<ports>]
monitor ports stats pos pathcurrent [<ports>]
monitor ports stats pos pathinterval <intervalid> [<ports>]
monitor ports stats pos pppiftbl [<ports>]
monitor ports stats pos sectioncurrent [<ports>]
monitor ports stats pos sectioninterval <intervalid>
 [<ports>]
monitor ports stats pos sonetmediumtbl [<ports>]
```

Using the test commands

This section describes the test commands available with the 8683POSM Module. The test commands allow you test the module while the switch is operating. The tests do not interfere with the module's normal switching functions, but they do occupy the CPU. The test commands allow you to test:

- Hardware
- LEDS
- Internal and external loopback

The syntax for the test commands is:

```
test hardware <ports>
```

```
test led <ports> <tx|rx> <off|yellow|green>
```

```
test loopback <ports> [<int|ext>]
```



Note: You must specify a slot and port number with the test commands.

test hardware

Use the `test hardware` command to run diagnostics on the 8683POSM Module. The command uses the following syntax:

```
test hardware <ports>
```

The output from the test hardware command is shown in [Figure 42](#).

Figure 42 test hardware command output

```
8610:test hardware 10/5
Port: 10/5
  IfIndex: 645
  Result: success
```

test led

Use the test led command to see if the lights on the port LEDs are functioning correctly on the 8683POSM Module. The command uses the following syntax:

```
test led <ports> <tx|rx> <off|yellow|green>
```



Note: You must physically inspect the LEDs on the actual 8683POSM Module to view the results of these tests.

[Table 49](#) describes the parameters and variables for the test led command.

Table 49 test led command parameters and variables

Parameters and variables	Description
tx	Tests the LED for transmitting data on each port.
rx	Tests the LED for receiving data on each port.
off	Tests whether the LEDs go off correctly.
yellow	Tests whether the LEDs can light yellow.
green	Tests whether the LEDs can light green.

test loopback

Use the `test loopback` command to run a loopback test on the port. You can perform either an internal or an external loopback test on the POSM module. The default is internal loopback. The syntax is:

```
test loopback <ports> <int|ext>
```



Note: The loopback tests test only the control path; they do not test the data path.

To test for loopback:

- 1 To configure the port for testing, enter:

```
config pos <ports> test
```

- 2 To test the loopback, either internal or external, enter:

```
test loopback <ports> <int|ext>
```

- 3 To stop the loopback testing, enter:

```
test stop loopback <ports>
```

[Figure 43](#) shows output for the `test loopback` command.

Figure 43 test loopback command output

```
8610:5/show/test# loopback 10/6

Running an internal loopback test...
Current test results:

    Port: 10/6
    IfIndex: 645
    Result: inProgress
    PassCount: 0
    FailCount: 0
```

Chapter 5

Web management

The Web interface allows you to monitor the 8683POSM Module through a World Wide Web browser from anywhere on your network. The Web interface provides many of the same monitoring features as the Device Manager software.

Refer to *Getting Started with the 8000 Series Management Software* for information on:

- Accessing your switch through the Web interface
- Descriptions of the Web page layout

Use the Web interface to monitor the 8683POSM Module parameters. When you access the Web interface, the System page is displayed. The POS folder is in the navigation pane on the left of the System page ([Figure 44](#)).

Figure 44 System page

The screenshot shows a web browser window displaying the Nortel Networks System page. The browser's address bar shows the URL `http://134.177.128.129/`. The page title is "System > System". On the left, there is a navigation menu with the following items: "PP 8610 / 134.177.128.129", "System", "Layer2", "Layer3", "ATM", "PDS", "QOS", "Statistics", and "Support". The main content area displays a table of system configuration fields.


System	
ppDescr	Passport 8610 (3.1.0)
ppUpTime	0 day(s), 20:23:16 [WED NOV 01 11:11:58 2000]
ppContact	sapco@nortelnetworks.com
ppName	Passport 8610
ppLocation	4401 Great America Parkway, Santa Clara, CA 95052
Authentication Traps	disabled
EnableWebServer	true
EnableAccessPolicy	false
LastChange	WED NOV 01 11:12:32 2000
LastWarnChange	none
LastStatisticsReset	none
LastPdsTime ConfigSave	none
LastPdsTime ConfigSaveToSlave	none
LastBeetConfigSave	none
LastBeetConfigSaveOnSlave	none
DefaultRantimeConfigFileName	/flash/config.dig
DefaultBeetConfigFileName	/flash/beet.dig
ConfigFileName	

Table 50 describes the System page fields.

Table 50 System page fields

Field	Description
sysDescr	System description.
sysUpTime	Value of system up time.
sysContact	Contact name.
sysName	Port name.
sysLocation	System location.
Authentication Traps	Displays whether traps are enabled or disabled.
EnableWebServer	Indicates whether the web server has been enabled.
EnableAccessPolicy	Indicates whether access policy has been enabled.
LastChange	Value of sysUpTime at the time the interface entered its current operational state.
LastVlanChange	Value of sysUpTime at the time the VLAN entered its current operational state.
LastStatisticsReset	Value of sysUpTime at the time that statistics were enabled.
LastRuntimeConfigSave	Value of sysUpTime at the time that configuration was saved.
LastRuntimeConfigSavetoSlave	Value of sysUpTime at the time that configuration was saved.
LastBootConfigSave	Value of sysUpTime at the time the last reboot occurred.
LastBootConfigSaveOnSlave	Value of sysUpTime at the time the last reboot saved configuration changes.
DefaultlRuntimeConfigFileName	Default runtime configuration file name.
DefaultBootConfigFileName	Default configuration file name.
ConfigFileName	Configuration file name.

When you click on POS in the navigation pane, the headings in the POS menu are displayed. The headings provide options for viewing POS parameters ([Figure 45](#)).

Figure 45 System page showing the POS menu

To view the current SONET parameters, in the POS menu, click Sonet. The Sonet page opens (Figure 46).

Figure 46 SONET page




Table 51 describes the SONET page fields.

Table 51 SONET page fields

Field	Description
Index	Unique value assigned to each interface.
Framing	Indicates if framing is enabled or disabled.
Section Trace	Indicates the integer that the section trace is set to.
Signal Label	Indicates operational value of Path Signal Label.
Clock Source	Indicates setting of the clock source.
Scramble	Indicates operational value of SONET scramble.

To view the current link parameters, in the POS menu, click Link. The Link page opens (Figure 47).


Figure 47 Link page

Table 52 describes the Link page fields.

Table 52 Link page fields

Field	Description
Index	Unique value assigned to each interface.
Link Config Magic Number	If set to enable, selects a random number (“magic number”) used in loopback detection.
Link Config Crc Size	Indicates if the size of redundancy check field used in PPP framing has been configured.

To view the current bridging parameters, in the POS menu, click Bridge. The Bridge page opens (Figure 48).


Figure 48 Bridge page

Table 53 describes the Bridge page fields.

Table 53 Bridge page fields

Field	Description
Index	Unique value assigned to each interface.
Bcp Admin Status	Indicates the status of bridging.
Oper Status	Indicates the operational state of bridging.

To view the current IP parameters, in the POS menu, click IP. The IP page opens (Figure 49).


Figure 49 IP page

Table 54 describes the IP page fields.

Table 54 IP page

Field	Description
Index	Unique value assigned to each interface.
Ipcp Admin Status	Indicates the status of IP routing, either enabled or disabled.
Oper Status	Indicates the operational value of IP link.

To view the current IPX parameters, in the POS menu, click IPX. The IPX page opens (Figure 50).


Figure 50 IPX page

Table 55 describes the fields displayed IPX page fields.

Table 55 IPX page fields

Field	Description
Index	Unique value assigned to each interface.
Ipxcp Admin Status	Indicates the status of IPX routing, either enabled or disabled.
Oper Status	Indicates the operational value of IPX link.
Net Addr	Network address.

To view the current Lqr parameters, in the POS menu, click Lqr. The Lqr page opens (Figure 51).


Figure 51 Lqr page

Table 56 describes the Lqr page fields.

Table 56 Lqr page fields

Field	Description
Index	Unique value assigned to each interface.
Config Status	Status of link quality reporting.
Config Interval	Link quality reporting interval.

To view the current Line parameters, in the POS menu, click Line. The Line page opens (Figure 52).

Figure 52 Line page




Table 57 describes the Line page fields.

Table 57 Line page fields

Field	Description
Index	Unique value assigned to each interface.
Config PPP Stp	Status of PPP bridging.
Local Ip Addr	Local Internet Protocol address.
Remote IP Addr	Remote Internet Protocol address.
Config Lqr Threshold	Link quality reporting threshold.

To view the current Sonet Medium parameters, in the POS menu, click Sonet Medium. The Sonet Medium page opens (Figure 53).

Figure 53 SONET Medium page




Table 58 describes the SONET Medium page fields.

Table 58 SONET Medium page fields


Field	Description
Index	Unique value assigned to each interface.
Type	Signal type, whether sonet or sdh.
Time Elapsed	Number of seconds that have elapsed since the beginning of the current measurement period.
Valid Intervals	Number of previous 15-minute intervals for which data was collected.
Line Coding	Line coding for this interface: the B3ZS and CMI are used for electrical SONE/SDH signals (STS-1 and STS-3). The Non-Return to Zero (NZR) and the Return to Zero are used for optical SONET/SDH signals.
Line Type	Line type: short and long range single-mode fiber or multimode fiber interfaces, and COAX and UTP for electrical interfaces.
Circuit Identifier	Transmission vendor's circuit identifier, to facilitate troubleshooting.

Statistics

Use the Web interface to view the 8683POSM Module statistics. Under the Statistics heading in the navigation pane, there are two options: Chassis and Port. Click Port to view the options. Sonet is the last entry in the Port folder.

The Sonet heading contains the options shown in [Figure 54](#).


Figure 54 Sonet options



Click any of the headings to view the relevant statistics.

See [Figure 55](#) for an example of PPP Link statistics.

Figure 55 PPP Link statistics page



Appendix A

Technical Specifications

This appendix lists the technical specifications for the 8683POSM Module.

Standards supported

Bell Communications Research, SONET Transport Systems: Common Generic Criteria, GR-253-CORE, January 1999, Revision 2 (partial compliance)

RFC 1213, Network Management of TCP/IP-based internets, March 1991

RFC 1332, PPP Internet Protocol Control Protocol (IPCP), May 1992

RFC 1471, Link Control Protocol of the PPP, June 1993

RFC 1473, IP Network Control Protocol of the PPP, June 1993

RFC 1474, Bridge Network Control Protocol of the PPP, June 1993

RFC 1552, PPP Internetwork packet Exchange Control Protocol (IPXCP), May 1992

RFC 1661, The Point-to-Point Protocol (PPP), July 1994.

RFC 1638, PPP Bridging Control Protocol (BCP), June 1994

RFC 1989, PPP Link Quality Monitoring, August 1996

RFC 2558, SONET/SDH, March 1999

RFC 2615, PPP Over SONET/SDH (obsoletes RFC 1619), June 1999

Environmental specifications

Operating temperature:	5° to 40° C (41° to 104° F)
Storage temperature:	-25° to 70° C (-13° to 158° F)
Operating humidity:	85% maximum relative humidity, noncondensing
Storage humidity:	95% maximum relative humidity, noncondensing
Operating altitude	3,000 m (10,000 feet) maximum
Storage altitude	Up to 9,000 m (30,000 feet) above sea level
Free Fall/drop:	ISO 4180-s, NSTA 1A
Vibration:	IEC 68-2-6/34
Shock/bump:	IEC 68-2-27/29

Physical specifications

Height:	1.050 inches
Width:	12.968 inches
Depth:	10.950 inches
Weight (single module):	3.12 lbs.

Performance specifications (64-byte packets)

Mean time between failure (MTBF)	150,000 hours
Frame length:	64 to 1750 octets

Interface options

RJ-45 (8-pin modular) connectors for MDI-X interface

Safety agency approvals

- UL Listed (UL 1950)
- CUL CSA 22.2 No. 950
- IEC 950/EN 60950
- CE mark
- CB Scheme Test Report and Certification
- NOM (NOM-019-SCFI-1994)

Electromagnetic emissions

Meets requirements of:

US: FCC, CFR 47, Part 15, Subpart B, Class A

Canada: ICES-003, Issue-2, Class A

Australia/New Zealand: AS/NZS 3548:1995, Class A

Japan: VCCI V-3/97.04, Class A

Taiwan: CNS 13438, Class A

EN 55 022:1998/CISPR22:1997

CE Mark

Electromagnetic immunity

Electromagnetic Immunity: EN55024:1998/CISPR24:1997

Index

A

AbsoluteValue statistics 63
Action field 42
AdminStatus field 41
alarm statistics 90
applications, typical 23
Average statistics 63

B

BCP 50, 83
Bridge Control Protocol (BCP, bcp)
 disabling 79
 enabling 50, 79
bridge-admin-status command 79

C

card-reset command 77
CLI
 IP parameter configuration commands 78
 IPX route command 79
 module configuration commands 76
 monitor commands 111
 port configuration commands 77
 port numbering 34
 PPP configuration commands 79
 show commands 85
 SONET configuration commands 82
 spanning tree 80
 test commands 61, 112
clocking 82
clock-source command 82

config pos command 77
config pos info command 81
configuration
 limitations and considerations 33
 with Device Manager 33
configuring bridging 50
console port 23
conventions, text 18
CPU 22
Cumulative statistics 63
customer support 20

D

debug command 77
debug mode 77
debugging 23
default configurations 38
default VLAN 78
default-vlan-id command 78
Device Manager
 editing card 43
displaying, image file name 76
distance, maximum 25
DVMRP
 POS 28

E

enabling trace messages 76
environmental specifications 130

F

failover 22
far end line interval statistics 93
far end line statistics 92
far end path interval statistics 96
far end path statistics 95
FE Line tab 70
FE Path tab 72
features 22
framing command 82

G

green command 113
GUI 33

H

hardware 61, 112

I

ICP 50, 83
ifDescr field 41
IGMP
 POS 28
image filename 76, 77
Index field 41
info 82
info command
 displaying the image file name 77
 last saved ports 78
 next-level CLI commands 78
information 85
Insert Trap Receiver dialog box 59
interface options 130
Interface tab
 graphic 40
 tab fields 41

intervals 62
IP Address tab
 graphic 53
 tab fields 53
IP commands 78
IP parameter configuration commands 78
IP routing 79
ipcp-admin-status command 79
IPX 79
ipx route command 79
ipxcp-admin-status command 79

L

LastChange field 42
LastValue statistics 63
LCP negotiation 27
LEDs, types
 test 113
line interval statistics 99
line statistics 98, 100
Line tab 69
link quality 79
link quality interval 79
link quality reporting statistics 101
link quality threshold 79
LinkConfigMagicNumber field 52
linktrap command 78
LinkTrap field 42
lock command 78
Locked field 42
locking a port 42
loopback 61, 112
loopback detection 52, 79
lqr-interval command 79
lqr-status command 79
lqr-threshold command 79

M

magic-number command 79
management 33
Maximum statistics 63
MDA information 45
MDAs
 description 21
Minimum statistics 63
MLT
 POS 28
MltID field 42
module
 configuration commands 76
 enabling trace messages 76
 resetting 76
module configuration 38, 75
monitor commands 111
MTU 26
Mtu field 41

N

name field 41

O

off command 113
OperDuplex field 42
OperSpeed field 42
OperStatus field 42
optical networks
 POS 28

P

Packet-over-SONET <italic font>See POS
Passport 8690SF module 22
path interval statistics 104
path statistics 102

Path tab 71
performance specifications 130
perform-tagging command 78
PhysAddress field 41
physical specifications 130
Point-to-Point Protocol 25
poll interval 63
port
 configuration commands 77
 disabling 46
 enabling 46
 information 85
 naming 41
 numbering, CLI 34
 setting 78
Port dialog box
 Interface tab 40
 IP Address tab 53
 POS PPP tab 51
 POS SONET tab 48
Port Test dialog box 61
portlock feature 78
POS 24
 802.1q VLANs 28
 address field 30
 BPDU transmission 31
 control field 30
 control signals 29
 description 28
 DVMRP 28
 flag sequence 30
 Frame Check Sequence (FCS) field 31
 frame format 29
 IGMP 28
 Multiframe Indicator (H4) 29
 Path Signal Label (C2) 29
 port-based VLANs 28
 PPP
 HDLC frame structure 29
 PPP over SONET 28
 protocol-based VLANs 28

- Synchronous Payload Envelope (SPE) 29
 - transmission rates 29
 - transport technology 28
- POS Graph statistics tab 64
- POS PPP tab
 - graphic 51
 - tab fields 52
- POS SONET tab
 - graphic 48
 - tab fields 48
- POS Statistics tab 65
- PPP 24, 25, 27
 - Bridging Control Protocol (BCP) 31
 - interface format 29
 - POS 28
- PPP and POS 28
- PPP configuration commands 79, 83
- PPP LQR tab
 - graphic 67
- PPP statistics 105
- ppp-stpmode command 80
- product support 20
- publications
 - hard copy 19

R

- reboot 77
- reset module 43, 77
- Result field 42
- RFCs 23
- routing 79
- rx command 113

S

- safety agency approvals 130
- scramble command 82
- SDH 24, 48, 82

- section interval statistics 108
- section statistics 107
- Section tab 68
- section-trace command 82
- security 82
- show ports info pos command 85
- show ports stats pos activealarms command 90
- show ports stats pos felinecurrent command 92
- show ports stats pos felineinterval command 93
- show ports stats pos fepathcurrent command 95
- show ports stats pos fepathinterval command 96
- show ports stats pos linecurrent command 98
- show ports stats pos lineinterval command 99
- show ports stats pos linkstatus command 100
- show ports stats pos lqrstatus command 101
- show ports stats pos pathcurrent command 102
- show ports stats pos pathinterval command 104
- show ports stats pos pppiftbl command 105
- show ports stats pos sectioncurrent 107
- show ports stats pos sectioninterval command 108
- show ports stats pos sonetmediumtbl command 109, 110
- SONET 24, 48, 82
- SONET configuration commands 82
- SONET medium statistics 110
- SONET terms 24
- SONET traps
 - configuring with Device Manager 57
- SonetFraming field 48
- spanning tree, CLI 80
- standards 129
- state command 78
- statistics 62, 63
- statistics, displaying 62
- statistics, graphing 62
- STP

POS 28
support, Nortel Networks 20

T

tagged-frames-discard command 78
tagging 78
tagging frames 78
technical publications 19
technical specifications 129
technical support 20
test hardware command 112
test led command 113
test mode 61, 112
testing 112
text conventions 18
The 67
timing 82
transmission distance 25
transmission rates 25
trap log 57
Trap Receivers tab 58
traps 57
troubleshooting
 CPU failover 22
 debug command 77
 loopback test 61
 maximum transmission distance 25
 port disabling and enabling 46
 test commands 112
 test hardware command 112
 test LED command 113
tx command 113
Type field 41

U

untagged-frames-discard command 78

V

VendorDescr field 41
VLAN
 POS 28

Y

yellow command 113

