



ORIGINATING TROUBLE INDICATOR RECORD  
CROSSBAR OFFICES

OFFICE \_\_\_\_\_

DATE \_\_\_\_\_ SHEET NO. \_\_\_\_\_

NO.	TI	CT	DT	DR	GO	C 100	DL GO	DL G100	CF	CN	SN	OF	TL	KEL	KOL	KER	KOR	G	GT1	GT3	GS	DF	SW	M	JC	P	CHL	CHR	Z	ZCK	ZO	ZL	ZK	PSI	NC1	OT1	TC1	TCK	TP1	RP1	TPK	ZR	A	B	C	D	F	AR			
1	✓			2					1	0	0	0	4				8	11		1,2	10	3	5	1	1																				2	2	2	2	10	✓	
2	✓			1					1	0	0	2	8	4				10		1,2	0	1	0	4	4																					2	2	1	4	0	✓
3	✓			2					1	0	0	2	8	6				8		1,2	0	1	0	4	4																				2	2	1	4	0	✓	
4	✓			2					1	0	0	2	8	2				4		1,2	13	1	0	4	7																			2	2	1	4	13	✓		
5	✓			0					1	0	0	2	8	6				7		1,2	0	1	0	4	4																			2	2	1	4	0	✓		

Column A - Trouble indication.  
 Column B - Any marker.  
 Column C - One particular sender in trouble. Same sender with GS 1-2 lamp in column E, reverse battery trunk code and AR lamp in column I,  
 XSL lamp in column O and TW lamp in column P indicates sender is in trouble.  
 Columns D,F,G,H,J,K,L,M,N - Have no significance.

A	B	C	D	E	F	G	H	I
---	---	---	---	---	---	---	---	---

NO.	OF	TP	EA	LA	SGR	CKG	K4	K5	SPE	SPD	NSE	NSO	DK	AK	TKE	TK	SR	RL	MS	CK	BK	CHE	A	C	S	SL	B	MR	S1K	MRL	ZS	Z	OT	TC	TP2	NM	RO	TB5	CRL	DT3	MRI	TRL	EC	X	SDT	OB	SD	SD1	OG	SO	CR	CL	TW	TIME
1						✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓						✓														✓	XSL					✓	3,4	3,4	✓	6:30		
2						✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓																					✓	XSL					✓	3,4	3,4	✓	6:44	
3						✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓																						✓	XSL					✓	3,4	3,4	✓	6:45
4						✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓																						✓	XSL					✓	3,4	3,4	✓	6:46
5						✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓																						✓	XSL					✓	3,4	3,4	✓	6:50

Analysis of Trouble: An XSL lamp indication on a particular sender selecting a reverse battery trunk results if the OF relay shunt in the sender is open. This causes the sender to request a second trial when it encounters the reverse battery. Marker selects a different trunk but original one will not release in time to remove ground from sleeve.

Immediate Procedure to Follow: Make sender busy.

Procedure for Locating and Clearing Trouble: Use subscriber sender test with RVT key operated.

J	K	L	M	N	O	P
---	---	---	---	---	---	---