

SYSTEM RECOVERY GUIDELINES

NO. 2B ELECTRONIC SWITCHING SYSTEM

1. GENERAL

- 1.01** This section provides procedural guidelines for the rapid recovery of No. 2B Electronic Switching System (ESS) call processing in the face of serious system disruption. When the automatic emergency actions have failed to establish a working system manual intervention will be necessary. This condition may be indicated by lack of network activity, continuous switching of control units, bootstrapping, teletypewriter (TTY) messages, etc.
- 1.02** This is the initial issue of this section.
- 1.03** Figure 1 should be used when there is a craftsperson at the central office. Figure 2 should be used when only remote TTY communication is available (as in a surveillance center or TAC).
- 1.04** The procedures are presented in flowchart form to enable the user to quickly arrive at the most likely cause of the problem and to take appropriate corrective action. ***The flowcharts given should be followed any time a serious system disruption occurs even if it is felt that the problem is entirely a hardware problem.***
- 1.05** The flowcharts (Fig. 1 and 2) assumes no prior knowledge of the system condition other than the systems' inability to process calls. The intra flowchart referencing is accomplished by double letters within the connector symbols, e.g. **(AA)** When the connector symbol directs the user to a different sheet within the flowchart, the sheet number will appear adjacent to the symbol.
- 1.06** If the procedures in the flowchart do not lead to the restoration of service, the problem under investigation is beyond the scope of this section and other trouble clearing methods should be employed.
- 1.07** Notes accompany the flowchart to provide a more detailed explanation of some operations. The note associated with a flowchart symbol is indicated in the symbol by an encircled letter, e.g., **(A)**. The notes are provided in 2.01.
- 1.08** Some useful material to supplement this section may be found in Section 232-306-301. Control and Display Procedures and Section 232-313-301 System Initialization Procedures.
- 1.09** In this section, the use of the terms ***operate*** and ***release*** refer to successive depressions of a locking type key. The term ***depress*** refers to each momentary operation of a nonlocking type key. Relays operated through the depressing of a nonlocking type key requires a depression of at least one-half second to insure system recognition. Some keys that can be ***operated*** manually can also be ***released*** by program.

2. SUPPLEMENTAL NOTES FOR RECOVERY PROCEDURES

- 2.01** The following notes are referred to by the flowcharts and will be used whenever they are identified in one of the symbols of the procedure.

(A) Whether or not a control unit (CU) is running can be determined by the success of any of the following checks. Perform these checks in the sequence given and stop when one check is successful.

- (1) At the maintenance TTY— Type the “!” character. Successful response is “?A” with a carriage return and line feed two times in succession.
- (2) At the SYSTEM EMERGENCY MANUAL CONTROL panel—Depress the TTY INIT key. Successful response is an INIT TTYC ALL message, and the TTY INIT key is immediately extinguished.

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement

(B) At the maintenance center frame SYSTEM EMERGENCY MANUAL CONTROL section of the SSP select the CU to be forced active by operating the SELECT - key. Operate the FORCE key to force the selected CU active. Observe that the SELECT - key for the inactive CU is released.

(C) All system initializations are executed from the SYSTEM EMERGENCY MANUAL CONTROL section of the SSP at the maintenance frame. Execute the type of emergency actions called for in the flowcharts as follows:

- (1) Observe lamp indications on the SYSTEM STATUS AND CONTROL PANEL.
- (2) If SERVICE LOSS lamp is flashing wait until it stops flashing before proceeding except when a memory reload, backdate initialization or a bootstrap operation is desired.

For an EMERGENCY AUDIT INITIALIZATION:

- (3) Operate ENABLE key.
- (4) Depress INIT EXECUTE key.

Note: If an initialization takes place, the operated key will be released by program action.

For a TRANSIENT CLEAR INITIALIZATION:

- (3) Operate the SELECT — and FORCE keys if no CU is locked on-line.
- (4) Operate ENABLE key.
- (5) Depress INIT EXECUTE key.
- (6) Operate ENABLE key.
- (7) Depress INIT EXECUTE key.
- (8) Release FORCE key if operated in Step 3 above.

Note: If an initialization takes place, the operated key will be released by program action.

For a RECENT CHANGE CLEAR INITIALIZATION:

- (3) Operate ENABLE key.
- (4) Operate RECENT CHANGE key.
- (5) Depress INIT EXECUTE key.

Note 1: If an initialization takes place, the operated keys will be released by program action.

Note 2: Inform service order personnel that a recent change (RC) clear initialization is being performed and request to have the RC paper tapes available to reinput changes when the machine is running well.

For a STABLE CLEAR INITIALIZATION:

- (3) Operate ENABLE key.
- (4) Operate STABLE key.
- (5) Depress INIT EXECUTE key.

Note: If an initialization takes place, the operated keys will be released by program action.

For a STABLE AND RECENT CHANGE CLEAR INITIALIZATION:

- (3) Operate ENABLE key.
- (4) Operate STABLE key.
- (5) Operate RECENT CHANGE key.
- (6) Depress INIT EXECUTE.

Note 1: If an initialization takes place, the operated keys will be released by program action.

Note 2: Inform service order personnel that an RC clear initialization is being performed and request to have the RC paper tapes available to reinput changes when the machine is running well.

For a MEMORY RELOAD INITIALIZATION:

- (3) Operate the SELECT — key for desired CU to reload.
- (4) Operate FORCE key.
- (5) Operate ENABLE key.
- (6) Depress MEMORY RELOAD key.
- (7) Operate STABLE key (if a stable clear initialization is desired).
- (8) Operate RECENT CHANGE key (if a RC clear initialization is desired).
- (9) Depress INIT EXECUTE key.

Note 1: If an initialization takes place, the operated keys will be released by program action.

Note 2: Inform service order personnel that an RC clear initialization is being performed and request to have the RC paper tapes available to reinput changes when the machine is running well.

- (10) If tape does not rewind immediately, repeat Steps (5) and (9) a minimum of two additional times.

Ⓓ Attempt to restore power to the converters by operating the POWER key on the 3A central control panel of the appropriate frame. If power cannot be applied to the converters, replace the bad converter pack.

Ⓔ To power down the CU:

- (1) Ensure that the SELECT key for the desired off-line CU is released at the SYSTEM EMERGENCY MANUAL CONTROL panel.
- (2) Operate the SELECT key for the desired on-line CU.
- (3) Operate FORCE key.

Note: Any time *both* CUs are powered down a bootstrap operation must be performed *with* a stable and RC clear initialization to

load memory before attempting to run after powering up.

- (4) At the front of the 3A central control panel of the selected processor frame, operate the MANUAL key.

- (5) At the back of the 3A central control panel set the TEST MODE switch to the TEST MODE position.

- (6) At the front of the 3A central control panel depress the POWER key.

- (7) Check that all lamps on the 3A central control panel are off except the TEST MODE lamp.

Note: If CU cannot be powered down, replace board FA1032 54-25 and FA1033 54-24. If this does not help, obtain further technical assistance.

Ⓕ To restore power to the CU:

- (1) Depress POWER key.
- (2) At the front of the 3A central control panel, release the MANUAL key.
- (3) Check that some of the lamps and LEDs are lighted on the 3A central control panel.

Ⓖ To display the error register (ERR) on the 3A central control panel LOAD AND DISPLAY LEDS operate the following switches and keys on the 3A central control panel of the on-line CU.

- (1) At the back of the 3A central control panel set the TEST MODE switch to the TEST MODE position.
- (2) At the front of the 3A central control panel operate the MANUAL key.
- (3) Set the HALT switch to the up position.
- (4) Set the REGISTER-DISPLAY switch to the up position.
- (5) Set the SPECIAL-GENERAL switch to the SPECIAL position.

SECTION 232-305-301

- (6) Set REGISTER SELECT switches 8, 2 and 1 to the up position.
 - (7) At the REGISTER SELECT section the ERR LED should be lighted.
 - (8) All other switches should be in the down position.
 - (9) Momentarily set the EXECUTE switch to the up position (this switch is spring loaded and is normally in the down position).
 - (10) The contents of the error register is displayed on the LOAD AND DISPLAY LEDs.
- (H) Test calls should include at least one intraoffice, one outgoing and one incoming call on **each** network. If an incoming call fails, make sure the distant office did not take the trunk out-of-service.
 - (I) A full dial tone check should include at least one terminal equipment number (TEN) on each network.
 - (J) Check for dial tone at each concentrator group of each network.
 - (K) See Input Message Manual (IM-2H200) and Output Message Manual (OM-2H200) for a detailed explanation of audit requests, postmortem dumps and/or other printouts.
 - (L) Check for dial tone on each concentrator group that was **previously** missing dial tone.
 - (M) Line Scanner AB is associated with concentrator groups 0, 1, 2, and 3. Line scanner CD is associated with concentrator groups 4, 5, 6, and 7.
 - (N) The 3A central control program timer can be shut off by setting the TEST MODE switch on back of the 3A central control panel to the TEST MODE position. When this switch is set to the TEST MODE position, the TEST MODE lamp on the front of the panel is lighted.
 - (O) The initialization sanity check (ISC) bits are used to check the sanity of the software initialization routines. Failures detected by these bits may result in a switch to the other 3A central control or the reloading of memory (refer to PK-1C900).
 - (P) A system bootstrap is recognized by a continuously moving pair of lights on the CU and SSP display buffers and/or the TTY bell sounding at approximately 1/2 second intervals.
 - (R) The bootstrap has completed when the changing bootstrap pattern on the display buffer and TTY bell ceases.
 - (S) Force an initialization by typing the following:

LOD:ST a;SGL:777!

Where: a = address of CURMON in Program' CTSD

Repeat the above message until desired (automatic) initialization level (or bootstrap) is reached.
 - (T) Send a craftsperson to the local central office. Upon arrival, restart recovery procedure from the beginning.
 - (U) Can calls be completed properly? Consider interoffice, incoming and outgoing, if possible. If incoming calls fail, make sure the distant office did not take its outgoing trunk out of service.




Fig. 1—No. 2B ESS System Recovery Flowchart (Sheet 1 of 6)




Fig. 1—No. 2B ESS System Recovery Flowchart (Sheet 2 of 6)




Fig. 1—No. 2B ESS System Recovery Flowchart (Sheet 3 of 6)




Fig. 1—No. 2B ESS System Recovery Flowchart (Sheet 4 of 6)




Fig. 1—No. 2B ESS System Recovery Flowchart (Sheet 5 of 6)





Fig. 1—No. 2B ESS System Recovery Flowchart (Sheet 6 of 6)



NOTE:
DO NOT SPEND MORE THAN 20 MINUTES
IN SYSTEM RECOVERY FLOWCHART WITHOUT
SEEKING TECHNICAL ASSISTANCE

Fig. 2—No. 2B ESS System Recovery Flowchart