

AT&T PRACTICE
Provisional

Task Oriented Practice
(TOP)


OFFICE EQUIPMENT

3"ESS" SWITCH
(GENERIC SO-2 AND 3E3)

Copyright ©1984 AT&T Technologies
All Rights Reserved

Printed in U.S.A.

Issue 3	AUG 1984
233-142-100	TPG
TITLE PAGE	000



FIND YOUR JOB IN THE LIST BELOW THEN GO TO

3A CC Control Unit and System Status - Display Panels - Check	NTP-016
7A Recorded Announcement Set - Miscellaneous Frame - Service	NTP-005
Acceptance	NTP-002
Alarms; Office - Check	NTP-004
Announcement - 7A or 13A Announcement Set - Record	NTP-006
Backup Tape Cartridge - Cartridge Tape Transport - Update	NTP-015
Bootstrap; Off-line - 3E3 Generic or Later - Perform	NTP-009
Bootstrap; Off-line - SO-2 Generic - Perform	NTP-003
Cartridge Tape Transport (Minirecorder) - Maintenance Frame - Service	NTP-007
Clock; System - Check	DLP-525
Coin Control Circuit (SD-3H411-01 [CPS-FB423]) - Add	NTP-010
Dial Pulse Receiver Circuit (SD-3H410-01) - Add	NTP-013
Dial Pulse Transmitter Circuit (SD-3H403-01) - Add	NTP-017
Display Panels - System Status and 3A CC Control Unit - Check	NTP-016
Generic Patch - 3E3 Generic or Later - Install	NTP-018
Generic Patch - SO-2 Generic - Install	NTP-019
Ground Start - Network Frame - Strap	NTP-020
Loop Start - Network Frame - Strap	NTP-020
Minirecorder (Cartridge Tape Transport) - Maintenance Frame - Service	NTP-007

Issue 3	AUG 1984
233-142-100	IXL
PAGE 1 of 3	001

FIND YOUR JOB IN THE LIST BELOW THEN GO TO

Multifrequency Receiver Circuit (SD-3H402-01) - Add NTP-022

Multifrequency Transmitter Circuit (SD-3H404-01) - Add NTP-023

Office Alarms - Check NTP-004

Off-line Bootstrap - 3E3 Generic or Later - Perform NTP-009

Off-line Bootstrap - SO-2 Generic - Perform NTP-003

Patch; Generic - 3E3 Generic or Later - Install NTP-018

Patch; Generic - SO-2 Generic - Install NTP-019

Record Announcement on 7A or 13A Announcement Set NTP-006

Recorded Announcement Set; 7A - Miscellaneous Frame - Service NTP-005

Regular Ringing Circuit (SD-3H410-01) - Add NTP-024

Remote Recording - 7A or 13A Announcement Circuit (SD-3H411-01 [CPS-FB426 for 7A
or CPS-FB686 for 13A]) - Add NTP-048

Superimposed Ringing Circuit (SD-3H406-01) - Add NTP-025

System Clock - Check NTP-525

System Status and 3A CC Control Unit - Display Panels - Check NTP-016

Tape Cartridge (Backup) - Cartridge Tape Transport - Update NTP-015

Tape Transport; Cartridge (Minirecorder) - Maintenance Frame - Service NTP-007

Test Voltages - Trunk and Line Test Panel - Check NTP-523

Tone and Announcement Circuit (SD-3H411-01 [CPS-FB383]) - 7A or 13A Announcement - Add NTP-026

Tone and Announcement Circuit (SD-3H411-01 [CPS-FB383]) - Tone Operation - Add NTP-027

Touch-Tone Receiver Circuit (SD-3H401-01 and SD-3H410-01) - Add NTP-028

TASK INDEX LIST

Issue 3	AUG 1984
233-142-100	IXL
PAGE 2 of 3	001

FIND YOUR JOB IN THE LIST BELOW THEN GO TO

Translations - Reallocate	NTP-029
Transmission Levels - Trunk - Measure	NTP-011
Transmission and Noise Levels - Trunk - Measure	NTP-012
Transmission Measuring Equipment - Milliwatt Reference Generator and 23CR Set - Calibrate	NTP-014
Trunk and Line Test Panel - Test Voltages - Check	DLP-523
Universal Trunk Circuit - Add	NTP-030
Update Backup Tape Cartridge	NTP-015

The acceptance tasks are procedures done to verify that new equipment has been installed properly and is operating as intended. Acceptance procedures precede any work performed to place the equipment in service.

Documents stored in the office useful in acceptance task procedures include: Input/Output Manuals (IM/OMs), Schematic Diagrams (SDs), Program Applications (PAs), Program Listings (PRs), and Bell System Practices (BSPs).

TABLE A contains an alphabetical list of the acceptance tasks and corresponding procedure numbers necessary for accepting office equipment. Acceptance tasks can be performed in a random order or sequenced according to any local circumstances. Procedures for accepting office power are in Volume 233-144-100. Refer all trouble encountered during the performance of the acceptance procedures to the installation group.

ACCEPTANCE

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 2	002

TABLE A	
ACCEPTANCE TASKS	PROCEDURE NUMBER
Alarms; Office - Accept	NTP-041
Autoconnect Facility - Check	DLP-536
Automatic Message Accounting Recording Service (AMARS) - Accept	NTP-044
Backup Tapes - Check	NTP-008
Backup TTY Controller - Maintenance Frame - Check	NTP-042
CAMA Trunk - Charging Capabilities - Check	NTP-038
Coin Control Circuits - Accept	NTP-039
Display Panel - 3A CC Control Unit - Accept	NTP-045
Display Panel - System Status - Accept	NTP-046
Half Office Test - Perform	NTP-036
Hashsums - Check	NTP-021
Line-Up Tests - Trunk Circuit - Perform	NTP-034
Longitudinal Voltage Measurements - Make	NTP-043
Network Fabric Exercises - Perform	NTP-032
Nightly Routine - Diagnostics Test Results - Check	DLP-565
Office Routing Capability - Check	NTP-037
Office-to-Office Tests - Perform	NTP-040
Operational Volume Tests - Procedures and Results - Observe	NTP-033
Recorded Announcement Set - Functional Capability - Check	NTP-047
System Initialization - Ability - Check	NTP-035
Test Calls - Special and Custom Calling Features - Perform	-
Test Circuits Not Tested by Diagnostics - Test Frame - Check	NTP-031

Issue 3	AUG 1984
233-142-100	NTP
PAGE 2 of 2	002

ACCEPTANCE

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	NOTE: The TAPE AUDIT required during this procedure requires approximately 2.5 hours (minimum) per tape to run and may take longer depending on traffic. Other Multiscan Functions are not possible while TAPE AUDIT is in process	
1	Obtain the Following Support Apparatus <ul style="list-style-type: none"> • Cloth (KS-2423) • Cleaning solvent (94% [or 91%] isopropyl alcohol and cleaning pad) • Vacuum cleaner (KS-14377,L5) 	-
2	At System Status Panel, Verify SYSTEM NORMAL Lamp is ON	-
3	Remove Cartridge Tape Transport Unit 1 (Minirecorder) From Service	DLP-684
4	Perform Tape Diagnostics on Tape 1	DLP-685
5	Remove Cartridge Tape Transport Unit 0 (Minirecorder) From Service	DLP-684
6	Perform Tape Diagnostics on Tape 0	DLP-685
7	Update Translation Files	DLP-681
8	Prepare System for Off-Line Bootstrap Procedure	DLP-675
9	Verify Generic Hashsums Using Broadcast Warning Message (BWM)	DLP-676
10	Calculate Translation Hashsums	DLP-677
11	Print Translation Hashsums	DLP-678
12	Power Down Off-Line Control Unit by Depressing POWER Key on 3A Central Control Panel	-
13	Power Up Off-Line Control Unit by Depressing POWER Key on 3A Central Control Panel	-
14	Perform Off-Line Bootstrap	DLP-686
15	Verify Generic Hashsums Using Previous Values	DLP-693
16	Verify Translation Hashsums Using Previous Values	DLP-694
17	Perform Post Off-Line Bootstrap Procedures	DLP-689
18	Remove Cartridge Tape Transport Unit 1 (Minirecorder) From Service	DLP-684

PERFORM OFF- LINE BOOTSTRAP PROCEDURE (SO-2 GENERIC)

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

19	Remove Tape Cartridge from TDC1 and Label with Time and Date	DLP-695
20	Clean Tape Cartridge Head Assembly and Chassis	DLP-687
21	Depress TDC POWER to Restore Power to Tape Unit	-
22	Obtain Backup Tape Cartridge and Insert into CTT 1	-
23	Perform Tape Diagnostics on Tape 1	DLP-685
24	Perform Tape Audit on Tape 1 (Copy Data from Tape 0 to Tape 1)	DLP-709

PERFORM OFF-LINE BOOTSTRAP PROCEDURE (SO-2 GENERIC)




FIG. 1 - Test Cord




FIG. 2 - Test Cord With 300-Ohm to 1000-Ohm Resistor in Cord





FIG. 3 - Master Scanner Terminal Strip Numbering Scheme



CONTROL 0

CHECK OPERATION OF OFFICE ALARMS

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 4	004

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain Support Apparatus Listed Below <ul style="list-style-type: none"> • One Test Cord (See FIG. 1) • One Test Cord (See FIG. 2) • 300-Ohm to 1000-Ohm Resistor • Ohmmeter (KS-14510 or Equivalent) 	-	
2	Notify Switching Control Center of Alarm Testing	-	
3	At System Status Panel (SSP), Depress ALARM CONTROL - ALARM TRFR Until It Extinguishes	-	
4	See FIG. 3 for Master Scanner Terminal Numbering Scheme	-	
5	Check Operation of Power Alarms in the Following Order		
	1. Test AC Distribution Alarm	DLP-577 ✓	
	2. Test Commercial Power Failure Alarm	DLP-580 ✓	
	3. Test Alarm Battery Alarm	DLP-581 ✓	
6	4. Test Toll Distribution Alarm	DLP-582	
	From Office Records Form ESS 3506 (Alarm Monitor Data Table) Identify and Record Row and Column (Point) of Scan Point Numbers Assigned to the Following Building Alarms: <ul style="list-style-type: none"> • High Water and Sump Pump Failure • High or Low Temperature and Air Conditioning • High or Low Humidity • Intrusion 	-	
	7	Check Operation of Available Building Alarms in the Following Order	
	1. Test High Water and Sump Pump Failure Alarm	DLP-597	
2. Test High or Low Temperature and Air Conditioning Alarm	DLP-597		
3. Test High or Low Humidity Alarm	DLP-597		
	(Continued on Page 3)		

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

7 (Contd)	4. Test Intrusion alarm	DLP-597	✓
	5. Test Fire alarm	DLP-598	✓
8	Check Maintenance Frame Alarms in the Following Order		
	1. Test TTY Controller Out-Of-Service Alarm	DLP-599	✓
	2. Test Tape Data Controller Major Power Alarm	DLP-600	✓
	3. Test Maintenance Frame Converter Out-of-Limits Alarm	DLP-601	✓
	4. Test System Status Panel Fuse Alarm	DLP-602	✓
9	Check Ringing and Tone (RT) Plants 0 and 1 Alarms in the Following Order		
	1. Test Manual Override - Forced Alarm	DLP-603	✓
	2. Test Ringer Voltage Inverter Alarm	DLP-604	✓
	3. Test Fuse Alarm	DLP-605	✓
	4. Test Touch-Tone Low Voltage Alarm	DLP-606	✓
	5. Test Low Tone Voltage Alarm	DLP-607	✓
	6. Test Audible Ring Alarm	DLP-608	✓
	7. Test High Tone Low Voltage Alarm	DLP-609	✓
	8. Test Call Waiting Low Voltage Alarm	DLP-611	✓
10	Check Network Frame Office Alarms in the Following Order		
	1. Test Fuse Alarm For Trunks, Junctors, and Service Circuits	DLP-621	✓
	2. Test Line Ferrod Fuse Alarm	DLP-622	✓
	3. Test Battery Boost Power Alarm	DLP-623	✓
11	Check Processor Alarms in the Following Order		
	1. Test Bay 0 Major Power Alarm	DLP-624	✓
	2. Test Bay 0 Minor Power Alarm	DLP-625	✓
	(Continued on Page 4)		

CHECK OPERATION OF OFFICE ALARMS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

11 (Contd)	3. Test Bay 1 Major Power Alarm	DLP-626	✓
	4. Test Bay 1 Minor Power Alarm	DLP-627	✓
12	Check Miscellaneous Power Frame Alarms in the Following Order		
	1. Test +24V Converter Fuse Alarm	DLP-635	
	2. Test +24V Converter Failure Alarm	DLP-636	✓
	3. Test +48V Converter Fuse Alarm	DLP-638	✓
	4. Test +48V Converter Failure Alarm	DLP-639	✓
	5. Test +48V Converter Manual Off Alarm	DLP-642	✓
	6. Test ±130V Converter Fuse Alarm	DLP-644	✓
	7. Test ±130V Converter Failure Alarm	DLP-646	✓
	8. Test ±130V Converter Manual Off Alarm	DLP-650	✓
13	Notify Switching Control Center of Alarm Verification Completion	-	
14	Depress ALARM CONTROL - ALARM TRFR	-	

CHECK OPERATION OF OFFICE ALARMS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain the Following Support Apparatus <ul style="list-style-type: none"> • Cloth (KS-2423) • Cleaner-Lubricant (KS-16328, L2) • Oil (KS-16326, L1) • Oil Can (486A) • Brush (KS-14164) 	-
2	Type RMV:SVC (a, b)! a - Group Number of Recorded Announcement Set b - Member of Recorded Announcement Set	-
3	Remove Power from Recorded Announcement Set (Disconnect Power Cord)	-
4	Remove Dust Cover from Recorded Announcement Set	-
5	Clean Recorded Announcement Set	DLP-560
6	Lubricate Recorded Announcement Set	DLP-561
7	Check Belts for Wear and Tension	DLP-562
8	Check Magnetic Head for Wear	DLP-554
9	Replace Dust Cover	-
10	Restore Power to Recorded Announcement Set (Connect Power Cord)	-
11	Type RST:SVC (a, b)!	-
12	Depending on Generic, Activate Trunk and Line Test Panel (TLTP) Using Method A or B	-
	A. In Offices With 3E3 Generic or Later, Depress ON Key at TLTP	-
	B. In Offices With SO-2 Generic, Activate TLTP	DLP-578
13	Set Up TLTP for Testing Recorded Announcement Circuit	DLP-579
14	Check Recording for Clarity	DLP-563
15	Repeat Step 2 Through Step 11 for Remaining Recorded Announcement Sets	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain the Following Support Apparatus • 52-Type Head Telephone Set	-
2	Depending on Announcement System, Record Announcement Using Method A or B	
	A. Record Announcement At 7A Announcement Set	DLP-652
	B. Record Announcement At 13A Announcement Set By Following Directions on Front Panel of 13A Announcement Set or Using Section 201-519-301	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	NOTE: The TAPE AUDIT required during this procedure requires approximately 2.5 hours (minimum) per tape to run and may take longer depending on traffic. Other Multiscan Functions are not possible while TAPE AUDIT is in process	
1	Obtain the Following Support Apparatus <ul style="list-style-type: none"> • Cloth (KS-2423) • Cleaning Solvent (94% [or 91%] isopropyl alcohol and cleaning pad) • Vacuum cleaner (KS-14377, L5) • Orange stick (KS-6320) • Flashlight 	-
2	Remove Cartridge Tape Transport from Service	DLP-684
3	Remove Cartridge From Cartridge Tape Transport	DLP-695
4	Clean Cartridge Tape Transport Head Assembly and Chassis	DLP-687
5	Inspect Cartridge Tape Transport for Wear	DLP-688
6	Depress TDC POWER to Restore Power to Cartridge Tape Transport	-
7	Replace Cartridge	-
8	Perform Tape Diagnostics	DLP-685
9	Perform Tape Audit	DLP-709

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	<p>NOTES: 1. Perform check of backup tapes during a period of minimum recent change activity because this procedure will block all recent change activity</p> <p>2. The TAPE AUDIT required during this procedure requires approximately 45 minutes (minimum) per tape to run. Other Multiscan Functions are not possible while TAPE AUDIT is in process</p> <p>3. All offices must have at least six good tapes in office at all times</p> <p>4. All tapes should be marked with current generic and date of last update</p> <p>5. A Broadcast Warning Message (BWM) log should be kept identifying BWMs on each tape</p>	
1	<p>Obtain the Following Support Apparatus</p> <ul style="list-style-type: none"> • Cloth (KS-2423) • Cleaning Solvent (94% [or 91%] Isopropyl Alcohol) <p>NOTE: TEXPAD-Manufactured by Texwipe, Hillsdale, N.J. 07642 Will Eliminate the Need of the Cloth and Solvent</p> <ul style="list-style-type: none"> • Vacuum Cleaner (KS-14377, L5) 	-
2	At System Status Panel, Verify SYSTEM NORMAL Lamp is ON	-
3	Remove Cartridge Tape Transport Unit 1 (Minirecorder) From Service	DLP-684
4	Perform Tape Diagnostics on Tape 1	DLP-685
5	Remove Cartridge Tape Transport Unit 0 (Minirecorder) From Service	DLP-684
6	Perform Tape Diagnostics on Tape 0	DLP-685
7	Update Translation Files	DLP-681
8	Verify Hashsum Values Using Broadcast Warning Message (BWM)	DLP-549
9	Perform Off-Line Bootstrap (All Recent Change Activity Will be Blocked During This Step)	DLP-551
10	Verify Hashsum Values Using Previous Values	DLP-552
11	Remove Cartridge Tape Transport Unit 1 (Minirecorder) From Service	DLP-684
12	Remove Tape Cartridge From TDC 1 and Label per Notes 4 and 5	DLP-695
13	Clean Tape Cartridge Head Assembly and Chassis	DLP-687
14	Depress TDC POWER to Restore Power to Tape Unit	-

CHECK BACKUP TAPES

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 2	008

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

15	Obtain Backup Tape Cartridge and Insert into CTT1	-
16	Perform Tape Diagnostics on Tape 1	DLP-685
17	Perform Tape Audit on Tape 1 (Copy Data from Tape 0 to Tape 1)	DLP-709
18	Repeat from Step 11 for Each Backup Tape	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	<p>NOTES: 1. Perform off-line bootstrap during a period of minimum recent change activity because this procedure will block all recent change activity</p> <p>2. The TAPE AUDIT required during this procedure requires approximately 45 minutes (minimum) per tape to run and may take longer depending on traffic. Other Multiscan Functions are not possible while TAPE AUDIT is in progress</p>	
1	<p>Obtain the Following Support Apparatus</p> <ul style="list-style-type: none"> • Cloth (KS-2423) • Cleaning Solvent (94% [or 91%] Isopropyl Alcohol) <p>NOTE: TEXPAD-Manufactured by Texwipe, Hillsdale, N.J. 07642 Will Eliminate the Need of the Cloth and Solvent</p> <ul style="list-style-type: none"> • Vacuum Cleaner (KS-14377, L5) 	-
2	At System Status Panel, Verify SYSTEM NORMAL Lamp is ON	-
3	Remove Cartridge Tape Transport Unit 1 (Minirecorder) From Service	DLP-684
4	Perform Tape Diagnostics on Tape 1	DLP-685
5	Remove Cartridge Tape Transport Unit 0 (Minirecorder) From Service	DLP-684
6	Perform Tape Diagnostics on Tape 0	DLP-685
7	Update Translation Files	DLP-681
8	Verify Hashsum Values Using Broadcast Warning Message (BWM)	DLP-549
9	Perform Off-Line Bootstrap (All Recent Change Activity Will be Blocked During This Step)	DLP-551
10	Verify Hashsum Values Using Previous Values	DLP-552
11	Remove Cartridge Tape Transport Unit 1 (Minirecorder) From Service	DLP-684
12	Remove Tape Cartridge From TDC1 and Label with Time and Date	DLP-695
13	Clean Tape Cartridge Head Assembly and Chassis	DLP-687
14	Depress TDC POWER to Restore Power to Tape Unit	-
15	Obtain Backup Tape Cartridge and Insert Into CTT 1	-

**PERFORM OFF-LINE BOOTSTRAP PROCEDURE FOR OFFICES WITH 3E3
GENERIC OR LATER**

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 2	009

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

16	Perform Tape Diagnostics on Tape 1	DLP-685
17	Perform Tape Audit on Tape 1 (Copy Data From Tape 0 to Tape 1)	DLP-709

**PERFORM OFF-LINE BOOTSTRAP PROCEDURE FOR OFFICES WITH 3E3
GENERIC OR LATER**

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Identify the Following Parameters for the Coin Control Circuit to be Installed: Trunk Group Number (GRP 071) Member Number (TER) Office Equipment Number (OE) Scan Point Number (SP) Distributor Triplet (DP) Mounting Location for Coin Control Circuit Equipment Frame Equipment Frame Level (EQL) Circuit Pack (FB 423) Position (0-3) at EQL	-
	A. All Offices May Obtain Parameter Information From Circuit Order or Office Records Form ESS 3201	-
	B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained from Office Records by Typing the Following on MC TTY OP:OFR/ OP:OFR/ FORM 3201/ FORM 3171/ HDR YES/ AND HDR YES/ GRP 071/ OE ALL/ TER ALL/ END! END!	-
2	At Distributing Frame, Locate Office Equipment Terminals (OE)	DLP-710
3	At Distributing Frame, Install Wiring for Coin Control Circuit	DLP-649
4	Install Coin Control Circuit Pack FB 423 in Assigned Position at Equipment Frame	-
5	Add Coin Control Circuit	DLP-653
6	Put Coin Control Circuit into Service	DLP-550
7	Update Office Records per Local Procedures	-

ADD COIN CONTROL CIRCUIT (SD-3H411-01 [CPS 423])

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain Following Support Apparatus • Two 3P6E Cords • 1024 B Headset • 23A Portable Transmission Measuring Set (TMS)	-
2	Obtain Test Number from Distant Office for Transmission Testing	-
3	Depending on Generic, Activate Trunk and Line Test Panel (TLTP) Using Method A or B	-
	A. In Offices with 3E3 or Later Generic, Depress ON Key	-
	B. In Offices with SO-2 Generic, Activate TLTP	DLP-578
4	Set Up Trunk Circuit to TLTP for Testing. Select One of the Following Procedures for Type of Trunk	-
	A. For Outgoing or Two-Way Trunk Circuits, Key in Test Number as Digits to be Outpulsed in Keying Format	DLP-579
	B. For Incoming Trunk Circuits Have Distant Office Dial Directory Number Assigned to TLTP Access Trunk 1	-
	C. For Trunk Circuits Which Connect to ACD (Automatic Call Distribution) Trunks	-
	1. Obtain J94742A Test Set	-
	2. Condition J94742A Test Set	DLP-575
	3. Set Trunk Circuit Up to TLTP ACCESS TRUNK 1	DLP-579
	D. For Intercept Trunks or Directory Assistance Trunks Not Connecting to ACD Trunks, Key in Special Code as Digits to be Outpulsed in Keying Format	DLP-579
E. For Operator Verification Trunks Have Distant Office Dial Directory Number Assigned to TLTP ACCESS TRUNK 1	-	
5	At TLTP Depress TRMT 1 Key	-
6	Make 1000 Hz Transmission Level Measurements	DLP-568
7	At TLTP Release TRMT 1 Key	-
8	Release J94742A Test Set From TLTP if Connected	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

9	Release Circuit from TLTP	-
	A. Make Circuit Available for Service - Depress ACTIVE IDLE , then RELEASE 1 Key	-
	B. Make Circuit Unavailable for Service - Depress OUT OF SERVICE , then RELEASE 1 Key	-
10	Repeat Steps 2 Through 9 on Every Trunk to be Tested	-

MEASURE TRUNK TRANSMISSION LEVELS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain the Following Support Apparatus <ul style="list-style-type: none"> • 3A Portable Noise Measuring Set • Two 3P6E Cords • 1024 B Headset • 23A Portable Transmission Measuring Set (TMS) 	-
2	Obtain Test Number from Distant Office for Transmission Testing	
3	Depending on Generic, Activate Trunk and Line Test Panel (TLTP) Using Method A or B	-
	A. In Offices with 3E3 or Later Generic, Depress ON Key at TLTP	-
	B. In Offices with SO-2 Generic, Activate TLTP	DLP-578
4	Set Up Trunk Circuit to TLTP for Testing. Select One of the Following Procedures for Type of Trunk	-
	A. For Outgoing or Two-Way Trunk Circuits, Key in Test Number as Digits to be Outpulsed in Keying Format	DLP-579
	B. For Incoming Trunk Circuits, Have Distant Office Dial Directory Number Assigned to TLTP ACCESS TRUNK 1	-
	C. For Trunk Circuits Which Connect to ACD (Automatic Call Distribution) Trunks	-
	1. Obtain J94742A Test Set	-
	2. Condition J94742A Test Set	DLP-575
	3. Set Trunk Circuit up to TLTP ACCESS TRUNK 1	DLP-579
	D. For Intercept Trunks or Directory Assistance Trunks Not Connecting to ACD Trunks, Key in Special Code as Digits to be Outpulsed in Keying Format	DLP-579
	E. For Operator Verification Trunks, Have Distant Office Dial Directory Number Assigned to TLTP ACCESS TRUNK 1 Key	-
5	At TLTP Depress TRMT 1 Key	-
6	Make 1000 Hz Transmission Level Measurements	DLP-568
7	Condition 3A Noise Measuring Test Set	DLP-683

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

8	Make Noise Level Measurements	DLP-570
9	At TLTP Release TRMT 1 Key	-
10	Release J94742A Test Set from TLTP if Connected	DLP-576
11	Release Circuit from TLTP	-
	A. Make Circuit Available for Service - Depress ACTIVE IDLE , then RELEASE 1 Key	-
	B. Make Circuit Unavailable for Service - Depress OUT OF SERVICE , then RELEASE 1 Key	-
12	Repeat Steps 2 Through 11 on Every Trunk to be Tested	

MEASURE TRUNK TRANSMISSION AND NOISE LEVELS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Identify the Following Parameters for the Customer Dial Pulse Receiver (CDPR) to be Installed: Trunk Group Number (GRP 065) Member Number (TER) Office Equipment Number (OE) Supervisory Scan Point Number (SP) Distributor Triplet (DP) Mounting Location for CDPR Circuit Pack (FB 367) Equipment Frame (Network or Control) Equipment Frame Level (EQL) Circuit Pack Position at EQL	-
	A. All Offices May Obtain Parameter Information from Circuit Order or Office Records Form ESS 3201	-
	B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained from Office Records by Typing the Following on MC TTY OP:OFR/ OP:OFR/ FORM 3201/ FORM 3171/ HDR YES/ AND HDR YES/ GRP 065/ OE ALL/ TER ALL/ END! END!	-
2	At Distributing Frame Identify CDPR Tip (DTO_) and Ring (DRO_) Terminations	DLP-640
3	At Distributing Frame Locate Office Equipment (OE) Terminations Indicated on Circuit Order	DLP-710
4	At Distributing Frame Cross-Connect CDPR Terminals (DTO_ and DRO_) to OE Terminals (T_ and R_)	-
5	Install CDPR Circuit Pack FB 367	-
6	Add CDPR Circuit	DLP-653
7	Put CDPR Circuit into Service	DLP-550
8	Update Office Records per Local Procedures	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain J94022A (22A) Milliwatt Reference Meter and 3P15A Cord Assembly	-
2	Verify that all Milliwatt Reference Generator Outlets are Properly Terminated (No Plugs or Cords in Milliwatt Reference Jacks)	-
3	Place 22A Meter in Horizontal Position and Calibrate per Instructions on Front Panel	-
4	Remove Faceplate Cover at Level 44	-
5	Calibrate Milliwatt Reference Generator	DLP-566
6	Calibrate 23CR Transmission Measuring Set on TLTP	DLP-567
7	Replace Faceplate Cover at Level 44	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	NOTE: The TAPE AUDIT required during this procedure takes approximately 2.5 hours (minimum) per tape to run and may take longer depending on traffic. Other Multiscan Functions are not possible while TAPE AUDIT is in process	
1	Obtain the Following Support Apparatus <ul style="list-style-type: none"> • Cloth (KS-2423) • Cleaning Solvent (94% [or 91%] isopropyl alcohol and cleaning pad) • Vacuum cleaner (KS-14377,L5) 	
2	Update On-Line Tape Copies of Translations	DLP-699
3	Remove TDC 1 from Service	DLP-684
4	Remove Tape Cartridge from CTT of TDC 1 (CCT 1)	DLP-695
5	Clean CTT 1 Head Assembly and Chassis	DLP-687
6	Obtain Backup Tape Cartridge and Insert into CTT 1	-
7	Perform Tape Audit on Tape 1 (Copy Data from Tape 0 to Tape 1)	DLP-709
8	Remove TDC 1 from Service	DLP-684
9	Remove Updated Backup Tape Cartridge from CTT 1	DLP-695
10	Mark Cartridge for Identification as a Most Up-to-Date Backup Tape Cartridge	-
11	If More Backup Tape Cartridges are to be Updated Repeat from Step 6	-
12	Insert Tape Cartridge, which was set Aside in Step 4, into CTT 1	-
13	Type: RST: TAPE 1!	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain the Following Support Apparatus • KS-14510 Volt-Ohm Milliammeter (VOM) or Equivalent	-
2	Test System Status Panel Input Voltages	DLP-664
3	Test Lamps and LEDs on System Status Panel (SSP)	DLP-657
4	Test SSP System Control (SYC) 0 and SYC 1 Status Indicators	DLP-658
5	Test SSP Panel Time Out Function	DLP-659
6	Test PASS , FAIL , and EXECUTE Lamps	DLP-660
7	Test Peripheral Unit Status Display LEDs	DLP-661
8	Test Lamps at STATUS Section of Not Active 3A CC Control Unit	DLP-662
9	Test 3A CC Panel Status Functions and Indicators for Not Active 3A CC Control Unit	DLP-663
10	At SSP, Depress LOCK Key	-
11	At STATUS Section of Not Active 3A CC Depress MANUAL Key	-
12	Test LEDs and Switches of REGISTER LOAD and DISPLAY Function for Not Active 3A CC Control Unit	DLP-665
13	Test LEDs and Switches of COMPARE Function on Not Active 3A CC Control Unit	DLP-666
14	Test 3A CC Panel Memory Functions and Indicators	DLP-667
15	Test 3A CC Panel Enable Manual Parity Function and Indicator	DLP-668
16	Test 3A CC Panel Reject Function and Indicators	DLP-669
17	Test 3A CC Panel Step Function	DLP-672
18	Return 3A CC to Normal Operating Condition	DLP-670
19	At TTY Type SW:SYC! and Repeat Items 8 Through 18 for Untested 3A CC Panel	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Identify the Following Parameters for the Dial Pulse Transmitter Circuit to be Installed: Trunk Group Number (GRP 068) Member Number (TER) Office Equipment Number (OE) Supervisory Scan Number (SP) Directed Scan Point Number (DSP) Distributor Triplet (DP) Mounting Location for Circuit Pack FB 403 Equipment Frame (Misc Frame) Equipment Frame Level (EQL) Circuit Pack Position at EQL	-
	A. All Offices May Obtain Parameter Information from Circuit Order or Office Records Form ESS 3201	-
	B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained from Office Records by Typing the Following on MC TTY OP:OFR/ OP:OFR/ FORM 3201/ AND FORM 3171/ HDR YES/ HDR YES/ GRP 068/ OE ALL/ TER ALL/ END! END!	-
2	At Distributing Frame Identify Dial Pulse Transmitter Circuit Tip (T_) and Ring (R_) Terminations [NOTE: These terminations must be identified at the Distributing Frame Connector Block stenciled T3H403-11]	-
3	At Distributing Frame Locate Office Equipment (OE) Terminations Indicated on Service Order	DLP-710
4	At Distributing Frame Cross-Connect Dial Pulse Transmitter Circuit T_ and R_ Terminations to OE Terminals (T_ and R_)	-
5	Install Circuit Pack FB 403	-
6	Add Dial Pulse Transmitter Circuit	DLP-653
7	Put Dial Pulse Transmitter Circuit into Service	DLP-550
8	Update Office Records per Local Procedures	-

ADD DIAL PULSE TRANSMITTER CIRCUIT (SD-3H403-01)

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 1	017

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	<p>NOTES: 1. Perform procedure during a period of minimum recent change activity because this procedure will block all recent change activity</p> <p>2. The TAPE AUDIT required during this procedure requires approximately 45 minutes (minimum) per tape to run and may take longer depending on traffic. Other Multiscan Functions are not possible while TAPE AUDIT is in progress</p>	
1	<p>Obtain the Following Support Apparatus</p> <ul style="list-style-type: none"> • Cloth (KS-2423) • Cleaning solvent (94% [or 91%] Isopropyl Alcohol) <p>NOTE: (TEXPAD-Manufactured by Texwipe, Hillsdale, N.J., 07642 Will Eliminate the Need of the Cloth and Solvent)</p> <ul style="list-style-type: none"> • Vacuum cleaner (KS-14377, L5) 	-
2	Check Patch Status	DLP-548
3	Verify Generic Hashsum Values Using Broadcast Warning Message (BWM)	DLP-549
4	Install Generic Patch	DLP-679
5	At System Status Panel, Verify SYSTEM NORMAL Lamp is ON	-
6	Remove Cartridge Tape Transport Unit 1 (Minirecorder) From Service	DLP-684
7	Perform Tape Diagnostics on Tape 1	DLP-685
8	Remove Cartridge Tape Transport Unit 0 (Minirecorder) From Service	DLP-684
9	Perform Tape Diagnostics on Tape 0	DLP-685
10	Update Translation Files	DLP-681
11	Verify Generic Hashsum Values Using Broadcast Warning Message (BWM)	DLP-549
12	Perform Off-Line Bootstrap (All Recent Change Activity Will be Blocked During This Step)	DLP-551
13	Verify Hashsum Values Using Previous Values	DLP-552
14	Remove Cartridge Tape Transport Unit 1 (Minirecorder) From Service	DLP-684
15	Remove Tape Cartridge From TDC1 and Label With Time and Date	DLP-695

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

16	Clean Tape Cartridge Head Assembly and Chassis	DLP-687
17	Obtain Backup Tape Cartridge and Insert Into CTT1	-
18	Perform Tape Diagnostics on Tape 1	DLP-685
19	Perform Tape Audit on Tape 1 (Copy Data From Tape 0 to Tape 1)	DLP-709

INSTALL GENERIC PATCH FOR OFFICES WITH 3E3 GENERIC OR LATER

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	NOTE: The TAPE AUDIT required during this procedure requires approximately 2.5 hours (minimum) per tape to run and may take longer depending on traffic. Other Multiscan Functions are not allowed while TAPE AUDIT is in progress	
1	Obtain the Following Support Apparatus <ul style="list-style-type: none"> • Cloth (KS-2423) • Cleaning Solvent (94%[or 91%] Isopropyl Alcohol and Cleaning Pad) • Vacuum Cleaner (KS-14377, L5) 	-
2	Check Patch Status	DLP-548
3	Verify Generic Hashsums Using Broadcast Warning Message (BWM)	DLP-676
4	Install Generic Patch	DLP-702
5	At System Status Panel, Verify SYSTEM NORMAL Lamp is ON	-
6	Remove Cartridge Tape Transport Unit 1 (Minirecorder) From Service	DLP-684
7	Perform Tape Diagnostics on Tape 1	DLP-685
8	Remove Cartridge Tape Transport Unit 0 (Minirecorder) From Service	DLP-684
9	Perform Tape Diagnostics on Tape 0	DLP-685
10	Update Translation Files	DLP-681
11	Prepare System for Off-Line Bootstrap Procedure	DLP-675
12	Verify Generic Hashsums Using Broadcast Warning Message (BWM)	DLP-676
13	Calculate Translation Hashsums	DLP-677
14	Print Translation Hashsums	DLP-678
15	Power Down Off-Line Control Unit by Depressing POWER Key on 3A CC Panel	-
16	Power Up Off-Line Control Unit by Depressing POWER Key on 3A CC Panel	-
17	Perform Off-Line Bootstrap	DLP-686
18	Verify Generic Hashsums Using Previous Values	DLP-693

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 2	019

INSTALL GENERIC PATCH FOR OFFICES WITH GENERIC SO-2

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

19	Verify Translation Hashsums Using Previous Values	DLP-694
20	Perform Post Off-Line Bootstrap Procedures	DLP-689
21	Remove Cartridge Tape Transport Unit 1 (Minirecorder) From Service	DLP-684
22	Remove Tape Cartridge From TDC 1 and Label with Time and Date	DLP-695
23	Clean Tape Cartridge Head Assembly and Chassis	DLP-687
24	Depress TDC POWER to Restore Power to Tape Unit	-
25	Obtain Backup Tape Cartridge and Insert into CTT 1	-
26	Perform Tape Diagnostics on Tape 1	DLP-685
27	Perform Tape Audit on Tape 1 (Copy Data From Tape 0 to Tape 1)	DLP-709

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

NOTE: All equipment is furnished with the loop start option. Only lines with the following switch and level number can be modified for ground start:

SWITCH	LEVEL(S)
0	7
1	6,7
2	6,7
3	7
4	7
5	6,7
6	6,7
7	7

1	From Service Order, Identify Office Equipment (OE) Number to be Changed: OE gg cws i: gg = concentrator group (1-15) (network frame number) c = concentrator (0-1) w = switch group (0-2) s = switch (0-7) i = input level (0-7)	-
2	At 296-6C Switch on Network Frame, Locate Line Sensor Coil to be Modified	DLP-524
3	Remove All Straps on Line Sensor Coil	-
4	Install Straps on Line Sensor Coil For Ground Start Line or Loop Start Line	DLP-526
5	Repeat Items 1 Through 4 for Strapping of Additional Lines	-

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 1	020

STRAP LINE FOR GROUND START OR LOOP START

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	NOTE 1: This procedure will block all recent change activity	
1	Check Patch Status	DLP-548
2	Verify All Hashsum Values	DLP-555

CHECK HASHSUMS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Identify the Following Parameters for the Multifrequency Receiver Circuit to be Installed: Trunk Group Number (GRP 066) Member Number (TER) Office Equipment Number (OE) Supervisory Scan Point Number (SP) Directed Scan Point Number (DSP) Distributor Triplet (DP) Mounting Location for Circuit Packs A260, A261, A262, A263, A152 (three), A264, A265, A266 Equipment Frame (Misc Frame) Equipment Frame Level (EQL) Circuit Pack Positions at EQL	-
	A. All Offices May Obtain Parameter Information from Circuit Order or Office Records Form ESS 3201	-
	B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained From Office Records by Typing the Following on MC TTY OP:OFR/ OP:OFR/ FORM 3201/ FORM 3171/ HDR YES/ HDR YES/ GRP 066/ AND OE ALL/ TER ALL/ END! END!	-
2	At Distributing Frame Connector Block Stenciled per T3H402-11, Identify Multifrequency Receiver T- and R- Terminations	-
3	At Distributing Frame Locate Office Equipment (OE) Terminations Indicated on Service Order	DLP-710
4	At Multifrequency Receiver Circuit Packs Mounting Location, Remove Power (Power is Off When PWR OFF Key Lamp is Lighted)	-
5	At Distributing Frame Cross-Connect Multifrequency Receiver Circuit T- and R- Terminations to OE Terminals (T- and R-)	-
6	Install Circuit Packs A260, A261, A262, A263, A152 (three), A264, A265, A266	-
7	At Multifrequency Receiver Circuit Packs Mounting Location, Restore Power. (Power is Restored When PWR OFF Key Lamp is Extinguished)	-

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 2	022

ADD MULTIFREQUENCY RECEIVER CIRCUIT (SD-3H402-01)

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

8	Add Multifrequency Receiver Circuit	DLP-653
9	Put Multifrequency Receiver Into Service	DLP-550
10	Update Office Records per Local Procedures	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	<p>Identify the Following Parameters for the Multifrequency Transmitter Circuit to be Installed:</p> <p>Trunk Group Number (GRP 067) Member Number (TER) Office Equipment Number (OE) Supervisory Scan Point Number (SP) Directed Scan Point Number (DSP) Distributor Triplet (DP) Mounting Location for Circuit Packs FB 362, FB 363, and FB 364 Equipment Frame (Misc Frame) Equipment Frame Level (EQL) Circuit Pack Positions at EQL</p> <p>A. All Offices May Obtain Parameter Information from Circuit Order or Office Records Form ESS 3201</p> <p>B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained from Office Records by Typing the Following on MC TTY</p> <p style="margin-left: 40px;"> OP:OFR/ OP:OFR/ FORM 3201/ FORM 3171/ HDR YES/ HDR YES/ GRP 067/ AND OE ALL/ TER ALL/ END! END! </p>	-
2	At Distributing Frame Identify Multifrequency Transmitter T- and R- Terminations	DLP-645
3	At Distributing Frame Locate Office Equipment (OE) Terminations Indicated on Service Order	DLP-710
4	At Distributing Frame Cross-Connect Multifrequency Transmitter Circuit T- and R- Terminations to OE Terminals (T- and R-)	
5	Install Circuit Packs FB 362, FB 363, and FB 364	
6	Add Multifrequency Transmitter Circuit	DLP-653
7	Put Multifrequency Transmitter Circuit into Service	DLP-550
8	Update Office Records per Local Procedures	-

ADD MULTIFREQUENCY TRANSMITTER CIRCUIT (SD-3H404-01)

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	<p>Identify the Following Parameters for the Regular Ringing Circuit to be Installed:</p> <p>Trunk Group Number (GRP 069) Member Number (TER) Office Equipment Number (OE) Supervisory Scan Point Number (SP) Directed Scan Point Number (DSP) Distributor Triplet (DP) Mounting Location for Regular Ringing Circuit Packs (FB 358): Equipment Frame (Network or Control) Equipment Frame Level (EQL) Circuit Pack Position at EQL</p> <p>A. All Offices May Obtain Parameter Information from Circuit Order or Office Records Form ESS 3201</p> <p>B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained from Office Records by Typing the Following on MC TTY</p> <p>OP:OFR/ OP:OFR/ FORM 3201/ AND FORM 3171/ HDR YES/ HDR YES/ GPR 069/ OE ALL/ TER ALL/ END! END!</p>	-
2	At Distributing Frame Identify Regular Ringing Circuit Tip (T_) and Ring (R_) Terminations	DLP-643
3	At Distributing Frame Locate Office Equipment (OE) Terminations Indicated on Circuit Order	DLP-710
4	At Distributing Frame Cross-Connect Regular Ringing Circuit Terminals (T_, R_) to OE Terminals (T_, R_)	-
5	Install Regular Ringing Circuit Pack FB 358	-
6	Add Regular Ringing Circuit	DLP-653
7	Put Regular Ringing Circuit into Service	DLP-550
8	Update Office Records per Local Procedures	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Identify the Following Parameters for the Superimposed Ringing Circuit to be Installed: Trunk Group Number (GRP 070) Member Number (TER) Office Equipment Number (OE) Supervisory Scan Point Number (SP) Directed Scan Point Number (DSP) Distributor Triplet (DP) Mounting Locations for Superimposed Ringing Circuit Packs (FB 375 and FB 376) Equipment Frame (Misc Frame) Equipment Frame Level (EQL) Circuit Pack Positions at EQL	-
	A. All Offices May Obtain Parameter Information from Circuit Order or Office Records Form ESS 3201	-
	B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained from Office Records by Typing the Following on MC TTY OP:OFR/ OP:OFR/ FORM 3201/ AND FORM 3171/ HDR YES/ HDR YES/ GRP 070/ OE ALL/ TER ALL/ END! END!	-
2	At Distributing Frame Identify Superimposed Ringing Circuit Tip (T_) and Ring (R_) Terminations [NOTE: These terminations must be identified at the Distributing Frame Connector Block stenciled T3H406-11]	-
3	At Distributing Frame Locate Office Equipment (OE) Terminations Indicated on Service Order	DLP-718
4	At Distributing Frame Cross-Connect Superimposed Ringing Circuit T_ and R_ Terminations to OE Terminals (T_ and R_)	-
5	Install Circuit Packs FB 375 and FB 376	-
6	Add New Superimposed Ringing Circuit (Service Circuit)	DLP-653
7	Put Superimposed Ringing Circuit into Service	DLP-550
8	Update Office Records per Local Procedures	-

ADD SUPERIMPOSED RINGING CIRCUIT (SD-3H406-01)

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	<p>Identify the Following Parameters for the Tone and Announcement Circuit to be Installed:</p> <p>Trunk Group Number (GRP) Two Member Numbers (TER) Two Office Equipment Numbers (OE) One Supervisory Scan Point Number Mounting Location for Tone and Announcement Circuit Pack Equipment Frame Equipment Frame Level Circuit Pack (FB 383) Position at EQL Mounting Location of 7A or 13A Announcement Machine on Miscellaneous Frame</p> <p>A. All Offices May Obtain Parameter Information from Circuit Order Office Records Form ESS 3201</p> <p>B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained from Office Records by Typing the Following on MC TTY</p> <p>OP:OFR/ OP:OFR/ FORM 3201/ AND FORM 3171/ HDR YES/ HDR YES/ GRP ALL/ OE ALL/ TER ALL/ END! END!</p>	-
2	At Distributing Frame, Locate Office Equipment Terminals (OE)	DLP-710
3	Install Wiring at Distributing Frame	DLP-647
4	Install Circuit Pack FB 383	-
5	<p>Add Tone and Announcement Circuit. [NOTE: One message is required for each of the member numbers. The scan point number is used in the first message only]</p>	DLP-653
6	Put Tone and Announcement Circuit into Service	DLP-550
7	Dial a Number Which Will Result in Connection to the Announcement	-
8	Update Office Records per Local Procedures	-

**ADD TONE AND ANNOUNCEMENT CIRCUIT (SD-3H411-01 [CPS 383])
 FOR OPERATION WITH 7A OR 13A ANNOUNCEMENT**

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 1	026

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	<p>Identify the Following Parameters for the Tone and Announcement Circuit to be Installed:</p> <p>Trunk Group Number (GRP) Two Member Numbers (TER) Two Office Equipment Numbers (OE) Mounting Location for Tone and Announcement Circuit Equipment Frame Equipment Frame Level (EQL) Circuit Pack (FB 383) Position at EQL</p> <p>A. All Offices May Obtain Parameter Information from Circuit Order or Office Records Form ESS 3201</p> <p>B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained from Office Records by Typing the Following on MC TTY</p> <pre> OP:OFR/ OP:OFR/ FORM 3201/ FORM 3171/ HDR YES/ HDR YES/ GRP ALL/ AND OE ALL/ TER ALL/ END! END! </pre>	-
2	At Distributing Frame, Locate Office Equipment Terminals (OE)	DLP-710
3	Install Wiring at Distributing Frame	DLP-648
4	Install Circuit Pack FB 383	-
5	Add Tone and Announcement Circuit (NOTE: One Message is Required for Each of The Member Numbers. No Scan Point Number is Used)	DLP-653
6	Put Tone and Announcement Circuit into Service	DLP-550
7	Update Office Records per Local Procedures	-

**ADD TONE AND ANNOUNCEMENT CIRCUIT (SD-3H411-01 [CPS 383])
TONE OPERATION**

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	<p>Identify the Following Parameters for the TOUCH-TONE Receiver to be Installed:</p> <p>Trunk Group Number (GRP 064) Member Number (TER) Office Equipment Number (OE) Supervisory Scan Point Number (SP) Directed Scan Point Number (DSP) Distributor Triplet (DP) Mounting Location for CDPR Circuit Pack (FB 367) Equipment Frame (Network or Control Frame) Equipment Frame Level (EQL) Circuit Pack Position at EQL Mounting Location for TOUCH-TONE Detector Circuit Packs A118, A120, A121, A122, A123, A124, A946, A1025 Equipment Frame (Misc Frame) Equipment Frame Level (EQL) Circuit Pack Positions at EQL</p>	-
	<p>A. All Offices May Obtain Parameter Information from Circuit Order or Office Records Form ESS 3201</p>	-
	<p>B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained from Office Records by Typing the Following on MC TTY</p> <p>OP:OFR/ OP:OFR/ FORM 3201/ FORM 3171/ HDR YES/ AND HDR YES/ GRP 064/ OE ALL/ TER ALL/ END! END!</p>	-
2	<p>At TOUCH-TONE Detector Circuit Packs Mounting Location, Remove Power (PWR OFF Key Lamp is Lighted when Power is Off)</p>	-
3	<p>At Distributing Frame Identify CDPR Tip (DTO_) and Ring (DRO_) Terminations</p>	DLP-640
4	<p>At Distributing Frame Identify TOUCH-TONE Detector Circuit Tip (T_) and Ring (R_) Terminations NOTE: These terminations must be identified at the Distributing Frame Connector Block stenciled T3H401-11</p>	-

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 2	028

ADD TOUCH-TONE RECEIVER CIRCUIT (SD-3H401-01 AND SD-3H410-01)

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

5	At Distributing Frame Cross-Connect CDPR Terminations (DTO_ and DRO_) to TOUCH-TONE Detector Terminations (T_ and R_)	-
6	At Distributing Frame Locate OE Terminations Indicated on Circuit Order	DLP-710
7	At Distributing Frame Cross-Connect CDPR Terminations (DTO_ and DRO_) to OE Terminations (T_ and R_)	-
8	Install CDPR Circuit Pack FB 367 per CP Location	-
9	Install TOUCH-TONE Detector Circuit Packs A118, A120, A121, A122, A123, A124, A946, and A1025	-
10	At TOUCH-TONE Detector Circuit Packs Mounting Location, Restore Power (Power is on when PWR OFF Key Lamp is Extinguished)	-
11	Add TOUCH-TONE Receiver Circuit	DLP-653
12	Put TOUCH-TONE Receiver Circuit into Service	DLP-550
13	Update Office Records per Local Procedures	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	NOTE: Reallocations involve taking the off-line SYC out of service	
1	Provide for an Attendant at Either 3ESS Switch or Switching Control Center	
2	From Circuit Order Identify Translators to be Reallocated	-
	<i>CAUTION: Schedule reallocations to be performed during a period of light traffic in case a memory reload must be performed due to system failure</i>	
3	Notify Service Order Bureau of Schedule and Request That No TTY Messages be Input During Reallocation	-
4	Update Tape Copies of Translation	DLP-699
5	Perform Reallocation Procedures	DLP-700
6	Notify Service Order Bureau That Reallocation is Complete	-
7	Allow System to Soak (Operate) for at Least 24 Hours With New Translation Layout	-
8	Verify Success of System Soak	DLP-538

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain the Following Support Apparatus <ul style="list-style-type: none"> • KS-19353, L1 Oscillator • 23A Transmission Test Set • 3A Noise Measuring Test Set 	-
2	Identify the Following Parameters for the Universal Trunk Circuit to be Installed Using Method A or B Trunk Group Number (GRP) Member Number (TER) Office Equipment Number (OE) Equipment Location (EQL) Circuit Code (CKT) Scan Point Number (SP) Distributor Triplet (DP) Circuit Pack (FBXXX)	
	A. In All Offices Parameters May be Obtained From Office Records Form ESS 3201 or Circuit Order	-
	B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained From Office Records by Typing the Following on MC TTY OP:OFR/ OP:OFR/ FORM 3201/ FORM 3171/ HDR YES/ AND HDR YES/ GRP ALL/ OE ALL/ END! END!	-
3	At Distributing Frame Install Wiring for Trunk Circuit	DLP-637
4	Install Universal Trunk Circuit Pack in Assigned Slot of Equipment Frame	-
5	Add New Trunk Circuit	DLP-653
6	At Maintenance TTY, Type DGN:TRK (a,b)! a = GRP, b = TER	-
7	Depending on Generic, Activate Trunk and Line Test Panel (TLTP) Using Method A or B	-
	A. Activate TLTP in Offices with SO-2 Generic	DLP-578
	B. Activate TLTP in Offices with 3E3 or Later Generic. Depress ON Key on TLTP	-

ADD UNIVERSAL TRUNK CIRCUIT

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

8	Set Up Trunk Circuit TLTP for Testing Using Access Trunk 1	DLP-579
9	At TLTP Depress TRMT 1 Key	-
10	Contact Distant Office to Set Up Schedule for Transmission Level Test	-
11	Measure 1000 Hz Transmission Levels	DLP-568
12	Condition Portable KS-19353, L1 Oscillator	DLP-682
13	Make Slope Gain Measurements	DLP-569
14	Condition Portable 3A Noise Measuring Set	DLP-683
15	Make Noise Level Measurements	DLP-570
16	At TLTP Release TRMT 1 Key	-
17	Release Circuit from TLTP	-
	A. Make Circuit Available for Service. Depress ACTIVE IDLE, then RELEASE 1 Key	-
	B. Make Circuit Unavailable for Service. Depress OUT OF SERVICE, then RELEASE Key	-
18	At Maintenance TTY Type: RST:TRK (a,b)! a = GRP, b = TER	-
19	Update Office Records per Local Procedures	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain The Following Support Apparatus <ul style="list-style-type: none"> • E-Z Hook Clip Leads • 900-Ohm Resistor • Oscilloscope (Tektronix Model 465) • Voltage Probe (Tektronix P6006) 	-
2	Depending on Generic, Activate Trunk and Line Test Panel (TLTP)	-
	A. Activate TLTP in Office with SO-2 Generic	DLP-578
	B. Activate TLTP in Office with 3E3 Generic by Depressing ON key	-
3	Check Trunk and Line Test Panel Test Voltages	DLP-523
4	Set Up Trunk and Line Test Panel for Testing Dial Pulse Receiver Test Circuit on Access Trunk 1 (Use Trunk Group Number 111 and Member Number 005)	DLP-579
5	Test Operation of Dial Pulse Receiver Test Circuit	DLP-533
6	Set Up Trunk and Line Test Panel for Testing Transmission Test Termination Circuit on Access Trunk 1 (Use Trunk Group Number 111 and Member Number 006)	DLP-579
7	Test Operation of Transmission Test Termination Circuit	DLP-534
8	Set Up Trunk and Line Test Panel for Testing Loop Environment Test Circuit on Access Trunk 1 (Use Trunk Group Number 111 and Member Number 003)	DLP-579
9	Test Operation of Loop Environment Test Circuit	DLP-541
10	Set Up Trunk and Line Test Panel for Testing Touch-Tone Receiver Test Circuit on Access Trunk 1 (Use Trunk Group Number 111 and Member Number 008)	DLP-579
11	Condition Oscilloscope	DLP-712
12	Test Operation of Touch-Tone Receiver Test Circuit	DLP-571
13	Test Operation of Station Ringer Test Circuit	DLP-539

CHECK OPERATION OF TEST CIRCUITS NOT TESTED BY DIAGNOSTICS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

14	Test Operation of Automatic Line Insulation Test (ALIT) Circuit Using One of the Following Methods:	-
	A. Verify Tests Performed by Installation Group Using Western Electric Handbook 269, Section 544	-
	B. Perform Following Tests:	-
	1. Verify ALIT Short or Ring to Ground Test Capability	DLP-572
	2. Verify ALIT Tip or Ring to Ground Test Capability	DLP-573
	3. Verify ALIT Foreign EMF Test Capability	DLP-574

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Verify That Diagnostic Tests Have Been Successfully Completed on All Network Controllers and Scanner Controllers	-
2	Verify Both SYCs; One Should Be Active, the Other in Standby	-
3	Verify That All Keys on SSP are Nonoperated	-
4	Exercise Network	DLP-542

PERFORM NETWORK FABRIC EXERCISES

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain the Following Support Apparatus • Speed Call 8 Load Boxes	
2	Verify That All Change Notices (CNs) Are Installed for Program Issue Being Used at Cutover	-
3	Verify That All Error Detection Systems and All TTYs Are Enabled During Test Periods	-
4	Initialize System From System Status Panel Using Stable Clear (Level 5)	DLP-613
5	Observe Procedures and Results of Maintenance Volume Tests	DLP-628
6	Check and Reset System Clock to Correct Time	DLP-525
7	Initialize System From System Status Panel Using Stable Clear (Level 5)	DLP-613
8	Observe Procedures and Results of Simulated Commercial Power Failure Tests	DLP-629
9	Observe Procedures and Results of Integrated Volume Tests	DLP-546
10	File Copies of Test Results (Form SD-97-1313 and SD-97-1315) Provided by the Installer and Retain for at Least 30 Days after Cutover	-

OBSERVE PROCEDURES AND RESULTS OF OPERATIONAL VOLUME TESTS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain the Following Support Apparatus <ul style="list-style-type: none"> • Portable KS-19353, L1 Oscillator • Portable 23A Transmission Measuring Set • Portable 3A Noise Measuring Set • Two 3P6E Cords • 1024 B Headset 	-
2	Obtain Test Numbers from Distant Office for Transmission Testing	-
3	Verify Number of Trunk Circuits Installed Using Office Records, Form E3202-3	-
4	Depending on Generic, Activate Trunk and Line Test Panel (TLTP) Using Method A or B	-
	A. In Offices with 3E3 or Later Generic, Depress ON Key at TLTP	DLP-578
	B. In Offices with SO-2 Generic, Activate TLTP	-
5	Set Up Trunk Circuit to TLTP for Testing Using One of the Following Procedures:	-
	A. For Outgoing or Two-Way Trunk Circuits, Key in Test Number as Digits to be Outpulsed in Keying Format	DLP-579
	B. For Incoming Trunk Circuits, Have Distant Office Dial Directory Number Assigned to TLTP Access Trunk 1	-
	C. For Trunk Circuits Which Connect to ACD (Automatic Call Distribution) Trunks	-
	1. Obtain J94742A Test Set	-
	2. Condition J94742A Test Set	DLP-575
	3. Set Up Trunk Circuit to TLTP ACCESS TRUNK 1	DLP-579
	D. For Intercept Trunks or Directory Assistance Trunks Not Connecting to ACD Trunks, Key in Special Code as Digits to be Outpulsed in Keying Format	DLP-579
	(Continued on Page 2)	

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 2	034

PERFORM TRUNK CIRCUIT LINE-UP TESTS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

5 (Contd)	E. For Operator Verification Trunks, Have Distant Office Dial Directory Number Assigned to TLTP ACCESS TRUNK 1 Key	-
6	At TLTP Depress TRMT 1 Key	
7	Measure 1000 Hz Transmission Levels (Circuit Net Loss)	DLP-568
8	Condition KS-19353, L1 Oscillator	DLP-682
9	Make Gain-Slope Measurements	DLP-569
10	Set Up 3A Noise Measuring Set	DLP-683
11	Make Noise Level Measurements	DLP-570
12	At TLTP Release TRMT 1 Key	-
13	Release J94742A Test Set From TLTP if Connected	DLP-576
14	Release Circuit from TLTP	-
	A. If Circuit is to be Made Available for Service, Depress ACTIVE IDLE , then RELEASE 1 Key	-
	B. If Circuit is to be Made Unavailable for Service - Depress OUT OF SERVICE , then RELEASE 1 Key	-
15	Repeat Tests From Step 3 on Every Trunk Circuit Installed	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Verify That SYSTEM NORMAL Lamp on SSP is Lighted	-
2	On MC TTY Type OP:DATA;CURR!	-
3	Initialize System From SSP Using Manual Transient Clear	DLP-612
4	Initialize System From SSP Using Stable Clear	DLP-613
5	Initialize System From SSP Using Memory Reload	DLP-614
6	Initialize System From SSP Using Past Office Data	DLP-615
7	Initialize System From SSP Using Backdate Office Data	DLP-616
8	Initialize System From 3A CC Panel, Program Timer Timeout Check	DLP-617
9	On MC TTY Type SW:SYC!	-
10	Initialize System From 3A CC Panel, Program Timer Timeout Check	DLP-617
11	Initialize System From 3A CC Panel, Error Register Bit Set Check	DLP-618
12	Verify that System Switched CUs While Performing Step 10	-
13	Initialize System From SSP Using Memory Reload (Reload Current Memory)	DLP-614
14	Reset System Clock	DLP-525

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	NOTE: This test should be made prior to installing the protectors in CDF. The office must be in the cutover mode	
1	Obtain the Following Support Apparatus • 1014A Test Set • ITE-4674 Test Set	
2	Obtain a List of All Assigned Directory Numbers (Subscriber Lines) and Their Associated Cable and Pair, OE, and Class of Service from Service Order Assignment Group	-
3	Identify all Ground Start Lines	-
4	Test for Dial Tone from Every Subscriber Line	DLP-704
5	Make a List of Random-Sampled Subscriber Lines Consisting of all Classes of Service [10% of Total]	-
6	Make Call Termination and Ringing Polarity Test of Subscriber Lines Selected in Step 5	DLP-705
7	If Error Rate of Test in Step 6 is More Than 1%, Select a Second Sample and Repeat Step 6	-

PERFORM HALF OFFICE TESTS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Test Routing to all NXX Codes in the Immediate Dialing Area	DLP-630
2	Repeat Step 1 on Each Class of Service	-
3	Test Routing to all NPA (Area) Codes	DLP-631
4	Test Routing to 3-Digit (411, 611, 911) Service Codes	-

CHECK CAPABILITY OF OFFICE ROUTING

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Establish Schedule to Test CAMA Trunks with CAMA Office and Accounting Department	-
2	Obtain 7-Digit Test Number at CAMA Office Location	-
3	Verify Number of CAMA Trunks Installed in Office Records, Form 3202-3	-
4	Prepare Log to List all Test Calls Dialed (See FIG. 1)	-
5	Make All Trunks Busy	DLP-610
6	Place Test Call on CAMA Trunk	DLP-671
7	Make Test Call to a Busy Number	DLP-692
8	Restore all CAMA Trunks to Service One at a Time Using TTY Message RST:TRK aaa,bbb;UCL! aaa = Trunk Group Number, bbb = Member Number	-
9	Make Test Call to Toll Directory Information (1+555-1212)	-
10	Make Test Call to Test for Billing in Different Area Code Location	-
11	Make Test Call to CAMA Office Test Number from 4-or 8-Party Line	-
12	Verify That all Calls Have Been Listed on Test Log	-
13	Verify Accuracy of Toll Billing Between Accounting Departments Billing Records and Test Log	-

CAMA BILLING TEST LOG							DATE: _____
Telephone No. Originating Call	Telephone Number Dialed	Time Call Made	Time of Disconnect	Duration of Call in Minutes	Busy	No Answer	Wrong Number (List Number Reached)

FIG. 1

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Install Single Slot Coin Telephone in Vicinity of the TLTP. Build Loop Resistance to Maximum 1300 Ohms and Station Ground Resistance to 50 Ohms	-
2	Determine From Office Records, Form ESS 3201-1, the Number of Coin Control Circuits Installed	-
3	Remove From Service All Coin Control Circuits Except One Circuit Using TTY Message RMV:SVC aaa,bbb! aaa = Trunk Group Number, bbb = Member Number	-
4	Make Local Charge Test	DLP-632
5	Check for Refund After Abandon Call	DLP-633
6	Check Stuck Coin Alarm Operation	DLP-634
7	If Equipped for Local Overtime Charging, Check Overtime Charging Feature	DLP-654
8	Perform the Following Tests on the Type of Coin Control Circuits Installed	-
	A. Coin First Coin Control Circuits	-
	1. Make Partial Dial Test	DLP-655
	2. Make Local Operational Tests with the Operator	DLP-656
	B. Dial Tone First Coin Control Circuits	-
	1. Check Recorded Announcement for Partial Deposit	DLP-690
	2. Make Local Operational Tests with the Operator	DLP-691
9	Remove From Service the Coin Control Circuit Just Tested Using TTY Message RMV:SVC aaa,bbb! aaa = Trunk Group Number, bbb = Member Number	-
10	Restore to Service a Different Coin Control Circuit Using TTY Message RST:SVC aaa,bbb;UCL! aaa = Trunk Group Number, bbb = Member Number	-
11	Repeat Steps 4 Through 10 Until Every Coin Control Circuit Has Been Tested	-

ACCEPT COIN CONTROL CIRCUITS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain a Trunk Circuit Pack FB-429	-
2	Plug Trunk Circuit Pack FB-429 into a Spare Universal Trunk Circuit Slot	-
3	Add New Trunk Circuit	DLP-706
4	Establish Test Circuit Between Old and New Offices	DLP-711
5	On MC TTY Type ALW:TOGO!	-
6	On MC TTY Type SET:PRECUT!	-
7	Install Protectors on CDF (Heat Coils or Cut Through Devices)	-
8	Verify that all Service Orders are Up-to-Date and are Input to Recent Change	-
9	Verify that Cross-Connections are Run for all Service Orders	-
10	On MC TTY Type EX:OTO(nxx,xxxx,yyyy),GLP! nxx = The Office Code xxxx = The First Telephone Number to be Tested yyyy = The Last Telephone Number to be Tested	-
11	Analyze MC TTY Trouble Printouts and Correct Faults	DLP-707
12	Verify that all Telephone Numbers have been Tested	DLP-708
13	On MC TTY Type ABT:MSF!	-
14	Remove Trunk Circuit Installed in Step 3	DLP-696
15	Remove Circuit Pack FB-429 Installed in Step 2	-
16	Remove CDF Cross-Connections Installed in Step 4	-

PERFORM OFFICE-TO-OFFICE TESTS




FIG. 1 - Test Cord With 300-Ohm to 1000-Ohm Resistor in Cord





FIG. 2 - Master Scanner Terminal Strip Numbering Scheme



ACCEPT OFFICE ALARMS

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 2	041

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Obtain the Following Support Apparatus • One Test Cord (See FIG. 1) • 300-Ohm to 1000-Ohm Resistor	-
2	Notify Switching Control Center of Alarm Acceptance Testing	-
3	On SYSTEM STATUS PANEL Depress ALARM CONTROL-ALARM TRFR Until It Extinguishes	-
4	Obtain Open Type 70 Fuse	-
	NOTE: See FIG. 2 for Master Scanner Terminal Numbering Scheme	
5	Test FIRE Alarm	DLP-500
6	Test TAPE DATA CONTROLLER POWER Alarm	DLP-501
7	Test TTY CONTROLLER POWER Alarm	DLP-502
8	Test SYSTEM STATUS PANEL POWER Alarm	DLP-503
9	Test SYSTEM STATUS PANEL POWER Status Switching	DLP-504
10	Test EMERGENCY LINE TRANSFER Status	DLP-505
11	Test MAINTENANCE FRAME CONVERTER LIMIT Alarm	DLP-506
12	Test TRUNK, JUNCTOR, and SERVICE CIRCUIT FUSE Alarm	DLP-507
13	Test LINE FERROD FUSE Alarm	DLP-508
14	Test CONTROL UNIT 0 POWER Alarm	DLP-509
15	Test CONTROL UNIT 1 POWER Alarm	DLP-510
16	On SSP Depress ALARM TRFR	-
17	Notify Switching Control Center of Testing Completion	-

ACCEPT OFFICE ALARMS

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Depending on Teletypewriter Type, Check Operation of Backup TTY Controller	
	A. For 35 ASR Type	-
	1. Switch Local Teletypewriter From Maintenance TTY Controller (TTYC 0) to Backup TTY Controller (TTYC 1)	DLP-619
	2. Verify That Local TTY is Operational While Using Backup TTY Controller	-
	3. Switch Local Teletypewriter From Backup TTY Controller (TTYC 1) to Maintenance TTY Controller (TTYC 0)	DLP-528
	B. For 43A Type	-
	1. Switch Local Teletypewriter From Maintenance TTY Controller (TTYC 0) to Backup TTY Controller (TTYC 1)	DLP-527
	2. Verify That Local TTY is Operational While Using Backup TTY Controller	-
	3. Switch Local Teletypewriter From Backup TTY Controller (TTYC 1) to Maintenance TTY Controller (TTYC 0)	DLP-556

CHECK OPERATION OF BACKUP TTY CONTROLLER

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	NOTE: If an oscilloscope is not available, use an RMS type digital multimeter, isolated from ground	-
1	Obtain a 1370-Ohm Resistor and One of the Following Type Test Sets	-
	A. Tektronix Oscilloscope Type 465 and a Tektronix P6011 Voltage Probe	-
	B. Hickok Model 3310 Digital Multimeter (DMM) must be a True RMS Meter, Isolated From Ground	-
2	On Combined Distributing Frame (CDF), Remove Protectors From Cable Pair (Subscriber Line) to be Tested	-
3	Connect 1370-Ohm Resistor in Series Between the Ring Side of Line and -48 Volt Battery	
4	Measure Longitudinal Voltage Using One of the Following Test Sets	-
	A. Oscilloscope	-
	1. Condition Oscilloscope	DLP-712
	2. Measure Longitudinal Voltage Using Oscilloscope	DLP-697
	B. Digital Multimeter	DLP-698
5	Remove 1370-Ohm Resistor Connected in Step 4	-
6	Replace Protectors Removed in Step 2	-
7	Repeat From Step 2 on all Ground Start Lines	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

	NOTE : Revenue loss may occur on calls during performance of this procedure	
1	Update Tape Copies of Translations	DLP-699
2	Inhibit Maintenance Functions	DLP-511
3	Set AMA Buffer to 100 Words	DLP-512
4	Type in the Following: RC:OFFICE/ AMA:YES/ END!	-
5	Depress TTY INIT	-
6	Prepare Log to List All Test Calls Dialed (See FIG. 1)	-
7	Notify AMARC to Monitor Test Line(s) Billing	-
8	Test Billing of Calls Into Local Test Line	DLP-513

(Continued on Page 2)

AMARC BILLING TEST LOG						DATE _____
Telephone No. Originating Call	Telephone Number Dialed	Time Call Mode	Time of Disconnect	Duration of Call in Minutes	Custom Calling Feature(s)	Notes Busy, No Answer, Wrong Number, etc

FIG. 1

Issue 3	AUG 1984
233-142-100	NTP
PAGE 1 of 3	044

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

9	Test Billing of Calls Into Regular Hold Trunk Line	DLP-514
10	Test Billing of Calls From Private Message-Rate Line Through All Trunk Groups	DLP-515
11	Test Billing of Miscellaneous Calls	DLP-516
12	Test Time Release Disconnect Billing	DLP-517
13	Test Custom Calling Features Billing	DLP-518
14	Test Switch to Backup Data Link	DLP-519
15	Repeat Items 7 Through 12 for Testing of Backup Facility	-
16	Test Switch to Primary Link	DLP-520
17	Type in the Following: RC:OFFICE/ AMA:YES/ END!	-
18	Depress TTY INIT	-
19	Reconfigure Software Message Area	DLP-521
20	Allow Maintenance Functions	DLP-522
21	Type in the Following: RC:OFFICE/ AMA:YES/ END!	-
22	Depress TTY INIT	-
23	Notify AMARC of Start Billing Time	-
24	Type in OP:DATA;CURR! to Place Translations on Tape Current File	-
	NOTE: System can fall back to original translations by initializing using PAST OFFICE DATA	
25	Soak System for at Least One Full Day	-
26	Update Tape Copies of Translations	DLP-699
	(Continued on Page 3)	

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

27	Notify Service Bureau of the Following:	-
	A. Line Software Registers can be Removed	
	B. Normal Toll Calls can be Routed Through Network Rather Than TSPS or CAMA Office	
	C. Recent Changes on Message Rate Lines do not Need Message Register Index	

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Condition System Controller for Testing	DLP-584
2	Depress and Hold LAMP TEST to Test STATUS Lamps at Not Active 3A Central Control Panel	-
3	At Not Active 3A Central Control Panel Verify All Switches Are In Down Position	-
4	Test Control Unit STATUS Functions and Indicators	DLP-585
5	Test Loading and Displaying of Registers	DLP-586
6	Test COMPARE Indicator	DLP-587
7	Test MEMORY Functions and Indicators	DLP-588
8	Test ENABLE MANUAL PAR (Parity) Functions and Indicator	DLP-589
9	Test REJECT Function and Indicator	DLP-590
10	Test STEP Function	DLP-591
11	Restore System to Normal Operating Condition	DLP-592
12	Type in SW:SYC!	-
13	Repeat Steps 1 Through 11 for Other Control Unit	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	Diagnose System Status Panel Controller	DLP-593
2	Test System Status Panel Indicators	DLP-594
3	Test System Status Panel Power Controls	DLP-595
4	Test PANEL TIME OUT Function	DLP-596

ACCEPT SYSTEM STATUS PANEL



DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	If No Announcements Have Been Recorded, Record a Test Announcement Using Method A or B	-
	A. Record Announcement at 7A Announcement Set	DLP-652
	B. Record Announcement at 13A Announcement Set by Following Directions on Front Panel of 13A Announcement Set or Using Section 201-519-301	-
2	Depending On Generic, Activate Trunk and Line Test Panel (TLTP) Using Method A or B	-
	A. In Offices with 3E3 Generic or Later, Depress ON Key at TLTP	-
	B. In Offices with SO-2 Generic Activate TLTP	DLP-578
3	Set Up TLTP for Testing Recorded Announcement Circuit	DLP-579
4	Perform Clarity Check on Recorded Announcement	DLP-537
5	At TLTP, Depress ON Key to Deactivate	-

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

1	<p>Identify the Following Parameters for the Remote Recording of Announcement Circuit to be Installed:</p> <p>Trunk Group Number (GRP) Member Number (TER) Office Equipment Number (OE) Supervisory Scan Point Number (SP) Directed Scan Point Number (DSP) Distributor Triplet (DP) Mounting Location for Announcement Circuit Equipment Frame Equipment Frame Level (EQL) Circuit Pack [(FB 426 for 7A) or (FB 686 for 13A)] Position at EQL Mounting Location of 7A or 13A Announcement on Miscellaneous Frame Trigger Number</p> <p>A. All Offices May Obtain Parameter Information from Circuit Order or Office Records Form ESS 3201</p> <p>B. If Office Has 3E3 or Later Generic, Parameter Information May Be Obtained From Office Records by Typing the Following on MC TTY</p> <p>OP:OFR/ OP:OFR/ FORM 3201/ FORM 3171/ HDR YES/ HDR YES/ GRP ALL/ AND OE ALL/ TER ALL/ END! END!</p>	-
2	At Distributing Frame, Locate Office Equipment Terminals (OE)	DLP-710
3	At Distributing Frame, Install Wiring for Remote Recording of Announcement Circuit	DLP-651
4	<p>Depending on Announcement System, Install Remote Recording of Announcement Circuit Pack in Assigned Slot of Equipment Frame</p> <p>A. For 7A Announcement Set, Install Circuit Pack FB 426</p> <p>B. For 13A Announcement Set, Install Circuit Pack FB 686</p>	-

**ADD REMOTE RECORDING OF 7A OR 13A ANNOUNCEMENT CIRCUIT
 (SD-3H411-01 [CPS FB 426] OR [CPS FB 686])**

DO THE ITEMS BELOW IN THE ORDER LISTED FOR DETAILS, GO TO

5	Add Remote Recording of Announcement Circuit	DLP-653
6	Put Remote Recording of Announcement Circuit into Service	DLP-550
7	Request Remote Location to Verify Operation of Announcement Circuit	-
8	Update Office Records per Local Procedures	-

**ADD REMOTE RECORDING OF 7A OR 13A ANNOUNCEMENT CIRCUIT
(SD-3H411-01 [CPS FB 426] OR [CPS FB 686])**





FIG. 1 - Control Frame 0, Bay 1 Fuse Unit

ANALYZE AUDIBLE ALARM FAULT


Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 1	100



NOTE 1
Performing memory reload causes the remark files and translation files to disagree


CLEAR TROUBLE ENCOUNTERED DURING REALLOCATION

Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 4	101




CLEAR TROUBLE ENCOUNTERED DURING REALLOCATION

Issue 3	AUG 1984
233-142-100	TAP
PAGE 2 of 4	101



CLEAR TROUBLE ENCOUNTERED DURING REALLOCATION

Issue 3	AUG 1984
233-142-100	TAP
PAGE 3 of 4	101



NOTE 2	
It takes approximately 10 minutes for CU diagnostics to run	
Issue 3	AUG 1984
233-142-100	TAP
PAGE 4 of 4	101

CLEAR TROUBLE ENCOUNTERED DURING REALLOCATION

[1] If CU has not been removed from service, type on TTY
RMV:CU!

[2] On 3A Control Panel, depress
MANUAL if lighted

[3] On TTY type RST:CU!

AND

[4] See NOTE 1.
Does system
respond with
DGN CU ATP
RST CU COMPL

Yes

No

Page 2

NOTE 1


It takes
approximately 10
minutes for CU
diagnostics to run

Issue 3 | AUG 1984

233-142-100 | TAP

PAGE 1 of 7 | 102

CLEAR CONTROL UNIT (CU) REMOVED FROM SERVICE



TEST BLOCK 8

M 14 DGN CU 0 STOPPED TST 8 SEG 1 ADR 01646 0039
 LOOP 3 TRBL 0804 DATA 0005 3535

TRUBLE NUMBER


FIG. 1

Issue 3	AUG 1984
233-142-100	TAP
PAGE 2 of 7	102

CLEAR CONTROL UNIT (CU) REMOVED FROM SERVICE

[12] On TTY type
DGN:CU;STEP:aa!
aa = test number received
when test failed

[13] On SSP depress
TEST CONTROL - EXECUTE
to repeat diagnostic test
of test that failed




CLEAR CONTROL UNIT (CU) REMOVED FROM SERVICE

Issue 3	AUG 1984
233-142-100	TAP
PAGE 3 of 7	102


[15] Replace first circuit pack not previously replaced listed in TLM under trouble number for off-line circuit pack [DLP-543] or for maintenance frame circuit pack [DLP-545]

[16] On SSP depress **EXECUTE** to repeat diagnostic test




CLEAR CONTROL UNIT (CU) REMOVED FROM SERVICE

Issue 3	AUG 1984
233-142-100	TAP
PAGE 4 of 7	102




CAUTION 1
On-line circuit packs cannot be replaced without causing a service loss. Replace only during low traffic periods if possible

Issue 3	AUG 1984
233-142-100	TAP
PAGE 5 of 7	102




CLEAR CONTROL UNIT (CU) REMOVED FROM SERVICE

Issue 3	AUG 1984
233-142-100	TAP
PAGE 6 of 7	102




WARNING 1	
<i>Running diagnostic tests 37 and 54 in repetitive form may cause equipment damage. Use step form</i>	
Issue 3	AUG 1984
233-142-100	TAP
PAGE 7 of 7	102




NOTE 1	
Trouble Locating Manuals list in order the circuit pack(s) most likely to cause failure	
Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 5	103

CLEAR TROUBLE IN CARTRIDGE TAPE TRANSPORT SUBSYSTEM




Issue 3	AUG 1984
233-142-100	TAP
PAGE 2 of 5	103




CLEAR TROUBLE IN CARTRIDGE TAPE TRANSPORT SUBSYSTEM

Issue 3	AUG 1984
233-142-100	TAP
PAGE 3 of 5	103




NOTE 2
 This message is not necessary for offices with 3E3 generic or later. Tape initiation is run automatically during tape diagnostics

Issue 3	AUG 1984
233-142-100	TAP
PAGE 4 of 5	103




CLEAR TROUBLE IN CARTRIDGE TAPE TRANSPORT SUBSYSTEM

Issue 3	AUG 1984
233-142-100	TAP
PAGE 5 of 5	103




CORRECT BROADCAST WARNING MESSAGE (BWM) HASHSUMS MISMATCH


Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 1	104



CLEAR BOOTSTRAP OPERATION TROUBLE


Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 2	105






CORRECT GENERIC HASHSUMS MISMATCH (SO-2 GENERIC)

Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 2	106



CORRECT GENERIC HASHSUMS MISMATCH (SO-2 GENERIC)

Issue 3	AUG 1984
233-142-100	TAP
PAGE 2 of 2	106




NOTE 1
This message is not necessary for offices with 3E3 generic or later. Tape initiation is run automatically during tape diagnostics

CAUTION 1
The replacement tape must be same generic and issue as removed tape


Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 2	107

CLEAR TAPE DATA CONTROLLER FATLREAD/FATLWRIT TROUBLE




CLEAR TAPE DATA CONTROLLER FATLREAD/FATLWRIT TROUBLE

Issue 3	AUG 1984
233-142-100	TAP
PAGE 2 of 2	107




CLEAR TROUBLE IN TAPE DATA CONTROLLER AND MINIRECORDER


Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 4	108



NOTE 1 - CONNECTOR PIN IDENTIFICATION, PROCESSOR FRAME 0




NOTE 2 - CONNECTOR PIN IDENTIFICATION, PROCESSOR FRAME 1



NOTE 3 - CABLING IS 30GA 100Ω COAX KS-21112,L2


FIG. 1 Tape Data Controller - 3A CC Cabling

Issue 3	AUG 1984
233-142-100	TAP
PAGE 2 of 4	108




CLEAR TROUBLE IN TAPE DATA CONTROLLER AND MINIRECORDER

Issue 3	AUG 1984
233-142-100	TAP
PAGE 3 of 4	108



Issue 3	AUG 1984
233-142-100	TAP
PAGE 4 of 4	108




Issue 3	AUG 1984
233-142-100	TAD
PAGE 1 of 1	109

SYSTEM STATUS PANEL CONTROL INTERFACE

[1] At System Status Panel, depress **ALARM RELEASE** until it extinguishes


[2] Place off-line control unit **OUT OF SERVICE** by typing in:
RMV:CU! _____



NOTE 1	
Trouble Locating Manuals list in order circuit pack(s) most likely to cause failure.	
Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 3	110


[7] Replace first circuit pack not previously replaced identified in TLM [DLP-673]

[8] Type in message to restore circuit to service:
RST:CU!




Issue 3	AUG 1984
233-142-100	TAP
PAGE 2 of 3	110

CLEAR TROUBLE IN SYSTEM STATUS PANEL CONTROLLER (SSPC)



CLEAR TROUBLE IN SYSTEM STATUS PANEL CONTROLLER (SSPC)

Issue 3	AUG 1984
233-142-100	TAP
PAGE 3 of 3	110



Miscellaneous
Power and
Ringing and
Tone Plant
82255-01

Test Frame
3H904-01

-48V Power
81999-01
82030-01
82304-01





FIG. 1 - System Connections


OFFICE SYSTEM CONNECTIONS

Issue 3	AUG 1984
233-142-100	TAD
PAGE 1 of 1	111





ANALYZE SYSTEM STATUS PANEL ALARM FAULT

Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 1	112




Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 2	113






RELAY IDENTIFICATION	
RELAY	KEY
K1	-STA
K2	+STA
K3	BT
K4	20K
K5	1K
K6	MVM
K8	VMR

TRUNK AND LINE TEST PANEL TEST VOLTAGE CONNECTIONS



CORRECT GENERIC HASHSUM MISMATCH FOR OFFICES WITH 3E3 GENERIC OR LATER

Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 1	115



CLEAR BOOTSTRAP OPERATION TROUBLE FOR OFFICES WITH 3E3 GENERIC OR LATER

Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 1	116

[1] At TTY
type
DMP:ST 420751,16!

[2] Do all
words of the
address contain
zeros

Yes → TAP-116

At TTY type:

[3] ALW:OW!

[4] OP:OWFILE!
See NOTE 1

See TABLE A
for TTY response

[5] IN:GENID xxxxxxxx!
xxxxxxx = office generic number

[6] IN:ISSID zzzzzzzz!
zzzzzzzz = issue identifier

[7] IN:OW n; TTY!
n = next available overwrite
number → COMPL

[8] IN:OWDATA: -,D,adr,old,new!
adr = absolute address of location
being overwritten
old = old content of location
being overwritten
new = new data to be used in
overwrite location
(zeros) → OK

AND


No

Page 2

TABLE A	
tt	OP OWFILE aa
	GENID xxxxxxxx
	ISSID zzzzzzzz
OW	nnnnn s mmdd yyhh type
.	
.	
.	
OW	nnnnn s mmdd yyhh type
CURR	cur LENGTH len
OP	OWFILE COMPL
Where:	
nnnnn	= overwrite number
s	= overwrite status
	0 = inactive
	1 = active
	3 = dead

NOTE 1	
It may take up to 10 minutes to obtain TTY printout	
Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 2	117

CORRECT SCHEDULER TROUBLE



CAUTION	
<i>Using Steps 20 and 21 will eliminate any recent change items, and zero the first two words.</i>	
Issue 3	AUG 1984
233-142-100	TAP
PAGE 2 of 2	117

CORRECT SCHEDULER TROUBLE

<u>DIAGNOSTIC TEST PROGRAMS</u>			
TEST NO.			
1	CDGMCH	MAINTENANCE CHANNEL	PR-1C912-32
2		GATING BUS	
3		CLOCK	
4		INITIALIZATION	
5	CDGTO	"TO" FIELD DECODER	PR-1C913-32
6		"FROM" FIELD DECODER	
7	CDGMLT	MULTIPLE "FROM" CROSSPOINTS	PR-1C914-32
8		MULTIPLE "TO" CROSSPOINTS	
9	CDGREG	GENERAL REGISTER GATING	PR-1C915-32
10		SPECIAL REGISTER GATING	
11	CDGMIC	MICRO STORE CONTENT	PR-1C916-32
12	CDGFN	FUNCTION REGISTER (DML)	PR-1C917-32
13		ADDER	
14		DML COMPARATOR	
15		BOOLEAN FUNCTIONS	
16		FIND LOW ZERO	
17		ROTATE	
18		PACK AND UNPACK	
19	CDGMC1	MICROCONTROL	PR-1C919-32
20		MICROCONTROL PT 2	
21		MICROCONTROL PT 3	
22		MICROCONTROL PT 4	
23	CDSPA1	DS FLIP-FLOP	PR-1C920-32
24		PA PLUS 1 ADDER	
25	CDGMSQ	STORE BUS CONTROLLER PT 1	PR-1C921-32
26		MAIN STORE BUS	
27	CDGSIO	MAIN STORE I/O ACCESS TO OFF-LINE STORE	PR-1C922-32
28		MAIN STORE-MAINTENANCE ORDERS	
29	CDGSMX	MAIN STORE MULTIPLEXOR	PR-1C923-32
30		MAIN STORE MULTIPLEXOR	
31		MAIN STORE MULTIPLEXOR	
32		MAIN STORE MULTIPLEXOR	
33	CDGSBS	MAIN STORE BUS - COMMANDS	PR-1C924-32
34		MAIN STORE BUS - ADDRESS	
35		MAIN STORE BUS - DATA	
36		MAIN STORE BUS - CONTROL	
37	CDGSCP	NORMAL SELECT SIGNAL TO FANOUT BOARDS	PR-1C934-32
38		DATA PARITY CHECK	
39		REFRESH SELECT	
40		ADDRESS SIGNAL	
41	CDGSFA	MAIN STORE FANOUT ADDRESS PARITY	PR-1C925-32
42		MAIN STORE FANOUT ADDRESS SIGNALS THRU MEMORY MODULES	
43		ADDRESS PARITY CHECKERS	
44		ADDRESS PARITY CHECKERS	
45	CDGSFB	MAIN STORE FANOUT BOARDS	PR-1C926-32
46		MAIN STORE FANOUT BOARDS	
47		MAIN STORE FANOUT BOARDS	
48		MAIN STORE FANOUT BOARDS	
49	CDGSWP	MAIN STORE WRITE PROTECT	PR-1C927-32
50		MAIN STORE WRITE PROTECT	
51		MAIN STORE WRITE PROTECT	
52	CDGSON	INTERPROCESSOR STORE BUS	PR-1C928-32
53	CDGSDF	MAIN STORE CONTROLLER DATA TEST	PR-1C935-32
54		MAIN STORE CONTROLLER DATA TEST	
55		MAIN STORE CONTROLLER DATA TEST	
56		MAIN STORE CONTROLLER DATA TEST	

Issue 3	AUG 1984
233-142-100	TAD
PAGE 1 of 2	118

DIAGNOSTIC TEST PROGRAMS

TEST NO.

57	CDGSD	MAIN STORE MEMORY MODULE TEST PATTERN (0)	PR-1C929-32
58		MAIN STORE MEMORY MODULE TEST PATTERN (1)	
59		MAIN STORE MEMORY MODULE TEST PATTERN (2)	
60		MAIN STORE MEMORY MODULE TEST PATTERN (3)	
61		MAIN STORE MEMORY MODULE TEST PATTERN (4)	
62		MAIN STORE MEMORY MODULE TEST PATTERN (5)	
63		MAIN STORE MEMORY MODULE TEST PATTERN (6)	
64		MAIN STORE MEMORY MODULE TEST PATTERN (7)	
65	CDGMI	MICROINTERPRET	PR-1C930-32
66		MULTIPLE MISC. XPOINTS	
67		DML PARITY GENERATOR	
68		GATING BUS PARITY CHECKER	
69		IB X AND Y FIELD PARITY GENERATOR	
70	CDGNTI	PROGRAM TIMER-TIMING COUNTER	PR-1C931-32
71		INTERRUPT	
72		ADDRESS MATCHER	
73		DATA MATCHER	
74		I/O TEST	
75	CSTATS	SYSTEM STATES 1	PR-1C932-32
76		SYSTEM STATES 2 (PROGRAM TIMER TIMEOUT)	
77		SYSTEM STATUS PANEL TEST	
78	CDGDSR	DOUBLE STORE READ	PR-1C911-32
79		DUMMY	

SCHEMATIC DRAWING
SD-1C900-01

Issue 3	AUG 1984
233-142-100	TAD
PAGE 2 of 2	118

CU DIAGNOSTIC PROGRAM NAMES, PR NUMBERS





TABLE A	
• Cloth (KS-2423)	
• Cleaner Lubricant (KS-16328, L2)	
• Oil can (486A)	
• Brush (KS-14164)	
• Oil (KS-16326, L1)	

- [6] Obtain support apparatus listed in TABLE A
- [7] Using office records Form ESS 3201, identify group number and member number(s) for recorded announcement set _____
- [8] Type RMV:SVC (a,b)!
 a = Group number of recorded announcement set
 b = Member number of recorded announcement set _____

Issue 3	AUG 1984
233-142-100	TAP
PAGE 1 of 2	119

CLEAR TROUBLE IN RECORDED ANNOUNCEMENT SET




CLEAR TROUBLE IN RECORDED ANNOUNCEMENT SET

Issue 3	AUG 1984
233-142-100	TAP
PAGE 2 of 2	119

[1] Connect patch cord from row 16H, column 9 to row 16L, column 9 of master scanner terminal strip

[2] Disconnect test cord



TEST FIRE ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	500




FIG. 1 - Maintenance Frame

TEST TAPE DATA CONTROLLER POWER ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	501

At TTY type:

[8] (See NOTE 1)
INIT:TAPE!

TTY response
INIT TAPE COMPL

[9] DGN:TAPE 1!

DGN TAPE 1 ATP

[10] RST:TAPE 1;UCL!

AND

[11] On maintenance frame replace
fuse ACOA with open fuse

[12] Are the
following
indicators lighted
on the SSP TDC,
MAJOR, and FUSE

Yes

No

[13] Record
incorrect
indication

[14] Is the
following message
printed on the TTY
tt REPT MISCA 19 0
xxxx OFN
(xxxx = invalid)

Yes


No

[15] Record
incorrect
message

Page 3

NOTE 1
This message is not
necessary for offices
with 3E3 generic or
later, tape
initiation is run
automatically during
tape diagnostics

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	501



TEST TAPE DATA CONTROLLER POWER ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	501

[1] On maintenance frame
[FIG. 1] replace fuse
BOB with open fuse

[2] Depress **POWER RESET**
key at bottom of
3A CC unit



[3] Are the
following indicators
lighted on SSP
MAJOR, MINOR and
FUZE

Yes

Page 2

No

[4] Record
incorrect
indication






FIG. 1 - Maintenance Frame


Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	502

TEST TTY CONTROLLER POWER ALARM



TEST TTY CONTROLLER POWER ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	502



TEST TTY CONTROLLER POWER ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	502





FIG. 1 - Maintenance Frame


Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	503

TEST SYSTEM STATUS PANEL POWER ALARM




TEST SYSTEM STATUS PANEL POWER ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	503



TEST SYSTEM STATUS PANEL POWER ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	503




TEST SYSTEM STATUS PANEL POWER STATUS SWITCHING

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	504

[7] See NOTE 1. Momentarily depress LAMP POWER key twice


[8] Depress POWER RESET key at bottom of 3A CC unit

[9] At ALARM CONTROL section of SSP, depress ALARM RELEASE key



TEST SYSTEM STATUS PANEL POWER STATUS SWITCHING

NOTE 1	
This will create an alarm condition to retire the audible alarm	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	504



TEST EMERGENCY LINE TRANSFER STATUS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	505




FIG. 1 - Maintenance Frame

TEST MAINTENANCE FRAME CONVERTER LIMIT ALARM

NOTE 1	
Ignore other alarm indications received	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	506




FIG. 1 - Network Frame

TEST TRUNK JUNCTOR AND SERVICE CIRCUIT FUSE ALARM






FIG. 1 - Network Frame

TEST LINE FERROD FUSE ALARM







FIG. 1



TEST CONTROL UNIT 0 POWER ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	509



TEST CONTROL UNIT 0 POWER ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	509







FIG. 1

TEST CONTROL UNIT 1 POWER ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	510





TEST CONTROL UNIT 1 POWER ALARM

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	510

[1] Type in the following:


INH:MSF 1!
INH:MSF 2!
INH:MSF 3!
INH:MSF 6!
INH:MSF 9!

[2] Wait for
OP DATA COMPL → (circle) → SC lighted on SSP


[3] Type in
LOD:ST xxxxx;SGL:0!
[NOTE 1]

[4] Type in
RST:SC 0x;UCL!
[x is SYC not active]

[5] Type in
SW:SYC! several
times



NOTE 1		
xxxxx is the address of first word of DIRouc found in PR-3H011 - ATSD		
Issue 3	AUG 1984	
233-142-100	DLP	
PAGE 1 of 1	511	



SET AMA BUFFER TO 100 WORDS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	512




TABLE A MISCELLANEOUS TEST CALL LINES	
1.	Private line
2.	Private flat-rate line marked as subscriber line usage
3.	Two-party line
4.	Four-party line with one 10-second call (no record will be generated, unless the line is marked as subscriber line usage study)
5.	Dial-tone-first coin line marked as traffic sampling
6.	Coin-first coin line marked as traffic sampling
7.	Three-way line
8.	Call-waiting line
9.	PBX line

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	513





TABLE A MISCELLANEOUS TEST CALL LINES	
1.	Private line
2.	Private flat-rate line marked as subscriber line usage
3.	Two-party line
4.	Four-party line with one 10-second call (no record will be generated, unless the line is marked as subscriber line usage study)
5.	Dial-tone-first coin line marked as traffic sampling
6.	Coin-first coin line marked as traffic sampling
7.	Three-way line
8.	Call-waiting line
9.	PBX line

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	514

[1] From private message-rate line place calls through all trunk groups



[2] Compare log with AMARC records.
See NOTE 1

**TEST BILLING OF CALLS FROM PRIVATE MESSAGE-RATE LINE
THROUGH ALL TRUNK GROUPS**

NOTE 1

With the exception of 411, 800 calls and calls marked as traffic sampling of subscriber line usage study, no records should be generated for TSPS, TSP, CAMA, or operator board calls

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	515






TABLE A MISCELLANEOUS TEST CALL LINES	
1.	TLTP line to a trunk only
2.	Incoming call to a call-forward line which forwards its phone to a local station
3.	Regular tandem call with duration 10 seconds (no record will be generated, except when induced by the call-forward action)
4.	WATS line to a trunk only



TEST TIME RELEASE DISCONNECT BILLING

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	517



Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	518





FIG. 1

TEST SWITCH TO BACKUP DATA LINK

NOTE 1	
TTY may print REPT CKT TRBL AMA	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	519






FIG. 1 - Data Interface Unit


TEST SWITCH TO PRIMARY DATA LINK

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	520



NOTE 1	
Message holds administration MSF active for 5 minutes	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	521

RECONFIGURE SOFTWARE MESSAGE AREA





ALLOW MAINTENANCE FUNCTIONS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	522



[1] Adjust zero setting screw to indicate zero volts on voltmeter, if necessary

[2] Verify fuses on KS-19412 rectifier are good [NOTE 1]

[3] On TLTP voltmeter set VMR key




Page 2



NOTES	
1. Fuses F2-F7 are .25A (Type 70K), F8-F16 are .75A (Type 70K)	
2. When used for acceptance, refer troubles to installation group	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	523

CHECK TRUNK AND LINE TEST PANEL TEST VOLTAGES



CHECK TRUNK AND LINE TEST PANEL TEST VOLTAGES

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	523

[1] At front of network frame (gg) identified by service order, locate 15A grid for concentrator (c) and switch group (w) [FIG.1]

[2] On 296-6C switches, locate line sensor coil for switch (s) and level (i) identified by service order [FIG. 2]





FIG. 1 - Location of 15A Remreed Grid on Network Frame




FIG. 2 - Location of Switch (s) and level (i) on Line Sensor Coil


LOCATE LINE SENSOR COIL

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	524

[1] Call Standard Time number _____

[2] While connection is being established, on MC TTY type OP:CLK!

[3] Compare Standard Time, present day of week, and date with TTY printout _____



Form 1	SET:CLK:TIME(hh,mi,ss)
Form 2	SET:CLK:TIME(hh,mi,ss),day(mo,dd,yy)
V A R I A B L E S	hh = Hour of day (00-23) mi = Minutes past the hour (00-59) ss = Seconds past the minute (00-59) day = Day of week (SUN, MON, TUE, WED, THURS, FRI, SAT) mo = Month of year (Jan is 01, Dec is 12) dd = Day of month (01-31) yy = Year (00-99)


NOTE 1
Observe that message does not include an execute instruction (!). The execute instruction will be typed later when the time entered in the input message becomes correct

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	525

CHECK AND RESET SYSTEM CLOCK

[10] Wait until Standard Time
from recorded announcement
agrees with time typed
in set clock message

[11] Immediately type:!



Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	525

CHECK AND RESET SYSTEM CLOCK





FIG. 1 - Terminals Strapped On Line Sensor Coil For Ground Start




FIG. 2 - Terminals Strapped On Line Sensor Coil For Loop Start

INSTALL STRAPS ON LINE SENSOR COIL

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	526




FIG. 1 - Typical TTYC Layout

SWITCH LOCAL TELETYPEWRITER FROM MAINTENANCE TTY CONTROLLER (TTYC 0) TO BACKUP TTY CONTROLLER (TTYC 1) FOR 43A-TYPE TTY

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	527

TTYC PWR & RESET




FIG. 2

SWITCH LOCAL TELETYPEWRITER FROM MAINTENANCE TTY CONTROLLER (TTY 0) TO BACKUP TTY CONTROLLER (TTYC 1) FOR 43A-TYPE TTY

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	527

TTYC PWR & RESET




FIG. 1

SWITCH LOCAL TELETYPEWRITER FROM BACKUP TTY CONTROLLER (TTYC 1) TO MAINTENANCE TTY (MC) CONTROLLER (TTYC 0)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	528





FIG. 2

**SWITCH LOCAL TELETYPEWRITER FROM BACKUP TTY CONTROLLER
(TTYC 1) TO MAINTENANCE TTY (MC) CONTROLLER (TTYC 0)**

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	528


[7] Disconnect local MC TTY plug from
TTYC 1, port 0 [FIG. 1 and 2]

[8] Connect local MC TTY plug to
TTYC 0, port 0 [FIG. 1 and 2]

[9] At TTYC 0 and TTYC 1
depress **TTYC PWR & RESET**
to restore power [FIG. 2]

[10] Set TTY switch to **ON** or **LINE**

[11] Depress **TTY INIT**



**SWITCH LOCAL TELETYPEWRITER FROM BACKUP TTY CONTROLLER
(TTYC 1) TO MAINTENANCE TTY (MC) CONTROLLER (TTYC 0)**

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	528

[1] From Office Form ESS 3400, Schedule D, verify time nightly routine is set to run

[2] Is nightly routine set to run during test period

Yes

No

[3] On MC TTY, set system clock to 5 minutes before nightly routine is scheduled to start. See TABLE A

[4] What is TTY response

OK

NG

[5] Check input message and repeat from Step 3 using correct setting

[6] Type OP:CLK!

[7] Does TTY print set time correctly


Yes

No

[8] Repeat from Step 3


TABLE A SET CLOCK MESSAGE	
SET:CLK:TIME(hh,mi,ss)!	
or	
SET:CLK:TIME(hh,mi,ss),day(mo,dd,yy)!	
hh	= Hour of day (00-23)
mi	= Minutes past the hour (00-59)
ss	= Seconds past the minute (00-59)
day	= Day of week (SUN, MON, TUES, WED, THURS, FRI, SAT)
mo	= Month of year (Jan is 01, Dec is 12)
dd	= Day of month (01-31)
yy	= Year (00-99)

At SSP:




PERFORM A MEMORY RELOAD INITIALIZATION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	530




PERFORM A PAST OFFICE INITIALIZATION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	531



PERFORM A BACKDATE OFFICE INITIALIZATION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	532



TEST OPERATION OF DIAL PULSE RECEIVER TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 7	533

On TLTP:


[11] Release +STA key

[12] Release TRR key

[13] Release 20K key

[14] Set STATE CONTROL
keys to A B C

[15] Depress EXECUTE




On TLTP:

[16] Set 1K key

[17] Set BT key

[18] Set TRR key


Bit lamp 0 on SSP
display buffer
lights



Page 3

TEST OPERATION OF DIAL PULSE RECEIVER TEST CIRCUIT


Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 7	533



TEST OPERATION OF DIAL PULSE RECEIVER TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 7	533

On TLTP:




Page 5

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 7	533


TEST OPERATION OF DIAL PULSE RECEIVER TEST CIRCUIT

On TLTP:



TEST OPERATION OF DIAL PULSE RECEIVER TEST CIRCUIT


Issue 3	AUG 1984
233-142-100	DLP
PAGE 5 of 7	533



TEST OPERATION OF DIAL PULSE RECEIVER TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 6 of 7	533


On TLTP:



TEST OPERATION OF DIAL PULSE RECEIVER TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 7 of 7	533

On TLTP



TEST OPERATION OF TRANSMISSION TEST TERMINATION CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	534




Using Form ESS 3100,

[1] Identify Office Equipment
Number for all unassigned lines

[2] At 296-6C switch on Network
Frame, locate line sensor coil
to be modified [DLP-524]

[3] Remove all straps on line
sensor coil

[4] Install straps on line sensor
coil for loop start line [DLP-526]



Yes

No

REWIRE UNASSIGNED LINES AS LOOP START

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	535

[1] Using office records Form ESS 3107, identify all return telephone numbers without automatic dial-up feature

[2] For each identified return telephone number, list corresponding office code and telephone number (trigger number)

[3] See NOTE 1. Dial trigger number from prepared list

[4] Remain off-hook for at least 10 seconds without exceeding a 30-second maximum

[5] Place receiver on-hook

High tone received

AND

[6] Does 3ESS switch office return call to terminal

Yes


No

[7] Refer trouble to installation group

NOTE 1
Busy tone may be received if another autoconnect is in progress, port is busy, TTYC is in use by a different message class, or an incorrect translation linkage exits from line to callback terminal


Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	536

CHECK AUTOCONNECT FACILITY




PERFORM CLARITY CHECK ON RECORDED ANNOUNCEMENT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	537



NOTES	
1. TTY responds with following output message tt OP DATA COMPL	
2. TTY responds with following message: tt COPY LCCTBL COMPL	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	538


VERIFY SUCCESS OF SYSTEM SOAK



NOTES


1. Special 3-digit code for STA RNG TST CRT can be found in office records, form ESS 3300-1
2. High tone can be interrupted if tip party is on party line

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	539



Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	539

TEST OPERATION OF STATION RINGER TEST CIRCUIT



Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	540

REPLACE DEFECTIVE CONVERTER IN PROCESSOR FRAME




TABLE A									
CONV. OUTPUT DESIG.	+3V PM054D	+3V PM054C	+5V PM061C	+3V PM054A	+3V PM054B	+5V PM061D	+3V PM058D	+3V PM054F	+3V PM054E
+24V fuse	AA11	AA5	AA5	AA5	AA5	AA12	AA12	AA12	AA12
-48V fuse	A0	A1	A1	A1	A1	A2	A2	A2	A2
EQUIP. LOCATION	10-04	10-09	10-14	10-19	10-24	10-29	10-34	10-38	10-42
CONV. OUTPUT DESIG.	+3V PM058A	+3V PM058E	+5V PM061A	+3V PM062C	+3V PM062A	+5V PM061B	+3V PM062B	+3V PM058F	+3V PM058C
+24V fuse	AA11	AA10, AA6	AA6	AA6	AA6	AA4	AA4	AA4	AA4
-48V fuse	A0	A3	A3	A3	A3	A4	A4	A4	A4
EQUIP. LOCATION	06-05	06-09	06-14	06-19	06-24	06-29	06-34	06-38	06-42
CONV. OUTPUT DESIG.	+5V PM039A	+3V PM058B							
+24V fuse	AA10	AA10							
-48V fuse	A0	A0							
EQUIP. LOCATION	02-05	02-09							

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	540

REPLACE DEFECTIVE CONVERTER IN PROCESSOR FRAME

On TLTP:

[1] Set PD TRIPLET to ABC

[2] Set STATE CONTROL keys to A \bar{B} \bar{C}

[3] Depress EXECUTE

[4] Set VM1 key

[5] Set 20K key

[6] Set GRD key

[7] Set STATE CONTROL keys to A B \bar{C}

[8] Depress EXECUTE

Circuit placed in Minimum Leakage Resistance State

Voltmeter indicates between 9.5 and 11 volts on 24V scale

Voltmeter indicates between 14 and 16.3 volts on 24-volt scale


Minimum resistance level checked

Circuit placed in Maximum Leakage Resistance State and resistance level checked

Page 2

TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 13	541



TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 13	541

ON TLTP:

[15] Set STATE CONTROL keys \bar{A} \bar{B} \bar{C}

[16] Depress EXECUTE

[17] Set VM1 key

[18] Set TRR key

[19] Set STATE CONTROL keys \bar{A} \bar{B} \bar{C}

[20] Observe voltmeter
and depress EXECUTE

Voltmeter indicates
a capacitor discharge
(a slight deflection)

AND

Circuit placed in
Ring on Tip State
and path tested

On TLTP:

[21] Release VM1 key

[22] Release TRR key

[23] Set STATE CONTROL keys to A \bar{B} C


[24] Depress EXECUTE

AND

Circuit
placed in
Trip Test
State

Page 4


Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 13	541



TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 13	541


On TLTP:



TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT


Issue 3	AUG 1984
233-142-100	DLP
PAGE 5 of 13	541

On TLTP:




TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 6 of 13	541



TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 7 of 13	541



TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 8 of 13	541

On TLTP:

[70] Set STATE CONTROL
keys to \bar{A} \bar{B} \bar{C}

[71] Depress EXECUTE

[72] Release FEMF key

[73] Set 1K key

Voltmeter indicates
approximately 7.8
volts on 24V scale

[74] Set STATE CONTROL
keys to A \bar{B} \bar{C}

[75] Depress EXECUTE

[76] Release 1K key

[77] Set FEMF key

Voltmeter indicates
approximately 5.8
volts on 24V scale

Voltmeter indicates 0

Coin Plus
Voltage
State set up
and tested

Coin Relay
Nonoperate
State set up
and tested

Page 10

TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 9 of 13	541

On TLTP:

[78] Set STATE CONTROL
keys to A B \bar{C}

[79] Depress EXECUTE → Voltmeter indicates
50 volts on 120V scale

[80] Set TRR key

[81] Release FEMF key → Voltmeter indicates
between 97 and 100
volts on 120V scale

[82] Set STATE CONTROL
keys to \bar{A} B \bar{C}

[83] Depress EXECUTE

[84] Set FEMF key

[85] Release TRR key → Voltmeter indicates
between 50 and 52
volts on 120V scale

Coin Relay
Operate
State set up
and tested

AND


Coin Minus
Voltage State
set up and
tested

AND


Page 11

TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 10 of 13	541




Issue 3	AUG 1984
233-142-100	DLP
PAGE 11 of 13	541




Issue 3	AUG 1984
233-142-100	DLP
PAGE 12 of 13	541

TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT



TEST OPERATION OF LOOP ENVIRONMENT TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 13 of 13	541



MC TTY indicates
 tt EX NW ATP
 tt = minutes of hour


[3] See NOTE 1. On MC TTY type
 EX:NW;UCL!

[4] On MC TTY type
 SW:SYC!


[5] On MC TTY type
 EX:NW,JSW;UCL!

MC TTY indicates
 tt EX NW ATP
 tt = minutes of hour

NOTE 1	
All equipped concentrator groups (1-15) are exercised. Running time exceeds 30 minutes for each concentrator group	
WARNING 1	
<i>Equipment damage may occur unless unassigned lines are loop start</i>	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	542



CAUTION 1	
<i>Contact contamination may occur unless circuit pack is handled only by the edges</i>	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 4	543




NOTE 1	
A CU is OOS when either the CU or peripheral controller (SC, NWC, PPD and/or FIOC) are removed from service. A CU is UAV when any of the above have power removed or LOCK and/or FORCE SELECT are lighted	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 4	543

REPLACE CIRCUIT PACK IN PROCESSOR FRAME


[14] See CAUTION 2. Determine which side appears to be on-line _____

[15] Open the off-line 3A Control Panel and set TEST MODE key located on rear side of panel door to TEST _____




CAUTION 2	
<i>This procedure may result in system initialization if off-line 3A CC cannot be determined. If possible, perform during low traffic periods</i>	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 4	543

REPLACE CIRCUIT PACK IN PROCESSOR FRAME




REPLACE CIRCUIT PACK IN PROCESSOR FRAME

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 4	543




NOTE 1
Variables c and s are both 1 if SYC 1 is marked standby, or are both 0 if SYC 0 is marked standby on the SSP

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	544



RUN MAJOR CONTROL UNITS DIAGNOSTICS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	544



CAUTION 1	
<i>Contact contamination may occur unless circuit pack is handled only by the edges</i>	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	545

REPLACE CIRCUIT PACK IN MAINTENANCE FRAME

SUMMARY

This test must be run for a minimum period of 24 consecutive hours at a call volume of at least 500 calls per hour, per network frame (may be waived for offices not equipped with enough service circuits). Investigate and resolve all maintenance TTY printouts that occur during test procedure.

No more than 1 in 10,000 calls should fail to complete during test interval. The number of troubles which indicate a failure to complete shall not exceed 5 in 10,000 calls. If trouble or major alarms disrupt this test, restart test.

TABLE A

CONDITION	RESULT
Calling Rate	At least 500 calls per hour, per network frame
Failure Rate	1 failure to complete in 10,000 calls
Malfunctions, (does not indicate a failure to complete)	5 in 10,000 Calls

[1] See NOTE 1. Verify that installation group performs this test within two weeks of turnover date _____

[2] Verify generic program issue is one that office will be cut into service with and that all overwrites have been installed _____

[3] See NOTE 2. Using Speed Call 8 load boxes, maintain a call volume of at least 500 calls per hour, per network frame for a minimum of 2 hours _____

[4] Verify that test is run for 24 consecutive hours without major alarm or trouble causing interruption _____

[5] Investigate and resolve all Maintenance TTY printouts for test period and compare results to TABLE A _____

AND

[6] Are requirements met

Yes

No

[7] Verify that installation group corrects troubles and reruns tests


NOTES

1. The system should be in a trouble-free state before starting this test. If trouble or major alarm disrupts test, then test must be restarted
2. The call volume of 500 calls per hour, per network frame, may be reduced if office is not equipped with enough service circuits to handle the 500 call rate

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	546

OBSERVE PROCEDURES AND RESULTS OF INTEGRATED VOLUME TESTS

On SSP:



RUN DIAGNOSTICS ON TAPE DATA CONTROL UNITS 0 AND 1

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	547

[1] At System Status Panel
verify **SYSTEM NORMAL**
lamp is on

[2] At TTY type
ALW:OW!

ALW OW COMPL

AND

Page 2

[3] At TTY type
OP:OWFILE!
See NOTE 1

See TABLE A
for TTY
response

CHECK PATCH STATUS

TABLE A


```

SO-2 Generic Response
++ OP OWFILE
GENID xxxxxxxx
ISSID zzzzzzzz
OW nnnnn s mmdd yyhh nsss
.
.
.
OW nnnnn s mmdd yyhh nsss
OP OWFILE COMPL
Or for 3E3
And later Generic Response
++ OP OWFILE aa
GENID xxxxxxxx
ISSID zzzzzzzz
OW nnnnn s mmdd yyhh type
.
.
.
OW nnnnn s mmdd yyhh type
CURR cur LENGTH len
OP OWFILE COMPL
Where: (for both generics)
nnnnn = overwrite number
s      = overwrite status
        0 = inactive
        1 = active
        3 = dead
  
```

NOTE 1

It may take up to
10 minutes to obtain
TTY printout

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	548



CHECK PATCH STATUS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	548

At TTY type:

[1] ALW:OW!

[2] OP:HASH:GENERIC!
[NOTE 1]

OP HASH HHHHHH NNNNN

[3] OP:HASH:TRNSLN!
[NOTE 1]

OP HASH HHHHHH NNNNN

[4] OP:HASHNR: SEG!
[NOTE 1]

OP HASH SS NNNNN

[5] Obtain the latest
Broadcast Warning Message
(BWM) and locate the MOD
values

AND

[6] Do generic hashsum
[NNNNN] values printed
match MOD values published
for the latest BWM
installed in machine

No

TAP-104

Yes

[7] Record generic and translation
hashsum [NNNNN] values for each
address for future references

AND

[8] At TTY type STOP:OW!

NOTE 1
HHHHHH is the
generic or
translation hashsum
address
NNNNN is the
generic or
translation hashsum
value in decimal
SS is SEG number

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	549

**VERIFY HASHSUM VALUES USING BROADCAST WARNING
MESSAGE FOR OFFICES WITH 3E3 GENERIC OR LATER**





TABLE A	
CIRCUIT	TLM
Regular Ringing - SD-3H410-01	TLM 3H110-01
Dial Pulse Transmitter - SD-3H403-01	TLM 3H110-01
Coin Control - SD-3H411-01	TLM 3H110-01
Tone and Recorded Announcement - SD-3H110-01	TLM 3H110-01
Touch-Tone calling Detector - SD-3H401-01	TLM 3H111-01
Customer Dial Pulse Receiver - SD-3H410-01	TLM 3H111-01
Superimposed Ringing - SD-3H406-01	TLM 3H112-01
Multifrequency Receiver - SD-3H402-01	TLM 3H113-01
Multifrequency Transmitter - SD-3H404-01	TLM 3H114-01

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	550



**PERFORM OFF-LINE BOOTSTRAP FOR OFFICES WITH
3E3 GENERIC OR LATER**

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	551

At TTY type:

[1] ALW:OW!

[2] OP:HASH:GENERIC!
[NOTE 1]

OP HASH HHHHHH NNNNN

[3] OP:HASH:TRNSLN!
[NOTE 1]

OP HASH HHHHHH NNNNN

[4] OP:HASHNR:SEG
[NOTE 1]

OP HASH SS NNNNN

AND

[5] Do hashsum
[NNNNN] values printed
match previous values
obtained for each
address

No


Page 2

Yes

[6] At TTY
type
STOP:OW!

NOTE 1	
HHHHH is the generic or translation hashsum address	
NNNNN is the generic or translation hashsum value in decimal	
SS is SEG number	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	552

**VERIFY HASHSUM VALUES USING PREVIOUS VALUES
FOR OFFICES WITH 3E3 GENERIC OR LATER**



**VERIFY HASHSUM VALUES USING PREVIOUS VALUES
FOR OFFICES WITH 3E3 GENERIC OR LATER**

NOTE 2	
Mismatch may be due to customer-initiated recent changes (changing call forwarding and/or speed calling list)	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	552

[1] Read CAUTION 1. Obtain circuit packs listed in TLM _____

[2] Depress on-line POWER if not lighted _____

[3] Depress MANUAL on both controllers _____

[4] Set TEST MODE key to TEST (up) position on both controllers _____

[5] Depress LOCK if not lighted _____



On On-Line Controller: [FIG. 1, Page 2]

[6] Set REGISTER SELECT to SPECIAL _____

[7] Set REGISTER LOAD and DISPLAY to up position _____

[8] Set LOAD AND DISPLAY keys 0-19 to up position _____

[9] Set REGISTER SELECT keys 1 and 2 to up position _____

On both Controllers:

[10] Set HALT key to up position _____



Page 3

CAUTION 1
On-line circuit packs cannot be replaced without causing a service loss. Replace only during low traffic periods if possible

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 4	553

REPLACE CIRCUIT PACK IN ON-LINE (ACTIVE) CONTROL UNIT




FIG. 1 - 3A CC Control Keys

REPLACE CIRCUIT PACK IN ON-LINE (ACTIVE) CONTROL UNIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 4	553

[11] On off-line 3A CC momentarily set **EXECUTE** key to up position

[12] Read CAUTION 2. On on-line 3A CC momentarily set **EXECUTE** key to up position

Call processing stopped; on-line 3A CC SAR set to octal 3777777

AND

On On-Line 3A CC:

[13] Read NOTE 1. Depress and hold **RESET CIRCUITS** key

[14] Remove faulty circuit pack

[15] Install replacement circuit pack

[16] Release **RESET CIRCUITS** key

AND

Page 4

NOTE 1 Power is not removed and RESET CIRCUITS key is held while circuit pack is changed	
CAUTION 2 <i>This step will stop call processing (PANEL TIMEOUT) for remainder of procedure</i>	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 4	553

REPLACE CIRCUIT PACK IN ON-LINE (ACTIVE) CONTROL UNIT

At both 3A CCs:

[17] Set **MALT** keys to down position

[18] Momentarily set **EXECUTE** keys to up position

[19] Set **TEST MODE** keys to down position

[20] Depress **MANUAL** keys

MANUAL
extinguishes

[21] Set all panel keys to down position

[22] Depress **LOCK**

AND

```
graph LR; I1[ ] --> AND((AND)); I2[ ] --> AND; I3[ ] --> AND; I4((MANUAL extinguishes)) --> AND; I5[ ] --> AND; AND --- OUT[ ]
```

REPLACE CIRCUIT PACK IN ON-LINE (ACTIVE) CONTROL UNIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 4	553






FIG. 1


CHECK MAGNETIC HEAD FOR WEAR

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	554



NOTE 1	
HHHHHH is the generic or translation hashsum address	
NNNNN is the hashsum value in decimal	
ident is the segment number or track of the nonresident hashsum	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	555

VERIFY ALL HASHSUM VALUES



NOTE 2	
HHHHHH is the hashsum address	
hashtp is the hashsum value stored in the CHECKSUM file	
hashmas is the hashsum computed from on-line main store	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	555

VERIFY ALL HASHSUM VALUES

[1] At TTY type
RMV:TTYC 1!

[2] Disconnect TTY plug from
TTYC 1, port 0 [FIG. 1
and 2]

[3] Connect TTY plug to
TTYC 0, port 0
[FIG. 1 and 2]

[4] At System Status Panel,
depress TTY INIT key

AND




FIG. 1 - Typical TTYC Layout

**SWITCH LOCAL TELETYPEWRITER FROM BACKUP TTY CONTROLLER (TTYC 1)
TO MAINTENANCE TTY CONTROLLER (TTYC 0) FOR 43A TYPE TTY**

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	556




FIG. 2

**SWITCH LOCAL TELETYPEWRITER FROM BACKUP TTY CONTROLLER (TTYC 1)
TO MAINTENANCE TTY CONTROLLER (TTYC 0) FOR 43A TYPE TTY**

[1] Obtain 553A tool
or equivalent _____

[2] Using 553A tool,
remove LED(s) by
pulling away from
base _____

[3] Replace LED(s)
per TABLE A _____






TABLE A	
LED COLOR	TYPE
Green	534E
Amber	534F
Red	534D

REPLACE LIGHT EMITTING DIODE (LED)



REPLACE SSP LAMP

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	558



REPLACE RECORDED ANNOUNCEMENT SET

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	559

[1] Pivot magnetic head away from band and lock against carriage with head-retaining spring [FIG. 1]

[2] Remove flat drive belt from drum pulley

[3] Moisten cloth with cleaner

[4] See CAUTION 1. Clean surface of magnetic head and recording band (the drum may be rotated to facilitate cleaning)

[5] Using clean cloth, rub magnetic head and recording band until surface is dry and polished

Recording area is clean

[6] Wipe dust and/or cleaner from other parts of mechanism with dry cloth [FIG. 2]

[7] Return flat drive belt to drum pulley

[8] Release head lock and return magnetic head to position against recording drum




FIG. 1




FIG. 2

CAUTION 1
Equipment damage may occur if cleaner gets on any part other than the part being cleaned

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	560

CLEAN THE RECORDED ANNOUNCEMENT SET





FIG. 1 - L3 Recorder (Front View)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	561






FIG. 1 - L3 Recorder (Rear View)

CHECK DRIVE BELTS


Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	562



CHECK RECORDED ANNOUNCEMENT SET FOR CLARITY

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	563

[1] At announcement set jacks J3 and J4, install 52-type telephone head set



MAKE NEW RECORDING OF ANNOUNCEMENT AT 7A ANNOUNCEMENT SET

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	564

SUMMARY

If more than two nights are required for automatic system diagnostics to test trunks, junctors, and service circuits, the RC:OFFICE message must be input to change the testing rate. Observe the nightly routine printouts to verify if

every circuit installed (CU, TAPE, FIOC, SC, NWC, PPD, RT, test circuits, service circuits, and junctors) that is not service-busy has successfully passed diagnostics. The results should indicate ATP (All Tests Pass) on each circuit tested.




TABLE A	
MESSAGE	VARIABLE FIELD
RC:OFFICE/ JC n/ SVC n/ TRK n/ END!	n = A 1-digit number (1 through 5) that specifies the testing rate of circuit diagnostics

[4] Using TTY printouts of nightly routine and Form ESS 3201-1, verify that all service groups have been tested

[5] See NOTE 1. Using at least two days TTY printouts, verify that messages in TABLES B and C were received




TABLE B	
DGN CU a COMPL ATP	
DGN TAPE a ATP	
DGN FIOC a ATP	
DGN SC a ATP	
DGN NWC a ATP	
DGN PPD a ATP	
DGN RT a ATP	
DGN SVC g n ATP	
DGN TRUNK g b ATP	
DGN JC f n ATP	
DGN TV TC n ATP	
a = side 0 or 1	
b = member number	
n = number of circuit	
g = group number	
f = network frame number	

TABLE C
OP: DATA COMPL
SOFTWARE MESSAGE REGISTERS
EX NW COMPL ATP
OP HASH COMPL
AUDIT TAPE MATCH 0
TST LINE COMPL

NOTE 1	
Diagnostics will be run on side 0 one night and on side 1 on alternate nights. A minimum of two nights diagnostics will be required for checking results. Tests on service group for test circuits will be run every night	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	565

[1] Connect 22A meter to 600 ohm
OUTPUT jack on generator

[2] See NOTE 1. Set 22A meter
FUNCTION switch to 600 and
REFERENCE LEVEL switch to 0



[3] Does meter
indicate between
red lines on
scale (-0.03 to
+0.03 dBm)

Yes

[7] Set
meter
FUNCTION
switch to
OFF

[8] Disconnect
cord
assembly

[4] Remove
generator
cover

[5] Adjust MW
ADJ so meter
indicates between
red lines on
scale (-0.03 to
+0.03 dBm)

[6] Replace
generator
cover

NOTE 1
22A meter must be
calibrated and
used in the
horizontal position.
It must be
calibrated every
15 minutes while
in use

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	566

CALIBRATE MILLIWATT REFERENCE GENERATOR

[1] At 23CR Transmission
Measuring Set on TLTP
set ADD DBM to 0

[2] At TLTP set CAL

AND

[3] Does 23CR
meter indicate
exactly 0 dBm

Yes

[5] Set ADD
DBM to +5

No

[4] Adjust CAL
1 to obtain
0 dBm on meter

[6] Does 23CR
meter indicate
exactly -5 dBm

No

[7] Adjust
CAL 2 to
obtain -5 dBm
on meter

Yes


[8] Repeat Steps
1 thru 7 until
no adjustments
are required

[9] At TLTP
release
CAL

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	567


SUMMARY

Send 1000 Hz at 0 DBM and have distant office measure level and adjust if necessary. With the distant office sending 1000 Hz, use a 23-type TMS to measure the level. The level should be adjusted to within 0.5 dB of the Expected Measured Loss (EML) specified on the circuit layout card.



MEASURE 1000 HZ TRANSMISSION LEVELS (CIRCUIT NET LOSS)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	568



MEASURE 1000 HZ TRANSMISSION LEVELS (CIRCUIT NET LOSS)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	568

[1] Connect KS-19353, L1 oscillator output jacks to TM1 jack on TLTP writing shelf

[2] Adjust oscillator frequency output to 400 Hz, 0 dB and have distant office record level


[3] Adjust oscillator frequency output to 2800 Hz, 0 dB and have distant office record level

[4] On TLTP set **REVERSE ACCESS TRUNKS**

[5] Use TMS provided at TLTP or connect portable 23A TMS to TM2 writing shelf

[6] Have distant office send 400 Hz at 0 dB then measure and record level of tone

[7] Have distant office send 2800 Hz at 0 dB then measure and record level of tone



MAKE GAIN-SLOPE MEASUREMENTS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	569




TABLE A		
GAIN-SLOPE DEVIATION RELATIVE TO 1000 HZ*		
TYPE OF FACILITY	400 Hz	2800 Hz
N1 Carrier	Within 1.5 db more and 1.0 db less loss	Within 3.0 db more and 1.0 db less loss
N2 Carrier	Within 1.5 db more and 1.0 db less loss	Within 2.0 db more and 1.0 db less loss
N3 Carrier	Within 2.0 db more and 1.0 db less loss	Within 1.5 db more and 1.0 db less loss
O, ON Carrier	Within 2.0 db more and 1.0 db less loss	Within 2.5 db more and 1.0 db less loss
D1, D2, D3 Channel Bank	Within 2.0 db more and 1.0 db less loss	Within 2.0 db more and 1.0 db less loss
E Repeated Trunks	Within 4.0 db more and 1.5 db less loss	Within 4.5 db more and 1.0 db less loss
Repeated Cable	Within 2.0 db more and 1.5 db less loss	Within 3.0 db more and 2.5 db less loss
	Within 3.0 db more and 1.0 db less loss	Within 4.5 db more and 1.0 db less loss

* On combination trunks, the total gain slope deviation is the sum of the various facilities

[1] Connect 3A Noise Measuring Test Set IN jack or IN binding posts to TM1 jack on TLTP writing shelf

[2] Connect 723A receiver into AC MON jack on 3A Noise Measuring Test Set

[3] Have distant office terminate the circuit in proper termination [600 or 900 ohms] for their office

[4] Set FUNCTION to NM 900

[5] Rotate DBRN counterclockwise until meter indicates between +2 and +9 and observe for 10 to 30 seconds. See NOTE 1

[6] Observe point where needle appears most of the time and add reading to setting of DBRN

[7] Listen to noise on 723A receiver and record type (atmospheric static, switching-type noise, etc)



Page 2

NOTE 1
When measuring rapidly fluctuating noise, the **DAMP** setting may be used. Read only the maximum of the most frequently occurring peaks in this position.

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	570

MAKE NOISE LEVEL MEASUREMENTS




TABLE A	
TYPE OF WORK	VOICE FREQUENCY C-MESSAGE WEIGHTING DBRNC LIMITS
Circuit Order	See noise requirement on circuit layout card. Use first number in the code. Example: <u>28</u> C36
Routine Maintenance	See noise requirement on circuit layout card. Use second number in code. Example: 28C <u>36</u>


Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	570

MAKE NOISE LEVEL MEASUREMENTS

[1] Connect clip leads to FB527 terminal 016

[2] Connect 900 ohm resistor per FIG. 1

[3] Connect oscilloscope per FIG. 1



Page 2




FIG. 1

TEST OPERATION OF TOUCH-TONE RECEIVER TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 5	571

At TLTP:

[4] Set associated junctor
to NO

[5] Set PD TRIPLET
to ABC

[6] Set STATE CONTROL
to $\bar{A} \bar{B} \bar{C}$

[7] Depress EXECUTE

[8] Set PD TRIPLET to DEF

[9] Depress EXECUTE

[10] Set PD TRIPLET to GHJ

[11] Depress EXECUTE

[12] Set PD TRIPLET to KLM


[13] Set STATE CONTROL to $\bar{A} \bar{B} C$

[14] Depress EXECUTE

[15] Set PD TRIPLET to ABC


[16] Set STATE CONTROL to A B C

[17] Depress RING key




TEST OPERATION OF TOUCH-TONE RECEIVER TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 5	571



TEST OPERATION OF TOUCH-TONE RECEIVER TEST CIRCUIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 5	571



Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 5	571

TEST OPERATION OF TOUCH-TONE RECEIVER TEST CIRCUIT








FIG. 2 - Scope Settings
 .5V/DIV .5MS/DIV



Issue 3	AUG 1984
233-142-100	DLP
PAGE 5 of 5	571

TEST OPERATION OF TOUCH-TONE RECEIVER TEST CIRCUIT

[1] Select and record in TABLE A the directory numbers and office equipment (OE) numbers for lines used in this test [NOTE 1]

[2] Install resistances at resistor test locations on distributing frame [TABLE A]

[3] For first line in TABLE A, at TTY, type in SRG test message for 80K range [NOTE 2, Page 2]

Page 2


**TABLE A
SRG TEST DATA**

L* I N E S	DIRECTORY NUMBER	OFFICE EQPT NUMBER					RESISTOR VALUE	RESISTOR TEST LOCATION *	EXPECTED FAILURE SEVERITY NUMBER		
		CONC GRP	CONC	SW GRP	SW	LEV			RANGE SPECIFIED ON INPUT		
									80K	320K	2.56M
GS1											
TL1						470K	R to G				
TL2						10K	R to G	7	7	7	
TL3						30K	R to G	3	7	7	
TL4						62K	R to G	1	7	7	
TL5						120K	R to G		3	7	
CL1						240K	R to G		1	7	
CL2						470K	R to G			7	
CL3						910K	R to G			3	
CL4						1.8M	R to G			1	
CL5						3.0M	R to G				
CL6						10K	T to G				
CL7						62K	T to G				
CL8						120K	T to G				
CL9						470K	T to G				
CL10						30K	T to R	3	7	7	
						62K	T to G	1	7	7	

* GS = Ground start line
 TL = Loop start test line
 CL = Loop start customer line
 R = Ring
 T = Tip
 G = Ground

NOTE 1
 After selection of lines, directory numbers and office equipment numbers can be found in office records

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	572



NOTES	
2. SRG test message: TST:LINE a bcde 1 g! a bcde = OE number g = Test Range (80K, 320K, or 2.56M)	
3. Responses to SRG test message: tt TST LINE a bcde TN f g ERR 0 or tt TST LINE a bcde TN f g COMPL a bcde = OE number f = Directory number g = Severity number or (in 3E3 Generic only) tt TST LINE a bcde TN f g ABT h a bcde = OE number f = Directory number g = Test and Range h = Reason for Abort	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	572

VERIFY ALIT SHORT OR RING TO GROUND (SRG) TEST CAPABILITY

[1] Record in TABLE A the directory numbers and office equipment (OE) numbers for lines used in SRG test [DLP-572]


[2] Verify that test resistors have been installed at test locations [TABLE A]

Page 2

TABLE A
TRG TEST DATA

L I N E S	DIRECTORY NUMBER	OFFICE EQPT NUMBER					RESISTOR VALUE	RESISTOR TEST LOCATION *	EXPECTED FAILURE SEVERITY NUMBER		
		CONC GRP	CONC	SW GRP	SW	LEV			RANGE SPECIFIED ON INPUT		
									80K	320K	2.56M
GS1						470K	R to G				
TL4						120K	R to G		3	7	
TL5						240K	R to G		1	7	
CL1						470K	R to G			7	
CL2						910K	R to G			3	
CL3						1.8M	R to G			1	
CL4						3.0M	R to G				
CL6						62K	T to G	1	7	7	
CL7						120K	T to G		3	7	
CL8						470K	T to G			7	
CL10						62K	T to R				

* GS - Ground start line
 TL - Loop start test line
 CL - Loop start customer line
 R - Ring
 T - Tip
 G - Ground



NOTES	
1. TRG test message: TST:LINE a bcde 2 g!	
a bcde = OE number	
g = Test Range (80K, 320K, or 2.56M)	
2. Responses to TRG test message	
tt TST LINE a bcde	
TN f g ERR 1 or	
tt TST LINE a bcde	
TN f g COMPL	
a bcde = OE number	
f = Directory number	
g = Severity number or (in 3E3 Generic only)	
tt TST LINE a bcde	
TN f g ABT h	
a bcde = OE number	
f = Directory number	
g = Test and Range	
h = Reason for abort	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	573

VERIFY ALIT TIP OR RING TO GROUND (TRG) TEST CAPABILITY


[1] Record in TABLE A directory numbers and office equipment (OE) numbers for lines used in SRG test [DLP-572]

[2] Change resistor locations as shown in TABLE A

Page 2

TABLE A FEMF TEST DATA										
L* I N E S	DIRECTORY NUMBER	OFFICE EQPT NUMBER					RESISTOR VALUE	RESISTOR TEST LOCATION *	EXPECTED FAILURE SEVERITY NUMBER	
		CONC GRP	CONC	SW GRP	SW	LEV			RANGE SPECIFIED ON INPUT	
										320K
GS1							470K	R to G		
TL3							62K	R to -48V	7	
TL4							120K	R to -48V	3	
TL5							240K	R to -48V	1	
CL5							10K	T to G		
CL9							30K	T to -48V	7	
CL10							62K	T to -48V	7	

* GS - Ground start line
 TL - Loop start test line
 CL - Loop start customer line
 R - Ring
 T - Tip
 G - Ground



NOTES	
1. FEMF test message: TST:LINE a bcde 4 g! a bcde = OE number g = Test Range (80K, 320K, or 2.56M)	
2. Responses to FEMF message: tt TST LINE a bcde TN f g ERR 2 or tt TST LINE a bcde TN f g COMPL a bcde = OE number f = Directory number g = Severity number or (in 3E3 Generic only) tt TST LINE a bcde TN f g ABT h a bcde = OE number f = Directory number g = Test and Range h = Reason for abort	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	574



[1] Connect one cord from
ACCESS TRK 1 jack on
TLTP to **TRK 1 - TRK**
jack on test set

[2] Connect one cord from
BAT jack on test set
to -48 volt battery
jack on test power
supply panel

[3] Connect headset to
TRK 1 - TST FAC
jack on test set


[4] Set **ALL KEYS** to
OFF position

[5] Set **TRK - TR** switch
to position 1




Page 2

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	575



CONDITION J94742A TEST SET

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	575



RELEASE J94742A TEST SET FROM TLTP

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	576

[1] Connect E-Z hooks [FIG. 1] to meter leads

[2] Set meter to RX1 scale

[3] See NOTE 1.
Momentarily connect E-Z hooks to Master Scanner terminals, row 26H,L column 12

[4] On System Status Panel (SSP), depress ALARM RELEASE key





TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR and MAJOR POWER lighted	TAP-112
TTY	tt REPT MISCA 26 12 OFN	TAP-113


NOTE 1
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	577



NOTE 1	
On some SSP vintages, the NRP ACT lamp may be labeled as SPARE	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	578

ACTIVATE TRUNK AND LINE TEST PANEL (TLTP) IN OFFICE WITH SO-2 GENERIC



SET UP TRUNK AND LINE TEST PANEL (TLTP) FOR TESTING

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	579

TABLE A						
ASSIGNED DIALING CODES						
TYPE OF CIRCUIT	KEYING FORMAT					
Trunk Circuit	1	TGN	MEMN	#		
Trunk Circuit With Outpulsing	1	TGN	MEMN	*	Wait for dial tone	Dial digits # to be outpulsed
Service and Test Circuits	1	TGN	MEMN	#		
Service Circuit With More Than One Port	1	TGN	MEMN	Number of port to be tested (0,1 or 2)	#	
Tone and Announcement Circuit	1	TGN	MEMN	#		
Subscriber Line	2	Directory Number		#		
Junctor	3	CGN	JSN	#		
Trunk to #5 XBAR ACD (with/without SF units)	6	TGN	MEMN	*	Wait for dial tone	1/0 [†] #
	TGN	Trunk Group Number		3 Digits	Prefix with zeros if necessary	
	MEMN	Member Number		3 Digits		
	CGN	Concentrator Group Number		2 Digits		
	JSN	Junctor Switch Number		2 Digits		
	*	Eleventh Button on Touch-Tone Pad				
	#	Twelfth Button on Touch-Tone Pad				
	[†] : 1 = with SF Unit 0 = without SF Unit					




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR and MAJOR POWER lighted	TAP-112
TTY	tt REPT MISCA 25 12 OFN	TAP-113

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	580




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR lighted	TAP-112
TTY	tt REPT ALMBATA 21 15 OFN	TAP-113

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	581




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR and FUSE lighted	TAP-112
TTY	tt REPT MISCA 18 2 OFN	TAP-113

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	582

TEST TOLL DISTRIBUTION ALARM

[1] Set VOM to measure 100V dc (KS-14510 or equivalent)

[2] Insert black VOM test lead (-) into rectifier COM jack [FIG. 1]

[3] Insert red VOM test lead (+) into rectifier +100V jack [FIG. 1]









FIG. 1

CHECK AND ADJUST KS-19412 RECTIFIER OUTPUT VOLTAGES

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	583

[8] Leave black VOM test lead (-) in rectifier COM jack

[9] Check +20V, +116V, and +200V test voltages by placing the red VOM test lead (+) in the appropriate jack [TABLE A]

[12] Move red VOM test lead (+) to rectifier COM jack

[13] Move black VOM test lead (-) to rectifier -116V jack






TABLE A	
VOLTAGE	REQUIREMENTS
+20	19.6 to 20.4 volts
+116	116 to 130 volts
+200	200 to 225 volts


CHECK AND ADJUST KS-19412 RECTIFIER OUTPUT VOLTAGES





NOTE 1	
Switch is located on back of panel. Switch arm must be pulled out before it can be moved	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	585

TEST CONTROL UNIT STATUS FUNCTIONS AND INDICATORS



Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	585

At Not Active 3A Central Control Panel:

- [1] Verify all switches except HALT key are in down position
- [2] At REGISTER section, set LOAD and DISPLAY switches to up position
- [3] Set LOAD AND DISPLAY switches 0 through 19 to up position
- [4] At REGISTER SELECT area select register to be tested [NOTE 1, TABLE A]
- [5] Momentarily set EXECUTE switch to up position





TABLE A	
REGISTER SELECTED	REGISTER SELECT SWITCHES IN UP POSITION
0	NONE
1	1
2	2
3	1, 2
4	4
5	4, 1
6	4, 2
7	4, 2, 1
8	8
9	8, 1
10	8, 2
11	8, 2, 1
12	8, 4
13	8, 4, 1
14	8, 4, 2
15	8, 4, 2, 1


NOTE 1	
Starting with register 0, all registers through 15 are tested one at a time	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	586

TEST LOADING AND DISPLAYING OF REGISTERS



NOTE 2	
Starting with register 15, all registers through 0 are tested	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	586

TEST LOADING AND DISPLAYING OF REGISTERS



TEST COMPARE INDICATOR

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	587

At Not Active 3A CC Panel:

[1] Verify all switches are in down position except HALT

[2] Set LOAD switch to up position


[3] Set the following REGISTER SELECT switches to up position SPECIAL-GENERAL, 2 and 1

[4] Momentarily set EXECUTE switch to up position

[5] Set LOAD switch to down position

[6] Set MEMORY DISPLAY switch to up position


[7] Momentarily set EXECUTE switch to up position




Set ST ADRS to 0



Memory location 0 displayed




LOAD AND DISPLAY LEDs PH, PL, 15, 12, 10, and 9 lighted




TEST MEMORY FUNCTIONS AND INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 5	588




TEST MEMORY FUNCTIONS AND INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 5	588




TEST MEMORY FUNCTIONS AND INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 5	588



TEST MEMORY FUNCTIONS AND INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 5	588



At Not Active 3A CC Panel:

[1] Verify all switches are in down position

[2] Set HALT switch to up position

[3] Set REGISTER LOAD and DISPLAY switches to up position

[4] Set ENABLE MANUAL PAR switch to up position

[5] Momentarily set EXECUTE switch to up position

ENABLE MANUAL PAR LED lighted

[6] Set ENABLE MANUAL PAR switch to down position

[7] Momentarily set EXECUTE switch to up position

PH and PL LED lighted



TEST ENABLE MANUAL PARITY FUNCTION AND INDICATOR

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	589

At Not Active 3A CC Panel


[1] Verify all switches are in down position except HALT

[2] Set MEMORY DISPLAY switch to up position

[3] Momentarily set EXECUTE switch to up position

[4] Set MEMORY DISPLAY switch to down position

[5] Momentarily set EXECUTE switch to up position



TEST REJECT FUNCTION AND INDICATOR

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	590

At SSP:

1. Test Step Function as follows:

1.1 Depress **LOCK** key

At Not Active 3A CC Panel:

1.2 Depress **MANUAL** key at **STATUS** section

1.3 Verify that all panel switches except **HALT** are in down position

1.4 At **REGISTER** section, set **LOAD** and **DISPLAY** switches to up position

1.5 At **REGISTER SELECT** section, set **SPECIAL/GENERAL EXTENDED** switch to **SPECIAL** and switch 4 to up position

Response: **SPECIAL** LED lighted
PROG ADRS LED lighted

1.6 At **LOAD AND DISPLAY** section, set switch 5 to up position

1.7 Momentarily operate **EXECUTE** switch

Response: At **LOAD AND DISPLAY** section:
LEDs 5 and PH lighted

1.8 Set all switches except **HALT** to down position

1.9 At **MODE** section, set **STEP** to up position

At TTY:

1.10 Type **DMP:ST 000040!**

Response: **DMP:ST:000040**
a b c d e f g h
a through h = contents of memory

At Not Active 3A CC Panel:

1.11 Momentarily operate **EXECUTE** switch

Response: At **MODE** section:
HALTED LED extinguished momentarily
At **LOAD AND DISPLAY** section:
LEDs lighted corresponding to octal contents of store address 000041 obtained in Step 1.10 (b)

1.12 Momentarily operate **EXECUTE** switch

Response: At **MODE** section:
HALTED LED extinguished momentarily
At **LOAD AND DISPLAY** section:
LEDs lighted corresponding to octal contents of store address 000042 obtained in Step 1.10 (c)

1.13 Set all switches to down position

1.14 Momentarily operate **EXECUTE** switch

1.15 At **STATUS** section, depress **RESET CIRCUITS** key

1.16 At **STATUS** section, depress **MANUAL** to release


At SSP:

1.17 Depress **LOCK** key

End of procedure


TEST STEP FUNCTION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	591



Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	592

RESTORE SYSTEM CONTROLLER TO NORMAL OPERATING CONDITION



DIAGNOSE SYSTEM STATUS PANEL CONTROLLER

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	593




TABLE A	
TTY INIT	MAJOR EQPT LOSS
INIT EXECUTE	MISC
BACKDT OFFICE DATA	AMA
PAST OFFICE DATA	RT
MEMORY RELOAD	PPD
STABLE CALLS	SC
FAIL	NWC
PASS	CU
SERVICE LOSS	FORCED
ALARM CIRCUIT	BLDG
FUSE	DSP
MINOR POWER	OVLD ANN
MAJOR POWER	NRP ACT
MINOR	TDC
MAJOR	TTYC
CRITICAL	SVC LIM
ACTIVE	TRK LIM
STAND BY	0
OUT OF SERVICE	1
UNAVAILABLE	2
ACTIVE	3
STAND BY	•
OUT OF SERVICE	•
UNAVAILABLE	•
EXECUTE	19
ALARM TRFR	20
ALARM RELEASE	21
INHIBIT BUILDING ALARM	22
PANEL TIME OUT	23
SYSTEM NORMAL	

[4] If SYC 1 is active
type SW:SYC!

[5] Depress LOCK  SELECT 0, FORCE, LOCK
and SYC 1 UNAVAILABLE lighted

[6] Depress LOCK

[7] Depress SELECT 0

[8] Depress FORCE  SELECT 0, FORCE,
SYC 1 UNAVAILABLE lighted

[9] Depress FORCE

[10] Depress SELECT 0

[11] Type SW:SYC!

[12] Depress SELECT 1

[13] Depress FORCE  SELECT 1, FORCE,
SYC 0 UNAVAILABLE lighted

[14] Depress FORCE


[15] Depress SELECT 1

AND


AND

TEST SYSTEM STATUS PANEL INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	594



Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	595



TEST PANEL TIMEOUT FUNCTION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	596

[1] See NOTE 1. Using test cord with 300-ohm to 1000-ohm resistor in cord, momentarily connect E-Z hooks to Master Scanner terminals for Building Alarm being tested.

[2] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR Red, BLDG Amber	TAP-112
TTY	tt REPT BLDG row pt OFN	TAP-113

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	597

[1] See NOTE 1. Using test cord with 300-ohm to 1000-ohm resistor in cord, momentarily connect E-Z hooks to Master Scanner terminals, row 16H,L column 9

[2] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Critical Sounding Alarm	TAP-100
SSP	CRITICAL Red, BLDG Amber	TAP-112
TTY	tt REPT BLDG 16 9 OFN	TAP-113

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	598

TEST FIRE ALARMS




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR and FUSE lighted	TAP-112
TTY	tt REPT MISCA 19 1 xxxx OFN	TAP-113

NOTES

1. Use care in connecting Master Scanner terminals. Improper connections cause erroneous results
2. If system does not respond to grounding terminal H, ground terminal L

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	599




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Minor Sounding Alarm	TAP-100
SSP	FUSE and MAJOR lighted	TAP-112
TTY	tt REPT MISCA 19 0 OFN	TAP-113

NOTES	
1. Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
2. If system does not respond to grounding terminal H, ground terminal L	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	600

[1] Connect one end of test cord to any frame ground

[2] See NOTE 1. Momentarily connect E-Z hook to Master Scanner terminal, row 20H column 3. See NOTE 2

[3] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Minor Sounding Alarm	TAP-100
SSP	MINOR and MINOR POWER lighted	TAP-112
TTY	tt REPT MISCA 20 3 OFN	TAP-113

NOTES

1. Use care in connecting Master Scanner terminals. Improper connections cause erroneous results
2. If system does not respond to grounding terminal H, ground terminal L

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	601

[1] Connect one end of test cord to any frame ground

[2] See NOTE 1. Momentarily connect E-Z hook to Master Scanner terminal, row 19H column 2. See NOTE 2

[3] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR and FUSE lighted	TAP-112
TTY	tt REPT MISCA 19 2 OFN	TAP-113

NOTES

1. Use care in connecting Master Scanner terminals. Improper connections cause erroneous results
2. If system does not respond to grounding terminal H, ground terminal L

Issue 3 | AUG 1984

233-142-100 | DLP

PAGE 1 of 1 | **602**

TEST SYSTEM STATUS PANEL FUSE ALARM




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	RT, MAJOR, and MAJOR EQPT LOSS lamp lighted	TAP-112
TTY	tt RMV RT p 0001	TAP-113

NOTES	
1. Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
2. If system does not respond to grounding terminal H, ground the L terminal	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	603




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	RT, MAJOR, and MAJOR EQPT LOSS lamp lighted	TAP-112
TTY	tt RMV RT p 0004	TAP-113

NOTES	
1. Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
2. If system does not respond to grounding terminal H, ground the L terminal	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	604

TEST RINGER VOLTAGE INVERTER ALARM

[1] Connect one end of test cord to any frame ground

[2] See NOTE 1. Momentarily connect E-Z hook to Master Scanner (MS) terminal, row 22H column 4 for plant 0 alarm. See NOTE 2

[3] Observe alarm conditions and record if necessary

[4] On System Status Panel (SSP), depress ALARM RELEASE key

[5] At TTY type RST:RT p;UCL!
p = out-of-service plant




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	RT, MAJOR, and MAJOR EQPT LOSS lamp lighted	TAP-112
TTY	tt RMV RT p 0002	TAP-113

NOTES	
1. Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
2. If system does not respond to grounding terminal H, ground the L terminal	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	605




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	RT, MAJOR, and MAJOR EQPT LOSS lamp lighted	TAP-112
TTY	tt RMV RT p 0010	TAP-113

NOTE 1
 Use care in connecting Master Scanner terminals. Improper connections cause erroneous results

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	606




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	RT, MAJOR, FUSE, and MAJOR EQPT LOSS lamp lighted	TAP-112
TTY	tt RMV RT p 0020	TAP-113

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	607




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	RT, MAJOR, and MAJOR EQPT LOSS lamp lighted	TAP-112
TTY	tt RMV RT p 0040	TAP-113

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	608

TEST AUDIBLE RING ALARM





TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	RT, MAJOR, and MAJOR EQPT LOSS lamp lighted	TAP-112
TTY	tt RMV RT p 0100	TAP-113

NOTE 1
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	609

[1] Remove all CAMA trunks from service using MC TTY message
RMV:TRK aaa,bbb;UCL!
aaa - Trunk group number
bbb - Member number

[2] From an office telephone dial 1 + test number in the CAMA office



MAKE ALL TRUNKS BUSY TEST

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	610




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	RT, MAJOR, and MAJOR EQPT LOSS lamp lighted	TAP-112
TTY	tt RMV RT p 0200	TAP-113

NOTE 1	
Use care in connecting Master Scanner Terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	611

On System Status Panel:

- [1] Depress **ENABLE**
- [2] Depress **INIT EXECUTE**.
See TABLE A
- [3] Wait approximately 1 to 3 minutes for RCOVRY CU message
- [4] Depress **ALARM RELEASE**




TABLE A	
IMMEDIATE RESPONSES	DELAYED RESPONSES (1 to 3 Minutes)
1. Major Audible Alarm 2. SERVICE LOSS LED lights	1. MAJOR EQUIP LOSS lamp lights 2. SYNC () OUT OF SERVICE LED lights 3. CU, NWC, SC, PPD LEDs light 4. SYSTEM NORMAL lamp goes off

NOTE 1
 c = Peripheral control frame number
 s = SYNC or side to be restored
 Offices having two control frames will be required to type RST:PCF message twice to restore both peripheral control frames

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	612

INITIALIZE SYSTEM FROM SSP USING MANUAL TRANSIENT CLEAR




TABLE B
CJ lamp goes off SERVICE LOSS lamp goes off MAJOR EQUIP LOSS lamp goes off SYSTEM NORMAL lamp lights

INITIALIZE SYSTEM FROM SSP USING MANUAL TRANSIENT CLEAR

Issue 3	AUG 19847
233-142-100	DLP
PAGE 2 of 2	612

On System Status Panel:

[1] Depress **ENABLE**

[2] Depress **STABLE CALLS**

[3] Depress **INIT EXECUTE**. See TABLE A for results

[4] Wait approximately 1 to 3 minutes for RCOVRY CU message

[5] Depress **ALARM RELEASE**

AND

[6] Does MC TTY indicate RCOVRY SYNC () STABLE

No

[7] Refer trouble condition to installation group

Yes

[8] On MC TTY type RST:PCF cs;UCL! to restore NWC, SC, and PPD. See NOTE 1

Page 2

TABLE A

IMMEDIATE RESPONSES	DELAYED RESPONSES (Approximately 1 to 3 Minutes)
1. Audible Critical alarm 2. FORCED LED lights 3. SERVICE LOSS LED lights	1. CRITICAL LED lights 2. SYNC () OUT OF SERVICE LED lights 3. MAJOR EQUIP LOSS lamp lights 4. CU, NWC, SC, PPD LEDs light 5. SYSTEM NORMAL lamp goes off

NOTE 1

c = Peripheral control frame number
 s = SYNC or side to be restored
 Offices having two control frames will be required to type RST:PCF message twice to restore both peripheral control frames

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	613

INITIALIZE SYSTEM FROM SSP USING STABLE CLEAR




TABLE B
CU LED goes off
SERVICE LOSS LED goes off
MAJOR EQUIP LOSS lamp goes off
SYSTEM NORMAL lamp lights

NOTES	
2. RST:CU message will automatically cause CU diagnostics to be run, which will require several minutes. When completed, alarm will sound two times	
3. On System Status Panel when CU lamp goes off, CU is in standby state	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	613

On System Status Panel:

- [1] Depress **ENABLE**
- [2] Depress **STABLE CALLS**
- [3] Depress **MEMORY RELOAD**
- [4] Depress **INIT EXECUTE**.
See TABLE A
- [5] Wait approximately 7 to 10 minutes for RCOVRY CU message




TABLE A	
IMMEDIATE RESPONSES	DELAYED RESPONSES (Approximately 3 minutes)
1. FORCED LED lights 2. SERVICE LOSS LED lights 3. CRITICAL LED lights 4. TTY bell rings (on 35ASR model only)	1. Audible alarm changes to major 2. SYNC () OUT OF SERVICE LED lights 3. MAJOR EQUIP LOSS lamp lights 4. CU, NWC, SC, PPD LEDs light 5. SYSTEM NORMAL lamp goes off

Issue 3	AUG 1984
233-142-100	DLP
Page 1 of 2	614

INITIALIZE SYSTEM FROM SSP USING MEMORY RELOAD




TABLE B
SERVICE LOSS LED off MAJOR EQUIP LOSS lamp goes off CU LED goes off SYSTEM NORMAL lamp lights

NOTES	
1. c = Peripheral control frame number	
s = SYNC or side to be restored	
Offices having two control frames will be required to type RST:PCF message twice to restore both peripheral control frames	
Issue 3	AUG 1984
233-142-100	DLP
Page 2 of 2	614

INITIALIZE SYSTEM FROM SSP USING MEMORY RELOAD

On System Status Panel:

[1] Depress **ENABLE**

[2] Depress **STABLE CALLS**

[3] Depress **PAST OFFICE DATA**

[4] Depress **INIT EXECUTE**.
See TABLE A

AND

[5] After approximately 7 to 10 minutes does MC TTY indicate RCOVRY SYNC () STABLE

No

[6] Refer trouble condition to installation group

Yes

[7] On SSP depress **ALARM RELEASE**

No

[8] Check 4th word of MC TTY OP POSTMORT message. Is bit 15 a 1

Yes

Page 2

TABLE A

IMMEDIATE RESPONSES	DELAYED RESPONSES (Approximately 3 minutes)
1. FORCED LED lights 2. SERVICE LOSS LED lights	1. Audible alarm changes to major 2. SYNC () OUT OF SERVICE LED lights 3. CRITICAL LED lights 4. MAJOR EQUIP LOSS lamp lights 5. CU, NWC, SC, PPD LEDs light 6. SYSTEM NORMAL lamp goes off

Issue 3	AUG 1984
233-142-100	DLP
Page 1 of 2	615

INITIALIZE SYSTEM FROM SSP USING PAST OFFICE DATA




TABLE B
SERVICE LOSS LED off
MAJOR EQUIP LOSS lamp goes off
CU LED goes off
SYSTEM NORMAL lamp lights

NOTE	
1. c = Peripheral control frame number	
s = SYNC or side to be restored	
Offices having two control frames will be required to type RST:PCF message twice to restore both peripheral control frames	
Issue 3	AUG 1984
233-142-100	DLP
Page 2 of 2	615

INITIALIZE SYSTEM FROM SSP USING PAST OFFICE DATA

On System Status Panel:

- [1] Depress **ENABLE**
- [2] Depress **STABLE CALLS**
- [3] Depress **BACKDATE OFFICE DATA**
- [4] Depress **INIT EXECUTE**. See TABLE A




TABLE A	
IMMEDIATE RESPONSES	DELAYED RESPONSES (Approximately 3 minutes)
1. FORCED LED lights 2. SERVICE LOSS LED lights	1. Audible alarm changes to major 2. SYNC () OUT OF SERVICE LED lights 3. CRITICAL LED lights 4. MAJOR EQUIP LOSS lamp lights 5. CU, NWC, SC, PPD LEDs light 6. SYSTEM NORMAL lamp goes off

Issue 3	AUG 1984
233-142-100	DLP
Page 1 of 2	616

INITIALIZE SYSTEM FROM SSP USING BACKDATE OFFICE DATA




TABLE B
SERVICE LOSS LED off
MAJOR EQUIP LOSS lamp goes off
CU LED goes off
SYSTEM NORMAL lamp lights

NOTES	
1. c = Peripheral control frame number	
s = SYNC or side to be restored	
Offices having two control frames will be required to type RST:PCF message twice to restore both peripheral control frames	
Issue 3	AUG 1984
233-142-100	DLP
Page 2 of 2	616

INITIALIZE SYSTEM FROM SSP USING BACKDATE OFFICE DATA

On System Status Panel:

[1] Depress **ALARM RELEASE**

At On-Line 3A CC Panel

[2] Open panel door. On back side of panel set **TEST MODE** key in upward position [NOTE 1]

[3] Depress **MANUAL** to activate manual control

[4] Set **MODE** to **HALT**. All other panel keys should be in downward position

[5] Momentarily depress **EXECUTE** key

See TABLE A for system response

At Not Active 3A CC Panel:

[6] Set **TEST MODE** and **HALT** keys to downward position

[7] At SSP depress **ALARM RELEASE**

[8] At Not Active 3A CC panel depress **MANUAL** to release manual condition

AND

AND

Page 2

TABLE A

Active SYC () switched sides
 SYC() OUT OF SERVICE LED lights
 SERVICE LOSS LED lights
 MAJOR EQUIP LOSS lamp lights
 CU LED lights
 CRITICAL alarm LED lights
 CRITICAL audible alarm sounds

NOTE 1

3A CC panel is mounted on hinges and will swing open for access to back side

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	617

INITIALIZE SYSTEM FROM 3A CC PANEL,
PROGRAM TIMER TIMEOUT CHECK




TABLE B
SYC () ACTIVE LED lights SYC () STANDBY LED lights CU LED goes off SERVICE LOSS LED goes off MAJOR EQUIP LOSS lamp goes off

NOTE 2
 RST:CU message will automatically cause CU diagnostics to be run, which will require several minutes. When completed, alarm will sound two times

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	617

**INITIALIZE SYSTEM FROM 3A CC PANEL,
 PROGRAM TIMER TIMEOUT CHECK**

At Off-Line 3A CC Panel

- [1] On back side of panel set TEST MODE key in upward position. [NOTE 1]

On SSP, FORCED LED lights


At On-Line 3A CC Panel

- [2] On back side of panel set TEST MODE key in upward position
- [3] Depress MANUAL
- [4] Set REGISTER SELECT to SPECIAL
- [5] Set REGISTER SELECT, register entry keys 1, 2, and 8 in upward position
- [6] At LOAD and DISPLAY section set 0 in upward position. All others in down position

REGISTER SELECT ERR (11) LED lights

At On-Line 3A CC Panel

- [7] Set REGISTER to both LOAD and DISPLAY
- [8] Set MODE to HALT
- [9] Momentarily operate EXECUTE



**INITIALIZE SYSTEM FROM 3A CC PANEL,
ERROR REGISTER BIT SET CHECK**

NOTE 1	
3A CC panel is mounted on hinges and will swing open for access to back side	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	618





TABLE A
RESPONSES
1. SYC () OUT OF SERVICE LED lights
2. CU LED lights
3. CRITICAL alarm - LED lights
4. SERVICE LOSS LED lights
5. MAJOR EQUIP LOSS lamp lights
6. CU switches active sides
7. TTY NC message responds in approximately 3 minutes
RECOVERY SYC () PART1 or RIM

**INITIALIZE SYSTEM FROM 3A CC PANEL,
ERROR REGISTER BIT SET CHECK**

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	618



**INITIALIZE SYSTEM FROM 3A CC PANEL,
ERROR REGISTER BIT SET CHECK**

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	618




FIG. 1 - Typical TTYC Layout

SWITCH LOCAL TELETYPEWRITER FROM MAINTENANCE (MC) TTY CONTROLLER (TTYC 0) TO BACKUP TTY CONTROLLER (TTYC 1)

NOTE 1	
AR17 interface pack must be removed from any unused port	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 5	619





FIG. 2


SWITCH LOCAL TELETYPEWRITER FROM MAINTENANCE (MC) TTY CONTROLLER (TTY 0) TO BACKUP TTY CONTROLLER (TTYC 1)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 5	619




SWITCH LOCAL TELETYPEWRITER FROM MAINTENANCE (MC) TTY CONTROLLER (TTY 0) TO BACKUP TTY CONTROLLER (TTYC 1)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 5	619



SWITCH LOCAL TELETYPEWRITER FROM MAINTENANCE (MC) TTY CONTROLLER (TTYC 0) TO BACKUP TTY CONTROLLER (TTYC 1)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 5	619



SWITCH LOCAL TELETYPEWRITER FROM MAINTENANCE (MC) TTY CONTROLLER (TTY 0) TO BACKUP TTY CONTROLLER (TTYC 1)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 5 of 5	619

[1] At TTY type: (see FIG. 1)

RC:SP/
TYP CHG/
SP ss RR pp/
ACT ttt/
USERID mm/
ALM n/
CKT n/
END!



[2] Retest alarm which provoked the problem



ENTER RECENT CHANGE ALARM UPDATE

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	620

ESS 3506-1 (02) TG-3

ALARM MONITOR DATA TABLE
NO. 3 ESS

BASE & CONTROL _____
6 11

FORM CODE 80
14 15

ESS UNIT _____

PAGE OF
17

ITEM	SCAN POINT NUMBER			ALARM TYPE							NORMAL CKT. STATE		USER ID	ACTIVE SCAN POINT	REMARKS	REVISE					
	SCANNER	ROW	POINT	CRITICAL	MAJOR	MINOR	MAJOR POWER	MINOR POWER	MAJOR FUSE	MINOR FUSE	ALARM CIRCUIT	OPEN					CLOSED				
18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	
50	0	0	2	6	0	9								√	√			5	2	+24V CONVERTER FAILURE	
51	0	0	2	6	1	0								√	√			5	2	+24V FUSE ALARM	
52	0	0	2	6	1	1								√				2	2	+24V NO POWER ALARM	
53	0	0	2	4	1	1							√					5	6	130V CONVERTER FAILURE	
54	0	0	2	4	1	2							√	√				5	6	130V CONVERTER FUSE ALARM	




FIG. 1 - Translation Guide Form 3506-1

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	620

ENTER RECENT CHANGE ALARM UPDATE

[1] Connect one end of test cord to any ground terminal on control frame

[2] See NOTE 1. Momentarily connect other end of test cord to Master Scanner terminal, row 20H column 12. See NOTE 2

[3] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Minor Sounding Alarm	TAP-100
SSP	MINOR and FUSE lighted	TAP-112
TTY	tt REPT MISCA 20 12 OFN	TAP-113

NOTES	
1. Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
2. If system does not respond to grounding terminal H, ground the L terminal	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	621

TEST FUSE ALARM FOR TRUNKS, JUNCTORS, AND SERVICE CIRCUITS

[1] Connect one end of test cord to any ground terminal on control frame

[2] See NOTE 1. Momentarily connect other end of test cord to Master Scanner terminal, row 20H column 13. See NOTE 2

[3] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Minor Sounding Alarm	TAP-100
SSP	MINOR and FUSE lighted	TAP-112
TTY	tt REPT MISCA 20 13 OFN MAJOR	TAP-113

NOTES

1. Use care in connecting Master Scanner terminals. Improper connections cause erroneous results
2. If system does not respond to grounding terminal H, ground L terminal

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	622

[1] Connect one end of test cord to any ground terminal on control frame

[2] See NOTE 1. Momentarily connect other end of test cord to Master Scanner terminal, row 25H column 11. See NOTE 2

[3] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR and MAJOR POWER lighted	TAP-112
TTY	tt REPT MISLA 25 11 OFN	TAP-113

TEST BATTERY BOOST POWER ALARM

NOTES

- Use care in connecting Master Scanner terminals. Improper connections cause erroneous results
- If system does not respond to grounding H terminal, ground L terminal

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	623

[1] Connect one end of test cord to any ground terminal on control frame

[2] See NOTE 1. Momentarily connect E-Z hook to Master Scanner terminal, row 22L column 9 for Bay Alarm. See NOTE 2

[3] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR lighted	TAP-112
TTY	tt REPT CUOPWR 22 9 OFW	TAP-113

NOTES

- Use care in connecting Master Scanner terminals. Improper connections cause erroneous results
- If system does not respond to grounding L terminal, ground H terminal

Issue 3	AUG 1984
233-142-100	BLP
PAGE 1 of 1	624

TEST BAY 0 MAJOR POWER ALARM

[1] Connect one end of test cord to any ground terminal on control frame

[2] See NOTE 1. Momentarily connect E-Z hook to Master Scanner terminal, row 22L column 10 for Bay Alarm. See NOTE 2

[3] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Minor Sounding Alarm	TAP-100
SSP	MINOR lighted	TAP-112
TTY	tt REPT CUOPWR 22 10 OFN	TAP-113

NOTES	
1. Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
2. If system does not respond to grounding L terminal, ground H terminal	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	625

TEST BAY 0 MINOR POWER ALARM

[1] Connect one end of test cord to any ground terminal on control frame

[2] See NOTE 1. Momentarily connect E-Z hook to Master Scanner terminal, row 24L column 3 for Bay Alarm. See NOTE 2

[3] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR lighted	TAP-112
TTY	tt REPT CU1PMR 24 3 OFN	TAP-113

NOTES

- Use care in connecting Master Scanner terminals. Improper connections cause erroneous results
- If system does not respond to grounding L terminal, ground H terminal

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	626

[1] Connect one end of test cord to any ground terminal on control frame

[2] See NOTE 1. Momentarily connect E-Z hook to Master Scanner terminal, row 24L column 4 for Bay Alarm. See NOTE 2

[3] On System Status Panel (SSP), depress ALARM RELEASE key




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Minor Sounding Alarm	TAP-100
SSP	MINOR lighted	TAP-112
TTY	tt REPT CU1PWR 24 4 OFN	TAP-113

TEST BAY 1 MINOR POWER ALARM

NOTES

- Use care in connecting Master Scanner terminals. Improper connections cause erroneous results
- If system does not respond to grounding L terminal, ground H terminal

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	627

SUMMARY

Increase room temperature no more than 10°F for every hour the test is run, not to exceed 115°F. The test must run for a minimum of 4 hours (2 hours on each CU). Maintain a call volume of at least 500 calls per hour (may be waived if office is not equipped with enough service circuits), per network frame. Observe that off-line duplicated units can

be powered down with no effect on service. Investigate and resolve all maintenance TTY printouts that occur during test period. No more than 1 in 10,000 calls should fail to complete during test interval. The number of troubles which indicate a malfunction but not a failure to complete must not exceed 5 in 10,000 calls.

- [1] Verify that cooling and circulating equipment has been turned off _____
- [2] Measure room temperature 5 feet above floor in center of aisle _____
- [3] Increase room temperature no more than 10°F for every hour test is run, not to exceed 115°F _____
- [4] Observing SERVICE LOSS lamp on SSP, verify that off-line duplicated units can be powered down and up with no effect on service _____
- [5] Verify that all duplicated units are powered up (POWER lamps ON) before testing _____
- [6] See NOTE 1. Using Speed Call 8 Load Boxes, maintain a call volume of at least 500 calls per hour per network frame for a minimum of 2 hours _____
- [7] Force Nightly Routine to run during test period [DLP-529] _____

AND

TABLE A	
CONDITION	RESULT
Calling Rate	At least 500 calls per hour, per network frame
Failure Rate	1 failure to complete in 10,000 calls
Malfunctions; Not Definite Failures to Complete	5 in 10,000 calls

[8] Were requirements in TABLE A met

Yes

Page 2

No

[9] Verify that installation group repairs faults and reruns tests

NOTE 1
The call volume of 500 calls per hour, per network frame, may be reduced if office is not equipped with enough service circuits to handle the 500 call rate.

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	628

OBSERVE PROCEDURES AND RESULTS OF MAINTENANCE VOLUME TESTS

[10] On MC TTY type
SW:SYC!

[11] Observing **SERVICE LOSS** lamp on SSP,
verify that off-line duplicated
units are powered down and up with
no effect on service

[12] Verify that all duplicated
units are powered up (**POWER**
lamp ON) before testing

[13] See NOTE 1, Page 1.
Using Speed Call 8 Load Boxes,
maintain a call volume of at least
500 calls per hour per network
frame for a minimum of 2 hours

[14] Force Nightly Routine to run
during test period [DLP-529]

AND

[15] Were
requirements in
TABLE A, Page 1
met

Yes

No

[16] Verify that
installation group
repairs faults and
reruns tests

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	628

OBSERVE PROCEDURES AND RESULTS OF MAINTENANCE VOLUME TESTS

SUMMARY

Increase room temperature no more than 10°F every hour test is run, not to exceed 115°F. The test must run for a minimum of 4 hours (2 hours on each CU). Maintain a call volume of at least 500 calls per hour (may be waived if office is not equipped with enough service circuits), per network frame. Observe that off-line duplicated units can

be powered down with no effect on service. Investigate and resolve all maintenance TTY printouts that occur during test period. No more than 1 in 10,000 calls should fail to complete during test interval. The number of troubles which indicate a malfunction but not a failure to complete must not exceed 5 in 10,000 calls.

- [1] Verify that cooling and circulating equipment has been turned off _____
- [2] Measure room temperature 5 feet above floor in center of aisle _____
- [3] Increase room temperature no more than 10°F for every hour test is run, not to exceed 115°F _____
- [4] Verify that all -48V 100 amp rectifiers are off and -48V distribution bus voltage is less than -47V, but not lower than -45.32V _____
- [5] Remove commercial ac power to ac inverter _____
- [6] Observing **SERVICE LOSS** lamp on SSP, verify that off-line duplicated units can be powered down with no effect on service _____

AND

Page 2

OBSERVE PROCEDURES AND RESULTS OF SIMULATED COMMERCIAL POWER FAILURE TESTS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 4	629

[7] Verify that off-line duplicated units are powered up before diagnostics are run

[8] See NOTE 1. Using Speed Call 8 load boxes, maintain a call volume of at least 500 calls per hour per network frame for a minimum of 2 hours

[9] Run major control units diagnostics at low voltage (CU, NWC, PPD, SC, RT) [DLP-544]





TABLE A	
CONDITION	RESULT
Calling Rate	At least 500 calls per hour, per network frame
Failure Rate	1 failure to complete in 10,000 calls
Malfunctions; (Not Definite Failures to Complete)	5 in 10,000 calls

NOTE 1
 The call volume of 500 calls per hour, per network frame, may be reduced if office is not equipped with enough service circuits to handle the 500 call rate


Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 4	629

OBSERVE PROCEDURES AND RESULTS OF SIMULATED COMMERCIAL POWER FAILURE TESTS



OBSERVE PROCEDURES AND RESULTS OF SIMULATED COMMERCIAL POWER FAILURE TESTS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 4	629



OBSERVE PROCEDURES AND RESULTS OF SIMULATED COMMERCIAL POWER FAILURE TESTS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 4	629

[1] Obtain test numbers for all office NXX codes in immediate dialing area. See NOTE 1

[2] Prepare a list of numbers to dial consisting of all NXX codes 200 through 999. Omit all NPA (area codes)

[3] On valid NXX codes assign test numbers obtained in Step 1 for this test. On invalid NXX codes assign any four digits

[4] Dial one of the numbers from list just prepared

AND

[5] If valid NXX code was dialed, was the correct office reached; for an invalid NXX code dialed, was the correct recorded announcement received

No

[6] Investigate cause of not routing correctly, wrong translations, misdialed number, or bad trunk circuit. Correct the fault

Yes

[8] Have all NXX codes been checked

Yes

[7] Repeat this procedure from Step 4


No

[9] Return to Step 4 until all numbers assigned in Step 2 have been checked

NOTE 1
 Use a switchroom directory number or a test number that provides a distinctive office identity tone

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	630


TEST ROUTING TO ALL NXX CODES



NOTE 1
 In offices providing toll dialing on coin telephone service, dial 0 in lieu of 1 on coin class of service prior to dialing area code


Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	631

TEST ROUTING TO ALL NPA (AREA) CODES




MAKE LOCAL CHARGE TEST

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	632



CHECK FOR REFUND AFTER ABANDON CALL


Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	633



NOTE 1
 a = Concentrator group
 b = Switch group
 c = Concentrator
 d = Switch
 e = Level
 tt = Minutes of hour
 xxx xxxx = Telephone number

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	634

CHECK STUCK COIN ALARM OPERATION



TEST +24V FUSE ALARM

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	635





TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Minor Sounding Alarm	TAP-100
SSP	MINOR and MINOR POWER lighted	TAP-112
TTY	tt REPT PWR A OOL	TAP-113

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	636

[1] At low profile distributing frame, shelf H or G, locate universal trunk circuit cross-connection terminal block

[2] At connecting block, locate row (0-23) of terminals which corresponds to circuit pack mounting position (0-23) on equipment frame
[FIG. 1 and 2]



MISC* 00-06	MB	0	0	0	0
	MA	0	0	0	0
	EB	0	0	0	0
	EA	0	0	0	0
	R1	0	0	0	0
	T1	0	0	0	0
	R	0	0	0	0
	T	0	0	0	0
TRUNK NO.	00	23			

CONT** 0 OR 1	MB	0	0	0	0
	MA	0	0	0	0
	EB	0	0	0	0
	EA	0	0	0	0
	R1	0	0	0	0
	T1	0	0	0	0
	R	0	0	0	0
	T	0	0	0	0
TRUNK NO.	00	23			

NETWORK† 01-15	MB	0	0	0	0
	MA	0	0	0	0
	EB	0	0	0	0
	EA	0	0	0	0
	R1	0	0	0	0
	T1	0	0	0	0
	R	0	0	0	0
	T	0	0	0	0
TRUNK NO.	00	23			




FIG. 2 - Universal Trunk Mounting Positions on Miscellaneous, Network, or Control Frame

* TRUNKS TERMINATED ON THESE BLOCKS ARE LOCATED ON MISCELLANEOUS FRAMES (00-06)
 ** TRUNKS TERMINATED ON THESE BLOCKS ARE LOCATED ON CONTROL FRAME 0 OR 1
 † TRUNKS TERMINATED ON THESE BLOCKS ARE LOCATED ON NETWORK FRAMES 01-15

FIG. 1 - Universal Trunk Terminations - Connecting Blocks

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	637

INSTALL UNIVERSAL TRUNK WIRING AT DISTRIBUTING FRAME




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR and FUSE lighted	TAP-112
TTY	tt REPT PWR D 27 9 OFN	TAP-113

NOTE 1
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	638




TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Major Sounding Alarm	TAP-100
SSP	MAJOR and MAJOR POWER lighted	TAP-112
TTY	tt REPT PWR D 27 8 OFN	TAP-113



NOTE 1
 Use care in connecting Master Scanner terminals. Improper connections cause erroneous results

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	639

TEST +48V CONVERTER FAILURE ALARM

[1] Identify circuit (0-3) and lead designations for the CDPR circuit being installed [FIG. 1]

[2] At distributing frame, Shelf J, Block 1 or Block 2, locate CDPR terminals DTO_ and DRO_ for the circuit being installed [DLP-641]



* CDPR CIRCUIT PACK MOUNTING POSITIONS ARE AS FOLLOWS:

CKT	CKT PACK POSITION	CDPR CKT PACK	LEAD DESIGNATION AT DISTRIBUTING FRAME
0	27	FB367	DT0-0, DR0-0
1	33	FB367	DT0-1, DR0-1
2	39	FB367	DT0-2, DR0-2
3	44	FB367	DT0-3, DR0-3

FIG. 1

IDENTIFY CDPR CIRCUIT TIP AND RING TERMINATIONS AT DISTRIBUTING FRAME

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	640

At Distributing Frame:

1. Locate terminals identified for circuit being installed as shown in FIG. 1

End of procedure

CABLED FROM FRAME	TEST								CONTROL 0			CONTROL 0		CONT 1		NETWORK 01		NETWORK 02		NETWORK 03		CONTROL 0				NETWORK 04	
									BAY 1		BAY 1		BAY 1		BAY 0							BAY 1					
									EQL 118		EQL 122		EQL 118		EQL 122												
CIRCUIT	PERIPHERAL TEST								TEST VERT AND PAIR CONT	TEST VERT AND PAIR CONT	MF TWTR	MF TWTR	REG RING	COPR	REG RING	COPR	REG RING	COPR	REG RING	COPR	REG RING	COPR	REG RING	COPR	REG RING	COPR	
																											REG RING
SHELF J BLOCK 1 ROM	7	TDR	CPNR	SRNR1	TENR0		ITTT21	ITTT31	PCRO		R3	R3		DR0-3		DR0-3		DR0-3		DR0-3		DR0-3		DR0-3		DR0-3	
	6	TDNT	CPNT	SRNT1	TENTO		ITTT21	ITTT31	PCTO		T3	T3		DT0-3		DT0-3		DT0-3		DT0-3		DT0-3		DT0-3		DT0-3	
	5	TPPDR	ITNR11	SRNR0	TPNR00		ITTTG11	ITTTG21	PWR1		R2	R2	R2	DR0-2	R2	DR0-2	R2	DR0-2	R2	DR0-2	R2	DR0-2	R2	DR0-2	R2	DR0-2	
	4	TPPDT	ITNT11	SRNT0	TPNT00		ITTS14	ITTS21	PWT1		T2	T2	T2	DT0-2	T2	DT0-2	T2	DT0-2	T2	DT0-2	T2	DT0-2	T2	DT0-2	T2	DT0-2	
	3	TPNR2	ITNR10	DTNR	TPNR10	LENR	ITTT20	ITTT30	PWR0		R1	R1	R1	DR0-1	R1	DR0-1	R1	DR0-1	R1	DR0-1	R1	DR0-1	R1	DR0-1	R1	DR0-1	
	2	TPRNG0	ITNT10	DTNT	TPNT10	LENT	ITTT20	ITTT30	PWT0		T1	T1	T1	DT0-1	T1	DT0-1	T1	DT0-1	T1	DT0-1	T1	DT0-1	T1	DT0-1	T1	DT0-1	
	1	TPPDR1	LIR	TTNR	RTR	TENR1	ITTTG10	ITTTG20	SIBR		R0	R0	R0	DR0-0	R0	DR0-0	R0	DR0-0	R0	DR0-0	R0	DR0-0	R0	DR0-0	R0	DR0-0	
	0	TPPDT1	LIT	TTNT	RTT	TENT1	ITTS10	ITTS20	SIB		T0	T0	T0	DT0-0	T0	DT0-0	T0	DT0-0	T0	DT0-0	T0	DT0-0	T0	DT0-0	T0	DT0-0	
COLUMN	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24		

FIG. 1 - Distributing Frame Terminals (Page 1)

**LOCATE SERVICE AND TEST CIRCUIT TERMINALS
AT DISTRIBUTING FRAME**


Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	641

CABLED FROM FRAME	NETWORK 05		NETWORK 06		NETWORK 07		NETWORK 08		NETWORK 09		NETWORK 10		NETWORK 11		NETWORK 12		NETWORK 13		NETWORK 14		NETWORK 15		TEST			
	REG RING	CDPR	PERIPHERAL TEST																							
SHELF J BLOCK 2 ROW	7	DR0-3		DR0-3	TTYPLR10	TTYMR11	TTYR11																			
	6	DT0-3		DT0-3	TTYPLT10	TTYNT11	TTYT11																			
	5	R2	DR0-2	TTYPLR00	TTYMR01	TTYR01																				
	4	T2	DT0-2	TTYPLT00	TTYNT01	TTYT01																				
	3	R1	DR0-1	TTYMR10	TTYR10	TTYPLR11																				
	2	T1	DT0-1	TTYNT10	TTYT10	TTYPLT11																				
	1	R0	DR0-0	TTYMR00	TTYR00	TTYPLR01																				
	0	T0	DT0-0	TTYNT00	TTYT00	TTYPLT01																				
COLUMN	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	

FIG. 1 - Distributing Frame Terminals (Page 2)

**LOCATE SERVICE AND TEST CIRCUIT TERMINALS
AT DISTRIBUTING FRAME**



Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	641



NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	642

[1] Identify circuit (0-2) and lead designations for the regular ringing circuit being installed [FIG. 1]

[2] At distributing frame, shelf J, block 1 or block 2, locate regular ringing circuit terminals T_ and R_ [DLP-641]



* CKT PACK MOUNTING POSITIONS AND LEAD DESIGNATIONS ARE AS FOLLOWS:

CKT	CKT PACK POSITION	CKT PACK	LEAD DESIGNATIONS AT DISTRIBUTING FRAME
0	14	FB 358	T0, R0
1	18	FB 358	T1, R1
2	22	FB 358	T2, R2

FIG. 1 - Regular Ringing Circuit Pack Positions

IDENTIFY REGULAR RINGING CIRCUIT TIP AND RING TERMINATIONS AT DISTRIBUTING FRAME

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	643





TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Minor Sounding Alarm	TAP-100
SSP	MINOR and FUSE lighted	TAP-112
TTY	tt REPT PWR C 24 12 OFN	TAP-113

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	644


TEST ±130V CONVERTER FUSE ALARM

[1] Identify circuit (0-3) and distributing frame terminations for multifrequency transmitter circuit being installed

[FIG. 1]



[2] At distributing frame connector block stenciled per T3H404-11, locate T- and R- terminals [DLP-641]



* TERMINATIONS AT DISTRIBUTING FRAME<

SHELF J, BLOCK 1 ARE AS FOLLOWS:

CKT	LEAD DESIGNATIONS
0	T0, R0
1	T1, R1
2	T2, R2
3	T3, R3

FIG. 1 - Identification of Multifrequency Transmitter Circuit at Equipment Frame and at Distributing Frame

IDENTIFY MULTIFREQUENCY TRANSMITTER CIRCUIT TIP AND RING TERMINATIONS AT DISTRIBUTING FRAME

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	645





TABLE A		
INDICATOR LOCATION	INDICATION NOT OBSERVED	TROUBLE CLEARING DATA
Building	Minor Sounding Alarm	TAP-100
SSP	MINOR and MINOR POWER lighted	TAP-112
TTY	tt REPT PWR C 24 11 OFN	TAP-113

NOTE 1	
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	646

TEST ±130V CONVERTER FAILURE ALARM

[1] At distributing frame shelf J, connecting block wired for 7A or 13A announcement, identify terminals for the announcement to be connected

[2] At distributing frame shelf J, connecting block stenciled T3H411-11 identify terminals for the tone and announcement circuit to be installed



**TABLE A
STRAPS AND CROSS-CONNECTIONS
FOR FIRST TONE AND ANNOUNCEMENT
CIRCUIT ASSIGNED TO 7A ANNOUNCEMENT**

CONNECT	TO	
FIRST TONE AND ANNOUNCEMENT	NETWORK (OE TERMINALS)	7A ANNOUNCEMENT
TO_	T	
RO_	R	
T1_	T	
R1_	R	
BA_		B_
CO_		MU2_
ST1A_		ST_
STA_		ST1_
TAO_*		T_
RAO_*		R_
TA1_*		
RA1_*		

* Strap TAO and TA1, RAO and RA1

**INSTALL WIRING FOR TONE AND ANNOUNCEMENT CIRCUIT
(SD-3H411-01 [CPS 383]) USED WITH 7A OR 13A ANNOUNCEMENT**

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	647

TABLE B STRAPS AND CROSS-CONNECTIONS FOR SECOND OR SUBSEQUENT TONE AND ANNOUNCEMENT CIRCUIT ASSIGNED TO 7A ANNOUNCEMENT	
CONNECT	TO
TONE AND ANNOUNCEMENT	NETWORK (OE TERMINALS)
TO_	T
RO_	R
T1_	T
R1_	R
BA_‡	
CO_‡	
ST1A_†	
STA_†	
TAO_*†	
RAO_*†	
TAl_*†	
RA1_*†	
* Strap TAO and RAO, RAO and RA1 † Multiple to other tone and announcement circuits assigned to the same 7A announcement ‡ No connection required	

**INSTALL WIRING FOR TONE AND ANNOUNCEMENT CIRCUIT
(SD-3H411-01 [CPS 383]) USED WITH 7A OR 13A ANNOUNCEMENT**

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	647

[1] At distributing frame, shelf J connecting block wired per R&TTS ckt T82255-30, locate terminals for the tone identified by the circuit order _____

[2] At distributing frame, shelf J, connecting block wired per T3H411-11, identify terminals for the tone and announcement circuit being installed [TABLE A] _____

[3] Install cross-connections as shown in TABLE A _____

[4] Locate tone and announcement circuit pack mounting position at control or miscellaneous frame [FIG. 1] _____





TABLE A		
CROSS-CONNECTIONS		
CONNECT	TO	
TONE AND ANNOUNCEMENT CIRCUIT	NETWORK (OE) TERMINALS	RINGING AND TONE PLANT
TO-	T	X
RO-	R	
TI-	T	
RI-	R	
TTO-	X	Tone connections must be shown on circuit order
RTO-		
TTI-		
RAI-		



THESE 7 SLOTS ARE THE ONLY CIRCUIT PACK MOUNTING POSITIONS AVAILABLE WHEN FB383 IS LOCATED ON CONTROL FRAME



*ONE FB383 CIRCUIT PACK IS REQUIRED FOR EACH TONE ANNOUNCEMENT CIRCUIT

FIG. 1 - Circuit Pack Mounting Positions On Miscellaneous Frame (All 12 slots reserved for FB383)

**INSTALL WIRING FOR TONE AND ANNOUNCEMENT CIRCUIT (SD-3H411-01)
USED FOR TONE SERVICE**

[1] Locate coin control circuit pack mounting position at control or miscellaneous frame [FIG. 1]

[2] At distributing frame, shelf J, connector block stenciled T3H411-11, identify cross-connection terminals for coin circuit being installed [FIG. 2]



*ONE FB423 CIRCUIT PACK IS REQUIRED FOR EACH COIN CONTROL CIRCUIT


FIG. 1 - Circuit Pack Mounting Positions

89A1-100 CONNECTING BLOCK SHELF J BAY 03	TOP TERM NO.	007	017	
	ROW	7	R1-01	R1-03
		6	T1-01	T1-03
		5	R0-01	R0-03
		4	T0-01	T0-03
		3	R1-00	R1-02
		2	T1-00	T1-02
		1	R0-00	R0-02
		0	T0-00	T0-02
	BOTTOM TERM NO.	000	010	
COLUMN	00	01		

FIG. 2 - Coin Control Circuit T and R Terminals

INSTALL WIRING FOR COIN CONTROL CIRCUIT (SD-3H411-01 [CPS 423])

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	649



NOTE 1
Use care in connecting Master Scanner terminals. Improper connections cause erroneous results

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	650

[1] At distributing frame, shelf J connecting block wired for 7A or 13A ANNOUNCEMENT, identify terminals for announcement machine and KS-20449, L1 Amplifier

[2] At distributing frame, shelf J, connecting block wired per T3H411-11, identify terminals for remote recorded announcement circuit to be installed

[3] Cross-connect terminals [TABLE A]





TABLE A CROSS-CONNECTIONS			
CONNECT	TO		
tone and ANNOUNCEMENT CKT	NETWORK (OE) TERMINALS	KS-20449 L1 AMPLIFIER	ANNOUNCEMENT SET
TO-11 RO-11	T R		
TA0-11 RA0-11		T2 R2	
TA1-11 RA1-11 BA-11 CO-11 ST1A-11 STA-11 DA-11 DL-11			T R B MU2 ST1 ST D DL1

**INSTALL WIRING FOR REMOTE RECORDED ANNOUNCEMENT
CIRCUIT (SD3H411-01 [CPS 426] OR [CPS 686])**

[1] At announcement set
jacks J3 and J4,
install 52-type head
telephone set


[2] Set CHECK-DICTATE
to DICTATE



D lamp lighted

[3] Speak in new
announcement

[4] Restore
CHECK-DICTATE



D lamp extinguished

[5] Set CHECK-DICTATE
to CHECK

[6] Listen to new
recorded
announcement

[7] Restore
CHECK-DICTATE

AND

[8] Was
recorded
announcement
satisfactory

Yes

[9] Remove
headset

No

TAP-119

RECORD ANNOUNCEMENT AT 7A ANNOUNCEMENT SET

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	652





TABLE A	
RC MESSAGE	VARIABLES
RC:CKT/ TYP NEW/ GRP nnn/ TER mmm/ OE gg cws i/	nnn = Group Number mmm = Member Number gg = Concentrator Group c = Concentrator w = Switch Group s = Switch i = Level on Switch
DP p ddd t/	p = Peripheral Pulse Distributor ddd = Peripheral Decoder t = Triplet
SP ss rr pp/ DSP ss rr pp/ END!	ss = Scanner Number rr = Scanner Row pp = Point in Scanner Row


NOTE 1
 DSP ss rr pp/ is only used when the circuit order requires a directed scan point

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	653




CHECK OVERTIME CHARGING FEATURE

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	654




MAKE PARTIAL DIAL TEST

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	655



Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	656

MAKE LOCAL COIN FIRST OPERATIONAL TESTS WITH OPERATOR





MAKE LOCAL COIN FIRST OPERATIONAL TESTS WITH OPERATOR

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	656




[1] AT PANEL POWER section of SSP,
depress and hold LAMP & POWER
TEST key

[2] Observe all lamps and LEDs
on SSP

[3] Release LAMP & POWER TEST
key




Page 2




TEST LAMPS AND LEDS ON SYSTEM STATUS PANEL (SSP)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	657



TEST LAMPS AND LEDs ON SYSTEM STATUS PANEL (SSP)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	657



TEST LAMPS AND LEDS ON SYSTEM STATUS PANEL (SSP)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	657





TABLE A
STANDBY LED extinguished
OUT OF SERVICE LED lighted
CU LED lighted
MAJOR EQPT LOSS lamp lighted

TEST SSP SYNC 0 AND 1 STATUS INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	658



TEST SSP SYC 0 AND 1 STATUS INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	658





TABLE D
LOCK lamp lighted
CU LED lighted
FORCED LED lighted
FORCE lamp lighted
SELECT 1 lamp lighted
At SYC 0 section:
OUT OF SERVICE LED extinguished
UNAVAILABLE LED lighted
At TTY: REPT CU STAT UAV 0

TEST SSP SYC 0 AND 1 STATUS INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	658



TEST SSP PANEL TIME OUT FUNCTION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	659




FIG. 1 - FA-1101 I/O Interface Circuit Pack

TEST SSP PANEL TIME OUT FUNCTION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	659




TABLE A
At SSP: PASS and EXECUTE lamps lighted MAJOR EQPT LOSS lamps lighted CU and MAJOR LEDs lighted At inactive 3A CC: ERROR STOPPED lamp flashes At TTY: DGN CU () COMPL 3

TABLE B
At SSP: PASS lamp flashes FAIL lamp lighted




TABLE C
At SSP: FAIL lamp extinguished PASS lamp lighted

TABLE D
At SSP PASS lamp extinguished EXECUTE lamp extinguished

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	660

TEST PASS, FAIL, AND EXECUTE LAMPS




TABLE A		
INDICATOR LOCATION	INDICATION TO BE OBSERVED	TROUBLE CLEARING DATA
SSP	NWC and MAJOR EQPT LOSS lighted	TAP-112
TTY	M tt RMV NWC cs ff	TAP-113

TABLE B		
INDICATOR LOCATION	INDICATION TO BE OBSERVED	TROUBLE CLEARING DATA
SSP	SC and MAJOR EQPT LOSS lighted	TAP-112
TTY	M tt RMV SC cs ff	TAP-113

NOTE 1	
c	= Control frame unit is located on (0 or 1)
s	= System control unit is located on (0 or 1)
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 4	661




TABLE C		
INDICATOR LOCATION	INDICATION TO BE OBSERVED	TROUBLE CLEARING DATA
SSP	PPD and MAJOR EQPT LOSS lighted	TAP-112
TTY	M tt RMV PPD cs ff	TAP-113

TABLE D		
INDICATOR LOCATION	INDICATION TO BE OBSERVED	TROUBLE CLEARING DATA
SSP	RT and MAJOR EQPT LOSS lighted	TAP-112
TTY	M tt RMV RT p ff	TAP-113

TEST PERIPHERAL UNIT STATUS DISPLAY LEDs

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 4	661




TABLE E
At SSP: TRK LIM LED lighted MAJOR EQPT LOSS lamp lighted

TABLE F
At SSP: SVC LIM LED lighted MAJOR EQPT LOSS lamp lighted





TABLE G		
INDICATOR LOCATION	INDICATION TO BE OBSERVED	TROUBLE CLEARING DATA
SSP	TDC LED lighted	TAP-112
TTY	OK	TAP-113



TEST LAMPS AT STATUS SECTION OF NOT ACTIVE 3A CC CONTROL UNIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	662

At SSP:

[1] Depress LOCK key

At Inside of Not
Active 3A CC Panel:

[2] Set TEST MODE/NORMAL
switch to TEST MODE

[3] Set TEST MODE/NORMAL
switch to NORMAL

At STATUS section:
TEST MODE lamp lighted
At TTY: REPT ERR KEY

At STATUS section:
TEST MODE lamp
extinguished

AND

[4] Are indicated
system responses
observed

Yes

Page 2

No

[5] Is TTY
response
correct

No

TAP-113

Yes

[6] Inspect
wiring per
SDs and CADs
and TAD-111

TEST 3A CC PANEL STATUS FUNCTIONS AND INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	663

At Not Active 3A CC Panel:

[7] Momentarily operate
EXECUTE switch

[8] Depress RESET
CIRCUITS key

[9] Depress MANUAL key

[10] Depress RESET
CIRCUITS key

At TTY:

[11] Type DGN:CU:15!

REPT STAT CU () MAN

REPT ERR MCH

At Not Active
3A CC Panel:
ERROR STOPPED lamp
momentarily lighted

At TTY:
DGN CU () COMPL ATP 15

AND

[12] Are
indicated system
responses observed

Yes

Page 3

No

No


[13] Replace
circuit pack
listed in
TABLE A
[DLP-543]

[15] Inspect
wiring per
SDs and CADs
and TAD-111


[14] Depress
LOCK and
repeat from
Step 7

TABLE A

Circuit Pack in Off-line Control Unit	Pack Location Inside 3A CC Control Panel	
	Tray Level	Position
FA1034	06	06



Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	663







FIG. 1 - Rear View of SSP Panel Power Section with VOM Connections

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	664

TEST SYSTEM STATUS PANEL INPUT VOLTAGES

[7] Set dc volts scale
on VOM to 12

[8] Connect VOM to pin 2
of LAMP POWER key (S2)
and ground. See FIG. 1,
Page 2



TEST SYSTEM STATUS PANEL INPUT VOLTAGES

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	664

At Not Active 3A CC Panel:


[1] Verify all panel switches are in down position except HALT switch

[2] At REGISTER SELECT section, set switch 4 to up position

[3] At REGISTER section, set LOAD and DISPLAY switches to up position

[4] At LOAD AND DISPLAY section, set switches 0 through 19 to up position

[5] At COMMAND section, momentarily operate EXECUTE switch




TEST LED_s AND SWITCHES AT LOAD AND DISPLAY AND REGISTER SELECT SECTIONS USING LOAD AND DISPLAY FUNCTION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 7	665

[10] At REGISTER SELECT section set switches per TABLE A, Page 3 to select first general or extended register listed


[11] Momentarily operate EXECUTE switch

[12] Observe associated REGISTER SELECT LED



TEST LEDs AND SWITCHES AT LOAD AND DISPLAY AND REGISTER SELECT SECTIONS USING LOAD AND DISPLAY FUNCTION


Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 7	665



**TABLE A
REGISTER SELECT SWITCH SETTINGS**

TO SELECT:		SET:
GENERAL REGISTER	EXTENDED REGISTER	8 4 2 1 <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
R0		↓ ↓ ↓ ↓
R1		↓ ↓ ↓ ↑
R2	Logic work (LW)	↓ ↓ ↑ ↓
R3	Logic register (LR)	↓ ↓ ↑ ↑
R4	Logic ask (LM)	↓ ↑ ↓ ↓
R5	Logic function/Rotate find (LF/RF)	↓ ↑ ↓ ↑
R6	Kall record Mode counter (KM)	↓ ↑ ↑ ↓
R7	General register (GR)	↓ ↑ ↑ ↑
R8	Enable register (ER)	↑ ↓ ↓ ↓
R9	R9	↑ ↓ ↓ ↑
R10	R10	↑ ↓ ↑ ↓
R11	R11	↑ ↓ ↑ ↑
R12	Program fil middle(PFM)	↑ ↑ ↓ ↓
R13	Call address (CA)	↑ ↑ ↓ ↑
R14	Data fil high (DFH)	↑ ↑ ↑ ↓
R15	Addition address (AA)	↑ ↑ ↑ ↑

TEST LEDs AND SWITCHES AT LOAD AND DISPLAY AND REGISTER SELECT SECTIONS USING LOAD AND DISPLAY FUNCTION



ITEM	LOCATION	INDICATION/RESPONSE
1	3A CC	0 through PH LEDs ON
2	3A CC	ENABLE MANUAL PAR LED OFF
3	3A CC	SPECIAL LED Lighted

TEST LEDs AND SWITCHES AT LOAD AND DISPLAY AND REGISTER SELECT SECTIONS USING LOAD AND DISPLAY FUNCTION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 7	665





TABLE C		
ITEM	LOCATION	INDICATION/RESPONSE
1	3A CC	PL through PH LEDs on
2	3A CC	0 through 19 and ENABLE MANUAL PAR LEDs off


TEST LEDs AND SWITCHES AT LOAD AND DISPLAY AND REGISTER SELECT SECTIONS USING LOAD AND DISPLAY FUNCTION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 5 of 7	665



TEST LEDs AND SWITCHES AT LOAD AND DISPLAY AND REGISTER SELECT SECTIONS USING LOAD AND DISPLAY FUNCTION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 6 of 7	665



TEST LEDs AND SWITCHES AT LOAD AND DISPLAY AND REGISTER SELECT SECTIONS USING LOAD AND DISPLAY FUNCTION


Issue 3	AUG 1984
233-142-100	DLP
PAGE 7 of 7	665

At Not Active 3A CC Panel:

[1] Verify all panel switches
are in down position
except HALT switch

[2] At COMPARE section, set
ADR switch to up position

[3] Momentarily operate
EXECUTE switch



TEST LED_s AND SWITCHES OF COMPARE FUNCTION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	666

[8] At COMPARE section,
set ADR switch to
down position

[9] Momentarily operate
EXECUTE switch

ENABLE LED
extinguished

[10] At COMPARE section,
set DATA switch to
up position

[11] Momentarily operate
EXECUTE switch

AND

[12] At COMPARE
section, is
ENABLE LED
lighted

Yes

Page 3

No

[13] Inspect
wiring per
SD-1C900 and
SD-1C901


TEST LEDs AND SWITCHES OF COMPARE FUNCTION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	666

[14] At **COMPARE** section,
set **DATA** switch to
down position

[15] Momentarily operate
EXECUTE switch

[16] At **MODE** section, set
HALT switch to down
position



At Not Active 3A CC Panel:

[1] Verify all panel switches except
HALT are in down position


[2] At REGISTER section, set LOAD and
DISPLAY switches to up position

[3] At REGISTER SELECT section, set SPECIAL/
GENERAL EXTENDED switch to SPECIAL and
switches 1 and 2 to up position

[4] Momentarily operate EXECUTE switch


[5] At REGISTER section, set LOAD and
DISPLAY switches to down position

[6] At MEMORY section, set DISPLAY
switch to up position



TEST 3A CC PANEL MEMORY FUNCTIONS AND INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 11	667



NOTES

1. Variables a through h are the octal contents of memory at store addresses 0 through 7
2. The binary equivalent of octal value a obtained in Step 7 is displayed by the **LOAD AND DISPLAY LEDs 0** through 15. If parity is even for bits 0 through 8 and 9 through 16, **PL** and **PH** LEDs are also lighted

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 11	667

TEST 3A CC PANEL MEMORY FUNCTIONS AND INDICATORS


At Not Active 3A CC Panel:

[12] At MEMORY section, set DISPLAY and INCR ADR switches to down position

[13] At REGISTER section, set DISPLAY switch to up position

[14] Momentarily operate EXECUTE switch

[15] At REGISTER section, set LOAD switch to up position




At LOAD AND DISPLAY LEDs 1 and PH lighted



Page 4

TEST 3A CC PANEL MEMORY FUNCTIONS AND INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 11	667



At TTY:

[20] Type
DMP:ST:100000!

DMP ST 0100000
a b c d e f g h

At Not Active 3A CC Panel:

[21] At REGISTER section, set LOAD and
DISPLAY switches to down position




[22] At MEMORY section, set STORE and
DISPLAY switches to up position

[23] At LOAD AND DISPLAY section, set
all switches to down position

[24] Momentarily operate EXECUTE switch

At LOAD AAD DISPLAY
LEDs PL and PH lighted


[25] At LOAD AND DISPLAY section, set
switches 0 through 15 to up position



Page 6


TEST 3A CC PANEL MEMORY FUNCTIONS AND INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 5 of 11	667



TEST 3A CC PANEL MEMORY FUNCTIONS AND INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 6 of 11	667




TEST 3A CC PANEL MEMORY FUNCTIONS AND INDICATORS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 7 of 11	667

At Not Active 3A CC Panel:

[36] At **LOAD AND DISPLAY** section
set switch 12 and 13 to up position

[37] Momentarily operate **EXECUTE** switch




At **LOAD AND DISPLAY**
LEDs 12,13,PL and PH lighted


[38] At **REGISTER** section, set **LOAD** and
DISPLAY switches to down position

At TTY:

[39] Type
DMP:ST 030000!



DMP ST 0030000
a b c d e f g h



At Not Active 3A CC Panel:


[40] At REGISTER section, set LOAD and DISPLAY switches to down position

[41] At MEMORY section, set STORE and DISPLAY switches to up position


[42] At LOAD and DISPLAY section, set all switches to down position

[43] Momentarily operate EXECUTE switch

[44] At LOAD AND DISPLAY section, set switches 0 through 15 to up position



At LOAD AND DISPLAY LEDs PL and PH lighted



Page 10

At Not Active 3A CC Panel:

[45] Momentarily operate EXECUTE switch

At LOAD AND DISPLAY LEDs 0 through 15, PL and PH lighted

[46] At LOAD AND DISPLAY section, set switches 0 through 15 to down position

[47] Momentarily operate EXECUTE switch

At LOAD AND DISPLAY LEDs PL and PH lighted

[48] Convert octal value a obtained in Step 39 to binary

[49] At LOAD AND DISPLAY section, set switches to binary value calculated


[50] Momentarily operate EXECUTE switch

[51] Type DMP:ST: 030000!

DMP ST 0030000
a b c d e f g h

AND

Page 11



At Not Active 3A CC Panel:

[1] Verify that all panel switches, except HALT, are in down positions

[2] At REGISTER section, set LOAD and DISPLAY switches to up position

[3] At LOAD AND DISPLAY section, set ENABLE MANUAL PAR switch to up position

[4] Momentarily operate EXECUTE switch

[5] At LOAD AND DISPLAY section, set ENABLE MANUAL PAR switch to down position

[6] Momentarily operate EXECUTE switch

ENABLE MANUAL PAR LED lighted

At LOAD AND DISPLAY section, PL and PH LEDs extinguished

ENABLE MANUAL PAR LED extinguished

At LOAD AND DISPLAY section, PL and PH LEDs lighted

AND

[7] Does ENABLE MANUAL PAR, PL, and PH LEDs light

Yes

No

No

[8] Replace extinguished LED [DLP-557]


[10] Inspect wiring per SDs and CADs and TAD-111

[9] Repeat from Step 1




Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	668

At Not Active 3A CC Panel:

- [1] Verify that all panel switches except HALT are in down position
- [2] At REGISTER section set LOAD and DISPLAY switches to up position
- [3] At MEMORY section set DISPLAY switch to up position
- [4] Momentarily operate EXECUTE switch



No




Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	669

TEST 3A CC PANEL REJECT FUNCTION AND INDICATOR

[9] At MEMORY section, set DISPLAY switch to down position

[10] Momentarily operate EXECUTE switch



At Not Active 3A CC Panel:

1. Return 3A CC to normal operating conditions as follows:

1.1 Verify that all panel switches are in down position

1.2 At STATUS section, depress MANUAL key

Response: MANUAL lamp extinguished

At SSP:

1.3 Depress LOCK key

Response: LOCK lamp extinguished
FORCED LED extinguished
FORCE lamp extinguished
SELECT (A) lamp extinguished (a = active CU)
At Not Active SYS section:
UNAVAILABLE LED extinguished
OUT OF SERVICE LED lighted
At TTY: REPT CU STAT AVL
After main store updates:
At SYC section:
OUT OF SERVICE LED extinguished
STANDBY LED lighted
At TTY: UPD OMAS COMPL

End of procedure

RETURN 3A CC TO NORMAL OPERATING CONDITION

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	670

[1] Restore one CAMA trunk to service. On MC TTY type
 RST:TRK aaa,bbb;UCL!
 aaa = Trunk group number
 bbb = Member number

[2] On local telephone dial
 1 + 7-digit test number in
 the CAMA office

[3] After distant end answers,
 continue a conversation for
 at least one minute

[4] Place telephone on-hook


[5] See NOTE 1. Log call
 on test log

Test call made and logged

[6] Remove the CAMA trunk from
 service. On MC TTY type
 RMV:TRK aaa,bbb;UCL!

[7] Restore a different CAMA
 trunk to service. On MC TTY type
 RST:TRK aaa,bbb;UCL!

[8] Repeat from Step 2 until
 all CAMA trunks have been
 tested



NOTE 1
 If the number reached is different from the number dialed, log both the number dialed and the number reached

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	671

PLACE TEST CALL ON A CAMA TRUNK

At Not Active 3A CC Panel:

[1] Verify that all panel switches except HALT are in down positions

[2] At REGISTER section, set LOAD and DISPLAY switches to up position

[3] At REGISTER SELECT section, set SPECIAL/GENERAL EXTENDED switch to SPECIAL and switch 4 to up position

[4] At LOAD AND DISPLAY section, set switch 5 to up position

[5] Momentarily operate EXECUTE switch

SPECIAL LED lighted
PROG ADRS LED lighted

AND

At LOAD AND DISPLAY section, LEDs 5 and PH lighted

[6] Are indicated system responses observed at Steps 3 and 5

Page 2

No

No

[7] Replace extinguished LED [DLP-557]

[9] Inspect wiring per SDs and CADs and TAD-111

[8] Repeat from Step 1

TEST 3A CC PANEL STEP FUNCTIONS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	672

At Not Active 3A CC Panel:

[10] Set all switches except
HALT to down position

[11] At **MODE** section, set
STEP to up position

At TTY:

[12] Type **DMP:ST 000040!**

DMP:ST 000040
a b c d e f g h
a through h =
contents of memory

At Not Active 3A CC Panel:

[13] Momentarily operate
EXECUTE switch

See TABLE A
for system
response

AND

[14] Are
indicated system
responses
observed at
Steps 12 and 13

Yes

Page 3

No

[15] Check
switch settings,
value used in
DMP:ST message,
and repeat from
Step 1

No

[16] Inspect
wiring per
SDs and CADs
and TAD-111

TABLE A


At **MODE** section:
HALTED LED extinguished momentarily
At **LOAD AND DISPLAY** section:
LEDs lighted corresponding to octal
contents of store address 000041
obtained in Step 12 (b)

At Not Active 3A CC Panel:

[17] Set all switches to
down position _____

[18] Momentarily operate
EXECUTE switch _____

[19] At **STATUS** section, depress
RESET CIRCUITS key _____



TEST 3A CC PANEL STEP FUNCTIONS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	672

[1] See CAUTION 1. Obtain appropriate packs (as defined in Trouble Locating Manual) from circuit pack storage

[2] Visually examine replacement circuit pack(s) for component damage, contact scratches, or other imperfections which may be potential sources of trouble

[3] At System Status Panel, depress **CIRCUIT POWER** until extinguished

[4] Depress **LAMP POWER** until extinguished

[5] Remove the questionable circuit pack from apparatus mounting

[6] Insert replacement pack into apparatus mounting

[7] At System Status Panel, depress **LAMP POWER**

[8] Depress **CIRCUIT POWER**



CAUTION 1 Contact contamination may occur unless circuit pack is handled only by the edges	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	673

REPLACE SYSTEM STATUS PANEL CONTROLLER CIRCUIT PACK

[1] See CAUTION 1. Obtain appropriate packs
(as defined in Trouble Locating Manual)
from circuit pack storage _____

[2] Visually examine replacement circuit pack(s)
for component damage, contact scratches, or
other imperfections which may be potential
sources of trouble _____

[3] Remove tape cartridge from Cartridge Tape
Transport [DLP-695] _____

[4] Depress TDC POWER to remove power _____


[5] Remove questionable circuit pack
from apparatus mounting _____

[6] Insert replacement pack into
apparatus mounting _____

[7] Depress TDC POWER
to restore power _____

[8] Replace tape cartridge _____

[9] At maintenance
teletypewriter, type:
INIT:TAPE! _____



CAUTION 1
Contact
contamination may
occur unless
circuit pack is
handled only by
the edges

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	674

REPLACE TAPE DATA CONTROLLER CIRCUIT PACK


At System Status Panel:

[1] Verify **SYSTEM NORMAL**
lamp is ON _____

[2] At System Status
Panel, depress
LOCK key _____


[3] At TTY type
RMV:CU! _____

[4] At 3A CC Panel
depress **MANUAL** key on
BOTH control units _____



PREPARE SYSTEM FOR OFF-LINE BOOTSTRAP PROCEDURE

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	675



**VERIFY GENERIC HASHSUMS USING BROADCAST
WARNING MESSAGE (BWM) (SO-2 GENERIC)**

NOTE 1	
NNNNN is the generic hashsum value in decimal	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	676

[1] See NOTE 1. At TTY type:
DMP:ST 261251!
[FIG. 1]

TTY output message printed:
tt DMP ST 261251
xxxxx A BCCCCC xxxxxx


[2] Record A and B values of output message for future reference

[3] Using TTY output message of Step 1, multiply value corresponding to A by 200000

[4] Add value corresponding to BCCCCC to result of Step 2

[5] Subtract 20 (octal) from result of Step 3

[6] Record result as address of translation hashsum (HHHHHH) for future reference



STEP 1 - DMP ST 261251
000001 177707 xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx
A VALUE | B VALUE | C VALUE

STEP 2 - (A = 1)
1 X 200000 = 200000


STEP 3 - (BCCCCC = 177707)
200000
177707
377707

STEP 4 - 377707
-20
377667 = ADDRESS OF TRANSLATION HASHSUM (HHHHHH)
TO BE RECORDED

FIG. 1 - Example of a Translation Hashsum Calculation

NOTE 1	
All calculations are performed in octal; A, B, and C are variables	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	677

CALCULATE TRANSLATION HASHSUMS




DMP:ST 261251
 000001 177707 xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx
 A VALUE — | B VALUE — | C VALUE —

NOTE: A, B, AND C ARE VARIABLES


FIG. 1 - Output from DMP:ST Message

NOTES	
1. HHHHHH is resulting address of translation hashsum calculation	
2. NNNNN is translation hashsum value in decimal	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	678




Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	678

PRINT TRANSLATION HASHSUMS




INSTALL GENERIC PATCH MANUALLY FOR OFFICES WITH 3E3 GENERIC OR LATER

NOTES	
1. System abnormalities must be corrected before this generic patch procedure is performed. The off-line SYC must be in standby	
2. The order for the generic patch includes a listing (chips listing) of messages required in Steps 3, 4, 5, and 15	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 6	679



INSTALL GENERIC PATCH MANUALLY FOR OFFICES WITH 3E3 GENERIC OR LATER

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 6	679




NOTES

3. The last IN:OWDATA input message specified an address that has been previously specified in this overwrite. This is a warning message. If the intent was to correct the previous specification, this message should be ignored

4. The last IN:OWDATA input message would have caused the overwrite buffer in the main store to overflow. It was thrown out. A similar response can be expected on any subsequent IN:OWDATA message for this overwrite. The overwrite is too big


Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 6	679

INSTALL GENERIC PATCH MANUALLY FOR OFFICES WITH 3E3 GENERIC OR LATER




INSTALL GENERIC PATCH MANUALLY FOR OFFICES WITH 3E3 GENERIC OR LATER

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 6	679



**INSTALL GENERIC PATCH MANUALLY FOR OFFICES WITH 3E3 GENERIC
OR LATER**

Issue 3	AUG 1984
233-142-100	DLP
PAGE 5 of 6	679



INSTALL GENERIC PATCH MANUALLY FOR OFFICES WITH 3E3 GENERIC OR LATER

Issue 3	AUG 1984
233-142-100	DLP
PAGE 6 of 6	679

At Maintenance TTY:

[1] Type

IN:OW n; TAPE!

n = number of overwrite

[NOTE 1]

[2] Type

VER:OW:NEW!

[3] Type

LOD:OW:OLD!

[4] Type

SW:SYC!

[5] Type


RMV:OW!

[6] Type

UPD:HASH:GENERIC!


[7] Type

STOP:OW!



**DISCONTINUE GENERIC PATCH BEFORE ACTIVATION
FOR OFFICES WITH 3E3 GENERIC OR LATER**

NOTE 1	
The number of the overwrite must be the number used in the attempted generic patch	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	680



NOTE 1	
Both tape units must be in service in order for update to complete successfully	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	681

UPDATE TRANSLATION FILES





FIG. 1




TABLE A		
FREQ	EXAMPLE OF CONTROL SETTINGS	
	FREQ RANGE	FREQ CPS
400 Hz	X10	40
1000 Hz	X10	100
2800 Hz	X10	280

NOTE 1	
If a precise frequency is desired the oscillator can be connected to a frequency counter and FREQ VERNIER adjusted to an exact frequency	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	682






FIG. 1 - 3A Noise Measuring Set - Cover Removed

NOTE 1
When measuring rapidly fluctuating noise, the DAMP setting may be used. Read only the maximum of the most frequently occurring peaks in this position


Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	683

SET UP 3A NOISE MEASURING SET




REMOVE CARTRIDGE TAPE TRANSPORT (MINIRECORDER) FROM SERVICE

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	684



NOTE 1	
This message is not necessary for offices with 3E3 generic or later. Tape initiation is run automatically during tape diagnostics.	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	685



PERFORM OFF-LINE BOOTSTRAP

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	686

[1] If cleaning equipment has not been obtained, procure equipment per TABLE A

[2] Read CAUTION 1

[3] Lightly moisten cloth with cleaning solvent

[4] Carefully clean head and baseplate assembly, drive capstan (while spinning), and cartridge sensor microswitches [FIG. 1] [NOTE 1]

[5] Wipe head and baseplate assembly clean with a dry cloth

[6] Using vacuum cleaner, remove all loose dust on, around, and inside recorder




FIG. 1

NOTE 1

Lightly depressing the cartridge sensor microswitch will spin the capstan. On CTT units with two microswitches, depress the right microswitch

CAUTION 1

Contamination may occur on drive capstan, EOT/BOT sensors, light window, cartridge sensor microswitches, or magnetic tape if touched with bare hands during CTT cleaning

TABLE A

EQUIPMENT REQUIRED	RECOMMENDED TYPE
Cloth	KS-2423
Cleaning solvent	94% [or 91%] Isopropyl Alcohol TEXPAD - manufactured by Texwipe, Hillsdale, N.J. 07642 will eliminate the need of the cloth and solvent
Vacuum cleaner	KS-14377, L5

Issue 3 | AUG 1984

233-142-100 | DLP

PAGE 1 of 1 | 687





FIG. 1

CAUTION 1	
<i>Touching the recording tape and recording head with hands or sharp instruments may cause equipment damage</i>	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	688

INSPECT CARTRIDGE TAPE TRANSPORT (MINIRECORDER) FOR WEAR







FIG. 2

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	688




PERFORM POST OFF-LINE BOOTSTRAP

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	689




CHECK RECORDED ANNOUNCEMENT FOR PARTIAL DEPOSIT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	690



MAKE LOCAL DIAL-TONE-FIRST OPERATIONAL TESTS WITH OPERATOR

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	691



Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	691

MAKE LOCAL DIAL-TONE-FIRST OPERATIONAL TESTS WITH OPERATOR

[1] Restore one CAMA trunk to service by typing in RST:TRK aaa,bbb:UCL where aaa = trunk group number and bbb = member number


[2] On CAMA trunk to be tested, place a call to 7-digit test number

[3] Instruct distant office to leave telephone off-hook

[4] Redial test number


[8] Log test call on test log indicating busy condition

[9] Place telephone on-hook




Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	692

MAKE TEST CALL TO A BUSY NUMBER




NOTE 1	
NNNNN is the hashsum value in decimal	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	693

**VERIFY GENERIC HASHSUMS USING PREVIOUS HASHSUM VALUES
(SO-2 GENERIC)**



**VERIFY GENERIC HASHSUMS USING PREVIOUS HASHSUM VALUES
(SO-2 GENERIC)**

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	693



DMP:ST 261251
 000001 177707 xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx
 A VALUE — B VALUE — C VALUE

NOTE: A, B, AND C ARE VARIABLES

FIG. 1 - Output from DMP:ST Message

NOTES
 1. HHHHHH is resulting address of translation hashsum calculation
 2. NNNNN is translation hashsum value in decimal

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 3	694

VERIFY TRANSLATION HASHSUMS

[8] At TTY type
VFY:OW:ADR 277777!
[NOTE 2, Page 1]

tt VFY OW 277777 NNNNN

[9] Does translation hashsum [NNNNN] value printed match previous translation hashsum value obtained for this address

No

[10] Seek further technical assistance

Yes

[11] Obtain value A recorded from DWP:ST 261251 output message of [DLP-677] [FIG. 1, Page 1]

[12] Is value of A equal to 1

No

Page 3


Yes

[13] At TTY type STOP:OW!

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 3	694

VERIFY TRANSLATION HASHSUMS

[14] At TTY type
VFY:OW:ADR 377777!
[NOTE 2, Page 1]



tt VFY OW 377777 NNNNN

[15] Does translation
hashsum [NNNNN] value
printed match previous
translation hashsum
value obtained for
this address

No

[16] Seek
further
technical
assistance

Yes

[17] At
TTY type
STOP:OW!

VERIFY TRANSLATION HASHSUMS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 3	694





FIG. 1

REMOVE CARTRIDGE FROM CARTRIDGE TAPE TRANSPORT (MINIRECORDER)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	695

[1] Obtain trunk group and member number used to install office-to-office trunk circuit prior to starting tests

[2] See TABLE A.
On MC TTY type
RC:CKT/
TYP OUT/
GRP nnn/
TER ooo/
END!



VARIABLE	DEFINITION
nnn	Trunk Group Number
ooo	Member Number

SUMMARY

Place a 1370-ohm resistor in series with the ring side of a ground start line. With an oscilloscope, measure the ac longitudinal voltage interference across the resistor. If

the measured interference exceeds 7.5 volts peak, or 15.08 volts peak-to-peak, install a noise immunity line circuit SD-3H208-01 to prevent possible false line originations.

[1] Set scope to measure 20 volts peak-to-peak

[2] Connect scope per FIG. 1

[3] Connect scope ground clip to CDF frame ground

[4] Measure voltage from point A to ground. See FIG. 1

[5] Measure voltage from point B to ground. See FIG. 2




FIG. 1




FIG. 2

MEASURE LONGITUDINAL VOLTAGE USING OSCILLOSCOPE

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	697





FIG. 3


NOTE 1
AC longitudinal voltage interference may vary widely throughout the day as well as from season to season. It is recommended to multiply the voltage reading by 2 unless interference is known to be at its maximum

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	697

SUMMARY

Place a 1370-ohm resistor in series with the ring side of a ground start line. With a digital multimeter, measure the ac longitudinal voltage interference across the resistor.

If the measured interference exceeds 5.319V rms, install a noise immunity line circuit (SD-3H208-01) to prevent possible false line originations.



NOTE 1	
AC longitudinal voltage interference may vary widely throughout the day as well as from season to season. It is recommended to multiply the voltage reading by 2 unless interference is known to be at its maximum	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	698

MEASURE LONGITUDINAL VOLTAGE USING DIGITAL MULTIMETER




FIG. 1





FIG. 2




NOTES

- Both tape units must be in service in order for the update to be completed successfully
- This message is not necessary for offices with 3E3 generic or later. Tape initiation is run automatically during tape diagnostics

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	699

UPDATE TAPE COPIES OF TRANSLATIONS



UPDATE TAPE COPIES OF TRANSLATIONS

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	699

**TABLE A
TRANSLATORS AND ASSOCIATED REALLOCATION AND VERIFICATION MESSAGES**

TRANSLATOR	REALLOCATION MESSAGE	REALLOCATION VARIABLE DEFINITION	SO-2 VERIFICATION MESSAGE	3E3 VERIFICATION MESSAGE
AMA Buffer	DIST:AMA nnnn! or DIST:AMA:RMV!	nnnn = Number of words an AMA buffer contains (1 - 4096)		
Country Access Code	DIST:CAC nn!	nn = Number of CAC Tables (0 - 63)		OP:OFR/CAC ALL/END!
Autoconnect Call Back*	DIST:CALLBK nn! or DIST:CALLBK;RMV!	nn = Number of autoconnect callback entries (0 - 63)		
Code Index	DIST:CDI nnn! or DIST:CDI;RMV!	nnn = Number of code index entries (0 - 255)	VER:CDI	OP:OFR/CDI ALL/END!
Call Forwarding	DIST:CF nnnn! or DIST:CF;RMV!	nnnn = Number of CF entries (1 - 4096)	VER:CFN	VER:CFN
Coin Triplet	DIST:CNTRIP nnnn! or DIST:CNTRIP;RMV!	nnnn = Number of coin triplet entries (1-1024)	VER:LINE	VER:LINE
Two-Word Code List Expansion Blocks*	DIST:COD2 nnnn! or DIST:COD2;RMV!	nnnn = Number of two-word code list expansion blocks (1 - 4096)		
Local and Foreign Area	DIST:DIG a! or DIST:DIG a sss! or DIST:DIG a;RMV!	a = Local area (0), Foreign area (1,2,3) sss = Number of nxx code entries (1 - 128)	VER:DIG	OP:OFR/DIG ALL/END!
One-Word Expansion	DIST:EXP1 nnnn! or DIST:EXP1;RMV!	nnnn = Number of one-word expansion blocks (1 - 4096)		
Two-Word Expansion	DIST:EXP2 nnnn! or DIST:EXP2;RMV!	nnnn = Number of two-word expansion blocks (1 - 4096)		
Four-Word Expansion	DIST:EXP4 nnnn! or DIST:EXP;RMV!	nnnn = Number of four-word expansion blocks (1 - 4096)		
Eight-Word Expansion*	DIST:EXP8 nnnn! or DIST:EXP8; RMV!	nnnn = Number of eight-word expansion blocks (1 - 4096)		

* 3E3 Generic Only

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 7	700

PERFORM REALLOCATION PROCEDURES

TABLE A (Contd)
TRANSLATORS AND ASSOCIATED REALLOCATION AND VERIFICATION MESSAGES

TRANSLATOR	REALLOCATION MESSAGE	REALLOCATION VARIABLE DEFINITION	SO-2 VERIFICATION MESSAGE	3E3 VERIFICATION MESSAGE
Multiline Hunting, Service Circuit, or Trunk Groups	DIST:GRP ggg! or DIST:GRP:ggg ttt! or DIST:GRP ggg;RMV!	ggg = Group number (0 - 255) ttt = Largest terminal number 0 - 63 for MLHG and 0 - 126 for trunk and service circuit groups	VER:GRP	OP:OFR/GRP ALL/END!
Line Class Code*	DIST:LCC nnn! or DIST:LCC; RMV!	nnn = Number of line class code entries (0 - 255)	-	OP:OFR/LCC ALL/END!
Message Register	DIST:MR nnnn! or DIST:MR;RMY!	nnnn = Number of message registers (1 - 4096)	VER:LINE	VER:LINE
Number Group	DIST:NG nxx! or DIST:NG nxx!t h! or DIST:NG nxx;RMV! or DIST:NG nxx t h;RMV!	nxx = Office code t = Thousands digit h = Hundreds digit	VER:LINE	VER:LINE
One Digit	DIST:ODIG nn! or DIST:ODIG;RMV!	nn = Number of one-digit tables (0 - 63)	-	OP:OFR/ODIG ALL/END!
Precut and Test Line Maps	DIST:PRECUT! or DIST:PRECUT;RMV!			
Route Index	DIST:RT1 nnn! or DIST:RT1; RMV!	nnn = Number of route index entries (0 - 255)	VER:RT1	OP:OFR/RT1 ALL/END!
Special Billing Table	DIST:SBIL nnnn! or DIST:SBIL;RMV!	nnnn = Number of special billing table entries (1 - 1024)	VER:LINE	VER:LINE
Scan Point	DIST:SCAN nn! or DIST:SCAN;RMV!	nn = Number of line scanners (1 - 15)	VER:OE	OP:OFR/SP ALL/END!
Screening Classes	DIST;SCRCLS cc!	cc = Screening classes (0 - 62)	VER:SCR	OP:OFR/SCR ALL/END!
Screening Tables	DIST:SCRTBL tt! or DIST:SCRTBL;RMV!	tt = Number of screening tables (0 - 63)	VER:SCR	OP:OFR/SCRTBL ALL/END!
Speed Call 30	DIST:SC30 nnnn! or DIST:SC30;RMV!	nnnn = Number of speed call 30 lists (1 - 546)	VER:SCN	VER:SCN
Speed Call 8	DIST:SC8 nnnn! or DIST:SC8;RMV!	nnnn = Number of speed call 8 lists (1 - 2047)	VER:SCN	VER:SCN
Terminal Office Test	DIST:TOTANI nn! or DIST:TOTANI;RMV!	nn = Number of TOTANI table indexes (1 - 63)		OP:OFR/TOTANI ALL/END!

* 3E3 Generic Only

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 7	700

[1] At System Status Panel
verify that off-line
control unit is on
standby

[2] At TTY type
ALW:ADM!

[3] At System Status
Panel depress
LOCK key

[6] Select one reallocation message
DIST:aaaa from TABLE A

[7] At TTY type
selected message

ADM PROG
READY

AND

[4] Is a
new trunk group
being reallocated

Yes

[5] At
TTY type
DIST:GRP ggg!
ggg = Group
Number (0-255)

No

AND

[8] Was TTY
response
tt DIST COMPL

Yes


Page 4

No

[9] Correct
error condition
and repeat
from Step 4


Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 7	700

PERFORM REALLOCATION PROCEDURES




PERFORM REALLOCATION PROCEDURES

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 7	700




PERFORM REALLOCATION PROCEDURES

Issue 3	AUG 1984
233-142-100	DLP
PAGE 5 of 7	700



PERFORM REALLOCATION PROCEDURES

Issue 3	AUG 1984
233-142-100	DLP
PAGE 6 of 7	700



PERFORM REALLOCATION PROCEDURES

Issue 3	AUG 1984
233-142-100	DLP
PAGE 7 of 7	700

[1] At Maintenance TTY type:
IN:OW n; TAPE!

n = number of overwrite
[NOTE 1]

[2] Type:
VFY:OW:NEW!

[3] Type:
LOD:OW:OLD!

[4] Type:
VFY:OW:OLD!

[5] Type:
SW:SYC!

[6] Type:
VFY:OW:NEW!

[7] Type:
LOD:OW:OLD!


[8] Type:
VFY:OW:OLD!

[9] Type:
RMV:OW!

[10] Type:
UPD:OW!


[11] Type:
STOP:OW!

NOTE 1
The number of the
overwrite must be
the number used
in the attempted
generic patch




DISCONTINUE GENERIC PATCH BEFORE ACTIVATION (SO-2 GENERIC)


Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	701



NOTES	
1. System abnormalities must be corrected before this generic patch procedure is performed. The off-line SYC must be in standby	
2. The order for the generic patch includes a listing (chips listing) of messages required in Steps 3, 4, 5, and 15	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 6	702

INSTALL GENERIC PATCH MANUALLY (SO-2 GENERIC)






NOTES

3. The last IN:OWDATA input message specified an address that has been previously specified in this overwrite. This is a warning message. If the intent was to correct the previous specification, this message should be ignored

4. The last IN:OWDATA input message would have caused the overwrite buffer in the main store to overflow. It was thrown out. A similar response can be expected on any subsequent IN:OWDATA message for this overwrite. The overwrite is too big

Issue 3	AUG 1984
233-142-100	DLP
PAGE 3 of 6	702



INSTALL GENERIC PATCH MANUALLY (SO-2 GENERIC)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 4 of 6	702

[32] Type
 OP:OW n;TAPE!
 n = overwrite
 number used
 in Step 5

[33] Type
 LOD:OW:NEW!
 COMPL

[34] Type
 VER:OW:NEW!
 (NOTE 1)

[35] Verify generic
 hashsum values
 using previously
 recorded generic
 hashsum values
 [DLP-693]

AND

[36] Type
 SW:SYC!

[37] Did SYC
 switch with no
 reported
 troubles

Yes

[39] Wait
 15 minutes


No

[38] Perform
 discontinue patch
 procedure for
 overwrite
 number used in
 Step 5 [DLP-701]

Page 6

Issue 3	AUG 1984
233-142-100	DLP
PAGE 5 of 6	702

INSTALL GENERIC PATCH MANUALLY (SO-2 GENERIC)



INSTALL GENERIC PATCH MANUALLY (SO-2 GENERIC)

Issue 3	AUG 1984
233-142-100	DLP
PAGE 6 of 6	702

[1] See FIG. 1. Remove connectors J5 and J6 from rear of CTT

[2] Remove eight mounting screws which secure CTT to TDC

[3] Carefully remove CTT through front of frame

[4] Install CTT from front of frame

[5] Replace eight mounting screws

[6] Replace J5 and J6





FIG. 1 - Rear View of CTT

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	703

REPLACE CARTRIDGE TAPE TRANSPORT (MINIRECORDER)


[1] Connect the clip leads of the 1014A test set to the cable pair tip and ring terminals of an assigned subscriber line [NOTE 1]

[2] On the 1014A test set, set TALK - MON key to TALK



[3] Move 1014A test set clip leads to different assigned subscriber line

[4] Repeat Steps 3 and 4 until all assigned directory numbers (subscriber lines) have been tested



NOTE 1	
For ground start lines, connect one test clip lead to the ring terminal and the other to frame ground	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	704

TEST FOR DIAL TONE FROM SUBSCRIBER LINES

[1] Connect ITE-4674 test set, jack T to the cable and pair of a subscriber line selected for the random sample

[2] On ITE-4674 test set, operate RLD key

[3] From a test telephone, dial the directory number of line selected in Step 2




TABLE A				
CLASS OF SERVICE	LAMP INDICATION FOR CORRECT RINGING POLARITY			
	R-	T-	R+	T+
IFR, PBX, Coin, IFB, other 1 party lines	X			
2FR -- Pty 1	X			
-- Pty 2		X		
4FR -- Pty 1	X			
-- Pty 2		X		
-- Pty 3			X	
-- Pty 4				X
8FR -- Pty 1	X			
-- Pty 2		X		
-- Pty 3			X	
-- Pty 4				X
-- Pty 5	X			
-- Pty 6		X		
-- Pty 7			X	
-- Pty 8				X

NOTE 1
 If ITE-4674 is unavailable, individual telephones wired for party and class of service being tested may be connected to terminals at CDF; to verify ringing applied to line is correct polarity

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 2	705

MAKE CALL TERMINATION AND RINGING POLARITY TEST

[6] On MC TTY type
VER:LINE:TN nxx-xxxx!
to verify that party
number and OE
assignment are correct

[7] Check CDF jumper to
ensure it has been run
correctly between cable
pair and OE assignment



[8] After
errors are
corrected
repeat test
from Step 4

MAKE CALL TERMINATION AND RINGING POLARITY TEST

Issue 3	AUG 1984
233-142-100	DLP
PAGE 2 of 2	705

[1] Obtain information for RC:CKT
 message from Traffic Facilities Group.
 See TABLE A

[2] On MC TTY type
 RC:CKT/
 TYP NEW/
 GRP nnn/
 TER ooo/
 OE gg cws1/
 SP ss rr pp/
 DSP ss rr pp/
 DP p ddd t/
 CKT 7/
 END!




TABLE A	
VARIABLE	DEFINITION
nnn	Trunk Group Number
ooo	Group Member Number
gg	Concentrator Group
c	Concentrator
w	Switch Group
s	Switch
l	Level
ss	Scanner Number
rr	Row Number
pp	Scan Point in the Row
p	Peripheral Pulse Distributor
ddd	Peripheral Decoder
t	Triplet

- [1] Analyze MC TTY message
 OTO ERR yy TN nxx-xxxx OE gg cwsl.
 nxx-xxxx = telephone number
 gg = concentrator group
 c = concentrator
 w = switch group
 s = switch
 l = level
 yy = Trouble Condition [TABLE A]

- [2] Correct faults. See remarks in
 TABLE A



TABLE A

YY	CONDITION TESTED	REMARKS (POSSIBLE TROUBLE AREA)
01	Gnd on ring, battery on tip, should be open circuit	Jumper run in error, crossed cable pair or cable pair half tap
02	Gnd on tip, battery on ring, should be open circuit	Jumper run in error, crossed cable pair or cable pair half tap
03	Battery on tip, should be open circuit	Jumper run in error, crossed cable pair or cable pair half tap
04	Battery on ring, should be open circuit	Jumper run in error, crossed cable pair or cable pair half tap
05	Gnd on tip, should be open circuit	Faulty protectors on 3ESS switch CDF
06	Gnd on ring, should be open circuit	Faulty protectors on 3ESS switch CDF
09	Open between old office and 3ESS switch	Open jumper, open cable pair or protector on 3ESS switch CDF missing
10	Tip and ring are reversed	Jumper on CDF or cable pair tip and ring reversed
11	Wiring of line-attending element in old office does not agree with 3ESS switch translations	Translations in error
12	Line cutoff in old office did not operate as expected	Test distributor or test distributor control circuit

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	707

[1] Analyze MC TTY message OTO COMPL.
See TABLE A _____

[2] Verify that all telephone numbers have
been tested or accounted for _____

[3] Verify clearance of trouble by typing
EX:OTO (nxx,xxx,yyy),GLP!
nxx = Office code
xxxx = First telephone number to
be tested
yyyy = Last telephone number to
be tested _____




TABLE A	
MCC TTY MESSAGE	EXPLANATION OF VARIABLE FIELDS
OTO COMPL aaaa bbbb cccc dddd eeee ffff	aaaa = Total Number Tested bbbb = Total Number with ATP (All Tests Pass) cccc = Total Number of BUSY Conditions on Two Attempts dddd = Total Number Untested* eeee = Total Number Unassigned ffff = Total Number of Errors
* PBX lines, multiline hunt groups, lines with special routing or lines not in precut mode must be tested manually	

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	708

VERIFY OFFICE-TO-OFFICE TESTS MADE ON ALL TELEPHONE NUMBERS

At TTY type:

[1] INIT:TAPE!

[2] RST:TAPE x;UCL!
x = unit 0 or 1

[3] ALW:TAPEUTIL!

AND

[4] Is office
using 3E3 or
later generic

Yes

[6] At TTY type:
AUDIT:TAPE;
DETL,CORR!
[See NOTE 2]

No

[5] At TTY type:
AUDIT:TAPE (aa,bb);
DETL,CORR!
aa - standard tape
[NOTE 1]
bb - compared tape

[7] Did TTY
respond with
AUDIT TAPE MATCH 0
TAPEUTIL STOPPED

Yes

No

[8] Request
assistance in
accordance with
local procedures

NOTES

1. The standard tape is unit (0 or 1) which was not receiving maintenance
2. The master (standard) tape is always assumed to be on unit 0


Issue 3 | AUG 1984

233-142-100 | DLP

PAGE 1 of 1 | 709

[1] From office equipment (OE) number identify the concentrator group (CG), concentrator (C), switch group (SG), switch, and level [NOTE 1]

[2] At distributing frame shelf B, C, D, E, or F locate the OE terminal [FIG. 1]



SECT. A-A
 FIG. 1 - Connecting Blocks for One Concentrator

NOTE 1
 The office equipment number identifies the following:

- Concentrator group (CG)
- Concentrator (C)
- Switch group (SG)
- Switch
- Level

OE gg cws1

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	710

LOCATE OFFICE EQUIPMENT (OE) TERMINAL AT DISTRIBUTING FRAME

- [1] Obtain two tie cable pair assignments between the old and new offices
- [2] Run cross-connections on CDF between office-to-office trunk circuit and tie cable pairs to old office [FIG. 1]
- [3] Run cross-connections on CDF between office-to-office trunk circuit and OE assignment termination [FIG. 1]
- [4] Have personnel in old office connect tip, ring, and sleeve leads [tie cable connections] to old office test distributor






FIG. 1

ESTABLISH TEST CIRCUIT FOR OFFICE-TO-OFFICE TESTS BETWEEN OLD AND NEW OFFICE

Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	711

On Oscilloscope:



NOTE 1	
After voltage probe is connected in test circuit, adjustment of sweep control may be required to display waveform	
Issue 3	AUG 1984
233-142-100	DLP
PAGE 1 of 1	712

CONDITION OSCILLOSCOPE

ITEM	ISSUE										
TPG-000		NTP-035		DLP-501		DLP-536		DLP-571		DLP-606	
• IXL-001		NTP-036		• DLP-502		DLP-537		DLP-572		DLP-607	
NTP-002		NTP-037		DLP-503		DLP-538		DLP-573		DLP-608	
NTP-003		NTP-038		DLP-504		DLP-539		DLP-574		DLP-609	
NTP-004		NTP-039		DLP-505		DLP-540		DLP-575		DLP-610	
NTP-005		NTP-040		DLP-506		DLP-541		DLP-576		DLP-611	
NTP-006		NTP-041		DLP-507		DLP-542		• DLP-577		DLP-612	
NTP-007		NTP-042		DLP-508		DLP-543		DLP-578		DLP-613	
NTP-008		NTP-043		DLP-509		DLP-544		DLP-579		DLP-614	
NTP-009		NTP-044		DLP-510		DLP-545		DLP-580		DLP-615	
NTP-010		NTP-045		DLP-511		DLP-546		DLP-581		DLP-616	
NTP-011		NTP-046		DLP-512		DLP-547		DLP-582		DLP-617	
NTP-012		NTP-047		DLP-513		DLP-548		DLP-583		DLP-618	
NTP-013		NTP-048		DLP-514		• DLP-549		DLP-584		• DLP-619	
NTP-014		TAP-100		DLP-515		DLP-550		DLP-585		DLP-620	
• NTP-015		TAP-101		DLP-516		DLP-551		DLP-586		DLP-621	
NTP-016		TAP-102		DLP-517		• DLP-552		DLP-587		DLP-622	
NTP-017		TAP-103		DLP-518		DLP-553		DLP-588		DLP-623	
• NTP-018		TAP-104		DLP-519		DLP-554		DLP-589		DLP-624	
NTP-019		TAP-105		DLP-520		DLP-555		DLP-590		DLP-625	
NTP-020		TAP-106		DLP-521		DLP-556		DLP-591		DLP-626	
NTP-021		TAP-107		DLP-522		DLP-557		DLP-592		DLP-627	
NTP-022		TAP-108		DLP-523		DLP-558		DLP-593		DLP-628	
NTP-023		TAP-109		DLP-524		DLP-559		DLP-594		DLP-629	
NTP-024		TAP-110		DLP-525		DLP-560		DLP-595		DLP-630	
NTP-025		• TAP-111		DLP-526		DLP-561		DLP-596		DLP-631	
NTP-026		TAP-112		DLP-527		DLP-562		DLP-597		DLP-632	
NTP-027		TAP-113		DLP-528		DLP-563		DLP-598		DLP-633	
NTP-028		TAP-114		DLP-529		DLP-564		DLP-599		DLP-634	
NTP-029		TAP-115		DLP-530		DLP-565		DLP-600		DLP-635	
NTP-030		TAP-116		DLP-531		DLP-566		DLP-601		DLP-636	
NTP-031		• TAP-117		DLP-532		DLP-567		DLP-602		DLP-637	
NTP-032		TAP-118		DLP-533		DLP-568		DLP-603		DLP-638	
NTP-033		TAP-119		DLP-534		DLP-569		DLP-604		DLP-639	
NTP-034		DLP-500		DLP-535		DLP-570		DLP-605		DLP-640	

• REVISED OR ADDED ITEM

□ CANCELED ITEM

Issue 3 AUG 1984

233-142-100

CKL

PAGE 1 of 2

891

CHECKLIST

ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE
DLP-641		DLP-676		DLP-711							
DLP-642		DLP-677		DLP-712							
DLP-643		DLP-678		CKL-891							
DLP-644		• DLP-679		TNG-893							
DLP-645		DLP-680		DPL-895							
DLP-646		DLP-681									
DLP-647		DLP-682									
DLP-648		DLP-683									
DLP-649		DLP-684									
DLP-650		DLP-685									
DLP-651		DLP-686									
DLP-652		• DLP-687									
DLP-653		DLP-688									
DLP-654		DLP-689									
DLP-655		DLP-690									
DLP-656		DLP-691									
DLP-657		DLP-692									
DLP-658		DLP-693									
DLP-659		DLP-694									
DLP-660		DLP-695									
DLP-661		DLP-696									
DLP-662		DLP-697									
• DLP-663		DLP-698									
DLP-664		DLP-699									
DLP-665		DLP-700									
DLP-666		DLP-701									
DLP-667		• DLP-702									
DLP-668		DLP-703									
DLP-669		DLP-704									
DLP-670		DLP-705									
DLP-671		DLP-706									
DLP-672		DLP-707									
DLP-673		DLP-708									
DLP-674		DLP-709									
DLP-675		DLP-710									
<input checked="" type="checkbox"/> REVISED OR ADDED ITEM <input type="checkbox"/> CANCELED ITEM									Issue 3	AUG 1984	
									233-142-100	CKL	
CHECKLIST									PAGE 2 of 2	891	

This book is called a Task Oriented Practice or "TOP". It is a programmed document that gives step-by-step instructions to enable you to do a job (or task). A TOP can be a very useful aid in doing your everyday work if you use it correctly.

An important thing to remember about TOP is that it is a programmed document giving step-by-step instructions to do a job. Since the instructions are given in the order that they must be done, you cannot enter a procedure except at the beginning. You *must* do the step-by-step instructions in the order given. Failure to follow the instructions in the proper order may cause service interruptions.

Another thing to remember about TOP is that it contains all the instructions that you need to do a job. If you are experienced on a particular job, TOP will provide you with just that information you need to do the job. If you are doing the job for the first time, you will be given step-by-step instructions with enough detail so that you will not have to guess or remember where to find the necessary details. Remember that TOP can provide you with just that information you need regardless of your experience in doing a job.

The work that you do can be classified into two broad job categories - *Trouble Clearing* and *Non Trouble Clearing*. This is how TOP defines these two types of work:

Trouble Clearing

Trouble clearing is simply what it says - that work you do to clear and repair troubles in the system. Trouble clearing may be done in answering a customer complaint or in responding to an office alarm, a trouble report, or an abnormal TTY printout, etc.

Non Trouble Clearing

Non trouble clearing is simply what it says - that work you do which is not connected with trouble clearing. This type is work that you do to accept a system after it has been installed, turn up a system for service, maintain a system according to a controlled maintenance plan, etc.

Now glance briefly at the front cover. In the upper right corner is a 9-digit number which identifies the volume. Near the center is the title of the volume which tells you something about the contents, such as the system (or subsystem) name and perhaps what kind of jobs are included in the volume. Next is the decision-action-logic diagram which directs you either to this training package or to 001 depending on your ability to use TOP.

Now turn to FIG. 1 which shows a typical page of 001. In the lower left is the title, "TASK INDEX LIST" which tells you something about this list, such as it is a listing of tasks arranged in alphabetical order. This list is actually a listing of the tasks included in the volume. The tasks are listed in alphabetical order and permuted on key words to simplify locating a task. On the right side of the page is a column of reference numbers under the heading "THEN GO TO." To use this list, locate the job to be done and turn to the reference number in the "THEN GO TO" column.

Now assume that you have been assigned the task of performing a system test on a system covered by a TOP. On 001 in FIG. 1, locate the job "System Test." Notice that this entry tells you to go to NTP-016 (Non Trouble Procedure) under the "THEN GO TO" column. Next you will have to locate the procedure, NTP-016. All procedures in a TOP are arranged in numerical sequence. In actual use of TOP, you would simply turn to the procedure. Look over

	TNG
PAGE 1 of 8	893

FIND YOUR JOB IN THE LIST BELOW	THEN GO TO
Alert; External - Horn, Ringer, Etc. - Remove	NTP-028
Amplifiers; Channel - Recorded Announcement Frame - Test	NTP-009
AR03 PWR ALM RA bb - bb = 16-30	TAP-105
BRDG LED - Does Not Light - Correct	TAP-117
Bridging Controller; Trunk - J1C015MB - Replace	DLP-572
Channel Amplifiers - Recorded Announcement Frame - Test	NTP-009
Drum Wiper - Common Systems Recorded Announcement Frame - Inspect	NTP-010
Extended Station Capability - Nonkey Set Only - Reported Failure	TAP-123
External Alert - Horn, Ringer, Etc. - Remove	NTP-028
Interchange Two Working Station Numbers	NTP-081
LED; BRDG - Does Not Light - Correct	TAP-117
Loudspeaker Paging - Add	NTP-059
Loudspeaker; - Remove	NTP-006
Station Capability; Extended - Nonkey Set Only - Reported Failure	TAP-123
System Test - Perform	NTP-016
Trunk Bridging Controller - J1C015MB - Replace	DLP-572
TTY Printout - AR03 PWR ALM RA bb - bb = 16-30	TAP-105
Wiper; Drum - Common Systems Recorded Announcement Frame - Inspect	NTP-010

TASK INDEX LIST (Contd)	Issue 1	DEC 1980
	123-456-789	IXL
	PAGE 2 of 2	001

FIG. 1

HOW TO USE TOP

	TNG
PAGE 2 of 8	893

the following example which shows a typical page of NTP-016. Note that the items are numbered in the left column. They *must* be completed in that order. You will also note that in item 2 there are some lettered (A, B, C) items. These lettered items are optional ways to do an item, that is you only have to do one of the lettered items.

Remember that this procedure gives you all the items that must be done and the order in which they must be done to complete the job. If you know how to do an item, you should go ahead and do it without going to the referenced details

in the "FOR DETAILS, GO TO" column. If, on the other hand, you need additional details on how to do the item, then you should turn to the procedure listed in the "FOR DETAILS, GO TO" column. In either case, after completing an item, you should continue with the next item.

A TOP is designed so that you have to read only what is necessary to get your job done. If you know how to do an item, look no further for the "how to" information - just do the item and go on to the next item. This idea is called "bypassing" in TOP. In addition to not having to

DO THE ITEMS BELOW IN THE ORDER LISTED		FOR DETAILS, GO TO
1	Obtain Support Apparatus Listed Below: • Hewlett-Packard 3531A Transmission Measuring Set • 2P4C Patching Cord	-
2	Place SEC/SEB in Off-Line Mode	-
	A. If in On-Line Mode, Change System From On-Line to Off-Line	DLP-509
	B. If Powered Down, Condition System for Off-Line Operation as Follows:	-
	1. Power up Minicomputer	DLP-503
	2. Power up Line Printer	DLP-528
	3. Power up Maintenance Terminal	DLP-510
7	Run Computer Display Terminal Test for All Positions	DLP-513
8	Mount Tape	DLP-500
PERFORM SYSTEM TEST		Issue 1 DEC 1980
		123-456-789 NTP
		PAGE 1 of 4 016

HOW TO USE TOP

	TNG
PAGE 3 of 8	893

look further for details, three other ways of "bypassing" are provided in TOP to help you bypass reading information you already know (see FIG. 2):

Summary Statement


A summary statement is used with a procedure to tell you briefly how to do the procedure and what type measurement or result can be observed. If you can do the procedure after reading the summary, go ahead and do it without reading any further. Simple procedures may not have summaries.

Result Statement

A result statement may be used in a flow-charted procedure along with the AND symbol. If, after reading the results statement, you know how to do the action indicated, go ahead and do it without reading the steps associated with the AND symbol.

Support Procedures

When you see the following kind of reference in TOP it refers to a support procedure:
 The support procedure [DLP-530] (Detailed Level Procedure) provides the information on how to




HOW TO USE TOP

operate the VTVM. Here again, if you already know how to operate the VTVM, go ahead and do it without looking up any further information.

Now assume that you are doing a system test on a system covered by a TOP. In the process of doing this test you are instructed to mount a tape. For the purposes of this example, assume that you do not know how to mount the tape and must look up additional details. Figure 2 on Page 5 shows you examples of bypassing that can be used. Take a few moments to examine this figure and make sure you understand the techniques of bypassing.

While using a TOP, you will probably run across a reference similar to this:



This reference to TAP-103 (Trouble Analysis Procedure) indicates that the equipment is not operating correctly, and that you should refer to TAP-103 and clear this trouble condition. After clearing the trouble, you should reenter the flowchart at the beginning (Step 1).





FIG. 2

This idea can be carried further. In some cases, a decision block may have more than one abnormal output. This means that you should try more than one solution to the problem. See the example below.




Trouble-clearing information in TOP is used basically the same way as non trouble-clearing information. When an alarm or trouble report requires you to troubleshoot a system covered by a TOP, the TASK INDEX LIST (IXL-001) is the place to start. After locating your job on IXL-001 you will be referenced to a Trouble Analysis Procedure (TAP) to find the information to aid in the location of the trouble. The TAP may reference to other information, such as Trouble Analysis Data (TAD) or Isolation Diagram (ISD) as an aid in the trouble-clearing process.

Now assume that you have to clear a major alarm on a terminal in a system covered by a TOP. Figure 3 on Page 7 shows how to access and how to use trouble-clearing information.

HOW TO USE TOP

A TOP shows hard-wired and plug-in units on Isolation Diagrams (ISD) in the following manner:



Always do a job safely. Below are three things you should heed in TOP:



DANGER

- means there is a possibility of personal injury



CAUTION

- means there is a possibility of service interruptions



WARNING

- means there is a possibility of equipment damage

TABLE A on Page 8 shows some of the more important symbols and definitions.

While using TOP, if you find errors, or if a procedure is inadequate or missing, call the TOP HOTLINE number shown on the front cover. Your comments are greatly needed to help prepare better documentation. Comments may also be forwarded using form E3973 which is available through your company.

Now that you know how to use TOP, return to IXL-001 and find the job you need to do.

	TNG
PAGE 6 of 8	893

FIND YOUR JOB IN THE LIST BELOW THEN GO TO						
Alert; External - Horn, Ringer, Etc. - Remove	NTP-028						
Alarm - Major - Clear	TAP-109						
TTY Printout - ARO3 PWR ALM RA bb - bb = 16-30	TAP-105						
Wiper; Drum - Common Systems Recorded Announcement Frame	NTP-010						
<table border="1"> <tr> <td>Issue 1</td> <td>DEC 1980</td> </tr> <tr> <td>123-456-789</td> <td>ISD</td> </tr> <tr> <td>PAGE 2 of 2</td> <td>000</td> </tr> </table>		Issue 1	DEC 1980	123-456-789	ISD	PAGE 2 of 2	000
Issue 1	DEC 1980						
123-456-789	ISD						
PAGE 2 of 2	000						
TASK INDEX LIST (Contd)							







FIG. 3

TABLE A IMPORTANT TOP SYMBOLS AND DEFINITIONS	
SYMBOL	DEFINITION
	<p>The AND operation symbol is used where the successful completion of a group of instructions accomplishes a meaningful result that can be defined. The symbol indicates that each input instruction must be performed in the order given to accomplish the output (result statement). In instances where results cannot be defined, results statements are not provided.</p>
	<p>The flow-through symbol relates graphically a single instruction to the expected observable result(s).</p>
	<p>The end-of-procedure symbol denotes that the procedure has been completed.</p>
	<p>The reference bubble symbol indicates an exit from a page (either to a continuation page or to trouble-clearing data) or indicates the starting point of a procedure.</p>
<p>Acceptance (NTP-002)</p>	<p>Acceptance gives an overview of the acceptance techniques and facilities.</p>
<p>Maintenance Philosophy (TAD-100)</p>	<p>The maintenance philosophy, when provided, gives an overview of the considerations designed into the trouble-clearing procedures.</p>
<p>Checklist (CKL-891)</p>	<p>The checklist reflects the volume content (inventory) at any given time, the issue identifier of each data element therein, those data elements revised and/or added, and those data elements deleted from a previous issue.</p>
<p>Documentation Plan (DPL-895)</p>	<p>The documentation plan gives a bird's-eye view of all the TOP volumes covering a system. This plan can help you to quickly determine the correct volume.</p>

**3ESS SWITCH
TOP DOCUMENTATION**

3ESS Switch	
Office Equipment	233-142-100
Routine Data	
Acceptance Data	
Company Order Data	
Remote Office Test Line	233-142-110
Acceptance Data	
System Trouble Clearing	233-143-100
Power Equipment	233-144-100
Routine Data	
Acceptance Data	