

**AT&T WESTERN ELECTRIC PRACTICES**  
**Provisional**

**Task Oriented Practice**  
**(TOP)**

**REMOTE OFFICE TEST LINE (ROTL)**

**WITH MINI-REMOTE TRUNK TEST UNIT (MINI-RTTU) APPLICATION**

**3"ESS" SWITCH**

**NOTICE**

Not for use or disclosure outside the  
AT&T Companies except under written agreement

Printed in U.S.A.

<b>Issue 2</b>	<b>DEC 1983</b>
<b>233-142-110</b>	<b>TP6</b>
<b>TITLE PAGE</b>	<b>000</b>



**FIND YOUR JOB IN THE LIST BELOW . . . . . THEN GO TO**

105-Type Test Line Buildout - Perform . . . . .	NTP-006
Acceptance . . . . .	NTP-002
Centralized Automatic Reporting on Trunks (CAROT) Reported Troubles - Clear . . . . .	TAP-114
Mini-RTTU Loss Build-out Adjustments - Perform . . . . .	NTP-009
Remote Office Test Line (ROTL) Buildout - Perform Using 92A Control Unit . . . . .	NTP-008
ROTL Buildout - Perform Using H-310-150 ROTL System Test Set . . . . .	NTP-005



Acceptance tests are performed by operating company personnel to verify that newly installed remote office test line (ROTL) equipment is capable of operating properly and that associated translations are correct.

When performing acceptance tasks for ROTL system, any troubles should be referred to the Western Electric Company installation group for correction. Since many of the tests performed for acceptance are later performed as office routines, many data elements (DLPs) contain references to trouble analysis procedures (TAPs). These TAPs may be useful in resolving any troubles that occur during acceptance testing, but final responsibility lies with the Installation Group to correct any troubles.

Verify that tests in Western Electric Company Handbook 269, Section 613 have been performed.

If the H-310-150 ROTL System test set is to be used when the acceptance tests are performed, perform the following acceptance tasks in the order listed:

TASK	PROCEDURE
1. Accept Mini-ROTL Unit	NTP-003
2. Perform ROTL Buildout Using H-310-150 ROTL System Test Set	NTP-005
3. Perform 105-Type Test Line Buildout	NTP-006
4. Accept ROTL System Overall Using H-310-150 ROTL System Test Set	NTP-004

If the 92A control unit is to be used when the acceptance tests are performed, perform the following acceptance tasks in the order listed:

TASK	PROCEDURE
1. Accept Mini-ROTL Unit	NTP-003
2. Perform ROTL Buildout Using 92A Control Unit	NTP-008
3. Perform 105-Type Test Line Buildout	NTP-006
4. Accept ROTL System Overall Using 92A Control Unit	NTP-007

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

1	Obtain Support Apparatus Listed Below: <ul style="list-style-type: none"> <li>• EXECUPORT Data Terminal or Equivalent With the Following Characteristics: 110-Baud Data Rate, American Standard Code for Information Interchange (ASCII Code) Electronic Industries Association (EIA) RS-232 Serial Interface Jack and Connecting Cable Accoustical Coupler and Modem or Equivalent Full-Duplex Capability Upper Case Keyboard</li> <li>• KS-4442A Voltohmmeter or Equivalent General Use Voltohmmeter</li> <li>• Two 2P4A Cords</li> </ul>	-
2	From Office Records Form 3100, Identify and Record Telephone Numbers (TNs) and Office Equipment (OE) Numbers for 105A- (ETYP 34) and 105B- (ETYP 35) Test Lines	-
3	For Each 105-Type Test Line Identified in Item 2, at Maintenance TTY, Type: RMV:LINE (a,bcde), TN fg! (a,bcde = OE Number) (fg = Telephone Number)	-
4	At Maintenance TTY, Type: RMV:SVC (103,0);UCL!	-
5	Set Up Data Terminal	DLP-513
6	Perform Central Processing Unit (CPU) Diagnostic Test - TE CP	DLP-514
7	Perform Diagnostic and Running Checksum Diagnostic Test - TE DC and TE RC	DLP-515
8	Perform Random Access Memory (RAM) Diagnostic Test - TE RA	DLP-516
9	Perform Multiplex Diagnostic Test - TE MU	DLP-517
10	Perform Message Channel Diagnostic Test - TE MC	DLP-518
11	Perform Remote Office Test Line (ROTL) Tones Diagnostic Test - TE RT	DLP-519
12	Perform Trunk Tones Diagnostic Test - TE TT	DLP-520
13	Perform Tone Detector Diagnostic Test - TE TD	DLP-521
	(Continued on Page 2)	

Issue 2	DEC 1983
233-142-110	NTP
PAGE 1 of 2	003

**ACCEPT MINI-ROTL UNIT**

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

14	Perform Multifrequency (MF) Detector Diagnostic Test - TE MF	DLP-522
15	Perform 105-Test Line Diagnostic Test - TE TL	DLP-523
16	Perform Port Select Relays Diagnostic Test - TE TR	DLP-524
17	Perform Port Continuity Relay Diagnostic Test - TE RO	DLP-525
18	Perform Hold Coil and Pulsing Relay Diagnostic Test - TE HB	DLP-526
19	Perform USART Diagnostic Test - TE 37	DLP-555
20	Check Responder Alignment	DLP-511
21	Remove Test Cord Between Mini-ROTL EIA Jack and Data Terminal	-
22	At Maintenance TTY, for Each 105-Type Test Line Removed From Service in Item 3, Type: RST:LINE (a,bcde), TN f g!	--
23	At Maintenance TTY Type: RST:SVC(103,000)!	-
24	At Mini-ROTL CP 19, Depress PWR OFF Switch to Turn Power Off	-
25	At Rear of Mini-ROTL, Plug in Connector P4	-
26	At Mini-ROTL, Restore Power	DLP-530
27	Check Dialup Connection	DLP-512

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

1	Obtain Support Apparatus Listed Below: <ul style="list-style-type: none"> <li>• ROTL System Test Set (RSTS) H-310-150</li> <li>• Two 3P15A Cords</li> </ul>	-
2	From Office Records Select: <ul style="list-style-type: none"> <li>• An Outgoing Trunk Circuit Which Terminates in an Office Equipped With a 100-Type Test Line (Balance Test Line Termination ETYP 25)</li> <li>• An Outgoing Trunk Circuit Which Terminates in an Office Equipped With a 102-Type Test Line (Interrupted Milliwatt Test Line Termination ETYP 26)</li> <li>• An Outgoing Trunk Circuit Which Terminates in an Office Equipped With a 105-Type Test Line</li> </ul>	-
3	For Each Trunk Circuit Identified in Item 3, Record: <ul style="list-style-type: none"> <li>• Trunk Group Number (TGN)</li> <li>• Member Number (MEM)</li> <li>• Test Line Directory Number</li> <li>• Estimated Measured Loss (EML)</li> <li>• Noise Requirement</li> </ul>	-
4	From Office Records Identify and Record: <ul style="list-style-type: none"> <li>• ROTL Access Port Directory Number</li> <li>• 105-Test Line No. 1 Directory Number and Office Equipment Number</li> <li>• 105-Test Line No. 2 Directory Number and Office Equipment Number</li> </ul>	-
5	Determine List Number of ROTL System Test Set	DLP-500
6	Perform ROTL System Test Set Self-Check Using A or B	-
	A. For Lists 1 Through 3	DLP-501
	B. For List 4	DLP-510
7	Using 3P15A Cord, Connect Tip and Ring Jack to Working Telephone Line	-
	(Continued on Page 2)	

**ACCEPT ROTL SYSTEM OVERALL USING H-310-150 ROTL SYSTEM TEST SET**

Issue 2	DEC 1983
233-142-110	NTP
PAGE 1 of 2	004

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

8	Assign Security Callback User No. 5 to Trunk and Line Test Panel Access Trunk 1	DLP-532
9	Access ROTL Port	DLP-509
10	Make Security Callback Unlock Request	DLP-502
11	Using One of the Trunk Circuits Identified in Item 3, Make Trunk Status Request	DLP-507
12	Using the Trunk Circuit Which Was Status Checked in Item 11, Make Busy and Restore Trunk Circuit	DLP-508
13	Using Test Line Data Recorded in Item 4, Test 105-Type Test Line Access	DLP-506
14	Using Trunk Data Recorded in Item 3, Test ROTL - 100-Type Test Line at Far End	DLP-503
15	Using Trunk Data Recorded in Item 3, Test ROTL - 102-Type Test Line at Far End	DLP-504
16	Using Trunk Data Recorded in Item 3, Test ROTL - 105-Type Test Line at Far End	DLP-505

**ACCEPT ROTL SYSTEM OVERALL USING H-310-150 ROTL SYSTEM TEST SET**

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

1	Obtain Support Apparatus Listed Below: <ul style="list-style-type: none"> <li>• EXECUPORT Data Terminal or Equivalent With the Following Characteristics:                 <ul style="list-style-type: none"> <li>110-Baud Data Rate (ASCII Code)</li> <li>EIA RS-232 Serial Interface Jack and Connecting Cable</li> <li>Accoustical Coupler and Modem or Equivalent</li> <li>Full-Duplex Capability</li> <li>Upper-Case Keyboard</li> </ul> </li> <li>• ROTL System Test Set (RSTS) H-310-150</li> <li>• Reference Level Test Set (RTS) WILCOM<sup>®</sup> T 105 B Equipped With Power Cord</li> <li>• Low Loss Test Cord Arranged for Connection to 310-Type Jacks</li> <li>• Two 3P15A Cords</li> <li>• One ED-35136-30 Circuit Pack Extender</li> </ul>	-
2	Determine List Number of ROTL System Test Set	DLP-500
3	Perform ROTL System Test Set Self-Check Using A or B	-
	A. For Lists 1 Through 3	DLP-501
	B. For List 4	DLP-510
4	Using 3P15A Cord, Connect Tip and Ring Jack to Working Telephone Line	-
5	Assign Security Callback User No. 5 to Trunk Line Test Panel Access Trunk 1	DLP-532
6	At Mini-ROTL, Extend CP 16	DLP-528
7	At CP 17, Verify That 105 Test Line Impedance and Level Straps Are in Place	DLP-537
8	Establish Office Connections to Mini-ROTL TUT PORT	DLP-531
9	Set Up Reference Level Test Set	DLP-535
10	Using Low Loss Cord Provided With Reference Level Test Set (RTS), Connect RTS 310 INPUT Jack to Trunk and Line Test Panel ACCESS TRUNK 1 Jack; Remove and Insert Plugs Several Times to Polish Contacts	-
11	Set Up Data Terminal Without Powering Down	DLP-540
	(Continued on Page 2)	

\* Registered trademark of Wilcom Products Inc.

**PERFORM ROTL BUILDOUT USING H-310-150 ROTL SYSTEM TEST SET**

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

12	Set Data Terminal Switches for 110 Baud, Full Duplex, On-Line	-
13	At Mini-ROTL, Adjust CP 16 Potentiometer R2(TUT) for 0-Ohm dBm Indications at RTS	DLP-536
14	At Trunk and Line Test Panel, Momentarily Depress <b>RELEASE 1</b> Key, Then Momentarily Depress <b>ON</b> Key	-
15	Remove Reference Level Test Set	-
16	Remove ROTL System Test Set	-
17	Remove Data Terminal	-
18	Remove Extended CP 16 and Reinstall Without Extender	DLP-529

--	--	--

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

1	Obtain Support Apparatus Listed Below: <ul style="list-style-type: none"> <li>• EXECUPORT Data Terminal or Equivalent With the Following Characteristics:  110-Baud Data Rate (ASCII Code)  <b>EIA RS-232</b> Serial Interface Jack and Connecting Cable  Accoustical Coupler and Modem or Equivalent  Full-Duplex Capability  Upper-Case Keyboard</li> <li>• Reference Level Test Set (RTS) <b>WILCOM</b> <sup>*</sup>T 105 B Equipped With Power Cord</li> <li>• Low Loss Cord Arranged for Connection to 310-Type Jacks</li> <li>• <b>ED-35136-30</b> Circuit Pack Extender</li> </ul>	-
2	From Office Records Form 3100, Identify Telephone Numbers (TNs) and Office Equipment (OE) Numbers for 105A- (ETYP 34) and 105B- (ETYP 35) Test Lines	-
3	At Maintenance TTY, Remove 105A- and 105B-Test Lines From Service. For Each Test Line, Enter: <ul style="list-style-type: none"> <li>• <b>RMV:LINE(a,bcde),TN f g!</b>  (a,bcde = Office Equipment Number)  (f g = Telephone Number)</li> </ul>	-
4	Remove ROTL Access Port From Service. Enter: <b>RMV:SVC(103,0);UCL!</b>	-
5	Extend CP 16	DLP-528
6	At CP 17, Verify That Impedance and Level Straps Are in Place	DLP-537
7	Near Combined Distributing Frame, Set Up Reference Level Test Set	DLP-535
8	Set Up Data Terminal	DLP-513
9	Build Out 105A Test Line	DLP-538
10	At TLTP, Depress <b>ON</b> Switch to Extinguish Lamp	-
11	Build Out 105B Test Line	DLP-539
	(Continued on Page 2)	

\* Registered trademark of Wilcom Products, Inc.

**PERFORM 105-TYPE TEST LINE BUILDOUT**

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

12	Release Trunk and Line Test Panel: • Momentarily Depress <b>ON</b> Key • Remove Test Cords	-
13	Remove Reference Level Test Set and Test Cord Connections	-
14	At Maintenance TTY Restore ROTL Access Port to Service, Enter: <b>RST:SVC(103,0)!</b>	-
15	Restore 105A- and 105B-Test Lines to Service; For Each Test Line, Enter: <b>RST:LINE(a,bcde),TN f g!</b>	-
16	Remove Extended CP 16 and Reinstall Without Extender	DLP-529

**PERFORM 105-TYPE TEST LINE BUILDOUT**

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

1	Obtain Support Apparatus Listed Below: <ul style="list-style-type: none"> <li>• 92A Control Unit</li> <li>• 225A Adapter</li> <li>• Two 3P15A Cords</li> </ul>	-
2	From Office Records Select: <ul style="list-style-type: none"> <li>• An Outgoing Trunk Circuit Which Terminates in an Office Equipped With a 100-Type Test Line (Balance Test Line Termination ETYP 25)</li> <li>• An Outgoing Trunk Circuit Which Terminates in an Office Equipped With a 102-Type Test Line (Interrupted Milliwatt Test Line Termination ETYP 26)</li> <li>• An Outgoing Trunk Circuit Which Terminates in an Office Equipped With a 105-Type Test Line</li> </ul>	-
3	For Each Trunk Circuit Identified in Item 3, Record: <ul style="list-style-type: none"> <li>• Trunk Group Number (TGN)</li> <li>• Member Number (MEM)</li> <li>• Test Line Directory Number</li> <li>• Estimated Measured Loss (EML)</li> <li>• Noise Requirement</li> </ul>	-
4	From Office Records Identify and Record: <ul style="list-style-type: none"> <li>• ROTL Access Port Directory Number</li> <li>• 105-Test Line No. 1 Directory Number and Office Equipment Number</li> <li>• 105-Test Line No. 2 Directory Number and Office Equipment Number</li> </ul>	-
5	Perform 92A Control Unit Self-Tests	DLP-541
6	Assign Security Callback User No. 5 to Trunk Line Test Panel Access Trunk 1	DLP-532
7	At 92A Control Unit, Access ROTL Port	DLP-542
8	Make Security Callback Unlock Request	DLP-543
	(Continued on Page 2)	

**ACCEPT ROTL SYSTEM OVERALL USING 92A CONTROL UNIT**

Issue 2	DEC 1983
233-142-110	NTP
PAGE 1 of 2	007

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

9	Using One of the Trunk Circuits Identified in Item 3, Make Trunk Status Request	DLP-544
10	Using the Trunk Circuit Which Was Status Checked in Item 9, Make Busy and Restore Trunk Circuit	DLP-545
11	Using Test Line Data Recorded in Item 4, Test 105-Type Test Line Access	DLP-506
12	Using Trunk Data Recorded in Item 3, Test ROTL - 100-Type Test Line at Far End	DLP-546
13	Using Trunk Data Recorded in Item 3, Test ROTL - 102-Type Test Line at Far End	DLP-547
14	Using Trunk Data Recorded in Item 3, Test ROTL - 105-Type Test Line at Far End	DLP-548

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

1	Obtain Support Apparatus Listed Below: <ul style="list-style-type: none"> <li>• EXECUPORT Data Terminal or Equivalent With the Following Characteristics:                      110-Baud Data Rate (ASCII Code)                      EIA RS-232 Serial Interface Jack and Connecting Cable                      Accoustical Coupler and Modem or Equivalent                      Full-Duplex Capability                      Upper-Case Keyboard</li> <li>• 92A Control Unit</li> <li>• Reference Level Test Set (RTS) WILCOM<sup>*</sup>T 105 B Equipped With Power Cord</li> <li>• Low Loss Test Cord Arranged for Connection to 310-Type Jacks</li> <li>• Two 3P15A Cords</li> <li>• One ED-35136-30 Circuit Pack Extender</li> </ul>	-
2	Perform 92A Control Unit Self-Tests	DLP-541
3	Assign Security CallBack User No. 5 to Trunk and Line Test Panel Access Trunk 1	DLP-532
4	At Mini-ROTL, Extend CP 16	DLP-528
5	At CP 17, Verify That 105-Test Line Impedance and Level Straps Are in Place	DLP-537
6	Establish Office Connections to Mini-ROTL TUT PORT	DLP-549
7	At Trunk and Line Test Panel (TLTP), Set Up Reference Level Test Set	DLP-535
8	Using Low Loss Cord Provided With Reference Level Test Set, Connect RTS 310 INPUT Jack to Trunk and Line Test Panel ACCESS TRUNK 1 Jack; Under Writing Table, Remove and Insert Plugs Several Times to Polish Contacts	-
9	Set Up Data Terminal	DLP-513
10	Set Data Terminal Switches for 110 Baud, Full Duplex, On-Line	-
11	At Mini-ROTL, Adjust CP 16 Potentiometer R2(TUT) for 0-Ohm dBm Indications at RTS	DLP-536
12	At Trunk and Line Test Panel, Momentarily Depress RELEASE 1 Key, Then Momentarily Depress ON Key	-
	(Continued on Page 2)	

\* Registered trademark of Wilcom Products, Inc.

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

13	Remove Reference Level Test Set	-
14	Remove 92A Control Unit	-
15	Remove Data Terminal	-
16	Remove Extended CP 16 and Reinstall Without Extender	DLP-529

**PERFORM ROTL BUILDOUT USING 92A CONTROL UNIT**

Issue 2	DEC 1983
233-142-110	NTP
PAGE 2 of 2	008

**DO THE ITEMS BELOW IN THE ORDER LISTED . . . . . FOR DETAILS, GO TO**

1	Obtain Support Apparatus Listed Below: <ul style="list-style-type: none"> <li>• Portable Data Terminal With <b>EIA RS 232</b> Interface Capabilities</li> <li>• <b>WILCOM* T 105 B</b> (or Equivalent) Reference Level Test Set (RTS)</li> <li>• Low Loss Test Cord With 310-Type Jacks on Both Ends</li> <li>• <b>914A</b> Tool (Extender Circuit Pack)</li> <li>• Directory Number of <b>ACCESS TRUNK 2</b> at TLTP</li> </ul>	-
2	Prepare <b>Mini-RTTU</b> for Loss Build-out Adjustments	DLP-550
3	Prepare <b>WILCOM T 105 B</b> Reference Level Test Set (RTS) for <b>Mini-RTTU</b> Loss Build-out Measurements	DLP-551
4	Adjust <b>Mini-RTTU</b> Loss Buildout	DLP-552
5	Depress the <b>POWER</b> Switch on the <b>WILCOM T 105 B</b> RTS to Turn Power Off	-
6	Disconnect <b>WILCOM T 105 B</b> Reference Level Test Set (RTS) From TLTP	-
7	Restore <b>Mini-RTTU</b> to Normal	DLP-553
<p>* Registered trademark of Wilcom Products, Inc.</p>		

**PERFORM MINI-RTTU LOSS BUILD-OUT ADJUSTMENTS**

[1] Obtain support apparatus  
[TABLE A]

[2] Using cord provided with RTS,  
connect RTS to ac outlet near  
mini-ROTL

[3] At data terminal, enter:  
AL 01

[4] Extend CP 5  
[DLP-528]

[5] Enter:  
AL 01

[6] Momentarily depress SPACE bar

[7] Using cord provided with  
RTS, connect RTS INPUT  
jack to mini-ROTL T,R  
jack

[8] Set RTS switches for  
600 ohms OTLP  
[TABLE B]






TABLE A		
QUANTITY	IDENTIFICATION	DESCRIPTION
1	R-1005	Jeweler's Screwdriver Set
1	258C	Plastic Busy Plug
1	425C	Shorting Plug
1	ED-35136-30	Extender
1	Reference Level Test Set (RTS) WILCOM* T 105 B	

TABLE B	
SWITCH	POSITION
METER RANGE	±.1DB
INPUT LEVEL	
-30 to +10	0
-9 to 0	0
-.9 to 0	0
INPUT	600 Ω DBM TERM
FUNCTION	MEAS INPUT
OUTPUT	OFF

Page 2


\* Registered trademark of Wilcom Products, Inc.

**ALIGN RESPONDER**




**ALIGN RESPONDER**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 2 of 23	100




[30] Momentarily depress  
SPACE bar

[31] At RTS, set INPUT  
LEVEL switch to  
-14 dBm



**ALIGN RESPONDER**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 4 of 23	100



**ALIGN RESPONDER**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 5 of 23	100

[42] Remove extended CP 5 and reinstall  
without extender [DLP-529]


[43] Extend CP 6 [DLP-528]

[44] At data terminal, enter:  
AL 02

[45] Momentarily depress SPACE bar


[46] Connect RTS to MWR jack at  
mini-ROTL [NOTE 1]


[47] Set RTS INPUT switch to  
600  $\Omega$  DBM TERM



**ALIGN RESPONDER**


<b>NOTE 1</b>	
All connections between RTS and mini-ROTL jacks are made with low loss cord provided with RTS	
<b>Issue 2</b>	<b>DEC 1983</b>
<b>233-142-110</b>	<b>TAP</b>
<b>PAGE 6 of 23</b>	<b>100</b>





**ALIGN RESPONDER**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 8 of 23	100



[71] Remove extended CP 6 and  
reinstall without extender  
[DLP-529]


[72] Extend CP 7 [DLP-528]

[73] At data terminal, enter:  
AL 03

[74] Momentarily depress SPACE bar


[75] Strap MWR jack to  
T,R jack


[76] Momentarily depress SPACE bar



**ALIGN RESPONDER**


Issue 2	DEC 1983
233-142-110	TAP
PAGE 10 of 23	100






**ALIGN RESPONDER**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 12 of 23	100




**ALIGN RESPONDER**


Issue 2	DEC 1983
233-142-110	TAP
PAGE 13 of 23	100



**ALIGN RESPONDER**


Issue 2	DEC 1983
233-142-110	TAP
PAGE 14 of 23	100






**ALIGN RESPONDER**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 16 of 23	100





**ALIGN RESPONDER**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 18 of 23	100





TABLE C	
CONTROL	POSITION
TEST PREPARATION	105-0-900
TEST REQUEST	SCK ALL
INTERROGATOR START	OFF
TST	ON HOOK
ROS	DIAL
SELECT	SMALL
DB INSERTION PADS	Normal (Nos. not visable)
VOL	Full clockwise

Issue 2	DEC 1983
233-142-110	TAP
PAGE 19 of 23	100



DB INSERTION PADS  
SLIDE SWITCHES

MF DIGITS  
ROTARY SWITCHES

FIG. 1 - ROTL System Test Set (H-310-150)

**ALIGN RESPONDER**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 20 of 23	100





TABLE D			
ITEM	DIGITAL READOUT	LAMPS LIGHTED	RESPONDER ANSWERS WITH THREE TONES
1	+00.0	ON, SCK, DATA RDY, NEW, N-E F-N, ODBM	Yes
2	-00.0	ON, SCK, NEW, F-E N-F, ODBM	No
3	-000	ON, SCK, NEW, N-E F-N, NOISE	No
4	+000	ON, SCK, DATA RDY, NEW, F-E N-F, NOISE	Yes
5	+00.0	ON, SCK, DATA RDY, NEW, N-E F-N, 400 HZ	Yes
6	-00.0	ON, SCK, NEW, F-E N-F, 400 HZ	No
7	+00.0	ON, SCK, DATA RDY, NEW, N-E F-N, 1K HZ	Yes
8	-00.0	ON, SCK, NEW, F-E N-F, 1K HZ	No
9	+00.0	ON, SCK, DATA RDY, NEW, N-E F-N, 2.8K HZ	Yes
10	-00.0	On, SCK, NEW, F-E N-F, 2.8K HZ	Yes
11	+00.0	ON, SCK, DATA RDY, NEW, N-E F-N, NOISE TONE	Yes
12	-00.0	ON, SCK, DATA RDY, NEW, F-E N-F, NOISE TONE	No

**NOTE 2**  
 If the responder times out, then the 105A test line would have to be redialed (Step 142)


Issue 2	DEC 1983
233-142-110	TAP
PAGE 21 of 23	100

**ALIGN RESPONDER**



**ALIGN RESPONDER**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 22 of 23	100







TABLE A		
EXPECTED PRINTOUT	TROUBLE INDICATION	REPLACEMENT CIRCUIT PACK
01 IS AN INOPERATIVE PORT	PORT 5 INOPERATIVE	CP 12
02 IS AN INOPERATIVE PORT		
03 IS AN INOPERATIVE PORT		
04 IS AN OK PORT		
05 IS AN OK PORT	PORT 11 INOPERATIVE	CP 17
06 IS AN INOPERATIVE PORT		
07 IS AN INOPERATIVE PORT		
08 IS AN INOPERATIVE PORT		
09 IS AN INOPERATIVE PORT		
10 IS AN INOPERATIVE PORT		
11 IS AN OK PORT		
12 IS AN INOPERATIVE PORT		
13 IS AN INOPERATIVE PORT		
14 IS AN INOPERATIVE PORT		
15 IS AN INOPERATIVE PORT		
-	All ports inoperative	CP 18 (or CP 38), CP 14 (or CP 36)

NOTE 1	
Port 04 indicates an OK port because CP 15 is not removed	
Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 2	101

**CLEAR MULTIPLEX DIAGNOSTIC TEST TROUBLE —  
TEST WILL NOT RUN**



**WARNING 1**  
*Pins in the backplane are fragile and easily bent. The circuit pack should slide smoothly with perceptible tension as the pins and connector engage*

Issue 2	DEC 1983
233-142-110	TAP
PAGE 2 of 2	101


**CLEAR MULTIPLEX DIAGNOSTIC TEST TROUBLE --  
 TEST WILL NOT RUN**




[1] Identify trouble indication and replacement circuit pack(s) [TABLE A]

[2] Replace first circuit pack not previously replaced [DLP-527]


[3] Enter:  
TE MU \_\_\_\_\_




Yes



Yes



No



No




TABLE A	
TROUBLE INDICATION (NOTE)	REPLACEMENT CIRCUIT PACK
All equipped ports inoperative	CP 14 (or CP 36) CP 18 (or CP 38)
Some but not all equipped ports inoperative	
01 IS AN INOPERATIVE PORT	CP 5
02 IS AN INOPERATIVE PORT	CP 6
03 IS AN INOPERATIVE PORT	CP 6
04 IS AN INOPERATIVE PORT	CP 15
05 IS AN INOPERATIVE PORT	CP 12
07 IS AN INOPERATIVE PORT	CP 16
08 IS AN INOPERATIVE PORT	CP 21
11 IS AN INOPERATIVE PORT	CP 17
12 IS AN INOPERATIVE PORT	CP 7
13 IS AN INOPERATIVE PORT	CP 7
NOTE: Inoperative ports 6, 9, 10, 14, and 15 are OK. They are not equipped.	

**CLEAR MULTIPLEX DIAGNOSTIC TEST TROUBLE --  
INOPERATIVE PORTS**

[1] See TABLE A and identify test and failure indication

[2] Replace first circuit pack not previously replaced [DLP-527]





TABLE A			
TEST THAT FAILED	FAILURE INDICATION	CIRCUIT PACK REPLACEMENTS	CORRECT INDICATION
TE CP	CPU not OK	CP 18 (or CP 38), CP 14 (or CP 36)	CP OK
TE DC	CHECKSUM not OK	CP 14 (or CP 36)	CHECKSUM OK
TE RC	CHECKSUM not OK	CP 14 (or CP 36)	CHECKSUM OK
TE RA	RAM not OK	CP 18 (or CP 38), CP 14 (or CP 36)	RAM OK

NOTE 1	
If ports 1 through 5, 7, 8, and 11 through 13 are OK, MONITOR RUNNING STATE REQUEST is printed	
Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 2	103

**CLEAR DIAGNOSTIC TEST TROUBLE BY CIRCUIT PACK REPLACEMENT**




**CLEAR DIAGNOSTIC TEST TROUBLE BY CIRCUIT PACK REPLACEMENT**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 2 of 2	103

[1] At front of **mini-ROTL**, remove connector at **MSG** jack and install at **EIA** jack

[2] Replace CP 17 [DLP-527]

[3] Enter:  
TE MC



### CLEAR MESSAGE CHANNEL DIAGNOSTIC TEST TROUBLE

Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 1	104







TABLE A (NOTE)		
TROUBLE CONDITION	CORRECTIVE ACTION (NOTE)	PROCEDURE
LOW tone (480 and 620 Hz) not heard	1. Replace CP 15 2. Replace CP 9	DLP-527 DLP-527
TPT tone not heard	1. Replace CP 15 2. Replace CP 9	DLP-527 DLP-527
GUARD tone (1200 Hz) not heard	1. Replace CP 15 2. Replace CP 9	DLP-527 DLP-527
TEST PROGRESS tone not heard after TPT FROM AGC printout	1. Replace CP 15 2. Replace CP 9 3. Replace CP 6	DLP-527 DLP-527 DLP-527
Tone level did not increase when indicated by printout	1. Adjust tone level at VOL potentiometer on CP 15 2. Replace CP 15	- DLP-527

NOTE: Only one circuit pack at a time should be replaced



<b>NOTE 1</b>	
Inoperative ports 6, 9, 10, 14, and 15 are OK. They are not equipped	
Issue 2	DEC 1983
233-142-110	TAP
PAGE 2 of 2	105





TABLE A	
TRUBLE CONDITION (NOTE)	CORRECTIVE ACTION (NOTE)
GUARD tone not heard	1. Replace CP 6 2. Replace CP 15
Milliwatt tone not heard	1. Replace CP 5 2. Replace CP 6
TPT tone not heard	1. Replace CP 15
MF 7 tone not heard	1. Replace CP 17
MF 9 tone not heard	
MF 11 tone not heard	
MF 13 tone not heard	
MF 15 tone not heard	
MF 17 tone not heard	
LT thru AGC tone not heard	1. Replace CP 15
405 Hz tone not heard*	1. Replace CP 5
2408 Hz tone not heard	1. Replace CP 5
NOTE: 405-Hz tone may be difficult to hear. To increase volume, hit <b>HOLD</b> key and adjust <b>VOL</b> potentiometer at CP 15. Restore volume to previous level after adjusting for 405 Hz	

Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 2	106



NOTE 1	
Inoperative ports 6, 9, 10, 14, and 15 are OK. They are not equipped	
Issue 2	DEC 1983
233-142-110	TAP
PAGE 2 of 2	106

[1] At rear of mini-ROTL, plug in connector P4 to 3ESS\* switch

[2] At CP 15, set TUT switch to down position

[3] Identify trouble condition and corrective action [TABLE A]

[4] Replace first circuit pack not previously replaced [DLP-527]

AND

[5] Enter:  
TE MU

[6] Did printout indicate test results

No

TAP-101

Yes

[7] Did printout indicate inoperative ports other than those listed in NOTE 1

No

Page 2

Yes

TAP-102


TABLE A


TROUBLE INDICATION	CIRCUIT PACK REPLACEMENT
TPT BIT ERROR, LT BIT SET, or MW BIT IS SET	CP 12 CP 6 CP 15
MW BIT ERROR, LT BIT ERROR, TPT BIT IS SET, BIT ERROR (BAL INPUT), or BIT ERROR (UNBAL INPUT)	CP 12

\* Trademark of Western Electric

NOTE 1 Inoperative ports 6, 9, 10, 14, and 15 are OK. They are not equipped	
Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 2	107


CLEAR TONE DETECTOR DIAGNOSTIC TEST TROUBLE





<b>NOTE 1</b>	
Inoperative ports 6, 9, 10, 14, and 15 are OK. They are not equipped	
Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 2	108

**CLEAR MF DETECTOR DIAGNOSTIC TEST TROUBLE**



**CLEAR MF DETECTOR DIAGNOSTIC TEST TROUBLE**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 2 of 2	<b>108</b>






TABLE A	
TEST FAILURE INDICATION	CIRCUIT PACK REPLACEMENT
105 A circuit 105 B circuit	CP 16, CP 21

Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 2	109




**CLEAR 105-TEST LINE DIAGNOSTIC TEST TROUBLE**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 2 of 2	109



**CLEAR PORT SELECT RELAYS DIAGNOSTIC TEST TROUBLE**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 2	110



**CLEAR PORT SELECT RELAYS DIAGNOSTIC TEST TROUBLE**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 2 of 2	110

[1] Identify trouble condition [TABLE A]

[2] Replace first indicated circuit pack [TABLE A] [DLP-527]

[3] Enter: TE MU





TABLE A	
TROUBLE INDICATION	CIRCUIT PACK REPLACEMENT
TCS relay failure	CP 16 CP 15
ROH relay failure	CP 15 CP 16

**CLEAR PORT CONTINUITY RELAY DIAGNOSTIC TEST TROUBLE**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 1	111



**CLEAR COIL AND PULSING RELAY DIAGNOSTIC TEST TROUBLE**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 1	112




TABLE A	
P4 CONNECTOR	
ROTL PIN NO.	TTYC PIN NO.
2	14
3	16
7	7
8	8
ROTL PIN NO.	HMDF ROTL BLOCK
9	CAR
10	CAT
11	TUTT
12	TUTR
13	RT
14	RR
15	TCN2
16	RCN2
17	TCN1
18	RCN1

**NOTE 1**  
 The cabling diagram of connector P4 is found on CAD1 of SD-99392-01

Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 10	113

**CLEAR MINI-ROTL ACCESS TROUBLE CONDITION**

[6] At maintenance TTY, verify TTYC mini-ROTL port translations. Enter:  
**VER:LINE TN f g!**  
 (f g = telephone number of TTYC mini-ROTL port)

[7] Does printout of translations agree with FIG. 1  
 [NOTES 2 and 3]

[9] At maintenance TTY, verify mini-ROTL access line translations. Enter:  
**VER:LINE TN f g!**  
 (f g = telephone number of mini-ROTL access line)

[8] Correct translations to agree with FIG. 1 in accordance with local procedures using RC:LINE input message

[10] Does printout of translations agree with FIG. 2  
 [NOTE 4]

[11] Correct translations to agree with FIG. 2 in accordance with local procedures using RC:LINE input message

Page 3

```

M 13 VER LINE
IN f g
OE 1 0 2 6 1
OESP 1 19 1
TN TRIG
ETYP 3
TTYC 5
CLS 10
PORT 1
TO 0
PRIOR 0
TONE 0
NDB
OE 1 0 2 6 1
RTI 1
LCC ATC
LCI 25
RAX 0
OMAJ 29
SCR 5
TMAJ 29
PLIT
GST
BTN 242 0051
END
  
```

```


M 11 VER LINE
TN f g
RTI 33
LCC SPL
LCI 24
RAX 0
TMAJ 31
END
  
```

FIG. 2 - Printout of Translations for TTYC Mini-ROTL Access Line

FIG. 1 - Printout of Translations for TTYC Mini-ROTL Port

- NOTES
2. Although OE is translated ground start, it is not wired ground start. In fact, it is not even wired to the frame
  3. TN, TTYC, PORT, and BTN will vary in different telephone offices
  4. TN and RTI will vary in different telephone offices

Issue 2	DEC 1983
233-142-110	TAP
PAGE 2 of 10	113



```

M 11 VER LINE
IN f g
OE 4 1 1 6 7
OESP 4 15 7
TN TRIG
ETYP 10
TER 5
OE 4 1 1 6 7
RTN
RTI 0
LCC ATC
LCI 25
RAX 0
OMAJ 29
SCR 5
TMAJ 29
PLIT
GST
BTN 242 0051
END
  
```


**FIG. 3 - Printout of Translations for TTT Line**

```

M 12 VER LINE
TN f g
OE 4 0 0 6 1
OESP 4 3 1
RTI 40
LCC DT1
LCI 8
RAX 0
OMAJ 8
SCR 0
TMAJ 30
PLIT
END
  
```

**FIG. 4 - Printout of Translations for Connection Appraisal Line**

NOTES	
5. TN, RTN, and BTN will vary in different telephone offices	
6. TN will vary in different telephone offices	
Issue 2	DEC 1983
233-142-110	TAP
PAGE 3 of 10	113



```

M 12 VER LINE
TN f g
OE 2 0 1 6 1
ETYP 34
OESP 2 11 1
SER 0242 0094
LCC 001
LCI 7
RAX 0
OMAJ 30
SCR 0
TMAJ 8
PLIT
END
  
```

FIG. 5 - Printout of Translations for 105A Test Line

```


M 13 VER LINE
TN f g
OE 3 0 2 6 1
ETYP 35
OESP 3 19 1
SER 0242 0093
LCC 001
LCI 7
RAX 0
OMAJ 30
SCR 0
TMAJ 8
PLIT
END
  
```

FIG. 6 - Printout of Translations for 105B Test Line

NOTE 7	
TN and SER will vary in different telephone offices	
Issue 2	DEC 1983
233-142-110	TAP
PAGE 4 of 10	113








**CLEAR MINI-ROTL ACCESS TROUBLE CONDITION**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 7 of 10	113



**CLEAR MINI-ROTL ACCESS TROUBLE CONDITION**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 8 of 10	113




TABLE B		
TTYC I/O CHANNEL ASSIGNMENTS		
TTYC	MAIN CHANNEL	SUBCHANNEL
2	0	9
3	0	10
4	0	1
5	0	15
6	0	4
7	1	5

NOTE 10	
Information in TABLE B per ED-4C018-01	
Issue 2	DEC 1983
233-142-110	TAP
PAGE 9 of 10	113

**CLEAR MINI-ROTL ACCESS TROUBLE CONDITION**






TABLE A		
QUANTITY	IDENTIFICATION	DESCRIPTION
1	KS-442A	Voltohmmeter or equivalent general use voltohmmeter
2	2P4A	Cords
3	<b>EXECUPORT</b> data terminal or equivalent with the following characteristics: <b>EIA RS-232</b> serial interface jack and connecting cable Acoustical coupler and modem or equivalent Full-duplex capability 110-baud data rate (ASCII code)	

- [1] Obtain support apparatus [TABLE A]
- [2] From office records Form 3100, identify and record telephone numbers (TNs) and office equipment (OE) numbers for 105A- (ETYP 34) and 105B- (ETYP 35) test lines
- [3] For each 105-type test line identified in Step 2. At maintenance TTY, enter:  
**RMV:LINE(a,bcde),TN f g!**  
 (a,bcde = office equipment number)  
 (f g = telephone number)
- [4] At maintenance TTY, enter:  
**RMV:SVC(103,0);UCL!**
- [5] Set up data terminal [DLP-513]




**CLEAR CAROT REPORTED TROUBLES**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 1 of 6	114




<b>NOTE 1</b>	
Ports 6, 9, 10, 14, and 15 are always listed as inoperative. They are not equipped	
Issue 2	DEC 1983
233-142-110	TAP
PAGE 2 of 6	114

**CLEAR CAROT REPORTED TROUBLES**




**CLEAR CAROT REPORTED TROUBLES**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 3 of 6	114




**CLEAR CAROT REPORTED TROUBLES**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 4 of 6	114



**CLEAR CAROT REPORTED TROUBLES**

Issue 2	DEC 1983
233-142-110	TAP
PAGE 5 of 6	114







TABLE A	
ITEM	CIRCUIT PACK
1	CP 37
2	CP 36 (or CP 14)
3	CP 38 (or CP 18)

**CLEAR USART DIAGNOSTIC TEST TROUBLE**



**IDENTIFY LIST NUMBER OF ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	500




TABLE A	
CONTROL	POSITION
TEST PREPARATION	INT CHK
TEST REQUEST	INT CHK
SELECT	EXPANDED
MFO	MAN
ROS	HOLD
TST	ON HOOK
DB insertion pads	Normal (Nos. not visible)
INTERROGATOR START	OFF
VOL	Full clockwise

NOTE 1	
If any one of RSTS self-checks fail, the test set should be returned for repair according to local instructions	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 4	501

**PERFORM ROTL SYSTEM TEST SET (RSTS) SELF-CHECK LIST 1 THROUGH 3**




FIG. 1 - ROTL System Test Set (H-310-150)

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 4	501

PERFORM ROTL SYSTEM TEST SET (RSTS) SELF-CHECK LIST 1 THROUGH 3






TABLE B																									
THUMBWHEEL																									
POSITION	KP	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
SETTING	KP	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	0	0	1	1	C F	ST

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 4	501

PERFORM ROTL SYSTEM TEST SET (RSTS) SELF-CHECK LIST 1 THROUGH 3






**TABLE A**

**THUMBWHEEL**

<b>POSITION</b>	KP	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
<b>SETTING</b>	KP	5	5	5	ST	← OFF →																			

**MAKE SECURITY CALLBACK UNLOCK REQUEST USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**



**MAKE SECURITY CALLBACK UNLOCK REQUEST USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	502

[1] Select outgoing trunk which terminates in office that has 100-type test line [NOTE 1]

[2] Record trunk group number, trunk member number, 100-type far-end test line directory number, estimated measured loss (EML), and noise requirement of trunk under test (TUT)

[3] At maintenance TTY, enter:  
 RMV:TRK(a,b), LKO;UCL!  
 (a = trunk group number)  
 (b = member number)

[4] At RSTS [FIG. 1, Page 2], set controls according to TABLE A

[5] Set MF digit thumbwheels 0 through 3 according to TABLE B




TABLE A	
CONTROL	POSITION
TEST PREPARATION	100-0-900
TEST REQUEST	MEAS ALL
SELECT	EXPANDED
MFO	AUTO
ROS	DIAL
TST	ON HOOK
DB insertion pads	Normal (Nos. not visable)
INTERROGATOR START	OFF
VOL	Full clockwise

TABLE B																									
		GROUP NUMBER						MEMBER NUMBER			FAR-END TEST LINE NUMBER														
POSITION	KP	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
SETTING	KP	1	0	0														ST	0 <sub>FF</sub>						

**NOTE 1**  
 A 100-type test line sends 1000-Hz 0-dBm tone for 10 seconds then connects a balance termination

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 7	503

**TEST ROTL - 100-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**




FIG. 1 - ROTL System Test Set (H-310-150)

TEST ROTL - 100-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 7	503

[6] Enter trunk group number  
at thumbwheel positions  
4, 5, and 6 \_\_\_\_\_

[7] Enter trunk member number  
at thumbwheel positions  
7, 8, and 9 \_\_\_\_\_

[8] Starting at thumbwheel  
position 10, enter 7- or  
10-digit far-end test line  
number to be outpulsed  
to the far end \_\_\_\_\_


[9] Set thumbwheel immediately  
following last digit of test  
number to ST and remaining  
thumbwheels to OFF \_\_\_\_\_

AND

Page 4


**TEST ROTL - 100-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 7	503



**TEST ROTL – 100-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**


Issue 2	DEC 1983
233-142-110	DLP
PAGE 4 of 7	503



**NOTE 2**  
 Timing on the following steps is critical. Steps 31 through 38 (Page 6) must be performed within the indicated times or readings will be erroneous


Issue 2	DEC 1983
233-142-110	DLP
PAGE 5 of 7	503

**TEST ROTL – 100-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**



**TEST ROTL – 100-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 6 of 7	503



**NOTE 3**  
 A reading of 002 together with TEST FAULT 2 lamp indicates noise measurement is less than 14 dBrn

Issue 2	DEC 1983
233-142-110	DLP
PAGE 7 of 7	503

**TEST ROTL – 100-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**



[1] Select outgoing trunk which terminates in office that has 102-type test line [NOTE 1]

[2] Record trunk group number, trunk member number, 102-type far-end test line directory number, and estimated measured loss (EML) of trunk under test (TUT)

[3] At maintenance TTY, enter:  
 RMV:TRK(a,b), LKO;UCL!  
 (a = trunk group number)  
 (b = member number)

[4] At RSTS [FIG. 1, Page 2], set controls according to TABLE A

[5] Set MF digit thumbwheels 0 through 3 according to TABLE B




TABLE A	
CONTROL	POSITION
TEST PREPARATION	102-0-900
TEST REQUEST	MEAS ALL
SELECT	EXPANDED
MFO	AUTO
ROS	DIAL
TST	ON HOOK
DB insertion pads	Normal (Nos. not visible)
INTERROGATOR START	OFF
VOL	Full clockwise

TABLE B																									
		GROUP NUMBER						MEMBER NUMBER						FAR-END TEST LINE NUMBER											
POSITION	KP	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
SETTING	KP	1	2	0														ST	Q <sub>FF</sub>						

**NOTE 1**  
 A 102-type test line sends 1000-Hz 0-dBm tone for 9 seconds followed by 1 second of on-hook balance termination, repeated continuously

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 7	504

**TEST ROTL - 102-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**




FIG. 1 - ROTL System Test Set (H-310-150)

TEST ROTL - 102-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 7	504

[6] Enter trunk group number  
at thumbwheel positions  
4, 5, and 6

[7] Enter trunk member number  
at thumbwheel positions  
7, 8, and 9

[8] Starting at thumbwheel  
position 10, enter 7- or  
10-digit far-end test line  
number to be outpulsed  
to the far end


[9] Set thumbwheel immediately  
following last digit of test  
number to **ST** and remaining  
thumbwheels to **OFF**

AND

Page 4


**TEST ROTL - 102-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 7	504




**TEST ROTL – 102-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 4 of 7	504




**TEST ROTL – 102-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
235-142-110	DLP
PAGE 5 of 7	504



**TEST ROTL – 102-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 6 of 7	<b>504</b>



**TEST ROTL - 102-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 7 of 7	504



[1] Select outgoing trunk which terminates in office that has 105-type test line [NOTE 1]

[2] Record trunk group number, trunk member number, 105-type test line directory number, estimated measured loss (EML), and noise requirements of trunk under test (TUT)

[3] At maintenance TTY, enter:  
 RMV:TRK(a,b), LKO;UCL!  
 (a = trunk group number)  
 (b = member number)

[4] At RSTS [FIG. 1, Page 2], set controls according to TABLE A

[5] Set MF digits thumbwheels 0 through 3 according to TABLE B




TABLE A	
CONTROL	POSITION
TEST PREPARATION	105-0-900
TEST REQUEST	MEAS ALL
SELECT	EXPANDED
MFO	AUTO
ROS	DIAL
TST	ON HOOK
DB insertion pads	Normal (Nos. not visible)
INTERROGATOR START	OFF
VOL	Full clockwise

TABLE B																									
		GROUP NUMBER						MEMBER NUMBER						FAR-END TEST LINE NUMBER											
POSITION	KP	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
SETTING	KP	1	5	0														ST	Q <sub>FF</sub>						

**NOTE 1**  
 A 105-type test line is a line which enables a 52A responder to be accessed

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 14	505

**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**




FIG. 1 - ROTL System Test Set (H-310-150)

TEST ROTL - 105-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)


Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 14	505

[6] Enter trunk group number  
at thumbwheel positions  
4, 5, and 6 \_\_\_\_\_

[7] Enter trunk member number  
at thumbwheel positions  
7, 8, and 9 \_\_\_\_\_


[8] Starting at thumbwheel  
position 10, enter 7- or  
10-digit far-end test line number  
to be outpulsed to the far end \_\_\_\_\_

[9] Set thumbwheel immediately  
following last digit of test  
number to **ST** and remaining  
thumbwheels to **OFF** \_\_\_\_\_




**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 14	505




**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 4 of 14	505




**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 5 of 14	505



**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**


NOTES	
2.	This is far-to-near 1000-Hz loss measurement
3.	No more than 18 seconds should elapse between depressions of DATA RCV key due to responder time-out
Issue 2	DEC 1983
233-142-110	DLP
PAGE 6 of 14	505



**NOTE 4**  
 This is near-to-far 1000-Hz loss measurement


<b>Issue 2</b>	<b>DEC 1983</b>
<b>233-142-110</b>	<b>DLP</b>
<b>PAGE 7 of 14</b>	<b>505</b>

**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**




<b>NOTES</b>	
5. This is far-to-near noise measurement in dBrn	
6. Reading of 002 together with TEST FAULT 2 lamp indicates noise measurement is less than 14 dBrn	
7. This is near-to-far noise measurement in dBrn	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 8 of 14	505

**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**




NOTE 8	
This is far-to-near 400-Hz loss measurement	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 9 of 14	505

**TEST ROTL - 105-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**




**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 10 of 14	505




**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 11 of 14	505




**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 12 of 14	505



**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 13 of 14	505




**TEST ROTL – 105-TYPE TEST LINE AT FAR END USING  
H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 14 of 14	505

[1] At maintenance TTY, make busy  
 105-test line No. 2; enter:  
 RMV:LINE(a,bcde),TN f g!  
 (a,bcde = office equipment number)  
 (f g = telephone number)

[2] From an office  
 telephone, dial  
 105-test line No. 2  
 directory number  
 [NOTE 1]

At CP 21  
 TL1 lighted



[5] At office telephone,  
 go on-hook

[6] At maintenance TTY,  
 restore 105-test line  
 No. 2; enter:  
 RST:LINE(a,bcde),TN f g!

Page 2

NOTE 1	
105-type test lines 1 and 2 are arranged for series completion	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	506

**TEST 105-TYPE TEST LINE ACCESS**


[7] At maintenance TTY, make busy  
 105-test line No. 1; enter:  
 RMV:LINE(a,bcde),TN fg!  
 (a,bcde = office equipment number)  
 (fg = telephone number)

[8] From an office telephone,  
 dial 105-test line No. 1  
 directory number

At CP 21  
 TL2  
 lighted

[11] At office telephone,  
 go on-hook

[12] At maintenance TTY,  
 restore 105-test line  
 No. 1; enter:  
 RST:LINE(a,bcde),TN fg!



[1] Identify the trunk group number (TGN) and trunk group member number (MEM) of the trunk selected for status test \_\_\_\_\_

[2] Set thumbwheel positions [TABLE A] \_\_\_\_\_

[3] Momentarily depress RECYCLE key for 1 second  Test progress tone heard





TABLE A																									
	GROUP NUMBER						MEMBER NUMBER																		
POSITION	KP	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
SETTING	KP	5	2	0	TGN			MEM			ST	← OFF →													

**MAKE TRUNK STATUS REQUEST USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	507



NOTE 1	
One-half second test progress tone indicates trunk is idle. Four seconds of 60 IPM indicates trunk is busy	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	507

**MAKE TRUNK STATUS REQUEST USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

[1] At ROTL system test set (RSTS), set thumbwheel positions 1, 2, and 3 to 500 [TABLE A]

[2] Depress **RECYCLE** key 1 second

[3] Momentarily depress **START MF** key [NOTE 1]

[4] Set thumbwheel positions 1, 2, and 3 to 520

[5] Depress **RECYCLE** key 1 second

[6] Momentarily depress **START MF** key

Trunk is maintenance busy

AND

1/2 second test progress tone

Busy condition verified

AND

4 seconds of 60-IPM low tone

Page 2


TABLE A

POSITION	GROUP NUMBER						MEMBER NUMBER																	
	KP	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
SETTING	KP	5	0	0	TGN			MEM			ST	← OFF →												

NOTE 1  
 After the release of the **START MF** key, the maintenance TTY will print:  
 RMV TRK a b ROTL LKL

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	508

**MAKE BUSY AND RESTORE TRUNK CIRCUIT USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**



**MAKE BUSY AND RESTORE TRUNK CIRCUIT  
USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

<b>NOTE 1</b>	
After the release of the <b>START MF</b> key, the maintenance TTY will print: <b>RST TRK a b ROTL</b>	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	508

[1] At RSTS, set RSTS controls according to TABLE A and FIG. 1, Page 2

[2] Set TST switch to OFF HOOK




TABLE A	
CONTROL	POSITION
TEST PREPARATION	100-0-900
TEST REQUEST	MEAS ALL
SELECT	EXPANDED
MFO	AUTO
ROS	DIAL
TST	ON HOOK
DB insertion pads	Normal (Nos. not visable)
INTERROGATOR START	OFF
VOL	Full clockwise

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 3	509





FIG. 1 - ROTL System Test Set (H-310-150)

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 3	509

ACCESS ROTL PORT USING H-310-150 ROTL SYSTEM TEST SET (RSTS)



**ACCESS ROTL PORT USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 3	509






TABLE A	
CONTROL	POSITION
TEST PREPARATION	INT CHK
TEST REQUEST	INT CHK
SELECT	EXPANDED
MFO	MAN
ROS	HOLD
TST	ON HOOK
DB insertion pads	Normal
INTERROGATOR START	OFF
VOL	Full clockwise

NOTE 1	
If any one of RSTS self-checks fail, the test set should be returned for repair according to local instructions	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 7	510

\* Trademark of Western Electric

**PERFORM ROTL SYSTEM TEST SET (RSTS) SELF-CHECK LIST 4 OR HIGHER**





FIG. 1 - ROTL System Test Set (H-310-150)

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 7	510

PERFORM ROTL SYSTEM TEST SET (RSTS) SELF-CHECK LIST 4 OR HIGHER



**PERFORM ROTL SYSTEM TEST SET (RSTS) SELF-CHECK LIST 4 OR HIGHER**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 7	510

[11] At MF DIGITS rotary switch, set thumbwheel positions to settings in TABLE B \_\_\_\_\_

[12] Set MFO switch to MAN \_\_\_\_\_

[13] Momentarily depress START MF pushbutton once → MF tones heard

[14] Momentarily depress START MF pushbutton 22 times → MF tones heard each time

[15] Momentarily depress START MF pushbutton once → No MF tones heard

[16] Momentarily depress START MF pushbutton once → MF tones heard

[17] Momentarily depress START MF pushbutton once → No MF tones heard

AND

Page 5


TABLE B

THUMBWHEEL

POSITION	KP	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
SETTING	KP	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	0	0	1	1	OFF	ST


Issue 2	DEC 1983
233-142-110	DLP
PAGE 4 of 7	510

PERFORM ROTL SYSTEM TEST SET (RSTS) SELF-CHECK LIST 4 OR HIGHER



**PERFORM ROTL SYSTEM TEST SET (RSTS) SELF-CHECK LIST 4 OR HIGHER**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 5 of 7	510



PERFORM ROTL SYSTEM TEST SET (RSTS) SELF-CHECK LIST 4 OR HIGHER


Issue 2	DEC 1983
233-142-110	DLP
PAGE 6 of 7	510

TABLE C					
OPERATION	RESPONSES		OPERATION	RESPONSES	
	LAMPS LIGHTED	DIGITAL READOUT DISPLAY		LAMPS LIGHTED	DIGITAL READOUT DISPLAY
1	ON, SCK, NEW, F-E N-F, ODBM, INT START	-00.0	7	ON, SCK, NEW, F-E N-F, 1KHZ, INT START	-00.0
2	ON, SCK, NEW, N-E F-N, NOISE, INT START	-000	8	ON, SCK, NEW, N-E F-N, 2.8 KHZ, INT START	-00.0
3	ON, SCK, NEW, F-E N-F, NOISE, INT START	-000	9	ON, SCK, NEW, F-E N-F, 2.8 KHZ, INT START	-00.0
4	ON, SCK, NEW, N-E F-N, 400 HZ, INT START	-00.0	10	ON, SCK, NEW, N-E F-N, NOISE, TONE, INT START	-000
5	ON, SCK, NEW, F-E N-F, 400 HZ, INT START	-00.0	11	ON, SCK, NEW, F-E N-F, NOISE, TONE, INT START	-000
6	ON, SCK, NEW, N-E F-N, 1KHZ, INT START	-00.0	12	SCK, NEW, N-E F-N, CHK2, INT START	000

PERFORM ROTL SYSTEM TEST SET (RSTS) SELF-CHECK LIST 4 OR HIGHER


Issue 2	DEC 1983
233-142-110	DLP
PAGE 7 of 7	510






**CHECK RESPONDER ALIGNMENT**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 3	511



**CHECK RESPONDER ALIGNMENT**


Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 3	511



**CHECK RESPONDER ALIGNMENT**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 3	511





**CHECK DIALUP CONNECTION**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	512




FIG. 1

NOTE 1	
Oscillators are not used for the tone detector test	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	512

[1] At data terminal,  
set switches [TABLE A]

[2] At mini-ROTL CP 19,  
depress PWR OFF switch  
to turn power off

PWR OFF  
lamp  
lighted

[3] Using cable provided with data  
terminal, connect  
mini-ROTL EIA jack to  
data terminal

[4] At mini-ROTL CP 19,  
depress PWR OFF switch  
to turn power on

PWR OFF  
lamp  
extinguished

[5] Connect data terminal  
to ac power outlet

[6] At data terminal,  
turn power on

MONITOR RUNNING  
STATE REQUEST  
printed

[7] See NOTE 1. At CP 18, slide  
DIAG ENAB switch toward the  
connector end of CP 18  
[NOTE 2]

DIAG ENAB red  
LED lighted  
(DS1)

[8] At CP 18 (or CP 38),  
momentarily operate RST  
switch

RUN green LED  
blinks (DS2)

[9] See NOTE 1. At CP 18, restore  
DIAG ENAB switch to extinguish  
DIAG ENAB red lamp

AND

AND


TABLE A EXECUPORT SWITCH SETTINGS	
SWITCH	POSITION
MODE	ISOLATE
DUPLEX	FULL
CHAR/SEC	10
PARITY	Either ODD or EVEN
QSL	UPPER
LINE SPACING SWITCH	Back (2-position slide switch mounted on right side of paper roll)
POWER	OFF (on back)
ON LINE	ON LINE

NOTES


- This step should be omitted if the mini-ROTL is equipped with CP 38 instead of CP 18
- DIAG ENAB is a slide switch located approximately 1 inch above the rear of the RST switch on CP 18

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	513

SET UP DATA TERMINAL




NOTE 1	
When A is typed, MONITOR RUNNING STATE REQUEST is printed	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	514




**PERFORM DIAGNOSTIC AND RUNNING CHECKSUM DIAGNOSTIC TEST – TE DC AND TE RC**

NOTES	
1. Printout maybe delayed 20 or 30 seconds	
2. After A is typed, MONITOR RUNNING STATE REQUEST is printed	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	515



NOTES	
1. Printout may be delayed 20 or 30 seconds	
2. After A is entered, MONITOR RUNNING STATE REQUEST is printed	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	516


**PERFORM RAM DIAGNOSTIC TEST – TE RA**



<b>NOTE 1</b>	
Ports 6, 9, 10, 14, and 15 are always listed as inoperative. They are not equipped	
<b>Issue 2</b>	<b>DEC 1983</b>
<b>233-142-110</b>	<b>DLP</b>
<b>PAGE 1 of 1</b>	<b>517</b>

**PERFORM MULTIPLEX DIAGNOSTIC TEST – TE MU**






**NOTES**

1. This step should be omitted if the mini-ROTL is equipped with CP 38 instead of CP 18
2. **DIAG ENAB** is a slide switch located approximately 1 inch above the rear of the **RST** switch on CP 18

**WARNING 1**  
*To prevent equipment damage, connector P4 at rear of the mini-ROTL must be unplugged from backplane during this test*

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	518






TABLE A	
PRINTOUT	TONE
LOW TONE	480 and 620 Hz
TPT	2225 Hz
GUARD	1200 Hz
TPT FROM AGC	2225 Hz test Progress tone




FIG. 1

**NOTES**

1. Volume can be controlled by VOL potentiometer at CP 15. Procedures for holding or continuing tones are on the printout
2. During low tone, typing H holds the tone for 10 seconds and typing C cancels the tone

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	519





FIG. 1

NOTES

1. Volume can be controlled by VOL potentiometer at CP 15. Procedures for holding or continuing tones are on the printout
2. During low tone, typing H holds the tone for 10 seconds and typing C cancels the tone

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	520





FIG. 1

**NOTE 1**  
Normally, external oscillators are not used for this test

**WARNING 1**  
*To prevent equipment damage, connector P4 to 3ESS\* switch must be unplugged at the mini-ROTL backplane during this test*

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	521

\* Trademark of Western Electric

**PERFORM TONE DETECTOR DIAGNOSTIC TEST – TE TD**





FIG. 1

TABLE A	
TEST PASS INDICATION	TEST FAILURE INDICATION
A series of MF digits heard one at a time. MF DETECTOR OK printed	Tones not heard. MF DETECTOR OK not printed. ERROR MESSAGES, -10 DB THRESHOLD, -50 DB THRESHOLD printed

NOTE 1	
Normally, external oscillators are not used for this test	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	522

[1] At data terminal, enter:  
TE TL \_\_\_\_\_

[2] See WARNING 1. Verify that  
connector P4 at mini-ROTL  
backplane is unplugged \_\_\_\_\_

[3] Patch 105A jack on CP 20 to  
T,R jack on jack panel using  
2P4A patch cord \_\_\_\_\_

[4] At CP 15, set TUT switch to  
up position [FIG. 1] \_\_\_\_\_

[5] Momentarily depress SPACE bar and  
follow printout instructions \_\_\_\_\_





FIG. 1



<b>WARNING 1</b>	
<i>To prevent equipment damage, connector P4 to 3ESS* must be unplugged at the mini-ROTL backplane during this test</i>	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	523

\* Trademark of Western Electric

**PERFORM 105-TEST LINE DIAGNOSTIC TEST – TE TL**

[1] At data terminal, enter:  
TE TR

[2] See WARNING 1. Verify that  
connector P4 at mini-ROTL  
backplane is unplugged

[3] At CP 15, set TUT switch to  
up position [FIG. 1]

[4] Patch MWR jack on jack panel  
to CA jack on CP 20 using  
2P4A patch cord

[5] Patch TUT jack to T,R jack  
using 2P4A patch cord

[6] Momentarily depress SPACE bar and  
follow printout instructions









FIG. 1

**WARNING 1**  
To prevent  
equipment damage,  
connector P4 to  
3ESS\* must be  
unplugged at the  
mini-ROTL  
backplane during  
this test

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	524

\* Trademark of Western Electric

**PERFORM PORT SELECT RELAYS DIAGNOSTIC TEST – TE TR**

[1] At data terminal, enter:  
TE RO \_\_\_\_\_



[2] See WARNING 1. Verify that  
connector P4 at mini-ROTL  
backplane is unplugged \_\_\_\_\_

[3] Connect ohmmeter between tip  
and ring of ROTL jack \_\_\_\_\_

[4] Set ohmmeter on X10,000  
ohm scale \_\_\_\_\_

[5] Observe that meter indicates  
continuity \_\_\_\_\_

[6] Momentarily depress  
SPACE bar \_\_\_\_\_



[8] Momentarily depress SPACE bar \_\_\_\_\_

[9] Connect ohmmeter between tip  
and ring of TUTT jack \_\_\_\_\_

[10] Observe that ohmmeter indicates  
an open circuit \_\_\_\_\_

[11] Momentarily depress SPACE bar \_\_\_\_\_




\* Trademark of Western Electric

<b>WARNING 1</b>	
<i>To prevent equipment damage, connector P4 to 3ESS* switch must be unplugged at the mini-ROTL backplane during this test</i>	

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	525

**PERFORM PORT CONTINUITY RELAY DIAGNOSTIC TEST – TE RO**



PERFORM PORT CONTINUITY RELAY DIAGNOSTIC TEST – TE RO

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	525

[1] At data terminal, enter:  
TE HB \_\_\_\_\_



[2] See WARNING 1. Verify that  
connector P4 at Mini-ROTL  
backplane is unplugged \_\_\_\_\_

[3] Connect ohmmeter between tip  
and ring of CA jack \_\_\_\_\_

[4] Set ohmmeter on X10,000  
ohm scale \_\_\_\_\_

[5] Observe that ohmmeter  
indicates an open circuit \_\_\_\_\_

[6] Momentarily depress  
SPACE bar \_\_\_\_\_




[8] Momentarily depress SPACE bar \_\_\_\_\_

[9] Connect ohmmeter between tip  
and ring of CA jack \_\_\_\_\_

[10] Observe that ohmmeter indicates  
an open circuit \_\_\_\_\_


[11] Momentarily depress SPACE bar \_\_\_\_\_




<b>WARNING 1</b> To prevent equipment damage, connector P4 to 3ESS* switch must be unplugged at the mini-ROTL backplane during this test	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	526

\* Trademark of Western Electric

**PERFORM HOLD COIL AND PULSING RELAY DIAGNOSTIC TEST - TE HB**





**NOTES**

1. This step should be omitted if the **mini-ROTL** is equipped with CP 38 instead of CP 18
2. **DIAG ENAB** is a slide switch located approximately 1 inch above the rear of **RST** switch on CP 18


**WARNING 1**

*Pins in the backplane are fragile and easily bent. The circuit pack or extender should slide smoothly with perceptible tension as the pins and connector engage*

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	527


## REPLACE CIRCUIT PACK

[1] If **PWR OFF LED** is off, momentarily depress **PWR OFF** key




[2] Remove circuit pack to be extended


[3] See **WARNING 1** and install extender and circuit pack [NOTE 1]




[4] Momentarily depress **PWR OFF** key



[5] See NOTE 2. At CP 18, slide **DIAG ENAB** switch toward the connector end of CP 18 [NOTE 3]




[6] At CP 18 (or CP 38), momentarily operate **RST** switch



[7] See NOTE 2. Restore **DIAG ENAB** switch



<b>NOTES</b>	
1. The circuit pack should be installed in the extender before installing the extender	
2. This step should be omitted if the mini-ROTL is equipped with CP 38 instead of CP 18	
3. <b>DIAG ENAB</b> is a slide switch located approximately 1 inch above the rear of <b>RST</b> switch on CP 18	
<b>WARNING 1</b>	
<i>Pins in the backplane are fragile and easily bent. The circuit pack or extender should slide smoothly with perceptible tension as the pins and connector engage</i>	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	528




**NOTES**

1. This step should be omitted if the mini-ROTL is equipped with CP 38 instead of CP 18
2. **DIAG ENAB** is a slide switch located approximately 1 inch above the rear of **RST** switch on CP 18

**WARNING 1**  
*Pins in the backplane are fragile and easily bent. The circuit pack should slide smoothly with perceptible tension as the pins and connector engage*


Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	529

**REMOVE EXTENDED CIRCUIT PACK AND REINSTALL WITHOUT EXTENDER**



**RESTORE POWER**


NOTES	
1. This step should be omitted if the mini-ROTL is equipped with CP 38 instead of CP 18	
2. <b>DIAG ENAB</b> is a slide switch located approximately 1 inch above the rear of <b>RST</b> switch on CP 18	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	530



**ESTABLISH OFFICE CONNECTIONS TO MINI-ROTL TUT PORT USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	531

[8] At TLTP, set: STATE CONTROL to  
ACCESS TRUNK 1; ASSOCIATED JUNCTOR  
to YES;  $\bar{A}$   $\bar{B}$  C [NOTE 1]



[9] Momentarily depress EXECUTE

**ESTABLISH OFFICE CONNECTIONS TO MINI-ROTL TUT PORT  
USING H-310-150 ROTL SYSTEM TEST SET (RSTS)**

NOTE 1	
The $\bar{A}$ $\bar{B}$ C switch settings are as follows:	
$\bar{A}$ down	
$\bar{B}$ down	
C up	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	531

[1] From office records Form ESS\* 3107-2, identify telephone number assigned ETYP 10, ROTL assignment, and any member number (0 through 4)

[2] From Form ESS 3100, identify and record office equipment number (OE *gg cws*) assigned to telephone number identified in Step 1 [TABLE A]

[3] From Form ESS 3100, identify and record any unassigned telephone number (TN *Nxx xxxx*) [TABLE A]



[4] From Form ESS 3100-1B, identify any office code and telephone number used as billing number

[5] From Form ESS 3100, identify unassigned telephone number having same office code and thousands digit as number identified in Step 4

[6] Using telephone number identified in Step 5, record BTN *Nxx xxxx* [TABLE A]

[7] From Form ESS 3500-2, identify office code and telephone number of trunk and line test panel access trunk 1

[8] Using number identified in Step 7, record return telephone number (RTN *Nxx xxxx*) [TABLE A]



[9] At maintenance TTY, type input message indicated in TABLE A

TABLE A	
INPUT MESSAGE	REFERENCE
RC:LINE/ ORD 9999/ TYP NEW/ OE <i>gg cws</i> / TN <i>Nxx xxxx</i> / BTN <i>Nxx xxxx</i> / RTN <i>Nxx xxxx</i> / LCC ATC/ GST YES/ ETYP 10/ TER 5/ RAML NO/ PLIT YES/ RMK ROTL SC TLTP1/ END!	Step 2 Step 3 Step 6 Step 8

\* Trademark of Western Electric

**ASSIGN SECURITY CALLBACK USER NO. 5 TO TRUNK AND LINE TEST PANEL ACCESS TRUNK 1**

[1] From office equipment (OE) number identify the concentrator group (CG), concentrator (C), switch group (SG), switch, and level [NOTE 1]

[2] At distributing frame shelf B, C, D, E, or F, locate the OE terminal [FIG. 1]




FIG. 1 - Connecting Blocks for One Concentrator


**NOTE 1**  
 The office equipment number identifies the following:

- Concentrator group (CG)
- Concentrator (C)
- Switch group (SG)
- Switch
- Level

OE *gg* *cwsl*

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	533

**LOCATE OFFICE EQUIPMENT TERMINAL AT DISTRIBUTING FRAME**



**ESTABLISH CONNECTION FROM TRUNK AND LINE TEST PANEL TO 105-TYPE TEST LINE AND TRIP RINGING**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	534

[1] Set reference level  
test set (RTS) switches  
[TABLE A]

[2] Using power cord provided  
with RTS, connect RTS to  
110 Vac power

[3] Depress **ON/OFF** switch  
to turn power on





TABLE A	
SWITCH	SETTING
METER RANGE	$\pm .1\text{DB}$
INPUT LEVEL	0
INPUT	900 $\Omega$ DBM TERM
FUNCTION	MEAS INPUT
OUTPUT	OFF

**SET UP REFERENCE LEVEL TEST SET**


Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	535



**NOTE 1**  
Potentiometer R2 (TUT) is a 30-turn pot. It may be necessary to make several turns before there is an indication

<b>Issue 2</b>	<b>DEC 1983</b>
<b>233-142-110</b>	<b>DLP</b>
<b>PAGE 1 of 1</b>	<b>536</b>

**ADJUST MINI-ROTL CP 16 POTENTIOMETER R2 FOR ROTL BUILDOUT**



**NOTES**

1. This step should be omitted if the mini-ROTL is equipped with CP 38 instead of CP 18
2. DIAG ENAB is a slide switch located approximately 1 inch above the rear of RST switch on CP 18

**WARNING 1**

*Pins in the backplane are fragile and easily bent. The circuit pack should slide smoothly with perceptible tension as the pins and connector engage*

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	537

**VERIFY THAT 105 TEST LINE IMPEDANCE AND LEVEL STRAPS ARE IN PLACE**

[1] At data terminal,  
enter:  
TE BU

[2] Momentarily depress  
SPACE bar

[3] To designate  
105A test line,  
enter: A

[4] At trunk and line test panel (TLTP),  
establish connection to 105A test line  
port and trip ringing [DLP-534]

[5] At data terminal, momentarily  
depress SPACE bar two times

Tone sounds at  
TLTP handset

[6] At TLTP, set: STATE CONTROL to  
ACCESS TRUNK 1;  
ASSOCIATED JUNCTION to YES;  
 $\bar{A}$   $\bar{B}$   $\bar{C}$  [NOTE 1]

[7] Momentarily depress  
EXECUTE key

Tone removed at  
TLTP handset

Page 2

NOTE 1  
The  $\bar{A}$   $\bar{B}$   $\bar{C}$  switch  
settings are as  
follows:  
 $\bar{A}$  down  
 $\bar{B}$  down  
 $\bar{C}$  down

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	538

**BUILD OUT 105A TEST LINE**

[8] Using 3P15A cord, connect reference level test set (RTS) INPUT 310 jack to 105A test line appearance (OE) at combined distributing frame [DLP-533]


[9] At CP 16, adjust 105 TL1 build-out potentiometer R12 for 0-dBm indication at RTS

[10] Remove RTS connection at distributing frame [NOTE 1]

[11] At TLTP, set ASSOCIATED JUNCTION to NO

[12] At TLTP, momentarily depress RELEASE 1

[13] At data terminal, enter:  
A



NOTE 1	
Potentiometer 105 TL1 (R12) is a 30-turn pot. It may be necessary to make several turns before an indication	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	538

**BUILD OUT 105A TEST LINE**

[1] At data terminal,  
enter:  
TE BU

[2] Momentarily depress  
SPACE bar

[3] To designate  
105 test line,  
enter: B

[4] At trunk and line test panel (TLTP),  
establish connection to 105B test line  
port and trip ringing [DLP-534]


[5] At data terminal,  
momentarily depress  
SPACE bar two times

Tone sounds at  
TLTP handset

[6] At TLTP, set: **STATE CONTROL** to  
**ACCESS TRUNK 1**;  
**ASSOCIATED JUNCTOR** to **YES**;  
 $\bar{A}$   $\bar{B}$   $\bar{C}$  [NOTE 1]

[7] Momentarily depress  
**EXECUTE** key

Tone removed at  
TLTP handset



Page 2

NOTE 1	
The $\bar{A}$ $\bar{B}$ $\bar{C}$ switch settings are as follows:	
$\bar{A}$ down	
$\bar{B}$ down	
$\bar{C}$ down	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	539

### BUILD OUT 105B TEST LINE

[8] Using cord provided with reference level test set (RTS), connect RTS **INPUT 310** jack to 105B test line appearance (OE) at combined distributing frame [DLP-533]

[9] At CP 16, adjust 105 TL2 build-out potentiometer **R19** for 0-dBm indication at RTS [NOTE 1]


[10] Remove RTS connection at distributing frame

[11] At TLTP, set **ASSOCIATED JUNCTION** to **NO**

[12] At TLTP, momentarily depress **RELEASE 1**

[13] At data terminal, enter:  
A

MONITOR RUNNING  
STATE REQUEST  
is printed



**NOTE 1**  
Potentiometer 105  
TL2 (R19) is a  
30-turn pot. It  
may be necessary  
to make several  
turns before an  
indication

**Issue 2** | **DEC 1983**

**233-142-110** | **DLP**

**PAGE 2 of 2** | **539**




TABLE A EXECUPORT SWITCH SETTINGS	
SWITCH	POSITION
MODE	ISOLATE
DUPLEX	FULL
CHAR/SEC	10
PARITY	Either ODD or EVEN
QSL	UPPER
LINE SPACING SWITCH	Back (2-position slide switch mounted on right side of paper roll)
POWER	OFF (on back)
ON LINE	ON LINE

**NOTES**

- Normally a power-down and power-up procedure is performed at the mini-ROTL when setting up the data terminal. When performing the ROTL buildout, the mini-ROTL should not be powered down and powered up because the ROTL connection will be lost
- This step should be omitted if the mini-ROTL is equipped with CP 38 instead of CP 18
- DIAG ENAB** is a slide switch located approximately 1 inch above the rear of the **RST** switch on CP 18

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	540

**SET UP DATA TERMINAL WITHOUT POWERING DOWN**



[1] Connect **92A CONTROL UNIT**  
[FIG. 1, Page 2] to 115 Vac source

[2] Set power switch to **POWER ON**

[3] Set **92A CONTROL UNIT** switches to  
positions listed in TABLE A

[4] At **DATA ENTRY** key pad,  
depress **RST** key

[5] Enter **99** into **DATA DISPLAY**  
using **DATA ENTRY** key pad

[6] Depress **TEST** pushbutton  
and observe **DATA DISPLAY**

AND

[7] Does **000**  
appear at left  
and right of  
**DATA DISPLAY**

Yes → Page 3

No

[8] Record any  
reading that  
appeared in **DATA  
DISPLAY**

[9] Request  
assistance in  
accordance with  
local procedures

**TABLE A**

CONTROL (NOTE)	POSITION
<b>VOLUME</b>	Midrange
<b>MONITOR</b>	LOOP
<b>DIAL PULSE/TOUCH TONE</b>	TOUCH TONE
<b>ON HOOK/OFF HOOK</b>	OFF HOOK
<b>T PADS</b>	0 dB
<b>AUTO/MAN</b>	AUTO
<b>SMALL/EXP</b>	SMALL
NOTE: Any control not listed may be in any position	

**PERFORM 92A CONTROL UNIT SELF-TESTS**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 6	541





FIG. 1 - 92A Control Unit

**PERFORM 92A CONTROL UNIT SELF-TESTS**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 6	541



DATA ENTRY KEY	STONE (Hz)
1	700
2	900
3	1000
4	1100
5	1300
6	1500
7	1700
8	2225
9	None

**PERFORM 92A CONTROL UNIT SELF-TESTS**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 6	541




TABLE C			
DATA ENTRY KEY	TONES HEARD FOR PRIMING FIELD 1	TONES HEARD FOR PRIMING FIELD 2	DATA DISPLAY CONTENTS
1	1209 Hz	697 Hz	1
5	1336 Hz	770 Hz	15
9	1477 Hz	852 Hz	159
0	1336 and 941 Hz	941 Hz	1590

Issue 2	DEC 1983
233-142-110	DLP
PAGE 4 of 6	541




TABLE D	
PUSHBUTTON DEPRESSED	DATA DISPLAY
PRIMING FIELD 1	111111111111
PRIMING FIELD 2	222222222222
PRIMING FIELD 3	888888888888

Page 6

**PERFORM 92A CONTROL UNIT SELF-TESTS**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 5 of 6	541




TABLE E	
PUSHBUTTON DEPRESSED	RESPONSE
-RECY/-DAT	Tone heard as long as key is depressed
103TL RFWD	Tone burst heard
RST	None
PRIMING FIELD 1	DATA DISPLAY blank
PRIMING FIELD 2	DATA DISPLAY blank
PRIMING FIELD 3	DATA DISPLAY blank

[1] Connect **92A CONTROL UNIT** to telephone line using **LOOP** jack and **225A** adapter

[2] From Form **ESS\* 3100-1**, obtain **ROTL** access port directory number

[3] At **92A CONTROL UNIT**, set controls per **TABLE A**






TABLE A	
CONTROL	SETTING
TOUCH TONE/DIAL PULSE	Type line used to access ROTL
ON HOOK/OFF HOOK	ON HOOK
T PADS	Off
MONITOR	LOOP
MBO/NORM	NORM
SMALL/EXP	EXP
AUTO/MAN	AUTO
MEAS/SC	MEAS
600/900	900
TP0/TP2	TP0
VOLUME	Midrange
POWER	ON

\* Trademark of Western Electric




Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	542



**MAKE SECURITY CALLBACK UNLOCK REQUEST USING 92A CONTROL UNIT**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	543



**MAKE SECURITY CALLBACK UNLOCK REQUEST USING 92A CONTROL UNIT**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	543

[1] Identify the trunk group number (TGN) and trunk group member number (MEM) of the trunk selected for status test \_\_\_\_\_

[2] At 92A CONTROL UNIT, momentarily depress RST key to clear all priming fields \_\_\_\_\_

[3] Momentarily depress PRIMING FIELD 1 pushbutton \_\_\_\_\_


[4] Enter DATA ENTRY 520 \_\_\_\_\_

[5] Momentarily depress PRIMING FIELD 2 pushbutton \_\_\_\_\_

[6] Enter DATA ENTRY for TGN and MEM identified in Step 1 \_\_\_\_\_


[7] Depress RECY key for 1 second \_\_\_\_\_

[8] Momentarily depress PRIME key \_\_\_\_\_




# MAKE TRUNK STATUS REQUEST USING 92A CONTROL UNIT

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	544




NOTE 1	
One-half second test progress tone indicates trunk is idle. Four seconds of 60 IPM indicates trunk is busy	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	544



NOTE 1	
After release of PRIME key, maintenance TTY prints: RMV TRK a b ROTL LKD	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	545

**MAKE BUSY AND RESTORE TRUNK CIRCUIT USING 92A CONTROL UNIT**



NOTE 1	
After release of PRIME key, maintenance TTY prints: RST TRK a b ROTL	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	545

**MAKE BUSY AND RESTORE TRUNK CIRCUIT USING 92A CONTROL UNIT**

[1] From office records, select outgoing trunk which terminates in office that has 100-type test line [NOTE 1]

[2] Determine trunk group number, trunk member number, 100-type far-end test line directory number, estimated measured loss (EML), and noise requirement of trunk under test (TUT)

[3] At maintenance TTY, enter RMV:TRK(*a*,*b*), LKO;UCL!  
(*a* = trunk group number)  
(*b* = members number)

[4] At 92A CONTROL UNIT [FIG. 1, Page 2], set controls according to TABLE A

[5] Depress RST pushbutton on 92A CONTROL UNIT




TABLE A	
SWITCH	POSITION
TOUCH TONE/DIAL PULSE	Type line used to access ROTL
ON HOOK/OFF HOOK	ON HOOK
T PADS	Off
MONITOR	LOOP
MBO/NORM	NORM
SMALL/EXP	EXP
AUTO/MAN	AUTO
MEAS/SC	MEAS
VOLUME	Midrange
POWER	ON
900/600	900
TP0/TP2	TP0

NOTE 1	
A 100-type test line sends 1000-Hz 0-dBm tone for 10 seconds, then connects balance termination	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 7	546

**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT —  
100-TYPE TEST LINE AT FAR END**





FIG. 1 - 92A Control Unit

TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT -  
100-TYPE TEST LINE AT FAR END

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 7	546


At 92A control unit:




\* Trademark of Western Electric

**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT —  
100-TYPE TEST LINE AT FAR END**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 7	546




**NOTE 2**  
No more than 1 minute may elapse between Steps 13 and 24 due to system time-out




**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT --  
100-TYPE TEST LINE AT FAR END**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 5 of 7	546



**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT --  
100-TYPE TEST LINE AT FAR END**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 6 of 7	546



**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT –  
100-TYPE TEST LINE AT FAR END**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 7 of 7	<b>546</b>



[1] From office records, select outgoing trunk which terminates in office that has 102-type test line [NOTE 1]

[2] Determine trunk group number, trunk member number, 102-type far-end test line directory number, and estimated measured loss (EML) of trunk under test (TUT)

[3] At maintenance TTY, enter:  
 RMV:TRK(*a*,*b*),LKO;UCL!  
 (*a* = trunk group number)  
 (*b* = member number)

[4] At 92A CONTROL UNIT [FIG. 1, Page 2], set controls according to TABLE A

[5] Depress RST pushbutton on 92A CONTROL UNIT




TABLE A	
CONTROL	POSITION
TOUCH TONE/DIAL PULSE	Type line used to access ROTL
ON HOOK/OFF HOOK	ON HOOK
T PADS	Off
MONITOR	LOOP
MBO/NORM	NORM
SMALL/EXP	EXP
AUTO/MAN	AUTO
MEAS/SC	MEAS
VOLUME	Midrange
POWER	ON
900/600	900
TP0/TP2	TP0

NOTE 1  
 A 102-type test line sends 1000-Hz 0-dBm tone for 9 seconds followed by 1 second of on-hook balance termination repeated continuously

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 7	547

**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT — 102-TYPE TEST LINE AT FAR END**





FIG. 1 - 92A Control Unit

TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT -  
102-TYPE TEST LINE AT FAR END

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 7	547


At 92A CONTROL UNIT:



\* Trademark of Western Electric

**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT —  
102-TYPE TEST LINE AT FAR END**


Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 7	547



**NOTE 2**  
 No more than 1 minute may elapse between Steps 13 and 24 due to system time-out

**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT —  
 102-TYPE TEST LINE AT FAR END**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 4 of 7	547




**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT --  
102-TYPE TEST LINE AT FAR END**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 5 of 7	547


[36] Enter 00 into DATA DISPLAY using DATA ENTRY key pad

[37] Depress TEST pushbutton



TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT --  
102-TYPE TEST LINE AT FAR END

Issue 2	DEC 1983
233-142-110	DLP
PAGE 6 of 7	547



**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT –  
102-TYPE TEST LINE AT FAR END**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 7 of 7	547



- [1] From office records, select outgoing trunk which terminates in office that has 105-type test line [NOTE 1]
- [2] Determine trunk group number, trunk member number, 105-type test line directory number, estimated measured loss and noise limit requirement of trunk under test (TUT)
- [3] At maintenance TTY, enter:  
RMV:TRK(*a*,*b*),LKO;UCL!  
(*a* = trunk group number)  
(*b* = member number)
- [4] At 92A CONTROL UNIT [FIG. 1, Page 2], set controls according to TABLE A
- [5] Depress RST pushbutton on 92A CONTROL UNIT




TABLE A	
CONTROL	POSITION
TOUCH TONE/DIAL PULSE	Type line used to access ROTL
ON HOOK/OFF HOOK	ON HOOK
T PADS	Off
MONITOR	LOOP
MBO/NORM	NORM
SMALL/EXP	EXP
AUTO/MAN	AUTO
MEAS/SC	MEAS
VOLUME	Midrange
POWER	ON
900/600	900
TP0/TP2	TP0

NOTE 1	
A 105-type test line is a line which enables a 52A responder to be accessed	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 7	548

**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT – 105-TYPE TEST LINE AT FAR END**





FIG. 1 - 92A Control Unit

TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT -  
105-TYPE TEST LINE AT FAR END

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 7	548


At 92A CONTROL UNIT:



\* Trademark of Western Electric

**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT —  
105-TYPE TEST LINE AT FAR END**


Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 7	548



**NOTE 2**  
 No more than 1 minute may elapse between Steps 13 and 24 due to system time-out


**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT –  
 105-TYPE TEST LINE AT FAR END**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 4 of 7	548




**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT -  
105-TYPE TEST LINE AT FAR END**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 5 of 7	548



**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT –  
105-TYPE TEST LINE AT FAR END**


Issue 2	DEC 1983
233-142-110	DLP
PAGE 6 of 7	548



**TEST REMOTE OFFICE TEST LINE (ROTL) USING 92A CONTROL UNIT –  
105-TYPE TEST LINE AT FAR END**


Issue 2	DEC 1983
233-142-110	DLP
PAGE 7 of 7	548





**ESTABLISH OFFICE CONNECTIONS TO MINI-ROTL TUT PORT USING 92A CONTROL UNIT**


Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 3	549



**ESTABLISH OFFICE CONNECTIONS TO MINI-ROTL TUT PORT  
USING 92A CONTROL UNIT**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 3	549

[11] At TLTP set, STATE CONTROL to ACCESS TRUNK 1; ASSOCIATED JUNCTOR to YES;  $\bar{A}$   $\bar{B}$  C [NOTE 1]



[12] Momentarily depress EXECUTE key [NOTE 2]

NOTES

1. The  $\bar{A}$   $\bar{B}$  C switch settings are as follows:  
 $\bar{A}$  down  
 $\bar{B}$  down  
C up
2. After release of EXECUTE key, EQUIPMENT STATUS 1 lamp lighted steady and PROGRESS OR ERROR lamps flashing 120 IPM


ESTABLISH OFFICE CONNECTIONS TO MINI-ROTL TUT PORT USING 92A CONTROL UNIT

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 3	549



At the mini-RTTU:

- [1] Depress the -48V PWR switch to turn -48 volt power off



-48V PWR OFF  
lamp lighted


- [2] Remove SM422

- [3] Ensure that all S1 switches on SM422 are in the down position [FIG. 1, Page 2]

- [4] Insert SM422 onto the 914A tool (extender circuit pack) [WARNING 1]

- [5] Insert the extender circuit pack (with SM422 installed) into the slot designated for SM422

- [6] Depress the -48V PWR switch to turn -48 volt power on



-48V PWR OFF  
lamp extinguishes



Page 2

**WARNING 1**  
*Damage may occur in mini-RTTU components if the circuit pack is not inserted into the extender before the extender is inserted into the mini-RTTU*

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 2	550

**PREPARE MINI-RTTU FOR LOSS BUILD-OUT ADJUSTMENTS**

At the mini-RTTU:

[7] Connect the portable data terminal to a 115 Vac outlet near the mini-RTTU

[8] Connect the EIA RS 232 connector on the data terminal to the EIA connector on the mini-RTTU

[9] Turn on power to the data terminal

[10] Set the data terminal controls as shown in TABLE A [NOTE 1]

At the mini-RTTU:

[11] Set the SPKR switch to the ON position

[12] Set the VOL switch to midrange

At the data terminal:

[13] Enter AD:\*\*/RA! to reset mini-RTTU circuitry

DC: *jn*/RR;DC!  
 TM: ~~00~~/RR;TM!  
 AD: *jn*/RA!  
 RF: *jn*/RR;RF!  
 OM: *jn*/RR;OM!  
 (where *jn*=job number)  
 appears on the data terminal

CONTROL	POSITION
Half duplex/full duplex	Half duplex
Parity	No parity
Auto line feed	On (on enabled)
Caps lock	On (or enabled)
Baud rate	300 or 1200




FIG. 1

**NOTE 1**  
 The default baud rate is 300. The BREAK key on the data terminal can be used to change the baud rate from 300 to 1200 or from 1200 to 300

Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 2	550

PREPARE MINI-RTTU FOR LOSS BUILD-OUT ADJUSTMENTS

At the test frame (TLTP):

- [1] Connect the **WILCOM\* T 105 B** reference level test set (RTS) to a 115 Vac outlet at the test frame \_\_\_\_\_
- [2] Set the **WILCOM T 105 B** RTS controls as shown in TABLE A \_\_\_\_\_
- [3] Depress the **POWER** switch (pushbutton) on the **WILCOM T 105 B** RTS to turn on power \_\_\_\_\_
- [4] Connect one end of the low loss test cord to **INPUT 310** jack on the **WILCOM T 105 B** RTS \_\_\_\_\_
- [5] Connect the other end of the low loss cord to the **ACCESS TRUNK 2** jack located under the writing shelf on the test frame \_\_\_\_\_




TABLE A	
CONTROL	POSITION
METER RANGE	±1 DB
INPUT LEVEL	0.00 DBM
INPUT	900Ω DBM TERM
FUNCTION	MEAS INPUT
OUTPUT	OFF

\* Trademark of Wilcom Products, Inc.

**PREPARE WILCOM T 105 B REFERENCE LEVEL TEST SET FOR MINI-RTTU  
LOSS BUILD-OUT MEASUREMENTS**



At portable data terminal:

[1] Enter ! to clear inputs

Error message appears on data terminal [NOTE 1]

[2] Enter:  
GR:\*\*/GR;RF;M;SA;9;TO!


GR: *jn*/GR;RF;M;SA;9;TO!  
(where *jn* = job number)  
appears on the data terminal

[3] Enter:  
GT: *jn*/GT;LN;*x*;01;N;NL;NL;AB;AB!  
(where *jn* = job number and  
*x* = 7-digit directory number of  
access trunk 2 at the TLTP

OM: *jn*/GC>AS;ID;AC;NL;NL;NL!  
OM: *jn*/KC;ND!  
OM: 00/SC;01;S;F!  
OM: 00/SC;01;S;F!  
OM: 00/SC;01;S;F!  
(where *jn* = job number)  
appears on the data terminal

[4] Enter:  
RF: *jn*/MT>SP!  
(where *jn* = job number)

A 1004-Hz tone is heard on the  
mini-RTTU speaker [NOTE 2]



**NOTES**

1. Error message may be ignored
2. The 1000-Hz tone will last for 5 minutes if it is not released via the data terminal

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 3	552





FIG. 1

<b>NOTE 3</b>	
S1 switches should be operated in pairs; 1 and 2, 3 and 4, 5 and 6, and 7 and 8	
Issue 2	DEC 1983
233-142-110	DLP
PAGE 2 of 3	<b>552</b>

At portable data terminal:

[10] Type **CM:jn/CM;RL!**

(where *jn* = job number)

**CM:jn/CM;RL!**

(where *jn* = job number)

appears on the data terminal;

the 1000-Hz tone disappears



**ADJUST MINI-RTTU BUILDOUT**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 3	552

At the mini-RTTU:

[1] Depress the -48V PWR switch to turn -48 volt power off

-48V PWR OFF  
lamp lighted

[2] Remove the extender circuit pack containing SM422

[3] Remove SM422 from the extender circuit pack

[4] Insert SM422 into its proper slot location on the mini-RTTU

[5] Depress the -48V PWR switch to turn -48 volt power on

-48V PWR OFF  
lamp extinguishes

At the mini-RTTU:

[6] Set the SPKR switch to the OFF position

DC: *jn*/RR;DC!  
TM: 00/RR;TM!  
AD: *jn*/RA!  
OM: *jn*/RR;OM!  
RF: *jn*/RR;RF!  
(where *jn* = job number)  
appears on the data terminal

At the data terminal:

[7] Enter AD:\*\*/RA! to reset inputs

[8] Set the power switch on the portable data terminal to the off position

[9] Disconnect the portable data terminal from the EIA connector on the mini-RTTU

AND


AND

**RESTORE MINI-RTTU TO NORMAL**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	553

At the mini-RTTU:

[1] Depress the -48V PWR switch to turn -48 volt power off




-48V PWR OFF  
lamp lighted


[2] Remove the desired circuit pack(s)

[3] Insert new (or good) circuit pack(s) into proper position(s) on the mini-RTTU

[4] Depress the -48V PWR switch to turn -48 volt power on




-48V PWR OFF  
lamp extinguishes



## REPLACE MINI-RTTU CIRCUIT PACK(S)


Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 1	554






**PERFORM USART DIAGNOSTIC TEST – TE 37**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 1 of 3	555





**PERFORM USART DIAGNOSTIC TEST – TE 37**

Issue 2	DEC 1983
233-142-110	DLP
PAGE 3 of 3	555

ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE
TPG-000		DLP-510		DLP-545							
IXL-001		DLP-511		DLP-546							
NTP-002		DLP-512		DLP-547							
NTP-003		DLP-513		DLP-548							
NTP-004		DLP-514		DLP-549							
NTP-005		DLP-515		DLP-550							
NTP-006		DLP-516		DLP-551							
NTP-007		DLP-517		DLP-552							
NTP-008		DLP-518		DLP-553							
TAP-100		DLP-519		DLP-554							
TAP-101		DLP-520		DLP-555							
TAP-102		DLP-521		CKL-891							
TAP-103		DLP-522		TNG-893							
TAP-104		DLP-523		DPL-895							
TAP-105		DLP-524									
TAP-106		DLP-525									
TAP-107		DLP-526									
TAP-108		DLP-527									
TAP-109		DLP-528									
TAP-110		DLP-529									
TAP-111		DLP-530									
TAP-112		DLP-531									
TAP-113		DLP-532									
TAP-114		DLP-533									
TAP-115		DLP-534									
DLP-500		DLP-535									
DLP-501		DLP-536									
DLP-502		DLP-537									
DLP-503		DLP-538									
DLP-504		DLP-539									
DLP-505		DLP-540									
DLP-506		DLP-541									
DLP-507		DLP-542									
DLP-508		DLP-543									
DLP-509		DLP-544									
									Issue 2	DEC 1983	
									233-142-110	CKL	
<b>CHECKLIST</b>									PAGE 1 of 1	<b>891</b>	



This book is called a Task Oriented Practice or "TOP". It is a programmed document that gives step-by-step instructions to enable you to do a job (or task). A TOP can be a very useful aid in doing your everyday work if you use it correctly.

An important thing to remember about TOP is that it is a programmed document giving step-by-step instructions to do a job. Since the instructions are given in the order that they must be done, you cannot enter a procedure except at the beginning. You *must* do the step-by-step instructions in the order given. Failure to follow the instructions in the proper order may cause service interruptions.

Another thing to remember about TOP is that it contains all the instructions that you need to do a job. If you are experienced on a particular job, TOP will provide you with just that information you need to do the job. If you are doing the job for the first time, you will be given step-by-step instructions with enough detail so that you will not have to guess or remember where to find the necessary details. Remember that TOP can provide you with just that information you need regardless of your experience in doing a job.

The work that you do can be classified into two broad job categories – *Trouble Clearing* and *Non Trouble Clearing*. This is how TOP defines these two types of work:

#### ***Trouble Clearing***

Trouble clearing is simply what it says – that work you do to clear and repair troubles in the system. Trouble clearing may be done in answering a customer complaint or in responding to an office alarm, a trouble report, or an abnormal TTY printout, etc.

#### ***Non Trouble Clearing***

Non trouble clearing is simply what it says – that work you do which is not connected with trouble clearing. This type is work that you do to accept a system after it has been installed, turn up a system for service, maintain a system according to a controlled maintenance plan, etc.

Now glance briefly at the front cover. In the upper right corner is a 9-digit number which identifies the volume. Near the center is the title of the volume which tells you something about the contents, such as the system (or subsystem) name and perhaps what kind of jobs are included in the volume. Next is the decision-action-logic diagram which directs you either to this training package or to 001 depending on your ability to use TOP.

Now turn to FIG. 1 which shows a typical page of 001. In the lower left is the title, "TASK INDEX LIST" which tells you something about this list, such as it is a listing of tasks arranged in alphabetical order. This list is actually a listing of the tasks included in the volume. The tasks are listed in alphabetical order and permuted on key words to simplify locating a task. On the right side of the page is a column of reference numbers under the heading "THEN GO TO." To use this list, locate the job to be done and turn to the reference number in the "THEN GO TO" column.

Now assume that you have been assigned the task of performing a system test on a system covered by a TOP. On 001 in FIG. 1, locate the job "System Test." Notice that this entry tells you to go to NTP-016 (Non Trouble Procedure) under the "THEN GO TO" column. Next you will have to locate the procedure, NTP-016. All procedures in a TOP are arranged in numerical sequence. In actual use of TOP, you would simply turn to the procedure. Look over

FIND YOUR JOB IN THE LIST BELOW . . . . .	THEN GO TO
Alert; External - Horn, Ringer, Etc. - Remove . . . . .	NTP-028
Amplifiers; Channel - Recorded Announcement Frame - Test . . . . .	NTP-009
AR03 PWR ALM RA bb - bb = 16-30 . . . . .	TAP-105
<b>BRDG</b> LED - Does Not Light - Correct . . . . .	TAP-117
Bridging Controller; Trunk - J1C015MB - Replace . . . . .	DLP-572
Channel Amplifiers - Recorded Announcement Frame - Test . . . . .	NTP-009
Drum Wiper - Common Systems Recorded Announcement Frame - Inspect . . . . .	NTP-010
Extended Station Capability - Nonkey Set Only - Reported Failure . . . . .	TAP-123
External Alert - Horn, Ringer, Etc. - Remove . . . . .	NTP-028
Interchange Two Working Station Numbers . . . . .	NTP-081
LED; <b>BRDG</b> - Does Not Light - Correct . . . . .	TAP-117
Loudspeaker Paging - Add . . . . .	NTP-059
Loudspeaker; - Remove . . . . .	NTP-006
Station Capability; Extended - Nonkey Set Only - Reported Failure . . . . .	TAP-123
System Test - Perform . . . . .	NTP-016
Trunk Bridging Controller - J1C015MB - Replace . . . . .	DLP-572
TTY Printout - AR03 PWR ALM RA bb - bb = 16-30 . . . . .	TAP-105
Wiper; Drum - Common Systems Recorded Announcement Frame - Inspect . . . . .	NTP-010

<b>TASK INDEX LIST (Contd)</b>	<b>Issue 1</b>	<b>DEC 1980</b>
	123-456-789	IXL
	PAGE 2 of 2	001

FIG. 1

**HOW TO USE TOP**

	<b>TNG</b>
<b>PAGE 2 of 8</b>	<b>893</b>

the following example which shows a typical page of NTP-016. Note that the items are numbered in the left column. They *must* be completed in that order. You will also note that in item 2 there are some lettered (A, B, C) items. These lettered items are optional ways to do an item, that is you only have to do one of the lettered items.

Remember that this procedure gives you all the items that must be done and the order in which they must be done to complete the job. If you know how to do an item, you should go ahead and do it without going to the referenced details

in the "FOR DETAILS, GO TO" column. If, on the other hand, you need additional details on how to do the item, then you should turn to the procedure listed in the "FOR DETAILS, GO TO" column. In either case, after completing an item, you should continue with the next item.

A TOP is designed so that you have to read only what is necessary to get your job done. If you know how to do an item, look no further for the "how to" information – just do the item and go on to the next item. This idea is called "bypassing" in TOP. In addition to not having to

DO THE ITEMS BELOW IN THE ORDER LISTED . . . . .		FOR DETAILS, GO TO						
1	Obtain Support Apparatus Listed Below: • Hewlett-Packard 3531A Transmission Measuring Set • 2P4C Patching Cord	-						
2	Place SEC/SEB in Off-Line Mode	-						
	A. If in On-Line Mode, Change System From On-Line to Off-Line	DLP-509						
	B. If Powered Down, Condition System for Off-Line Operation as Follows:	-						
	1. Power up Minicomputer	DLP-503						
	2. Power up Line Printer	DLP-528						
	3. Power up Maintenance Terminal	DLP-510						
7	Run Computer Display Terminal Test for All Positions	DLP-513						
8	Mount Tape	DLP-500						
<b>PERFORM SYSTEM TEST</b>		<table border="1"> <tr> <td>Issue 1</td> <td>DEC 1980</td> </tr> <tr> <td>123-456-789</td> <td>NTP</td> </tr> <tr> <td>PAGE 1 of 4</td> <td><b>016</b></td> </tr> </table>	Issue 1	DEC 1980	123-456-789	NTP	PAGE 1 of 4	<b>016</b>
Issue 1	DEC 1980							
123-456-789	NTP							
PAGE 1 of 4	<b>016</b>							

**HOW TO USE TOP**

	TNG
PAGE 3 of 8	<b>893</b>

look further for details, three other ways of "bypassing" are provided in TOP to help you bypass reading information you already know (see FIG. 2):

**Summary Statement**


A summary statement is used with a procedure to tell you briefly how to do the procedure and what type measurement or result can be observed. If you can do the procedure after reading the summary, go ahead and do it without reading any further. Simple procedures may not have summaries.

**Result Statement**

A result statement may be used in a flow-charted procedure along with the AND symbol. If, after reading the results statement, you know how to do the action indicated, go ahead and do it without reading the steps associated with the AND symbol.

**Support Procedures**


When you see the following kind of reference in TOP it refers to a support procedure:  
 The support procedure [DLP-530] (Detailed Level Procedure) provides the information on how to



operate the VTVM. Here again, if you already know how to operate the VTVM, go ahead and do it without looking up any further information.

Now assume that you are doing a system test on a system covered by a TOP. In the process of doing this test you are instructed to mount a tape. For the purposes of this example, assume that you do not know how to mount the tape and must look up additional details. Figure 2 on Page 5 shows you examples of bypassing that can be used. Take a few moments to examine this figure and make sure you understand the techniques of bypassing.

While using a TOP, you will probably run across a reference similar to this:



This reference to TAP-103 (Trouble Analysis Procedure) indicates that the equipment is not operating correctly, and that you should refer to TAP-103 and clear this trouble condition. After clearing the trouble, you should reenter the flowchart at the beginning (Step 1).





FIG. 2

This idea can be carried further. In some cases, a decision block may have more than one abnormal output. This means that you should try more than one solution to the problem. See the example below.




Trouble-clearing information in TOP is used basically the same way as non trouble-clearing information. When an alarm or trouble report requires you to troubleshoot a system covered by a TOP, the TASK INDEX LIST (IXL-001) is the place to start. After locating your job on IXL-001 you will be referenced to a Trouble Analysis Procedure (TAP) to find the information to aid in the location of the trouble. The TAP may reference to other information, such as Trouble Analysis Data (TAD) or Isolation Diagram (ISD) as an aid in the trouble-clearing process.

Now assume that you have to clear a major alarm on a terminal in a system covered by a TOP. Figure 3 on Page 7 shows how to access and how to use trouble-clearing information.

## HOW TO USE TOP

A TOP shows hard-wired and plug-in units on Isolation Diagrams (ISD) in the following manner:



Always do a job safely. Below are three things you should heed in TOP:




TABLE A on Page 8 shows some of the more important symbols and definitions.

While using TOP, if you find errors, or if a procedure is inadequate or missing, call the TOP HOTLINE number shown on the front cover. Your comments are greatly needed to help prepare better documentation. Comments may also be forwarded using form E3973 which is available through your company.

Now that you know how to use TOP, return to IXL-001 and find the job you need to do.

	TNG
PAGE 6 of 8	893

<b>FIND YOUR JOB IN THE LIST BELOW . . . . .</b>	<b>. . . . . THEN GO TO</b>
Alert; External - Horn, Ringer, Etc. - Remove . . . . .	NTP-028
Alarm - Major - Clear . . . . .	<b>TAP-109</b>
TTY Printout - AR03 PWR ALM RA bb - bb = 16-30 . . . . .	TAP-105
Wiper; Drum - Common Systems Recorded Announcement Frame . . . . .	NTP-010
	Issue 1 DEC 1980
	123-456-789 ISD
<b>TASK INDEX LIST (Contd)</b>	PAGE 2 of 2 001








FIG. 3

<b>TABLE A</b>	
<b>IMPORTANT TOP SYMBOLS AND DEFINITIONS</b>	
<b>SYMBOL</b>	<b>DEFINITION</b>
	<p>The AND operation symbol is used where the successful completion of a group of instructions accomplishes a meaningful result that can be defined. The symbol indicates that each input instruction must be performed in the order given to accomplish the output (result statement). In instances where results cannot be defined, results statements are not provided.</p>
	<p>The flow-through symbol relates graphically a single instruction to the expected observable result(s).</p>
	<p>The end-of-procedure symbol denotes that the procedure has been completed.</p>
	<p>The reference bubble symbol indicates an exit from a page (either to a continuation page or to trouble-clearing data) or indicates the starting point of a procedure.</p>
<p>Acceptance (NTP-002)</p>	<p>Acceptance gives an overview of the acceptance techniques and facilities.</p>
<p>Maintenance Philosophy (TAD-100)</p>	<p>The maintenance philosophy, when provided, gives an overview of the considerations designed into the trouble-clearing procedures.</p>
<p>Checklist (CKL-891)</p>	<p>The checklist reflects the volume content (inventory) at any given time, the issue identifier of each data element therein, those data elements revised and/or added, and those data elements deleted from a previous issue.</p>
<p>Documentation Plan (DPL-895)</p>	<p>The documentation plan gives a bird's-eye view of all the TOP volumes covering a system. This plan can help you to quickly determine the correct volume.</p>

3"ESS\*" Switch

Office Equipment	233-142-100
ROTL/Mini-RTTU	233-142-110
System Trouble Clearing	233-143-100
Power Equipment	233-144-100

\* Trademark of Western Electric

**3"ESS" SWITCH – TOP DOCUMENTATION PLAN**

	DPL
PAGE 1 of 1	895