

**BELL SYSTEM PRACTICES**  
**AT&TCo Provisional**

**Task Oriented Practice**  
**(TOP)**

## **NO. 3 ESS POWER EQUIPMENT**

**NOTE**

Before using TOP for the first time,  
complete the TOP-USER Plant Training  
Course-PTC No. 278.

A short version of PTC No. 278 is in  
the back of this volume.

**NOTICE**

Not for use or disclosure outside the  
Bell System except under written agreement

Printed in U.S.A.

<b>Issue 2</b>	<b>JUL 1980</b>
<b>233-144-100</b>	<b>TPG</b>
<b>TITLE PAGE</b>	



ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE	ITEM	ISSUE
● CHECKLIST		TAP-194		● DLP-507		DLP-556		● DLP-691			
● RTL-001		TAP-195		● DLP-508		DLP-557		□ DLP-692			
RTP-002		TAP-196		● DLP-509		● DLP-560		DLP-693			
● RTP-003		TAP-197		DLP-511		● DLP-561		● DLP-695			
□ RTP-004		● TAP-198		● DLP-512		● DLP-562		● DLP-696			
● RTP-005		● TAP-199		DLP-513		DLP-563		DLP-698			
RTP-006		● ISD-200		DLP-514		DLP-564		● DLP-699			
● RTP-007		● TAP-201		DLP-515		● DLP-565		● DLP-700			
● RTP-008		● TAP-202		● DLP-516		DLP-566		● DLP-701			
● RTP-009		TAP-203		DLP-517		DLP-567		● DLP-702			
● RTP-010		● TAP-204		DLP-518		DLP-568		● DLP-703			
● RTP-011		TAP-205		□ DLP-519		DLP-569		● DLP-704			
● RTP-012		□ TAP-207		□ DLP-520		DLP-570		● DLP-705			
● RTP-013		● TAP-209		□ DLP-521		● DLP-575		● DLP-710			
● ATL-030		● TAP-210		● DLP-522		● DLP-576		● DLP-711			
● ATP-031		□ TAP-212		● DLP-523		● DLP-577		● DLP-712			
● ATP-032		● TAP-215		● DLP-525		● DLP-578		● DLP-714			
● ATP-033		TAP-230		● DLP-526		DLP-579		● DLP-715			
● ATP-034		TAP-231		DLP-527		DLP-580		● DLP-716			
● ATP-035		● TAP-232		● DLP-528		DLP-581		● DLP-717			
● ATP-036		TAP-233		DLP-530		● DLP-582		● DLP-718			
● ATP-037		TAP-234		● DLP-540		DLP-610		● DLP-719			
● ATP-038		TAP-236		● DLP-541		DLP-611		● DLP-720			
COL-050		● TAP-237		● DLP-542		DLP-612		□ DLP-721			
TAP-134		● TAP-238		● DLP-543		● DLP-613		● IXL-890			
TAP-180		● TAP-239		● DLP-544		● DLP-614					
TAP-181		● TAP-240		● DLP-545		● DLP-615					
TAP-182		● TAP-241		● DLP-546		DLP-616					
TAP-183		DLP-500		● DLP-547		● DLP-617					
TAP-184		● DLP-501		DLP-550		DLP-618					
TAP-185		● DLP-502		DLP-551		DLP-620					
● TAP-190		● DLP-503		● DLP-552		□ DLP-685					
TAP-191		● DLP-504		● DLP-553		□ DLP-686					
ISD-192		DLP-505		● DLP-554		DLP-687					
● TAP-193		DLP-506		● DLP-555		DLP-689					

● REVISED OR ADDED ITEM

□ CANCELED ITEM

Issue 2 JUL 1980


233-144-100

CKL

PAGE 1 of 1

000

CHECKLIST



ROUTINE TASKS	PROCEDURE NUMBER
<b>SCHEDULED</b>	
Check Output of 151A Power Plant	RTP-006
Maintain -48V Battery Equipment	RTP-009
Inspect -48V Battery Equipment	RTP-010
Measure Individual Cell Voltage	DLP-576
Check KS-20816 L2 Inverter	RTP-002
Check Miscellaneous Power Units	RTP-003
Check 151A Power Plant	RTP-005
Check Side 0 - 881A Ringing and Tone Plant	RTP-007
Check Side 1 - 881A Ringing and Tone Plant	RTP-008
Check and Adjust 400A Tone Generator	DLP-560
Test Ringing Distribution Fuse Alarms	DLP-561
Check ITT-North KS-20493 48V Rectifier	RTP-011
Check Lorain KS-20493 48V Rectifier	RTP-012
Check J87437A 48V Rectifier	RTP-013
<b>RESPONSE TO REQUESTS</b>	
Remove Side 0 of Ringing and Tone Plant From Service	DLP-550
Remove Side 1 of Ringing and Tone Plant From Service	DLP-540
Turn Up and Restore to Service Side 0 of Ringing and Tone Plant	DLP-557
Turn Up and Restore to Service Side 1 of Ringing and Tone Plant	DLP-547
<b>ROUTINE TASK LIST NO. 3 ESS POWER EQUIPMENT</b>	Issue 2 JUL 1980
	233-144-100 RTL
	PAGE 1 of 1 001

ITEM	SUBTASKS	PROCEDURE NUMBER
	NOTE 1: There is a normal time delay of 30-50 seconds when operating the <b>INVERTER TEST</b> switch	
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Digital Multimeter      KS-20599, L4</li> <li>• Frequency Counter      Hewlett-Packard Model 779C</li> <li>• Jewelers Screwdriver    R1005</li> </ul>	-
2	Loosen Fastener Screws on Upper Front of Cover; Pull Cover Forward and Down	-
3	Check DC Input Voltage	DLP-612
4	Check AC Output Voltage	DLP-613
5	Calibrate Panel Voltmeter	DLP-614
6	Check AC Output Frequency	DLP-615
7	Close Cover; Tighten Fastener Screws	-
8	Check Inverter Transfer and Alarm Circuit	DLP-610

**CHECK KS-20816 L2 INVERTER**

Issue 2	JUL 1980
233-144-100	RTP
PAGE 1 of 1	002

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Digital Multimeter      KS-20599, L4</li> <li>• Jewelers Screwdriver    R1005</li> <li>• Test Cord                W1AY Cord</li> <li>• Test Pick                411C Tool</li> <li>• Cord Tip                 141 Cord Tip</li> <li>• Voltage Pickup Tool      720A Tool</li> </ul>	-
2	Prepare Fuse Alarm Test Cord	DLP-513
3	Check 188A Power Unit (+24V Converter) Power Alarm	DLP-691
4	Check 188A Power Unit (+24V Converter) No Power Alarm	DLP-693
5	Check/Adjust 188A Power Unit (+24 Volt Converter) DC Output Voltage	DLP-687
6	Repeat Items 3, 4, and 5 for Each Additional Individual 188A Power Unit	-
7	Check 184A Power Unit (+48V Converter) Output	DLP-695
8	Repeat Item 7 for Each Additional Individual 184A Power Unit	-
9	Remove Side 0 of Ringing and Tone Plant From Service	DLP-550
10	Check 184A Power Unit (+48V Converter) Fuse Alarm - Side 0	DLP-696
11	Restore Side 0 of Ringing and Tone Plant to Service	DLP-557
12	<del>Restore</del> <sup>Remove</sup> Side 1 of Ringing and Tone Plant From Service	DLP-540
13	Check 184A Power Unit (148V Converter) Fuse Alarm - Side 1	DLP-696
14	<del>Restore</del> <sup>Remove</sup> Side 1 of Ringing and Tone Plant to Service	DLP-547
15	Check 184B Power Unit ( $\pm$ 130V Converter) Output	DLP-698
16	Check 184B Power Unit ( $\pm$ 130V Converter) Fuse Alarms	DLP-699
17	Repeat Items 15 and 16 for Each Additional Individual 184B Power Unit	-

**CHECK MISCELLANEOUS POWER UNITS**

ITEM	SUBTASKS	PROCEDURE NUMBER						
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Digital Multimeter      KS-20599, L4</li> <li>• Jewelers Screwdriver    R1005</li> <li>• Jumper Cord              WIAP</li> <li>• Test Cord                 WIAY Cord</li> <li>• Test Pick                 411C Tool</li> <li>• Cord Tip                 141 Cord Tip</li> <li>• Voltage Pickup Tool      720A Tool</li> </ul>	-						
2	Check Battery Bus Voltage and 48V Rectifier Output Current	DLP-504						
3	Calibrate 151A Power Plant Voltmeter	DLP-505						
4	Prepare Fuse Alarm Test Cord	DLP-513						
5	Check 151A Power Plant Fuse Alarms	DLP-506						
6	Check Lorain or ITT-North KS-20493 48V Rectifier Failure Alarms	DLP-507						
7	Check 151A Power Plant High Voltage (HVM) Shutdown Circuit	DLP-508						
8	Check 151A Power Low Voltage (LV1 and LV2) Monitors	DLP-509						
9	Check Battery Bus Voltage and 48V Rectifier Output Current	DLP-504						
<b>CHECK 151A POWER PLANT</b>		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: center;">Issue 2</td> <td style="width: 50%; text-align: center;">JUL 1980</td> </tr> <tr> <td style="text-align: center;">233-144-100</td> <td style="text-align: center;">RTP</td> </tr> <tr> <td style="text-align: center;">PAGE 1 of 1</td> <td style="text-align: center;">005</td> </tr> </table>	Issue 2	JUL 1980	233-144-100	RTP	PAGE 1 of 1	005
		Issue 2	JUL 1980					
		233-144-100	RTP					
PAGE 1 of 1	005							

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Obtain Support Apparatus or Equivalent • Digital Multimeter KS-20599, L4	-
2	Check Battery Bus Voltage and 48V Rectifier Output Current	DLP-504
CHECK OUTPUT OF 151A POWER PLANT		Issue 2
		JUL 1980
		233-144-100
		RTP
		PAGE 1 of 1
		006

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Digital Multimeter      Hickok Model 3310 (ITE 5356)</li> <li>• Frequency Counter      General Radio Model 1159</li> <li>• Test Cord                  WIAY Cord</li> <li>• Test Pick                  411C Tool</li> <li>• Cord Tip                    141 Cord Tip</li> <li>• Voltage Pickup Tool      720A Tool</li> </ul>	-
2	Isolate DMM From Ground	DLP-720
3	Prepare Fuse Alarm Test Cord	DLP-513
4	Remove Side 0 From Service	DLP-550
<i>CAUTION: Tone voltages to be measured are complex ac waveforms. A True RMS indicating voltmeter is required to accurately adjust voltage levels. Peak and average ac voltmeters produce inaccurate readings</i>		
5	Check Tone Oscillators (350, 440, 480, and 620) - Side 0	DLP-552
6	Check Tone Amplifiers (TT, AR, BT, MT, and HT) - Side 0	DLP-553
7	Test Low Voltage Monitors (TTLVO, ARLVO, BTLVO, MTLVO, and HTLVO) - Side 0	DLP-554
8	Check 20-Hz Inverter - Side 0	DLP-555
9	Test 48-Volt Distribution Fuse Alarms - Side 0	DLP-556
10	Turn Up and Restore to Service Side 0	DLP-557
<b>CHECK SIDE 0 - 881A RINGING AND TONE PLANT</b>		Issue 2      JUL 1980
		233-144-100      RTP
		PAGE 1 of 1      007

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Digital Multimeter      Hickok Model 3310 (ITE 5356)</li> <li>• Frequency Counter      General Radio Model 1159</li> <li>• Test Cord                      W1AY Cord</li> <li>• Test Pick                      411C Tool</li> <li>• Cord Tip                        141 Cord Tip</li> <li>• Voltage Pickup Tool      720A Tool</li> </ul>	-
2	Isolate DMM From Ground	DLP-720
3	Prepare Fuse Alarm Test Cord	DLP-513
4	Remove Side 1 From Service  <i>CAUTION: Tone voltage to be measured are complex ac waveforms. A <u>True RMS</u> indicating voltmeter is required to accurately adjust voltage levels. Peak and average ac voltmeters produce inaccurate readings</i>	DLP-540
5	Check Tone Oscillators (350, 440, 480, and 620) - Side 1	DLP-542
6	Check Tone Amplifiers (TT, AR, BT, MT, and HT) - Side 1	DLP-543
7	Test Low Voltage Monitors (TTLV1, ARLV1, BTLV1, and HTLV1) - Side 1	DLP-544
8	Check 20-Hz Inverter - Side 1	DLP-545
9	Test 48-Volt Distribution Fuse Alarms - Side 1	DLP-546
10	Turn Up and Restore to Service Side 1	DLP-547

**CHECK SIDE 1 - 881A RINGING AND TONE PLANT**

ITEM	SUBTASKS	PROCEDURE NUMBER		
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Syringe-Type Hydrometer      KS-5499, L1305</li> <li>• Thermometer                      KS-5499, L1352 or L1353</li> <li>• Goggles                              R-4501</li> <li>• Rubber Acid Gloves              R-3034</li> <li>• Rubber Apron                      R-3043</li> <li>• Digital Multimeter              KS-20599, L4</li> <li>• 1/4 Lb Table Soda   or 1/8 Lb. Washing Soda              -</li> <li>• Clean Cloth                        -</li> <li>• Clean Water                        -</li> </ul>	-		
	<p><i><b>DANGER: Protective equipment such as rubber gloves, rubber aprons, and splash-proof goggles should be worn when performing maintenance on batteries. Rings, wrist watches, metal bracelets, necklaces, belt buckles, etc, should be removed</b></i></p>			
2	Measure Individual Cell Voltage (2.13 to 2.22 Volts) for All Cells	DLP-576		
3	Maintain Electrolyte Level	DLP-579		
4	Maintain Battery Terminals and Connectors	DLP-577		
5	Inspect and Clean Antiexplosion Device	DLP-582		
6	Clean Battery Jars	DLP-581		
7	Clean Racks and Stands	DLP-580		
<b>MAINTAIN -48V BATTERY EQUIPMENT</b>		<table border="1" style="width: 100%;"> <tr> <td style="width: 50%;">Issue 2</td> <td style="width: 50%;">JUL 1980</td> </tr> </table>	Issue 2	JUL 1980
		Issue 2	JUL 1980	
		<table border="1" style="width: 100%;"> <tr> <td style="width: 80%;">233-144-100</td> <td style="width: 20%;">RTP</td> </tr> </table>	233-144-100	RTP
233-144-100	RTP			
<table border="1" style="width: 100%;"> <tr> <td style="width: 80%;">PAGE 1 of 1</td> <td style="width: 20%; text-align: right;"><b>009</b></td> </tr> </table>	PAGE 1 of 1	<b>009</b>		
PAGE 1 of 1	<b>009</b>			

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Obtain Support Apparatus or Equivalent • Thermometer           KS-5499, L1352 or L1353    X • Pinlight Flashlight       -                                    X • Goggles                   R-4501                            X • Rubber Acid Gloves       R-3034                           X • Rubber Apron             R-3043                           X	-
	<i><b>DANGER: Protective equipment such as rubber gloves, rubber aprons, and splash-proof goggles should be worn when performing maintenance on batteries. Rings, wrist watches, metal bracelets, necklaces, belt buckles, etc, should be removed</b></i>	
2	Check Electrolyte Temperature	DLP-578
3	Inspect Individual Cells for Crystals	DLP-575
<b>INSPECT -48V BATTERY EQUIPMENT</b>		Issue 2    JUL 1980
		233-144-100    RTP
		PAGE 1 of 1    010

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Place ITT-North KS-20493 48V Rectifier in Test Mode	DLP-710
2	Check ITT-North KS-20493 48V Rectifier Output Voltage	DLP-711
3	Check ITT-North KS-20493 48V Rectifier Current Limiting Adjustment	DLP-712
4	Check ITT-North KS-20493 48V Rectifier TR Shutdown	DLP-714
5	Check ITT-North KS-20493 48V Rectifier HV Shutdown	DLP-715
6	Check ITT-North KS-20493 48V Rectifier Automatic Restart	DLP-716
7	Power Up Individual North KS-20493 48V Rectifier	DLP-717
<b>CHECK ITT-NORTH KS-20493 48V RECTIFIER</b>		Issue 2    JUL 1980
		233-144-100    RTP
		PAGE 1 of 1    011

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Power Down Individual Lorain 48V Rectifier	DLP-500
2	Check Lorain 48V Rectifier Output Voltage	DLP-501
3	Check Lorain 48V Rectifier Current Limit Circuit	DLP-502
4	Power Up Individual Lorain 48V Rectifier	DLP-503
<b>CHECK LORAIN KS-20493 48V RECTIFIER</b>		Issue 2    JUL 1980
		233-144-100    RTP
		PAGE 1 of 1    012

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Power Down Individual J87437A 48V Rectifier	DLP-701
2	Check J87437A 48V Rectifier Output Voltage	DLP-702
3	Power Up Rectifier	DLP-704
4	Check Adjustment of J87437A Rectifier Current Limit and Regulator Circuit	DLP-703

**CHECK J87437A 48V RECTIFIER**

ACCEPTANCE TASKS	PROCEDURE NUMBER
Accept 151A Power Plant	ATP-031
Accept Miscellaneous Power Units	ATP-032
Accept 881A Ringing and Tone Plant	ATP-033
Accept KS-20816 L2 Inverter	ATP-034
Accept KS-20472 Battery	ATP-035
Accept Individual North KS-20493 48V Rectifier	ATP-036
Accept Individual Lorain KS-20493 48V Rectifier	ATP-037
Accept Individual J87437A 48V Rectifier	ATP-038
ACCEPTANCE TASK LIST – NO. 3 ESS POWER EQUIPMENT	Issue 2   JUL 1980
	233-144-100   ATL
	PAGE 1 of 1   030

ITEM	SUBTASKS	PROCEDURE NUMBER
	NOTE 1: Refer trouble to installation group whenever indications in this procedure are not obtained	-
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Digital Multimeter                      KS-20599, L4</li> <li>• Jewelers Screwdriver                      R1005</li> <li>• 3-Inch C Screwdriver                      -</li> <li>• Jumper Cords (2)                              WIAP</li> <li>• Test Cord                                      W1AY Cord</li> <li>• Test Pick                                      411C Tool</li> <li>• Cord Tip                                        141 Cord Tip</li> <li>• Voltage Pickup Tool                        720A Tool</li> </ul>	
2	Check Battery Bus Voltage and 48V Rectifier Output Current	DLP-504
3	Calibrate 151A Power Plant Voltmeter	DLP-505
4	Prepare Fuse Alarm Test Cord	DLP-513
5	Check 151A Power Plant Fuse Alarms	DLP-506
6	Check 48V Rectifier Failure Alarms	DLP-507
7	Check 151A Power Plant High Voltage (HVM) Shutdown Circuit	DLP-508
8	Check 151A Power Plant Low Voltage (LV1 and LV2) Monitors	DLP-509
9	Check Battery Bus Voltage and 48V Rectifier Output Current	DLP-504

ITEM	SUBTASKS	PROCEDURE NUMBER
	NOTE 1: Refer trouble to installation group whenever indications in this procedure are not obtained	
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Digital Multimeter      KS-20599, L4</li> <li>• Jewelers Screwdriver    R1005</li> <li>• Test Cord                    W1AY Cord</li> <li>• Test Pick                    411C Tool</li> <li>• Cord Tip                     141 Cord Tip</li> <li>• Voltage Pickup Tool      720A Tool</li> </ul>	-
2	Prepare Fuse Alarm Test Cord	DLP-513
3	Check 188A Power Unit (+24V Converter) Power Alarm	DLP-691
4	Check 188A Power Unit (+24V Converter) No Power Alarm	DLP-693
5	Check/Adjust 188A Power Unit (+24 Converter) DC Output Voltage	DLP-687
6	Repeat Items 3, 4, and 5 for Each Additional Individual 188A Power Unit	-
7	Check 184A Power Unit (+48V Converter) Output	DLP-695
8	Repeat Item 7 for Each Additional Individual 184A Power Unit	-
9	Remove Side 0 of Ringing and Tone Plant From Service	DLP-550
10	Check 184A Power Unit (+48V Converter) Fuse Alarms (Side 0)	DLP-696
11	Restore Side 0 of Ringing and Tone Plant to Service	DLP-557
12	Remove Side 1 of Ringing and Tone Plant From Service	DLP-540
13	Check 184A Power Unit (+48V Converter) Fuse Alarms (Side 1)	DLP-696
14	Restore Side 1 of Ringing and Tone Plant to Service	DLP-547
15	Check 184B Power Unit ( $\pm$ 130V Converter) Output	DLP-698
16	Check 184B Power Unit ( $\pm$ 130V Converter) Fuse Alarms	DLP-699
17	Repeat Items 15 and 16 for Each Additional Individual 184B Power Unit	-
<b>ACCEPT MISCELLANEOUS POWER UNITS</b>		Issue 2    JUL 1980
		233-144-100    ATP
		PAGE 1 of 1 <b>032</b>

ITEM	SUBTASKS	PROCEDURE NUMBER						
	NOTE 1: Refer trouble to installation group whenever indications in this procedure are not obtained							
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Frequency Counter                      General Radio Model 1159</li> <li>• Digital Multimeter                      Hickok Model 3310</li> <li>• Test Cord                                      W1AY Cord</li> <li>• Test Pick                                      411C Tool</li> <li>• Cord Tip                                      141 Cord Tip</li> <li>• Voltage Pickup Tool                      720A Tool</li> </ul>	-						
2	Prepare Fuse Alarm Test Cord	DLP-513						
3	Isolate DMM From Ground	DLP-720						
4	Remove Side 0 From Service	DLP-550						
5	Measure -48 and +48 Volt Input Voltages - Side 0	DLP-551						
6	Check Tone Oscillators (350, 440, 480, and 620) - Side 0	DLP-552						
7	Check Tone Amplifiers (TT, AR, BT, MT, and HT) - Side 0	DLP-553						
8	Test Low Voltage Monitors (TTLV0, ARLV0, BTLV0, MTLV0, and HTLV0) - Side 0	DLP-554						
9	Check 20-Hz Inverter - Side 0	DLP-555						
10	Test 48-Volt Distribution Fuse Alarms Side 0	DLP-556						
11	Turn Up and Restore to Service Side 0	DLP-557						
12	Remove Side 1 from Service	DLP-540						
13	Measure -48 and +48 Volt Input Voltages - Side 1	DLP-541						
14	Check Tone Oscillators (350, 440, 480, and 620) - Side 1	DLP-542						
15	Check Tone Amplifiers (TT, AR, BT, MT, and HT) - Side 1	DLP-543						
16	Test Low Voltage Monitors (TTLV1, ARLV1, BTLV1, MTLV1, and HTLV1) - Side 1	DLP-544						
17	Check 20-Hz Inverter - Side 1	DLP-545						
<b>ACCEPT 881A RINGING AND TONE PLANT</b>		<table border="1" style="width: 100%;"> <tr> <td style="width: 50%;"><b>Issue 2</b></td> <td style="width: 50%;"><b>JUL 1980</b></td> </tr> <tr> <td><b>233-144-100</b></td> <td><b>ATP</b></td> </tr> <tr> <td><b>PAGE 1 of 2</b></td> <td><b>033</b></td> </tr> </table>	<b>Issue 2</b>	<b>JUL 1980</b>	<b>233-144-100</b>	<b>ATP</b>	<b>PAGE 1 of 2</b>	<b>033</b>
<b>Issue 2</b>	<b>JUL 1980</b>							
<b>233-144-100</b>	<b>ATP</b>							
<b>PAGE 1 of 2</b>	<b>033</b>							

ITEM	SUBTASKS	PROCEDURE NUMBER
18	Test 48-Volt Distribution Fuse Alarms - Side 1	DLP-546
19	Turn Up and Restore to Service Side 1	DLP-547
20	Check and Adjust 400A Tone Generator	DLP-560
21	Test Ringing Distribution Fuse Alarms	DLP-561

ITEM	SUBTASKS	PROCEDURE NUMBER	
	NOTE 1: Refer trouble to installation group whenever indications in this procedure are not obtained		
	NOTE 2: There is a normal time delay of 30-50 seconds when operating the INVERTER TEST switch		
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Volt-Ohm-Milliammeter           KS-20538</li> <li>• Frequency Counter                 779C Hewlett Packard</li> </ul>	-	
2	Remove From Service and Turn Down KS-20816 L2 Inverter	DLP-617	
3	Loosen Fastener Screws on Upper Front of Cover; Pull Cover Forward and Down	-	
4	Visually Inspect Inverter for Proper Mounting in Frame	-	
5	Visually Check Inverter for Loose Wires or Connections	-	
6	Restore KS-20816 L2 Inverter to Service	DLP-611	
7	Check DC Input Voltage	DLP-612	
8	Check AC Input Voltage	DLP-616	
9	Calibrate Panel Voltmeter	DLP-614	
10	Check AC Output Voltage	DLP-613	
11	Check AC Output Frequency	DLP-615	
12	Close Cover; Tighten Fastener Screws	-	
13	Check Inverter Transfer and Alarm Circuits	DLP-610	
<b>ACCEPT KS-20816 L2 INVERTER</b>		Issue 2	JUL 1980
		233-144-100	ATP
		PAGE 1 of 1	<b>034</b>

ITEM	SUBTASKS	PROCEDURE NUMBER						
	NOTE 1: Refer trouble to installation group whenever indications in this procedure are not obtained							
1	Obtain Support Apparatus or Equivalent <ul style="list-style-type: none"> <li>• Digital Multimeter                      KS-20599, L4</li> <li>• Syringe-Type Hydrometer              KS-5499, L1305</li> <li>• Thermometer                              KS-5499, L1352 or L1353</li> <li>• Goggles                                      R-4501</li> <li>• Rubber Acid Gloves                      R-3034</li> <li>• Rubber Apron                              R-3043</li> </ul>	-						
	<i>DANGER: Protective equipment such as rubber gloves, rubber aprons, and splash-proof goggles should be worn when performing maintenance on batteries. Rings, wrist watches, metal bracelets, necklaces, belt buckles, etc, should be removed</i>							
2	Measure Individual Cell Voltage (2.13 to 2.22 Volts)	DLP-576						
3	Maintain Electrolyte Level	DLP-579						
4	Check Electrolyte Temperature	DLP-578						
5	Inspect Individual Cells for Crystals	DLP-575						
<b>ACCEPT KS-20472 BATTERY</b>		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">Issue 2</td> <td style="text-align: center;">JUL 1980</td> </tr> <tr> <td style="text-align: center;">233-144-100</td> <td style="text-align: center;">ATP</td> </tr> <tr> <td style="text-align: center;">PAGE 1 of 1</td> <td style="text-align: center;"><b>035</b></td> </tr> </table>	Issue 2	JUL 1980	233-144-100	ATP	PAGE 1 of 1	<b>035</b>
Issue 2	JUL 1980							
233-144-100	ATP							
PAGE 1 of 1	<b>035</b>							

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Place ITT-North KS-20493 48V Rectifier in Test Mode	DLP-710
2	Check ITT-North KS-20493 48V Rectifier Output Voltage	DLP-711
3	Check ITT-North KS-20493 48V Rectifier Current Limiting Adjustment	DLP-712
4	Check ITT-North KS-20493 48V Rectifier TR Shutdown	DLP-714
5	Check ITT-North KS-20493 48V Rectifier HV Shutdown	DLP-715
6	Check ITT-North KS-20493 48V Rectifier Automatic Restart	DLP-716
7	Power Up Individual North KS-20493 48V Rectifier	DLP-717
<p style="text-align: center;"><b>ACCEPT ITT-NORTH KS-20493 48V RECTIFIER</b></p>		Issue 2
		JUL 1980
		233-144-100
		ATP
		PAGE 1 of 1 <b>036</b>


ITEM	SUBTASKS	PROCEDURE NUMBER
1	Power Down Individual Lorain 48V Rectifier	DLP-500
2	Check Lorain 48V Rectifier Output Voltage	DLP-501
3	Test Lorain 48V Rectifier Current Limit Circuit	DLP-502
4	Power Up Individual Lorain 48V Rectifier	DLP-503
<b>ACCEPT LORAIN KS-20493 48V RECTIFIER</b>		Issue 2
		233-144-100
		PAGE 1 of 1
		JUL 1980
		ATP
		<b>037</b>

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Power Down Individual J87437A 48V Rectifier	DLP-701
2	Check J87437A 48V Rectifier Output Voltage	DLP-702
3	Power Up Rectifier	DLP-704
4	Check Adjustment of J87437A 48V Rectifier Current Limit and Regulator Circuit	DLP-703
<b>ACCEPT J87437A 48V RECTIFIER</b>		Issue 2
		233-144-100
		PAGE 1 of 1
		JUL 1980
		ATP
		038

**COMPANY ORDER TASKS**

**PROCEDURE  
NUMBER**

None Required



**CLEAR STORAGE BATTERY TROUBLE**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	134

[1] At TST frame on rear of **INVERTER**, move TTY and any other protected equipment power cords to a service receptacle

[2] Condition DMM to measure 60 Vdc

[3] See **DANGER 1** and FIG. 1. Connect DMM across dc input terminals 1 and 2






FIG. 1

<b>DANGER 1</b>	
<i>Voltages inside INVERTER cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 3	180


- [6] See FIG. 2. Set protected equipment circuit breakers to OFF
- [7] Set INVERTER ON-OFF switch to OFF
- [8] At commercial AC input power panel, set ESS INVERTER circuit breaker to OFF
- [9] See DANGER 2. Remove fuse F1 and check for continuity with DMM. Replace if necessary



- [10] At commercial AC input power panel, set ESS INVERTER circuit breaker to ON
- [11] Set INVERTER ON-OFF switch to ON
- [12] Depress and hold TEST switch



Page 3




PROTECTIVE EQUIPMENT CIRCUIT BREAKERS

FIG. 2

**DANGER 2**  
*Voltages inside INVERTER cabinet are over 400 volts to ground*


Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 3	180

**CLEAR TROUBLE IN INVERTER AC OUTPUT**




**CLEAR TROUBLE IN INVERTER AC OUTPUT**

<b>DANGER 3</b>	
<i>Voltages inside INVERTER cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 3 of 3	180



**CLEAR INOPERATIVE INVERTER RUN LAMP**

<b>DANGER 1</b>	
<i>Voltages inside INVERTER cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	181



<b>DANGER 1</b>	
<i>Voltages inside INVERTER cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 3	182

**CLEAR TROUBLE IN INVERTER TRANSFER ALARM CIRCUIT**





TABLE A	
TEST SWITCH RELEASED	
CONNECT VOM TO TB4 BETWEEN TERMINALS	VOM RESPONSE
1 and 2	0 Ohms
2 and 3	Open circuit
4 and 5	0 Ohms
5 and 6	Open circuit


TABLE B	
TEST SWITCH OPERATED	
CONNECT VOM TO TB4 BETWEEN TERMINALS	VOM RESPONSE
1 and 2	Open circuit
2 and 3	0 Ohms
4 and 5	Open circuit
5 and 6	0 Ohms

<b>DANGER 2</b> <i>Voltages inside INVERTER cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 3	182




**CLEAR TROUBLE IN INVERTER TRANSFER ALARM CIRCUIT**

<b><i>DANGER 3</i></b> <b><i>Voltages inside INVERTER cabinet are over 400 volts to ground</i></b>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 3 of 3	182



**CLEAR TROUBLE IN INVERTER -48 VOLT DC CIRCUIT**

<b><i>DANGER 1</i></b>	
<b><i>Voltages inside INVERTER cabinet are over 400 volts to ground</i></b>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 2	<b>183</b>



**CLEAR TROUBLE IN INVERTER -48 VOLT DC CIRCUIT**


<b><i>DANGER 2</i></b> <b><i>Voltages inside INVERTER cabinet are over 400 volts to ground</i></b>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	183

[1] See DANGER 1. Carefully inspect pins 1 and 2 for broken or loose input wire connection

[2] Obtain KS-20538 volt-ohm-milliammeter or equivalent

[3] Condition VOM to measure approximately 300 Vac

[4] Connect VOM between pin 1 of A2 and terminal 2 of TB2



## CLEAR TROUBLE IN INVERTER AC TIMER CIRCUIT PACK A2

<b>DANGER 1</b> <i>Voltages inside INVERTER cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 2	184

[7] Remove **KS-20816 L2 INVERTER**  
from service [DLP-617]

[8] On circuit pack remove  
mounting screws and  
lift out **A2**

[9] See **DANGER 2**.  
Label and unsolder wires  
attached to terminals 1 and  
2 on **A2**

[10] Solder wires removed in [9] to  
respective terminals

[11] Insert replacement circuit pack  
and install mounting screws

[12] Restore **KS-20816 L2 INVERTER** to  
service [DLP-611]

[13] Depress and hold **TEST** switch

[14] Release **TEST** switch and  
start timing

CP  
removed

AND

AND

[15] Does  
**INVERTER RUN**  
lamp extinguish  
within 30 to 50  
seconds

Yes

[17] At **SSP**  
depress **ALARM**  
**RELEASE**  
pushbutton

No

[16] Check  
wiring per  
SD-82178-01


**DANGER 2**

*Voltages inside  
INVERTER cabinet  
are over 400  
volts to ground*

Issue 2 JUL 1980

233-144-100 TAP

PAGE 2 of 2 184



**DANGER 1**  
*Voltages inside  
 INVERTER cabinet  
 are over 400  
 volts to ground*

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 3	185

**CLEAR TROUBLE IN INVERTER OUTPUT FAIL ALARM CIRCUIT**





TABLE A	
TEST SWITCH RELEASED	
CONNECT VOM TO TB5 BETWEEN TERMINALS	VOM RESPONSE
1 and 2	0 Ohms
2 and 3	Open circuit
4 and 5	0 Ohms
5 and 6	Open circuit
7 and GRD	Open circuit


TABLE B	
TEST SWITCH OPERATED	
CONNECT VOM TO TB5 BETWEEN TERMINALS	VOM RESPONSE
1 and 2	Open circuit
2 and 3	0 Ohms
4 and 5	Open circuit
5 and 6	0 Ohms
7 and GRD	0 Ohms

<b>DANGER 2</b> <i>Voltages inside INVERTER cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 3	185



**CLEAR TROUBLE IN INVERTER OUTPUT FAIL ALARM CIRCUIT**

<b><i>DANGER 3</i></b> <b><i>Voltages inside INVERTER cabinet are over 400 volts to ground</i></b>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 3 of 3	185



**CLEAR TROUBLE – SYSTEM CONTROL WILL NOT REMOVE SIDE OF  
PLANT FROM SERVICE**

NOTE 1	
Plant has two sides (0 and 1). Small letter "a" is variable for "0" or "1". Use "0" or "1" as appropriate for side under test	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	190





TABLE A		
ASSOCIATED FUSE	CIRCUIT PACK CODE	FREQUENCY
F4 (-48 volt)	A980 or A1151	350-0
	A981 or A1152	440-0
	A982 or A1153	480-0
	A983 or A1154	620-0
F12 (-48 volt)	A980 or A1151	350-0
	A981 or A1152	440-0
	A982 or A1153	480-0
	A983 or A1154	620-0

**NOTE 1**  
 Trouble clearing procedures require original circuit pack be reinstalled if replacement does not correct trouble


Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 2	191

**CLEAR TONE OSCILLATOR TROUBLE**



**NOTE 2**  
 Trouble clearing procedures require original circuit pack be reinstalled if replacement does not correct trouble


Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	191



Page 2

**tone generation**

Issue 2	JUL 1980
233-144-100	ISD
PAGE 1 of 2	192




[1] See WARNING 1 and CAUTION 1.  
Obtain equipment in TABLE A

[2] See NOTE 1. At MP frame on RINGING & TONE panel, depress OFF-0 (or OFF-1) pushbutton

PWR OFF lamp lighted

[3] See FIG. 1 and NOTE 2. Use 723B circuit pack puller to remove amplifier and low voltage monitor circuit packs for tone being checked

[4] Use 158A circuit pack adapters to extend amplifier circuit pack and low voltage monitor circuit group




**NOTES**  
 1. Information enclosed in parentheses refers to side 0 or to side 1  
 2. For example, remove TT-0 amplifier and TTLV-0 monitor for TT tone on side 0

**WARNING 1**  
*Erroneous reading and damage to equipment may result if DMM is not isolated from ground*

**CAUTION 1**  
*Tone voltages to be measured are complex ac waveforms. A True RMS indicating voltmeter is required to accurately adjust voltage levels. Peak and average ac voltmeters produce inaccurate readings*


TABLE A	
EQUIPMENT REQUIRED	RECOMMENDED TYPE
Digital multimeter (DMM)	Hickok Model 3310 (ITE-5356)*†
Circuit pack puller	723B tool†
Circuit pack extender	158A adapter†
Jewelers screwdriver	R1005 tool†
(2) Connecting clips	EZ hook†
* DMM must be true RMS	
† Or equivalent	

**CLEAR TROUBLE – TONE AMPLIFIER AND LOW VOLTAGE MONITOR CIRCUIT**



\* NUMBERS ARE LOCATION NUMBERS

FIG. 1 - Tone Amplifier and Low Voltage Monitor  
Circuit Pack Arrangement - Front View




**CLEAR TROUBLE-TONE AMPLIFIER AND LOW VOLTAGE MONITOR CIRCUIT**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 3 of 4	193

[16] Remove extended amplifier and low voltage monitor circuit packs from plant

[17] Disconnect 158A adapter and return amplifier and low voltage monitor circuit pack to plant

[18] On RINGING & TONE panel, depress NOR pushbutton



PWR OFF lamp goes out



[19] For tone being checked, does DMM indicate required voltage level in TABLE B

No

[22] Trouble is defective 905B connector. Clear trouble per SD-82255-01


Yes

[20] Disconnect DMM from connector

[21] On RINGING & TONE panel, depress OFF-0 (or OFF-1) pushbutton


TABLE B	
TONE	OUTPUT VOLTAGE LEVEL OF TONE - VOLTS RMS
TT	1.176 to 1.224
AR	0.353 to 0.367
BT	0.196 to 0.204
MT	0.442 to 0.518
HT	0.267 to 0.313

**CLEAR TROUBLE-TONE AMPLIFIER AND LOW VOLTAGE MONITOR CIRCUIT**



**CLEAR TROUBLE IN 20-HZ PULSE GENERATOR**

<b>DANGER 1</b> <i>Voltages inside INVERTER cabinet are over 200 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 6	194



INVERTER OUTPUT	DMM CONNECTION AT TERMINALS ON INVERTER TB2 TERMINAL BOARD	OUTPUT VOLTAGE REQUIREMENTS
86(A) 86(B)	8 and 9 4 and 5	84.5 to 88.0
97(A) 97(B)	8 and 10 4 and 6	94.5 to 101.0
105(A) 105(B) 105(C)	8 and 11 4 and 5 1 and 3	103.0 to 110.0

**CLEAR TROUBLE IN 20-HZ PULSE GENERATOR**

<b>DANGER 2</b>	
<i>Voltages inside INVERTER cabinet are over 200 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 6	194




TABLE B	
DMM CONNECTION ACROSS TRANSISTOR TERMINAL	DMM INDICATION REQUIREMENT
Emitter to collector	High resistance in forward and reverse direction
Emitter to base	High resistance in one direction and low resistance in opposite direction
Collector to base	




FIG. 1

<b>DANGER 3</b> Voltages inside INVERTER cabinet are over 200 volts to ground	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 3 of 6	194

[25] See DANGER 4 and FIG. 2. Disconnect one lead from CR2, CR3, CR4, and CR5

[26] Are forward and reverse resistance requirements met for CR2, CR3, CR4, and CR5 as given in TABLE C

Yes

[28] Reconnect leads at CR2, CR3, CR4, and CR5

TABLE C	
DMM CONNECTION ACROSS DIODE TERMINALS	DMM INDICATION REQUIREMENT
Anode to cathode	High resistance in one direction and low resistance in opposite direction
Cathode to anode	

No  
[27] Replace defective diode

[29] See NOTE 1. Replace PULSE GENERATOR circuit pack with new circuit pack and install in inverter

[30] Which 20-Hz PULSE GENERATOR is being checked

INV-1

[31] At 48-volt fuse panel, install F9, F10, and F35 fuses

INV-0

[32] At 48-volt fuse panel, install F1, F2, and F33 fuses

[33] On RINGING & TONE panel, depress NOR pushbutton

Page 5

NOTE 1  
Trouble clearing procedure requires original circuit pack be returned to unit if replacement does not correct trouble

**DANGER 4**  
Voltages inside INVERTER cabinet are over 200 volts to ground




FIG. 2

**CLEAR TROUBLE IN 20-HZ PULSE GENERATOR**

[34] See DANGER 5. Condition DMM to measure approximately 100 Vac

[35] Does DMM indicate voltage requirements for 86-, 92-, and 105-volt outputs as given in TABLE D

Yes

[37] Disconnect DMM

No

[36] Trouble is defective ferroresonant circuit. Replace PULSE GENERATOR [DLP-569]

[38] See FIG. 3. Condition frequency counter

TABLE D		
INVERTER OUTPUT	DMM CONNECTION AT TERMINALS ON INVERTER TB2 TERMINAL BOARD	OUTPUT VOLTAGE REQUIREMENTS
86(A) 86(B)	8 and 9 4 and 5	84.5 to 88.0
97(A) 97(B)	8 and 10 4 and 6	94.5 to 101.0
105(A) 105(B) 105(C)	8 and 11 4 and 5 1 and 3	103.0 to 110.0

[39] Does frequency counter indicate between 19.95 and 20.05 Hz when connected across INVERTER TB2 terminals 8 and 9

No

[40] Trouble is defective ferroresonant circuit. Replace PULSE GENERATOR [DLP-569]

Yes

[41] Disconnect frequency counter

Page 6





FIG. 3

**DANGER 5**  
*Voltages inside INVERTER cabinet are over 200 volts to ground*


Issue 2	JUL 1980
233-144-100	TAP
PAGE 5 of 6	194

**CLEAR TROUBLE IN 20-HZ PULSE GENERATOR**




**CLEAR TROUBLE IN 20-HZ PULSE GENERATOR**

<b>DANGER 6</b>	
<i>Voltages inside INVERTER cabinet are over 200 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 6 of 6	194




**CLEAR TROUBLE IN 48-VOLT FUSE ALARM CIRCUIT**

<b>DANGER 1</b>	
<i>48-volt potential is present on tip of test pick</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 2	195




## CLEAR TROUBLE IN 48-VOLT FUSE ALARM CIRCUIT

Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	195



**CLEAR TROUBLE- SYSTEM CONTROL WILL NOT RESTORE PLANT TO SERVICE**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	196



**CLEAR BLOWN FUSE**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	197

TABLE A		
TEXT PHRASE	MEANING	TROUBLE CLEARING PROCEDURE
0000	MANUAL OFF	TBS
0001	FUSE ALARM	TAP-197
0010	INV FAIL	TAP-194
0011	TTLV	TAP-199
0100	BTLV	TAP-199
0101	ARLV	TAP-199
0110	HTLV	TAP-199
0111	MTLV	TAP-199
1000	GROUND	TBS
1001	+48V CONV	TAP-230
1010	+48V CONV	TAP-230
1011	+48V CONV	TAP-230
1100	INT FAIL	TBS
1101	BUS TRANS TO NETWORK	TBS
1110	RT FAIL DIAGNOSTICS	TBS

TABLE B					
SIDE 0		SIDE 1		MEANING	TROUBLE CLEARING PROCEDURE
ROW	POINT	ROW	POINT		
22	03	16	11	MANUAL OFF	TBS
22	04	16	12	FUSE ALARM	TAP-197
22	05	16	13	INV FAIL	TAP-194
22	06	16	14	TTLV	TAP-199
22	07	16	15	BTLV	TAP-199
23	03	17	11	ARLV	TAP-199
23	04	17	12	HTLV	TAP-199
23	05	17	13	MTLV	TAP-199
23	06	17	14	GROUND	TBS
NONDUPLICATED					
ROW	POINT				
17	04			ROH FAIL	DLP-560
18	04			RING DISTRIBUTION FUSE ALARM	TAP-197

**ANALYZE TTY TROUBLE MESSAGE FOR RINGING AND TONE PLANT**





FIG. 1





FIG. 2

**NOTE 1**  
 Plant has two sides (0 and 1). Small letter "a" is variable for "0" or "1". Use "0" or "1" as appropriate for side under test

Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	198



**CLEAR TONE FAULT**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 5	199

[4] See DANGER 1 and WARNING 1. Isolate DMM from ground [DLP-720] and condition to measure approximately 1V rms






FIG. 1 - A1111 Connector - Rear View

TABLE A		
TONE LOW VOLTAGE ALARM	DMM CONNECTION AT A1111 CONNECTOR	VOLTAGE RANGE-VOLTS RMS
TTLV	14 and 25	1.02 to 1.38
BTLV	18 and 22	0.170 to 0.230

**WARNING 1**  
Erroneous reading and damage to equipment may result if DMM is not isolated from ground

**CAUTION 1**  
Tone voltages to be measured are complex ac waveforms. A True RMS indicating voltmeter is required to accurately adjust voltage levels. Peak and average ac voltmeters produce inaccurate readings

**DANGER 1**  
Voltage potentials of up to 400 volts to ground are present at rear of plant



**CLEAR TONE FAULT**

<b>DANGER 2</b>	
<i>Voltage potentials of up to 400 volts to ground are present at rear of plant</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 3 of 5	199

[22] See DANGER 3 and WARNING 2. Condition to measure approximately 1V rms

[23] See CAUTION 2. At rear of A1111 (0 or 1) circuit pack connector, connect DMM at terminals in TABLE B for low voltage alarm that is given

[24] Does DMM indicate voltage level in TABLE B

Yes

[25] Trouble is in low voltage monitor circuit. Clear trouble for voltage alarm that is given per TAP-193

No

[26] Disconnect DMM

Page 5

TABLE B		
TONE LOW VOLTAGE ALARM	DMM CONNECTION AT A1111 CONNECTOR	VOLTAGE RANGE-VOLTS RMS
MTLV	16 and 24	0.408 to 0.552
ARLV	2 and 10	0.306 to 0.414
HTLV	5 and 7	0.246 to 0.334

**WARNING 2**  
Erroneous reading and damage to equipment may result if DMM is not isolated from ground

**CAUTION 2**  
Tone voltages to be measured are complex ac waveforms. A True RMS indicating voltmeter is required to accurately adjust voltage levels. Peak and average ac voltmeters produce inaccurate readings

**DANGER 3**  
Voltage potentials of up to 400 volts to ground are present at rear of plant




TABLE C		
TONE LOW VOLTAGE ALARM	DMM CONNECTION AT A1111 CONNECTOR	VOLTAGE RANGE-VOLTS RMS
TTLV	13 and 26(GRD)	4.35 to 4.65
MTLV	15 and 20(GRD)	4.35 to 4.65
ARLV	1 and 12(GRD)	4.35 to 4.65
HTLV	4 and 9(GRD)	4.35 to 4.65
BTLV	17 and 21(GRD)	4.35 to 4.65


**WARNING 3**  
DMM(-) lead must be connected to terminal designated GRD as given in TABLE C

**DANGER 4**  
Voltage potentials of up to 400 volts to ground are present at rear of plant

Issue 2	JUL 1980
233-144-100	TAP
PAGE 5 of 5	199

**CLEAR TONE FAULT**





**LORAIN RECTIFIER CONTROL CIRCUIT**

Issue 1	JUL 1980
233-144-100	ISD
PAGE 1 of 1	200

- [1] Obtain test equipment in TABLE A
- [2] At 151A PWR PLANT, turn off 48V RECTIFIER by depressing POWER ON-POWER OFF pushbutton and remove rectifier front panel
- [3] Remove RB fuse associated with rectifier from plant
- [4] Set EXTERNAL-CHARGE circuit breaker associated with rectifier to OFF
- [5] See DANGER 1. Remove circuit pack front cover and CP4 circuit pack from rectifier
- [6] Connect CP4 to CP5 extender board
- [7] Observe arrows and UP stamping on CP5 extender, then install extender at CP4 connector


TABLE A	
EQUIPMENT REQUIRED	RECOMMENDED TYPE
Extender board (CP5)	KS-20618, L10
Digital multimeter (DMM)	KS-20599, L4*
Oscilloscope	Tektronix 545B*
Voltage probe	Tektronix P6006*
* Or equivalent	

[8] Condition DMM to measure approximately 100 Vdc

On rectifier:

[9] Connect DMM across OUTPUT VOLTS (+) and (-) test jacks

[10] See WARNING 1. Turn on rectifier by depressing POWER ON-POWER OFF pushbutton, record indication on DMM then turn OFF rectifier by depressing pushbutton



Rectifier output voltage measured



Page 2


**WARNING 1**  
Rectifier circuit could be damaged if output voltage is abnormally high for extended period of time

---

**DANGER 1**  
Voltages inside rectifier cabinet are over 400 volts to ground

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 9	201

**CLEAR DEFECTIVE LORAIN 48V RECTIFIER CIRCUIT PACK**



**WARNING 2**  
*Rectifier circuit could be damaged if output voltage is abnormally high for extended period of time*

**DANGER 2**  
*Voltages inside rectifier cabinet are over 400 volts to ground*

Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 9	201

**CLEAR DEFECTIVE LORAIN 48V RECTIFIER CIRCUIT PACK**

TABLE B	
DMM CONNECTED FROM TP12 (GRD) ON EXTENDER TO FOLLOWING TEST POINTS (FIG. 1)	DMM INDICATION IF CP4 IS GOOD
(A) TP28 on extender	+13.5 to 16.5 Vdc
(B) TP11 on CP4	-5.0 to 9.0 Vdc
(C) TP8 on CP4	+13.5 to 16.5 Vdc

TABLE D	
DMM CONNECTED FROM TP12 (GRD) ON EXTENDER TO FOLLOWING TEST POINTS (FIG. 1)	DMM INDICATION IF CP4 IS GOOD
(A) TP34 on extender	-13.5 to 16.5 Vdc
(B) TP11 on CP4	-5.0 to 9.0 Vdc
(C) TP8 on CP4	+13.5 to 16.5 Vdc

TABLE C	
DMM CONNECTED FROM TP12 (GRD) ON EXTENDER TO FOLLOWING TEST POINTS (FIG. 1)	DMM INDICATION IF CP4 IS GOOD
(A) (Use DMM ACV scale) TP20 on extender	18 to Vac
(B) (Use DMM ACV scale) TP19 on extender	18 to 22 Vac
(C) TP5 on extender	+22 to 28 Vdc
(D) TP14 on extender	-22 to 28 Vdc
(E) TP3 on extender	+13.5 to 16.5 Vdc
(F) TP16 on extender	-13.5 to 16.5 Vdc
(G) TP28 on extender	+13.5 to 16.5 Vdc
(H) TP34 on extender	-13.5 to 16.5 Vdc
(I) TP11 on CP4	-5.0 to 9.0 Vdc
(J) TP8 on CP4	+13.5 to 16.5 Vdc
(K) TP6 on CP4	-22 to 28 Vdc





FIG. 1






<b>WARNING 3</b> <i>Rectifier circuit could be damaged if output voltage is abnormally high for extended period of time</i>	
<b>DANGER 3</b> <i>Voltages inside rectifier cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 4 of 9	<b>201</b>

**CLEAR DEFECTIVE LORAIN 48V RECTIFIER CIRCUIT PACK**

[25] See DANGER 4, WARNING 4, and FIG. 2.  
Connect voltage probe at test point TP1 as given in TABLE E

[26] Observe waveform on oscilloscope



VOLTAGE PROBE CONNECTION	WAVEFORM FIG. 3 IF CP1 IS GOOD	VOLTS/CM	VOLTS
TP1 TP2	(A)	5	4 to 6
TP4 TP5	(B)	50	20 to 28
TP12 TP13	(C)	50	13.5 to 16.5
TP7	(D)	50	24 to 30

**WARNING 4**  
Use properly grounded oscilloscope. Connect only voltage probe to test points. Do not connect ground lead of oscilloscope to rectifier

**DANGER 4**  
Voltages inside rectifier cabinet are over 400 volts to ground

Issue 2	JUL 1980
233-144-100	TAP
PAGE 5 of 9	201

[31] Depress **POWER ON-POWER OFF** pushbutton to turn off rectifier

[32] Disconnect voltage probe

[33] Disconnect **CP5** extender from rectifier and **CP1**

[34] Install **CP1** firmly in **CP1** connector

[35] Remove **CP2** circuit pack from rectifier

[36] Connect **CP2** to **CP5** extender, then install extender at **CP2** connector

CP2 extended

Page 7




FIG. 4

TABLE F

DMM CONNECTED FROM TP13 (GRD) ON CP2 TO FOLLOWING TEST POINTS [FIG. 4]	DMM INDICATION IF CP2 IS GOOD
TP1	-0.01 to 0.05 Vdc
TP2	+13.5 to 16.5 Vdc
TP3	-1.6 to 2.0 Vdc
TP4	-9.0 to 11.0 Vdc
TP5	-10.0 to 14.0 Vdc
TP6	-0.1 to 1.5 Vdc
TP7	0.0 to 1.0 Vdc
TP10	-10.0 to 14.0 Vdc
TP11	-13.5 to 16.5 Vdc
TP29 on extender	+22.0 to 28.0 Vdc
TP14	+8.5 to 9.5 Vdc

**CLEAR DEFECTIVE LORAIN 48V RECTIFIER CIRCUIT PACK**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 6 of 9	201

[37] See DANGER 5 and WARNING 5.  
Depress **POWER ON-POWER OFF**  
pushbutton to turn on  
rectifier

[38] See FIG. 4. Condition DMM  
to check dc voltages  
on CP2 per TABLE F

[41] Depress **POWER ON-POWER OFF**  
pushbutton to turn off  
rectifier


[42] Disconnect DMM

[43] Disconnect CP5 extender  
from rectifier and CP2

[44] Install CP2 firmly in  
CP2 connector

[45] At commercial AC input power  
panel, place circuit breaker  
associated with rectifier to OFF

[46] At rectifier, remove CP3 circuit pack



<b>WARNING 5</b> <i>Rectifier circuit could be damaged if output voltage is abnormally high for extended period of time</i>	
<b>DANGER 5</b> <i>Voltages inside rectifier cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 7 of 9	201

[47] On CP3 [FIG. 5], verify connection of jumper wire between pins B1 to C1, and pins B2 to C2

[48] Connect CP3 to CP5 extender

[49] Place CP3 with extender on suitable insulated test surface

[50] Condition DMM to  $K\Omega \times 1$  range

[51] Condition DMM to check continuity on CP3 per TABLE G





FIG. 5


TABLE G			
OHMMETER CONNECTION AT FOLLOWING TEST POINTS ON EXTENDER	DMM INDICATION		
	RELAY	RELAY RELEASED	RELAY MANUALLY OPERATED *
TP10 to TP4	ST1	Short	Open
TP10 to TP14		Short	Open
TP10 to TP11		Open	Short
TP12 to TP3		Short	Open
TP17 to (+) terminal of CR2 on CR3 [FIG. 5]	RF	Open	Short
TP3 to TP12 **		Open	Short
TP10 to TP14 **		Open	Short
TP18 to (+) terminal of CR2 on CP3 [FIG. 5]	HV	Open	Short
TP10 to TP26	SNS	Short	Open
TP24 to TP25		Short	Open
TP30 to TP31		Short	Open
TP32 to TP29		Short	Open
TP26 to TP28		Open	Short
TP25 to TP27		Open	Short
TP34 to TP35	LO	Open	Short

\* Relay is manually operated by pressing downward on relay armature  
 \*\*Both ST1 and TR relays must be manually operated for this test



<b>WARNING 6</b>	
<i>Rectifier circuit could be damaged if output voltage is abnormally high for extended period of time</i>	
<b>DANGER 6</b>	
<i>Voltages inside rectifier cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 9 of 9	201


**CLEAR DEFECTIVE LORAIN 48V RECTIFIER CIRCUIT PACK**



**DANGER 1**  
*Voltages inside rectifier cabinet are over 400 volts to ground*


Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	<b>202</b>

**CLEAR TROUBLE IN 48V RECTIFIER CURRENT LIMIT CIRCUIT**




<b>NOTE 1</b>	
Major alarms should not turn on when only S1 switch is operated	
<b>DANGER 1</b> Voltages inside cabinet are over 50 volts to ground	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	<b>203</b>

**CLEAR TROUBLE IN HV MONITOR – SHUTDOWN LEVEL LOW**




**CLEAR TROUBLE IN HV MONITOR – SHUTDOWN LEVEL HIGH**

<b>DANGER 1</b> Voltages inside cabinet are over 50 volts to ground	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 2	204




**CLEAR TROUBLE IN HV MONITOR – SHUTDOWN LEVEL HIGH**

<b>DANGER 2</b>	
<i>Voltages inside cabinet are over 50 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	<b>204</b>




<b>DANGER 1</b> <i>Voltages inside cabinet are over 50 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	205

**CLEAR TROUBLE IN LOW VOLTAGE (LV1 AND LV2) MONITORS**




<b>DANGER 1</b> <i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 2	209

**CLEAR TROUBLE IN 48V RECTIFIER OUTPUT CAPACITOR CHARGE CIRCUIT**




**CLEAR TROUBLE IN 48V RECTIFIER OUTPUT CAPACITOR CHARGE CIRCUIT**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	209



**CLEAR TROUBLE IN LORAIN OR ITT-NORTH KS-20493 48V  
RECTIFIER MINOR ALARM CIRCUIT**

<b>DANGER 1</b> <i>Extremely high current potential present in this circuit</i>		
Issue 2	JUL 1980	
233-144-100	TAP	
PAGE 1 of 2	210	



**CLEAR TROUBLE IN LORAIN OR ITT-NORTH KS-20493 48V  
RECTIFIER FAIL MINOR ALARM CIRCUIT**

<b>DANGER 2</b> <i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	210

[1] See DANGER 1. At 151A PWR PLANT, on 48V RECTIFIER depress POWER ON-POWER OFF pushbutton to turn off rectifier. Loosen 4 corner screws and remove front panel from rectifier

[2] See FIG. 1 and FIG. 2. Disconnect J1 connector from P2 plug

[3] Condition DMM to measure approximately 100 Vdc

[4] Connect DMM (+) lead to VM CAL (+) test jack on CONTROL UNIT

[5] On J1 connector [FIG. 1], connect DMM (-) lead to terminal 14

[6] Reconnect 720A tool at CAP fuse position then touch 411C test pick to CFA resistor associated with rectifier circuit breaker




FIG. 1 - Lorain Rectifier Only

<b>DANGER 1</b> <i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 2	215

**CLEAR TROUBLE IN LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER FAILURE (RF) CIRCUIT**





FIG. 2 - P1 Pin Location - North Rectifier Only

**CLEAR TROUBLE IN LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER FAILURE (RF) CIRCUIT**

<b>DANGER 2</b> <i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	215

**SUMMARY**

Reset high voltage shutdown circuit or replace power unit






FIG. 1 - Top of Miscellaneous Power Frame

**CLEAR POWER UNIT NO-OUTPUT CONDITION**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 2	230




**CLEAR POWER UNIT NO-OUTPUT CONDITION**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	230

[1] Condition KS-20538 VOM to measure approximately 10 megohms

[2] Remove A2 circuit pack and disconnect one end of capacitors C1 and C2

[3] Connect VOM across C1



# CLEAR TROUBLE IN INVERTER INPUT CAPACITOR CIRCUIT PACK A2

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 4	231

[9] Reconnect C1 and C2 and  
reinstall A2

[10] Disconnect VOM

[11] Restore KS-20816 L2 INVERTER to  
service [DLP-611]

AND

Page 3

**CLEAR TROUBLE IN INVERTER INPUT CAPACITOR CIRCUIT PACK A2**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 4	231





FIG. 1




TABLE A POWER ALARMS	
LOCATION	INDICATION
1. SSP	Major (red) Major power (red) Alarm release (red)
2. TTY	** REPT MISCA 25 12 OFN
3. BUILDING	Major audible
4. INVERTER	Inverter run (amber)

**SUMMARY**

Replace POWER UNIT, check connector and wiring per SD-3H905-01.





FIG. 1 - Top of Miscellaneous Power Frame

[1] Condition DMM to measure approximately 100 Vdc

[2] Connect DMM across pins 1 and 2 of A1. See FIG. 1



[3] Does DMM indicate between +14 and +16 Vdc

Yes

No

[4] Disconnect DMM

[5] Check components of INVERTER providing power to A1 [TAP-234]

[6] Disconnect DMM

[7] Condition DMM to measure approximately 10 Vac

[8] Connect DMM across pins 3 and 5 of A1

[9] Depress and hold TEST switch



Page 2





FIG. 1

### CHECK THYRISTOR DRIVER CIRCUIT PACK A1

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 2	233






**CHECK THYRISTOR DRIVER CIRCUIT PACK A1**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	233

[1] Condition KS-20538 VOM to measure approximately 90 ohms

[2] Connect VOM across R1. See FIG. 1



[6] Reconnect VOM across pins 1 and 2 of A1

[7] Condition VOM to measure approximately 10 megohms












FIG. 1

CHECK COMPONENTS OF INVERTER PROVIDING POWER TO A1

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	234

[1] Disconnect thyristors  
CR1 and CR2

[2] Condition KS-20538  
VOM to the 1000-ohm  
scale

[3] Connect VOM from  
anode to cathode of  
CR1. See FIG. 1







FIG. 1






**CLEAR TROUBLE IN INVERTER THYRISTOR CIRCUIT PACK A1**


Issue 2	JUL 1980
233-144-100	TAP
PAGE 2 of 2	236






**CLEAR ITT-NORTH KS-20493 48V RECTIFIER TR SHUTDOWN TROUBLE**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	238




CLEAR ITT-NORTH KS-20493 48V RECTIFIER HV SHUTDOWN TROUBLE

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	239



**CLEAR ITT-NORTH KS-20493 48V RECTIFIER AUTOMATIC RESTART TROUBLE**

Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	240





<b>DANGER 1</b>	
<i>Voltages inside rectifier cabinet are over 400 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	TAP
PAGE 1 of 1	241

**CLEAR TROUBLE IN ITT-NORTH KS-20493 48V RECTIFIER CURRENT LIMIT CIRCUIT**

**SUMMARY**


See WARNING 1. Depress **POWER ON-POWER OFF** pushbutton to turn off rectifier. Remove RB fuse, and set circuit breaker on **EXTERNAL CHARGE CIRCUIT BREAKER/RECT** panel to **OFF**



**FIG. 1**

**WARNING 1**  
*Rectifier circuit could be damaged when rectifier is turned on if RB fuse is installed and EXTERNAL CHARGE circuit breaker is set to OFF. When RB fuse is removed, rectifier may be turned on to operate in test mode*

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	500



**SUMMARY**

See NOTE 1. DMM connected across **OUTPUT VOLTS** test jacks indicates desired output level. Rotate **OUTPUT VOLTS ADJUST** rheostat until DMM indicates desired output level

[1] Condition DMM to measure approximately 100 Vdc

[2] At 151A PWR PLANT on 48V RECTIFIER [FIG. 1], Connect DMM across **OUTPUT VOLTS (+)** and **(-)** test jacks

[3] Depress **POWER ON-POWER OFF** pushbutton to turn on rectifier

POWER ON lamp lights. POWER OFF and RECT FAIL lamps go out

DMM connected across output

[4] See NOTE 1. Does DMM indicate required charge bus voltage

Yes

[5] Verify locking device is secure on **OUTPUT VOLTS ADJUST** rheostat

No

Page 2

[6] Disconnect DMM





FIG. 1

**NOTE 1**  
Charge voltage is determined by local requirements. Refer to office records for exact setting. In absence of local requirements, charge voltage is at a level that produces 52.08 Vdc measured at battery bus

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	501

**CHECK LORAIN KS-20493 48V RECTIFIER OUTPUT VOLTAGE**



**CHECK LORAIN KS-20493 48V RECTIFIER OUTPUT VOLTAGE**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	501

**SUMMARY**

See NOTE 1. Connect DMM at **CURRENT LIMIT** test jacks. DMM should indicate approximately -12 to -15 Vdc. Depress and hold **SIMULATED OUTPUT CURRENT** pushbutton. Rotate **SIMULATED OUTPUT CURRENT** rheostat slowly cw until DMM

indicates -1.25 to -1.50 volts. **OUTPUT CURRENT** ammeter should indicate 100 amperes. Release **SIMULATED OUTPUT CURRENT** pushbutton and rotate **SIMULATED OUTPUT CURRENT** rheostat fully ccw.

[1] Condition DMM to measure approximately 100 Vdc

[2] At 151A PLANT on 48V RECTIFIER [FIG. 1], connect DMM at **CURRENT LIMIT** (+) and (-) test jacks

DMM indicates approximately -12 to -15 Vdc

[3] Verify **SIMULATED OUTPUT CURRENT** rheostat is rotated fully ccw

[4] Depress and hold **SIMULATED OUTPUT CURRENT** pushbutton

**SIMULATED OUTPUT CURRENT** lamp lights

[5] See NOTE 1. Rotate **SIMULATED OUTPUT CURRENT** rheostat slowly cw until indication on DMM decreases to -1.25 to -1.50 volts






FIG. 1

**NOTE 1**

Voltage changes from approximately -15 volts at no load toward approximately -1.5 volts at current limit. Further increase in simulated load would result in voltage change through 0 volts toward a (+) level

**TEST LORAIN KS-20493 48V RECTIFIER CURRENT LIMIT CIRCUIT**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	502



**SUMMARY**

See WARNING 1. Turn off rectifier. Install RB fuse. Charge rectifier output filter capacitors and set circuit breaker to ON. Turn on rectifier

At 151A PWR PLANT:

[1] On 48V RECTIFIER, depress  
**POWER ON-POWER OFF**  
pushbutton to turn off  
rectifier

[2] At CONTROL UNIT,  
install RB fuse associated  
with rectifier


LOCAL SNS  
lamp off

[3] Charge rectifier output filter  
capacitors [DLP-517]

[4] See WARNING 1. On **EXTERNAL CHARGE CIRCUIT**  
**BREAKER/RECT** panel set to **ON** circuit breaker  
associated with rectifier

[5] Depress **POWER ON-POWER OFF**  
pushbutton to turn on  
rectifier

TTY message  
REPT PWR B 16 a 000000 NORM  
given



**WARNING 1**  
*Circuit breaker  
damage may occur  
if capacitors  
are not charged  
before operating  
circuit breaker  
to ON*

Issue 2 | JUL 1980

233-144-100 | DLP

PAGE 1 of 1 | 503

**SUMMARY**

See NOTES 1 and 2. In **BATTERY** and **DISCHARGE** position. **DMM** should indicate 52.08 volts dc at **VM CAL** test jacks. Ammeter on each rectifier should indicate some load current.

[1] Condition **DMM** to measure approximately 100 Vdc

[2] At 151A **PWR PLANT CONTROL UNIT** [FIG. 1], connect **DMM** across **VM CAL (+)** and **(-)** test jacks

[3] Set plant voltmeter selector switch to **BATTERY**

**DMM** connected

[4] See NOTE 1. Does **OUTPUT CURRENT** ammeter on each rectifier indicate some load current

Yes

Page 2

No

[5] Adjust battery bus voltage and rectifier output current [DLP-530]





FIG. 1

**CHECK BATTERY BUS VOLTAGE AND 48V RECTIFIER OUTPUT CURRENT**

<b>NOTE 1</b>	
Rectifiers are not required to share plant load equally	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	<b>504</b>



**NOTE 2**  
 Charge voltage is determined by local requirements. Refer to office records for exact setting. In absence of local requirements, charge voltage is at a level that produces 52.08 Vdc measured at battery bus

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	504

**CHECK BATTERY BUS VOLTAGE AND 48V RECTIFIER OUTPUT CURRENT**

**SUMMARY**


Calibrate plant voltmeter to match indication on DMM.

[1] Condition DMM to measure approximately 100 Vdc


[2] At 151A PWR PLANT CONTROL UNIT [FIG. 1], connect DMM across VM CAL (+) and (-) test jacks



DMM connected



Yes



No







FIG. 1

**CALIBRATE 151A POWER PLANT VOLTMETER**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	505

**SUMMARY**

See NOTE 1. Use test cord to connect -48 volt battery to test point on alarm fuse cap. Fuse alarms are given



<b>NOTE 1</b>	
TTY message REPT PWR B18 1 OFN is given for all fuses except DISCHARGE fuse. For DISCHARGE fuse, TTY message REPT PWR B26 8 00000 OFN is given	
<b>Issue 2</b>	<b>JUL 1980</b>
<b>233-144-100</b>	<b>DLP</b>
<b>PAGE 1 of 3</b>	<b>506</b>

**CHECK 151A POWER PLANT FUSE ALARMS**

TABLE A			
FUSE ALARMS			
FUSE	FUSE ALARM RELAY OPERATES	PLANT ALARM LAMP LIGHTS	SYSTEM STATUS PANEL LAMPS LIGHT
RB1, RB2, RB3, RB4, RB5	FAN	RECT FAIL	MINOR *FUSE
TEST INV (-48) (discharge)	FAJ	DISCHG FUSE	MAJOR *FUSE
C1, C2 (filter fuse)	FAN	RECT FAIL	MINOR *FUSE
CBS, R	FAN	RECT FAIL	MINOR *FUSE
HVM	FAN	RECT FAIL	MINOR *FUSE
VM	FAN	RECT FAIL	MINOR *FUSE
VM2	FAN	RECT FAIL	MINOR *FUSE
LVB1	FAN	RECT FAIL	MINOR *FUSE
LVB2	FAN	RECT FAIL	MINOR *FUSE

\* FUSE lamp on System Status Panel extinguishes when test pick is removed from fuse cap




FIG. 1 - Alarm Fuse Cap - Typical





FIG. 2 - Fuse Location



**CHECK 151A POWER PLANT FUSE ALARMS**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 3 of 3	506

[1] At 151A PWR PLANT on EXTERNAL CHARGE CIRCUIT BREAKER/RECT panel, remove screws from circuit breaker cover

[2] Remove circuit breaker cover

[3] See FIG. 1. Remove CAP fuse from fuse block

[4] Using fuse alarm test cord, install 720A tool at CAP fuse position

[5] See DANGER 1. At one CFA resistor [FIG. 1], use 411C test pick to touch rear terminal of CFA resistor

AND

Page 2




FIG. 1


**CHECK LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER FAILURE ALARMS**

**DANGER 1**  
*Extremely high current present in this circuit.*

Issue 2 JUL 1980

233-144-100 DLP


PAGE 1 of 3 507



**CHECK LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER FAILURE ALARMS**

NOTE 1 TTY message **REP PWR B 16 a 000000 OFN and *REP PWR B 18 1 000000 is given	
<b>DANGER 2</b> <i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 3	507

- [10] See DANGER 3.  
Remove 411C test  
pick from  
CFA resistor
- [11] On rectifier  
that shut down, depress  
**POWER ON-POWER OFF**  
pushbutton one time to  
reset relays, then  
depress pushbutton  
second time to start  
rectifier
- [12] On SSP depress  
**ALARM RELEASE**  
pushbutton
- [13] Repeat from  
Step 5, Page 1  
for each  
additional circuit  
breaker in turn
- [14] Disconnect 720A  
from fuse block
- [15] Install **CAP** fuse
- [16] Install circuit breaker cover  
and screws



**CHECK LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER  
FAILURE ALARMS**

<b>DANGER 3</b> <i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 3 of 3	<b>507</b>

**SUMMARY**


See NOTE 1 and NOTE 2. Remove CBS fuse. Set S1 switch on HV circuit pack to TST, HLW lamp should not come on. Set S2 switch to TST, HLW lamp comes on. Set S1 and S2 to NOR. Install CBS fuse.

[1] At 151A PWR PLANT CONTROL UNIT, open circuit pack door [FIG. 1]

[2] On HVM circuit pack, verify both S1 and S2 switches are set to NOR

[3] Remove CBS fuse from CONTROL UNIT fuse panel

[4] On HVM circuit pack, set S1 switch to TST



Page 2

TAP-203





FIG. 1

**NOTE 1**  
If high voltage monitor is properly adjusted, HLW lamp should NOT light with only S1 operated

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	508

**CHECK 151A POWER PLANT HIGH VOLTAGE (HVM) SHUTDOWN CIRCUIT**



**NOTE 2**  
 Plants equipped with ITT-North rectifiers will encounter rectifier shutdown and RECT FAIL light at this time

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	508

**CHECK 151A POWER PLANT HIGH VOLTAGE (HVM) SHUTDOWN CIRCUIT**

**SUMMARY**

See NOTE 1 and FIG. 1. Connect DMM across VM-CAL test jacks, set plant voltmeter selector switch to LV-ADJ. Set LV-CAL switch to CAL, rotate LV-ADJ cw to verify HLV lamp lights at low setting and major alarm turns on at low-low setting. Rotate LV-ADJ fully ccw, set LV-CAL switch to BAT, set plant VOLTMETER SELECTOR switch to BATTERY

- [1] At 151A PWR PLANT CONTROL UNIT [See NOTE 1 and FIG. 1], open circuit pack door and verify LV-ADJ potentiometer is rotated fully ccw
- [2] Set plant voltmeter selector switch to LV ADJ & TST
- [3] Condition DMM to measure approximately 100 Vdc
- [4] Connect DMM across VM CAL (+) and (-) test jacks
- [5] Set LV-CAL switch to CAL
- [6] Slowly rotate LV-ADJ cw until HLV lamp lights and minor alarms turn on or until DMM indication drops to 50.0 volts maximum. See NOTE 2






FIG. 1

NOTES	
1. LV ADJ is 10 turn pot. Equipped with ratchet slip at end of travel	
2. Alarm may be reported as a major alarm in some offices	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	509

**CHECK 151A POWER PLANT LOW VOLTAGE (LV1 AND LV2) MONITORS**



**CHECK 151A POWER PLANT LOW VOLTAGE (LV1 AND LV2) MONITORS**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	509

[1] At 151A PWR PLANT on  
48V RECTIFIER [FIG. 1], depress  
POWER ON-POWER OFF pushbutton  
to turn off rectifier

[2] Loosen screws and remove  
front panel from rectifier

[3] Remove circuit pack cover

[4] Remove circuit pack  
from connector

[5] Install replacement circuit  
pack firmly in connector

[6] Install circuit pack cover

[7] Install front panel on rectifier

[8] Depress POWER ON-POWER OFF  
pushbutton to turn on  
rectifier

Circuit  
pack  
removed

AND

AND




FIG. 1

## REPLACE LORAIN 48V RECTIFIER CIRCUIT PACK

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	511

[1] At 151A PWR PLANT on  
48V RECTIFIER,  
loosen locking device  
on CURRENT LIMIT  
ADJUST rheostat

[2] Rotate CURRENT LIMIT  
ADJUST rheostat  
fully cw

[3] Depress and hold SIMULATED  
OUTPUT CURRENT pushbutton  
lamp lighted


[4] Adjust SIMULATED OUTPUT CURRENT rheostat  
until rectifier OUTPUT CURRENT ammeter  
indicates 100 amperes

[5] See WARNING 1. Rotate CURRENT LIMIT ADJUST  
rheostat slowly ccw until DMM indicates  
-1.25 to -1.50 volts dc or until CURRENT  
LIMIT ADJUST is fully cw

[6] Release SIMULATED OUTPUT  
CURRENT pushbutton  
lamp off

[7] Rotate SIMULATED OUTPUT CURRENT  
rheostat fully ccw

[8] Secure locking device on CURRENT  
LIMIT ADJUST rheostat



<b>WARNING 1</b>	
<i>Current limit level of 1.25 to 1.50 volts dc must be negative (-) polarity</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	512

## ADJUST 48V RECTIFIER CURRENT LIMIT CIRCUIT

[1] See FIG. 1. Connect W1AY cord to 720A voltage pickup tool using 141 cord tip

[2] On 411C tool, loosen knurled knob and remove test pick

[3] Connect test pick to 360A tool attached to end of W1AY cord

[4] Insert test pick into 411C tool and extend 1 inch

[5] Tighten knurled knob on 411C tool

[6] Verify that 720A tool is equipped with 70F 1/4 ampere fuse





FIG. 1 - Fuse Alarm Test Cord - Assembly

### PREPARE FUSE ALARM TEST CORD

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	513



111 1  
111 2




FIG. 1

REPLACE 151A POWER PLANT CONTROL CIRCUIT PACK

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	514

[1] At 151A PWR PLANT turn off 48V RECTIFIER by depressing POWER ON-POWER OFF pushbutton

[2] At commercial AC input power panel, set RECTIFIER circuit breaker to OFF

[3] Condition DMM to  $K\Omega \times 10$  range

At 48V RECTIFIER [FIG. 1]:

[4] Disconnect leads from power diodes CR1 and CR2

[5] Connect DMM across anode and cathode of diode and then reverse DMM across diode

AND

[6] Does DMM indicate high resistance in one direction and low resistance in opposite direction

No

[7] Diode is defective

Yes

[8] Disconnect DMM and reconnect leads at power diodes




FIG. 1

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	515

### CHECK 48V RECTIFIER POWER DIODES (CR1 AND CR2)

[1] At 151A PWR PLANT on  
EXTERNAL CHARGE CIRCUIT  
BREAKER/RECT panel, set  
48V RECTIFIER circuit  
to OFF

[2] At commercial AC input power  
panel, set rectifier circuit  
breaker to OFF

See DANGER 1 and FIG. 1. At  
rectifier C2 output capacitor bank:

[3] Remove cover from  
capacitor bank  
bus bars

[4] Obtain 100-ohm, 10-watt  
resistor and temporarily  
connect resistor across  
filter capacitor POS and  
NEG bus bars

[5] Disconnect capacitor  
fuse wires

[6] With KS-20538 VOM set on  
 $\Omega \times 100$  range, observe  
proper polarity and connect  
VOM across capacitor  
POS and NEG bus bars

AND

[7] Does VOM indicate  
low resistance  
initially, then increase  
in resistance to greater  
than 100 K $\Omega$  as  
capacitor(s) charge

No

No

[8] Disconnect  
individual  
capacitors from bus  
bars and check each  
capacitor with  
ohmmeter

[9] Capacitor  
is defective

Yes


Page 2

C2  
CAPACITOR  
BANK

POS  
BUS  
BAR

NEG  
BUS  
BAR

FIG. 1 - Lorain Rectifier Only




<b>DANGER 1</b> <i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	516

**CHECK OUTPUT FILTER CAPACITOR BANK**

[10] See DANGER 2. Disconnect VOM and verify all capacitor leads are connected

[11] Verify that fuse wires are not defective, then reconnect fuse wires to capacitors

[12] Install cover at capacitor bank bus bar



**CHECK OUTPUT FILTER CAPACITOR BANK**

<b><i>DANGER 2</i></b> <b><i>Extremely high current potential present in this circuit</i></b>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	516

[1] See FIG. 1. At 151A PWR PLANT on EXTERNAL CHARGE CIRCUIT BREAKER/RECT panel, set CHG switch to LAMP TEST

[2] Does CAP CHG lamp light

No

[3] Release CHG switch

TAP-209

Yes

[4] Release CHG switch

[5] On circuit breaker associated with rectifier, depress and hold pushbutton

[6] Does CAP CHG lamp glow brightly initially

No

[8] Release pushbutton

TAP-209

[7] Does CAP CHG lamp dim out within approximately 15 to 45 seconds

No

Yes

[9] Set circuit breaker to ON and release pushbutton




FIG. 1 - External Charge Circuit Breaker/Rect Panel




TABLE A	
EQUIPMENT REQUIRED	RECOMMENDED TYPE
Oscilloscope	Tektronix 545B*
Voltage probe	Tektronix P6006*
* Or equivalent	

**NOTE 1**  
 After voltage probe is connected in test circuit, adjustment of sweep control may be required to display waveform

**CONDITION OSCILLOSCOPE**





FIG. 1

REPLACE 151A POWER PLANT CONTROL CIRCUIT PACK

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	522





FIG. 1

## REPLACE 151A POWER PLANT CONTROL CIRCUIT PACK

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	523

At 151A PWR PLANT CONTROL UNIT:

[1] See NOTE 1 and FIG 1. Open circuit pack door and rotate LV-ADJ potentiometer fully ccw

Minor Alarm turns off, HLV lamp goes out

[2] Set LV-CAL switch to CAL

[3] Set plant voltmeter selector switch to LV ADJ & TST

[4] On LV1 circuit pack, rotate VOLT ADJ potentiometer fully cw

[5] Rotate LV-ADJ potentiometer cw until plant voltmeter indicates 50.75 volts

[6] Slowly rotate VOLT ADJ potentiometer ccw until minor alarm just turns on

[7] Rotate LV-ADJ potentiometer fully ccw

[8] Set LV-CAL switch to BAT

[9] At SSP depress ALARM RELEASE pushbutton

[10] Set plant voltmeter selector switch to BATTERY





FIG. 1

NOTE 1	
LV-ADJ is 10 turn pot. equipped with ratchet slip at end of travel	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	525

ADJUST LV1 PLANT VOLTAGE MONITOR

At 151A PWR PLANT CONTROL UNIT:

[1] See NOTE 1 and FIG. 1. Open circuit pack door and rotate LV-ADJ potentiometer fully ccw

Major and minor Alarm turns off, HLV lamp goes out

[2] Set LV-CAL switch to CAL

Ready to adjust LV2

[3] Set voltmeter selector switch to LV ADJ & TST

[4] On LV2 circuit pack, rotate VOLT ADJ potentiometer fully cw

[5] See NOTE 2. Rotate LV-ADJ potentiometer cw until plant voltmeter indicates 47.75 volts

HLV lamp lights, minor alarm turns on

[6] Slowly rotate VOLT ADJ potentiometer ccw until major alarm just turns on

LV2 adjusted

[7] Rotate LV-ADJ potentiometer fully ccw

HLV lamp goes out, major and minor alarms turn off

[8] Set LV-CAL switch to BAT

[9] At SSP depress ALARM RELEASE pushbutton

[10] Set plant voltmeter selector switch to BATTERY




FIG. 1

NOTES

1. LV-ADJ is 10 turn pot. not equipped with stop
2. At approximately 50.75 volts, LV1 low monitor should turn on to light HLV lamp and turn on minor alarm

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	526

ADJUST LV2 PLANT VOLTAGE MONITOR

At 151A PWR PLANT CONTROL UNIT:

[1] See FIG. 1. Open circuit pack door and on HV circuit pack, set S1 switch to NOR

[2] Rotate SHUTDOWN VOLT ADJ potentiometer 1/4 turn cw

[3] Wait approximately 30 seconds

[4] Set S1 switch to TST

Major alarm turns off, HLV lamp goes out






FIG. 1

At 151A PWR PLANT CONTROL UNIT:

[1] Open circuit pack door and on HV circuit pack set both S1 and S2 switches to TST


[2] Rotate SHUTDOWN VOLT ADJ potentiometer ccw until major alarm turns on




[3] Rotate SHUTDOWN VOLT ADJ potentiometer additional 1/8 turn ccw

[4] Wait approximately 30 seconds

[5] Set both S1 and S2 switches to NOR



[6] At SSP, depress ALARM RELEASE pushbutton




ADJUST HV MONITOR TO DECREASE SHUTDOWN LEVEL

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	528

**SUMMARY**

See NOTES 1 and 2. Adjust rectifiers for DMM indication of 52.08 Vdc. Ammeter on each rectifier should indicate some load current.




**NOTES**


1. Rectifiers are not required to share plant load current equally
2. Charge voltage is determined by local requirements. Refer to office records for exact setting. In absence of local requirements, charge voltage is at a level that produces 52.08 Vdc measured at battery bus

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	530

**SUMMARY**  
 Ensure that Side 1 is nonactive and then remove from service



**FIG. 1 - Ringing & Tone Panel**



**REMOVE RT SIDE 1 FROM SERVICE**



Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	540

**SUMMARY**

Connect DMM across -48 volt fuse load terminal and associated ground terminal strip [FIG. 1]. DMM should indicate between -48.0 and -52.5 Vdc. Connect DMM across +48 volt load terminal and associated ground terminal strip. DMM should indicate between +51.0 and +52 Vdc. Depress **OFF-1** pushbutton.


[1] Condition DMM to measure approximately 100 Vdc

[2] See FIG. 1. At MP frame on rear of 48-volt fuse panel below **INVERTER**, connect DMM across one fuse load terminal and associated ground terminal strip on **F9** to **F16** fuse block



**FIG. 1 - Fuse Block - Typical Connection - Rear View**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	541



**MEASURE -48 VOLT AND +48 VOLT INPUT VOLTAGES - SIDE 1**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	541

**SUMMARY**

See DANGER 1, DANGER 2, CAUTION 1, and WARNING 1. Connect DMM between terminal 12(+) and 14(-) on rear of oscillator circuit pack connector. Depress **NOR** pushbutton. DMM should indicate 2.540 to 2.660 volts. Connect frequency counter

between terminals 12(+) and 14(-). Output frequency is in accordance with TABLE B. Depress **OFF-1** pushbutton. Disconnect frequency meter. Repeat check for each oscillator.

[1] See CAUTION 1 and WARNING 1.

Condition DMM to measure approximately 10V rms

[2] Connect one connecting clip to each DMM lead

At MP frame on rear of **RINGING & TONE** plant:

[3] See DANGER 1, DANGER 2, TABLE A, and FIG. 1.

Use connecting clip to connect DMM(-) lead to terminal 14 (GRD) on oscillator connector

[4] Use connecting clip to connect DMM(+) lead to terminal 12 on oscillator connector

[5] On **RINGING & TONE** panel, depress **NOR** pushbutton





FIG. 1 - Oscillator Connector - Rear View

TABLE A		
CIRCUIT PACK CODE	CIRCUIT PACK LOCATION	OSCILLATOR BEING CHECKED
A980 or A1151	0-7-48	350-1
A981 or A1152	0-7-46	440-1
A982 or A1153	0-9-48	480-1
A983 or A1154	0-9-46	620-1




**WARNING 1**  
Erroneous reading and damage to equipment may result if DMM is not isolated from ground

**CAUTION 1**  
Tone voltages to be measured are complex ac waveforms. A True RMS indicating voltmeter is required to accurately adjust voltage levels. Peak and average ac voltmeters produce inaccurate readings

**DANGERS**

1. Voltage potentials of up to 400 volts to ground are present at rear of plant
2. Isolation of DMM from ground creates potential hazard. Avoid bodily contact between test meter and other components, conductors, or ground



[7] Disconnect DMM from connector

[8] Set frequency counter controls per FIG. 2

[9] Connect one connecting clip to each frequency counter lead



At rear of RINGING & TONE plant:

[10] Connect ground lead of frequency counter at terminal 14 on oscillator connector

[11] Connect frequency counter input lead (+) at terminal 12 on oscillator connector



Page 3




FIG. 2

CHECK TONE OSCILLATORS – SIDE 1

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 3	542






TABLE B		
OSCILLATOR CIRCUIT PACK		FREQUENCY RANGE - HERTZ
CODE	FREQUENCY	
A980 or A1151	350	348.250 to 351.750
A981 or A1152	440	437.800 to 442.200
A982 or A1153	480	477.600 to 482.400
A983 or A1154	620	616.900 to 623.100

**SUMMARY**

See DANGER 1, DANGER 2, CAUTION 1, and WARNING 1. Connect DMM across A1111 connector terminals as given in TABLE A. Depress **NOR** pushbutton. DMM should indicate voltage level in TABLE B. Depress **OFF-1** pushbutton. Repeat check for each tone amplifier

- [1] Condition DMM to measure approximately 1 Vac \_\_\_\_\_
- [2] See CAUTION 1 and WARNING 1. Connect one connecting clip to each DMM lead \_\_\_\_\_
- [3] See DANGER 1, DANGER 2, and FIG. 1. At MP frame on rear of **RINGING & TONE** plant, use connecting clips to connect DMM leads across terminals of A1111 circuit pack connector as given in TABLE A \_\_\_\_\_
- [4] On **RINGING & TONE** panel, depress **NOR** pushbutton \_\_\_\_\_




**FIG. 1 - A1111 Connector - Rear View**

**WARNING 1**  
*Erroneous reading and damage to equipment may result if DMM is not isolated from ground*

**CAUTION 1**  
*Tone voltages to be measured are complex ac waveforms. A TRUE RMS indicating voltmeter is required to accurately adjust voltage levels. Peak and average ac voltmeters produce inaccurate readings.*

**DANGERS**

1. Voltage potentials of up to 400 volts to ground are present at rear of plant
2. Isolation of DMM from ground creates potential hazard. Avoid bodily contact between test meter and other components, conductors, or ground



TONE AMPLIFIER	DMM CONNECTIONS AT A1111 CONNECTOR	VOLTAGE RANGE-VOLTS RMS
TT	14 and 25	1.02 to 1.38
AR	2 and 10	0.306 to 0.414
BT	18 and 22	0.170 to 0.230
MT	16 and 24	0.408 to 0.552
HT	5 and 7	0.246 to 0.334

**SUMMARY**


Remove oscillator circuit pack associated with low voltage monitor as given in TABLE A. Depress **NOR** pushbutton. Restore Side 1 of plant to service. TTY printout should indicate low voltage alarm. Depress **OFF-1** pushbutton. Install oscillator

circuit pack. Depress **NOR** pushbutton. Restore Side 1 of plant to service. TTY printout should indicate low voltage alarm has cleared. Remove Side 1 of plant from service. Depress **OFF-1** pushbutton. Repeat for each additional monitor in side of plant.

[1] At MP frame on **RINGING & TONE** plant, use 723B circuit pack puller to remove oscillator circuit pack as given in TABLE A for voltage monitor being checked

[2] On **RINGING & TONE** panel, depress **NOR** pushbutton

[3] At TTY, type message **RST:RT 1;UCL!**



LOW VOLTAGE MONITOR BEING CHECKED	OSCILLATOR TO BE REMOVED	OSCILLATOR LOCATION	CIRCUIT PACK CODE
TTLV1	350-1	0-7-43	A980 or A1151
ARLV1	440-1	0-7-46	A981 or A1152
BTLV1	620-1	0-9-46	A983 or A1154
MTLV1	440-1	0-7-46	A981 or A1152
HTLV1	480-1	0-9-48	A982 or A1153







TABLE B		
CIRCUIT PACK REMOVED	OSCILLATOR	ALARM GIVEN
A980 or A1151	350	TTLV
A981 or A1152	440	TTLV, MTLV, & ARLV
A982 or A1153	480	ARLV, BTLV, & HTLV
A983 or A1154	620	BTLV



LOW VOLTAGE MONITOR BEING CHECKED	OSCILLATOR TO BE REMOVED	OSCILLATOR LOCATION	CIRCUIT PACK CODE
TTLV1	440-1	0-7-46	A981 or A1152
ARLV1	480-1	0-9-48	A982 or A1153
BTLV1	480-1	0-9-48	A982 or A1153





**SUMMARY**

See DANGER 1, DANGER 2, and WARNING 1. Depress **NOR** pushbutton. Measure ac outputs as given in TABLE A. Voltage requirements should be met as given IN TABLE A.

Connect frequency counter at **INVERTER TB2** terminals 8 and 9. Frequency should be 19.25 to 20.05 Hz. Depress **OFF-1** pushbutton.

[1] See WARNING 1. Condition DMM to measure approximately 100 Vac

[2] See DANGER 1, DANGER 2, and FIG. 1. At MP frame on rear of **RINGING & TONE** plant for inverter being checked, locate **TB2** terminal board and connect DMM per TABLE A

[3] On **RINGING & TONE** panel, depress **NOR** pushbutton




TABLE A		
INVERTER OUTPUT	DMM CONNECTION AT TERMINALS ON INVERTER TB2 TERMINAL BOARD	OUTPUT VOLTAGE REQUIREMENT
86(A)	8 and 9	84.5 to 88.0
86(B)	4 and 5	
97(A)	8 and 10	94.5 to 101.0
97(B)	4 and 6	
105(A)	8 and 11	103.0 to 110.0
105(B)	4 and 7	
105(C)	1 and 3	




FIG. 1

**WARNING 1**  
*Erroneous reading and damage to equipment may result if DMM is not isolated from ground*

**DANGERS**

- 1. Voltage potentials of up to 400 volts to ground are present at rear of plant*
- 2. Isolation of DMM from ground creates potential hazard. Avoid bodily contact between test meter and other components, conductors, or ground*

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 3	545






FIG. 2



**CHECK 20-HZ INVERTER – SIDE 1**


Issue 2	JUL 1980
233-144-100	DLP
PAGE 3 of 3	545

**SUMMARY**


See DANGER 1, FIG. 1, and FIG. 2. Connect 720A voltage pickup tool at F32 spare fuse position. Depress NOR pushbutton. Restore Side 1 of plant to service. Touch tip of 411C test pick to test point on fuse cap of F9. OFF-1 lamp should light, TTY printout should indicate RT fuse alarm. Remove test pick from fuse cap. OFF-1 lamp should

go out. Depress OFF-1 pushbutton, then depress NOR pushbutton. Restore Side 1 of plant to service. TTY should indicate that fuse alarm has cleared. Test remainder of fuses [TABLES A and B] by observing that OFF-1 lamp lights and then goes out when test connection is made at fuse cap and then is released. Depress OFF-1 pushbutton.

- [1] See DANGER 1 and FIG. 1. At distribution fuse panel located at bottom of miscellaneous power frame, using fuse alarm test cord, install 720A tool at F32 position
- [2] On RINGING & TONE panel, depress NOR pushbutton
- [3] At TTY type message RST:RT 1;UCL!
- [4] See FIG. 2. At F9 fuse, touch tip of 411C test pick to test point on fuse cap




**FIG. 2 - Alarm Fuse Cap - Typical**



**FIG. 1 - 48-Volt Distribution Fuse Panel**

**DANGER 1**  
*When 720A tool is installed, 48-volt potential is present on tip of test pick*

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 4	546



<b>DANGER 2</b>	
<i>When 720A tool is installed, 48-volt potential is present on tip of test pick</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 4	546





TABLE A		
SPARE FUSE POSITION	FUSES ASSOCIATED WITH SPARE	ALARM RELAY
F32	F10 thru F16 F25 thru F31	FA1



SPARE FUSE POSITION	FUSES ASSOCIATED WITH SPARE	ALARM RELAY
F40	F35, F36, F39	FA1

NOTE 1  
F36 and F39 not equipped in all offices

Issue 2	JUL 1980
233-144-100	DLP
PAGE 4 of 4	546




TABLE A
DGN RT1 ATP
RST RT1 COMPL

**TURN UP AND RESTORE TO SERVICE RT SIDE 1**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	547

**SUMMARY**  
Ensure that Side 0 is nonactive and then remove from service.






FIG. 1 - Ringing & Tone Panel



**REMOVE RT SIDE 0 FROM SERVICE**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	550

**SUMMARY**

Connect DMM across -48 volt fuse load terminal and associated ground terminal strip [FIG. 1]. DMM should indicate between -48.0 and -52.5 Vdc. Connect DMM across +48 volt fuse load terminal and associated ground terminal strip. DMM should indicate between +51.0 and +52.0 Vdc. Depress OFF-0 pushbutton.

[1] Condition DMM to measure approximately 100 Vdc

[2] See FIG. 1. At MP frame on rear of 48-volt fuse panel below INVERTER, connect DMM across one fuse load terminal and associated ground terminal strip on F1 to F8 fuse block






FIG. 1 - Fuse Block - Typical Connection - Rear View

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	551



**SUMMARY**

See DANGER 1, DANGER 2, CAUTION 1, and WARNING 1. Connect DMM between terminal 12(+) and 14(-) on rear of oscillator circuit pack connector. Depress **NOR** pushbutton. DMM should indicate 2.540 to 2.660 volts rms. Connect frequency counter between terminals 12(+) and 14(-). Output frequency is in accordance with TABLE B. Depress **OFF-0** pushbutton. Repeat check for each oscillator.

*[8] DEPRESS OFF-0 PUSHBUTTON*

[1] See CAUTION 1 and WARNING 1. Condition DMM to measure approximately 10V rms

[2] Connect one connecting clip to each DMM lead

At MP frame on rear of **RINGING & TONE** plant:

[3] See DANGER 1, DANGER 2, TABLE A, and FIG. 1. Use connecting clip to connect DMM(-) lead to terminal 14 (GRD) on oscillator connector

[4] Use connecting clip to connect DMM(+) lead to terminal 12 on oscillator connector





FIG. 1 - Oscillator Connector - Rear View

TABLE A		
CIRCUIT PACK CODE	CIRCUIT PACK LOCATION	OSCILLATOR BEING CHECKED
A980 or A1151	0-7-3	350-0
A981 or A1152	0-7-5	440-0
A982 or A1153	0-9-3	480-0
A983 or A1154	0-9-5	620-0


**WARNING 1**  
Erroneous reading and damage to equipment may result if DMM is not isolated from ground

**CAUTION 1**  
Tone voltages to be measured are complex ac waveforms. A True RMS indicating voltmeter is required to accurately adjust voltage levels. Peak and average ac voltmeters produce inaccurate readings


**DANGERS**

1. Voltage potentials of up to 400 volts to ground are present at rear of plant
2. Isolation of DMM from ground creates potential hazard. Avoid bodily contact between test meter and other components, conductors, or ground

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 3	552



No  
TAP-191



[8] Set frequency counter controls per FIG. 2

[9] Connect one connecting clip to each frequency counter lead



Frequency counter conditioned

At rear of RINGING & TONE plant:

[10] Connect ground lead of frequency counter at terminal 14 on oscillator connector

[11] Connect frequency counter input lead (+) at terminal 12 on oscillator connector





FIG. 2

Frequency counter connected



Page 3

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 3	552



CIC 4-7-3

TABLE B		
OSCILLATOR CIRCUIT PACK		FREQUENCY RANGE - HERTZ
CODE	FREQUENCY	
A980 or A1151	350	348.250 to 351.750
A981 or A1152	440	437.800 to 442.200
A982 or A1153	480	477.600 to 482.400
A983 or A1154	620	616.900 to 623.100

CHECK TONE OSCILLATORS - SIDE 0


**SUMMARY**

See DANGER 1, DANGER 2, CAUTION 1, and WARNING 1. Connect DMM across A1111 connector terminals as given in TABLE A. Depress **NOR** pushbutton. DMM should indicate voltage level in TABLE A. Depress **OFF-0** pushbutton. Repeat check for each tone amplifier.

[1] See CAUTION 1 and WARNING 1.  
Condition DMM to measure approximately 1V rms

[2] Connect one connecting clip to each DMM lead

[3] See DANGER 1, DANGER 2, and FIG. 1. At MP frame on rear of **RINGING & TONE** plant, use connecting clips to connect DMM leads across terminals of A1111 circuit pack connector as given in TABLE A



**FIG. 1 - A1111 Connector - Rear View**

AND Page 2

**WARNING 1**  
*Erroneous reading and damage to equipment may result if DMM is not isolated from ground*

**CAUTION 1**  
*Tone voltages to be measured are complex ac waveforms. A True RMS indicating voltmeter is required to accurately adjust voltage levels. Peak and average ac voltmeters produce inaccurate readings*

**DANGERS**

1. *Voltage potentials of up to 400 volts to ground are present at rear of plant*
2. *Isolation of DMM from ground creates potential hazard. Avoid bodily contact between test meter and other components, conductors, or ground*




TABLE A		
TONE AMPLIFIER	DMM CONNECTION AT A1111 CONNECTOR	VOLTAGE RANGE - VOLTS RMS
TT	14 and 25	1.02 to 1.38
AR	2 and 10	0.306 to 0.414
BT	18 and 22	0.170 to 0.230
MT	16 and 24	0.408 to 0.552
HT	5 and 7	0.246 to 0.334

**SUMMARY**


Remove oscillator circuit pack associated with low voltage monitor as given in TABLE A. Depress **NOR** pushbutton. Restore Side 0 of plant to service. TTY printout should indicate low voltage alarm. Depress **OFF-0** pushbutton.

Install oscillator circuit pack. Depress **NOR** pushbutton. Restore Side 0 of plant to service. TTY printout should indicate low voltage alarm has cleared. Remove Side 0 of plant from service. Depress **OFF-0** pushbutton. Repeat for each additional monitor in side of plant.

[1] At MP frame on **RINGING & TONE** plant, use 723B circuit pack puller to remove oscillator circuit pack as given in TABLE A for low voltage monitor being checked

[2] On **RINGING & TONE** panel, depress **NOR** pushbutton

[3] At TTY, type message **RST:RT 0;UCL!**



**TABLE A**

LOW VOLTAGE MONITOR BEING CHECKED	OSCILLATOR TO BE REMOVED	OSCILLATOR LOCATION	CIRCUIT PACK CODE
TTLV0	350-0	0-7-3	A980 or A1151
ARLV0	440-0	0-7-5	A981 or A1152
BTLV0	620-0	0-9-5	A983 or A1154
MTLV0	440-0	0-7-5	A981 or A1152
HTLV0	480-0	0-9-3	A982 or A1153




TABLE B		
CIRCUIT PACK REMOVED	OSCILLATOR	ALARM GIVEN
A980 or A1151	350	TTLV
A981 or A1152	440	TTLV, MTLV, & ARLV
A982 or A1153	480	ARLV, BTLV, & HTLV
A983 or A1154	620	BTLV

[13] Remove side of plant from service by typing message RMV:RT 0!

[14] On RINGING & TONE panel, depress OFF-0 pushbutton

[15] Which low voltage monitor is being checked

TTLV,  
ARLV,  
BTLV

[18] Use 723B circuit pack puller to remove oscillator circuit pack as given in TABLE C for low voltage monitor being checked

MTILV,  
HTLV

[16] Is other low voltage monitor to be checked

No

[19] Depress NOR pushbutton

Yes

[17] Repeat from Step 1, Page 1 for low voltage monitor to be checked

[20] At TTY, type message RST:RT 0;UCL!

[21] Does TTY remove Side 0 due to alarm condition [TABLE B, Page 2]

No


[22] Remove side of plant from service by typing message RMV:RT 0!


Yes

Page 4

TAP-193

LOW VOLTAGE MONITOR BEING CHECKED	OSCILLATOR TO BE REMOVED	OSCILLATOR LOCATION	OSCILLATOR CODE
TTLVO	440-0	0-7-5	A981 or A1152
ARLVO	480-0	0-9-3	A982 or A1153
BTLVO	480-0	0-9-3	A982 or A1153





**SUMMARY**

See DANGER 1, DANGER 2, and WARNING 1. Depress **NOR** pushbutton. Measure ac outputs as given in TABLE A. Voltage requirements should be met as given in TABLE A.

Connect frequency counter at **INVERTER TB2** terminals 8 and 9. Frequency should be 19.95 to 20.05 Hz. Depress **OFF-0** pushbutton.

[1] See WARNING 1. Condition DMM to measure approximately 100 Vac

[2] See DANGER 1, DANGER 2, and FIG. 1. At MP frame on rear of **RINGING & TONE** plant for inverter being checked, locate **TB2** terminal board and connect DMM per TABLE A

[3] On **RINGING & TONE** panel, depress **NOR** pushbutton




TABLE A		
INVERTER OUTPUT	DMM CONNECTION AT TERMINALS ON INVERTER TB2 TERMINAL BOARD	OUTPUT VOLTAGE REQUIREMENT
86(A)	8 and 9	84.5 to 88.0
86(B)	4 and 5	
97(A)	8 and 10	94.5 to 101.0
97(B)	4 and 6	
105(A)	8 and 11	103.0 to 110.0
105(B)	4 and 7	
105(C)	1 and 3	




FIG. 1

**WARNING 1**  
*Erroneous reading and damage to equipment may result if DMM is not isolated from ground*

**DANGERS**

- Voltage potentials of up to 400 volts to ground are present at rear of plant*
- Isolation of DMM from ground creates potential hazard. Avoid bodily contact between test meter and other components, conductors, or ground*

**CHECK 20-HZ INVERTER – SIDE 0**






FIG. 2

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 3	555



**CHECK 20-HZ INVERTER – SIDE 0**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 3 of 3	555

**SUMMARY**

See DANGER 1. Connect 720A voltage pickup tool at F24 spare fuse position. Depress NOR pushbutton. Restore Side 0 of plant to service. Touch tip of 411C test pick to test point on fuse cap of F1. OFF-0 lamp should light, TTY printout should indicate RT fuse alarm. Remove test pick from fuse cap. OFF-0

lamp should go out. Depress OFF-0 pushbutton, then depress NOR pushbutton. Restore Side 0 of plant to service. TTY should indicate that fuse alarm has cleared. Test remainder of fuses [TABLES A and B] by observing that OFF-0 lamp lights and then goes out when test connection is made at fuse cap and then is released. Depress OFF-0 pushbutton.

- [1] See DANGER 1 and FIG. 1. At distribution fuse panel, using fuse alarm test cord, install 720A tool at F24 position
- [2] On RINGING & TONE panel, depress NOR pushbutton
- [3] At TTY type message RST:RT 0;UCL!
- [4] See FIG. 2. At F1 fuse, touch tip of 411C test pick to test point on fuse cap





FIG. 2 - Alarm Fuse Cap - Typical






FIG. 1 - 48-Volt Distribution Fuse Panel

<b>DANGER 1</b>	
<i>When 720A tool is installed, 48-volt potential is present on tip of test pick</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 4	556



<b>DANGER 2</b>	
<i>When 720A tool is installed, 48-volt potential is present on tip of test pick</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 4	556

[12] At each fuse given in TABLE A, touch tip of 411C test pick to test point on fuse cap



[13] Does PWR OFF-0 lamp light

Yes

No

[15] Remove test pick from fuse cap and observe that PWR OFF-0 lamp goes out

[16] Repeat from Step 12 for each additional fuse given in TABLE A

[14] Trouble is possible open connection in fuse cap or open lead going to FA0 alarm relay. Clear trouble per SD-82255-01

[17] Depress OFF-0 pushbutton

[18] Disconnect 720A tool from spare fuse position and install fuse cap

Page 4

TABLE A		
SPARE FUSE POSITION	FUSES ASSOCIATED WITH SPARE	ALARM RELAY
F24	F2 thru F8 F17 thru F24	FA0





TABLE B		
SPARE FUSE POSITION	FUSES ASSOCIATED WITH SPARE	ALARM RELAY
F38	F33, F34, F37	FA0



**TURN UP AND RESTORE TO SERVICE RT SIDE 0**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	557

**SUMMARY**

See CAUTION 1 and WARNING 1. At 400A T GEN connect 3A NOISE MEASURING SET across terminals 17 and 26 on TB1 terminal board. Meter should indicate 10 ±1 dBrn. Repeat across terminals 26 and 27

TABLE A	
EQUIPMENT REQUIRED	RECOMMENDED TYPE
Noise measuring set	J94003A 3A noise measuring set*
Test leads (2)	-
Test plugs (2)	241A plug *
* Or equivalent	

[1] Obtain test equipment in TABLE A

On 3A NOISE MEASURING SET:

[2] Connect two test leads with 241A plugs at IN jacks

[3] Rotate FUNCTION switch to 900 NM

[4] Set DAMP-NORM switch to NORM

[5] Rotate DBRN switch to 85



[6] Plug in 497A NETWORK to 3KC FLAT WTG position

[7] Connect GRD terminal to ground

At MP frame on 400A T GEN:

[8] Remove front cover

[9] See CAUTION 1 and WARNING 1. At right of 400A T GEN, connect 3A NOISE MEASURING SET at terminals 17 and 26




Page 2

**WARNING 1**  
Generator may be damaged if 3A NOISE MEASURING SET is connected to incorrect terminal

**CAUTION 1**  
When using the 3A or 3B set in BRDG function on a working line, dialing pulses may become distorted. It is recommended that the set be connected to the line no longer than necessary

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 3	560


**CHECK AND ADJUST 400A TONE GENERATOR**



**WARNING 2**  
Generator may be damaged if 3A NOISE MEASURING SET is connected to incorrect terminals

**CAUTION 2**  
When using the 3A or 3B set in BRDG function on a working line, dialing pulses may become distorted. It is recommended that the set be connected to the line no longer than necessary

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 3	560



**CHECK AND ADJUST 400A TONE GENERATOR**


NOTE 1	
Diagnostics for either side 0 or side 1 will initiate diagnostics on 400A tone generator	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 3 of 3	560

**SUMMARY**

See DANGER 1. Connect test cord at ringing distribution fuse load terminal. Touch tip of test pick to alarm test point on fuse cap. Fuse alarms are given. Remove test pick. Alarms turn off.

[1] Get test equipment in TABLE A

[2] See FIG. 1. Connect 411C tool at one end of W1AY cord and at other end of cord, connect connecting clip



[3] At MP frame on back of RINGING & TONE plant: See DANGER 1 and FIG. 2. On ringing distribution fuse panel, connect clip at load terminal of one distribution fuse as given in TABLE B

Page 2





FIG. 2

TABLE A	
EQUIPMENT REQUIRED	RECOMMENDED TYPE
Test cord	W1AY cord*
Test pick	411C tool*
Connecting clip	Insulated alligator clips
*or equivalent	

TABLE B		
RINGING OUTPUTS	FUSE NUMBERS ASSOCIATED WITH RINGING OUTPUT*	FUSE PANEL LOCATION
+AC-DC	F1-F8	0-17-0
-SUP 105	F1-F12	0-16-0
GEN1	F1-F8	0-18-0
105V±	F1-F8	
-AC-DC	F1-F24	0-17-0
105±EML	F1-F16	0-16-0
SUP-97	F1-F10	
SUP+97	F1-F10	0-17-0
+SUP 105	F1-F16	
+TRP	F1-F8	0-18-0
-TRP	F1-F24	

\* Fuses are assigned locally

**DANGER 1**  
When 411C tool is connected, up to 300 volts peak-to-peak is present on tip of test pick

Issue 2 JUL 1980  
233-144-100 DLP  
PAGE 1 of 2 561

[4] See FIG. 3. At front of one fuse associated with ringing output in TABLE B, touch tip of 411C test pick to exposed test point on fuse cap

[5] See NOTE 1. Does system control initiate fuse alarm and TTY trouble report

[6] Trouble in defective FA2 alarm relay or open alarm lead. Clear trouble per SD-82255-01

[7] Remove test pick from fuse cap and observe that TTY printout indicates trouble clear

[8] Repeat from Step 4 for each additional fuse associated with ringing output in TABLE B

[9] Disconnect clip from distribution fuse load terminal

[10] Repeat from Step 3, Page 1 for each additional ringing output as given in TABLE B





FIG. 3 - Alarm Fuse Cap - Typical



**TEST RINGING DISTRIBUTION FUSE ALARMS**

NOTE 1	
For exact TTY messages, refer to IM/OM 3H300	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	561

[1] Obtain test equipment in TABLE A

At MP frame:

[2] See NOTE 1. On RINGING & TONE panel, depress OFF-0 (or OFF-1) key

[3] See FIG. 1. Using 723B circuit pack puller, remove oscillator circuit pack being adjusted

[4] Connect oscillator circuit pack to 158A adapter, then install adapter in circuit pack connector




TABLE A	
EQUIPMENT REQUIRED	RECOMMENDED TYPE
Digital multimeter (DMM)	Hickok Model 3310 (ITE-5356)*†
Circuit pack puller	723B tool†
Circuit pack extender	158A adapter†
Jewelers screwdriver	R1005 tool†
(2) Connecting clips	EZ Hook†
* DMM must be true RMS and isolated from ground † or equivalent	




FIG. 1

NOTE 1  
Information enclosed in parentheses refers to Side 0 or Side 1

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 3	562

[5] See WARNING 1. Isolate DMM from ground [DLP-720] and condition to measure approximately 10V rms

[6] See DANGER 1, DANGER 2, CAUTION 1, WARNING 2, and FIG. 2. At rear of plant, connect DMM across oscillator circuit pack connector terminals 12 and 14 (GRD)

[7] On RINGING & TONE panel, depress NOR pushbutton

[8] On oscillator circuit pack, adjust potentiometer in TABLE B until DMM indicates 2.60 volts




TABLE B		
OSCILLATOR CIRCUIT PACK	CIRCUIT PACK LOCATION	VOLTAGE ADJUST POTENTIOMETER
350-0	0-7-3	R10 for A980 R3 for A1151
350-1	0-7-48	
440-0	0-7-5	R10 for A981 R3 for A1152
440-1	0-7-46	
480-0	0-9-3	R10 for A982 R3 for A1153
480-1	0-9-48	
620-0	0-9-5	R10 for A983 R3 for A1154
620-1	0-9-46	





FIG. 2 - Oscillator Connector - Rear View

<b>WARNINGS</b>	
<ol style="list-style-type: none"> <li>Erroneous reading and damage to equipment may result if DMM is not isolated from ground</li> <li>DMM(-) lead must be connected to terminal 14 on oscillator connector</li> </ol>	
<b>CAUTION 1</b>	
<p>Tone voltages to be measured are complex ac waveforms. A <u>True RMS</u> indicating voltmeter is required to accurately adjust voltage levels. Peak and average ac voltmeters produce inaccurate readings.</p>	
<b>DANGERS</b>	
<ol style="list-style-type: none"> <li>Voltage potentials of up to 400 volts to ground are present at rear of plant</li> <li>Isolation of DMM from ground creates potential hazard. Avoid bodily contact between test meter and other components, conductors, or ground</li> </ol>	

**ADJUST OSCILLATOR VOLTAGE LEVEL**



**ADJUST OSCILLATOR VOLTAGE LEVEL**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 3 of 3	562






FIG. 1 - A1111 Connector - Rear View

**WARNING 1**  
 Erroneous reading and damage to equipment may result if DMM is not isolated from ground

**DANGERS**

1. Voltage potentials of up to 400 volts to ground are present at rear of plant
2. Isolation of DMM from ground creates potential hazard. Avoid bodily contact between test meter and other components, conductors, or ground

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	563



**TABLE A**

TONE AMPLIFIER BEING ADJUSTED	OSCILLATOR CIRCUIT PACK TO BE REMOVED		CONNECTION OF DMM ACROSS TERMINALS OF CPA1111 TRAN CONNECTOR	VOLTAGE ADJUST POTENTIOMETER
	FREQUENCY	CODE		
TT	350	A980 or A1151	13 and 26	ADJ-2 (R4)
AR	440	A981 or A1152	1 and 12	ADJ-1 (R3)
BT	480	A982 or A1153	17 and 21	ADJ-2 (R4)
MT	*		15 and 20	ADJ-2 (R4)
HT	*		4 and 9	ADJ-1 (R3)

\* No oscillator circuit pack is removed

[1] On A751A or B circuit pack, rotate **LV ADJ** potentiometer fully ccw and observe low voltage relay is released or LED lights [FIG. 1]

[2] Very slowly rotate **LV ADJ** cw until low voltage relay operates or LED extinguishes

[3] Very slowly rotate **LV ADJ** ccw until low voltage relay just releases or LED lights






FIG. 1

# ADJUST LOW VOLTAGE MONITOR

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	564



TONE AMPLIFIER	OSCILLATOR CIRCUIT PACK THAT IS REMOVED		CONNECTION OF DMM ACROSS TERMINALS OF CPA1111 TRAN CONNECTOR	POTENTIOMETER TO BE ADJUSTED	VOLTAGE LEVEL - VOLTS RMS †
	FREQUENCY	CODE			
TT	350	A980 or A1151	14 and 25	ADJ-2 (R4)	0.850
AR	440	A981 or A1152	2 and 10	ADJ-1 (R3)	0.255
BT	480	A982 or A1153	18 and 22	ADJ-2 (R4)	0.1414
MT	*		16 and 24	ADJ-2 (R4)	0.480
HT	*		5 and 7	ADJ-1 (R3)	0.290

\* No oscillator circuit pack is removed

† True RMS meter must be used

NOTE 1 Information enclosed in parentheses refers to Side 0 or to Side 1	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 4	565

**ADJUST TONE AMPLIFIER TO NORMAL VOLTAGE LEVEL**

[4] See WARNING 1 and CAUTION 1.  
Isolate DMM from ground  
[DLP-720] and condition to  
measure approximately 10V rms

[5] See DANGER 1, DANGER 2, and  
FIG. 1. At rear of plant use  
connecting clips to connect DMM  
across A1111 (Side 0 or 1)  
connector terminals per TABLE A

[6] On RINGING & TONE panel,  
depress NOR pushbutton

[7] On 305 amplifier circuit pack, adjust  
potentiometer given in TABLE A until  
DMM indicates voltage level in TABLE A

[8] Depress OFF-0 (or OFF-1) pushbutton




FIG. 1 - A1111 Connector -  
Rear View

Page 3

**WARNING 1**  
*Erroneous reading and damage  
to equipment may result if DMM  
is not isolated from ground*

**CAUTION 1**  
*Tone voltages to be measured  
are complex ac waveforms. A  
True RMS indicating voltmeter  
is required to accurately  
adjust voltage levels. Peak  
and average ac voltmeters  
produce inaccurate readings.*

**DANGERS**

1. Voltage potentials of up to 400 volts to ground are present at rear of plant
2. Isolation of DMM from ground creates potential hazard. Avoid bodily contact between test meter and other components, conductors, or ground

**ADJUST TONE AMPLIFIER TO NORMAL VOLTAGE LEVEL**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 4	565





TABLE B				
TONE AMPLIFIER	OSCILLATOR CIRCUIT PACK TO BE REMOVED		POTENTIOMETER TO BE ADJUSTED	VOLTAGE LEVEL - VOLTS RMS
	FREQUENCY	CODE		
TT	440	A981 or A1152	ADJ-1(R3)	0.850
AR	480	A982 or A1153	ADJ-2(R4)	0.255
BT	620	A983 or A1154	ADJ-1(R3)	0.1414

**ADJUST TONE AMPLIFIER TO NORMAL VOLTAGE LEVEL**

[13] On 305 amplifier circuit pack, adjust potentiometer given in TABLE B until DMM indicates voltage in TABLE B


[14] Depress OFF-0 (or OFF-1) pushbutton

[15] Install oscillator circuit pack




**ADJUST TONE AMPLIFIER TO NORMAL VOLTAGE LEVEL**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 4 of 4	565




**REPLACE CIRCUIT PACK**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	566




**REPLACE BLOWN FUSE**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	567



**INSTALL MP 0 OR MP 1 FUSE**



**REPLACE 20-HZ PULSE GENERATOR**

At front of **INVERTER**:




[11] Carefully position and align replacement **PULSE GENERATOR** in framework

[12] Install **PULSE GENERATOR** mounting screws


At rear of **INVERTER**:

[13] At **TB2** terminal board, reconnect leads at terminals 1 through 12


[14] At **TB1** terminal board, reconnect leads at terminals 1 and 2



INV 1



INV 0



# REPLACE 20-HZ PULSE GENERATOR

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	569

[1] At MP frame below **INVERTER**,  
remove **F26** and **F18** fuses

[2] On rear of **400A T GEN** terminal  
board **TB1**, label and disconnect  
leads at terminals **17, 26, 27,**  
**36, 41, 44, 47,** and **48**

At rear of **400A T GEN** [FIG. 1]:

[3] Remove 4 mounting bolts and insulated  
bushings that bolt generator to  
mounting bracket

[4] Carefully remove generator from  
front of framework

[5] Secure all wiring that was disconnected

[6] Carefully position and align replacement  
generator in mounting bracket

[7] Install generator mounting bolts  
and insulated bushings

[8] At **TB1** terminal board, reconnect leads  
at terminals **17, 26, 27, 36, 41, 44,**  
**47,** and **48**

[9] Install **F26**  
and **F18** fuses







FIG. 1 - 400A Tone Generator - Rear View

## REPLACE 400A TONE GENERATOR

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	570

[1] See DANGERS 1 and 2. Discharge static electricity from body by touching a ground away from battery area before performing each operation

[2] See FIG. 1. Hold flashlight close to each cell jar at 45° angle and inspect vertical positive plate column from top to bottom for diamond like reflecting particles or gray coloration

[3] Does diamond like reflecting particles or gray coloration appear

No

Yes

Page 2


**DANGERS**

1. *Battery gas is extremely explosive when sufficiently concentrated. Avoid creating static sparks and use of open flames*
2. *Protective equipment such as rubber gloves, rubber aprons and splash-proof goggles should be worn when performing maintenance on batteries. Rings, wrist watches, metal bracelets, necklaces, belt buckles, etc, should be removed*

Issue 2 JUL 1980

233-144-100 DLP

PAGE 1 of 3 575



[5] See NOTE 1. Battery float voltage low. Adjust battery bus voltage [DLP-504]

**NOTE 1**  
 Battery discharge resulting from a power failure or other reason will normally produce bad sulphate crystals. Crystals will gradually disappear from top to bottom of plate when cells are fully recharged to float






FIG. 1



Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 3	575

**INSPECT INDIVIDUAL CELLS FOR CRYSTALS**



**INSPECT INDIVIDUAL CELLS FOR CRYSTALS**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 3 of 3	575




**WARNING 1**  
*Never disconnect leads from meter without first disconnecting them from battery*

**DANGERS**

- Protective equipment such as rubber gloves, rubber aprons, and splash-proof goggles should be worn when performing maintenance on batteries. Rings, wrist watches, metal bracelets, necklaces, belt buckles, etc, should be removed*
- Extremely high current potential present in this circuit*

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	576

**MEASURE INDIVIDUAL CELL VOLTAGE**



[4] Obtain materials and tools in Table A

[5] See CAUTION 1 and FIG. 1. Install temporary wiring and switch

[6] Close switch

[7] Use two insulated wrenches to remove intercell connector

AND

Page 2

TABLE A	
EQUIPMENT REQUIRED	RECOMMENDED TYPE
NO-OX-ID A	R-3266 L1
4/0 sandpaper	-
Table soda	-
Wiper paper	Scott #58 or #59
Insulated wrenches	-
Switch and wire	-
Typewriter brush	R2969




FIG. 1


**CAUTION 1**  
Wiring must be of sufficient size to carry the load under power failure conditions

**DANGER 1**  
Extremely high current potential present in this circuit

Issue 2 JUL 1980

233-144-100 DLP

PAGE 1 of 3 577



**WARNINGS**

1. Do not allow neutralizing solutions to enter cell
2. Sandpaper, stiff wire brushes, or other abrasive tools should not be used on intercell connectors or fastening hardware as this will remove the protective lead coating

**DANGER 2**  
Extremely high current potential present in this circuit

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 3	577

**MAINTAIN BATTERY TERMINALS AND CONNECTORS**


[15] See DANGER 3. Coat contact areas with NO-OX-ID A

[16] Using insulated wrenches, connect intercell connector to terminal post

[17] Open switch and remove temporary wiring

[18] Coat terminal areas of cell with NO-OX-ID A

[19] Wipe off any excess NO-OX-ID A compound




## MAINTAIN BATTERY TERMINALS AND CONNECTORS

<b>DANGER 3</b> <i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 3 of 3	577

[1] See DANGER 1, WARNING 1 and NOTE 1.  
Insert thermometer through vent tunnel in  
one cell on battery tier

[2] Completely submerge thermometer bulb  
in electrolyte for at least 2 minutes

[3] Record thermometer reading (reference  
temperature) for the battery tier on  
form provided



## CHECK ELECTROLYTE TEMPERATURE

NOTE 1 Only one temperature measurement per battery tier is necessary.	
<b>WARNING 1</b> <i>Do not use mercury filled thermometers to take cell temperature</i>	
<b>DANGER 1</b> <i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	578






FIG. 1

TABLE A		
MAXIMUM ALLOWABLE IMPURITIES IN BATTERY WATER		
TYPE OF IMPURITY	PPM OR MG/LITER (BY WEIGHT)	PERCENT
Total solids	500	0.0500
Fixed solids	350	0.0350
Organic & volatile matter	50	0.0050
Chloride	25	0.0025
Iron	4	0.0004
Nitrates & nitrites	15	0.0015
Ammonia	5	0.0005
Manganese	0.007	0.0000007

- WARNINGS**
1. Acid or electrolyte shall not be added to any cell as a substitute for adequate charging. Do not contaminate the electrolyte of KS-20472 cells by using electrolyte from lead-calcium or lead-antimony.
  2. Plastic funnels will not contaminate but must be rinsed with clean water before using to fill different type cells. Do not use funnels of lead-calcium composition. Only clean plastic funnels shall be used.
  3. Under no circumstances shall electrolyte be disposed of in a manner that may result in environmental pollution or damage to equipment. The electrolyte should be neutralized where the possibility of damage may occur.

**DANGER 1**  
*Extremely high current potential present in this circuit*



<b>WARNING 1</b>	
<i>At no time shall wire brush be brought in close proximity to cell terminals and intercell connectors</i>	
<b>DANGER 1</b>	
<i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	580

**CLEAN RACKS AND STANDS**

[1] See DANGER 1.


Prepare weak soda solution of 1/4 lb  
table soda (bicarbonate) (or 1/8 lb  
washing soda) in 1 gal water

[2] See WARNING 1. Dampen  
cloth in weak soda  
solution

[3] Wipe jars


[4] Dampen clean cloth  
in clean water

[5] Wipe jars



## CLEAN BATTERY JARS

<b>WARNING 1</b> <i>Do not allow neutralizing solutions to enter cell</i>	
<b>DANGER 1</b> <i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	<b>581</b>





<b>DANGER 1</b>	
<i>Extremely high current potential present in this circuit</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	582

**INSPECT AND CLEAN ANTIEXPLOSION DEVICE**

**SUMMARY**

See FIG. 1. In test mode, panel voltmeter indicates 110 to 125 Vac and **INVERTER RUN** lamp lights. **INVERTER** restores to normal within 30 to 50 seconds.



**FIG. 1**




TABLE A POWER ALARMS	
LOCATION	INDICATION
1. SSP	Major (red) Major power (red)
2. TTY	** REPT MISCA 25 12 OFN
3. BUILDING	Major audible
4. INVERTER	Inverter run (amber)

**CHECK INVERTER TRANSFER AND ALARM CIRCUITS**

**SUMMARY**

Operate AC input circuit breaker to **ON**. Install fuses **P** and **ACL**. Install fuse supplying power to **INVERTER**. Set **ON-OFF** switch, **CB1**, and **CB2** to **ON**. Plug **ANNOUNCEMENT** machine and **TTY** into output of **INVERTER**

[1] At commercial AC input power panel, set **INVERTER** circuit breaker to **ON** or install fuse

[2] At TST frame below **INVERTER**, install fuses **P** and **ACL**


[3] At 151A PWR PLANT, on -48V discharge distribution panel, install 30A FRN TST INV fuse supplying power to **INVERTER**

At TST frame on front panel of **INVERTER**:

[4] Set **ON-OFF** switch to **ON**

[5] Set **CB1** and **CB2** to **ON**

[6] Plug **ANNOUNCEMENT** machine and **TTY** into **INVERTER** output



**RESTORE KS-20816 L2 INVERTER TO SERVICE**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	611

**SUMMARY**

See DANGER 1. Measure input DC voltage on TB1 terminals 1 and 2. Reading should be -42 to -56 Vdc

[1] Condition DMM to measure approximately 100 Vdc

[2] See DANGER 1. At TST frame INVERTER, connect DMM across direct current input TB1 terminals 1 and 2 [FIG. 1]





FIG. 1

**CHECK DC INPUT VOLTAGE**

**DANGER 1**  
Voltages in this circuit are over 150 volts to ground

**SUMMARY**

See DANGER 1. Measure output voltage of operating **INVERTER** on TB 2 terminals 1 and 2. Indication should be 110 to 125 Vac






FIG. 1

**CHECK AC OUTPUT VOLTAGE**

**DANGER 1**  
*Voltages in this circuit are over 150 volts to ground*

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	<b>613</b>

**SUMMARY**

See DANGER 1. Adjust panel meter for exact voltage indication

At TST frame **INVERTER**:

- [1] See DANGER 1 and FIG. 1.  
Connect DMM leads across panel voltmeter terminals

- [2] Depress and hold **TEST** switch






FIG. 1

**DANGER 1**  
Voltages in this circuit are over 150 volts to ground

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	614



**CALIBRATE PANEL VOLTMETER**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	614

**SUMMARY**

See DANGER 1. Measure the output frequency at TB2 terminals 1 and 2 of operating **INVERTER**. Frequency should be between 59.7 and 60.3 Hz. Adjust R23 on A1 for 60 Hz.

- [1] Set frequency counter controls to measure 60 Hz

At TST frame **INVERTER**:

- [2] See DANGER 1. Connect frequency counter across TB2 terminals 1 and 2

- [3] Depress and hold **TEST** switch

AND

Page 2





FIG. 1

**CHECK AC OUTPUT FREQUENCY**

<b>DANGER 1</b> Voltages in this circuit are over 150 volts to ground	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	615



**DANGER 2**  
*Voltages in this circuit are over 150 volts to ground*

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	615


**CHECK AC OUTPUT FREQUENCY**

**SUMMARY**


See DANGER 1. Check input voltages at TB2 terminals 4 and 5. Indication should be 110 to 125 Vac

[1] Condition VOM to measure approximately 125 Vac

[2] See DANGER 1. Connect VOM to AC input TB2 terminals 4 and 5 [FIG. 1]



Yes



No





FIG. 1

**CHECK INVERTER AC INPUT VOLTAGE**

**DANGER 1**  
*Voltages in this circuit are over 150 volts to ground*

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	616

**SUMMARY**

Plug **ANNOUNCEMENT** machine and TTY into utility outlet.  
Remove fuses **P** and **ACL**. Set **ON-OFF** switch, **CB1**, and **CB2**  
to **OFF**. Remove fuse supplying power to **INVERTER**. Set  
**INVERTER** input circuit breaker to **OFF**

At **TST** frame:

[1] At back of **INVERTER**, plug  
TTY into utility outlet

[2] If equipped with 7A  
**ANNOUNCEMENT** machine,  
plug into utility outlet

[3] Below **INVERTER**, remove fuses  
**P** and **ACL**

On front panel of **INVERTER**:

[4] Set **ON-OFF** switch to **OFF**

[5] Set **CB1** and **CB2** to **OFF**

[6] At 151A **PWR PLANT**, on -48V  
discharge distribution panel,  
remove 30A **FRN TST INV** fuse supplying  
power to **INVERTER**

[7] At commercial AC input power  
panel, set **INVERTER** circuit  
breaker to **OFF** or remove fuse

**AND**

**REMOVE FROM SERVICE AND TURN DOWN KS-20816 L2 INVERTER**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	617

[1] See DANGER 1. Lift and carefully position 87-pound **INVERTER** in rack

[2] Insert and tighten 8 mounting bolts


[3] See CAUTION 1. Connect -48 volt direct current input cable to **TB1** terminals 1 and 2

[4] Connect 110 Vac input cable to **TB2** terminals 4 and 5

[5] Connect 110 Vac output cable to **TB6** terminals 1 through 6

[6] Connect transfer alarm cables to **TB4**

[7] Connect fail alarm cables to **TB5**



## INSTALL INVERTER IN RACK

<b>CAUTION 1</b> <i>Proper polarity should be observed when connecting dc input. Improper polarity will cause serious damage to INVERTER</i>	
<b>DANGER 1</b> <i>Provide equipment with sufficient capability to handle heavy INVERTER</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	618

[1] Label and disconnect -48 Vdc  
input cable from TB1  
terminals 1 and 2

[2] Label and disconnect 110 Vac  
**INVERTER** input cable from  
TB2 terminals 4 and 5


[3] Label and disconnect  
110 Vac **INVERTER**  
output cable from TB6  
terminals 1 through 6

[4] Label and disconnect transfer  
and **OUTPUT FAIL** alarm cable  
from TB4 and TB5

[5] Provide a means to  
support and move 87-pound  
weight of **INVERTER**

[6] Remove 8 mounting bolts

[7] Carefully remove **INVERTER**  
from rack



## REMOVE INVERTER FROM RACK

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	620

**SUMMARY**

Check the output of the 24-volt DC converter at the output voltage test jacks. Adjust the output voltage potentiometer if necessary.

[1] Condition DMM to measure approximately 100 Vdc

[2] See FIG. 1. Connect meter leads to (+)V OUT and (-)V OUT.







FIG. 1 - Top of Miscellaneous Power Frame

**CHECK/ADJUST 188A POWER UNIT (+24 VOLT CONVERTER) DC OUTPUT VOLTAGE**





TABLE A INPUT FUSES		
POWER UNIT	CONVERTER	FUSE
188A POWER UNIT 189A POWER UNIT	+24 CONVA(0)	1ABS0 1CV0
188A POWER UNIT 189A POWER UNIT	+24 CONVB(0)	2ABS0 2CV0
188A POWER UNIT 189A POWER UNIT	+24 CONVA(1)	1ABS1 1CV1
188A POWER UNIT 189A POWER UNIT	+24 CONVB(1)	2ABS1 2CV1
184A POWER UNIT	+48CONV(0)	D0
184A POWER UNIT	+48CONV(1)	D1
184B POWER UNIT	±130CONV(0)	C0
184B POWER UNIT	±130CONV(1)	C1

**REPLACE 184A, 184B, 188A, OR 189A POWER UNIT**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	689

[6] Install and firmly seat new **POWER UNIT**

[7] Insert input fuse



# REPLACE 184A, 184B, 188A, OR 189A POWER UNIT

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	689

**SUMMARY**

See CAUTION 1. Test the power alarm by increasing output voltage to 27.5 volts and decreasing output voltage to 23.5 volts to set power alarms of TABLE A.

- [1] At MP miscellaneous power frame, condition DMM to measure approximately 100 Vdc
- [2] See CAUTION 1. Connect DMM to (+)V OUT and (-)V OUT. See FIG. 1
- [3] Observe and note output voltage reading (24.7 volts)
- [4] With jewelers screwdriver slowly rotate V ADJ cw until ALM led lights or until meter indicates maximum 27.5 volts






FIG. 1 - Top of Miscellaneous Power Frame


TABLE A POWER ALARMS	
LOCATION	INDICATION
1. SSP	MINOR (amber) MINOR POWER (amber)
2. TTY	Message
3. Building	Minor audible



**CAUTION 1**  
Test converter power alarms only when normal service will not be affected.

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	691

**CHECK 188A POWER UNIT (+24 VOLT CONVERTER) POWER ALARM**





**CHECK 188A POWER UNIT (+24 VOLT CONVERTER) POWER ALARM**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	691

**SUMMARY**

See NOTE 1 and FIG. 1. Operate **ALM TEST** switch. **ALM** lamp on front panel lights and remains lighted until **ALM RESET** switch is operated.



**FIG. 1 - Top of Miscellaneous Power Frame**

<b>NOTE 1</b>	
This test does not operate TTY printout or remote alarms	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	693

**CHECK 188A POWER UNIT (+24 VOLT CONVERTER) NO POWER ALARM**

[1] Condition DMM to measure approximately 50 Vdc

[2] See DANGER 1, FIG. 1, and NOTE 1. On connector J5 at back of 184A POWER UNIT, connect DMM to terminal A(-) and F(+)





FIG. 1

**CHECK 184A POWER UNIT (+48V CONVERTER) OUTPUT**

<b>NOTE 1</b>	
Back of connector is lettered in fine print next to connecting pins	
<b>DANGER 1</b>	
<i>Voltages in this circuit are over 50 volts to ground</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	695


**SUMMARY**

Using fuse alarm test cord, check input and distribution fuse alarm circuitry of 184A POWER UNIT.

TABLE A INPUT FUSES	
CIRCUIT	DESIGNATION
0	D0
1	D1

[1] See FIG. 1. Install 720A voltage pickup tool at suitable spare -48 position

[2] See FIG. 2 and CAUTION 1. At fuse in TABLE A, for circuit out of service touch tip of 411C test pick to exposed test point on fuse cap



[4] Clear defective wiring and/or +48 FA alarm relay per SD-3H905-01

TABLE B FUSE ALARMS	
LOCATION	INDICATION
1. SSP	FUSE (red) MAJOR (red)
2. TTY	Message
3. Building	Audible, Major




FIG. 2 - Alarm Fuse Cap - Typical

<b>CAUTION 1</b> <i>Test fuses in circuit out of service only</i>	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 3	696




FIG. 1 - Top of Miscellaneous Power Frame

CHECK 184A POWER UNIT (+48 VOLT CONVERTER) FUSE ALARM



Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 3	696

[5] Remove test pick from fuse cap \_\_\_\_\_

[6] At SSP depress **ALARM RELEASE** pushbutton \_\_\_\_\_

[7] See FIG. 1. Move 720A voltage pickup tool to suitable spare +48V position \_\_\_\_\_

[8] See FIG. 2. At one fuse in TABLE C for circuit out of service, touch tip of 411C test pick to exposed test point on fuse cap \_\_\_\_\_



Yes

No



TABLE C DISTRIBUTION FUSES	
CIRCUIT	DESIGNATION
0	DF00 DF01 RTP0
1	DF10 DF11 RTP1

[11] Remove test pick from fuse cap \_\_\_\_\_

[12] At SSP depress **ALARM RELEASE** pushbutton \_\_\_\_\_

[13] Repeat Steps 8 through 12 for each additional fuse in TABLE C for side out of service \_\_\_\_\_

[14] Disconnect 720A tool from spare fuse position and install fuse cap \_\_\_\_\_

**CHECK 184A POWER UNIT (+48 VOLT CONVERTER) FUSE ALARM**

[1] Condition DMM to measure approximately 130 Vdc

[2] See DANGER 1 and FIG. 1. On connector J6 at back of 184B POWER UNIT, connect DMM to terminal D(+) and H(-)





FIG. 1

NOTE 1 Terminal H is a common return	
<b>DANGER 1</b> Voltages in this circuit are over 130 volts to ground	
Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	<b>698</b>

**CHECK 184B POWER UNIT ( $\pm 130V$  CONVERTER) OUTPUT**

**SUMMARY**

Using fuse alarm test cord, check input and distribution fuse alarm circuitry of 184B POWER UNIT.

[1] See FIG. 1. Install 720A voltage pickup tool at suitable spare -48 position

[2] See FIG. 2. At one fuse in TABLE A, touch tip of 411C test pick to exposed test point on fuse cap





FIG. 2 - Alarm Fuse Cap - Typical

TABLE A INPUT FUSES	
CIRCUIT	DESIGNATION
0	C0
1	C1

TABLE B FUSE ALARMS	
LOCATION	INDICATION
1. SSP	FUSE (red) MINOR (amber)
2. TTY	Message
3. Building	Audible, Minor

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 4	699




FIG. 1 - Top of Miscellaneous Power Frame

CHECK 184B POWER UNIT ( $\pm 130$  VOLT CONVERTER) FUSE ALARM

[5] Remove test pick from fuse cap and observe alarms retire

[6] At SSP depress **ALARM RELEASE** pushbutton

[7] Move 720A voltage pickup tool to suitable spare -48V position. See FIG. 1

[8] See FIG. 2. At one fuse in TABLE C, touch tip of 411C test pick to exposed test point on fuse cap

[11] Remove test pick from fuse cap and observe alarms retire

[12] At SSP depress **ALARM RELEASE** pushbutton

[13] Repeat Steps 8 through 12 for each additional fuse in TABLE C

[14] Disconnect 720A tool from spare fuse position and install fuse cap

AND

[9] Are TABLE B alarms given

Yes

No

[10] Clear defective wiring and/or FA alarm relay per SD-3H905-01

AND

Page 4


**TABLE C  
DISTRIBUTION FUSES**

CIRCUIT	DESIGNATION
0	+C1-0 +C2-0 +T1-0
1	+C1-1 +C2-1 +T1-1

Issue 2	JUL 1980
233-144-100	DLP
PAGE 3 of 4	699

[15] Connect 720A voltage pickup tool to suitable spare -48V position. See FIG. 1

[16] See FIG. 2. At one fuse in TABLE D, touch tip of 411C test pick to exposed test point on fuse cap



CIRCUIT	DESTINATION
0	-C1-0
	-C2-0
	-T1-0
	-F1-0
	-F2-0
1	-C1-1
	-C2-1
	-T1-1
	-F1-1
	-F2-1


**SUMMARY**

See DANGER 1. Adjust R3 on A2 for time delay of 30 to 50 seconds.

[1] See DANGER 1. Loosen fastener screws on upper front of cover. Pull cover forward and down

[2] Depress and hold TEST switch

[3] Release TEST switch and start timing



Page 2




FIG. 1


**DANGER 1**  
Voltages in this circuit are over 150 volts to ground

Issue 2 JUL 1980

233-144-100 DLP

PAGE 1 of 2 700

**ADJUST INVERTER AC RESTORAL TIME**



**ADJUST INVERTER AC RESTORAL TIME**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	700

**SUMMARY**

See WARNING 1 and FIG. 1. Depress **POWER ON-OFF** switch to **OFF** to turn off rectifier. Remove **RB** fuse and set circuit breaker on **EXTERNAL CHARGE CIRCUIT BREAKER/RECT** panel to **OFF**. Set **CB1** to **OFF** and depress **ALARM RELEASE** pushbutton.

[1] See FIG. 1. At 151A PWR PLANT on 48V rectifier meter panel, depress **POWER ON-OFF** switch to **OFF**

[2] See WARNING 1. On **CONTROL UNIT** remove **RB** fuse associated with rectifier



[3] On **EXTERNAL CHARGE CIRCUIT BREAKER/RECT** panel, set circuit breaker associated with rectifier to **OFF**

[4] On rectifier, set **CB1** to **OFF**

Major audible alarm sounds. **RECT FAIL** lamp lights

[5] At SSP panel depress **ALARM RELEASE** pushbutton

Major alarm is silenced. **RECT FAIL** lamp goes out



**FIG. 1**

**WARNING 1**  
*Rectifier circuit could be damaged when rectifier is turned on if RB fuse is installed and EXTERNAL CHARGE circuit breaker is set to OFF. When RB fuse is removed, rectifier may be turned on to operate in test mode*

Issue 2 | JUL 1980

233-144-100 | DLP

PAGE 1 of 1 | 701

**SUMMARY**

See NOTE 1. DMM connected across **OUTPUT VOLTS** test jacks indicates desired output level. Rotate **OUTPUT VOLTS ADJ** rheostat until DMM indicates desired output level.

[1] Condition DMM to measure approximately 100 Vdc

[2] See FIG. 1. At **48V RECTIFIER**, connect DMM across **OUTPUT VOLTS REG+** and **REG-** test jacks

[3] Depress **POWER ON-OFF** switch to **ON**

AND

[4] See NOTE 1. Does DMM indicate required charge bus voltage

Yes

No

[5] Can output **VOLTS ADJ** rheostat be adjusted to required charge bus voltage

Yes

No

TAP-237




FIG. 1


**NOTE 1**  
Charge voltage is determined by local requirements. Refer to office records for exact setting. In absence of local requirements, charge voltage is at a level that produces 52.08 Vdc measured at battery bus

**CHECK J87437A 48V RECTIFIER OUTPUT VOLTAGE**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	702


**SUMMARY**

Operate **RECT NL/FL** switch to **NL**. Voltage decreases 0.25 volt and current decreases. Operate **RECT NL/FL** switch to **FL**. Voltage increases 0.25 volt and current increases.



**CHECK ADJUSTMENT OF J87437A 48V RECTIFIER CURRENT LIMIT AND REGULATOR CIRCUIT**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	703



**CHECK ADJUSTMENT OF J87437A 48V RECTIFIER CURRENT LIMIT AND REGULATOR CIRCUIT**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	703

**SUMMARY**

See WARNING 1. Turn off rectifier. Install RB fuse. Charge rectifier output filter capacitors and set circuit breaker to ON. Turn on rectifier. Set CB1 to ON

At 151A PWR PLANT:

[1] On 48V RECTIFIER, depress POWER ON-OFF switch to turn off rectifier

[2] At CONTROL UNIT, install RB fuse associated with rectifier


LOCAL SNS lamp goes out

[3] See WARNING 1. Charge rectifier output filter capacitors and set external circuit breaker to ON [DLP-517]

[4] Depress POWER ON-OFF switch to turn on rectifier

TTY message REPT PWR B 16 a 000000 NORM is given

[5] After 10 seconds, set rectifier CB1 to ON




**WARNING 1**

*Do not turn circuit breaker to ON before charging the capacitors as damage to the circuit breaker may occur*

Issue 2 | JUL 1980

233-144-100 | DLP

PAGE 1 of 1 | 704



**REPLACE CIRCUIT PACK IN J87437A 48V RECTIFIER**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	705

**SUMMARY**

See WARNING 1, FIG. 1 and FIG. 2. Depress **POWER ON-POWER OFF** pushbutton to turn off rectifier. Remove RB fuse and set circuit breaker on **EXTERNAL CHARGE CIRCUIT BREAKER/RECT**

panel to **OFF**. See **DANGER 1**. Remove front panel on **48V RECTIFIER** and disconnect the plant control disconnect **J1**. Connect jumper between **DC OUTPUT** terminal and pin 15 of **P1**.

[1] See FIG. 1. At **151A PWR PLANT** on **48V RECTIFIER** meter panel, depress **POWER ON-POWER OFF** pushbutton


[2] See WARNING 1. On **CONTROL UNIT**, remove RB fuse associated with rectifier

[3] On **EXTERNAL CHARGE CIRCUIT BREAKER/RECT** panel, set circuit breaker associated with rectifier to **OFF**

[4] See **DANGER 1**. Remove front panel on **48V RECTIFIER**

[5] Disconnect the plant control disconnect **J1** from the rectifier

[6] See FIG. 2. Connect a **W1AP** jumper cord between **DC OUTPUT** output **BAT** terminal and pin 15 of **P1**



**WARNING 1**  
Rectifier circuit could be damaged when rectifier is turned on if RB fuse is installed and **EXTERNAL CHARGE** circuit breaker is set to **OFF**. When RB fuse is removed, rectifier may be turned on to operate in test mode

**DANGER 1**  
Extremely high current potentials present. Do not allow a test pick to touch two metal parts at the same time as dangerous and destructive short circuits may occur

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	710




FIG. 1




FIG. 2 - P1 Pin Location

PLACE ITT-NORTH KS-20493 48V RECTIFIER IN TEST MODE

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	710

**SUMMARY**

See NOTE 1. DMM connected across **OUTPUT VOLTS** test jacks indicates desired output level. Rotate **OUTPUT VOLTS ADJUST** rheostat until DMM indicates desired output level

[1] Condition DMM to measure approximately 100 Vdc

[2] At 151A PWR PLANT on 48V RECTIFIER [FIG. 1], Connect DMM across **OUTPUT VOLTS (+)** and **(-)** test jacks

[3] Depress **POWER ON-POWER OFF** pushbutton to turn on rectifier

**POWER ON and LOCAL SNS** lamps light

DMM connected across output

[4] See NOTE 1. Does DMM indicate required charge bus voltage

Yes

[5] Verify locking device is secure on **OUTPUT VOLTS ADJUST** rheostat

No

Page 2

[6] Disconnect DMM





FIG. 1

**NOTE 1**  
Charge voltage is determined by local requirements. Refer to office records for exact setting. In absence of local requirements, charge voltage is at a level that produces 52.08 Vdc measured at battery bus

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	711



**CHECK ITT-NORTH KS-20493 48V RECTIFIER OUTPUT VOLTAGE**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	711


[1] Condition DMM to measure approximately 100 Vdc

[2] At 151A PLANT on 48V RECTIFIER, connect DMM at CURRENT LIMIT (+) and (-) test jacks

[3] Verify SIMULATED OUTPUT CURRENT rheostat is rotated fully ccw

[4] Depress and hold SIMULATED OUTPUT CURRENT pushbutton

[5] See FIG. 1. Using jewelers screwdriver, rotate SIMULATED OUTPUT CURRENT rheostat slowly cw until DMM indication increased to greater than 0 volt



AND

Page 2





FIG. 1

# CHECK ITT-NORTH KS-20493 48V RECTIFIER CURRENT LIMITING ADJUSTMENT

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	712



**CHECK ITT-NORTH KS-20493 48V RECTIFIER CURRENT  
LIMITING ADJUSTMENT**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	712





FIG. 1 - P1 Pin Location

CHECK ITT-NORTH KS-20493 48V RECTIFIER TR SHUTDOWN

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	714

**SUMMARY**

Connect ground to pin 6 of P1 plug. Depress and hold **SIMULATED OUTPUT CURRENT** switch. Rotate the **SIMULATED OUTPUT CURRENT** rheostat cw. Release the **SIMULATED OUTPUT**

**CURRENT** switch. Disconnect the jumper. Depress the **POWER ON-POWER OFF** switch twice. Rotate **SIMULATED OUTPUT CURRENT** rheostat fully ccw.

[1] See FIG. 1. Using a WIAP jumper cord, connect ground to pin 6 of P1 plug

[2] Depress and hold the **SIMULATED OUTPUT CURRENT** switch

[3] Rotate the **SIMULATED OUTPUT CURRENT** rheostat cw

[4] Release the **SIMULATED OUTPUT CURRENT** switch

[5] Disconnect the jumper

[6] Depress the **POWER ON-POWER OFF** switch twice

[7] Rotate the **SIMULATED OUTPUT CURRENT** rheostat fully ccw





FIG. 1 - P1 Pin Location



CHECK ITT-NORTH KS-20493 48V RECTIFIER HV SHUTDOWN

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	715

**SUMMARY**

See WARNING 1. Depress and hold **SIMULATED OUTPUT CURRENT** switch. Rotate **SIMULATED OUTPUT CURRENT** rheostat until **OUTPUT CURRENT** meter indicates 10 amperes. Release **SIMULATED OUTPUT CURRENT** switch. Connect ground to pin 6

of P1. Depress and hold **SIMULATED OUTPUT CURRENT** switch. Release switch. Connect pin 4 and pin 5 of P1. Depress **SIMULATED OUTPUT CURRENT** switch. Temporarily remove jumper from pin 4 of P1; then replace. Remove jumpers from pin 6 to ground and pins 4 and 5.




**FIG. 1 - P1 Pin Location**

Page 2

**WARNING 1**  
*Make sure the EXTERNAL CHARGE CIRCUIT BREAKER is off before depressing the SIMULATED OUTPUT CURRENT switch*

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 2	716



CHECK ITT-NORTH KS-20493 48V RECTIFIER AUTOMATIC RESTART

Issue 2	JUL 1980
233-144-100	DLP
PAGE 2 of 2	716

**SUMMARY**

See WARNING 1. Turn off rectifier. Remove jumper. Connect J1. Install RB fuse. Charge rectifier output filter capacitors and set circuit breaker to ON. Turn on rectifier

**At 151A PWR PLANT:**

[1] On 48V RECTIFIER, depress **POWER ON-POWER OFF** pushbutton to turn off rectifier


[2] Disconnect jumper between **DC OUTPUT** and pin 15 of P1, then connect J1 to P1

[3] At **CONTROL UNIT**, install RB fuse associated with rectifier

[4] Install front panel on rectifier

[5] Charge rectifier output filter capacitors [DLP-517]

[6] Depress **POWER ON-POWER OFF** pushbutton to turn on rectifier




**WARNING 1**

*Do not turn circuit breaker to ON before charging the capacitors as damage to the circuit breaker may occur*

Issue 2 JUL 1980

233-144-100 DLP

PAGE 1 of 1 717



**REPLACE CIRCUIT PACK IN ITT-NORTH KS-20493 48V RECTIFIER**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	718

On 48V RECTIFIER

[1] Rotate **CURRENT LIMIT ADJUST**  
rheostat fully cw \_\_\_\_\_

[2] Rotate **SIMULATED OUTPUT CURRENT**  
rheostat fully cw \_\_\_\_\_


[3] Depress and hold **SIMULATED**  
**OUTPUT CURRENT** pushbutton \_\_\_\_\_

[4] Adjust **SIMULATED OUTPUT CURRENT**  
rheostat until rectifier **OUTPUT**  
**CURRENT** ammeter indicates 100  
amperes \_\_\_\_\_

[5] Rotate **CURRENT LIMIT ADJUST** rheostat  
slowly ccw until DMM indicates an  
increasing voltage (greater than 0  
volt) \_\_\_\_\_

[6] Release **SIMULATED OUTPUT CURRENT**  
pushbutton \_\_\_\_\_

[7] Rotate **SIMULATED OUTPUT CURRENT**  
rheostat fully ccw \_\_\_\_\_



ADJUST ITT-NORTH KS-20493 48V RECTIFIER CURRENT LIMIT CIRCUIT

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	719





FIG. 1

**CAUTION 1**  
*The test meter must be isolated from ground to prevent equipment damage during testing. If meter is battery powered and not connected to ac power, the meter is isolated, and no additional isolation is required. If the meter is ac powered, this procedure must be followed*

**ISOLATE AC OPERATED MULTIMETER**

Issue 2	JUL 1980
233-144-100	DLP
PAGE 1 of 1	720

+48 VOLT INPUT VOLTAGE - SIDE 1 ... MEASURE -48 VOLT AND	541
+48 VOLT INPUT VOLTAGES - SIDE 0 ... MEASURE -48 VOLT AND	551
- NO. 3 ESS POWER EQUIPMENT ... COMPANY ORDER TASK LIST	050
-48 VOLT AND +48 VOLT INPUT VOLTAGE - SIDE 1 ... MEASURE	541
-48 VOLT AND +48 VOLT INPUT VOLTAGES - SIDE 0 ... MEASURE	551
-48V BATTERY EQUIPMENT ... MAINTAIN	009
151A POWER PLANT ... CHECK OUTPUT OF	006
151A POWER PLANT FUSE ALARMS ... CHECK	506
151A POWER PLANT HIGH VOLTAGE (HVM) SHUTDOWN CIRCUIT ... CHECK	508
151A POWER PLANT LOW VOLTAGE (LV1 AND LV2) MONITORS ... CHECK	509
151A POWER PLANT VOLTMETER ... CALIBRATE	505
184A POWER UNIT (+48 VOLT CONVERTER) FUSE ALARM ... CHECK	696
184A POWER UNIT (+48V CONVERTER) OUTPUT ... CHECK	695
184A, 184B, 188A, OR 189A POWER UNIT ... REPLACE	689
184B POWER UNIT ( $\pm 130$ VOLT CONVERTER) FUSE ALARM ... CHECK	699
184B POWER UNIT ( $\pm 130$ V CONVERTER) OUTPUT ... CHECK	698
188A POWER UNIT (+24 VOLT CONVERTER) DC OUTPUT VOLTAGE ... CHECK/ADJUST	687

188A POWER UNIT (+24 VOLT CONVERTER) NO POWER ALARM ... CHECK	693
188A POWER UNIT (+24 VOLT CONVERTER) POWER ALARM ... CHECK	691
20-HZ INVERTER - SIDE 0 ... CHECK	555
20-HZ INVERTER - SIDE 1 ... CHECK	545
20-HZ PULSE GENERATOR ... CLEAR TROUBLE IN	194
20-HZ PULSE GENERATOR ... REPLACE	569
400A TONE GENERATOR ... CHECK AND ADJUST	560
400A TONE GENERATOR ... REPLACE	570
48-VOLT BATTERY DISTRIBUTION FUSE ALARMS - SIDE 0 ... TEST	556
48-VOLT BATTERY DISTRIBUTION FUSE ALARMS - SIDE 1 ... TEST	546
48-VOLT FUSE ALARM CIRCUIT ... CLEAR TROUBLE IN	195
48V RECTIFIER CURRENT LIMIT CIRCUIT ... ADJUST	512
48V RECTIFIER CURRENT LIMIT CIRCUIT ... CLEAR TROUBLE IN	202
48V RECTIFIER OUTPUT CAPACITOR CHARGE CIRCUIT ... CLEAR TROUBLE IN	209
48V RECTIFIER OUTPUT FILTER CAPACITORS ... CHARGE	517
48V RECTIFIER POWER DIODES (CR1 AND CR2) ... CHECK	515
881A RINGING AND TONE PLANT ... CHECK SIDE 0 -	007
881A RINGING AND TONE PLANT ... CHECK SIDE 1 -	008
881A RINGING AND TONE PLANT ... ACCEPT	033
AC OUTPUT FREQUENCY ... CHECK	615

AC OUTPUT VOLTAGE ... CHECK . . . . .	613
ACCEPT 881A RINGING AND TONE PLANT . . . . .	033
ACCEPT ITT-NORTH KS-20493 48V RECTIFIER . . . . .	036
ACCEPT J87437A 48V RECTIFIER . . . . .	038
ACCEPT KS-20472 BATTERY . . . . .	035
ACCEPT KS-20816 L2 INVERTER . . . . .	034
ACCEPT LORAIN KS-20493 48V RECTIFIER . . . . .	037
ACCEPT MISCELLANEOUS POWER UNITS . . . . .	032
ACCEPTANCE TASK LIST - NO. 3 ESS POWER EQUIPMENT . . . . .	030
ADJUST 400A TONE GENERATOR ... CHECK AND . . . . .	560
ADJUST 48V RECTIFIER CURRENT LIMIT CIRCUIT . . . . .	512
ADJUST BATTERY BUS VOLTAGE AND RECTIFIER OUTPUT CURRENT . . . . .	530
ADJUST HV MONITOR TO DECREASE SHUTDOWN LEVEL . . . . .	528
ADJUST HV MONITOR TO INCREASE SHUTDOWN LEVEL . . . . .	527
ADJUST INVERTER AC RESTORAL TIME . . . . .	700
ADJUST ITT-NORTH KS-20493 48V RECTIFIER CURRENT LIMIT CIRCUIT . . . . .	719
ADJUST LOW VOLTAGE MONITOR . . . . .	564
ADJUST LV1 PLANT VOLTAGE MONITOR . . . . .	525
ADJUST LV2 PLANT VOLTAGE MONITOR . . . . .	526
ADJUST OSCILLATOR VOLTAGE LEVEL . . . . .	562
ADJUST TONE AMPLIFIER TO NORMAL VOLTAGE LEVEL . . . . .	565
ADJUST TONE AMPLIFIER TO TEST VOLTAGE LEVEL . . . . .	563
ANALYZE TTY TROUBLE MESSAGE FOR RINGING AND TONE PLANT . . . . .	198

BATTERY BUS VOLTAGE AND 48V RECTIFIER OUTPUT CURRENT ... CHECK . . . . .	504
BATTERY BUS VOLTAGE AND RECTIFIER OUTPUT CURRENT ... ADJUST . . . . .	530
BATTERY JARS ... CLEAN . . . . .	581
BATTERY TERMINALS AND CONNECTORS ... MAINTAIN . . . . .	577
BLOWN FUSE ... CLEAR . . . . .	197
BLOWN FUSE ... REPLACE . . . . .	567
CALIBRATE 151A POWER PLANT VOLTMETER . . . . .	505
CALIBRATE PANEL VOLTMETER . . . . .	614
CHARGE 48V RECTIFIER OUTPUT FILTER CAPACITORS . . . . .	517
CHECK 151A POWER PLANT FUSE ALARMS . . . . .	506
CHECK 151A POWER PLANT HIGH VOLTAGE (HVM) SHUTDOWN CIRCUIT . . . . .	508
CHECK 151A POWER PLANT LOW VOLTAGE (LV1 AND LV2) MONITORS . . . . .	509
CHECK 184A POWER UNIT (+48 VOLT CONVERTER) FUSE ALARM . . . . .	696
CHECK 184A POWER UNIT (+48V CONVERTER) OUTPUT . . . . .	695
CHECK 184B POWER UNIT ( $\pm$ 130 VOLT CONVERTER) FUSE ALARM . . . . .	699
CHECK 184B POWER UNIT ( $\pm$ 130V CONVERTER) OUTPUT . . . . .	698
CHECK 188A POWER UNIT (+24 VOLT CONVERTER) NO POWER ALARM . . . . .	693
CHECK 188A POWER UNIT (+24 VOLT CONVERTER) POWER ALARM . . . . .	691
CHECK 20-HZ INVERTER - SIDE 0 . . . . .	555
CHECK 20-HZ INVERTER - SIDE 1 . . . . .	545
CHECK 48V RECTIFIER POWER DIODES (CR1 AND CR2) . . . . .	515

**INDEX**

Issue 2	JUL 1980
233-144-100	IXL
PAGE 2 of 8	890

CHECK AC OUTPUT FREQUENCY . . . . .	615
CHECK AC OUTPUT VOLTAGE . . . . .	613
CHECK ADJUSTMENT OF J87437A 48V RECTIFIER CURRENT LIMIT AND REGULATOR CIRCUIT . . . . .	703
CHECK AND ADJUST 400A TONE GENERATOR . . . . .	560
CHECK BATTERY BUS VOLTAGE AND 48V RECTIFIER OUTPUT CURRENT . . . . .	504
CHECK COMPONENTS OF INVERTER PROVIDING POWER TO A1 . . . . .	234
CHECK DC INPUT VOLTAGE . . . . .	612
CHECK ELECTROLYTE TEMPERATURE . . . . .	578
CHECK INVERTER AC INPUT VOLTAGE . . . . .	616
CHECK INVERTER TRANSFER AND ALARM CIRCUITS . . . . .	610
CHECK ITT-NORTH KS-20493 48V RECTIFIER . . . . .	011
CHECK ITT-NORTH KS-20493 48V RECTIFIER AUTOMATIC RESTART . . . . .	716
CHECK ITT-NORTH KS-20493 48V RECTIFIER CURRENT LIMITING ADJUSTMENT . . . . .	712
CHECK ITT-NORTH KS-20493 48V RECTIFIER HV SHUTDOWN . . . . .	715
CHECK ITT-NORTH KS-20493 48V RECTIFIER OUTPUT VOLTAGE . . . . .	711
CHECK ITT-NORTH KS-20493 48V RECTIFIER TR SHUTDOWN . . . . .	714
CHECK J87437A 48V RECTIFIER . . . . .	013
CHECK J87437A 48V RECTIFIER OUTPUT VOLTAGE . . . . .	702
CHECK KS-20816 L2 INVERTER . . . . .	002
CHECK LORAIN KS-20493 48V RECTIFIER . . . . .	012
CHECK LORAIN KS-20493 48V RECTIFIER OUTPUT VOLTAGE . . . . .	501

CHECK LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER FAILURE ALARMS . . . . .	507
CHECK MISCELLANEOUS POWER UNITS . . . . .	003
CHECK OUTPUT FILTER CAPACITOR BANK . . . . .	516
CHECK OUTPUT OF 151A POWER PLANT . . . . .	006
CHECK SIDE 0 - 881A RINGING AND TONE PLANT . . . . .	007
CHECK SIDE 1 - 881A RINGING AND TONE PLANT . . . . .	008
CHECK THYRISTOR DRIVER CIRCUIT PACK A1 . . . . .	233
CHECK TONE AMPLIFIERS - SIDE 0 . . . . .	553
CHECK TONE AMPLIFIERS - SIDE 1 . . . . .	543
CHECK TONE OSCILLATORS - SIDE 0 . . . . .	552
CHECK TONE OSCILLATORS - SIDE 1 . . . . .	542
CHECK/ADJUST 188A POWER UNIT (+24 VOLT CONVERTER) DC OUTPUT VOLTAGE . . . . .	687
CIRCUIT PACK ... REPLACE . . . . .	566
CLEAN BATTERY JARS . . . . .	581
CLEAN RACKS AND STANDS . . . . .	580
CLEAR BLOWN FUSE . . . . .	197
CLEAR DEFECTIVE LORAIN 48V RECTIFIER CIRCUIT PACK . . . . .	201
CLEAR INOPERATIVE INVERTER RUN LAMP . . . . .	181
CLEAR ITT-NORTH KS-20493 48V RECTIFIER AUTOMATIC RESTART TROUBLE . . . . .	240
CLEAR ITT-NORTH KS-20493 48V RECTIFIER HV SHUTDOWN TROUBLE . . . . .	239

CLEAR ITT-NORTH KS-20493 48V RECTIFIER TR SHUTDOWN TROUBLE . . . . .	238
CLEAR J87497A 48V RECTIFIER OUTPUT VOLTAGE ADJUSTMENT TROUBLE . . . . .	237
CLEAR POWER UNIT FUSE CONDITION . . . . .	232
CLEAR POWER UNIT NO-OUTPUT CONDITION . . . . .	230
CLEAR STORAGE BATTERY TROUBLE . . . . .	134
CLEAR TONE FAULT . . . . .	199
CLEAR TONE OSCILLATOR TROUBLE . . . . .	191
CLEAR TROUBLE - SYSTEM CONTROL WILL NOT REMOVE SIDE OF PLANT FROM SERVICE . . . . .	190
CLEAR TROUBLE - TONE AMPLIFIER AND LOW VOLTAGE MONITOR CIRCUIT . . . . .	193
CLEAR TROUBLE IN 20-HZ PULSE GENERATOR . . . . .	194
CLEAR TROUBLE IN 48-VOLT FUSE ALARM CIRCUIT . . . . .	195
CLEAR TROUBLE IN 48V RECTIFIER CURRENT LIMIT CIRCUIT . . . . .	202
CLEAR TROUBLE IN 48V RECTIFIER OUTPUT CAPACITOR CHARGE CIRCUIT . . . . .	209
CLEAR TROUBLE IN HV MONITOR - SHUTDOWN LEVEL HIGH . . . . .	204
CLEAR TROUBLE IN HV MONITOR - SHUTDOWN LEVEL LOW . . . . .	203
CLEAR TROUBLE IN INVERTER -48 VOLT DC CIRCUIT . . . . .	183
CLEAR TROUBLE IN INVERTER AC OUTPUT . . . . .	180
CLEAR TROUBLE IN INVERTER AC TIMER CIRCUIT PACK A2 . . . . .	184
CLEAR TROUBLE IN INVERTER INPUT CAPACITOR CIRCUIT PACK A2 . . . . .	231
CLEAR TROUBLE IN INVERTER OUTPUT FAIL ALARM CIRCUIT . . . . .	185

CLEAR TROUBLE IN INVERTER THYRISTOR CIRCUIT PACK A1 . . . . .	236
CLEAR TROUBLE IN INVERTER TRANSFER ALARM CIRCUIT . . . . .	182
CLEAR TROUBLE IN ITT-NORTH KS-20493 48V RECTIFIER CURRENT LIMIT CIRCUIT . . . . .	241
CLEAR TROUBLE IN LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER FAILURE (RF) CIRCUIT . . . . .	215
CLEAR TROUBLE IN LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER MINOR ALARM CIRCUIT . . . . .	210
CLEAR TROUBLE IN LOW VOLTAGE (LV1 AND LV2) MONITORS . . . . .	205
CLEAR TROUBLE- SYSTEM CONTROL WILL NOT RESTORE PLANT TO SERVICE . . . . .	196
COMPANY ORDER TASK LIST - NO. 3 ESS POWER EQUIPMENT . . . . .	050
CONDITION OSCILLOSCOPE . . . . .	518
CURRENT LIMIT CIRCUIT ... ADJUST ITT-NORTH KS-20493 48V RECTIFIER . . . . .	719
CURRENT LIMIT CIRCUIT ... TEST LORAIN KS-20493 48V RECTIFIER . . . . .	502
CURRENT LIMITING ADJUSTMENT ... CHECK ITT-NORTH KS-20493 48V RECTIFIER . . . . .	712
DC INPUT VOLTAGE ... CHECK . . . . .	612
ELECTROLYTE LEVEL ... MAINTAIN . . . . .	579
ELECTROLYTE TEMPERATURE ... CHECK . . . . .	578
FUSE ALARM TEST CORD ... PREPARE . . . . .	513
FUSE ALARMS - SIDE 0 ... TEST 48-VOLT BATTERY DISTRIBUTION . . . . .	556
FUSE ALARMS - SIDE 1 ... TEST 48-VOLT BATTERY DISTRIBUTION . . . . .	546
HV MONITOR - SHUTDOWN LEVEL HIGH ... CLEAR TROUBLE IN . . . . .	204

**INDEX**

Issue 2	JUL 1980
233-144-100	IXL
PAGE 4 of 8	890

HV MONITOR - SHUTDOWN LEVEL LOW ... CLEAR TROUBLE IN . . . . .	203
HV MONITOR TO DECREASE SHUTDOWN LEVEL ... ADJUST . . . . .	528
(HVM) SHUTDOWN CIRCUIT ... CHECK 151A POWER PLANT HIGH VOLTAGE . . . . .	508
INDIVIDUAL CELL VOLTAGE ... MEASURE . . . . .	576
INSPECT INDIVIDUAL CELLS FOR CRYSTALS . . . . .	575
INSTALL INVERTER IN RACK . . . . .	618
INSTALL MP 0 OR MP 1 FUSE . . . . .	568
INVERTER -48 VOLT DC CIRCUIT ... CLEAR TROUBLE IN . . . . .	183
INVERTER AC INPUT VOLTAGE ... CHECK . . . . .	616
INVERTER AC OUTPUT ... CLEAR TROUBLE IN . . . . .	180
INVERTER AC RESTORAL TIME ... ADJUST . . . . .	700
INVERTER AC TIMER CIRCUIT PACK A2 ... CLEAR TROUBLE IN . . . . .	184
INVERTER FROM RACK ... REMOVE . . . . .	620
INVERTER IN RACK ... INSTALL . . . . .	618
INVERTER INPUT CAPACITOR CIRCUIT PACK A2 ... CLEAR TROUBLE IN . . . . .	231
INVERTER OUTPUT FAIL ALARM CIRCUIT ... CLEAR TROUBLE IN . . . . .	185
INVERTER PROVIDING POWER TO A1 ... CHECK COMPONENTS OF . . . . .	234
INVERTER RUN LAMP ... CLEAR INOPERATIVE . . . . .	181
INVERTER THYRISTOR CIRCUIT PACK A1 ... CLEAR TROUBLE IN . . . . .	236
INVERTER TRANSFER ALARM CIRCUIT ... CLEAR TROUBLE IN . . . . .	182
INVERTER TRANSFER AND ALARM CIRCUITS ... CHECK . . . . .	610
ISOLATE AC OPERATED MULTIMETER . . . . .	720

ITT-NORTH KS-20493 48V RECTIFIER ... ACCEPT . . . . .	036
ITT-NORTH KS-20493 48V RECTIFIER AUTOMATIC RESTART ... CHECK . . . . .	716
ITT-NORTH KS-20493 48V RECTIFIER AUTOMATIC RESTART TROUBLE ... CLEAR . . . . .	240
ITT-NORTH KS-20493 48V RECTIFIER ... CHECK . . . . .	011
ITT-NORTH KS-20493 48V RECTIFIER CURRENT LIMIT CIRCUIT ... ADJUST . . . . .	719
ITT-NORTH KS-20493 48V RECTIFIER CURRENT LIMITING ADJUSTMENT ... CHECK . . . . .	712
ITT-NORTH KS-20493 48V RECTIFIER HV SHUTDOWN ... CHECK . . . . .	715
ITT-NORTH KS-20493 48V RECTIFIER HV SHUTDOWN TROUBLE ... CLEAR . . . . .	239
ITT-NORTH KS-20493 48V RECTIFIER IN TEST MODE ... PLACE . . . . .	710
ITT-NORTH KS-20493 48V RECTIFIER ... POWER UP INDIVIDUAL . . . . .	717
ITT-NORTH KS-20493 48V RECTIFIER TR SHUTDOWN ... CHECK . . . . .	714
ITT-NORTH KS-20493 48V RECTIFIER TR SHUTDOWN TROUBLE ... CLEAR . . . . .	238
J87437A 48V RECTIFIER ... ACCEPT . . . . .	038
J87437A 48V RECTIFIER ... CHECK . . . . .	013
J87437A 48V RECTIFIER CURRENT LIMIT AND REGULATOR CIRCUIT ... CHECK ADJUSTMENT OF . . . . .	703
J87437A 48V RECTIFIER OUTPUT VOLTAGE ADJUSTMENT TROUBLE ... CLEAR . . . . .	237
J87437A 48V RECTIFIER OUTPUT VOLTAGE ... CHECK . . . . .	702
J87437A 48V RECTIFIER ... POWER DOWN INDIVIDUAL . . . . .	701
J87437A 48V RECTIFIER ... POWER UP INDIVIDUAL . . . . .	704

**INDEX**

KS-20472 BATTERY ... ACCEPT . . . . .	035
KS-20816 L2 INVERTER ... ACCEPT . . . . .	034
KS-20816 L2 INVERTER ... CHECK . . . . .	002
KS-20816 L2 INVERTER ... REMOVE FROM SERVICE AND TURN DOWN . . . . .	617
KS-20816 L2 INVERTER TO SERVICE ... RESTORE . . . . .	611
LORAIN 48V RECTIFIER CIRCUIT PACK ... CLEAR DEFECTIVE . . . . .	201
LORAIN 48V RECTIFIER CIRCUIT PACK ... REPLACE . . . . .	511
LORAIN KS-20493 48V RECTIFIER ... ACCEPT . . . . .	037
LORAIN KS-20493 48V RECTIFIER ... CHECK . . . . .	012
LORAIN KS-20493 48V RECTIFIER CURRENT LIMIT CIRCUIT ... TEST . . . . .	502
LORAIN KS-20493 48V RECTIFIER ... POWER DOWN INDIVIDUAL . . . . .	500
LORAIN KS-20493 48V RECTIFIER ... POWER UP INDIVIDUAL . . . . .	503
LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER FAILURE ALARMS ... CHECK . . . . .	507
LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER FAILURE (RF) CIRCUIT ... CLEAR TROUBLE IN . . . . .	215
LORAIN OR ITT-NORTH KS-20493 48V RECTIFIER MINOR ALARM CIRCUIT ... CLEAR TROUBLE IN . . . . .	210
LORAIN RECTIFIER CONTROL CIRCUIT . . . . .	200
LOW VOLTAGE (LV1 AND LV2) MONITORS ... CLEAR TROUBLE IN . . . . .	205
LOW VOLTAGE MONITOR ... ADJUST . . . . .	564
LOW VOLTAGE MONITORS - SIDE 0 ... TEST . . . . .	554
LOW VOLTAGE MONITORS - SIDE 1 ... TEST . . . . .	544

(LV1 AND LV2) MONITORS ... CHECK 151A POWER PLANT LOW VOLTAGE . . . . .	509
LV1 PLANT VOLTAGE MONITOR ... ADJUST . . . . .	525
LV2 PLANT VOLTAGE MONITOR ... ADJUST . . . . .	526
MAINTAIN -48V BATTERY EQUIPMENT . . . . .	009
MAINTAIN BATTERY TERMINALS AND CONNECTORS . . . . .	577
MAINTAIN ELECTROLYTE LEVEL . . . . .	579
MEASURE -48 VOLT AND +48 VOLT INPUT VOLTAGE - SIDE 1 . . . . .	541
MEASURE -48 VOLT AND +48 VOLT INPUT VOLTAGES - SIDE 0 . . . . .	551
MEASURE INDIVIDUAL CELL VOLTAGE . . . . .	576
MISCELLANEOUS POWER UNITS ... ACCEPT . . . . .	032
MISCELLANEOUS POWER UNITS ... CHECK . . . . .	003
MONITOR TO INCREASE SHUTDOWN LEVEL ... ADJUST HV . . . . .	527
MP 1 FUSE ... INSTALL MP 0 OR . . . . .	568
MP 0 OR MP 1 FUSE ... INSTALL . . . . .	568
NO. 3 ESS POWER EQUIPMENT ... ACCEPTANCE TASK LIST - . . . . .	030
NO. 3 ESS POWER EQUIPMENT ... ROUTINE TASK LIST . . . . .	001
OSCILLATOR VOLTAGE LEVEL ... ADJUST . . . . .	562
OSCILLOSCOPE ... CONDITION . . . . .	518
OUTPUT FILTER CAPACITOR BANK ... CHECK . . . . .	516
OUTPUT VOLTAGE ... CHECK ITT-NORTH KS-20493 48V RECTIFIER . . . . .	711
OUTPUT VOLTAGE ... CHECK J87437A 48V RECTIFIER . . . . .	702
OUTPUT VOLTAGE ... CHECK LORAIN KS-20493 48V RECTIFIER . . . . .	501

**INDEX**

Issue 2	JUL 1980
233-144-100	IXL
PAGE 6 of 8	890

PANEL VOLTMETER ... CALIBRATE . . . . .	614
PLACE ITT-NORTH KS-20493 48V RECTIFIER IN TEST MODE . . . . .	710
POWER DOWN INDIVIDUAL J87437A 48V RECTIFIER . . . . .	701
POWER DOWN INDIVIDUAL LORAIN KS-20493 48V RECTIFIER . . . . .	500
POWER UNIT FUSE CONDITION ... CLEAR . . . . .	232
POWER UNIT NO-OUTPUT CONDITION ... CLEAR . . . . .	230
POWER UP INDIVIDUAL ITT-NORTH KS-20493 48V RECTIFIER . . . . .	717
POWER UP INDIVIDUAL J87437A 48V RECTIFIER . . . . .	704
POWER UP INDIVIDUAL LORAIN KS-20493 48V RECTIFIER . . . . .	503
PREPARE FUSE ALARM TEST CORD . . . . .	513
RACKS AND STANDS ... CLEAN . . . . .	580
RECTIFIER OUTPUT CURRENT ... ADJUST BATTERY BUS VOLTAGE AND . . . . .	530
REGULATOR CIRCUIT ... CHECK ADJUSTMENT OF J87437A 48V RECTIFIER CURRENT LIMIT AND . . . . .	703
REMOVE FROM SERVICE AND TURN DOWN KS-20816 L2 INVERTER . . . . .	617
REMOVE INVERTER FROM RACK . . . . .	620
REMOVE RT SIDE 0 FROM SERVICE . . . . .	550
REMOVE RT SIDE 1 FROM SERVICE . . . . .	540
REPLACE 184A, 184B, 188A, OR 189A POWER UNIT . . . . .	689
REPLACE 20-HZ PULSE GENERATOR . . . . .	569
REPLACE 400A TONE GENERATOR . . . . .	570
REPLACE BLOWN FUSE . . . . .	567
REPLACE CIRCUIT PACK . . . . .	566

REPLACE CIRCUIT PACK IN ITT-NORTH KS-20493 48V RECTIFIER . . . . .	718
REPLACE CIRCUIT PACK IN J87437A 48V RECTIFIER . . . . .	705
REPLACE LORAIN 48V RECTIFIER CIRCUIT PACK . . . . .	511
RESTORE KS-20816 L2 INVERTER TO SERVICE . . . . .	611
RESTORE TO SERVICE RT SIDE 0 ... TURN UP AND . . . . .	557
RESTORE TO SERVICE RT SIDE 1 ... TURN UP AND . . . . .	547
RINGING AND TONE PLANT ... ANALYZE TTY TROUBLE MESSAGE FOR . . . . .	198
RINGING DISTRIBUTION FUSE ALARMS ... TEST . . . . .	561
ROUTINE TASK LIST NO. 3 ESS POWER EQUIPMENT . . . . .	001
RT SIDE 0 FROM SERVICE ... REMOVE . . . . .	550
RT SIDE 0 ... TURN UP AND RESTORE TO SERVICE . . . . .	557
RT SIDE 1 FROM SERVICE ... REMOVE . . . . .	540
STORAGE BATTERY TROUBLE ... CLEAR . . . . .	134
SYSTEM CONTROL WILL NOT REMOVE SIDE OF PLANT FROM SERVICE ... CLEAR TROUBLE - . . . . .	190
SYSTEM CONTROL WILL NOT RESTORE PLANT TO SERVICE ... CLEAR TROUBLE- . . . . .	196
TEST 48-VOLT BATTERY DISTRIBUTION FUSE ALARMS - SIDE 0 . . . . .	556
TEST 48-VOLT BATTERY DISTRIBUTION FUSE ALARMS - SIDE 1 . . . . .	546
TEST LORAIN KS-20493 48V RECTIFIER CURRENT LIMIT CIRCUIT . . . . .	502
TEST LOW VOLTAGE MONITORS - SIDE 0 . . . . .	554
TEST LOW VOLTAGE MONITORS - SIDE 1 . . . . .	544
TEST RINGING DISTRIBUTION FUSE ALARMS . . . . .	561

**INDEX**


Issue 2	JUL 1980
233-144-100	IXL
PAGE 7 of 8	890

THYRISTOR DRIVER CIRCUIT PACK A1 ... CHECK . . . . .	233
TONE AMPLIFIER AND LOW VOLTAGE MONITOR CIRCUIT ... CLEAR TROUBLE - . . . . .	193
TONE AMPLIFIER TO NORMAL VOLTAGE LEVEL ... ADJUST . . . . .	565
TONE AMPLIFIER TO TEST VOLTAGE LEVEL ... ADJUST . . . . .	563
TONE AMPLIFIERS - SIDE 0 ... CHECK . . . . .	553
TONE AMPLIFIERS - SIDE 1 ... CHECK . . . . .	543
TONE FAULT ... CLEAR . . . . .	199

TONE GENERATION . . . . .	192
TONE OSCILLATOR TROUBLE ... CLEAR . . . . .	191
TONE OSCILLATORS - SIDE 0 ... CHECK . . . . .	552
TONE OSCILLATORS - SIDE 1 ... CHECK . . . . .	542
TTY TROUBLE MESSAGE FOR RINGING AND TONE PLANT ... ANALYZE . . . . .	198
TURN UP AND RESTORE TO SERVICE RT SIDE 0 . . . . .	557
TURN UP AND RESTORE TO SERVICE RT SIDE 1 . . . . .	547

**INDEX**

Issue 2	JUL 1980
233-144-100	IXL
PAGE 8 of 8	<b>890</b>




**WARNING**  
*Always be safety  
 conscious on  
 and off the job*


*This is a . . . . .*

# TASK ORIENTED PRACTICE..... or TOP

*The next few pages will tell  
 you how to use this document.*



[DLP-540]



Page 2

## HOW TO USE THIS "TOP"

This book is called a Task Oriented Practice or a "TOP." It is a type of programmed document – one which gives you step-by-step instructions of how to do a job (or task). A TOP can be a big help in your everyday work, but you must know how to use it correctly. Take a few minutes, say 15 or 20, and study these few pages until you feel you understand how to use a TOP. Taking this time now will very likely save you time and effort later on.

An important thing to remember about TOP is that it contains all the needed instructions to complete a job. If you are doing the job for the first time, you will be directed through each action without having to guess or remember where to find the necessary information. If you are experienced on a particular job, TOP can provide just that information which you may have forgotten.

Almost all of your jobs can be classified into one of four types – *Routine*, *Acceptance*, *Company Order*, or *Trouble Clearing*. This is how TOP defines these four work types:

### *Routine*

that work you do as part of a Controlled Maintenance Plan like scheduled cleaning or scheduled tests. Routine work may also include those things you do as a "routine" part of your job like requesting a TTY printout or turning on equipment in the mornings and off in the evenings.

### *Acceptance*

that work you do to verify that equipment is installed properly. Normally this is a test or inspection you perform when Western Electric has completed a new installation or addition. It could also be a test you perform when another group from *your* Company has completed

an installation or addition of equipment. Acceptance work, however, is always related to testing or checking newly installed equipment.

### *Company Order*

that work you do in response to one of several different "orders" which may be given to you. Some of the orders you may be familiar with are Circuit Orders, Service Orders, Traffic Orders, Recent Change Orders, etc. Normally, company order type work is something done to install, establish, change, or discontinue some service offered by the telephone company.

### *Trouble Clearing*

is simply what it says – that work you do to clear and repair troubles in the system. Trouble clearing may be done in answering a customer complaint, responding to some office alarm, an abnormal TTY printout, etc.

Try to fix these four work types firmly in your mind. As you will see, you must classify each job you get in one of these four types before you will be able to look up the instructions in the TOP.

Now glance briefly at the front cover; there are several things which will be useful there. In the upper-right corner is the 9-digit volume number. Near the center is the volume title which tells you something about the contents – such things as the system (or subsystem) name and perhaps the type of jobs included in the volume. Next is a four-line index located in the lower-left corner. This index provides the location of four "lists" which are simply a listing of all the jobs in each of the four job types. If a nine-digit (XXX-XXX-XXX) number appears on

the front cover index, that particular list is located in another volume of the TOP. A three-digit number on the line means that the list is in this volume, and the list can be located by searching the lower-right corner of each page for the referenced number.

Issue 1	APR 1976
XXX-XXX-XXX	COL
PAGE 1 of 2	050

These numbers will always be arranged in numerical order; however, all numbers in the sequence will not be used.

Some TOP volumes may cover only a small part of a system, so on the inside of each front cover you will find a documentation plan. This plan will give a bird's-eye view of all the volumes in the TOP and can help you quickly determine the correct volume.

Locate one of the TOP volumes which contains a Company Order List, and note from the front cover that this list is numbered "050." Turn to that number in the TOP.

This Company Order List (COL) is simply a listing of all the Circuit Order jobs, Service Order jobs, etc, that may be done on this system. Once you know the job you have to do, use the lists as an index to find the number of the "procedure" which tells you *what to do* to complete that job.

Now pick one of these jobs from the list which references to a COP (Company Order Procedure), and using the referenced number, locate that procedure in the TOP. Look over this procedure and note that it gives all the items which must be done to complete the job.

The items are numbered and must be completed in that order; however, you may see some lettered (A, B, C...) items in the procedure. These letters are assigned to options or other items which may be done differently because of equipment variations, etc. Look over the following example to get a better idea of what is meant by the numbers (1, 2, 3...) and letters (A, B, C...) which may be used in the procedure.

ITEM	SUBTASKS	PROCEDURE NUMBER
1	Do the first thing first	DLP-XXX
2	Do the second item next	DLP-XXX
3	Do the following optional items as required by the Company Order or as is required by the system you are working on	
	A. An optional item	DLP-XXX
	B. Another optional item	-
	C. Another optional item which must be done in the sequence below	
	1. First part of Option "C"	DLP-XXX
	2. Last part of Option "C"	DLP-XXX
4	Do the next part of the job	DLP-XXX
5	Do the last part of the job	DLP-XXX

Remember that this procedure tells you *what* to do in order to complete the total job. If you know *how* to do an item in the procedure, you should go ahead and complete it. If you need further information on *how* to do part of the job, then you should turn to the referenced DLP or Detail Level Procedure. When you complete all the steps in the DLP, then you must turn back to the COP or Company Order Procedure to find the next item to be done.

TOP is designed so that you will have to read only what is necessary to get your job done. At any time when you know how to perform all the steps in an item, it is not necessary to look further for the "how to" information – simply complete the item and go on to the next one. This idea, in TOP, is known as "bypassing."


Here are some of the things designed into TOP to help you "bypass" information you may already know:

### Summary Statement

A summary statement is used with a DLP (or the flow-charted procedures). It tells you briefly what the procedure does and what type measurement or result can be observed. After reading the summary, you may be able to complete the procedure without reading further. Some shorter DLPs, of course, do not have summary statements.

### Result Statement


A result statement may be used in a flow-charted procedure along with the "AND" symbol. Here is an example of the "AND" symbol and a *result statement*:



When using a procedure, read the result statement first. If you know how to place standby power system in off-line status, it would be unnecessary to read steps 1, 2, and 3.

### Support Procedures


When you see this kind of reference in TOP, it refers to a support procedure.



The support procedure (DLP-591) would provide information about how to operate the TMS-1A. Of course, if you are familiar with the TMS-1A, there is no reason to look up DLP-591.


So far, the Company Order type jobs have been the main topic; however, you will find that the Routine and Acceptance categories are used in the same manner. You may come across a couple of new abbreviations in those categories, namely, Acceptance Task Procedure (ATP) and Routine Task Procedure (RTP). These categories are used in the same way that the Company Order Procedure (COP) is used in the Company Order work.

While using TOP, you probably will run across a reference similar to this:



This reference to TAP-XXX indicates that the equipment is not operating correctly and the TAP (Trouble Analysis Procedure) should be used to help you find and repair the trouble.

This idea can be carried further. In some cases, a decision block may have more than one abnormal output. This simply means that you should try more than one solution to the problem. See the example below.



Trouble clearing information in TOP is basically used the same way as the other types. When a trouble report or equipment alarm requires you to troubleshoot a system, the Trouble Indicator List (TIL) is the place to start. This (TIL) is a listing of trouble symptoms or alarms with a reference to a Trouble Analysis Procedure (TAP). The TAP is an aid in analyzing and locating the cause of the trouble. The TAP may reference to other information such as a Trouble Analysis Data (TAD) or an Isolation Diagram (ISD) as an aid in the trouble clearing process.

Any job must always be done safely and it is no different with TOP. Here are three items which you should look for in TOP:



- means there is a possibility of personal injury



- means there is a possibility of service interruption



- means there is a possibility of equipment damage

The last page of this introductory section is a diagram which shows all the elements used to make up a TOP and basically how they are organized to make a complete document. The diagram may, at first, seem to be complex; but remember, TOP is a programmed document and it always tells you where to find the next bit of information required to do the job. The diagram, however, may be useful later if you need to know the words which DLP, TAP, etc, represent or simply a memory jogger about TOP in general.

While using any TOP, if you find errors, or if a procedure is inadequate or missing, your comments are greatly needed. They may be forwarded by using the standard form E3973 which is available through your Company. Thank you for helping us prepare better documentation.

