

NO. 3 ESS  
 SYSTEM VERIFICATION,  
 COMMON OPERATOR PROCEDURES,  
 3A CC CONTROL PANEL

CONTENTS

1. GENERAL	3.05 Display a Register
1.1 Description	3.06 Load a Register
1.2 References	3.07 Load and Display a Register
2. PREREQUISITES	3.08 Insert Incorrect Register Parity
3. COMMON OPERATOR PROCEDURES	3.09 Compare Address
3.01 Select a General Register	3.10 Compare Data
3.02 Select a Special Register	3.11 Compare Address and Data
3.03 Enable Panel Interrupt	3.12 Display Contents of Store Address
3.04 Honor Panel Interrupt	3.13 Display Contents of Consecutive Store Addresses
	3.14 Load Store Address
	3.15 Load Consecutive Store Addresses
	3.16 Step Function
	3.17 Execute a Program

1. GENERAL

1.1 Description

1.11 This section presents some 3A CC Control Panel operator procedures which could be used more than one time during the conduction of Handbook 269 installation testing.

1.12 Reference to a procedure in this section may take the following form:

"Place an address match (compare) at address 000400; COP, 3A CC CP, 3.09".

- NOTES:
- (1) COP - Common Operator Procedures (Handbook 269, Section 503.41)
  - (2) 3A CC CP - 3A CC Control Panel (Handbook 269, Section 503.41)
  - (3) 3.09 - Paragraph 3.09

1.2 References

<u>TYPE</u>	<u>NUMBER</u>	<u>TITLE</u>
CPS	FA-1034	Console and 3A CC Interface
SD/CD	1C 901-01	3A CC Control Panel

2. PREREQUISITES

2.1 Hardware and software environmental prerequisites must normally be those which support those requirements of the referencing section.

2.2 Generally power must be applied to the 3A CC and the TEST MODE switch must be "active". The TEST MODE switch permits panel

functions in an on-line 3A CC. The MANUAL key must be "active" and the 3A CC must be offline to enable manual functions.

2.3 For most operator procedures associated with the 3A CC control panel (those requiring operation of the EXECUTE switch) bit 13 of Interrupt Mask register must be set to allow "manual panel interrupts". Refer to paragraphs 3.03 and 3.04 of this section.

2.4 Normally, it should be verified that all other 3A CC control panel UP/DOWN toggle switches are in the unoperated or DOWN position when specific procedures are conducted. One exception to this general case could be the HALT switch which may or may not have already been operated (in the UP position) upon entry to common 3A CC control panel procedures. Due to the fact that the 3A CC may have been halted because of a hardware, hardware/software, or operator manipulation upon entry to this section: the operator may have provided additional action on the HALT switch during 3A CC control panel common operator procedures in order to properly obtain the needed results. Operator discretion is required in such cases.

3. COMMON OPERATOR PROCEDURES

3.01 Select a General Register

3.011 Place the SPECIAL/GENERAL EXTENDED switch to the GENERAL EXTENDED position.

3.012 Operate the REGISTER SELECT switches (8,4,2,1) so that their binary equivalent is equal to the decimal general register designation in accordance with the following:

GR (3)	REGISTER SELECT SWITCH			
	8	4	2	1
0	D	D	D	D (1)
1	D	D	D	U (2)
2	D	D	U	D
3	D	D	U	U
4	D	U	D	D
5	D	U	D	U
6	D	U	U	D
7	D	U	U	U
8	U	D	D	D
9	U	D	D	U
10	U	D	U	D
11	U	D	U	U
12	U	U	D	D
13	U	U	D	U
14	U	U	U	D
15	U	U	U	U

- NOTES: (1) D - Switch in the DOWN position  
 (2) U - Switch in the UP position  
 (3) All general registers are 16-bit registers.

3.02 Select a Special Register

3.021 Place the SPECIAL/GENERAL EXTENDED switch to the SPECIAL position.

3.022 Operate the REGISTER SELECT switches so that their binary equivalent is equal to the Special Register (SR) designation in accordance with the following:

SR	NB (3)	REGISTER SELECT SWITCH			
		8	4	2	1
MCTL STAT (4)	20	D	D	D	D (1)
TIM	8	D	D	D	U (2)
SY STA	20	D	D	U	D
ST ADR	20	D	D	U	U
PROG ADR	20	D	U	D	D
MTC STA	16	D	U	D	U
M.MEM STAT	14	D	U	U	D
MCH BUFR	20	D	U	U	U
INT SET	16	U	D	D	D
INT MASK	16	U	D	D	U
HOLD GET	16	U	D	U	D
ERR	22	U	D	U	U
DATA MASK	20	U	U	D	D
DATA IN	16	U	U	D	U
ADR MASK	20	U	U	U	D
ADR IN	20	U	U	U	U

- NOTES: 1) D - Switch in the DOWN position.  
 2) U - Switch in the UP position.  
 3) NB - Number of bits contained in register.  
 4) The definition or title of the special register switch designations is as follows:

SWITCH	
DESIGNATION	DEFINITION
MCTL STAT	Microcontrol Status Register (read only)
TIM	Timing Counter (read only)
SY STA	System Status Register (read only)
ST ADR	Store Address Register
PROG ADR	Program Address Register
MTC STA	Maintenance State Register
M.MEM STAT	Main Memory Status Register
MCH BUFR	Maintenance Channel Buffer
INT SET	Interrupt Set Register
INT MASK	Interrupt Mask Register
HOLD GET	Hold Get Register
ERR	Error Register
DATA MASK	Data Mask Register
DATA IN	Data Input Register
ADR MASK	Address Mask Register
ADR IN	Address Input Register

3.03 Enable Panel Interrupt

3.031 3A CC panel interrupt is obtained (originated) when the EXECUTE switch is depressed and released and either one of the following conditions is present.

3.032 Condition I

- A. The MANUAL switch is operated (the MANUAL switch lamp is lighted).
- B. The associated CC is OFFLINE (the STBY switch lamp is lighted).

OR

3.033 Condition 2

- A. The TEST MODE switch is operated (the TEST MODE switch lamp is lighted).

3.04 Honor Panel Interrupt

3.041 A 3A CC panel interrupt is honored (effective) when the following conditions are all present.

- A. Bit 13 of the Interrupt Mask Register is zero.
- B. The Block Interrupt's flip-flop is zero.

- NOTES: (1) The RESET CKTS switch on the 3A CC control panel forces conditions A and B above.

### 3.05 Display a Register

**NOTE:** Generally, for this action to be effective, the 3A CC must be halted at some designated point and, if program is cycling, bit 17 of the System Status Register must be set to disable the gating of the PA to the display buffer. Additionally, that condition when program is cycling, interpretation of any actual register display obtained may be difficult except under rather controlled conditions.

3.051 Select the general purpose or special register concerned in accordance with either paragraph 3.01 or 3.02 respectively of this section.

3.052 Place the REGISTER DISPLAY switch in the UP position.

3.053 Depress and release the EXECUTE switch.

3.054 Return the REGISTER DISPLAY switch to the DOWN position.

### 3.06 Load a Register

**NOTE:** Generally, for this action to be effective, the 3A CC must be halted at some designated point. For that condition when program is cycling meaningful utilization of any actual register load may be difficult except under rather controlled conditions.

3.061 Select the general purpose or special register concerned in accordance with either paragraph 3.01 or 3.02 respectively of this section.

3.062 Place the REGISTER LOAD switch in the UP position.

3.063 Insert the contents with which it is required to load the register into the LOAD AND DISPLAY switches.

3.064 Depress and release the EXECUTE switch.

3.065 Return the REGISTER LOAD switch to the DOWN position.

### 3.07 Load and Display a Register

#### 3.08 Insert Incorrect Register Parity

3.081 Select the general purpose or special register concerned in accordance with either paragraph 3.01 or 3.02 respectively of this section.

3.082 Place the REGISTER LOAD switch in the UP position.

3.083 Insert the contents with which it is required to load the register into the LOAD AND DISPLAY switches.

3.084 Place the ENABLE MANUAL PARITY switch in the UP position.

3.085 Insert incorrect parity into PL for bits 0 to 7 if required.

3.086 Insert incorrect parity into PH for bits 8 to 15 or bits 8 to 19 if required.

**NOTE:** (1) Parity High (PH) is over those additional register bits not covered by Parity Low (PL).

3.087 Depress and release the EXECUTE switch.

### 3.09 Compare Address

**NOTES:** (1) Only one hardware compare address request may be contained within the system at any one time.

(2) Compare address is used with an address mask. In any event, the contents of the Address Mask register should be verified to insure that it contains the correct mask.

3.091 Display the Address Mask register. Insure that it contains the proper mask for the compare address function required. If not, load the proper mask into the Address Mask register in accordance with the procedures in paragraph 3.06, Load Register, of this section.

3.092 Load the required address into the Address Input register in accordance with the procedures in paragraph 3.06, Load Register, of this section.

3.093 Place the COMPARE ADR switch in the UP position.

3.094 Depress and release the EXECUTE switch.

### 3.10 Compare Data

**NOTES:** (1) Only one hardware compare data request may be contained within the system at any one time.

(2) Compare data is used with a data mask. In any event, the contents of the Data Mask register should be verified to insure that it contains the correct mask.

3.101 Display the Data Mask register. Insure that it contains the proper mask for the compare data function required. If not, load the proper mask into the Data Mask register in accordance with the procedures in paragraph 3.06, Load Register, of this section.

3.102 Load the required data into the Data Input register in accordance with the procedures in paragraph 3.06, Load Register, of this section.

3.103 Place the COMPARE DATA switch in the UP position.

3.104 Depress and release the EXECUTE switch.

### 3.11 Compare Address and Data

**NOTE:** If a compare function for both some designated address, as described in paragraph 3.09, and for some designated data, as described in paragraph 3.10, is established, an interrupt will occur when either compare is found, not both.

### 3.12 Display Contents of Store Address

NOTE: (1) The Store Address Register (SAR) must be loaded with the address of the store word it is required to display.

3.121 Load the store address of the word it is required to display into the Store Address Register (SAR) in accordance with the procedures in paragraph 3.06, Load Register, of this section.

3.122 Place the MEMORY DISPLAY switch in the UP position.

3.123 Depress and release the EXECUTE switch.

### 3.13 Display Contents of Consecutive Store Addresses

3.131 Set up to display the contents of the initial store address in accordance with the procedures in paragraphs 3.121 to 3.122, Display Contents of Store Address, of this section.

3.132 Place the MEMORY INCR ADR switch in the UP position.

3.133 Depress and release the EXECUTIVE switch.

3.134 Continue to depress and release the EXECUTE switch until the entire store address block it is required to observe has been displayed.

### 3.14 Load Store Address

NOTE: (1) The Store Data Register (SDR) must be loaded with the data it is required to load.

(2) The "STORE" label of that switch in the MEMORY section of the 3A CC front panel is synonymous with the meaning of the word "LOAD".

3.141 Load the required data into the Store Data register in accordance with the procedures in paragraph 3.06, Load Register, of this section.

3.142 Load the store address of the word it is required to load (write) into the SAR in accordance with the procedures in paragraph 3.06, Load Register, of this section.

3.143 Place the MEMORY STORE switch in the UP position.

3.144 Depress and release the EXECUTE switch.

### 3.15 Load Consecutive Store Addresses

3.151 Set up to load the required data of the initial store address in accordance with the procedures in paragraph 3.141 to 3.142, Load Store Address, of this section.

3.152 Place the MEMORY STORE switch in the UP position.

3.153 Place the MEMORY INCR ADR switch in the UP position.

3.154 Depress and release the EXECUTE switch.

3.155 If it is required to write identical data into subsequent consecutive store addresses continue to depress and release the EXECUTE switch until the entire store address block into which it is required to load identical data has been loaded; otherwise, continue with the immediately following paragraph.

3.156 Place the MEMORY INCR ADR switch in the DOWN position.

3.157 Place the MEMORY STORE switch in the DOWN position.

3.158 Load the required next word's data into the SDR in accordance with the procedures in paragraph 3.06, Load Register, of this section.

3.159 Place the REGISTER LOAD switch in the DOWN position.

3.1510 Place the MEMORY INCR ADR switch in the UP position.

3.1511 Place the MEMORY STORE switch in the UP position.

3.1512 Continue with paragraph 3.154 of this section until the entire store address block it is required to load has been loaded.

### 3.16 Step Function

NOTES: (1) The step function controls program execution, one instruction for each EXECUTE switch operation.

(2) It is assumed, that for purposes of the following procedures the 3A CC has been halted by some condition: hardware, hardware/software combination or direct operator manipulation of the HALT or RESET CIRCUITS switches. (Refer to paragraph 2.4 of this section.)

3.161 If the 3A CC is not halted at the start of the desired address, continue with the following paragraph; otherwise, go to paragraph 3.163.

3.162 Load the store address of the first program word it is required to step through into the SAR in accordance with the procedures in paragraph 3.06, Load Register of this section.

3.163 Place the STEP switch in the UP position.

3.164 Depress and release the EXECUTE switch.

3.165 Continue with paragraph 3.164 of this section until the STEP function requirements have been satisfied.

3.17 Execute a Program

NOTES: (1) It is assumed that the 3A CC is halted.

(2) The program required to cycle is already in store.

3.171 If the 3A CC is not halted at the start of the desired address, continue with the following paragraph; otherwise, go to paragraph 3.173.

3.172 Load the store address of the first program word it is required to cycle into the SAR in accordance with the procedures in paragraph 3.06, Load Register, of this section.

3.173 Place the HALT switch in the DOWN position.

3.174 Depress and release the EXECUTE switch.

NOTE: (1) It may be required to take further action (to satisfy program cycling) either at the 3A CC control panel or the System Status Panel.