

DIMENSION[®] 2000 AND CUSTOM PBX

NETWORK OVER TEMPERATURE ALARMS
(PROC 502)

CONTENTS

1. GENERAL
2. RECORDS
3. MAAP DISPLAY FIELDS
4. MAAP CONTROL KEY SEQUENCES
5. PROCEDURES
6. TROUBLESHOOTING AIDS

1. GENERAL

- 1.1 This section provides information for interrogating PROC 502 in the event that the craftsperson is directed to this procedure due to a NETWORK OVER TEMPERATURE alarm. Whenever this type of alarm occurs the ALARM PANEL - OVER TEMP and MINOR LED'S will be lit.

2. RECORDS

- 2.1 Form SD 97-1313 is required for recording the results of this test.

3. MAAP DISPLAY FIELDS (PROC 502 FORMAT)

- 3.1 The following describes each of the display fields for the NETWORK OVER TEMPERATURE (PROC 502) format:

FIELD	DESCRIPTION
1	TEST NO. - Displays active test number (maximum of 3) per the following encodes:
	ENCODE . DESCRIPTION
	1 Displays failure history.
	2 Tests all circuits sequentially.
	3 Tests a particular circuit (as displayed in fields 2 & 3).

PRIVATE

Printed in U.S.A.

THE INFORMATION CONTAINED HEREIN SHOULD NOT BE DISCLOSED TO UNAUTHORIZED PERSONS. IT IS MEANT SOLELY FOR USE BY AUTHORIZED BELL SYSTEM EMPLOYEES.

FIELD	DESCRIPTION								
2,3	<p>EQUIPMENT LOCATION (MODULE/CAB) - (TESTS 1,2 and 3), for TESTS 1 & 2, Displays fault location. For TEST 3, displays test location. Allowable encodes are as follows:</p> <table border="0" style="margin-left: 40px;"> <thead> <tr> <th style="text-align: left;">ENCODE</th> <th style="text-align: left;">DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>00 - MM</td> <td>Allowable module encodes for FIELD 2. (MM = highest module number in system under test).</td> </tr> <tr> <td>0 - C</td> <td>Allowable cabinet encodes for FIELD 3. (C = highest cabinet number in system under test).</td> </tr> </tbody> </table>	ENCODE	DESCRIPTION	00 - MM	Allowable module encodes for FIELD 2. (MM = highest module number in system under test).	0 - C	Allowable cabinet encodes for FIELD 3. (C = highest cabinet number in system under test).		
ENCODE	DESCRIPTION								
00 - MM	Allowable module encodes for FIELD 2. (MM = highest module number in system under test).								
0 - C	Allowable cabinet encodes for FIELD 3. (C = highest cabinet number in system under test).								
4	<p>Failure code - (TESTS 1,2 & 3), displays failure code per the following encodes:</p> <table border="0" style="margin-left: 40px;"> <thead> <tr> <th style="text-align: left;">ENCODE</th> <th style="text-align: left;">DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Pass</td> </tr> <tr> <td>1</td> <td>Over temperature failure</td> </tr> <tr> <td>9</td> <td>Network order incomplete</td> </tr> </tbody> </table>	ENCODE	DESCRIPTION	0	Pass	1	Over temperature failure	9	Network order incomplete
ENCODE	DESCRIPTION								
0	Pass								
1	Over temperature failure								
9	Network order incomplete								
5	TOTAL CABINETS - (TESTS 1,2 &3), displays total number of network cabinets.								
6	TOTAL CABINETS FAILED - (TESTS 1 & 2), displays total number of network cabinet failures.								
7	<p>FAILURE INDEX - (TESTS 1 & 2), displays an index number which either indicates:</p> <p style="margin-left: 40px;">A) Locations with highest number of failures in descending order (TEST 1) or B) locations in order of detected failures. Index number "0" in TEST 1, indicates a display of the failure history totals: in TEST 2, indicates that no failures were detected.</p>								
8	FAILURES PER HOUR - (TEST 1), displays a 2 hour average failure rate.								
9	FAILURES BEGAN - HOURS AGO - (TEST 1), displays number of hours since failures started to nearest hour (17 hours maximum).								
10,11	MOST RECENT FAILURE - HOURS/MINUTES AGO - (TEST 1), Displays time since last failure to nearest minute (136 hours/31 minutes maximum).								

4. MAAP CONTROL KEY SEQUENCES

4.1 PROC NO. 5, 0, 2, ENTER - causes program for PROC 502 to be loaded into memory from tape for execution.

- 4.2 CLEAR DATA, EXECUTE - (TEST 1), Clears failure history records stored in memory.
- 4.3 EXECUTE - starts executing test number displayed in FIELD 1.
- 4.4 NEXT CIRCUIT - (TEST 1 & 2), displays next failure. (TEST 3), advances test to next equipped cabinet when test is stopped.
- 4.5 NEXT TEST - advances procedure to the next test.
- 4.6 RESET - resets the procedure to the beginning of TEST 1.
- 4.7 STOP - stops test 3 from further testing. Note: This key must be operated before the next circuit key can be operated if test 3 is executing.

5. PROCEDURES

- 5.1 The following describes the repair procedure that should be used in the event of a network over temperature alarm.
- 5.11 Execute TEST 1 and record failure history generated by ON-LINE maintenance.
- 5.12 Execute TEST 2 and record the results. If there are no failures use TEST 3 to continuously test each cabinet displayed in test 1 to check for intermittent faults. If failures occur either during TEST 2 or 3 use the following repair procedures:
 - A) FAILURE CODE - 1, proceed as follows:
 - AA) If more than one cabinet is indicated then possibly the system ambient temperature is being exceeded (refer to ED-1E301 for requirements). If true, take appropriate steps to lower system ambient temperature. If not true, proceed to the next step.
 - AB) Refer to attachment 2 and check sensor and fan operations at cabinets indicating failures. Note: Fans should operate only when the cabinet temperature exceeds $130 + 5\%$ degrees farhenheit and the LC105 temp led should light only when the cabinet temperature exceeds $145 + 5\%$ degrees farhenheit. If cabinet temperature does not exceed the above limits proceed to the next step.
 - AC) Replace LC105 at cabinet indicating failure. Use test 1 to clear failure history and execute test 2. If over temperature failure still exists, go to PROC 508 to test LC105 more thoroughly.
 - B) FAILURE CODE - 9, use PROC 505 and also refer to paragraph 6, of this section for further testing information.

- 5.13 After the trouble(s) has been cleared go to Test 1 and clear the on-line maintenance records (use CLEAR DATA EXECUTE keys).

6. TROUBLESHOOTING AIDS

6.1 GENERAL TEST INFORMATION

- 6.11 TEST 1 - TEST 1 is the default test when the procedure is first read in from the tape or when the MAAP - RESET key is operated. When the MAAP - EXECUTE key is operated. Data accumulated by on-line maintenance is displayed on the MAAP starting with the display of the total failures (Failure Index - 0). If failures were detected, FIELD 6 should display the total cabinet failure number and FIELDS 8 thru 11 will display the failure history. If no failures were detected, FIELD 6 will display a "0" and FIELDS 9 thru 11 will contain dashes. Note: If failures were detected and if failure index is a "0", FIELDS 2 thru 4 will be dashed since this type of display only indicates totals and not a display of a cabinet failure.

If failures were detected, operation of the NEXT CIRCUIT key will display the location of the cabinet failure by index number. FIELDS 2 & 3 will display the failure location, FIELD 4 displays the type of failure and FIELD 7 displays the failure index. Repeated operation of the NEXT CIRCUIT key displays other failures until all detected failures have been display, in which case all FIELDS except 1 and 6 will dashed.

Operation of the CLEAR DATA, EXECUTE keys clears the fault records.

- 6.12 TEST 2 - The purpose of this test, is to test all network over temperature alarm detectors, to display the failed circuits, and to control alarm panel - NETWORK OVER TEMPERATURE alarms.

The test is initiated when the MAAP - EXECUTE key is operated, which turns on the MAAP - WAIT lamp and begins testing each of the network cabinet maintenance circuits (LC105's). At the end of the test, the WAIT lamp is turned off and the appropriate data and alarms are displayed.

If a failure is detected, the NETWORK OVER TEMP and MINOR lamps are turned on. All failed circuit data is stored and at the conclusion of the test, the first failed circuit will be displayed in FIELDS 2 & 3. Operation of the MAAP - NEXT CIRCUIT key will display other detected failures if more than one failure exists.

If no failures are detected, the alarms - NETWORK OVER TEMP and MINOR - are turned off.

- 6.13 TEST 3 - The purpose of this test is to test a particular circuit continuously and to turn on the alarms if a failure exists. If a default circuit (last circuit failure detected) is not displayed, the craftsperson must enter a circuit location. If the displayed location is not the one desired, it can be changed by the CHANGE FIELD sequence or by continually operating the NEXT CIRCUIT key until the desired one is obtained.

The test is started by operating the EXECUTE key. The WAIT lamp is not turned on since the test is continuous however the failure code is flashed (60 IPM) in FIELD 4 to indicate that the test is running. If a failure is detected, the test continues to run and FIELD 4 flashes the appropriate failure code. The test can be stopped by either operating the STOP key (which allows a NEXT CIRCUIT key operation) or operating the NEXT TEST, RESET, or PROC NO. keys.




6.2 GENERAL TROUBLESHOOTING INFORMATION

- 6.21 PROC 502 checks for network over temperature failures by addressing each of the network cabinet maintenance circuits (LC105) and checking the status of the TEMP* lead (input to LC105). To check the TEMP* input, the BBS15* lead is activated (made low) and the status of the TEMP* will appear on the SS1* output lead (all these leads appear on the LC105). That is, if the TEMP* is low, when the BBS15* lead is activated the SS1* output lead should pulse low.

The LC105 - TEMP led should light whenever the TEMP* lead is active.

The above describes what is verified and should be checked in the event that a fail code of "1" is displayed in FIELD 4 and the normal troubleshooting procedures described in paragraph 5, of this section did not clear the trouble.

Fail code 9, in FIELD 4 indicates failure to receive an I/O done signal from the network and if this is the case PROC 505 should be used to clear the problem.



TEST 1: DISPLAYS FAILURE HISTORY. USE 'NEXT CIRCUIT' TO DISPLAY FAILURE HISTORY. USE 'CLEAR DATA,EXECUTE' TO CLEAR FAILURE HISTORY.				TEST 2: TESTS ALL CIRCUITS. USE 'NEXT CIRCUIT' TO DISPLAY NEXT FAILURE.				TEST 3: TESTS A PARTICULAR CIRCUIT CONTINUOUSLY. USE 'NEXT CIRCUIT' TO DISPLAY NEXT EQUIPMENT LOCATION. FAILURE CODES: 0= PASS 9= NETWORK ORDER 1= FAIL INCOMPLETE						
ISSUE L7.8				PROC 502										
ISSUE L7.8				NETWORK OVER TEMPERATURE FAILURES				PROC 502						
TEST NO	TEST 3 EQUIPMENT LOCATION		FAILURE CODE	TOTAL CABINETS	TOTAL CABINETS FAILED	FAILURE INDEX	FAILURE HISTORY							
	MODULE	C A B					FAILURES PER HOUR					FAILURES BEGAN- HOURS AGO	MOST RECENT FAILURE	
1	2	3	4	5	6	7	8	9	10	11				