

DIMENSION[®] 2000
AND CUSTOM PBX

PAM AMPLIFIER TEST (PART 1)
(PROC 508)

CONTENTS

- | | |
|------------------------|-------------------------------|
| 1. GENERAL | 4. MAAP CONTROL KEY SEQUENCES |
| 2. RECORDS | 5. PROCEDURES |
| 3. MAAP DISPLAY FIELDS | 6. TROUBLE-SHOOTING AIDS |

1. GENERAL

- 1.1 This section provides information for interrogating PROC 508 in the event that the craftsperson is directed to this procedure due to a NETWORK PAM failure. Whenever this type of alarm occurs, the ALARM PANEL-PAM and MINOR lamps will be lit.

2. RECORDS

- 2.1 Form SD-97-1313 is required for the recording the results of this test.

tech tells Vol 2 #3 when using the new flat cables with the aluminum sheathing you have to upgrade the network clock to LC 12 IC's or you will get PAM & network alarms

PRIVATE

THIS INFORMATION CONTAINED HEREIN SHOULD NOT BE DISCLOSED TO UNAUTHORIZED PERSONS. IT IS MEANT SOLELY FOR USE BY AUTHORIZED BELL SYSTEM EMPLOYEES.

3. MAAP DISPLAY FIELDS

3.1 The following describes each of the display fields for the Network - PAM Amplifier Tests (PROC 508) format:

| <u>FIELD</u> | <u>DESCRIPTION</u> | | | | | | | | | | |
|---------------|---|---------------|--------------------|---|--|---|---|---|---|---|---|
| 1 | TEST NO - Displays active test number (Maximum of 4) per the following encodes: | | | | | | | | | | |
| | <table border="0" style="margin-left: 40px;"> <thead> <tr> <th style="text-align: left;"><u>ENCODE</u></th> <th style="text-align: left;"><u>DESCRIPTION</u></th> </tr> </thead> <tbody> <tr> <td style="vertical-align: top;">1</td> <td>Displays failure history per each unit type, as detected by on-line maintenance.</td> </tr> <tr> <td style="vertical-align: top;">2</td> <td>Tests all circuits per a unit type (Displays failure summary only).</td> </tr> <tr> <td style="vertical-align: top;">3</td> <td>Tests all circuits per a unit type (Displays each failure).</td> </tr> <tr> <td style="vertical-align: top;">4</td> <td>Tests a particular circuit per a unit type.</td> </tr> </tbody> </table> | <u>ENCODE</u> | <u>DESCRIPTION</u> | 1 | Displays failure history per each unit type, as detected by on-line maintenance. | 2 | Tests all circuits per a unit type (Displays failure summary only). | 3 | Tests all circuits per a unit type (Displays each failure). | 4 | Tests a particular circuit per a unit type. |
| <u>ENCODE</u> | <u>DESCRIPTION</u> | | | | | | | | | | |
| 1 | Displays failure history per each unit type, as detected by on-line maintenance. | | | | | | | | | | |
| 2 | Tests all circuits per a unit type (Displays failure summary only). | | | | | | | | | | |
| 3 | Tests all circuits per a unit type (Displays each failure). | | | | | | | | | | |
| 4 | Tests a particular circuit per a unit type. | | | | | | | | | | |
| 2 | UNIT TYPE - Displays unit type under test per the following encodes: | | | | | | | | | | |
| | <table border="0" style="margin-left: 40px;"> <thead> <tr> <th style="text-align: left;"><u>ENCODE</u></th> <th style="text-align: left;"><u>DESCRIPTION</u></th> </tr> </thead> <tbody> <tr> <td style="vertical-align: top;">0</td> <td>MAINTENANCE CIRCUIT (LC105)</td> </tr> <tr> <td style="vertical-align: top;">1</td> <td>Amplifiers and Bus Select Switches (LC101, LC102, LC103 and LC104).</td> </tr> <tr> <td style="vertical-align: top;">2</td> <td>Amplifier Cables. (Intercabinet)</td> </tr> <tr> <td style="vertical-align: top;">3</td> <td>Port Transmit switch stuck closed.</td> </tr> </tbody> </table> | <u>ENCODE</u> | <u>DESCRIPTION</u> | 0 | MAINTENANCE CIRCUIT (LC105) | 1 | Amplifiers and Bus Select Switches (LC101, LC102, LC103 and LC104). | 2 | Amplifier Cables. (Intercabinet) | 3 | Port Transmit switch stuck closed. |
| <u>ENCODE</u> | <u>DESCRIPTION</u> | | | | | | | | | | |
| 0 | MAINTENANCE CIRCUIT (LC105) | | | | | | | | | | |
| 1 | Amplifiers and Bus Select Switches (LC101, LC102, LC103 and LC104). | | | | | | | | | | |
| 2 | Amplifier Cables. (Intercabinet) | | | | | | | | | | |
| 3 | Port Transmit switch stuck closed. | | | | | | | | | | |
| 3 | MTCE CKT EQPT LOC - MODULE displays module under test. | | | | | | | | | | |
| 4,5 | MTCE CKT EQPT LOC - SOURCE - CAB/CARR - displays cabinet and carrier containing LC101 that a LC105 source signal is connected. | | | | | | | | | | |

| <u>FIELD</u> | <u>DESCRIPTION</u> |
|--------------|--|
| 6,7 | MTCE CKT EQPT LOC - RECEIVER - CAB/CARR - Displays cabinet and carrier containing LC101 that a LC105 receiver is connected. |
| 8 | MTCE CKT EQPT LOC - TIME SLOT BUS - Displays time slot bus under test (0 = Bus 0, 1 = Bus 1). |
| 9 | MTCE BUSY STAT OF BUS - displays maintenance busy status of bus (displayed in field 8) under test, (0 = bus not busied out, 1 = all time slots busied out). |
| 10 | FAILURE CODE - displays failure code for circuit path displayed in fields 4-7. |
| 11 | NTWK GAIN - displays network gain for circuits under test. Encodes for normal gains per types of connections should be as follows: |

| <u>CONNECTION</u> | <u>ENCODE</u> |
|-------------------|---------------|
| LINE TO LINE | 1 |
| LINE TO TRUNK | 2 |
| LINE TO LINK | 2 |
| LINK TO TRUNK | 2 |
| TRUNK TO LINK | 2 |
| TRUNK TO TRUNK | 2 |
| LINK TO TRUNK | 3 |
| TRUNK TO LINE | 3 |

NOTE: When a failure is detected, the encodes
will be different from what is displayed above.
(Higher or lower).

| | |
|----|--|
| 12 | NUMBER OF FAILURES (test 1) - displays total number of failures detected by on-line maintenance. (Maximum of 6). |
| | TOTAL CIRCUITS TESTED (Tests 2 and 3) - displays total number of circuits tested. |

| <u>FIELD</u> | <u>DESCRIPTION</u> |
|--------------|---|
| 13 | FAILING CIRCUIT INDEX (Test 1) - displays one index, which indicates a display of the totals of all failing circuits detected by on-line maintenance (index = 0) or the failure history for a particular circuit (index = 1 to 6). TOTAL CIRCUITS FAILED - (Tests 2 and 3) - displays total number of all failed circuits. |
| 14 | FAILURES PER HOUR - (test 1) - displays average failure rate per every two hours. (Maximum of 99). |
| 15 | FAILURES BEGAN (Hours Ago) - displays number of hours since failures began to the nearest hour (17 hours maximum). |

4. MAAP CONTROL KEY SEQUENCES

- 4.1 PROC NO., 5, 0, 8, ENTR - Causes program to be loaded from the tape to the memory.
- 4.2 BUSY OUT - (Tests 3 and 4), busies out displayed time slot bus in a module for unit type 1 only.
- 4.3 NEXT CIRCUIT - (Tests 1, 3 and 4), in test 1 and 3, causes display of next failing circuit. In test 4, increments to next equipped LC105 circuit or PAM network path.
- 4.4 NEXT TEST - (Tests 1, 2, 3 and 4) causes procedure to advance to the next test number. (Field 1)
- 4.5 NEXT UNIT - (Tests 1, 2, 3 and 4), causes procedure to advance to the next unit. (Field 2).
- 4.6 RELEASE BUSY OUT - (Tests 3 and 4), causes displayed time slot bus to be released from a busied out condition.
- 4.7 RESET - (Tests 1, 2, 3 and 4), causes procedure to be reset to the beginning.
- 4.8 STOP - (Tests 2, 3 and 4), causes a test that is executing to be stopped.
- 4.9 CLEAR DATA, EXECUTE - (Test 1 only), causes on-line maintenance failure history, for the displayed unit type to be cleared.

5. PROCEDURES

- 5.1 The following describes the repair procedures that should be used in the event of a NETWORK PAM ALARM.
- 5.2 Execute Test 1 for each unit type and record the on-line maintenance failure history. NOTE: Presently there are now on-line maintenance tests for type "2" units.
- 5.3 UNIT TYPE 0 FAILURES
- 5.31 If failures (failure codes 1-20) were recorded for unit type "0", execute test 3. If no failures are detected, use test 4 to test the circuits recorded in step 5.2. If failures are detected either during test 3 or 4, use the repair procedures listed below and re-execute test 4 for the failing circuit. If the test passes, go to step 5.5; otherwise go to the next repair procedure.
- a) Replace LC105
 - b) Replace LC49 in the same carrier as LC105
 - c) Replace LC101 in the same carrier as LC105
 - d) Replace LC46
 - e) See paragraph 6 of this section

5.4 UNIT TYPE 1 FAILURES

5.41 If failures (failure codes 31-35) were recorded for unit type "1", execute test 3. If no failures are detected, use test 4 to test the circuits recorded in step 5.2. If failures are detected either during test 3 or 4, use the repair procedures listed below and then re-execute test 4 for the failing circuit. If the test passes, go to step 5.5; otherwise go to the next repair procedure.

5.411 FAILURE CODE 31 ONLY.

NOTE: This type of failure indicates an invalid network gain was detected.

- a) Single carrier, single bus.
 - aa) Replace LC101 in carrier displayed in fields 4 and 5.
 - ab) Replace LC102 for the indicated bus.
 - ac) Check cables, especially the cables for the CFC --, CTC --, TTS - and TTR - leads. Check also for pulsing on associated GOS --, CIS -- leads. Refer to cabling tables and diagrams at end of this section.
- b) Single carrier, both buses.
 - ba) Replace LC101 for carrier displayed in fields 4 and 5, (should be same as displayed in fields 6 and 7).
 - bb) Check cables, see step ac.
 - bc) Replace LC105 for the indicated cabinet.
- c) Single bus, carriers of the same type (line, trunk, or link) in a cabinet.
 - ca) Replace LC102 for the indicated bus.
 - cb) Replace LC103 (line or trunk failures) or LC104 (link failures).

*check the work
cables between
cabinets
example
400 type cable
for continuity
they break easy*

- cc) Check cables, especially the CFG --, CTG -- cables.
See diagrams and tables at end of this section.
- d) Both buses, carriers of the same type (line, trunk, or link) in a cabinet.
 - da) Check cables, especially CFG --, CTG -- cables and cables for CBI -- leads. See diagrams and tables at end of this section.
 - db) Replace each LC103 (line or trunk failures) or LC104 (link failures) within a module.
 - dc) Replace each LC102, especially for the group indicated.
- e) Carriers of the same type (line, trunk, or link) in a module, single bus.
 - ea) Replace LC103 (line or trunk failures) or LC104 (link failures).
 - eb) Check cables, especially CFG --, CTG -- cables. See diagrams and tables at end of this section.

5.412

FAILURE CODES 31 AND 32.

NOTE: This type of failure indicates a select stuck sum bus switch which can cause gain failures on same bus in other groups.

- a) Fail code 32 in a single carrier, single bus.
 - aa) Replace LC102 for indicated bus.
 - ab) Replace LC101 in indicated carrier.

5.413

FAILURE CODES 31, 32 and 33.

NOTE: This type of failure indicates a stuck distribute select switch which can cause gain failures and sum bus failures in some group.

- a) Fail code 33 on one bus and fail code 32 on opposite bus for a single carrier.
 - aa) Replace LC101 in carrier associated with the failure code 33.
- b) Fail code 33 on one bus and fail code 31 on opposite bus for a single carrier.

- ba) Replace LC101 in carrier with failure code 33.
- bb) Unplug port circuits one at a time until failure is cleared; replace defective port circuit.

5.414 FAILURE CODE 35

NOTE: This type of failure indicates a 3-Way Pad switch stuck open.

- a) All carriers in a group, single bus.
 - aa) Replace LC102 for indicated bus.
 - ab) Check cabling, especially WT3 --*, SRD3C- leads.

5.415 FAILURE CODE 98

NOTE: This type of failure indicates a failure to complete a Network command.

- a) Use PROC's 501, 505, 506 to trouble-shoot this problem.

5.416 FAILURE CODE 99

NOTE: This type of failure indicates a failure to find a time slot that is idle on both buses.

- a) This fault code may occur during heavy traffic, re-execute procedure until fault code doesn't reappear.

5.5 If problem is cleared, go to TEST 1 and clear on-line maintenance records. (Operate MAAP-CLEAR DATA, EXECUTE keys).

6. TROUBLE-SHOOTING AIDS

6.1 GENERAL TEST INFORMATION

6.11 TEST 1 - Test 1 is the default test when procedure 508 is first read in from the tape, or when the MAAP-RESET key is operated. In either case, field 1 will display a 1, field 2 will flash, and fields 3 through 15 will be dashed. When the MAAP-EXECUTE key is operated, the failure history for the unit type displayed in field 2 is displayed. Initially the failure history will display the totals (failure index = 0) of all failures for a particular unit type. Operation of the MAAP-NEXT CIRCUIT key causes a failure history display for particular equipment locations. If the MAAP-NEXT UNIT key is operated, field 2 will be incremented to the next unit type.

Operation of the MAAP-CLEAR DATA, EXECUTE keys clears the on-line maintenance records for the unit type displayed in field 2.

6.12 TEST 2 - Tests all circuits per a unit type, displays a testing summary and controls the PAM alarm. When the MAAP-EXECUTE key is operated, the MAAP-WAIT lamp turns on, fields 3 through 8 displays the PAM circuit equipment locations under test and fields 12 and 13 display the testing progress. When the test is finished, the MAAP-WAIT lamp is turned off and fields 12 and 13 display the test results. If no failures were detected, the PAM and MINOR alarm indicators are turned off. The test may be stopped at any time by operating the MAAP-STOP key.

6.13 TEST 3 - Test 3 does the same thing as test 2, except that it will stop on the first failure detected. To continue testing, operate the MAAP-NEXT CIRCUIT key.

6.14 TEST 4 - Tests a particular PAM circuit as displayed in fields 3 thru 8. If a default PAM circuit is not displayed, the craftsperson must enter one. When the MAAP-EXECUTE key is operated, the MAAP-LAMP is not turned on (since the test is continuous); however, field 10 will flash the failure code. The test must be stopped before the MAAP-NEXT CIRCUIT key is operated.

if there are any tone plants buzzed out you will get a pam alarm after a while showing a unit trouble which will clear every time you test it. we also reseted the Pam amp cards and cleared a unit 2 (cable) trouble

6.2 GENERAL TROUBLE-SHOOTING INFORMATION

6.21 PROC 508 is used to test the LC105 maintenance circuits (UNIT 0) and to test the PAM circuits (UNIT 1) within each cabinet. To test intercabinet cables and to check for stuck port circuit switches, PROC 580 must be used.

6.22 LC105 Maintenance Circuit Functions

6.221 The LC105 - Maintenance Circuit consists of two parts, (1) circuitry to test the PAM network and (2) circuitry to serve as a maintenance monitor.

The maintenance monitor detects the presence of temperature, fuse, network clock and power interrupt alarms. When the BBS15* is enabled, the status of the following leads is returned via the scan leads as follows:

| <u>ALARM LEAD</u> | <u>SCAN LEAD</u> |
|-------------------|------------------|
| APMJ, ANMJ* | SS0* |
| TEMP* | SS1* |
| NCKSCN | SS2* |
| +5V, -9V Power | SS3* |

The PAM test circuitry consists of a time slot shift register, receiver, source (tone generator), threshold detector, group output selector, carrier input selector and internal test circuitry.

When a PAM test is performed, an idle time slot is found and the LC105 shift register is set to that time slot. The receiver is then enabled and a particular group output select and carrier input select is chosen. Next the source is enabled, and the threshold detector decodes the level of the signal received. A scan (BBS14~~0~~ enabled) is made of threshold detector outputs (SS0*-SS3*) to determine if the level is correct.

The internal test circuitry allows the LC105 to be tested at both high and low gain levels. The test to perform a self test is the same as a regular PAM test except that the group output and carrier input selectors select internal LC105 time slot switches.

The group output selector, carrier input selector, source and receiver are all under control of the LC105 time slot shift register so that signals are sent and received only during a time slot that is not used by the rest of the PAM circuits under test.

The following tables show the port address available on the LC105 and also the data required to perform LC105 functions.

LC105 PORT SELECTS

| BBS15* | BBS14* | BAD10* | BPS3* | BPS2* | BPS1* | BPS0* | DESCRIPTION |
|--------|--------|--------|-------|-------|-------|-------|--|
| * | - | - | - | - | - | - | PWR, NETWORK CLOCK, TEMP, FUSE AND SHIFT REGISTER BII STATUS |
| - | * | - | - | - | - | - | THRESHOLD DETECTOR STATUS |
| * | - | * | - | - | - | * | SOURCE FF PORT SELECT (1) |
| * | - | * | - | - | * | - | RECEIVER FF PORT SELECT (2) |
| * | - | * | - | * | - | - | TIME SLOT SHIFT REGISTER SELECT |
| * | - | * | * | - | - | - | POWER RETURN PORT SELECT (3) |
| - | * | * | - | - | - | * | GROUP OUTPUT SELECT (1st HALF) |
| - | * | * | - | - | * | - | GROUP OUTPUT SELECT (2nd HALF) |
| - | * | * | - | * | - | - | CARRIER INPUT SELECT (1st HALF) |
| - | * | * | * | - | - | - | CARRIER INPUT SELECT (2nd HALF) |

HB 281

13.

NOTE (1) - Source is enabled when BRBS3 is active, when BKRB3 is active, the source is set to low (977HZ) frequency and when BKRB3 is inactive, the high (1954HZ) frequency is set.

(2) - Receiver is enabled, when BRBS3 is active.

(3) - Power return flip flop is set when BKRB3 is active.

* = Lead is active
 - = Lead is inactive

508T

THIS PAGE IS RESERVED FOR FUTURE USE.

BKRB3 AND BRBS3 DATA INPUT
LC105 GROUP OUTPUT AND CARRIER INPUT SELECT

| GOS -- | BPS1*, | | BPS0*, | |
|-----------------|--------|-------|--------|-------|
| CIS -- | BPS3* | | BPS2* | |
| SELECT | BKRB3 | BRBS3 | BKRB3 | BRBS3 |
| 00 | 0 | 0 | 0 | 0 |
| 01 | 0 | 0 | 0 | 1 |
| 02 | 0 | 0 | 1 | 0 |
| 03 | 0 | 0 | 1 | 1 |
| 04 | 0 | 1 | 0 | 0 |
| 05 | 0 | 1 | 0 | 1 |
| INT., LOW GAIN | 0 | 1 | 1 | 0 |
| 06 | 0 | 1 | 1 | 1 |
| 16 | 1 | 0 | 0 | 0 |
| INT., HIGH GAIN | 1 | 0 | 0 | 1 |
| 10 | 1 | 0 | 1 | 0 |
| 11 | 1 | 0 | 1 | 1 |
| 12 | 1 | 1 | 0 | 0 |
| 13 | 1 | 1 | 0 | 1 |
| 14 | 1 | 1 | 1 | 0 |
| 15 | 1 | 1 | 1 | 1 |

HB 281

15.

508T

6.3 LC105 SELF TESTS (UNIT 0)

6.31 The following describes the steps used to self test the LC105 circuit packs.

6.311 Initialize Maintenance Circuit. The LC105 time slot shift register, receiver and source flip flops are cleared. The failure code returned during this is a 98, which means that the network failed to complete the commands sent to it.

6.312 Write Time Slot into Maintenance circuit:

- a) A search is made for two idle time slots, one in each bus. The time slot found for one bus must match the one in the other bus. The time slot # is then written into the LC105 shift register. If two time slots cannot be found, failure code "99" is indicated.
- b) The time slot written into the LC105 is then checked. If it is not correct, failure code "1" is indicated.
- c) The LC105 receiver is then enabled, and the LC105 threshold detector is neutralized, and checked. If the detector cannot neutralize, a failure code of "2" is indicated.

6.313 High Frequency, Low gain loop around test:

The Group Select and Carrier Select are set to the internal low gain loop around test. The tone source is set to high frequency and then the threshold detector is checked for a correct response. An incorrect threshold response is indicated by failure code "3".

6.314 Low Frequency, Low gain loop around test:

First the threshold detector is neutralized and the source is set to a low frequency. The threshold detector is then checked for a correct response. If the level is incorrect, failure code "4" is indicated.

6.315 High Frequency, High Gain loop around test:

The Group Select and Carrier Select are set to internal high gain loop around test. The source is set to high frequency and then the threshold detector is checked. If the threshold is incorrect, a failure code of "6" is indicated.

6.316 Low Frequency, High gain loop around test:

First the threshold detector is neutralized and the source is set to a low frequency. The threshold detector is checked for a correct response; and if it is incorrect, a failure code of "10" is indicated.

6.317 Power Return Flip Flop and Network Clock Gate Tests:

- a) First the LC105 maintenance FF outputs are scanned, and the power return flip flop is checked to see what state it is in. It is then set to the opposite state and checked to see that it did change state. Finally, it is then set to the original state. If the flip-flop fails to switch states, a failure code of 18 is indicated.
- b) The network clock scan lead (NCKSCN) is then checked; if it is for a line group control carrier and the scan lead indicates a clock failure, a failure code of 19 is indicated.

6.318 Release Time Slot and Connection Number:

The LC105 maintenance circuit is reinitialized, (time slot shift register is cleared, receiver is disabled, and source is disabled), and the routine clears record of time slot from memory tables.

6.4 AMPLIFIERS AND BUS SELECT SWITCHES

6.41 The following describes the steps used to perform the unit 1 type tests.

6.411 Initialize Maintenance Ckt. Initialize LC105, clear the time slot shift register, disable receiver and disable the source.

6.412 Write Time into Maintenance Circuit

- a) Get two time slots - one in bus "0" and one in bus "1". Both time slots must be the same number. If matching time slots cannot be found, a failure code of "99" is indicated.
- b) Check the time slot written into the LC105 time slot register. If an error is found, a failure code of "1" is indicated.
- c) Enable the receiver and neutralize the LC105 threshold level detector. Check the scan leads to verify that the threshold detector is neutralized. If the threshold detector is not neutralized, a failure code of "2" is indicated.

6.413 Amplifier and Bus Select Switch Transmission Test

- a) Enable the LC105 receiver.
- b) Starting with Bus "0" and 1st Group (Line or Trunk) Control Carrier, select the Group Select (GOS00*) and Carrier Input (CIS00*) leads for that carrier.
- c) Enable the LC105 source, wait 130 usec, and then disable the source. Check that the threshold level matches the expected threshold level. If threshold level does not match, indicate failure code of "31" and gain detected.

6.414 Carrier Input Bus Select Switch Test

Disable the Carrier Input select and enable the Group Output select. Check the scan leads for a detectable level; and if anything is detected, indicate a failure code of "33".

6.415 Group Output Bus Select Switch Test

Disable the Group Select by choosing the opposite bus for the carrier under test and enable the Carrier Input select. Check for no detectable output; and if anything is detected, indicate a failure code of "32".

6.416 3 Way Pad Switch Test

- a) Insert the three way pad. Enable source and receiver and check that the level detected is not at the normal level,

(i.e. when the 3 way pad is not inserted).
If the threshold level is still at the
normal level, then a failure code of 35
is indicated.

- 6.417 Repeat steps 6.411 thru 6.416 for Bus 1.
- 6.418 Go back to Bus "0" and next carrier, (if all
carriers have been tested, go to next cabinet),
and repeat steps 6.411 thru 6.417.
- 6.419 After all carriers within the cabinet have been
tested, go to the next module and repeat steps
6.411 thru 6.418.

CABLE TO GROUP (CTG--) CONNECTIONS FOR BUS "0"

| LEAD DESIGN. | F R O M | | | | | T O | | | | COAX CABLE TERM | COMMENTS | |
|--------------|---------|-------------|--------------|------------|------------|------|-------------|--------------|------------|-----------------|------------------|-------------|
| | CAB. | CARR. LEVEL | CONN (CABLE) | LC103 TERM | LC104 TERM | CAB. | CARR. LEVEL | CONN (CABLE) | LC102 TERM | | | |
| CTG00 | 0 | 0 | MC11 | 94 | - | 2 | 0 | LG08 | 59 | 2 | Line Group | |
| CTG01 | 0 | 0 | MC13 | 95 | - | 3 | 0 | LG08 | 59 | 2 | | |
| CTG02 | 0 | 0 | MC07 | 96 | - | 1 | 1 | LG08 | 59 | 2 | | |
| | | | | | | 4 | 0 | | | | | |
| CTG03 | 0 | 0 | MC14 | 97 | - | 0 | 1 | LG08 | 59 | 2 | | |
| CTG04 | 0 | 0 | - | 65 | - | 0 | 0 | - | 59 | - | | Trunk Group |
| CTG05 | 0 | 0 | MC19 | 66 | - | 1 | 0 | MC20 | 59 | 7 | | |
| CTG06 | 0 | 0 | MC10 | - | 96 | 0 | 2-4 | L01 | 59 | 2 | 1st Link Carrier | |
| CTG07 | 0 | 0 | MC16 | - | 97 | 1 | 2-4 | L01 | 59 | 5 | 2nd Link Carrier | |

CABLE TO GROUP (CTG--) CONNECTIONS FOR BUS "1"

| LEAD DESIGN. | F R O M | | | | | T O | | | | COAX CABLE TERM | COMMENTS |
|--------------|---------|-------------|--------------|------------|------------|------|-------------|--------------|------------|-----------------|------------------|
| | CAB. | CARR. LEVEL | CONN (CABLE) | LC103 TERM | LC104 TERM | CAB. | CARR. LEVEL | CONN (CABLE) | LC102 TERM | | |
| CTG10 | 1 | 0 | MC11 | 94 | - | 2 | 0 | LG10 | 59 | 2 | Line Group |
| CTG11 | 1 | 0 | MC13 | 95 | - | 3 | 0 | LG10 | 59 | 2 | |
| CTG12 | 1 | 0 | MC07 | 96 | - | 1 | 1 | LG10 | 59 | 2 | |
| | | | | | | 4 | 0 | | | | |
| CTG13 | 1 | 0 | MC14 | 97 | - | 0 | 1 | LC10 | 59 | 2 | |
| CTG14 | 1 | 0 | MC19 | 65 | - | 0 | 0 | MC20 | 59 | 3 | Trunk Group |
| CTG15 | 1 | 0 | - | 66 | - | 1 | - | - | 59 | - | |
| CTG16 | 1 | 0 | MC10 | - | 96 | 0 | 2-4 | L03 | 59 | 2 | 1st Link Carrier |
| CTG17 | 1 | 0 | MC16 | - | 97 | 1 | 2-4 | L03 | 59 | 2 | 2nd Link Carrier |

TABLE A

CABLE FROM GROUP (CFG--) FOR BUS "0" CONNECTIONS

| LEAD DESIG. | F R O M | | | | T O | | | | | COAX CABLE TERM | COMMENTS |
|----------------|---------|----------------|-----------------|---------------|------|----------------|-----------------|---------------|---------------|-----------------------|---|
| | CAB. | CARR. LEVEL | CONN (CABLE) | LC102 TERM | CAB. | CARR. LEVEL | CONN (CABLE) | LC103 TERM | LC104 TERM | | |
| CFG00 | 2 | 0 | LG08 | 99 | 0 | 0 | MC11 | 81 | 81 | 4 | Line Group to Module Control Connections. |
| CFG01 | 3 | 0 | LG08 | 99 | 0 | 0 | MC13 | 82 | 82 | 4 | |
| CFG02 | 1 | 1 | LG08 | 99 | 0 | 0 | MC07 | 83 | 83 | 4 | |
| | 4 | 0 | | | | | | | | | |
| CFG03 | 0 | 1 | LG08 | 99 | 0 | 0 | MC14 | 88 | 88 | 4 | |
| CFG04 | 0 | 0 | - | 99 | 0 | 0 | - | 89 | 89 | - | Trunk Group |
| CFG05 | 1 | 0 | MC20 | 99 | 0 | 0 | MC19 | 90 | 90 | 9 | |
| CFG06 | 0 | 2-4 | L01 | 99 | 0 | 0 | MC10 | 91 | - | 4 | 1st Link Carrier |
| CFG07 | 1 | 2-4 | L01 | 99 | 0 | 0 | MC16 | 92 | - | 4 | 2nd Link Carrier |

CABLE FROM GROUP (CFG--) FOR BUS "1" CONNECTIONS

| LEAD DESIG. | F R O M | | | | T O | | | | | COAX CABLE TERM | COMMENTS |
|----------------|---------|----------------|-----------------|---------------|------|----------------|-----------------|---------------|---------------|-----------------------|---|
| | CAB. | CARR. LEVEL | CONN (CABLE) | LC102 TERM | CAB. | CARR. LEVEL | CONN (CABLE) | LC103 TERM | LC104 TERM | | |
| CFG10 | 2 | 0 | LG10 | 99 | 1 | 0 | MC11 | 81 | 81 | 4 | Line Group to Module Control Connections. |
| CFG11 | 3 | 0 | LG10 | 99 | 1 | 0 | MC13 | 82 | 82 | 4 | |
| CFG12 | 1 | 1 | LG10 | 99 | 1 | 0 | MC07 | 83 | 83 | 4 | |
| | 4 | 0 | | | | | | | | | |
| CFG13 | 0 | 1 | LG10 | 99 | 1 | 0 | MC14 | 88 | 88 | 4 | |
| CFG14 | 0 | 0 | MC20 | 99 | 1 | 0 | MC19 | 89 | 89 | 5 | Trunk Group |
| CFG15 | 1 | 0 | - | 99 | 1 | 0 | - | 90 | 90 | - | |
| CFG16 | 0 | 2-4 | L03 | 99 | 1 | 0 | MC10 | 91 | - | 4 | 1st Link Group |
| CFG17 | 1 | 2-4 | L03 | 99 | 1 | 0 | MC16 | 92 | - | 4 | 2nd Link Group |

TABLE B

HB 281

21.

508T

MODULE CONTROL CABINET
CFC --, CTC --- PAM COAX CABLE CONNECTIONS

| LEAD DESIG. | FROM LC101 TERM | TO BUS "0" LC102 TERM | TO BUS "1" LC102 TERM | CO-AX CABLE TERM | FROM CONN | TO LEVEL | TO CONN | COMMENTS |
|---------------------------|-----------------------|--------------------------------|--------------------------------|------------------------|--------------|-------------|-------------|---|
| CFCAO CTCOA) CTC1AO | 68 92 95 | 93 64 | 93 64 | X X X | X X X | 0 | X X X | ALL WIRING INTERNAL TO MODULE CONTROL CARRIER |
| CFCBO CTCOBO CTC1BO | 68 92 95 | 94 65 | 65 | 8 14 9 | MC09 | 1 | T01 | -TRUNK PORT CARRIER |
| CFCCO CTCOCO CTC1CO | 68 92 95 | 95 66 | 66 | 8 14 9 | MC12 | 2 | T01 | -TRUNK PORT CARRIER |
| CFCDO CTCODO CTC1DO | 68 92 95 | 96 67 | 67 | 8 14 9 | MC03 | 3 | T01 | -TRUNK PORT CARRIER |
| CFCEO CTCOEO CTC1EO | 68 92 95 | 97 68 | 68 | 8 14 9 | MC05 | 4 | T01 | -TRUNK PORT CARRIER |

TABLE C

LINK CARRIERS
CFC --, CTC --- PAM COAX CABLE CONNECTIONS

| LEAD DESIG. | FROM LC101 TERM | TO BUS "0" LC102 TERM | TO BUS "1" LC102 TERM | COAX CABLE TERM | FROM CONN (CABLE) | TO LEVEL | TO CONN (CABLE) | COMMENTS |
|----------------|-----------------------|--------------------------------|--------------------------------|-----------------------|-------------------------|--------------|-----------------------|------------------|
| CFCA2 | 68 | 93 | - | | X | X | X | |
| CTCOA2 | 92 | 64 | - | | | | | |
| CTC1A2 | 95 | - | 64 | | | | | |
| CFCB2 | 68 | 94 | - | | | | | |
| CTCOB2 | 92 | 65 | - | | | | | |
| CTC1B2 | 95 | - | 65 | | | | | |
| CFCC2 | 68 | 95 | - | 3 | L04 | 3 or 4 | L05 | 2nd LINK CARRIER |
| CTCOC2 | 92 | 66 | - | 7 | | | | |
| CTC1C2 | 95 | - | 66 | 9 | | | | |
| CFCD2 | 68 | 96 | - | 13 | L04 | 3 or 4 | L05 | 2nd LINK CARRIER |
| CTCOD2 | 92 | 67 | - | 17 | | | | |
| CTC1D2 | 95 | - | 67 | 19 | | | | |

TABLE C (Cont'd)

HB 281

23.

508T

LINE GROUP CONTROL CARRIER
CFC --, CTC ---, PAM CABLE CONNECTIONS

| LEAD DESIG. | FROM LC101 TERM | TO BUS "0" LC102 TERM | TO BUS "1" LC102 TERM | COAX CABLE TERM | FROM CONN (CABLE) | TO LEVEL | TO CONN (CABLE) | COMMENTS |
|----------------|-----------------------|--------------------------------|--------------------------------|-----------------------|-------------------------|-------------|-----------------------|--|
| CFCA1 | 68 | 93 | 93 | X | X | 0 | X | Internally Wired Within Line Group Control Carrier |
| CTCOA1 | 92 | 64 | | | | | | |
| CTC1A1 | 95 | | 64 | | | | | |
| CFCB1 | 68 | 94 | 94 | 2 | LG09 | 1 | LK01 | LINE PORT CARRIER |
| CTCOB1 | 92 | 4 65 | | 15 | | | | |
| CTC1B1 | 95 | | 65 | 3 | | | | |
| CFCC1 | 68 | 95 | 95 | 2 | LG07 | 2 | LK01 | LINE PORT CARRIER |
| CTCOC1 | 92 | 66 | | 15 | | | | |
| CTC1C1 | 95 | | 66 | 3 | | | | |
| CFCD1 | 68 | 96 | 96 | 2 | LG06 | 3 | LK01 | LINE PORT CARRIER |
| CTCOD1 | 92 | 67 | | 15 | | | | |
| CTC1D1 | 95 | | 67 | 3 | | | | |
| CFCE1 | 68 | 97 | 97 | 2 | LG05 | 4 | LK01 | LINE PORT CARRIER |
| CTCOE1 | 92 | 68 | | 15 | | | | |
| CTC1E1 | 95 | | 68 | 3 | | | | |

TABLE C (Cont'd)

MODULE CONTROL CABINET
GOS- -, CIS - - FLAT CABLE CONNECTIONS

| LEAD DESIGN. | FROM LC105 TERM | TO LC101 TERM | FLAT CABLE TERM. | FROM CONN | TO LEVEL | TO CONN | COMMENTS |
|--------------|-----------------|---------------|------------------|-----------|--------------|--------------------------|--|
| GOS00 | 100 | 2 | X | X | 0 | X | All Wiring Within Module Control Carrier |
| GOS10 | 99 | 3 | | | | | |
| CIS00 | 50 | 66 | | | | | |
| CIS10 | 49 | 74 | | | | | |
| GOS01 | 98 | 2 | 3 | MC15 | 1 | LG11 Or T09 | -Line Group Control Carrier Or -Trunk Port Carrier |
| GOS11 | 97 | 3 | 2 | | | | |
| CIS01 | 48 | 66 | 12 | | | | |
| CIS11 | 47 | 74 | 16 | | | | |
| GOS02 | 96 | 2 | 3 | MC08 | 2 | L06 T09 or LK09 | -Link Carrier Or -Trunk Port Carrier Or -Line Port Carrier |
| GOS12 | 95 | 3 | 2 | | | | |
| CIS02 | 46 | 66 | 12 | | | | |
| CIS12 | 45 | 74 | 16 | | | | |
| GOS03 | 94 | 2 | 3 | MC02 | 3 | L06 T09 or LK09 | -Link Carrier Or -Trunk Port Carrier Or -Line Port Carrier |
| GOS13 | 93 | 3 | 2 | | | | |
| CIS03 | 44 | 66 | 12 | | | | |
| CIS13 | 43 | 74 | 16 | | | | |
| GOS04 | 92 | 2 | 3 | MC01 | 4 | L06 T09 or LK09 | -Link Carrier Or -Trunk Port Carrier Or -Line Port Carrier |
| GOS14 | 91 | 3 | 2 | | | | |
| CIS04 | 42 | 66 | 12 | | | | |
| CIS14 | 41 | 74 | 16 | | | | |
| GOS05 | 90 | 2 | 3 | MC04 | 3 or 4 | L11 | Link Carrier |
| GOS15 | 89 | 3 | 2 | | | | |
| CIS05 | 40 | 66 | 12 | | | | |
| CIS15 | 39 | 74 | 16 | | | | |
| GOS06 | 88 | 2 | 3 | MC18 | 2 | L11 | Link Carrier |
| GOS16 | 87 | 3 | 2 | | | | |
| CIS06 | 36 | 66 | 12 | | | | |
| CIS16 | 84 | 74 | 16 | | | | |

TABLE D

HB 281

25.

508T

LINE GROUP CONTROL CABINET
GOS --, CIS --, FLAT CABLE CONNECTIONS

| LEAD DESIGN. | FROM LC105 TERM | TO LC101 TERM | FLAT CABLE TERM | FROM CONN (CABLE) | TO LEVEL | TO CONN (CABLE) | COMMENTS |
|--------------|-----------------|---------------|-----------------|-------------------|----------|-----------------|--|
| GOS00 | 100 | 2 | X | X | 0 | X | Internally wired within Line Group Control Carrier |
| GOS10 | 99 | 3 | | | | | |
| CIS00 | 50 | 66 | | | | | |
| CIS10 | 49 | 74 | | | | | |
| GOS01 | 98 | 2 | 3 | LG12 | 1 | LK09 | To First Line Port Carrier |
| GOS11 | 97 | 3 | 2 | | | | |
| CIS01 | 48 | 66 | 12 | | | | |
| CIS11 | 47 | 74 | 16 | | | | |
| GOS02 | 96 | 2 | 3 | LG03 | 2 | LK09 | To 2nd Line Port Carrier |
| GOS12 | 95 | 3 | 2 | | | | |
| CIS02 | 46 | 66 | 12 | | | | |
| CIS12 | 45 | 74 | 16 | | | | |
| GOS03 | 94 | 2 | 3 | LG04 | 3 | LK09 | To 3rd Line Port Carrier |
| GOS13 | 93 | 3 | 2 | | | | |
| CIS03 | 44 | 66 | 12 | | | | |
| CIS13 | 43 | 74 | 16 | | | | |
| GOS04 | 92 | 2 | 3 | LG01 | 4 | LK09 | To 4th Line Port Carrier |
| GOS14 | 91 | 3 | 2 | | | | |
| CIS04 | 42 | 66 | 12 | | | | |
| CIS14 | 41 | 74 | 16 | | | | |

TABLE D (Cont'd)

PAM CO-AX CABLE CONNECTIONS
MODULE CONTROL CABINET

| LEAD DESIGN. | LC105 TERM | LC101 TERM | CO-AX CABLE TERM | FROM CONN | TO LEVEL | TO CONN | COMMENTS |
|--------------|------------|------------|------------------|-----------|----------|---------|--|
| TTS0 | 80 | 67 | - | X | 0 | X | Internally Wired |
| TTR0 | 30 | 38 | - | | | | |
| TTS1 | 79 | 67 | 2 | MC09 | 1 | TO1 | -Trunk Port Carrier See Line Group Carrier Below |
| TTR1 | 29 | 38 | 13 | | | | |
| TTS2 | 78 | 67 | 2 | MC12 | 2 | L02 | -Link Carrier or -Trunk Port Carrier |
| TTR2 | 28 | 38 | 13 | | | | |
| TTS3 | 77 | 67 | 2 | MC03 | 3 | L02 | -Link Carrier or -Trunk Port Carrier |
| TTR3 | 27 | 38 | 13 | | | | |
| TTS4 | 76 | 67 | 2 | MC05 | 4 | L02 | -Link Carrier or -Trunk Port Carrier |
| TTR4 | 26 | 38 | 13 | | | | |
| TTS5 | 75 | 67 | 5 | MC03 | 3 or 4 | L02 | -Link Carrier or Trunk Port Carrier |
| TTR5 | 25 | 38 | 19 | MC05 | | | |
| TTS6 | 74 | 67 | 5 | MC12 | 2 | L02 | -Link Carrier or Trunk Port Carrier |
| TTR6 | 24 | 38 | 19 | | | | |
| LEAD DESIGN. | LC105 TERM | LC105 TERM | CO-AX CABLE TERM | FROM CONN | TO LEVEL | TO CONN | |
| TTS1 | 79 | 80 | 2 | MC06 | 1 | LG02 | Line Group Control Carrier. <u>NOTE:</u> Connections to Line Port Carriers Made Via This Carrier. |
| TTR1 | 29 | 30 | 12 | | | | |
| TTS2 | 78 | 67 | 6 | | | | |
| TTR2 | 28 | 38 | 16 | | | | |
| TTS3 | 77 | 77 | 8 | | | | |
| TTR3 | 27 | 27 | 18 | | | | |
| TTS4 | 76 | 76 | 4 | | | | |
| TTR4 | 26 | 26 | 14 | | | | |

TABLE E

HB 281

27.

508T

LINE GROUP CONTROL CARRIER
TTS -, TTR - COAX PAM CABLE CONNECTIONS

| LEAD DESIGN. | FROM LC105 TERM | TO LC101 TERM | COAX CABLE TERM | FROM CONN (CABLE) | TO LEVEL | TO CONN TERM | COMMENTS |
|--------------|-----------------|---------------|-----------------|-------------------|----------|--------------|-------------------|
| TTS0 | 80 | 67 | - | X | 0 | X | Internally Wired |
| TTR0 | 30 | 38 | - | | | | |
| TTS1 | 79 | 67 | 5 | LG09 | 1 | LK01 | Line Port Carrier |
| TTR1 | 29 | 38 | 12 | | | | |
| TTS2 | 78 | 67 | 5 | LG07 | 2 | LK01 | Line Port Carrier |
| TTR2 | 28 | 38 | 12 | | | | |
| TTS3 | 77 | 67 | 5 | LG06 | 3 | LK01 | Line Port Carrier |
| TTR3 | 27 | 38 | 12 | | | | |
| TTS4 | 76 | 67 | 5 | LG05 | 4 | LK01 | Line Port Carrier |
| TTR4 | 26 | 38 | 12 | | | | |

TABLE E (Cont'd)

MODULE CONTROL CARRIERS
CBI_ _*. GBI_ _*, LCP_ _*, FLAT CABLE CONNECTIONS

| LEAD DESIG. | FROM | | | | VIA CABLE | | | TO | | | | COMM- ENTS |
|---|------|-----|------|-------|-----------|----------------|-------|------|-----|------|-------|---------------|
| | CAB. | LC- | SLOT | TERM. | CONN. | CONN. TERM. | CONN. | CAB. | LC- | SLOT | TERM. | |
| CBI0A0* | 0/1 | 101 | -- | 96 | --- | -- | --- | 0/1 | 102 | 03 | 83 | Bus 0 |
| CBI0B0* | 0/1 | 101 | 01 | 96 | T09 | 18 | MC15 | 0/1 | 102 | 03 | 82 | Bus 0 |
| CBI0C0* | 0/1 | 101 | 01 | 96 | T09 | 18 | MC08 | 0/1 | 102 | 03 | 81 | Bus 0 |
| CBI0D0* | 0/1 | 101 | 01 | 96 | T09 | 18 | MC02 | 0/1 | 102 | 03 | 89 | Bus 0 |
| CBI0E0* | 0/1 | 101 | 01 | 96 | T09 | 18 | MC01 | 0/1 | 102 | 03 | 88 | Bus 0 |
| CBI1A0* | 0/1 | 101 | -- | 76 | --- | -- | --- | 0/1 | 102 | 04 | 83 | Bus 1 |
| CBI1B0* | 0/1 | 101 | 01 | 76 | T09 | 13 | MC15 | 0/1 | 102 | 04 | 82 | Bus 1 |
| CBI1C0* | 0/1 | 101 | 01 | 76 | T09 | 13 | MC08 | 0/1 | 102 | 04 | 81 | Bus 1 |
| CBI1D0* | 0/1 | 101 | 01 | 76 | T09 | 13 | MC02 | 0/1 | 102 | 04 | 89 | Bus 1 |
| CBI1E0* | 0/1 | 101 | 01 | 76 | T09 | 13 | MC01 | 0/1 | 102 | 04 | 88 | Bus 1 |
| <p>NOTE: When a line group control carrier is in a Module Control Cabinet, see Line Group Control Carrier in cabinets "0" and "1".</p> | | | | | | | | | | | | |
| GBI04* | 0 | 121 | 27 | 57 | --- | -- | --- | 0 | 102 | 03 | 80 | Bus 0 |
| GBI05* | 0 | 121 | 27 | 56 | MC27 | 2 | MC21 | 1 | 102 | 03 | 80 | Bus 0 |
| GBI14* | 1 | 121 | 27 | 57 | MC28 | 6 | MC22 | 0 | 102 | 04 | 80 | Bus 1 |
| GBI15* | 1 | 121 | 27 | 56 | --- | -- | --- | 1 | 102 | 04 | 80 | Bus 1 |
| LCP04* | 0 | 121 | 27 | 5 | --- | -- | --- | 0 | 102 | 03 | 56 | Bus 0 |
| LCP05* | 0 | 121 | 27 | 4 | MC27 | 4 | MC21 | 1 | 102 | 03 | 56 | Bus 0 |
| LCP14* | 1 | 121 | 27 | 5 | MC28 | 8 | MC22 | 0 | 102 | 04 | 56 | Bus 1 |
| LCP15* | 1 | 121 | 27 | 4 | --- | -- | --- | 1 | 102 | 04 | 56 | Bus 1 |

TABLE F

LINK CARRIER CABLING
CBI_ _ _ *, GBI_ _ *, FLAT CABLE CONNECTIONS

| LEAD DESIG. | FROM | | | | VIA CABLE | | | TO | | | | COMM- ENTS |
|----------------|------|-----|------|-------|-----------|----------------|-------|------|-----|------|-------|---------------|
| | CAB. | LC- | SLOT | TERM. | CONN. | CONN. TERM. | CONN. | CAB. | LC- | SLOT | TERM. | |
| CBI0A2* | 0/1 | 101 | 03 | 96 | --- | -- | --- | 0/1 | 102 | 01 | 83 | Bus 0 |
| CBI0B2* | 0/1 | 101 | 16 | 96 | --- | -- | --- | 0/1 | 102 | 01 | 82 | Bus 0 |
| CBI0C2* | 0/1 | 101 | 03 | 96 | L10 | 2 | L08 | 0/1 | 102 | 01 | 81 | Bus 0 |
| CBI0D2* | 0/1 | 101 | 16 | 96 | L10 | 6 | L08 | 0/1 | 102 | 01 | 89 | Bus 0 |
| CBI1A2* | 0/1 | 101 | 03 | 76 | --- | -- | --- | 0/1 | 102 | 02 | 83 | Bus 1 |
| CBI1B2* | 0/1 | 101 | 16 | 76 | --- | -- | --- | 0/1 | 102 | 02 | 82 | Bus 1 |
| CBI1C2* | 0/1 | 101 | 03 | 76 | L10 | 4 | L08 | 0/1 | 102 | 02 | 81 | Bus 1 |
| CBI1D2* | 0/1 | 101 | 16 | 76 | L10 | 8 | L08 | 0/1 | 102 | 02 | 89 | Bus 1 |
| GBI06* | 0 | 121 | 27 | 55 | MC10 | 9 | L01 | 0 | 102 | 01 | 80 | Bus 0 |
| GBI07* | 0 | 121 | 27 | 54 | MC16 | 9 | L01 | 1 | 102 | 01 | 80 | Bus 0 |
| GBI16* | 1 | 121 | 27 | 55 | MC10 | 9 | L03 | 0 | 102 | 02 | 80 | Bus 1 |
| GBI17* | 1 | 121 | 27 | 54 | MC16 | 9 | L03 | 1 | 102 | 02 | 80 | Bus 1 |

TABLE F (Cont'd)

LINE GROUP CONTROL CARRIER IN CABINETS "0" OR "1"
 CBI_ _ _ *, GBI_ _ *, LCP_ _ *, FLAT CABLE CONNECTIONS

| LEAD DESIG. | FROM | | | | VIA CABLE | | | TO | | | | COMM- ENTS |
|--|------|-----|------|-------|-----------|----------------|-------|------|-----|------|-------|---------------|
| | CAB. | LC- | SLOT | TERM. | CONN. | CONN. TERM. | CONN. | CAB. | LC- | SLOT | TERM. | |
| CBI0A1* | 0/1 | 101 | -- | 96 | --- | -- | --- | 0/1 | 102 | 02 | 83 | Bus 0 |
| CBI0B1* | -- | -- | -- | -- | --- | -- | --- | -- | -- | -- | -- | -- |
| CBI0C1* | 0/1 | 101 | 01 | 96 | 2LK09 | 96 | MC08 | 0/1 | 102 | 02 | 81 | Bus 0 |
| CBI0D1* | 0/1 | 101 | 01 | 96 | 3LK09 | 96 | MC02 | 0/1 | 102 | 02 | 89 | Bus 0 |
| CBI0E1* | 0/1 | 101 | 01 | 96 | 4LK09 | 96 | MC01 | 0/1 | 102 | 02 | 88 | Bus 0 |
| CBI1A1* | 0/1 | 101 | -- | 76 | --- | -- | --- | 0/1 | 102 | 02 | 83 | Bus 1 |
| CBI1B1* | -- | -- | -- | -- | --- | -- | --- | -- | -- | -- | -- | -- |
| CBI1C1* | 0/1 | 101 | 01 | 76 | 2LK09 | 76 | MC08 | 0/1 | 102 | 03 | 81 | Bus 1 |
| CBI1D1* | 0/1 | 101 | 01 | 76 | 3LK09 | 76 | MC02 | 0/1 | 102 | 03 | 89 | Bus 1 |
| CBI1E1* | 0/1 | 101 | 01 | 76 | 4LK09 | 76 | MC01 | 0/1 | 102 | 03 | 88 | Bus 1 |
| <p><u>NOTE:</u> CABLING LG13 to MC17 routes CBI(0-1) (C-E) 1* leads from Module Control Carrier to line group control carrier.</p> | | | | | | | | | | | | |
| GBI03* | 0 | 121 | 27 | 58 | MC31 | 3 | LG23 | 0 | 102 | 02 | 80 | Bus 0 |
| GBI02* | 0 | 121 | 27 | 59 | MC33 | 3 | LG23 | 1 | 102 | 02 | 80 | Bus 0 |
| GBI13* | 1 | 121 | 27 | 58 | MC31 | 3 | LG26 | 0 | 102 | 03 | 80 | Bus 1 |
| GBI12* | 1 | 121 | 27 | 59 | MC33 | 3 | LG26 | 1 | 102 | 03 | 80 | Bus 1 |
| LCP03* | 0 | 121 | 27 | 7 | MC31 | 2 | LG23 | 0 | 102 | 02 | 56 | Bus 0 |
| LCP02* | 0 | 121 | 27 | 6 | MC33 | 2 | LG23 | 1 | 102 | 02 | 56 | Bus 0 |
| LCP13* | 1 | 121 | 27 | 7 | MC31 | 2 | LG26 | 0 | 102 | 03 | 56 | Bus 1 |
| LCP12* | 1 | 121 | 27 | 6 | MC33 | 2 | LG26 | 1 | 102 | 03 | 56 | Bus 1 |


TABLE F (Cont'd)

LINE GROUP CONTROL CARRIER IN CABINETS 2 THROUGH 4
 CBI_ _ _ *, GBI_ _ *, LCP_ _ *, FLAT CABLE CONNECTIONS


| LEAD DESIG. | FROM | | | | VIA CABLE | | | TO | | | | COMM- ENTS |
|----------------|------|-----|------|-------|-----------|----------------|-------|------|-----|------|-------|---------------|
| | CAB. | LC- | SLOT | TERM. | CONN. | CONN. TERM. | CONN. | CAB. | LC- | SLOT | TERM. | |
| CBIOA1* | 2-4 | 101 | -- | 96 | --- | -- | --- | 2-4 | 102 | 02 | 83 | Bus 0 |
| CBIOB1* | 2-4 | 101 | 01 | 96 | 1LK09 | 19 | LG12 | 2-4 | 102 | 02 | 82 | Bus 0 |
| CBIOC1* | 2-4 | 101 | 01 | 96 | 2LK09 | 19 | LG03 | 2-4 | 102 | 02 | 81 | Bus 0 |
| CBIOD1* | 2-4 | 101 | 01 | 96 | 3LK09 | 19 | LG04 | 2-4 | 102 | 02 | 89 | Bus 0 |
| CBIOE1* | 2-4 | 101 | 01 | 96 | 4LK09 | 19 | LG01 | 2-4 | 102 | 02 | 88 | Bus 0 |
| CBIIA1* | 2-4 | 101 | -- | 76 | --- | -- | --- | 2-4 | 102 | 03 | 83 | Bus 1 |
| CBII B1* | 2-4 | 101 | 01 | 76 | 1LK09 | 14 | LG12 | 2-4 | 102 | 03 | 82 | Bus 1 |
| CBII C1* | 2-4 | 101 | 01 | 76 | 2LK09 | 14 | LG03 | 2-4 | 102 | 03 | 81 | Bus 1 |
| CBII D1* | 2-4 | 101 | 01 | 76 | 3LK09 | 14 | LG04 | 2-4 | 102 | 03 | 89 | Bus 1 |
| CBII E1* | 2-4 | 101 | 01 | 76 | 4LK09 | 14 | LG01 | 2-4 | 102 | 03 | 88 | Bus 1 |
| GBI00* | 0 | 121 | 27 | 61 | MC32 | 3 | LG23 | 2 | 102 | 02 | 80 | Bus 0 |
| GBI01* | 0 | 121 | 27 | 60 | MC30 | 3 | LG23 | 3 | 102 | 02 | 80 | Bus 0 |
| GBI02* | 0 | 121 | 27 | 59 | MC33 | 3 | LG23 | 4 | 102 | 02 | 80 | Bus 0 |
| GBII0* | 1 | 121 | 27 | 61 | MC32 | 3 | LG26 | 2 | 102 | 03 | 80 | Bus 1 |
| GBII1* | 1 | 121 | 27 | 60 | MC30 | 3 | LG26 | 3 | 102 | 03 | 80 | Bus 1 |
| GBII2* | 1 | 121 | 27 | 59 | MC33 | 3 | LG26 | 4 | 102 | 03 | 80 | Bus 1 |
| LCP00* | 0 | 121 | 27 | 9 | MC32 | 2 | LG23 | 2 | 102 | 02 | 36 | Bus 0 |
| LCP01* | 0 | 121 | 27 | 8 | MC30 | 2 | LG23 | 3 | 102 | 02 | 36 | Bus 0 |
| LCP02* | 0 | 121 | 27 | 7 | MC33 | 2 | LG23 | 4 | 102 | 02 | 36 | Bus 0 |
| LCPI0* | 1 | 121 | 27 | 9 | MC32 | 2 | LG26 | 2 | 102 | 03 | 36 | Bus 1 |
| LCPI1* | 1 | 121 | 27 | 8 | MC30 | 2 | LG26 | 3 | 102 | 03 | 36 | Bus 1 |
| LCPI2* | 1 | 121 | 27 | 7 | MC33 | 2 | LG26 | 4 | 102 | 03 | 36 | Bus 1 |

TABLE F (Cont'd)

SIMPLIFIED PAM TEST DIAGRAM



(A)...(F) INDICATE TABLE A THRU TABLE F



- NOTES:
1. ALL LINES IN A GROUP MUST BE IN THE SAME NETWORK CABINET. MAXIMUM OF 4 LINE GROUPS PER MODULE.
 2. ALL TRUNKS IN A GROUP MUST BE IN THE SAME NETWORK CABINET. MAXIMUM OF 2 TRUNK GROUPS PER MODULE.
 3. ALL LINKS IN A GROUP MUST BE IN THE SAME NETWORK CABINET. MAXIMUM OF 2 LINK CARRIERS PER GROUP. MAXIMUM OF 2 GROUPS PER MODULE.

CSS 201L NETWORK MODULE TRANSMISSION BLOCK DIAGRAM

Reason for Issue:
New section

MANAGER, DENVER PBX PECC