

DIMENSION® PBX  
FEATURE TEST  
CALL FORWARDING - BUSY AND DON'T ANSWER

\*4

CONTENTS

1. GENERAL INFORMATION
2. RECORDS
3. TEST EQUIPMENT AND DOCUMENTATION
4. TEST SETUP
5. CALL FORWARDING - BUSY AND DON'T ANSWER FEATURE TEST
6. RESTORATION

---

1. GENERAL INFORMATION

1.1 Description

1.11 This section describes the procedures to be used to test the "Call Forwarding - Busy and Don't Answer" feature of the CSS 201 system.

2. RECORDS

2.1 Troubles found during the test should be recorded on SD-97-1313 Trouble Record form.

2.2 Form SD-97-1313 should be sufficiently clear and complete so that the required information can be accurately posted to SD-97-1315.

3. TEST EQUIPMENT AND DOCUMENTATION

3.1 Test Equipment

3-500 Type Telephone Set (Rotary Dial)  
or  
2500 Type Telephone Set (TOUCH-TONE)

3.2 Documentation

3.21 Using the Customer Order Document, determine the following:

3.211 From the Trunk and Feature Dial Code Summary, determine the Call Forwarding - Busy and Don't Answer access code and cancel code. Record on Figure 1.

3.212 From the Class of Service Assignments Table, determine a Class of Service which includes the Call Forwarding - Busy and Don't Answer Feature. Record on Figure 1.

3.213 From the Station Line Assignments Table, select one station line which has a Class of Service, determined in Paragraph 3.212. Record in Figure 1 as Station A.

3.214 Select two station lines which are not restricted from originating calls. Record in Figure 1 as Station B and C.

4. TEST SETUP

4.1 Connect a telephone set to the three stations selected in Paragraphs 3.213 and 3.214. These stations will be referred to as Station A, B or C in the test procedure.

5. CALL FORWARDING - BUSY AND DON'T ANSWER FEATURE TEST

5.01 At Station A go off-hook, dial tone is heard, dial the access code to activate Call Forwarding - Busy and Don't Answer feature.

5.02 Dial tone is heard again.

5.03 Dial the station number for Station B.

5.04 Dial tone is removed and confirmation tone (stutter dial tone) is heard. At the forwarding Station A, go on-hook.

5.05 At Station A go off-hook, dial tone is heard and originate a call to the attendant.

\*4  
#3

PRIVATE

THE INFORMATION CONTAINED HEREIN SHOULD NOT BE DISCLOSED TO UNAUTHORIZED PERSONS. IT IS MEANT SOLELY FOR USE BY AUTHORIZED BELL SYSTEM EMPLOYEES.

5.06 At Station C go off-hook, dial tone is heard and dial the station number for Station A.

5.07 Station B starts ringing in a normal ringing cycle. Answer Station B verifying that a connection has been established between Station B and Station C. Place Station A, B and C on-hook.

5.08 Repeat Paragraph 5.06.

5.09 Station A starts ringing. Station A should ring for approximately 16 seconds, then Station B should start ringing.

5.091 Answer Station B verifying that a connection has been established between Station B and Station C. Place Station B and C on-hook.

5.10 At Station A go off-hook, dial tone is heard. Dial the access code to cancel Call Forwarding. Confirmation tone is heard. Place Station A on-hook.

5.11 At Station C go off-hook, dial tone is heard. Dial the station code for Station A. After 30 seconds, Station A continue to ring. Answer Station A and verify that a connection has been established between Station A and C. Place Station A and C on-hook.

5.12 At the console operate a loop pickup key. Operate the Start key, dial tone is heard. Dial the access code to activate Call Forwarding - Busy and Don't Answer feature. Dial tone is removed and then reapplied. Dial the station code of Station A. Dial tone is removed and then reapplied. Dial the station code of Station B. Dial tone is removed and confirmation tone is applied. Operate the Position Release key.

5.13 Repeat Paragraphs 5.05 through 5.11.

## 6. RESTORATION

6.1 Disconnect the three telephone sets connected in Paragraph 4.1.

Manager, Denver PBX PECC

### ATTACHMENT:

FIGURE 1 on Page 3.

FIGURE 1

CALL FORWARDING - BUSY AND DON'T ANSWER

- 1. CALL FORWARDING -  
BUSY AND DON'T ANSWER DIAL CODE \_\_\_\_\_  
CANCEL CODE \_\_\_\_\_
  
- 2. CLASS OF SERVICE WITH CALL  
FORWARDING - BUSY AND DON'T ANSWER \_\_\_\_\_
  
- 3. STATION LINE WITH CALL FORWARDING  
(DESIGNATE AS STATION A) \_\_\_\_\_
  
- 4A. STATION LINE (ORIGINATING)  
(DESIGNATE AS STATION B) \_\_\_\_\_
  
- 4B. STATION LINE (ORIGINATING)  
(DESIGNATE AS STATION C) \_\_\_\_\_