

405-TYPE DATA SYSTEM AND INTERFACE CIRCUIT FOR MESSAGE REGISTER REMOTING INSTALLATION AND CONNECTIONS

	CONTENTS	PAGE	
1. GENERAL	1	● Means of connecting -48V to 405 data sets.
2. OPTIONS	1	● Means of connecting data set to transmission facility.
A. Data Set 405-Type	1	● Means of connecting to central office (CO) alarm circuits.
B. SD-1C451-01 Interface Circuit	3	● Visual alarm indications for data system (located at interface circuit).
3. INSTALLATION AND CONNECTION PROCEDURE	3	● The originating interface circuit provides a test circuit which may be used to verify cross-connections and to test the delay circuit.
A. Data Set 405A and Interface Circuit	4	● The terminating interface circuit provides an optional 250 to 300 ms delay operating pulse for message registers associated with dial tone speed (machines) register circuits.
B. Data Set 405B and Interface Circuit	5	
4. REFERENCES	9	

1. GENERAL

1.01 This section provides installation and connection procedures to be followed when installing the 405-type Data System used with the SD-1C451-01 interface circuit. In this section, the SD-1C451-01 interface circuit will be referred to as interface circuit.

1.02 The basic 405-type Data System consists of data set (DS) 405A (transmitter) located at the originating end and DS 405B (receiver) located at the terminating end. The data sets are interconnected by a 2-wire private line voiceband channel. An interface circuit (SD-1C451-01) is required to be used with each data set when the system is used for remote register operation.

1.03 The interface circuit provides the following features:

- Wire-wrap cross-connection for 8, 20, or 32 message registers.

1.04 The private line (2-wire) voiceband channel requires conditioning depending on the transmitted bit rate as follows:

- 880 bps—No conditioning
- 1400 bps—C1 conditioning

Note: The output level of DS 405A is factory set to 0 dBm which corresponds to a power level at a +13 dB TLP.

1.05 Each data set and its interface circuit are located in a central office environment.

1.06 This section is to be used in conjunction with Sections 312-809-301 and 312-809-501.

2. OPTIONS

A. Data Set 405-Type

2.01 The data set options required for the remote message register application are factory

SECTION 312-809-201

installed. Verify that factory-furnished options for DS 405A are properly installed per Table A. The factory-furnished options for DS 405A are defined and keyed to Table A as follows:

- **Option Y (Continuous Scan):** This option provides a continuous scan of the input parallel data.
- **Option W (8 Bits Only):** This option provides for 8 input data bits and is limited to data set L1A.
- **No Option W (More Than 8 Bits):** This option provides 20 or 32 input data bits and is limited to data set L1/2 or L1/3, respectively.
- **Option R (880 bps):** This option provides a serial data transmission rate of 880 bits per second.
- **Option Q (1400 bps):** This option provides a serial data transmission rate of 1400 bits per second.

2.02 Verify that factory-furnished options for DS 405B are properly installed per Table B.

The factory-furnished options for DS 405B are defined and keyed to Table B as follows:

- **Option Y (End of Word Check):** This option provides monitoring of the end-of-word signal for proper pattern. This is used in conjunction with the continuous scan mode of DS 405A (also designated option Y).
- **Option W (8 Bits Only):** This option provides for 8 input data bits and is limited to data set L1A.
- **No Option W (More Than 8 Bits):** This option provides 20 or 32 input data bits and is limited to data sets L1/2 or L1/3, respectively.
- **Option R (Mark Hold):** The mark hold option forces all outputs open during an alarm condition or loss of power.
- **Option N (880 bps):** This option provides a serial data transmission rate of 880 bits per second.
- **Option M (1400 bps):** This option provides a serial data transmission rate of 1400 bits per second.

**TABLE A
405A-TYPE TRANSMITTER FACTORY-FURNISHED OPTIONS**

OPTION	DESIG	CONNECT TERMINALS	405A LIST NO.		
			L1A	L1/2	L1/3
Continuous Scan	Y	2 (BE 70) to 13 (BE 70) 6 (BE 70) to 19 (BE 70) 4 (BE 70) to 7 (BE 89)	X	X	X
8 Bits Only	W	3 (BE 70) to 27 (BE 70)	X		
More Than 8 Bits	No W			X	X
880 BPS	R	2 (BE 67) to 10 (BE 67) Close S2, Open S1	X	X	
1400 BPS	Q	2 (BE 67) to 8 (BE 67) Close S1, Open S2			X

Note: An X indicates a factory-furnished option.
S1 and S2 are located on BE 67 circuit pack.

TABLE B
405B-TYPE RECEIVER FACTORY-FURNISHED OPTIONS

OPTION	DESIG	CONNECT TERMINALS	405A LIST NO.		
			L1A	L1/2	L1/3
End of Word Check	Y	7 (BE 68) to 10 (BE 71)	X	X	X
8 Bits Only	W	9 (BE 71) to 30 (BE 71)	X		
More Than 8 Bits	No W			X	X
Mark Hold	R	6 (BE 68) to 25 (BE 71)	X	X	X
880 BPS	N	2 (BE 67) to 10 (BE 67) Close S2, Open S1	X	X	
1400 BPS	M	2 (BE 67) to 8 (BE 67) Close S1, Open S2			X

Note: An X indicates a factory-furnished option.
S1 and S2 are located on BE 67 circuit pack.

B. SD-1C451-01 Interface Circuit

2.03 The interface circuit provides wiring options which are installed per local operating needs. The interface options are defined as follows:

- **Option W:** Major central office alarm (connected to pins 12 and 13) at transmitting and/or receiving interface circuit.
- **Option X:** Minor central office alarm (connected to pins 12 and 13) at transmitting and/or receiving interface circuit.
- **Option Y:** 250 ms delay circuit associated with dial tone speed register in receiving interface circuit only. Refer to Fig. 1.

- **Option Z:** Receiving interface circuit with *no* 250 ms delay circuit or transmitting interface circuit.

3. INSTALLATION AND CONNECTION PROCEDURE

3.01 Figure 1 illustrates the connecting arrangement for the 405-type Data System (with expansion units as required) when arranged for remote message register operation. Table C provides the interface pin assignment for the 405-type Data System. Table C is used in conjunction with Fig. 1 when installing the 405-type Data System. The procedure is as follows:

STEP	PROCEDURE
1	<p>A. Data Set 405A and Interface Circuit</p> <p>Mount data set as required (23- or 25-inch wide central office frame).</p>
2	<p>Mount transmitting interface circuit directly above or below data set. (Do not plug data set and interface circuit together until after Step 3.)</p> <p><i>Note:</i> Refer to Table C for interface pin assignment.</p>
3	<p>Wire-wrap -48 volts and GRD to the interface circuit.</p>
4	<p>Connect data set (P1) to interface circuit via interface cable (8-bit 405A-L1A). For 20-bit 405A-L1/2 or 32-bit 405A-L1/3, a second interface cable is connected to the data set (J4).</p> <p><i>Requirement:</i> The red alarm lamp on the interface circuit lights for about 2 seconds and then extinguishes.</p>
5	<p>Measure signal level between tip and ring of the interface circuit using a TMS (600Ω termination).</p> <p><i>Requirement:</i> Meter reads between 0 dBm and -0.5 dBm.</p>
6	<p>Wire-wrap tip and ring of private line to the interface circuit terminals designated tip and ring.</p>
7	<p>Call the receiving station and perform the verification test per Section 312-809-501.</p>
8	<p>Unplug connectors (P1, J4). J4 is present for DS 405A-L1/2 or L1/3.</p>
9	<p>Wire-wrap data inputs to the pins of the interface circuit designated as follows:</p> <ul style="list-style-type: none"> ● DS 405A-L1A D1 through D8 ● DS 405A-L1/2 D1 through D20 ● DS 405A-L1/3 D1 through D32. <p>Refer to Table C for interface pin assignment.</p> <p><i>Note:</i> Each data input should be a contact closure to ground. All relay or message register coils associated with the data inputs must have contact protection.</p>
10	<p>Wire-wrap the alarm circuit of the interface circuit to the central office alarm circuit.</p>

STEP	PROCEDURE
11	<p>Connect the data set to interface circuit (P1, J4). Screw the plugs down.</p> <p>Requirement: Alarm lamp lights for a few seconds and then extinguishes. The central office (CO) alarm should activate for the same interval of time.</p>
12	<p>End of installation.</p>
	<p>B. Data Set 405B and Interface Circuit</p>
1	<p>Mount data set as required (23- or 25-inch wide central office frame).</p>
2	<p>Mount the receive interface circuit directly above or below data set.</p>
	<p>Note: Refer to Table C for interface pin assignment.</p>
3	<p>Wire-wrap -48 volts and GRD to the interface circuit.</p>
4	<p>Wire-wrap all data outputs (designated D per Table C) to the message register coils.</p>
5	<p>Wire the other side of each coil (Step 4) to -48 volts.</p>
	<p>Note: The message register coil resistance must be greater than or equal to (\geq) 600Ω. IF THE COIL RESISTANCE IS less than ($<$) 600Ω, a series resistor of sufficient value must be added to the coil. No contact protection is required.</p>
6	<p>Wire-wrap the alarm circuit of the interface circuit to the CO alarm circuit.</p>
7	<p>Call the transmitting station.</p>
8	<p>When the transmitter (DS 405A-type) has been connected to the private line, measure the signal level between tip and ring of the receive interface circuit with a TMS (600Ω termination).</p>
	<p>Requirement: The meter at the receiving location reads as follows:</p> <ul style="list-style-type: none"> ● 405A-L1A (8 bits) -8.0 to -18.5 dBm ● 405A-L1/2 (20 bits) or L1/3 (32 bits) -13 to -17.5 dBm.
9	<p>Wire-wrap tip and ring of the private line to receive interface circuit pins designated tip and ring.</p>
10	<p>Connect data set to interface circuit (P1, J4).</p>
	<p>Requirement: The red alarm lamp on the interface circuit lights for about 2 seconds and then extinguishes. The CO alarm activates for the same amount of time.</p>
11	<p>When the transmitting end is ready, perform the verification test per Section 312-809-501.</p>

TABLE C
INTERFACE PIN ASSIGNMENT FOR THE 405A-TYPE TRANSMITTER AND 405B-TYPE RECEIVER

DS	DESIG	J1/P1 NO	TS A NO	TS B NO	DESIG	J4/P4 NO	TS A NO	TS B NO	DS	DS
L1A	None	1	—	—	D9	1	34	34	L1/2	L1/3
	None	2	—	—	D10	2	44	44		
	D8	3	53	53	D11	3	54	54		
	D7	4	43	43	D12	4	15	15		
	D6	5	33	33	D13	5	25	25		
	D5	6	23	23	D14	6	35	35		
	Fault	7	24	41	D15	7	45	45		
	D4	8	13	13	D16	8	55	55		
	D3	9	52	52	D17	9	16	16		
	D2	10	42	42	D18	10	26	26		
	D1	11	32	32	D19	11	36	36		
	Alarm	12	—	22	D20	12	46	46		
	Alarm	13	—	12	D21	13	56	56		
	-48V	14	31	31	D22	14	17	17		
	None	15	—	—	D23	15	27	27		
	Ground	16	11	11	D24	16	37	37		
	None	17	—	—	D25	17	47	47		
	None	18	—	—	D26	18	57	57		
	None	19	—	—	D27	19	18	18		
	None	20	—	—	D28	20	28	28		
	Tip	21	—	14	D29	21	38	38		
	None	22	—	—	D30	22	48	48		
	Ring	23	—	24	D31	23	58	58		
	G1	24	—	—	D32	24	21	21		
	EOW	25	—	—	—	25	—	—		




Fig. 1—405 Data System in Remote Message Register Application—Connection

4. REFERENCES

4.01 The following documents pertain to data sets 405-type and interface circuit SD-1C451-01 used in the remote message register application:

- CD- & SD-1D203-01 Data Set 405A-Type
- CD- & SD-1D204-01 Data Set 405B-Type
- CD- & SD-1C451-01 Interface Circuit for Use Between 405-Type Data Sets and Message Registers

SECTION	TITLE
252-140-501	Interface Circuit for Use Between 405-Type Data Sets and Message Registers in Remote Register Operation (SD-1C451-01), Verification Procedure
312-809-100	405-Type Data Systems, Description
312-809-150	405-Type Data System, Supplementary Information
312-809-200	405-Type Data System, Installation and Connections
312-809-301	405-Type Data System and Interface Circuit for Message Register Remoting, Maintenance
312-809-501	405-Type Data System and Interface Circuit for Message Register Remoting, Test Procedures.

SECTION	TITLE
252-140-101	Interface Circuit for Use Between 405-Type Data Sets and Message Registers in Remote Registers Operation (SD-1C451-01), Description