

363-206-302

**DDM-2000 FiberReach Wideband Shelf System Commands Quick
Reference Guide - 363-206-302 - Issue 3**

1. DDM-2000 FiberReach Wideband Shelf System Commands Quick Reference Guide

HELP

? (help)
obtain command/parameter list

SPECIAL CHARACTERS

At-sign (@) - erases an input line.
Backspace [^H [Ctrl] h (Ctrl h)] or underbar (_) - erases a character.
Question mark (?) - help
Semicolon (;) - ends a command.
Carriage return [RETURN] or [ENTER] - ends line of input
CANcel or DElete - aborts a command

CROSS-CONNECT

dlt-crs-sts1:Address1,Address2:[cct=Crstype];(Caution*)
deletes STS-1 cross-connections
Address1 & 2=addresses of two STS-1 channels or one STS-1 channel and one OC-1 line
cct=two-way or drop and continue cross-connections

dlt-crs-vt1:Address1,Address2:[cct=Crstype];(Caution*)
deletes VT1.5 (DS1) cross-connections
Address1 and 2=addresses of two VT1.5 channels or one VT1.5 channel and one DS1 or T1 port
cct=two-way or locked cross-connections

ent-crs-sts1:Address1,Address2:[cct=Crstype];
sets bidirectional STS-1 cross-connections
Address1 and 2=addresses of two STS-1 channels
cct=two-way or locked cross-connections

ent-crs-vt1:Address1,Address2:[cct=Crstype][,ring=RingID];
sets bidirectional VT1.5 (DS1) cross-connections
Address1 and 2=addresses of two VT1.5 channels or one VT1.5 channel and one DS1 or T1 port
cct=two-way or locked cross-connections
ring=ring identification for locked cross-connections

LOOPBACK

opr-lpbk-t1:Address:[lpbktype=LoopbackType];(Caution*)
loops back DS1 or T1 port toward fiber
Address=DS1 or T1 port(s)
lpbktype=terminal loopback

rls-lpbk-t1:Address;
releases loopback on DS1 or T1 port
Address=DS1 or T1 port(s)

MISCELLANEOUS**cpy-prog:** *TID*;

copies local NE system controller program to remote
NE system controller

tid=target identifier of NE program is to be copied into

ent-tlmsgmap: *acid=ACID,msgtype=MessageType,*

action=Action;

maps TL1 message types to OS for NE

ACID=OS function (up to 23 alphanumeric characters)

msgtype=supported class of TL1 messages

action= enabled or disabled

ent-ulsdcc: [*L3org=OrganizationID*]

[, *L3res=Reserved*][, *L3rou=RoutingData*];

enter upper layer section (3 thru 7) of OSI stack

L3org=company code (6-digit)

L3res=currently not used

L3rou=covers routing domain and area fields (8-digit)

init-pm:reg=Register;

initializes current day & qh pm registers

reg=register being initialized (day,qh,all)

init-sys:Address; (**Caution***)

initializes provisionable parameters to default values

Address=SYSCTL or all slots (sysctl or all)

ins-prog: *TID*;

installs new program into the SYSCTL

TID=shelf name

logout;

ends CIT session

opr-aco;

silence audible office alarms

reset;

resets shelf software program

rlgn: *TID*;

sets up remote login session via SONET DCC

TID=target identifier of the desired remote shelf

rstr-passwd: *login,passwd,user_type,clr;*

restores the login, password, and user type information

login=login name

passwd=current encrypted and encoded password

user_type=privileged, general, maintenance, or reports-only

clr=indicates whether existing login data should

be deleted (clear or noclear)

toggle or [Ctrl] **t** (**Ctrl t**)

toggles between local and remote sessions

upd; (**Caution***)

updates system database

RETRIEVE**rtrv-alm:** [*alm=AlarmLevel*];

displays report of alarms and status of NE

alm=alarm level being reported (all,cr,mj,mn,pmn,other)

rtrv-attr-alm;
displays current alarm attributes (Alarm Delay, Clear Delay, PMN)

rtrv-attr-cont:[Address];
displays name of current misc. discrete environmental control points
Address=environmental control pt. (cont-{1-4,all})

rtrv-attr-env:[Address];
displays current misc. discrete environmental alarm/status pts.
Address=env. input pt. (env-{1-15},env-{all})

rtrv-crs-sts1:[Address];
retrieves STS-1 cross-connections
Address=one or more STS-1 channels (m-{1-3,all})

rtrv-crs-vt1:[Address];
retrieves VT1.5 (DS1) cross-connections
Address=VT1.5 channels or DS1 or T1 ports

rtrv-eqpt:[Address];
displays circuit pack type and version information
Address=one or more slot(s)

rtrv-feat;
report displays enabled feature options

rtrv-fecom:[Address];
displays provisioned state of NE's DCC channel(s)
Address=address of the DCC

rtrv-hsty;
displays history report of most recent events

rtrv-lgn;
report displays login authorization information

rtrv-link;
displays CIT Link, PageLength, and Baud rate

rtrv-ne;
displays NE provisioning information

rtrv-map-neighbor;
displays NEs that can be accessed by the local NE and its immediate DCC neighbors

rtrv-map-network;
displays all NEs, their product type, and if they are DSNE

rtrv-oc1:[Address];
displays configuration of OC-1 line(s)
Address=OC-1 line(s)

rtrv-oc3:[Address];
displays configuration of OC-3 line(s)
Address=OC-3 line(s)

rtrv-passwd;
displays logins, passwords (encrypted), and user type

rtrv-pm-line:[Address];
displays PM OC-1 or OC-3 lines terminated on system
Address=OC-1 or OC-3 line(s)

rtrv-pm-sect:[Address];
displays PM OC-1 and OC-3 optics, STS-1 and STS-3 (within OC-3 line only)
Address=OC-1 or OC-3 line(s)

rtrv-pm-sts1:[Address];
displays PM STS-1 status report
Address=STS-1 channels

rtrv-pm-t1:[Address];
displays PM DS1 status report
Address=DS1 or T1 port(s)

rtrv-pm-tca;
displays PM threshold crossing alert (TCA) report

rtrv-pm-vt1:[Address];
displays PM status report for one or more VT1.5 channels
Address=one or more VT1.5 channels

rtrv-pmthres-line;
displays current OC-1 and OC-3 line PM threshold report

rtrv-pmthres-sect;
displays section PM threshold report

rtrv-pmthres-sts1;
displays STS-1 path PM threshold report

rtrv-pmthres-t1;
displays DS1 path and line PM threshold report

rtrv-pmthres-t3;
displays DS3 PM threshold report

rtrv-pmthres-vt1;
displays VT1.5 PM threshold report

rtrv-secu;
displays CIT and DCC port security and timeout information report

rtrv-state-eqpt:[Address];
displays slot, port, and protection switching state information for NE
Address=one or more slot(s)

rtrv-state-path:[Address];
displays signal path state information for paths dropped at NE
Address=any connected VT1.5 path

rtrv-state-sts1:[Address];
displays STS-1 channel states
Address=any STS-1 channel

rtrv-state-vt1:[Address];
displays VT1.5 channel states
Address=any VT1.5 channel

rtrv-sts1:[Address];
displays provisioned parameters for STS-1 channels
Address=any STS-1 channel

rtrv-sync;
displays sync report, provisioning and operational information

rtrv-tllmsgmap;

displays the OS ACID to TL1 autonomous message types

rtrv-tl:[Address];

displays DS1 or T1 port provisioning report

Address=DS1 or T1 port(s)

rtrv-ulsdcc;

displays upper layer section DCC report for NSAP address

rtrv-vt1:[Address];

displays provisioned values for terminated

or dropped VT1.5 channels

Address=VT1.5 channels

SWITCH**switch-ls:Address:pri=Priority;(Caution*)**

controls low-speed circuit pack protection switching

Address=low-speed slot(s)

pri=priority of protection switch request

(reset,lockout,forced>manual)

switch-path-vt1:Address:pri=Priority;

controls VT1.5 path switching on path protected ring configurations

Address=VT1.5 path carrying traffic

pri=priority of protection switch request (manual)

switch-sync:s=SyncFunction:pri=Priority;(Caution*)

controls synchronization protection switching

s=synchronization function (mode or src)

pri=priority of protection switch request (reset or manual)

SET**set-attr-alm:[almdel=AlarmDelay][,clrdel=ClearDelay]**

[,pnm=PowerMinor];

sets alarm holdoff and clear delays

almdel=alarm delay in sec. (0-30)

clrdel=alarm clear delay in sec. (0-30)

pnm=power minor alarm level (MN or MJ)

set-attr-cont:Address:desc=Description;

provision name of environmental control points

Address=control point (cont-{1-4})

desc=name (up to 26 alphanumeric characters)

set-attr-env:Address:[alm=Alarm][,almtype=AlarmType]

[,desc=Description];

provision alarm level of environmental input points

Address=environmental point (env-{1-15},env-{all})

alm=level of alarm (cr,mj,mn,na)

almtype=alarm type (up to 10 alphanumeric characters)

desc=name (up to 26 alphanumeric characters)

set-date:[date=Date][,time=Time];

sets date and time

date=year, month, and day (YYMMDD)

time=hour, minute, and second (HHMMSS)

set-feat:feat=Feature,act=Action;

```

configure NE for feature options licensed for use
  feat=feature options licensed for use (vtpm or dslpm)
  act=enabled or disabled feature
set-fecom:Address:[com=Communication]
  [,nsus=NS/US];
  enables or disables DCC channel
  Address=address of the DCC
  com=communication over DCC (enabled or disabled)
  nsus=NetworkSide/UserSide DCC identity (ns or us)
set-lgn:[act=Action];
  enters, edits, and deletes logins and passwords
  act=enter, edit, or delete
set-link:pg=PageLength;
  sets vertical page size
  pg=page size in lines (3-150)
set-ne:tid=TID:[dsne=DSNE][,almgrp=AlarmGroup]
  [,agne=AGNE][,site=Site][,ne=NE][,cort=CO/RT]
  [,tbaddr=TBOSAddress][,tblink=TBOSLink]
  [,tbrem=TBOSRemote][,idle=IdleChannelSignal];
  sets network element parameters of DDM-2000
  tid=shelf name (up to 20 alphanumeric characters)
  dsne=directory services network element (yes or no)
  almgrp=alarm group (1-255)
  agne=alarm gateway network element (yes or no)

  site=numeric identification of NEs at same site (1-64)
  ne=numeric identification of system at a site (1-5)
  cort=parameter for central office or remote terminal
  tbaddr=TBOS display address of NE (1-8)
  tblink=TBOS link function (normal,primary,secondary,notBOS)
  tbrem=TBOS remote reporting status (enabled or disabled)
  idle=whether AIS or unequipped signal is inserted in
  VT1.5 or STS-1 channels that are not cross connected
set-oc1:Address:[dgr=SignalDegradThreshold][,aisalm=Alarm];
  sets parameters for OC-1 line
  Address=OC-1 line(s)
  dgr=signal degrade threshold (-9 to -5)
  aisalm=provisioned alarm level of OC-1 line (cr,mj,mn,na)
set-oc3:Address:[dgr=SignalDegradThreshold]
  [,syncmsg=SynchronizationMessaging][,aisalm=Alarm];
  sets several parameters of specified OC3 line or line pair
  Address=OC-3 line(s) or line pair(s)
  dgr=signal degrade threshold (-9 to -5)
  syncmsg=allows timing to be reconfigured in a network
  upon a node or fiber failure (Kbyte,Sbyte,disabled)
  aisalm=provisioned alarm level of OC-3 line AIS (cr,mj,mn,na)
set-passwd;
  changes a user's password
set-pmthres-line:[,QHB2CVOC3=nnnnn][,DayB2CVOC3=nnnnn]
  [,QHB2CVOC1=nnnnn][,DayB2CVOC1=nnnnn][,QHB2ES=nnn]
  [,DayB2ES=nnnnn][,QHB2ESA=nnn][,DayB2ESA=nnnnn]

```

```

[ ,QHB2ESB=nnn][ ,DayB2ESB=nnnnn][ ,QHB2SES=nn]
[ ,DayB2SES=nnnn][ ,QHB2UAS=nn][ ,DayB2UAS=nnnn];
sets performance parameter thresholds of OC-3 or OC-1 line
  QHB2CVOC3=OC-3 coding violations count (qtr. hr.)
  DayB2CVOC3=OC-3 coding violations count (daily)
  QHBb2CVOC1=OC-1 coding violations count (qtr. hr.)
  DayB2CVOC1=OC-1 coding violations count (daily)
  QHB2ES=errored seconds (ES) count (qtr. hr.)
  DayB2ES=errored seconds (ES) count (daily)
  QHB2ESA=errored seconds (ES) type A count (qtr. hr.)
  DayB2ESA=errored seconds (ES) type A count (daily)
  QHB2ESB=errored seconds (ES) type B count (qtr. hr.)
  DayB2ESB=errored seconds (ES) type B count (daily)
  QHB2SES=severely errored seconds (SES) count (qtr. hr.)
  DayB2SES=severely errored seconds (SES) count (daily)
  QHB2UAS=unavailable seconds (UAS) count (qtr. hr.)
  DayB2UAS=unavailable seconds (UAS) count (daily)
set-pmthres-sect: [ ,Qhsefs=nn][ ,Daysefs=nnnn];
sets performance parameter thresholds of OC-1 section
  Qhsefs=severely errored frame seconds (SEFS) (qtr. hr.)
  Daysefs=severely errored frame seconds (SEFS) (daily)
set-pmthres-sts1: [QHB3CV=nnnn][ ,DayB3CV=nnnnnn]
[ ,QHB3ES=nnn][ ,DayB3ES=nnnnn][ ,QHB3ESA=nnn]
[ ,DayB3ESA=nnnnn][ ,QHB3ESB=nnn][ ,DayB3ESB=nnnnn]
[ ,QHB3SES=nn][ ,DayB3SES=nnnn][ ,QHB3UAS=nn]
[ ,DayB3UAS=nnnn];
sets performance parameter thresholds of STS-1 path
  QHB3CV=coding violations count (qtr. hr.)
  DayB3CV=coding violations count (daily)
  QHB3ES=errored seconds (ES) count (qtr. hr.)
  DayB3ES=errored seconds (ES) count (daily)
  QHB3ESA=errored seconds (ES) type A count (qtr. hr.)
  DayB3ESA=errored seconds (ES) type A count (daily)
  QHB3ESB=errored seconds (ES) type B count (qtr. hr.)
  DayB3ESB=errored seconds (ES) type B count (daily)
  QHB3SES=severely errored frame seconds (SEFS) count (qtr. hr.)
  DayB3SES=severely errored frame seconds (SEFS) count (daily)
  QHB3UAS=unavailable seconds count (qtr. hr.)
  DayB3UAS=unavailable seconds count (daily)

set-pmthres-t1: [DayESL=nnnn][ ,DayCVPSF=nnnn]
[ ,DayCVPESF=nnnn][DayESP=nnnnn][ ,DaySESP=nnnnnnn]
[ ,DayUASP=nnn][ ,DayCVPFE=nnnn][ ,DayESPFE=nnnnn]
[ ,DaySESPFE=nnn][ ,DayUASPFE=nnnnn];(R2.0 & Earlier)
set-pmthres-t1: [QHESL=nnn][ ,DayESL=nnnnn]
[ ,QHCVPFSF=nnnnn][ ,DayCVPSF=nnnnnnn][ ,QHCVPESF=nnnnn]
[ ,DayCVPESF=nnnnnnn][ ,QHESP=nnn][ ,DayESP=nnnnn]
[ ,QHSESP=nn][ ,DaySESP=nnnn][ ,QHUASP=nn]
[ ,DayUASP=nnnn][ ,QHCVPFE=nnnnn][ ,DayCVPFE=nnnnnnn]
[ ,QHESPFE=nnn][ ,DayESPFE=nnnnn][ ,QHSESPFE=nn]
[ ,DaySESPFE=nnnn][ ,QHUASPFE=nn][ ,DayUASPFE=nnnn];

```

(R2.1 & Later)

sets performance monitoring thresholds of DS1 signal

- QHESL=errored seconds line (ESL) count (qtr. hr.)
- DayESL=errored seconds line (ESL) count (daily)
- QHCVPSPF=code violations path SF (CVPSF) count (qtr. hr.)
- DayCVPSF=code violations path SF (CVPSF) count (daily)
- QHCVPESF=code violations path ESF (CVPESF) count (qtr. hr.)
- DayCVPESF=code violations path ESF (CVPESF) count (daily)
- QHESP=errored seconds path (ESF) count (qtr. hr.)
- DayESP=errored seconds path (ESF) count (daily)
- QHSESP=severely errored seconds path (SESP) count (qtr. hr.)
- DaySESP=severely errored seconds path (SESP) count (daily)
- QHUASP=unavailable seconds path (UASP) count (qtr. hr.)
- DayUASP=unavailable seconds path (UASP) count (daily)
- QHCVPFE=code violations path far-end (CVPFE) count (qtr. hr.)
- DayCVPFE=code violations path far-end (CVPFE) count (daily)
- QHESPFE=errored seconds path far-end (ESPFE) count (qtr. hr.)
- DayESPFE=errored seconds path far-end (ESPFE) count (daily)
- QHSESPFE=severely errored seconds path far-end (ESPFE) count (qtr. hr.)
- DaySESPFE=severely errored seconds path far-end (ESPFE) count (daily)
- QHUASPFE=unavailable seconds path far-end (UASPFE) count (qtr. hr.)
- DayUASPFE=unavailable seconds path far-end (UASPFE) count (daily)

set-pmthres-vt1: [QHV5ES=nnnnn] [, DayV5ES=nnnnnnn]

[, QHV5SES=nnn] [, DayV5SES=nnnnn] [, QHV5UAS=nnn]

[, DayV5UAS=nnnnn];

sets performance parameter thresholds of VT1.5 signal

- QHV5ES=errored seconds (ES) count (qtr. hr.)
- DayV5ES=errored seconds (ES) count (daily)
- QHV5SES=severely errored seconds (SES) count (qtr. hr.)
- DayV5SES=severely errored seconds (SES) count (daily)
- QHV5UAS=unavailable seconds (UAS) count (qtr. hr.)
- DayV5UAS=unavailable seconds (UAS) count (daily)

set-secu: Address[:sec=Security][, to=Timeout];

- enables or disables CIT security on CIT and DCC interfaces
- Address=one or more CIT and/or DCC ports (dcc-all, cit-1)
- sec=security on specified CIT or DCC port(s) (enabled, disabled, lockout)
- to=timeout of inactive session on CIT (minutes)

set-state-sts1: Address:ps=PrimaryState;

- sets state of STS-1 channels
- Address=STS-1 channel(s)
- ps=channel state (auto or nmon)

set-state-t1: Address:ps=PrimaryState;

- sets state of DS1 or T1 ports
- Address=DS1 or T1 port(s)
- ps=port state (auto or nmon)

set-state-vt1: Address:ps=PrimaryState;

```

sets state of VT1.5 channels
  Address=VT1.5 channel(s)
  ps=channel state (auto or nmon)
set-sts1:Address:dgr=SignalDegrade:sfail=SignalFailure
[ ,nsa=Alarm][ ,sa=Alarm];
provisions signal degrade threshold of dropped STS-1
channels
  Address=STS-1 channels
  dgr=degrade threshold (-9 to -5)
  sfail=BER of STS-1 channel (-3 or -6)
  nsa=provisioned alarm level of non-service
affecting STS-1 path AIS (mn or nr)
  sa=provisioned alarm level of service
affecting STS-1 path AIS (cr or na)
set-sync:[mdsw=ModeSwitching]
[ ,src=SynchronizationSource]
[ ,auto=SyncAutoreconfiguration];(R2.2 & Later)(Caution*)
provisions the synchronization mode switching and
synchronization source of timing signals
  mdsw=mode of switch (revertive or nonrevertive)
  src=synchronization source (main-1 or main-2)
  auto=syncautoreconfiguration (enabled or disabled)
set-t1:Address:[lc=LineCode][ ,alm=AlarmLevel]
[ ,fth=FailureThreshold][ ,dlc=DLCPVtoLOS]
[ ,ais=AlarmIndicationSignal][ ,pmmd=PMMode]
[ ,fmt=Format];(Caution*)
provisions parameters of DS1 or T1 ports
  Address=DS1 or T1 port(s)
  lc=line code (ami,b8zs,noOverride)
  alm=level of alarm (mj,mn,na)
  fth=fail threshold (-8,-7,-6,-3)
  dlc=inc. sig. fail translated to LOS (yes or no)
  ais=alarm indication signal (yes or no)
  pmmd=performance monitoring mode of ports (off or on)
  fmt=format to be monitored (sf,esf,esfn)
set-vt1:Address:dgr=SignalDegrade[ ,nsa=Alarm]
[ ,sa=Alarm];
sets signal degrade alarm threshold of VT1.5 channels
  Address=VT1.5 channels(R2.1 & Later)
  dgr=degrade threshold (-8 to -5)
  nsa=provisioned alarm level of non-service affecting
VT path AIS (mn or nr)(R2.1 & Later)
  sa=provisioned alarm level of service affecting
VT path AIS (mj or na)(R2.1 & Later)

```

TEST

```

test-alm:[md=Mode][ ,r=Repeat];
tests audible and visible office alarms and
associated user panel LEDs
  md=office alarm to test (all,cr,mj,mn)
  r=number of times (1-10) to repeat test

```

test-led:[Address]:[r=Repeat];
tests shelf LEDs
Address=slot(s) or userpanel
r=number of times (1-10) to repeat test

test-sysctl;
self test of SYSCTL

test-tlm-par:[md=Mode][,r=Repeat];
tests parallel telemetry output(s)
md=parallel telemetry output(s)
r=number of times (1-10) to repeat test

test-tlm-ser:[d=Display][,p=Point][,r=Repeat];
tests serial telemetry TBOS outputs
d=TBOS display being used
p=TBOS display point(s) to be tested
r=number of times (1-10) to repeat test

test-trmsn-t1:Address:[dirn=Direction][,dur=Duration];(**Caution***)
test DS1 transmission
Address=DS1 or T1 port
dirn=direction of test (mux or demux)
dur=length of test in min. (1-120)

SPECIAL CHARACTERS

At-sign (@) - erases an input line.
Backspace [^H [Ctrl] h (Ctrl h)] or underbar (_) - erases a character.
Question mark (?) - help
Semicolon (;) - ends a command.
Carriage return [RETURN] or [ENTER] - ends line of input
CANcel or DElete - aborts a command

**Caution! Execution of this command may affect service.*