



# **WaveStar<sup>®</sup> ITM-SC Release 8.0**

## Provisioning Guide for *WaveStar* AM 1 PLUS

365-312-521  
CC109113019  
Issue a  
June 2001

**Lucent Technologies - Proprietary**

This document contains proprietary information  
of Lucent Technologies and is not to be disclosed or used  
except in accordance with applicable agreements

Copyright © 2001 Lucent Technologies  
Unpublished and Not for Publication  
All Rights Reserved





**Support****Technical support**

Please contact your Lucent Technologies Local Customer Support Team (LCS) for technical questions about the information in this document.

**Information product support**



# Lucent Technologies values your comments!

**Lucent Technologies**  
Bell Labs Innovations



WaveStar® ITM-SC Release 8.0  
Provisioning Guide for WaveStar AM 1 PLUS

365-312-521 Issue a June 2001

Lucent Technologies welcomes your comments on this information product. Your opinion is of great value and helps us to improve.

## 1. Was the information product:

	Yes	No	Not applicable
In the language of your choice?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
In the desired media (paper, CD-ROM, etc.)?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Available when you needed it?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Please provide any additional comments:

---



---

## 2. Please rate the effectiveness of this information product:

	<i>Excellent</i>	<i>More than satisfactory</i>	<i>Satisfactory</i>	<i>Less than satisfactory</i>	<i>Unsatisfactory</i>	<i>Not applicable</i>
Ease of use	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of detail	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Readability and clarity	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Completeness	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Technical accuracy	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Quality of translation	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Appearance	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

If your response to any of the above questions is "Less than satisfactory" or "Unsatisfactory," please explain your rating.

---



---

## 3. If you could change one thing about this information product, what would it be?

---



---

## 4. Please write any other comments about this information product:

---



---

Please complete the following if we may contact you for clarification or to address your concerns:


Name: \_\_\_\_\_ Date: \_\_\_\_\_

Company/organization: \_\_\_\_\_ Telephone number: \_\_\_\_\_

Address: \_\_\_\_\_

Email address: \_\_\_\_\_ Job function: \_\_\_\_\_

*If you choose to complete this form online, go to <http://www.lucent-info.com/comments>  
Otherwise fax to 407 767 2760 (U.S.) or +1 407 767 2760 (outside the U.S.) or email comments to [ctiphotline@lucent.com](mailto:ctiphotline@lucent.com)*





# Lucent Technologies values your comments!

**Lucent Technologies**  
Bell Labs Innovations



WaveStar® ITM-SC Release 8.0  
Provisioning Guide for WaveStar AM 1 PLUS

365-312-521 Issue a June 2001

Lucent Technologies welcomes your comments on this information product. Your opinion is of great value and helps us to improve.

## 1. Was the information product:

	Yes	No	Not applicable
In the language of your choice?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
In the desired media (paper, CD-ROM, etc.)?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Available when you needed it?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Please provide any additional comments:

---



---

## 2. Please rate the effectiveness of this information product:

	Excellent	More than satisfactory	Satisfactory	Less than satisfactory	Unsatisfactory	Not applicable
Ease of use	<input type="checkbox"/>					
Level of detail	<input type="checkbox"/>					
Readability and clarity	<input type="checkbox"/>					
Organization	<input type="checkbox"/>					
Completeness	<input type="checkbox"/>					
Technical accuracy	<input type="checkbox"/>					
Quality of translation	<input type="checkbox"/>					
Appearance	<input type="checkbox"/>					

If your response to any of the above questions is "Less than satisfactory" or "Unsatisfactory," please explain your rating.

---



---

## 3. If you could change one thing about this information product, what would it be?

---



---

## 4. Please write any other comments about this information product:

---



---

Please complete the following if we may contact you for clarification or to address your concerns:


Name: \_\_\_\_\_ Date: \_\_\_\_\_

Company/organization: \_\_\_\_\_ Telephone number: \_\_\_\_\_

Address: \_\_\_\_\_

Email address: \_\_\_\_\_ Job function: \_\_\_\_\_

If you choose to complete this form online, go to <http://www.lucent-info.com/comments>  
Otherwise fax to 407 767 2760 (U.S.) or +1 407 767 2760 (outside the U.S.) or email comments to [ctiphotline@lucent.com](mailto:ctiphotline@lucent.com)







# Contents

## About this information product

Purpose	<a href="#">xxiii</a>
Reason for reissue	<a href="#">xxiii</a>
Safety labels	<a href="#">xxiii</a>
Intended audience	<a href="#">xxiii</a>
How to use this information product	<a href="#">xxiv</a>
Conventions used	<a href="#">xxvi</a>
Approval mark	<a href="#">xxvi</a>
Customer Documentation network element (NE) Related	<a href="#">xxvii</a>
Customer Documentation Subnetwork Controller Related	<a href="#">xxvii</a>
How to comment	<a href="#">xxviii</a>
How to order	<a href="#">xxviii</a>

---

## 1 DCN Management

Overview	<a href="#">1-1</a>
<b>Section : Edit General Network Element Information</b>	
Overview	<a href="#">1-2</a>

Edit General Network Element Information [1-3](#)

Parameters for Editing General Network Element Information [1-6](#)

**Section: Data Communications Channel (DCC)**

Overview [1-12](#)

Provisioning the Data Communications Channel (DCC) [1-13](#)

Parameters for Provisioning Data Communications Channel (DCC) [1-15](#)

**Section: Data Communication Test**

Overview [1-16](#)

Performing the Data Communication Test [1-17](#)

Parameters for Performing the Data Communication Test [1-19](#)

---

**2 Equipment Provisioning**

Overview [2-1](#)

**Section: Creating an NE Template**

Overview [2-2](#)

Create NE Template [2-3](#)

Parameters for Creating an NE Template [2-5](#)

**Section: Viewing NE Template Slot Information**

Overview [2-6](#)

View NE Template Slot Information [2-7](#)

Parameters for Viewing Template NE Slot Information [2-9](#)

**Section: Modifying an NE Template**

Overview [2-10](#)

Modify NE Template [2-11](#)

Parameters for Modifying an NE Template [2-13](#)

## **Section: Deleting an NE Template**

Overview	<a href="#">2-14</a>
Delete NE Template	<a href="#">2-15</a>
Parameters for Deleting an NE Template	<a href="#">2-16</a>

## **Section: Creating a Pre-Provisioned NE**

Overview	<a href="#">2-17</a>
Create a Pre-Provisioned NE	<a href="#">2-18</a>
Parameters for Creating a Pre-Provisioned NE	<a href="#">2-20</a>

## **Section: Editing Pre-Provisioned NE Information**

Overview	<a href="#">2-23</a>
Edit Pre-Provisioned NE Information	<a href="#">2-24</a>
Parameters for Editing Pre-Provisioned NE Information	<a href="#">2-26</a>

## **Section: Viewing Pre-Provisioned NE Slot Information**

Overview	<a href="#">2-29</a>
View Pre-Provisioned NE Slot Configuration	<a href="#">2-30</a>
Parameters for Viewing Pre-Provisioned NE Slot Configuration	<a href="#">2-32</a>

## **Section: Editing Pre-Provisioned NE Slot Information**

Overview	<a href="#">2-33</a>
Edit Pre-Provisioned NE Slot Information	<a href="#">2-34</a>
Parameters for Editing Pre-Provisioned NE Slot Information	<a href="#">2-37</a>

## **Section: Deleting a Pre-Provisioned NE**

Overview	<a href="#">2-38</a>
Delete a Pre-Provisioned NE	<a href="#">2-39</a>

## **Section: Creating an NE from a Template**

Overview	<a href="#">2-41</a>
Create an NE from a Template	<a href="#">2-42</a>
Parameters for Creating an NE from a Template	<a href="#">2-44</a>

## **Section: Creating an NE from a Pre-Provisioned NE**

Overview	<a href="#">2-47</a>
Create an NE from a Pre-Provisioned NE	<a href="#">2-48</a>

## **Section: Creating an MIB Image from an NE**

Overview	<a href="#">2-50</a>
Create an MIB Image from an NE	<a href="#">2-51</a>
Parameters for Creating an MIB Image from an NE	<a href="#">2-53</a>

## **Section: Viewing NE Slot Information**

Overview	<a href="#">2-56</a>
View NE Slot Information	<a href="#">2-57</a>
Parameters for Viewing NE Slot Information	<a href="#">2-58</a>

## **Section: Viewing Card Inventory**

Overview	<a href="#">2-60</a>
View Card Inventory	<a href="#">2-61</a>
Parameters for Viewing Card Inventory	<a href="#">2-62</a>

## **Section: Editing General NE Information**

Overview	<a href="#">2-63</a>
Edit General NE Information	<a href="#">2-64</a>
Parameters for Editing General NE Information	<a href="#">2-67</a>

## **Section: Editing NE Slot Information**

Overview [2-71](#)

Edit NE Slot Information [2-72](#)

Parameters for Editing NE Slot Information [2-74](#)

## **Section: Viewing and Editing MDI Information**

Overview [2-75](#)

View and Edit MDI Information [2-76](#)

Parameters for Viewing and Editing MDI Information [2-78](#)

## **Section: Viewing and Editing MDO Information**

Overview [2-79](#)

View and Edit MDO Information [2-80](#)

Parameters for Viewing and Editing MDO Information [2-82](#)

## **Section: Viewing Optical Information**

Overview [2-83](#)

View Optical Information [2-84](#)

Parameters for Viewing Optical Information [2-86](#)

## **Section: Deleting a Provisioned NE**

Overview [2-87](#)

Delete a Provisioned NE [2-88](#)

---

## **3 Topology management**

Overview [3-1](#)

### **Section: Network Map**

Overview [3-2](#)

Customizing the Network Map [3-6](#)

Creating Map Groups	<a href="#">3-7</a>
Parameters for Creating Map Groups	<a href="#">3-8</a>
Create Map Groups	<a href="#">3-9</a>
Modifying Map Groups	<a href="#">3-11</a>
Parameters for Modifying Map Groups	<a href="#">3-12</a>
Modify Map Groups	<a href="#">3-13</a>
Placing NEs in Map Groups	<a href="#">3-15</a>
Place NEs in Map Groups	<a href="#">3-16</a>

---

#### **4 Provisioning Timing**

Overview	<a href="#">4-1</a>
<b>Section: Provision Timing Sources.</b>	
Overview	<a href="#">4-2</a>
Provision Timing Sources	<a href="#">4-3</a>
Parameters to Provision Timing Sources	<a href="#">4-5</a>
<b>Section: Provision System Timing</b>	
Overview	<a href="#">4-11</a>
Provision System Timing	<a href="#">4-12</a>
Parameters to Provision System Timing	<a href="#">4-14</a>
<b>Section: Provision Station Clock Output</b>	
Overview	<a href="#">4-18</a>
Provision Station Clock Output	<a href="#">4-19</a>
Parameters to Provision Station Clock Output	<a href="#">4-21</a>
<b>Section: Provision Output Port Timing</b>	
Overview	<a href="#">4-25</a>

---

Provision Output Port Timing	<a href="#">4-26</a>
Parameters to Provision Output Port Timing	<a href="#">4-29</a>
<b>Section: Provision with Timing Templates.</b>	
Overview	<a href="#">4-32</a>
Provision with Timing Templates	<a href="#">4-33</a>
Parameters to Provision with Timing Templates	<a href="#">4-37</a>
<b>Section: Use the Timing Event Log .</b>	
Overview	<a href="#">4-39</a>
Use the Timing Event Log	<a href="#">4-40</a>
Parameters to Use the Timing Event Log	<a href="#">4-42</a>
<b>Section: View the Synchronization Summary.</b>	
Overview	<a href="#">4-44</a>
View the Synchronization Summary	<a href="#">4-45</a>
Parameters to View the Synchronization Summary	<a href="#">4-46</a>

---

## **5 Path Provisioning and Protection**

Overview	<a href="#">5-1</a>
<b>Section: Provision Ethernet over SDH</b>	
Overview	<a href="#">5-3</a>
Procedures to Provision LAN groups	<a href="#">5-4</a>
Procedures to Provision LAN ports and WAN ports	<a href="#">5-7</a>
Procedure to Provision SDH Channels	<a href="#">5-10</a>
Procedure to Check the Sequence Number of a Virtually Concatenated VC-12 or VC-3	<a href="#">5-12</a>
Parameters for provisioning LAN groups	<a href="#">5-13</a>

Parameters for Provisioning SDH Channels	<a href="#">5-15</a>
<b>Section: Display Cross Connections</b>	
Overview	<a href="#">5-17</a>
Procedure to Display Cross Connections	<a href="#">5-18</a>
Parameters for Displaying Cross Connections	<a href="#">5-19</a>
<b>Section: Provision Cross Connections without Protection</b>	
Overview	<a href="#">5-21</a>
Procedure to Add Cross Connections	<a href="#">5-22</a>
Procedure to Delete a Cross Connection	<a href="#">5-24</a>
Parameters for Provisioning Cross Connections without Protection	<a href="#">5-25</a>
<b>Section: Provision Cross Connections with SNC Protection</b>	
Overview	<a href="#">5-26</a>
Procedure to Add Cross Connections with SNC Protection	<a href="#">5-27</a>
Procedure to Add Protection to an Unprotected Cross Connection	<a href="#">5-30</a>
Procedure to Remove a Protection from an SNC Protected Cross Connection	<a href="#">5-32</a>
Procedure to Delete a Cross Connection with SNC Protection	<a href="#">5-34</a>
Parameters for Provisioning Cross Connections with SNC Protection	<a href="#">5-35</a>
<b>Section: View SNC Protection</b>	
Overview	<a href="#">5-37</a>
Viewing SNC Information	<a href="#">5-38</a>
Parameters for Viewing SNC	<a href="#">5-39</a>
<b>Section: View MSP Protection</b>	
Overview	<a href="#">5-40</a>

Viewing MSP Information	<a href="#">5-41</a>
Parameters for viewing MSP	<a href="#">5-42</a>
<b>Section: Edit MSP Protection</b>	
Overview	<a href="#">5-43</a>
Editing MSP Information	<a href="#">5-44</a>
Parameters for Editing MSP	<a href="#">5-46</a>

---

## **6 Maintenance Settings for Transmission**

Overview	<a href="#">6-1</a>
<b>Section: Port Provisioning</b>	
Overview	<a href="#">6-3</a>
Procedure for Port Provisioning	<a href="#">6-4</a>
Parameters for Port Provisioning	<a href="#">6-6</a>
<b>Section: Provisioning Termination Points</b>	
Overview	<a href="#">6-9</a>
Procedure to Provision Termination Points	<a href="#">6-10</a>
Parameters for Provisioning Termination Points	<a href="#">6-12</a>
<b>Section: Path Trace Provisioning</b>	
Overview	<a href="#">6-14</a>
Procedure to Provision a Path Trace	<a href="#">6-15</a>
Parameters for Path Trace Provisioning	<a href="#">6-18</a>
<b>Section: Provision Degraded Signal Thresholds</b>	
Overview	<a href="#">6-20</a>
Procedure to Select a Threshold Value for a Signal	<a href="#">6-21</a>
Procedure to Set or Modify the Threshold Values for a Signal	<a href="#">6-23</a>

Parameters for Provisioning Degraded Signal Thresholds [6-25](#)

**Section: Switch SNC Protection**

Overview [6-27](#)

Switching SNC Protection [6-28](#)

Parameters for Switching SNC Protection [6-30](#)

**Section: Switch MSP Protection**

Overview [6-31](#)

Switching MSP [6-32](#)

Parameters for Switching MSP [6-34](#)

---

**7 NE Software Upgrade**

Overview [7-1](#)

**Section: View Software stored in the Network Element**

Overview [7-2](#)

Procedure to View Software stored in the Network Element [7-3](#)

Parameters for Viewing Software stored in the Network Element [7-5](#)

**Section: Download Software into a Network Element**

Overview [7-6](#)

Parameters: Download Software into a Network Element [7-7](#)

Procedure to Download Software into a Network Element [7-9](#)

Parameters: Download Software into a Network Element [7-11](#)

**Section: Switch the Stores in a Network Element**

Overview [7-13](#)

Procedure to Switch the Stores [7-14](#)

Parameters to Switch the Stores [7-16](#)

---

## 8 Concepts

Overview [8-1](#)

### Section: DCN Management Concepts

Overview [8-2](#)

SDH Data Communications Network [8-3](#)

OSI Network Protocol [8-5](#)

DCN Addresses [8-6](#)

NSAP Address Format [8-7](#)

IS-IS Level 2 [8-10](#)

Partitioning Networks into Areas [8-11](#)

DCN Configuration [8-13](#)

Undivided Data Communications Network [8-14](#)

IS-IS Clustered DCN [8-15](#)

IS-IS Area Divided DCN [8-16](#)

DCC Concepts [8-17](#)

Dual Stack with Tunneling (DSwT) [8-18](#)

Example of Dual Stack with Tunneling [8-23](#)

DSwT Tunnel Auto Provisioning (TAP) [8-26](#)

DSwT Connecting Areas with Manual TAP Tunnels [8-28](#)

### Section: Equipment Provisioning Concepts

Overview [8-29](#)

Node Creation [8-30](#)

Provisioning Methods [8-31](#)

Addressing and Management Concepts [8-34](#)

WaveStar® AM 1 Configuration Possibilities [8-35](#)

Miscellaneous Discrete Inputs and Outputs [8-36](#)

**Section: Timing Concepts.**

Overview [8-37](#)

Network Element Timing [8-38](#)

Network Synchronization [8-41](#)

Timing Quality Levels [8-43](#)

Priorities [8-45](#)

Example of Network Timing [8-46](#)

Timing Loop [8-47](#)

Retiming [8-48](#)

Timing Configuration of the WaveStar® AM 1 Plus [8-50](#)

**Section: Concepts of Path Provisioning and Protection**

Overview [8-52](#)

Transmission Plan [8-53](#)

Cross Connections [8-55](#)

Ethernet over SDH [8-58](#)

VC-3 Concatenation [8-69](#)

VC-12 Concatenation [8-70](#)

Multiplexer Section Protection [8-71](#)

Sub Network Connection Protection [8-73](#)

**Section: Traffic Maintenance Concepts**

Overview [8-76](#)

Port Types	<a href="#">8-77</a>
Termination Points	<a href="#">8-79</a>
<b>Section: Concepts of Software Upgrade</b>	
Overview	<a href="#">8-81</a>
Software Upgrade of a WaveStar® AM 1 plus	<a href="#">8-82</a>

---

## **9 Using the ITM-SC Interface**

Overview	<a href="#">9-1</a>
----------	---------------------

### **Section: HP-Vue Specific Subjects**

Overview	<a href="#">9-2</a>
Front Panel	<a href="#">9-3</a>
General Modules	<a href="#">9-4</a>
Buttons and Mouse Movement	<a href="#">9-8</a>

### **Section: ITM-SC Specific Modules and Windows**

Overview	<a href="#">9-9</a>
Accessing the ITM-SC Specific Modules	<a href="#">9-10</a>
Management Module	<a href="#">9-11</a>
Administration Module	<a href="#">9-12</a>
General ITM-SC Windows	<a href="#">9-14</a>
Main EMS—Menu Window	<a href="#">9-18</a>

### **Section: ITM-SC General Tasks**

Overview	<a href="#">9-24</a>
Parameters for Accessing the ITM-SC	<a href="#">9-25</a>
Accessing the ITM-SC	<a href="#">9-26</a>
Changing Password	<a href="#">9-27</a>

---

Report Concepts	<a href="#">9-28</a>
Printing a Report	<a href="#">9-30</a>
View a Report	<a href="#">9-31</a>
Logout of the ITM-SC	<a href="#">9-32</a>
Logout	<a href="#">9-33</a>

**Section: ITM-SC Network Map**

Overview	<a href="#">9-34</a>
ITM-SC Network Map Concepts	<a href="#">9-35</a>
Customizing ITM-SC Network Map Concepts	<a href="#">9-39</a>
Parameters for Managing Map Groups	<a href="#">9-40</a>
Windows for Managing Map Groups	<a href="#">9-41</a>
Managing Map Groups Procedures	<a href="#">9-43</a>

---

<b>GL</b>	<b>Glossary</b>	GL-1
-----------	-----------------	------

---

<b>IN</b>	<b>Index</b>	IN-1
-----------	--------------	------



# List of Figures

## 8 Concepts

8-1	OSI-DCN	<a href="#">8-3</a>
8-2	ISO-DCC NSAP address format	<a href="#">8-7</a>
8-3	Local-Lucent NSAP address format	<a href="#">8-8</a>
8-4	Flexible NSAP address format	<a href="#">8-9</a>
8-5	Network areas	<a href="#">8-11</a>
8-6	Types of OSI-DCN networks	<a href="#">8-13</a>
8-7	Network Architecture example	<a href="#">8-18</a>
8-8	IP Tunnel example	<a href="#">8-19</a>
8-9	Next Hop Identification	<a href="#">8-21</a>
8-10	Example of an DSwT Network	<a href="#">8-23</a>
8-11	Tunnel Auto Provisioning Principle (TAP)	<a href="#">8-26</a>
8-12	The principle of connecting IS-IS Areas with manual TAP Tunnels	<a href="#">8-28</a>
8-13	Timing references	<a href="#">8-39</a>
8-14	Timing modes	<a href="#">8-40</a>
8-15	An example of timing in a network	<a href="#">8-42</a>

8-16	An example of priority settings in a network	<a href="#">8-45</a>
8-17	An example of a timing chain with a regenerator loop.	<a href="#">8-46</a>
8-18	A timing loop	<a href="#">8-47</a>
8-19	A 2 Mbit/s signal entering an SDH network and leaving it with 2 Mbit/s retiming	<a href="#">8-49</a>
8-20	The three basic timing functionalities.	<a href="#">8-51</a>
8-21	Example of a Transmission Plan	<a href="#">8-53</a>
8-22	Drawing of the current network configuration	<a href="#">8-54</a>
8-23	Cross Connections on the WaveStar® AM1	<a href="#">8-55</a>
8-24	TUG Structure	<a href="#">8-56</a>
8-25	WaveStar® AM 1 network elements in Point-to-Point configuration	<a href="#">8-59</a>
8-26	WaveStar® AM 1 network elements in LAN-interconnect configuration	<a href="#">8-60</a>
8-27	WaveStar® AM 1 network elements in LAN-VPN configuration	<a href="#">8-61</a>
8-28	Relation LAN ports, WAN ports and SDH channels	<a href="#">8-63</a>
8-29	Example of a learning bridge with multiple ports	<a href="#">8-65</a>
8-30	Example of SDH ports that are switched off due to the spanning tree algorithm	<a href="#">8-66</a>
8-31	Ports for LAN Unit	<a href="#">8-68</a>
8-32	Example of MSP protection.	<a href="#">8-71</a>
8-33	Example of SNC protection	<a href="#">8-74</a>
8-34	Physical and Logical Ports	<a href="#">8-77</a>
8-35	Test Loop for Physical Ports of 2 Mbit/s Port Units	<a href="#">8-78</a>
8-36	path trace on termination points	<a href="#">8-79</a>







# About this information product

---

<b>Purpose</b>	The ITM-SC Provisioning Guide (PG) is a network management oriented guide. The guide instructs the user how to use the ITM-SC to provision network equipment.
<b>Reason for reissue</b>	First issue.
<b>Safety labels</b>	Not applicable for the Provisioning Guide.
<b>Intended audience</b>	<p>Network operators and other personnel who need to provision equipment with an management system (ITM-SC).</p> <p>Provisioning personnel have to perform the tasks:</p> <ul style="list-style-type: none"><li>• Collect information of provisioning data (e.g. check shelf layout, units list)</li><li>• Put ports in-service and out-service</li><li>• Assign timeslots (Cross Connections)</li><li>• Assign service to network units</li><li>• Configure the network according to the required adjustments</li><li>• Download and upload the provisioning data to and from the network elements</li><li>• Recognize, interpret, analyze or correct failures, caused by provisioning data that is configured incorrectly.</li></ul>

## How to use this information product

The ITM-SC Provisioning Guide (PG) for the network element is divided into a number of chapters. Through this readers can quickly select the subject of their interest and need.

This guide is divided into the chapters:

- About this Information Product (IP). This chapter describes the structure and organization of the Provisioning Guide (PG).
- Management communication setup. This chapter, the user gets support for subjects such as:
  - Set network element address
  - Set network element name (TID)
  - Change management area
  - Set date and time.
- Equipment provisioning. The user would come to this chapter either with a network element that has no information about the equipment or only has default information. This chapter provides instructions to move from that state to a network element with complete provisioning information on that equipment, including the equipment protection according to the user's needs. Examples are:
  - Modify equipping information
  - Modify equipping defaults
  - Provision equipment protection
  - Define automatic laser shutdown settings
  - Provision miscellaneous discrete inputs and outputs.
- Topology management. This chapter explains to the user of a management system how to:
  - Define connections between network elements
  - Create network element groups (aggregates).
- Timing provisioning. This chapter explains to the user how to deliver a timing signal with predefined quality. The user gets support on tasks as:
  - Provisioning the timing of a network element
  - Provision the timing marker settings.
- Traffic provisioning. This chapter explains how to set up the network traffic, including paths and cross connections. This chapter needs to be used in conjunction with the next chapter (Traffic Maintenance).

Examples tasks are:

- Set up a path
  - Create low level cross connection
  - Modify an existing path
  - View the present cross connections and protection
  - Create new cross connections with or without the different types of protection
  - Change existing cross connections and/or existing protection.
- Traffic maintenance. This chapter explains how to set up the maintenance for paths and check the path including its protection. The user starts with a path through the network, including its protection. The user ends with a tested path including its protection, and complete performance monitorin and alarm thresholds settings.

Examples tasks are:

- Set termination points to be monitored
  - Create Traffic Ports, both physically and logically
  - Create Termination points
  - Verify the path using trail trace
  - Set the signal degradation threshold for the path (the signal degradation thresholds determines whether or not to generate an alarm and whether or not a protective switch will take place)
  - Switch the protection of the path
  - Verify the protection path using trail trace
  - Start performance monitoring.
- Software upgrade. This chapter explains how to manage and upgrade the network element software.

Examples are:

- Find out what software versions are loaded in the network element
  - Download the new software image
  - Check whether software download was successful
  - Switch stores.
- Concepts. The concepts chapter(s) contains all the knowledge information. The user can use this chapter(s) when they don't understand a task.
  - ITM-SC tutorial. This chapter provides instruction on common system functions.

For example:

- View alarms
- Distinguish network element alarms from ITM-SC alarms (ITM-SC alarms need to be forwarded to the Administrator)
- Display alarm reports
- Back matter. Glossary, Index, Abbreviations, and so on.

### Conventions used

The samples of windows shown in this guide are examples of typical windows. The text on a window as well as the window itself may differ slightly from the window displayed on the ITM-SC.

This guide uses the following notations:



### DANGER

*Suggests the possibility of a personal injury*



### CAUTION

*Suggests the possibility of service interruption*



### WARNING

*Suggests the possibility of equipment damage or software corruption*

**Important!** Gives supplementary information

### Approval mark

The following CE approval mark applies to this product.



CE Marking is the indicator for products conform with relevant European Community (EC) Directives. CE stands for Conformité Européenne. The CE-marked transmission equipment is compliant with one EC Directive: 89/336/EEC - Electro-magnetic compatibility

(EMC). In this manual you will find several chapters in relation with the CE-marking, for example the use of EMC closed connector Hoods, filtered connectors, and warnings to use a wrist strap when handling equipment.

**Customer Documentation  
network element (NE)  
Related**

The following documents are NE related:

- The APPLICATION AND PLANNING GUIDE provides an understanding of what the network element is and how to plan to use and order it.
- The NETWORK ELEMENT INSTALLATION GUIDE provides an understanding on physical installation of the network element and for connecting the cabling to the NE.
- The USER OPERATIONS GUIDE instructs the user how to operate the network element using an ITM-CIT, including provisioning and maintenance tasks.
- The ALARM MESSAGES AND TROUBLE CLEARING GUIDE instructs the user how to respond to alarms and fix problems with the network element using the ITM-CIT.

**Customer Documentation  
Subnetwork Controller  
Related**

The following documents are Subnetwork Controller related:

- The ITM-SC APPLICATION AND PLANNING GUIDE provides an understanding of what the ITM-SC is and how and how to plan to use and order it.
- The ITM-SC INSTALLATION GUIDE instructs the user how to install the ITM-SC and configure the running environment.
- The ITM-SC ADMINISTRATION GUIDE instructs the user how to administer the ITM-SC.
- The ITM-SC MAINTENANCE GUIDE Instructs the user how to maintain the ITM-SC and network.
- The ITM-SC PROVISIONING GUIDE for the network element instructs the user how to use the ITM-SC to provision network equipment.
- The ITM-SC ALARM MESSAGES AND TROUBLE CLEARING GUIDE instructs the user how to respond to alarms and fix problems with the ITM-SC.

**How to comment** A feedback form has been placed after the title page for your comments or suggestions about this information product. Please copy this feedback form and follow the instructions on the form to submit your feedback.

**How to order** Copies of this document can be obtained from the Customer Training and Information Products organization within Lucent Technologies, which can be found at URL <http://www.lucent-info.com/>



# 1 DCN Management

## Overview

---

- Purpose** The purpose of DCN Management is provisioning the DCN parameters for a network element.
- Objective** The objective of provisioning the DCN parameters is to optimize the communication between network elements and the ITM-SC.
- Outcome** An optimized DCN in which the exchange of routing data is minimized with full management of NEs.
- Intended use** This chapter explains the concepts of provisioning the DCN. After the concepts the procedures used for DCN Management are described.



## Section : Edit General Network Element Information

### Overview

---

**Purpose** The purpose of this procedure is to edit the general network element Information containing the location, address and DCN parameters.



## Edit General Network Element Information

---

- When to use** Use this procedure to change:
- The network element location.
  - The NSAP address of the network element (Area Identifier or SID).
  - Management Connection settings.
  - IS-IS Level settings.
  - Designated Router Priority.
  - Additional Manual Area Addresses.

- Before you begin** Before changing network element information notice the following precautions and prerequisites:
- If the Association State has changed after the Edit screen was displayed, the changes are discarded and an error message is displayed.
  - When the IS-IS parameters are changed this may cause the network element to restart, resulting in a temporary loss of association. If the network element is participating in a GR scheme this may cause an automatic protection switch. A warning message is displayed.
  - If the values of the IS-IS parameters are incorrect this may cause instabilities in the DCN and may result in many network elements becoming unmanageable. A warning message is displayed.
  - Do not create an area with the area ID 0000, because this is already the default area ID for all newly ceated NEs.
  - Choosing the Static value for the Connection Type option makes the Gateway network element a single point of failure in the management of the network element.
  - When the *LAN IS-IS Level* is set to *None* (NO-IS-IS) a network element cluster that is not directly connected to the ITM-SC Q-LAN may become unmanageable when *None* is chosen for the cluster gateway. *None* also prevents traffic from one cluster from being routed to another cluster over the Q-LAN.
  - The value of the designated router priority is composed in a specialized plan, so do not change it unless this plan is available.

Edit General Network Element Information

- If an additional Manual Area Address is provisioned when the Computed Area Address Table (CAAT) is full, this may cause a loss of entries in the CAAT which results in a loss of association. If the network element is participating in a GR scheme this may cause an automatic protection switch. A warning message is displayed.
- Before starting to change the provisioned network element information, all information about the Data Communications Network (DCN) must be available: the network element name, location, NSAP address, the type of management connection, the IS-IS level parameters, the designated router priority and Additional Manual Area Addresses.

**Related information**

The following procedures are related:

- Provision a network element from a template
- Create a MIB image from a network element
- Create a pre-provisioned network element
- Section DCN Management Concepts in chapter Concepts.

**Procedure**

Follow these steps to change the general information of a network element:

- .....
- 1 Select *Provisioning --> Equipment --> NE Information*.

**Result:**

The *EMS - Provisioned NE Information* window appears.

.....

- 2 To select an NE or to switch to another NE, click the Selection Dialog Button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.
- .....

- 3 Click *Edit*.

**Result:**

The *EMS - Edit Provisioned NE Information* window appears.

.....

- 4 Fill in the new NE Location, the IS-IS Level of the NE, and LAN IS-IS Level fields, also set the Designated Router Priority.

**Result:**

All the information to change is filled in.

.....

- 
- 5 Click OK to confirm the current changes.

**Result:**

The changes are now stored.

---

- 6 Confirm the current changes if an Edit confirmation window displaying the consequence of the changes to the network appears.

**Result:**

The changes are confirmed.

---

- 7 Click Cl ose to exit the *EMS - Edit Provisioned NE Information* window and click Cl ose again to exit the *EMS - Provisioned NE Information* window.

**Result:**

All windows disappear.

END OF STEPS

---



## Parameters for Editing General Network Element Information

---

**Provisioned NE** Name of the network element. The name must be unique across management domains. The value can be up to 20 uppercase or lowercase characters.

**Association State** The possible association states between the ITM-SC and the network element are described below:

Association State	Description
Closed	No active association.
Connected	An association is active.
Associating	An association is being attempted.
Maintaining	An association failed, regularly a new attempt is made.
Released (12NC failure)	An association was released because ITM-SC did not recognize the NE software version.
Released (Interface Error)	An association was not established because the ITM-SC NE interface failed.
Released (Manually Disabled)	An association was manually disconnected.
Released (GR Switched/Retrieved)	An association was released after a manual geographic redundancy switch/handback.
Released (Association Failed)	The link association the ITM-SC and NE failed.

**NE Type** Shows the type of network element, for example SLM, ISM, ADM155C, WaveStar® ADM 16/1, etc.

**NE Location** The NE location field shows the geographical location of the provisioned network element. The value can be up to 20 uppercase or lowercase characters.

The NE location field is grayed out when the association state between the ITM-SC and the NE is *Released*.

**Automatic Power Down** Enables/disables automatic power down function. Only applicable for OLS80G network elements.

**Single End Terminal Type** Type of single end terminal configuration. Only applicable for OLS80G network elements.

**OA Mode** Configuration mode of the OAs (Optical Amplifiers) of the OLS80G network element.

**OA State** The actual operation mode of the OA of the network element. Only applicable for OLS80G network elements.

**NSAP format** The NSAP address of a node is its DCN wide identifier which uniquely identifies the node in the network. The different formats are described in the table below:

NSAP format	Description
Fixed 20 byte	40 hexadecimal digits.
Fixed 10 byte	20 hexadecimal digits.
Flexible	Else (16 - 40 hexadecimal digits).

**Area ID** The Area ID indicates the area to which a node belongs and thus its logical location in the network.

Area ID for fixed 20 byte and fixed 10 byte NSAP format: 4 hexadecimal digits (2 bytes).

**Area Address** Area address for flexible NSAP format: 2 - 26 hexadecimal digits (1-13 bytes).

**SID Entry Format** **Important!** The *Short* code is only applicable for ISM NEs. Grayed out otherwise.

Format of the network element address. The values are described in the table below:

SID Entry Format	Description
SID	System Identifier (12 hexadecimal digits).
Short	2 hexadecimal digits.

**NE SID** Identifies the network element. Consists of 12 hexadecimal digits (6 bytes).

**Connection type** Controls network management data routing. The connection type field is grayed out when the association state between the ITM-SC and the NE is *Connected*. The possible connection type values are described

in the table below:

Connection type	Description
Dynamic	Management data is routed dynamically. The ITM-SC chooses the most suitable Intermediate System (IS) on the Q-LAN through which it communicates with this network element.
Static	The management data route is forced. The management system uses a user-defined network element (Ethernet) address to select one Intermediate System (IS) via which the ITM-SC communicates with a node. This network element is referred to as the Gateway network element.

**NE Connected** The NE connected field determines how the network element is connected. The possible values are described in the table below:

NE Connected	Description
Via Gateway	The network element is connected via a gateway node through which it is managed by the ITM-SC.
on LAN	The ITM-SC manages the network element directly through a Q-LAN connection.

The NE connected field is grayed out when:

- The association state between the ITM-SC and the NE is *Connected*.
- The connection type is set to *Dynamic*.

**Gateway Format** The gateway format field determines the format of the gateway via which this network element is managed. The possible gateway format values are described in the table below:

Gateway Format	Description
Ethernet	12 Hexadecimal digits.
Short	2 Hexadecimal digits.

The gateway format field is grayed out when:

- The association state between the ITM-SC and the NE is *Connected*.
- The connection type is set to *Dynamic*.
- The NE connected option is set to *on Lan*.

### **Gateway Ethernet Address**

Address of the gateway via which this network element is managed. The format depends on setting of Gateway Format field.

The gateway ethernet address field is grayed out when:

- The association state between the ITM-SC and the NE is *Connected*.
- The connection type is set to *Dynamic*.
- The NE connected option is set to *on Lan*.

### **Designated Router Priority**

The designated router priority is a value which indicates the priority of the Designated Router connected to the Q-LAN. A higher number has priority over a lower one. Valid values are 0-127. The default value is 64.

This value is composed in a specialized plan, so do not change it unless this plan is available.

The designated router priority field is grayed out when:

- The association state between the ITM-SC and the NE is *Released*.
- The NE is a TM1 node.

### **Additional Manual Area Addresses**

A synonymous Area Address associated with an Intermediate System. Together with the SID and SEL fields, it is a valid synonymous NSAP address for an Intermediate System. The Manual Area Address can be used to connect subnetworks to the OSI-DCN with nodes having a different NSAP format than the formats supported.

The additional manual area address field is grayed out when:

- The association state between the ITM-SC and the NE is *Released*.
- The NE is a TM1 node.

### **IS-IS Functionality of NE**

The IS-IS functionality of NE field changes the IS-IS level of the network element.

The IS-IS level of NE field is grayed out when:

- The association state between the ITM-SC and the NE is *Released*.
- The NE is a TM1 node.

The possible IS-IS level values for an NE are described in the table below:

IS-IS Functionality of NE	Description
Level 1	Provides interconnectivity between network elements in the same area.
Level 1+2	Provides interconnectivity between areas and between network elements in the same area.
Level 1+2 Area Repair Access	Provides interconnectivity between areas and between network elements in the same area and enables Area Partition Repair Access.

Note: The option Level 1+ 2 + Area Repair Access is only applicable for AM1 NEs.

#### LAN IS-IS Level on LAN

The LAN IS-IS level on LAN field changes the IS-IS level on the Q-LAN port.

The LAN IS-IS level on LAN field is grayed out when:

- The association state between the ITM-SC and the NE is *Released*.
- The NE is a TM1 node.

**Important!** *Level 2* is grayed out if the IS-IS Level of NE is set to *Level 1*!

The possible LAN IS-IS level values are described in the table below:

LAN IS-IS Level on LAN	Description
Normal IS-IS	The LAN IS-IS level is the same as the level of the network element provisioned in IS-IS Level of NE. Under normal circumstances the network element should use this value.

<b>LAN IS-IS Level on LAN</b>	<b>Description</b>
Level 2	The LAN IS-IS level is set to level 2. This value should only be used temporarily during upgrade activities.
No IS-IS	Disables the Q-LAN port of an network element for the IS-IS protocol (NO-IS-IS). This value is used in combination with static routing to the management system.



## Section: Data Communications Channel (DCC)

### Overview

---

**Purpose** The purpose of this procedure is to change the DCC status in the Regenerator Section (RS) and Multiplexer Section (MS) of each STM-N port.



## Provisioning the Data Communications Channel (DCC)

---

**When to use** Use this procedure to reduce the exchange of routing data between network elements. Reduction of the exchange of management data is done in order to optimize the Data Communications Network (DCN). The DCC status can be set to enabled or disabled in order to achieve this.

**Before you begin** Pay attention to the following:

- Disabling DCC can cause permanent loss of association between the ITM-SC and the network element. In that case the DCC ports can be enabled by a local login with the Local Workstation
- Enabling DCC can cause instability in the Data Communications Network (DCN)
- A data communications network plan must be available.

**Related information** Related procedures and information are:

- Change general Network Element information
- Manage Network Element associations
- Section DCN Management Concepts in chapter Concepts.

**Procedure** Follow this procedure to provision the DCC:

---

**1** Select *Management --> Overlay Comms Network --> DCC List*.

**Result:**

The *EMS - DCC List* window appears.

---

**2** To select an NE or to switch to another NE, click the Selection Dialog Button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The *EMS - DCC List* window is updated with the information of the selected network element.

---

**3** Select the port for which the DCC parameter must be changed and click Edit.

**Result:**

The *EMS - Edit DCC* window for this port appears.

- 
- 4** Select the DCC status for the selected port.

**Result:**

The DCC status is selected.

- 
- 5** Click OK.

**Result:**

The new setting is confirmed and the *EMS - DCC Edit* window disappears.

END OF STEPS



## Parameters for Provisioning Data Communications Channel (DCC)

---

**Port** Shows the line and tributary ports on which DCC is available.

**DCC** Shows the current status of the DCC. This can be enabled or disabled.  
When not applicable, "-" is displayed.



## Section: Data Communication Test

### Overview

---

**Purpose** The Data Communication Test checks the association between the network element and the ITM-SC to ensure that they communicate successfully.



## Performing the Data Communication Test

---

- When to use** Use this procedure when assuming bad or no association between the ITM-SC and the network element.
- Before you begin** The network element is provisioned and has a association with the ITM-SC.
- Related information** Related procedures and information are:
- Disabling/enabling association
  - NE status list
  - MIB update
  - MIB download
  - MIB upload
  - Provisioning NE information
  - Section DCN Management Concepts in chapter Concepts.
- Procedure** To perform the Data Communications Test follow this procedure:
- 
- 1 Select *Management --> Overlay Comms Networks --> Data Comms Test*.  
**Result:**  
*The EMS - Data Communications Test window appears.*

---

  - 2 Click *Edit* to prepare a new Data Communications Test.  
**Result:**  
*The EMS - Edit Data Communications Test window appears.*

---

  - 3 Select one or more network elements from the list, or click the *Select All* button to perform the test on all network elements.  
**Result:**  
This selects the NEs on which the test will be performed.

---

  - 4 Click *Apply*.  
**Result:**  
The test is started.

- 
- 5 Click Cl ose on the EMS - *Edit Data Communications Test* window.

**Result:**

The EMS - *Edit Data Communications Test* window disappears.

---

- 6 Click Cl ose on the Data Communications Test window.

**Result:**

The *EMS - Data Communications Test* window disappears.

END OF STEPS

---



## Parameters for Performing the Data Communication Test

---

**Last Tested** Shows the time and date of the last performed test.

**Test Status** Use this table to decide the status of the Data Communication Test:

Test status	Description
No Test	No test has been made.
Test Passed	There is communication between the ITM-SC and the network element.
Test Failed	No communication could be established between the ITM-SC and the network element during the test.







## 2 Equipment Provisioning

### Overview

---

**Objectives** Equipment provisioning provides the configuration data for the WaveStar® AM 1. Provisioning is the preparatory work that is done to ensure that a network element (NE) properly functions and so that the NE may be included in a network. After initial provisioning, any subsequent changes in the NE's equipment mean that provisioning must once more be performed.

Through provisioning, the correct configuration data is provided for the *WaveStar*® AM 1.

**Outcome** The objective of equipment provisioning is to eventually include a network element in an SDH network. To enable the *WaveStar*® AM 1 to become a functioning part of a network, it must first be provided with the correct configuration data.

**Intended use** This chapter provides all procedures needed to provision the equipment of a *WaveStar*® AM 1 network element when using the ITM-SC. The chapter begins with the conceptual information necessary to properly execute the procedures. After these concepts, the procedures are presented.



## Section: Creating an NE Template

### Overview

---

**Purpose** Creating an NE template provides a basis for provisioning or pre-provisioning several similar NEs.



## Create NE Template

---

**When to use** Creating a network element template provides a basis for provisioning or pre-provisioning several similar network elements.

**Before you begin** Before starting to create a network element template be sure to have information about:

- The name the template must have
- Which template (default or user-defined) to use as a basis for the new template.

**Related information** The following procedures and information are related:

- View NE Template Slot Information
- Modify an NE Template
- Delete an NE Template
- Provision an NE from a Template
- Create a Pre-Provisioned NE
- Section Equipment Provisioning Concepts in chapter Concepts.

**Procedure** Follow these steps to create a network element template.

---

**1** Select *Templates -> Equipment -> Create*.

**Result:**

The EMS - Create NE Template window is displayed. It is possible to create a network element template with an existing network element template (default or user-defined) as the basis.

---

**2** Enter the name for the new template in the field *User NE Template Name*.

---

**3** Click the selection dialog button, and select the desired template (default or user-defined) from the EMS - NE Template Selection Dialog window. Then, click OK.

**Result:**

The EMS - Create NE Template is updated with the information from the selected template. The new template will use the selected template as a basis.

---

**4** Click *Apply* to create the new network element template.

---

- 
- 5** Click Cl ose to exit this window.

**Result:**

The EMS - Create NE Template window disappears.

END OF STEPS

---



## Parameters for Creating an NE Template

---

<b>Base NE Template</b>	The name of the template being used as a basis for the creation of the new template.
<b>Base NE Type</b>	The type of NE associated with the base NE template.
<b>Base NE Template Type</b>	This lists the type of template being used as the basis. It may be <i>Default</i> , a template existing in the system software; or it may be <i>User Defined</i> , a template previously created by a user.
<b>User NE Template Name</b>	This is the name given to the new template being created.



## Section: Viewing NE Template Slot Information

### Overview

---

**Purpose** This procedure allows the user to see exactly how the slots are configured for any existing NE template.



## View NE Template Slot Information

---

**When to use** It is useful to view the slot configuration of a template:

- When choosing an existing template to serve as a basis in creating a new template
- After creating a user-defined template to see what must be modified to adapt this template to the user's needs.

The slots of a template are configured in a certain way in each template. This procedure allows the user to see how each slot is provisioned.

**Before you begin** No prerequisites or precautions are needed when performing this procedure.

**Related information** The following procedures and information are related:

- Create an NE Template
- Modify an NE Template
- Delete an NE Template
- Provision an NE from a Template
- Section Equipment Provisioning Concepts in chapter Concepts.

**Procedure** Follow these steps to view network element template slot information.

---

- 1 Select *Templates* -> *Equipment* -> *NE Inventory*.

**Result:**

The EMS - NE Template Inventory window is displayed.

---

- 2 Click the selection dialog button and select the required template (default or user-defined) from the EMS - NE Template Selection Dialog window. Then, click OK.

**Result:**

The EMS - NE Template Inventory window is updated with the units associated with the selected template.

---

- 3 To view details for a particular slot, select the *Slot* and click *Details*.

**Result:**

The EMS - NE Template Slot Information window displays information for the selected slot.

.....

- 4** To view information for a different slot, either in the selected template or in another template, return to step 2.
- .....

- 5** Click Cl ose.

**Result:**

The EMS - NE Template Slot Information window disappears.

.....

- 6** Click Cl ose.

**Result:**

The EMS - NE Template Inventory window disappears.

END OF STEPS

.....



## Parameters for Viewing Template NE Slot Information

---

- NE template name** This is the name of the selected template.
- NE type** The type of NE associated with the template.
- NE template type** There are two types of templates. The first is *Default*, a template that is part of the system software. The other is *User Defined*, a template custom designed by the user.
- Slot** The slot position is listed here.
- Unit item code** The special alphanumeric code associated with a particular unit is listed.
- Unit type** The type of unit provisioned in the listed slot is shown.
- Slot state** Displays the status of the listed slot. The different slot states are given in the table below.

Slot State	Description
Assigned	Slot is assigned.
Unassigned	Slot is unassigned.
Auto	Slot is provisioned but waiting for unit. Once the provisioned unit is present, the slot state will automatically change to <i>Assigned</i> .

- Cards** This is a list of the possible units that may be provisioned.



## Section: Modifying an NE Template

### Overview

---

**Purpose** The slot configuration for an existing user-defined template can be edited.



## Modify NE Template

---

**When to use** After creating a user-defined template, this template still is configured in the same way as the basis template. This configuration can be altered using this procedure. Moreover, any existing user-defined template can be changed to suit the user's needs.

**Before you begin** Before modifying an NE templatler determine the following:

- The selected template to be modified must be a user-defined template: default templates cannot be modified.
- The desired configuration of the template's slots should be known
- For the *WaveStar*® AM 1, it is possible to modify slot TS2 and to change the slot states
- Before starting to assign units to a slot, be sure that it is possible to assign a particular unit type to the selected slot. For each slot, a unit may be selected from the list "Cards". All possible units for the *WaveStar*® AM 1 appear in the "Cards" list; however, not all units may be provisioned in the available slot. If an incorrect unit is provisioned in any of the template slots, then no error message appears. Only later, when this template is used for provisioning, will the error message be shown. The creation of the NE from this template will fail and a slot configuration error will be displayed.

**Related information** The following procedures and information are related:

- Create an NE Template
- View NE Template Slot Information
- Provision an NE from a Template
- Section Equipment Provisioning Concepts in chapter Concepts.

**Procedure** Follow these steps to modify a network element template.

---

**1** Select *Templates -> Equipment -> Slot*.

**Result:**

The EMS - NE Template Slot Information window is displayed.

---

**2** Click the selection dialog button to select a particular slot. Select the required template from the list of NE Templates, then select a slot from the list of slots. Confirm by clicking OK.

**Result:**

The *EMS - NE Template Slot Information* window is updated with the information for the selected slot.

---

- 3** Click *Edit* to modify the slot information.

**Result:**

The *EMS - Edit NE Template Slot* window appears.

---

- 4** Select the unit for the slot from the list *Cards*. Then, if necessary, change the *Slot State*.

**Important!** If it is not possible to select the required unit from the list *Cards*, contact the system administrator.

**Result:**

For the selected slot, the correct unit with the proper slot state are displayed.

---

- 5** Click *OK* to confirm the current settings.

**Result:**

The modified slot information is entered, and the *EMS - Edit NE Template Slot* window disappears.

---

- 6** Click *Close* to exit this window.

**Result:**

The *EMS - NE Template Slot Information* window disappears.

END OF STEPS

---



## Parameters for Modifying an NE Template

---

**NE template type** There are two types of templates. The first is *Default*, a template that is part of the system software. The other template type is *User Defined*, a template designed by the user.

**Slot** The slot position is listed here.

**Unit item code** The special alphanumeric code associated with a particular unit is listed.

**Unit type** The type of unit provisioned in the listed slot is shown.

**Slot state** Displays the status of the listed slot. The different slot states are given in the table below.

Slot State	Description
Assigned	Slot is assigned.
Unassigned	Slot is unassigned.
Auto	Slot is provisioned but waiting for unit. Once the provisioned unit is present, the slot state will automatically change to <i>Assigned</i> .

**Cards** This is a list of the possible units that may be provisioned.



## Section: Deleting an NE Template

### Overview

---

**Purpose** Deleting an NE template removes the template from the ITM-SC database.



## Delete NE Template

---

**When to use** A template can be deleted from the ITM-SC database when it is no longer necessary for provisioning.

**Before you begin** Only user defined templates can be deleted. Attempts to delete a factory defined template will result in an error message.

**Related information** The following procedures and information are related:

- Create an NE Template
- View NE Template Slot Information
- Modify an NE Template
- Provision an NE from a Template
- Section Equipment Provisioning Concepts in chapter Concepts.

**Procedure** Follow these steps to delete a template.

---

**1** Select *Templates -> Equipment -> Delete*.

**Result:**

The EMS - Delete NE Template window is displayed.

---

**2** Click the selection dialog button and select the desired template (user-defined) from the EMS - NE Template Selection Dialog window. Then, click OK

**Result:**

The EMS - Delete NE Template window displays the selected template.

---

**3** Click *Apply* to delete the network element template. Note that default templates may not be deleted.

---

**4** Click *Close* to exit this window.

**Result:**

The EMS - Delete NE Template window disappears.

END OF STEPS

---



## Parameters for Deleting an NE Template

---

**NE template name** This is the name of the selected template.

**NE type** The type of NE associated with the displayed NE template.

**NE template type** This is the type of template. It may be *Default*, a template existing in the system software; or it may be *User Defined*, a template previously created by a user.



## Section: Creating a Pre-Provisioned NE

### Overview

---

**Purpose** Creating a pre-provisioned NE involves completing the initial provisioning work to include a network element in the network. Obviously, since pre-provisioning may be done before the NE is operational, the NE may be more quickly placed into service.



## Create a Pre-Provisioned NE

---

**When to use** A pre-provisioned NE is generally created when the network element is not yet operational. It could be the case, for instance, that the configuration and management information is known but the NE has not been installed yet.

**Before you begin** To create a pre-provisioned NE, the following information must be available: the NE name and location, the NSAP address, the management connection information, and the template to be used as the basis for the pre-provisioned NE.

**Related information** The following procedures and information are related:

- Edit Pre-Provisioned NE Information
- View the Pre-Provisioned NE Slot Configuration
- Edit Pre-Provisioned NE Slot Information
- Delete a Pre-Provisioned NE
- Provision an NE from a Pre-Provisioned NE
- Section Equipment Provisioning Concepts in chapter Concepts.

### Procedure

---

- 1 Select *Pre-Provisioning -> Create*.

**Result:**

The EMS - Create Pre-Provisioned NE window appears. This window allows creation of a pre-provisioned network element in the ITM-SC database using a selected network element template.

---

- 2 Click the selection dialog button and select the desired template (default or user-defined) from the EMS - NE Template Selection Dialog window. Then, click OK.

**Result:**

The EMS - Create Pre-Provisioned NE window is updated with the information from the selected template.

---

- 3 Enter the *NE Name*, and if desired, click in the *ITM-NM Style* box.

**Important!** If the network element is managed by the ITM-NM, select the *ITM-NM Style* box. If this box is selected, then the name format can fail at two levels. It may be completely ITM-NM incompatible, or it may be compatible but not the preferred format.

See the parameters section for a complete explanation of how to choose an ITM-NM compatible name.

**Result:**

The network element name appears in the field *NE Name*.

.....

- 4** Enter the *NE Location*.
- .....

- 5** Enter the information in *Address to Connect to NE*.

**Result:**

The NSAP address of the network element is entered.

.....

- 6** Enter the *Initial Management Connection* fields.
- .....

- 7** Click *Apply*.

**Result:**

The pre-provisioned network element is now created.

.....

- 8** Click *Close*.

**Result:**

The EMS - Create Pre-Provisioned NE window disappears.

END OF STEPS

.....



## Parameters for Creating a Pre-Provisioned NE

---

**NE name** The network element's name is listed. The name must be unique across management domains. If the NE is not managed by the ITM-NM, then the name may be up to 20 characters in length. If the NE will be managed by the ITM-NM, then the name must be 3 to 10 characters long with the last three characters a slash and two digits. Only A-Z, 0-9, \_, /, and - are permitted for network elements managed by the ITM-NM. An example of an ITM-NM compatible name is LONDON/02.

**NE location** The location of the network element is given. The location may have up to 20 uppercase or lowercase characters.

**Address to connect to NE** The address of the selected NE is indicated. There are various parts of the address; the table below describes these different parts and their possible values.

Field Name	Description	Possible Values
NSAP Format	The format of the NSAP address.	<i>Fixed 20 Byte, Fixed 10 Byte, or Flexible.</i>
Area	Indicates the area to which an NE belongs.	<i>Area ID</i> for fixed 20 byte and fixed 10 byte NSAP format: 4 hexadecimal digits (2 bytes). <i>Area Address</i> for flexible NSAP format: 2 - 26 hexadecimal digits (1-13 bytes).
SID Entry Format	The format of the NE address.	<i>SID</i> : System Identifier. <i>Short</i> : Not applicable.
NE SID	Identifies the NE.	12 hexadecimal digits (6 bytes).

**Initial management connection** Like the address, the initial management connection has several different parts. These are described in the table below. Note that the three fields NE Connected, Gateway Format and Gateway Ethernet Address are only valid if the connection type is *Static*. When

connection type is set to *Dynamic* these fields are grayed out.

Field Name	Description	Possible Values
Connection Type	Controls network management data routing.	<i>Dynamic</i> : Management data is routed dynamically by the network using ES-IS/IS-IS protocols.  <i>Static</i> : The management data route is forced. The management system uses a user-defined network element (Ethernet) address to select one Intermediate System (IS) via which the ITM-SC communicates with a node.
NE Connected	Determines how the NE is connected.	<i>via Gateway</i> : The network element is connected via a gateway node through which it is managed by the ITM-SC.  <i>on LAN</i> : The ITM-SC manages the network element directly through a Q-LAN connection.
Gateway Format	Determines the format of the gateway via which this NE is managed.	<i>Ethernet</i> (12 Hexadecimal digits) or <i>Short</i> (2 Hexadecimal digits): only if the gateway is an ISM.
Gateway Ethernet Address	Address of the gateway via which this NE is managed.	Address format depends on setting of <i>Gateway Format</i> field.

**Management connection options**

There are several ways in which the management connection can be provisioned. Use the table below to complete the *Initial Management Connection* parameter and thus set the desired management connection.

If...	then...
Dynamic routing is to be used. This is preferable when using IS-IS areas.	Set the <i>Connection Type</i> to <i>Dynamic</i> .

If...	then...
<p>The NE is to be managed via a gateway NE using long addressing, Note this introduces IS-IS clustering. The routing is static. If the gateway network element fails, no alternative route is sought to the NE.</p>	<p>Set the <i>Connection Type</i> to <i>Static</i>. Set <i>NE Connected</i> to <i>via Gateway</i>. Set <i>Gateway Format</i> to <i>Ethernet</i>. Enter the full <i>Gateway Ethernet Address</i> (12 Hex digits).</p>
<p>The NE is to be managed via a gateway NE using short addressing, Note this is only possible if the gateway is an ISM. This introduces IS-IS clustering. If the gateway network element fails, no alternative route is sought to the NE.</p>	<p>Set the <i>Connection Type</i> to <i>Static</i>. Set <i>NE Connected</i> to <i>via Gateway</i>. Set <i>Gateway Format</i> to <i>Short</i>. Enter the short <i>Gateway Ethernet Address</i> (2 Hex digits).</p>
<p>The NE is to be managed via a Q-LAN connection, (The network element is connected on the Q-LAN of the ITM-SC.)</p>	<p>Set the <i>Connection Type</i> to <i>Static</i> and <i>NE Connected</i> to <i>on LAN</i>.</p>



## Section: Editing Pre-Provisioned NE Information

### Overview

---

**Purpose** The purpose of this procedure is to change the location, the address, or the management connection information of an existing pre-provisioned network element.



## Edit Pre-Provisioned NE Information

---

**When to use** Follow this procedure when:

- Changing the location of the pre-provisioned NE
- Changing the DCN design.

**Before you begin** Before starting to edit pre-provisioned network element information, all information about DCN must be available, such as:

- The network element name and location
- The NSAP address
- The information related to the management connection
- If the values of the IS-IS parameters are incorrect this may cause instabilities in the DCN and may result in many network elements becoming unmanageable. A warning message is displayed
- Choosing the static value for the connection type option makes the Gateway network element a single point of failure in the management of the network element
- If the LAN IS-IS level is set to 'None' (NO-IS-IS) a network element cluster that is not directly connected to the ITM-SC Q-LAN may become unmanageable when 'None' is chosen for the cluster gateway. 'None' also prevents traffic from one cluster from being routed to another cluster over the Q-LAN.

**Related information** The following procedures and information are related:

- Create a Pre-Provisioned NE
- View the Pre-Provisioned NE Slot Configuration
- Edit Pre-Provisioned NE Slot Information
- Delete a Pre-Provisioned NE
- Provision an NE from a Pre-Provisioned NE
- Section Equipment Provisioning Concepts in chapter Concepts.

### Procedure

---

- 1 Select *Pre-Provisioning -> NE Information*.

**Result:**

The EMS - Pre-Provisioned NE Information window appears.

- 
- 2** Click the selection dialog button to select a pre-provisioned network element. Select the required network element from the EMS - NE Selection Dialog window, and click OK.

**Result:**

The EMS - Pre-Provisioned NE Information window is updated with the information from the selected pre-provisioned network element.

---

- 3** Click Edit.

**Result:**

The EMS - Edit Pre-Provisioned NE Information window appears.

---

- 4** Modify, as necessary, the displayed information for *NE Location*, *Address to Connect to NE*, and *Initial Management Connection*.

**Result:**

The correct information appears in the appropriate fields.

---

- 5** Click OK.

**Result:**

The changes for the pre-provisioned network element are now confirmed, and the window EMS - Edit Pre-Provisioned NE Information disappears.

---

- 6** Click Close.

**Result:**

The EMS - Pre-Provisioned NE Information window disappears.

END OF STEPS

---



## Parameters for Editing Pre-Provisioned NE Information

---

**NE name** The network element's name is listed. The name must be unique across management domains. If the NE is not managed by the ITM-NM, then the name may be up to 20 characters in length. If the NE will be managed by the ITM-NM, then the name must be 3 to 10 characters long with the last three characters a slash and two digits. Only A-Z, 0-9, \_, /, and - are permitted for network elements managed by the ITM-NM. An example of an ITM-NM compatible name is LONDON/02.

**NE location** The location of the network element is given. The location may have up to 20 uppercase or lowercase characters.

**Address to connect to NE** The address of the selected NE is indicated. There are various parts of the address; the table below describes these different parts and their possible values.

Field Name	Description	Possible Values
NSAP Format	The format of the NSAP address.	The default value is <i>Fixed 20 Byte</i> .
Area	Indicates the area to which an NE belongs.	<i>Area ID</i> for fixed 20 byte and fixed 10 byte NSAP format: 4 hexadecimal digits (2 bytes). <i>Area Address</i> for flexible NSAP format: 2 - 26 hexadecimal digits (1-13 bytes).
SID Entry Format	The format of the NE address.	<i>SID</i> : System Identifier. <i>Short</i> : Not applicable.
NE SID	Identifies the NE.	12 hexadecimal digits (6 bytes).

**Initial management connection** Like the address, the initial management connection has several different parts. These are described in the table below. Note that the three fields NE Connected, Gateway Format and Gateway Ethernet Address are only valid if the connection type is *Static*. When

connection type is set to *Dynamic* these fields are grayed out.

Field Name	Description	Possible Values
Connection Type	Controls network management data routing.	<i>Dynamic</i> : Management data is routed dynamically by the network using ES-IS/IS-IS protocols.  <i>Static</i> : The management data route is forced. The management system uses a user-defined network element (Ethernet) address to select one Intermediate System (IS) via which the ITM-SC communicates with a node.
NE Connected	Determines how the NE is connected.	<i>via Gateway</i> : The network element is connected via a gateway node through which it is managed by the ITM-SC.  <i>on LAN</i> : The ITM-SC manages the network element directly through a Q-LAN connection.
Gateway Format	Determines the format of the gateway via which this NE is managed.	<i>Ethernet</i> (12 Hexadecimal digits) or <i>Short</i> (2 Hexadecimal digits): only if the gateway is an ISM.
Gateway Ethernet Address	Address of the gateway via which this NE is managed.	Address format depends on setting of <i>Gateway Format</i> field.

### Management connection options

There are several ways in which the management connection can be provisioned. Use the table below to complete the *Initial Management Connection* parameter and thus set the desired management connection.

If...	then...
Dynamic routing is to be used, This is preferable when using IS-IS areas.	Set the <i>Connection Type</i> to <i>Dynamic</i> .

## Information

## Parameters for Editing Pre-Provisioned NE

## Information

If...	then...
<p>The NE is to be managed via a gateway NE using long addressing, Note this introduces IS-IS clustering. The routing is static. If the gateway network element fails, no alternative route is sought to the NE.</p>	<ol style="list-style-type: none"> <li>1. Set the <i>Connection Type</i> to <i>Static</i>.</li> <li>2. Set <i>NE Connected</i> to <i>via Gateway</i>.</li> <li>3. Set <i>Gateway Format</i> to <i>Ethernet</i>.</li> <li>4. Enter the full <i>Gateway Ethernet Address</i> (12 Hex digits).</li> </ol>
<p>The NE is to be managed via a gateway using long addressing. Note this is only possible if the gateway is an ISM. This introduces IS-IS clustering. If the gateway network element fails, no alternative route is sought to the NE.</p>	<ol style="list-style-type: none"> <li>1. Set the <i>Connection Type</i> to <i>Static</i>.</li> <li>2. Set <i>NE Connected</i> to <i>via Gateway</i>.</li> <li>3. Set <i>Gateway Format</i> to <i>Short</i>.</li> <li>4. Enter the short <i>Gateway Ethernet Address</i> (2 Hex digits).</li> </ol>
<p>The NE is to be managed via a Q-LAN connection. (The network element is connected on the Q-LAN of the ITM-SC.)</p>	<p>Set the <i>Connection Type</i> to <i>Static</i> and <i>NE Connected</i> to <i>on LAN</i>.</p>



## Section: Viewing Pre-Provisioned NE Slot Information

### Overview

---

**Purpose** Use this procedure to view how the slots of a pre-provisioned network element are configured.



## View Pre-Provisioned NE Slot Configuration

---

**When to use** This procedure is useful for checking:

- The unit assigned to a certain slot
- The state of a particular slot (assigned, unassigned or auto).

**Before you began** No prerequisites or precautions are needed when performing this procedure.

**Related information** The following procedures and information are related:

- Create a Pre-Provisioned NE
- Edit Pre-Provisioned NE Information
- Modify the Subrack Slots
- Delete a Pre-Provisioned NE
- Provision an NE from a Pre-Provisioned NE
- Section Equipment Provisioning Concepts in chapter Concepts.

### Procedure

---

**1** Select *Pre-Provisioning -> NE Card Inventory*.

**Result:**

The EMS - Pre-Provisioned NE Inventory window is displayed. This window lists the units associated with a selected pre-provisioned network element.

---

**2** Click the selection dialog button to select a pre-provisioned network element. Select the required network element from the EMS - NE Selection Dialog window, and click OK.

**Result:**

The EMS - Pre-Provisioned NE Inventory window is updated with the information from the selected pre-provisioned network element.

---

**3** Select the desired slot from the list *Slot*, and click *Details*.

**Result:**

The EMS - Pre-Provisioned NE Slot Information window is displayed. This window displays detailed information for the selected slot. Note that the procedure to change the slot

information is described in the subsection “Modify Subrack Slots.”

---

- 4** Click Close.

**Result:**

The EMS - Pre-Provisioned NE Slot Information window disappears.

---

- 5** Click Close.

**Result:**

The EMS - Pre-Provisioned NE Inventory window disappears.

END OF STEPS

---



## Parameters for Viewing Pre-Provisioned NE Slot Configuration

---

- Pre-provisioned NE** The name of the pre-provisioned NE is listed.
- NE type** The type of the selected pre-provisioned NE is shown.
- Slot** The slot position is given here.
- Unit item code** The special alphanumeric code associated with the provisioned unit is displayed.
- Unit type** The type of unit provisioned in the listed slot is shown.
- Slot state** Displays the status of the listed slot. The different slot states are given in the table below.

Slot State	Description
Assigned	Slot is assigned.
Unassigned	Slot is unassigned.
Auto	Slot is provisioned but waiting for unit. Once the provisioned unit is present, the slot state will automatically change to <i>Assigned</i> .



## Section: Editing Pre-Provisioned NE Slot Information

### Overview

---

**Purpose** Use this procedure to modify the subrack slots of a pre-provisioned NE.



## Edit Pre-Provisioned NE Slot Information

---

- When to use** Follow this procedure when:
- Assigning new units to the pre-provisioned network element
  - Making changes in the slot occupation of the NE subrack.
  - Changing the slot state of a unit.

- Before you begin** Before editing pre-provisioned NE slot information determine the following:
- the information concerning the desired subrack slot assignments for the pre-provisioned NE should be available
  - For the *WaveStar*® AM 1, it is possible to provision, and thus edit, slot TS2. Changes to any of the other units should not be made
  - If it is not possible to select the desired unit from the list of cards contact the system administrator.

- Related information** The following procedures and information are related:
- Create a Pre-Provisioned NE
  - Edit Pre-Provisioned NE Information
  - View the Pre-Provisioned NE Slot Configuration
  - Delete a Pre-Provisioned NE
  - Provision an NE from a Pre-Provisioned NE
  - Section Equipment Provisioning Concepts in chapter Concepts.

**Important!** For the *WaveStar*® AM 1, it is only possible to provision, and thus edit, slot TS2. When selecting *Pre-Provisioning -> Slot* to access the EMS - Pre-Provisioned NE Slot Information window, begin with step 4 of this procedure.

### Procedure

---

- 1 Select *Pre-Provisioning -> Subrack*.

**Result:**

The EMS - Pre-Provisioned NE Subrack Information window appears. This window graphically displays the contents of the subrack, with the subrack layout corresponding to the selected network element.

- 
- 2 Click the selection dialog button to select a pre-provisioned network element. Select the required network element from the EMS - NE Selection Dialog window, and click OK.

**Result:**

The EMS - Pre-Provisioned NE Subrack Information window is updated with the information from the selected pre-provisioned network element.

---

- 3 On the subrack layout, click on the desired slot.

**Result:**

The EMS - Pre-Provisioned NE Slot Information window appears with information concerning the selected slot.

---

- 4 Click Edit .

**Result:**

The window EMS - Edit Pre-Provisioned NE Slot Information appears.

---

- 5 Select the appropriate *Slot State*.

**Important!** If the *Slot State* is *Unassigned*, then no selection will be possible from the list *Cards*.

---

- 6 Select the proper unit from the list *Cards*.

**Important!** Verify that the *Unit Item Code* of the selected unit corresponds with that of the actual unit. If the values do not match, or if it is not possible to select the required unit from the list of cards contact the system administrator.

**Result:**

The proper unit and the appropriate slot state are selected.

---

- 7 Click OK.

**Result:**

The slot is modified, and the EMS - Edit Pre-Provisioned NE Slot Information window disappears.

- 
- 8** Click **C**l **o**se in the EMS - Pre-Provisioned NE Slot Information window, and then click **C**l **o**se in the EMS - Pre-Provisioned NE Subrack Information window.

**Result:**

The windows disappear.

**E N D O F S T E P S**

---



## Parameters for Editing Pre-Provisioned NE Slot Information

---

- Pre-provisioned NE** The name of the pre-provisioned NE is listed.
- NE type** The type of the selected pre-provisioned NE is shown.
- Slot** The slot position is listed here.
- Unit item code** The special alphanumeric code associated with a particular unit is listed.
- Unit type** The type of unit provisioned in the listed slot is shown.
- Slot state** Displays the status of the listed slot. The different slot states are given in the table below.

Slot State	Description
Assigned	Slot is assigned.
Unassigned	Slot is unassigned.
Auto	Slot is provisioned but waiting for unit. Once the provisioned unit is present, the slot state will automatically change to <i>Assigned</i> .

- Cards** This is a list of the possible units that may be provisioned.



## Section: Deleting a Pre-Provisioned NE

### Overview

---

**Purpose** The purpose of this procedure is to remove a pre-provisioned network element from the management system database.



## Delete a Pre-Provisioned NE

---

**When to perform** When the pre-provisioned network element is no longer needed, it can be deleted. For example, if the network element is not going to be installed or if the NE will be placed elsewhere in the network and configured in a different way, then obviously the pre-provisioned NE is not useful.

**Before you begin** The name of the pre-provisioned NE to be deleted must be known.

**Related information** The following procedures and information are related:

- Create a Pre-Provisioned NE
- Edit Pre-Provisioned NE Information
- View the Pre-Provisioned NE Slot Configuration
- Edit Pre-Provisioned NE Slot Information
- Provision an NE from a Pre-Provisioned NE
- Section Equipment Provisioning Concepts in chapter Concepts.

### Procedure

---

1 Select *Pre-Provisioning -> Delete*.

**Result:**

The EMS - Delete Pre-Provisioned NE window appears.

---

2 Click the selection dialog button and select the desired pre-provisioned network element from the EMS - NE Template Selection Dialog window. Then, click OK.

**Result:**

The EMS - Delete Pre-Provisioned NE window is updated with the information from the selected pre-provisioned NE.

---

3 Click *Apply*.

**Result:**

A window appears asking for confirmation of deletion.

---

4 Click *Yes* in the confirmation window.

**Result:**

The pre-provisioned network element is now deleted.

---

- 
- 5** Click Cl ose.

**Result:**

The EMS - Delete Pre-Provisioned NE window disappears.

END OF STEPS

---



## Section: Creating an NE from a Template

### Overview

---

**Purpose** The provisioning of a network element will be completed using a template.



## Create an NE from a Template

---

**When to use** When a new network element becomes operational and an association with the management system can be made, a network element can be provisioned.

**Before you begin** Before starting to provision a network element the following information must be available:

- The network element name
- Location and NSAP address
- The type of management connection, and
- The network element template used as a basis for configuration
- The provisioned configuration data will override any configurations provided via the Craft Interface Terminal (ITM-CIT).
- Be careful with selecting the management connection type (static/dynamic). This can be changed afterwards only by deleting the provisioned network element and creating it again.

**Related information** The following procedures are related:

- Create an NE Template
- Modify an NE Template
- View NE Template Slot Information
- Delete an NE Template
- Section Equipment Provisioning Concepts in chapter Concepts.

**Important!** Also, a node cannot be created with the ITM-SC if it is in an isolated state. This can only be checked with the ITM-CIT. If the node is isolated, then it must be created with the ITM-CIT. A node is not capable of any type of remote management if it is in the isolated state.

### Procedure

---

- 1 Select *Provisioning -> Equipment -> Create -> NE From Template*.

**Result:**

The EMS - Create Provisioned NE from Template window appears. This window allows creation of a provisioned network element using a selected network element template.

- 
- 2 Click the selection dialog button and select the desired template (default or user-defined) from the EMS - NE Template Selection Dialog window. Then, click OK.

**Result:**

The EMS - Create Provisioned NE from Template window is updated with the information from the selected template.

- 
- 3 Enter the *NE Name*, and if desired, click in the *ITM-NM Style* box.

**Important!** If the network element is managed by the ITM-NM, select the *ITM-NM Style* box. If this box is selected, then the name format can fail at two levels. It may be completely ITM-NM incompatible, or it may be compatible but not the preferred format. See the parameters section for a complete explanation of how to choose an ITM-NM compatible name.

**Result:**

The network element name and location are entered.

- 
- 4 Enter the information in *Address to Connect to NE*.

**Result:**

The NSAP address of the network element is entered.

- 
- 5 Enter the *Initial Management Connection* fields.

- 
- 6 Click *Apply*.

**Result:**

The network element has been created, and it is now provisioned.

- 
- 7 Click *Close*.

**Result:**

The EMS - Create Provisioned NE from Template window disappears.

END OF STEPS



## Parameters for Creating an NE from a Template

---

**NE template name** Indicates the name of the selected template.

**NE type** The type of NE associated with the template.

**Template type** There are two types of NE templates. The first is *Default*, a template that is part of the system software. The other is *User Defined*, a template custom designed by the user.

**NE name** The network element's name is listed. The name must be unique across management domains. If the NE is not managed by the ITM-NM, then the name may be up to 20 characters in length. If the NE will be managed by the ITM-NM, then the name must be 3 to 10 characters long with the last three characters a slash and two digits. Only *A-Z*, *0-9*, *\_*, */*, and *-* are permitted for network elements managed by the ITM-NM. An example of an ITM-NM compatible name is LONDON/02.

**NE location** The location of the network element is given. The location may have up to 20 uppercase or lowercase characters.

**Address to connect to NE** The address of the selected NE is indicated. There are various parts of the address; the table below describes these different parts and their possible values.

Field Name	Description	Possible Values
NSAP Format	The format of the NSAP address.	The default value is <i>Fixed 20 Byte</i> .
Area	Indicates the area to which an NE belongs.	<i>Area ID</i> for fixed 20 byte and fixed 10 byte NSAP format: 4 hexadecimal digits (2 bytes). <i>Area Address</i> for flexible NSAP format: 2 - 26 hexadecimal digits (1-13 bytes).
SID Entry Format	The format of the NE address.	<i>SID</i> : System Identifier. <i>Short</i> : Not applicable.
NE SID	Identifies the NE.	12 hexadecimal digits (6 bytes).

**Initial management connection**

Like the address, the initial management connection has several different parts. These are described in the table below. Note that the fields NE Connected, Gateway Format and Gateway Ethernet Address are only valid if the connection type is *Static*. When connection type is set to *Dynamic* these fields are grayed out.

Field Name	Description	Possible Values
Connection Type	Controls network management data routing.	<i>Dynamic</i> : Management data is routed dynamically by the network using ES-IS/IS-IS protocols.  <i>Static</i> : The management data route is forced. The management system uses a user-defined network element (Ethernet) address to select one Intermediate System (IS) via which the ITM-SC communicates with a node.
NE Connected	Determines how the NE is connected.	<i>via Gateway</i> : The network element is connected via a gateway node through which it is managed by the ITM-SC.  <i>on LAN</i> : The ITM-SC manages the network element directly through a Q-LAN connection.
Gateway Format	Determines the format of the gateway via which this NE is managed.	<i>Ethernet</i> (12 Hexadecimal digits) or <i>Short</i> (2 Hexadecimal digits): only if the gateway is an ISM.
Gateway Ethernet Address	Address of the gateway via which this NE is managed.	Address format depends on setting of <i>Gateway Format</i> field.

**Management connection options**

There are several ways in which the management connection can be provisioned. Use the table below to complete the *Initial Management Connection* parameter and thus set the desired management

connection.

If...	then...
dynamic routing is to be used, Note: This is preferable when using IS-IS areas.	set the <i>Connection Type</i> to <i>Dynamic</i> .
the NE is to be managed via a gateway NE using long addressing. Note: This introduces IS-IS clustering. The routing is static. If the gateway network element fails, no alternative route is sought to the NE.	<ol style="list-style-type: none"> <li>1. Set the <i>Connection Type</i> to <i>Static</i>.</li> <li>2. Set <i>NE Connected</i> to <i>via Gateway</i>.</li> <li>3. Set <i>Gateway Format</i> to <i>Ethernet</i>.</li> <li>4. Enter the full <i>Gateway Ethernet Address</i> (12 Hex digits).</li> </ol>
the NE is to be managed via a gateway NE using short addressing, Note: This is only possible if the gateway is an ISM. Note: This introduces IS-IS clustering. If the gateway network element fails, no alternative route is sought to the NE.	<ol style="list-style-type: none"> <li>1. Set the <i>Connection Type</i> to <i>Static</i>.</li> <li>2. Set <i>NE Connected</i> to <i>via Gateway</i>.</li> <li>3. Set <i>Gateway Format</i> to <i>Short</i>.</li> <li>4. Enter the short <i>Gateway Ethernet Address</i> (2 Hex digits).</li> </ol>
the NE is to be managed via a Q-LAN connection, (The network element is connected on the Q-LAN of the ITM-SC.)	set the <i>Connection Type</i> to <i>Static</i> and <i>NE Connected</i> to <i>on LAN</i> .



## Section: Creating an NE from a Pre-Provisioned NE

### Overview

---

**Purpose** All initial provisioning of the NE will be completed, and the NE will be placed into service in the network under the management of the ITM-SC.



## Create an NE from a Pre-Provisioned NE

---

**When to use** This procedure should be performed after a pre-provisioned network element becomes operational and an association with the management system can be made.

**Before you begin** Before completing the provisioning of a pre-provisioned network element:

- Check to verify that the network element is installed and that it has been properly pre-provisioned
- The ITM-SC must be installed and connected to the network element
- Check if the node is in an isolated state, because a node cannot be created with the ITM-SC if it is in an isolated state. This can only be checked with the ITM-CIT. If the node is isolated, then it must be created with the ITM-CIT. A node is not capable of any type of remote management if it is in the isolated state
- The management connection type setting (dynamic or static) completed during pre-provisioning cannot be changed after the NE is created. Therefore it should be checked before completing the procedure in this section.

**Related information** The following procedures are related:

- Create a Pre-Provisioned NE
- Edit Pre-Provisioned NE Information
- View Pre-Provisioned NE Slot Information
- Edit Pre-Provisioned NE Slot Information
- Delete a Pre-Provisioned NE
- Section Equipment Provisioning Concepts in chapter Concepts.

### Procedure

---

- 1 Select *Provisioning* -> *Equipment* -> *Create* -> *NE From Pre-Provisioned*.

**Result:**

The EMS - Create NE from Pre-Provisioned NE window appears. This window allows creation of a provisioned network element through the use of a pre-provisioned NE.

---

- 2 To select a pre-provisioned NE or to switch to another pre-provisioned NE, click the selection dialog button.

- 
- 3** A list of possible NEs then appears in the the *EMS - NE Selection Dialog window*. Select the desired pre-provisioned NE and click OK.

**Result:**

The EMS — Create NE from Pre-Provisioned window reappears with the information for the selected pre-provisioned NE.

- 
- 4** Click Apply.

**Result:**

The network element is now configured.

- 
- 5** Click Close.

**Result:**

The EMS - Create NE from Pre-Provisioned NE window disappears.

END OF STEPS



## Section: Creating an MIB Image from an NE

### Overview

---

**Purpose** The purpose of creating a MIB image of the network element is to provide the management system with the configuration data of the network element.



## Create an MIB Image from an NE

---

**When to use** Creating a MIB image assumes management of a network element that is already provisioned (for example via the Craft Interface Terminal).

**Before you begin** Before creating a MIB image from an network element, it is assumed that:

- A check has been made to verify that the network element is installed and provisioned, so that the MIB of the network element contains the correct configuration data
- The ITM-SC is installed and connected to the network element
- The network element name, location, NSAP address, and the type of management connection are known
- Check if the node is in an isolated state, because a node cannot be created with the ITM-SC if it is in an isolated state. This can only be checked with the ITM-CIT. If the node is isolated, then it must be created with the ITM-CIT. A node is not capable of any type of remote management if it is in the isolated state
- The management connection type setting (dynamic or static) cannot be changed after creating the MIB image, therefore it must be correct.

**Related information** The following procedures and information are related:

- Provision an NE from a Template
- Create an NE from a Pre-Provisioned NE
- View NE Slot Information
- View Card Inventory
- Edit NE Information
- Edit NE Slot Information
- Section Equipment Provisioning Concepts in chapter Concepts.

### Procedure

---

- 1 Select *Provisioning -> Equipment -> Create -> MIB Image from NE*.

**Result:**

The EMS - Create MIB Image from NE window appears. This window allows creation of an image of a network element MIB in the ITM-SC database.

---

- 2 Set the *NE Type* to the correct network element type.
-

Create an MIB Image from an NE

- 
- 3 Enter the *NE Name*, and if desired, click in the *ITM-NM Style* box.

**Important!** If the network element is managed by the ITM-NM, select the *ITM-NM Style* box. If this box is selected, then the name format can fail at two levels. It may be completely ITM-NM incompatible, or it may be compatible but not the preferred format. See the parameters section for a complete explanation of how to choose an ITM-NM compatible name.

**Result:**

The network element name appears in the field *NE Name*.

---

- 4 Enter the information in *Address to Connect to NE*.

**Result:**

The NSAP address of the network element is entered.

---

- 5 Enter the *Initial Management Connection* fields and click *Apply*.

**Result:**

The network element is selected and the MIB image of the network element is created.

---

- 6 Click *Close*

**Result:**

The EMS - Create MIB Image from NE window disappears.

END OF STEPS

---



## Parameters for Creating an MIB Image from an NE

---

**NE name** The network element's name is listed. The name must be unique across management domains. If the NE is not managed by the ITM-NM, then the name may be up to 20 characters in length. If the NE will be managed by the ITM-NM, then the name must be 3 to 10 characters long with the last three characters a slash and two digits. Only A-Z, 0-9, \_, /, and - are permitted for network elements managed by the ITM-NM. An example of an ITM-NM compatible name is LONDON/02.

**NE location** The location of the network element is given. The location may have up to 20 uppercase or lowercase characters.

**Address to connect to NE** The address of the selected NE is indicated. There are various parts of the address; the table below describes these different parts and their possible values.

Field Name	Description	Possible Values
NSAP Format	The format of the NSAP address.	The default value is <i>Fixed 20 Byte</i> .
Area	Indicates the area to which an NE belongs.	<i>Area ID</i> for fixed 20 byte and fixed 10 byte NSAP format: 4 hexadecimal digits (2 bytes). <i>Area Address</i> for flexible NSAP format: 2 - 26 hexadecimal digits (1-13 bytes).
SID Entry Format	The format of the NE address.	<i>SID</i> : System Identifier. <i>Short</i> : Not applicable.
NE SID	Identifies the NE.	12 hexadecimal digits (6 bytes).

**Initial management connection** Like the address, the initial management connection has several different parts. These are described in the table below. Note that the fields NE Connected, Gateway Format and Gateway Ethernet Address are only valid if the connection type is *Static*. When connection type

is set to *Dynamic* these fields are grayed out.

Field Name	Description	Possible Values
Connection Type	Controls network management data routing.	<i>Dynamic</i> : Management data is routed dynamically by the network using ES-IS/IS-IS protocols.  <i>Static</i> : The management data route is forced. The management system uses a user-defined network element (Ethernet) address to select one Intermediate System (IS) via which the ITM-SC communicates with a node.
NE Connected	Determines how the NE is connected.	<i>via Gateway</i> : The network element is connected via a gateway node through which it is managed by the ITM-SC.  <i>on LAN</i> : The ITM-SC manages the network element directly through a Q-LAN connection.
Gateway Format	Determines the format of the gateway via which this NE is managed.	<i>Ethernet</i> (12 Hexadecimal digits) or <i>Short</i> (2 Hexadecimal digits): only if the gateway is an ISM.
Gateway Ethernet Address	Address of the gateway via which this NE is managed.	Address format depends on setting of <i>Gateway Format</i> field.

### Management connection options

There are several ways in which the management connection can be provisioned. Use the table below to complete the *Initial Management Connection* parameter and thus set the desired management connection.

If...	then...
dynamic routing is to be used, Note: This is preferable when using IS-IS areas.	set the <i>Connection Type</i> to <i>Dynamic</i> .

Parameters for Creating an MIB Image from an NE

If...	then...
<p>the NE is to be managed via a gateway NE using long addressing,                      Note: This introduces IS-IS clustering. The routing is static. If the gateway network element fails, no alternative route is sought to the NE.</p>	<ol style="list-style-type: none"> <li>1. Set the <i>Connection Type</i> to <i>Static</i>.</li> <li>2. Set <i>NE Connected</i> to <i>via Gateway</i>.</li> <li>3. Set <i>Gateway Format</i> to <i>Ethernet</i>.</li> <li>4. Enter the full <i>Gateway Ethernet Address</i> (12 Hex digits).</li> </ol>
<p>the NE is to be managed via a gateway NE using short addressing,                      Note: This is only possible if the gateway is an ISM.                      Note: This introduces IS-IS clustering. If the gateway network element fails, no alternative route is sought to the NE.</p>	<ol style="list-style-type: none"> <li>1. Set the <i>Connection Type</i> to <i>Static</i>.</li> <li>2. Set <i>NE Connected</i> to <i>via Gateway</i>.</li> <li>3. Set <i>Gateway Format</i> to <i>Short</i>.</li> <li>4. Enter the short <i>Gateway Ethernet Address</i> (2 Hex digits).</li> </ol>
<p>the NE is to be managed via a Q-LAN connection, (The network element is connected on the Q-LAN of the ITM-SC.)</p>	<p>set the <i>Connection Type</i> to <i>Static</i> and <i>NE Connected</i> to <i>on LAN</i>.</p>



## Section: Viewing NE Slot Information

### Overview

---

**Purpose** Use this procedure to view how the slots of a provisioned network element are configured.



## View NE Slot Information

---

**When to use** When additional units are to be added or units are to be changed, it is useful to have a complete overview of the network element's slots.

**Before you begin** Before viewing the network element slot configuration it is assumed that:

- The management system is installed and connected to the network element
- The name and type of the network element are known.

**Related information** The following procedures and information are related:

- Create an MIB image from an NE
- Modify Subrack Slots
- Section Equipment Provisioning Concepts in chapter Concepts.

### Procedure

---

1 Select *Provisioning* -> *Equipment* -> *NE Card Inventory*.

**Result:**

The EMS - Provisioned NE Card Inventory window is displayed.

---

2 To select an NE or to switch to another NE, click the selection dialog button.

---

3 To view more detailed information for a particular slot, select the slot and click *Details*.

**Result:**

The *EMS - Provisioned NE Slot Information* window is displayed. This window shows all detailed information of the selected slot.

---

4 Click *Close*.

**Result:**

The *EMS - Provisioned NE Card Inventory* window disappears.

END OF STEPS

---



## Parameters for Viewing NE Slot Information

---

**Provisioned NE** Indicates the name of the provisioned NE.

**NE type** The type of the selected NE is given.

**Subrack** Displays the subrack type for the selected NE.

**Slot** The slot position is given here.

**Expected Item code** The special alphanumeric code associated with the provisioned unit is displayed.

**Actual item code** The special alphanumeric code associated with the actual unit present is displayed.

**Unit type** The type of unit provisioned in the listed slot is shown.

**Slot state** Displays the status of the listed slot. The different slot states are given in the table below.

Slot State	Description
Assigned	Slot is assigned.
Unassigned	Slot is unassigned.
Auto	Slot is provisioned but waiting for unit. Once the provisioned unit is present, the slot state will automatically change to <i>Assigned</i> .

**Interchangeability marker** This is an identification mark retrievable from any hardware component in the system. This marker indicates the interchangeability among circuit packs. A circuit pack can be replaced by another pack that has the same *Item Code* and the same or a subsequent *Interchangeability Marker*.

**Com code** Indicates the code identifying the component.

**Hardware serial number** The serial number of the displayed hardware component.

**Equipment alarm status** The equipment alarm status of the displayed unit. Possible values are *Not Alarmed*, *Prompt*, *Deferred*, and *Info*.

**Transmission alarm status** The transmission alarm status of the displayed unit. This is grayed out for units not involved in transmission. Possible values are *Not Alarmed*, *Prompt*, *Deferred*, and *Info*.



## Section: Viewing Card Inventory

### Overview

---

**Purpose** This procedure gives an overview of the network elements in which equipment with a specific Item Code is provisioned.



## View Card Inventory

---

**When to use** Follow this procedure to see where in the network a specific unit is provisioned.

**Before you begin** Before viewing the card inventory it is assumed that:

- The management system is installed and connected to the NEs
- The correct item code of the unit to be viewed is known.

**Related information** Related procedure and information include:

- Modify Subrack Slots
- View NE Slot Information
- Section Equipment Provisioning Concepts in chapter Concepts.

### Procedure

---

**1** Select *Provisioning -> Equipment -> Card Inventory*.

**Result:**

The EMS - Card Inventory window is displayed.

---

**2** To select a unit or to switch to another unit, click the selection dialog button. Select the NE Type and a list of possible units appears in the *EMS- Card Selection Dialog* window. Select the desired unit and click OK.

**Result:**

The EMS - Card Inventory window reappears with the information for the selected unit.

---

**3** Click Cl ose.

**Result:**

The EMS - Card Inventory window disappears.

END OF STEPS

---



## Parameters for Viewing Card Inventory

---

- Item code** The special alphanumeric code associated with the desired unit.
- Physical unit type** The unit with the selected item code is displayed.
- Node name** Indicates the name of the NE containing the unit with the selected item code.
- NE type** The type of the NE is given.
- Subrack** Displays the subrack type for the NE.
- Slot** The slot position is given here.
- Protection function** Displays the protection status of the listed unit. The different possible values and their meanings are given in the following table.

Protection Function	Description
Worker	This unit is a working unit in an equipment protection group.
Protection	This unit is a protection unit.
Not Protected	This unit is not protected
Not Applicable	Protection is not applicable for this unit.

- Slot state** Displays the status of the listed slot. The different slot states are given in the table below.

Slot State	Description
Assigned	Slot is assigned.
Unassigned	Slot is unassigned.
Auto	Slot is provisioned but waiting for unit. Once the provisioned unit is present, the slot state will automatically change to <i>Assigned</i> .

- Hardware actual item code** The item code for the unit actually occupying the particular slot.



## Section: Editing General NE Information

### Overview

---

**Purpose** The purpose of this procedure to change general network element Information concerning the location, address, and DCN.



## Edit General NE Information

---

**When to use** When any of the following must be changed, perform the editing procedure in this section.

- The network element location
- The NSAP address of the network element (Area Code or SID)
- The Management Connection settings
- The IS-IS Level settings
- The Designated Router Priority
- The Additional Manual Area Addresses.

**Before you begin** Before editing provisioned network element information determine the following:

- The network element name
- Location and the NSAP address
- The type of management connection
- The IS-IS level parameter,
- The designated router priority and
- The additional manual area addresses
- If the Association State has changed after the Edit screen was displayed, the changes are discarded and an error message is displayed
- When the IS-IS parameters are changed this may cause the network element to restart, resulting in a temporary loss of association
- If the network element is participating in a GR scheme this may cause an automatic protection switch. A warning message is displayed
- If the values of the IS-IS parameters are incorrect this may result in many network elements becoming unmanageable. A warning message is displayed
- If the LAN IS-IS level is set to 'None', then a network element cluster that is not directly connected to the ITM-SC Q-LAN may become unmanageable when 'None' is chosen for the cluster gateway. 'None' also prevents traffic from one cluster from being routed to another cluster over the Q-LAN
- The value of the designated router priority is composed in a specialized plan, so do not change it unless this plan is available

- If an additional Manual Area Address is provisioned when the Computed Area Address Table (CAAT) is full, this may cause a loss of entries in the CAAT which results in a loss of association
- If the NSAP format or the SID are changed, then management will be lost so long as these parameters are different than the ITM-SC settings

**Related information** The following procedures are related:

- Create an NE from a Template
- Create an NE from a Pre-Provisioned NE
- Create an MIB Image from an NE
- Section Equipment Provisioning Concepts in chapter Concepts.

**Procedure** .....

- 1 Select *Provisioning -> Equipment -> NE Information*.

**Result:**

The EMS - Provisioned NE Information window appears.

.....

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The EMS - Provisioned NE Information window reappears with the information for the selected NE.

.....

- 3 Click *Edit*.

**Result:**

The EMS - Edit Provisioned NE Information window appears.

.....

- 4 Modify, as necessary, the displayed information for *NE Location, IS-IS Level of NE, LAN IS-IS Level, NSAP Format, SID*, and the *Designated Router Priority*.

**Result:**

The correct information appears in the appropriate fields.

.....

- 5 Click *OK*.

**Result:**

A window appears asking for confirmation of the changes.

---

- 6** Click Yes.

**Result:**

The changes for the network element are now confirmed, and the window EMS - Edit Provisioned NE Information disappears.

---

- 7** Click Close.

**Result:**

The EMS - Provisioned NE Information window disappears.

END OF STEPS

---



## Parameters for Editing General NE Information

---

**NE name** The network element's name is listed. The name must be unique across management domains. If the NE is not managed by the ITM-NM, then the name may be up to 20 characters in length. If the NE will be managed by the ITM-NM, then the name must be 3 to 10 characters long with the last three characters a slash and two digits. Only A-Z, 0-9, \_, /, and - are permitted for network elements managed by the ITM-NM. An example of an ITM-NM compatible name is LONDON/02.

**NE location** The location of the network element is given. The location may have up to 20 uppercase or lowercase characters.

**Address to connect to NE** The address of the selected NE is indicated. There are various parts of the address; the table below describes these different parts and their possible values.

Field Name	Description	Possible Values
NSAP Format	The format of the NSAP address.	The default value is <i>Fixed 20 Byte</i> .
Area	Indicates the area to which an NE belongs.	<i>Area ID</i> for fixed 20 byte and fixed 10 byte NSAP format: 4 hexadecimal digits (2 bytes). <i>Area Address</i> for flexible NSAP format: 2 - 26 hexadecimal digits (1-13 bytes).
SID Entry Format	The format of the NE address.	<i>SID</i> : System Identifier. <i>Short</i> : Not applicable.
NE SID	Identifies the NE.	12 hexadecimal digits (6 bytes).

**Initial management connection** Like the address, the initial management connection has several different parts. These are described in the table below. Note that the fields NE Connected, Gateway Format and Gateway Ethernet Address are only valid if the connection type is *Static*. When connection type

is set to *Dynamic* these fields are grayed out.

Field Name	Description	Possible Values
Connection Type	Controls network management data routing.	<i>Dynamic</i> : Management data is routed dynamically by the network using ES-IS/IS-IS protocols.  <i>Static</i> : The management data route is forced. The management system uses a user-defined network element (Ethernet) address to select one Intermediate System (IS) via which the ITM-SC communicates with a node.
NE Connected	Determines how the NE is connected.	<i>via Gateway</i> : The network element is connected via a gateway node through which it is managed by the ITM-SC.  <i>on LAN</i> : The ITM-SC manages the network element directly through a Q-LAN connection.
Gateway Format	Determines the format of the gateway via which this NE is managed.	<i>Ethernet</i> (12 Hexadecimal digits) or <i>Short</i> (2 Hexadecimal digits): only if the gateway is an ISM.
Gateway Ethernet Address	Address of the gateway via which this NE is managed.	Address format depends on setting of <i>Gateway Format</i> field.

### Designated router priority

The designated router priority is a value which indicates the priority of the designated router connected to the Q-LAN. A higher number has priority over a lower one. Valid values are 0-127. The default value is 64. This value is composed in a specialized network plan, so it should not be changed unless this plan is available.

*Designated Router Priority* is grayed out when the association state between the ITM-SC and the NE is *Released*.

**Additional manual area addresses**

This is a synonymous area address associated with an Intermediate System. Together with the SID and SEL fields, it is a valid synonymous NSAP address for an Intermediate System. The manual area address can be used to connect subnetworks to the OSI-DCN with nodes having a different NSAP format than the formats supported.

*Additional Manual Area Address* is grayed out when the association state between the ITM-SC and the NE is released.

**IS-IS functionality of NE**

This field changes the IS-IS level of the network element. The *IS-IS Functionality of NE* field is grayed out when the association state between the ITM-SC and the NE is released.

The possible IS-IS level values for an NE are described in the table below

IS-IS Functionality of NE	Description
Level 1	Provides inter connectivity between network elements in the same area.
Level 1+2	Provides inter connectivity between areas and between network elements in the same area.
Level 1+2 Area Repair Access	Provides inter connectivity between areas and between network elements in the same area and enables Area Partition Repair Access.

**IS-IS level on LAN**

The LAN IS-IS level field changes the IS-IS level on the Q-LAN port. The LAN IS-IS level field is grayed out when the association state between the ITM-SC and the NE is released.

**Important!** Note: *Level 2* is grayed out if the IS-IS Level of NE is set to *Level 1*.

The possible LAN IS-IS level values are described in the table below:

LAN IS-IS Level	Description
Follow NE IS-IS	The LAN IS-IS level is the same as the level of the network element provisioned in IS-IS Level of NE. Under normal circumstances the network element should use this value.

<b>LAN IS-IS Level</b>	<b>Description</b>
Level 2	The LAN IS-IS level is set to level 2. This value should only be used temporarily during upgrade activities.
None	Disables the Q-LAN port of a network element for the IS-IS protocol (NO-IS-IS). This value is used in combination with static routing to the management system.



## Section: Editing NE Slot Information

### Overview

---

**Purpose** The slot information for the NE is edited.



## Edit NE Slot Information

---

**When to use** Use this procedure to modify subrack slots of provisioned network elements when:

- Assigning new units to the provisioned network element
- Changing the slot occupation of the network element subrack
- Changing the slot state of a unit.

**Before you begin** Before editing the NE slot information determine the following:

- Before modifying a provisioned network element be certain that information concerning the units' slot assignments is known
- If it is not possible to select the desired unit from the list of units contact the system administrator
- For the *WaveStar*® AM 1, the only slot which may be edited is TS2. The slot information can also be accessed by selecting *Provisioning -> Equipment -> Slot*. When making this selection, begin with step 4 of the following procedure.

**Related information** The following procedures and information are related:

- View the NE Slot Information
- View the Card Inventory
- Edit the Card Type Inventor
- Section Equipment Provisioning Concepts in chapter Concepts.

### Procedure

---

- 1 Select *Provisioning -> Equipment -> Subrack*.

**Result:**

The EMS - Provisioned NE Subrack Information window appears. This window graphically displays the contents of the subrack, with the subrack layout corresponding to the selected network element.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The EMS - Provisioned NE Subrack Information window reappears with the information for the selected NE.

- 
- 3 On the subrack layout of the *WaveStar*® AM 1, click on the slot *TS2*.

**Result:**

The EMS - Provisioned NE Slot Information window appears with information concerning the selected slot.

---

- 4 Click *Edit*.

**Result:**

The window EMS - Edit Provisioned NE Slot Information appears.

---

- 5 Select the appropriate *Slot State*.

**Important!** If the *Slot State* is *Unassigned*, then no selection will be possible from the list *Cards*.

---

- 6 Select the proper unit from those listed under *Units List*.

**Important!** Verify that the *Expected Unit Item Code* of the selected unit corresponds with that of the actual unit. If the values do not match, or if it is not possible to select the required unit from the list of cards contact the system administrator.

**Result:**

The proper unit and the appropriate slot state are selected.

---

- 7 Click *OK*.

**Result:**

The slot is modified, and the EMS - Edit Provisioned NE Slot Information window disappears.

---

- 8 Click *Close* in the EMS - Provisioned NE Slot Information window, and then click *Close* in the EMS - Provisioned NE Subrack Information window.

**Result:**

The windows disappear.

END OF STEPS

---



## Parameters for Editing NE Slot Information

---

**Provisioned NE** The name of the selected NE is displayed.

**NE type** The type of the selected NE is shown.

**Slot** The slot position is given here.

**Expected item code** The special alphanumeric code associated with the provisioned unit is displayed.

**Actual item code** The special alphanumeric code associated with the actual unit present is displayed.

**Unit type** The type of unit provisioned in the listed slot is shown.

**Slot state** Displays the status of the listed slot. The different slot states are given in the table below.

Slot State	Description
Assigned	Slot is assigned.
Unassigned	Slot is unassigned.
Auto	Slot is provisioned but waiting for unit. Once the provisioned unit is present, the slot state will automatically change to <i>Assigned</i> .

**Interchangeability marker** This is an identification mark retrievable from any hardware component in the system. This marker indicates the interchangeability among circuit packs. A circuit pack can be replaced by another pack that has the same *Item Code* and the same or a subsequent *Interchangeability Marker*.

**Com code** Indicates the code identifying the component.

**Hardware serial number** The serial number of the displayed hardware component.

**Equipment alarm status** The equipment alarm status of the displayed unit. Possible values are *Not Alarmed*, *Prompt*, *Deferred*, and *Info*.

**Transmission alarm status** The transmission alarm status of the displayed unit. This is grayed out for units not involved in transmission. Possible values are *Not Alarmed*, *Prompt*, *Deferred*, and *Info*.



## Section: Viewing and Editing MDI Information

### Overview

---

**Purpose** Use this procedure to view and edit MDI names and statuses.



## View and Edit MDI Information

---

**When to use** Whenever Miscellaneous Discrete Inputs are a part of the network operation, names must be given to MDIs to allow for identification when an alarm is raised. Should a discrete be changed, then the name must also be changed.

**Before you begin** The following precautions and prerequisites should be noted.

- The MDO name can be no longer than 26 characters
- There are four MDIs that may be provisioned for an NE
- The user should select names for the Miscellaneous Discrete Outputs that are both well-chosen and unique
- The *WaveStar*® AM 1 contains 4 MDIs
- Also, the miscellaneous discrete input must be connected to the NE.

**Related information** The procedure “View and Edit MDO Information” is related.

---

**1** Select *Provisioning* -> *Equipment* -> *MDI*.

**Result:**

The EMS - Provisioned NE MDI Information window appears.

---

**2** To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The EMS - Provisioned NE MDI Information window reappears with the information for the selected NE.

---

**3** Select an MDI from the list under *ID* and *Name*.

**Result:**

The appropriate MDI is selected.

---

**4** Click *Edit*.

**Result:**

The EMS - Edit Provisioned NE MDI Information window is displayed. The current name of the selected MDI is displayed on the name line of this window.

---

- 5 Enter the *MDI Name* (max. 26 characters) and click OK

**Result:**

The new MDI name is entered and the EMS - Edit Provisioned NE MDI Information window is closed.

---

- 6 Click Close.

**Result:**

The EMS - Provisioned NE MDI Information window disappears.

END OF STEPS

---



## Parameters for Viewing and Editing MDI Information

---

**Provisioned NE** The name of the selected NE is displayed.

**NE type** The type of the selected NE is shown.

**Id** The number associated with the MDI.

**Name** Indicates the name of the MDI.



## Section: Viewing and Editing MDO Information

### Overview

---

**Purpose** Use this procedure to view and edit MDO names and statuses.



## View and Edit MDO Information

---

**When to use** Whenever Miscellaneous Discrete Outputs are a part of the network operation, names must be given to MDOs to allow for identification when an alarm is raised. Should a discrete be changed, then the name must also be changed.

**Before you begin** The following precautions and prerequisites should be noted.

- The MDO name can be no longer than 26 characters
- The user should select names for the Miscellaneous Discrete Outputs that are both well-chosen and unique
- The *WaveStar*® AM 1 contains 4 MDOs
- The miscellaneous discrete output must be connected to the NE.

**Related information** The procedure “View and Edit MDI Information” is related.

### Procedure

---

1 Select *Provisioning -> Equipment -> MDO*.

**Result:**

The EMS - Provisioned NE MDO Information window appears.

---

2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The EMS - Provisioned NE MDO Information window reappears with the information for the selected NE.

---

3 Select an MDO from the list under *ID* and *Name*.

**Result:**

The appropriate MDO is selected.

---

4 Click *Edit*.

**Result:**

The EMS - Edit Provisioned NE MDO Information window is displayed. The current name of the selected MDI is displayed on the name line of this window.

---

.....  
**5** Enter or change the *MDO Name* (max. 26 characters).  
.....

**6** Set the Status of the MDO to *MDO Active* (closed loop) or *MDO Inactive* (open loop).

**Result:**

The status field is defined.  
.....

**7** Click OK.

**Result:**

The new MDO name is entered, and the EMS - Edit Provisioned NE MDO Information window is closed.  
.....

**8** Click Close.

**Result:**

The EMS - Provisioned NE MDO Information window disappears.

.....  
E N D O F S T E P S  
.....



## Parameters for Viewing and Editing MDO Information

---

**Provisioned NE** The name of the selected NE is displayed.

**NE type** The type of the selected NE is shown.

**Id** The number associated with the MDO.

**Name** Indicates the name of the MDO.

**MDO status** Indicates the status of the MDO. The possible values are *MDO Active* and *MDO Inactive*.



## Section: Viewing Optical Information

### Overview

---

**Purpose** This procedure should be used to view various optical parameters related to the STM-1 line ports and the STM-4 line ports of the *WaveStar*® AM 1.



## View Optical Information

---

**When to use** Key optical parameters can be inspected, and by so doing more pro-active maintenance may be possible.

**Before you begin** The user should possess information concerning the proper values for the various optical parameters given the NE's provisioned optical components.

**Related information** The following procedure and information are related:

- The procedures port provisioning in the chapter "Transmission Provisioning.
- Section Equipment Provisioning Concepts in chapter Concepts.

### Procedure

---

**1** Select Provisioning -> Equipment -> Port.

**Result:**

The *EMS - Provisioned NE Port Information* window appears.

---

**2** To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The *EMS - Provisioned NE Port Information* window reappears with the information for the selected NE.

---

**3** Click Opt i cs.

**Result:**

The window *EMS - NE Optics Information* appears. Optical information for the selected port is displayed here.

---

**4** Click Cl ose.

**Result:**

The window *EMS - NE Optics Information* disappears.

---

**5** Click Cl ose.

**Result:**

The window *EMS - Provisioned NE Port Information* disappears.

END OF STEPS

---



## Parameters for Viewing Optical Information

---

**Selection** Displays the selected port.

**Port mode** The *Port Mode* controls whether input signals should be monitored or not. The following values can be set.

Value	Description
Monitored	The port is configured to provide service and the port signal is monitored.
Auto	The port is not yet configured to provide service. Use this mode when the signal source in the remote NE is not operational yet. As soon as the NE establishes the continuous presence of a fault-free signal for a certain period ( <i>Port Mode Time</i> ), the port automatically changes to <i>Monitored</i> .
Not Monitored	The port is not configured to monitor the port signal on the port. No alarms are generated for this port. If there still is a signal present on a not monitored port it is possible to receive a Not Expected Input Signal (NES) alarm.

**Port mode time** The time in minutes during which a fault-free signal must be received continuously before the *Port Mode* switches from *Auto* to *Monitored*. The default is 10 minutes.

The *Port Mode Time* can be set between 0 and 30 minutes while the default is 10 minutes.

**Optical wavelength** Displays the optical wavelength at the selected port. If this cannot be determined, *Unknown* will be shown.

**STM level** Indicates the STM level of the signal at the selected port. For the *WaveStar*® AM 1, the only possible values are *STM-1* and *STM-4*.



## Section: Deleting a Provisioned NE

### Overview

---

**Purpose** The purpose of this procedure is to remove a provisioned network element from the management system. In other words, the MIB image of the selected NE is removed from the management system database.



## Delete a Provisioned NE

---

- When to use** Use this procedure when:
- The NE will no longer be managed with this management system
  - Removing a MIB image from a failed "Create an MIB Image" operation.

- Before you begin** Before deleting a provisioned NE determine the following:
- The name of the NE to be deleted must be known
  - After deleting the MIB image there is no longer an association with the management system. It is no longer possible manage the network element with the management system. To get the association back, a MIB image must be created from the network element.

- Related information** The following procedures are related:
- Create an NE from a Pre-Provisioned NE
  - Create an NE from a Template
  - Create an MIB Image from an NE

### Procedure

---

- 1 Select *Provisioning -> Equipment -> Delete MIB Image*.

**Result:**

The EMS - Delete MIB Image window appears.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The EMS - Delete MIB Image window is updated with the information from the selected NE.

---

- 3 Click *Apply*.

**Result:**

A window appears asking for confirmation of deletion.

---

- 4 Click *Yes* in the confirmation window.
-

**Result:**

The MIB image is now deleted.

---

- 5 Click Cl ose.

**Result:**

The EMS - Delete Provisioned NE window disappears.

END OF STEPS

---







# 3 Topology management

## Overview

---

- Purpose** Using the ITM-SC interface provides information on how to use the Integrated Transport Management-Subnetwork Controller.
- Objectives** To customize or change network map settings of the ITM-SC Interface according to the users needs.
- Outcome** Be able to work with the ITM-SC Interface.
- Intended Use** N.A..




## Section: Network Map

### Overview

**Purpose** After activating Network Element Management from the Management Module, the Subnetwork Map window is displayed. This window is the main window for managing all network elements within the subnetwork and gives direct information about network elements, their status and Map groups.

**Example of Network Map** An example of the Network Map is shown below.



**Network Map Icons** The Network Map icons are described in the table below:

Icon	Name	Description
	Up	To go up a group from the current group (unless at top-level already). Changes the display to show the group.
	Connections	This button will toggle the display of the RR connectivity lines. Note: only applicable for Radio Relay NEs.
	Display groups	Toggles the display between the contents of groups and the group icon. This also can be done by pressing control (CTRL) and selecting the Group or NE.
	Modify groups	Used to modify the grouping of network elements. This also can be done by selecting and NE or Group together with the right mouse button. Select from the pop up menu Modify Map Grouping of Nodes

**Network Element Icons** The following icons represent the different types of network elements:

	Add/Drop Multiplexer STM 1	Ring Drop & Insert 2 Mb	Regenerator	Terminator	Dual Facing Terminator	Cross Connect
Normal						
Geographic Redundancy						
Lining Up						
Lining Up + Geographic Redundancy						

**Group Icon** The following icon represents a group of nodes:



**NE Status** The color of each icon on the window represents the current status of the network element or connection. If two conditions exist for the same network element or connection, the network element icon or line is colored to indicate the condition with the highest severity. All alarms of the entire subnetwork are shown in one window; this is sometimes called the Alarm Map.

**Colors of Alarms** The list below describes alarm colors and severity or status.

Color	Meaning
White	The NE or Connection is currently selected.
Grey	No current 'associations' exist with the NE or Connection. An association exist when there is communication between an ITM-SC and an NE.
Red	A 'Prompt Alarm' is currently on the NE or Connection.
Yellow	A 'Deferred Alarm' is currently on the NE or Connection.
Orange	An 'Information Alarm' is currently on the NE or Connection.
Green	No alarms currently on the NE or Connection.
Blue	The node has been pre-provisioned.

**Additional Alarm Information** Additional information about an alarm can be given by the flashing square or "outlined" icon:

Action	Description
Flashing square	The alarm is not acknowledged yet. This is valid to each NE type but not for connections.
Outline	The network element is protected under Geographic Redundancy by this ITM-SC, but is not managed currently by this ITM-SC. This ITM-SC is not associated with this network element, so the outline is shown in grey. Valid for each NE type.
Short Beep	Indicates the arrival of a new alarm.

**Specific Actions on the Network Map** Information about network elements or connections can easily be obtained using the Network Map. The alarms display can be filtered in such a way that only alarms of the selected network element or connection are shown.

To ...	Do this ...

Select an NE or group of NEs	Click once on the specific item.
Select multiple NEs	Press shift and draw using the cursor to make a rectangle over all NEs to select. This can also be done by pressing Ctrl and clicking with left mouse button on the desire NEs
Clear all selections	Click once on the Network Map outside any node or group.
Retrieve the alarm list of a NE or connection	Double click left-button on the specific NE or connection.
Drag selected nodes/groups	select nodes/groups and hold middle mouse button and drag to new position.

**Pop-up Menus**

The following pop-up menus can be accessed via selecting an item using the right mouse button.

Selecting item	provides shortcut to
NE	Alarm ListShelf Display
background	Change the Groupings



## Customizing the Network Map

---

**Introduction** To prevent the Network Map from appearing cluttered when several network elements occupy a small space, those network elements can be grouped together into a map group which is represented by a single icon. For example network elements can be grouped in a geographical or functional way. It is possible that a map group contains another map group.

**Customizing Features** In order to customize the Network Map three features are provided:

- Creating of Map Groups.
- Modifying of Map Groups.
- Placing NEs in Map Groups.

These features are described in more detail in the procedures in this section.

### Icons for Customizing the Network Map

Four icons are provided to customize the Network Map. When network elements are mentioned, this is irrespective of network element type or whether the network element is associated or not. Non-associated network elements are called nodes. Within Map Groups nodes are treated in the same way as network elements.

Icon	Name	Description
	Up	To go up a group from the current group (unless at top-level already). Changes the display to show the group.
	Con- nec- tions	This button will toggle the display of the RR connectivity lines. Note: only applicable for Radio Relay NEs.
	Display groups	Toggles the display between the contents of groups and the group icon. This also can be done by pressing control (CTRL) and selecting the Group or NE.
	Modify groups	Used to modify the grouping of network elements. This also can be done by selecting a NE or Group together with the right mouse button. Select from the pop up menu Modify Map Grouping of Nodes

**Moving icons** To move a node or Map Group icon, select the node/group icon and drag the icon to the new position while holding the middle mouse button.

□

## Creating Map Groups

---

**Purpose** The purpose of this procedure is to group NEs in a geographical or functional way.



## Parameters for Creating Map Groups

---

- Background Image File** This is the name of the background GIF filename used for the background image when the group is displayed. By default for a new group, it will be the Lucent logo file. The files available are the files in the directory:../lib/map\_data. To make a new file available, the file must be placed in this directory.
- New Group Name** When creating a group: this is the name of the group to be created.  
When modifying a group: this is the new group name.
- Old Group Name** Displays the old name of a group. This field is grayed out when creating a map group.
- Parent Group Name** This is the name of the group's parent in the hierarchy.  
When creating a group: specifies where in the hierarchy the group appears.  
When modifying a group: provides a mechanism for moving the group to a different parent.



## Create Map Groups

---

**When to use** Use this procedure to create a network element group and display a background image file in this Map Group.

The background image file can display e.g. a geographical map to offer geographical navigation. The background image file must be placed in the ....lib/map\_data directory.

**Before you begin** The items below gives information on tasks to perform before beginning the procedure:

- No prerequisite are needed when performing this procedure.
- No precaution are needed when performing this procedure.

**Related information** The items below list other relevant information to this procedure:

- The related procedures are *Modifying Group Maps* and *Placing NE's in Map Groups*. Note that there is no correlation between Map Groups and NE Groups. Map groups only re-arrange the graphical presentation of NEs and Nodes on the Network Map.
- The related concepts are explained in the Section: *Concepts of Topology Management*.

**Procedure** Follow these steps to create a network element group and apply a background image file:

---

- 1 Click with the right mouse button on Network Map (NOT on a node!) or click on the Modify groups icon.

**Result:**

When using the first option the The Network Map Background Pop-up menu appears.

When using the Modify groups icon the *EMS - Map Group Create/Change* window appears. Proceed with step 3!

---

- 2 Select Change the Groupings.

**Result:**

The *EMS - Map Group Control* window appears, showing a hierarchical view of the Network map's Map Groups.

---

- 3 Select Create Group.

**Result:**

The *EMS - Map Group Create/Change* window appears.

---

- 4 Fill in *New Group Name*.
- 

- 5 Select the *Parent Group Name* when the created Group has to be placed in a other Map Group.
- 

- 6 Select the appropriate filename in *Background Image File* and click Apply.

**Result:**

A new Map Group is created and is displayed in the *EMS - Map Group Control* window. Double click on the Map Group to display the content of the Map Group with the selected background image file as background.

---

- 7 Click on the Close button.

**Result:**

The *EMS - Map Group Control* window appears. It is possible to continue to modify Map Groups.

---

- 8 Click the Close button in the *EMS - Map Group Control* window when the Map Groups modifications is completed.

**Result:**

The *EMS - Map Group Control* window disappears.

END OF STEPS

---



## Modifying Map Groups

---

**Purpose** The purpose of this procedure is to group NEs in a geographical of functional way.



## Parameters for Modifying Map Groups

---

- Background Image File** This is the name of the background GIF filename used for the background image when the group is displayed. By default for a new group, it will be the Lucent logo file. The files available are the files in the directory:../lib/map\_data. To make a new file available, the file must be placed in this directory.
- New Group Name** When creating a group: this is the name of the group to be created.  
When modifying a group: this is the new group name.
- Old Group Name** Displays the old name of a group. This field is grayed out when creating a map group.
- Parent Group Name** This is the name of the group's parent in the hierarchy.  
When creating a group: specifies where in the hierarchy the group appears.  
When modifying a group: provides a mechanism for moving the group to a different parent.



## Modify Map Groups

---

**When to use** Use this procedure to modify or change the arrangement or names of map groups as they are displayed on windows.

**Before you begin** The items below gives information on tasks to perform before beginning the procedure:

- No prerequisite are needed when performing this procedure.
- No precaution are needed when performing this procedure.

**Related information** The items below list other relevant information to this procedure:

- The related procedures are *Creating Map Groups* and *Placing NE's in Map Groups*.
- The related concepts are explained in the Section: *Concepts of Topology Management*.

**Procedure** Follow these steps to modify network element groups:

---

- 1 Click with the right mouse button on Network Map (NOT on a node!) or click on the Modify groups icon.

**Result:**

When using the first option the The Network Map Background Pop-up menu appears.

When using the Modify groups icon the *EMS - Map Group Create/Change* window appears. Proceed with step 3!

---

- 2 Select Change the Groupings.

**Result:**

The *EMS - Map Group Control* window appears. This window provides a hierarchical presentation of the Network map's Map Groups.

---

- 3 Select a Map Group.
- 

- 4 Click the Modify Group button.

**Result:**

The *EMS - Map Group Create/Change* window appears.

- 
- 5 Select the Map Group to modify, enter the modifications and click Apply to activate the changes.
- 

- 6 Click Close.

**Result:**

The *EMS - Map Group Control* window appears.

---

- 7 Click Close in the *EMS - Map Group Control* window.

**Result:**

The changes made are activated and accessible and the Map Groups are updated with the changes to complete the procedure.

END OF STEPS

---



## Placing NEs in Map Groups

---

**Purpose** The purpose of this procedure is to group NEs in a geographical of functional way.



## Place NEs in Map Groups

---

**When to use** Use this procedure to (re)arrange the network elements in the created map groups. As result network elements are placed in the appropriate Map Group.

**Before you begin** The items below gives information on tasks to perform before beginning the procedure:

- No prerequisite are needed when performing this procedure.
- No precaution are needed when performing this procedure.

**Related information** The items below list other relevant information to this procedure:

- The related procedures are *Modifying Group Maps* and *Creating Map Groups*.
- The related concepts are explained in the Section: *Concepts of Topology Management*.

**Procedure** Follow these steps to rearrange network elements in network element groups:

---

- 1 Click with the right mouse button on Network Map (NOT on a node!) or click on the Modify groups icon.

**Result:**

When using the first option the The Network Map Background Pop-up menu appears.

When using the Modify groups icon the *EMS - Map Group Create/Change* window appears. Proceed with step 3!

---

- 2 Select Change the Groupings.

**Result:**

The *EMS - Map Group Control* window appears. This window provides a hierarchical view of the network map's Map Groups. All NEs, whether or not a member of a Map group, are shown.

---

- 3 To add an NE to a group, use the mouse to drag the node to the hierarchy display. Select an NE with the left mouse button, and drag it with the middle mouse button to the group. Release the button.

- 
- 4** When an NE is difficult to find, select the NE number or name in the *Name of Node to Locate* field.

**Result:**

The requested node is highlighted.

- 
- 5** Continue to move the nodes until they are arranged within the Map Groups as wanted.

- 
- 6** Click *C*lose.

**Result:**

Modifications are activated for the Map groups and the procedure is completed.

END OF STEPS







# 4 Provisioning Timing

## Overview

---

**Purpose** The purpose of provisioning timing is to synchronize the network element with a timing reference and to distribute this timing reference to SDH and non-SDH equipment.

**Outcome** The outcome of provisioning timing is a synchronized network element working according to the timing network plan.

**Intended use** This chapter consists of the procedures that are necessary to provision timing and the explanation of the different parameters that are to be used.



## Section: Provision Timing Sources.

### Overview

---

**Purpose** The purpose of provisioning timing sources is to provide a timing source with a defined quality level (QL), and to assign a valid physical timing reference to the logical timing source used to synchronize the network element.



## Provision Timing Sources

---

- When to perform** In the following two cases this procedure must be performed:
- As the first procedure to complete when provisioning the network element timing.
  - If the network element system timing will operate in the locked mode.

- Before you begin** Before starting this procedure, make sure that:
- A network element synchronization plan must be available.
- Pay attention to the following items:
- An MSP transmission protection pair is considered as a single timing reference. Thus in the case of MSP on the lines, only one line port is available as a timing reference.
  - Incorrect settings for worker/protection references and quality level-provisioning can cause a timing loop.

- Related information** Related procedures are:
- "Provision System Timing"
  - "Provision Output Port Timing"
  - "Provision MSP."

- Procedure** To edit the provisioned timing source information follow this procedure:
- 

- 1 Select *Provisioning --> Synchronization -->AM 1/AM 1 Plus Synchronization --> Timing Source*

**Result:**

The EMS-Provisioned NE Timing Sources Information window appears.

---

- 2 To select a network element or to switch to another network element, click the Selection Dialog Button. A list of possible network elements then appears in the *EMS- NE Timing Source Selection Dialog* window. Select the desired network element and timing source and click OK.

**Result:**

The EMS - Provisioned NE Timing Sources Information window is updated with the information of the selected timing source in the selected network element.

---

3 Click Edit.

**Result:**

The EMS-Edit Provisioned NE Timing Source Information window appears.

---

4 Select a *Working Reference* from the list and, if desired, a *Protection Reference*.

You can now edit the following fields:

- *QL Provisioned*
- *Monitored*
- *Global Wait to Restore Time*
- *Switch Request*(If a *Protection Reference* is assigned)
- *Clear Wait To Restore State*.

**Important!** A *Protection Reference* can only be assigned if the optional STM-1 tributary card is present.

---

5 Click OK to confirm the settings.

**Result:**

The *EMS-Edit Provisioned NE Timing Source Information* window disappears and the *EMS-Provisioned NE Timing Sources Information* window is updated with the latest settings.

---

6 Click Close.

**Result:**

The *Provisioned NE Timing Source Information* window disappears.

END OF STEPS




# Parameters to Provision Timing Sources

**Introduction** The procedure for provisioning timing sources defines the timing sources for network element synchronization.

The diagram below gives an overview of the relationship between the physical timing references and the logical timing sources. The physical timing references are indicated on the left side, the logical timing sources on the right side. Physical references can be assigned to the timing sources, therefore parameters are used. The parameters are indicated in the functional diagram. The arrows pointing towards the block indicate the parameters that can be provisioned. The arrows that point away from the block indicate read only parameters. The dotted arrows indicate that arrows apply to more references or sources.

**Important!** The *WaveStar*® AM 1 Plus can have an optional STM-1 tributary board present when working in the STM-4 mode. In that case some of the screens and parameters are slightly different from the default version. This is because of the possibility to then provision a protection reference.

**Functional Diagram** A functional diagram of the timing sources functionality



**Clear Wait to Restore State** *Clear Wait to Restore State* resets the wait to restore timer and the signal status will revert to normal.

Possible values of the *Clear Wait to Restore State* are *Yes* and *No*.

**Global Wait to Restore Time** In case of a failure the system switches to a valid reference. When the failure is no longer present, the system switches back, after a certain waiting period (the switching is revertive). This waiting period is called the *Global Wait to Restore Time*. It can range from 0 minutes to 60 minutes. The signal status will become *Wait to Restore*.

The *Global Wait to Restore Time* setting holds for all the timing in the network element. That is, for the Timing Sources, for the System Timing, and for the Station Clock Output Timing.

**Monitored** The user can enable or disable the option for monitoring a timing source. If a timing source is monitored, the timing source will forward the *Reference Fail* and *Reference Unequipped* alarms to the management system when applicable.

*Monitored* can have the values *Yes* or *No*.

**Protection Reference** The protection ports that can be assigned to the timing sources:

Timing Sources	Possible Timing References
TRIB-1	TP2.1 to TP2.2
TRIB-2	TP2.1 to TP2.2

**QL-in** When the quality level is read from the S1-byte from the timing references, it is reflected in the *QL-in* parameter. This parameter can have all of the defined quality level values. See subsection "Timing Quality Levels."

**QL-in Status** The user can view the status of the incoming quality level (*QL-in Status*) for each timing source. The possible values are:

QL-in status	Description
Valid	The received quality level is in the valid range.
Invalid	The received quality level falls outside the valid range or is unstable.
Not Supported	The corresponding input port does not provide S1-byte extraction.
Not Applicable	No reference is assigned to the timing source, or the assigned signal experiences a reference fail.

**QL-out** The *QL-out* parameter indicates the actual quality level value of the timing source that is used by the system timing block and the station clock output block. The *QL-out* value, is the quality level that enters the system timing and station clock output blocks. When *QL-Provisioned* is *AUTO*, *QL-out* equals *QL-in*. When *QL-Provisioned* has a value which is different from *AUTO*, *QL-out* equals *QL-Provisioned*.

**QL-Provisioned** The quality level of timing references can be provisioned by the user. The provisioned quality level is called *QL-Provisioned*. In case of a timing reference without an S1-byte, *QL-Provisioned* allows the user to provision a quality level.

When a timing reference does have an S1-byte (*QL-in* can be read by the system), this *QL-Provisioned* can be set to *AUTO*; in this case the S1-byte will be read from the incoming signal and will be sent to the System Timing function.

**Reference Fail** When the incoming signal cannot provide a timing reference, the timing reference is considered to fail. *Reference Fail* can take the values *Yes* or *No*.

**Signal Status** The signal status is received in the timing sources block and forwarded to the system timing block and the station clock output timing block. The possible values are:

Signal Status	Description
Not Connected	No reference is assigned to the timing source.
Failed	A timing link fail is declared for the assigned timing link.
Wait to Restore	The assigned reference signal will be available again when the Wait to Restore timer has expired.
Normal	The logical timing source is assigned to a valid timing reference.

**Switch Request** Switch requests are shown in the table in order of priority, together with their description.

Switch Request	Description
No Request	This is the default value. The system timing is operating under normal conditions.

Switch Request	Description
Clear Switch	Replaces the status by the normal status (in case of a previous switch).
Forced Switch	Unconditional switch, issued by the user, even if it is service degrading.
Manual Switch	A conditional switch, which is issued by the user. The switch will not be performed if it is service degrading.  If <i>QL=Enabled</i> , the switch will not be performed if it is service degrading.  If <i>QL=Disabled</i> , the switch will be performed even if it is service degrading.

**Switch request** Switch requests are shown in the table, together with their description and priority.

Priority	Switch Request	Description
	No Request	This is the default value. The system timing is operating under normal conditions.
1	Clear	Replaces the status by the normal status (in case of a previous switch).
2	Forced to Working	Unconditional switch, issued by the user, even if this is service degrading.
3	Forced to Protection	Unconditional switch, issued by the user, even if this is service degrading.
4	Reference Failure	Initiates a switch to protection. This request is not issued by the user, but by the node itself.
5	Manual to Working	A conditional switch, which is issued by the user. The switch will not be performed if it is service degrading.
6	Manual to Protection	A conditional switch, which is issued by the user. The switch will not be performed if it is service degrading.

**Switch Status** This parameter indicates the latest switch request. When no protection reference is provisioned, this parameter is not available. The possible values of this parameter are listed in the table below:

Switch Status	Description
No Request	No switch request has been issued.
Forced to Worker	A forced switch has been made to the timing reference that is provisioned as the worker timing reference.
Forced to Protection	A forced switch has been made to the timing reference that is provisioned as the protection timing reference.
Manual to Worker	A manual switch has been made to the timing reference that is provisioned as the worker timing reference.
Manual to Protection	A manual switch has been made to the timing reference that is provisioned as the protection timing reference.
Failed	No switch could be made.
Not Applicable	No protection has been provisioned

**Timing Source** Physical timing references can be assigned to logical timing sources. Once a timing reference is assigned to a timing source, no other reference can be assigned to the same source.

**Transmission Protected** Transmission Protected indicates whether the timing reference is MSP-protected for transmission. The values for Transmission Protected are *Yes* and *No*.

**Worker Reference** The worker references that can be assigned to the timing sources:

Timing Source	Possible Timing Reference
Line_1	LP1.1, LP2.1
Line_2	LP1.1, LP2.1
TRIB_1	TP1.1 .. TP1.16 TP2.1 .. TP2.16, if an optional 2 Mbit/s board is present TP2.1 .. TP 2.2, if an optional STM-1 board is present

<b>Timing Source</b>	<b>Possible Timing Reference</b>
TRIB_2	TP1.1 .. TP1.16 TP2.1 .. TP2.16, if an optional 2 Mbit/s board is present TP2.1 .. TP 2.2, if an optional STM-1 board is present



## Section: Provision System Timing

### Overview

---

**Purpose** The purpose of "Provision System Timing" is to lock the network element synchronization and outgoing timing signals to a timing source with the highest quality level.



## Provision System Timing

---

- When to perform** This procedure should be performed in the following cases:
- As the second procedure in network element timing provisioning.
  - If the network element system timing is required to operate in the locked mode.

- Before you begin** Before starting this procedure, make sure that:
- The "Provision Timing Sources" procedure is completed.
  - The network element synchronization plan must be available.
- Pay attention to the following items:
- When used, do not forget to clear the lockout condition after maintenance.

- Related information** Related procedures are:
- "Provision Timing Sources"
  - "Provision Output Port Timing."

**Procedure** To edit the provisioned timing source information follow this procedure:

- 
- 1 Select *Provisioning --> Synchronization --> AM I/AM I Plus Synchronization --> System Timing*.

**Result:**

The *EMS-Provisioned NE System Timing Information* window appears.

---

- 2 To select a network element or to switch to another network element, click the Selection Dialog Button. A list of possible network elements then appears in the *EMS- NE Selection Dialog* window. Select the desired network element and click OK.

**Result:**

The *EMS-NE System Timing Information* window is updated with the information of the selected timing source in the selected network element.

---

- 3 Click Edit.

**Result:**

The *EMS-Edit Provisioned NE System Timing Information* window appears.

- 
- 4** Select a timing source and select the required *Timing Mode*. If *Free Running* or *Hold-over* must be selected go to step 6, else set the *Timing Mode* to *Locked*

Select a timing source in top window; now you can edit the following fields:

- *Priority*
- *Lock Out Request*
- *Switch Request*
- *System and Timing QL mode*
- *Timing Source to Switch to*

Note that the *System and Timing QL mode* can also be set in the *Station Clock Output* window. This is the *same* parameter!

- 
- 5** If you want to provision another timing source from the selected network element, click OK to confirm the changes. The *EMS-Edit Provisioned NE System Timing Information* window is updated with the changes you have made.

- 
- 6** To provision another Timing Source go to step 4, otherwise go to step 7.

- 
- 7** Click Cl ose

**Result:**

The *EMS-Provisioned NE System Timing Information* window disappears.

END OF STEPS




## Parameters to Provision System Timing

**Introduction** The system timing functional block in the network element is responsible for:

- Selecting the timing sources to synchronize the system.
- Selecting the timing mode for the system
- Translating the quality level into the S1-byte of the outgoing signal.

The different parameters that can be set in the system timing functionality are indicated in the figure below.

**Functional Diagram** A functional diagram of the System Timing functionality



**Active System Timing Source** The *Active System Timing Source* indicates the timing source currently used to synchronize the system, together with the *Switch Status* of the source and the latest issued *Switch Request*.

**Lock out** The user can disable a specific timing source that enters the timing source selection without changing the priority settings. If a timing source is locked out, it will not take part in the timing source selection.

Whether a timing source is locked out is indicated by the Lockout parameter. The possible values for the Lockout parameter are: *Yes* and *No*.

**Lock Out Request** The *Lock out* state can be changed with the *Lock Out Request* parameter. This can be set to *No Request*, *Clear* or *Set*.

The *Lock Out Request* is for maintenance purposes. A Timing Source, which has a priority value assigned to it, can be temporarily locked out. When the Timing Source is already disabled, *Set* is rejected. A *Lockout Request* is set to *No Request* automatically when the Timing Source is disabled.

To turn off a Locked Out state, the Lock Out Request must be set to *Clear*.

When *Priority = Disabled* the *Lock Out Request* field is greyed out.

When a timing source is locked out, the network element is in the Abnormal State.

**Priority** The priority can be set for each timing source. For a network element with N timing sources provisioned, the priority can have values from 1 to N.

The *Priority* parameter can also have the value *Disabled*. A disabled timing source will not be taken into account in the Timing Source Selection for the system timing.

**Important!** Make sure not to provision identical Priority values to multiple timing sources.

**QL** The quality level of a timing source, that is used for automatic timing mode selection is indicated in the Provisioned NE System Timing Information window. This QL is identical to the QL-out as described in "Parameters to Provision Timing Sources."

**Signal Status** The signal status is received in the timing sources block and forwarded to the system timing block and the station clock output timing block. The possible values are:

Signal Status	Description
Not Connected	No reference is assigned to the timing source.
Failed	A timing link fail is declared for the assigned timing link.
Wait to Restore	The assigned reference signal will be available again when the Wait to Restore timer has expired.
Normal	The logical timing source is assigned to a valid timing reference.

**Switch Request** Switch requests are shown in the table in order of priority, together with their description.

Switch Request	Description
No Request	This is the default value. The system timing is operating under normal conditions.
Clear Switch	Replaces the status by the normal status (in case of a previous switch).
Forced Switch	Unconditional switch, issued by the user, even if it is service degrading.
Manual Switch	A conditional switch, which is issued by the user. The switch will not be performed if it is service degrading.  If <i>QL=Enabled</i> , the switch will not be performed if it is service degrading.  If <i>QL=Disabled</i> , the switch will be performed even if it is service degrading.

**Switch status** This parameter indicates the latest switch request. When no protection reference is provisioned, this parameter is not available. The possible values of this parameter are listed in the table below:

Value	Description
No Request	No switch request has been issued.
Clear	The former switch request is cleared. Switching will be system controlled after this request.
Forced Switch	A forced switch has been made to a timing source as indicated by the user.
Manual Switch	A manual switch has been made to a timing source as indicated by the user.

**System and Output Timing  
 QL Mode**

The *Timing Reference Switch* can operate in two modes: *QL-Enabled* and *QL-Disabled*.

- If the *Timing Reference Switch* is set to *QL-Enabled*, it selects the source according to the quality level and the source priorities (if two or more sources have equal, highest quality levels)
- If the *Timing Reference Switch* is set to *QL-Disabled*, it selects the best source according to the signal status and the priorities (if several sources have equal signal status).

**System QL** This parameter shows the quality level value of the timing signal used to clock the system. Possible values are the quality levels as described in the section "Timing Concepts."

**Timing Mode** This parameter is used to set one of the three timing modes: *Locked*, *Holdover*, and *Free Running*. The nature of the modes is discussed in the Section Concepts

**Timing** If, while operating in the *Locked* mode, the incoming reference becomes unacceptable, the timing mode selector switches to *Holdover*. This is reflected in the *Timing* parameter. When the system stays in the *Locked* mode, the timing status remains *Normal*.

In the *Free Running* mode, the *Timing* parameter always reflects *Normal*.



## Section: Provision Station Clock Output

### Overview

---

**Purpose** The purpose of this procedure is to specify the timing source to be used as a reference for the station clock output signals.



## Provision Station Clock Output

---

- When to perform** The procedure must be executed when:
- A timing reference needs to be provided to external “in station” equipment.
  - A regenerator loop is needed.

- Before you begin** Before starting this procedure, make sure that:
- The “Provision Timing Source” procedure is completed
  - The network timing plan is available

- Related information** Related procedures are:
- “Provision Timing Sources”
  - “Provision System Timing”
  - “Provision Output Port Timing.”

**Procedure** To edit the station clock output timing follow this procedure:

---

- 1 Select *Provisioning --> Synchronization --> AM 1/AM 1 Plus Synchronization --> Output Timing*.

**Result:**

The *EMS-Provisioned NE Station Clock Output Timing Information* window appears.

---

- 2 To select an network element or to switch to another network element (NE), click the Selection Dialog Button. A list of possible network elements then appears in the *EMS- NE Selection Dialog* window. Select the desired network element and click OK.

**Result:**

The *EMS-Provisioned NE Station Clock Output Timing Information* window is updated with the information of the selected timing source in the selected network element.

---

- 3 Click Edit.

**Result:**

The *EMS-Edit Provisioned NE Station Clock Output Timing Information* window appears.

---

.....  
4 Set *STCLK Output*. If *Disabled* is selected, go to step 11, else go to step 5.  
.....

5 Set the *Acceptance QL*.  
.....

6 Set *Source Selection*.  
.....

7 If Source selection is *System Timing* go to step 11. Else go to step 9.  
.....

8 Select a Timing Source in the top window, and set its

- *Priority*
  - *Lock Out Request*
  - *Switch Request*
  - *Timing Source to Switch to*
- .....

9 To change the *System and Output Timing QL* mode, click the diamonds.

**Important!** Note that this parameter can be set also in the *System Timing* window. This is the same parameter!  
.....

10 Click OK to confirm the changes.

**Result:**

The *EMS-Edit Provisioned NE Station Clock Output Timing Information* window disappears. The *EMS-Provisioned NE Station Clock Output Timing Information* window becomes visible again and is updated with changes that are made.  
.....

11 To provision another timing source go to step 6, else go to step 12.  
.....

12 Click Cl ose.

**Result:**

The *EMS-Provisioned NE Station Clock Output Timing Information* window disappears.


.....  
E N D O F S T E P S  
.....



## Parameters to Provision Station Clock Output

**Introduction** The station clock output functional block in the network element is responsible for selecting the timing source for the station clock output. The different parameters in the station clock output timing block are indicated graphically in the figure below.

**Functional Diagram** A functional diagram of the station clock output functionality



**Acceptance QL** The user can provision an *Acceptance QL*, applicable to all station clock output ports (if more than one). This quality level is the minimal quality level value that is accepted by the station clock output process. If the quality level of the signal for the station clock output falls below the *Acceptance QL*, the network element “squelsches” the station clock output signal.

**Active System Timing Source** The *Active System Timing Source* indicates the timing source currently used to synchronize the system, together with the *Switch Status* of the source and the latest issued *Switch Request*.

**Lock out** The user can disable a specific timing source that enters the timing source selection without changing the priority settings. If a timing source is locked out, it will not take part in the timing source selection.

Whether a timing source is locked out is indicated by the Lockout parameter. The possible values for the Lockout parameter are: *Yes* and *No*.

**Lock Out Request** The *Lock out* state can be changed with the *Lock Out Request* parameter. This can be set to *No Request*, *Clear* or *Set*.

The *Lock Out Request* is for maintenance purposes. A Timing Source, which has a priority value assigned to it, can be temporarily locked out. When the Timing Source is already disabled, *Set* is rejected. A *Lockout Request* is set to *No Request* automatically when the Timing Source is disabled.

To turn off a Locked Out state, the Lock Out Request must be set to *Clear*.

When *Priority = Disabled* the *Lock Out Request* field is greyed out.

When a timing source is locked out, the network element is in the Abnormal State.

- Output State** The user can view the *Output State* of the signal generated by the station clock output(s). Possible values are *Normal*, *Disabled*, and *Unacceptable*.
- *Normal*: indicates that the output is not disabled and has a quality level equal to or above the *Acceptance QL*
  - *Disabled*: indicates that the station clock output is disabled
  - *Unacceptable*: indicates a quality level below the *Acceptance QL*, or a signal status is failed.
- Priority** The priority can be set for each timing source. For a network element with N timing sources provisioned, the priority can have values from 1 to N.
- The *Priority* parameter can also have the value *Disabled*. A disabled timing source will not be taken into account in the Timing Source Selection for the system timing.
- Important!** Make sure not to provision identical Priority values to multiple timing sources.
- Signal Type** The *Signal Type* for the station clock outputs is always 2 MHz.
- Source Selection** The station clock output timing can be derived from one of the system clock processes or from the independent station clock output timing *Source Reference Selector*. This is provisioned by the user. Two options are available:
- *System Timing*
  - *Independent Station Clock Timing*.
- STCLK Output** The user can enable or disable the *Station Clock Output*. If it is disabled it forwards no signal at all and can not be used.

**Switch Request** Switch requests are shown in the table in order of priority, together with their description.

Switch Request	Description
No Request	This is the default value. The system timing is operating under normal conditions.
Clear Switch	Replaces the status by the normal status (in case of a previous switch).
Forced Switch	Unconditional switch, issued by the user, even if it is service degrading.
Manual Switch	A conditional switch, which is issued by the user. The switch will not be performed if it is service degrading.  If <i>QL=Enabled</i> , the switch will not be performed if it is service degrading.  If <i>QL=Disabled</i> , the switch will be performed even if it is service degrading.

**Switch status** This parameter indicates the latest switch request. When no protection reference is provisioned, this parameter is not available. The possible values of this parameter are listed in the table below:

Value	Description
No Request	No switch request has been issued.
Clear	The former switch request is cleared. Switching will be system controlled after this request.
Forced Switch	A forced switch has been made to a timing source as indicated by the user.
Manual Switch	A manual switch has been made to a timing source as indicated by the user.

**System and Output Timing  
QL Mode**

The *Timing Reference Switch* can operate in two modes: *QL-Enabled* and *QL-Disabled*.

- If the *Timing Reference Switch* is set to *QL-Enabled*, it selects the source according to the quality level and the source priorities (if two or more sources have equal, highest quality levels)
- If the *Timing Reference Switch* is set to *QL-Disabled*, it selects the best source according to the signal status and the priorities (if several sources have equal signal status).

**Timing Source** Physical timing references can be assigned to logical timing sources. Once a timing reference is assigned to a timing source, no other reference can be assigned to the same source.



## Section: Provision Output Port Timing

### Overview

---

**Purpose** The purpose of output port timing provisioning is to provision the timing properties for the 1.5 Mbit/s, 2 Mbit/s and X.21 output ports and the station clock output ports.



## Provision Output Port Timing

---

**When to perform** If a 1.5 Mbit/s, 2 Mbit/s or Mbit/s tributary port has to be used as a timing reference for other equipment. This can be done for both SDH and non-SDH equipment.

**Before you begin** Pay attention to the following:

- Use of retiming on the 1.5 Mbit/s or 2 Mbit/s tributary ports can affect the data integrity of the signal. This is not so in case of X.21 retiming.
- When quality level information must be sent out on the 2 Mbit/s station clock output ports the *Signal Type* must be *2 Mbit/s Framed*.
- The provisioned *Signal Type* for the station clock output is the same for both station clock output ports.

**Related information** Related procedures are:

- "Port Provisioning"
- "Provision Station Clock Output."

**Provision 1.5 Mbit/s, 2 Mbit/s or X.21 Output Port Timing** To provision the output port timing follow this procedure:

---

**1** Select Provisioning --> Equipment --> Port.

**Result:**

The *EMS-Provisioned NE Port Information* window appears.

---

**2** To select a network element or to switch to another network element, click the Selection Dialog Button. A list of possible network elements then appears in the *EMS- NE Selection Dialog* window. Select the desired network element and click OK.

**Result:**

The *EMS-Provisioned NE Port Information* window is updated with the information for the selected network element.

---

**3** Select a 1.5 Mbit/s, 2 Mbit/s, X.21 or a station clock output port (indicated in the list by *Portname (2Mb)* in the column named *Port*).

**Result:**

The contents of the *EMS-Provisioned NE Port Information* window are changed according to the properties of the selected point.

---

- 4 Click *Edit*.

**Result:**

The *EMS-Edit Provisioned NE Port Information* window appears.

---

- 5 Set the *Timing Alarm Reporting* and the *Timing Mode*.

When the timing mode is *Self-timed*, the fields *Fallback mode* and *Acceptance QL* are greyed out. In that case, go to step 7.

---

- 6 Set the *Fallback Mode* and the *Acceptance QL*.
- 

- 7 Select OK to confirm the settings.

**Result:**

The *EMS-Edit Provisioned NE Port Information* window disappears.

---

- 8 If you want to provision another output port go to step 2, else click *Close*

**Result:**

The *EMS-Provisioned NE Port Information* window disappears.

END OF STEPS

---

**Force DNU on STM-1  
Output Port Timing**

To force a DNU timing marker on an outgoing SDH signal follow this procedure:

---

- 1 Select *Provisioning --> Transmission --> Trail Terminations --> RS and MS*.

**Result:**

The *EMS-Provisioned NE RS and MS Termination Point Information* window appears.

- 
- 2** To select a network element or to switch to another network element, click the Selection Dialog Button. A list of possible network elements then appears in the *EMS- NE Selection Dialog* window. Select the desired network element and click OK.

**Result:**

The *EMS-Provisioned NE RS and MS Termination Point Information* window is updated with the information of the selected network element.

---

- 3** Select an STM-1 port from the port list and click Edit.

**Result:**

The *EMS-Edit Provisioned NE RS and MS Termination Point Information* window appears.

---

- 4** Select a *Force DNU* value.
- 

- 5** Click Close

**Result:**

The *EMS-Edit Provisioned NE RS and MS Termination Point Information* window disappears.

---

- 6** Click Close

**Result:**

: The *EMS-Provisioned NE RS and MS Termination Point Information* window disappears.

END OF STEPS


---



## Parameters to Provision Output Port Timing

**Introduction** The 1.5 Mbit/s, 2 Mbit/s and X.21 transmission ports are managed by a number of parameters, which are related to timing. These parameters are shown in the functional diagram below.

**Functional diagram** The functional diagram of the Output Port Timing functionality



**Acceptance QL** For each individual 1.5 Mbit/s, 2 Mbit/s or X.21 tributary output port in the *Re-Timed* mode, an *Acceptance QL* can be provisioned. If the *System QL* (in case of system timing) or the *QL-out* (in case of independent timing) falls below the *Acceptance QL*, the timing will go into the *Fallback* mode.

**Fallback mode** If a 2 Mbit/s port is operating in the *Re-timed* mode and if the *System and Output QL mode* is enabled, the output is automatically switched to the provisioned *Fallback* mode, if the quality level of the system timing drops below the *Acceptance QL*.

The three *Fallback* modes are:

- *Re-timed AIS*: A Re-timed AIS is sent out.
- *Self-timed*: The signal is sent out, from the port in the *Self-timed* mode
- *None*: no Fallback applies.

**Force DNU** *Force DNU* allows to force an S1-byte value: *DNU* into an outgoing signal.

The values for *Force DNU* are given below:

Option	Description
Yes	A DNU is forced on the outgoing signal
No	No DNU is forced on the outgoing signal
No Request	This option resets a force DNU setting. It is the default value for <i>Force DNU</i> .

When an outgoing signal is forced to carry DNU, this signal can not be used for synchronization by another network element.

**Forced DNU** *Forced DNU* is a read only parameter. It indicates whether a DNU is forced on an outgoing signal.

When an outgoing signal is forced to carry DNU, this signal cannot be used for synchronization by another network element.

**Outgoing QL** *Outgoing QL* indicates the quality level that is sent out on a given transmission output port which supports S1-byte quality level information carriage.

**SSM Out** *SSM Out* displays the quality level corresponding to the current S1-byte value that is sent out from the selected port.

**Timing Mode** The timing mode of each individual 1.5 Mbit/s, 2 Mbit/s and X.21 tributary output port can be set to the *Self-Timed* or *Re-Timed* mode:

- In the *Self-Timed* mode the 2 Mbit/s signal is extracted from the container contents of the VC-12.
- In the *Re-Timed* mode, the timing of the 2 Mbit/s output signal is derived from the network element system timing; the 2 Mbit/s signal is routed through the elastic buffer.

If the *ISDN mode* of a 2 Mbit/s ISDN port is set to Leased Line (*LL*), the default value of the *Timing Mode* parameter will be *Re-Timed*.

For more information see the section "Timing Concepts."

**Timing Alarm Reporting** When the *Timing State* of a 1.5 Mbit/s, 2 Mbit/s or X.21 tributary output port is *Fallback*, a defect is declared. The reporting of this *Timing Alarm* can be *Enabled* or *Disabled* for each individual 2 Mbit/s tributary output port. This is done with the *Timing Alarm Reporting* parameter.

**(Port) Timing State** The *(Port) Timing State* of each individual 1.5 Mbit/s, 2 Mbit/s and X.21 tributary output port can be viewed. The *(Port)Timing State* can have two values:

- *Normal*: The port operates as specified in the timing mode
- *Fallback*:The timing mode has fallen back as specified in the *Fallback Mode*parameter.



## Section: Provision with Timing Templates.

### Overview

---

**Purpose** To speed up the provisioning and to limit the chance of making mistakes in provisioning several network elements with the same timing configuration, timing templates are used.



## Provision with Timing Templates

---

**When to perform** When several network elements within the network must have identical timing configurations.

**Before you begin** Before the procedure is performed, make sure that the following prerequisites are met:

- The *Licence Key* for the timing templates must be set.
- The network timing plan must be available and contain several network elements with an identical timing configuration.

Beware of the fact that when a timing template is used, it is not possible to provision any port.

**Related information** Related procedures are:

- "Provision Timing Source"
- "Provision System Timing"
- "Provision Station Clock Output".

**Create a Timing Template** To create a timing template follow this procedure:

---

**1** Select Templates --> Synchronization --> Create.

**Result:**

The *EMS-Create Timing Template* window appears.

---

**2** Select a *System Type* and a *Timing Template Name*, using the Selection Dialog Button, as the base for the "to-be-created" template

---

**3** Type the *User Template Name* in the *User Template Name* field.

---

**4** Click Apply

**Result:**

The creation of a new template is confirmed.

---

**5** To create another timing template go to step 2, else click Close.

**Result:**

The *EMS-Create Timing Template* window disappears.

END OF STEPS

---

**Edit a Timing Template** To edit the timing templates perform this procedure:

---

- 1 Select *Templates --> Synchronization -->AM 1/AM 1 Plus Information*.

**Result:**

The *EMS-AM 1/AM 1 Plus Timing Template Information* window appears. No values are filled in.

---

- 2 Use the Selection Dialog Button to select a timing template name.

**Result:**

The *EMS-Timing Template Selection Dialog* window appears.

---

- 3 Select a template of the *User Defined* type and click OK.

**Result:**

The *EMS-AM 1/AM 1 Plus Timing Template Information* window is filled with values from the selected template.

---

- 4 Set *Timing Template Details to Edit* to one of the following

- *Timing Source*
- *System Timing*
- *Output Timing*

and click *Edit*.

**Result:**

The corresponding *EMS-Edit AM 1/AM 1 Plus Timing Template* window appears.

---

- 5 Select the required *Timing Source* and set the parameters by selecting the required diamonds. When you are finished selecting the diamonds click OK

For output timing, a timing source must only be selected when the *Source Selection* is *Independent*.

**Result:**

The *EMS-Edit AM 1/AM 1 Plus Timing Template* window is filled with the new values.

---

- 6 Click *Close*.
-

**Result:**

The *EMS-Edit Timing Template* window disappears.

- .....
- 7 To edit other timing template details go to step 3. Else go to step 7.
- .....

- 8 To edit another template go to step 2. Else go to step 8.
- .....

- 9 Click **C**lose to leave the *EMS-AM 1/AM 1 Plus Timing Template Information* window.

**Result:**

The *AM 1/AM 1 Plus Timing Template Information* window disappears.

.....  
E N D O F S T E P S  
.....

**Configure from Template** To configure timing from a template follow this procedure:

.....

- 1 Select *Provisioning --> Synchronization --> AM 1/AM 1 Plus Synchronization --> Configure from Template*.

**Result:**

The *EMS-Configure NE Timing from Template* window appears. The first time the window is opened, all fields are empty.

.....

- 2 To select a network element or to switch to another network element, click the Selection Dialog Button. A list of possible network elements then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The *Configure EMS-NE Timing from Template* window reflects the available templates.

.....

- 3 Select the required *Timing Source*, and set the parameters by clicking the diamonds. When finished click OK to confirm.

**Result:**

The *EMS-Configure NE Timing from Template* window is filled with the new values.

- 
- 4 Click Cl ose.

**Result:**

The *EMS-Configure NE Timing from Template* window disappears.

END OF STEPS

---

### Delete a Timing Template

To delete a timing template follow this procedure:

---

- 1 Select Templates --> Synchronization -->Delete

**Result:**

The *EMS-Delete Timing Template* window appears.

---

- 2 Use the selection dialog button to select a timing template to delete.
- 

- 3 Click Appl y to confirm the deletion of the timing template.

**Result:**

In the message window, the ITM-SC reflects the deletion process.

---

- 4 If you want to delete another Timing Template go to step 2. Else click Cl ose to exit.

**Result:**

The *EMS-Delete Timing Template* window disappears.

END OF STEPS

---



## Parameters to Provision with Timing Templates

---

**Introduction** A timing template is a model of an network element for which only the timing parameters are configured. This model can be copied onto real network elements, thus provisioning all timing parameters at once.

Before you can configure timing from template, a template must be present. Default templates are available, but you can also create your own user defined templates by modifying an existing template.

Within a user defined timing template you can set the parameters for:

- *Timing Source*
- *System Timing*
- *Output Timing*

The information window shows information about parameters from all these three functionalities. To edit a template you must use three different edit-windows corresponding to the three functionalities. The three edit options are identified by the *Timing Template Details to Edit* parameter.

When a user defined template is not needed any more it can be deleted.

<b>Base Timing Template Name</b>	<p>This is the name of an already existing template. It can be a default template which is presented by the ITM-SC, or a template which was created before.</p> <p>A default template can be used as a base template for the creation of a new template. The edited template must be saved then with a new timing template name. This name must be unique within the system type.</p>
<b>Base Timing Template Type</b>	<p>This is the type of template. Two types of templates exist:</p> <ul style="list-style-type: none"> <li>• <i>User Defined:</i>A template which is created by a user.</li> <li>• <i>Default:</i>A template as it is presented by the ITM-SC</li> </ul>
<b>Default Templates</b>	<p>Different default timing templates are available in the ITM-SC, for the different system types.</p> <p>No editing is allowed in default templates.</p>
<b>Timing Template Details to Edit</b>	<p>This parameter indicates for which functional block a timing template is provided to edit. When a default template is used to provision timing, this option is not available.</p>

The available *Timing Templates Types* are:

<b>Timing Template Details to Edit</b>	<b>Allows to edit the parameters shown in</b>
Timing Source	The <i>Edit AM 1/AM 1 Plus Timing Template Timing Details</i> window. See also "Parameters to Provision Timing Source".
System Timing	The <i>Edit AM 1/AM 1 Plus Timing Template System Timing Details</i> window. See also "Parameters to Provision System Timing".
Output Timing	The <i>Edit AM 1/AM 1 Plus Timing Template Station Clock Output Timing Details</i> window. See also "Parameters to Provision Station Clock Output".



## Section: Use the Timing Event Log .

### Overview

---

**Purpose** The purpose of the timing event log is to gain insight in the history of timing events throughout the whole network.



## Use the Timing Event Log

---

**When to perform** When network element alarms occur, the timing event log can help to locate their origin.

**Before you begin** Make sure that the timing event log is enabled, when it is to be used. If the timing event log is disabled, the complete event history is deleted.

**Related information** "View the Synchronization Summary".

**Enable / Disable Timing Event Log** To enable or disable the timing event log an administrator user must follow this procedure:

---

- 1 Select File --> Logging --> Synchronization Logs --> Synchronization Control.

**Result:**

The *EMS-Timing Event Log Information* window appears.

---

- 2 To enable/disable the timing event log, click Edit.

**Result:**

The *EMS-Edit Timing Event Log Control* window appears.

---

- 3 Select *Disable* or *Enable*.
- 

- 4 Click OK to confirm the change.

**Result:**

When you are disabling the timing event log a warning window appears.

---

- 5 If a warning window appears, select Yes when you are sure you want to disable the timing event log, and go to step 7. Else select No, and go to step 6.
- 

- 6 Click Close.

**Result:**

The *EMS-Control Timing Event Log* window disappears.

---

---

7 Click Cl ose.

**Result:**

The *EMS-Timing Event Log Information* window disappears.

END OF STEPS

---

**View the Timing Event Log** To view the timing event log follow this procedure:

---

1 Select File --> Logging -->Synchronization Logs --> Synchronization Logs.

**Result:**

The *EMS-Timing Event Log* window appears.

---

2 Now you can view the timing events.

- If you are satisfied with the way the events are presented, you can read or print the event log and go to step 5.
  - If you want to change the presentation go to step 3.
- 

3 If you want to change the order of the event list you set the *Sort By* parameter to *Node Name* or *Time Occurred*.

**Result:**

The order of the events list is adjusted.

---

4 If you want to delete the listed timing events click Del et e and then click Appl y.

**Result:**

The timing event log is cleared.

---

5 Click Cl ose.

**Result:**

The *EMS-Timing Event Log* window disappears.

END OF STEPS

---



## Parameters to Use the Timing Event Log

---

<b>Introduction</b>	The timing event log reflects a list of the timing events that have taken place in the network. A timing event is a change in the settings of a timing provisioning parameter. The timing event log is available to all users. It can be enabled or disabled by the administrator users.
<b>Delete Log</b>	To delete the timing event log-list, the <i>delete</i> -check box must be selected. This parameter is only accessible for administrator users.
<b>Node Name</b>	The name of the node in the network where a timing event has occurred.
<b>Sort by</b>	The <i>Sort by</i> parameter indicates the parameter that must be used to sort the list of timing events in the <i>EMS-Timing Event Log</i> window. It can be: <ul style="list-style-type: none"><li>• <i>Node Name</i></li><li>• <i>Time Occurred</i>.</li></ul>
<b>Time Occurred</b>	The time and day at which a timing event occurred. The format is: <i>hh:mm:ss dd/mm/yy</i> .
<b>Timing Event</b>	The system stores in its Timing Event Log all timing events sent by the NEs under its management. A timing event stored in the log reflects a notification related to the following : <ul style="list-style-type: none"><li>• Changes in Reference assignments related to a timing source enabled in at least one timing link switch</li><li>• Changes in the Reference Switch Status related to a timing source enabled in at least one timing link switch.</li><li>• Changes in the Signal status of a timing source enabled in at least one timing link switch.</li><li>• Changes in the incoming QL value and status of a timing source enabled in at least one timing link switch.</li><li>• Changes in the provisioned QL of a timing source enabled in at least one timing link switch.</li><li>• Changes in the Timing Mode.</li><li>• Changes in the Timing State.</li><li>• Changes in source priorities in both timing link switches.</li><li>• Changes in lockout status in both timing link switches.</li><li>• Changes in Link Switch status in both timing link switches.</li><li>• Changes in the System &amp; Output Timing QL mode.</li></ul>

- Changes in the System QL.
- Changes in the Source Selection for the Station Clock Output.
- Changes in Acceptance QL for the Station Clock Output.
- Changes in the STCLK Output.
- Changes in the Output State for the Station Clock Output.
- Changes in the Output QL for the Station Clock Output.
- Changes in the application of forced DNU in a transmission output port.

**Timing Event Log**

This parameter indicates whether the timing event log records the timing events. The *Timing Event Log* parameter can have two values:

Timing Event Log	Indicates that...
Enabled	All timing events in the network are recorded
Disabled	No timing events are recorded. When you set this value, all timing event records are deleted.



## Section: View the Synchronization Summary.

### Overview

---

**Purpose** The purpose of the Synchronization Summary is to provide insight in the timing configuration of the whole network.



## View the Synchronization Summary

---

**When to perform** When you need to know the timing configuration of the network the *Synchronization Summary* is the first window to use.

**Before you begin** There are no prerequisites or precautions to be taken for this procedure.

**Related information** "View the Timing Event Log".

**Procedure** To view the Synchronization Summary perform the following procedure:

---

- 1 Select Provisioning --> Synchronization --> Summary.

**Result:**

The *EMS-Synchronization Summary* window appears.

---

- 2 Now you can view the synchronization summary.  
This screen is *NOT* automatically updated!
- 

- 3 Click Refresh.

**Result:**

The information in the *EMS-Synchronization Summary* window is updated.

---

- 4 Click Close.

**Result:**

The *EMS-Synchronization Summary* window disappears.

END OF STEPS

---



## Parameters to View the Synchronization Summary

---

- Introduction** The synchronization summary provides an overview of the timing parameter settings throughout the network.
- Only the parameters that are relevant for this network element are explained in this subsection.
- Node Name** This parameter indicates the name of the node for which the timing parameters are shown. This is the name of a node in the network. It is shown together with the type of network element.
- Output QL** *Output QL* gives the output quality level of the timing signal which is generated by the station clock outputs.
- Output Ref.** The *Output Ref.* parameter identifies the timing source which is used to synchronize the station clock output.
- System QL** *System QL* indicates the quality level of the timing signal which is used to synchronize the system.
- System Ref.** The *System Ref.* parameter identifies the timing source which is used to synchronize the system.





# 5 Path Provisioning and Protection

## Overview

---

**Purpose** Path Provisioning and Protection sets up the network elements to route the traffic through the network.

**Objective** To create transmission paths through the network with or without protection. The protected transmission path can maintain the transmission signal in case of transmission failures.

**Outcome** The outcome of transmission provisioning is:

- all traffic can be transported through the network according to the transmission plan
- if protection is used, the traffic that is routed through the network is protected against failures.

**Protection Types** The following protection types can be used:

- SNC: Sub Network Connection protection protects a specific transmission path in a ring.
- MSP: Multiplex Section Protection protects the transmission path in a point-to-point connection.

**Intended use** This chapter describes setting up traffic on VC-4, VC-3 and VC-12 level in a network with WaveStar® AM 1 network elements.

The following table shows the tasks that can be performed and the type of protection they are related to:

<b>Task</b>	<b>Protection</b>
Provision Ethernet over SDH	No
Display the cross connections of a network element	No Protection
Provision and delete Cross Connections without protection	No protection
Provision and delete Cross Connections with SNC protection	SNC
View SNC protection	SNC
View MSP protection	MSP
Edit MSP protection	MSP



## Section: Provision Ethernet over SDH

### Overview

---

**Purpose** To connect remote PC LAN network sites via an SDH network without the need for intermediate bridges or routers and enable the transport of ethernet packets across the SDH network.



## Procedures to Provision LAN groups

---

**When to use** Perform these procedures to create, modify or delete LAN groups.

**Before you begin** Before provisioning LAN groups it is assumed that the following items are known:

- the LAN group name
- the LAN group label
- the LAN group mode.

**Related information** Related information can be found in section Traffic Provisioning Concepts.

### Procedure to Create a LAN Group

---

- 1 Select *Provisioning* —> *Packet over SDH* —> *LAN Group*.

**Result:**

The *EMS —Provisioned NE LAN Groups Information* window appears with a list of existing LAN groups

---

- 2 Click *Create LAN Group*.

**Result:**

The *EMS - Edit LAN Group Information* window appears.

---

- 3 Enter a name of maximum 20 characters in the *LAN Group Label* field.
- 

- 4 Select the *LAN Group Mode*; this can be Point-to Point, LAN, LAN-Interconnect or LAN-VPN and click *Apply*.

**Result:**

TS2 will be automatically selected (there is only one slot available). The LAN group is created.

---

- 5 Click *Close*.

**Result:**

The *EMS — Provisioned NE LAN Groups Information* window reappears. The created LAN group is now displayed in the list.

---

From this window LAN and WAN ports can be attached to the LAN group.

END OF STEPS

---

### Procedure to Modify or Delete a LAN group

---

- 1 Select *Provisioning* —> *Packet over SDH* —> *LAN Group*.

**Result:**

The *EMS —Provisioned NE LAN Groups Information* window appears with a list of existing LAN Groups.

---

- 2 Select the LAN group to modify or to remove and click *Edit LAN Group*.

**Result:**

The *EMS - Edit LAN Group Information* window appears. The LAN ports and WAN ports assigned to the selected LAN group are displayed in the lower part of the window.

---

- 3

To	Then
Modify the LAN group label	Select <i>Modify</i> in the <i>Operation</i> field. Change the name of the LAN group in the <i>LAN Group Label</i> field (maximum 20 characters). The slot can not be modified. Click <i>Apply</i> .  <b>Result:</b> The label of the LAN group is modified.
Modify the LAN group mode	Select <i>Modify</i> in the <i>Operation</i> field and select the LAN group mode; this can be Point-to-Point, LAN-Interconnect or LAN-VPN. The slot can not be modified. Click <i>Apply</i> .  <b>Result:</b> The LAN mode is modified.

To	Then
Delete a LAN group	Select <i>Delete</i> in the <i>Operation</i> field and click <i>Apply</i> .  <b>Result:</b> A warning message is displayed stating that deleting the LAN group may disrupt traffic. Click <i>Yes</i> to proceed.

4 Click *Close*.

**Result:**

The *EMS — Provisioned NE LAN Groups Information* window reappears. The modifications are displayed in the LAN group list. The deleted LAN group is removed from the list.

END OF STEPS



## Procedures to Provision LAN ports and WAN ports

---

- When to use** Perform these procedures to:
- attach or detach LAN ports to or from a LAN group and how to modify LAN ports details
  - attach or detach WAN ports to/from a LAN group.

- Before you begin** Before provisioning LAN ports and WAN ports it is assumed that the LAN group has been created and the following items are known:
- the LAN group name
  - the LAN port name
  - the LAN port details, such as CID and CIR
  - WAN port name.

**Related information** Related information can be found in section Traffic Provisioning Concepts.

### Procedure to attach/detach LAN ports and how to modify LAN port details.

---

- 1 Select in the main menu: *Provisioning* —> *Packet over SDH* —> *LAN Group*.

**Result:**

The *EMS — Provisioned NE LAN Groups Information* window appears with a list of all the created LAN Groups.

---

- 2 Select a LAN group

**Result:**

In the lower area of the window, lists of LAN ports and WAN ports that are members of the selected LAN group appear.

---

- 3 Click *Edit LAN Port Details*.

**Result:**

The *EMS — Edit LAN Port Information* window appears with a list of all LAN ports that are either members of the current selected LAN Group or unassigned LAN Ports available for use within the selected LAN Group.

- 
- 4 Select a LAN port from the list.

**Result:**

The fields of the lower part of the window are filled in with details of the selected LAN port.

- 
- 5

To	Then
Attach a LAN port to the LAN group	Select <i>Attach</i> in the <i>Assignment</i> field.
Detach a LAN port to the LAN group	Select <i>Detach</i> in the <i>Assignment</i> field.
Modify LAN port details.	Change the parameters in the <i>LAN Port Details</i> area, such as LAN port label, the CID and the CIR.
Select the operation mode.	Change the operation mode (Strict Policing or Oversubscription).

- 
- 6 Several LAN Ports may be selected in turn and their details and/or assignment changed. Click *OK* to apply the changes to all the selected LAN ports.

**Important!** If a LAN port is detached from a LAN group, a warning message is displayed stating that this may disrupt traffic on the LAN group. Click yes to confirm.

END OF STEPS

---

**Procedure to attach/detach  
 WAN ports to/from a LAN  
 group.**

- 
- 1 Select in the main menu: *Provisioning* —> *Packet over SDH* —> *LAN Group*.

**Result:**

The *EMS — Provisioned NE LAN Groups Information* window appears with a list of all the created LAN Groups.

- 
- 2 Select a LAN group.

**Result:**

In the lower area of the window, lists of LAN ports and WAN ports that are members of the selected LAN group appear.

- 
- 3** Click *Edit WAN Port Details*.

**Result:**

The *EMS — Edit WAN Port Information* window appears with a list of all WAN ports that are either members of the current selected LAN Group or unassigned WAN Ports available for use within the selected LAN Group.

---

**4**

To	Then
Attach a WAN port to the LAN group	Select <i>Attach</i> in the <i>Assignment</i> field.
Detach a WAN port to the LAN group	Select <i>Detach</i> in the <i>Assignment</i> field.

- 
- 5** Several WAN ports may be selected in turn and their assignment changed. Click *OK* to apply the changes to all the selected WAN ports.

**Important!** If a WAN port is detached, a warning message appears, stating that detaching the WAN port may disrupt the traffic. Click *Yes* to confirm

END OF STEPS



## Procedure to Provision SDH Channels

---

**When to use** Perform these procedures to select the required channel capacity and to enable or disable monitoring the SDH channel.

**Before you begin** Before provisioning SDH channels it is assumed that the following items are known:

- the TTP of the SDH channel
- the required capacity of the SDH channel
- the SDH channel TTP mode.

**Related information** Related information can be found in section Traffic Provisioning Concepts.

### Procedure

---

- 1 Select from the main menu: *Provisioning* —> *Packet over SDH* —> *SDH Channels*.

**Result:**

The *EMS — NE SDH Channel Information* window appears with a list of SDH channels configured for the network element. In this list the capacity of the channel is displayed and whether the TTP (Trail Termination Point) of the channel is monitored or not.

---

- 2 Select an SDH channel from the list.

**Result:**

In the lower part of the window a list of all termination points associated with the selected SDH channel appears. These are the VC-TTPs to make the cross connections. The capacity of the VCs is also displayed.

---

- 3 Click *Edit*.

**Result:**

The *EMS — Edit NE SDH Channel Information* window appears. Here the capacity of the selected SDH channel can be changed. Monitoring on the SDH channel can be enabled or disabled in the *SDH Channel TTP Mode* field.

---

- 4 Select the required VC capacity from the SDH Channel Capacity list.
-

- 
- 5** Set the SDH Channel TTP Mode to Monitored or Not Monitored to enable or disable monitoring of the SDH channel.
- 

- 6** Click *OK*.

**Result:**

The *EMS — NE SDH Channel Information* window reappears with the updated SDH Channel information.

---

- 7** Click *Close*

to exit.

END OF STEPS

---



## Procedure to Check the Sequence Number of a Virtually Concatenated VC-12 or VC-3

---

**When to use** Perform this procedure to check the sequence number of a virtual concatenated VC-12 or VC-3.

**Before you begin** No prerequisites or precautions are needed when performing this procedure.

**Related information** Related information can be found in section Traffic Provisioning Concepts.

### Procedure

---

- 1 Select Provisioning -> Transmission -> Trail Terminations and then select VC12 or VC3.

**Result:**

The *EMS - Provisioned NE TP Information* window is displayed.

---

- 2 Fill in the type of termination point in the *TP Type* box and select the termination point, to be checked, from the list.

**Result:**

The information about the selected termination point is displayed. In the *TP Numbering* field the Transmitted and Accepted (received) Sequence number are displayed.

END OF STEPS

---



## Parameters for provisioning LAN groups

---

<b>LAN Group</b>	A LAN group is a set of LAN/WAN ports on a LAN unit that is used by one or more end users who can share the common WAN bandwidth. There are more than one LAN group. The end users in the same LAN group are recognizable by a Customer Identifiers (CID).
<b>LAN group name</b>	This is a fixed name for the LAN group: LANGRP2.x, where LANGRP2 is the slot name and x is the number of the LAN group.
<b>LAN group label</b>	A label can be created for each LAN group. This label can be any character string of maximum 20 characters. The label is not used as an identifier, it is only for convenience of the user. The system does not check its uniqueness.
<b>LAN group mode</b>	The LAN group mode can be set to: <ul style="list-style-type: none"><li>• Point to point LAN. In this mode the ethernet interfaces are connected in a point-to-point manner across the SDH network. The LAN group supports 1 LAN port and 1 WAN port. The principle of the TransLAN is described in section Traffic Provisioning Concepts.</li><li>• LAN-Interconnect. . In this mode a LAN group contains multiple LAN ports and multiple WAN ports. Only one end user is connected to one or up to four LAN port(s). The NE functions as a learning bridge; Spanning Tree algorithms are supported. The principle of the TransLAN+ type is described in section Traffic Provisioning Concepts.</li><li>• LAN-VPN (Virtual Private Network), also mentioned as M-LAN. In this mode a LAN group contains multiple LAN ports and multiple WAN ports. The LAN port(s) can be shared by multiple end users. The NE functions as a learning bridge; Spanning Tree algorithms are supported.. The principle of the M-LAN type is described in section Traffic Provisioning Concepts.</li></ul>
<b>LAN port name</b>	LAN port name The LAN Port name is a fixed name: LAN2.x, where LAN2 is the slot name and x is the number of the LAN port. x can be up 1 up to 4.
<b>LAN port label</b>	The label can be created/changed for each LAN port. The label can be up to 20 characters long.

**Customer Identity (CID)** Customer Identity for a LAN group. This is an integer between 0 and 4094. The Customer Identifier separates the end users. If the CID is 0, the system implicitly disables the functions of the corresponding LAN port. Only the values between 1 and 4094 are used to identify a customer in a network.

**Committed Information Rate (CIR)** The CIR represent the bandwidth being allocated to a customer in the range: 0 kBit/s, 64 kBit/s ... 100 Mbit/s in steps of 12 kBit/s. The default value is 64 kBit/s.

**Mode of operation (PIR)** There are two options to select the Peak Information Rate (PIR).

- Strict Policing; the PIR is set to the same value as the CIR
- Oversubscription; the PIR is set to infinity.

**WAN port name** The WAN Port name is a fixed name: WAN2.x, where WAN2 refers to the slot and x is the number of the WAN port. The number of the WAN Port can be 1 up to 4.

**SDH Channel** The name of the SDH channel associated with the WAN port is fixed: SDHChann2.x, where SDHChann2 refers to the slot and x is the number of the SDH channel. This is the same number as the WAN port associated to the SDH Channel.

**Auto-Negotiation** It is possible to enable or disable the Auto-negotiation function at the physical layer of the LAN port by setting the mode to enabled respectively disabled. Setting the mode to disabled will be done when the TransLAN board interworks with equipments not supporting the auto-negotiation function. In this case the user can force the port speed (10 Mbit/s or 100 Mbit/s) and select the half duplex or full duplex mode.

**Ethernet Port Parameters** The following ethernet port parameters can be set when the auto-negotiation is disabled:

- port speed; set to 10 Mbit/s or 100 Mbit/s
- duplex mode; set to half duplex or full duplex
- pause mode; this fuction can be set to enabled or disabled only when the duplex mode is full duplex.

□

## Parameters for Provisioning SDH Channels

---

**SDH Channel** The name of the SDH channel associated with the WAN port is fixed: SDHChann2.x, where SDHChann2 refers to the slot and x is the number of the SDH channel. This is the same number as the WAN port associated to the SDH Channel.

**SDH Channel Capacity** The Capacity of the SDH channel. This can be VC-12, VC-12-2v,-3v,-4v,-5v, VC-3, VC-3-2v or none.

**SDH Channel TTP Mode** Indicates whether the signal on the TTP (Trail Termination Point) of the SDH channel will be monitored.

When *Monitored* alarms are generated related to the selected termination point. When *Not Monitored* no alarms are generated for the selected termination point.

**VC-TTP Name** The mapping relationship between WAN ports and TPs is fixed. On a LAN unit the TUs for the 4 ports are together within a single VC-4.

When a virtually concatenated VC-12 is used (capacity is 10 Mbit/s) then the first 4 TU-12s in the VC-4 are used and TU-12#1 (WAN port 1) to TU-12#4 (WAN port 4) are used.

When a virtually concatenated VC-3 is used (capacity on WAN port 1 is 100 Mbit/s) then the first 2 TU-3s in the VC-4 are used. In this situation the first 3 TU-12s in the VC-4 are used and TU-12#1 (WAN port 2) to TU-12#3 (WAN port 4) are used.

When a virtually concatenated VC-3 are used (capacity is 50 Mbit/s) and either TU-3#1 (WAN port 1) or TU-3#2 (WAN port 2) or both are used. In this situation the first 2 TU-12s in the VC-4 are used and TU-12#1 (WAN port 3) to TU-12#2 (WAN port 4) are used.

The name of the termination point associated with the selected SDH channel. This termination point is a VC-TTP. These TPs are used to make the cross connections. The TPs used are TP2.1100 and TP2.1200, where TP2 refers to the slot, the first digit of the number is always 1 and the other 3 digits is the klm number. .

**WAN capacity** The capacity of the WAN port is depending on which mode is selected as shown in the table.

Mode	Capacity WAN port 1	Capacity WAN port 2	Capacity WAN port 3	Capacity WAN port 4
1	100 Mbit/s	2 Mbit/s	2 Mbit/s	2 Mbit/s

<b>Mode</b>	<b>Capacity WAN port 1</b>	<b>Capacity WAN port 2</b>	<b>Capacity WAN port 3</b>	<b>Capacity WAN port 4</b>
2	50 Mbit/s	50 Mbit/s	2 Mbit/s	2 Mbit/s
3	2 Mbit/s	2 Mbit/s	2 Mbit/s	2 Mbit/s



## Section: Display Cross Connections

### Overview

---

**Purpose** To get an overview of the cross connections present in a network element.



## Procedure to Display Cross Connections

---

**When to use** To get an overview of the cross connections present in a network element for example when a new traffic plan is implemented or the existing traffic plan is changed.

**Before you begin** Before displaying cross connections determine the following:

- the capacity of the cross connection
- the connection type of the cross connection
- the termination points of the cross connection.

**Related information** Related procedures and information are:

- provision cross connections without protection.
- provision cross connections with SNC protection
- Traffic Provisioning Concepts.

**Procedure** Follow these steps to display the cross connect protection:

---

- 1 Select Provisioning -> Transmission -> AM1/AM1 Plus Cross Connects ->List.

**Result:**

The *EMS - Provisioned AM1/AM1 Plus Cross Connect List* window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous window which displays the requested information of the selected NE.

---

- 3 Select the Capacity for the to be viewed cross connection or select the option All to view all cross connections present in the NE.

**Result:**

The *EMS - Provisioned AM1 Cross Connections* window shows the cross connections according to the settings.

---

- 4 Click Close to exit.

END OF STEPS

---



## Parameters for Displaying Cross Connections

---

- Overview** The following parameters are used to display cross connections without protection.
- Capacity** The capacity of the cross connection: This can be VC-4, VC-3 or VC-12.
- Connection Type** The following types of cross connections are possible:
- <----->: an unprotected bidirectional cross connection or a working cross connection (SNC/N protection)
  - <- - - ->: a bidirectional protection cross connection (SNC/N protection)
  - -- - - ->: an unidirectional cross connection (loopback connection).
- From, To and Protection Termination Points** The cross connections are made between termination points. The *From*, *To* and *Protection* columns are used to view these termination points.
- For unprotected bidirectional cross connections it makes no difference which TP is in the From and which TP is selected in the To list.
  - For protected bidirectional cross connections the tributary TP is always in the To area. The TP used for protection is always in the Protection area.
  - For a loopback connection the termination points (TP) in the *From* and *To* columns are the same.
- A cross connection is made between termination points (TP). On the tributary units a VC-12 termination point is selected. On the line units, the TU number inside the VC-4 must be selected. The TU number consists of 3 numbers:
- k: the number of the TUG-3 inside the VC-4
  - l: the number of the TUG-2 inside the TUG-3
  - m: the TU-12 number inside the TUG-2.
- Example:



**Fixed** The cross connection is fixed by the network element hardware. These cross connections can not be modified. The *WaveStar*® AM-1 does not have fixed cross connections.

□

## Section: Provision Cross Connections without Protection

### Overview

---

**Purpose** To provide traffic over the network, cross connections must be provisioned in the network elements. The cross connection settings can be modified if the traffic demand changes. The following changes can be made:

- add a new cross connection.
- delete a cross connection.



## Procedure to Add Cross Connections

---

**When to use** When a new traffic plan is implemented or the existing traffic plan is changed.

**Before you Begin** To make a cross connection first determine the following:

- What is the capacity of the cross connection; VC-12, VC-3 or VC-4.
- Is the TUG Structure provisioned in such a way that the capacity can be selected? The procedure to check and change the TUG Structure is described in the section "Provision TUG Structure".
- Check if this cross connection require no protection
- Before *adding* a cross connection be sure to have information regarding the design of the transmission path.
- Before *deleting* a cross connection or part of a cross connection be sure to know whether the cross connection to be removed still carries traffic? If yes this traffic will be lost after removing the cross connection
- Deleting or changing a cross connection is traffic affecting if the current existing cross connection is carrying traffic.

**Related information** This section describes the provisioning of unprotected transmission paths. The provisioning of paths with SNC/N protection is described in the following separate section "Provision Cross Connections with SNC/N Protection".

The following procedures are used for test and maintenance of the provisioned path. These procedures are described in the chapter "Maintenance Settings for Transmission".

- port provisioning.
- provisioning termination points
- path trace provisioning.

More information about provisioning cross connection can be found in section Traffic Provisioning Concepts.

**Procedure** Use the following procedure to add a cross connection in the *WaveStar*® AM 1 plus network element.

---

- 1 Select Provisioning -> Transmission -> AM1/AM1 Plus Cross Connects.

**Result:**

The *EMS - Provisioned AMI and AMI Plus Cross Connect List* window is displayed.

.....

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous window which displays the requested information of the selected NE.

.....

- 3 Set the Operation to *Add* and select the *Capacity*.
- .....

- 4 Set the Protection Type to *Unprotected*.

The direction in the Direction field is always set to *Bidirectional*.

.....

- 5 Select the *Line Port* or *Cross Connect unit* in the upper list and select the VC or *TU* in the lower list for each termination point in the From and To columns.

If not all available termination points appear check if the TUG structure is provisioned to make the cross connections on the desired level. Change the TUG Structure if necessary. The procedure to change the TUG Structure is described in the section "Provision TUG structure".

.....

- 6 Click *Apply* and verify in the message box if the operation is successful (Operation Successful).

**Result:**

A cross connection is made between the termination points selected in the From and To columns.

.....

- 7 Click *Close* to return to the previous window.

**Result:**

The new cross connections appear in the *EMS - Provisioned AMI Cross Connect List* window.

.....

- 8 Click *Close* to exit.

END OF STEPS

.....



## Procedure to Delete a Cross Connection

---

**Procedure** Follow these steps to delete cross connections.

---

- 1 Select Provisioning -> Transmission -> AM1/AM1 Plus Cross Connects.

**Result:**

The *EMS - Provisioned AM1 and AM1 Plus Cross Connect List* window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous window which displays the requested information from the selected NE.

---

- 3 Set the Operation to *Delete* and select the *Capacity*.
- 

- 4 Select the *Line Port* or *Cross Connect unit* in the upper list and select the *VC* or *TU* in the lower list for each termination point in the From and To columns.

**Important!** If the cross connection to be deleted still carries traffic, this traffic will be lost.

---

- 5 Click *Apply* and verify in the message box if the operation is successful (Operation Successful).

**Result:**

The selected cross connection is deleted.

---

- 6 Click *Close* to return to the previous window.

**Result:**

The deleted cross connection no longer appears in the *EMS - Provisioned AM1 Cross Connect List* window.

---

- 7 Click *Close* to exit.

END OF STEPS

---



## Parameters for Provisioning Cross Connections without Protection

---

**Overview** The following parameters are used to provision cross connections without protection.

**Operation** In this field, select one of the operation options to perform provisioning cross connection without protection.

**Capacity** The capacity of the cross connection: This can be VC-4, VC-3 or VC-12.

**Direction** The following types of cross connections are possible:

- uni-directional cross connection or VCn loopback connection
- bi-directional cross connections.

**From and To Termination Points** The cross connections are made between the termination points. The From and To columns are used to select these termination points. For a VCn loopback connection the termination points in the From and To columns are the same.

For unprotected cross connections it makes no difference which TP is selected in the From list and which TP is selected in the To list.

The termination point is selected from a list of available termination points.

- In the Upper List all available Line Ports and Tributary unit are listed.
- In the Lower List all available VC's (Tributary) or TU's are listed.



## Section: Provision Cross Connections with SNC Protection

### Overview

---

**Purpose** To provide traffic over the network, cross connections must be provisioned in the network elements. The cross connection settings can be modified if the traffic demands changes. The following changes can be made:

- add a cross connection with SNC protection
- add protection to or remove protection from an existing cross connection
- delete a cross connection with SNC protection



## Procedure to Add Cross Connections with SNC Protection

---

**When to use** When a new traffic plan is implemented or the existing traffic plan is changed.

**Before you begin** To make a cross connection first determine the following:

- What is the capacity of the cross connection? VC-12, VC-3 or VC-4?
- Is the TUG Structure provisioned in such a way that the capacity can be selected? The procedure to check and change the TUG Structure is described in the section "Provision TUG Structure".
- Does the cross connection require SNC/N protection or is it unprotected ?
- Between which termination points is the cross connection made and which termination point is used for the SNC/N protection path
- Before *adding* a cross connection or a part of a cross connection be sure to have all information regarding the design of the transmission path
- Before *deleting* a cross connection or part of a cross connection be sure that the cross connection to be removed doesn't still carry traffic? After removing the cross connection this traffic will be lost
- Deleting or changing a cross connection is traffic affecting if the current existing cross connection is carrying traffic.

**Related information** This section describes the provisioning of SNC protected transmission paths. The provisioning of paths without protection is described in the following separate section:

- section "Provision Cross Connections without Protection"

The following procedures are used for test and maintenance of the provisioned path.

- port provisioning.
- provisioning termination points
- path trace provisioning

These procedures are described in the chapter "Maintenance Settings for Transmission".

**Procedure** Use the following procedure to add a cross connection in the  
*WaveStar* ®AM 1 network element.

---

- 1 Select Provisioning -> Transmission -> AM1/AM1 Plus Cross  
Connects.

**Result:**

The *EMS - Provisioned AM1 and AM1 Plus Cross Connect List*  
window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog  
button. A list of possible NEs then appears in the *EMS- NE Selection*  
*Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous window which  
displays the requested information of the selected NE.

---

- 3 Set the Operation to *Add* and select the *Capacity*.
- 

- 4 Set the Protection Type to *Protected*.

The direction in the Direction field is always set to *Bidirectional*.

---

- 5 Select the *Slot* or *Port* in the upper list and select the VC or *TU* in the  
lower list for each termination point in the From, To and Protection  
columns.

If not all available termination points appear check if the TUG  
structure is provisioned to make the cross connections on the desired  
level. Change the TUG Structure if necessary. The procedure to  
change the TUG Structure is described in the section "Provision TUG  
structure".

---

- 6 Click *Apply* and verify in the message box if the operation is  
successful (Operation Successful).

**Result:**

A cross connection is made between the termination points  
selected in the From, To and Protection columns.

---

- 7 Click *Close* to return to the previous window.

**Result:**

The new cross connections appear in the *EMS - Provisioned  
AMI Cross Connect List* window.

- 
- 8** Click Close to exit.

END OF STEPS

---



## Procedure to Add Protection to an Unprotected Cross Connection

---

**When to use** When a new traffic plan is implemented or the existing traffic plan is changed.

**Before you begin** To make a cross connection first determine the following:

- What is the capacity of the cross connection? VC-12, VC-3 or VC-4.?
- Is the TUG Structure provisioned in such a way that the capacity can be selected? The procedure to check and change the TUG Structure is described in the section "Provision TUG Structure".
- Does the cross connection require SNC/N protection or is it unprotected ?
- Between which termination points is the cross connection made and which termination point is used for the SNC/N protection path
- Before *adding* a cross connection or a part of a cross connection be sure to have all information regarding the design of the transmission path
- Before *deleting* a cross connection or part of a cross connection be sure that the cross connection to be removed doesn't still carry traffic? After removing the cross connection this traffic will be lost
- Deleting or changing a cross connection is traffic affecting if the current existing cross connection is carrying traffic.

**Related information** This section describes the provisioning of SNC protected transmission paths. The provisioning of paths without protection is described in the following separate section:

- section "Provision Cross Connections without Protection"
- The section "Provision TUG Structure" describes how to check and if necessary change the TUG Structure.

The following procedures are used for test and maintenance of the provisioned path.

- port provisioning.
- provisioning termination points
- path trace provisioning

These procedures are described in the chapter "Maintenance Settings for Transmission".

Procedure to Add Protection to an  
Unprotected Cross Connection

**Procedure** Follow these steps to add protection to an unprotected cross connection.

---

- 1 Select Provisioning -> Transmission -> AM1/AM1 Plus Cross Connects.

**Result:**

The *EMS - Provisioned AM1 and AM1 Plus Cross Connect List* window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous window which displays the requested information of the selected NE.

---

- 3 Select an unprotected cross connection from the list and click Edit.

**Result:**

The *EMS - Edit Provisioned AM 1 and AM1 Plus Cross Connections* window appears. The selected cross connection is preselected in the *To* and *From* list.

---

- 4 Set the Protection Type to *Protected*.

The direction in the Direction field is always set to *Bidirectional*.

---

- 5 Select a termination point in the *Protection* column, click Apply and verify in the message box if the operation is successful (Operation Successful).

**Result:**

The cross connection appears with protection in the *EMS-Provisioned AM 1 Cross Connect List* window

---

- 6 Click Close to exit.

END OF STEPS

---



## Procedure to Remove a Protection from an SNC Protected Cross Connection

---



### WARNING

*Removing the protection of the cross connection degrades the transmission path. The transmission path is no longer protected. A failure in the signal results in loss of traffic.*

**Procedure** Follow these steps to remove the protection of an existing SNC protected cross connections

---

- 1 Select Provisioning -> Transmission -> AM1/AM1 Plus Cross Connects.

**Result:**

The *EMS - Provisioned AM1 and AM1 Plus Cross Connect List* window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous window which displays the requested information of the selected NE.

---

- 3 Select an SNC protected cross connection from the list and click Edit.

**Result:**

The *EMS - Edit Provisioned AM1 and AM1 Plus Cross Connect* window appears. The selected cross connection is pre-selected in the *From*, *To* and *Protection* lists.

---

- 4 Select *Delete Protection* in the Operation area. De-select the termination point in either the *From* or *Protection* list. Low order cross connections (VC-12 or VC-3 level) must be deselected in the lower list, high order cross connections (VC-4 level) in the upper list.

**Important!** When removing the protection from low order cross connections, check if it the high order cross connection made from the

Procedure to Remove a Protection from an  
SNC Protected Cross Connection

protection line port to the cross connect unit should also be removed  
(delete the VC-4 cross connection).

---

- 5 Click **Apply** and verify in the message box if the operation is successful (Operation Successful).

**Result:**

The cross connection appears in the *EMS-Provisioned AMI Cross Connect List* window without protection.

---

- 6 Click **Close** to exit.

END OF STEPS

---



## Procedure to Delete a Cross Connection with SNC Protection

---

**Procedure** Follow these steps to delete cross connections.

---

- 1 Select Provisioning -> Transmission -> AM1/AM1 Plus Cross Connects.

**Result:**

The *EMS - Provisioned AM1 and AM1 Plus Cross Connect List* window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous window which displays the requested information from the selected NE.

---

- 3 Select Delete in the Operation field and the cross connection to be deleted from the list and click Edit.

**Important!** If the cross connection to be deleted still carries traffic, this traffic will be lost.

**Result:**

The *EMS - Edit Provisioned AM1 and AM1 Plus Cross Connect* window appears. The delete option is preselected.

---

- 4 Click Apply and verify in the message box if the operation is successful (Operation Successful).

**Result:**

The selected cross connection is deleted.

---

- 5 Click Close to return to the previous window.

**Result:**

The deleted cross connection no longer appears in the *EMS - Provisioned AM1 Cross Connect List* window.

---

- 6 Click Close to exit.

END OF STEPS


---



## Parameters for Provisioning Cross Connections with SNC Protection

---

- Overview** The following parameters are used to provision cross connections with protection.
- Operation** In this field, select one of the operation options to perform provisioning cross connection with protection.
- Capacity** The capacity of the cross connection: This can be VC-4, VC-3 or VC-12.
- Connection Type** The following types of cross connections are possible:
- *From <-> To*: an unprotected cross connection
  - *From <-> To <-> Protection*: a cross connection with SNC/N protection.
- From, To and Protection Termination Points** The cross connections are made between termination points. The *From*, *To* and *Protection* columns are used to select these termination points.
- For protected cross connections the tributary TP must always be in the To area. The TP used for protection is always selected in the Protection area
- The termination point is selected by the *Slot* and *Port* where the termination point belongs to. The *AU4#* is 1 when the line port carry STM-1 signals and 4 when the line port carry STM-4 signals.
- In the Upper List (Tributary/Line) a line port or tributary unit can be selected from a list of available ports/units.
  - In the Lower List (VC/TU) a VC (on tributary ports) or TU (on line ports) is selected from a list of available VC/TUs.
- Example:



□

## Section: View SNC Protection

### Overview

---

**Purpose** To view the SNC connectivity Information in the selected network.



## Viewing SNC Information

---

**When to use** To view the SNC connectivity information in the selected network. The SNC connectivity information can be used to check line capacity in the ring and to determine if existing protection is provisioned correctly.

**Before you begin** NO prerequisites or precautions are needed when performing this procedure.

**Related information** Section Traffic Provisioning Concepts provides information about SNC protection.

### Procedure

---

- 1 Select *Protection -> Transmission -> AM-1 VC# SNC*.

**Result:**

The *EMS - Provisioned AM-1 SNC Protection Information* window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous screen which will display the requested information of the selected NE..

---

- 3 Click *Close* to exit this window.

**Result:**

The window closes.

END OF STEPS

---



## Parameters for Viewing SNC

---

- Selection** Displays the selected Provisioned NE and its configuration.
- Capacity** This selection allows the user to filter on particular cross connect capacities. Values are: All, VC-4, VC-3 and VC-12.
- SNC list** Lists the SNC pairs and switch state. Displays the current state of the protection switch.



## Section: View MSP Protection

### Overview

---

**Purpose** To view the MSP connectivity information for established MSP protection pairs in the selected network element.



## Viewing MSP Information

---

**When to use** To view the MSP connectivity information for established MSP protection pairs in the selected network element. The MSP connectivity information can be used to check availability and to determine if existing protection is provisioned correctly according the transmission plan.

**Before you begin** No prerequisites or precautions are needed when performing this procedure.

**Related information** Section Traffic Provisioning Concepts provides information about MSP protection.

### Procedure

---

- 1 Select *Protection -> Transmission -> MSP*.

**Result:**

The *EMS - MSP Protection Information* window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous screen which will display the requested information of the selected NE.

---

- 3 Click *Close* to exit this window.

**Result:**

The window closes.

END OF STEPS

---



## Parameters for viewing MSP

---

<b>Selection</b>	Displays the selected Provisioned NE and its configuration.
<b>MSP list</b>	Lists the MSP protection pairs and the Operation State. The operation state indicates the current operation state for MSP pair.
<b>Communication Mode</b>	Displays whether the protection is Unidirectional or Bidirectional. In the case of failure with Unidirectional mode the receive side switches. In the Bidirectional mode both sides are switched. When the Unidirectional mode is displayed the Far End selections are greyed out.
<b>Service Reference</b>	Displays what the service of the selected reference is. This can be Working, Protection or Unclear.
<b>Switch State</b>	Shows the current state of the MSP pair.
<b>Wait to Restore Time</b>	If MSP mode is ETSI, then WTR is the wait to restore time after the failure on the active section has cleared in the revertive mode. Values are 0..60.
<b>Near End</b>	Displays the service reference at the Near end. This can be Working, Protection or Unclear.
<b>Last switch request</b>	Displays the last switch MSP request.



## Section: Edit MSP Protection

### Overview

---

**Purpose** To set or change protection on a point-to-point connection.



## Editing MSP Information

---

**When to use** To set or change protection on a point-to-point connection. MSP protection should be established when the transmission plan calls for a protection of a particular point to point connection.

**Before you begin** Before editing MSP information determine the following:

- A protected switch is always traffic affecting.
- If the physical timing reference of units is assigned to a single logical timing references then these units are no longer available for MSP protection.
- If a port loopback is set on a port, then this port is not available for MSP protection.
- MSP pair must be present and physically set up on the Near End and Far End Network Elements. In other words, a MSP card inserted and fiber pairs connected on both Network Elements.

**Related information** Related procedures and information are:

- Slot provisioning
- Port provisioning
- Section Traffic Provisioning Concepts provides information about MSP protection.

### Procedure

---

1 Select *Protection -> Transmission -> MSP*.

**Result:**

The *EMS - MSP Protection Information* window is displayed.

---

2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS - NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous screen which will display the requested information of the selected NE.

---

3 Click *Edit*.

**Result:**

The *EMS - Edit MSP Protection Information* window is displayed.

- 
- 4 First select Add, Modify or Delete and make a selection from the list.

**Result:**

The parts that are not applicable for a certain selection are greyed out.

- 
- 5 Add: Allows the creation of a MSP pair (selecting the working and protection section) and filling in the MSP parameters. Modify: Allows only entering WTR for a selected pair. Delete: Deletes the selected pair. Make the selections with usage of the above parameter information and click OK.

**Result:**

If Delete is chosen the message: This operation may be service affecting will be displayed. After confirming the operation status can be verified in the message box. If the operation is accepted the message Operation Successful will be displayed. Otherwise Operation failed will be displayed. The window will close and returns to the previous screen.

- 
- 6 Click Close to exit this window.

**Result:**

The window closes.

END OF STEPS



## Parameters for Editing MSP

---

**Operation** The possible operations which can be performed on MSP protection. Values are Add, Modify, Delete or Switch.

**MSP list** Lists the MSP protection pairs and the Operation State. The operation state indicates the current operation state for MSP pair.

**Working/Protection Section** Working section shows the available ports on assigned cards supporting MSP that can be protected. Protection section will be filled in with the associated protection port once the working section has been selected.

**Communication Mode** Displays whether the protection is Unidirectional or Bidirectional. In the case of failure with Unidirectional mode the receive side switches. In the Bidirectional mode both sides are switched. When the Unidirectional mode is displayed the Far End selections are greyed out.

**Switch Mode** Displays whether the protection is Revertive or Non-Revertive. In the case of failure with Revertive mode the traffic switches to the protected line and switches back when the failure is solved. In the Non-Revertive mode the traffic switches to the protected line and remains even when the failure is solved.

**Switch Request** Selection of the switch requests that can be performed on the MSP.

**Wait to Restore Time** If MSP mode is ETSI, then WTR is the wait to restore time after the failure on the active section has cleared in the revertive mode. Values are 0..60.





# 6 Maintenance Settings for Transmission

## Overview

---

**Purpose** In this chapter each section describes a task which can be executed to test or monitor an existing path or to perform maintenance on an existing path. In this chapter it is assumed that a path is already created. The chapter "Path Provisioning and Protection" describes how to create these transmission paths.

**Objective** To set up the network element for testing, monitoring and maintenance of the transmission paths.

**Outcome** The outcome of the maintenance settings can be:

- traffic that is transported through the network element can be tested and/or monitored
- if protection is used, a switch can be performed when a path has to be rerouted due to maintenance activities
- alarm messages come up if the traffic contains errors.

**Intended Use** The following table describes the tasks that are described in this chapter.

Task	Purpose
Port Provisioning	Configures, whether input signals are monitored or not, specifies the type of signal
Provision Termination Points	Configures the logical ports
Provision Path Trace	Test the established path

<b>Task</b>	<b>Purpose</b>
Provision Signal Degrade Thresholds	Define the values at which the signal is considered of degraded quality, so that an alarm is raised or a SNC protection switch is performed
Switch SNC Protection	Switch traffic for maintenance
Switch MSP	Switch traffic for maintenance

Each task is described in a separate section. The first section of this chapter describes the concepts of the maintenance settings for transmission.



## Section: Port Provisioning

### Overview

---

**Purpose** The purpose of port provisioning is to get an overview of all the physical ports of the network element or a specific unit, and to change the settings of these ports. The provisioning of timing ports is described in the chapter "Provisioning Timing" of this guide.



## Procedure for Port Provisioning

---

- When to use** Use this procedure to:
- know which ports are provisioned in an NE and how they are provisioned
  - change the port mode for the alarm handling
  - enable or disable test loops.

- Before you begin** Before starting to modify NE ports it is assumed that:
- information about the port is available: what is the port name? on which unit is it?
  - there is no traffic on the ports that you want to test with a loopback.
  - take care that loopbacks are disabled for normal operations. No normal traffic is possible when a loopback is enabled.

- Related information** For more information reference is made to:
- Provisioning timing ports
  - Traffic maintenance concepts in chapter Concepts.

**Procedure** The following procedure describes the steps to provision a port of a network element.

---

- 1 Select *Provisioning -> Equipment -> Port*.

**Result:**

The *EMS - Provisioned NE Port Information* window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and the *EMS - Provisioned NE Port Information* window lists all ports of the selected NE.

---

- 3 Select a port from the *EMS - Provisioned NE Port Information List* and click Edit. Only one port can be selected at the same time, therefore each port must be provisioned separately.

**Result:**

The *EMS - Edit Provisioned NE Port Information* window is displayed.

---

- 4 Set the desired parameters for the selected port. Then, click OK.

**Important!** If Inloop is enabled, normal traffic via this port is no longer possible. Only enable Inloop or Outloop for testing.

**Result:**

The status can be verified in the message box. If the operation is accepted the message Operation Successful will be displayed. The window closes.

---

- 5 Click Cl ose to exit the *EMS - Provisioned NE Port Information* window

END OF STEPS

---



## Parameters for Port Provisioning

**Introduction** For each port type there is a special window to provision the ports. The WaveStar® AM 1 always has two STM-1 or STM-4 line ports and sixteen 2Mbit/s ports. If an additional tributary board is installed the following ports can also be available:

- 1.5 Mbit/s
- 2 Mbit/s ports, which can be used for ISDN PRI interface
- 34 Mbit/s ports
- 45 Mbit/s ports
- X.21 ports
- Ethernet ports
- STM-1 ports

### Port Types

The following table shows the port types and which parameters are valid for each port.

Parameters	2 Mbit/s	34 Mbit/s	45 Mbit/s	X.21	Ethernet	STM 1 (trib)	STM 1 or 4 (line)
Physical Interface Type	—	—	—	—	—	—	x
Port Mode	x	x	x	x	x	x	x
Auto Mode Time	x	x	x	x	x	x	x
Loop-back State	x	x	x	x	—	—	—
Cable length	x	—	—	x	—	—	—
Auto-negotiation	—	—	—	—	x	—	—
Ethernet port parameters	—	—	—	—	x	—	—

**Port** The name of the physical ports consist of two parts separated by a dot. The first part is related to the (logical) slot name, the second part is the port number within that slot.

Example: LP2.1, TP1.3, LAN2.1

Between brackets the type of signal, for which the port is an interface point, is indicated.

Example: 2 Mbit/s, 34 Mbit/s, STM-1.

**Port Mode** The *Port Mode* controls whether input signals should be monitored or not monitored. The following values can be set.

Value	Description
Monitored	The port is configured to provide service and the port signal is monitored.
Auto	The port is configured not to provide service yet. Use this mode when the signal source in the remote NE is not operational yet. As soon as the NE establishes the continuous presence of a fault-free signal for a certain period ( <i>Port Mode Time</i> ), the port automatically changes to <i>Monitored</i> .
Not Monitored	The port is configured to not monitor the port signal on the port. No alarms are generated for this port. If there still is a signal present on the not monitored port it is possible to receive a Not Expected Input Signal (NES) alarm. The alarm status of NES must then be provisioned to be <i>Reported</i> .

**Auto Mode Time** The time in minutes during which a fault-free signal must be received continuously before the *Port Mode* switches from *Auto* to *Monitored*.. The default is 10 minutes.

The *Port Mode Time* can be set from 0-30 minutes in steps of 1 minute.

**Loopback State** Loopbacks are used to test the physical ports.

- No Loop is set for normal use of the physical port. The port is not looped back for testing
- An Inloop is a loopback that routes an input signal, received at the physical port, directly back to its corresponding output without altering the signal format. The inloop can be used to test the connectors. Only one inloop can be set at the same time.
- An Outloop is a loopback that routes an output signal, coming from the cross connect, at the physical port back to the corresponding input port. The Outloop can be used to test the signal passes through the system.

**Cable Length** For 1.5 Mbit/s (DS1) and 45 Mbit/s (DS3) signals.

For 1.5 Mbit/s signal a cable length of 0 to 200 metres can be provisioned in steps of 40 metre.

For 45 Mbit/s a cable length can be up to 136 metres (450 feet). Two levels can be provisioned, covering the following cable lengths:

- 0 - 35 metres (0-120 feet)
- 35 - 136 metres (120 - 450 feet).

**Auto-Negotiation** It is possible to enable or disable the Auto-negotiation function at the physical layer of the LAN port by setting the mode to enabled respectively disabled. Setting the mode to disabled will be done when the TransLAN board interworks with equipments not supporting the auto-negotiation function. In this case the user can force the port speed (10 Mbit/s or 100 Mbit/s) and select the half duplex or full duplex mode.

**Ethernet Port Parameters** The following ethernet port parameters can be set when the auto-negotiation is disabled:

- port speed; set to 10 Mbit/s or 100 Mbit/s
- duplex mode; set to half duplex or full duplex
- pause mode; this fuction can be set to enabled or disabled only when the duplex mode is full duplex.



## Section: Provisioning Termination Points

### Overview

---

**Purpose** The termination points enable the user to set or view parameters derived from data stored in the overhead bytes of the signals.



## Procedure to Provision Termination Points

---

**When to use** Termination points should be set after provisioning the transmission path according to the transmission plan.

**Before you begin** If the Trace Identifier Mismatch detection (TIM) is enabled, traffic will be lost when a mistake in the trace string is made. Upon mismatch Alarm Indication Signal (AIS) is inserted in the downstream signal and Remote Defect Indicator (RDI) is inserted in the upstream signal

**Related information** The following procedures and information are related:

- Provision Cross Connections: in "Path Provisioning and Protection" chapter
- Path Trace Provisioning
- Provision Degraded Signal Thresholds
- Section Traffic Maintenance Concepts in chapter Concepts.

**Procedure** Follow this procedure to provision termination points. The following termination point types can be provisioned: PDH signal, VC-12, VC-3, VC-4, TU-12, TU-3, AU-4, RS and MS.

---

- 1 Select Provisioning -> Transmission -> Terminations Points and then select one of the listed signals.

To provision RS and MS termination points select RS and MS.

**Result:**

The *EMS - Provisioned NE TP Information* window is displayed.

---

- 2 To select a port or to switch to another port or to another NE, click the selection dialog button. Select the correct slot, port and NE in the *Provisioned Port Selection Dialog* window

**Result:**

The *EMS - Provisioned NE TP Information* window appears with a list of termination points on the selected port.

---

- 3 Select the type of termination point in the *TP Type* box and the termination point to be provided from the TP list.

**Result:**

The information about the selected termination point is displayed.

---

- 4 Check the current settings and click *Edit* to modify it.

**Result:**

The *EMS - Edit Provisioned NE Termination Point Information* window appears.

---

- 5 Make the required changes and Click *OK*.

**Result:**

A confirmation window appears, stating that changes in this window may be traffic affecting.

---

- 6 Click *Yes* to confirm.

**Result:**

The *Edit* window closes and the changed termination point settings are displayed in the *EMS - Provisioned NE Termination Point Information* window.

---

- 7 Click *Close* to exit.

END OF STEPS

---



## Parameters for Provisioning Termination Points

---

**Introduction** The following Termination Points can be provisioned for the WaveStar® AM 1plus: VC-12, VC-3, VC-4, TU-12, TU-3, AU4 and PDH signal.

The following list shows which parameter can be set for which termination points

- TP mode: VC-12, VC-3, VC-4 and PDH signal
- Path trace: VC-12, VC-3, VC-4, TU-12, TU-3.
- Signal label: VC-12, VC-3, VC-4
- TUG structure: VC-4
- Degraded Signal Threshold: VC-12, VC-3, VC-4, TU-12, TU-3


**Selected TP** The name of the selected termination point.

The termination point is selected by the *Slot* and *Port* where the termination point belongs to. The AU4# is 1 when the line ports carry STM-1 signals and 4 when the line ports carry an STM-4 signal.

The name of the termination points consist of the physical port name (slot name and port number) followed by the AU-4 number and for low order signals, the VC number (VC-12 or VC-3). The VC number consists of:

- the number of the TUG-3 inside the VC-4
- the number of the TUG-2 inside the TUG-3
- the TU-12 number inside the TUG-2.

Example:



**TP Type** The termination point type indicates where the signal is terminated.

Example: VC-12, TU-3, AU-4

**TP Mode** Indicates whether the signal on the termination point will be monitored.

When *Monitored* alarms are generated related to the selected termination point. When *Not Monitored* no alarms are generated for the selected termination point.

**Path Trace** This area is used to provision a path trace. Provisioning a path trace is described in the section "Path Trace Provisioning".

**TP Numbering** The Transmitted and Accepted (received) sequence number of a VC-3 that is part of a virtually concatenated VC-3 (VC-3-2v). The sequence number is either 1 or 2. The VC-3-2v is used to map Ethernet packets over SDH signals. The concept section of this chapter describes virtually concatenated VC-3s.

**Signal Label** The signal label is part of the path overhead of a VC-n signal and indicates what type of signal is carried by the container.

Example: Unequipped, Asynchronous, TUG structure, ATM

- Signal Label Transmit is the signal label of the transmitted signal
- Signal Label Accepted is the signal label of the received signal
- Signal Label Accepted Status is the status of the received signal label.

Example: Normal, Unavailable, Unequipped, AIS

**TUG Structure** Displays the TUG structure of the VC-4. This is described in the section "Provisioning TUG Structure".

**Degraded Signal Threshold** Indicates the number of errors (EB: Errored Blocks) that are allowed to occur during the given period before the signal is declared degraded. If this number is exceeded and the *Port Mode* is set to Monitored, a signal degrade alarm is generated. A choice can be made between 2 thresholds. The section "Provision Degraded Signal Thresholds" describes the setting of these thresholds.

□

## Section: Path Trace Provisioning

### Overview

---

**Purpose** The purpose of provisioning a path trace is to make sure the traffic is not delivered to the wrong destination.



## Procedure to Provision a Path Trace

---

**When to use** A path trace can be set at any time. Path trace provisioning can be done once, after provisioning a path, to check whether the path is correctly provisioned. Path trace can also be used continuously to check if the traffic is delivered to the correct destination. When provisioning a path trace on a path with traffic on it, take notice of the precautions.

**Before you begin** Before provisioning a path trace determine the following:

- in which termination point is the path trace inserted and in which termination points is it monitored?
- which label is used as path trace?
- if the Trace Identifier Mismatch (TIM) detection is enabled, traffic will be lost when a mistake in the trace string is made. Upon mismatch, an Alarm Indication Signal (AIS) is inserted in the downstream signal and Remote Defect Indicator (RDI) is inserted in the upstream signal.

**Related information** Related procedures and information are:

- Provisioning Cross Connections in the chapter Path Provisioning and Protection
- Provisioning Termination Points
- Traffic Maintenance Concepts.

**Procedure** Use the following procedure to provision a path trace. For the *WaveStar*® AM 1 plus a path trace can be set on the VC-12, VC-3 and VC-4 and STM-N signals.

---

- 1 Select Provisioning -> Transmission -> Termination Points and then select the termination point type

**Result:**

The *EMS - Provisioned NE TP Information* window is displayed.

---

- 2 To select a port or to switch to another port or to another NE, click the selection dialog button. Select the correct slot, port and NE in the *Provisioned Port Selection Dialog* window

**Result:**

The *EMS - Provisioned NE Termination Point Information* window appears with a list of termination points on the selected port.

---

- 3 Select the type of termination point in the *TP Type* box and the termination point, where the path trace is inserted or received, from the list.

**Result:**

The path trace information of the selected termination point is displayed in the *path trace* area of the *EMS - Provisioned NE TP Information* window.

---

- 4 Check the current settings and click *Edit* to modify them.

**Result:**

The *EMS - Edit Provisioned NE Termination Point Information* window appears.

---

- 5 Fill in the path trace (API transmit and/or API expected) and/or set the other parameters. Click *OK*.

**Important!** If the Trace Identifier Mismatch (TIM) detection is enabled, traffic will be lost when a mistake in the trace string is made. Upon mismatch, an Alarm Indication Signal (AIS) is inserted in the downstream signal and Remote Defect Indicator (RDI) is inserted in the upstream signal

**Result:**

A confirmation window appears, stating that changes in this window may be traffic affecting. If the Transmit and/or Expected Access Point Identifier are blank another confirmation window is opened.

---

- 6 Click *Yes* to confirm.

**Result:**

The *Edit* window closes and the changed path trace settings are displayed in the *EMS - Provisioned NE Termination Point Information* window.

---

- 
- 7** Check if the Access Point Identifier Accepted equals the Access Point Identifier Expected. Click Close to exit.

END OF STEPS


---



## Parameters for Path Trace Provisioning

**Introduction** To make sure the traffic is not delivered to the wrong destination, a path trace can be set. A label (TI), for example a word, is inserted in the path overhead. To check if the path is correctly provisioned the received path trace is compared with the expected value. For the *WaveStar*® AM 1 a path trace can be set on the STM-N, VC-12, VC-3 and VC-4 signals.

Example of a Path Trace



**Trace Identifier (TI)** The Trace Identifier (TI) is inserted in the path overhead. For STM-N signals the J0 byte in the RSOH is used, for VC-4/VC-3 signals byte J1 is used and for VC-12 signals byte J2 is used. For the TI a 16 byte frame is composed which includes one CRC-7 byte for error detection. therefore the TI can be 15 bytes long (15 characters or 30 hexadecimal digits). There are 3 TI values:

- **TI Transmit:** The TI inserted in the path overhead is sent to the other side of the path.
- **TI Expected:** The TI expected from the other side of the path.
- **TI Accepted:** The TI actually received.

**TI Mode** The TI Mode can be set for TI Transmit and *TI Expected* and can have the following values:

- **Specific String:** The TI is a string with maximum length of 15 bytes. This string is identified in the Access Point Identifier (API). In *Alphanumeric* mode any alphanumeric character can be used, in *HEX* mode only 00 .. 7F can be used.
- **Non Specific Byte:** The Trace Identifier matches if it is any constant byte value within the range 00 .. FF. If the byte value is not constant, Trace Identifier Mismatch is assumed. No check between Accepted API and Expected API is performed.

**Access Point Identifier** The Access Point Identifier (API) is the label that is inserted in the path overhead. This is not valid if the *TI Mode* is set to *Non Specific Byte*.

There are 3 API values:

- Access Point Identifier Transmit: The API that is sent to the other side of the path.
- Access Point Identifier Expected: The API expected from the other side of the path.
- Access Point Identifier Accepted: The API actually received.

**Access Point Identifier Format** The format can be set for Access Point Identifier Transmit and Access Point Identifier Expected.

The format can be set to alphanumeric (*ASCII*) or hexadecimal (*HEX*).

**TIM Detection** TIM is Trace Identifier Mismatch comparison between the expected and accepted API. If this is enabled and the APIs do not match, a Path Trace Identifier Mismatch alarm is raised.

**Important!** If the Trace Identifier Mismatch (TIM) detection is enabled, traffic will be lost when a mistake in the trace string is made. Upon mismatch, an Alarm Indication Signal (AIS) is inserted in the downstream signal and Remote Defect Indicator (RDI) is inserted in the upstream signal



## Section: Provision Degraded Signal Thresholds

### Overview

---

**Purpose** The purpose of provisioning degraded signal thresholds is to define how many errors a signal may have before it is considered degraded. A degraded signal causes a *Moderate Block Error Rate* alarm. A degraded signal can cause an SNC/N protection switch if the path for that signal is SNC/N protected, or an MSP switch if MSP protection is used.



## Procedure to Select a Threshold Value for a Signal

---

**When to use** Changing the degraded signal thresholds is only done according to a change in the transmission plan.

**Before you begin** Before you begin determine the following:

- The threshold values (number of errored blocks and number of seconds) must be known.
- Changing the values of the Signal Degrade Thresholds can degrade the transmission path. Depending on these values alarms are generated and SNC/N or MSP protection switches are made.

**Related information** Related Procedures are:

- Port Provisioning
- Provisioning Termination Points
- Section Traffic Maintenance Concepts in chapter Concepts.

**Procedure** This procedure describes how to select a threshold value for a specific signal. A choice can be made between two threshold values. Modifying the values of these two thresholds is described in the "Procedure to Set or Modify the Threshold Values".

---

- 1 Select Provisioning -> Transmission -> Termination Points and then select the termination point type for which the signal threshold value must be selected.
- 
- 2 To select another NE, click the selection dialog button. Select the correct NE in the *Provisioned Port Selection Dialog* window and click Edit.

**Result:**

The *EMS - Edit Provisioned NE RS and MS Termination Point Information* window appears for the STM-1 or STM-4 signal, the *EMS - Edit Provisioned NE Termination Point Information* window for the VC-4, VC-3, TU-3, VC-12 and TU-12 termination points and the *EMS - Edit Provisioned NE PDH Information* window for the PDH signal.

---

- 3 In the Degraded Value Selection box make a choice between Value 1 and Value 2 and click OK.

Procedure to Select a Threshold Value for a  
Signal

**Result:**

The new threshold is set and its values are displayed in the  
concerning windows.

- 
- 4** Click Cl ose to exit.

END OF STEPS



## Procedure to Set or Modify the Threshold Values for a Signal

---

**When to use** Changing the degraded signal thresholds is only done according to a change in the transmission plan.

**Before you begin** Before you begin determine the following:

- The threshold values (number of errored blocks and number of seconds) must be known.
- Changing the values of the Signal Degrade Thresholds can degrade the transmission path. Depending on these values alarms are generated and SNC/N or MSP protection switches are made.

**Related information** Related Procedures are:

- Port Provisioning
- Provisioning Termination Points
- Section Traffic Maintenance Concepts in chapter Concepts.

**Procedure** This procedure describes how to set or modify the threshold values 1 and 2 for a specific signal.

---

- 1 Select Provisioning -> Transmission -> Termination Points and then select Signal Degrade Threshold.

**Result:**

The *EMS - Signal Degrade Thresholds* window appears.

---

- 2 To select another NE, click the selection dialog button and select the correct NE in the *Provisioned NE Selection Dialog* window

**Result:**

The *EMS - Signal Degrade Thresholds NE* window appears with a list of termination points on the selected NE.

---

- 3 Select the termination point type for which the threshold values must be set or modified and click Edit.

**Result:**

The *EMS - Edit Signal Degrade Thresholds* window appears.

---

- 4 Fill in the Value One and Value Two fields the amount of Errored Blocks/Second and the Time Interval in seconds and click OK.

Procedure to Set or Modify the Threshold  
Values for a Signal

**Important!** An error message popped up if values entered are out of range.

---

**5** Click Cl ose.

**Result:**

The new threshold is set and its values are displayed in the *EMS - Signal Degrade Thresholds* window.

---

**6** Click Cl ose to exit.

END OF STEPS

---



## Parameters for Provisioning Degraded Signal Thresholds

**Introduction** A degraded signal is a signal with more Errored Blocks (EB) per second than the defined *Errored Blocks* value during a period of consecutive seconds. A degraded signal causes a *Moderate Block Error Rate* alarm. A degraded signal can cause an SNC/N or MSP protection switch.

**Degraded Values Selection** Two Thresholds can be defined for each signal level to declare a signal degraded. The thresholds are called *Value 1* and *Value 2*. A choice between these two thresholds can be made in the following windows:

- the *EMS - Edit Provisioned NE RS and MS Termination Point Information* window for the STM-1 and STM-4 signals
- the *EMS - Edit Provisioned NE Termination Point Information* window for the VC-4, VC-3 and VC-12 signal.
- the *EMS - Edit Provisioned NE PDH Information* window for PDH signals (ISDN PRI interfaces).

**TP Type** The termination points on which the degraded signal thresholds can be set are *RS and MS* of the STM-1 signal and STM-4 signal, *VC-4* , *VC-3* , *TU-3*, *VC-12* or *TU-12*.

**Errored Blocks /Second** In the termination points the signal is terminated and a Bit Interleaved Parity (BIP) check is performed on the received data. The result of this BIP check is compared to the values in the B or V5 bytes in the overhead of the signal. When there is a difference, an errored block is detected. The *Errored Blocks/Second* value determines how many Errored Blocks are allowed per second, before the second is declared a bad second.

The following table shows the range for the values for each signal type.

Signal Type	Range
MS for STM-N (N=1 or 4)	1 to $N \times 24 \times 8000$ EB/s
AU-4, AU-4c, VC-4	1 to 8000 EB/s
TU-3, VC-3	1 to 8000 EB/s
TU-12, VC-12, VC-11	1 to 2000 EB/s
2 Mbit/s (PDH to SDH)	1 to 1000 EB/s
2 Mbit/s (SDH to PDH)	1 to 1000 EB/s

Section: Provision Degraded Signal  
Thresholds  
Parameters for Provisioning Degraded  
Signal Thresholds

**Seconds** The number of consecutive bad seconds to declare a signal degraded.



## Section: Switch SNC Protection

### Overview

---

**Purpose** To switch protection for individual paths on VC-4, VC-3 or VC-12 level.



## Switching SNC Protection

---

**When to use** Follow these steps to switch lines for individual paths on VC-4, VC-3 or VC-12 level.

**Before you begin** This switch should be requested when a number of specific path has to be rerouted due to maintenance activities.

- A switch is always traffic affecting
- An SNC path should have been provisioned.

**Related information** Related information are

- Set cross connections and their protection
- Traffic Maintenance Concepts

### Procedure

---

- 1 Select *Protection -> Transmission -> AM-1 VC# SNC*.

**Result:**

The *EMS - Provisioned AM-1 SNC Protection Information* window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous screen which will display the requested information of the selected NE.

---

- 3 Make a selection from the list and click Edit.

**Result:**

The *EMS - Edit Provisioned AM-1 SNC Protection Information* window is displayed.

---

- 4 Fill in the fields *Switch Request* and *Hold Off Time (Seconds)* with usage of the above parameter information and click Apply.

**Result:**

Message: This operation may be service affecting will be displayed.

- 
- 5 Click Yes to continue.

**Result:**

In the messages box can be verified what the status is. If the operation is accepted the message Operation Successful will be displayed. Otherwise Operation failed will be displayed. The window will close and returns to the previous screen.

- 
- 6 Click Cl ose to exit.

**Result:**

The window closes.

END OF STEPS



## Parameters for Switching SNC Protection

---

**Hold Off Time** Provides the delay between the moment that the signal fail or degrade condition is set, and the start of the execution of the switch-over. The default value is 0.0 seconds. Values are 0.0 ... 10.0.

**Switch Request** The Switch Request descriptions and values are:

Description	Values
No change is made to the current state of the protection switch	<i>No Request</i>
Executing Clear on a line will undo only the previous switch request that is initiated on that specific line.	<i>Clear</i>
Will switch the traffic to the working regardless of the state of that leg. This will override a hardware protection switch. This is canceled with the clear command.	<i>Forced To Working</i>
Will switch the traffic to the protection regardless of the state of that leg. This will override a hardware protection switch. This is canceled with the clear command.	<i>Forced To Protection</i>
Will switch traffic to the working only when that working is error free and is not satisfying an equal or higher priority request. A hardware protection switch will override.	<i>Manual To Working</i>
Will switch traffic to the protection only when that protection is error free and is not satisfying an equal or higher priority request. A hardware protection switch will override.	<i>Manual To Protection</i>



## Section: Switch MSP Protection

### Overview

---

**Purpose** To perform a switch on a transmission signal in a point-to-point connection. In executing this request, the signal will be switched from the worker to the protection or the other way around.



## Switching MSP

---

**When to use** Follow these steps to switch MSP:

**Before you begin** A MSP protection switch should be made if maintenance operations force traffic over a specific point-to-point connection to be rerouted. Before switching MSP determine the following:

- A switch is always traffic affecting
- MSP pair must be present and physically set up on the Near End and Far End Network Elements. In other words, a MSP card inserted and fiber pairs connected on both Network Elements.

**Related information** Related procedures and information are:

- Slot provisioning.
- Port provisioning.
- Add MSP protection
- Section Traffic Maintenance Concepts in chapter Concepts.

### Procedures

---

- 1 Select *Protection -> Transmission -> MSP*.

**Result:**

The *EMS - MSP Protection Information* window is displayed.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The window closes and reverts to the previous screen which will display the requested information of the selected NE.

---

- 3 Click *Edit*.

**Result:**

The *EMS - Edit MSP Protection Information* window is displayed.

---

- 4 First select *Switch* and select an MSP pair from the list.

**Result:**

The parts that are not applicable for a certain selection are greyed out.

---

- 5 Make the selections with usage of the above parameter information and click OK.

**Result:**

In the message box can be verified what the status is. If the operation is accepted the message Operation Successful will be displayed. Otherwise Operation Failed will be displayed. Switch priority to low will be displayed if the switch request can not be processed because another one with higher priority is active. Invalid action parameters will be displayed if the switch request is not allowed for the current MSP selections.

---

- 6 Click Cl ose to exit this window.

**Result:**

The window closes.

END OF STEPS

---



## Parameters for Switching MSP

---

**Operation** The possible operations which can be performed on MSP protection. Values are Add, Modify, Delete or Switch.

**MSP list** Lists the MSP protection pairs and the Operation State. The operation state indicates the current operation state for MSP pair.

**Working/Protection Section** Working section shows the available ports on assigned cards supporting MSP that can be protected. Protection section will be filled in with the associated protection port once the working section has been selected.

**Communication Mode** Displays whether the protection is Unidirectional or Bidirectional. In the case of failure with Unidirectional mode the receive side switches. In the Bidirectional mode both sides are switched. When the Unidirectional mode is displayed the Far End selections are greyed out.

**Switch Mode** Displays whether the protection is Revertive or Non-Revertive. In the case of failure with Revertive mode the traffic switches to the protected line and switches back when the failure is solved. In the Non-Revertive mode the traffic switches to the protected line and remains even when the failure is solved.

**Switch Request** Selection of the switch requests that can be performed on the MSP.

Description	Value
No request to switch has been issued.	<i>No Request</i>
Switch request which conditionally switches service to the working TP. In case a failure is detected an automatic switch will take place to the protection TP. If a failure exist manual switch is rejected because the switch priority is to low.	<i>Manual Switch to working</i>
Switch request which conditionally switches service to the protecting TP. In case a failure is detected an automatic switch will take place to the working TP. If a failure exist manual switch is rejected because the switch priority is to low.	<i>Manual Switch to protection</i>

Description	Value
Switch request which forces switching service to the working TP. It prevents automatic switching to the protecting TP even in case a failure is detected.	<i>Forced Switch to working</i>
Switch request which forces switching service to the protecting TP. It prevents automatic switching to the working TP even in case a failure is detected.	<i>Forced Switch to protection</i>
The last protection switch is cleared.	<i>Clear</i>

**Wait to Restore Time**

If MSP mode is ETSI, then WTR is the wait to restore time after the failure on the active section has cleared in the revertive mode. Values are 0..60.







# 7 NE Software Upgrade

## Overview

---

- Purpose** A software upgrade provides the network element with a new version of controller software.
- Objective** A software upgrade enhances the functionality of the network element by running new software.
- Outcome** The previous software in the network element is inactive and the newly installed software is active.
- Intended use** The first section of this chapter explains the concepts of software upgrade of a network element. The remaining sections describe the procedures related to software upgrade.
- In this chapter it is assumed that the required controller software is available on the management system.



## Section: View Software stored in the Network Element

### Overview

---

- Purpose** Use the inventory information to:
- check which software is stored in a particular network element
  - check if a specific software load is *active*
  - retrieve certain codes of the software in the network element
  - make an inventory of all network elements that contain a specific software load.



## Procedure to View Software stored in the Network Element

---

**When to use** When performing this procedure the user will know the current type of software stored in the NE.

**Before you begin** There are two ways to view an inventory of the software stored in the NE. Use the following table to select the required window.

Purpose	Select	Window
View software loaded in a network element	Provisioning -> Equipment -> NE Software Inventory	<i>EMS - Provisioned NE Software Inventory</i>
View list of NEs with particular software load	Provisioning -> Equipment -> Software Inventory	<i>EMS - Software Inventory</i> (first a selection window appears where the NE type and the software version can be selected)

Before viewing the software inventories it is assumed that the:

- names and types of the network elements are known
- correct Item Code of the software you want to view is known (only for a Software Inventory).

**Related information** Theoretical information can be found in section Software Upgrade in chapter Concepts.

**Procedure** Use the following procedure to find information about the software installed in the network elements.

---

- 1 Select the required command as described in the table above.

**Result:**

The requested inventory window appears.

---

- 2 Click the selection dialog button to update the:
  - *EMS - Provisioned NE Software Inventory* window for another network element,
  - *EMS - Software Inventory* window for another software version.

- 
- 3** Click the Close button to close the window.

END OF STEPS

---



## Parameters for Viewing Software stored in the Network Element

---

**Introduction** It is possible to view the following information about the network element controller software:

- the software version now stored in the active and backup store.
- the store state shows whether the software in the store is valid.

**Active Store** The software version of the executing code of the software loaded in the network elements active store is described by four codes. In the Software Inventory window only the Item Code is displayed.

Code	Description
Actual Item Code	A code used to uniquely identify any system component.
Interchangeability Marker	An identification mark to indicate interchangeability among components.
Serial Number	A number that indicates the sequence number and the year, date and location of manufacture.
Com Code	A code which identifies the component.

**Backup Store** The same codes as those listed for the Active Store are used to describe the software stored in the backup store.

**Active Store State** The active store contains valid software if the store state is: *Store Active*.

**Backup Store State** The backup store contains valid software if the store state is: *Store Inactive*.



## Section: Download Software into a Network Element

### Overview

---

**Purpose** Use this procedure to download new software from the management system into the backup store on the system controller of the network element.



## Parameters: Download Software into a Network Element

---

**Introduction** Before downloading new software it is possible to check the following information about the backup store:

- the state of the System Controller
- the software versions stored
- the state of the active and the backup stores.

**Controller Overall State** The Controller Overall State shows whether the System Controller unit is available to perform a software update. This state can have two values:

Value	Description
Controller Busy	The controller card is busy. Software download cannot be done until the controller becomes available.
Controller Available	The controller card is available for updates.

**Active Store** Shows the software load that is now active, stored in the active store.

**Backup Store** Shows the software load that is now stored in the backup store.

**Active Store State** The state of the active store of the network element can have two values:

Value	Description
Store Active	Memory contains a valid code that is being executed.
Store Active Not Committed.	If no association is made between the management system and the network element after a software switch.  The software that was active before the switch is now in the backup store. If the association is not made within 2 hours after the switch, the system will switch the stores back so that the previous active software is made active again. Therefore it is not wise to download software while the active store is in this state.

Element

Parameters: Download Software into a

Network Element

**Backup Store State** The state of the backup store can have the following values:

Value	Description
Store Error	Memory has corrupted data.
Store Clearing	After the download command the inactive store is cleared.
Store Empty	The clearing of the store has been successful and new software will now be downloaded.
Store Downloading	Code is being downloaded to the memory.
Store Inactive	Memory contains valid code that is not being executed.

## Procedure to Download Software into a Network Element

---

**When to use** Follow this procedure when a new software version must be available on the network element.

**Before you begin** Before starting to download new software check the following:

- The procedures for downloading software can only be performed with supervisor privileges. Contact the system administrator to have these privileges set
- The required controller software is available on the management system. If not contact the system administrator
- There is sufficient time to complete the procedure. The procedure lasts about one hour
- The management system is installed and able to communicate with the network element. When the management system cannot communicate with the network element it is only possible to download new software into the network element on a local basis, such as by using a ITM-CIT
- Do not download software into the backup store while the active store is not committed. As long as the active store is not committed the network element may perform an automatic switch.

**Related information** The following procedure and information are related:

- The procedure to switch to new software in a network element is related
- Section Software Upgrading Concepts in chapter Concepts.

**Procedure** Follow these steps to download new software to the backup store of the network element.

---

**1** Select Provisioning -> Equipment -> NE Software Inventory.

**Result:**

The *EMS - NE Software Inventory* window displays the contents and states of the software stores of the selected network element.

---

**2** To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

## Element

Procedure to Download Software into a  
Network Element**Result:**

The *EMS - NE Software Inventory* window is updated with software inventory information of the selected network element.

---

- 3 Select Edit to download software into the network element.

**Result:**

The *EMS - S/W Download and Switching* window appears. Use this window to download a new MEC file into a network element. After a successful download, the same window is used to switch to the new software.

---

- 4 Select one of the available MEC files from the list of loaded files.

**Result:**

The loaded file contains the software for the network element.

---

- 5 Select Start Software Download to start downloading and click Apply.

**Result:**

All operation buttons on this window apart from Abort Software Download become inactive during the download and an Operation Started message appears in the message box at the bottom of the window. After the download, the operation buttons become active again and an Operation Successful message appears in the message box.

---

- 6 To stop the download operation select Abort Software Download and click Apply.

**Result:**

Communications between the network element and the management system are maintained during an abort. Traffic carried by the network element is not interrupted. All operation buttons on this window become inactive and an Operation Started message appears in the message box. When the download is aborted, the relevant operation buttons become active again and an Operation Successful message appears in the message box.

---

- 7 Click Close to exit the window.

END OF STEPS

---



## Parameters: Download Software into a Network Element

---

**Introduction** Before downloading new software it is possible to check the following information about the backup store:

- the state of the System Controller
- the software versions stored
- the state of the active and the backup stores.

**Controller Overall State** The Controller Overall State shows whether the System Controller unit is available to perform a software update. This state can have two values:

Value	Description
Controller Busy	The controller card is busy. Software download cannot be done until the controller becomes available.
Controller Available	The controller card is available for updates.

**Active Store** Shows the software load that is now active, stored in the active store.

**Backup Store** Shows the software load that is now stored in the backup store.

**Active Store State** The state of the active store of the network element can have two values:

Value	Description
Store Active	Memory contains a valid code that is being executed.
Store Active Not Committed.	If no association is made between the management system and the network element after a software switch.  The software that was active before the switch is now in the backup store. If the association is not made within 2 hours after the switch, the system will switch the stores back so that the previous active software is made active again. Therefore it is not wise to download software while the active store is in this state.

Element

Parameters: Download Software into a  
Network Element**Backup Store State** The state of the backup store can have the following values:

Value	Description
Store Error	Memory has corrupted data.
Store Clearing	After the download command the inactive store is cleared.
Store Empty	The clearing of the store has been successful and new software will now be downloaded.
Store Downloading	Code is being downloaded to the memory.
Store Inactive	Memory contains valid code that is not being executed.

## Section: Switch the Stores in a Network Element

### Overview

---

**Purpose** Use this procedure to switch between the active and backup stores and thus switch the network element from one software version to another.



## Procedure to Switch the Stores

---

**When to use** Follow this procedure when new software is loaded into the backup store, and the backup store must become active to execute the new software.

**Before you begin** Before starting to switch to new software check the following:

- the procedures for switching to new software can only be performed with supervisor privileges. Contact your system administrator to have these privileges set
- the correct software is stored in the backup store.
- the management system is installed and able to communicate with the network element
- the management system has the software version that can communicate with the new software on the network element. If no association can be made after the switch, the network element will switch the stores back automatically
- the Management Information Base (MIB) must be compatible with the new software. If not chose Switch (MIB clear) and download a new MIB into the network element when the new software is active and an association with the ITM-SC is made. In this case the ITM-SC must also have had a software upgrade
- if active and backup stores are switched over, the network element will reset using the software that was previously in the backup store. If this software is invalid, it may not be possible to continue to manage the network element
- the switch operation may cause an interruption of traffic. This depends on the software that is in the backup stor.
- after the confirmation of the switch command the management system loses its association with the network element for approximately 1 minute. If geographic redundancy (GR) is enabled a GR switch may occur.

**Related information** The following procedures and information are related:

- Download New Software to a Network Element
- View Software Stored in the Network Element
- Section Software Upgrading Concepts in chapter Concepts.

**Procedure** Follow these steps to switch to the software in the backup store of the network element:

---

- 1 Select Provisioning -> Equipment -> NE Software Inventory.

**Result:**

The *EMS - NE Software Inventory* window displays the contents and states of the software stores of the selected network element.

---

- 2 To select an NE or to switch to another NE, click the selection dialog button. A list of possible NEs then appears in the *EMS- NE Selection Dialog* window. Select the desired NE and click OK.

**Result:**

The *EMS - NE software inventory* window is updated with software inventory information of the selected network element.

---

- 3 Select Edit to switch to the new software in the selected network elements.

**Result:**

The *EMS - S/W Download and Switching* window appears. Use this window to switch the active and backup stores.

---

- 4 Chose one of two switching modes as described earlier.
- 

- 5 A confirmation window appears. Click No to return to the *EMS - S/W Download and Switching* window or Yes to confirm the software switch.

**Result:**

After approximately two minutes the ITM-SC loses its association with the network element. One minute later the association is re-established and the network element works with the new software. If the association is not re-established the stores will switch back after two hours.

---

- 6 Click Close to exit the *EMS - S/W Download and Switching* window.

END OF STEPS

---



## Parameters to Switch the Stores

---

**Introduction** Before switching the stores of the network element it is possible to view the following information about the network element:

- the state of the system controller,
- which software version is now stored in both the stores,
- the state of both stores.

**Controller Overall State** The Controller Overall State shows whether the System Controller unit is available to perform a software update. This state can have two values:

Value	Description
Controller Busy	The controller card is busy. Software download cannot be done until the controller becomes available.
Controller Available	The controller card is available for updates.

**Active Store** Shows the software load that is now active, stored in the active store.

**Backup Store** Shows the software load that is now stored in the backup store. This software version will become active after the switch.

**Active Store State** The state of the active store of the network element can have two values:

Value	Description
Store Active	Memory contains a valid code that is being executed.
Store Active Not Committed.	If no association is made between the management system and the network element after a software switch.  The software that was active before the switch is now in the backup store. If the association is not made within 2 hours after the switch, the system will switch the stores back so that the previous active software is made active again. Therefore it is not wise to download software while the active store is in this state.

**Backup Store State** The backup store contains valid software if the store state is *Store Inactive*.

**Switching modes** The possible switching modes are described in the table below:

Select	Result
Switch (No MIB Clear)	During the switch the MIB in the network element remains unchanged.
Switch (MIB Clear)	During this switch the network elements MIB is cleared. At the end of the procedure the networks elements MIB is cleared and a new MIB must be downloaded from the management system to the network element.







# 8 Concepts

## Overview

---

**Purpose** This chapter describes all the concepts related to WaveStar® Network Elements.

**Topics** The main topics covered in this chapter are:

- Management Communication Setup concepts
- Equipment Provisioning concepts
- Alarm Management concepts
- Timing concepts
- Path Provisioning and Protection concepts
- Traffic Maintenance concepts
- Performance Monitoring concepts
- Software Upgrade concepts



## Section: DCN Management Concepts

### Overview

---

**Purpose** This section explains the concepts of provisioning the Data Communications Network (DCN). To complete the procedures in this chapter, the user should first be acquainted with the concepts contained in this section.




## SDH Data Communications Network

**SDH management network** The SDH management network is an overlay of the transmission network. The Element Management System (EMS) and the Network Elements (NEs) together are the nodes of this network. The Q-LAN and Data Communication Channel (DCC) provide the physical connection between the nodes.

**DCN physical components** The figure below illustrates a Data Communications Network (DCN) as defined by the Open Systems Interconnection (OSI) model. This figure refers to the physical components and connections in the DCN. It does not give information on the logical configuration of the DCN.

**Figure 8-1 OSI-DCN**



The figure of the OSI-DCN consists of 2 Q-LANs and a number of DCC channels in an SDH transmission network with point-to-point configuration and two rings connected to an EMS. The ITM-SC server is used as an EMS. The ITM-SC is connected to the transmission network via Gateway Network Elements (GNEs) by Q-LAN. The network elements are connected to each other by DCC channels.

**LCN** In the case where there is no DCC connectivity between nodes, a Local Communications Network (LCN) can be used to connect the nodes to each other. See the LCN on the right side of the figure.

**DCN communication protocols**      Communication protocols used in the Data Communications Network (DCN) between the nodes include:

- Ethernet (on the Q-LAN) LAPD (on the DCC channels)
- OSI Network Protocol (DCN wide)

The OSI Network Protocol (OSI-DCN) is used for routing management data between nodes in the DCN.



## OSI Network Protocol

---

- Network protocol used** The network protocol used between nodes is the ISO-OSI Network Protocol (ISO/IEC 8648). According to this protocol a node in the network can behave as an End System (ES) or as an Intermediate System (IS), sometimes called a router.
- End Systems** Nodes behaving as End Systems perform no forwarding of data packets. They communicate with each other on an end-to-end basis via Intermediate Systems.
- Intermediate Systems** Intermediate Systems are used for routing data between nodes and (sub) networks. The End System - Intermediate System (ES-IS) protocol is responsible for the exchange of data between an End System and Intermediate System. A network element can act both as an End System as well as an Intermediate System. However, an ITM-SC, for example, can only act as End System.
- IS - IS protocol** The Intermediate System to Intermediate System (IS-IS) protocol is used between Intermediate Systems in the DCN. The IS-IS protocol maintains the IS Routing Information Base (RIB). The information in this information base is used for the routing of management data packets in the DCN by the Intermediate Systems.
- Routing Information Base and LSPs** Each RIB comprises a number of tables. These tables contain information on Network Service Access Point (NSAP) addresses of nodes in the network and ports of the IS through which these nodes can be reached. Intermediate Systems exchange routing information regularly with one another as part of the IS-IS protocol by the use of Link State Protocol Data Units (LSPs).
- The LSPs contain the information on the NSAP addresses of nodes used in the tables of the RIBs.

□

## DCN Addresses

---

**DCN addresses** The system has two addresses in the DCN:

- Ethernet address
- NSAP address

**Ethernet address** The Ethernet address is the unique 6-byte address of a Network Element. Sometimes it is also referred to as the hardware or physical address of the node. The Ethernet address has only local meaning on the Q-LAN and can not be used for routing purposes. It does not contain the information on where the node is in the data communications network.

**NSAP address** The Network Service Access Point (NSAP) address is used by the network protocol for location information. The NSAP address of a node is its DCN wide identifier which uniquely identifies the node in the network.



## NSAP Address Format

---


**Background** The following three NSAP formats can be distinguished:

- ISO-DCC NSAP address format. This format is used by most Lucent network element types in the network,
- Local-Lucent NSAP address format. This format is also used by some Lucent network element types in the network,
- Flexible NSAP address format. An alternative to the previous two formats.

Although different NSAP address formats exist, preferably all nodes in a network should use the same address format.

**ISO-DCC NSAP address format** The ISO-DCC NSAP address format is presented below.

**Figure 8-2 ISO-DCC NSAP address format**



**ISO-DCC NSAP address fields** This ISO-DCC NSAP address format is hierarchical and consists of the following fields:



Field	Function It Provides
Area Address	Has three parts: <ul style="list-style-type: none"> <li>• AFI (Authority and Format Identifier) is equal to 39 (HEX).</li> <li>• The fixed part is equal to 00008000000000000000 (HEX).</li> <li>• Area Id indicates the area to which a node belongs and thus its logical location in the network.</li> </ul>
System Identifier (SID)	Identifies the node. In most network element types, the Ethernet address is copied into the SID address field and this makes the NSAP address unique throughout the DCN.

Field	Function It Provides
Selector (Sel)	Set to 01 (HEX) for the network elements.

**Local-Lucent NSAP address format**

The Local-Lucent NSAP address format is presented below.

**Figure 8-3 Local-Lucent NSAP address format**



**Local-Lucent NSAP address fields**

The Local-Lucent NSAP address format has the following fields:


Field	Function It Provides
Area Address	Has two predefined parts: <ul style="list-style-type: none"> <li>• AFI (Authority and Format Identifier) field, equal to 49 (HEX).</li> <li>• Area Id indicates the area to which a node belongs and thus its logical location in the network.</li> </ul>
System Identifier (SID)	Identifies the node. In most network element types, the Ethernet address is copied into the SID address field and this makes the NSAP address unique throughout the DCN.
Selector (Sel)	Set to 01 (HEX) for the network elements.

There is no fixed part in this address type.

**Flexible NSAP address format**

The flexible NSAP address format is presented below.

**Figure 8-4 Flexible NSAP address format**



**Flexible NSAP address fields**

The flexible NSAP address has the following fields:

Field	Function It Provides
Area Address	Has two provisionable parts: <ul style="list-style-type: none"> <li>• AFI (Authority and Format Identifier) field, which may vary between 10 and 99 (HEX).</li> <li>• Flexible part, which may vary from 0 to 12 bytes.</li> </ul>
System Identifier (SID)	Identifies the node. In most network element types, the Ethernet address is copied into the SID address field and this makes the NSAP address unique throughout the DCN.
Selector (Sel)	Set to 01 (HEX) for the network elements.

In this way, the flexible NSAP address can vary from 8 to 20 bytes.

Notice that the flexible NSAP address format can be used to derive the other formats.

□

## IS-IS Level 2

---

**Background** Hierarchical routing is used for large networks when the number of NSAP entries in the RIB databases of the Intermediate Systems is too large. When this happens, it causes an exponential increase of exchanged LSPs between Intermediate Systems. This in turn causes the performance of the DCN to decrease due to the computation of the shortest path first algorithm.

**Hierarchical routing Definition** In hierarchical routing, the DCN addressing domain is divided into a number of areas. Each area is assigned a unique identifier. The value of the Area Identifier of each node's NSAP address is set according to the area the node is part of.

**Level 1, Level 2 Definition** Each area contains a number of:

- End Systems,
- first level (Level 1) Intermediate Systems and,
- second level (Level 2) Intermediate Systems.

Level 1 Intermediate Systems provide interconnectivity between nodes within the same area. Level 2 Intermediate Systems provide interconnectivity between nodes belonging to different areas.

**Level 2 Subdomain** The complete set of Level 2 Intermediate Systems is also referred to as the Level 2 Subdomain. All areas in a network are connected via the Level 2 Subdomain.



## Partitioning Networks into Areas

---


**Definition** Partitioning is configuration of the DCN in such a way that the exchange of LSPs between Intermediate Systems is limited.

**Partitioning use** When networks are partitioned into areas, the RIB database(s) in the systems are much smaller and hence the routing overhead is significantly reduced. Intermediate Systems in an area only exchange information (LSPs) on nodes with other systems in their own area. Information on other areas is exchanged by Level 2 Intermediate Systems only and maintained by the Level 2 Intermediate Systems of the area.

In this way, the data management load in the network is strongly reduced, while keeping the dynamic re-routing capabilities of Intermediate Systems in case of failures intact. It is important to notice that although the DCN is divided into areas, ES-ES communication between all nodes in the DCN is still possible.

**Network areas** The figure below illustrates how a network can be partitioned into areas, connected by Level 2 Intermediate Systems. Each area has at least one Level 2 Intermediate System assigned and can have a number of Level 1 Intermediate Systems and End Systems.

**Figure 8-5 Network areas**



- End system
- ◉ Level 1 Intermediate system
- Level 2 Intermediate system

**Routing management data** The following scenario describes routing management data in a divisioned network. Suppose a node A wants to send messages to another node. If this node is in its own area (determined by the Area Id part in the Area Address field), the messages from A to this particular node (B) are routed directly using the Level 1 Intermediate System. (See previous figure)

Alternatively, if the required destination is in a different area (C), the messages are sent to a second, higher level (Level 2) Intermediate System. This Intermediate System routes the messages coming from node A to other Level 2 Intermediate Systems until they reach a Level 2 Intermediate System attached to the destination area of C. From there it is routed within the area using Level 1 Intermediate Systems to node C.

Notice that in both of the above cases the ES-ES communication between nodes in the same or in different areas is still possible.

□

## DCN Configuration


---

**OSI-DCN networks types** In general the OSI-DCN network can be classified in three types:

- Undivided
- IS-IS Clustered
- IS-IS Area Divided network

The three types are illustrated in the figure below:

**Figure 8-6 Types of OSI-DCN networks**



□

## Undivided Data Communications Network

---

**Undivided network definition**

An undivided network consists of a single routing domain. There is no division between the nodes at the network protocol level. All nodes in the network and especially the Intermediate Systems can exchange routing information with each other. Although a network element can only be managed by one ITM-SC at a time, the IS-IS protocol is running between all nodes in the network. This leads to the exchange of LSPs between all Intermediate Systems of the network.

□

## IS-IS Clustered DCN

---

**IS-IS LSP exchange** In order to avoid the decrease of performance, the exchange of LSPs over a certain port can be disabled in some nodes. A node can exchange LSPs over its DCC or Q-LAN ports. The exchange of LSPs over the DCC channel can be disabled. However, this also prevents the exchange of management data over this port and prevents the use of this DCC port for re-routing in case of a failure of another port.

**Disabling exchange of LSPs** Another option is to disable the exchange of LSPs over the Q-LAN port. This can be done by choosing the IS to have a NO-IS-IS port. This node is also referred to as a NO-IS-IS (gateway) node. If this is done for all Intermediate Systems on a Q-LAN, the Q-LAN becomes a NO-IS-IS Q-LAN. In NO-IS-IS LANs, the IS-IS protocol is not run on the Q-LAN. This prevents the exchange of LSPs between Intermediate Systems on a Q-LAN. This results in a network which comprises several clusters of nodes. Between the clusters there is no IS-IS traffic.

**ES-ES communication** Within a cluster the ES-ES, ES-IS and IS-IS communication is still possible. There is however no communication possible between nodes in different clusters. For example a Craft Interface Terminal (CIT) can be connected to a node in a cluster for maintenance activities on nodes within a cluster. However, it is then not possible to do a remote login from this node to a node of another cluster.

**ITM-SC connections** The ITM-SC connected to the Q-LAN can still communicate with all nodes in the clusters since the ES-IS protocol on the Q-LAN is not disabled. Important to notice is that the nodes in a Remote Cluster lose their association with the ITM-SC when NO-IS-IS is chosen on the gateway node of the remote cluster. It is advised to connect the ITM-SC to the Q-LAN that connects the clusters to each other and to assign NO-IS-IS only to nodes on this Q-LAN.

□

## IS-IS Area Divided DCN

---

**Divided areas definition** The division of the DCN in areas by introducing Level 2 Intermediate Systems is similar to disabling the IS-IS protocol over the Q-LAN port of nodes, as described earlier.

Similar to clustering, the exchange of Level 1 LSPs between Intermediate Systems in different areas is prevented. However Level 2 LSPs are still exchanged between Level 2 Intermediate Systems.

□

## DCC Concepts

---

**Data Communication Channels (DCC)**

The Data Communication Channels (DCC) are part of the Data Communications Network (DCN). The channels are used to exchange management data between the ITM-SC and the Network Elements. The channels are also used for communication between the different Network Elements (for example remote logins). DCC channels (D1 - D12) are provided by reserved bytes in the regenerator section (RS) and the multiplexer section (MS) overhead of the STM-N signal.

□

## Dual Stack with Tunneling (DSwT)

**Introduction** The Dual Stack with Tunneling (DSwT) feature provides a way to manage IP devices through the DCN network.


An IP EMS (Element Management System) is used to manage NEs which use IP based management protocols (IP NEs).

**Dual Stack** Dual Stack means adding an IP Router stack to an existing OSI stack.

**Tunnel** A tunnel is a unidirectional path through the OSI domain capable of transporting IP packets. The tunnel consists of an endpoint in the OSI domain (NSAP) and the encapsulation/decapsulation mechanism to transport an IP packet in an OSI network. The actual path taken by the encapsulated IP packet is completely determined by the normal OSI routing mechanisms.


**Network Architecture** The network architecture in the figure is used in this example.

**Figure 8-7 Network Architecture example**



**IP Tunnel Architecture** The IP Tunnel architecture in the figure is used in this example.

**Figure 8-8 IP Tunnel example**



**Tunnel Configuration** A tunnel can be seen as a set of two static routing entries in nodes on the edge of the OSI network and the corresponding static entries in the routing table. The term tunnel may be misleading because it is often associated with connections which must be set up in advance. In this case, only some routing and mapping information needs to be provisioned and no communication between two systems is needed to set up the “tunnel” between them. To avoid confusion, it is better to speak of encapsulation and to think of the OSI network as a NBMA (non broadcast multiple access) subnetwork within the IP network.

The NEs need to be configured with one IP address on the LAN side, connected to the IP subnet with the IP NEs. The LAN can be used for both OSI and IP traffic. The same ethernet address will be used for both protocols.

**IP Encapsulation** The IP packets are encapsulated in CLNP (Connectionless Network Protocol) packets which are routed through the OSI-only node which routes the CLNP packets as normal, totally oblivious of the CLNP packets contents.

**IP and DCC** A benefit of the tunneling approach, is that IP need not to be carried on the DCC. Only the CLNP packets (possibly carrying IP) go on to the DCC.

**IP Routing** In the Dual Stack with Tunnelling configuration, a second network layer entity (the IP router) is added alongside the existing OSI network layer entity (CLNP). The CLNP entity has the routing tables and the mechanisms to automatically populate them - namely the IS-IS and ES-IS dynamic routing protocols.

This is not the case for the IP routing tables since there is no IP dynamic routing protocol to populate the IP routing tables. IP routing tables have to be manually provisioned by the operator.

### DSwT Routing Table

A Routing Table, IP or OSI, is divided into 2 columns:

- “Final Destinations” of each Network Node,
- for each Final Destination, the identity of the “Next Hop” which is the next network node in the path towards the Final Destination.

The table below shows a simplified IP routing table for IP router in a DSwT stack. It is divided into 2 main columns. These two parts of the routing table will be discussed separately.

FinalDestination	Next Hop	
	Subnetwork	Node
130.44.5.0/24	LAN 0	<local>
120.23.4.0 / 24	LAN 0	130.44.5.8
150.35.10.0 / 24	DCC 1	-
150.35.20.0 / 24	DCC 2	-
160.22.0.0 / 16	CLNP-Tunnel	NSAP (node X)

### Final Destination

This column of the Routing Table is a list of all the final destination nodes. When a packet is received at this node, then the destination address in that packet is checked against the list of destinations in the destination column of the routing table. If there is no entry in the table for the packet destination, then the node won't know how to route the packet and will execute the error procedure (which involves discarding the packet and trying to send an error message packet back to the source). If a match is found, the next hop towards the destination can be looked up in the “Next Hop” column.

### IP Prefixes


An IP Prefix is a mechanism of identifying a collection of IP addresses with some common root. The general principle is to choose a mask which identifies a suitable first part of the IP address which summarizes a number of addresses. For example, the addresses 120.10.2.1, 120.10.2.5 and 120.10.2.13 can be summarized by the IP Prefix: 120.10.2.0 / 24. The 24 identifies the first 24 bits of the address. Summarizing IP addresses is a very powerful way to reduce the number of entries in a Routing Table.

**Next Hop** Two pieces of information are needed in order to identify the next hop node:

- on which subnetwork (for example on which exit port) is the next hop node,
- which node on that subnetwork is the next hop.

This is shown in the figure below.

**Figure 8-9 Next Hop Identification**



To send a packet to the destination Dest, the Source must identify the node Next Hop. This is identified by the subnetwork (on Port 2 of Source) and then the node on that subnetwork (identified by B). In OSI terminology the address B is known as a Subnetwork Point of Attachment (SNPA), which is the point that the node is attached to the subnetwork.

The second column in the Routing Table is the next hop and is divided into 2 parts:

- the Next Hop Subnetwork
- the Next Hop Node.

### **Next Hop Subnetwork**

A router, by its nature, must be connected to multiple subnetworks. Each subnetwork is connected to a separate port on that router. The Next Hop Port identifies the subnetwork to exit this node for the next hop towards the destination.

For the DSwT IP router entity, there are 2 types of port/subnetwork:

1. LAN. This is the ethernet (common subnetwork type for IP routers).
2. CLNP-Tunnel. This is a logical subnetwork created by the OSI CLNP network itself. From the IP router perspective, this subnetwork is seen as a “Non-Broadcast Multiple Access” (NBMA) subnetwork. The IP router simply sees all the neighbour IP router entities connected together to this NBMA. It does not see any of the OSI CLNP nodes inside this network.

**Next Hop Node** Once the correct exit port (subnetwork) has been identified, the correct node on that subnetwork must be identified by its SNPA. This could be an Ethernet address (for a LAN), or a X.121 address for a X.25 subnetwork. When the subnetwork is a point-to point link then there is no need to identify the Next Hop. There are various ways to identify the Next Hop Node, and they depend on the type of subnetwork that node is attached to. The following table provides an overview:


Subnetwork Type	Next Hop Node (Identity Type)
LAN	IP address or none if the destination is actually on this LAN (there is no Next Hop Node).
CLPN-Tunnel	NSAP



# Example of Dual Stack with Tunneling

**Network Architecture** The network architecture in the figure is used in this example.

**Figure 8-10 Example of an DSwt Network**



## Routing Tables for IP Host Nodes

Not only IP router nodes but also IP host nodes have Routing Tables. The Routing Table is used for every IP packet generated by this IP host. As can be seen in the table below, each node has 2 routing entries. These two routing entries will be discussed separately.

The routing tables for nodes I1, I2, I3, I4 and I5:

IP Host Node	FinalDestination	Next Hop	
		Port	Node
I1	120.2.1.0 / 24	LAN	<local Subnet>
	0.0.0.0 / 0	LAN	120.2.1.2
I2	120.1.2.0 / 24	LAN	<local Subnet>
	0.0.0.0 / 0	LAN	120.1.2.1
I3	120.2.3.0 / 24	LAN	<Local Subnet>
	0.0.0.0 / 0	LAN	120.1.3.2
I4, I5	120.3.4.0 / 24	LAN	<Local Subnet>
	0.0.0.0 / 0	LAN	120.3.4.2

**Local Route** The first routing entry in the IP host node routing table is called the Local Route and is often generated automatically after the node's interface is configured with an IP address and a subnet mask. This IP Prefix is simply the subnet address (IP address with subnet mask) of the locally attached subnet. This entry says that every packet generated with destination address of the local subnet will be sent out on the local LAN. There is no "Next Hop Node". Instead <Local Subnet> is simply a flag which says to take the destination IP address from the IP packet and resolve it directly on the local LAN. Notice this routing entry would be essential in nodes I4 and I5 if they wished to communicate with each other. There is one Local Route entry for each interface. These IP Hosts only have a single interface and so only a single Local Route entry.

**Default Route** The second routing entry in the IP host node routing table is the IP Prefix 0.0.0.0 / 0, which is called the Default Route. This prefix will match every destination IP address and so in effect, this routing entry says that every packet generated will be sent to the specified next hop. In all cases, the specified next hop is the DSWT node which is identified by its IP address. Notice that routes for the local subnet also match the Default Route. Of course this is not the intention and so there is another essential rule for all routing tables, which says that match with the longest prefix route must be selected. This is fundamental to IP Routing Tables and must be followed in all cases.

**Routing Table for External Routers** For external routers there are 2 possible hop ports (LAN 1 and LAN 2). The <Local subnet> routes can be added automatically when the router interfaces are configured (assigned IP address and subnet mask).

The routing tables for routers C1 and C2:

External Routers	FinalDestination	Next Hop	
		Port	Node
C1	120.2.1.0 / 24	LAN 1	<Local Subnet>
	120.1.1.0 / 24	LAN 2	<Local Subnet>
	120.1.0.0 / 16	LAN 2	120.1.1.2
	120.3.0.0 / 16	LAN 2	120.1.1.2
C2	120.3.4.0 / 24	LAN 1	<Local Subnet>
	120.1.4.0 / 24	LAN 2	<Local Subnet>
	120.1.0.0 / 16	LAN 2	120.1.4.3
	120.2.0.0 / 16	LAN 2	120.1.4.3

**Routing Table for DSWT Nodes**

These Routing Tables have been completed with a specific application in mind: namely the management of IP based fringe equipment. In this example, only routes between I1 and I2, I3, I4, I5 are necessary: I3 does not need to communicate with I2 for example. This has been done to minimize the routes in the routing table and give a realistic indication of what the operator must provision to get the application to work.

The routing tables for DSWT nodes D1, D2, D3 and D4:

DSwT Nodes	FinalDestination	Next Hop	
		Port	Node
D1	120.1.1.0 / 24	LAN	<Local Subnet>
	120.2.0.0 / 16	LAN	120.1.1.1
	120.1.2.0 / 24	CLNP-Tunnel	NSAP (D2)
	120.1.3.0 / 24	CLNP-Tunnel	NSAP (D3)
	120.1.4.0 / 24	CLNP-Tunnel	NSAP (D4)
	120.3.4.0 / 24	CLNP-Tunnel	NSAP (D4)
D2	120.1.2.0 / 24	LAN	<Local Subnet>
	120.2.0.0 / 16	CLNP-Tunnel	NSAP (D1)
D3	120.1.3.0 / 24	LAN	<Local Subnet>
	120.2.0.0 / 16	CLNP-Tunnel	NSAP (D1)
D4	120.1.4.0 / 24	LAN	<Local Subnet>
	120.3.4.0 / 24	LAN	120.1.4.1
	120.2.0.0 / 16	CLNP-Tunnel	NSAP (D1)

In the Routing Tables for DSWT nodes, the Subnet CLNP-Tunnel is seen for next hops across the OSI (CLNP) DCN. Whenever the subnet is a CLNP-Tunnel, the Next Hop Node is identified by the NSAP address of that node. As can be seen, nodes D2, D3, D4 have routes (tunnels) back to D1 only and D1 has routes to D2, D3, D4.

Notice nodes D1 and D4 have an extra route. This is because another router is involved; the extra route points to the subnet at the far side of the router. This route must be added since, unlike the Local Route, there is no way to add this route automatically (without a full blown Dynamic Routing Protocol).


□

## DSwT Tunnel Auto Provisioning (TAP)

**Introduction** Provisioning all the entries in the Routing Tables of all the nodes can be considerable effort and is error prone, particularly when networks comprise hundreds of nodes. It would be desirable to have a mechanism which reduces some of the necessary provisioning to alleviate this problem. Such a mechanism has been designed. It is a Lucent proprietary mechanism called “Tunnel Auto Provisioning” (TAP).

**TAP Principle** The principle behind TAP is that IP routes known by DSwT nodes at the edge of the OSI network are advertised across the OSI network to the other DSwT nodes which can then insert these routes into their own Routing Tables. This basic principal is illustrated in the figure below.

**Figure 8-11 Tunnel Auto Provisioning Principle (TAP)**



Example of 2 DSwT nodes advertising the IP networks they can reach. Each Node learns the others advertised routes it hears and places them in its Routing Table.

Notice that the advertising node is not limited to giving one IP prefix but could provide a list of all the IP prefixes it can reach, if appropriate, each one resulting in a routing table entry.



## DSwT Connecting Areas with Manual TAP Tunnels

---

**Introduction** The TAP mechanism does not work across IS-IS Areas because it distributes information using IS-IS Level 1 LSPs. However, it is likely to have a considerable number of nodes in the OSI network and multiple areas.

**Connecting Areas** To allow DSwT nodes to communicate across IS-IS Areas enjoying the benefits of the auto-provisioning, a pair of “tunnels” must be manually configured between the areas. This principle is illustrated in the figure below.

**Connecting Areas Principle** A pair of provisioned “Tunnels” connecting any two nodes, one from each area, provides bi-directional communication between the Areas.

**Figure 8-12 The principle of connecting IS-IS Areas with manual TAP Tunnels**



NOTE: TAP “Tunnels” are not transitive. That is a “Tunnel” connecting Areas A and B, and a “Tunnel” connecting Areas B and C does NOT connect Areas A and C. A separate “Tunnel” between Areas A and C is needed.

□

## Section: Equipment Provisioning Concepts

### Overview

---

**Purpose** This section explains the concepts of equipment provisioning. The information in this section can be used as background information for equipment provisioning.

The following concepts are described in this section:

- Node creation
- Provisioning methods
- Addressing and management concepts
- *WaveStar*<sup>™</sup> AM 1 configuration possibilities
- Miscellaneous discrete inputs and outputs.



## Node Creation

---

**Node** A node is literally “a point at which subsidiary parts originate or center.” So, in other words the NE or the node is the central collection point of its various parts. Creating a node means, then, identifying this central point (the NE name and address) and inputting the exact parts comprising the node. All of this information is compiled and stored in the Management Information Base.

**Management Information Base** The Management Information Base (MIB) is the provisioning information stored in the database of the NE. This includes the configuration of the units within the NE, the name and type of the NE, as well as addressing and network information necessary for management.

**Confirm MIB** Confirming the MIB will send all of the basic NE information that has been entered to the System Controller. This is an essential step in the creation of the NE.

**Update MIB** The MIB can be updated rather than confirmed, if the MIB already exists and there have been few changes made. This operation can be advantageous as it takes considerably less time than that of confirming the MIB.

**Isolated State** Arriving from the factory, the WaveStar® AM 1 Plus is in an isolated state. This means that communication via DCN is not possible. In other words, no association with the ITM-SC can be established while the network element is in the isolated state.

To enable an association with the ITM-SC the network element must be brought out of the isolated state. To do so, use the ITM-CIT to either change or reselect any of the “Provisioned DCN Information” parameters. Once this is done, the network element will be removed from isolation.

□

## Provisioning Methods

---

**Provisioning methods** Providing provisioning information to the network element, the management system, or both the NE and the management system can be accomplished in three different ways.

- Using an NE template.
- Using a pre-provisioned NE.
- Performing an MIB upload.

**Management Information Base** The Management Information Base (MIB) is the provisioning information stored in the database of the NE. This includes the configuration of the units within the NE, the name and type of the NE, as well as addressing and network information necessary for management.

**MIB image** As suggested by the name, the MIB image is a copy of the data stored in the MIB. The MIB image is stored in the ITM-SC thereby enabling the ITM-SC to manage the NE.

**Templates** A template is a collection of configuration data. There are two types of templates, default and user-defined. In the system software of the ITM-SC are a set of default templates, which have the essential units already provisioned. User-defined templates are templates created by the user, and they may use a default template as a basis. All of these templates can be used to pre-provision and provision network elements.

The provisioning information contained in a template includes only data concerning the network element contents; it does not include any information regarding the position of the NE within the network. For this reason, the templates are a basic provisioning tool capable of serving as the basis for pre-provisioning or provisioning an NE.

**Pre-provisioning** Pre-provisioning allows a network elements configuration data to be stored on the management system before an actual association with this NE is established. Thus, creating a pre-provisioned NE prepares for the provisioning of an NE by storing a dummy NE on the management system. This data, stored as a pre-provisioned NE, is accessed later when the actual network element is installed and ready to be provisioned.


A template serves as the basis for creation of a pre-provisioned NE; however, the MIB image created by pre-provisioning an NE includes not only the information from the template, it also has the essential information concerning the network element's place in the network.

**Creating an MIB image**

An MIB image is created during pre-provisioning; however, it may also be created from an existing network element already provisioned with its configuration data. For example, an MIB could have been created for an NE using the ITM-CIT. In this case, the NE is provisioned, but it is not yet under control of the ITM-SC. Once a physical connection exists between the NE and the ITM-SC, the ITM-SC can assume management of the NE by creating an MIB image from the network element's MIB.

**Overview of provisioning methods**

In the figure below, the methods of provisioning using the ITM-SC are illustrated. As discussed above, templates can be used as the basis for creation of the MIB images of pre-provisioned or provisioned NEs. Pre-provisioned NEs have the same provisioning information as a provisioned NE, and thus they can be used to quickly create the provisioned NE because no additional information must be entered. Finally, an MIB image can be created from the MIB of an existing NE.



**Provisioning outcomes**

A properly completed template will appear in the list of NE templates. After successfully pre-provisioning an NE, the proper equipment configuration data for the network element is stored in the management system. The NE is displayed on the network map with a blue color, indicating that it is a pre-provisioned network element.

Finally, a fully provisioned NE is integrated into the network and is displayed on the network map in green.



## Addressing and Management Concepts

---

**Introduction** To enable management, the ITM-SC must have addressing and management connection information for each NE under its control. The basic information concerning such topics as addressing and management connection information are given in this section; however, much more detailed information about all of these Data Communications Network (DCN) concepts can be found in the chapter "DCN Management".

**Data Communications Network** The Data Communications Network (DCN) is a general name for the collection of various communication means between network management devices, such as the ITM-SC, and the NEs. By providing the communication between management systems and the NEs, the DCN makes management possible. For further information, the chapter "DCN Management" discusses this network in depth.

**DCN addresses** The NE has two addresses in the DCN:

- Ethernet address
- NSAP address

**Ethernet address** The Ethernet address is the unique 6-byte address of a network element. Sometimes it is also referred to as the hardware or physical address of the node. The Ethernet address has only local meaning on the Q-LAN and can not be used for routing purposes. It does not contain the information on where the node is in the Data Communications Network.

**NSAP address** The Network Service Access Point (NSAP) address is used by the network protocol for location information. The NSAP address of a node is its DCN wide identifier which uniquely identifies the node in the network. Although different NSAP formats exist, it is preferable that all nodes in a network should use the same address structure. Complete details concerning the structural formatting of the NSAP address can be found in the section "NSAP Address" of the chapter "DCN Management."

□

## WaveStar® AM 1 Configuration Possibilities

---

**Standard configuration** The *WaveStar*<sup>™</sup> AM 1 has standard 16 x 2Mbit/s connections. This unit is designated tributary slot 1 (TS1), and it is a part of the network element's main board.

Since the unit in TS1 is a part of the main board, it may not be changed; however, six different types of option cards may be placed for use in TS2.

**Option cards in TS2** It is possible to place an optional cards in the *WaveStar*<sup>™</sup> AM 1. This tributary port unit will occupy TS2, and it has various possibilities. It may be another card with 16 x 2Mbit/s interfaces. There are also cards available with 16 x 1.5 Mbit/s (DS1) or 2 x 34Mbit/s (E3) or 2 x 45Mbit/s (DS3) or 4 x X.21 interfaces or 2 x STM-1 interfaces. Finally, the TransLAN+ optional card has four 10/100 Mbit/s interfaces.

All of these units must be installed by a Lucent technician, as installation requires removal of the locked front panel. Moreover, each optional port unit to be placed in TS2 has its own distinctive front panel.

**Potential configurations** The following table gives the possible configurations of the *WaveStar*<sup>™</sup> AM 1.

Optional cards present in TS2	TS1	TS2
None	16 x 2Mbit/s	-
16 x 1.5 Mbit/s	16 x 2Mbit/s	16 x 1.5Mbit/s
16 x 2Mbit/s	16 x 2Mbit/s	16 x 2Mbit/s
2 x 34Mbit/s	16 x 2Mbit/s	2 x 34Mbit/s
2 x 45Mbit/s	16 x 2Mbit/s	2 x 45Mbit/s
4 x X.21	16 x 2Mbit/s	4 x X.21
4 x 10/100 BaseT Ethernet	16 x 2Mbit/s	4 x 10/100 Mbit/s
2 x STM-1 1330 nm SH	16 x 2Mbit/s	2 x 155 Mbit/s



## Miscellaneous Discrete Inputs and Outputs

---

- MDIs and MDOs** Network elements may contain Miscellaneous Discrete Inputs (MDI) and Miscellaneous Discrete Outputs (MDO).
- MDIs are inputs to a network element for external equipment. MDIs can be monitored by the management system. MDOs are outputs from a network element used to drive external equipment. MDOs can be activated or deactivated by the management system.
- Objectives** MDIs can be used to collect status information from other transmission equipment or to monitor external events (for example a door contact).
- MDOs are used to drive external equipment or to influence the behavior of equipment external to the system .
- About** The *WaveStar*<sup>™</sup> AM 1 contains four MDIs and four MDOs.
- To help with general purpose surveillance, each network element MDI and MDO can be given a unique name, which is stored in the management system. The name can be no longer than 26 characters.
- Outcome** Using the MDIs, external events are reported to the management system via the alarm representation. If this event occurs an alarm is raised. Also, the severity of these alarms can be set. Once provisioned, MDOs can place external equipment under the system's control.



## Section: Timing Concepts.

### Overview

---

**Purpose** This section explains the concepts of timing in SDH networks. In the procedures in this chapter, the user is considered to be acquainted with the concepts.

Features and jargon concerning timing distribution in a network element and a network are treated together with the basic timing architecture of the network element.



## Network Element Timing

---

**Introduction** For telephone exchanges or switches, accurate timing is critical. Therefore switches are synchronized with each other. One way of synchronizing is through the network. In this case all the SDH-network elements in the network are synchronized with one master clock. All the switches in the network can synchronize with the network, and consequently to the master clock.

**Timing reference** The timing signal received by a network element is called the timing reference.

The *WaveStar*® AM 1 Plus can work in two different mode, the STM-1 and the STM-4 mode.

If it is working in the STM-1 mode, the different ports that provide the input signals that are available as timing references are the:

- Line ports
- Tributary port.

If the *WaveStar*® AM 1 Plus is working in the STM-4 mode *and* if the STM-1 option board is available, an extra tributary port is present as a timing reference.

**Timing output** A network element can provide a synchronization signal to other equipment by sending an output timing signal.

Different output timing sources that can be used are:


- Station clock output
- Line port
- Tributary port.

**External clock output** For synchronization of equipment that is not connected to the network element by tributary or line signals, the network element can provide an external clock signal (usually 2 Mhz). However, this equipment must be in close proximity to the network element as the clock signal can only be carried a few hundred meters.

**Timing sources and outputs**

A schematic drawing of a network element with the timing sources and output is shown. The dotted arrows indicate outgoing timing signals. The straight arrows indicate the timing inputs on which the internal clock of the network element can be synchronized.

**Figure 8-13 Timing references**



**Timing modes**

Timing units can be set in different modes:

- Free running
- Hold over
- Locked.

**Free running**

In the Free running mode, the timing unit generates a clock signal from its own oscillator. No timing signal from other equipment is used for the network element synchronization.

**Hold over**

The Hold over mode will prevent a frequency step in case of a reference failure. Therefore it uses a frequency memory of the last available frequency.


**Locked**

In the Locked mode, the timing unit locks the oscillator-frequency to one of the external timing sources.

**Schematic view of the timing modes**

The next figure gives a schematic view of the three different timing modes.

**Figure 8-14 Timing modes**



□

## Network Synchronization

---

**Introduction** For telephone exchanges or switches, accurate timing is critical. Therefore switches are synchronized with each other. One way of synchronizing is through the network. In this case all the SDH-network elements in the network are synchronized with one master clock. All the switches in the network can synchronize with the network, and consequently to the master clock.

### Timing equipment

A network can use different types of equipment as a timing reference, each having its own, well defined, accuracy.

- Primary reference clock (PRC)
- Synchronization supply unit-transit (SSU-T)
- Synchronization supply unit-local (SSU-L)
- SDH equipment timing source (SEC).

**PRC** The master clock should be a primary reference clock (PRC), that provides a very accurate network clock (a clock satisfying the ITU-T recommendations G.811). The other network elements in the ring are slaved to this clock. A second clock in the network can be used to act as the backup of the master clock.

The PRC can either be an autonomous clock or it is able to accept synchronization from a radio or satellite signal.

**SSU** Noise, called jitter, may accumulate on the signal after passing through many nodes. It therefore becomes necessary at some point to recover and reshape the signal. In this case a synchronization supply unit (SSU) will be used. In addition to recovering and reshaping, the SSU will also be able to run on its own when the reference signal (for instance coming from the PRC) is lost. In this case, the SSU will be able to maintain the quality of the reference signal it produces by means of a holdover mode: the frequency and phase of the reference signal are stored in a memory and used to generate a reference signal locally.

Two kinds of SSUs exist:


- SSU-T: SSU-Transit
- SSU-L: SSU-Local

The functionality of both SSUs is equal, the accuracy of the SSU-T is higher than the accuracy of the SSU-L.

**SEC** An SDH network element has its own internal oscillator, called the SDH equipment clock (SEC). The accuracy of a SEC is lower than the accuracy of both the SSU and the PRC.

**Network example** The next figure gives an example of a network. Four network elements (NEs) of a large network are drawn, plus a master clock (PRC) and a SSU.

**Figure 8-15 An example of timing in a network**



□

## Timing Quality Levels

---

**Introduction** To choose the most appropriate timing signal from all the incoming timing signals, the quality of the timing signals must be known.

Different quality levels are defined for timing signals. The quality levels specify the quality of the incoming or outgoing timing signal. The quality levels are related to the equipment used to produce the corresponding timing signal.

**Accuracy** The accuracy of a timing signal can be given in an accuracy value. Every timing signal will have an average frequency, and a deviation in time from the average frequency value. The deviation from the average frequency, can be represented as a fraction of the average frequency. This fraction is known as the accuracy value.

**Example** When a timing reference has an average frequency of 2048 MHz, and varies in time between 2048.01 MHz and 2047.99 MHz, the deviation from the average value is plus or minus 0.01 MHz. This is can be expressed in an accuracy value:

$$\text{Accuracy} = 0.01 / 2048 = 0.0000049 = 4.9 \times 10^{-6}$$

**Quality Levels** The quality level (QL) values are transported as a synchronization status message in the S1 Byte in the STM-N signal or in the 4th position of the Sa-bit in a framed 2 Mbit/s signal.

QL	S1-byte	Accuracy	Description
Quality Unknown	S1=0	N/A	No QL information of the signal is available.
PRC	S1=02	10 <sup>-11</sup>	Primary Reference Clock indicates that the timing signal is provided by a Primary Reference Clock.
SSU-T	S1=04	1.5 x 10 <sup>-9</sup>	Synchronization Supply Unit-Transit indicates that the timing signal is derived from a Transit SSU
SSU-L	S1=08	3 x 10 <sup>-8</sup>	Synchronization Supply Unit-Local indicates that the timing signal was derived from a Local SSU

<b>QL</b>	<b>S1-byte</b>	<b>Accuracy</b>	<b>Description</b>
SEC	S1=11	$4.6 \times 10^{-6}$	SDH Equipment Clock indicates that the timing signal is provided by an SDH Equipment Clock.
DNU	S1=15	N/A	Do not use for synchronization indicates that the timing signal should not be used, since it may cause timing loops.



# Priorities


**Introduction** The timing reference signal is transported through a synchronized network by the network elements. The path this timing signal will follow can be controlled by the network operator.

**Description** When only the quality level of the timing reference signal is used, more signals with equal quality level can arrive at a network element. To determine the timing source that the network element will choose in such a case, a priority is assigned to each timing source.

In choosing a timing source, the network element first selects the timing source with the highest quality level. When there are several timing sources available with this highest quality level, the priority is taken into account.

**Example** In this figure, notice how the priorities define the timing path when each node receives two signals of PRC quality. The priority in the upper node is disabled since this input signal depends on an output signal of this network element; this could cause a timing loop, as explained in "Timing Loop."

**Figure 8-16 An example of priority settings in a network**




## Example of Network Timing

**Introduction** Timing in a network can be realized in numerous ways and configurations. The following example shows a timing chain with a regenerator loop and one PRC. The quality levels indicated in the figure represent the information that is carried by the S1 byte of that signal.

### Example

**Figure 8-17 An example of a timing chain with a regenerator loop.**



This network contains a station clock (PRC quality), a number of network elements and an SSU. A dotted line indicates the outgoing timing signals, a straight arrow inside a network element indicates the timing signal that is used to synchronize with. The connection between the network elements can either be line signals or tributary ports.

**Different types of timing** From left to right, the following types of network element timing can be identified:

- Station clock timing
- Line/Tributary timing
- Regenerator loop
- Line/Tributary timing.

□


## Timing Loop

---

**Introduction** If a timing plan is not engineered correctly, a timing loop may occur. In a timing loop the timing signal that is received by a network element can not be traced back to an independent reference. The reference signal that a network element receives in a timing loop, depends on the timing signal that this network element sends out itself. In the figure below an example of a timing loop is given. Both network elements get a timing reference which depends on itself.

### Timing Loop Sketched

**Figure 8-18 A timing loop**



**Timing Loop** In a timing loop the timing reference of a network element is derived from the timing output of the same network element. Due to this, the reference signal becomes very instable. This affects the performance of the network in a negative way.

To prevent timing loops, the quality level and priority for every port must be provisioned correctly. By disabling certain ports timing loops can be avoided.

□

## Retiming

---

**Introduction** When, for instance, a 2 Mbit/s PDH signal enters an SDH network, it is mapped into a VC-12. This VC-12 itself is aligned to a TU-12 in larger containers (for instance VC-4) and then transported through the network. A pointer is carried along to indicate the position of the VC-12 in the container. During transport through the SDH network, the VC-12 may shift in the TU-12. As a consequence, the pointer will also change, since it dynamically indicates the position of the VC-12.

In other words, the payload can float in the container. Due to this floating, the phase information of the original 2 Mbit/s signal inside the VC-12 can no longer be used.

This problem can be overcome using (2 Mbit/s) retiming. The main idea of retiming is the enforcement of timing integrity at the cost of data integrity.

**Retiming** A phase difference might occur between the tributary signal entering the SDH Network and the network element clock of the node where this signal leaves the SDH network. Even if the whole SDH network is synchronized with one reference clock, this clock can be out of phase with the original clock of the tributary signal. To clock the signal out with the SDH-PRC frequency, the signal is unpacked (from its virtual container) and stored in an elastic buffer. From there it is sent out, and then the retimed signal will carry the SDH-PRC frequency. Now it can be used as a timing reference outside the SDH network.

Retiming is possible on the following tributary interfaces:

- 1.5 Mbit/s interfaces
- 2 Mbit/s interfaces
- X.21 interfaces.


**Important!** Due to the nature of the X.21 protocol, enforcement of timing integrity does not go at the cost of data integrity on this interface.

**Self-timed** In the self-timed mode, the timing signal is derived from the bitrate of the, in case of 2 Mbit/s retiming, VC-12. The bitrate may fluctuate due to pointer adjustments within the SDH network. Therefore the self-timed mode is not suitable for carrying a timing reference through the SDH network.

**Retiming diagram**

In the following figure, the dotted lines indicate the timing sources and outputs that are used in the network. The solid lines indicate the data transport.

**Figure 8-19 A 2 Mbit/s signal entering an SDH network and leaving it with 2 Mbit/s retiming**



□

## Timing Configuration of the WaveStar® AM 1 Plus

---

**Timing functions** Timing functions of the network element can be divided into three main functionalities. These three functionalities correspond to the three main windows for timing management.


To provision the network element timing, all these functionalities must be addressed.

**Block functionality** The table below indicates the actions that can be performed in the procedures addressing the three functionalities.

Timing Sources	Input port timing process Timing source assignment Timing source functions
System Timing	System timing link switch System clock processes Output port timing process
Station Clock Output Timing	Output clock timing link switch Station clock output selection Station clock output process Station clock output distribution functions

**Functional diagram** The following diagram indicates the three main functionalities.

**Figure 8-20 The three basic timing functionalities.**



## Section: Concepts of Path Provisioning and Protection

### Overview

---

**Purpose** This section explains the concepts of transmission provisioning. The information in this section can be used as background information for transmission provisioning. The following concepts are described in this section:

- Transmission Plan
- Cross Connections
- Ethernet over SDH
- VC-3 Concatenation
- VC-12 Concatenation
- Multiplexer Section Protection (MSP)
- Sub Network Connection (SNC) protection




# Transmission Plan

**Introduction** A network element can be an Add Drop Multiplexer (ADM) or a Terminal Multiplexer (TM). An ADM can be part of a ring, an TM is part of a point to point connection. The transmission plan shows an overview of the network and the traffic. To provide traffic in the network, cross connections are made in each separate network element.

**Design Transmission Plan** Transmission provisioning is based on a transmission plan, which must be available when the separate network elements are configured. The transmission plan shows:

- the parameters needed for making the cross connections
- which ports are terminating ports


**Figure 8-21 Example of a Transmission Plan**



The following hints can be used to set up a transmission plan:

- Make a drawing of the current network configuration (for example a ring) in which to provision a transmission path. It is important to make clear in this drawing how the network elements are connected to each other.  
Example: LB-side of network element A connected to LA-side of network element B.

**Figure 8-22 Drawing of the current network configuration**



- Identify path channels within the line connections between network elements: first check which channels are available.  
Example: Between network elements A and B: #1.153, between network elements B and C: #1.111 etc. (#1 is AU-4 number 1). A ring with *WaveStar*® AM 1 network elements is only possible on STM-1 level, therefore only #1 is available
- Identify network elements in which add-drop cross connections should be established. These are the terminating network elements of the transmission path.
- Identify terminating ports. First check which ports are available.  
Example: TP2.1 in network element A and TP1.2 in network element D.
- Identify the network elements in which through connections should be established (in between terminating network elements).  
Example: network element C.

□

## Cross Connections


**Introduction** A cross connection is made to create a path from one point to another point in the network. A transmission plan is made to provision paths in a network and according to this plan cross connections can be made in each network element involved in the path.

The Cross Connect Unit connects the signals at VC-4, VC-3 or VC-12 level between the termination points of the line ports or tributary ports.

**Cross Connect Units** The WaveStar® AM 1 network element is an Add Drop Multiplexer. Cross connections can be made between the 2 line ports and between a line port and a tributary port. It is also possible to make a cross connection with SNC/N protection.

**Diagram** The following diagrams show the transmission architecture for the WaveStar® AM 1 network element for STM-1 interfaces. The WaveStar® AM 1 network element supports STM-4 interfaces as well.


**Figure 8-23 Cross Connections on the WaveStar® AM1**



**Connection points** A cross connection is made between termination points (TP). On the tributary units a VC-12 termination point is selected. On the line units, the TU number inside the VC-4 must be selected. The TU number consists of 3 numbers:

- k: the number of the TUG-3 inside the VC-4
- l: the number of the TUG-2 inside the TUG-3
- m: the TU-12 number inside the TUG-2.

**Example:**



The following table shows the names of the termination points.


Unit	TP Type	TP name
Line 1 and Line 2 (STM-1 or STM-4)	TU-12/TU-3	LP1.1,1.[klm] and LP2.1,1.[klm]
Tributary 1 (2 Mbit/s)	VC-12	TP1.1 - TP1.16
Tributary 2 (1.5 Mbit/s)	VC-11	TP2.1 — TP2.16
Tributary 2 (2 Mbit/s)	VC-12	TP2.1 - TP2.16
Tributary 2 (34/45 Mbit/s)	VC-3	TP2.1 - TP2.2
Tributary 2 (X.21)	VC-12	TP2.1 ... TP2.4
Tributary 2 (Ethernet)	VC-12/ VC3	LAN2.1 ... LAN2.4
Tributary 2 (STM-1)	VC-4	TP2.1 — TP2.2

**TUG Structure**

A VC-12 cross connection can only be made if the TUG structure of the VC-4 (of the line unit) is structured to contain TU-12s. A VC-3 cross connection can only be made if the TUG structure of the VC-4 (of the line unit) is structured to contain TU-3s. If the TUG structure is not set correctly, the termination points will not appear in the lists to make the cross connections.

The following picture shows an example of a sub-structured VC-4

**Figure 8-24 TUG Structure**



**Alarms** The cross connections can only be created at one network element at the same time. If the termination points are monitored this will cause the following alarms: VC-4/VC3/VC12 unequipped and TU3/TU12 Loss Of Pointer. Therefore first provision the complete transmission path and then set the ports and termination points to monitored.



## Ethernet over SDH


---

**Introduction** To connect remote PC LAN network sites via an SDH network without the need for intermediate bridges or routers, the WaveStar® AM 1 plus network element is equipped with the Ethernet Interface extension card. The Ethernet Interface extension card contains four 10/100BaseT Ethernet ports (LAN ports). The LAN ports automatically determine the speed of the network, whether it is 10BaseT or 100BaseT. All valid Ethernet packets are accepted (both Ethernet 2 and IEEE 802.3). The WaveStar® AM 1plus network element can be configured in a Point-to-Point, a LAN-interconnect or a LAN-VPN configuration.

**Point—to—point** The WaveStar® AM 1plus network elements are connected in a point-to-point manner across a Wide Area Network (WAN) which is an SDH network. The ethernet traffic is thus carried across the WAN as a client of the configured SDH paths. The NE's acts as simple ethernet bridges across the WAN. The NE's runs on the ethernet in a promiscuous mode receiving every packet on the LAN and every packet is then forwarded across the configured WAN. In this point-to-point configuration each NE can contain up to 4 LAN groups each of them assigned to one end-user.

The following figure shows the Point-to-Point network topology.

**Figure 8-25 WaveStar® AM 1 network elements in Point-to-Point configuration**




The ethernet packets are carried across the SDH network in a channel. Each channel comprises up to 4 VC12 or up to 2 VC3 concatenated. These VC12s and VC3s behave in the same way as normal SDH VC12s from an E1 port or SDH VC3s from an E3 port. They are connected as point-to-point links across the SDH network to the VCs on the remote NE. There is some buffering in the NE, but it is still possible to lose packets because the channel bandwidth can be less than the ethernet traffic rate.

**LAN-interconnect**

In this configuration there are more than two NEs connected to each other. Each NE contains one or more LAN groups (V-LANs). Each LAN group is assigned to one end-user.

The following figure shows the LAN-interconnect network topology.

**Figure 8-26 WaveStar® AM 1 network elements in LAN-interconnect configuration**



The ethernet packets are carried across the SDH network in a channel. Each channel comprises up to 4 VC12 or up to 2 VC3 concatenated. These VC12s and VC3s behave in the same way as normal SDH VC12s from an E1 port respectively normal SDH VC3s from an E3 port.

This configuration mode support the following features:


- Learning bridges
- Spanning tree
- Additional SDH bandwidth and
- V-LAN.
- CID (Customer Identifier)

**LAN-VPN (M-LAN)**

In the LAN-VPN (Virtual Private Network) configuration, also mentioned as M-LAN there are more than two NEs connected to each other. Each NE contains one or more LAN groups (V-LANs) and each LAN group can be shared by more than one end-user. The end-users are assigned bandwidth by the operator. The operator also specifies a traffic policy for each end-user. The operator offers the end-users multiples of 64 kBit/s bandwidth without the cost burden of a full 2 Mbit/s link. Extra bandwidth may be added by the operator at any time.

The following figure shows the LAN—VPN network topology.

**Figure 8-27 WaveStar® AM 1 network elements in LAN-VPN configuration**



The ethernet packets are carried across the SDH network in a channel. Each channel comprises up to 5 VC12 or up to 2 VC3 concatenated. These VC12s and VC3s behave in the same way as normal SDH VC12s from an E1 port respectively SDH VC3s from an E3 port.


This configuration mode supports the following features:

- Learning bridges
- Spanning tree

- Additional SDH bandwidth and
- V-LAN (Virtual-LAN)
- CID (Customer Identifier)
- Assigned bandwidth policy (CIR = Committed Information Rate and PIR = Peak Information Rate)

**LAN ports** The LAN ports automatically determine the speed of the network (whether it is 10Base T or 100Base T). All valid ethernet packets are accepted (both ethernet 2 and IEEE 802.3). A 2 Mbit/s channel is usable for the ethernet transport if the VC-12 cross connection is made. A 34 Mbit/s channel is usable for the ethernet transport if the VC-3 cross connection is made. It is the operator responsibility to configure the bandwidth dedicated to each WAN port (2, 4, 8, 10, 50 or 100 Mbit/s).

**Cross connection termination points** The following figure shows the names of the physical ports and of the termination points used to make a (VC-12 ) cross connections:




**Loss of signal** A "Link Integrity Failure" detected at the ethernet physical layer results in a Loss of Signal defect on a 10/100Base T ethernet port (LANdLOS). When a LANdLOS occurs, the transfer of bits to and from the twisted pair physical medium shall be disabled. Test pulses are still generated/sensed. Each 10/100BaseT LAN port has a green LED, which is normally lit. In case of a LANdLOS the green LED is off.

### LAN groups, V-LAN, LAN ports and WAN ports

A LAN group can contain multiple LAN ports and multiple WAN ports.

**Figure 8-28 Relation LAN ports, WAN ports and SDH channels**



Multiple LAN ports can be assigned to different LAN groups, also mentioned as Virtual LAN's (V-LAN). This keeps the traffic on each V-LAN totally separate. LAN groups are used to connect LAN ports and WAN ports. The LAN ports are the physical 10BaseT or 100BaseT Ethernet ports on the NE. The WAN ports are the logical connection points to the SDH channels. The LAN port is the interface between the customer's ethernet LAN and the ethernet switch on the LAN unit. The WAN port is the internal port between the ethernet switch and the part of the LAN unit where the ethernet frame is mapped into or demapped from SDH payloads.

The following configurations are possible:

- point to point (one LAN, one WAN)
- point to multipoint (one LAN, multiple WANs)
- multipoint to point (multiple LANs, one WAN)
- multipoint to multipoint (multiple LANs, multiple WANs)
- local bridge (multiple LANs, no WAN).

### WAN ports and SDH channels

The Ethernet packets are carried across the SDH network in a channel.

Each SDH channel associated with a LAN group can be connected to a number of SDH containers which provide a path across the SDH network. The following types of containers are supported:

- VC-12
- Virtually concatenated VC-12
- VC-3
- Virtually concatenated VC-3

The VC-path which is used as a channel for the ethernet packets transport can be monitored as a normal SDH connection. The standard SDH protection scheme SNC and MSP may be used. The only limitation is that only bidirectional point-to-point paths may be used, because the data network expects to use the SDH path as a bidirectional data link.


**Virtually concatenated VCs  
(additional SDH bandwidth)**

The channel that carries the encapsulated Ethernet packets across the SDH network channel can be a virtually concatenated VC-3 or a virtually concatenated VC-12. Virtual concatenation is a mechanism by which a number of independent VCs can be used to carry a single payload with a size greater than one VC-3 or VC-12. Virtual concatenation breaks the contiguous bandwidth (a concatenated C3 or C12 container) into individual VCs, transports them individually and recombines the VCs again to a contiguous bandwidth at the end point of the transmission path. Virtual concatenation requires only concatenation functionality at the path termination network elements. When a virtually concatenated VC-3 or VC-12 path is used, the remote WAN port must receive all elements of the concatenated signal within a fixed time interval. This means that the concatenated signals must be routed (and protected) all in the same way. At the end of the path, each VC-3 or VC-12 must be realigned and connected symmetrically back to the same WAN port (in the same sequence). Therefore each VC-3 or VC-12 is assigned a sequence number to verify that the connection is made correctly. The payload is mapped into the VC-3s or VC-12s in this sequence. On each trail termination point (TTP) the actual (accepted) and expected or transmitted sequence number can be checked.

The term VC-3-Xv is used to indicate a virtually concatenated VC-3. X is the number of concatenated VC-3s. X = 2. The term VC-12-Xv is used to indicate a virtually concatenated VC-12. X is the number of concatenated VC-12s. X = 2, 3, 4 or 5..

**Learning bridges** To increase the efficiency of the network a network can be separated in segments. A bridge passes packets between multiple network segments. A bridge can have several ports. By noting at which port an Ethernet packet with a certain source address arrives, the bridge learns to which ports a packet with a certain destination address must be sent. If the port does not know the destination address it will send it to all the ports except the port where it comes from. The tables which the learning bridge uses to pass the Ethernet packets to its ports are not shown to the user by the management systems.

**Figure 8-29 Example of a learning bridge with multiple ports**




Example: After the bridge has received a packet from station C it knows that station C is attached to port 2. When the bridge knows to which ports a station is attached, it will send packets with destination addresses of these stations only to the port the station is attached to (e.g. a packet from station B to station C is only forwarded to port 2). When a destination address of a packet is of a station in its own segment, the packet is not forwarded by the bridge (e.g. a packet from station D to station E).

**Spanning tree** If more than one bridge is used between segments of the network a bridging loop occur, which cause packets to circulate forever. The spanning tree algorithm avoids the occurrence of these bridging loops. The spanning tree algorithm elects a root node and makes sure that each bridge blocks its ports in such a manner that there is only one path from any given point on the network to the root. In this way a mesh network is reduced to a tree which spans every node. The WAN part of the network formed by the NEs maintains its own spanning tree, independent of the spanning tree maintained on the customer's LANs. Thus the spanning tree protocol behavior is different on the LAN side and the WAN side of an NE. Note that users have no way to know which is the root.

Due to the spanning tree algorithm meshed configuration can be made to enhance availability (alternative channels if one fails). If multiple VC-n paths are provisioned between two nodes, the spanning tree algorithm closes down SDH channels to avoid loops. Thus the increase of bandwidth for payload due to multiple VC-n paths may not be as expected. So, to increase the capacity of the path use virtual concatenated VC-3s or VC-12s in stead of multiple VC-3 or VC-12 paths.

**Figure 8-30 Example of SDH ports that are switched off due to the spanning tree algorithm**



**Customer identifier**

To allow a system to identify which LANs belongs to each end-user, each user's LAN port are assigned a Customer Identifier (CIR).

**Assignment of bandwidth and assigned bandwidth policy**

Each LAN port is assigned a data rate which the customer can rely on being available called the Committed Information Rate (CIR). This information is provisioned per LAN port and applies to the rate of data which is inserted at that port. Each LAN port of a V-LAN may have different CIRs assigned.

If a end-user exceeds the assigned CIR, the NE's behaviour depends on the chosen bandwidth policy mechanism for that port. a choicse can be made between:

- Strict policy; any packet above the CIR will be dropped
- Oversubscription mode; any packets above the CIR will be carried over the network if there is bandwidth available.


**Port names** The following table shows the names of the physical and logical ports used for the TransLAN plus card.

Port Type	Name	Description
Physical Port	LAN2.a	a is the port number. The port number can be 1 to 4.
VC-12 Termination point	TP2.1klm	klm specifies the TU position in a fixed so-called VC-4. The number before the klm number is always 1. These TPs are the connection point for the cross connections
VC-3 Termination point	TP2.1klm	klm specifies the TU position in a fixed so-called VC-4. The number before the klm number is always 1. These TPs are the connection point for the cross connections
SDH Channel	SDHChan2.b	b can be 1 to 4. This is the same number as in the associated logical WAN port
WAN Port	WAN2.b	b is the same number as in the associated SDH Channel (1 to 4)
LAN Group	LANGRP2.c	c is the number of the LAN group (1 to 8)

The following diagram shows the relation between the ports

**Figure 8-31 Ports for LAN Unit**

Connected to TU-3s  
 associated with VC-4



□

## VC-3 Concatenation

---

**Introduction** The concatenation of two VC-3s provides a mechanism to transport payloads greater than the capacity of a single VC-3, for example to transport ethernet data in SDH networks. This feature is for the LAN tributary only.

A concatenated VC-3 group is indicated as VC-3-2v. V means virtual concatenation.

**Virtual Concatenation** Virtual concatenation allows the transport of a single VC-3-2v structure in 2 individual TU-3 without the use of any concatenation indication in the pointer bytes (which is the case for contiguous concatenation). It only requires the path termination function to provide concatenation functionality, hence guaranteeing interworking with other standard low order connection functions.

**Termination** VC-3 concatenation is only supported without termination. This means that only VC-3 level cross connections can be made.

A VC-3-2v signal is handled like two individual VC-3 signals. The same alarms and performance values are supported as for VC-3. The result of the VC-3-2v supervision is copied into the two VC-3s.

- An alarm in an VC-3-2v group is displayed as one alarm for the entire group.
- Two VC-3s can have different path and path trace.



## VC-12 Concatenation

---

**Introduction** The concatenation of two VC-12s provides a mechanism to transport payloads greater than the capacity of a single VC-12, for example to transport ethernet data in SDH networks. This feature is for the LAN tributary only.

A concatenated VC-12 group is indicated as VC-12-xv. V means virtual concatenation. X can be 2,3,4,5.

**Virtual Concatenation** Virtual concatenation allows the transport of a single VC-12-xv structure in x individual TU-12 without the use of any concatenation indication in the pointer bytes (which is the case for contiguous concatenation). It only requires the path termination function to provide concatenation functionality, hence guaranteeing interworking with other standard low order connection functions.

**Termination** VC-12 concatenation is only supported without termination. This means that only VC-12 level cross connections can be made.

A VC-12-xv signal is handled like X individual VC-12 signals. The same alarms and performance values are supported as for VC-12. The result of the VC-12-xv supervision is copied into the X VC-12s.

- An alarm in an VC-12-xv group is displayed as one alarm for the entire group.
- X VC-12s can have different path and path trace.

□

## Multiplexer Section Protection

---

**Introduction** Multiplex Section Protection (MSP) is used to protect the traffic in a point-to-point connection. A requirement for this kind of protection is that the transmission lines are doubled. Multiplex Section Protection is only applicable for WaveStar® AM 1 network element configurations with STM-1 interfaces.

**Definition** MSP provides the capability for switching the transmission path from the working section to the protection section in a point-to-point connection. The protection line can not be used for carrying low priority traffic.

**Objective** To protect a multiplexer section in a point-to-point connection.


**Outcome** A protection setting to protect the transmission path against transmission failures in a point-to-point connection (MS-AIS, LOF, MS-DEG) and port equipment failures.

**Principle** In a point-to-point connection between network elements, protected by MSP, the lines must be doubled. One pair is selected as a designated worker and the other pair is designated protection. The capacity in the protection or stand-by section must be reserved but is not available for traffic.

Simply put, the protection or stand-by section carries the same traffic as the worker section and it can not be used for carrying any other kind of traffic.

A trail continues to use the working route until a fault condition occurs or a external switch request is issued to switch to the protection route.

**Figure 8-32 Example of MSP protection.**



**Revertive** In the case of failure when in the Revertive mode the traffic switches to the protection line and switches back when the failure is solved.

**Non-Revertive** In the Non-Revertive mode the traffic switches to the protection line and remains on the protected line even when the failure is solved.

**Bi-directional** In the case of failure in the Bidirectional mode both sides, the transmit and receive, are switched.




## Sub Network Connection Protection

---

- Introduction** Sub Network Connection (SNC) protection is used to protect the traffic for a pre-selected path (path protection). This type of path protection can only be used for VC-3 and VC-12 level.
- Definition** SNC protection is characterized by sending the signal in both directions. When a fault condition occurs the receive NE switches to the protecting line. The capacity for protection can not be used for any other traffic.
- Objective** To be able to protect every provisioned path on an individual basis within a subnetwork.
- Outcome** A provisioned subnetwork containing individually paths that are 1+1 protected against service failures.

**Principle** Sub Network Connection (SNC) protection switching deals with protection against transmission failures in and between Ring Add/Drop NEs. One leg is selected as a designated worker and the other leg as a designated protecting. This means that the capacity is used for protection even if the normal route is available. A trail continues to use the working route until a fault condition occurs or an external switch request is issued to switch to the protecting route. This type of protection is non revertive. This means that when a traffic failure in the working route has been cleared, traffic will remain on the protection route until a manual or forced switch is applied, or when a failure occurs on the protection line. This behavior is irrespective of any service restoration in the working route.

**Figure 8-33 Example of SNC protection**



**SNC/I** Sub Network Connection Inherent protection or SNC/I monitoring. The switching criteria for SNC/I are based on signal failures. Signal failures that cause SNC/I protection switch are: AIS (Alarm Indication Signal), UNEQ (unequipped VC), TIM (Trace Identifier Mismatch), TU-AIS and TU-LOP (Loss of Pointer).

**SNC/N** Sub Network Connection Non-intrusive protection or SNC/N monitoring. The switching criteria for SNC/N are based on both signal failures and signal degrade. Signal failures that cause SNC/N protection switch are the same as for SNC/I: AIS (Alarm Indication Signal), UNEQ (unequipped VC), TIM (Trace Identifier Mismatch), TU-AIS and TU-LOP (Loss of Pointer). Signal degrades that cause SNC/N protection switching are based on the number of Errored Blocks detected during a certain period. The Threshold that defines when a signal is declared degraded can be set by the user.

The WaveStar® AM 1 only uses SNC/N Protection.



## Section: Traffic Maintenance Concepts

### Overview

---

**Purpose** This section explains the concepts of the maintenance settings that can be done for transmission. The information in this section can be used as background information for provisioning these settings. The following concepts are described in this section:

- Port Types
- Termination Points

The concepts of MSP and SNC protection are described in the chapter “Path Provisioning and Protection”




## Port Types

---

**Introduction** A Port is an interface point for signals. A distinction can be made between physical and logical ports. At the logical port the overhead bytes are terminated: in the transmit direction overhead bytes are added, in the receive direction overhead bytes are extracted. Therefore logical ports are also called Termination Points.

**Figure 8-34 Physical and Logical Ports**



**Physical ports** The WaveStar® AM 1 network element contains two STM-1/4 line ports and 1 or 2 tributary port units. The first tributary unit has sixteen 2 Mbit/s ports, The second tributary unit is an optional extension unit.

The following table shows the different types of extension units with its port types and number of ports


Extension Unit	number of ports
1.5 Mbit/s	16 x 1.5 Mbit/s (DS1)
2 Mbit/s	16 x 2 Mbit/s (E1)
34 Mbit/s	2 x 34 Mbit/s (E3)
45 Mbit/s	2 x 45 Mbit/s (DS3)
X.21	4 x 2 Mbit/s
TransLAN™ Plus	4 x 10/100 BaseT Ethernet
STM-1 1330 nm SH	2 x 155 Mbit/s

**Port Names** The name of the physical ports consists of two parts separated by a dot. The first part is related to the slot name, the second part is the port number within that slot.

Example: LP2.1, TP1.3

The name of the logical ports consists of the physical port name followed by the AU-4 number and for low order signals, the VC number (VC-12 or VC-3). The VC number consists of:

- the number of the TUG-3 inside the VC-4
- the number of the TUG-2 inside the TUG-3
- the TU-12 number inside the TUG-2.



### Test Loops


An incoming test loop can be set on the 1.5 Mbit/s, 2 Mbit/s, 34 Mbit/s, 45 Mbit/s and X.21 ports. The input signal is directly routed back to its corresponding output without altering the signal format. This loop can be used to test the connectors. Only one inloop can be set at the same time.

An outgoing test loop can be set on the 1.5 Mbit/s, 2 Mbit/s, 34 Mbit/s, 45 Mbit/s and X.21 ports. The output signal is directly routed back to its corresponding input without altering the signal format. This loop can be used to test how the signal passes through the system.

If an testloop is enabled, the **Abnormal** state is activated. After disabling the testloop the cross connections that existed before setting the testloop are restored.

Setting a testloop is achieved by making a unidirectional cross connection. The termination points of the source and the sink are the same. Setting testloops is only possible on VC-3 and VC-12 level.

**Figure 8-35 Test Loop for Physical Ports of 2 Mbit/s Port Units**



□

## Termination Points

**Introduction** In the termination points the path overhead bytes of the VC-4, VC-3 or VC-12 signal is terminated (added or removed). In the AU-4, TU-3 and TU-12 termination points the path overhead is not terminated, but can be monitored.


The following information can be retrieved from the path overhead:

- a Trail Trace Identifier (TTI), used for path trace
- a Signal Label, indicating what type of signal is carried
- error checking information, a threshold can be set to determine in case of how many errors a signal is declared degraded

**Alarms** When a termination point is set to *Monitored*, alarms related to this termination point are reported. A termination point is set to *Not Monitored* (alarms are not reported) when it is not used.

### Path Trace

**Figure 8-36 path trace on termination points**



To check whether a path is correctly provisioned a path trace can be set. A label (for example a word) is sent along the path from one termination point to the other. This label is called *Trace Identifier* (TI). If the TI is a specific string, this string is called *Access Point Identifier* (API). If the expected API equals the accepted API, the transmission path is well provisioned.

In the path overhead of a VC-4/VC-3 signal, byte J1 in the regenerator section is used for the TI. For a VC-12 signal, byte J2 is used. A 16 byte frame is formed of which one byte is used for error detection. Therefore the string that can be inserted in these bytes has a maximum length of 15 characters (or 30 hexadecimal digits).

**TIM Detection** If the *Trace Identifier Mismatch* (TIM) detection is enabled, traffic will be lost when a mistake in the trace string is detected. Upon mismatch, an *Alarm Indication Signal* (AIS) is inserted in the downstream signal and a *Remote Defect Indicator* (RDI) is inserted in the upstream signal.

**Signal label** The signal label contains information about the signal that is part of the VC. The signal label indicates whether the VC is unequipped, whether it is a structured signal, which type of mapping is used or whether it is an AIS (Alarm Indication Signal).

**Signal Degrade Thresholds** The signal degrade threshold can be set for the Multiplex Section (MS), VC-12, VC-3 and VC-4 levels. The signal degrade threshold determines when a signal is considered degraded. Two parameters can be set:

- number of errored blocks per second
- number of adjacent bad seconds.

The signal is considered degraded, when during the defined number of bad seconds the signal contains more than the defined errored blocks per second. This causes an alarm STM-n Moderate Block Error Rate (n is 0,1 or 16) or VC-n Moderate Block Error Rate (n is 12, 3 or 4).

On VC-12, VC-3 and VC-4 level the signal degrade threshold is also used as a switching criterion if SNC/N protection switching is used. When the signal is determined degraded an SNC/N protection switch is performed.

□

## Section: Concepts of Software Upgrade

### Overview

---

**Purpose** This section describes the background information necessary to perform the procedures for upgrading the software.



## Software Upgrade of a WaveStar® AM 1 plus

**Introduction** The controller software of the network element is stored on the controller unit of the network element. To upgrade this software the new software must be downloaded on the network element. This can be done from the ITM-SC or from the ITM-CIT.


**System Controller Software** The System Controller contains the software to control and support the network element. The Manufacturers Executable Code (MEC) file contains the complete software package for one network element. The software in the system controller is also used to provide a basic configuration to the units connected to the system controller. These other units obtain the appropriate part of the software package from the System Controller during the system start-up or when a unit is inserted.

**Two Memory Stores** On the System Controller of the WaveStar® AM 1 plus are two memory stores that can contain each a different MEC. The store with the software that is executed is called the active store and the other store is called the backup store. In case of a software upgrade, the management system downloads a complete software package to the backup store of the System Controller.

**Switch Stores** With a switch command from the management system, the software in the backup store can be made active. The switch command switches between the two stores, thus the active store becomes the backup store and vice versa.

**Diagram** This diagram shows the software stores in the network element.

**Figure 8-37 Software Stores in a network element**



**Commit the Software**

After confirmation of a switch command between the active and backup store, the management system loses its association with the network element for approximately one minute. If the management system can renew the association with the network element the active store is committed. If the active store is not committed within two hours after the switch, the network element will switch back to the old software load.







# 9 Using the ITM-SC Interface

## Overview

---

- Purpose** Using the ITM-SC interface provides information on how to use the Integrated Transport Management-Subnetwork Controller (ITM-SC).
- Objectives** To customize or change settings of the ITM-SC Interface according to the users needs.
- Outcome** Be able to work with the ITM-SC Interface.
- Intended Use** This chapter contains four sections. The first section described the HP-View specific subjects. The other sections describe the subjects which are more ITM-SC specific, such as Module description, general ITM-SC tasks and the Network Map.
- Each section starts with a conceptual explanation and, if available, this is followed by a procedure.



## Section: HP-Vue Specific Subjects

### Overview

---

- Purpose** This section describes the more HP-Vue specific subjects such as:
- Buttons and Mouse usage.
  - The general software modules.



# Front Panel


**About the ITM-SC Front Panel**

To navigate and control the ITM-SC application, the HP graphical user interface (GUI) displays a front panel. Depending on the user class, a number of different icons on the front panel give access to the different modules of the application. The procedure to open or close a module is explained and a short description of the modules is given.

The front panel window is different for administrator, supervisor and operator.

**System Administrator Front Panel**

The front panel of the system administrator is shown below.



□


## General Modules

---

**Purpose** General modules available to each user are described below. For more information about the general modules can be found in the on-line documentation via the Help button. Refer to System Administrator Front Panel to locate the buttons and modules.

**Help Manager** The Help Manager provides access to online help for HP-VUE. This information includes coverage of workstation controls and tool use.

The Help Manager menu is shown below.




**Print Manager** The Print Manager makes it possible to:

- Check the status of a print job.
- Cancel a print job.

The Print Manager Menu differs depending on the printers that are defined with the System Administration Manager (SAM). (Refer to the Subnetwork Installation Guide).

The Print Manager icon gives access to a menu of available printers.



**Workspace Switch** The Workspace Switch provides greater workspace flexibility by using a virtual window on which multiple windows can be created.

Several workspaces can be selected on the workstation, however only one of these is shown on the physical window at a time.

**Style Manager** The Style Manager makes it possible to customize visual elements and the workstation behavior. Select the Style Manager icon to access the menu for customizing.

Icons on the Style Manager menu are described below:

Menu Option	Function
<i>Color</i>	Sets workspace colors and palettes.
<i>Font</i>	Sets HP-VUE font sizes.
<i>Backdrop</i>	Sets workspace backdrop pattern.
<i>Keyboard</i>	Sets keyboard click volume and character repeat settings.

<b>Menu Option</b>	<b>Function</b>
<i>Mouse</i>	Sets mouse left or right handed control, button click settings, double click speed, pointer acceleration and pointer movement threshold.
<i>Audio</i>	Sets beeper volume, tone and duration.
<i>Screen</i>	Sets number of minutes before the window times out to prevent burn out of the monitor, and set password protection at time out.
<i>Window</i>	Sets the way windows are opened and activated.
<i>Startup</i>	Sets the start up and ending of a session.

### Screen Saver Options

A screen saver will protect the terminal window from burned-in images and enhances security by blanking the screen. Note that a screen saver does not password protect the screen. When requiring a password lock activate the screenlock as well.

The Screen Saver is invoked when no keyboard or mouse activity occurs after a predetermined time. Applications active when the Screen Saver is invoked remain open. However, those applications are subject to their time-out restrictions.

Screen Saver properties can be set only when the user is logged in as root. The ITM-SC Administrator as well as the other ITM-SC users do *not* have the rights to change these settings.

The Screen Saver time-out can be set from 1 minute to 120 minutes. Options for the screen saver are described below:

<b>Option</b>	<b>What It Does</b>
<i>Time-out</i>	Specifies the time interval (from 1 to 120 minutes) from the last mouse move or keystroke to when the window times out. The slider control decreases or increases the number of minutes.
<i>Full Screen Cover</i>	Determines whether or not to completely cover the window when Lock is used from the front panel.

### Terminal Window

The Terminal icon provides access to a terminal window.

A terminal window is a screen that allows HP-UX commands to be executed.



## Buttons and Mouse Movement

---

### Button Names and Functions

The ITM-SC guides the user through the system by means of windows. These windows can contain the following buttons:

Button	Function
Apply	Executes the changes made. The window remains open to permit similar action.
OK	Accepts or executes changes and closes the window.
Edit	Provides the option to change data in shown data entry fields. A different window can be displayed.
Close	Closes the window and resumes normal operation of the application, without changes.
Print	Prints the information to the selected output.
Help	Provides additional information through the context-sensitive on-line help.
Cancel	Cancels the selected action or changes.

### Using the Mouse

Mouse movements are described in the table below:

Movement	Function
Select	Select an object or menu item, click the left button (default) on the mouse with the pointer on the object.
Drag	<p>To move an object to an other location, select the object by using the left button (default). Then click it with the middle mouse button and hold that button down, while moving the mouse.</p> <p>To move a group of objects to another location, use the left button to define a box over the group of objects and move the box.</p> <p>Moving of a group can also be done by pressing <b>Ctrl + left mouse button</b> to select each object of the group. Then click it with the middle mouse button and hold that button down, while moving the mouse.</p>
Menu	To display a menu that is associated with the pointer location or the selected object, click the right button (default) of the mouse.



## Section: ITM-SC Specific Modules and Windows

### Overview

---

**Purpose** This section describes subjects which are more ITM-SC specific. Subjects described in the section are:

- ITM-SC specific modules
- General ITM-SC windows
- Main EMS menu window



## Accessing the ITM-SC Specific Modules

---

- Module Icons** Some of the modules on the frontpanel have submenus for accessing one or more applications. The Management and Administration module both contain several applications.
- Opening a Module** Select the triangle just above the modules to open the modules.
- Closing a Module** Modules can be closed by selected closing the window (or **ALT-F4**) or by selecting the triangle at the bottom of the menu.



## Management Module

- Purpose** Through the Management Module the operator has the choice to:
- Start the network element management.
  - Monitor a number of ITM-SCs for raised alarms.

**Management Menu** The Management menu provides options for managing network elements.




**Menu Options** Selections on the Management menu are described below:

Menu Option	Function
<i>Default ITM-SC NE Management</i>	Default ITM-SC NE Management allows the user to access the default ITM-SC server.
<i>Any ITM-SC NE Management</i>	Any ITM-SC NE Management allows the user to access any ITM-SC server.
<i>Alarm Monitor</i>	Alarm Monitor to configure, start and stop the monitoring of listed ITM-SCs for raised alarms. This is only relevant for a multi-server configuration.
<i>Set Admin/Default ITM-SC</i>	Set Admin/Default ITM-SC allows the user to change the default ITM-SC server.
<i>Change Password</i>	Change password allows to change the ITM-SC password of the user currently logged in.

## Administration Module

**Purpose** The Administration Module is only accessible when the administrator is logged in. This module gives access to the ITM-SC administration tasks.

**Administration Menu** The Administration menu is shown below:



**Menu Options** The Administration menu options are described below:

Menu Option	Function
<i>User Administration</i>	Add, delete or modify user logins.
<i>System Administration</i>	Start or stop the ITM-SC application.
<i>DCN Data</i>	Manage the Data Communications Network data.
<i>Log File Administration</i>	View or delete ITM-SC logins.
<i>Backup/Restore Database</i>	Backup or restore the application database.

<b>Menu Option</b>	<b>Function</b>
<i>Licences</i>	Enter or change licence information.
<i>Alarm Monitor Configure</i>	Configure a selected server to provide system alarm monitoring information.
<i>Set Admin/Default ITM-SC</i>	Select the server to which the subsequent administration commands are applied to.
<i>Password Ageing</i>	Enable/disable the password ageing parameters.
<i>Message Of The Day</i>	Enable/disable the message of the day parameters.
<i>Illegal Access Monitor</i>	Enable/disable the illegal access monitor parameters.



## General ITM-SC Windows

---


**Introduction** The Element Management System (ITM-SC) contains four types of windows:

- EMS-Menu.
- Selection Dialog window.
- Information window.
- Edit window.

**Button Names and Functions** The ITM-SC guides the user through the system by means of windows. These windows can contain the following buttons:


Button	Function
Apply	Executes the changes made. The window remains open to permit similar action.
OK	Accepts or executes changes and closes the window.
Edit	Provides the option to change data in shown data entry fields. A different window can be displayed.
Close	Closes the window and resumes normal operation of the application, without changes.
Print	Prints the information to the selected output.
Help	Provides additional information through the context-sensitive on-line help.
Cancel	Cancel the selected action or changes.

**Information Window** An Information window makes it possible to change or view information of a component (for instance a node).




It is possible to click on the selection dialogue button to select a specific NE. When clicking the selection dialogue button a list with node names appears. From this list a node can be selected to edit or view the nodes information.

**Edit Window** An Edit window makes it possible to edit the data of a network element. The message field will display information about the action performed by the ITM-SC.



**Selection Dialog Window** The Selection Dialog window makes it possible to select a NE, slot, port, termination point, time, date etc. out of a list. The chosen items will be used to edit the characteristics of the item or filter lists by means of the item.

This example window below provides a list of network elements.



To speed up the search for an item the Search Pattern can be used. When using the Search pattern and when a match for the typed selection is found, the found item is highlighted in the list. When more than one match is found, the first match is marked with a diamond symbol.

□


## Main EMS—Menu Window

**Introduction** The EMS - Menu window is the main window of the ITM-SC application. The EMS - Menu contains several fields that either provide information about the current status of the network element, or that can be used to manage the network element.

**Parts of the EMS - Menu** The EMS - Menu can be divided into three parts:


- Menu Bar.
- Alarm Summary.
- Network Map.


The picture below distinguishes the 3 parts.





**Menu Bar** Via the Menu Bar it is possible to manage the network element. It consist of several buttons that have one or more submenus attached to it. By clicking a menu bar button, the submenus will scroll down and the submenu that is required can be selected. These submenus can, on their part, contain several sub-submenus as well.


**Menu bar structure** The structure underlying the menu bar is as follows:











**Alarm Summary** The Alarm Summary provides an overview of the alarms risen on both the NEs and the NE management system. A more detailed description of the alarm summary can be found in the chapter “Event Management”.

**Network map** The Network Map is the main window for managing all NEs within the subnetwork and gives direct information about NEs their status. A more detailed description of the Network Map can be found in the section “Network Map” of this chapter.



## Section: ITM-SC General Tasks

### Overview

---

**Purpose** This section describes subjects which are ITM-SC related such as:

- Accessing the ITM-SC.
- Changing of ITM-SC passwords.
- ITM-SC Reports
- Log out of the ITM-SC.



## Parameters for Accessing the ITM-SC

---

**Login** Before the ITM-SC application can be started the user needs to login.

**Window to use** The following window is used to login into the ITM-SC.



**Login and Password** The login or user name has up to 8 alphanumeric characters (a..z, A..Z, 0..9). The Password requires a minimum of 6 characters (a..z, A..Z, 0..9 and other printable characters e.g. - \* +) with at least 2 alphabetic characters and at least 1 non alphabetic character.

**Button Description** Buttons on the window are described below:

Button	Function
OK	Confirms the start of the login after filling in the “Login” and “Password” fields.
Start Over	Removes data from the “Login” and “Password” fields. Lets the user begin the login procedure again, without registering a login attempt. Clear is quicker than backspacing, which can also be used.
Options	Displays a menu containing Restart Server, Copyright, Fail-safe Session, HP-VUE Lite Session, HP-VUE Session and Languages. These items are HP specific and control features of the workstation and what happens after login. For more information about the selectable items, refer to the HP system documentation.
Help	Provides information on how to login.



## Accessing the ITM-SC

---

**Purpose** To login in to the ITM-SC.

**Related information** For more information on the parameters used refer to:

- Parameters for Accessing the ITM-SC

**Procedure** Perform the following procedure to Log in to the ITM-SC.

---

**1** Enter Login (user name) and click OK or press **ENTER**.

---

**2** Enter password. Click OK or press **ENTER**.

**Result:**

If the login is successful, an HP copyright message appears.  
After this the Front Panel appears.

An “Incorrect Login” message appears when the login or password entered is incorrect. Press **ENTER** or click OK when this message appears. After this the login process can be restarted.

END OF STEPS

---



## Changing Password

---

**Purpose** To increase the security of the ITM-SC and its network managed the user is able to change his/her own ITM-SC password.

**Before you begin** In this procedure a shell window is provided to change the password. A script will guide the user through the change of password.

**Related information** Related procedures are:

- Modifying ITM-SC User Information
- Configuring Password Ageing.

**Procedure** Follow the script below to change the ITM-SC password.

---

- 1 Open the *ITM-SC Management* menu and select the *Changing Password* icon.

**Result:**

A shell window appears asking the user for the current password.

---

- 2 Enter the current password. Press **ENTER**.

**Result:**

The user is asked to enter a new password.

---

- 3 Enter a new password. Press **ENTER**.

**Result:**

The user is asked to re-enter the new password.

---

- 4 Re-enter the new password. Press **ENTER**.

**Result:**

If the new password is accepted the following message will appear: Password has been updated successfully. The shell window will disappear automatically.

END OF STEPS

---



## Report Concepts

---


**Background** When selecting anywhere in the ITM-SC the **Print** button, system information that is shown in that window, can be sent to two different outputs. It can be printed directly to a printer or to a file (a report). A report will be stored on the ITM-SC for later use.

**File directory and format** If a report is created a file, representing the report, is stored on the ITM-SC.

The location of these files is: `/var/spool/itm/sc/reports/<ServerName>/` where `<ServerName>` is the name of the server. The format of these files are ASCII.

**Limited printing capacity** When printing long reports, only the first 2000 lines will be printed. The user will be notified if the report is not printed entirely.

**Report Printing window** The Report Printing window allows the user to decide which type of output is generated.




**Fields to Use** Use these fields to determine the print output:

Field	Description
<i>Report Destinations</i>	Shows the possible outputs: Printer or File. <i>Print to Printer Only</i> is the default setting.

Field	Description
<i>Print Options</i>	Is only highlighted if <i>Print to Printer Only</i> is selected. The Printer Name is the name of the default printer, but if an other printer is required, its name can be entered. The number of copies can also be entered.
<i>File Options</i>	Is only highlighted if <i>Print to File Only</i> is selected. The name of the file to print to can be entered. Note that if the entered file name already exists, the old file will be overwritten!

**Report Browser window** The Report Browser window is used to view the reports stored on the ITM-SC system.



- Report Options** Use the *File* menu of the Report Browser to:
- Browse online or hardcopy a report.
  - Rename a report.
  - Copy a report to another device, such as computer disk.
  - Delete a report.
  - View the report names of all the users.



## Printing a Report

---

**Purpose** To store or print all kinds of system data for evaluation.

**Related information** The related concept is:

- Report Concepts

**Procedure** Perform the following procedure for printing data by a selected printer.

---

**1** Click on the **Print** button in the information window from which the data is to be printed.

---

**2** Select the desired output device.

If the output device is a printer, enter the number of copies and, if needed the name of the printer.

If the output device is a file, enter the file name.

---

**3** Click OK.

**Result:**

The report will be printed. Note that the only the first 2000 lines will be printed of reports which exceed this limit.

END OF STEPS

---



## View a Report

---

**Purpose** Use this procedure to view the information that has been printed to files.

**Related information** The related concept is:

- Report Concepts

**Procedure** Follow these steps to browse a report:

---

- 1 Select *File -> Reports -> Browser*.

**Result:**

The Report Browser window appears.

---

- 2 Select the Report Name from the list of report names. When no reports are shown select View and All or User successively.
- 

- 3 Execute the desired operation.
- 

- 4 After operating on the file select *File -> Close* to complete the procedure.

END OF STEPS

---




## Logout of the ITM-SC

---

**Background** When the user has completed his work on the ITM-SC, he or she can log out of the Graphical User Interface. Then unauthorized users will not be able to access the ITM-SC.

**Security** In the style manager the administrator can enable logout confirmation, so an accidental logout can be prevented. Furthermore, an administrator is the only user that can make lasting changes in the style manager. Any changes to settings made by other users are lost at logout.

**Windows to Use** To log out of the system, the Logout icon and the Logout Confirmation window (optional) are used.



□

# Logout

---

**Related information** The related concept is:

- Logout of the ITM-SC

**Procedure** To logout perform the following procedure:

---

- 1 Click on the Logout icon.

**Result:**

If provisioned, the Logout confirmation window appears. A confirmation is then requested to make sure that the session has to be ended.

---

- 2 Click OK.

**Result:**

After confirming, the login window is displayed until the workstation time-out threshold is reached, then the screen saver appears and the log out procedure is completed.

END OF STEPS

---



## Section: ITM-SC Network Map

### Overview

---


**Purpose** This section will give an description of the features and use of the Network Map as well as provide some tasks to manage the Network Map.



## ITM-SC Network Map Concepts

**Introduction** After activating Network Element Management from the Management Module, the Subnetwork Map window is displayed. This window is the main window for managing all network elements within the subnetwork and gives direct information about network elements, their status and Map groups.

**Example of Network Map** An example of the Network Map is shown below.




**Network Map Icons** The Network Map icons are described in the table below:

Icon	Name	Description
	Up	To go up a group from the current group (unless at top-level already). Changes the display to show the group.

Icon	Name	Description
	Con- nec- tions	This button will toggle the display of the RR connectivity lines. Note: only applicable for Radio Relay NEs.
	Display groups	Toggles the display between the contents of groups and the group icon. This also can be done by pressing control (CTRL) and selecting the Group or NE.
	Modify groups	Used to modify the grouping of network elements. This also can be done by selecting and NE or Group together with the right mouse button. Select from the pop up menu Modify Map Grouping of Nodes

**Network Element Icons** The following icons represent the different types of network elements in different statuses.

	Add/Drop Multiplexer STM 1	Ring Drop & Insert 2 Mb	Regenerator	Terminator	Dual Facing Terminator	Cross Connect
Normal						
Geographic Redundancy						
Lining Up						
Lining Up + Geographic Redundancy						

**Map Group** A Map Group is a group of NEs which are put together because they are geographically or functionally related.

**Group Icon** The following icon represents a group of nodes:



**NE Status** The color of each icon on the window represents the current status of the network element or connection. If two conditions exist for the same network element or connection, the network element icon or line is colored to indicate the condition with the highest severity. All alarms of the entire subnetwork are shown in one window; this is sometimes called the Alarm Map.

**Colors of Alarms** The list below describes alarm colors and severity or status.

Color	Meaning
White	The NE or Connection is currently selected.
Grey	No current 'associations' exist with the NE or Connection. An association exist when there is communication between an ITM-SC and an NE.
Red	A 'Prompt Alarm' is currently on the NE or Connection.
Yellow	A 'Deferred Alarm' is currently on the NE or Connection.
Orange	An 'Information Alarm' is currently on the NE or Connection.
Green	No alarms currently on the NE or Connection.
Blue	The node has been pre-provisioned.

**Additional Alarm Information** Additional information about an alarm can be given by the flashing square or "outlined" icon:

Action	Description
Flashing square	The alarm is not acknowledged yet. This is valid to each NE type but not for connections.
Outline	The network element is protected under Geographic Redundancy by this ITM-SC, but is not managed currently by this ITM-SC. This ITM-SC is not associated with this network element, so the outline is shown in grey. Valid for each NE type.
Short Beep	Indicates the arrival of a new alarm.

**Specific Actions on the Network Map** Information about network elements or connections can easily be obtained using the Network Map. The alarms display can be filtered in such a way that only alarms of the selected network element or connection are shown.

To ..	Do this ..
-------	------------

Select an NE or group of NEs	Click once on the specific item.
Select multiple NEs	Press shift and draw using the cursor to make a rectangle over all NEs to select. This can also be done by pressing Ctrl and clicking with left mouse button on the desire NEs
Clear all selections	Click once on the Network Map outside any node or group.
Retrieve the alarm list of a NE or connection	Double click left-button on the specific NE or connection.
Drag selected nodes/groups	select nodes/groups and hold middle mouse button and drag to new position.

**Pop-up Menus**

The following pop-up menus can be accessed via selecting an item using the right mouse button.

Selecting item	provides shortcut to
NE	Alarm List Shelf Display
background	Change the Groupings



## Customizing ITM-SC Network Map Concepts

---

**Introduction** To prevent the Network Map from appearing cluttered when several network elements occupy a small space, those network elements can be grouped together into a map group which is represented by a single icon. For example network elements can be grouped in a geographical or functional way. It is possible that a map group contains another map group.

**Customizing Features** In order to customize the Network Map three procedures are provided:

- Creating of Map Groups.
- Modifying of Map Groups.
- Placing NEs in Map Groups.

These procedures can be found in this section under Managing Map Groups Procedures.

### Icons for Customizing the Network Map

Four icons are provided to customize the Network Map. When network elements are mentioned, this is irrespective of network element type or whether the network element is associated or not. Non-associated network elements are called nodes. Within Map Groups nodes are treated in the same way as network elements.

Icon	Name	Description
	Up	To go up a group from the current group (unless at top-level already). Changes the display to show the group.
	Connections	This button will toggle the display of the RR connectivity lines. Note: only applicable for Radio Relay NEs.
	Display groups	Toggles the display between the contents of groups and the group icon. This also can be done by pressing control (CTRL) and selecting the Group or NE.
	Modify groups	Used to modify the grouping of network elements. This also can be done by selecting a NE or Group together with the right mouse button. Select from the pop up menu Modify Map Grouping of Nodes

**Moving icons** To move a node or Map Group icon, select the node/group icon and drag the icon to the new position while holding the middle mouse button.



## Parameters for Managing Map Groups

---

<b>Old Group Name</b>	Displays the old name of a group. This field is grayed out when creating a map group.
<b>New Group Name</b>	When creating a group: this is the name of the group to be created. When modifying a group: this is the new group name.
<b>Parent Group Name</b>	This is the name of the group's parent in the hierarchy. When creating a group: specifies where in the hierarchy the group appears. When modifying a group: provides a mechanism for moving the group to a different parent.
<b>Background Image File</b>	This is the name of the background GIF filename used for the background image when the group is displayed. By default for a new group, it will be the Lucent logo file. The files available are the files in the directory: <i>../lib/map_data</i> . To display a new file, this file must be present in this directory.




## Windows for Managing Map Groups

---


**Windows to use** The windows to be used to managing the Map Groups and their contents are:

- *EMS - Map Group Control.*
- *EMS - Map Group Create/Change.*

### EMS - Map Group Control



**EMS - Map Group  
Create/Change**



□

## Managing Map Groups Procedures

---

- Purpose** Three procedures are provided to:
- create new map groups
  - modify existing map groups
  - Place/insert NEs into a map group
- Before you begin** Before performing this procedure make sure:
- The background image file is present in the *.../lib/map\_data* directory.
- Before performing this procedure note the following:
- There is no correlation between Map Groups and Access Groups. Map groups only re-arrange the graphical presentation of NEs and Nodes on the Network Map. Access Groups are groups of NEs created for user security.
- Related information** Related concepts are:
- ITM-SC Network Map Concepts
  - Customizing ITM-SC Network Map Concepts
- Create Map Groups** Follow these steps to create a network element group and apply a background image file:
- 
- 1** Click with the right mouse button on Network Map (NOT on a node!) or click on the Modify groups icon.
- Result:**
- When using the first option the Network Map Background pop-up menu appears.
- When using the Modify groups icon the *EMS - Map Group Create/Change* window appears. Proceed with step 3!
- 
- 2** Select Change the Groupings.
- Result:**
- The *EMS - Map Group Control* window appears, showing a hierarchical view of the Network map's Map Groups.
- 
- 3** Select Create Group.

**Result:**

The *EMS - Map Group Create/Change* window appears.

---

- 4 Fill in New Group Name.
- 

- 5 Select the Parent Group Name when the created group has to be placed in a other Map Group.
- 

- 6 Select the appropriate filename in Background Image File and click Apply.

**Result:**

A new Map Group is created and is displayed in the *EMS - Map Group Control* window. Double click on the Map Group to display the content of the Map Group with the selected background image file as background.

---

- 7 Click on the Close button.

**Result:**

The *EMS - Map Group Control* window appears. It is possible to continue to modify Map Groups.

---

- 8 Click the Close button in the *EMS - Map Group Control* window when the Map Groups modifications is completed.

**Result:**

The *EMS - Map Group Control* window disappears.

END OF STEPS

---

**Modify Map Groups** Follow these steps to modify network element groups:

---

- 1 Click with the right mouse button on Network Map (NOT on a node!) or click on the Modify groups icon.

**Result:**

When using the first option the Network Map Background pop-up menu appears.

When using the Modify groups icon the *EMS - Map Group Create/Change* window appears. Proceed with step 3!

- 
- 2 Select Change the Groupings.

**Result:**

The *EMS - Map Group Control* window appears. This window provides a hierarchical presentation of the Network map's Map Groups.

---

- 3 Select a Map Group.
- 

- 4 Click the Modify Group button.

**Result:**

The *EMS - Map Group Create/Change* window appears.

---

- 5 Select the Map Group to modify, enter the modifications and click Apply to activate the changes.
- 

- 6 Click Close.

**Result:**

The *EMS - Map Group Control* window appears.

---

- 7 Click Close in the *EMS - Map Group Control* window.

**Result:**

The changes made are activated and accessible and the Map Groups are updated with the changes to complete the procedure.

END OF STEPS

---

**Place NEs in Map Groups**

Follow these steps to rearrange network elements in network element groups:

---

- 1 Click with the right mouse button on Network Map (NOT on a node!) or click on the Modify groups icon.

**Result:**

When using the first option the Network Map Background pop-up menu appears.

When using the Modify groups icon the *EMS - Map Group Create/Change* window appears. Proceed with step 3!

- 
- 2 Select Change the Groupings.

**Result:**

The *EMS - Map Group Control* window appears. This window provides a hierarchical view of the network map's Map Groups. All NEs, whether or not a member of a Map group, are shown.

---

- 3 To add an NE to a group, use the mouse to drag the node to the hierarchy display. Select an NE with the left mouse button, and drag it with the middle mouse button to the group. Release the button.
- 

- 4 When an NE is difficult to find, select the NE number or name in the *Name of Node to Locate* field.

**Result:**

The requested node is highlighted.

---

- 5 Continue to move the nodes until they are arranged within the Map Groups as wanted.
- 

- 6 Click Close.

**Result:**

Modifications are activated for the Map groups and the procedure is completed.

END OF STEPS

---





# Glossary

# **5ESS**

Number 5 Electronic Switching System

**5TAD**

Five Tributary Add Drop subrack (WaveStar® ADM 16/1)

**9TAD**

Nine Tributary Add Drop subrack (WaveStar® ADM 16/1)

**12 digit Numerical Code (12NC)**

Used to uniquely identify an item or product. The first ten digits uniquely identify an item. The eleventh digit is used to specify the particular variant of an item. The twelfth digit is used for the revision issue. Items with the first eleven digits the same, are functionally equal and may be exchanged.

---

**A AAU**

Alarm Adapter Unit (RR)

**AC**

Alternating Current

**ACU**

Alarm Collection Unit (RR)

**ADM**

Add-Drop Multiplexer

**Add-Drop Multiplexer 155 Mbit/s Compact Subrack (ADM-155C)**

A network multiplexer that is designed to flexibly multiplex plesiochronous and STM-1 tributary port signals into STM-1 line port signals.

**Administrative Unit (AU)**

Carrier for TUs.

**Administrative Unit Pointer (AU PTR)**

Indicates the phase alignment of the VC-n with respect to the STM-N frame. The pointer position is fixed with respect to the STM-N frame.

**Administrator**

See ITM-SC System Administrator.

**Agent**

Performs operations on managed objects and issues events on behalf of these managed objects. All SDH managed objects will support at least an agent. Control of distant agents is possible via local "Managers".

**Alarm**

The notification (audible or visual) of a significant event. See also Event.

**Alarm Adapter Unit (AAU)**

Radio Relay circuit pack that is used for collection of external alarms and remote control of external equipment.

**Alarm Collection Unit (ACU)**

Radio Relay circuit pack that performs collection of equipment alarms, analogue measurement from internal monitoring points and calculating data.

**Alarm Indication Signal (AIS)**

Code transmitted downstream in a digital Network that shows that an upstream failure has been detected and alarmed if the upstream alarm has not been suppressed. Also referred to as All OneS.

**ALS**

Automatic Laser Shutdown

**Alarm Severity**

An attribute defining the priority of the alarm message. The way alarms are processed depends on the severity.

**Aligning**

Indicating the head of a virtual container by means of a pointer, i.e. creating an Administrative Unit (AU) or a Tributary Unit (TU).

**Alternate Mark Inversion (AMI)**

A line code that employs a ternary signal to convert binary digits, in which successive binary ones are represented by signal elements that are normally of alternative positive and negative polarity but equal in amplitude and in which binary zeros are represented by signal elements that have zero amplitude.

**American Standard Code for Information Interchange (ASCII)**

A standard 8-bit code used for exchanging information among data processing systems and associated equipment.

**Anomaly**

A difference between the actual and desired operation of a function.

**ANSI**

American National Standards Institute

**Assembly**

Gathering together of payload data with overhead and pointer information (an indication of the direction of the signal).

**APS**

Automatic Protection Switching

**AS**

Alarm Suppression assembly

**Association**

A logical connection between manager and agent through which management information can be exchanged.

**Asynchronous**

See Non-synchronous.

**ATC**

Auxiliary Transmission Channel

**ATM**

Asynchronous Transfer Mode

**ATPC**

Automatic Transmit Power Control

**AU**

Administrative Unit

**AU4AD**

Administrative Unit 4 Assembler/Disassembler

**AUG**

Administrative Unit Group

**AUTO**

Automatic

**Automatic Transmit Power Control (ATPC)**

Reduces the transmitter power output level during normal propagation conditions, and increase the power output to maximum level during fading periods trying to maintain nominal receiver input level.

**Autonomous Message**

A message transmitted from the controlled Network Element to the ITM-SC which was not a response to an ITM-SC originated command.

---

**B B3ZS**

Bipolar 3-Zero Substitution

**B8ZS**

Bipolar 8-Zero Substitution

**BBTR**

Backplane Bus TRansceiver

**BC**

Board Controller

**BCC**

Board Controller Complex

**BIN**

BINary

**BIP**

Bit Interleaved Parity

**BISDN**

Broadband Integrated Services Digital Network

**Bit Error Ratio (BER)**

The ratio of bits received in error to bits sent.

**Bit Interleaved Parity (BIP)**

A method of error monitoring using a specified number of bits (BIP-8)

**BLD OUT LG**

Build-Out Lightguide

**Board Controller Local Area Network (BC-LAN)**

The internal local area network that provides communications between the Line Controller circuit pack and board controllers on the circuit packs associated with a high speed line.

**Branching**

Interconnection of independent line systems.

**Broadband Communication**

Voice, data, and/or video communication at greater than 2 Mbit/s rates.

**Broadband Service Transport**

STM-1 concatenation transport over the SLM for ATM applications.

**BUSTR**

BUS Transmitter and Receiver

---

**C CAS**

Channel Associated Signalling

**CAT**

CATastrophic

**CC**

Cross-Connection Cross-Connect (WaveStar® ADM 16/1)

**CCIR**

See ITU-R.

**CCITT**

See ITU-T.

**CCS**

Common Channel Signaling

**CEPT**

Conférence Européenne des Administrations des Postes et des Télécommunications

**Channel**

A sub-unit of transmission capacity within a defined higher level of transmission capacity, e.g. a CEPT-4 (140 Mbit/s) within a 565 Mbit fiber system.

**Circuit**

A combination of two transmission channels permitting bi-directional transmission of signals between two points, to support a single communication.

**CIT**

Craft Interface Terminal

**Clear Channel (Cl. Ch.)**

A provisionable mode for the 34 and 140 Mbit/s tributary outputs that causes parity violations to not be monitored or corrected before the 34 and 140 Mbit/s are encoded.

**Client**

Computer in a computer network that generally offers a user interface to a server. See also Server.

**CMI**

Coded Mark Inversion

---

**CO**

Central Office

**Concatenation**

A procedure whereby a multiplicity of Virtual Containers is associated one with another with the result that their combined capacity can be used as a single container across which bit sequence integrity is maintained.

**Configuration Management (CM)**

Subsystem of the ITM-SC that, among other things, configures the network and processes messages from the network.

**CONN PCB**

Connector Printed Circuit Board

**Container (C)**

Carries plesiochronous signal, the "payload".

**Co-resident**

A hardware configuration where the ITM-SC and ITM-NM applications can be active at the same time independently on the same hardware and software platform without interfering each others functioning.

**Common Object Request Broker Architecture (CORBA)**

CORBA allows applications to communicate with one another no matter where they are located or who has designed them.

**CP**

Circuit Pack

**Craft Interface Terminal (CIT)**

Local manager for SDH Network Elements.

**CRC**

Cyclic Redundancy Check

**Cross-Connect Map**

Connection map for an SDH Network Element; contains information about how signals are connected between high speed timeslots and low speed tributaries. See also Squelch Map.

**Cross Polarization Interference Cancellation**

This feature permits both orthogonal polarizations of one Radio Frequency carrier to be used simultaneously, thus achieving greater spectral efficiency.

**CV**

Code Violation

---

**D DACS**

Digital Access & Cross-connect System

**DACScan-T**

See Integrated Transport Management Network Manager.

**Database Administrator**

A user who administers the database of the ITM-SC application. See also User Privilege.

**Data Communication Channel (DCC)**

The embedded overhead communication channel in the SDH line. This is used for end-to-end communication and maintenance. It carries alarm, control, and status information between Network Elements in an SDH network.

**Data Communication Equipment (DCE)**

Provides the signal conversion and coding between the data terminating equipment and the line. The DCE may be separate equipment or a part of the data terminating equipment.

**Data Terminating Equipment (DTE)**

Originates data for transmission and accepts transmitted data.

**DC**

Direct Current

**DCF**

Data Communications Function

**DCN**

Data Communications Network

**DCS**

Digital Cross-connect System

**DDF**

Digital Distribution Frame

**Dedicated Protection Ring (DP-Ring)**

A protection method used in ISM Network Elements.

**Defect**

A limited interruption of the ability of an item to perform a required function. It may or may not lead to maintenance action depending on the results of additional analysis.

**Demultiplexing**

A process applied to a multiplexed signal for recovering signals combined within it and for restoring the distinct individual channels of these signals.

**Digital Link**

A transmission span such as a point-to-point 2 Mbit/s, 34 Mbit/s, 140 Mbit/s, VC12, VC3 or VC4 link between controlled Network Elements. The channels within a digital link are insignificant.

**Digital Section**

A transmission span such as an STM-N or 565 Mbit/s signal. A digital section may contain multiple digital channels.

**DIL**

Dual In Line

**Directory Service Network Element (DSNE)**

A designated Network Element that is responsible for administering a database that maps Network Elements names (node names) to addresses (node Id). There can be one DSNE per (sub)network.

**Disassembly**

Splitting up a signal into its constituents as payload data and overhead (an indication of the direction of a signal).

**Domain**

The domain of an ITM-SC is the set of all SDH Network Elements that are controlled by that particular ITM-SC.

**Downstream**

At or towards the destination of the considered transmission stream, i.e. looking in the same direction of transmission.

**DPLL**

Digital Phase Locked Loop

**DPS**

Data communication Packet Switch (ISM)

**DR**

Digital Radio

**DRI**

Dual Ring Interworking

**DS-n**

Digital Signal, Level n

**DTMF**

Dual Tone Multi-Frequency

**DUS**

Do not Use for Synchronization

**DWDM**

Dense Wavelength Division Multiplexing

---

**E EC-n**

Electrical Carrier, Level n

**ECC**

Embedded Control Channel

**Electronic Industries Association (EIA)**

A trade association of the electronic industry that establishes electrical and functional standards.

**Element Management System (EMS)**

See Integrated Transport Management Subnetwork Controller.

**EMC**

ElectroMagnetic Compatibility

**EMI**

ElectroMagnetic Interference

**EOW**

See Orderwire.

**Equivalent Bit Error Ratio (EBER)**

The calculated average bit error rate over a data stream.

**Errored Second (ES)**

A performance monitoring parameter.

**ES**

End System

**ESD**

ElectroStatic Discharge

**ESPG**

Elastic Store & Pointer Generator

**ETSI**

European Telecommunication Standardisation Institute

**Event**

A significant change. Events in controlled Network Elements include signal failures, equipment failures, signals exceeding thresholds, and protection switch activity. When an event occurs in a controlled Network Element, the controlled Network Element will generate an alarm or status message and send it to the ITM-SC.

**Event Management (EM)**

Subsystem of ITM-SC that processes and logs event reports of the network.

**Externally Timed**

An operating condition of a clock in which it is locked to an external reference and is using time constants that are altered to quickly bring the local oscillator's frequency into the approximate agreement with the synchronization reference frequency.

**Extra Traffic**

Unprotected traffic that is carried over the protection channels when that capacity is not used for the protection of service traffic.

---

**F Far End Block Error (FEBE)**

An indication returned to the transmitting node that an errored block has been detected at the receiving node. A block is a specified grouping of bits.

**Far End Receive Failure (FERF)**

An indication returned to a transmitting Network Element that the receiving Network Element has detected an incoming section failure.

**FAS**

Frame Alignment Signal

**FAW**

Frame Alignment Word

**FC**

Full contact Connector

**FCC**

Federal Communications Commission

**FDDI**

Fiber Distributed Data Interface

**FEP**

Front End Processor

**Free Running**

An operating condition of a Network Element in which its local oscillator is not locked to any synchronization reference and is using no storage techniques to sustain its accuracy.

---

**G Geographic Location**

Location of the ITM-SC server. This is entered as part of the installation procedure of an ITM-SC.

**Gateway Network Element (GNE)**

Passes information between other Network Elements and management systems via a Data Communications Network.

**Geographic Redundancy (GR)**

Allows protection of management for a Network Element by assigning it to two ITM-SCs. The first primary ITM-SC, usually manages the Network Element and is now in the protected domain. If the primary ITM-SC or the link between the Network Element and the primary fails, the secondary ITM-SC will automatically take over management of the Network Element and is now in the protecting domain. The two ITM-SCs are connected by a peer to peer link, which they use to pass Geographic Redundancy management information over. This link must be established before any Network Element can be protected by Geographic Redundancy.

**Global Wait to Restore Time**

Corresponds to the time to wait before switching back to the timing reference occurs after a timing link failure has cleared. This time applies for all timing sources in a system hence the name global. This can be between 0 and 60 minutes, in increments of one minute.

**GUI**

Graphical User Interface

---

**H HE**

Host Exchange

**High Density Bipolar 3 code (HDB3)**

Line code for e.g. 2 Mbit/s transmission systems.

**High level Data Link Control (HDLC)**

OSI reference model datalink layer protocol.

**Higher order Path Adaptation (HPA)**

Function that adapts a lower order Virtual Container to a higher order Virtual Container by processing the Tributary Unit pointer which indicates the phase of the lower order Virtual Container Path Overhead relative to the higher order Virtual Container Path Overhead and assembling/disassembling the complete higher order Virtual Container.

**Higher order Path Connection (HPC)**

Function that provides for flexible assignment of higher order Virtual Containers within an STM-N signal.

**Higher order Path Termination (HPT)**

Function that terminates a higher order path by generating and adding the appropriate Virtual Container Path Overhead to the relevant container at the path source and removing the Virtual Container Path Overhead and reading it at the path sink.

**HMI**

Human Machine Interface

**HO**

High Order

**Holdover**

An operating condition of a clock in which its local oscillator is not locked to an external reference but is using storage techniques to maintain its accuracy with respect to the last known frequency comparison with a synchronized reference.

**Host Name**

Name of the server on which the ITM-SC is running.

**HP-UX**

Unix Operating System for Hewlett Packard platform.

**HS**

High Speed

---

**I ICB**

Interconnection Box

**ICP**

InterConnection Panel

**IEC**

International Electrotechnical Committee

**IEEE**

Institute of Electrical and Electronic Engineers

**IF**

Intermediate Frequency

**IFT**

InterFace Terminal

**Intelligent Synchronous Multiplexer (ISM)**

A network multiplexer that is designed to flexibly multiplex plesiochronous and STM-1 tributary port signals into STM-1 or STM-4 line port signals.

**Intergrated Transport Management Craft Interface Terminal (ITM-CIT)**

Local manager for SDH Network Elements in a subnetwork. Also referred to as Craft Interface Terminal.

**Intermediate System (IS)**

A system which routes/relays management information. An SDH Network Element may be a combined Intermediate and end system.

**IPS**

Inter Processor Status

**IS**

In-Service

**ISDN**

Integrated Services Digital Network

**IS-IS Routing**

The Network Elements in a management network, route packets (data) between each other using a IS-IS level protocol. The size of a network running IS-IS Level 1 is limited, and therefore certain mechanisms are employed to facilitate the management of larger networks. For STATIC ROUTING, the capability exists for disabling the protocol over the LAN connections, effectively causing the management network to be partitioned into separate IS-IS Level 1 areas. In order for the ITM-SC to communicate with a specific Network Element in one of these areas, the ITM-SC must identify through which so-called Gateway Network Element this specific Network Element is connected to the LAN. All packets to this specific Network Element are routed directly to the Gateway Network Element by ITM-SC, before being re-routed (if necessary) within the Level 1 area. For DYNAMIC ROUTING an IS-IS Level 2 routing protocol is used allowing a number of Level 1 areas to interwork. The Network Elements which connect an IS-IS area to another area are set to run the IS-IS Level 2 protocol within the Network Element and on the connection between other Network Elements. Packets can now be routed between IS-IS areas and the ITM-SC does not have to identify the Gateway Network Elements.

**ISO**

International Standards Organisation

**ITM-SC Administrator**

See ITM-SC System Administrator.

**ITM-SC System Administrator**

A user of the ITM-SC application with System Administrator privileges. See also User Privilege.

**ITU**

International Telecommunications Union

**ITU-R**

International Telecommunications Union - Radio standardization sector. Formerly known as CCIR: Comité Consultatif International Radio; International Radio Consultative Committee.

**ITU-T**

International Telecommunications Union - Telecommunication standardization sector. Formerly known as CCITT: Comité Consultatif International Télégraphique & Téléphonique; International Telegraph and Telephone Consultative Committee.

---

**J Jitter**

Short term variations of amplitude and frequency components of a digital signal from their ideal position in time.

---

**L LAN**

Local Area Network

**LBA**

Lightwave Booster Amplifier.

**LCN**

Local Communications Network

**LDI**

Linear Drop/Insert (Add-Drop)

**LED**

Light Emitting Diode

**LEN**

Local Exchange Node

**LF**

Low Frequency

**LH**

Long Haul

**License key**

An encrypted code that is required to enable the use of specific modules in the ITM-SC. Valid license keys can be obtained from your provider.

**Line**

Transmission line; refers to a transmission medium, together with the associated high speed equipment, required to provide the means of transporting information between two consecutive Network Elements, one of which originates the line signal and the other terminates the line signal.

**Line Build Out (LBO)**

An optical attenuator that guarantees the proper signal level and shape at the receiver input.

**Line Overhead Controller (LOC)**

SLM circuit pack that accesses the overhead bytes from the high speed line.

**LNC**

LiNe Controller (SLM)

**LO**

Low Order

**LOF**

Loss Of Frame

**LOM**

Loss Of Multiframe

**LOP**

Loss Of Pointer

**LOS**

Loss Of Signal

**Lower order Path Adaptation (LPA)**

Function that adapts a PDH signal to a synchronous network by mapping the signal into or de-mapping the signal out of a synchronous container.

**Lower order Path Connection (LPC)**

Function that provides for flexible assignment of lower order VCs in a higher order VC.

**Lower order Path Termination (LPT)**

Function that terminates a lower order path by generating and adding the appropriate VC POH to the relevant container at the path source and removing the VC POH and reading it at the path sink.

**LPU**

Line Port Unit (ISM)

**LPU155**

Line Port Unit 155 Mbit/s (WaveStar® ADM 4/1)

**LRX**

Line Receiver (SLM)

**LS**

Low Speed

**LTA**

Line Terminal Application (SLM)

**LTX**

Line Transmitter (SLM)

**LTX/EML**

Line Transmitter with Electro-absorption Modulated Laser (SLM)

---

**M MAF**

Management Application Function

**Management Connection**

Identifies the type of routing used (STATIC or DYNAMIC), and if STATIC is selected allows the Gateway Network Element to be identified. See also IS-IS Routing.

**Management Information Base (MIB)**

The database in the Network Element and contains the configuration data of the Network Element. A copy of each MIB is available in the ITM-SC and is called the MIB image. Under normal circumstances the MIB and MIB image of one Network Element are synchronized.

**Manager**

Capable of issuing network management operations and receiving events. The manager communicates with the Agent in the controlled Network Element.

**Manufacturer Executable Code (MEC)**

Network Element system software in binary format that after being downloaded to one of the stores can be executed by the system controller of the Network Element.

**Mapping**

Gathering together of payload data with overhead, i.e. packing the PDH signal into a Virtual Container.

**MDI**

Miscellaneous Discrete Input

**MDO**

Miscellaneous Discrete Output

**Mediation Device (MD)**

Allows for exchange of management information between Operations System and Network Elements.

**MEF**

Maintenance Entity Function (in NE)

**MEM**

System MEMory unit (for SLM ADM NEs)

**Message Communications Function (MCF)**

Function that provides facilities for the transport and routing of Telecommunications Management Network messages to and from the Network Manager.

**MF**

Mediation Function

**MFS**

Multi Frame Synchronization signal

**MIB image**

See Management Information Base.

**Midspan Meet**

The capability to interface between two lightwave Network Elements of different vendors. This applies to high speed optical interfaces.

**MMI**

Man-Machine Interface Also referred to as Human Machine Interface (HMI)

**MO**

Managed Object

**Motif**

X-Windows System supplied by Open Software Foundation.

**MS**

Multiplexer Section

**MTBF**

Mean Time Between Failures

**MTBMA**

Mean Time Between Maintenance Activities

**MTIE**

Maximum Time Interval Error

**MTPI**

Multiplexer Timing Physical Interface

**MTTR**

Mean Time To Repair

**Multiplexer Section OverHead (MSOH)**

Part of the Section Overhead. Is accessible only at line terminals and multiplexers.

**Multiplexer Section Protection (MSP)**

Provides capability for switching a signal from a working to a protection section.

**Multiplexer Section Shared Protection Ring (MS-SPRING)**

A protection method used in SLM Add-Drop Multiplexer Network Elements.

**Multiplexer Section Termination (MST)**

Function that generates the Multiplexer Section OverHead in the transmit direction and terminates the Multiplexer Section OverHead in the receive direction.

**Multiplexer Timing Source (MTS)**

Function that provides timing reference to the relevant component parts of the multiplex equipment and represents the SDH Network Element clock.

**Multiplexing**

A procedure by which multiple lower order path layer signals are adapted into a higher order path, or the multiple higher order path layer signals are adapted into a multiplex section.

---

**N NEF**

Network Element Function

**NEM**

Network Element Manager

**Network Element (NE)**

A Network Element is comprised of telecommunication equipment (or groups/parts of telecommunication equipment) and support equipment that performs network element functions and has one or more standard Q-type interfaces. A Network Element is direct manageable by a management system. See also Node.

**Network Element Equivalent (NEE)**


The functionality, database size and processing power required from the ITM-SC is different for each Network Element type supported. Therefore each type represents an amount of Network Element Equivalent.

**Network Mediation Unit (NMU)**

Used to collect fault and alarm events from transmission equipment. The ITM-SC can forward alarms to the NMU. The NMU can forward alarms to an Operations System.

**Network Service Access Point (NSAP)**

An end system address of the System Controller according to ISO 8348 AD2. The format used is ISO\_DCC\_LUCENT, which has the following structure:



Where

Field	Description	Length	Fixed Values
IDP	Initial Domain Part	3 octets	-
DSP	Domain Specific Part	17 octets	-
AFI	Authority and Format Identifier	1 octet	39
IDI	Initial Domain Identifier	2 octets	00 00
DFI	DSP Format Identifier	1 octet	80
Organization		3 octets	00 00 00
Spare		2 octets	00 00
RD	Routing Domain	2 octets	00 00
Area_id		2 octets	Provisionable
SID	System Identification	6 octets	-
SEL	NSAP Selector	1 octet	01
Area_Address	All Octets from AFI to Area_id	13 or 3 octets	-

### NMC

Network Maintenance Center

### NMS

Network Management System

### NNE

Non-SDH Network Element

### NNI

Network Node Interface

### Node

Defined as all equipment that is controlled by one system controller. A node is not always direct manageable by a management system. See also Network Element.

### NOMC

Network Operation Maintenance Channel

### Non-revertive switching

In non-revertive switching there is an active and standby high speed line, circuit pack, etc. When a protection switch occurs, the standby line, circuit pack, etc., is selected causing the old standby line, circuit pack, etc., to be used for the new active line, circuit pack, etc. The original active line, circuit pack, etc., becomes the standby line, circuit pack, etc. This status remains in effect when the faults clears. Therefore, this protection scheme is non-revertive in that there is no switch back to the original status in effect before the fault occurred.

**Non-synchronous**

The essential characteristic of time-scales or signals such that their corresponding significant instants do not necessarily occur at the same average rate.

**Not Protected Domain**

The not protected domain for the ITM-SC contains all the Network Elements which are managed by one ITM-SC and are not currently protected by another ITM-SC. If the ITM-SC fails, the Network Elements in this domain are not managed by any ITM-SC. See also Geographic Redundancy.

**NPI**

Null Pointer Indication

**NRZ**

Non-Return to Zero

**NSA**

Non-Service Affecting

**NVM**

Non-Volatile Memory

- 
- O OA**  
Optical Amplifier (OLS)

**OAA case tools**

A software package/tool to aid the process of requirements, analysis, design and implementation of object orientated systems.

**OAM&P**

Operations, Administration, Maintenance and Provisioning

**OC-n**

Optical Carrier, Level n

**ODF**

Optical Distribution Frame

**ODU**

Optical Demultiplexer Unit (OLS)

**OFS**

Out of Frame Second

**OI**

Optical Interface (WaveStar® ADM 16/1)

**OMU**

Optical Multiplexer Unit (OLS)

**Operations System (OS)**

Operations System is the system which provides operations, administration and maintenance functions.

**Operator**

A user of the ITM-SC application with Operator privileges. See also User Privilege.

**Optical Line System (OLS)**

A high-capacity lightwave system that is designed to multiplex eight optical signals with different wavelengths into one combined signal through an optical fiber. There is a difference of 1.5 micrometer in wavelength between two multiplexed signals.

**OOF**

Out Of Frame

**OOS**

Out Of Service

**OSB**

Optical Splice Box

**OSF**

Open Software Foundation Operations System Function

**OSF/Motif**

The WaveStar® ITM-SC application has an X-windows graphical representation and the components used in the “Graphical User Interface” are OSF/Motif compliant, these components comprise of items such as: scrollbars, menus, radio buttons, etc.

**OSI**

Open Systems Interconnection

**OW**

(Engineering) Order Wire

---

**P PABX**

Private Automatic Branch eXchange

**Paddle Board - Peripheral Control and Timing link (PB-PCT)**

Is a small circuit board used in a 5ESS exchange for protection switching and optical to electrical conversion of the PCT-link.

**Path**

A logical connection between a termination point at which a standard format for a signal at the given rate is assembled, and transmitted and another termination point at which the received

standard frame format for the signal is disassembled.

**Path Overhead (POH)**

Virtual Container Path Overhead provides for integrity of communication between the point of assembly of a Virtual Container and its point of disassembly.

**PC**

Personal Computer

**PCB**

Printed Circuit Board

**PCM**

Pulse Code Modulation

**PCT-link**

Peripheral Control and Timing-link

**PDH**

Plesiochronous Digital Hierarchy

**Peer ITM-SC**

ITM-SC at the other end of the Peer to Peer link.

**Peer to Peer link**

Connection between two ITM-SCs with Geographic Redundancy. The link is used to co-ordinate the management of a Network Element. See also Geographic Redundancy.

**Performance Monitoring (PM)**

Measures the quality of service and identifies degrading or marginally operating systems (before an alarm is generated).

**Peripheral Control and Timing Facility Interface (PCTFI)**

A proprietary physical link interface supporting the transport of 21 \* 2 Mbit/s signals.

**PI**

Physical Interface Plesiochronous Interface (WaveStar® ADM 16/1)

**Platform**

Family of equipment and software configurations designed to support a particular Application.

**Plesiochronous Network**

A network that contains multiple subnetworks, each internally synchronous and all operating at the same nominal frequency, but whose timing may be slightly different at any particular instant.

**PMA**

Performance Monitoring Application

**Pointer**

An indicator whose value defines the frame offset of a virtual container with respect to the frame reference of the transport entity on which it is supported.

**POTS**

Plain Old Telephone Service

**PP**

Pointer Processing

**PPC**

Pointer Processor and Cross-connect (ISM)

**Primary ITM-SC**

ITM-SC that is usually managing a Network Element. If the primary ITM-SC fails, management of the Network Element is passed over to the secondary ITM-SC. A Network Element should be provisioned normally on the primary ITM-SC and then be configured for use on the secondary. See also Geographic Redundancy.

**Primary Reference Clock (PRC)**

The main timing clock reference in SDH equipment.

**Protected Domain**

The protected domain for an ITM-SC contains all the Network Elements this manager is the primary ITM-SC for and are protected by another secondary ITM-SC. See also Geographic Redundancy.

**Protecting Domain**

The protecting domain for an ITM-SC contains all the Network Elements this manager is the secondary ITM-SC for. See also Geographic Redundancy.

**Protection**

Extra capacity (channels, circuit packs) in transmission equipment that is not intended to be used for service, but rather to serve as backup against equipment failures.

**PSA**

Partially Service Affecting

**PSDN**

Public Switched Data Network

**PSF**

Power Supply Filter

**PSF-SIP**

Power Supply Filter; originally designed for Italian customer.

**PSN**

Packet-Switched Network

**PSTN**

Public Switched Telephone Network

**PT**

Protected Terminal Power supply filter and Timing circuit pack (WaveStar® ADM 16/1)

---

**Q QAF**

Q Adapter Function (in NE)

**Q-LAN**

Thin Ethernet LAN which connects the manager to Gateway Network Elements so that management information between Network Elements and management systems can be exchanged.

**QOS**

Quality Of Service

**Quality Level (QL)**

The quality of the timing signal(s) provided to clock a Network Element. The level is provided by the Synchronization Status Marker which can accompany the timing signal. If the System and Output Timing Quality Level mode is “Enabled”, and if the signal selected for the Station Clock Output has a quality level below the Acceptance Quality Level, the Network Element “squelsches” the Station Clock Output Signal, which means that no signal is forwarded at all. Possible levels are: - PRC (Primary Reference Clock) - SSU\_T (Synchronization Supply Unit - Transit) - SSU\_L (Synchronization Supply Unit - Local) - SEC (SDH Equipment Clock) - DUS (Do not Use for Synchronization)

---

**R RA**

Regenerator Application (SLM)

**Radio Protection Switching system (RPS)**

Its main function is to handle the automatic and manual switching from a main channel to a common protection channel in an N+1 system.

**Radio Relay (RR)**

A point-to-point Digital Radio system to transport STM-1 signals via microwaves.

**RCU**

Rigid Connect Unit (SLM)

**RCVR Data Distribution Unit (RCVR)**

Radio Relay circuit pack that performs distribution of the protection channel and the low priority traffic in the receiver side.

**RDDU**

RCVR Data Distribution Unit (RR)

---

**RDI**

Remote Defect Indicator. Previously known as Far End Receive Failure (FERF).

**RDI**

Ring Drop/Insert (Add-Drop)

**RDSV**

Running Digital Sum Violations

**Receive-direction**

The direction towards the cross-connect.

**REGEN**

Regenerator (SLM)

**Regenerator Loop**

Loop in a Network Element between the Station Clock Output(s) and one or both Station Clock Inputs, which can be used to dejitterize the selected timing reference in network applications.

**Regenerator Overhead Controller (ROC)**

SLM circuit pack that provides user access to the SDH overhead channels at repeater sites.

**Regenerator Section Termination (RST)**

Function that generates the Regenerator Section Overhead (RSOH) in the transmit direction and terminates the RSOH in the receive direction.

**REI**

Remote Error Indication. Previously known as Far End Block Error (FEBE).

**Relay Unit (RU)**

Radio Relay circuit pack whose main function is to perform protection switching when the Alignment Switch in the demodulator unit is unable to perform protection switching.

**Restore Timer**

Counts down the time (in minutes) during which the switch waits to let the worker line recover before switching back to it. This option can be set to prevent the protection switch continually switching if a line has a continual transient fault. This field is greyed out if the mode is non-revertive.

**Revertive Switching**

In revertive switching, there is a working and protection high speed line, circuit pack, etc. When a protection switch occurs, the protection line, circuit pack, etc., is selected. When the fault clears, service reverts back to the original working line.

**RF**

Radio Frequency

**RFI**

Remote Failure Indicator

**RGU**

ReGenerator Unit (SLM)

**Route**

A series of contiguous digital sections.

**RPS**

Ring Protection Switching

**RSM**

Remote Switching Module

**RSOH**

Regenerator Section OverHead; part of SOH.

**RZ**

Return to Zero

---

**S SA**

Service Affecting Synchronous Adapter (WaveStar® ADM 16/1)

**SAI**

Station Alarm Interface

**SC**

Square coupled Connector

**SD**

Signal Degrade

**SDH-TE**

SDH - Terminal Equipment

**Specification and Design Language (SDL)**

This is a standard formal language for specifying (essentially) finite state machines.

**SEC**

SDH Equipment Clock

**Secondary ITM-SC**

Backup ITM-SC for a Network Element should the primary ITM-SC fail. A Network Element should be provisioned normally on the primary ITM-SC and then be configured for use on the secondary. See also Geographic Redundancy.

**Section**

A transport entity in the transmission media layer network which provides integrity of information transfer across a section layer network connection by means of a termination function at the section layer.

**Section Adaptation (SA)**

Function that processes the AU-pointer to indicate the phase of the VC-3/4 POH relative to the STM-N SOH and assembles/disassembles the complete STM-N frame.

**Section Overhead (SOH)**

Capacity added to either an AU-4 or assembly of AU-3s to create an STM-1. Contains always STM-1 framing and optionally maintenance and operational functions. SOH can be subdivided in MSOH (multiplex section overhead) and RSOH (regenerator section overhead).

**SEF**

Support Entity Function (in NE)

**Self-healing**

A network's ability to automatically recover from the failure of one or more of its components.

**Server**

Computer in a computer network that performs dedicated main tasks which require generally sufficient performance. See also Client.

**Severely Errored Frame Seconds (SEFS)**

A performance monitoring parameter.

**Severely Errored Second (SES)**

A second with a binary error ratio and used as a performance monitoring parameter.

**Severity**

See Alarm Severity

**Service**

The operational mode of a physical entity that indicates that the entity is providing service. This designation will change with each switch action.

**SH**

Short Haul

**SI**

Synchronous Interface (WaveStar® ADM 16/1)

**SIB**

Subrack Interface Box

**SLC**

Subscriber Loop Carrier

**SLM**

Signal Label Mismatch

**Smart Communication Channel (SCC)**

A HDLC messaging channel between the SDH-TE and the 5ESS host node. Similar to the DCC messaging channels located in the STM-N section overhead.

**SML**

Service Management Level

**SMN**

SDH Management Network

**SMS**

SDH Management Subnetwork

**SNC/I**

SubNetwork Connection (protection) / Inherent monitoring

**SNC/NI**

SubNetwork Connection / Non Intrusive monitoring

**SNR**

Signal to Noise Ratio

**Soft Windows**

PC emulator package for HP platforms.

**SONET**

Synchronous Optical Network

**Space Diversity (SD)**

Reception of the Radio signal via mirror effects on earth.

**SPB2M**

Subrack Protection for 2 Mbit/s Board (WaveStar® ADM 4/1)

**SPI**

SDH Physical Interface Synchronous-Plesiochronous Interface (WaveStar® ADM 16/1)

**Squelch Map**

Traffic map for SLM Add-Drop Multiplexer Network Elements that contains information for each cross-connection in the ring and indicates the source and destination Network Elements for the low speed circuit that the cross-connection is part of. This information is used to prevent traffic misconnection in rings with isolated Network Elements or segments. See also Cross Connection Map.

**SSM**

Synchronization Status Marker

**Standby**

The operational mode of a physical entity that indicates that the entity is not providing service, but standby. This designation will change with each switch action.

**Station Clock Input (SCI)**

An external clock may be connected to a Station Clock Input.

**Station Clock Output (SCO)**

A clock signal that can be used for other systems.

**Stretched Ring (STRING)**

An open ring in which each node is an Add-Drop Multiplexer. The end nodes operate with one high speed line equipped.

**STS**

Synchronous Transport Signal; used in SONET.

**Subnetwork**

A group of interconnected/interrelated Network Elements. The most common connotation is an SDH network in which the Network Elements have data communications channels (DCC) connectivity.

**Supervisor**

A user of the ITM-SC application with Supervisor privileges. See also User Privilege.

**Supervisory Unit (SU)**

Radio Relay circuit pack that gives comprehensive supervision and control facilities to the user by collecting information from the Alarm Collection Units and Alarm Adapter Units.

**SUPV**

Supervision unit (WaveStar® ADM 4/1)

**SUPV\_SVC**

Supervision with Service Channel unit (WaveStar® ADM 4/1)

**SVCE**

Service

**Switch Receive Unit (SWR)**

SLM circuit pack that provides the cross-connect in the receive direction between high speed line timeslots and low speed tributaries.

**Switch Transmit Unit (SWT)**

SLM circuit pack that provides the cross-connect in the transmit direction between high speed line timeslots and low speed tributaries.

**Switching Module (SM)**

An access module from the 5ESS switch.

**Synchronization Supply Unit (SSU)**

A circuit pack that recovers and reshapes the clock signal in order to filter out jitter. The Local (SSU\_L) and Transit (SSU\_T) types are available.

**Synchronous**

The essential characteristic of time-scales or signals such that their corresponding significant instants occur at precisely the same average rate.

**Synchronous Digital Hierarchy (SDH)**

A hierarchical set of digital transport structures, standardized for the transport of suitable adapted payloads over transmission networks.

**Synchronous Equipment Management Function (SEMF)**

Function that converts performance data and implementation specific hardware alarms into object-oriented messages for transmission over the DCC and/or Q-interface. It also converts object-oriented messages related to other management functions for passing across the S reference points.

**Synchronous Line Multiplexer (SLM)**

A line multiplexer that is designed to multiplex VC-4 and STM-1 tributary port signals into STM-16 line port signals.

**Synchronous Network**

The synchronization of synchronous transmission systems with synchronous payloads to a master Network clock that can be traced to a single reference clock.

**Synchronous Transport Module (STM)**

The information structure used to support (section layer) connections in SDH.

**System Administrator**

A user of the computer system on which the ITM-SC application can be installed. See also User Privilege.

**System Controller (CTL)**

ISM circuit pack that controls the configuration of an Intelligent Synchronous Multiplexer system.

**System Controller (SC)**

WaveStar® ADM 16/1 circuit pack that controls and provisions all units. It also contains the data communication packet switch functionality which is necessary for routing of management information between Network Elements and their management system.

**System Controller (SCT)**

SLM Line Terminal and Regenerator Network Element circuit pack that provides the highest level of system control for the Synchronous Line Multiplexer system. The SCT circuit pack provides overall administrative control of the system. Its memory is included in the same one circuit pack.

**System Controller (STC)**

SLM Add-Drop Multiplexer Network Element circuit pack that provides the highest level of system control for the Synchronous Line Multiplexer system. The STC circuit pack provides overall administrative control of the system. Its memory is provided by the MEM circuit pack.

**System Controller (SYSCTL)**

OLS circuit pack that provides the highest level of system control for the Optical Line System. The SYSCTL circuit pack provides overall administrative control of the system. Its memory is provided by the SYSMEM circuit pack.

**System Memory Unit (MEM)**

SLM Add-Drop Multiplexer Network Element circuit pack that provides the highest level of system control for the Synchronous Line Multiplexer system. The MEM circuit pack provides memory support for the System Controller (STC) circuit pack.

**System Memory Unit (SYSMEM)**

OLS circuit pack that provides the highest level of system control for the Optical Line System. The SYSMEM circuit pack provides memory support for the SYSCTL circuit pack.

---

**T TCA**

Threshold Crossing Alarm

**TCP/IP**

Transmission Control Protocol/Internet Protocol

**TDEV**

Timing DEVIation

**TDM**

Timing Division Multiplexing

**Template**

A collection of parameters that define a specific Network Element configuration. A Template gives the user the opportunity to configure parameters in a Network Element with a single operation. They are re-usable, and allow the user to configure the parameters in many Networks Elements in the same way. A set of Default templates is provided, and the user can create new templates and edit or delete user-created ones. Note that a template is always associated with one specific Network Element type and can not be used for other Network Element types.

**TERM**

Terminal Multiplexer

**TGU**

Timing Generator Unit

**TI**

Timing Interface (WaveStar® ADM 16/1)

**TLM**

TeLeMetry Unit (OLS)

**TLP**

Terminal with Line Protection

**TMN**

Telecommunications Management Network

**TPU**

Tributary Port Unit

**TPU-PCT**

Tributary Port Unit - Peripheral Control and Timing link

**TPU2**

Tributary port Unit 2 Mbit/s (WaveStar® ADM 4/1)

**TPU34/45**

Tributary port Unit 34 / 45 Mbit/s (WaveStar® ADM 4/1)

**TPU155**

Tributary port Unit 155 Mbit/s (WaveStar® ADM 4/1)

**Transmit-direction**

The direction outwards from the cross-connect.

**Trellis Code Modulation**

A combined coding and modulation scheme for improving the reliability of a digital transmission system without increasing the transmitted power or the required bandwidth.

**TRF**

TRansFer unit (WaveStar® ADM 4/1)

**Tributary**

A signal of a specific rate (2 Mbit/s, 34 Mbit/s, 140 Mbit/s, VC12, VC3, VC4, STM-1 or STM-4) that may be added to or dropped from a line signal.

**Tributary Overhead Controller (TOC)**

SLM circuit pack that allows access to the overhead bytes of the incoming tributary signal.

**Tributary Overhead Controller (TOHCTL)**

OLS circuit pack that allows access to the overhead bytes of the Supervisory channel.

**Tributary Unit (TU)**

An information structure which provides adaptation between the lower order path layer and the higher path layer. Consists of a VC-n plus a tributary unit pointer TU PTR.

**Tributary Unit Pointer (TU PTR)**

Indicates the phase alignment of the VC with respect to the TU in which it resides. The pointer position is fixed with respect to the TU frame.

**TSA**

Time Slot Assignment

**TSI**

Time Slot Interchange

**TTP**

Trail Termination Point

**TUG**

Tributary Unit Group

---

**U UAS**

UnAvailable Seconds

**ULDT**

Ultra Long Distance Transmission

**UIM/X**

A package used for developing the WaveStar® ITM-SC GUI for X-windows.

**Unavailable Seconds**

A performance monitoring parameter.

**Uninterruptable Power Supply (UPS)**

Allows connected computer equipment to gracefully shutdown, therefore preventing damage in case of a power fail and absorb dips in the supplied power.

**Universal Co-ordinated Time (UTC)**

A time-zone independent indication of an event. The local time can be calculated from the Universal Co-ordinated Time.

**UPL**

User Panel

**Upstream**

At or towards the source of the considered transmission stream, i.e. looking in the opposite direction of transmission.

**User Privilege**

Permissions a user has to perform actions on the computer system on which the ITM-SC application runs. The following users can be distinguished:

User Type	User name	Permissions
System Administrator this is NOT an ITM-SC user	root (fixed)	maintain platform .
Database Administrator this is NOT an ITM-SC user	informix (fixed)	maintain database .
ITM-SC System Administrator	i2kadmin (fixed)	maintain ITM-SC application , maintain Network Element templates , maintain MEC files on the ITM-SC , set default ITM-SC parameters .
Supervisor	free choice	perform all data retrieval functions , perform all alarm suppression functions , perform configuration changes .
Operator	free choice	perform all data retrieval functions , perform all alarm suppression functions .

---

## V VF

Voice Frequency

### Virtual Container (VC)

Container with path overhead.

---

## W Wait to Restore Time (WRT)

Corresponds to the time to wait before switching back after a failure has cleared, in a revertive protection scheme. This can be between 0 and 15 minutes, in increments of one minute.

### WAN

Wide Area Network

### Wander

Long term variations of amplitude frequency components (below 10 Hz) of a digital signal from their ideal position in time possibly resulting in buffer problems at a receiver.

### WaveStar® ADM 16/1

A network multiplexer that is designed to flexibly multiplex plesiochronous and STM-1 tributary port signals into STM-4 or STM-16 line port signals.

### WaveStar® Integrated Transport Management Subnetwork Controller (ITM-SC)

Manager for SDH Network Elements in a subnetwork. Also referred to as Element Management System.

### WaveStar® Network Management System (NMS)

Manager for SDH Network Elements in a network. Formerly known as DACScan-T.

### WDM

Wavelength Division Multiplexing

### What You See Is What You Get (WYSIWYG)

Information as displayed on the screen will appear in the same way on printed output.

---

**Wideband Communications**

Voice, data, and/or video communication at digital rates from 64 kbit/s to 2 Mbit/s.

**Windows**

Graphical User Interface on PC systems.

**Working**

Label attached to a physical entity. In case of revertive switching the working line or unit is the entity that is carrying service under normal operation. In case of non-revertive switching the label has no particular meaning.

**WS**

Work Station

**WSF**

Work Station Facility

---

**X XMTR**

Transmitter (RR)

**XMTR Switch Unit**

Radio Relay circuit pack that performs connections for protection switching and transmission of low priority traffic on the protection channel.

**XPIC**

Cross Polarization Interference Cancellation

**XSU**

XMTR Switch Unit (RR)

**X-Terminal**

Workstation that can support an X-Windows interface

**X-Windows**

Graphical User Interface on Unix Systems.





# Index

## A

Acceptance QL, [4-21](#) [4-29](#)  
 Active system timing  
 source, [4-14](#) [4-21](#)  
 Administration module,  
[9-12](#)  
 Alarm status, [2-59](#)  
 Alarms, [8-57](#) [8-79](#)  
 API, [6-19](#)  
 API format, [6-19](#)  
 Auto mode time, [6-7](#)

## B

Background image file,  
[9-40](#)  
 Button names, [9-8](#)

## C

Cable length, [6-8](#)  
 Card inventory  
 view, [2-61](#)  
 Checking sequence number  
 of VC-n, [5-12](#)  
 CIR, [8-66](#)  
 Committed information rate  
 CIR, [5-14](#)  
 Communication mode,  
[5-42](#) [5-46](#) [6-34](#)  
 Connection type, [5-19](#)  
[5-35](#)

Cross connections, [5-26](#)  
[8-55](#)  
 add, [5-22](#)  
 add protection, [5-30](#)  
 add with SNC  
 protection, [5-27](#)  
 delete, [5-24](#) [5-34](#)  
 display, [5-18](#)  
 remove SNC protection,  
[5-32](#)  
 Customer identity  
 CID, [5-14](#)

## D

Data communication test  
 perform, [1-17](#)  
 Data communications  
 network  
 See: DCN  
 DCC  
 provision, [1-13](#)  
 DCN address, [8-34](#)  
 Degraded signal, [6-25](#)  
 Degraded signal threshold,  
[6-13](#)  
 Degraded values, [6-25](#)  
 Delete log, [4-42](#)  
 Designated router priority,  
[2-68](#)  
 DNU, [8-43](#)

## E

EMS - Menu window, [9-18](#)  
 Equipment provisioning,  
[2-1](#)  
 Error blocks, [6-25](#)  
 Ethernet address, [8-34](#)  
 External clock output, [8-38](#)

## F

Fallback mode, [4-29](#)  
 Force DNU, [4-29](#)  
 Forced DNU, [4-30](#)  
 Free running mode, [8-39](#)  
 Front panel, [9-3](#)

## H

Help manager, [9-4](#)  
 Hold off time, [6-30](#)  
 Hold over mode, [8-39](#)

## I

Input signal, [8-38](#)  
 Interchangeability marker,  
[2-58](#)  
 IS-IS functionality, [2-69](#)  
 IS-IS level, [2-69](#)  
 Isolate state, [8-30](#)  
 Item code, [2-62](#)  
 ITM-SC  
 login, [9-26](#)

logout, [9-33](#)  
ITM-SC Windows  
general, [9-14](#)

---

**L** LAN group, [5-13](#) [5-13](#)  
LAN group label, [5-13](#)  
LAN group mode, [5-13](#)  
LAN group name, [5-13](#)  
LAN groups and ports  
Wan ports, [8-63](#)  
LAN port, [8-62](#)  
LAN port label, [5-13](#)  
Learning bridges, [8-65](#)  
Lock out, [4-14](#) [4-21](#)  
Lock out request, [4-14](#)  
[4-21](#)  
Locked, [8-39](#)  
Locked mode, [8-39](#)  
Logout of the ITM-SC,  
[9-32](#)  
Loopback state, [6-7](#)

---

**M** Management connection,  
[2-45](#) [2-53](#) [2-67](#)  
Management connections,  
[2-21](#)  
Management information  
base, [8-31](#)  
Management module, [9-11](#)  
Manual area address, [2-69](#)  
Map group, [9-36](#)  
Map groups  
create, [9-43](#)  
modify, [9-44](#)  
place NEs, [9-45](#)  
MDI, [8-36](#)  
view and edit  
information, [2-76](#)

---

MDO, [8-36](#)  
view and edit  
information, [2-80](#)  
Menu bar, [9-19](#)  
MIB, [8-31](#)  
MIB confirm, [8-30](#)  
MIB image, [8-31](#)  
create, [2-51](#)  
MIB update, [8-30](#)  
Modules  
general, [9-4](#)  
ITM-SC specific, [9-10](#)  
Monitored, [4-6](#)  
Mouse usage, [9-8](#)  
MSP, [5-42](#) [8-71](#)  
switch protection, [6-32](#)  
view information, [5-41](#)  
MSP information  
edit, [5-44](#)  
MSP list, [6-34](#)  
Multiplex section  
protection, [8-71](#)

---

**N** NE  
create from  
pre-provisioned NE,  
[2-48](#)  
create from template,  
[2-42](#)  
delete a provisioned  
NE, [2-88](#)  
edit general  
information, [2-64](#)  
edit slot information,  
[2-72](#)  
NE address, [2-26](#) [2-53](#)  
[2-67](#)  
NE information  
edit, [1-3](#)

---

NE location, [2-20](#) [2-26](#)  
[2-44](#) [2-53](#) [2-67](#)  
NE name, [2-20](#) [2-26](#) [2-44](#)  
[2-53](#) [2-67](#)  
NE template  
create, [2-3](#)  
delete, [2-15](#)  
modify, [2-11](#)  
view information, [2-7](#)  
Network  
synchronization, [8-41](#)  
Network element  
timing, [8-38](#)  
Network Map, [9-35](#)  
New group name, [9-40](#)  
Non-revertive, [8-72](#)  
NSAP address, [8-34](#)

---

**O** Old group name, [9-40](#)  
Optical information, [2-83](#)  
view, [2-84](#)  
Option cards, [8-35](#)  
Outgoing QL, [4-30](#)  
Output port timing, [4-25](#)  
[4-29](#)  
Output QL, [4-46](#)  
Output ref., [4-46](#)  
Output state, [4-22](#)

---

**P** Parent group name, [9-40](#)  
Password  
change, [9-27](#)  
Path trace, [6-13](#) [6-18](#) [8-79](#)  
provision, [6-15](#)  
Peak information rate  
PIR, [5-14](#)  
Physical ports, [8-77](#)

---

Port, [6-6](#)  
    provision, [6-4](#)  
Port mode, [6-7](#)  
Port names, [8-67](#) [8-77](#)  
Port timing state, [4-31](#)  
Port types, [8-77](#)  
PRC, [8-41](#) [8-43](#)  
Pre-provisioned NE  
    create, [2-18](#)  
    delete, [2-39](#)  
    edit, [2-24](#)  
    edit slot information,  
        [2-34](#)  
    view, [2-30](#)  
Pre-provisioning, [8-31](#)  
Primary reference clock  
    See: PRC  
Print manager, [9-5](#)  
Priority, [4-15](#) [4-22](#) [8-45](#)  
Provisioning LAN and  
    WAN ports, [5-7](#)  
Provisioning LAN groups,  
    [5-4](#)  
Provisioning methods, [8-31](#)  
Provisioning SDH  
    channels, [5-10](#)

---

**Q** QL, [4-15](#) [8-43](#)  
    -in, [4-6](#)  
    -in status, [4-6](#)  
    -out, [4-7](#)  
    -provisioned, [4-7](#)  
Quality level  
    See: QL

---

**R** Reference fail, [4-7](#)  
Report, [9-28](#)  
    print, [9-30](#)

    view, [9-31](#)  
Retiming, [8-48](#)  
Revertive, [8-71](#)

---

**S** Screen saver, [9-6](#)  
SDH channel, [5-14](#) [5-15](#)  
SDH channel capacity, [5-15](#)  
SDH channel TTP mode,  
    [5-15](#)  
SDH equipment timing  
    source  
    See: SEC  
SEC, [8-42](#) [8-43](#)  
Self-timed, [8-48](#)  
Signal degrade threshold,  
    [8-80](#)  
Signal label, [6-13](#) [8-80](#)  
Signal status, [4-7](#) [4-15](#)  
Signal type, [4-22](#)  
Slot information  
    view, [2-57](#)  
Slot state, [2-32](#)  
SNC, [8-73](#)  
    switch protection, [6-28](#)  
    view information, [5-38](#)  
SNC/I, [8-74](#)  
SNC/N, [8-75](#)  
Software  
    download, [7-9](#)  
    switch stores, [7-14](#)  
    view, [7-3](#)  
Source selection, [4-22](#)  
Spanning tree, [8-65](#)  
SSM out, [4-30](#)  
SSU, [8-41](#)  
SSU-L, [8-41](#) [8-43](#)  
SSU-T, [8-41](#) [8-43](#)

Station clock output, [4-18](#)  
    [4-21](#) [4-22](#) [8-38](#) [8-50](#)  
STCLK output, [4-22](#)  
Style manager, [9-5](#)  
Sub network connection,  
    [8-73](#)  
Switch  
    request, [4-7](#) [4-16](#) [4-23](#)  
    status, [4-16](#) [4-23](#)  
Switch mode, [5-46](#) [6-34](#)  
Switch request, [4-8](#) [5-46](#)  
    [6-30](#) [6-34](#)  
Switch status, [4-9](#)  
Synchronization summary,  
    [4-44](#)  
synchronization summary,  
    [4-46](#)  
Synchronization supply  
    unit  
    See: SSU  
    -local  
        See: SSU-L  
    -transit  
        See: SSU-T  
System and output timing  
    QL mode, [4-16](#) [4-23](#)  
System QL, [4-17](#) [4-46](#)  
System ref., [4-46](#)  
System timing, [4-11](#) [4-14](#)  
    [8-50](#)

---

**T** Template type, [2-9](#) [2-13](#)  
    [2-44](#)  
Templates, [8-31](#)  
    timing, [4-32](#) [4-37](#)  
        [4-37](#) [4-37](#) [4-37](#) [4-37](#)  
Terminal window, [9-6](#)  
Termination points, [5-19](#)  
    [5-25](#) [5-35](#) [6-12](#) [8-79](#)  
    provision, [6-10](#)

Test loop, [8-78](#)

Threshold values

select, [6-21](#)

set or modify, [6-23](#)

TI mode, [6-18](#)

TIM, [6-19](#)

TIM detection, [8-80](#)

Timing, [4-17](#)

alarm reporting, [4-30](#)

event, [4-42](#)

event log, [4-39](#) [4-42](#)  
[4-43](#)

loop, [8-47](#)

mode, [4-17](#) [4-30](#) [8-39](#)  
[8-40](#)

output, [8-38](#) [8-39](#)

reference, [8-38](#) [8-39](#)

source, [4-9](#) [4-24](#) [8-38](#)  
[8-39](#)

Sources, [4-2](#)

sources, [4-5](#) [8-50](#)

state, [4-31](#)

TP mode, [6-12](#)

TP numbering, [6-13](#)

TP type, [6-12](#) [6-25](#)

Trace identifier, [6-18](#)

Transmission plan, [8-53](#)

Transmission protected, [4-9](#)

TUG structure, [6-13](#) [8-56](#)

.....  
**W** Wait to restore time, [5-42](#)  
[5-46](#)

clear, [4-5](#)

global, [4-6](#)

WAN port, [5-14](#)

WAN port capacity, [5-15](#)

WAN ports

SDH channels, [8-63](#)

Worker reference, [4-9](#)

Working section

Protection section, [5-46](#)

Workspace switch, [9-5](#)

.....  
**U** Unit item code, [2-37](#)

Unit type, [2-37](#)

.....  
**V** VC-TTP name, [5-15](#)

View template, [2-6](#)

Virtually concatenated

VCs, [8-64](#)