

**Lucent Technologies**  
Bell Labs Innovations



**I-2000 Controller for DACS II**  
**Release 5.1**

User's Guide

365-353-925  
Issue 2  
August 1998

This material is protected by the copyright and trade secret laws of the United States and other countries. It may not be reproduced, distributed or altered in any fashion by any entity, including other Lucent Technologies Business Units or Divisions, without the expressed written consent of the Customer Technical Support and Information organization.

### **Notice**

Every effort was made to ensure that the information in this document was complete and accurate at the time of printing. However, information is subject to change.

### **Trademarks**

DACScan and Teletype are registered trademarks of AT&T Corporation

MS-DOS is a registered trademark of Microsoft Corporation

OpenWindow is a trademark of Sun Microsystems

Sun is a registered trademark of Sun Microsystems

UNIX is a registered trademark of X/Open Company Ltd.

VT220 is a trademark of Digital Equipment Corporation

### **Warranty**

Lucent Technologies provides no warranty for this document.

# How Are We Doing?

Title: I-2000 Controller for DACS II Release 5.1 User's Guide

Identification No.: 365-353-925 Issue No.: 2 Date: August 1998

Lucent Technologies welcomes your feedback on this Customer Information Product (CIP). Your comments can be of great value in helping us improve our CIPs.

1. Please rate the effectiveness of this CIP in the following areas:

	Excellent	Good	Fair	Poor	Not Applicable
Ease of Use					////////////////////
Clarity					////////////////////
Completeness					////////////////////
Accuracy					////////////////////
Organization					////////////////////
Appearance					////////////////////
Examples					
Illustrations					
Overall Satisfaction					////////////////////

2. Please check the ways you feel we could improve this CIP.

- |  |   |
|--|---|
| <input type="checkbox"/> Improve the overview/introduction | <input type="checkbox"/> Make it more concise/brief                 |
| <input type="checkbox"/> Improve the table of contents     | <input type="checkbox"/> Add more step-by-step procedures/tutorials |
| <input type="checkbox"/> Improve the organization          | <input type="checkbox"/> Add more troubleshooting information       |
| <input type="checkbox"/> Include more figures              | <input type="checkbox"/> Make it less technical                     |
| <input type="checkbox"/> Add more examples                 | <input type="checkbox"/> Add more/better quick reference aids       |
| <input type="checkbox"/> Add more detail                   | <input type="checkbox"/> Improve the index                          |

Please provide details for the suggested improvement. \_\_\_\_\_

3. What did you like most about this CIP?

\_\_\_\_\_

4. Feel free to write any comments below or on an attached sheet.

\_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

If we may contact you concerning your comments, please complete the following:

Name: \_\_\_\_\_ Telephone Number: \_\_\_\_\_


Company/Organization: \_\_\_\_\_ Date: \_\_\_\_\_

Address: \_\_\_\_\_


When you have completed this form, please fold, tape and return to address on back or Fax to: 910 727-3043.

----- Do Not Cut — Fold Here And Tape -----

**Lucent Technologies**  
Bell Labs Innovations



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES



**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 1999 GREENSBORO, NC

POSTAGE WILL BE PAID BY ADDRESSEE

**DOCUMENTATION SERVICES**  
**2400 Reynolda Road**  
**Winston-Salem, NC 27199-2029**



# How Are We Doing?

Title: I-2000 Controller for DACS II Release 5.1 User's Guide

Identification No.: 365-353-925 Issue No.: 2 Date: August 1998

Lucent Technologies welcomes your feedback on this Customer Information Product (CIP). Your comments can be of great value in helping us improve our CIPs.

1. Please rate the effectiveness of this CIP in the following areas:

	Excellent	Good	Fair	Poor	Not Applicable
Ease of Use					////////////////////
Clarity					////////////////////
Completeness					////////////////////
Accuracy					////////////////////
Organization					////////////////////
Appearance					////////////////////
Examples					
Illustrations					
Overall Satisfaction					////////////////////

2. Please check the ways you feel we could improve this CIP.

- |  |   |
|--|---|
| <input type="checkbox"/> Improve the overview/introduction | <input type="checkbox"/> Make it more concise/brief                 |
| <input type="checkbox"/> Improve the table of contents     | <input type="checkbox"/> Add more step-by-step procedures/tutorials |
| <input type="checkbox"/> Improve the organization          | <input type="checkbox"/> Add more troubleshooting information       |
| <input type="checkbox"/> Include more figures              | <input type="checkbox"/> Make it less technical                     |
| <input type="checkbox"/> Add more examples                 | <input type="checkbox"/> Add more/better quick reference aids       |
| <input type="checkbox"/> Add more detail                   | <input type="checkbox"/> Improve the index                          |

Please provide details for the suggested improvement. \_\_\_\_\_

3. What did you like most about this CIP?

\_\_\_\_\_

4. Feel free to write any comments below or on an attached sheet.

\_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

If we may contact you concerning your comments, please complete the following:

Name: \_\_\_\_\_ Telephone Number: \_\_\_\_\_


Company/Organization: \_\_\_\_\_ Date: \_\_\_\_\_

Address: \_\_\_\_\_


When you have completed this form, please fold, tape and return to address on back or Fax to: 910 727-3043.

----- Do Not Cut — Fold Here And Tape -----

**Lucent Technologies**  
Bell Labs Innovations



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES



**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 1999 GREENSBORO, NC

POSTAGE WILL BE PAID BY ADDRESSEE

**DOCUMENTATION SERVICES**  
**2400 Reynolda Road**  
**Winston-Salem, NC 27199-2029**



---

# Contents

---

<b>About This Manual</b>	xxi
■ Purpose of This Manual	xxi
■ Intended Audience	xix
■ How to Use This Manual	xxi
■ What's New in This Release?	xxiii
■ Additional Documents	xxiii
■ Ordering Information	xxv
■ Documentation Conventions	xxv
■ Screen Conventions	xxvi
■ Training	xxvi
■ How to Comment on This Manual	xxvii

---

<b>1</b>	<b>Introduction</b>	1-1
	■ Product Description	1-1
	■ Features	1-8

---

<b>2</b>	<b>Getting Started</b>	2-1
	■ Introduction	2-1
	■ Configuring the DACS	2-1
	■ Setting Environment Variables	2-5
	■ Time Zone	2-16
	■ Logging Into the I-2000	2-18
	■ Remote Printers	2-22
	■ Administering X.25 Links	2-25
	■ Administering Frames	2-25
	■ Configuring Login Ports	2-26
	■ Changing Passwords	2-26
	■ Using the System	2-27
	■ Summary of Menus And Forms	2-42

---

# Contents

---

---

<b>3</b>	<b>System Administration</b>	3-1
	■ Introduction	3-1
	■ SYSTEM ADMINISTRATION Menu	3-1
	■ LOGIN PORTS	3-2
	■ X.25 LINK ADMINISTRATION	3-6
	■ FRAME ADMINISTRATION	3-9
	■ PRINTER ADMINISTRATION	3-26
	■ SHUTDOWN	3-31
	■ DATE and TIME	3-34
	■ SYNCHRONIZE FRAME DATE & TIME	3-36

---

<b>4</b>	<b>NPC Provisioning</b>	4-1
	■ Introduction	4-1
	■ NPC PROVISIONING Form	4-8
	■ NPC Provisioning Examples	4-25
	■ NPC Provisioning ERP	4-35

---

<b>5</b>	<b>Test Port Provisioning</b>	5-1
	■ Introduction	5-1
	■ TEST PORT PROVISIONING Form	5-2

---

<b>6</b>	<b>Circuit Provisioning</b>	6-1
	■ Introduction	6-1
	■ CIRCUIT PROVISIONING Form	6-5
	■ Circuit Provisioning Examples	6-24
	■ BCON Circuits	6-43

---

# Contents

- TSO to Non-TSO Circuits 6-50
- Circuit Provisioning ERP 6-51

---

<b>7</b>	<b>Subrate Provisioning</b>	7-1
	■ Introduction	7-1
	■ Cross-Connection Architecture	7-2
	■ Subrate Provisioning	7-7
	■ DS0 Channel Provisioning	7-7
	■ DS0 Channel Examples	7-14
	■ Subrate Cross-Connect Provisioning	7-17
	■ Subrate Cross Connect Examples	7-22

---

<b>8</b>	<b>Alternate Routing</b>	8-1
	■ Introduction	8-1
	■ Altrouting	8-1
	■ Preempting	8-6
	■ Normalizing	8-7
	■ Altrouting and Normalizing Examples	8-8
	■ NPC ROLL	8-18

---

<b>9</b>	<b>Reconfiguration Plans</b>	9-1
	■ Introduction	9-1
	■ Single Plans	9-2
	■ Reconfiguration Plan Examples	9-9
	■ Modification Plan Examples	9-13
	■ Automatic Plans	9-16
	■ Automatic Reconfiguration Plan Examples	9-19

---

# Contents

---

<b>10</b>	<b>Database Administration</b>	10-1
	■ Introduction	10-1
	■ Database Administration Menu	10-1
	■ Backing Up and Restoring I-2000 Databases	10-26
	■ Entering and Retrieving Outage Data	10-35
	■ Moving a Database from One I-2000 to Another	10-39

---

<b>11</b>	<b>Task Administration</b>	11-1
	■ Introduction	11-1
	■ TASK ADMINISTRATION Menu	11-2

---

<b>12</b>	<b>User Administration</b>	12-1
	■ Introduction	12-1
	■ Constraints	12-2
	■ USER ADMINISTRATION Menu	12-2

---

<b>13</b>	<b>Passthrough</b>	13-1
	■ Introduction	13-1
	■ Passthrough	13-2
	■ Multiplexed Passthrough	13-2
	■ Full Passthrough	13-7
	■ Using Passthrough Selections	13-8
	■ Frame Command Script	13-11

---

# Contents

---

---

<b>14</b>	<b>Report Operations</b>	14-1
	■ Introduction	14-1
	■ REPORT OPERATIONS Menu	14-2
	■ Report Categories	14-6
	■ Custom Report Formats	14-14

---

<b>15</b>	<b>Test Access</b>	15-1
	■ Introduction	15-1
	■ TEST ACCESS Form	15-8
	■ Test Access Examples	15-14

---

<b>16</b>	<b>Fault Management</b>	16-1
	■ Introduction	16-1
	■ Alarm Notification Feature	16-1

---

<b>17</b>	<b>24-Hour Performance Monitoring</b>	17-1
	■ Introduction	17-1
	■ Scheduling Performance Monitoring Reports	17-4
	■ 24-Hour Performance Form	17-5
	■ 24-Hour Performance Monitoring Examples	17-9

---

# Contents

---

---

<b>A</b>	<b>Summary of Fields for Customized Reports</b>	A-1
	■ Introduction	A-1
	■ CIRCUITS Reports	A-2
	■ NPCS Reports	A-4
	■ CHANNELS Reports	A-9
	■ ALTROUTES/PREEMPTIONS	A-10
	■ RECONFIGURATION PLANS Reports	A-11
	■ RECONFIGURATION PLAN ALTROUTE Reports	A-11
	■ AUTO RECONFIGURATION PLANS Reports	A-13
	■ OUTAGES Reports	A-15
	■ ALARM LOG Reports	A-15
	■ TEST PORT Reports	A-17
	■ TEST ACCESS Reports	A-18
	■ FRAMES/LINKS Reports	A-20
	■ USER ADMINISTRATION Reports	A-22
	■ NPC ALARMS Reports	A-22
	■ CIRCUIT ALARMS Reports	A-24
	■ LOST RESPONSE LOG Reports	A-26
	■ 24-HOUR PERFORMANCE MONITORING STATISTICS Reports	A-26
	■ COMMON EQUIPMENT ALARM Reports	A-30

---

<b>B</b>	<b>Error Messages</b>	B-1
	■ Introduction	B-1
	■ Status Error Messages	B-1
	■ Troubleshooting	B-8

---

## **Contents**

---

<b>GL</b>	<b>Glossary</b>	GL-1
-----------	-----------------	------

---

<b>AB</b>	<b>Abbreviations and Acronyms</b>	AB-1
-----------	-----------------------------------	------

---

<b>IN</b>	<b>Index</b>	IN-1
-----------	--------------	------

---

## Figures

Figure 1-1.	Example I-2000 Configuration	1-2
Figure 1-2.	PDN X.25 Configuration	1-6
Figure 1-3.	Point-to-point X.25 Configuration	1-7
Figure 1-4.	Point-to-point SNIDER Configuration	1-8
Figure 2-1.	Sample ui_dval.eng File	2-16
Figure 2-2.	MAIN MENU	2-27
Figure 2-3.	Command Response Pop-up Window	2-36
Figure 2-4.	Confirmation Window	2-37
Figure 2-5.	Select Schedule or Confirm Window	2-37
Figure 2-6.	Task Scheduling Window	2-38
Figure 2-7.	Database Selection Window	2-41
Figure 3-1.	SYSTEM ADMINISTRATION Menu	3-2
Figure 3-2.	LOGIN PORT ADMINISTRATION Form	3-4
Figure 3-3.	X.25 LINK ADMINISTRATION Form	3-7
Figure 3-4.	Fully Backed-up Configuration (DACS II)	3-10
Figure 3-5.	Backup of Link to Frame Only (DACS II)	3-11
Figure 3-6.	Backup of I-2000 Link Only	3-11
Figure 3-7.	FRAME ADMINISTRATION Form	3-13
Figure 3-8.	Creating a Frame Using X.25	3-19
Figure 3-9.	Change Site Name	3-21
Figure 3-10.	Creating a Frame, Using SNIDER	3-22
Figure 3-11.	I-2000 NAME CHANGE Form	3-25
Figure 3-12.	PRINTER MANAGEMENT Form	3-27
Figure 3-13.	Sample Print-Job Status	3-29
Figure 3-14.	SHUTDOWN TIME Pop-up Menu	3-32
Figure 3-15.	SHUTDOWN TYPE Pop-up Menu	3-33
Figure 3-16.	TIME and DATE ADMINISTRATION Form	3-35
Figure 4-1.	PROVISIONING Menu	4-8
Figure 4-2.	CEPT NPC Provisioning Form (Types PB/PC)	4-9
Figure 4-3.	Subrate NPC Provisioning Form (Type SD)	4-10
Figure 4-4.	Enhanced CEPT NPC Provisioning Form (Type PA)	4-11
Figure 4-5.	NAS NPC Provisioning Form (Types DE/TE)	4-12
Figure 4-6.	Enhanced NAS NPC Provisioning Form (Types DA/TA)	4-12
Figure 4-7.	Clear DS1 NAS NPC Provisioning Form (Type DE9y9)	4-13

---

## Figures

Figure 4-8.	Clear DS1 through DS3 NAS NPC Provisioning Form (Type TE9y9)	4-13
Figure 4-9.	DMB NPC Provisioning Form (Type MB)	4-14
Figure 4-10.	CEPT NPC Query For PB Type	4-31
Figure 4-11.	CEPT NPC Query Form, PA, First Page	4-32
Figure 4-12.	CEPT NPC Query Form, PA, Second Page	4-33
Figure 4-13.	NAS NPC Query Form	4-34
Figure 4-14.	NPC Browse Screen	4-35
Figure 5-1.	TEST PORT PROVISIONING Form	5-2
Figure 6-1.	Circuit Provisioning Example—Two Sequential Time Frames	6-5
Figure 6-2.	CIRCUIT PROVISIONING Form	6-6
Figure 6-3.	CIRCUIT PROVISIONING SEARCH CRITERIA Form	6-7
Figure 6-4.	Sample Full-duplex Circuit	6-25
Figure 6-5.	Sample Clear DS1 Full-duplex Circuit	6-26
Figure 6-6.	Sample Half-duplex Circuit	6-27
Figure 6-7.	Sample Half-Duplex Loopback Circuit	6-28
Figure 6-8.	Ideal Broadcast Circuit	6-32
Figure 6-9.	Sample Broadcast Circuit	6-34
Figure 6-10.	Sample Symmetric Voice Circuit	6-36
Figure 6-11.	Sample Polling Data Circuit	6-38
Figure 6-12.	Cascaded Symmetric Voice Circuit	6-41
Figure 6-13.	Single Polling Data Circuit	6-41
Figure 6-14.	BBL-to-BBL Cascaded Polling Data Circuit	6-42
Figure 6-15.	BBL-to-BRD Cascaded Polling Data Circuit	6-42
Figure 6-16.	CIRCUIT PROVISIONING Form, Adding a LEG for Contiguous Circuits	6-44
Figure 6-17.	CIRCUIT PROVISIONING Form, Adding a LEG for Random Circuits	6-45
Figure 6-18.	CIRCUIT PROVISIONING Form, Adding a BKB for E1 Circuits	6-46
Figure 6-19.	CIRCUIT PROVISIONING Form, Modifying a BKB E1 Circuits	6-48
Figure 6-20.	CIRCUIT PROVISIONING Form, Deleting a LEG from a BKB Circuit	6-49
Figure 6-21.	CIRCUIT PROVISIONING Form, Changing the Return Path of a BCON Circuit	6-50
Figure 7-1.	Cross Connection Architecture	7-2
Figure 7-2.	Inter-NPC Bus Architecture for DSPP Circuit Pack	7-3

---

## Figures

Figure 7-3.	X.50 Customer Circuit Cross-Connection Diagram	7-4
Figure 7-4.	X.50 to X.57 Customer Circuit Cross-Connection Diagram	7-6
Figure 7-5.	PROVISIONING Menu	7-9
Figure 7-6.	ESTABLISH DS0 CHANNEL Form	7-10
Figure 7-7.	ESTABLISHED DS0 CHANNELS SEARCH CRITERIA Form	7-16
Figure 7-8.	SUBRATE CROSS CONNECT Form	7-18
Figure 7-9.	SUBRATE CIRCUITS SEARCH CRITERIA Form	7-24
Figure 8-1.	CIRCUIT PROVISIONING Form	8-3
Figure 8-2.	ALTRROUTE Screen	8-4
Figure 8-3.	Example of Altrouting	8-10
Figure 8-4.	NPC ROLL Form	8-19
Figure 9-1.	RECONFIGURATION PLAN (RP) PROVISIONING Form	9-3
Figure 9-2.	AUTOMATIC RECONFIGURATION PLAN PROVISIONING Form	9-16
Figure 10-1.	DATABASE ADMINISTRATION Menu	10-2
Figure 10-2.	Virtual Multipoint Circuit	10-9
Figure 10-3.	Stage 1 of the UPLOAD Action: NPC SYNC	10-11
Figure 10-4.	Stage 2 & 3 of the UPLOAD Action: CHANNEL SYNC/ SUBRATE SYNC	10-11
Figure 10-5.	DATABASE AUDIT/SYNCHRONIZATION Form	10-14
Figure 10-6.	Two Two-point, One-way Circuits	10-18
Figure 10-7.	A Two-point, Two-way Circuit	10-18
Figure 10-8.	DATABASE AUDIT/SYNCHRONIZATION Form	10-19
Figure 10-9.	AUDIT/SYNCHRONIZATION SEARCH CRITERIA Form	10-21
Figure 10-10.	NPC Range Fields	10-22
Figure 10-11.	BACKUP/RESTORE Menu	10-27
Figure 10-12.	DATABASE BACKUP/RESTORE (TAPE) Form	10-28
Figure 10-13.	LOG BACKUP/RESTORE (TAPE) Form	10-31
Figure 10-14.	LOG BACKUP/RESTORE (DISKETTE) Form	10-33
Figure 10-15.	Insert Disk Prompt	10-34
Figure 10-16.	OUTAGE LOG Form	10-36
Figure 11-1.	TASK ADMINISTRATION Menu	11-2
Figure 11-2.	TASK ADMINISTRATION Form	11-3
Figure 11-3.	A Displayed Task	11-5
Figure 11-4.	PRINTER QUEUE STATUS Form	11-6

---

## Figures

Figure 11-5	PRINTER QUEUE STATUS Form	11-8
Figure 11-6.	Sample Print-job Status	11-9
Figure 12-1.	USER ADMINISTRATION Menu	12-2
Figure 12-2.	USER MANAGEMENT Form	12-3
Figure 12-3.	PASSWORD CHANGE Form	12-7
Figure 13-1.	PASSTHROUGH Choices Menu	13-4
Figure 13-2.	Output Choices Menu for MULTIPLEXED PASSTHROUGH	13-5
Figure 13-3.	MULTIPLEXED PASSTHROUGH Screen	13-6
Figure 13-4.	Passthrough Screen	13-8
Figure 13-5.	Passthrough Form	13-11
Figure 13-6.	FRAME COMMAND SCRIPT Form	13-13
Figure 13-7.	FRAME COMMAND SCRIPT Screen	13-17
Figure 14-1.	REPORT OPERATIONS MENU	14-2
Figure 14-2.	CHANNEL USAGE SEARCH CRITERIA Form	14-3
Figure 14-3.	REPORT TO DOS DISKETTE Form	14-5
Figure 14-4.	RECONFIGURATION SUB-MENU	14-12
Figure 14-5.	Selection of Report Format Category	14-15
Figure 14-6.	Sample Edit Custom Report Format Form	14-16
Figure 14-7.	Sample Report Format	14-18
Figure 15-1.	Illustration Of Monitor Test Access	15-3
Figure 15-2.	Illustration Of Monitor Test Access, TLA Applied in T Direction	15-3
Figure 15-3.	Illustration Of Monitor Test Access, TLA Applied in F Direction	15-4
Figure 15-4.	Illustration Of Monitor Test Access, TLA Applied in B(oth) Directions	15-4
Figure 15-5.	Illustration Of Split Test Access	15-5
Figure 15-6.	Illustration Of Split Test Access, TLA Applied in T Direction	15-5
Figure 15-7.	Illustration Of Split Test Access, TLA Applied in F Direction	15-6
Figure 15-8.	Illustration of Split Test Access, TLA Applied in B(oth) Directions	15-6
Figure 15-9.	Illustration Of Hub Test Access	15-7
Figure 15-10.	TEST ACCESS Form	15-8
Figure 16-1.	Sample Alarm Report	16-3
Figure 17-1.	Intervals when Performance Monitoring Reports are Expected	17-5
Figure 17-2.	PROVISIONING Menu	17-6

---

## Figures

Figure 17-3.	24-HOUR PERFORMANCE Form	17-6
Figure 17-4.	24-HOUR PERFORMANCE Browse Screen	17-9
Figure 17-5.	24-HOUR PERFORMANCE Reset Screen	17-10

---

## Tables

Table 2-1.	Environmental Variables	2-5
Table 2-2.	G2_FMT_STRING And BTLP_FMT_STRING Characters	2-12
Table 2-3.	G2_FMT_STRING And BTLP_FMT_STRING Conversion Specifications	2-12
Table 2-4.	G2_DATE_FORMAT And BTLP_DATE_FORMAT Conversion Specifications	2-13
Table 2-5.	Menu Control Keystrokes	2-29
Table 2-6.	Form Control Keystrokes	2-30
Table 2-7.	Passthrough Control Keystrokes	2-32
Table 2-8.	Preprogrammed Function Keys	2-34
Table 2-9.	TASK SCHEDULING Field Descriptions	2-39
Table 2-10.	Screen Contents	2-40
Table 2-11.	Summary of Menus and Forms	2-43
Table 3-1.	Port Numbering Scheme	3-3
Table 3-2.	LOGIN PORT ADMINISTRATION Field Descriptions	3-4
Table 3-3.	X.25 LINK ADMINISTRATION Field Descriptions	3-7
Table 3-4.	FRAME ADMINISTRATION Field Descriptions	3-14
Table 3-5.	PRINTER MANAGEMENT Field Descriptions	3-26
Table 4-1.	NPC Provisioning Types	4-4
Table 4-2.	Supported Activities for DSP Applications and Echoed Response Processing	4-4
Table 4-3.	Valid Old/New Types for a MODIFY Action	4-5
Table 4-4.	NPC Number Equivalents for DACS II FTU-type Units	4-7
Table 4-5.	NPC Number Equivalents for DACS II DSPU-type Units	4-7
Table 4-6.	NPC Number Equivalents for DACS II DS3U-type Units	4-8
Table 4-7.	NPC PROVISIONING Field Descriptions	4-14
Table 4-8.	Alarms For CEPT NPC Performance Parameters For Types Other Than PA	4-24
Table 4-9.	Alarms For CEPT NPC Performance Parameters For Type PA	4-24
Table 4-10.	Alarms For NAS NPC Performance Parameters	4-25
Table 5-1.	Test Port Groups Supported, By Frame	5-2
Table 5-2.	TEST PORT PROVISIONING Field Descriptions	5-3
Table 6-1.	CIRCUIT PROVISIONING Field Descriptions	6-8
Table 6-2.	Summary of CIRCUIT PROVISIONING Field Values	6-22
Table 6-3.	DMB Conference Information	6-40

---

## Tables

Table 6-4.	ERP Messages	6-52
Table 7-1.	ESTABLISH DS0 CHANNEL Field Descriptions	7-11
Table 7-2.	SUBRATE CROSS CONNECT Field Descriptions	7-19
Table 8-1.	ALTRROUTE Field Descriptions	8-5
Table 8-2.	Sample Provisioned NPCs	8-9
Table 8-3.	Sample Provisioned Circuits	8-9
Table 8-4.	NPC ROLL Field Descriptions	8-19
Table 9-1.	RECONFIGURATION PLAN PROVISIONING Field Descriptions	9-3
Table 9-2.	AUTOMATIC RECONFIGURATIN PLAN Field Descriptions	9-17
Table 10-1.	NPC Parameters Audited	10-4
Table 10-2.	Circuit Parameters Audited	10-5
Table 10-3.	DSPP Types supported for Subrate Provisioning	10-12
Table 10-4.	DATABASE AUDIT/SYNCHRONIZATION Field Descriptions	10-14
Table 10-5.	Outage Log Field Descriptions	10-36
Table 10-6.	Record Number Field Descriptions	10-39
Table 11-1.	Task Administration Field Descriptions	11-3
Table 11-2.	TASK ADMINISTRATION Field Descriptions	11-5
Table 11-3.	PRINTER QUEUE STATUS Descriptions	11-7
Table 12-1.	USER MANAGEMENT Field Descriptions	12-4
Table 13-1.	Full PASSTHROUGH Control Keys	13-9
Table 13-2.	MULTIPLEXED PASSTHROUGH Control Keys	13-10
Table 13-3.	FRAME COMMAND SCRIPT Field Descriptions	13-14
Table 14-1.	REPORT TO DOS DISKETTE Field Descriptions	14-5
Table 14-2.	Edit Custom Report Format Field Descriptions	14-16
Table 15-1.	Test Access Field Descriptions	15-9
Table 15-2.	Allowed Test State Sequences	15-13
Table 16-1.	Explanation of DACS II and DACS II ISX Alarm Message Elements	16-3
Table 16-2.	Alarm Thresholds	16-8
Table 16-3.	Error Status Register <i>field1</i> Bit Mask	16-9
Table 16-4.	Error Status Register <i>field2</i> Bit Mask	16-9
Table 16-5.	Error Status Register <i>field1</i> Bit Mask	16-10
Table 16-6.	Error Status Register <i>field2</i> Bit Mask	16-10
Table 17-1.	Invalid PA Parameters (Based on <i>x</i> value in PAxyz NPC Type)	17-3
Table 17-2.	Invalid PA Parameters (Based on <i>y</i> value in PAxyz NPC Type)	17-3

---

## Tables

Table 17-3.	24-HOUR PERFORMANCE Field Descriptions	17-7
Table A-1.	CIRCUITS Reports Fields	A-2
Table A-2.	NPCS Reports Fields	A-4
Table A-3.	CHANNELS Reports Fields	A-9
Table A-4.	ALTROUTES/PREEMPTIONS Reports Fields	A-10
Table A-5.	RECONFIGURATION PLANS Reports Fields	A-11
Table A-6.	RECONFIGURATION PLAN ALTROUTE Reports Fields	A-11
Table A-7.	AUTO RECONFIGURATION PLAN Reports Fields	A-13
Table A-8.	OUTAGES Reports Fields	A-15
Table A-9.	ALARM LOG Report Fields	A-15
Table A-10.	TEST PORT Reports Fields	A-17
Table A-11.	TEST ACCESS Reports Fields	A-18
Table A-12.	FRAMES/LINKS Reports Fields	A-20
Table A-13.	USER ADMINISTRATION Reports Fields	A-22
Table A-14.	NPC ALARMS Reports Fields	A-22
Table A-15.	CIRCUIT ALARMS Reports Fields	A-24
Table A-16.	LOST RESPONSE LOG Report Fields	A-26
Table A-17.	24-HOUR PERFORMANCE MONITORING Report Fields	A-26
Table A-18.	COMMON EQUIPMENT ALARM Report Fields	A-30
Table B-1.	STATUS Error Messages	B-1

---

## About This Manual

---

### **Purpose of This Manual**

This manual provides step-by-step procedures on how to use the I-2000 Controller for DACS II. For information on installation and maintenance, refer to the list of documents in "Accompanying Documents" in this chapter.

### **Intended Audience**

This manual is written for customers who have some familiarity with DACS operations.

### **How to Use This Manual**

A brief description of each chapter's contents is provided to give the user an overview of the document:

- **About This Manual** provides information on how to use this manual, information about related documents, documentation conventions, and descriptions of new features for this release.
- **Chapter 1: Introduction** provides information on the I-2000 Controller and its features.
- **Chapter 2: Getting Started** provides information on configuring the DACS II frame, setting environment variables, logging into and using the I-2000 software.

- **Chapter 3: System Administration** provides an introduction to system administration, such as login ports, X.25 link administration, frame administration, and printer administration.
- **Chapter 4: NPC Provisioning** provides information on NPC provisioning, its forms, field descriptions and examples of operations, such as creating an NPC and placing it in service, removing an NPC, and querying an NPC.
- **Chapter 5: Test Port Provisioning** provides information on test port provisioning and its forms, field descriptions, and examples of operations, such as creating and deleting a test port group.
- **Chapter 6: Circuit Provisioning** provides information on circuit provisioning, its forms, field descriptions, and examples of circuit provisioning, such as full duplex circuit, loopback circuit, and cascaded multipoint circuits.
- **Chapter 7: Subrate Provisioning** provides information on provisioning DS0 channels, and establishing subrate cross connections.
- **Chapter 8: Alternate Routing** provides information on alternate routing, preempting, normalizing, and examples, such as altrouting and normalizing single channel circuits, and multipoint circuits.
- **Chapter 9: Reconfiguration Plans** provides information and examples on reconfiguration plans, single plans, and automatic plans for the I-2000 Controller.
- **Chapter 10: Database Administration** provides information on database audit synchronization, backing up and restoring the database, entering and retrieving outage data, and moving a frame.
- **Chapter 11: Task Administration** provides information on task administration and printer status.
- **Chapter 12: User Administration** provides information on I-2000 features and constraints, user management, and password administration.
- **Chapter 13: Passthrough** provides information on multiplexed passthrough, full passthrough, and how to use the passthrough feature, as well as field descriptions and examples.
- **Chapter 14: Report Operations** provides information on report operations, such as generating and displaying reports, report categories, and report formats.
- **Chapter 15: Test Access** provides information on Test access, field descriptions, and examples, such as NAS two-point circuits, unmapped NAS circuits, and NAS multipoint circuits.
- **Chapter 16: Fault Management** provides information on the Alarm Notification feature, a list of DACS II alarm message elements, and an explanation of these elements.

- **Chapter 17: 24-Hour Performance Monitoring** provides information on how to RESET and BROWSE performance statistics for the I-2000.
- **Appendix A: Summary of Report Fields** provides information on the fields for the reports.
- **Appendix B: Error Messages** provides information on the error messages that appear on the I-2000 STATUS line. Procedures for resolving problems are also included.
- **Glossary** defines the terms used throughout this document.
- **Abbreviations and Acronyms** provides the definitions for the acronyms used throughout this document.
- **Index** allows you to quickly locate information on topics covered in the document. To use the index, look up the topic you want and turn to the page references listed by that topic.

## What's New in This Release?

---

New features for the I-2000 Controller for DACS II Release 5.1 are:

- **DACS II Release 8.2.x and DACS II ISX Release 3.1.2 support**

All features are supported. Exceptions are the DS3 hybrid unit and subrate features of DACS II and LSIU NPCs feature of DACS II ISX.

- **Year 2000 compliance**

This release of I-2000 is fully year 2000 compliant.

## Additional Documents

---

The following documents provide additional information on DACS, and can be useful when using the I-2000 with DACS II and DACS II ISX.

Some documents are not specifically relevant to I-2000 features; however, they can be useful; for example, to an expert user in passthrough mode.

The DACS II and DACS II ISX documents are issued to support each release. Be sure to obtain the documents that support the release that is running with your I-2000 system.

## **DACS II Additional Documents**

---

The list below provides additional DACS II documentation for Release 8.2.2:

- *DACS II Operations and Maintenance*  
Release 8.2.2 MML  
2.048-Mbit/s Interface  
Number: 365-353-191
- *DACS II Commands and Messages*  
Release 8.2.2 MML  
2.048-Mb/s Interface  
Number: 365-353-192
- *DACS II Quick Reference Guide*  
Release 8.2.2 MML  
2.048-Mb/s Interface  
Number: 363-353-193

## **DACS II ISX Additional Documents**

---

The list below provides additional DACS II ISX documentation for Release 3.1.2:

- *DACS II ISX Operations and Maintenance*  
Release 3.1.2 MML  
Number: 365-359-103
- *DACS II ISX Commands and Messages*  
Release 3.1.2 MML  
Number: 365-359-104
- *DACS II ISX Quick Reference Guide*  
Release 3.1.2 MML  
Number: 365-359-105
- *DACS II ISX Installation Manual*  
Number: 365-359-080

## Ordering Information

---

Documentation for the I-2000, DACS II, and DACS II ISX can be ordered through the Customer Information Center (CIC) in Indianapolis. Many documents are available in hard copy and on compact disk. For more information, call:

**1-888-LUCENT-8 (1-888-582-3688)**

**1-317-322-6416 (Outside North America)**

For automatic updates (for one year), request that the document be given "standing order" status. The mailing address follows:

Customer Information Center  
ATTN: Customer Service Representative  
2833 N. Franklin Road  
Indianapolis, IN 46219

The Lucent CIC also maintains a netsite that can be used for obtaining delivery of Lucent customer information products. The netsite address for the Lucent CIC homepage follows:

**[/http://www.cic.lucent.com/](http://www.cic.lucent.com/)**

Once you access the Lucent CIC home page, clicking on the:

### **Documents**

selection will take you to the area through which numerous types of customer information products can be located, ordered, and/or downloaded.

## Documentation Conventions

---

The following conventions are used throughout this manual.

- Key names are shown as they are on a typical keypad and are enclosed in a box, such as:

**Enter** or **^**

- **Enter** represents the Enter or **Return** key on your keyboard.
- Function key labels are in all capital letters and are enclosed in a box; for example:

**EXECUTE**

- Field names appear in bold type; for example:

**Site Name**

- Literal command examples, screen prompts, and screen examples are in monospace font:

THE COMMAND COMPLETED SUCCESSFULLY

- In command formats, literals to be typed are in **bold** type:  
`cd root`
- In command formats, and sometimes in literal examples, value names to be filled in are in italic type:  
`mm dd yy`
- Field values are in monospace font:  
`Ckt ID: circuit01`
- Menu selections are stated as they are on the screen in unemphasized capital letters:  
`PROVISIONING`
- Screens and printouts are in 8-point monospace.

The above conventions allow you to distinguish easily between menu selections, field names, field values and function key names in instructions and field descriptions. Bold and italic are used in other contexts for table titles, emphasis or document references.

## Screen Conventions

---

The I-2000 screens shown in this manual depict the system with these options enabled: X.50 subrate feature and 24-hour performance monitoring. The screens on your system may appear differently depending on the features that are installed.

The I-2000 screens display the host name of the workstation and a user interface session number just above the list of function keys on each screen (**UI-00** to **UI-15**). This number is used to identify the user commands and print jobs associated with a user interface session. This information is not shown on the screens in this manual.

## Training

---

This document, as well as the I-2000 course material, are used in the I-2000 Controller for DACS II training courses.

## **How to Comment on This Manual**

---

A comment form is located after the title and legal pages in front of this document. If you have comments, please do the following:

1. Fill out the form (name, company, address, and telephone number are optional).
2. Remove the form from the binder.
3. Fold it in half so that the address can be seen by the postal service (tape the ends together at the bottom).
4. Mail the form to:

Lucent Technologies  
Documentation Services  
2400 Reynolda Road  
Winston-Salem, NC 27199-2029

---

**Contents**

<b>Product Description</b>	1-1
■ Types of Provisioning	1-4
■ Additional Functionality	1-5
<b>Features</b>	1-8
■ System Features	1-8
■ Features Under Menu Control	1-9
■ Autonomous Features	1-10
Alarm Monitoring	1-10
Echoed Response Processing	1-11

---

## **Introduction**


# **1**

---

### **Product Description**

The Lucent Technologies I-2000 Controller for DACS II is a computing system configuration that allows up to 16 users, which includes the console, to simultaneously manage multiple cross-connect DACSs through a user-friendly interface. In addition, the I-2000 supports up to 30 DACS and/or 15,360 NPCs, whichever is less. In addition, optional connections to the Event Management System Interface are also available through the I-2000 Controller.

The elements of the configuration are the DACS frames and the I-2000 computing system. Figure 1-1 illustrates how the I-2000 connects to the DACS and user terminals.



**Figure 1-1. Example I-2000 Configuration**

The terms *DACS* and *frame* used in this manual refer to any supported configured cross-connect frame.

The I-2000 Controller allows you to configure a variety of products, and establish links to a range of DACS.

**⇒ NOTE:**  
You must make hardware and networking selections before installing the I-2000 Controller.

A Digital Access and Cross-connect System (DACS) is a device for cross-connecting, or switching, between lines that have been time-division multiplexed; for example, the DACS provisions cross-connections for multiplexed digital transmission. Typically, a DACS is used for connecting trunk lines.

The voice-circuit input for trunk transmission is collected and multiplexed by other switching and multiplexing equipment. It enters the DACS and is routed through a cross-connection to a channel on another DACS some distance away, where it is again routed to telephone switching equipment for demultiplexing and delivery. The DACS on the other side is the far end.

The first electronic cross-connect frame was termed the DACS, currently DACS I. It features modularized circuits called circuit packs that can easily be replaced.

In the DACS I, the basic integrated circuits to make cross-connections are located in a circuit pack, the digroup circuit, which receives a multiplexed, Digital Signal, level 1 (DS1) signal and makes available two groups of 12 channels each. As other types of circuit packs were added to implement different types of cross-connection, such as multipoint and subrate, a more generic name was needed for the other circuit packs that accomplish cross-connection and are interchangeable in the same slots. The term Network Processing Circuit (NPC) was applied.

DACS II upgrades DACS I functions and takes advantage of a more advanced technology; specifically, miniaturization.

For DACS II, two digroups are located on a single circuit pack, which is called a Dual Digroup Card (DDC). NPC is one digroup of 24 channels for the North American Standard (NAS) transmission.

DACS II circuit packs, which are designed for transmission according to the Conference European Postale et Telephonique (CEPT) standard, feature Dual Primary Circuits (DPCs). One DPC contains two NPCs of 32 channels each; however, one channel is used for timing signals and one channel is used for signalling bits. When signalling is used there are 30 voice/data channels available, when signalling is not used, there are 31 voice/data channels.

DACS II is a cross-connect frame which provides for:

- Terminating DS1/E1 multiplexed signals:
  - Digital Signal, level 3 units (DS3U) contain a maximum of six DS3 terminations per unit. A Capacity Expansion Frame (CEF) features up to 16 DS3Us. Each DS3 termination has the capacity for 28 NPCs.
  - Facility Terminating Units (FTUs) contain a maximum of four facility terminating modules (FTMs) per unit. A CEF features up to 16 FTUs. Each module contains up to 20 dual digroup cards (DDCs) for NAS provisioning or up to 16 dual primary circuits (DPCs) for CEPT provisioning.
  - Each DDC or DPC contains two NPCs.
  - One NPC terminates one digroup of 24 channels each for NAS provisioning or 31 channels each for CEPT provisioning.

For example, one DACS II configured with four FTUs, 16 FTMs, and 320 DDCs or DPCs can make available 640 NPCs for cross-connection. A fully configured CEF with 16 DS3Us can make available 2,688 NPCs.

- Establishing DS0 two-point cross-connections between the channels.

One or two Cross-connect Network (CCN) cards contain the circuits to analyze the multiplexed signal into its constituent Digital Signal, level 0 (DS0) signals and re-time and switch the constituent DS0s into the desired channels.

- Establishing multipoint cross-connections.

Digital signal processing units (DSPUs) can perform these functions. Multipoint cross-connections can also be virtual; for example, they can be established without the aid of the DSP shelf.

Additional hardware supports other cross-connect capabilities for the DACS II. One or more TG80 cards support clear DS1 signals, and DS3 signal packs support DS3-level signals, which can be cross-connected as 672 DS0 channels per DS3 pack or as 28 clear DS1 signals.

The I-2000 allows you to take advantage of DACS capabilities in a more user-friendly way. Prior to the I-2000, an operator utilized a command-line interface to generate DACS commands. You can still use the DACS as a stand-alone in this way.

The I-2000 adds a control interface to generate DACS commands; for example, it is a user-friendly front-end, as well as a circuit and facility management system. Provisioning operations are selected from menus and the number of circuit characteristics through preformatted screens (forms). The I-2000 automatically generates the appropriate DACS commands and sends them to the target DACS.

Provisioning is the main task of an I-2000, such as establishing, deleting or restoring circuits between communications channels that terminate at the DACS channel ends (external facility terminations).

## **Types of Provisioning**

---

The I-2000 provides four types of provisioning:

- **NPC Provisioning**—informs the I-2000 computer database what channels are terminated in a DACS and what their characteristics are. It establishes logical NPCs and channels corresponding to the physical ones.

For more information on NPC provisioning, refer to Chapter 4 “NPC Provisioning.”

- **Subrate Provisioning**—allows you to provision subrate circuits on a specified NPC for X.50 and X.57 subrate functionality.

For more information on Subrate provisioning, refer to Chapter 7 “Subrate Provisioning.”

- **Test Port Provisioning**—establishes logical test ports that can be connected to test equipment that can be used for testing channels. The equipment must be physically in place.

For more information on Test Port provisioning, refer to Chapter 5 “Test Port Provisioning.”

- **Circuit Provisioning**—makes the logical cross-connections needed to create circuits between NPCs (all channels of the NPC) or between individual channels of an NPC, and sends the commands effecting the physical cross-connecting to the DACS. Circuits can also be created, deleted or changed automatically according to stored, user-defined reconfiguration plans.

For more information on Circuit Provisioning, refer to Chapter 6 "Circuit Provisioning."

Other cross-connect administrative operations performed by the I-2000 include:

- Circuit altrouting (alternate routing on a temporary basis)
- Preempting (temporary overrouting)
- Normalizing (restoring altrouted or preempted circuits)

### **Additional Functionality**

---

Additional functionality includes the following features:

Circuit reconfiguration allows the operator to create, execute, and store circuit reconfiguration plans.

- Test access lets the operator route circuits to test ports or test groups.
- Alarm reporting notifies the operator of all major and critical DACS alarms.

There is also an I-2000-transparent mode of operation, called passthrough, in which an expert operator can communicate with a DACS directly, as though the I-2000 console were a DACS console. You can also write scripts of DACS commands in huMan Machine Language (MML), store them on a DOS diskette, or retrieve them from there, and execute them.

The I-2000 maintains its own databases in order to track its operations and record the state of its circuits. You can back them up on tape or diskette, and restore from there. The information in the databases is accessible by the operator as printed or displayed reports. The I-2000's report generation functions are very flexible and let you create report templates and individual reports as required.

There are occasions when the I-2000 and DACS databases may not correspond; that is, they can have become inadvertently out of synchronization.

As part of its repertoire of administrative functions, the I-2000 supports automatic or scheduled synchronization of:

- NPC provisioning data
- Circuit provisioning data
- Alarm data

The security of the network is an important concern, especially because it can contain so many elements and, therefore, has a greater risk of intrusion. Access to any I-2000 is controlled by a password. Within an I-2000, the system administrator assigns logins. In addition, access to the network is also limited.

The quantity and arrangement of the pool of available resources: DACSs, I-2000, DACScan and the peripherals for mass storage, display or printing available to each, is widely variable. You can build whatever system is practical and economic for the application. Within an I-2000, the element configuration is user-selectable on installation or reinstallation only.

The possible configurations between the I-2000 and the DACS it controls are:

- X.25 packet data network
- X.25 direct (point-to-point)
- SNIDER direct




**NOTE:**

Systems including multiple I-2000s or the DACScan require the Packet Data Network (PDN).

In the X.25 network, each DACS and the I-2000 computer become nodes. The user terminals are peripheral to an I-2000 computer. Communication between an I-2000 computer and a DACS is defined by the Comite Consultatif International Telegraphique et Telephonique (CCITT) standard X.25 Data Terminal Equipment/ Data Circuit-terminating Equipment (DTE/DCE) interface.

Users may access the I-2000 and obtain a user interface over X.25. The user must have access to the PDN, an X.25 PAD, and the I-2000 network address(es).

The network supports link protection. Without link protection, the I-2000 computer is connected to the network by two links, and a DACS by one. With full link protection, the I-2000 computer is connected by up to four lines: two primary and two backup, and a DACS is connected by one primary and one backup, as shown in Figure 1-2.



---


**Figure 1-2. PDN X.25 Configuration**

The automatic switching of the Primary to Backup X.25 communication link is not revertive. For example, if the Primary link fails the system will automatically switch to the Backup link, but it will not automatically switch back when the Primary is fixed. The Backup link will need to fail for the system to switch back to the fixed Primary or it can be manually switched back.

In the direct configurations, the user terminals and the DACSs are connected directly to an I-2000 computer and communicate under either the X.25 or the SNIDER protocol.

Although the X.25 is designed to interface to a PDN, it can be used with a point-to-point connection (I-2000 computer to DACS) if each DACS line contains a Synchronous Modem Eliminator (SME) to provide the timing signals.

Figure 1-3 shows a point-to-point X.25 configuration with link protection.




---

**Figure 1-3. Point-to-point X.25 Configuration**

Figure 1-4 shows a direct configuration that uses the SNIDER protocol (asynchronous data link), instead of the X.25. In that case, SMEs or modems are not required, and also link protection is not available.

**⇒ NOTE:**  
X.25 configuration files are set up, by default, to support PDN. X.25. Configuration files must be modified to support direct connection. Contact Lucent technical support for information.



---

**Figure 1-4. Point-to-point SNIDER Configuration**

## Features

---

I-2000 features are packaged into basic configurations called releases. A number of releases have been issued and they continue on an ongoing basis. This manual covers Release 5.1 only.

The features associated with this release are listed in the "Summary of Menus And Forms," in Chapter 2 "Getting Started."

## System Features

---

The hardware and system software features for the I-2000 Controller are listed below:

- A variety of hardware platforms described in the I-2000 Controller for DACS II Installation Manual and the Software Release Description for this release.
- A choice of configurations varying the type and the capacity of disk and tape drives.
- Within one configuration, a choice of boards for the slots, to vary the number and type of input/output (I/O) ports.
- Optional remote printer connection through a DECserver 700.

- Control of one through 30 DACS in DACS II Releases 4 and higher, and DACS II ISX Releases 1.0 and higher.
- Cross-connections for a combined total of up to 15,360 DACS II NPCs. For example, 20 DACS IIs of 512 NAS NPCs per DACS would make available approximately 10,240 digroups and 345,760 channel ends, supporting 123,880 full-duplex circuits.
- With DACS II only, clear DS1-level cross-connections through the DACS II's TG80 and TG191 Cards. DACS II Release 6 adds CEPT clear E1 cross-connections through the TG192 Card.
- Support for the DACS II's DS3-level circuit packs.
- TS0 to non-TS0 CEPT cross-connections.
- Login and password protection. Support of up to 16 simultaneous sessions and 64 different logins. Each window counts as a user session.
- Remote terminal support for AT&T 605, 615, 620, 705, 4425, TELETYPE® 5425 asynchronous user terminals, and DEC vt220®.
- Color monitor and a keyboard.
- Selection of communication with individual DACS through the X.25 or SNIDER interfaces.
- With the X.25, selection of either point-to-point interfaces or the packet data network.
- Full protection of X.25 switched virtual circuits (SVCs) with optional extra links.
- Optional DECserver 700 interface to remote printers through Transport Control Protocol/Internet Protocol (TCP/IP) networking services.
- Substrate provisioning for X.50 and X.57 circuits.

### **Features Under Menu Control**

---

Features that can be user-controlled through menus and forms are:

- User-defined names (IDs) for cross-connects and NPCs.
- Cross-connect altrouting, preempting and normalizing.
- Preplanned circuit reconfigurations, executed on command, according to schedule or triggered on cue from an NPC alarm.
- User administration.
- Command partitioning between administrators and users.
- Task scheduling.
- Task administration, to list or delete tasks on queue.

- DACS support:
  - Facility (NPC) provisioning
  - Two-point cross-connections
  - Contiguous and noncontiguous nxDS0 cross-connections
  - One-way cross-connections
  - Virtual broadcast (one-way) cross-connections
  - Symmetric voice circuits
  - Polling data circuits
  - Test access to single-channel or nxDS0 cross-connections
  - Subrate cross-connections through the DACScan only
- DACS alarm logging and notification.
- Passthrough (expert DACS user) mode, direct to the DACS.
- MML script editing, storage and execution.
- Querying of database from forms, including NPC and circuit browse selections.
- Remote printing, if a DECserver 700 is configured and a remote printer is in the network.
- Database backup and recovery to/from diskette or tape.
- Report capability, including user-defined reports.
- Database administration:
  - Upload I-2000 database with frame provisioning data
  - NPC audit
  - Scheduled NPC, channel or alarm synchronization between the I-2000 and a DACS

## **Autonomous Features**

---

The I-2000 offers some features that are not controllable through menus and screens, such as the Alarm monitor port.

### **Alarm Monitoring**

The I-2000 automatically makes available on the alarm monitor port all alarms sent to it by DACS that it controls. For its location, refer to the *I-2000 Controller for DACS II Installation Manual*.

You *must* provide your own equipment to connect to the port and receive the alarms. The hardware connection procedure also is stated in the *I-2000 Controller for DACS II Installation Manual*. If a modem is going to be attached to the port, you must insure that everything is done that is necessary to put the modem in a DATA TERMINAL READY state.

By default, the Alarm Monitor Port is on. You can turn it off by changing the value of the `ALARM_DEV` variable. For more information, refer to “Setting Environmental Variables” in Chapter 2 “Getting Started.”

Alarms are placed on the Alarm Monitor Port exactly as they are received from the DACS. Since multiple alarms can be received simultaneously, the I-2000 buffers them for output.

### **Echoed Response Processing**

Real-time Echoed Response Processing (ERP) is the automatic response of the I-2000 to provisioning changes made in the DACS through the DACS console or via other frame administrative links. Such changes cause messages to be sent to the I-2000, which then places NPCs and channels in service or takes them out of service (NPC ERP), or connects or disconnects circuits (circuit ERP) to make the information in the I-2000 database match the DACS cross-connections.

ERP can be switched on or off at two levels: by setting a field value on the appropriate I-2000 form, and by entering DACS commands to configure the DACS output. Alarm synchronization also can also be turned on or off by entering a field value.

---

## Contents

<b>Introduction</b>	2-1
<b>Configuring the DACS</b>	2-1
■ Procedure: Configuring the DACS II & DACS II ISX	2-1
■ Procedure: Configuring Frame Using SNIDER Protocol	2-2
■ Procedure: Configuring Frame Using X.25 Protocol	2-3
■ Procedure: Configuring DACS for 24-Hour Performance Monitoring	2-4
<b>Setting Environment Variables</b>	2-5
■ Procedure: Changing Environment Variables	2-14
■ Setting/Changing Default Form Values for NPC and Circuit Provisioning	2-15
<b>Time Zone</b>	2-16
■ Procedure: Setting the Time Zone	2-17
<b>Logging Into the I-2000</b>	2-18
■ Direct Access	2-18
Procedure: Changing the Root Password	2-18
Procedure: Logging In, I-2000 Operator on Console	2-18
Procedure: Using the Windows Environment and the Root Window	2-19
Procedure: Logging In, I-2000 Administrator	2-20
■ Remote Access	2-21
Procedure: Logging in Through X.25 Ports	2-21
Procedure: Logging In From DECserver 700	2-21
Procedure: Logging In Using I-2000	2-22
Procedure: Logging In Using Another Host	2-22

---

# Contents

<b>Remote Printers</b>	2-22
■ Procedure: Administering Remote Printers	2-23
<b>Administering X.25 Links</b>	2-25
<b>Administering Frames</b>	2-25
<b>Configuring Login Ports</b>	2-26
<b>Changing Passwords</b>	2-26
<b>Using the System</b>	2-27
■ MAIN MENU	2-27
■ Procedure: Navigating Between Menus, Forms, and Fields	2-27
■ Using Function Keys	2-33
■ Using the EXECUTE Key	2-35
■ Using the RECNCILE Key	2-39
■ Understanding the Screen Line	2-40
■ Procedure: Updating the Database	2-41
<b>Summary of Menus And Forms</b>	2-42

### Introduction

---

This chapter gets you started configuring the frame for DACS II and DACS II ISX, as well as configuring the DACS using the X.25 and SNIDER protocols. After the I-2000 controller has been successfully installed, use this chapter to start configuring the system.

### Configuring the DACS

---

When the I-2000 system is operational, configure the DACS administrative link that will be connected to the I-2000. Perform this step at the DACS.

Compatibility with I-2000 is crucial. If DACSs are already operative, see your system administrator for the details of their settings.

### Procedure: Configuring the DACS II & DACS II ISX

---

To configure the DACS II and DACS II ISX Releases 1.0 and higher, follow these steps:

1. Log in directly on a dumb DACS terminal as a frame administrator using either MML or PDS.

- a. For **MML**, type in the following commands:

```
LGN-USER: : : : DAX  
(enter password)
```

- b. For **PDS**, type in the following commands:

```
LOGIN: : USER DAX  
(enter password)
```

2. If the USER DAX input language is **PDS**, change it to **MML** following these steps:
  - a. Type in the following command:  

```
ADD::USER DAX, LANG M
```
  - b. Log off:  

```
LOGOFF::USER DAX
```
  - c. Log in again:  

```
LGN-USER::::DAX
```
3. Follow one of the procedures below to configure the frame using either the SNIDER or X.25 protocols.
  - a. To configure the DACS as a node in a direct configuration utilizing the SNIDER protocol, refer to "Procedure: Configuring the Frame Using SNIDER Protocol."
  - b. To configure the DACS as a node in a direct or network configuration utilizing the X.25 protocol, refer to "Procedure: Configuring the Frame Using X.25 Protocol."

### **Procedure: Configuring Frame Using SNIDER Protocol**

---



**NOTE:**

The procedures for configuring the frame for a SNIDER protocol differ slightly between the DACS II and DACS II ISX. The differences are noted below.

To configure the DACS as a node in a SNIDER configuration using MML, follow these steps:

1. Set the baud rate to 1200 (12), 2400 (24), 4800 (48), or 9600 (96) and the protocol to SNIDER (S):
  - a. For DACS II:  

```
ED-PRMTR-LINK::n::BAUD-bb,PTCOL-S;
```

where n is 1, 2, 3, or 4 and refers to the DACS link, and bb is 12, 24, 48 or 96.
  - b. For DACS II ISX:  

```
ED-PRMTR-LINK::1::BAUD-bb,PTCOL-S,ENQ-1,XON-0!
```

**NOTE:**

On reset, the DACS re-establishes the port default speed of 1200 baud until the DACS reboot is completed. If the administrative link is set to any other speed through I-2000 FRAME ADMINISTRATION, communication will be temporarily lost during the DACS reboot. Either change the I-2000 administrative link to match the DACS port, or change the DACS port to match the link. If you use PASSTHROUGH to change the DACS port, you must first set the administrative link to 1200. As soon as you press **[Enter]**, communication is lost again. Leave PASSTHROUGH and reset the I-2000 link.

2. Set the language to MML (M) and select the NPC addressing system:

```
SET-PRVG-TERM:::n:LANG-M:NPCAD-m;
```

where m is:

- E for 3-digit extended numbering (default for DACS II ISX)
- X for 4-digit extended numbering
- H for hierarchical numbering (recommended for DACS II)

3. To disable echoed responses from the DACS II, set the link screening level to 2:

```
SET-PRVG-TERM:::n:SCR-2;
```

4. To enable echoed responses from the DACS II, set the link screening level to 4:

```
SET-PRVG-TERM:::n:SCR-4,GR-1&-1&-1&-1&-0&-1;
```

For more information on echoed responses, refer to Echoed Response Processing in Chapter 4 "NPC Provisioning" and Chapter 6 "Circuit Provisioning."

### **Procedure: Configuring Frame Using X.25 Protocol**

To configure a frame as a node in a direct or network configuration for DACS II using the X.25 protocol, follow these steps:

1. Using MML, initialize one or both frame links to handle X.25.

```
ED-PRMTR-LINK::n::PTCOL-X:INIT;
```

where n is the link number, 5 or 6.

2. Change the default setting of 8 SVCs and 8 PVCs per link to 16 SVCs and no PVCs per link:

```
ED-PRMTR-LINK::n::VC-0016&-0000;
```

3. Set each virtual circuit on the link to the MML language:

```
SET-PRVG-TERM:::n01:LANG-M:NPCAD-m;
SET-PRVG-TERM:::n02:LANG-M:NPCAD-m;
...
SET-PRVG-TERM:::n16:LANG-M:NPCAD-m;
```

where n is the link number (501 to 516 and 601 to 616), and m is:

E for 3-digit extended NPC numbering

X for 4-digit extended numbering

H for hierarchical numbering

4. Set the screening of virtual circuits on the link.
5. To disable echoed responses from the DACS II, set the link screening level to 2:

```
SET-PRVG-TERM:::n01:SCR-2;
SET-PRVG-TERM:::n02:SCR-2;
...
SET-PRVG-TERM:::n16:SCR-2;
```

6. To enable echoed responses from the DACS II, set the link screening level to 4:

```
SET-PRVG-TERM:::n01:SCR-4,GR-1&-1&-1&-1&-0&-1;
SET-PRVG-TERM:::n02:SCR-4,GR-1&-1&-1&-1&-0&-1;
...
SET-PRVG-TERM:::n16:SCR-4,GR-1&-1&-1&-1&-0&-1;
```

7. Set the frame level 2 parameters to match the parameters of the I-2000:

```
ED-PRMTR-LINK::n::K-3,N2-7,T1-6;
```

### Procedure: Configuring DACS for 24-Hour Performance Monitoring

1. If 24-Hour Performance Monitoring is enabled on the I-2000, schedule 24-Hour Performance Monitoring at the DACS and DACS II ISX using the following commands:

#### At a gateway DACS II:

```
SCHED-PMREPT-ALL:::HH-MM-SS,FAC-X-0002b5,,PRIM-X-FBFF
SCHED-PMREPT-ALL:::HH-MM-SS,MONDAT
```

#### At a DACS II ISX or a non-gateway CEPT DACS II:

```
SCHED-PMREPT-ALL:::HH-MM-SS,PRIM-X-FBFF
SCHED-PMREPT-ALL:::HH-MM-SS,MONDAT
```

See the DACS II or DACS II ISX *Command and Message Manual* for more details on these commands.



#### NOTE:

For an I-2000 supporting multiple DACSs, it is recommended that each DACS has a different execution time for performance monitoring reports, so that two or more DACSs are not reporting performance data at the same time. It is also recommended that the time of execution be set to off-peak usage hours, when the I-2000 is not being heavily used. Do not schedule performance reports to be executed at midnight.

## Setting Environment Variables

To insure proper operation of the I-2000 system, you may need to check that some environmental variables used by the I-2000 have the proper values. Also, you can vary the values to achieve different operational effects.

Table 2-1 describes the environment variables, their purposes and their values.



### CAUTION:

*If a variable appears in the variable file, but does not appear in the table, it is recommended that you **do not** alter it.*

*A specification of no value means the variable name followed by an =.*

**Table 2-1. Environmental Variables**

ALARM_DEV	The device name of the alarm monitor port. The default is <b>/dev/ttyb</b> for the Sun, and <b>/dev/tty01</b> for all other systems.
ALARM_DEV_SPEED	The baud rate of the alarm monitor port. The default is <b>9600</b> . Other possible values are <b>1200</b> , <b>2400</b> , <b>4800</b> and <b>19200</b> .
BROWSE_TIMEOUT	The time, in seconds, for which the I-2000 will wait for a response from a circuit <b>BROWSE Action</b> . At the end of that time, the I-2000 will return control of the terminal to the user. The default is <b>1800</b> seconds (30 minutes). The range is <b>60</b> through <b>3600</b> seconds (1 through 60 minutes).
BTCHLOOP	Whether or not the enhanced test access feature is enabled. If it is enabled, the I-2000 will execute channel loop and release actions. Otherwise, the I-2000 will ignore them. A value of <b>1</b> enables. Any other value disables. The default is <b>0</b> .
BTEMI	Whether or not messages will be sent to the Event Management System Interface. The default of no value presumes this interface is not present. If a value is entered, it should be the name of the device entered into the <b>/etc/printcap</b> file for this interface. The recommended name is <b>btemi</b> .
BTHOTSTANDBY	Whether or not the hot standby feature is enabled. If it is disabled, the I-2000 will process echoed responses normally. A value of <b>1</b> enables. Any other value disables. The default is <b>0</b> .

**Table 2-1. Environmental Variables (Contd)**

BTLP	Whether or not messages will be sent to the Event Management System Alarm Logging Printer. The default of no value presumes that this interface is not present. If a value is entered it should be the name of the device entered into the <code>/etc/printcap</code> file for this interface. The recommended name is <code>btlp</code> .
BTLP_ALARM_STATE	Ignored if BTLP is not set. Which DACS alarm messages, by alarm state, are sent to the Event Management System Alarm Logging Printer Interface. The default is all alarm messages, regardless of alarm state.
BTLP_DATE_FORMAT	Ignored if BTLP is not set. The format of the date string in messages to the Event Management System Alarm Logging Printer Interface. The default is the UNIX long time value. For example, to have the date appear as <code>2_digit_month/2_digit_day/2_digit_year hour:min:sec</code> use the following line: <pre>%m/ %d/ %y %H:%M:%S</pre> You can find descriptions of the specifiers in the Tables 2-2 through 2-4.
BTLP_EXCLUDE	Ignored if BTLP is not set. Which frame alarm messages are sent to the Event Management System Alarm Logging Printer Interface. The default is only to send non-NPC alarms: 65011 65021 65031 65035 65036 65041 65045 65046 65061 33351
BTLP_FMT_STRING	Ignored if BTLP is not set. The format of output messages to the Event Management System Alarm Logging Printer Interface. The default is: <pre>ae\n\ttid\t%d\n\teqtype\t%1\n\teqid\t%E\n\tcondtype\t%C\n\talarmtype\t\F\n\talarm_state\t%\V\n\tdacsmsgno\t%m\n\tsummary\t%n\n\ttime\t%T\n\tnpc_id\t%N\n\tckts\t%K\n\n</pre> Descriptions of the specifiers are listed in Table 2-2.
COMMAND_TIMEOUT	The time for which the I-2000 will wait for a response from the DACS to a command issued by the user during a multiplexed passthrough session. At the end of that time, the I-2000 will return control of the terminal to the user. The default is <b>60</b> seconds. The range is <b>15</b> through <b>180</b> seconds.

**Table 2-1. Environmental Variables (Contd)**

D2_MIN_TG	For DACS II. This variable specifies the minimum number to be used as a test group ID when using Test Access.
D2_MAX_TG	For DACS II. This variable specifies the maximum number to be used as a test group ID when using Test Access.
D2_MIN_NPCTG	For DACS II. This variable specifies the minimum number to be used as an NPC test group ID when using Test Access.
D2_MAX_NPCTG	For DACS II. This variable specifies the maximum number to be used as an NPC test group ID when using Test Access.
DACSCAN_STRING	The system name that will be appended to the header lines of history and alarm reports. The default is no value. A typical value that can be used for the unified application is " <b>DACScan-2000 Controller</b> ".
DACS_HIST_SIZE	The maximum number of characters in a single history log. The default is <b>60000</b> . The range is <b>60000-600000</b> .
DACS_TIMEOUT	The timeout for frame commands. The default is <b>180</b> seconds (three minutes). The range is <b>180-600</b> (ten minutes).
DATE_FORMAT	The format of the date in the alarm report, the history log report header, the non-NPC alarm events sent to the DACScan, and all other I-2000 reports. The default of no value obtains a format of ddmmmyy. A value of <b>AMERICAN</b> changes it to mm/dd/yy and a value of <b>EUROPEAN</b> changes it to dd/mm/yy.
FDX_CKT_LOOP	Controls the two-way loopback circuit for I-2000. The default value is <b>0</b> , which denies provisioning of two-way loop circuits.  A value of <b>1</b> allows to you to provision two-way loop back circuits, echo response processing, and audit/synchronization.
G2_ALARM_STATE	Ignored if BTEMI is not set. Which DACS alarm messages, by alarm state, are sent to the Event Management System Interface. The default is to send all alarm messages regardless of alarm state. The values can be <b>OOS, CRIT, MAJ, MIN, INFO, IDLD</b> .

**Table 2-1. Environmental Variables (Contd)**

G2_DATE_FORMAT	<p>Ignored if BTEMI is not set. The format of the date string in messages sent to the Event Management System Interface. The default is the UNIX long time value. For example, to have the date appear as:</p> <p>hour:min:sec 2_digit_month/2_digit_day/2_digit_year</p> <p>use the following line:</p> <pre>%H:%M:%S %m/ %d /%y</pre> <p>You can find descriptions of the specifiers in Tables 2-2 through 2-4.</p>
G2_DELIMITER	<p>The character to be used between selected G2 Data Language message fields. The default is a /, which will delimit aid1, aid2 and condition fields. However, if the / will be used in a DACS name, you may wish to set this variable to another delimiter.</p>
G2_EXCLUDE	<p>Ignored if BTEMI is not set. Which DACS alarm messages are sent to the Event Management System Interface. The default is to send all alarms.</p>
G2_FMT_STRING	<p>The format of output messages to the Event Management System Interface. The default of no value causes the G2 data language to be used. For the Event Management System Interface, this variable can be set to the following value:</p> <pre>ae\n\ttid\t%d\n\teqtype\t%1\n\teqid\t%E\n\tcondtype\t%C\n\talarmtype\t\F\n\talarm_state\t%\V\n\tdacsmsgno\t%m\n\tsummary\t%\n\n\ttime\t%T\n\tnpc_id\t%N\n\tckts\t%K\n\n</pre> <p>You can find descriptions of the specifiers in Tables 2-2 through 2-4.</p>

**Table 2-1. Environmental Variables (Contd)**

INFO_ALARMS	<p>Authorization to alter the I-2000 algorithm for processing DACS II 0.65011 CGA/PBA messages. Two alterations are available, specified by <b>PA</b> and <b>MINOR</b>. The default is no value. In that case, the algorithm is not altered.</p> <p>For both <b>PA</b> and <b>MINOR</b> record the alarm in the I-2000 alarm log and NPC databases, and transmit the DACS II output message from the alarm monitoring port exactly as it was received from the DACS. The difference is in the severity recorded for the alarm and therefore appearing in reports.</p> <p>For a value of <b>PA</b>, the severity will be made the same as the priority of action (pa) field, except that, if the "pa" field has a value of <b>A</b> (autonomous), the severity is made minor.</p> <p>For a value of <b>MINOR</b>, the severity will depend on the value of the alarm state field. For an <b>MI</b> or a <b>DMA</b>, the severity will be made minor; for a <b>PMA</b>, the severity will be made the same as the pa field.</p>
ISX_MIN_TG	For DACS II ISX. This variable specifies the minimum number to be used as a test group ID when using Test Access.
ISX_MAX_TG	For DACS II ISX. This variable specifies the maximum number to be used as a test group ID when using Test Access.
ISX_MIN_NPCTG	For DACS II. This variable specifies the minimum number to be used as an NPC test group ID when using Test Access.
ISX_MAX_NPCTG	For DACS II. This variable specifies the maximum number to be used as an NPC test group ID when using Test Access.
LINES_PER_PAGE	The number of lines per page in I-2000 reports sent to the printer. The default is <b>66</b> . It is standard for printing 6 lines per inch on 8.5 inch by 11.0 inch paper.
MAX_ALM_LOGS	The maximum number of alarms in the alarm log. The default is <b>1000</b> . The allowed range is <b>100-10000</b> . Once this number of records is inserted in a frame's alarm log, the next alarm will cause the number of alarms in the log to be reduced to the value contained in the <code>SAVE_ALMS</code> variable.

**Table 2-1. Environmental Variables (Contd)**

MAX_PM_LOGS	The maximum number of messages in the 24-Hour PM log. The default is 1000. The allowed range is 100-1000. Once this number of records is inserted in a DACS' PM log, the next record entry will cause the number of records in the log to be reduced to the value contained in the SAVE_PM_LOGS variable.
PM24HR_NONFT	Enables the 24-Hour Performance Monitoring feature. <b>YES</b> makes the Performance Monitoring feature available. The Performance Monitoring feature is available for CEPT type NPCs only. No Performance Monitoring data is stored or processed for non-CEPT NPCs.
RP_DACS_TIMEOUT	The number of seconds the I-2000 will wait before timing out commands associated with a restoration plan. The default is <b>1800</b> (30 minutes). The range is <b>180</b> (3 minutes) - <b>86400</b> (24 hours).
SAVE_ALMS	The number of alarms to leave in the alarm log when the maximum has been reached. The default is <b>60</b> . Allowed values are 1 through 1 less than the value of MAX_ALM_LOGS.
SAVE_ERPS	The number of echoed response messages to leave in the ERP Log when the maximum number of messages has been reached. The default is <b>60</b> . The allowed range is 1 to 1 less than the value in the MAX_ERP_LOGS variable.
SAVE_PM_LOGS	The number of entries to leave in the 24-Hour PM log when the maximum has been reached. The default is 60. Allowed values are 1 through 1 less than the value of MAX_PM_LOGS.
SEND_ALARM_EVENTS	Authorization to send alarm event messages to a network controller connected to the I-2000 in accordance with the appropriate interface agreement. The default is no value. A <b>YES</b> value sends the messages.
SEND_NON_NPC_ALARMS	Authorization to send non-NPC alarm messages to a network controller connected to the I-2000 in accordance with the appropriate interface agreement. The default is no value. A <b>YES</b> value sends the messages.

**Table 2-1. Environmental Variables (Contd)**

SESSION_TIMEOUT	The time in minutes over which the I-2000 will wait for some activity during a multiplexed passthrough session. After that time, the I-2000 will end the idle session autonomously and will return the user to the previous menu. The default is <b>480</b> minutes (8 hours). The range is 0 through <b>10080</b> (1 week).
SH_TMOUT	<p>The I-2000 shell inactivity timer. This variable sets the shell TMOUT variable when a user logs in to the system as an I-2000 user. When TMOUT seconds have elapsed with no terminal activity, a 60-second warning displays. If there is no further activity, the shell times out and the user is logged off.</p> <p>The SH_TMOUT variable is set by the user login .profile. It is disabled when an I-2000 user interface session is started and is imposed again when the user quits the I-2000 interface.</p> <p>Examples:  SH_TMOUT=0           no timer (unlimited login time)  SH_TMOUT=1800       30-minute timeout (default)</p> <p>If the value for SH_TMOUT is changed, users who are currently logged in, must log out and log in again for the new timeout value to take effect.</p> <p>The IDLE_THRESHOLD variable performs a similar function for the I-2000 user interface.</p>
SITENAME_SIZE	Controls the number of characters allowed in the <b>Site Name</b> field on the FRAME ADMINISTRATION form. If not set, the field is a maximum of 17 characters. The value range of this variable is 18-24.
SORT_NAME_BY	The list order of the DACS names in the WHICH DACS? pop-up window. <b>ALPHA</b> , the default, displays the DACS names in alphabetic order. <b>CREATE</b> displays the names in the order created through the Frame Provisioning form. <b>&lt;blank&gt;</b> displays the names in the same order as displayed in older releases, that is, sequential as per global memory.

**Table 2-1. Environmental Variables (Contd)**

SYNC_DEACTIVATE_CKTS	Controls whether or not channel synchronization, when the DACS is master, or circuit echoed response processing, will delete all non-matching I-2000 circuits (any other value than 1) or only non-matching circuits created by channel synchronization or circuit echoed response processing (a value of 1). Non-matching circuits not deleted are deactivated.
X25BRXDBIT	For delivery confirmation for X.25 data packets. The default value is NULL. Otherwise, a value of 1 will enable delivery confirmation.

Table 2-2 shows the G2\_FMT\_STRING and BTLP\_FMT\_STRING characters.

**Table 2-2. G2\_FMT\_STRING And BTLP\_FMT\_STRING Characters**

Character	Definition
\n	Newline.
\t	Tab.
\r	Carriage return.
%[d12EcCfFtsvVTnmNK]	Conversion specification (see the succeeding table)
%%	Same as %
Any other character	Copy as is

Table 2-3 shows the conversion specifications for the G2\_FMT\_STRING and BTLP\_FMT\_STRING.

**Table 2-3. G2\_FMT\_STRING And BTLP\_FMT\_STRING Conversion Specifications**

Conversion Specification	Field name for Ev. Sys.	Description
%d	tid	Name of DACS II in I-2000.
%1	eqtype	Kind of equipment.
%2		Number(s) of failed equipment.
%E	eqid	Number(s) of failed equipment.
%c		Performance parameter or condition type.
%C	condtype	<b>PBA, CGA, LOS, THR</b> or null.
%f		Type of alarm.

**Table 2-3. G2\_FMT\_STRING And BTLP\_FMT\_STRING Conversion Specifications (Contd)**

Conversion Specification	Field name for Ev. Sys.	Description
%F	alarmtype	Kind of CGA, PBA or THR alarm.
%t		Message counter tag.
%s		Alarm status.
%v		Alarm severity.
%V	alarm_state	<b>OOS, CRIT, MAJ, MIN, INFO or IDLD.</b>
%T	time	I-2000 time of alarm.
%n	summary	DACS message summary.
%m	dacsmsgno	DACS output message number.
%N	npc_id	Name of NPC for NPC alarm.
%K	ckts	Name of ckts on NPC for NPC alarm.

Table 2-4 shows the conversion specifications for G2\_DATE and BTLP\_FORMAT.

**Table 2-4. G2\_DATE\_FORMAT And BTLP\_DATE\_FORMAT Conversion Specifications**

Character	Description
%a	Abbreviated weekday name.
%A	Full weekday name.
%b	Abbreviated month name.
%B	Full month name.
%d	Day of month { <b>01-31</b> }.
%e	Day of month { <b>1-31</b> }.
%H	Hour { <b>00-23</b> }.
%l	Hour { <b>00-12</b> }.
%j	Day number of year { <b>001-366</b> }.
%m	Month { <b>01-12</b> }.
%M	Minute { <b>00-59</b> }.
%S	Seconds { <b>00-59</b> }.
%y	Year within century { <b>00-99</b> }.

**Table 2-4. G2\_DATE\_FORMAT And BTLP\_DATE\_FORMAT Conversion Specifications (Contd)**

%Y	Year as ccyy { <b>1995</b> }.
%D	Date as %m/%d/%y.
%R	Time as %H:%M.
%T	Time as %H:%M:%S.
%%	Same as %.
Any other character	Copy as is.

### **Procedure: Changing Environment Variables**

To change a system environment variable, you *must* log in as a system administrator.

To change the environment variables, follow these steps:



**NOTE:**  
You must know the UNIX text editor "vi."

1. Log into the I-2000 Controller system as **dacsadm**.
2. The system will display the following message:  
Do you want to escape to unix ...?
3. Type **y** to go to the UNIX environment.
4. The system will display the following message:  
Do you want to start windows ...?
5. Type **n**. You are now placed in the UNIX environment.
6. Type **vienv** to edit the environment file.
7. Find the name of the variable and change the value:

```
name=value
export name
```

where name is the name of the variable and value is the new value. Use only one entry per line. White space is allowed in value only, provided value is enclosed in double quotes, and is only allowed for strings (not numbers).

**Examples:**

```
SEND_ALARM_EVENTS=YES
export SEND_ALARM_EVENTS
SEND_ALARM_EVENTS=Enter
export SEND_ALARM_EVENTS
```

8. The first example sets the variable to `YES`. The second example sets it to no value.
9. Exit from `vi`.
10. Restart the I-2000 by executing `kill_I`.
11. This step is not necessary if you are changing the following variables only:
  - `BTEMI`
  - `BTLP`
  - `BTLP_ALARM_STATE`
  - `BTLP_DATE_FORMAT`
  - `BTLP_EXCLUDE`
  - `BTLP_FMT_STRING`
  - `G2_ALARM_STATE`
  - `G2_DATE_FORMAT`
  - `G2_DELIMITER`
  - `G2_EXCLUDE`
  - `G2_FMT_STRING`
12. Log off by typing `exit`, if necessary.

### **Setting/Changing Default Form Values for NPC and Circuit Provisioning**

---

To set/change the default field values for the NPC and Circuit Provisioning forms you *must* log in as `root`.

When setting/changing these values, the following files *must* be edited and the same changes made to all files:

- `ui_dval.ini`
- `ui_dval.fre`
- `ui_dval.eng`

To change the default form values, follow these steps:



**NOTE:**

You must know the UNIX text editor “`vi`.”

1. Log into the I-2000 Controller system as `root`.
2. Type `cd /usr/ems/initstr`. You are now placed in the directory where the `ui_dval` file resides.
3. Type `vi ui_dval.ini` to edit this file.
4. Find the default value to be changed:

The default value is surrounded by double quotes. A description of the default value is contained in the comment on the same line, as shown in the example file below. Edit the word within the double quotes.

5. Use **:w!** to save the changes.
6. Exit from vi.
7. Next, you *must* make the same changes in the following files: ui\_dval.fre and ui\_dval.eng.
8. Log out, then log back in. Default values take effect in the next session.

```
/*ENGLISH customized default values for CIRCUIT and NPC
provisioning forms */

/* CIRCUIT PROVISIONING DEFAULTS */

1 "0011.0011" /*trunk conditioning (CKT_TC) */
2 "TRB" /* insertion word (CKT_IW) */
3 "" /*tso to non-ts0 framing bits in FW
(CKT_FW) */
4 "" /* framing other */
5 "" /* Signaling conversion (CKT_SC) */
6 "A" /* bandwidth type */

/* NPCPROVISIONING DEFAULTS */

7 "PB100" /* NPC type for DACS II (NPC_TYPE_DACS2)
*/
8 "PA100" /* NPC type for DACS II ISX
(NPC_TYPE_ISX) */
9 "" /* insertion word (NPC_TYPE_IW) */
10 "MJ" /* AIS (NPC_AIS) */
11 "PPPPPPPPP" /* NFS (NPC_NFS) */
12 "10" /* cbit aging (CBIT_AGING) */
```

---

**Figure 2-1. Sample ui\_dval.eng File**

## **Time Zone**

---

Time zone information is set on the Sun workstation at installation and usually does not need to be reset during the life of the workstation. Time zone information and daylight savings time adjustments take place automatically for most time zones around the world.

Use the timezone command in the following procedure if any of these conditions apply:

- You wish to change the default time zone for special applications. For example, when all users are in a time zone that is different from the location of the I-2000.
- The installation procedure was unable to identify the proper time zone for your region.
- The automatic time zone adjustments made by the workstation are inaccurate, and there is another time zone that better reflects the regional adjustments.

-  **NOTE:**  
If you adjust the time zone manually using the I-2000 timezone command, you must use the timezone command on a yearly basis to update the daylight savings time information for that year.

### **Procedure: Setting the Time Zone**

---

To set the time zone for I-2000, follow these steps:

1. Log in as an administrator and verify that the current year is displayed in the top line of the menu. If necessary, use SYSTEM ADMINISTRATION to set the date and time.
2. Log off from the I-2000.
3. Log in as **dacsadm**
4. The system will display the following message:  

```
Do you want to escape to unix ...?
```
5. Type **y** to go to the UNIX environment.
6. The system will display the following message:  

```
Do you want to start windows ...?
```
7. Type **n**. You are now placed in the UNIX environment.
8. Type **timezone** to start the timezone command.
9. A series of menus are displayed to facilitate time zone selection. Enter the menu item that corresponds to the appropriate country or time zone

-  **NOTE:**  
**Help** provides additional information about menu items.

10. Fill out the menu items to select time zone parameters.
11. You will be prompted to confirm time zone modification and restart I-2000. Type **y** to confirm the time zone modification restart.
12. Log in as an I-2000 administrator and verify that the correct time and date is displayed on the top line of the main menu.

## Logging Into the I-2000

---

This section provides procedures on how to login in directly, remotely, through I-2000 X.25 ports, and through another host for the I-2000 Controller.

### Direct Access

---

#### Procedure: Changing the Root Password

The root password is the password assigned to the login, `root`, which grants full access to the system. The I-2000's computing system is supplied with a default root password. Immediately following installation, you must change this password to one you have devised.



#### CAUTION:

*It is important to remember this password, since it is the only way to recover from forgotten I-2000 passwords (refer to "CHANGE PASSWORD" in Chapter 12 "User Administration".) If the worst case does occur, please contact your Lucent Technologies representative for assistance.*

To change the root password, follow these steps:

1. Log in as **root**.
2. At the `password` prompt, enter the default password.
3. At the `#` prompt, enter **passwd**.
4. Enter the old password as requested.
5. Enter the new password twice as requested.
6. At the `#` prompt, enter **exit**.

#### Procedure: Logging In, I-2000 Operator on Console

To log into the I-2000 computer on the console as an operator, follow these steps:

1. Turn on the I-2000's computer. The `login` prompt is displayed.  
Ensure that Caps Lock is not on.



#### NOTE:

You can log on with Caps Lock on if both login name and password are lower case. If the password is mixed or all uppercase, you will not get beyond the login name. To return to the initial prompt, press Ctrl + d until lower-case letters appear.

2. Enter your login name and password.  
After accepting the login name and password, the system runs OpenWindows™, which displays the root window (background), one I-2000 USER INTERFACE window, containing the I-2000 MAIN MENU, and a read-only CONSOLE window, in which messages from the UNIX system are displayed.



**NOTE:**

You are automatically logged off if you do not enter a keystroke within `IDLE_THRESHOLD` minutes, provided the **UI Idle Option** field on the **USER MANAGEMENT** form is set to `ON`. See "Setting Environmental Variables," earlier in this chapter for information on changing the value of the `IDLE_THRESHOLD` variable.

Once your logged into the I-2000 system, there are two control capabilities: the I-2000 User Interface and the Root window. Follow one of the procedures below, depending on the type of control you need.

**Procedure: Using the Windows Environment and the Root Window**

To use the windows environment, use these tips:

1. Shrink the window to an icon by pointing the cursor at the small box in the upper left corner and clicking the left-hand mouse button once. Restore the window by clicking twice on the icon.
2. Move the window by pointing the cursor to the top margin, pressing the right-hand mouse button, moving the window to where you want it, and releasing the button.
3. Obtain a pop-up menu, offering a number of choices concerning window disposition, by pointing the cursor to the top margin and holding down the right-hand mouse button. Select by pointing the cursor at the choice and releasing the right-hand mouse button.

To use the Root window interface, use these tips:

1. Obtain a pop-up window allowing you to lock the screen.
2. Exit, refresh, or start another I-2000 **USER INTERFACE** window, running another I-2000 session, by placing the cursor in the root window and holding down the right-hand mouse button.
3. Select by pointing the cursor at the selection and releasing the right-hand mouse button. You can have as many as 16 I-2000 **USER INTERFACE** windows open.
4. Enter any one of the windows by placing the cursor in it and clicking the left-hand mouse button once.
5. You have the following logoff options:
  - a. Select `LOGOFF` from the **MAIN MENU** to logoff from one session. If no other sessions are running, the system logs you off also.
  - b. Bring up an I-2000 **USER INTERFACE** window menu and select `Quit`. If no other sessions are running, the system logs you off.
  - c. Bring up the Root window menu and select `Exit`. You are logged off from all sessions and the system.

### Procedure: Logging In, I-2000 Administrator

To log into the I-2000 computer as a I-2000 administrator, follow these steps:

1. Turn on the I-2000's computer. The `login` prompt is displayed. Ensure that `Caps Lock` is not on.



**NOTE:**

You can log on with `Caps Lock` on if both login name and password are lower case. If the password is mixed or all uppercase, you will not get beyond the login name. To return to the initial prompt, press `Ctrl` + `d` until lower-case letters appear.

2. Log in as **dacsadm** and enter the `dacsadm` password. The system displays the following message:

```
Do you want to escape to UNIX (y/[n])?
```



**NOTE:**

The system can manage up to 62 operator logins: 61 operator logins can be created in addition to the default **ems** operator login. Refer to Chapter 12 "User Administration." If this is the first entry to the system, it will be necessary for you to create those logins. But first, it is suggested you administer the links and DACS as part of the initial setup.

- a. If you type **n**, the system runs `OpenWindows`, which displays the root window (background) and one I-2000 `USER INTERFACE` window, containing the I-2000 `MAIN MENU`.
  - b. If you type **y** to the UNIX escape prompt, the system will display the following message:

```
Do you want to start windows (y/[n])?
```
3. If you type **n**, the `unix>` prompt is displayed.
  4. To run the I-2000 at a later time, type `openwin`, which will start a windows environment. The result is the same as for an I-2000 operator login, with one exception: logoff from the last I-2000 `USER INTERFACE` window returns you to the `unix>` prompt. Log off by typing `exit`.
  5. If you type **y**, you are placed in an enhanced `OpenWindows` environment.

### Enhanced OpenWindowsUNIX

The enhanced `OpenWindows` environment consists of the following:

- `CONSOLE` window for UNIX system messages
- `Cmd-tool` window running a UNIX shell
- Clock
- Wastebasket
- File manager

To obtain a pop-up menu on any of these objects, place the cursor on the object and hold down the right-hand key. For windows, use the top margin. You can quit any object or exit from the entire system by typing `exit` after the `unix>` prompt or selecting `Exit` from the root window pop-up menu. To start an I-2000 `USER INTERFACE` window, select it from that same menu.

You are automatically logged off if you do not enter a keystroke within `IDLE_THRESHOLD` minutes, provided the **UI Idle Option** field on the `USER`

MANAGEMENT form is set to ON. See "Setting Environmental Variables," earlier in this chapter for information on changing the value of the IDLE\_TRESHOLD variable.

## Remote Access

---

The I-2000 can be accessed by logging into the I-2000's X.25 ports.

When the I-2000 is accessed through the X.25 ports, the system tracks logins over the X.25 network. When the user disconnects or a link failure occurs, the I-2000 updates the list of users connected. The total number of X.25 sessions that can be used to access the I-2000 cannot exceed 15. The I-2000 reserves one session for an I-2000 console user interface.

### Procedure: Logging in Through X.25 Ports

To access the I-2000 using this method, follow these steps:

1. Dial into the I-2000 through the X.25 Packet Data Network (PDN).



**NOTE:**

The assigned I-2000 X.25 PDN number must be used to dial into the I-2000.

2. Log in as **dacsadm** or **username** (use the user name assigned to you by the system administrator).
3. The system will display the following message:

```
Do you want to escape to UNIX?
```

4. Type **n**. The system runs OpenWindows, and displays the I-2000 USER INTERFACE window.

### Procedure: Logging In From DECserver 700

In this login scenario, both the I-2000 and the remote station must be located on the same LAN. The I-2000 interface is through the DECserver 700.

As a prerequisite for a successful remote login, your remote station and the network must be recognized by the I-2000. Refer to "Procedure: Administering Remote Printers" in this chapter.

In addition, the **/etc/hosts** file of your login station *must* contain entries for each DECServer that it will access.

To login in remotely using the DECserver 700, follow these steps:

1. At the DECserver 700 system prompt, enter **telnet hostname**

where:

**hostname** is the name of the I-2000.

2. Enter the login name, password and terminal type, which you will be successively prompted.

### Procedure: Logging In Using I-2000

This login procedure is for remote access from one I-2000 to another on the same local area network (LAN), or on a bridged LAN.

To log in remotely from the I-2000, follow these steps:

1. Log in as a system administrator.
2. From the cmd-tool window, create an xterm window by typing **uixterm**.
3. Activate the xterm window by placing the cursor in it and clicking the left mouse button.
4. Type **rlogin netname**

where:

**netname** is the name of the network on which the I-2000 to be accessed resides. The I-2000 responds with a prompt.

5. Enter the login name, password and terminal type, for which you will be successively prompted.

Once you have logged in, the I-2000 behaves as it would for the I-2000 operator or system administrator login.

### Procedure: Logging In Using Another Host

This login procedure is for remote access from a terminal other than an I-2000 located on the same LAN or on a bridged LAN.

The initial procedure depends on the capabilities available to the other host. Typically, you will be starting a window. In that case, follow the same procedure as for access from another I-2000.

If the host does not support multiple windows, refer to "Procedure: Logging In Using DECserver 700."

## Remote Printers

---

The DECserver 700, if installed, can make remote printers and connections to other asynchronous interfaces, such as event management systems, available to the I-2000 through TCP/IP networking. The I-2000 application software treats all output type devices connected to DECserver 700 ports as printers and thus accesses all of them through the SunOS line printer spooling system.

The I-2000 system administrator *must* make entries in certain operating system files. If the entries are made correctly, the remote printer name appears in **CHOICES** menus for fields requiring entry of a printer name.

To make these entries, you can use any UNIX editor on the I-2000 platform, such as "vi" or "ed", or you can open a window on the Sun and use the Administration Tools menu, or you can use UNIX support tools, such as **lpadmin** or **snap** commands. Any of these methods require that you be logged on as **root**.

Using the Sun tools is the preferred method over direct entries in files, since several activities need to be coordinated. For information on how to use Sun tools,

refer to the Sun manuals. For information on the precise form of the entries, refer to the Sun System Administrator's Manual.

### **Procedure: Administering Remote Printers**

---

To administer remote printers, follow these steps:

1. Make these changes or check that they have been made:
2. Enter, into the **/etc/defaultdomain** file, the domain name of the network containing the remote printer.
3. Reboot the system.
4. Enter, into the **/etc/hosts** file, the TCP/IP address and host name of the DECserver 700 interfacing to the network containing the remote printer.
5. Enter, into the **/etc/networks** file, the name and number of the network.
6. Enter, into the **/etc/printcap** file, specific information identifying each remote printer. The name by which the I-2000 will refer to the printer goes here.
7. As a guide to you in making the proper printcap file entries for a remote printer connected to DECserver 700 ports, AT&T has placed in the file a template, which you can modify. Replace `nameofprinter` with the actual name you want to give the printer, and remove the initial # comment line markers.

```
#nameofprinter:\  
  
# :lp=/dev/null1:\  
# :lp=/dev/null2:\  
# ...  
# :sf:\  
# :sh:\  
# :of=/usr/ems/bin/nameofprinter_o:\  
# :if=/usr/ems/bin/nameofprinter_i:\  
# :lf=/usr/spool/nameofprinter/log:\  
# :sd=/usr/spool/nameofprinter:
```

8. Examine the **/etc/services** file and determine what unused tcp port numbers can be used as a relay port number for communication between the input and output line printer filters for each of the printers added to the **/etc/printcap** file.
9. Enter, into the **/etc/services** file, a line for each port selected. For example, suppose three remote printer entries were added to the **//printcap** file and the tcp port numbers: 3000, 3001 and 3002, are not being used in the **/etc/services** file.

The following three lines would then be added to the end of the **/etc/services** file. Replace `nameofprinter` with the actual name given the printer in the **/etc/printcap** file

```
nameofprinter_r 3000/tcp
nameofprinter_r 3001/tcp
nameofprinter_r 3002/tcp
```

**NOTE:**

Each printer entered in the **printcap** file needs one and only one **:lp=** line. The first must contain **null1**, the second, **null2**, and so on.

10. Log in as **root** and create directories appearing in any **:sd=** lines added to **printcap**.
11. Create files appearing in any **:lf=** lines added to **printcap**.
12. Create files appearing in any **:lp=** lines added to **printcap**. Use the **mknod** command to create these special files. They must be created as "character-type" and the major/minor device numbers should be the same as `/dev/null`.
13. Execute **chmod 666** on the files just created in the previous step.
14. Log off as **root**.
15. Log in as **dacsadm** and create files appearing in any **:of=** lines added to **printcap**. Make them executable with **chmod a+x**. These files must contain two lines only:

```
#!/bin/ksh
```

```
exec /usr/ems/bin/d700_filter -o -h DECserver_name -p port# -r relayport#
```

where:

`DECserver_name` is the name added in the **/etc/hosts** file.

`port#` is the port number selected for the physical device when the DECserver-700 setup was done. The range is 2001-2016.

`relayport#` is the tcp port number added to the **/etc/services** file used to communicate between the input and output scripts for this printer.

16. Create files added in any **:if=** lines added to **printcap**. Make them executable with **chmod a+x**. They must contain just two lines:

```
#!/bin/ksh
```

```
exec /usr/ems/bin/d700_filter -i -h I2000_name -r relayports#
```

where:

`I2000_name` is the name of the I-2000 as recorded in the **/etc/hosts** file.

relayport# is the tcp port number chosen for the output filter script.

17. Restart the I-2000 by executing **kill\_I** (where the last letter is an I as in Iota). This is necessary so the I-2000 can rebuild its internal table that is used to repopulate the list of printers displayed in the `Printer Name` field of the USER MANAGEMENT, PRINTER MANAGEMENT and PRINTER QUEUE STATUS forms (refer to the appropriate sections of this manual for the form descriptions).

All printers in the **/etc/printcap** file with the exception of those defined in the `BTEMI` and `BTLF` environment variables (refer to Table 2-1) will be in this list.



**NOTE:**

It is NOT necessary to modify **/etc/ethers**, **/etc/protocols**, or **/etc/inetd.conf** files, as they already support Telnet and TCP/IP protocols and services. Moreover, if the default domain, host and network are already specified, simply make **printcap** and **/etc/services** entries for each printer.

## Administering X.25 Links

---



**NOTE:**

This feature is available *only* to system administrators.

Administering the X.25 links means placing them in service or taking them out of service. The network and its nodes must already have been physically installed before links can be placed in service. Placing the links in service is not required for merely running the I-2000. Once a link is in service, it can be used to establish communication with one or more frames. Refer to the next section, "Administering Frames". For the details on how to administer an X.25 link, refer to "X.25 LINK ADMINISTRATION" in Chapter 3 "System Administration."

## Administering Frames

---



**NOTE:**

This feature is available *only* to system administrators.

Administering a frame means establishing communication with the frame or taking it away. A link over which communication can occur must already have been provisioned. Refer to the preceding section, "Administering X.25 Links."

For the details on how to administer a frame, refer to "FRAME ADMINISTRATION" in this chapter.

## Configuring Login Ports

---

 **NOTE:**  
This feature is available *only* to system administrators.

Configuring a login port means placing an asynchronous line in service. The I-2000 supports up to 16 login ports. These appear as login ports 1 through x. They represent the first 16 ports. For example, if 32 ports are available on the system, only the first 16 can be used as login ports. The I-2000 supports up to six simultaneous login sessions, including the console session. For the details on how to administer the login ports, refer to "LOGIN PORTS" in Chapter 3 "System Administration."

## Changing Passwords

---

 **NOTE:**  
This feature is available *only* to system administrators.

You may need to change your password from the *root* password. For information on how to change passwords, refer to "CHANGE PASSWORD" in Chapter 12 "User Administration."


## Using the System

---

### MAIN MENU

---

When you log into the I-2000 system, the MAIN MENU is displayed, as shown in Figure 2-2.



**Figure 2-2. MAIN MENU**

### Procedure: Navigating Between Menus, Forms, and Fields

---

The user interface of the I-2000 features screens, which comprise menus and forms, in a logical “tree” structure. The complete structure is summarized at the end of this chapter.

A menu is a list of operations and actions from which you can select by one of the following methods:

1. Press **Enter** if the cursor is already at the desired choice; otherwise, use the arrow keys to get there.
2. Type the first letter of your choice. For selections beginning with the same letter, type additional letters. Use **Ctrl** + **X** to clear the field before making any entry (does not apply to vt220).
3. Some menu choices branch to subsequent submenus, but in any case lead eventually to a form. Forms contain fields. You type information into the fields and press **Enter**.

4. As soon as the cursor enters a field, INSERT typing mode is in effect. Each keystroke appears to the left and the cursor character with characters to the right are moved to the right.
5. To switch to OVERLAY typing mode, press **[Esc]** (not available on vt220). A keystroke appears at the cursor position, overlaying the character there, and the cursor moves over the next character to the right. **[Esc]** switches between INSERT and OVERLAY typing modes, but entry to a field is always in INSERT.
6. To remove the contents of the field and start over, type **[Ctrl] + [X]** (not supported for vt220).
7. Once you press **[Enter]**, if the information entered is not in the correct format for that field, an error message is displayed with a request to re-enter the information. Once the information in the field is correct, the cursor advances to the next field.
8. **[Tab]** (does not apply to vt220) can be used to move forward between fields. However, not all fields allow user input. In such cases, the next field is the next that allows user input.
9. Some fields are mandatory; for example, **NPC ID** in an NPC PROVISIONING form. You are not allowed to continue until the field contains a valid value. Of course, the special function keys are always valid when they are shown on the screen; you can always start over by pressing **[QUIT]**. Refer to "Using Function Keys" in this chapter.

For further information on allowed keystrokes for menus, forms and passthrough, refer to Tables 2-5 through 2-8.



**NOTE:**

The title of each table states the proper application of its keystrokes. For example, **[PAGE DOWN]** as a menu control keystroke obtains the next page of a menu, but not necessarily the next page of a displayed report, form, or report.

**Table 2-5. Menu Control Keystrokes**

Keystrokes	Function
⤴	Return to the MAIN MENU.
?	Pop-up Help menu for current item.
Enter Return Ctrl + j Ctrl + m	Select an item from the menu.
Ctrl + a	Get an alarm report.
Ctrl + b Pg Dn	Scroll down a page.
Ctrl + d	Scroll menu down a line.
Ctrl + c	Return to the MAIN MENU from a second level menu; log the user off from the MAIN MENU level.
Ctrl + n Ctrl + i ↓	Move to the next item.
Ctrl + f Pg Up	Scroll up a page.
Ctrl + u	Scroll menu up a line.
Ctrl + h	Erase the last character in the pattern matching buffer.
Ctrl + o	Output the screen to the printer.

**Table 2-5. Menu Control Keystrokes (Contd)**

Keystrokes	Function
[Ctrl] + [p] ↑	Move to the previous item.  <b>⚠ CAUTION:</b> <i>When connected to the I-2000 using the X.25 network, pressing [Ctrl] + [p] will disconnect you from the network. Use the ↑ key to move to a previous item.</i>
[Ctrl] + [w]	Refresh the screen.
[Ctrl] + [x]	Clear the pattern matching buffer.
[Ctrl] + [z]	Move to the previous pattern match.

**NOTE:**

The pattern matching buffer holds keystrokes as you type them. For example, typing [p] places "p" in the pattern matching buffer. [Ctrl] + [z] moves to the next menu selection beginning with p. [Ctrl] + [x] and [Ctrl] + [h] clear the p.

**Table 2-6. Form Control Keystrokes**

Keystrokes	Function
[Enter] [Ctrl] + [m]	Enter the information in the field.
[Ctrl] + [a]	Get an alarm report.
[Ctrl] + [b]	Move down a character.
[Ctrl] + [d]	Move down to a field.
[Ctrl] + [e]	Move to a position just to the right of the last input character of the field.
[Ctrl] + [f]	Move up a character.

Table 2-6. Form Control Keystrokes (Contd)

Keystrokes	Function
<b>Ctrl</b> + <b>g</b>	Delete the word at the cursor.
<b>Ctrl</b> + <b>h</b>	Backspace and erase a character.
<b>Ctrl</b> + <b>i</b> <b>Tab</b> <b>Ctrl</b> + <b>m</b>	<p>Request new line. For single-line fields, move to the next field. For multi-line fields, operation depends on whether insert or overlay editing mode is in effect at the time of the request.</p> <p>For insert mode, a cursor at the beginning of a field or on the last line moves to the next field. Otherwise, the text on the current line, to the cursor's right, moves to the next line. The cursor itself moves to the beginning of the next line.</p> <p>For overlay mode, a cursor at the beginning of a field moves to the next field. If the cursor is on the last line of the field, all data from the cursor position to the end of the line is erased, and then the cursor moves to the next field. Otherwise, all data from the cursor position to the end of the line is erased, and the cursor moves to the beginning of the new line.</p>
<b>Ctrl</b> + <b>k</b>	Clear to the end of the field.
<b>Ctrl</b> + <b>l</b>	Move left to a field.
<b>Ctrl</b> + <b>n</b>	Move to the next field.
<b>Ctrl</b> + <b>o</b>	Output the screen to the printer.
<b>Ctrl</b> + <b>p</b> ↑	<p>Move to the previous field.</p> <p><b>⚠ CAUTION:</b> <i>When connected to the I-2000 using the X.25 network, pressing <b>Ctrl</b> + <b>p</b> will disconnect you from the network. Use the ↑ key to move to a previous item.</i></p>
<b>Ctrl</b> + <b>r</b>	Move right to a row.
<b>Ctrl</b> + <b>u</b>	Move up to the next closest field.

**Table 2-6. Form Control Keystrokes (Contd)**

Keystrokes	Function
<b>Ctrl</b> + <b>q</b>	Move to the next line of a multiline field.
<b>Ctrl</b> + <b>s</b>	Move to the previous line of a multiline field.
<b>Ctrl</b> + <b>t</b>	Move to the previous word in the field.
<b>Ctrl</b> + <b>v</b>	Delete a character.
<b>Ctrl</b> + <b>w</b>	Refresh the screen.
<b>Ctrl</b> + <b>x</b>	Clear the field.
<b>Ctrl</b> + <b>y</b>	Delete the line at the cursor.
<b>Ctrl</b> + <b>z</b>	Move to the previous listed choice.
<b>Esc</b>	Toggle the editing mode between insert and overlay. In insert mode (the default), new text is inserted at the current character position, while existing text gets moved to the right. In overlay mode, entered text overlays (replaces) existing text in the field. In either mode, the cursor advances one character position as you enter each character.

**Table 2-7. Passthrough Control Keystrokes**

Keystrokes	Function	Application
<b>Home</b>	Position the cursor at the input line.	Full PASSTHROUGH only
<b>Ctrl</b> + <b>a</b>	Get an alarm report.	All
<b>Ctrl</b> + <b>b</b>	Scroll back a page.	Full only
+ <b>Ctrl</b> + <b>d</b>	Scroll forward a line.	Full only
<b>Ctrl</b> + <b>e</b>	EXIT from passthrough	Full only

**Table 2-7. Passthrough Control Keystrokes (Contd)**

Keystrokes	Function	Application
Ctrl + f	Scroll forward a page.	Full only
Ctrl + h	Backspace and erase a character.	All
Ctrl + l	Move to the last page of the buffer.	Full only
Ctrl + o	Output the screen to the printer.	All
Ctrl + t	Move to the top of the buffer.	Full only
Ctrl u	Scroll back a line.	Full only

### Using Function Keys

Function keys **F1** through **F8** across the top of the I-2000 keyboard perform the I-2000 functions that are shown along the bottom of each I-2000 screen. The functions may change from screen to screen. For a DEC vt220, the function keys are **F7** through **F14**.



**NOTE:**

If environmental considerations necessitate changing the VT220 function keys **F7** through **F14** to some other combination, refer to the System V curses and terminfo section of the SunOS documentation.



**NOTE:**

The function keys are under software control and cannot be programmed by the user. However, some terminals permit selection of user function keys and system function keys. In that case, the user function keys can still be user programmed. To obtain the preprogrammed system function keys, you must select them. See your terminal user's guide for instructions on how to program the user function keys.

Some of the common preprogrammed function keys are described in Table 2-8.

**Table 2-8. Preprogrammed Function Keys**

Keystrokes	Function						
<b>CHOICES</b>	Displays a pop-up window showing the list of choices available for this field.						
<b>EXECUTE</b>	Sends the requested operation to the I-2000 for processing. In most cases, a pop-up window is displayed asking you if "you are sure?" about the command you are about to execute.						
<b>FIRST</b>	Moves the selection highlighting to the first list item.						
<b>HELP</b> +	Displays a brief help message for the item on which the cursor is currently resting.						
<b>LAST</b>	Moves the selection highlighting to the last list item.						
<b>NEXT</b>	Moves the selection highlighting to the next list item.						
<b>PREVIOUS</b>	Moves the selection highlighting to the previous list item.						
<b>PRINT</b>	Prints the screen just as it is.						
<b>RECNCILE</b>	<p>Provides the following choices about updating the database after selecting a provisioning <b>Action</b>:</p> <table> <tr> <td>Site and Local -</td> <td>Updates both DACS and I-2000 database. (default)</td> </tr> <tr> <td>Site Only</td> <td>Updates only the DACS database.</td> </tr> <tr> <td>Local Only</td> <td>Updates only the I-2000 database.</td> </tr> </table> <p>See "Using the RECNCILE Key," later in this chapter for more details.</p> <p><b>⇒ NOTE:</b> The <b>EXECUTE</b> must be performed after choosing your <b>RECNCILE</b> choice. Hitting any other key after choosing the non-default choice will reset the choice back to "Site and Local."</p>	Site and Local -	Updates both DACS and I-2000 database. (default)	Site Only	Updates only the DACS database.	Local Only	Updates only the I-2000 database.
Site and Local -	Updates both DACS and I-2000 database. (default)						
Site Only	Updates only the DACS database.						
Local Only	Updates only the I-2000 database.						
<b>QUIT</b>	Returns to the previous menu.						
<b>TOP MENU</b>	Returns to the MAIN MENU.						

Other function keys are described at the appropriate locations in this manual. If a key does not appear on the screen, it has no definition for that screen. Pressing it results in a message:

Unimplemented Function Key.

If the key appears on the screen, and pressing the key results in the Unimplemented message, its definition may not be applicable to the attempted operation.

Two keys have functions that require explanation in detail: **EXECUTE** and **RECNCILE**. Refer to "Using the EXECUTE Key" and "Using the RECNCILE Key" in this chapter.

### Using the EXECUTE Key

By entering data through a screen you set up an operation to be performed on the DACS. The DACS commands generated by the I-2000 are sent to the DACS when you specify execution through the **EXECUTE** special function key. Since an improperly timed or ill-prepared operation can have serious consequences, some safeguards are built into the use of the **EXECUTE** key.

As soon as you press **EXECUTE**, the I-2000 displays a pop-up window.


In some cases, the system will display a pop-up window asking you "ARE YOU SURE?" about the command you are about to execute. At this point you either answer **Yes** or **No**. In other cases, a pop-up window is displayed asking when you want the task to be run; for example, IMMEDIATE or SCHEDULE.

In addition, the I-2000 begins by making a number of consistency checks before deciding that the command might succeed and passing it on to the DACS. If the consistency checks indicate that the command cannot succeed, an error message is placed at the bottom of the screen.

If the consistency check passes, the command will begin execution. This will be noted in a message in the left-hand corner of the screen.

If an error occurs, then a Command Response pop-up window will appear. To acknowledge the error message and close the command response pop-up window, press **Enter**.

Some commands execute in the background. After the **EXECUTE**, a command pop-up window appears describing the operation. See Figure 2-3.



---


**Figure 2-3. Command Response Pop-up Window**




**NOTE:**

The DACS may also reject a command for reasons not checked by the I-2000. An explanation message is then displayed in the command response pop-up window, which will remain on the screen until acknowledged by Enter.

When the database checking indicates that the command can succeed, one of two possible pop-up windows are displayed, as shown in Figures 2-4 and 2-5.



**Figure 2-4. Confirmation Window**



**Figure 2-5. Select Schedule or Confirm Window**


The confirmation window asks if you are sure you want to send the request to the DACS, and allows you to choose Y or N. As soon as you make your selection, the I-2000 either performs the operation immediately or cancels it as you requested.

If the I-2000 sends a command to the DACS, it may not receive a timely reply. The I-2000 waits a period equal to the time stored in the `DACS_TIMEOUT` environment variable and then displays a `timeout error` message in the `COMMAND RESPONSE` box. The default is three minutes. For information on how to change it, refer to "Setting Environmental Variables" in this chapter.

Scheduling is an important I-2000 feature. Many operations can be performed immediately or scheduled to occur at a more convenient time. The I-2000 provides the capability of executing the operation in the foreground or in the background. It can be scheduled to run in the background once, repeatedly, or indefinitely at a specified frequency.

For operations that can be scheduled, the `EXECUTION MODE` window appears when you press `EXECUTE`. It allows you to select a scheduling menu. You can also just select YES or NO, as in the `ARE YOU SURE?` menu.

If you select QUIT or NO, the operation is canceled. If you select IMMEDIATE or YES, the operation is executed immediately in the foreground; for example, the screen is not usable until the operation is complete. If you select SCHEDULE, the `TASK SCHEDULING` window is displayed, as shown in Figure 2-6.



**Figure 2-6. Task Scheduling Window**

**⇒ NOTE:** Database audit/synchronization is always performed in the background, no matter which choice you select.

## Field Descriptions

Table 2-9 provides field descriptions for all fields on the TASK SCHEDULING screen.

**Table 2-9. TASK SCHEDULING Field Descriptions**

<b>Date</b>	The date of first scheduled execution. The format is dd mmm yy where:  dd        The day of the month, 1 through 31.  mmm      A 3-letter standard abbreviation for the month: Jan, Feb, Mar, Apr, May, Jun, Jul, Aug, Sep, Oct, Nov, Dec. The month is not case-sensitive.  yy        The last two numbers of the year, 90 through 37.
<b>Time</b>	The time of first scheduled execution. The format is hh:mm where:  hh        The hour on a 24-hour clock, 00-23.  mm        The minute, 00-59.
<b>Number of times</b>	Two numeric digits. A value specifying the number of times the task is to execute. The default is 01. The value 00 obtains indefinitely repeated execution.
<b>Interval</b>	The number of <b>Scale</b> units between successive executions of the <b>Action</b> . The range of values is 01-99.
<b>Scale</b>	The type of units in which the <b>Interval</b> is expressed.  MINUTES HOURS DAYS

For information on how to remove a task from the task list, refer to Chapter 11 "Task Administration."

## Using the RECNCILE Key

Pressing **EXECUTE** alone to enter a provisioning **Action** such as CREATE or RESTORE updates both DACS and I-2000 databases automatically. However, there will be situations where you need to change the DACS and I-2000 databases individually to reconcile them.

For example, if you are installing the I-2000 at a site where the DACS NPCs have already been provisioned, pressing **RECNCILE** followed by **EXECUTE** lets you provision the I-2000 database independently, without sending a corresponding command to the DACS.

## Understanding the Screen Line

Table 2-10 describes the areas of the screen and the type of information they contain.

**Table 2-10. Screen Contents**


Area	Description
Top line	Gives the time, date and I-2000 software release number.
Second line ( <b>Status</b> line)	<p>Contains the most recent message about I-2000 status for system-wide communication to logged-in users. For example, when you enter passthrough mode on a SNIDER link, a message appears that passthrough is in progress for that DACS. This line also gives the status of background processes, such as preplanned reconfigurations and report generation. This line is termed the I-2000 status in this manual to avoid confusion with the various status or state fields that may appear on the screen.</p> <p><b>⇒ NOTE:</b> The previous message is overwritten by the next message, and that you cannot count on a message remaining in the <b>Status</b> line for long. If the response to your I-2000 operation does not seem to appear, it may already have been overwritten by a system message.</p>
Third line ( <b>Alarm</b> line)	Shows any unacknowledged DACS alarms on supported DACSs that have occurred since user login. Pressing <b>[Ctrl] + [a]</b> displays a report of the most recent alarms for the chosen DACS and retires the alarm indication. See Chapter 16, "Fault Management," for more information.
Middle screen	Shows the menu or a form with its fields.
Near bottom	Displays a line of text that prompts, gives an error message, or displays the completion status of the last command you requested.
Bottom screen	Contains the labels for the function keys in effect for that screen. Also displays the number assigned to the current user interface session ( <b>UI1</b> to <b>UI16</b> ). This number is used to identify the user commands and print jobs associated with a user interface session.

### Procedure: Updating the Database

---

To update the I-2000 database independently, follow these steps.

1. Fill out the screen.
2. Press **RECNCILE**. The WHICH DATABASE? window is displayed, as shown in Figure 2-7.



---

**Figure 2-7. Database Selection Window**

3. Select `Local Only`. The following message is displayed toward the bottom of the screen:

```
DATABASE CHOSEN: LOCAL ONLY
```

4. Press **EXECUTE**.

The `Site Only` selection lets you send a provisioning command to the DACS for execution, bypassing the I-2000 database and its consistency checking. This feature allows the I-2000 screen displays to control the DACSs without the need for you to enter passthrough mode.



**NOTE:**

If you select a database; for example, Local Only, and press **EXECUTE**, only the local database is updated.

If you select a database and change other information and press **EXECUTE** the database selected is lost and both the local and site databases will be updated.

The constraints concerning the use of **RECNCILE** are:

- For Local only mode, the results of a **RECNCILE** followed by an **EXECUTE** are the same as for Site and Local, except that no commands at all are sent to the DACS. You can provision NPCs and circuits for practice, or for future use in the DACS, without altering the DACS provisioning in any way.
- For Site only mode, fields that would affect the I-2000 database only are ignored. Minimal checking of DACS information is performed, and the I-2000 database is not updated at all.



**CAUTION:**

*You must take care when using local only mode: since the I-2000 does not cross-check every parameter in the form and relies on the DACS for some checking, it is possible to store invalid circuit or provisioning attributes in the I-2000 database.*

*For example, if you store an illegal TC value. A later attempt to synchronize the circuit will result in a failure. To prevent this type of failure, consult your local network engineering staff or refer to the DACS I/O manuals for proper value pairs.*

After command completion the database selection reverts to Site and Local, the normal mode, in which the DACS and the I-2000 are provisioned together.

## Summary of Menus And Forms

---

The list of operating features in this summary is comprehensive.

Table 2-11 lists menu selections starting at the highest level to the left and moving to the lowest level to the right. At the lowest level is typically a form. Nearly all forms include an **Action** field. The **Action** identifies the task you want to perform. This table summarizes the **Actions** available.

**Table 2-11. Summary of Menus and Forms**

<b>MAIN MENU</b>	<b>Second Level</b>	<b>Action/Third Level</b>
PROVISIONING	CIRCUIT	ACTIVATE MODIFY PEND DELETE DEACTIVATE ALTRROUTE NORMALIZE COMBINE BROWSE ADDLEG DELLEG CHGRPATH
	TEST PORT	CREATE TP DIGROUP DELETE TP DIGROUP CREATE TEST PORT DELETE TEST PORT
	NPC	BROWSE CREATE DELETE REMOVE RESTORE MODIFY QUERY LOOPBACK
	RECONFIGURATION PLAN	CREATE DESTROY BOOT INSERT REMOVE CHANGE EXECUTE IDLE CHECK ABORT CLEAN
	AUTOMATIC RECONFIGURATION PLAN	CREATE DESTROY INSERT REMOVE CHANGE EXECUTE IDLE CHECK CLEAN ABORT

**Table 2-11. Summary of Menus and Forms (Contd)**

<b>MAIN MENU</b>	<b>Second Level</b>	<b>Action/Third Level</b>
PROVISIONING (Continued...)	ESTABLISHED DS0 CHANNELS <sup>1</sup>	ACTIVATE MODIFY DELETE DEACTIVATE BROWSE
	SUBRATE CROSS CONNECT <sup>1</sup>	ACTIVATE MODIFY DELETE DEACTIVATE BROWSE
	NPC ROLL	
	24-HOUR PERFORMANCE <sup>2</sup>	BROWSE RESET
SYSTEM ADMINISTRATION	LOGIN PORTS	RESTORE REMOVE
	X.25 LINK ADMINISTRATION	RESTORE REMOVE
	FRAME ADMINISTRATION	CREATE RESTORE BRESTORE REMOVE DELETE MODIFY CHGSITE
	NAME CHANGE	
	PRINTER ADMINISTRATION	ENABLE DISABLE LIST CANCEL LOGALL LOGALARMS STOPLOGGING
	SHUTDOWN	QUIT IMMEDIATE 1 MINUTE 5 MINUTE 10 MINUTE NO
	DATE AND TIME	
	SYNCHRONIZE FRAME DATE & TIME	

Table 2-11. Summary of Menus and Forms (Contd)

MAIN MENU	Second Level	Action/Third Level
DATABASE ADMINISTRATION	DATABASE AUDIT/SYNCHRONIZATION	ALARM SYNC CHANNEL AUDIT CHANNEL SYNC NPC AUDIT NPC SYNC UPLOAD ABORT
	BACKUP/RESTORE	DATABASE BACKUP/ RESTORE (TAPE)  LOG BACKUP/RESTORE (TAPE)  LOG BACKUP/RESTORE (DISKETTE)  REPORT FORMAT BACKUP/RESTORE (DISKETTE)  FORMAT DISKETTE
	ENTER OUTAGE DATA	INSERT CHANGE DELETE DESTROY
TASK ADMINISTRATION	TASK MANAGEMENT	LIST DELETE
	PRINTER QUEUE STATUS	LIST CANCEL
USER ADMINISTRATION	USER MANAGEMENT	ADD CHANGE DELETE
	CHANGE PASSWORD	
PASSTHROUGH	MULTIPLIED PASSTHROUGH	
	PASSTHROUGH	
	FRAME COMMAND SCRIPT	EDIT DELETE EXECUTE ABORT DOSREAD DOSWRITE
PASSTHROUGH ABORT		

**Table 2-11. Summary of Menus and Forms (Contd)**

<b>MAIN MENU</b>	<b>Second Level</b>	<b>Action/Third Level</b>
REPORT OPERATIONS	CIRCUITS	CIRCUIT CONNECTIONS CIRCUIT OPTIONS CIRCUIT INFORMATION CIRCUIT AVAILABILITY
	NPCS	NPC IDS NPC NUMBERS
	CHANNELS	CHANNEL USAGE
	ALTROUTES/PREEMPTIONS	ALTROUTED CIRCUITS PREEMPTED CIRCUITS
	OUTAGES	
	TEST PORT	TEST PORT STATUS TEST PORT PROVISIONING
	TEST ACCESS	
	FRAMES/LINKS	PROVISIONING LINK STATUS LINK CONNECTIVITY FRAME CONTROL
	USER ADMINISTRATION	USER LOGINS
	NPC ALARMS	
	CIRCUIT ALARMS	
	ALARM LOG	
	AUDIT/SYNCHRONIZATION RESULTS	ALARM SYNC CHANNEL AUDIT CHANNEL SYNC NPC AUDIT NPC SYNC UPLOAD
	NPC ROLL RESULTS	
	ECHOED RESPONSE PROCESSING	CKT NPC TA
	TASK SCHEDULE LIST	

Table 2-11. Summary of Menus and Forms (Contd)

MAIN MENU	Second Level	Action/Third Level
REPORT OPERATIONS (Continued)	TASK SCHEDULE RESULTS	
	LOST RESPONSE LOG	CIRCUIT NPC FRAME
	HISTORY LOG	SCREEN PRINTER DOS DISKETTE
	SCRIPT LOG	SCREEN PRINTER DOS DISKETTE
	DISPLAY LAST GENERATED REPORT	SCREEN PRINTER DOS DISKETTE
	EDIT CUSTOM REPORT FORMAT	CREATE DELETE MODIFY RENAME
	ALARM QUERY	
	DISPLAY ALARM QUERY	SCREEN PRINTER DOS DISKETTE
	RECONFIGURATION SUB-MENU	RECONFIGURATION PLANS  RECONFIGURATION PLANS ALTROUTE  RECONFIGURATION PLAN RESULTS  AUTO RECONFIGURA- TION PLAN RESULTS
	ESTABLISHED DS0 CHANNELS <sup>1</sup>	
	SUBRATE CIRCUITS <sup>1</sup>	
	COMMON EQUIPMENT ALARMS	
	24-HOUR PERFORMANCE <sup>2</sup>	

**Table 2-11. Summary of Menus and Forms (Contd)**

<b>MAIN MENU</b>	<b>Second Level</b>	<b>Action/Third Level</b>
TEST ACCESS		MONITOR SPLIT HUB TERMINATE UNTERMINATE RELEASE LOOP CHLOOP <sup>3</sup> CHUNLOOP <sup>3</sup>
LOGOFF		

- 1 This option appears if the X.50 substrate feature is enabled.
- 2 This option appears if the 24-hour performance monitoring feature is enabled.
- 3 This option appears if the BT feature is enabled.

---

## Contents

<b>Introduction</b>	3-1
<b>SYSTEM ADMINISTRATION Menu</b>	3-1
<b>LOGIN PORTS</b>	3-2
■ LOGIN PORT ADMINISTRATION Form	3-4
Field Descriptions	3-4
■ Procedure: Setting the Login Port Speed	3-6
<b>X.25 LINK ADMINISTRATION</b>	3-6
■ X.25 LINK ADMINISTRATION Form	3-6
Field Descriptions	3-7
■ Procedure: Placing a Line in Service	3-8
■ Procedure: Removing a Line From Service	3-9
<b>FRAME ADMINISTRATION</b>	3-9
■ X.25 Configurations	3-10
Fully Backed-Up Configuration	3-10
Backup of Link to Frame Only	3-11
Backup of I-2000 Link Only	3-11
■ FRAME ADMINISTRATION Form	3-13
Verification of FRAME ADMINISTRATION Information	3-13
Field Descriptions	3-14
■ To Create and Restore a Frame	3-18
Procedure: Creating and Restoring a Frame, X.25 Administration	3-18
Procedure: Changing the Site Name	3-21
Procedure: Creating and Restoring a Frame, SNIDER Administration	3-22

---

## Contents

Procedure: Unprovisioning a Frame in X.25 or SNIDER	3-23
■ Changing The I-2000 Name	3-24
Procedure: Changing the I-2000 Name Using the I-2000 User Interface	3-24
<b>PRINTER ADMINISTRATION</b>	3-26
Field Descriptions	3-26
■ Procedure: Viewing Printer Management	3-27
■ Procedure: Enabling a Printer	3-28
■ Procedure: Disabling a Printer	3-28
■ Procedure: Displaying Print Jobs Queued	3-28
■ Procedure: Removing Prints Jobs Queued	3-29
■ Procedure: Printing/Stop Printing Output or Frame Alarms	3-30
■ Procedure: Enabling/Disabling Banner Page	3-30
■ Procedure: Enabling/Disabling Form Feed	3-31
<b>SHUTDOWN</b>	3-31
<b>DATE and TIME</b>	3-34
■ Procedure: Setting the Date and Time	3-34
<b>SYNCHRONIZE FRAME</b>	
<b>DATE &amp; TIME</b>	3-36
■ Procedure: Synchronizing Frame Date & Time	3-36

## Introduction

---

**NOTE:**

This chapter is *only* for users with system administration privileges.


The SYSTEM ADMINISTRATION menu allows the system administrator to perform a number of administrative tasks, such as:

- Login Ports
- X.25 Link Administration
- Frame Administration
- Printer Administration
- Shutdown
- Date and Time
- Synchronize Date and Time

## **SYSTEM ADMINISTRATION Menu**

---

To obtain the SYSTEM ADMINISTRATION menu, select SYSTEM ADMINISTRATION from the MAIN MENU. The SYSTEM ADMINISTRATION menu is displayed, as shown in Figure 3-1.



**Figure 3-1. SYSTEM ADMINISTRATION Menu**

## **LOGIN PORTS**

LOGIN PORTS allow you to enable or disable an asynchronous port. An I-2000 asynchronous port is the logical means by which a terminal operator accesses the I-2000 computer through an asynchronous line.

Login ports are not the only use of asynchronous lines. SNIDER connections are made through them as well; however, the two uses are incompatible. If you are going to enable a port, you cannot use the corresponding line for a SNIDER link, and vice versa. For details on SNIDER links, refer to "FRAME ADMINISTRATION" in this chapter.

The number of asynchronous lines available at the I-2000 computer depends on its hardware configuration. For details concerning hardware configuration, refer to the I-2000 Controller for DACS II Installation Manual regarding the Aurora 800 SX, or their equivalents. The hardware makes available lines 1 through n, where n must be known to the administrator.



**NOTE:**

Although Aurora products support line 0 through n, the I-2000 numbering starts at 1. See Table 3-1.

The system administrator must restore a login port before an operator can log in on it. Restoring the port places a login prompt on the terminal.

Different terminals may require different asynchronous line speeds. It is possible to change the line speed through this selection.

**Table 3-1. Port Numbering Scheme**

Aurora Lines	1-2000 Lines
0	1
1	2
2	3
3	4
4	5
5	6
6	7
7	8
8	9
9	10
10	11
11	12
12	13
13	14
14	15
15	16

The system administrator must restore a login port before a user can log in on it. Restoring the port places a login prompt on the terminal.

Different terminals may require different asynchronous line speeds. It is possible to change the line speed through this selection.



**NOTE:**

The console does not communicate with the I-2000 computer via these asynchronous lines. Therefore, the system administrator does not need access through one of these ports.

Link or frame administration are not required prior to the use of this selection.

## LOGIN PORT ADMINISTRATION Form

Select LOGIN PORTS from the SYSTEM ADMINISTRATION menu. The LOGIN PORTS ADMINISTRATION menu is displayed, as shown in Figure 3-2.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- LOGIN PORT ADMINISTRATION -----

Action:
Port:           Speed:           Status:NULL

Enter the desired Link Administrative Action: RESTORE or REMOVE

HELP  CHOICES  [ ]  QUIT  [ ]  TOP MENU  PRINT  EXECUTE
    
```

**Figure 3-2. LOGIN PORT ADMINISTRATION Form**

### Field Descriptions

The field values for the LOGIN PORTS ADMINISTRATION form are described in Table 3-2.

**Table 3-2. LOGIN PORT ADMINISTRATION Field Descriptions**

<b>Action</b>	Mandatory. The values are:
	RESTORE    Enable the port.
	REMOVE     Disable the port.

**Table 3-2. LOGIN PORT ADMINISTRATION Field Descriptions (Contd)**

<p><b>Port</b></p>	<p>Mandatory. Numeric, 1 through the number of asynchronous lines up to 16.</p> <p>Pressing <b>[CHOICES]</b> when the cursor is in <b>Port</b> displays the available ports, their <b>Status</b>, the user log-in, if there is one, and the <b>Speed</b>. Use the display to select a port, or enter the port number.</p> <p>If you have a port configured as a SNIDER link, <b>[CHOICES]</b> will display the site name.</p> <p>An * before a listed port means that it is being used as a SNIDER link to a DACS. You may not enable it as a login port.</p> <p style="text-align: center;">  <b>CAUTION:</b>  <i>You can REMOVE an INUSE port by a remote terminal, but the user will be logged off. You cannot REMOVE an INUSE port by a DACS.</i> </p>
<p><b>Speed</b></p>	<p>Mandatory. Numeric. The baud rate to be in effect. The possible values are 1200, 2400, 4800, and 9600.</p>
<p><b>Status</b></p>	<p>Not accessible to the user.</p> <p>NULL      The port has not yet been restored in this database.</p> <p>INUSE      The port is currently in use. You can display the login by pressing <b>[CHOICES]</b> when the cursor is in <b>Port.S</b>. You may not enable it as a login port.</p> <p style="text-align: center;">  <b>CAUTION:</b>  <i>You can REMOVE an INUSE port by a remote terminal, but the user will be logged off. You cannot REMOVE an INUSE port by a DACS.</i> </p> <p>IS            The port is ready for remote login and may not be pre-empted by a DACS. To disable it, enter a REMOVE <b>Action</b>.</p> <p>OOS          The port is no longer available for remote login without restoral, but may be utilized by a DACS. To enable it, enter a RESTORE <b>Action</b>.</p>

### **Procedure: Setting the Login Port Speed**

---

To set the speed of a login port, follow these steps:

1. Obtain the LOGIN PORT ADMINISTRATION form. The **Status** can be any value except `INUSE`. In the latter case, access will be denied.
2. Enter an **Action** of `RESTORE`.
3. Enter the **Port** number.

The I-2000 displays that port's current speed, if there is one. The **Status** now reflects the status of the **Port**.

4. Enter the new **Speed**.
5. Press `EXECUTE` and answer YES to ARE YOU SURE? The results are:
  - The **Status** changes to or remains `IS` (In Service).
  - The command completed successfully message is displayed.

## **X.25 LINK ADMINISTRATION**

---



**NOTE:**

This feature is available *only* to system administrators.

An X.25 link is the logical means by which you access a synchronous line from the I-2000 computer. Therefore, if you are going to access a frame through the X.25, you need to restore a synchronous link.

X.25 links are configured at installation time. Lines 1 through 4 should already be in place, and you have only to put them in service or take them out of service.

### **X.25 LINK ADMINISTRATION Form**

---

Select X.25 LINK ADMINISTRATION from the SYSTEM ADMINISTRATION menu. The X.25 LINK ADMINISTRATION form is displayed, as shown in Figure 3-3.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
_____ X.25 LINK ADMINISTRATION _____

Action:RESTORE           Line No.:           Status:

Connection Type:

_____Enter desired action _____

HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE
    
```

**Figure 3-3. X.25 LINK ADMINISTRATION Form**

**Field Descriptions**

The field values for the X.25 LINK ADMINISTRATION form are described in Table 3-3.

**Table 3-3. X.25 LINK ADMINISTRATION Field Descriptions**

<b>Action</b>	<p>Mandatory. The values are:</p> <p>RESTORE Places the X.25 link in service. The <b>Status</b> must be OOS; otherwise, the <b>Action</b> is denied and a message is displayed:</p> <p style="padding-left: 40px;">Link already in service</p> <p>REMOVE Removes the X.25 link from service. This <b>Action</b> is allowed whether the <b>Status</b> indicates IS, in service, or OOS, out of service.</p> <p>A rejection with the message:</p> <p style="padding-left: 40px;">There are active circuits on this link. Link not removed.</p> <p>refers to extant packet-level connections to the DACS. To remove the link, you must first place the DACS sites in an OOS <b>Site Status</b> through FRAME ADMINISTRATION.</p>
---------------	---

**Table 3-3. X.25 LINK ADMINISTRATION Field Descriptions (Contd)**

<b>Line No.</b>	Mandatory, one numeric character. The physical line number of the link supporting the connection. Entries are one through four.
<b>Status</b>	The status of the link, not user-accessible.  IS            In service. The link can support switched virtual circuits (SVCs). A DACS can be placed in service on this link. OOS         Out of service. A DACS cannot be placed in service on this link.
<b>Connection Type</b>	Not accessible through the I-2000. The information shown reflects how the links were set up during installation. If X.25 links have been configured during installation, this field assumes the appropriate value. If X.25 links have not been configured, then this field is blank, and any attempt to RESTORE a line is rejected.  PDN         Packet data network. The network acts as DCE for the connection, and the I-2000 acts as DTE. The X.25 link must be connected to a PDN. Up to 250 virtual circuits are supported.  DIRECT      The I-2000 act as DCE for the connection. The X.25 link must be connected directly to an X.25 port of the DACS II ISX frame through a synchronous modem eliminator.

**Procedure: Placing a Line in Service**

To place a line in service, follow these steps:

1. Obtain the X.25 LINK PROVISIONING form.
2. Fill in the following fields:
  - **Action:** RESTORE
  - **Line No.:** x

where x is the number of the line. The **Status** is now displayed. Verify that it is OOS.

3. Press **EXECUTE** and answer YES to ARE YOU SURE?

When the link is successfully established:

- The **Status** field changes to IS.
  - The command completed successfully message is displayed.
4. Enter a new line number to establish another link.

### **Procedure: Removing a Line From Service**

---

To remove a line from service, follow these steps:

1. Obtain the X.25 LINK ADMINISTRATION form.
2. Fill in the following fields:
  - **Action:** REMOVE
  - **Line No.:** x

where x is the number of the line. The **Status** is filled in automatically. Verify that it is IS.

3. Press **EXECUTE** and answer YES to ARE YOU SURE?

When the link has been taken out of service:

- The **Status** field changes to OOS.
- The command completed successfully message is displayed.



**NOTE:**

If any packet level connections are active through this link, this action is denied.

### **FRAME ADMINISTRATION**

---

A frame is a DACS II or DACS II ISX. Before the I-2000 can communicate with a DACS, identify each DACS through the FRAME ADMINISTRATION form. On the FRAME ADMINISTRATION form, you provide the I-2000 with such information as the protocol and language to be used in communicating with the DACS, as well as the line numbers and speeds.

Before you can use FRAME ADMINISTRATION, perform all the set-up procedures described in "Configuring the Frame" in Chapter 2.



**NOTE:**


For X.25 configurations, link administration is a prerequisite to frame administration.

## X.25 Configurations

Another target of frame administration is to configure the primary and backup lines in the X.25 configuration. These lines are the links that were restored in LINK ADMINISTRATION. You have a few options.

### Fully Backed-Up Configuration

Figure 3-4 shows a configuration example for DACS II, where line 1 and line 2 are two links from the -2000 computer to the X.25 network. net\_ad\_1 is the **Network Address** of one link from the X.25 network to the DACS and net\_ad\_2 is the **Network Address** of another. An example of a **Network Address** is a telephone number, such as 5555555555.



**Figure 3-4. Fully Backed-up Configuration (DACS II)**

The following configuration backs up the entire path from the I-2000 to the DACS:

- **Primary Line:** 1
- **Network Address:** net\_ad\_1
- **Backup Line:** 2
- **Network Address:** net\_ad\_2

Figure 3-4 shows a configuration example for DACS II, where a break in line 1 establishes a backup path through line 2 and a break in net\_ad\_1 establishes a backup path through net\_ad\_2.

### Backup of Link to Frame Only

It is possible to back up only net\_ad\_1, if for some reason line 2 is not present or you do not wish to use it to back up line 1:




Figure 3-5. Backup of Link to Frame Only (DACS II)

- **Primary Line:** 1
- **Network Address:** net\_ad\_1
- **Backup Line:** 1
- **Network Address:** net\_ad\_2

The path in both the primary and backup case goes through line 1, which is, therefore, not backed up, as shown in Figure 3-5.

### Backup of I-2000 Link Only

It is also possible to back up only line 1, if the DACS has only one link available, as shown in Figure 3-6.




Figure 3-6. Backup of I-2000 Link Only

- **Primary Line:** 1
- **Network Address:** net\_ad\_1
- **Backup Line:** 2

— **Network Address:** net\_ad\_1

The path in both the primary and backup case goes through net\_ad\_1, which is, not backed up, as shown in Figure 3-6.

The I-2000 attempts to establish communication over an X.25 link when it receives a **RESTORE Action** or a **BRESTORE Action** through FRAME ADMINISTRATION, or when the SVC is lost to a DACS that was previously restored on the primary line. While reading the discussion below, refer to the subsequent FRAME ADMINISTRATION form and the field descriptions, if necessary.

If you are executing a **RESTORE**, and are using only the primary line, or if the primary line has been restored without a backup line and the SVC has been lost, the I-2000 makes up to two attempts to establish communication through the **Primary Line** and **Network Address**. A third try is preceded by a 60-second delay. If all three fail, the I-2000 begins the three-try sequence again, to an indefinite number of attempts, only terminated when it succeeds or you enter a **REMOVE Action**.

If you are executing a **BRESTORE**, the I-2000 goes through the same cycle of attempts, over the **Backup Line** and its **Network Address**.

If the SVC is lost to a DACS that was previously restored with both a primary and a backup line, the I-2000 makes up to two attempts to restore communication over the primary line, then one attempt over the backup line, then one more attempt over the primary line, ending the cycle with a 60-second delay. Then it starts the cycle again, up to an indefinite number of attempts.

When communication “switches” from one line to another because of a failure, the switch is non-revertive. That is, the DACS will not automatically switch back to the original line when the failure clears.

The Aurora X.25 interface provides a cause code and a diagnostic code to the I-2000 when a link is broken.

The I-2000 then displays one of three diagnostic messages in the I-2000 **Status** field:

```
Primary link n is down for site sitename, cause xx diag yy.  
Backup link n is down for site sitename, cause xx diag yy.  
Net addr mmm is down for site sitename, cause xx diag yy.
```

For the meanings of xx and yy in each case, refer to the vendor manual entitled X.25 Software From Aurora Technology.

## FRAME ADMINISTRATION Form

Select FRAME ADMINISTRATION from the SYSTEM ADMINISTRATION menu. The FRAME ADMINISTRATION form is displayed, as shown in Figure 3-7.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- FRAME ADMINISTRATION -----
Action:CREATE          Site Name:NJ1          Site Status:UEQD
Type:DACS II          Protocol:X.25          Language:MML
NPC Addr:HIER         Location:New Jersey    Generic:7.0
ERP Control:OFF       Programmable Priority Output:OFF
NPC Alarm Sync:00
Primary Line:1         Network Address:2016151106 Status:IS
Backup Line:2         Network Address:2016151107 Status:IS

Enter desired action _____
HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE

```

Figure 3-7. FRAME ADMINISTRATION Form



### NOTE:

The subset of possible fields that appear on the FRAME ADMINISTRATION form depends on the **Protocol** that you are using.

### Verification of FRAME ADMINISTRATION Information

When a DACS is restored, the I-2000 queries the DACS for the language, generic, and NPC addressing format as entered on the FRAME ADMINISTRATION form. During this time, the **Site Status** for the DACS is set to QRY (query).

If the DACS and the I-2000 database match, the **Site Status** will change to IS (In Service). If there are differences between the DACS and the I-2000 database or the I-2000 does not receive a response to its queries, the **Site Status** will change to ERR (error). The errors will appear on the STATUS line.

In both the QRY and ERR conditions, the DACS continues to process echo responses and DACS alarms. However, provisioning commands cannot be processed, such as cross connect. Non-provisioning commands, such as reports and passthrough are allowed.

**NOTE:**

If you modify the Type, Protocol, Language, NPC Addressing, Generic, or Line Information on the FRAME ADMINISTRATION form, first remove the DACS from service, enter the modifications, then restore the DACS to service. You must also remove the DACS from service before switching to a backup X.25 link.

**Field Descriptions**

The field values for the FRAME ADMINISTRATION form are described in Table 3-4.

**Table 3-4. FRAME ADMINISTRATION Field Descriptions**

<b>Action</b>	<p>Mandatory. Valid entries are:</p> <p>CREATE Provisions a new DACS in the I-2000 as a <b>Site Name</b> and sets the <b>Site Status</b> to OOS. The frame's database(s) is(are) created.</p> <p>RESTORE Establishes the administrative link to the DACS using the <b>Primary Line</b>.</p> <p>BRESTORE Establishes the administrative link to the DACS using the <b>Backup Line</b> and <b>Network Address</b> specified on the form. If none were specified, the request is denied. Not available for a <b>Protocol</b> of SNIDER.</p> <p>REMOVE Disconnects the virtual administrative link between the I-2000 and the DACS specified in <b>Site Name</b>.</p> <p>DELETE Deletes the DACS and related data from the I-2000 database.</p> <p>MODIFY Changes non-link information of this form when the <b>Site Status</b> is either IS or OOS. For changing line and network data: <b>Type, Protocol, Primary Line, Backup Line, Network Address</b> and <b>Speed</b>, the <b>Site Status</b> must be OOS. The <b>MODIFY Action</b> does not access <b>Site Name</b>.</p> <p>CHGSITE Changes the <b>Site Name</b> for the selected DACS.</p>
<b>Site Name</b>	<p>Mandatory. 1 through <i>n</i> characters (as specified in the <code>SITENAME_SIZE</code> environment variable) from the set A-Z, a-z, 0-9, /, _, and -. All other characters are illegal. Blanks are not allowed within a name.</p> <p>The name of the DACS where the requested <b>Action</b> will take place. Pressing <code>[CHOICES]</code> displays WHICH DACS? with a list of the DACS names. These names were established during frame administration, described in this chapter.</p>

Table 3-4. FRAME ADMINISTRATION Field Descriptions (Contd)

<b>Site Status</b>	<p>The status of the DACS, not user-accessible.</p> <p>IS P For SNIDER. In service.</p> <p>IS n For X.25. In service on line n, where n is P for primary or B for backup. A RESTORE for the DACS referenced in <b>Site Name</b> has successfully been completed and a message has been received saying that this link is on-line. Communications are active.</p> <p>OOS Out of service. Communications are not currently active, either because some portion of the link between the I-2000 and the DACS is down or because the DACS has been created, but has not yet been restored. If the RESTORE <b>Action</b> succeeded, but the DACS is not yet on line, the <b>Site Status</b> will be OOS.</p> <p>UEQD Unequipped. Either a CREATE has never been done for this DACS, or a DELETE was done on it.</p> <p>ALM The DACS has been RESTORED, but the communication to the DACS is not currently active.</p> <p>AS An audit/sync is in progress on this DACS.</p> <p>QRY Query. The DACS is in-service but is in a "query" state. The I-2000 queries the DACS to verify the language, generic, and NPC addressing information. On an X.25 link, the query is in progress. On a SNIDER link, the query is sent when communications are established, which may be some time after the link is placed in service.</p> <p>ERR The information entered through the Frame Provisioning form is inconsistent with the connected DACS or the query for information failed (e.g. timeout). This condition must be corrected before any other commands can be entered into the system. In this condition, the DACS will still continue to process echo responses and DACS alarms.</p>
<b>Type</b>	<p>Mandatory. Specifies the type of DACS.</p> <p>DACS II The frame is a DACS II. The <b>Language</b> must be MML.</p> <p>D II ISX The frame is a DACS II ISX, Releases 1.0 and higher. The <b>Language</b> must be MML.</p>
<b>Protocol</b>	<p>Mandatory. The transmission protocol to be used over the path between the I-2000 and the frame.</p> <p>SNIDER The configuration is direct. You must enter a line <b>Speed</b>.</p> <p>X.25 The configuration is either PDN, or direct, with synchronous modem eliminators (SMEs) in the lines between the frames and the I-2000 computer. In the PDN case, you must enter a <b>Network Address</b> for the primary line and for the backup line if one was configured.</p>

**Table 3-4. FRAME ADMINISTRATION Field Descriptions (Contd)**

<b>Language</b>	<p>Mandatory. Specifies the command language to be used for frame commands generated by the I-2000. You must independently insure that this value conforms to the way the DACS is configured according to "Configuring the DACS" in Chapter 2 "Getting Started."</p> <p>MML            Use HuMan-Machine Language.</p> <p> <b>NOTE:</b> MML is the <i>only</i> language allowed for I-2000 when the <b>Action</b> is CREATE.</p>
<b>NPC Addr</b>	<p>Mandatory. Specifies the type of NPC addressing to be used in DACS commands generated by the I-2000. You must independently insure that this value conforms to the way the DACS is configured according to "Configuring the DACS" in Chapter 2 "Getting Started."</p> <p>HIER            Use hierarchical addressing. EXT3            Use 3-digit extended addressing. EXT4            Use 4-digit extended addressing.</p> <p>For the CREATE <b>Action</b>, this field defaults to the appropriate value for the Type of DACS. The default for DACS II ISX is EXT3, which also is the only valid choice for those systems. Changing to some other value will prevent the I-2000 from communicating properly with the DACS.</p>
<b>Location</b>	<p>Optional. Up to 13 characters. States the physical location of the DACS. An informational field only.</p>
<b>Generic</b>	<p>Mandatory. Up to eight printable characters. The first must be numeric. States the DACS software release number of DACS II or DACS II ISX software running at <b>Site Name</b>.</p> <p>For release 7 of DACS II, the entry 7.0 is required. This field distinguishes between releases prior to 7, release 7, and subsequent releases. The I-2000 supports NPC type PA only beginning with release 7.</p> <p>For DACS II ISX, only Release 1.1 and higher support the nxDS0 test access feature.</p>
<b>ERP Control</b>	<p>The selection or nonselection of conditional echoed response processing for this DACS.</p> <p>ON              Process NPC and circuit echoed response messages only on condition that all NPCs cited in the message are already in the I-2000 database.</p> <p>OFF             Process echoed response messages unconditionally. The default, if the <b>Action</b> is CREATE.</p>

Table 3-4. FRAME ADMINISTRATION Field Descriptions (Contd)

<b>Alarm Sync</b>	<p>The selection or nonselection of NPC alarm synchronization for this DACS.</p> <p>00 Do not update the I-2000 database with information concerning the DACS's current alarms when the <b>Site Status</b> becomes IS, IS P or IS B.</p> <p>nn Provided nn hours have elapsed, when the <b>Site Status</b> becomes IS, IS P or IS B again, query the DACS and update the <b>Alarm State</b> information for the DACS. For more information, refer to Chapter 4 "NPC Provisioning."</p>
<b>Programmable Priority Output</b>	<p>This field allows you to specify whether to activate/deactivate the Programmable Priority feature. When an NPC or another hardware component goes down, there are many DACS alarm messages that are generated and queued based on the order they are received. When Programmable Priority is set to "ON", any MML command entered from the DACS with the keyword "PRIOUT" is automatically prioritized and placed before other messages in the DACS queue. This request only impacts the order of the output and does not change the execution of commands.</p> <p>This option can be specified on a frame-by-frame basis. The values are:</p> <p>OFF            Default value. ON             Activates this feature on a frame-by-frame basis.</p> <p> <b>NOTE:</b> This field is only available for DACS II, Release 7.0 and later.</p>
<b>Primary Line</b>	<p>The number of the line that will be used for communication between the I-2000 computer and the network or DACS in the case of the X.25 configuration, or between the I-2000 computer and the DACS in the case of the SNIDER configuration. This link must be In Service (<b>Status</b> of IS, see LINK PROVISIONING).</p> <p><b>For X.25</b>      One numeric character. Enter the physical line number of the primary connection. Valid entries are one through four times the number of X.25 boards.</p> <p><b>For SNIDER</b> Two numeric characters. Enter the tty port number on the I-2000 ports card for this connection, provided that the line has not been restored as a login port.</p>

**Table 3-4. FRAME ADMINISTRATION Field Descriptions (Contd)**

<b>Backup Line</b>	<p>X.25 only. The number of the line to be used as the backup path from the I-2000 computer to the network. This link must be IS.</p> <p>Specifying the same line as in <b>Primary Line</b> means that you are making the primary and backup links to the network the same; for example, no backup.</p>
<b>Network Address</b>	<p>Appears only for a <b>Protocol</b> of X.25. A maximum of 16 numeric characters. For a primary line, this field contains the PDN address for the X.25 connection to the DACS. For a backup line, this field contains the PDN address for the backup line. The address specifies the link from the network to the DACS.</p> <p>Specifying the same address for primary and backup lines means that you are making the primary and backup links the same; for example, no backup.</p>
<b>Status</b>	<p>A display-only field, which can appear twice, once for the primary line and once for the backup line. It displays the status of the link associated with the <b>Network Address</b>. The <b>Status</b> can be IS or OOS.</p>
<b>Speed</b>	<p>Values are 1200, 2400, 4800, and 9600. The baud rate for this I-2000 SNIDER port. You must independently insure that this value conforms to the way the DACS is configured according to "Configuring the DACS" in Chapter 2 "Getting Started." This field only appears if the <b>Protocol</b> is SNIDER.</p>

### **To Create and Restore a Frame**

The procedures below describe how to create and restore a DACS using either the X.25 or SNIDER protocol.

#### **Procedure: Creating and Restoring a Frame, X.25 Administration**

To create and restore a DACS on the X.25 network, follow these steps:

1. Obtain the FRAME ADMINISTRATION form, as shown in Figure 3-8.

```
06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- FRAME ADMINISTRATION -----
Action:CREATE          Site Name:EREWHON          Site Status:UEQD
Type:DACS II          Protocol:X.25              Language:MML
NPC Addr:HIER         Location:1F-11            Generic:7.0
ERP Control:OFF       Programmable Priority Output:OFF
Alarm Sync:00
Primary Line:1        Network Address:6174536499  Status:IS
Backup Line:2         Network Address:6174536500  Status:IS

Enter desired action _____

HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE
```

**Figure 3-8. Creating a Frame Using X.25**

2. Fill in the following fields:
  - **Action:** CREATE
  - **Site Name:** EREWHON
3. After you enter the **Site Name**, the **Site Status** changes to UEQD, provided the site is not already provisioned. If it is provisioned, the provisioning information is filled into the appropriate fields. Verify that the **Site Status** is UEQD.
4. Then fill in the following fields:
  - **Type:** DACS II
  - **Protocol:** X.25
5. After you enter the **Protocol**, the fields for specifying the **Primary Line** and **Backup Line** appear.
6. Fill in the following fields:
  - **Language:** MML
  - **NPC Addr:** HIER
  - **ERP Control:** OFF

- **NPC Alarm Sync:** 00
- **Programmable Priority Output:** OFF
- **Primary Line:** 1

7. After you enter the **Primary Line**, the **Network Address** field appears and the **Status** changes to the status of the link from the network to the DACS. Fill in the following fields:

- **Network Address:** 6174536499
- **Backup Line:** 2

8. The backup line **Network Address** field appears and the **Status** changes to the associated status. Enter:

- **Network Address:** 6174536500

9. Press **EXECUTE** and answer YES to ARE YOU SURE?

The provisioning request is sent to the DACS. When the DACS is successfully provisioned:

- The **Site Status** changes to OOS.
- The command completed successfully message is displayed.

10. Change the **Action** to RESTORE, press **EXECUTE** and verify.

When the DACS is in service:

- The **Site Status** changes to IS P.
- The I-2000 **Status** field displays: Primary link 1 is on for site EREWHON
- The command completed successfully message is flashed.

11. To place the DACS in service on the backup path, you would enter an **Action** of BRESTORE. The **Site Status** would become IS B. The I-2000 **Status** field would display: Backup link 2 is on for site EREWHON.



**NOTE:**

The command completed successfully message indicates that the I-2000 has successfully started all processes involved with servicing that DACS. It does not necessarily indicate that communication was successfully established. If communications are not established, the **Site Status** will display ALM. When the connection has been established, the I-2000 notifies all users and makes an entry in the I-2000 Alarm Log. You can view the log by pressing **Ctrl** + **a**, or you can view the **Site Status** in a FRAMES/LINKS report, selected from the REPORT OPERATIONS MENU.

The **Site Status** of a successfully linked DACS will be IS P or IS B; of an unsuccessfully, OOS.



### Procedure: Creating and Restoring a Frame, SNIDER Administration

To create and restore a DACS with a direct link and place it in service, follow these steps:

1. Obtain the FRAME ADMINISTRATION form. An example of the FRAME ADMINISTRATION form is shown in Figure 3-10.

```
06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:

----- FRAME ADMINISTRATION -----
Action:CREATE          Site Name:SHANGRILA      Site Status:UEQD
Type:DACS II          Protocol:SNIDER          Language:MML
NPC Addr:HIER         Location:1F-11          Generic:7.0
ERP Control:OFF       Programmable Priority Output:OFF
Alarm Sync:00
Primary Line:01       Speed:4800

Enter the type of frame _____

HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE
```

**Figure 3-10. Creating a Frame, Using SNIDER**

2. Fill in the following fields:
  - **Action:** CREATE
  - **Site Name:** SHANGRILA
3. After you enter the **Site Name**, the **Site Status** changes to UEQD, provided the site is not already provisioned. If it is provisioned, the provisioning information is filled into the appropriate fields. Verify that the **Site Status** is UEQD. Then fill in the following fields:
  - **Type:** DACS II
  - **Protocol:** SNIDER

4. After you enter the **Protocol**, the fields for specifying **Primary Line** and **Speed** appear. Fill in the following fields:
  - **Language:** MML
  - **NPC Addr:** HIER
  - **ERP Control:** OFF
  - **NPC Alarm Sync:** 00
  - **Programmable Priority Output:** OFF
  - **Primary Line:** 1
  - **Speed:** 4800
5. Press **EXECUTE** and answer YES to ARE YOU SURE? The provisioning request is sent to the DACS. When the DACS is successfully provisioned:
  - The **Site Status** changes to OOS.
  - The command completed successfully message is displayed.
6. Change the **Action** to RESTORE, press **EXECUTE**, and verify. When the DACS is in service:
  - The **Site Status** changes to IS.
  - The command completed successfully message is displayed.

### **Procedure: Unprovisioning a Frame in X.25 or SNIDER**

To take a DACS out of service on a network or direct link, and remove it from the database (unprovision), follow these steps:

1. Obtain the FRAME ADMINISTRATION form.
2. Fill in the following fields:
  - **Action:** REMOVE
  - **Site Name:** UTOPIA

As soon as you enter a valid **Site Name**, the fields are filled in.

3. Press **EXECUTE** and answer YES to ARE YOU SURE?
  - The **Site Status** changes to OOS.
  - The I-2000 **Status** field displays one of the following two messages, depending on whether the primary or backup link was in service:
    - Primary link 1 is off for site UTOPIA
    - Backup link 2 is off for site UTOPIA
  - The command completed successfully message is displayed.

4. Change the **Action** to DELETE.
5. Press **EXECUTE**. Along with the ARE YOU SURE? insert, a message is displayed:

```
WARNING! You are about to delete a DACS database
from I-2000
```
6. Acknowledge by pressing **Enter**; then answer YES to ARE YOU SURE?.
  - The **Site Status** changes to UEQD.
  - The command completed successfully message is displayed.

### **Changing The I-2000 Name**

---

Release 5.0 and higher of the I-2000 provides the capability to change the name of the I-2000. This name will be placed on the tape of a database backup and will be displayed when the database is restored. The change can be performed by the System Administrator from the I-2000 user interface.

The same character set for the **Site Name** also applies to the I-2000 name. Valid entries for this field are A-Z, a-z, 0-9, /, \_ , and -. All other characters are illegal. Blanks are allowed within a name, but leading and trailing blanks are ignored.

#### **Procedure: Changing the I-2000 Name Using the I-2000 User Interface**

This procedure enables you to change the I-2000 name using the I-2000 user interface.



**NOTE:**

This feature is available *only* to system administrators.

To change the I-2000 name using the I-2000 user interface, follow these steps:

1. Select NAME CHANGE from the SYSTEM ADMINISTRATION menu. An example of the I-2000 NAME CHANGE form is shown in Figure 3-11.

```
06:15 01 Nov 1997  I-2000 Controller Release x.x for DACS-II
State:
Alarms:
      I-2000 NAME CHANGE
Current I-2000 Name: CENTRAL NJ
New I-2000 Name:     CENTRAL NJ -- 1
Enter 23 character new I-2000 name.
```

HELP [ ] [ ] QUIT [ ] TOP MENU PRINT EXECUTE

**Figure 3-11. I-2000 NAME CHANGE Form**

2. The current I-2000 name is displayed in the **Current I-2000 Name** field. Enter the new I-2000 name in the **New I-2000 Name** field.
3. Press **EXECUTE**. A confirmation message is displayed.
4. Acknowledge by pressing **Enter**; then answer YES to ARE YOU SURE?
  - The command completed successfully message is displayed.
  - Or
  - The command can be denied if no new name is specified or an invalid new name is specified.

## PRINTER ADMINISTRATION

This selection is reserved for system administrators. However, if you are in operator status, you can use TASK ADMINISTRATION selections (refer to Chapter 11 "Task Administration") to list or cancel your own print jobs.

The I-2000 supports printing of screens, DACS output, and reports.

Printing is multiplexed and spooled so that users can queue their jobs to the print service, to be sent to the printer one by one.

The **Actions** of the PRINTER MANAGEMENT form do not actually print the reports and screens; that is done under the REPORTS selections, and by pressing the **PRINT** key for screens that offer the option of screen printing. The PRINTER MANAGEMENT **Actions** allow you to enable or disable the printer, to list and cancel print jobs and to allow printer logging of the alarm or other output from one or more DACSs.

The PRINTER MANAGEMENT **Actions** allow you to:

- enable or disable the printer,
- list and cancel print jobs
- allow printer logging of the Alarm Messages or DACS Messages from one or more DACS.

### Field Descriptions

The field values for the PRINTER MANAGEMENT form are listed in Table 3-5..

**Table 3-5. PRINTER MANAGEMENT Field Descriptions**

<b>Action</b>	Mandatory. Enter the action to be performed with regard to the printer job.
	ENABLE            Select ENABLE to enable the printer.
	DISABLE         Select DISABLE to disable the printer.
	LIST             Select LIST to display the printer queue.
	CANCEL          Select CANCEL to cancel any printer job.
	LOGALL          Select LOGALL to log the DACS output messages to the printer.
	LOGALARMS      Select LOGALARMS to log the DACS alarm messages to the printer.
	STOPLOGGING    Select STOPLOGGING to cancel message logging.
<b>Printer Name</b>	Press <b>CHOICES</b> when the cursor is in the <b>Printer</b> field to display the available printers. Use the display to select a printer.
<b>Printer Status</b>	The status of the printer.

### **Procedure: Viewing Printer Management**

---

To view PRINTER MANAGEMENT actions, follow these steps:

1. Select PRINTER ADMINISTRATION from the SYSTEM ADMINISTRATION menu. The PRINTER MANAGEMENT form is displayed, as shown in Figure 3-12.

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II  
Status:  
Alarms:

PRINTER MANAGEMENT

Action:	Printer Name: CONSOLE PRINTER
Printer Status: DISABLED	
Site Name:	Logging Status: OFF

Enter the desired action \_\_\_\_\_

HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE

**Figure 3-12. PRINTER MANAGEMENT Form**

The **Site Name** and **Logging Status** are shown only for **Actions** of LOGALL, LOGALARMS and STOPLOGGING. Also for those **Actions**, the **Printer Name** is display-only, and cannot be modified by the user.

2. Select a site. The cursor moves to **Action** automatically.
3. Press **[CHOICES]**. The PRINTER MANAGEMENT **Actions** are listed:
  - ENABLE: PRINTER
  - DISABLE: PRINTER
  - LIST: PRINTER JOBS
  - CANCEL: PRINTER JOBS
  - LOGALL: DACS MESSAGES
  - LOGALARMS: ALARM MESSAGES
  - STOPLOGGING: MESSAGES

### **Procedure: Enabling a Printer**

---

The `ENABLE` **Action** turns on the printer for print service. Before any printing can occur, you must enable the printer.

To enable the printer, follow these steps:

1. Obtain the `PRINTER MANAGEMENT` form.
2. Select an **Action** of `ENABLE` from the `CHOICES` menu.
3. Select a **Printer Name** from the `CHOICES` menu.
4. Press `EXECUTE`.
  - The **Printer Status** field changes to `ENABLED`.
  - `Printer now enabled` message is displayed.

### **Procedure: Disabling a Printer**

---

The `DISABLE` **Action** turns the printer off.

To disable the printer, follow these steps:

1. Obtain the `PRINTER MANAGEMENT` form.
2. Select an **Action** of `DISABLE` from the `CHOICES` menu.
3. Select a **Printer Name** from the `CHOICES` menu.
4. Press `EXECUTE`.
  - The **Printer Status** field changes to `DISABLED`.
  - `Printer now disabled` message is displayed.

### **Procedure: Displaying Print Jobs Queued**

---

To display a list of the print jobs that are queued to the printer, follow these steps:

1. Obtain the `PRINTER MANAGEMENT` form.
2. Select an **Action** of `LIST` from the `CHOICES` menu.
3. Select a **Printer Name** from the `CHOICES` menu.
4. Press `EXECUTE`.

A chronological list of the queued print jobs for all users is displayed. The list reflects the status of the queue at the time you execute `LIST` or select `JOB STATUS`, but the jobs continue to be processed.

The list includes the following information for each job in the queue:

- job number
- print request originator
- file size

5. To return to the PRINTER MANAGEMENT form, press **QUIT**.

If no jobs are on the queue, a message is displayed:

No jobs queued to the printer.

An example of a printer queue is shown in Figure 3-13.

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II  
Status:  
Alarms:

PRINTER MANAGEMENT

Action:LIST Printer Name:CONSOLE PRINTER

Printer Queue

Job no.	User	Size
16	root	5
17	rootadm	6

Page 1 of 3 Display Page:1

Enter the page number

HELP NEXTPAGE PREVPAGE QUIT TOP MENU PRINT

Figure 3-13. Sample Print-Job Status

### Procedure: Removing Prints Jobs Queued

To remove a print job from the queue, follow these steps:

1. Obtain the PRINTER MANAGEMENT form.
2. Select an **Action** of CANCEL from the **CHOICES** menu.
3. Select a **Printer Name** from the **CHOICES** menu.
4. Press **EXECUTE**. The jobs are listed as for the **LIST Action**. However, an additional field, **Cancel**, appears before **Job No.**
5. Using **Enter**, move the cursor to the beginning of the line for the job you wish to cancel and type an **x** or **X**.
6. Press **CANCEL**.



**NOTE:**

If the cursor remains on **Display Page**, you are in `LIST` rather than in `CANCEL`. Press `QUIT` and enter `CANCEL` as an **Action**.

### **Procedure: Printing/Stop Printing Output or Frame Alarms**

---

To print or stop printing the output or alarms of a DACS, follow these steps:

1. Obtain the `PRINTER MANAGEMENT` form.
2. Enter one of the following **Actions**:
  - `LOGALL` To print a log of all output from the **Site Name** you select.
  - `LOGALARMS` To print a log of only the alarms issued by the **Site Name** you select.
  - `STOPLOGGING` To stop printing the log of output or alarms for the **Site Name** you select.
3. Enter the **Site Name** of the DACS from which you wish to log all output or alarms only.
  - Depending on the **Action** you chose, the **Logging Status** indicates `ALL`, `ALARMS`, or `OFF`.
  - The `command completed successfully` message is displayed.
4. To print or stop printing the output or alarms from another site, perform the previous steps again, changing the **Site Name**.

The print buffer holds one page at a time; that is, it does not print until it contains one page (66 lines). A separate page buffer is maintained for each DACS.

### **Procedure: Enabling/Disabling Banner Page**

---

To enable/disable the banner page printed before each output, follow these steps:

1. Log into the I-2000 Controller system as **dacsadm**.
2. The system will display the following message:

```
Do you want to escape to unix?
```
3. Type **y** to go to the UNIX environment.
4. The system will display the following message:

```
Do you want to start windows?
```
5. Type **n**. You are now placed in the UNIX environment.
6. Type **vi /etc/printcap**.
7. Edit the second line in the file. (To disable printing the banner page, the **:sh** should be present as shown below. To enable printing the banner page, remove the **:sh**.)

```
:br#9600:tr=\f:lf=/usr/adm/lpd-errs:sf:sh:if=/usr/ems/bin/epson_if
```

8. Exit from vi.
9. Log off by typing **exit**, if necessary.

### **Procedure: Enabling/Disabling Form Feed**

---

To enable/disable the form feed initiated before each output, follow these steps:

1. Log into the I-2000 Controller system as **dacsadm**.
2. The system will display the following message:  
Do you want to escape to unix?
3. Type **y** to go to the UNIX environment.
4. The system will display the following message:  
Do you want to start windows?
5. Type **n**. You are now placed in the UNIX environment.
6. Type **vi /etc/printcap**.
7. Edit the second line in the file. To disable printing the banner page, type **:sf** as shown below. To enable printing the banner page, remove the **:sf**.

```
:br#9600:tr=\f:lf=/usr/adm/lpd-errs:sf:sh:if=/usr/ems/bin/epson_if
```

8. Exit from vi.
9. Log off by typing **exit**, if necessary.

## **SHUTDOWN**

---

The I-2000 system can be shutdown immediately, or you can specify a time DACS from one to 10 minutes.


To shutdown the I-2000 system, follow these steps:

1. From the SYSTEM ADMINISTRATION menu, select SHUTDOWN to power down the I-2000. The SHUTDOWN TIME pop-up menu is displayed, as shown in Figure 3-14.



#### **CAUTION:**

*Do not remove power from the I-2000 without selecting SHUTDOWN. Important files may be damaged or corrupted.*



**Figure 3-14. SHUTDOWN TIME Pop-up Menu**

2. From the SHUTDOWN TIME pop-up menu, select the appropriate value:

QUIT	Do not execute a shutdown.
IMMEDIATE	Shut down immediately.
1 MINUTE	Shut down after 1 minute.
5 MINUTES	Shut down after 5 minutes.
10 MINUTES	Shut down after 10 minutes.
NO	Do not execute a shutdown.

3. If you selected the 1, 5 or 10 minute options, at intervals of 1 minute, a command line message appears at the bottom of the screen:

```
SHUTDOWN STARTING IN X MINUTES
```


4. A **Status** message is broadcast to every terminal:

```
SYSTEM GOING DOWN IN X MINUTE(S), PLEASE LOG OFF
```

5. At the end of the last minute, the **Status** displays:

```
SYSTEM GOING DOWN, PLEASE LOG OFF NOW
```

6. The SHUTDOWN TYPE pop-up menu is displayed, as shown in Figure 3-15.



**Figure 3-15. SHUTDOWN TYPE Pop-up Menu**

7. From the SHUTDOWN TYPE menu, select the appropriate value.

QUIT	Do not execute a shutdown.
SHUTDOWN	Shut down the computer and the I-2000. This is done as preparation for powering down the computer.
REBOOT	Shut down and restart the computer and the I-2000.
I-2000 REBOOT	Shut down and restart only the I-2000. The workstation continues to run; only the I-2000 software restarts.
I-2000 UPDATE	Shut down only the I-2000, update the port information in the I-2000 database and restart. This procedure compares the hardware configuration to the I-2000 database and, if required, modifies to I-2000 database. The <b>/etc/passwd</b> is updated from the I-2000 database.
NO	Do not execute a shutdown.

8. If you selected `QUIT` or `NO`, the following **status** message is displayed:

```
SYSTEM SHUTDOWN HAS BEEN ABORTED
```

9. If you chose any of the shutdown selections, the I-2000 **Status** now changes to:

```
SYSTEM SHUTDOWN IS NOW IN PROGRESS
```

A number of messages will be displayed as the I-2000 shuts down. When the software has finished shutting down, follow the established policy regarding turning off the hardware or leaving it on.

## DATE and TIME

---

Occasionally, it may be necessary to reset the I-2000 computer date and time. Be sure to notify the users that you are going to reset the date and time.



**NOTE:**

Setting the Data and Time *must* be done from the console.

The reset of the I-2000 date and time may affect time-dependent activities, such as the execution of scheduled tasks, and timeouts on commands to a DACS, as well as on terminating passthrough sessions, or other tasks. We suggest that you shut down and restart immediately after resetting the date and time, so that all time parameters also will be reset.

### Procedure: Setting the Date and Time

---

To set the date and time on the I-2000 computer, follow these steps:

1. Select `DATE AND TIME` from the `SYSTEM ADMINISTRATION` menu. The `DATE and TIME ADMINISTRATION` form is displayed, as shown in Figure 3-16.

```
06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- DATE and TIME ADMINISTRATION -----
                Hour:                Minute:
                Day:                  Month:
                Year:
----- Enter the desired hour [0-24] -----
HELP  [ ]  [ ]  QUIT  [ ]  [ ]  TOP MENU  PRINT  EXECUTE
```

**Figure 3-16. TIME and DATE ADMINISTRATION Form**

2. Enter the desired hour, 0-24. Either 24:00 or 00:00 is accepted.

⇒ **NOTE:**  
An initial 0 is not necessary, but if you omit it, you need to press **Enter**.

3. Enter the minute, 00-59.

⇒ **NOTE:**  
After 24:00, go to 00:01.

4. Enter the day, 1-31.

5. Enter the first three letters of the month: Jan, Feb, Mar . . . Dec.

⇒ **NOTE:**  
Case is irrelevant.

6. Enter all four digits of the year. The range is 1990 through 2038.

7. Press **EXECUTE**.

- The new date and time appear on the screen.
  - The command completed successfully message is displayed.
8. Perform SHUTDOWN and restart so that the new time and date will be reflected by automatic functions that use them.

## **SYNCHRONIZE FRAME DATE & TIME**

---

### **Procedure: Synchronizing Frame Date & Time**

---

To change the time on one DACS to the I-2000 time, follow these steps:

1. Select SYNCHRONIZE FRAME DATE & TIME from the SYSTEM ADMINISTRATION menu.
2. The WHICH DACS? prompt and the list of DACSs appears in an insert. Select the desired DACS, confirm and press **Enter**. The I-2000 sends a time and date command to the DACS.

The command is successful if the frame time is set to within one second of the I-2000 time. A message, *The command completed successfully*, means that the time has been successfully reset.

A failure can happen when the frame is too busy to respond to the I-2000 within one second of the request: for example, during backup-memory transfers, error recovery, and other maintenance conditions. If a failure occurs, you will get a message, *Frame time is within X seconds of local time*, which is displayed in a pop-up window, and requires you to press **Enter**.

The time has been reset, but not to within one second.

A third possibility is that the I-2000 cannot complete the synchronization. In that case, an explanation of denial is displayed in the pop-up window.

If the time synchronization fails, try to reset again.

---

## Contents

<b>Introduction</b>	4-1
■ Types of NPCs	4-2
■ Modifying NPC Provisioning	4-5
■ I-2000 Supported NPC Addressing Schemes	4-6
<b>NPC PROVISIONING Form</b>	4-8
■ Procedure: Provisioning an NPC	4-8
Field Descriptions	4-14
Performance Monitoring Fields	4-22
<b>NPC Provisioning Examples</b>	4-25
■ Creating an NPC and Placing It in Service	4-26
■ Example: Creating a CEPT NPC	4-26
■ Procedure: Creating an NAS NPC	4-27
■ Example: Creating an NPC as a Subrate Type	4-28
■ Example: Creating an NPC Using DMB Multipoint	4-29
■ Example: Removing an NPC	4-29
■ Example: Deleting an NPC	4-30
■ Example: Querying an NPC	4-30
■ Example: Browsing NPCs	4-34
<b>NPC Provisioning ERP</b>	4-35
■ Procedure: Disabling Echoed Responses	4-37

### Introduction

---

Network Processing Circuits (NPCs) must be provisioned before circuits can be created. Provisioning takes place on two different levels:

- **Physical Provisioning**—This level is beyond the scope of this manual, and must already have taken place before the I-2000 can be operational.

In physical provisioning, individual lines are brought to a frame and are terminated there by circuit cards. A line can be ultimately thought of as a signal carried by a single telephone or computer wire. When signals are multiplexed together and are carried by a single cable or other transmission path, they become channels.

Cross-connects between channels within the circuit cards are made under computer control. Each card is intelligent, has its own memory, and responds to direction by the frame computing system.

- **Logical Provisioning**—This level is the concern of PROVISIONING in the I-2000.

In provisioning NPCs you are providing the I-2000 with the operational characteristics of the pertinent NPCs. You are making the channels in these NPCs known to the I-2000, so that it can send HuMan Machine Language (MML) commands to the DACS to cross-connect them.

The unit of cross-connection is typically the channel. For example, the 1.544 megabits per second (Mbps) of a Digital Signal 1 (DS1) signal becomes 24 channels of 64 kilobits per second (Kbps) under the North American Standard (NAS). The channel has a width of 8 bits, or one byte. All 8000 bytes per second being transmitted over this channel belong to the same customer.

You are the agent that provisions NPCs and cross-connects their channels. The I-2000 is only your means of doing so. You use the I-2000 by entering values in the NPC PROVISIONING **Action** field and executing that form.

The major I-2000 logical provisioning **Actions** are `CREATE` and `RESTORE`, `REMOVE` and `DELETE`. These **Actions** are based on the DACS concepts of "provision" and "place in service," "remove from service," and "unprovision."

In the DACS, provisioning is a process called growing the NPC. During provisioning, data concerning the NPC that is being made available is stored in the DACS database. The command to grow an NPC in MML is `CRTE-EQPT`.

In the I-2000 software, the `CREATE` **Action** performs a similar, but enhanced function. The `CREATE` **Action** stores NPC information in either or both of the I-2000 and DACS databases, depending on which one(s) you select. For more information about the `RECNCILE` key, refer to Chapter 2 "Getting Started." To change a DACS database, the I-2000 typically generates one or more `GRTH` or `CRTE` commands to the DACS, possibly supplemented by a `CHG` command for some of the options.

The opposite command, `DGRTH` or `DISC`, de-grows the NPC, or removes it from the DACS database. De-growth has been expanded into the `DELETE` **Action**.

In a DACS, a grown NPC must be placed in service, or restored, before it can be utilized in cross-connection. The `RST` command tests and initializes various hardware parameters associated with the NPC, and leaves it ready for cross-connection.

In the I-2000, the restore concept is expanded into the `RESTORE` **Action**. On the I-2000 side, restoral means little more than that the NPC is marked restored in the I-2000 database. A `RESTORE` **Action** applied to both the I-2000 and DACS or just to the DACS generates one or more `RST` commands.

The opposite command, `RMV`, is expanded into the I-2000 `REMOVE` **Action**, which again affects either or both I-2000 and DACS databases. In the case of both or just DACS, `REMOVE` generates one or more `RMV` commands.

The information to generate the parameters for these various commands are typically taken from the fields on the I-2000 forms. A person knowledgeable in DACS concepts will have no trouble discerning the associations between field values and parameters. However, discerning such associations is not necessary; you can work entirely within I-2000 concepts. Informational fields, which do not affect either the I-2000 or the DACS, are also included.

## Types of NPCs

---

For the DACS II, the type of channel available to you depends on the facility hardware that supports it. Vanilla-flavored NPCs are provided by dual digroup cards for NAS provisioning or dual primary circuits for CEPT provisioning. One Dual Digroup Card (DDC) or Dual Primary Circuit (DPC) terminates two NPCs of digitally multiplexed Digital Signal 0 (DS0) signals. An NPC is a digroup, or two groups of 12 channels in NAS transmission or 32 channels in CEPT transmission. DDCs and DPCs are used in *n* DS0 cross-connects, one-way or two-way.

The DS3 shelf containing various Digital Signal 3 (DS3) circuit packs, such as the KCR1 Multiplexer, provides 28 DS1-level signals per DS3 multiplexer card. These are available as 28 clear DS1 signals or 672 DS0-level channels.

A virtual multipoint circuit requires connection to a virtual node, which is one or more “conferences” in a virtual NPC. As the term virtual implies, a virtual NPC is not a real NPC, provided by hardware; instead, it is a software emulation. Its use is covered under virtual broadcast (or virtual multipoint) circuits in Chapter 6 “Circuit Provisioning.”

Virtual NPCs are created automatically during installation. By default, the I-2000 initializes all DACSs to six virtuals, regardless of type of DACS. On the DACS II Capacity Expansion Frame (CEF), you may use all six. On the non-CEF DACS II, you may use only two, and none on the DACS II ISX Release 1.0. However, this restriction should not present a problem, as the number of channels available in only one virtual NPC is 500.

Virtual NPCs are defined with **NPC IDs** of VIRTUAL1, VIRTUAL2, etc., and are always in service. They are not associated with any one **Type**. They cannot be accessed through the NPC PROVISIONING form, except during the **BROWSE Action**.

The Digital Multipoint Bridge (DMB) card supports DMB multipoint circuits, which are not the same as the virtual multipoint described under the **Ckt Class** field in Chapter 6 “Circuit Provisioning.” In these circuits, a DMB NPC is used as a branch point instead of a virtual node, and the cross-connections are two-way. DMB NPCs are located in the DSPU shelf. For additional information, refer to Chapter 6 “Circuit Provisioning” and the DACS II Operation and Maintenance Manual.

The specification of a DMB NPC requires a few additional fields on the NPC PROVISIONING form. A DMB provides redundant NPCs, so that any NPC number *n* accesses one of two duplicate NPCs, Side 0 or Side 1. The **SIDE** field appears on the screen in the appropriate circumstances, when you must select a side. Also, the DMB circuit pack is duplexed, requiring the growth of two NPCs at a time, one of which is termed here the upper NPC.

The type of NPC is specified by the first two letters of the **Type** field value on the NPC PROVISIONING form.

Not every type of NPC is available for every type of DACS; for example, the **Type** field value of NPC PROVISIONING depends on the **Type** field value of FRAME PROVISIONING (refer to Chapter 3 “System Administration”).

The NPC **Types** are correlated in Table 4-1.

Table 4-1. NPC Provisioning Types

	PB	PC	PA	DC	DE	TE	DA	TA	MB	SR	SD	MJ	Virtual
<b>DACS II before Release 6.0</b>	X	X			X	X			X	X		X	X
<b>DACS II, R6.0 to Release 8.0</b>	X	X	X		X	X	X	X	X	X		X	X
<b>DACS II Release 8.2 and higher</b>	X	X	X		X	X	X	X	X	X	X	X	X
<b>DACS II ISX Release 1.0 and higher</b>			X				X				X*		

\* Applies only to SD111 and DACS II ISX Release 2.0 or higher with X.50 subrate application.

I-2000 supports X.50 subrate cross-connect provisioning for DACS II ISX; it does not fully support the other DSP applications. DSP NPCs can be created using the NPC PROVISIONING form, however circuits on DSP NPCs cannot be provisioned from the I-2000. The same support applies for echoed response processing. The following table summarizes the supported activities for the available DSP applications and the associated echoed response processing.

Table 4-2. Supported Activities for DSP Applications and Echoed Response Processing

DSP	DACS II	DACS II ISX
SD411 (x.50)	NPC provisioning	NPC provisioning and circuit provisioning
SD111 (DDS)	NPC provisioning	NPC provisioning
SD311 (DMB)	NPC provisioning	NPC provisioning

**NOTE:**

I-2000 does not support TE/TH type NPCs as provided by the HYbrid DS3U feature of DACS II Release 8.0 and higher. Echoed response processing for provisioning of Hybrid DS3U equipment is discarded by the I-2000.

**Modifying NPC Provisioning**

Circuits on some types of NPC are not compatible with circuits on other types. As a result, a MODIFY of the NPC PROVISIONING form for an in-service NPC can only change the **Type** field to certain other values, which are listed in Table 4-3.

Table 4-3. **Valid Old/New Types for a MODIFY Action**

<b>Old</b>	<b>New</b>	PB	PC	PA	Clear PA	DE	Clear DE	DA	Clear DA	TE	Clear TE	TA	Clear TA
PB		X		X									
PC			X	X									
PA		X	X	X									
Clear PA					X								
DE						X		X					
Clear DE							X		X				
DA						X		X					
Clear DA							X		X				
TE										X		X	
Clear TE											X		X
TA										X		X	
Clear TA											X		X

The NPC PROVISIONING form provides fields based on the NPC type. You can change one or more of the parameters that appear on the form. If an error occurs when you execute the command, the command stops and a message appears in the Command Response window. The NPC parameters are processed in the following order: NPC ID (local database update only), Alarm Aging (local database update only), Type, IW, AIS, TSO, TSOM, NFS, and PM options.

If you attempt to **MODIFY** the **Type** for an NPC, be aware of the following:

- The DACS may deny certain changes based on the **Service State** of the NPC and the type of modification. In this case, you may want to delete the NPC and create it again with the new type.
- When you choose the **MODIFY** action, the default for the **Service State** field is In-Service (IS). If any part of the command fails, the NPC remains in service. If you set the Service State to Out of Service (OOS), the NPC may be removed from service in order to make the modifications and traffic may be interrupted. When the command completes, the NPC will be restored to service.
- NPC provisioning parameters are based on NPC type. If you change the NPC type, the NPC parameters may change also. Any new parameters will be given default values.

## **I-2000 Supported NPC Addressing Schemes**

---

Channels are identified by channel numbers within an NPC. NPCs are identified by one of two numbering schemes: hierarchical or extended. The hierarchy is a logical hierarchy: NPC identifier within module identifier within shelf identifier. The extended scheme simply offers a set of sequential numbers.

The DACS can be set to recognize either numbering scheme. This type of DACS configuration is a software operation and is performed just after installation or when the need arises. Refer to Chapter 2 "Getting Started" for the procedure. After the DACS has been configured, you must inform the I-2000 which scheme is going to be in use. Refer to "Frame Administration Selection" in Chapter 3 "System Administration."

 **NOTE:**  
The DACS configuration **must** match the I-2000 setting.

Extended numbers in the DACS can be 3-digit or 4-digit, and the FRAME ADMINISTRATION form requires you to make this distinction. The 4-digit numbers apply to a CEF frame; on a non-CEF frame, the numbers do not run as high as 4 digits. I-2000 forms accept 4 digits in all cases and truncate the initial 0 if necessary. Remember, the I-2000 accepting a number does not insure that the DACS will accept it; if the DACS does not, the **Action** is denied. The DACS will not accept a number for an NPC that does not exist.

The I-2000 displays both hierarchical and extended NPC numbers. If you only enter one, the I-2000 obtains the other also, by conversion. The conversion algorithm depends on the type of NPC. To find out what the equivalencies are, refer to [Tables 4-4 through 4-6](#).

**Table 4-4. NPC Number Equivalents for DACS II FTU-type Units**

Extended	Hierarchical	Extended	Hierarchical
0001 to 0160	01101 to 01440	1761 to 1920	12101 to 12440
0161 to 0320	02101 to 02440	1921 to 2080	13101 to 13440
0321 to 0480	03101 to 03440	2081 to 2240	14101 to 14440
0481 to 0640	04101 to 04440	2241 to 2400	15101 to 15440
0641 to 0800	05101 to 05440	2401 to 2560	16101 to 16440
0801 to 0960	06101 to 06440	9961	99101
0961 to 1120	07101 to 07440	9962	99102
1121 to 1280	08101 to 08440	9963	99103
1281 to 1440	09101 to 09440	9964	00104
1441 to 1600	10101 to 10440	9965	99105
1601 to 1760	11101 to 11440	9966	99106

**Table 4-5. NPC Number Equivalents for DACS II DSPU-type Units**

Extended	Hierarchical	Extended	Hierarchical
0001 to 0002	01101 to 01102	...	...
0021 to 0022	01201 to 01202	0301 to 0302	02801 to 02802
...	...	...	...
0141 to 0142	01801 to 01802	2401 to 2402	16101 to 16102
0161 to 0162	02101 to 02102	...	...
0181 to 0182	02201 to 02202	2541 to 2542	16801 to 16802

Table 4-6. NPC Number Equivalents for DACS II DS3U-type Units

Extended	Hierarchical	Extended	Hierarchical
0001 to 0160	01101 to 01620	...	...
016A to 016H	01621 to 01628	2401 to 2560	16101 to 16620
0161 to 0320	02101 to 02620	256A to 256H	16621 to 16628
032A to 032H	02621 to 02628		

## NPC PROVISIONING Form

The sections below provide information on the types of NPC Provisioning forms.

### Procedure: Provisioning an NPC

To access the NPC PROVISIONING forms, follow these steps:

1. Select PROVISIONING from the MAIN MENU. The PROVISIONING menu is displayed, as shown in Figure 4-1.




Figure 4-1. PROVISIONING Menu

2. Select NPC from the PROVISIONING menu. The NPC PROVISIONING form is displayed, as shown in Figure 4-2.

```
06:15 01 Nov 1997  I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- NPC PROVISIONING -----
Site Name: DACS00           Alarm State:   Service State:
Action: CREATE NPC ID:
Type:PB100 Number(Hier):   (Ext):      Alarm Aging:0000 IW:  AIS: MJ
FE Site:                   TS0:11011111 TSOM:00000000
      Lpbk Trans: N                               Usage:

                                Short Interval Option   Long Interval Option
Slips                        D Inf                D Inf
Degraded Minutes             D Inf                D Inf
Unavailable Seconds          D Inf                D Inf
Errored Seconds              D Inf                D Inf
Sev Errored Seconds          D Inf                D Inf

Enter the NPC number in extended format._____

[HELP] [ ] [NEXTPAGE] [QUIT] [RECNCILE] [TOP MENU] [PRINT] [EXECUTE]
```

Figure 4-2. CEPT NPC Provisioning Form (Types PB/PC)

```
06:15 01 Nov 1997  I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- NPC PROVISIONING -----
Site Name: ISX           Alarm State:      Service State:
Action: CREATE          NPC ID:
Type:SD111 Number(Hier):  (Ext):

Enter the NPC number in hierarchical format.

HELP CHOICES NEXTPAGE QUIT RECNCILE TOP MENU PRINT EXECUTE
```

**Figure 4-3. Substrate NPC Provisioning Form (Type SD)**

This is the default form. The fields that appear depend on the value of the default form **Type** and **Action** fields. In addition, the defaults that appear may be different depending if you are using a DACS II or DACS II ISX. The form shown above appears for CEPT equipment (**Type of PB or PC**).

The **QUERY Action** has its own forms. These forms are described under Querying an NPC later in this chapter.

On all the forms, the default values indicated for **Type**, **IW**, **TS0**, and **TS0M**, if they are present, are those provided as defaults by the DACS as well.

Figures 4-4 through 4-9 illustrate the remaining NPC distinct forms.



```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
      _____ NPC PROVISIONING _____
Site Name: ISX           Alarm State:      Service State:
Action: CREATE NPC ID:
Type:DE100 Number(Hier): (Ext):      Alarm Aging:0000 IW: AIS:
FE Site:

Minor Alarm Option      Major Alarm Option
Slips                   0                   0
Bit Error Rate          0                   0
Frame Alignment         0                   0
Errored Seconds         0                   0
Sev Errored Seconds    0                   0

Enter the NPC number in extended format. _____
HELP  [ ]  NEXTPAGE  QUIT  RECNCILE  TOP MENU  PRINT  EXECUTE
    
```

**Figure 4-5. NAS NPC Provisioning Form (Types DE/TE)**

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
      _____ NPC PROVISIONING _____
Site Name: ISX           Alarm State:      Service State:
Action:CREATE           NPC ID:
Type:DA100 Number(Hier): (Ext):      Alarm Aging:000 IW: AIS:MJ
FE Site:

Enter the NPC number in hierarchical format. _____
HELP  [ ]  NEXTPAGE  QUIT  RECNCILE  TOP MENU  PRINT  EXECUTE
    
```

**Figure 4-6. Enhanced NAS NPC Provisioning Form (Types DA/TA)**

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
      _____ NPC PROVISIONING _____
Site Name: ISX           Alarm State:      Service State:
Action: CREATE NPC ID:
Type:DE919 Number(Hier):      (Ext):      Alarm Aging:0000 AIS: MJ
FE Site:

                Minor Alarm Option      Major Alarm Option
Slips                0                    0
Bit Error Rate      0                    0

The NPC number is required
Enter the NPC number in extended format. _____
HELP CHOICES NEXTPAGE QUIT RECNCILE TOP MENU PRINT EXECUTE
    
```

**Figure 4-7. Clear DS1 NAS NPC Provisioning Form (Type DE9y9)**

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
      _____ NPC PROVISIONING _____
Site Name:ISX           Alarm State:      Service State:
Action: CREATE NPC ID:
Type:TE919 Number(Hier):      (Ext):      Alarm Aging:0000 AIS: MJ
FE Site:

                Minor Alarm Option      Major Alarm Option
Slips                0                    0

The NPC number is required
Enter the NPC number in extended format. _____
HELP [ ] NEXTPAGE QUIT RECNCILE TOP MENU PRINT EXECUTE
    
```

**Figure 4-8. Clear DS1 Through DS3 NAS NPC Provisioning Form (Type TE9y9)**

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- NPC PROVISIONING -----
Site Name: CEF           Alarm State:      Service State:
Action:CREATE   NPC ID:
Type:MB100      Number(Hier):          (Ext):

Upper NPC ID:
Upper NPC No(Hier):

The NPC number is required
Enter the NPC number in extended format.
HELP CHOICES NEXTPAGE QUIT RECNCILE TOP MENU PRINT EXECUTE
    
```

**Figure 4-9. DMB NPC Provisioning Form (Type MB)**

For the **CREATE Action**, you must fill in the **Site Name**, **NPC ID**, and **Number** fields. Most other fields contain default values.

After an NPC is created, you can use the other actions: **MODIFY**, **RESTORE**, and **QUERY**. For these actions, enter the **Site Name**, **Action**, and **NPC ID** or the **Number**, and the I-2000 automatically displays the related data for the NPC on the NPC PROVISIONING form.

### Field Descriptions

Descriptions of the NPC PROVISIONING fields are described in Tables 4-7 through 4-10.

**Table 4-7. NPC PROVISIONING Field Descriptions**

<p><b>Site Name</b></p>	<p>Mandatory. 1 through 24 characters from the set A-Z, a-z, 0-9, /, _, and -. All other characters are illegal. Blanks are not allowed within a name.</p> <p>The name of the DACS where the requested <b>Action</b> will take place. Pressing <b>CHOICES</b> displays WHICH DACS? with a list of the DACS names. These names were established during frame administration, described in Chapter 3 "System Administration."</p>
-------------------------	---

**Table 4-7. NPC PROVISIONING Field Descriptions (Contd)**

<p><b>Alarm State</b></p>	<p>The status of an alarm currently being received or asserted by this NPC. This field is under software control of the I-2000 and cannot be changed by the user. The possible values are:</p> <p>OOS            The NPC has been removed from service autonomously.</p> <p>LOS            The alarm is a loss-of-signal alarm.</p> <p>CGA            The alarm is a carrier group alarm (NAS).</p> <p>PBA            The alarm is a primary block alarm (CEPT).</p> <p>PERF          The alarm is a performance alarm of major severity.</p> <p>MAJ            The alarm is of major severity and is not a performance alarm.</p> <p>MINR          The alarm is of minor severity.</p> <p>NONE          No alarm is asserted.</p> <p>blanks        The NPC is not yet registered in the I-2000 database.</p>
<p><b>Service State</b></p>	<p>The status of the NPC. This field cannot be changed by the user except as the result of an <b>Action</b>. Possible values:</p> <p>UEQD    Unequipped. The NPC referenced by the <b>NPC ID</b> is not currently recorded in the I-2000 and/or DACS databases (equipped). To place it there, use the <b>CREATE Action</b>.</p> <p>OOS      Out of service. The NPC is currently equipped, but is not operable. To place it in service, use the <b>RESTORE</b> command. To unequip it, use the <b>DELETE</b> command.</p> <p>IS        In service. The NPC is equipped and operable (ready for <b>CIRCUIT PROVISIONING</b>). To remove it from service, use the <b>REMOVE Action</b>.</p> <p>On currently unmapped channels in an NPC that is <b>IS</b>, the disconnect channel code is asserted repeatedly if there is one; otherwise, the NPC's <b>IW</b> is used as the default disconnect code.</p> <p>0 IS      With reference to DMB, CB102 circuit pack, and subrate NPCs, side 0 is in service and side 1 is out of service.</p> <p>1 IS      With reference to DMB, CB102 circuit pack, and subrate NPCs, side 1 is in service and side 0 is out of service.</p>

**Table 4-7. NPC PROVISIONING Field Descriptions (Contd)**

Action	
	CREATE Adds a new NPC.
	DELETE Deletes the specified NPC. An NPC must be removed from service before it can be deleted.
	<p>MODIFY Changes allowed combinations of fields for the specified NPC. These combinations are stated under "Types of NPCs" in this chapter. Constraints on possible new values of <b>Type</b> are also stated there.</p> <p><b>⇒ NOTE:</b> If <b>OOS</b> is set to <b>Yes</b>, changing the <b>Type</b> or <b>IW</b> of an <b>IS</b> NPC results in the I-2000 placing the NPC in <b>OOS Service State</b> before making the change and in doing a <b>RESTORE</b> after the change. However, if <b>OOS</b> is set to <b>No</b>, the <b>MODIFY</b> is denied.</p> <p><b>⇒ NOTE:</b> Only those fields whose specification on the form differs from the I-2000 database cause changes to be sent to the DACS. In particular, if the value is correct in the I-2000 but is not correct in the DACS, a <b>MODIFY</b>, even in <b>Site Only</b> mode, will not correct the value in the DACS.</p>
	<p>RESTORE Places the specified NPC in service. An NPC must be in service before it can be used for <b>CIRCUIT PROVISIONING</b>.</p> <p>For <b>TRANSMIC 2G</b> circuit packs, a restore consists of an NPC restoral and a cross connect to the <b>CPR</b> circuit pack in the <b>DSPU</b></p>
	QUERY Requests the current state of the NPC from the DACS and displays the data received upon successful completion of the <b>QUERY</b> .

**Table 4-7. NPC PROVISIONING Field Descriptions (Contd)**

<p><b>Action (Continued)</b></p>	<p>REMOVE      Removes the specified NPC from service.</p> <p style="text-align: center;"><b>⇒ NOTE:</b> Removing an NPC with active circuits may result in transmission loss for those circuits.</p> <p style="text-align: center;">An NPC carrying red-lined circuits cannot be removed unless <b>INCL</b> is <b>YES</b>.</p> <p>BROWSE      Gives you read-only access to the I-2000 database for retrieving and scrolling NPC records. You can use wild-card characters (*?), in the <b>NPC ID</b> field only, to match any character or set of characters.</p> <p>LOOPBACK    Allows you to start, change, and stop the loopback setting on an NPC. You can select <b>LOOPBACK</b> for NPCs that are out of service (OOS), or in service (IS). In addition this actions can also be applied to a traffic-carrying NPC.</p>
<p><b>NPC ID</b></p>	<p>Mandatory. 1 through 41 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored. An identifier, or name, associated with the specified <b>Number</b>. The <b>CREATE Action</b> associates the name and number. Only one <b>NPC ID</b> can be associated with a <b>Number</b> within a DACS, and also, an <b>NPC ID</b> can be associated with only one NPC. An <b>NPC ID</b> uniquely identifies an NPC.</p> <p>An identifier, or name, associated with the specified <b>Number</b>. The <b>CREATE Action</b> associates the name and number. Only one <b>NPC ID</b> can be associated with a <b>Number</b> within a DACS, and also, an <b>NPC ID</b> can be associated with only one NPC. An <b>NPC ID</b> uniquely identifies an NPC.</p>
<p><b>Type</b></p>	<p>PA      For DACS II, Generic 6.0 and higher, and DACS II ISX Release 1.0, the hardware is a TG192 enhanced dual primary circuit (EDPC) supporting a CEPT 75/120-ohm NPC with enhanced functionality. PA100 is the default value for ISX systems.</p> <p><b>Type</b> PAxCz provides clear, framed E1 cross-connections and PAxDz provides clear, unframed E1 cross-connections. Support of PA-<b>Type</b> NPCs is expanded to include the setting, modifying and querying of performance monitoring thresholds. And finally, you can provision and query the TSO receive (<b>NFS</b>) spare bit manipulation settings.</p>

Table 4-7. NPC PROVISIONING Field Descriptions (Contd)

<p><b>Type (Continued)</b></p>	<p><b>DE</b> The hardware is a dual digroup card (DDC) supporting a NAS NPC for channelized DS1 signals or a TG80 Card for clear unframed DS1 signals (DE9y9).</p> <p><b>TA</b> For DACS II, release 6.0 only, the hardware is a KCR5 and 6 within a DS3 card. <b>Type</b> TAxy9 provides clear unframed cross-connections.</p> <p><b>TE</b> The hardware is a DS3 card for channelized or clear unframed DS1 (TE9y9).</p> <p><b>MB</b> The hardware is a DMB card for DMB multipoint cross-connections. xyz must be 100.</p> <p><b>MJ</b> Not available.</p> <p><b>SR</b> Not available.</p> <p><b>SD</b> For subrate provisioning for X.50 and X.57. The only option for this type is SD111. For PA, PB, PC, DA/TA and DE types, the xyz defines facility characteristics. For example, for DE types, xyz defines the framing format (x is 1-3), the line and signaling format (y is 0, 1, 2, 4), and the channel-counting sequence (z is 0 or 4). See the DACS I/O manuals.</p>
<p><b>Number (Hier)</b></p>	<p>For CREATE, either this field or <b>(Ext)</b> must be entered. The I-2000 converts and fills in the other.</p> <p>The number of the NPC in hierarchical (hier) numbering. Hierarchical numbers have the following format: xyzz</p> <p>where:</p> <p>xx Is the shelf or unit number in the range 01 to 16. For units less than 10, the leading 0 is required.</p> <p>y Is the module number in the range 1 to 8.</p> <p>zz Is the NPC within the module, ranging from 01 through 40. Not all units are allowed in all frames, nor all positions in all units and modules. A module or shelf of a certain type is associated with a definite range of numbers. If you enter a number within that range, the <b>Type</b> field must be compatible with the type of NPC belonging to the number. If it is not, an error message is displayed: NPC type is inconsistent with FTMI type</p>
<p><b>(Ext)</b></p>	<p>The number of the NPC in extended numbering. The range is 1 through 256H. Some NPC numbers may not be allowed in a frame, depending on the frame's equipage.</p>
<p><b>SIDE</b></p>	<p>This field appears for types MB, MJ, and SR only. Specifies the side when the <b>Action</b> will change the <b>Service Status</b> of a duplex NPC. Values are 0 or 1. A value is required when the <b>Action</b> is REMOVE or RESTORE.</p>

**Table 4-7. NPC PROVISIONING Field Descriptions (Contd)**

<p><b>Alarm Aging</b></p>	<p>The number of seconds after a CGA or PBA message has been received or asserted, before action is taken by the I-2000. The default is 0.</p> <p>x Age the alarm x seconds, where x is 1 through 9999.  0 Do not age the alarm, but act immediately.  -1 Ignore the alarm.</p>
<p><b>IW</b></p>	<p>Insertion Word. Two hex digits for NAS, 3 for CEPT, [0-9, A-F/a-f]. Specifies the 8-bit code transmitted by an IS NPC on unassigned channels. The third digit of a CEPT <b>IW</b> contains signaling-channel data. The default for NAS NPCs is 7F and for CEPT is D5D.</p> <p><b>⇒ NOTE:</b>  This is an open field and the I-2000 lets you enter any 2- or 3-character <b>IW</b>. But for NAS (DE) NPCs only, two characters are allowed, and entering three sends a <i>bad syntax</i> message to the DACS and also displays it on the I-2000 prompt line. If this happens, correct the <b>IW</b> and execute again. For CEPT NPCs, if you do not enter a third digit, it is supplied by the I-2000.</p> <p>On DACS II, Release 6.0, and DACS II ISX Release 1.0 frames, a 0 in the 7th bit (from the right) position generates a D4 yellow alarm for the NPC when the <b>IW</b> is transmitted.</p>
<p><b>AIS</b></p>	<p>The user-defined severity of an AIS alarm on this NPC.</p> <p>MJ An AIS alarm is to be major.  MN Minor.  MI A maintenance information alarm.</p>
<p><b>FE Site</b></p>	<p>Far end site. 1-24 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %. Blanks are allowed in the name, but leading and trailing blanks are ignored.</p> <p>The name of the DACS at the far end of the facility terminating on the specified NPC. This field appears only for types PA, PB, PC, DA/TA and DE, and is informational.</p>

Table 4-7. NPC PROVISIONING Field Descriptions (Contd)

<b>Upper NPC ID</b>	<p>Mandatory. 1 through 41 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored.</p> <p>An identifier, or name, associated with the specified <b>Number</b>. The <b>CREATE Action</b> associates the name and number.</p> <p>Only one <b>NPC ID</b> can be associated with a <b>Number</b> within a DACS, and also, an <b>NPC ID</b> can be associated with only one NPC. An <b>NPC ID</b> uniquely identifies an NPC.</p> <p>An identifier, or name, associated with the specified <b>Number</b>. The <b>CREATE Action</b> associates the name and number.</p> <p>Only one <b>NPC ID</b> can be associated with a <b>Number</b> within a DACS, and also, an <b>NPC ID</b> can be associated with only one NPC. An <b>NPC ID</b> uniquely identifies an NPC.</p>
<b>Upper NPC No (Hier)</b>	<p>This field appears for type MB only. A number in hierarchical format automatically assigned to the NPC specified in <b>Upper NPC ID</b>.</p>
<b>(Ext)</b>	<p>This field appears for type MB only. A number in extended format automatically assigned to the NPC specified in <b>Upper NPC ID</b>.</p>
<b>TS0</b>	<p>Time slot 0 transmit. Eight characters. The field appears for CEPT NPCs only, and is accessible via the <b>MODIFY Action</b>. Describes how to process bits in time slot 0 for transmission. A single character is entered for each bit. The bit values are:</p> <ul style="list-style-type: none"> <li>P Cross-connect this bit position unchanged.</li> <li>0 Overwrite the incoming bit with a 0 for this position.</li> <li>1 Overwrite the incoming bit with a 1 for this position.</li> <li>V For <b>Type PA</b> only, invert the value of this bit.</li> </ul> <p>If either of the two rightmost bits is P, both must be P. Use either upper or lower case for P or V. The default is 11011111.</p>
<b>TS0M</b>	<p>Time slot 0 monitor. Eight characters. The field appears for CEPT NPCs only, and is accessible via the <b>MODIFY Action</b>.</p> <p>Describes what Time Slot 0 bits are to be monitored by the DACS. A single character is entered for each bit. The bit values are:</p> <ul style="list-style-type: none"> <li>0 Stop monitoring the signal in this bit position.</li> <li>1 Start monitoring the signal in this bit position.</li> </ul> <p>Whenever the DACS detects a change in a monitored TS0 bit, it generates an autonomous message. The default is 00000000.</p>

**Table 4-7. NPC PROVISIONING Field Descriptions (Contd)**

<p><b>NFS</b></p>	<p>Non-frame word setting. Nine characters. This field appears for <b>Type PA</b> only, and is accessible by the <b>MODIFY Action</b>. Specifies how the spare bits in timeslot 0 are to be handled when they are cross-connected to a timeslot other than 0. This is a special case, the spare bit manipulation feature. Refer to the discussion of TS0 to non-TS0 cross-connects in the Introduction in Chapter 6 "Circuit Provisioning." The field format is: abcdefghi</p> <p>where:</p> <p>a                    is bit 1 of the FW bcdefghi           are bits 1-8 of the NFW</p> <p>Enter a single character for each bit. The bit values are:</p> <p>P    Pass unchanged. V    Pass inverted, except for bit c. 0    Set output to 0, except for bit c. 1    Set output to 1, except for bit c. Bit c is passed unchanged in every case. If h or i are set to P, then the other of the two must be set to P. The creation default is P P P P P P P P P.</p>
<p><b>INCL</b></p>	<p>This field appears for the <b>REMOVE Action</b> only. It is parallel to the <b>INCL</b> selection of the <b>Options</b> field on the <b>CIRCUIT PROVISIONING</b> form; however, where the <b>CIRCUIT PROVISIONING</b> option applies to disconnecting or deactivating a circuit, this <b>INCL</b> field applies to removing an NPC.</p> <p>YES Allow an NPC that is carrying a red-lined circuit to be removed. NO Deny removal of an NPC that is carrying a red-lined circuit.</p>
<p><b>OOS</b></p>	<p>This field appears for the <b>MODIFY Action</b> only.</p> <p>YES Allow the NPC to be taken out of service if the modification requires. NO Deny any modification that would result in the NPC being taken out of service.</p>

**Table 4-7. NPC PROVISIONING Field Descriptions (Contd)**

<b>Lpbk Trans</b>	<p>This option can be changed while a loopback is active to change the loopback signal transmission or the Performance Monitoring options.</p> <p>A Starts looping the signals. Also sends AIS downstream or upstream, turns off facility Performance Monitoring, freezes alarm and parameter counts for the NPC.</p> <p>B <b>(PA type NPCs only)</b> Starts looping the signals. Also sends AIS downstream or upstream and continues normal Performance Monitoring and alarm processing for the NPC.</p> <p>C <b>(PA type NPCs only)</b> Starts looping the signal and transparently passes through the received signal. Turns off facility Performance Monitoring and freezes alarm and parameter counts for the NPC.</p> <p>T Starts looping the signal and transparently passes through the received signal. Continues facility Performance Monitoring and alarm processing for the NPC.</p> <p>N Stops looping the signal.</p>
<b>Dir</b>	<p>Direction. This is a one character field to indicate the direction of the loopback. This is a mandatory field when the action selected is LOOPBACK and the NPC is a PA type.</p> <p>F Facility Loopback. This loops the incoming 2 Mbit/s bipolar signal back to the facility.</p> <p>E Equipment loopback. This loops the outgoing 2 Mbit/s signal back to the DACS II equipment. This option is not applicable to PB/PC type NPCs.</p> <p>N Stop loopback.</p>
<b>Usage</b>	<p>Optional. This is a 10-character field for data entry and display. Valid entries for this field are:</p> <p>UNKNOWN INTER DACS ACCESS</p> <p>The default value is ACCESS, which also applies to the ERP/ SYNC generated NPC.</p>

### Performance Monitoring Fields

The fields on the bottom half of the screen allow you to set the thresholds for generating various types of facility performance alarms. These fields are available for all **Types** except **DA** and **TA**. For the latter **Types**, the threshold fields disappear when you enter a **Type** value.

A DACS II does not send a facility performance alarm message until a parameter error rate has exceeded a stored threshold. Each DACS II stores up to four sets of threshold values for each facility performance parameter for each NPC. Each set is called a data set: data sets 0, 1, 2, and 3 for NAS or data sets D, 1, 2, and 3 for CEPT. The D stands for default. In NAS, 0 is used for the default.



**NOTE:**

If a data set is *not* defined in the frame, it will reject requests for a data set value, such as are made when you provision an NPC after setting the performance parameters.



**NOTE:**

For any options other than D-xxx, refer to the ED-OPT-T1 command in the *DACS II Command and Message Manual* for setting up secondary databases.

For a CEPT NPC choose a threshold setting in the following format:

**n ccc**

where:

- n is 1, 2, 3, or D, referring to data set 1, data set 2, data set 3 or the default data set.
- ccc is Maj, Min, or Inf, referring to alarm severities of Major, Minor or Informational. D Inf is the default.

For example, an entry of D Inf in the **Short Interval Option of Degraded Minutes** means use the threshold of the default data set for a **DM1H** alarm and send the alarm with informational severity when the threshold is exceeded.

The performance parameters are classified in the following table. For an explanation of the types, refer to the end of Chapter 3 "System Administration."



**NOTE:**

Do not confuse the performance parameters shown in Table 4-7 with the values to be entered on the screen.

**Table 4-8. Alarms For CEPT NPC Performance Parameters For Types Other Than PA**

	Short Interval Options	Long Interval Options
<b>Slips</b>	SLIP15M alarm	SLIP24H alarm
<b>Degraded Minutes</b>	DM1H alarm	DM24H alarm
<b>Unavailable Seconds</b>	US15M alarm	US24H alarm
<b>Errored Seconds</b>	ERS15M alarm	ERS24H alarm
<b>Severe Errored Seconds</b>	SERS15M alarm	SERS24H alarm

For example, if the default threshold on errored seconds is 5. You enter `D MAJ` under the **Short Interval Options** for **Errored Seconds**. If during any 15-minute period the number of errored seconds detected by the NPC exceeds 5 seconds, an `ERS15M` alarm of severity `MAJ` is asserted and is reported on I-2000 terminals connected to the DACS. After the next 15-minute interval with less than 5 errored seconds, the DACS will clear the alarm and send a message to the I-2000 indicating that the performance alarm has been cleared.

The performance parameters of **Type PA** is enhanced. These parameters along with the alarms resulting from their thresholds being exceeded are shown in the next table, organized by near end (NE) and far end (FE), as they are on the NPC PROVISIONING form.

**Table 4-9. Alarms For CEPT NPC Performance Parameters For Type PA**

	Daily NE	Daily FE	15-Min NE	15-Min FE
<b>CRC Block Errors</b>	CRCDAILY	FEBEDAILY	CRC15MIN	FEBE15MIN
<b>Errored Seconds</b>	ESDAILY	FESDAILY	ES15MIN	FES15MIN
<b>Sev Errored Seconds</b>	SESDAILY	FSESDAILY	SES15MIN	FSES15MIN
<b>Unavailable Seconds</b>	UASDAILY	FUASDAILY	UAS15MIN	FUAS15MIN
<b>Framing Errors</b>	FRERDAILY		FRER15MIN	
<b>Out-of-Frame Seconds</b>	OFSDAILY		OFS15MIN	
<b>Controlled Slip Seconds</b>	CSSDAILY		CSS15MIN	

**Table 4-9. Alarms For CEPT NPC Performance Parameters For Type PA (Contd)**

	Daily NE	Daily FE	15-Min NE	15-Min FE
<b>Coding Violations</b>	CVDAILY		CV15MIN	
<b>Unavailable Time Count</b>	UATCDAILY		UATC15MIN	
<b>Multiframe Errors</b>	MERDAILY		MER15MIN	

The possible selections of field values for an NAS NPC are: n

where: n is 0, 1, 2, or 3, referring to data sets 0, 1, 2, or 3. The default is 0.

The types of performance parameters are classified in Table 4-10.

**Table 4-10. Alarms For NAS NPC Performance Parameters**

	Minor Alarm Option	Major Alarm Option
<b>Slips</b>	SLIP, severity Minor	SLIP, severity Major
<b>Bit Error Rate</b>	BER, severity Minor	BER, severity Major
<b>Frame Alignment</b>	COFA, severity Minor	COFA, severity Major
<b>Errored Seconds</b>		severity Major
<b>Severe Errored Seconds</b>		severity Major

A severity of Minor is not correctly defined for **Errored Seconds** and **Severe Errored Seconds** for NAS NPCs.

## **NPC Provisioning Examples**

---

The following examples demonstrate the use of the NPC Provisioning capabilities. Enter information into the forms and then execute the chosen **Action**. These examples are generic in order to serve as a general guide to NPC PROVISIONING functionality.

The **RECNCILE** Key is especially useful in providing additional functionality in this area. The use of this key is described in Chapter 2 "Getting Started."



**CAUTION:**

*Entry of improper data through use of the **RECNCILE** key may result in contradictory data for one or more NPCs between the I-2000 and DACS databases. When you then try to use the NPCs in a circuit, the discrepancies may result in degraded performance or loss of the circuit's ability to carry traffic.*

### **Creating an NPC and Placing It in Service**

---

Successful creation of an NPC places the NPC in the database, and successful restoral places it in service; for example, ready to be used in cross-connection. The CREATE or RESTORE will be denied if:

- mandatory field information is missing
- the **Type** is of improper form or content
- the number does not refer to an NPC of that **Type**
- the NPC is already in the desired **Service State**
- the **NPC ID** is already in use
- a field contains an invalid value.

### **Example: Creating a CEPT NPC**

---

To create a CEPT NPC, follow these steps:

1. Select NPC from the PROVISIONING menu.
2. Enter, or select from the CHOICES menu, the following information:

— **Site Name:** `DACS00`

The site name must already have been provisioned as a frame (refer to Chapter 2 "Getting Started").

— **Action:** `CREATE`

— **NPC ID:** `dgrp01`

— **Type:**`PB144`

— **Number (Hier):** `01101`

If you fill this in, **(Ext)** is automatically supplied. Here it is `0001`. The NPC number must be compatible with the Type.

These are the minimum requirements for creating an NPC. You may wish to fill out other fields as well:

— **Alarm Aging:** `5`

— **IW:** `D5D` (the default value)

— **TS0:** `11011111`

— **TS0M:** `00000000`

- **Slips, Short Interval Option:** `D Inf`
3. Fill in all the other threshold selections. In this case, suppose they are all `D Inf`.
  4. Press `EXECUTE` and select IMMEDIATE. (You can create the NPC in `Local only` mode. Refer to Chapter 2 “Getting Started” on the use of the `RECNCILE` Key.) The result is that the:
    - **Service State** field changes to `OOS`
    - **Alarm State** changes to `NONE`.
    - I-2000 command completion message is displayed on the screen.
  5. Move to the **Action** field and select `RESTORE`.
  6. Press `EXECUTE` and select IMMEDIATE. The result is that the:
    - **Service State** field changes to `IS`.
    - I-2000 command completion message is displayed.

### **Procedure: Creating an NAS NPC**

---

To create an NAS NPC, follow these steps:

1. Select NPC from the PROVISIONING menu.
2. Enter, or select from the CHOICES menu, the following information:
  - **Site Name:** `DACS00`
  - `DACS00` must already have been provisioned as a frame (see Chapter 2 “Getting Started.”)
  - **Action:** `CREATE`
  - **NPC ID:** `dgrp02`
  - **Type:** `DE310` (or some other `DE` value)
  - **Number (Hier):** `01102`
  - If you fill this in, **(Ext)** is automatically supplied. The NPC number must be compatible with the **Type**.
  - These are the minimum requirements for creating an NPC. You may wish to fill in other fields as well:
  - **Alarm Aging:** `5`
  - **IW:** `7F` (the default value)
  - **FE Site:** `DACS01`
  - **Slips, Minor Alarm Option:** `0`
3. Fill in all the other threshold selections. In this case, suppose they are all the default.

4. Press **EXECUTE** and select IMMEDIATE. The result is that the
  - I-2000 command completion message appears on the screen.
  - **Service State** field changes to OOS.
  - **Alarm State** changes to NONE.
5. Move to the **Action** field and select RESTORE.
6. Press **EXECUTE** and select IMMEDIATE. The result is that the:
  - **Service State** field changes to IS.
  - I-2000 command completion message appears.

### **Example: Creating an NPC as a Subrate Type**

---

To create an NPC as a subrate type, which will then allow you to provision DS0 channels and subrate cross connections for the X.50 and X.57 subrate standards, follow these steps.

1. Select NPC from the PROVISIONING menu. The NPC PROVISIONING form is displayed.
2. Enter, or select from the CHOICES menu, the following information:
  - **Site Name:** DACS00  
DACS00 must already have been provisioned as a frame (refer to Chapter 2 "Getting Started.")
  - **Action:** CREATE
  - **NPC ID:** DS01
  - **Type:** SD111
  - **Number (Hier):** 01101
    - If you fill this in, **(Ext)** is automatically supplied. The NPC number must be compatible with the Type.
3. Press **EXECUTE** and select IMMEDIATE. (You can create the NPC in *local only* mode. Refer to Chapter 2 "Getting Started" on the use of the **RECNCILE** key.) The result is that the
  - **Service State** field changes to OOS
  - **Alarm State** changes to None
  - I-2000 command completed message is displayed on the screen.
4. Move to the **Action** field and select RESTORE.
5. Press **EXECUTE** and select IMMEDIATE. The result is that the:
  - Subrate NPC is in service.
  - **Service State** field changes to IS
  - I-2000 command completion message is displayed.

For more information on provisioning DS0 channels and subrate cross connections for this subrate NPC, refer to Chapter 7 "Subrate Provisioning."

### **Example: Creating an NPC Using DMB Multipoint**

---

To create an NPC using DMB multipoint, follow these steps:

1. Select NPC from the PROVISIONING menu.
2. Enter, or select from the CHOICES menu, the following information:

— **Site Name:** DACS00

The site name must already have been provisioned as a frame (see Chapter 2 "Getting Started)."

— **Action:** CREATE

— **NPC ID:** dmb01

— **Type:** MB100

— **Number (Hier):** 02101

— If you fill this in, **(Ext)** is automatically supplied. The NPC number must be compatible with the **Type**. Note that **Upper NPC Number** also is supplied.

— **Upper NPC ID:** dmb02

This field is mandatory.

3. Press **EXECUTE** and select IMMEDIATE. The result is that the:

— **Service State** field changes to OOS.

— I-2000 command completion message is displayed.

4. Move to the **Action** field and select RESTORE.

5. Enter **SIDE:** 0

6. Press **EXECUTE** and select IMMEDIATE. The result is that the

— **Service State** field changes to 0 IS.

— **Alarm State** changes to NONE.

— I-2000 command completion message is displayed.

7. Repeat Steps 5 and 6 for **SIDE** 1.

### **Example: Removing an NPC**

---

This example demonstrates removal of a NPC from service. It is the opposite **Action** from RESTORE. A REMOVE will fail if:

- a mandatory field is missing
- the NPC is not in service

- the NPC is carrying red-lined circuits and the **INCL** field is set to **NO**.

To remove an NPC, follow these steps:

1. Assuming the **NPC ID**, **Type**, and other data are still displayed, move to the **Action** field and select **REMOVE**.
2. Check that the data for the NPC are displayed, and that the **Service State** field is **IS**. Press **EXECUTE** and select **IMMEDIATE**. The result is that the:
  - **Service State** field changes to **OOS**.
  - **Alarm State** changes to **NONE**.
  - I-2000 command completion message is displayed.



**NOTE:**  
The **MB Type** requires entry of **SIDE**.

### **Example: Deleting an NPC**

---

This example shows how to unprovision an NPC (remove) it from the I-2000 and frame databases. It is the opposite **Action** from **CREATE**. You cannot delete the NPC if it:

- isn't there
- has active or deactivated circuits using any of its channels
- is a test port group
- [has an alarm listed in an ARP](#).

To delete an NPC, follow these steps:

1. Assuming the **NPC ID**, **Type**, and other data are still displayed, move to the **Action** field and select **DELETE**.
2. The data for the NPC are displayed; the **Service State** field is **OOS**. Press **EXECUTE** and select **IMMEDIATE**. Observe that the:
  - **Service State** field now is **UEQD**.
  - **Alarm State** is now blank.
  - I-2000 command completion message is displayed.

### **Example: Querying an NPC**

---

The **QUERY** selection retrieves the provisioning and status information concerning an NPC from the DACS and displays it on the screen.

To query an NPC, follow these steps:

1. Select **PROVISIONING** from the **MAIN MENU** and **NPC** from the **PROVISIONING** menu.
2. Navigate to **Action** and select **QUERY**.

3. The bottom fields on the lower part of the screen become temporarily blank.
4. Enter the NPC number in hierarchical or extended format, or the **NPC ID**. Whichever identifying field you decide to enter, the values of the other two also are displayed.
5. Press **EXECUTE** and select IMMEDIATE.

The I-2000 command completion message is displayed. In addition, the first page of the QUERY form is displayed, as shown in Figure 4-10.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- NPC PROVISIONING -----
Site Name:eaol123           Alarm State:NONE   Service State:IS
Action:QUERY              NPC ID:testnpc0001
Type:PB100 Number(Hier):  (Ext):   Alarm Aging:000 IW:FFD AIS:MN
                          TS0:11011111   TSOM:00000000

<<MISMATCH>>
          Interval Reading      Threshold/Option
          Current  Last  Long      Short      Long
Slips          00000  00000  00000  00000/NONE 00000/NONE
Degraded Minutes 00000  00000  00000  00000/NONE 00000/NONE
Unavailable Seconds 00000  00000  00000  00000/NONE 00000/NONE
Errored Seconds  00000  00000  00000  00000/NONE 00000/NONE
Sev Errored Seconds 00000  00000  00000  00000/NONE 00000/NONE

Errors: CRC:00000 Framing:00000 LOFA:00000 Multiframe Alignment:00000

The command completed successfully
Enter the site name _____
    
```

HELP [ ] NEXTPAGE QUIT RECNCILE TOP MENU PRINT EXECUTE

**Figure 4-10. CEPT NPC Query For PB Type**

**⇒ NOTE:**  
 The <<MISMATCH>> advice on the form above appears if there is a mismatch between the data obtained from the frame and the data in the I-2000 database. In that case, all the information on the form reflects the frame values.

```
06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS II
Status:
Alarms:
-----NPC PROVISIONING-----
Site Name:eao123           Alarm State:NONE   Service State:OOS
Action:QUERY             NPC ID:testnpc0001
Type:PA100 Number(Hier):08103(Ext):1123 Alarm Aging:000 IW:D5D AIS:MJ
FE Site:                 TSO:11011111 TSOM:00000000 NFS:PPPPPPPP

          Daily Far-End           15-Min Far-End
          Reading  Threshold/Opt Reading  Threshold/Opt
CRC Block Errors  00000000 00000000/D Inf 00000000 00000000/D Inf
Errored Seconds  00000000 00000000/D Inf 00000000 00000000/D Inf
Sev Errored Seconds 00000000 00000000/D Inf 00000000 00000000/D Inf
Unavailable Seconds 00000000 00000000/D Inf 00000000 00000000/D Inf

CRC Status:0

The command completed successfully
Enter the site name _____
```

HELP [ ] NEXTPAGE QUIT RECNCILE TOP MENU PRINT EXECUTE

Figure 4-11. CEPT NPC Query Form, PA, First Page

6. Use **NEXTPAGE** to obtain the second page of the **QUERY** form, which is available only for **Type PA**.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS II
Status:
Alarms:
-----NPC PROVISIONING-----
Site Name:eaol23           Alarm State:NONE   Service State:OOS
Action:QUERY              NPC ID:testnpc0001
Type:PA100                Number(Hier):08103 (Ext):1123 Alarm Aging:000 AIS:MJ

                        Daily Near-End      15-Min Near-End
                        Reading Threshold/Opt Reading Threshold/Opt

CRC Block Errors          00000    00176947 /D Inf 00000    018432 /D Inf
Errored Seconds          00000    04320 /D Inf 0000    300 /D Inf
Sev Errored Seconds      00000    00090 /D Inf 0000    030 /D Inf
Unavailable Seconds      00000    00090 /D Inf 0000    030 /D Inf
Framing Errors           00000    00090 /D Inf 00000    0018432 /D Inf
Out-of-Frame Seconds    00000    00004 /D Inf 000    004 /D Inf
Controlled Slip Seconds  00000    00004 /D Inf 000    001 /D Inf
Coding Violations        00000    00004 /D Inf 00000    0018432 /D Inf
Unavailable Time Count    0000    00009 /D Inf 00    03 /D Inf
Multiframe Errors        00000    04095 /D Inf 000    255 /D Inf
    
```

HELP        NEXTPAGE    QUIT    RECNCILE    TOP MENU    PRINT    EXECUTE

Figure 4-12. CEPT NPC Query Form, PA, Second Page

```

06:15 01 Nov 1997  I-2000 Controller Release x.x for DACS II
Status:
Alarms:
-----NPC PROVISIONING-----
Site Name:ea0123           Alarm State:NONE   Service State:OOS
Action:QUERY             NPC ID:testnpc0001
Type:      Number(Hier):  (Ext):      Alarm Aging:000 IW:  AIS:
                    TS0:11011111      TS0M:00000000

                    Reading      Minor Alarm      Minor Alarm
                    Thresh Opt    Thresh Opt      Thresh Opt

Slips
Bit Error Rate
Frame Alignment
Errored Seconds
Sev Errored Seconds

Errors:      CRC:      Framing:      Bipolar Violations:

The command completed successfully
Enter the site name _____
HELP  [ ]  NEXTPAGE  QUIT  RECNCILE  TOP MENU  PRINT  EXECUTE

```

**Figure 4-13. NAS NPC Query Form**

### Example: Browsing NPCs

The **BROWSE** selection retrieves the provisioning and status information concerning each of a range of NPCs.

To browse an NPC, follow these steps:

1. Select **PROVISIONING** from the **MAIN MENU** and **NPC** from the **PROVISIONING** menu.
2. In the **Action** field, select **BROWSE**.
3. Enter search criteria. The **BROWSE** action can retrieve information for up to 50 NPCs at one time.
  - Enter data in the **NPC ID** field. You can use wild-card characters (\*?), in the **NPC ID** field only, to match any character or set of characters.
  - To browse the first 50 NPC's, enter \* in the **NPC ID** field.
  - To search for NPCs that match certain criteria, enter search criteria in the other fields.
4. Press **EXECUTE**.

A search is conducted for the specified NPCs. Also, the data for the first NPC is displayed.

5. To obtain the next NPC, press **NEXT**.

6. To stop the BROWSE, press **QUIT**.

Figure 4-14 shows the first item of a BROWSE through all NPCs.




Figure 4-14. NPC Browse Screen

## NPC Provisioning ERP

An echoed response is a message that is sent from a DACS to the I-2000 when the I-2000 does not expect a response; for example, when a change in frame NPC provisioning is entered through the DACS console, through a passthrough command to the DACS, or by some other means not initiated by the I-2000. Such provisioning would cause the DACS and I-2000 databases to differ if the I-2000 did not respond to the echoed response message.

The I-2000, therefore, is designed to respond by provisioning NPCs. It searches for the NPCs and channels referenced in the message. If it does not find them in the I-2000 database, it executes a **CREATE Action**. The I-2000 also executes a **RESTORE, REMOVE, MODIFY, or DELETE** when required by the message.

You can partially control the I-2000 response to a message of this type. Under **FRAME ADMINISTRATION**, if you set the value of **ERP Control** to **ON**, the I-2000 processes echoed response messages only if the NPC is already in the I-2000 database. The database is updated and event messages are published. If the NPC is missing, the message is not processed and no action of any kind is taken.

If, on the other hand, ERP Control is set to OFF, the I-2000 responds fully to every message of this type.

If the I-2000 must create an NPC that is not in the I-2000 database at all, it automatically assigns an **NPC ID** in the following format:

nnnnn**NPC00**m

where:

- |       |  |
|-------|--|
| nnnnn | Is the NPC number as represented at the DACS. The nnnnn is in hierarchical format if the DACS is provisioned for hierarchical format, or in extended format if provisioned for extended numbering. |
| m     | Is a sequence number assigned to this NPC record. The number is incremented with each new NPC activated by this method.  |

The default values used by the CREATE Action are the same as those specified under "Field Descriptions." They are displayed on the screens.



**CAUTION:**

*You **SHOULD AVOID** creating NPC IDs from the NPC Provisioning form according to the ERP scheme.*

With any other I-2000 **Action**, an action generated in ERP can succeed or fail. The result of the attempt is reported in the **Status** field at the top of the screen, in the following format:

database/result:action explanation

where:

- |             |  |
|-------------|--|
| database    | Is the <b>Site Name</b> field value for this frame.                                  |
| result      | Is one of these values:<br>SUCCESS The action succeeded.<br>ERROR The action failed. |
| action      | Is a terse English description of the attempted action.                              |
| explanation | Is the <b>NPC ID</b> field value or an error message.                                |

Due to the length of the **Site Name** and the **NPC ID**, the full message may not fit on the **Status** line. You can obtain it by generating an ERP report under REPORT OPERATIONS.

Echoed responses for circuits and equipment are enabled whenever a frame screening level is set to 4. Refer to "Configuring the Frame" in Chapter 2, "Getting Started."

### **Procedure: Disabling Echoed Responses**

---

Echoed responses can be disabled for a particular DACS by changing the link screening options in the frame.

To disable an echoed response, follow these steps

1. Enter passthrough mode (refer to Chapter 13 "Passthrough").
2. Log in as USER DAX.
3. Type the following command to set the link screening level to 2:

```
SET-PRVG-TERM::::n01:SCR-2;  
SET-PRVG-TERM::::n02:SCR-2;  
...  
SET-PRVG-TERM::::n16:SCR-2;
```

If you disable echoed responses, the I-2000 database could drift apart from the frame database, necessitating that you periodically perform a database audit followed by a database synchronization (refer to Chapter 10 "Database Administration").

4. Log off.

---

## Contents

<b>Introduction</b>	5-1
<b>TEST PORT PROVISIONING Form</b>	5-2
■ Field Descriptions	5-3
■ Procedure: Creating a Test-Port Group	5-4
■ Procedure: Creating a Test Port	5-6
■ Procedure: Deleting a Test Port	5-6
■ Procedure: Deleting a Test-Port Group	5-7

## Introduction

---

Test port provisioning is an extension of the NPC provisioning process. Once an NPC is created, it can be further designated as a test port group. The NPC does not have to be restored; however, it must be restored before it can be cross-connected.

A test port group is an NPC whose channels can be used for test ports, provided test equipment is being connected by them. After the test port groups and test ports have been provisioned, you can then use TEST ACCESS to connect the test ports in test circuits. These circuits test other channels or test the test port channels. Refer to Chapter 15 "Test Access."

The I-2000 test port provisioning concept, like provisioning in general, extends DACS II test port provisioning. In the DACS II, additional parameters in provisioning commands applying to an already grown NPC further grow the NPC as a test port group. In the I-2000, the TPG designation can apply in the I-2000 only, in the DACS only, or in both databases.

DACS II releases prior to 6.0 allow four possible test port groups: 1, 2, 3, and 4, which do not have to be created in any order. Within each test group are 12 test ports, which must be created in ascending numerical order. For DACS II release 6.0, the test port group capability is increased to 8 and the test port capability to 96.

Table 5-1 summarizes, by frame, the number of test port groups supported.

**Table 5-1. Test Port Groups Supported, By Frame**

Frame Type	No. of TP Groups	No. of TPs
DACS II before Release 6.0	4	1-48
DACS II Release 6.0 and higher	8	1-96
DACS II ISX Release 1.0 and higher	8	1-96

One test port consists of two channels, designated in the DACS manuals as channel A, or the lower- or odd-numbered channel, and channel B, or the higher- or even-numbered channel. Thus, if a hypothetical NAS NPC, JJ36N24, is designated as a test port digroup through test port provisioning, it makes available 24 test channels configured as 12 test ports: channel 1 is port 1, channel A; channel 2 is port 1, channel B; etc. The uses of these channels are explained in Chapter 15, "Test Access."

Constraints on the use of test ports are: test port provisioning is not available to the DACScan™-2000 Controller C-Module.

## TEST PORT PROVISIONING Form

To obtain the TEST PORT PROVISIONING form, select TEST PORT from the PROVISIONING menu. The TEST PORT PROVISIONING form is displayed, as shown in Figure 5-1.

```

06:15 01 Dec 1995  I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
_____ TEST PORT PROVISIONING _____
Site Name:DACS00
Action:
Test Port Group:
Test Port No.:          TC:          IW:
NPC Number (Hier):      (Ext):
                        NPC ID:
_____
Enter the site name (at least 5 characters)_____
HELP CHOICES [ ] QUIT RECNCILE TOP MENU PRINT EXECUTE

```

**Figure 5-1. TEST PORT PROVISIONING Form**

**Field Descriptions**



**NOTE:**

Initially, only **Site Name** and **Action** appear on the screen. The remaining fields that appear depend on the **Action**.

The field values for the TEST PORT PROVISIONING form are described in Table 5-2.

**Table 5-2. TEST PORT PROVISIONING Field Descriptions**

<b>Site Name</b>	<p>Mandatory. 1 through 24 characters from the set A-Z, a-z, 0-9, /, _, and -. All other characters are illegal. Blanks are not allowed within a name.</p> <p>The name of the DACS where the requested <b>Action</b> will take place. Pressing <b>CHOICES</b> displays WHICH DACS? with a list of the DACS names. These names were established during frame administration, described in Chapter 3 "System Administration."</p>																
<b>Action</b>	<p>Mandatory. The provisioning actions are:</p> <p>CREATE TP DIGROUP (CREATETPG) designates a previously provisioned NPC as a test-port digroup.</p> <p>DELETE TP DIGROUP (DELETETPG) removes the designation (and all associated test ports).</p> <p>CREATE TEST PORT (CREATETP) designates a channel pair as a test port within a test port digroup.</p> <p>DELETE TEST PORT (DELETETP) removes the designation.</p>																
<b>Test Port Group</b>	<p>This field appears only for <b>Actions</b> of CREATETPG and DELETETPG. With DACS II releases prior to 6.0, the possible values are 1-4. With DACS II Release 6.0, the possible values are 1 through 8. Clear DS1/E1 NPCs are excluded.</p>																
<b>Test Port No.</b>	<p>This field appears only for <b>Actions</b> of CREATETP and DELETETP. The number of the test port within the NPC. The test port groups contain the following test ports.</p> <table border="0" data-bbox="613 1591 1393 1659"> <tr> <td>TPG1</td><td>1-12</td><td>TPG3</td><td>25-36</td><td>TPG5</td><td>49-60</td><td>TPG7</td><td>73-84</td> </tr> <tr> <td>TPG2</td><td>13-24</td><td>TPG4</td><td>37-48</td><td>TPG6</td><td>61-72</td><td>TPG8</td><td>85-96</td> </tr> </table>	TPG1	1-12	TPG3	25-36	TPG5	49-60	TPG7	73-84	TPG2	13-24	TPG4	37-48	TPG6	61-72	TPG8	85-96
TPG1	1-12	TPG3	25-36	TPG5	49-60	TPG7	73-84										
TPG2	13-24	TPG4	37-48	TPG6	61-72	TPG8	85-96										

**Table 5-2. TEST PORT PROVISIONING Field Descriptions (Contd)**

<b>TC</b>	<p>This field is shown only for an <b>Action</b> of <code>CREATETP</code>. The test port trunk conditioning. The values are:</p> <p><i>value</i> This value is described in Chapter 6, "Circuit Provisioning," under the section "Field Descriptions." If entered, it applies to all channels put under test on this test port; for example, the TP conditioning is static.</p> <p><i>none</i> The conditioning changes to match the circuit under test; for example, the TP conditioning is dynamic.</p>
<b>IW</b>	<p>This field appears for an <b>Action</b> of <code>CREATETP</code>. The value of <b>IW</b> depends on the value of <b>TC</b>. You can not enter an <b>IW</b> when you have not entered a <b>TC</b>. In that case, the <b>IW</b> is dynamic. If you have entered a <b>TC</b>, whether you enter a value for <b>IW</b> or not, the <b>IW</b> is static.</p> <p>For DACS II, the static/dynamic designation has meaning only for access to unmapped terminations. For access to a mapped circuit, trunk conditioning is always adopted from the circuit under test.</p>
<b>NPC Number (Hier)</b>	<p>This field appears only for an <b>Action</b> of <code>CREATETPG</code>. The NPC number in hierarchical format of the NPC to be designated as a test port group. It must already have been equipped, but it does not have to be in service.</p> <p>Alternatively, you can enter the number in extended format, or the <b>NPC ID</b>.</p> <p>Not every type of NPC can be grown as a TP Digroup. Specifically not supported are <b>Types</b> MJ and SR, subrate, MB, multipoint, and DE/TE, clear DS1/E1.</p>
<b>(Ext)</b>	The NPC number in extended format.
<b>NPC ID</b>	The <b>NPC ID</b> of the NPC to be designated as a test port group.

### **Procedure: Creating a Test-Port Group**

The procedure below shows how to designate an NPC as a NAS test port group. This procedure for a CEPT test port group is the same, except for the values of certain fields, noted at the appropriate places. The NPC is NPC 120 and the type is DE110.

The example first provisions the NPC and, in this instance, places it in service. Provisioning and placing in service are discussed in the NPC PROVISIONING section. When the NPC is in service, it is then designated as a test port group.

The `CREATE` **Action** will fail if

- A mandatory field is missing.
- The TP group already exists.
- The **Test Port No.** is inappropriate to the DACS.
- The NPC is already a test port group.

To create a Test-Port group, follow these steps:

1. Enter the following data on the NPC PROVISIONING form:

- **Site Name:** DACS00
- **Action:** CREATE
- **NPC ID:** 999120
- **Type:** DE110

A CEPT NPC would require a CEPT **Type**.

- **Number (Hier):** 01340

For this example, we assume that neither NPC Number 120 or an NPC whose ID is 999120 have been created. In that case, the I-2000 assumes a new NPC (no existing data).

2. Press `EXECUTE`, select IMMEDIATE and observe the:

- **Service State** field of OOS.
- **Alarm State** of NONE.
- I-2000 command completion message.

3. Enter an **Action** of RESTORE.

4. Press `EXECUTE`, select IMMEDIATE and observe the

- **Service State** field of IS.
- **Alarm State** of NONE.
- I-2000 command completion message.

5. Press the `QUIT` function key to return to the PROVISIONING menu.

6. Select TEST PORT and enter the following data on the TEST PORT PROVISIONING form:

- **Site Name:** DACS00
- **Action:** CREATETPG

7. Additional fields appear on the screen. Enter:

- **Test Port Group:** 1
- **(Ext):** 0120

The remaining fields are filled in.

8. Press **EXECUTE** and confirm. The command completion message is displayed.



**NOTE:**

The NPC need not be in service (**RESTORED**) to be designated as a test port group, but it must have been equipped.

Now that test port group 1 exists, test ports 1 through 12 can be created. Within a test port group, test ports must be created in order and deleted in reverse order.

### **Procedure: Creating a Test Port**

---

This procedure designates a channel pair of a test port group as a test port. A trunk conditioning (TC) code is specified, so the test port will have static trunk conditioning.

You can create up to 12 test ports for the group; however, test port 2 cannot be created until test port 1 exists; test port 3 cannot be created until test ports 1 and 2 exist. In addition, a lower-numbered port cannot be deleted when a higher-numbered port exists in that test port group.

To create a Test Port, follow these steps:

1. Enter the following data: **Action:** `CREATETP`
2. A third line appears on the screen. Enter:
  - **Test Port No:** 01
  - **TC:** 0011,0011
  - For a CEPT test port, the value of **TC** is not the same. You might use X-AF.
  - **IW:** TRB
  - For a CEPT NPC, the value of **IW** is not the same. You might use AF.
3. Press **EXECUTE** and confirm. I-2000 command completion message is displayed.

### **Procedure: Deleting a Test Port**

---

This procedure removes the designation of test port from a channel pair.

To delete a Test Port, follow these steps:

1. At the PROVISIONING menu, select TEST PORT and enter these data:
  - **Site Name:** DACS00
  - **Action:** `DELETETP`
2. A third line appears on the screen. Enter **Test Port No:** 01

3. Press **EXECUTE** and confirm. A I-2000 command completion message is displayed.

### **Procedure: Deleting a Test-Port Group**

---

This procedure removes the designation of test port group from an NPC (DELETETPG), takes the NPC out of service (REMOVE), and unprovisions it (DELETE).



**NOTE:**

If test ports are in use, DELETETPG first releases and de-grows the ports, then de-grows the test port group.

To delete a Test Port Group, follow these steps:

1. Proceed from the MAIN MENU to TEST PORT PROVISIONING and enter the following data to remove the designation of Test Port Group from the NPC:
  - **Site Name:** DACS00
  - **Action:** DELETETPG
2. A third line appears on the screen. Enter **Test Port Group:** 1
3. Press **EXECUTE** and confirm. Observe the I-2000 command completion message.
4. Press **QUIT**.
5. To take the NPC out of service, navigate to NPC PROVISIONING.
6. To identify the NPC, enter:
  - **Site Name:** DACS00
  - **Action:** REMOVE
  - **NPC ID:** 999120

The NPC Number in hierarchical and extended format is displayed, as well as the **Type**.
7. Press **EXECUTE** and select IMMEDIATE. The result is that:
  - **Service State** field now says OOS.
  - **Alarm State** now says NONE.
  - Command completion message is displayed.
8. Enter the following field: **Action:** DELETE
9. Press **EXECUTE** and select IMMEDIATE.
  - **Service State** field changes to UEQD. In addition, a command completion message is displayed.

---

## Contents

<b>Introduction</b>	6-1
<b>CIRCUIT PROVISIONING Form</b>	6-5
■ Field Descriptions	6-8
■ Summary of Fields And Values	6-22
<b>Circuit Provisioning Examples</b>	6-24
■ Example: Circuit Provisioning, Full-duplex Circuit	6-25
■ Example: Circuit Provisioning, Clear DS1 Full-duplex Circuit	6-26
■ Example: Circuit Provisioning, Half-duplex Circuit	6-27
■ Example: Circuit Provisioning, Half-Duplex Loopback Circuit	6-28
■ Example: Circuit Provisioning, Full-Duplex Loopback Circuit	6-29
■ Example: Circuit Provisioning, Full-Duplex Random Loopback Circuit	6-30
■ Example: Circuit Provisioning, High-Rate Circuits From Multiple Circuits	6-30
■ Example: Circuit Provisioning, Virtual Multipoint Circuits	6-32
■ Example: Circuit Provisioning, DMB Multipoint Circuits	6-35
■ Procedure: Circuit Provisioning, Polling Data Circuit	6-38
■ Cascaded Multipoint Circuits	6-40
<b>BCON Circuits</b>	6-43
■ Example: Adding a LEG to a Full-Duplex Contiguous 64 Kbps Circuit	6-43
■ Example: Adding a LEG to a Random Bandwidth 4 Circuit	6-44
■ Example: Adding a LEG to a Clear E1 Circuit	6-45

---

## Contents

■ Example: Modifying a BKB From an Existing Circuit	6-47
■ Example: Deleting a LEG from a BCON Circuit	6-48
■ Example: Changing the Return Path of a BCON Circuit	6-49
<b>TS0 to Non-TS0 Circuits</b>	6-50
■ Example: Provisioning TSO to Non-TSO Circuits	6-50
<b>Circuit Provisioning ERP</b>	6-51
■ Procedure: Disabling Echoed Response Processing	6-54

---

## Introduction

---

Circuit provisioning is a process of defining cross-connections between external facility terminations in the DACS.

A cross-connection can be established either as an elementary circuit (one cross-connection) or as multiple cross-connections. Multiple cross-connections are combined in complex circuits. These cross-connections are established on the CIRCUIT PROVISIONING form. Complex circuits, in most cases, require using multiple forms.

The execution of a properly filled out CIRCUIT PROVISIONING form sends the appropriate commands to the DACS to physically establish the cross-connection. In addition, the I-2000 records the circuit definition in the I-2000 and DACS databases.

Alternatively, you can have the circuit recorded in the I-2000 database only, in which case no DACS cross-connection is made, or in the DACS database only, in which case no data is changed in the I-2000 database. Refer to "Using the RECNCILE Key" in Chapter 2 "Getting Started."

The I-2000 supports a variety of circuit types, depending on what DACS hardware is present. Hardware and NPC types are described in Chapter 4, "NPC Provisioning." For complete details concerning the circuit types, refer also to the *DACS II Operations and Maintenance Manual*. A brief summary of the supported circuit types is stated here.

A cross-connection is similar to plugging each end of a jumper cable into a selection of plugs, which was the procedure followed on the first types of frames ever built. In the electronic switching environment, the plugs are represented by external facility terminations (EFTs), or channels, and the former cables are now electronic paths in the supporting hardware switching modules, which are integrated circuits (ICs). Cross-connections are between EFTs and are controlled by computer.

The type of connection depends on the circuit pack providing it. Every I-2000 can cross-connect the following types of circuits, supported by standard DDCs and DPCs. (You should be familiar with the frame terminology used below; however, if you are not, refer to the Glossary.)

- Single-channel, two-point, one-way or two-way circuits.
- Single-channel, two-point, one-way or two-way circuits between NAS NPCs and CEPT NPCs (gateway circuits).
- High-rate, or high bandwidth (multichannel), NAS, CEPT, or gateway two-point, one-way or two-way circuits. The maximum bandwidth for NAS and gateway is 24 channels per circuit; for CEPT, 32.
- Virtual multipoint, one-way, receive-only broadcast circuits of bandwidth 1 through 24 for NAS or 1 through 32 for CEPT. Gateway circuits are allowed, with a bandwidth up to 24.
- BCON circuits of bandwidth 1 through 24 for NAS or 1 through 32 for CEPT. Gateway circuits are allowed, with a bandwidth up to 24.

If DMB circuit packs are installed in the frame, the following DMB multipoint two-way circuits are available in single-channel bandwidth only:

- Symmetric voice circuits. Each station can communicate both ways at all times, but the I-2000 allows disabling of transmission in one direction (**NTR** field).
- Polling data circuits. Equipment is polled one way and the replies are sent the other. Again, the I-2000 allows disabling of transmission in one direction.

If the frame features a TG80 Card, this circuit is available, NAS only:

193-bit, clear DS1, half-duplex, full-duplex, or BCON.

If the frame features a TG192 card, this circuit is available, CEPT only:

256-bit, clear E1, half-duplex, full-duplex, or BCON.

If a DS3 shelf containing DS3 circuit packs is present in the frame, these circuits are available, NAS only:

- Channelized DS3; such as 28 channelized DS1 signals per DS3 circuit pack. Each DS1 signal becomes 24 NAS-only DS0 channels, which can be connected in bandwidths of up to 24. There are no CEPT DS3s; however, gateway circuits with other NPCs that are CEPT are supported.
- DS3 with 28 clear DS1s, full- or half-duplex only.

When a form is executed, the I-2000 makes use of a number of MML commands to achieve the appropriate cross-connections, or to disconnect them. Some of these commands are CONN and DISC in MML, with the appropriate parameters to specify one- or two-way, or clear, etc.

This partial list gives you some idea of the large variety of cross-connect and disconnect commands available to the I-2000. In general, there is no one-to-one correspondence between MML commands and I-2000 circuits.

For example, high-rate circuits in the I-2000 are implemented in the DACS as a range command or individual one- or two-way circuits, depending on the **Bandwidth Type** chosen (*Contiguous, Alternating, or Random*). To the frame operator, the complex process of building circuits by individual MML commands, and selecting from a large variety of types with many possible parameters; becomes a much simpler process using I-2000 by filling out unit forms.

Initially, you must use the NPC PROVISIONING form to **CREATE** the NPCs that will be used in establishing a circuit. At that time, you specify the **Type** of NPC that you want to **CREATE**. Then you must place the NPCs in service, again under NPC PROVISIONING. At that point you are ready to **ACTIVATE** a specific type of circuit between appropriate NPCs that are in service. Attempts to **ACTIVATE** circuits between NPCs that are inappropriate to the type of circuit are rejected.

If an **ACTIVATE Action** fails, the I-2000 will attempt to undo any connection it has already put up. In the case of a timeout, the I-2000 sends a disconnect command.

The most important characteristic of any circuit is its operating status. When you enter a **Ckt ID** for a circuit that is not on record in the I-2000 database, the **Ckt Status** field on the screen is assigned a **NULL**. Any other **Ckt Status** means that a circuit of that ID is on record.

To successfully **ACTIVATE** a circuit means to cross-connect it as a successful, traffic-bearing circuit. In that case, the **Ckt Status** is **ACTIVE**. However, you do not have to **ACTIVATE** a circuit to place it on record; a **PEND Action** places it on record in **PENDING Ckt Status**.

When a circuit is disconnected, it does not automatically disappear. It remains in the database as **DEACTIVATED**, **ALTROUTED**, or **PREEMPTED**, depending on how it was disconnected. These **Ckt Statuses** are covered in greater detail in this and the following chapters. To return a circuit to **NULL**; for example, to delete it, enter an **Action** of **DELETE**.

The type of circuit is determined mainly by **Ckt Class**, **Bandwidth**, **Options**, and the EFT identifiers.

- **Ckt Class** is the most significant. Through it you can specify two-way or, one-way, virtual multipoint, DMB multipoint, and BCON circuits.
- The EFT identifiers determine whether the connections are entirely NAS, entirely CEPT, or gateway.
- However, if you connect NAS with CEPT EFTs, you need to make sure the NAM keyword of **Options** is unselected; for example, that a-to-mu law conversion is in effect.
- High-rate circuits are specified with **Bandwidth**.

For instructions on how to activate specific types of circuits, refer to "Circuit Provisioning" in this chapter.

---

\* Traffic-bearing refers to the fact that the circuit is marked as cross-connected and, in theory, is capable of supporting customer traffic. However, the **Service State** of the NPC (In Service or Out of Service), as well as external parameters beyond control of the I-2000, will affect the ability of the cross-connect to actually carry customer traffic.

A circuit is considered to go from one external facility termination (EFT) to another, or from one set of EFTs to another (high-rate). One side is, therefore, considered FROM and the other is considered TO. These conventions apply to all circuits established with one CIRCUIT PROVISIONING form. For one-way circuits (half duplex), the transmitting side must be considered FROM. For two-way circuits, either side can be FROM or TO, since the circuit is full duplex. Whatever NPC and channel you enter under **FROM NPC** and **FROM Ch** is the FROM EFT.

The **ACTIVATE Action** sends a command to connect EFTs that are IS. If the NPC of an EFT should go OOS after the circuit is in **ACTIVE Ckt Status**, the circuit remains **ACTIVE**. You can disconnect it immediately by setting **Options D** (OOS). If you neglect to do that and attempt to **DEACTIVATE** or **DELETE** the circuit, the I-2000 would need to send two commands before disconnection would be successful.

You can red-line the circuit as not to be disconnected without authorization, through the RDLD and INCL **Options**.


Once a circuit is in place, you may want to test it. Refer to Chapter 5, "Test Port Provisioning," and Chapter 15, "Test Access," which describes provisioning test ports and connecting test circuits. You may want to terminate normal traffic through circuits that have also been connected for testing, so that they can be tested under optimum conditions. The Terminate and Leave command to the frame is useful for that purpose. It is a switch. When Terminate and Leave is activated, normal traffic on the circuit is terminated, or discontinued; when released, continued. Accordingly, the I-2000 defines the TLA Option (Terminate and Leave Activated), which, when not selected, becomes TLR (Terminate and Leave Released).

**NOTE:**

Do not confuse the CIRCUIT PROVISIONING **TLA** and **TLR Options** with the test circuit **TERMINATE** and **RELEASE Actions** or with the frame's **TLA** and **TLR** commands.

A TS0 cross-connect feature is supported by I-2000 NPC and CIRCUIT PROVISIONING, for CEPT circuits of **Type PA** NPCs and **Bandwidth 1** only. In the CEPT standard, channel 0 (time slot 0) is used to transmit the framing pattern and other data channel information. For various reasons, you may want to utilize channel 0 for other purposes, such as transmitting alarm information, or for testing, and therefore you may want to connect it to some channel other than 0 in some other CEPT NPC. This is a special case, and requires a value in the **Framing** field.

Figure 6-1 shows two sequential time frames in one direction for two different NPCs. Channel 0 (time slot 0) is to be connected to channel 1 (time slot 1). The last 7 bits of the first time frame's channel 0 contain an arbitrary pattern, the framing word (FW), which is used to identify the beginning of a pair of time frames. Channel 0 of the alternate time frame contains the non-framing word (NFW), consisting of 8 bits used to transmit various signals.



**Figure 6-1. Circuit Provisioning Example—Two Sequential Time Frames**

If you connected channel 0 unmodified to channel 1, the FW would appear twice within the pair of time frames on NPC b, and therefore would destroy the framing sequence. The **Framing** field allows you to insert another arbitrary pattern, the pseudo-FW, into the stream of frames on NPC b. Alternatively, you can communicate the NFW of NPC a to both frames of NPC b. In either case, the NFW is used to transmit the channel data you want to transmit.

The FW and the NFW each consist of 8 bits. Bit 1 of the FW and bits 1 through 8 of the NFW are not used for framing purposes and therefore are called the spare bits. Spare bit manipulation also is supported. To access these bits, however, use the **NFS** field on the NPC PROVISIONING form.

There are two types of BCON circuit classes *backbone circuits* (BKB) and *tributary circuits* (LEG). BKB circuits are used as the backbone circuit in BCON provisioning. LEG circuits are used as the tributary circuit in BCON provisioning. To create a BCON circuit through the I-2000 user interface, create a Full Duplex circuit and add a LEG. The Full Duplex circuit will be converted into a BCON backbone with the new leg. Similarly, when the last LEG of a BCON circuit is deleted through the I-2000 user interface, the remaining backbone will be converted back to a Full Duplex circuit automatically. The Circuit ID of a LEG circuit is automatically generated during execution of the ADDLEG action, and is displayed after the action completes.

You can modify a BCON circuit by adding a leg (ADDLEG), deleting an existing leg (DELLEG), or by changing the base name (MODIFY of BKB). BCON circuits cannot be DEACTIVATED, ALTROUTED, PREEMPTED, or COMBINED.

## **CIRCUIT PROVISIONING Form**

Select CIRCUIT from the PROVISIONING menu. The CIRCUIT PROVISIONING form is displayed, as shown in Figure 6-2.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- CIRCUIT PROVISIONING -----
Site Name:
Action:                               Ckt Status:
Ckt ID:                               Ckt Class:BRD
BBL ID:                               Bandwidth Type:
      Hier      Ext      NPC ID              Ch      Mode
FROM:
TO:
Bandwidth:                            Options:
TC:                                    IW:      SC:                Framing:
Loc A:                                Loc Z:
Customer Name:                        Service Date:DD MMM YY  Ckt Priority:00
Rmks:
Enter the site name _____
HELP CHOICES NEXTPAGE QUIT RECNCILE TOP MENU PRINT EXECUTE

```

**Figure 6-2. CIRCUIT PROVISIONING Form**



**NOTE:**

**BBL ID** appears only for **Ckt Class** BRD. **NEW ID** appears in place of **BBL ID** for **Action** MODIFY. **LEG ID** appears in place of **BBL ID** for **Action** ADDLEG, DELLEG, and CHGRPATH. **Mode** and **NTR** appear only for **Ckt Class** DMB. **TC**, **IW**, **SC**, **Bandwidth**, and **Bandwidth Type** disappear if you enter an NPC that is clear DS1/E1. If the **Bandwidth Type** is Random, the **Ch** column will be removed and rows for the FROM and TO random channels (**F\_CH**) and **T\_CH**) will appear. A row for BCON LEG channels (**L\_CH**) will appear for Random BCON circuits.

You can browse through the circuits stored in the I-2000 database. In that case, you will use the CIRCUIT PROVISIONING SEARCH CRITERIA form, which is displayed after you enter an **Action** of BROWSE and press **EXECUTE**. The CIRCUIT PROVISIONING SEARCH CRITERIA form is displayed, as shown in Figure 6-3.

```
06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
_____ CIRCUIT PROVISIONING SEARCH CRITERIA _____
Site Name:
Ckt ID:
Ckt Status:          Ckt Class:

FROM/TO Connection:
  Hier      Ext      NPC ID                      Ch  Mode

Bandwidth:  Bandwidth Type:  Options:      NTR:
TC:         IW:             SC:          Framing:

Customer Name:          Service Date:DD MMM YY  Ckt Priority:
Loc A:                  Loc Z:
Rmks:

Enter the Circuit ID _____
```

HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE

**Figure 6-3. CIRCUIT PROVISIONING SEARCH CRITERIA Form**

## Field Descriptions

Field descriptions for Circuit Provisioning are described in Table 6-1.

**Table 6-1. CIRCUIT PROVISIONING Field Descriptions**

<b>Site Name</b>	<p>Mandatory. 1 through 24 characters from the set A-Z, a-z, 0-9, /, _, and -. All other characters are illegal. Blanks are not allowed within a name.</p> <p>The name of the frame where the requested <b>Action</b> will take place. Pressing <b>CHOICES</b> displays WHICH DACS? with a list of the frame names. These names were established during frame administration, described in Chapter 3 "System Administration."</p>
<b>Action</b>	<p>Mandatory. Enter the action to be performed with regard to the circuit.</p> <p><b>ACTIVATE</b>      Enters the circuit specified by <b>Ckt ID</b> in the I-2000 database (if it does not yet exist) and cross-connects it in the frame, making it an existing, traffic-carrying circuit. <b>ACTIVATE</b> also changes the <b>Ckt Status</b> of already existing circuits from <b>PENDING</b>, <b>PREEMPTED</b>, or <b>DEACTIVATED</b> to <b>ACTIVE</b> and from <b>ALTROUTED</b> to <b>ACTIVE</b> in <b>local only</b> mode. <b>ACTIVATE</b> is the default <b>Action</b>.</p> <p><b>MODIFY</b>      Retrieves the specified circuit from the I-2000 database for purposes of altering circuit attributes or <b>Ckt ID</b>. <b>MODIFY</b> does not change the <b>Ckt Status</b>. You can <b>MODIFY</b> any user-accessible field for circuits in the <b>PENDING</b> or <b>DEACTIVATED</b> <b>Ckt Status</b>. You can <b>MODIFY</b> the following fields for circuits in the <b>ACTIVE</b> or, <b>PREEMPTED</b> or <b>ALTROUTED</b> <b>Ckt Status</b>:</p> <p>Non-service affecting fields: <b>Ckt ID</b>, <b>Customer Name</b>, <b>Service Date</b>, <b>Ckt Priority</b>, <b>Loc A</b>, <b>Loc Z</b>, <b>Rmks</b>, <b>Options</b>: OOS, INC, DCC.</p> <p>Service affecting fields: <b>TC</b>, <b>IW</b>, <b>SC</b>, <b>Framing</b>, <b>NTR</b>, <b>Options</b>: NAM, AIS, RDLD.</p> <p> <b>CAUTION:</b> <i>Changes to service affecting fields will interrupt traffic.</i></p>

Table 6-1. CIRCUIT PROVISIONING Field Descriptions (Contd)

<b>Action</b> <b>(Continued)</b>	DELETE	<p>Removes the specified circuit from the I-2000 and DACS databases, returning the <b>Ckt Status</b> to NULL.</p> <p> <b>NOTE:</b>          Deletion of an ACTIVE circuit results in deactivation of the circuit in the DACS before the record is deleted in the I-2000.</p> <p>Deletion of an ALTROUTED circuit results in normalization of the circuit in the DACS before the record is deleted in the I-2000.</p> <p>Deletion of a circuit that is listed in a Reconfiguration Plan is not allowed (except in local only mode). First delete it from the plan.</p>
	PEND	<p>Enters the specified circuit (including DEACTIVATED ones) in the I-2000 database as PENDING, to indicate it may soon be made ACTIVE. Activation of PENDING circuits may be dependent on equipment installation or on other sections of the circuit being established.</p>
	DEACTIVATE	<p>Enters the specified circuit in the I-2000 database as DEACTIVATED and disconnects it in the frame.</p>
	ALTROUTE	<p>Enters the specified circuit in the I-2000 database as ALTROUTED. The I-2000 may reroute the specified circuit over a path involving the preemption of other circuits. The operator will be informed of each preemption and will be required to confirm it. A circuit can be altrouted only once, and an ALTROUTED circuit cannot be preempted.</p>
	NORMALIZE	<p>Tries to place a real altrouted circuit in ACTIVE <b>Ckt Status</b> or a pseudo-altrouted circuit in DEACTIVATED <b>Ckt Status</b>. If the circuit returns to ACTIVE, it is cross-connected in the frame over its normal path. If the circuit returns to DEACTIVATED, it is not cross-connected in the frame.</p> <p>During the altrouting, one or more circuits may have been placed in the PREEMPTED <b>Ckt Status</b>. If the circuit now being normalized is the only circuit preempting a PREEMPTED circuit, NORMALIZE attempts to return the PREEMPTED circuit to ACTIVE. Otherwise, NORMALIZE does not make the attempt.</p>

Table 6-1. **CIRCUIT PROVISIONING Field Descriptions (Contd)**

<b>Action</b> <b>(Continued)</b>	BROWSE	<p>Gives you read-only access to the I-2000 database for retrieving and scrolling circuit records.</p> <p>As soon as you press <b>EXECUTE</b> after entering an <b>Action</b> of BROWSE, the I-2000 displays the CIRCUIT PROVISIONING SEARCH CRITERIA form. Its fields are taken from the CIRCUIT PROVISIONING form. Entering a value in any defined field restricts the search. To initiate the search, press <b>EXECUTE</b>. To return to CIRCUIT PROVISIONING without executing, press <b>QUIT</b>.</p> <p>The following rules apply:</p> <ul style="list-style-type: none"> <li>— You can search on <b>Ckt ID, Ckt Status, Ckt Class, NPC ID, Mode, Bandwidth Type, Options, NTR, TC, IW, SC, Framing, Customer Name, Ckt Priority, Loc A, Loc Z, Rmks.</b></li> <li>— The default for all fields is all values of the fields.</li> <li>— The wildcard character, *, replaces zero or more characters. The ? replaces any single character. Wildcards are allowed in all alphanumeric fields except <b>Options</b>.</li> <li>— The character, &lt;, followed by a value, in numeric fields: <b>Hier, Ext, Ch, Bandwidth, Service Date</b>, obtains records for values less than the entered value; the character, &gt;, greater.</li> </ul>
	COMBINE	<p>Combines multiple circuits that exist over either an alternate or a contiguous range of channels into a single, new high-rate circuit in the I-2000 database. The source circuits must be ACTIVE and the combined circuit is made ACTIVE.</p> <p>Remember, high-rate circuits are implemented in the frame as single-channel circuits; thus, they are already in the frame. After the source circuits have been deleted in the I-2000 database, the combined circuit is created there. At no time during the process is a command sent to the frame.</p> <p>The <b>Circuit Classes</b> of the source circuits must be all HDX or all FDX only. Use of channel 0 and of test circuits is prohibited.</p>

Table 6-1. CIRCUIT PROVISIONING Field Descriptions (Contd)

<p><b>Action</b> <b>(Continued)</b></p>	<p>Specify the combined circuit characteristics on a single CIRCUIT PROVISIONING form. The channel numbers in the combined circuit are the same as the source circuits'; however, the <b>Bandwidth</b> of the combined circuit must be made equal to the sum of the <b>Bandwidths</b> of the source circuits. Therefore, the source circuits' channels must run contiguously or alternately upward from the combined circuit's starting channel, and the combined <b>Bandwidth Type</b> must be correct for the channels</p> <p>The following fields of the source circuits must have the same values: <b>TC, IW, SC, Circuit Class. Options</b> settings of RDL and no NAM must be the same throughout.</p> <p>The <b>Ckt ID</b> of the combined circuit can be unique, or it can be one of the source circuits' <b>Ckt IDs</b>. You can reuse the <b>Ckt ID</b> of a DEACTIVATED or PENDING circuit, provided all the channels of that circuit are also in use by the ACTIVE source circuits. No other cases are allowed.</p> <p>ADDLEG Adds a LEG to an existing BKB circuit. This action can also convert an existing FDX circuit to a BKB and add the first LEG Ckt ID (automatically populated and displayed) when this action is completed successfully.</p> <p>DELLEG Deletes a LEG from an existing BKB circuit. If it is the last LEG in the remaining backbone (BKB) circuit, it will be automatically converted to a FDX circuit.</p> <p>CHGRPATH Changes the return path for a BCON circuit to the specified LEG. It has the effect of swapping the BKB and LEG circuit.</p>
<p><b>Ckt Status</b></p>	<p>A display only mode indicating the status of the circuit.</p> <p>NULL The circuit has not been defined and, therefore, is not in the frame or I-2000 databases. To define the circuit, use the <b>ACTIVATE Action</b>.</p> <p>PENDING The circuit is in the I-2000 database, but is not cross-connected in the frame. The circuit has been noted as PENDING with the <b>PEND Action</b>. It is ready to be made ACTIVE on user request. To cross-connect the circuit, use the <b>ACTIVATE Action</b>.</p> <p>DEACTIVATED The circuit is in the I-2000 database but is not cross-connected in the frame. The I-2000 record is marked DEACTIVATED. To cross-connect the circuit, use the <b>ACTIVATE Action</b>.</p>

Table 6-1. CIRCUIT PROVISIONING Field Descriptions (Contd)

<b>Ckt Status</b> <b>(Continued)</b>	<p><b>ALTROUTED</b> The circuit is present in the frame and I-2000 databases, is cross-connected in the frame, and is carrying transmission. However, it was temporarily rerouted over an alternate path with an <b>ALTROUTE Action</b>. If any part of the alternate path was in use by another circuit, that circuit was placed in <b>PREEMPTED Ckt Status</b>. A <b>NORMALIZE Action</b> is required to return the <b>ALTROUTED</b> circuit to its original path.</p> <p><b>PREEMPTED</b> The circuit was <b>ACTIVE</b> in the frame but has been temporarily disconnected so that one or more of its channels can be used by one or more <b>ALTROUTED</b> circuits. The circuit is in the I-2000 database only and is not carrying transmission. The <b>NORMALIZE</b> commands that return the <b>ALTROUTED</b> circuits to normal also return the <b>PREEMPTED</b> circuits to normal.</p> <p><b>ACTIVE</b> The circuit is present in the frame and I-2000 databases, is cross-connected in the frame, and is carrying transmission. A circuit can be defined in the I-2000 database, but if it is not <b>ACTIVE</b>, it is not defined in the frame database. A circuit that exists in the frame is in both the frame and I-2000 databases (unless there is a discrepancy).</p> <p><b>P_ACTIVE</b> The <b>P_ACTIVE</b> status will be applied to partially connected n x 64 Kbps BCON circuits through the echoed response process (ERP). <b>P_ACTIVE</b> status marks the n x 64 Kbps circuit when there is at least one disconnected cross-connect in the LEG circuit from ERP.</p> <p>The bandwidth in a <b>P_ACTIVE</b> LEG circuit is the number of <b>ACTIVE</b> (connected) cross-connects in that circuit.</p> <p><b>DEROUTED</b> The circuit was in <b>ALTROUTED Ckt Status</b> but was placed in <b>DEROUTED Ckt Status</b> at the beginning of an NPC ROLL, and the system failed during the roll. You can <b>DELETE</b>, <b>DEACTIVATE</b>, or <b>NORMALIZE</b> a <b>DEROUTED</b> circuit. If the roll completes successfully, you will never observe the circuit in <b>DEROUTED Ckt Status</b>.</p>
<b>Ckt ID</b>	<p>Mandatory. must be unique. One through 41 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored.</p> <p>Associates the name entered in this field with the circuit described by this form.</p>

Table 6-1. CIRCUI T PROVISIONING Field Descriptions (Contd)

<b>BBL ID</b>	Appears when the <b>Ckt Class</b> is BRD. Mandatory, when activating a new BRD circuit. One through 41 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored.	
<b>LEG Ckt ID</b>	Appears when the action is ADDLEG, DELLEG, or CHGRPATH. When the Action is ADDLEG, this is a display-only field that is automatically filled in after the action is executed. One through 41 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored.	
<b>Ckt Class</b>	FDX	Full-duplex. Applies to single-channel or high-rate DS0 cross-connections between NAS or CEPT NPCs, and to gateway circuits. Specifies a two-way, two-point circuit. FDX can be abbreviated to F.
	HDX	Half-duplex. Applies to single-channel or high-rate DS0 cross-connections between NAS or CEPT NPCs, and to gateway circuits. Specifies a one-way, two-point circuit. HDX can be abbreviated to H.
	BBL	Backbone leg. Applies to single-channel or high-rate, DS0, virtual multipoint circuits between NAS or CEPT NPCs, and to gateway circuits. These circuits are complex; which are composed of multiple cross-connections requiring multiple CIRCUI T PROVISIONING forms. A <b>Ckt Class</b> of BBL identifies this unit as a one-way backbone leg broadcast circuit. Abbreviation not allowed (not unique).
	BRD	Broadcast, or branch, leg. Applies to single-channel or high-rate, DS0, virtual multipoint circuits between NAS or CEPT NPCs, and to Gateway circuits. Specifies a one-way branch leg broadcast circuit. Abbreviation not allowed (not unique).  In virtual multipoint operations, enter the BBL first. With existing circuits, <b>Ckt Class</b> is known and protected, and the field cannot be changed.  In Site and local mode, you can not enter the FROM side NPC of any BRD, such as the virtual node. It is selected by the system. Up to 20 BRDs can be entered for one BBL.

Table 6-1. CIRCUIT PROVISIONING Field Descriptions (Contd)

<b>Ckt Class (Continued)</b>	<p>DMB Digital multipoint bridge. Applies to single-channel, two-way, multipoint circuits. These circuits are complex; for example, are composed of multiple cross-connections requiring multiple CIRCUIT PROVISIONING forms. A <b>Ckt Class</b> of DMB identifies this cross-connection as a unit in a DMB circuit. The two types of DMB multipoint circuits are the symmetric voice circuit and the polling data circuit.</p> <p>Provision the backbone first and the branches subsequently. Use a <b>Mode</b> of LEG to identify an EFT, but a <b>Mode</b> of BBL or BRD on the opposite side of each leg to identify its use as a backbone or branch.</p> <p>Be sure to read the operating examples for DMB. The examples also cover cascading, the building of still more complex circuits using DMB circuits as units.</p> <p>BKB A circuit is classified as a BKB class if it is being used as the backbone circuit in BCON provisioning.</p> <p>LEG A circuit is classified as a LEG class if it is being used as the tributary circuit in BCON provisioning. LEG circuits have the same parameters as the BKB circuit that it belongs to except for the following:</p> <p style="padding-left: 40px;">Circuit ID Circuit status Circuit class Service date</p> <p>If a LEG circuit is classified as P_ACTIVE, its bandwidth will be smaller than the bandwidth of its BKB circuit.</p>
<b>Dir</b>	<p>Optional. This field appears only when the action is ADDLEG or when browsing a BCON BKB. This field defines which side of the backbone is the source broadcast side, <b>FROM</b> or <b>TO</b>.</p> <p>Mandatory. This field is mandatory when the first leg is added to a FDX circuit which will become the BKB.</p>
<b>NEW ID</b>	<p>New circuit ID. 1-41 characters. Appears only when the <b>Action</b> is MODIFY. One through 41 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored.</p>

Table 6-1. CIRCUI T PROVISIONING Field Descriptions (Contd)

<b>Bandwidth Type</b>	<p>Mandatory. Indicates how bandwidth is allocated in an NPC; valid entries are:</p> <p>C Contiguous A Alternating R Random</p> <p>Alternating bandwidth is allocated on alternate channels. A maximum of 12 channels are available for NAS; 16 for CEPT. Contiguous bandwidth is allocated on consecutive channels. For example, starting with Channel 5, a <b>Bandwidth</b> of 3 allocates 5, 6, and 7 for contiguous; 5, 7, and 9 for alternating.</p> <p>Random permits allocation of channels between two NPCs in a random fashion; for example, channel 1 to channel 10, 2 to 5, 3 to 7, etc. The default is A. The value is set to C for a <b>Ckt Class</b> of DMB.</p> <p>You can scroll through the <b>FROM</b> and <b>TO</b> fields for information on the channel series by pressing <b>[NEXT]</b>. If you do this and find the <b>Bandwidth</b> of the circuit is greater than 1, then the circuit is a high-rate circuit. For example, if the <b>Bandwidth</b> is 5, you can scroll from 1 through 5 and the channels for both the <b>FROM</b> and the <b>TO</b> fields scroll along in synchronization.</p> <p>This field disappears for clear DS1/E1 connections.</p>
<b>Hier</b>	<p>An NPC number in hierarchical format. (See Chapter 4, "NPC PROVISIONING" for an explanation of hierarchical and extended formats.) As shown in the diagrams under <b>Ckt Class</b> above, an NPC identifier for the NPC of the FROM channel and another for the NPC of the TO channel are required for one-way and two-way, two-point circuits. For the <b>ADDLEG</b> action, there is an identifier for the NPC of the leg channel. The identifier can be a number in hierarchical format, a number in extended format, or the <b>NPC ID</b>. The NPC must have been provisioned.</p>
<b>Ext</b>	<p>The FROM or TO NPC number in extended format. For the <b>ADDLEG</b> action, there is an identifier for the NPC of the leg channel. Automatically provided if <b>Hier</b> or <b>NPC ID</b> was entered.</p>
<b>NPC ID</b>	<p>The FROM or TO <b>NPC ID</b>. With the entry of a value in <b>Hier</b>, <b>Ext</b>, or <b>NPC ID</b>, the I-2000 automatically performs a database query and displays the corresponding FROM or TO information in each field. For the <b>ADDLEG</b> action, there is an identifier for the NPC of the leg channel.</p>

**Table 6-1. CIRCUIT PROVISIONING Field Descriptions (Contd)**

<b>Ch</b>	<p>The FROM or TO channel number, 0-31 for CEPT or 1-24 for NAS. This field is displayed for contiguous or alternating circuits.</p> <p>Virtual channel numbers can range from 1 to 500; however, one is automatically selected by the system during provisioning of virtual multipoint circuits.</p> <p>For the ADDLEG action there is an identifier for the LEG channel.</p> <p>For DMB circuits, the DMB-side <b>Ch</b> contains the conference number. It can range from 1 through 85 for DACS II.</p> <p>If the NPC identifying information (<b>Hier, Ext, NPC ID</b>) indicates that this is a clear DS1/E1 or DS3 configured as clear DS1 <b>Type</b> of NPC (see Chapter 4), then the value, DS1/E1, appears in the FROM <b>Ch</b> field. The <b>TC, IW, SC, Bandwidth</b>, and <b>Bandwidth Type</b> fields disappear. If you attempt to enter a DS0 <b>TO Ch</b>; for example, to cross-connect clear DS1 to DS0, the previously mentioned fields reappear and you get a warning message:</p> <p>WARNING: Non-clear DS1 can not connect to Clear DS1 NPC.</p>
<b>Mode</b>	<p>Appears only when the <b>Ckt Class</b> is DMB. Specifies the use of the preceding <b>Ch</b> in a DMB multipoint circuit.</p> <p>SYM The associated channel is to be used as the DMB side of a leg in a symmetric voice circuit.</p> <p>BRD The associated channel is to be used as the DMB side of a broadcast, or branch, leg of a polling data circuit.</p> <p>BBL The associated channel is to be used as the DMB side of the backbone leg of a polling data circuit.</p> <p>LEG The associated channel is to be used as an EFT in any leg of the circuit.</p> <p>A DMB channel must be in a DMB NPC.</p>
<b>Bandwidth</b>	<p>Mandatory. Two numeric characters. Indicates the number of 64 Kbps channels constituting a high-rate circuit. For example, a 128 Kbps data channel consists of two 64 Kbps channels.</p> <p>For NAS NPCs, the available bandwidth is 1-24 channels; for CEPT NPCs, the available bandwidth is 1 through 32 channels.</p> <p>If not specified, <b>Bandwidth</b> defaults to 1 channel. It is set to 1 for a <b>Ckt Class</b> of DMB.</p> <p>The bandwidth of a random circuit must be greater than 1.</p> <p>This field disappears for clear DS1/E1 connections.</p>

Table 6-1. CIRCUIT PROVISIONING Field Descriptions (Contd)

<b>Options</b>	<p>Optional. 0 through 7 characters. Names options for activating, deleting, or deactivating the circuit.</p> <p>When you press <b>CHOICES</b> to see the menu of <b>Options</b>, <b>SELECT</b> and <b>UNSELECT</b> function keys appear. The <b>CHOICES</b> menu for this field is a multiselect menu and operates differently from any other I-2000 menu. Pressing <b>Enter</b> does not select the item, as is the case with all other I-2000 menus. Instead, pressing <b>SELECT</b> selects the item. Use <b>SELECT</b> to choose as many options as are appropriate. Press <b>Enter</b> to place them on the screen.</p> <p><b>⇒ NOTE:</b> Only <b>RDL</b>, <b>OOS</b>, and <b>INCL</b> are available for clear DS1/E1 circuits.</p> <p>The choices are as follows. If you type into the field, use only the letter.</p> <p>A <b>NAM</b>. No a-to-mu law conversion is to be applied to the circuit if it is <b>CEPT</b> only; for example, if it is not a gateway.</p> <p>B <b>AIS</b>. Alarm indication signal (all 1s, including the framing bit) is to be asserted on the downstream NPC when it is detected on the upstream NPC or when the upstream NPC asserts a <b>CGA</b>. Applies to <b>NAS</b>, <b>FDX</b>, high-rate circuits of bandwidth 24 only.</p> <p>C <b>RDL</b>. Red-lined. The circuit is to require specific authorization to disconnect; the <b>INCL</b> keyword must be set.</p> <p>For <b>DMB</b> circuits, if one leg of a conference is designated as <b>RDL</b>, all legs must be. This condition applies only to <b>DACS II</b>.</p> <p>D <b>OOS</b>. Out of service. A disconnect is to be effected when the NPC at one or both ends of the circuit are <b>OOS</b>.</p> <p>E <b>INCL</b>. Included. Authorizes disconnects of <b>RDL</b> circuits.</p> <p><b>⇒ NOTE:</b> This <b>INCL</b> keyword applies to a <b>DACS II</b> disconnect only. The <b>INCL</b> keyword (like the <b>CUS</b> keyword) from a <b>DACS II</b> connect is not supported.</p> <p>F <b>DCC</b>. Disconnect channel code. Causes the frame to assert the user-defined disconnect code (specified in the <b>IW</b> field) on disconnected channels.</p> <p>G <b>TLA</b>. Terminate and Leave Activated. If it is unselected, <b>TLR</b>, Terminate and Leave Released is to be in effect for this circuit.</p>
----------------	---

Table 6-1. CIRCUIT PROVISIONING Field Descriptions (Contd)

Options (Continued)	<p>⇒ <b>NOTE:</b> TLR is the normal state for traffic-carrying circuits. It means that the circuit is not terminated. (Terminate and Leave released. Refer to "Introduction" in this chapter and Chapter 15, "Test Access.") TLA is a state generally used only for initial testing from end to end. If you make a circuit <b>ACTIVE</b> (or <b>ALTROUTED</b>) on the frame in the TLA state, the I-2000 system automatically reverses this state to TLR in the I-2000 database once the command has been sent. To change the termination state of the circuit on the frame back to TLR, send the command again. You would have to reset this field manually to TLA to override this automatic reversal.</p> <p>⇒ <b>NOTE:</b> The unassigned <b>IW</b>, specified under NPC PROVISIONING for the NPC, is transmitted in the terminated direction(s).</p>
<b>NTR</b>	<p>No transmit. Appears only when <b>Ckt Class</b> is <b>DMB</b>. Specifies whether the leg is one-way or two-way.</p> <p>The <b>NTR</b> capability applies only to DACS II.</p> <p>F           Transmission is shut off toward the FROM direction. T           Transmission is shut off toward the TO direction. blanks     Transmission is not shut off.</p>
<b>F_CH</b>	Mandatory. These FROM channel fields appear when the bandwidth is Random (up to 32 fields each).
<b>T_CH</b>	Mandatory. These TO channel fields appear when the bandwidth is Random (up to 32 fields each).
<b>L_CH</b>	Mandatory. These LEG channel fields appear when a bandwidth is Random and the action is <b>ADDLEG</b> .
<b>TC</b>	<p>Trunk conditioning specifies whether A/B-robbed-bit signaling is to be used to signal failure on the specified circuit.</p> <p>This information will only be used during failure of either an incoming signal or an NPC. When the NPC can no longer frame on the signal, it initiates trunk conditioning on all DS0 channels of the NPC. The signaling bits sent during failure are intended to disconnect active calls and hold the circuits busy (if appropriate) for the duration of the failure.</p> <p>DDC circuits require a <b>TC</b> of <b>TRSP</b> and an <b>IW</b> of <b>MUX</b>, which inserts <b>MUX</b> for the duration of the failure, and does not send the signaling bits. The value of <b>TC</b> also is set at <b>TRSP</b> for a <b>Ckt Class</b> of <b>DMB</b>.</p> <p>The <b>TC</b> field disappears for clear DS1/E1 connections; trunk conditioning is not supported for them.</p>

**Table 6-1. CIRCUIT PROVISIONING Field Descriptions (Contd)**

<p><b>TC (Continued)</b></p>	<p>The trunk-conditioning code is:</p> <p>0011, 0011 Default. Indicates the circuit will use A/B signaling. The A/B bits sent upon detection of a failure condition are:</p> <table border="1"> <thead> <tr> <th>Duration of failure</th> <th>FROM Facility</th> <th>TO Facility</th> </tr> </thead> <tbody> <tr> <td>First 2.5 sec</td> <td>00</td> <td>00</td> </tr> <tr> <td>Remainder</td> <td>11</td> <td>11</td> </tr> </tbody> </table> <p>Logic 0 is an on-hook (idle). Logic 1 is an off-hook (busy). Circuits that use A/B signaling must always have an <b>IW</b> specified.</p> <p><b>⇒ NOTE:</b> The <b>TC</b>-value format shown is for FDX, full duplex. For HDX, replace the FROM side's number with hyphens. For an FDX version of X-05, X-63 the HDX result would be X---, X-63.</p> <p><b>⇒ NOTE:</b> It is important to remember that with HDX, you must put hyphens on one side. Virtual multipoint circuits also are HDX.</p> <p>0101, 0101 ----, 0011</p> <p>The previous value is used in connection with four-state signaling only. TRSP</p> <p>Transparent. Indicates the circuit will not use A/B signaling. X-FF, X-FF X-99, X-99 X---, X-FF</p> <p>The previous two values are used in connection with 16-state signaling only. 11111111, 11111111 -----, 11111111</p> <p>If your preferred code is not in the list shown in the <b>CHOICES</b> menu, you can type it on the <b>TC</b> line. However, the syntax must be correct or the frame will not accept it. The I-2000 does not correct or complete it for you. If you specify it incorrectly, the MML command line appears toward the screen bottom with = = (equation marks) surrounding the offending string. See the DACS I/O manual for other valid TC codes and for more information about trunk conditioning.</p>	Duration of failure	FROM Facility	TO Facility	First 2.5 sec	00	00	Remainder	11	11
Duration of failure	FROM Facility	TO Facility								
First 2.5 sec	00	00								
Remainder	11	11								

**Table 6-1. CIRCUIT PROVISIONING Field Descriptions (Contd)**

<b>IW</b>	<p>Insertion Word. Specifies the 8-bit alternate code to be inserted into the DS0 outgoing time slots of mapped channels of an NPC during OOS conditions, including carrier failure and removal of an NPC. The DDC is still sent toward both DS1 lines on unmapped channels. A yellow alarm is sent toward the failed DS1. The selections are:</p> <p>TRB Insert the standard trouble code, Hex E4, or 11100100. You can also enter X-E4.</p> <p>MUX Insert the MUX out-of-sync code, Hex 1A, or 00011010. You can also enter 1A.</p> <p>When DS0 channels of DDS lines are cross-connected in the CCN, TRSP is used for <b>TC</b> and MUX for <b>IW</b>. The latter is inserted in the mapped DS0 channels of the outgoing DS1 line away from the failure. UMC is still inserted on unmapped channels.</p> <p>nn Insert an 8-bit pattern specified by Hex nn. Currently 7F, FF, and BF are selections.</p>
<b>SC</b>	<p>Optional. Signaling conversion is used in CEPT and GATEWAY cross-connections in conjunction with CAS signaling. If the <b>SC</b> field is not specified, all four signaling bits will be cross-connected unchanged. The <b>SC</b> field is defined as:</p> <p>xxxx,yyyy</p> <p>where the first four bits, xxxx, represent the FROM side and the last four bits, yyyy represent the TO side. The comma separator is mandatory. All eight bits can be controlled independently. The valid values for these bits are:</p> <p>P Pass unchanged.  V Pass inverted.  0 Set output to 0.  1 Set output to 1.</p> <p>-No value, the circuit is one-way.</p> <p>All 8 bits are used only for FDX, full duplex. For HDX, replace the FROM side's number with hyphens. For example:</p> <p>0011,0011  in FDX would become</p> <p>----,0011  in HDX.</p> <p>If - is used, all four characters in the group must be -. If they are not, the frame may deny the command.</p> <p>This field disappears for clear DS1/E1 connections.</p>

**Table 6-1. CIRCUIT PROVISIONING Field Descriptions (Contd)**

<b>Framing</b>	<p>The value of the framing bits in the FW in cases where a CEPT channel 0 (time slot 0) is being connected to some other CEPT channel (non-TS0). Refer to the Introduction to this chapter.</p> <p>abcdefg, hijklmn    An arbitrary bit pattern of 0s and 1s, where abcdefg is the pseudo-FW in the TO-FROM direction and hijklmn is the pseudo-FW in the FROM-TO direction. Make sure that the pseudo-FW can in no case be the same as the FW or the NFW.</p> <p>NFW                    Use the NFW in channel 0 of all time frames.</p>
<b>Loc A</b>	Optional. Up to 24 characters. The Station ID of the FROM side of the circuit being provisioned. This field is informational only.
<b>Loc Z</b>	Optional. Up to 24 characters. The Station ID of the TO side of the circuit being provisioned. This field is informational only.
<b>Customer Name</b>	Optional. Up to 12 characters. An informational field only. The name of the customer to be associated with the circuit of this screen. An automatically supplied value of C2000 identifies circuits created by the DACScan-2000 Controller C-Module. An automatically supplied value of ERP identifies circuits created by the ERP feature.
<b>Service Date</b>	<p>Three fields. Enter the date the circuit is first placed into service. The format is:</p> <p style="text-align: center;">dd mmm yy</p> <p>dd    1 or 2 digits that represent the day. Days 1 through 9 do not have to be entered as 01 through 09.</p> <p>mmm    The first three letters of the month, as in Jan, Feb, Mar, . . . Dec. Upper- or lower-case or any combination is acceptable.</p> <p>yy    The last two digits of the year. Entries of 90 through 99 are for the years 1990 through 1999. Entries of 00 through 89 are for the years 2000 through 2089.</p> <p>For example,</p> <p style="text-align: center;">01 Dec 97</p> <p>The default date is today's date.</p>
<b>Ckt Priority</b>	Optional. Circuit priority. Informational only, one or two alphanumeric characters. Indicates to the user the relative importance of the circuit for restoral actions. Regardless of its use, a circuit can not be assigned more than one CP. The default is 00.
<b>Rmks</b>	Optional. 0-72 characters. A user-defined informational field. An I-2000 operator can enter informational comments.

## Summary of Fields And Values

Field values for CIRCUIT PROVISIONING are described in Table 6-2.

**Table 6-2. Summary of CIRCUIT PROVISIONING Field Values**

Name	Field Size	Values
<b>Site Name*</b>	24	Previously created under frame administration.
<b>Action*</b>	10	ACTIVATE, MODIFY, PEND,DELETE DEACTIVATE, ALTRROUTE,NORMALIZE, BROWSE, COMBINE, ADDLEG, DELLEG, and CHGRPATH.
<b>Ckt Status</b>	11	NULL, PENDING, DEACTIVATED,ALTROUTED, PRE-EMPTED, ACTIVE, DEROUTED, and P_ACTIVE.
<b>Ckt ID*</b>	41	All printable characters except *, ?, \, [, ], ^, ", %,  .
<b>BBL ID</b>	41	Previously activated.
<b>NEW ID</b>	41	All printable characters except *, ?, \, [, ], ^, ", %,  .
<b>LEG Ckt ID</b>	41	All printable characters except *, ?, \, [, ], ^, ", %,  .
<b>Ckt Class †</b>	3	FDX, HDX, BBL, BRD, DMB, BKB, and LEG.
<b>Dir</b>	1	F, T
<b>Hier</b>	5	xx yzz, xx is 01-16, y is 1-8, zz is 01-40.
<b>Ext</b>	4	1-x, depending on the frame type and hardware configuration.
<b>NPC ID*</b>	41	All printable characters except *, ?, \, [, ], ^, ", %,  .
<b>Ch†</b>	3	00-24 NAS, 00-31 CEPT, 1-500 virtual, 1-85 DMB with DACS II.
<b>Mode†</b>	3	SYM, BRD, BBL, and LEG
<b>Bandwidth†</b>	2	1-24 NAS, 1-31 CEPT.
<b>Bandwidth Type†</b>	1	A, C, or R
<b>Options**</b>	7	A-G. (applies only to A-C).
<b>NTR**</b>	1	F, T
<b>F_CH</b>	3 (up to 32 fields)	000-031
<b>T_CH</b>	3 (up to 32 fields)	000-031

**Table 6-2. Summary of CIRCUIT PROVISIONING Field Values (Contd)**

Name	Field Size	Values
<b>L_CH</b>	3 (up to 32 fields)	000-031
<b>TC†</b>	17	0011,0011 0101,0101 ----,0011 TRSP X-FF,X-FF X-99,X-99 X---,X-FF 11111111,11111111 -----,11111111
<b>IW**</b>	3	TRB, MUX, 7F, FF, BF.
<b>SC**</b>	9	xxxx,yyyy where x, y = [P, V, 0, 1, -].
<b>Framing</b>	15	abcdefg,hijklmn where a letter is 0 or 1. Alternatively, NFW.
<b>Loc A</b>	24	All printable characters except *, ?, \, [, ], ^, ", %,  .
<b>Loc Z</b>	24	All printable characters except *, ?, \, [, ], ^, ", %,  .
<b>Customer Name</b>	12	All printable characters except *, ?, \, [, ], ^, ", %,  .
<b>Service Date</b>	7	dd mmm yy
<b>Ckt Priority</b>	2	a-z, A-Z, 0-9
<b>Rmks</b>	72	All printable characters except   (pipe).

\* Mandatory field

\*\* Traffic-affecting field

† Both Mandatory and Traffic-affecting fields

## Circuit Provisioning Examples

---

In I-2000 you can provision various types of circuits, such as:

- Full duplex
- Clear DS1/E1
- Half duplex
- BCON circuits
- Loopback
- High rate from multiple circuits
- Virtual multipoint
- DMB multipoint
- Polling data

The examples that follow describe how to provision the various types of circuits available. Provisioning is achieved with the **ACTIVATE Action**. If it succeeds, the **Ckt Status** becomes **ACTIVE**. If it fails, or is denied:

- The **Ckt Status** becomes **NULL**. No entry for the circuit is made in any database.
- Messages relating to the conflict appear in a pop-up. You must press **Enter** to continue.




**CAUTION:**

*Entry of improper data through use of the **RECNCILE** key may result in contradictory data for one or more circuits between the I-2000 and frame databases.*

### Example: Circuit Provisioning, Full-duplex Circuit

One CIRCUIT PROVISIONING form is required to provision a two-way, two-point circuit of **Ckt Class** FDX. Figure 6-4 shows a sample of a full duplex circuit.

⇒ **NOTE:**  
Selection of the NPC determines whether the DS0 channels are provided by NAS DDCs, CEPT DPCs, or DS3 Cards (channelized configuration). The procedure is the same in each case.



**Figure 6-4. Sample Full-duplex Circuit**

To provision a full duplex circuit, follow these steps:

1. Select PROVISIONING from the MAIN MENU and then select CIRCUIT from the PROVISIONING menu. The CIRCUIT PROVISIONING form may already have values in it; these are defaults. The **Ckt Status** field displays NULL.
2. Enter the following data, or use the displayed defaults:
  - **Site Name:** DACS00
  - **Action:** ACTIVATE
  - **Ckt ID:** CKT1
 

If you are making a change to an existing circuit, the current values are filled into the fields on the screen.
  - **Ckt Class:** FDX
 

You can fill in **Hier** or **Ext** instead of **NPC ID**, shown next. Whichever of the three fields you pick, the values of the other two are filled in automatically.
  - **Bandwidth Type:** A
  - **FROM NPC ID:** 55KC35
  - **FROM Ch:** 007
  - **TO NPC ID:** 55US02
  - **TO Ch:** 014
  - **Bandwidth:** 1
  - **TC:** 0011,0011

— **IW:** TRB

3. Press **EXECUTE** and select IMMEDIATE, or use the **RECNCILE** key to select the database and then press **EXECUTE**.

If the command completes successfully: The **Ckt Status** field changes from NULL to ACTIVE. In addition, the command completed successfully message is displayed.


### Example: Circuit Provisioning, Clear DS1 Full-duplex Circuit

One CIRCUIT PROVISIONING form is required to provision a two-way, two-point circuit of **Ckt Class** FDX, where the NPCs are clear DS1, as shown in Figure 6-5.



**NOTE:**

A clear DS1/E1 NPC can only connect to another clear DS1/E1 NPC.



**Figure 6-5. Sample Clear DS1 Full-duplex Circuit**

To provision a circuit with a clear DS1 full duplex circuit, follow these steps:

1. Select PROVISIONING from the MAIN MENU and then select CIRCUIT from the PROVISIONING menu.
2. Enter the following data, or use the displayed defaults:
  - **Site Name:** DACS00
  - **Action:** ACTIVATE
  - **Ckt ID:** CKT1
  - **Ckt Class:** FDX
  - **FROM NPC ID:** 55KC35

**TC, IW, SC, Bandwidth,** and **Bandwidth Type** disappear from the form. **FROM Ch** assumes a value of DS1.

— **TO NPC ID:** 55US02


**TO Ch** assumes a value of DS1.

3. Press **EXECUTE** and select IMMEDIATE, or use the **RECNCILE** key to select the database and then press **EXECUTE**.

If the command completes successfully, the **Ckt Status** field changes from NULL to ACTIVE. In addition, the command completed successfully message is displayed.

### Example: Circuit Provisioning, Half-duplex Circuit

One CIRCUIT PROVISIONING form is required to provision a one-way, two-point circuit of **Ckt Class** HDX. Figure 6-6 shows trunk conditioning is specified and the circuit is TLR (not terminated); for example, it will carry normal traffic.



**Figure 6-6. Sample Half-duplex Circuit**

To provision a circuit with a half-duplex circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** ACTIVATE
  - **Ckt ID:** CKT1
  - **Ckt Class:** HDX
  - **Bandwidth Type:** A
  - **FROM NPC ID:** 55KC35
  - **FROM Ch:** 007
  - **TO NPC ID:** 55US02
  - **TO Ch:** 014
  - **Bandwidth:** 1
  - **TC:** ----,0011
  - **IW:** TRB

3. Press **EXECUTE** and select IMMEDIATE. The result is:
  - The **Ckt Status** field changes from NULL to ACTIVE.
  - The command completed successfully message is displayed.
  - Transmission is shut off toward the FROM direction.
  - Transmission is shut off toward the TO direction.

### **Example: Circuit Provisioning, Half-Duplex Loopback Circuit**

---

One CIRCUIT PROVISIONING form is required to provision a half-duplex loopback circuit. The FROM and TO sides must be the same channel of the same NPC. The cross-connect must be HDX, freeing the return direction. The Tx then loops around to the Rx of the same channel, as shown in Figure 6-7.



---

**Figure 6-7. Sample Half-Duplex Loopback Circuit**

To provision a circuit with a loopback circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** ACTIVATE
  - **Ckt ID:** CKT1
  - **Ckt Class:** HDX
  - **Bandwidth Type:** A
  - **FROM NPC ID:** 55KC35
  - **FROM Ch:** 007
  - **TO NPC ID:** 55KC35
  - **TO Ch:** 007
  - **Bandwidth:** 1

- **TC:** ----,0011
  - **IW:** TRB
3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** field changes from NULL to ACTIVE. In addition, the command completed successfully message is displayed.

### **Example: Circuit Provisioning, Full-Duplex Loopback Circuit**

---

One CIRCUIT PROVISIONING form is required to provision a full-duplex loopback circuit. The FROM and TO sides must be the same channel of the same NPC. The cross-connect must be HDX, freeing the return direction. The Tx then loops around to the Rx of the same channel, as shown previously in Figure 6-7.



**NOTE:**

The full-duplex loopback circuit is *only* available when the environment variable FDX\_LOOP\_CKT is set to 1. For more information on environment variables, refer to Chapter 2 "Getting Started."

To provision a circuit with a loopback circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** ACTIVATE
  - **Ckt ID:** CKT1
  - **Ckt Class:** FDX
  - **Bandwidth Type:** A
  - **FROM NPC ID:** 55KC35
  - **FROM Ch:** 007
  - **TO NPC ID:** 55KC35
  - **TO Ch:** 007
  - **Bandwidth:** 1
  - **TC:** 0011,0011
  - **IW:** TRB
3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** field changes from NULL to ACTIVE. In addition, the command completed successfully message is displayed.

### Example: Circuit Provisioning, Full-Duplex Random Loopback Circuit

---

One CIRCUIT PROVISIONING form is required to provision a full-duplex loopback circuit. The FROM and TO sides must be the same channel of the same NPC. The cross-connect must be FDX. The Tx then loops around to the Rx of the same channel.



**NOTE:**

The full-duplex loopback circuit is *only* available when the environment variable FDX\_LOOP\_CKT is set to 1. For more information on environment variables, refer to Chapter 2 "Getting Started."

To provision a FDX circuit with a random loopback circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** ACTIVATE
  - **Ckt ID:** CKT1
  - **Ckt Class:** FDX
  - **Bandwidth Type:** R
  - **FROM NPC ID:** 55KC35
  - **TO NPC ID:** 55KC35
  - **Bandwidth:** 4
  - **F\_CH:** 10 11 13 25
  - **T\_CH:** 10 11 13 25
  - **TC:** X-FF, X-FF
  - **IW:** FF
3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** field changes from NULL to ACTIVE. In addition, the command completed successfully message is displayed.

### Example: Circuit Provisioning, High-Rate Circuits From Multiple Circuits

---

You may combine multiple circuits into one high-rate circuit on the same NPCs. The procedure given in this example can be used to recombine an original high-rate circuit of Bandwidth *n* that was restored in the I-2000 as *n* single-channel circuits by an UPLOAD or CHANNEL SYNC **Action** under database synchronization. (See Chapter 10, Database Administration.)

The technical reason for this anomaly during synchronization is that the frame, when queried by the I-2000 for its cross-connect map, cannot provide information that  $n$  DS0 cross-connects were actually  $nx$ DS) cross-connects of one high-rate circuit in the I-2000. Therefore, without this critical information, the I-2000 during synchronization is required to generate separate circuit records for each cross-connect extracted from the frame.

You must perform this procedure prior to the DACScan-2000 Controller Circuit Module placing an existing wide-band circuit in Effect (IE-IE).

You can identify circuits resulting from a CHANNEL SYNC or from an UPLOAD, which utilizes a CHANNEL SYNC, by the format of their circuit IDs.

The format is:

```
SYN from_npc-from_ch to_npc-to_ch BW/01 FDX:000
```

where:

`from_npc` is the FROM NPC number in hierarchical or extended format, depending on how the frame was provisioned.

`from_ch` is the FROM channel number.

`to_npc` is the TO NPC number in hierarchical or extended format.

`to_chan` is the TO channel number.

You should verify that the source circuits conform to the requirements for a successful COMBINE. These requirements are started in the CIRCUIT PROVISIONING Field Descriptions. You can obtain the information by:

- Generating a CIRCUIT CONNECTIONS report through the CIRCUITS selection of the REPORT OPERATIONS menu using wild-cards in the SEARCH CRITERIA form to obtain only circuits of the given FROM NPC.

For circuits to be recombined after a CHANNEL SYNC, we recommend a circuit ID search string of:

```
SYN from_npc *
```

- Obtain a display, which you can print with the **PRINT** key, through the BROWSE **Action** of the CIRCUIT PROVISIONING form. Use the same search string in the **Ckt ID** field.

To combine single-channel circuits, follow the example below. Source circuits can be high-rate. Here, we are going to recall the channel information of the first circuit to the screen, so that we can reuse it, however this step is not necessary. You could enter the information for the combined circuit independently.

1. Verify the range of the single-channel circuits.

In this example, the **Ckt ID** search string is `SYN 000*` which lists the following:

```
SYN 0001-001 ...BW/01 FDX:00
```

SYN 0001-002 ...BW/01 FDX:00

...

SYN 0001-024 ...BW/01 FDX:00

2. Select CIRCUI from the PROVISIONING menu.
3. Recall the first circuit to the screen:
  - **Site Name:** DACS00
  - **Ckt ID:** SYN 0001-002 ... BW/01 FDX:000
4. Enter the following information, noting that we are reusing the previous **Ckt ID** and therefore do not have to change it:
  - **Action:** COMBINE
  - **Bandwidth:** 24
  - **Bandwidth Type:** C
5. Press **EXECUTE** and select Y or IMMEDIATE. The source circuits are deleted. In addition, the command completed successfully message is displayed, indicating that the combined circuit has been created successfully.




**NOTE:**

If a time-out message appears, the COMBINE may be in-progress. If full-Bandwidth COMBINES are issued simultaneously, on different terminals, all but one are placed on queue and timeout messages may appear while there are in the queue. They are then executed successively after completion of the first one. A full-Bandwidth COMBINE requires over a minute to complete. Lower-rate COMBINES require less time.

**Example: Circuit Provisioning, Virtual Multipoint Circuits**

---

To visualize the virtual multipoint, broadcast model, imagine a black box with one input and multiple outputs, as shown in Figure 6-8.



---

**Figure 6-8. Ideal Broadcast Circuit**

What happens inside the box is a matter of design. The I-2000 design is shown in the exhibit for the **BBL** and **BRD** values of **Ckt Class** under the preceding "CIRCUIT PROVISIONING Field Descriptions" table.

In the single-channel bandwidth case, the initial **FROM** side and the final **TO** sides are single directions of one channel each on an **NPC**. In the high-rate case, the **FROM** and the **TO** points must be represented by multichannel circuits.

Internally, within the black box, branching is accomplished by means of a virtual node. This node is a logical channel that is both the **TO** side of the input **FROM** side and the **FROM** side of the output **TO** sides. In effect, the I-2000 sets up an input one-way, two-point circuit and one such output circuit for each broadcast point.

Ordinarily the channel for this virtual node is system-selected from the 1-500 range, but you can select one yourself, as is explained under **Ckt Class**. Such a procedure is unusual. The connection through the node is handled by the I-2000 software once you enter a **Ckt Class** of **BBL** or **BRD**.


As many **CIRCUIT PROVISIONING** forms are required as there are legs.

Each form must have a different **Ckt ID**. High-rate circuits count as one leg and take one form to specify. In that case, channels are displayed on the real **EFT** line only.

There are a few caveats:

- All legs must have the same **Bandwidth**, and the **Bandwidth Type** must be **C** (contiguous).
- You must establish the backbone leg first. The broadcast legs cannot exist without it; if you try to create a **BRD** before a **BBL**, your attempt is denied.
- The **NPCs** must not be **UEQD**. If they are **OOS**, the I-2000 accepts the form, but the frame does not accept the command. A successful circuit must contain **NPCs** that are all **IS**.

Figure 6-9 shows an example of a broadcast circuit. Once you have provisioned the **BRD** Legs, if the cursor is positioned on the **FROM NPC ID**, you can scroll through the branch legs by pressing **[NEXT]**. The **TO NPC ID** and **TO Ch** change. To display **CIRCUIT PROVISIONING** data for a branch leg, press **[Enter]** at the appropriate **NPC ID**.



**Figure 6-9. Sample Broadcast Circuit**

To provision a circuit with virtual multipoint circuits, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS01
  - **Action:** ACTIVATE
  - **Ckt ID:** MULTIN
  - **Ckt Class:** BBL
  - **Bandwidth Type:** C
  - **FROM NPC ID:** 33JJ09
  - **FROM Ch:** 001



**NOTE:**  
Note that you cannot access the **TO** fields.

- **Bandwidth:** 1
  - **TC:** TRSP
  - **IW:** FF
3. Enter or select values for any other relevant data fields for this circuit (the rest are primarily informational).
  4. Press **EXECUTE** and select IMMEDIATE, or use the **RECNCILE** key with **EXECUTE**. The **Ckt Status** field displays ACTIVE and the The virtual node appears in the TO fields. In addition, the command completed successfully message is displayed.
  5. Enter the following fields to provision one BRD:
    - **Ckt ID:** MULTOUT1
    - **Ckt Class:** BRD

- **BBL ID:** MULTIN
  - The virtual node appears in the FROM fields.
  - **Bandwidth Type:** C  
You must enter C.
  - **TO NPC ID:** 55NN11
  - **TO Ch:** 005
  - **Bandwidth:** 01  
You must enter the same **Bandwidth** as the BBL.
  - **TC:** TRSP
  - **IW:** FF
6. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** changes to ACTIVE. In addition, the command completed successfully message is displayed.
7. Enter the following fields to provision the other BRD.
- **Ckt ID:** MULTOUT2
  - **Ckt Class:** BRD
  - **BBL ID:** MULTIN
  - **Bandwidth Type:** C
  - **TO NPC ID:** 55PP04
  - **Bandwidth:** 01
  - **TC:** TRSP
  - **IW:** FF
8. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** changes to ACTIVE. In addition, the command completed successfully message is displayed.

### Example: Circuit Provisioning, DMB Multipoint Circuits


---

 **NOTE:**  
DMB multipoint is supported *only* for DACS II.

The model for a DMB multipoint circuit is similar to that of the virtual multipoint circuit, except that a DMB multipoint circuit is two-way, and, therefore, the concept of FROM and TO sides becomes arbitrary. Either direction of a circuit can be the FROM or the TO. Also, DMB multipoint circuits require the selection of a DMB NPC and channel as a branch point.

⇒ **NOTE:**  
 The DMB NPC number must be in the range supported by the DMB circuit pack. If it is not, the NPC is not a DMB NPC. If you do not know the ranges of each type of NPC, consult your system administrator.

Figure 6-10 shows an example of a symmetric voice circuit.



**Figure 6-10. Sample Symmetric Voice Circuit**

In this example, three CIRCUIT PROVISIONING forms are required. Each form must have a different **Ckt ID**.


To provision a circuit with DMB multipoint circuits, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS01
  - **Action:** ACTIVATE
  - **Ckt ID:** MULT1
  - **Ckt Class:** DMB
  - **FROM NPC ID:** SITE11  
This NPC contains EFTs.
  - **FROM Ch:** 003
  - **FROM Mode:** LEG
  - **TO NPC ID:** CONFWEST  
This is the DMB NPC.
  - **TO Ch:** 017

- **TO Mode:** SYM
3. Enter or select values for any other relevant data fields.
  4. Press **EXECUTE** and confirm. The **Ckt Status** changes to ACTIVE. In addition, the command completed successfully message is displayed.
  5. Enter the following information, understanding that the **Ckt Class** is still DMB:
    - **Ckt ID:** MULT2
    - **FROM NPC ID:** SITE82
    - **FROM Ch:** 016
    - **FROM Mode:** LEG
    - **TO NPC ID:** CONFWEST
    - **TO Ch:** 017
    - **TO Mode:** SYM
  6. Press **EXECUTE** and confirm. The **Ckt Status** displays ACTIVE. In addition, the command completed successfully message is displayed.
  7. Enter the following information, understanding that the **Ckt Class** is still DMB:
    - **Ckt ID:** MULT3
    - **FROM NPC ID:** SITE101  
This NPC contains EFTs.
    - **FROM Ch:** 032
    - **FROM Mode:** LEG
    - **TO NPC ID:** CONFWEST  
This is the DMB NPC.
    - **TO Ch:** 017
    - **TO Mode:** SYM
  8. Press **EXECUTE** and confirm. The **Ckt Status** displays ACTIVE. In addition, the command completed successfully message is displayed.

### Procedure: Circuit Provisioning, Polling Data Circuit

Figure 6-11 shows an example of a polling data circuit. This figure is essentially the same as Figure 6-10; however, it is strictly conventional. The Tx direction of the backbone does not really go through the DMB NPC.



**Figure 6-11. Sample Polling Data Circuit**

In this example, three CIRCUIT PROVISIONING forms are required. Each form must have a different **Ckt ID**.

To provision a circuit with a polling data circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS01
  - **Action:** ACTIVATE
  - **Ckt ID:** MULT1
  - **Ckt Class:** DMB
  - **FROM NPC ID:** SITE11  
This NPC contains EFTs.
  - **FROM Ch:** 003
  - **FROM Mode:** LEG
  - **TO NPC ID:** CONFWEST  
This is the DMB NPC.
  - **TO Ch:** 017
  - **TO Mode:** BBL

3. Enter or select values for any other relevant data fields.
4. Press **EXECUTE** and confirm. The **Ckt Status** displays ACTIVE. In addition, The command completed successfully message is displayed.
5. Enter the following information, understanding that the **Ckt Class** is still DMB:
  - **Ckt ID:** MULT2
  - **FROM NPC ID:** SITE82
  - **FROM Ch:** 016
  - **FROM Mode:** LEG
  - **TO NPC ID:** CONFWEST
  - **TO Ch:** 017
  - **TO Mode:** BRD
6. Press **EXECUTE** and confirm. The **Ckt Status** displays ACTIVE. In addition, the command completed successfully message is displayed.
7. Enter the following information, understanding that the **Ckt Class** is still DMB:
  - **Ckt ID:** MULT3
  - **FROM NPC ID:** SITE101
  - **FROM Ch:** 032
  - **FROM Mode:** LEG
  - **TO NPC ID:** CONFWEST
  - **TO Ch:** 017
  - **TO Mode:** BRD
8. Press **EXECUTE** and confirm. The **Ckt Status** displays ACTIVE. In addition, the COMMAND COMPLETED SUCCESSFULLY message is displayed.

## Cascaded Multipoint Circuits

The number of legs that can be hung from one branch point in a DMB multipoint circuit is limited by the number of time slots in a DMB circuit pack. Some limits are stated for the DACS II, as shown in Table 6-3.

**⇒ NOTE:**  
DMB is supported *only* for the DACS II.

**Table 6-3. DMB Conference Information**


Machine	DMB Conference Number Range	Maximum Number of DMB Conferences Per Frame	Maximum Number of DMB Conference Legs Per Pack
DACS II	1-85 (170 per pack)	2720	512
DACS II (CEF)	1-85 (170 per pack)	10880	512

**⇒ NOTE:**  
\* If you assume eight DMB packs per DSPU per frame, and two DSPUs per frame, the maximum number of conferences is 170x8x2, or 2720.

The above limitations can be overcome for multipoint circuits by a configuration called cascading, in which two or more conferences are included in the same network of DMB multipoint circuits.

Figure 6-12 represents a cascaded symmetric voice circuit.

**⇒ NOTE:**  
The representations shown in this section are not to be taken as circuit diagrams. They represent graphically the relations between the cross-connects to be entered on the various CIRCUIT PROVISIONING forms required by the cascade.




**Figure 6-12. Cascaded Symmetric Voice Circuit**

Using Figure 6-12 as an example, the following rules are evident:

- LEG always connects to SYM.
- Clusters of SYM must be the same NPC and channel, and it must be a DMB NPC.
- The number of SYM-to-SYM cross-connects is equal to one less than the number of DMB conferences in the circuit.

In the illustration, seven cross-connects are shown, requiring seven CIRCUIT PROVISIONING forms. The **Mode** Field values associated with each channel are shown. Whether a channel is TO or FROM has no bearing, except, of course, that a FROM and a TO have to appear in every cross-connect.


Figure 6-13 represents a single polling data circuit for comparison purposes.



**Figure 6-13. Single Polling Data Circuit**

Notice that the same DMB NPC and channel are labeled BBL in one form and BRD in three forms.


Figure 6-14 shows two polling data circuits cascaded through the backbone legs.



**Figure 6-14. BBL-to-BBL Cascaded Polling Data Circuit**

Notice that the LEG to BBL cross-connects of a single circuit have been replaced by a common BBL to BBL cross-connect. Seven CIRCUIT PROVISIONING forms are required.

Figure 6-15 shows an example of a BBL to BRD cross-connect.



**Figure 6-15. BBL-to-BRD Cascaded Polling Data Circuit**

From this figure, the following rules are evident:

- LEG always connects to BBL or BRD.
- A cluster of points representing one DMB and channel must include one BBL with the rest being BRD.

- As many BRD to BBL cross-connects are required as one less than the number of DMB conferences in the circuit.

## **BCON Circuits**

---

BCON circuits provide the capability to provision multi-point circuits. For additional information on BCON circuits, refer to *DACS II Release 7.1 MML Operation and Maintenance Manual* or *DACS II ISX Release 2.1 MML Operation and Maintenance Manual*.

A BCON circuit cannot be created directly through the I-2000 user interface, however a BCON circuit can be directly created by an ERP. To create a BCON circuit through the I-2000 user interface, create a Full Duplex circuit and add a LEG. The Full Duplex circuit will be converted to a BCON. Similarly, when the last LEG of a BCON circuit is deleted through the I-2000 user interface, the remaining backbone will be converted back to a Full Duplex circuit automatically.

### **Example: Adding a LEG to a Full-Duplex Contiguous 64 Kbps Circuit**

---

To add a LEG to a contiguous 64 Kbps circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** ADDLEG
  - **BKB Ckt ID:** CKT2
  - **LEG NPC ID:** 55US02
  - **LEG Ch:** 002
  - **Dir:** F
3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** field changes from NULL to ACTIVE. In addition, the command completed successfully message is displayed. The **LEG Ckt ID** field will be filled in automatically after the form executes.

Figure 6-16 shows an example of the CIRCUIT PROVISIONING form when the action selected is ADDLEG.

The **Circuit Class** field is hidden when the action is ADDLEG.

```

06:15 01 Nov 1997          I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
-----
CIRCUIT PROVISIONING
-----
Site Name:DACS00
Action :ADDLEG
BKB Ckt ID:CKT2
LEG Ckt ID:
    Hier      Ext      NPC ID
FROM: 01104  0004    55KC35
TO:   01105  0005    55US02
LEG : 01105  0005    55US02
Bandwidth:01
Options:
Ckt Status:
Ckt Class :
Bandwidth Type: C
Ch  dir
001
001
002 FSIDE

Service Date: 01 Nov 97

Enter the service data as 'DD MMM YY'
-----
HELP  [ ]  NEXT PAGE  QUIT  RECNCILE  TOP MENU  PRINT  EXECUTE

```

**Figure 6-16. CIRCUIT PROVISIONING Form, Adding a LEG for Contiguous Circuits**

### Example: Adding a LEG to a Random Bandwidth 4 Circuit

To add a LEG to a random 64 Kbps circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** ADDLEG
  - **BKB Ckt ID:** CKT1
  - **LEG NPC ID:** 55US02
  - **Dir:** F
  - **L\_CH:** 2 9 11 17

3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** field changes from blank to ACTIVE. In addition, the command completed successfully message is displayed. The **LEG Ckt ID** field will be filled in automatically after the form executes.

Figure 6-17 shows an example of the CIRCUIT PROVISIONING form when the action selected is ADDLEG.



**NOTE:**

The **Circuit Class** field is hidden when the action is ADDLEG.

```

06:15 01 Nov 1997          I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
-----  CIRCUIT PROVISIONING  -----
Site Name:DACS00
Action :ADDLEG              Ckt Status:
BKB CKT ID:CKT1            Ckt Class :
LEG Ckt ID:                Bandwidth Type: R
                            dir
    Hier      Ext      NPC ID
FROM: 01104   0004     55KC35
TO:   01105   0005     55US02
LEG:  01105   0005     55US02
Bandwidth: 1                Options:
F_CH:003 007 009 010
T_CH:005 006 008 010
L_CH: 002 009 011 017
                            FSIDE

                            Service Date: 01 Nov 97

-----Enter the first fifteen characters of the BCON backbone ID -----
HELP  [ ]  NEXT PAGE  QUIT  RECNCILE  TOP MENU  PRINT  EXECUTE
    
```

**Figure 6-17. CIRCUIT PROVISIONING Form, Adding a LEG for Random Circuits**

**Example: Adding a LEG to a Clear E1 Circuit**

To add a LEG to a clear E1 circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:

— **Site Name:** DACS00

- **Action:** ADDLEG
- **BKB Ckt ID:** CKT3
- **LEG NPC ID:** NPC3
- **Dir:** T

3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** field changes from blank to ACTIVE. In addition, the command completed successfully message is displayed. The **LEG Ckt ID** field will be filled in automatically after the form executes.

Figure 6-18 shows an example of the Circuit Provisioning Form when the action selected is ADDLEG.

**NOTE:**  
The **Circuit Class** field is hidden when the action is ADDLEG.

```

06:15 01 Nov 1997          I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
-----  CIRCUIT PROVISIONING  -----
Site Name: DACS00
Action :ADDLEG                Ckt Status:
BKB Ckt ID: CKT3              Ckt Class:
LEG Ckt ID:
  Hier      Ext      NPC ID      Ch dir
FROM: 01101 0001   NPC1        E1
TO:   01102 0002   NPC2        EI
LEG:  01103 0003   NPC3        E1 TSIDE

Options:

Service Date: 01 Nov 97

Enter the service data as 'DD MMM YY'
    
```

HELP        NEXT PAGE    QUIT    RECNCILE    TOP MENU    PRINT    EXECUTE

**Figure 6-18. CIRCUIT PROVISIONING Form, Adding a BKB for E1 Circuits**

### Example: Modifying a BKB From an Existing Circuit

---

To modify a BKB from an active circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** MODIFY
  - **BKB Ckt ID:** CKT3
  - **New ID:** NEWCKT3
3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** field changes from blank to ACTIVE. In addition, the command completed successfully message is displayed. When you change the **Ckt ID** field of a **BKB**, all **LEG Ckt IDs** will be updated automatically.

Figure 6-19 shows an example of the CIRCUIT PROVISIONING form when the action selected is MODIFY.



**NOTE:**

The **Circuit Class** field is hidden when the action is ADDLEG.



**NOTE:**

The BKB Circuit ID can be modified. No other parameters can be changed. When a BKB Circuit ID is modified, the base name of all corresponding LEG circuits will also be modified.

```

06:15 01 Nov 1997          I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
-----  CIRCUIT PROVISIONING  -----
Site Name: DACS00
Action:MODIFY                Ckt Status: ACTIVE
Ckt ID:CKT3                  Ckt Class:BKB
New ID: NEWCKT3
  Hier      Ext      NPC ID      Ch
FROM: 01101 0001    NPC1      E1
TO:   01102 0002    NPC2      E1

Options:

Loc A:                      Loc Z:
Customer Name:              Service Date: 01 Nov 97  Ckt Priority:00
Rmks:

Enter the next fifteen characters of New Circuit _____

HELP  [ ]  NEXT PAGE  QUIT  RECNCILE  TOP MENU  PRINT  EXECUTE

```

**Figure 6-19. CIRCUIT PROVISIONING Form, Modifying a BKB E1 Circuits**

### Example: Deleting a LEG from a BCON Circuit

To delete a LEG from an active circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** DELLEG
  - **LEG Ckt ID:** CKT2 01
3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** field changes from to ACTIVE to NULL. In addition, the command completed successfully message is displayed.

Figure 6-20 shows an example of the CIRCUIT PROVISIONING form when the action selected is DELLEG.

```

06:15 01 Nov 1997          I-2000 Controller Release x.x for DACS-II
Status:
Alarms:

          CIRCUIT PROVISIONING

Site Name:  DACS00
Action:DELLEG                      Ckt Status: ACTIVE
                                      Ckt Class: LEG
                                      Bandwidth Type: C

LEG Ckt ID: CKT2 01

      Hier      Ext      NPC ID      Ch
FROM:  01104    0004    55KC35      001
TO:    01105    0005    55US02      002
Bandwidth: 01                      Options:

                                      Service Date: 01 Nov 97

Enter the first fifteen characters of the BCO leg ID _____

HELP  [ ]  NEXT PAGE  QUIT  RECNCILE  TOP MENU  PRINT  EXECUTE

```

**Figure 6-20. CIRCUIT PROVISIONING Form, Deleting a LEG from a BKB Circuit**

**Example: Changing the Return Path of a BCON Circuit**

To change the return path of an active BCON circuit, follow these steps:

1. Select CIRCUIT from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** CHGRPATH
  - **LEG Ckt ID:** CKT2 01
3. Press **EXECUTE** and select IMMEDIATE. The command completed successfully message is displayed.

Figure 6-21 shows an example of the CIRCUIT PROVISIONING form when the action selected is CHGRPATH.

```

06:15 01 Nov 1997          I-2000 Controller Release x.x for DACS-II
Status:
Alarms:

          CIRCUIT PROVISIONING

Site Name: DACS00
Action:CHGRPATH                Ckt Status: ACTIVE
                                Ckt Class: LEG
                                Bandwidth Type: C
LEG Ckt ID: CKT2 01

  Hier      Ext      NPC ID      Ch
FROM:  01104  0004  55KC35      001
TO:    01105  0005  55US02      002
Bandwidth:01                    Options:

                                Service Date: 01 Nov 97

Enter the first fifteen characters of the BCON leg ID
HELP  NEXT PAGE  QUIT  RECNCILE  TOP MENU  PRINT  EXECUTE

```

**Figure 6-21. CIRCUIT PROVISIONING Form, Changing the Return Path of a BCON Circuit**

## TS0 to Non-TS0 Circuits

The I-2000 allows you to provision a circuit between a TS0 and non-TS0. One side of the termination must be a TS0 on a channelized PA type NPC and the other termination must be a channel/time slot other than TS0 on the channelized CEPT NPC. In addition, the circuit class must be set to FD~~X~~. In order to provision this type of circuit, the framing field must be specified.

### Example: Provisioning TS0 to Non-TS0 Circuits

To provision TS0 to Non-TS0 circuits, follow these steps:

1. Select PROVISIONING from the MAIN MENU and then select CIRCUIT from the PROVISIONING menu. The CIRCUIT PROVISIONING form may already have values in it; these are defaults. The **Ckt Status** field displays NULL.

2. Enter the following data, or use the displayed defaults:

— **Site Name:** DACS00

— **Action:** ACTIVATE

— **Ckt ID:** CKT1

If you are making a change to an existing circuit, the current values are filled into the fields on the screen.

— **Ckt Class:** FDX

You can fill in **Hier** or **Ext** instead of **FROM NPC ID** or **To NPC ID**, shown next. Whichever of the three fields you pick, the values of the other two are filled in automatically.

— **Bandwidth Type:** C

— **FROM NPC ID:** 55KC35

— **FROM Ch:** 000

— **TO NPC ID:** 55US02

— **TO Ch:** 014

— **Bandwidth:** 1

— **TC:** 0011,0011

— **IW:** TRB

— **Framing:** NFW

3. Press **EXECUTE** and select IMMEDIATE, or use the **RECNCILE** key to select the database and then press **EXECUTE**.

If the command completes successfully: The **Ckt Status** field changes from NULL to ACTIVE and the **Framing** changes to NFW. In addition, the command completed successfully message is displayed.

## Circuit Provisioning ERP

---

Echoed response processing (ERP) is an autonomous circuit provisioning feature; for example, it is not under menu control. An echoed response is a message that is sent from a frame to the I-2000 when the I-2000 does not expect a response; for example, when a change in frame circuit provisioning has been entered through the frame console or by some other means not initiated on the I-2000. Such provisioning means that the frame and I-2000 databases no longer correspond.

The I-2000, is designed to respond to the following types of frame output messages:

**Table 6-4. ERP Messages**

ERP Message Number	Message Description
0.11001	connection of two-way or a range of cross-connect circuits
0.11011	connection of two-way clear DS1/E1 circuits
0.11021	connection of two-way multipoint circuits
0.11101	connection of one-way or a range of cross-connect circuits
0.11121	connection of one-way multipoint or a range of cross-connect circuits
0.11131	connection of one-way clear DS1/E1 circuits
0.13001	addition of up to eight legs for BCON circuits
0.13002	addition of one leg for a BCON circuit
0.13011	addition of up to eight clear legs for BCON circuits
0.13021	addition of one clear leg for a BCON circuit
0.15001	disconnection of a two-way or a range of cross-connect circuits
0.15002	disconnection of two-way or a range of cross-connect circuits
0.15011	disconnection of two-way clear DS1/E1 circuits
0.15101	disconnection of one-way circuits
0.15111	disconnection of one-way clear DS1/E1 circuits
0.15102	disconnection of one-way multipoint or a range of cross-connect circuits
0.15201	disconnection of one leg for a BCON circuit
0.15211	disconnection of up to eight legs for a BCON circuit
0.15221	disconnection of up to eight clear legs for a BCON circuit
0.15231	disconnection of one clear leg for a BCON circuit
0.18001	change the return path for up to eight BCON circuits
0.18011	change the return path for up to eight clear circuits

You can partially control the I-2000 response to a message of this type. In the FRAME ADMINISTRATION form, if you set the value of **ERP Control** to **ON**, the I-2000 processes echoed response messages only if all point terminations are already in the I-2000 database. The database is updated and event messages are published. If any terminations are missing, the message is not processed and no action of any kind is taken.

If, on the other hand, **ERP Control** is set to **OFF**, the I-2000 responds fully to every message of this type.

The I-2000 automatically activates or deletes one-way, two-way, virtual multipoint, DMB multipoint, or BCON circuits. It searches for the NPCs and channels referenced in the message. If it does not find them in the I-2000 database, it logs the message, but takes no action. If it finds the terminations, but no circuit is active, it activates a circuit.

If the I-2000 must activate a circuit that is not in the I-2000 database at all, it automatically assigns a **Ckt ID** of the following format:

```
ERP fromnpc-fromchan tonpc-tochan BW/bw class
```

where:

`fromnpc` is the FROM NPC number in hierarchical or extended format, depending on how the frame was provisioned.

`fromchan` is the FROM channel number.

`tonpc` is the TO NPC number in hierarchical or extended format.

`tochan` is the TO channel number.

`bw` is the bandwidth, which is either 1 or the number of contiguous channels of a high-rate circuit.

`class` is the circuit class

If an ERP message indicating a disconnect has occurred, I-2000 will delete the circuit using the same **From** point and **To** point. If an ERP circuit, a SYN circuit or a C2000 circuit must be deactivated, it is deleted. Otherwise, a circuit taken out of service is placed in **DEACTIVATED Ckt Status**.

The frame does not recognize high-rate circuits with an alternating or random type of bandwidth. If the I-2000 receives a deactivation message for a circuit included in such a bandwidth, it deletes all the circuits of the bandwidth and reactivates the ones not specified in the message.

All actions taken by ERP are logged and the log can be retrieved as a report. For more information, refer to Chapter 14 "Report Operations."

As with any other I-2000 **Action**, an action generated in ERP can succeed or fail. The result of the attempt is reported in the **Status** field at the top of the screen, in the following format:

*database/result:action explanation*

where:

*database* Is the **Site Name** field value for this frame.

*result* Is one of these values:

SUCCESS The action succeeded.  
FAILURE The action failed.

*action* Is a terse English description of the attempted action.

*explanation* Is the **Ckt ID** field value or an error message.

For BCON ERP messages which result in the addition or modification of LEGs to an existing BCON circuit, the standard LEG circuit naming is used. However, for new BCON circuits that have been created via ERP, the I-2000 assigns a **Ckt ID** of the following format:

**BRP** fromnpc-fromchan tonpc-tochan **BW**

### **Procedure: Disabling Echoed Response Processing**

Echoed response processing for circuits and equipment are enabled whenever a frame screening level is set to 4. Refer to "Configuring the Frame" in Chapter 2 "Getting Started." Echoed response processing can be disabled for a particular frame by changing the link screening options in the frame.

To disable echoed response processing, follow these steps:

1. Enter passthrough mode (refer to Chapter 13 "Passthrough.")
2. Type the following command to set the link screening level to 2:

```
SET-PRVG-TERM:::n01:SCR-2;  
SET-PRVG-TERM:::n02:SCR-2;  
...  
SET-PRVG-TERM:::n16:SCR-2;
```

For additional details concerning this command, refer to the input message format for NPC provisioning in the Generic 3 (MML) Input/Output Message Reference Manual, V. II.



**NOTE:**

If you disable ERP, the I-2000 database could drift apart from the frame database, necessitating that you periodically perform a database audit followed by a database synchronization. For more information, refer to Chapter 10 "Database Administration."

---

## Contents

<b>Introduction</b>	7-1
<b>Cross-Connection Architecture</b>	7-2
■ Relevant Architecture Elements the DSPP Circuit Pack	7-3
■ X.50 Customer Circuit Cross-Connections	7-4
■ X.50 to X.57 Customer Circuit Cross-Connections	7-6
<b>Subrate Provisioning</b>	7-7
<b>DS0 Channel Provisioning</b>	7-7
■ Procedure: Creating an NPC as a Subrate Type	7-8
■ ESTABLISH DS0 CHANNEL Form	7-8
■ Procedure: Establishing a DS0 Channel	7-10
■ Field Descriptions	7-11
<b>DS0 Channel Examples</b>	7-14
■ Example: Deactivating a DS0 Channel	7-14
■ Example: Deleting a DS0 Channel	7-15
■ Example: Modifying a DS0 Channel	7-15
■ Example: Browsing a DS0 Channel	7-16
<b>Subrate Cross-Connect Provisioning</b>	7-17
■ SUBRATE CROSS CONNECT Form	7-17
■ Procedure: Establishing Subrate Cross-Connection	7-18
■ Field Descriptions	7-19

---

## Contents

<b>Subrate Cross Connect Examples</b>	7-22
■ Example: Deactivating a Subrate Cross Connect	7-22
■ Example: Deleting a Subrate Cross Connect	7-23
■ Example: Modifying a Subrate Cross Connect	7-23
■ Example: Browsing a Subrate Cross Connect	7-23

---

## Introduction

---

**NOTE:**

The subrate application described in this chapter is *only* for DACS II ISX.

There is a growing market to support Digital Data Networks (DDNs) at the 2.4, 4.8, 9.6, and 19.2 kbit/s rates. The I-2000 supports these digital data rates by being able to cross-connect individual DDN circuits and the ability to connect to multiplexed DNN circuits and individual DNN circuits.


The following subrate circuits are supported by the I-2000:

- **X.50**—A 64 kbit/s circuit that carries a number of multiplexed circuits of lower data rates using the International Telecommunications Union (ITC) X.50 recommendation.
- **X.57**—DACS II ISX supports these data rates by cross connecting individual DNN circuits and the ability to connect to individual or multiplexed DNN circuits.

The subrate application requires the use of the Digital Signal Processing Platform (DSPP), which consists of both hardware and software. The hardware consists of the Digital Signal Processing (DSP) TG193 circuit pack. The software that runs on the DSPP is referred to as application software because DACS II ISX treats it as a separate application.

## Cross-Connection Architecture

X.50 and X.57 circuits are all cross-connected to a DSPP circuit pack (TG193), which performs the function of demultiplexing and multiplexing customer circuits that are being carried on the X.50 and X.57 circuits. Figure 7-1 illustrates this cross connection architecture.



**Figure 7-1. Cross Connection Architecture**

The information is cross-connected in its original form, at 16 bits at a time. A set of 16 bits is sent through the cross-connect network every 125 microseconds per each cross-connected channel. The lower eight bits of the 16 bit set consists of customer circuit data and overhead bits. These eight bits consists of four signalling bits, three control bits, and one parity bit.



**NOTE:**

It cannot be assumed that the data in the form of 8-bit envelopes lines up with the lower 8 bits shown in Figure 7-1. However, for X.57 circuits it can be assumed that the 8-bit envelopes will line up with the lower 8 bit bits shown in this figure.

---


## Relevant Architecture Elements

### the DSPP Circuit Pack

---

The DSPP circuit pack (TG193) contains 64 channels (time slots), which can be cross-connected to another channel on another NPC in the system. This is illustrated by a dashed line in Figure 7-2. In addition, the DSPP circuit packs can have access to an Inter-NPC bus that connects the DSPP circuit packs among themselves.

Each DSPP circuit pack has the ability to write data for up to 64 channels to the Inter-NPC bus, if present. This is illustrated in Figure 7-2 by a “W”. This can be modified or unmodified data. Each DSPP circuit pack can read up to 1024 channels from the Inter-NPC bus, which is illustrated as “R” in Figure 7-2. These 1024 channels represent the total number of channels for up to 16 DSPP circuit packs. Each DSPP circuit pack can read the channels of all other DSPP circuit packs as well as its own from the Inter-NPC bus, if these channels are written to the Inter-NPC bus by the individual DSPP circuit pack.



---

**Figure 7-2. Inter-NPC Bus Architecture for DSPP Circuit Pack**

This Inter-NPC bus allows substrate cross-connections between more than 64 X.50 circuits, if the Inter-NPC bus is not used, the number of circuits that can exchange substrate circuits between themselves is 64.


The limit of 64 channels without the Inter-NPC bus and a limit of 1024 channels with the Inter-NPC bus are theoretical limits. The actual limits depend on the capacity of the DSP1611 chip on the DSPP circuit pack.

With the exception of growing and restoring the DSPP circuit pack, the I-2000 will ignore all commands that pertain to the DSPP circuit pack.

### X.50 Customer Circuit Cross-Connections

To connect X.50 customer circuits to each other, a total of three cross connects are required. Two of these cross-connects are illustrated in Figure 7-1, which illustrates how two X.50 circuits are connected from their NPCs to the DSPP circuit packs. These two cross-connects are established by the DACS II ISX cross-connect network.

The cross-connection of customer circuits takes place in the DSPP circuit packs along with the demultiplexing/multiplexing necessary. Figure 7-3 shows a schematic view of how these customer circuit cross-connections are made. In Figure 7-3, the left side the column of 8-bit envelopes represents an incoming X.50 data stream in memory and on the right side of the column of 8-bit envelopes in memory go out to NPC 2.



193

Figure 7-3. X.50 Customer Circuit Cross-Connection Diagram

Only one direction of the cross-connection is shown for clarity. Both columns have the X.50 framing bit pattern in the first bit position, which is column one. On the incoming side, this framing pattern needs to be checked to maintain subrate framing, on the outgoing side this framing pattern is set by the program. Figure 7-2 shows the "A" (alarm) bit in the beginning of each framing pattern. The long lines that from the column show a single frame, and the shorter lines divide the 20 envelope frame into four sets of five envelopes.

Individual 9.6 kbit/s circuits occupy one of the five envelope positions in a set of five. For example, if a circuit is designated as 911\* in Figure 7-2 occupies the first envelope position of each set of five.

There are six data bits "D" and one status bit "S", which is the eighth bit position. In addition, the 9.6 kbit/s circuit envelopes occupy the data stream in every fifth envelope position.

The customer circuit 411 is a 4.8 kbit/s circuit that occupies the fourth envelope (phase) position and it is the first of a possible set of two 4.8 kbit/s circuits that can be in that envelope position. The envelopes from circuit 411 repeat every 10 envelopes because it is a 4.8 kbit/s circuit. Another 4.8 kbit/s circuit is called 442 and is located in the fourth envelope (phase) position, but it occupies the second position. Note that from Figure 7-2, circuit 442 occupies the second and fourth set of five envelopes in the frame, while circuit 411 occupies the first and third set of five envelopes in the frame.


Finally there are three 2.4 kbit/s circuits in the incoming frame, which are 251, 253, and 254. All three circuits occupy the fifth envelope (phase) position in the frame. Circuit 251 is the first set of five envelopes, circuit 253 is the third set of five envelopes, and circuit 254 is the fourth set of five envelopes. Note that 2.4 kbit/s circuits occupy every 20th envelope position, which is one envelope per frame.

Using Figure 7-2 as an example, three customer circuit cross-connections are established between the incoming and outgoing frame. Circuit 911 is cross-connected to circuit 921 in the outgoing frame. This means there are four envelopes per frame that are transferred from the incoming stream to the outgoing stream. In addition, there are only seven bits of the envelope that are transferred since the framing bit is not transferred. Circuit 441 is cross connected to circuit 432 in the outgoing frame, and circuit 254 (2.4 kbit/s) is cross connected to circuit 251 in the outgoing frame.

\* The 9 in the 911 designation refers to a 9.6 kbit/s circuit. The first 1 in 911 refers to the first envelope position, which is also called phase 1. The second 1 is the position phase 1; since 9.6 kbit/s circuits occupy all positions in their phase, this number is always 1 for 9.6 kbit/s circuits.

**X.50 to X.57 Customer Circuit Cross-Connections**

Figure 7-4 shows the customer circuit cross-connections between an X.50 and X.57 circuit.



193

**Figure 7-4. X.50 to X.57 Customer Circuit Cross-Connection Diagram**

The incoming frame is identical to the frame in Figure 7-3; however, the outgoing frame is a X.57 circuit. Note that all framing bits are "0" because there is no agreed upon framing patten for X.57 circuits. The cross-connection is between 9.6 kbit/s circuit 911 and the X.57 circuit. Each envelope that is obtained from the X.50 circuit is transferred, with the exception of the framing bit, to the X.57 circuit and repeated five times.

Figure 7-4 illustrates the direction from an X.50 circuit to a X.57 circuit and not in the other direction. The other direction the cross-connection is comparable to the one shown in this figure. Every fifth envelope in the X.57 circuit is used and multiplexed onto the X.50 circuit. If a 4.8 kbit/s circuit was cross-connected, every 10th envelope would have been transferred and for 2.4 kbit/s circuits every 20th envelope would have been transferred.

## Subrate Provisioning

---

Subrate provisioning allows you to provision subrate circuits *only* on DACS II ISX Releases 2.0 and higher.

This chapter describes the procedures to:

- Create a subrate NPC
- Activate, deactivate, delete, and modify a DS0 channel
- Activate, deactivate, delete, and modify a subrate cross connection

The Report Operations menu provides two forms that allow you to search subrate channels and cross connections:

- The ESTABLISHED DS0 CHANNELS SEARCH CRITERIA form allows you to search established channel information.
- The SUBRATE CIRCUITS SEARCH CRITERIA form allows you to search subrate cross connect information.

For more information on these reports, refer to Chapter 14 “Report Operations.”

In addition, the Database Audit/Synchronization feature allows you to perform a SUBRATE AUDIT and SUBRATE SYNC to synchronize subrate circuit in the I-2000 and/or DACS database. For more information on database synchronization, refer to Chapter 10 “Database Administration.”

 **NOTE:**  
I-2000 will deny NPC Roll commands if a DS0 channel is connected to a DSPP platform.

## DS0 Channel Provisioning

---

Before a subrate cross-connect can be performed, a DS0 channel needs to be established to carry subrate traffic. This DS0 channel then needs to be connected to the DSPP platform, which is referred to as an *established channel*.

 **NOTE:**  
Before you can establish a DS0 channel, you must create an NPC that is a subrate type (SD111).

### **Procedure: Creating an NPC as a Subrate Type**

To create an NPC as a subrate type, follow these steps:


1. Select NPC from the PROVISIONING menu. The NPC PROVISIONING form is displayed.
2. Enter, or select from the CHOICES menu, the following information:
  - **Site Name:** DACS00  
DACS00 must already have been provisioned as a frame (refer to Chapter 2 "Getting Started.")
  - **Action:** CREATE
  - **NPC ID:** DS01
  - **Type:** SD111
  - **Number (Hier):** 01101
  - If you fill this in, **(Ext)** is automatically supplied. The NPC number must be compatible with the Type. Note that the NPC number should always be an odd.
3. Press **EXECUTE** and select IMMEDIATE. (You can create the NPC in `local only` mode. Refer to Chapter 2 "Getting Started" on the use of the **RECNCILE** key.) The result is that the
  - **Service State** field changes to OOS
  - **Alarm State** changes to None
  - I-2000 command completed message is displayed on the screen.
4. Move to the **Action** field and select RESTORE.
5. Press **EXECUTE** and select IMMEDIATE. The result is that the
  - Subrate NPC is in service.
  - **Service State** field changes to IS
  - I-2000 command completion message is displayed.

Now that you have created a subrate NPC, you can establish DS0 channels for that NPC. Follow the procedures below establish a DS0 channel.

### **ESTABLISH DS0 CHANNEL Form**

To access the ESTABLISH DS0 CHANNEL form, follow these steps:

1. Select PROVISIONING from the MAIN MENU. The PROVISIONING menu is displayed, as shown in Figure 7-5.



---

**Figure 7-5. PROVISIONING Menu**

2. Select ESTABLISH DS0 CHANNEL from the PROVISIONING menu. The ESTABLISH DS0 CHANNEL form is displayed, as shown in Figure 7-6.

```
06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
      _____ ESTABLISH DS0 CHANNEL _____
Site Name:
Action:           Ckt Status:
Ckt ID:           Ckt Class:

      Hier      Ext      NPC ID           Ch      TYPE
FROM:
TO:

Transmission Standard:  Transmission Rate:  Bit Framing Pattern:
UMC:                    MUX:                SIG:
```

Enter the site name \_\_\_\_\_

HELP CHOICES [ ] QUIT RECNCILE TOP MENU PRINT EXECUTE

**Figure 7-6. ESTABLISH DS0 CHANNEL Form**

### **Procedure: Establishing a DS0 Channel**

---

To establish a DS0 channel, follow these steps:

1. Obtain the ESTABLISH DS0 CHANNEL form.
2. Fill in the following fields:
  - **Site Name:** DACS00
  - **Action:** ACTIVATE
  - **Ckt ID:** CKT01
  - **FROM NPC ID:** NPC01
  - **CH:** 01
  - **TO NPC:** NPC02
  - **Transmission Standard:** X.50



**NOTE:**

If you enter X.50 as the transmission standard the Transmission Rate field is not applicable.

If you enter X.57 as a transmission standard, enter the Transmission Rate.

- **Transmission Rate:** 2.4
- **Bit Framing Pattern:** F20 (valid only for X.50)

The following fields are optional:



**NOTE:**

The following fields are optional: **UMC**, **MUX**, and **SIG**:

- **UMC:** FF (Unoccupied multiplexer channel)
- **MUX:** FF (Multiplexer out of synchronization code)
- **SIG:** F (Signalling bits)

3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** changes to ACTIVE. In addition, the command completed successfully message is displayed.

## Field Descriptions

---

Field descriptions for the ESTABLISH DS0 CHANNEL form are described in Table 7-1.

**Table 7-1. ESTABLISH DS0 CHANNEL Field Descriptions**

<b>Site Name</b>	<p>Mandatory. 1 through 24 characters from the set A-Z, a-z, 0-9, /, _, -. All other characters are illegal. Blanks are not allowed within the name.</p> <p>Enter the name of the frame in which the channel is to be provisioned. Pressing <b>CHOICES</b> displays WHICH DACS? with a list of the names that were established during frame administration, described in Chapter 2 "Getting Started." The default is the first name.</p>
------------------	--

**Table 7-1. ESTABLISH DS0 CHANNEL Field Descriptions (Contd)**

<b>Action</b>	<p>Mandatory. Enter the action to be performed with regard to the circuit.</p> <p><b>ACTIVATE</b> Enters the channel specified by <b>Ckt ID</b> in the I-2000 database (if it does not yet exist) and connect the DS0 channel to a DSPP platform. When this action is completed successfully, the <b>Ckt Status</b> changes from NULL to ACTIVE.</p> <p><b>DELETE</b> Removes the specified circuit from the I-2000 and frame databases, returning the <b>Ckt Status</b> to NULL.</p> <p> <b>NOTE:</b> Deletion of an ACTIVE circuit results in disconnection deactivation of the circuit in the frame before the record is deleted in the I-2000.</p> <p><b>MODIFY</b> Allows you to change the <b>Ckt ID</b> of the establishing DS0 channel.</p> <p><b>DEACTIVATE</b> As a result of this action, enters the specified circuit in the I-2000 database as DEACTI-VATED and disconnects it in the frame.</p> <p><b>BROWSE</b> Gives you read-only access to the I-2000 database for retrieving and scrolling circuit records.</p>
<b>Ckt ID</b>	<p>Mandatory. must be unique. One through 41 characters from the printable ASCII character set, excluding *, \, ?, ", ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored.</p> <p>This field associates the name entered in this field to a connection between a DS0 channel and a DSPP platform.</p>

**Table 7-1. ESTABLISH DS0 CHANNEL Field Descriptions (Contd)**

<b>Ckt Status</b>	<p>A display-only field indicating the operating status of the circuit.</p> <p>NULL            The circuit has not been defined and, therefore, is not in the frame or I-2000 databases. To define the circuit, use the <b>ACTIVATE Action.</b></p> <p>ACTIVE            The circuit is active in the I-2000 database and/or the frame.</p> <p>DEACTIVATED    The circuit is in the I-2000 database but is not cross-connected in the frame. The I-2000 record is marked <b>DEACTIVATED</b>. To cross-connect the circuit, use the <b>ACTIVATE Action.</b></p>
<b>Ckt Class</b>	Mandatory. Read only field that specifies the type of circuit for an established DS0 channel. The only class for this field is EST.
<b>Hier</b>	An NPC number in hierarchical format. (See Chapter 4, "NPC Provisioning" for an explanation of hierarchical and extended formats.) As shown in the diagrams under <b>Ckt Class</b> above, an NPC identifier for the NPC of the FROM channel and another for the NPC of the TO channel are required for one-way and two-way, two-point circuits. The identifier can be a number in hierarchical format, a number in extended format, or the <b>NPC ID</b> . The NPC must have been provisioned.
<b>Ext</b>	The FROM or TO NPC number in extended format. Automatically provided if <b>Hier</b> or <b>NPC ID</b> was entered.
<b>NPC ID</b>	The FROM or TO <b>NPC ID</b> . With the entry of a value in <b>Hier</b> , <b>Ext</b> , or <b>NPC ID</b> , the I-2000 automatically performs a database query and displays the corresponding FROM or TO information in each field.
<b>Ch</b>	<p>The FROM channel number from 0-31 for CEPT or 1-24 for NAS.</p> <p>Virtual channel numbers can range from 1 to 500; however, one is automatically selected by the system during provisioning of virtual multipoint circuits.</p>
<b>TYPE</b>	<p>Mandatory. This field is populated automatically if a DSPP slot address has been selected.</p> <p style="text-align: center;"> <b>DANGER:</b> The <b>TO NP</b> type is read only.</p>

**Table 7-1. ESTABLISH DS0 CHANNEL Field Descriptions (Contd)**

<b>Transmission Standard</b>	Mandatory. This field accepts the following transmission standards: X.50, and X.57.  x . 50 A 64 kbit/s circuit that carries a number of multiplexed circuits of lower data rates using the International Telecommunications Union (ITC) X.50 recommendation.  x . 57 An individual lower rate circuit (lower than 64 kbit/s) that is transmitted on a 64 kbit/s facility using the ITC X.57 recommendation.
<b>Transmission Rate</b>	Entry for this field is required only if the Transmission Standard field is X.57.  Valid entries are: 2.4, 4.8, and 9.6.
<b>Bit Framing Pattern</b>	The I-2000 provides a blank default bit framing. Otherwise, the option F20 can be selected.
<b>UMC</b>	Optional. Unoccupied Multiplexer Channel. This field accepts two alphabetic characters.
<b>MUX</b>	Optional. If the multiplexer out of synchronization code is not specified. This field accepts two alphabetic characters.
<b>SIG</b>	Optional. If the signalling bits are not specified. This field accepts one alphabetic character.

## **DS0 Channel Examples**

The examples below describe how to deactivate, delete, modify, and modify DS0 channels.

### **Example: Deactivating a DS0 Channel**

This procedure deactivates the DS0 channel. To deactivate a DS0 channel, follow these steps:

1. At the PROVISIONING menu, select ESTABLISH DS0 CHANNEL and enter these data:
  - **Site Name:** DACS00
  - **Action:** DEACTIVATE
  - **Ckt ID:** CKT01



**NOTE:**

Once the Ckt ID of the established channel is entered, the rest of the data is populated on the screen.

2. Press **EXECUTE** and select IMMEDIATE. The result is that the I-2000 command completed message is displayed on the screen.

### **Example: Deleting a DS0 Channel**

---

This procedure removes the DS0 channel from the specified NPC. To remove a DS0 channel, follow these steps:

1. At the PROVISIONING menu, select ESTABLISH DS0 CHANNEL and enter these data:
  - **Site Name:** DACS00
  - **Action:** DELETE
  - **Ckt ID:** CKT01



**NOTE:**

Once the Ckt ID of the established channel is entered, the rest of the data is populated on the screen.

2. Press **EXECUTE** and select IMMEDIATE. The result is that the
  - I-2000 command completed message is displayed on the screen.
  - **Ckt Status** changes to NULL.

### **Example: Modifying a DS0 Channel**

---

This procedure allows you modify *only* the **Ckt ID**. To modify the **Ckt ID** for a DS0 channel, follow these steps:

1. At the PROVISIONING menu, select ESTABLISH DS0 CHANNEL and enter these data:
  - **Site Name:** DACS00
  - **Action:** MODIFY
  - **Ckt ID:** CKT09
2. Press **EXECUTE** and select IMMEDIATE. The result is that the I-2000 command completed message is displayed on the screen.

**Example: Browsing a DS0 Channel**

You can browse through the DS0 channels stored in the I-2000 database. In that case, you will use the ESTABLISH DS0 SEARCH CRITERIA form, which is displayed after you enter an **Action** of BROWSE and press **EXECUTE**. The CIRCUIT PROVISIONING SEARCH CRITERIA form is displayed, as shown in Figure 7-7.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- ESTABLISHED DS0 CHANNELS SEARCH CRITERIA -----
Site Name: ISX
Ckt Status:
Ckt ID:

Hier      Ext      NPC ID      Ch  TYPE
FROM:
TO:

Transmission Standard:      Transmission Rate:
UMC:                        MUX:                        SIG:

Enter Status to be searched.

```

HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE

**Figure 7-7. ESTABLISHED DS0 CHANNELS SEARCH CRITERIA Form**

The BROWSE selection retrieves the provisioning and status information concerning each of a range of established DS0 channels.

To browse an established DS0 channel, follow these steps:

1. Select PROVISIONING from the MAIN MENU and ESTABLISHED DS0 CHANNEL from the PROVISIONING menu.
2. Navigate to **Action** and select BROWSE.
3. Whatever value you enter into the **NPC ID** field limits the range of the BROWSE. Enter the wild card, \*, to BROWSE the first 50.
4. Press **EXECUTE**.

A search is conducted for the specified channel. Also, the data for the first established DS0 channel is displayed.

5. To obtain the next DS0 channel, press **NEXT**.
6. To stop the **BROWSE**, press **QUIT**.

## **Subrate Cross-Connect Provisioning**

---

In order to provision subrate cross connections, you must first have created a subrate NPC and established one or more DS0 channels. Refer to the previous sections "Procedure: Creating an NPC as a Subrate Type" and "Procedure: Establishing a DS0 Channel."

### **SUBRATE CROSS CONNECT Form**

---

To access the SUBRATE CROSS CONNECT form, follow these steps:

1. Select **PROVISIONING** from the **MAIN MENU**. The **PROVISIONING** menu is displayed, as shown in Figure 7-5.
2. Select **SUBRATE CROSS CONNECT** from the **PROVISIONING** menu. The **SUBRATE CROSS CONNECT** form is displayed, as shown in Figure 7-8.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- SUBRATE CROSS CONNECT -----
Site Name:
Action:                               Ckt Status:
Ckt ID:                               Ckt Class:
FROM EST CHANNEL CKT ID:
TO EST CHANNEL CKT ID:

      Hier      Ext      NPC ID          Ch      CUST
FROM:
TO:
Data Rate:

Customer Name:                        Service Date:
Loc A:                                Loc Z:
Rmks:

Enter the site name _____
HELP CHOICES [ ] QUIT RECNCILE TOP MENU PRINT EXECUTE

```

**Figure 7-8. SUBRATE CROSS CONNECT Form**

### Procedure: Establishing Subrate Cross-Connection

To establish a subrate cross connection, follow these steps:

1. Obtain the SUBRATE CROSS CONNECT form.
2. Fill in the following fields:
  - **Site Name:** DACS00
  - **Action:** ACTIVATE
  - **Ckt ID:** CKT03
  - **FROM EST CHANNEL CKT ID:** ckt03



**NOTE:**

The **FROM NPC** corresponding to the from channel will be automatically populated. However, if you enter the **FROM NPC** and **From Ch**, the **FROM EST CHANNEL ID** will be populated.

If you enter the **TO NPC** and the **TO Ch** of the **ESTABLISHED CHANNEL ID** the **TO ESTABLISHED Ckt ID** will be populated.

- **TO EST CHANNEL CKT ID:** ckt04
- **From CUST:** 1-1
- **To CUST:** 1-2



**NOTE:**

You must enter the number of the customer's subrate circuit for both the **FROM** and **TO EST CHANNEL CKT ID**.

- **Data Rate:** 4.8

3. Press **EXECUTE** and select **IMMEDIATE**. The **Ckt Status** changes to **ACTIVE**. In addition, the command completed successfully message is displayed.

**Field Descriptions**

Field descriptions for the **SUBRATE CROSS CONNECT** form are described in Table 7-2.

**Table 7-2. SUBRATE CROSS CONNECT Field Descriptions**

<p><b>Site Name</b></p>	<p>Mandatory. 1 through 24 characters from the set A-Z, a-z, 0-9, /, _, -. All other characters are illegal. Blanks are not allowed within the name.</p> <p>Enter the name of the frame in which the channel is to be provisioned. Pressing <b>CHOICES</b> displays WHICH DACS? with a list of the names that were established during frame administration, described in Chapter 2 "Getting Started." The default is the first name.</p>
<p><b>Action</b></p>	<p>Mandatory. Enter the action to be performed with regard to the circuit.</p> <p><b>ACTIVATE</b>      Enters the channel specified by <b>Ckt ID</b> in the I-2000 database (if it does not yet exist) and allows you to connect subrate customer circuits in the frame, making it an existing, traffic-carrying circuit.</p> <p>When this action is completed successfully, the <b>Ckt Status</b> changes from <b>NULL</b> to <b>ACTIVE</b>.</p>

**Table 7-2. SUBRATE CROSS CONNECT Field Descriptions (Contd)**

<p><b>Action</b></p>	<p><b>⇒ NOTE:</b>  <b>MODIFY</b> Retrieves the specified circuit from the I-2000 database for purposes of altering circuit attributes or <b>Ckt ID</b>. <b>MODIFY</b> does not change the <b>Ckt Status</b>.</p> <p><b>DELETE</b> Removes the specified circuit from the I-2000 and frame databases, returning the <b>Ckt Status</b> to NULL.</p> <p><b>⇒ NOTE:</b>          Deletion of an <b>ACTIVE</b> circuit results in deactivation of the circuit in the frame before the record is deleted in the I-2000. Deletion of an <b>ALTROUTED</b> circuit in the frame before the record is deleted in the I-2000.</p> <p><b>DEACTIVATE</b> The specified circuit in the I-2000 database as <b>DEACTIVATED</b> and disconnects it in the frame.</p> <p><b>BROWSE</b> Gives you read-only access to the I-2000 database for retrieving and scrolling circuit records.</p> <p>As soon as you press <b>EXECUTE</b> after entering an <b>Action</b> of <b>BROWSE</b>, the I-2000 displays the <b>CIRCUIT PROVISIONING SEARCH CRITERIA</b> form. Its fields are taken from the <b>CIRCUIT PROVISIONING</b> form. Entering a value in any defined field restricts the search. To initiate the search, press <b>EXECUTE</b>. To return to <b>CIRCUIT PROVISIONING</b> without executing, press <b>QUIT</b>.</p> <p><b>MODIFY</b> Allows you to change the <b>Ckt ID</b> of the establishing DS0 channel.</p>
<p><b>Ckt ID</b></p>	<p>Mandatory. must be unique. One through 41 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored.</p>
<p><b>Ckt Status</b></p>	<p>A display-only field indicating the operating status of the circuit.</p> <p><b>NULL</b> The circuit has not been defined and, therefore, is not in the frame or I-2000 databases. To define the circuit, use the <b>ACTIVATE Action</b>.</p> <p><b>ACTIVE</b> The circuit is active.</p>

Table 7-2. SUBRATE CROSS CONNECT Field Descriptions (Contd)

<b>Ckt Status (Continued)</b>	DEACTIVATED The circuit is in the I-2000 database but is not cross-connected in the frame. The I-2000 record is marked DEACTIVATED. To cross-connect the circuit, use the ACTIVATE Action.
<b>Ckt Class</b>	Mandatory. This is a read-only field that specifies the type of circuit. The only option displayed is SUB for subrate.
<b>Hier</b>	An NPC number in hierarchical format. (See Chapter 4, "NPC Provisioning" for an explanation of hierarchical and extended formats.) As shown in the diagrams under <b>Ckt Class</b> above, an NPC identifier for the NPC of the FROM channel and another for the NPC of the TO channel are required for one-way and two-way, two-point circuits. The identifier can be a number in hierarchical format, a number in extended format, or the <b>NPC ID</b> . The NPC must have been provisioned.
<b>Ext</b>	The FROM or TO NPC number in extended format. Automatically provided if <b>Hier</b> or <b>NPC ID</b> was entered.
<b>Ch</b>	The FROM or TO channel number, 0-31 for CEPT or 1-24 for NAS.
<b>FROM NPC</b>	The FROM NPC of the cross connection.
<b>FROM CH</b>	The From channel of the cross connection.
<b>FROM EST CHANNEL CKT ID</b>	Optional. This field allows you to specify the FROM <b>Ckt ID</b> for an established DS0 channel.  One through 41 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored.
<b>TO EST CHANNEL CKT ID</b>	Optional. This field allows you to specify the TO <b>Ckt ID</b> for an established DS0 channel.  One through 41 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored.
<b>TO NPC</b>	The To NPC of the cross connection.
<b>TO NPC</b>	The To channel of the cross connection.

**Table 7-2. SUBRATE CROSS CONNECT Field Descriptions (Contd)**

<b>CUST</b>	Mandatory. This field allows you to specify the customer number of a subrate circuit. This field accepts up to three characters. The formats for each of the following standards are:  <b>X.50 Standard:</b> Allowed values are "a-B", where "a" and "b" are two digits, for example 1-1. The "a" can be within a range from 1 to 5 and the "b" can be in a range from 1-4.  <b>X.57 Standard:</b> "1-1" is the <i>only</i> value for this standard.
<b>Data Rate</b>	Mandatory. This valid entries for this field are: 2.4, 4.8, and 19.2.
<b>Customer Name</b>	Optional. This field allows you to specify the customer name associated with a subrate circuit. This field accepts up to 12 characters.
<b>Service Date</b>	The I-2000 provides a default date as "today's" date. There are three fields associated with this field in the format DD MMM YY, where DD is the day, MMM is the first three letters of the month, and YY is the year.
<b>Loc A and Loc Z</b>	Optional. Up to 24 alphanumeric characters. Loc A is the location identifier for the FROM end of the circuit being provisioned and Loc Z is the TO end of the circuit being provisioned.
<b>Rmks</b>	Optional. This field allows you to specify up to 77 characters for remarks.

## Subrate Cross Connect Examples

The examples below describe how to deactivate, delete, and modify subrate cross connections.

### Example: Deactivating a Subrate Cross Connect

This procedure deactivates the subrate cross connection. To deactivate a subrate cross connection, follow these steps:

- At the PROVISIONING menu, select SUBRATE CROSS CONNECT and enter these data:
  - **Site Name:** DACS00
  - **Action:** DEACTIVATE
  - **Ckt ID:** CKT01

The rest of the data will automatically be populated.

2. Press **EXECUTE** and select IMMEDIATE. The result is that the: **Ckt Status** field changes to DEACTIVATED.

### **Example: Deleting a Subrate Cross Connect**

---

This procedure removes the subrate cross connection from the specified NPC.

To remove a subrate cross connection, follow these steps:

1. At the PROVISIONING menu, select SUBRATE CROSS CONNECT and enter these data:
  - **Site Name:** DACS00
  - **Action:** DELETE
  - **Ckt ID:** ckt09

The rest of the data will automatically be populated.

2. Press **EXECUTE** and select IMMEDIATE. The result is that the **Ckt Status** field changes to DELETED.

### **Example: Modifying a Subrate Cross Connect**

---

This procedure allows you modify *only* the **Ckt ID**. To modify the **Ckt ID** for a subrate cross connect, follow these steps:

1. At the PROVISIONING menu, select SUBRATE CROSS CONNECT and enter these data:
  - **Site Name:** DACS00
  - **Action:** MODIFY
  - **Ckt ID:** ckt09

2. Press **EXECUTE** and select IMMEDIATE. The result is that the:
  - **Service State** field changes to OOS
  - **Alarm State** changes to None
  - I-2000 command completed message is displayed on the screen.

### **Example: Browsing a Subrate Cross Connect**

---

You can browse through the subrate cross connections stored in the I-2000 database. In that case, you will use the SUBRATE CROSS CONNECT SEARCH CRITERIA form, which is displayed after you enter an **Action** of BROWSE and press **EXECUTE**. The SUBRATE CROSS CONNECT SEARCH CRITERIA form is displayed, as shown in Figure 7-9.

```
06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
SUBRATE CIRCUITS SEARCH CRITERIA
Site Name: ISX
Ckt Status:
Ckt ID:

Hier      Ext      NPC ID      Ch  Cust
FROM:
/ TO
Data Rate:

Enter the site name.
```

HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE

**Figure 7-9. SUBRATE CIRCUITS SEARCH CRITERIA Form**

The **BROWSE** selection retrieves the provisioning and status information concerning each of a range of subrate cross connections.

To browse a subrate cross connection, follow these steps:

1. Select **PROVISIONING** from the **MAIN MENU** and **SUBRATE CROSS CONNECT** from the **PROVISIONING** menu.
2. Navigate to **Action** and select **BROWSE**.
3. Whatever value you enter into the **NPC ID** field limits the range of the **BROWSE**. Enter the wild card, \*, to **BROWSE** the first 50.
4. Press **EXECUTE**.

A search is conducted for the specified channel. Also, the data for the first established subrate cross connection is displayed.

5. To obtain the next subrate cross connection, press **NEXT**.
6. To stop the **BROWSE**, press **QUIT**.

---

## Contents

<b>Introduction</b>	8-1
<b>Altrouting</b>	8-1
■ Procedure: Specifying a “real” Altroute	8-2
Field Descriptions	8-5
■ Procedure: Completing a “real” Altroute	8-6
<b>Preempting</b>	8-6
<b>Normalizing</b>	8-7
■ Procedure: Normalizing an Altrouted Circuit	8-8
■ Procedure: Normalizing an Out of Service NPC	8-8
<b>Altrouting and Normalizing Examples</b>	8-8
■ Single Channel Circuits	8-9
Example: Configuring a “Real” Altroute	8-9
Example: Normalizing a “real” Altroute	8-11
Example: Performing a Pseudo-Altroute	8-11
Example: Normalizing a Pseudo-Altroute	8-12
Example: Altrouting a Half-duplex Circuit to a Full-duplex Circuit	8-12
Example: Normalizing an ALTRROUTE of a Half-duplex Circuit to Part of a Full-duplex Circuit	8-12
Example: Altrouting a Half-duplex Circuit to an Unused Pre-empted Full-duplex Circuit	8-13
Example: Normalizing an ALTRROUTE of a Half-duplex Circuit to a Full-duplex Circuit	8-13

---

## Contents

■ High-rate Circuits	8-14
Example: Altrouting a Real, High-rate Circuit	8-14
Example: Normalizing an Altroute of a Real, High-rate Circuit	8-15
Example: Altrouting a Single-channel Circuit to a Pre-empted High-rate Circuit	8-16
Example: Normalizing an ALTRROUTE of a Single-channel Circuit to a Preempted High-rate Circuit	8-17
■ Multipoint Circuits	8-17
Example: Altrouting a Leg in a Broadcast Circuit	8-17
<b>NPC ROLL</b>	8-18
■ NPC ROLL Form	8-18
■ Field Descriptions	8-19
■ Example: Rolling NPC Circuits	8-20

## Introduction

---

When a transmission facility fails, it may be necessary for the I-2000 operator to switch circuits connected to that facility to an alternate route. This section describes how to use the **ALTROUTE Action** to execute alternate routing, or altrouting, from the I-2000, and how the I-2000 handles circuit preempting and normalizing of altrouted circuits.

Also, the NPC ROLL selection moves all the circuits on one NPC to another.

## Altrouting

---

The following constraints apply to altrouting:

- A circuit in any **Ckt Status** can be altrouted (rerouted to an alternate route), except circuits that are already in the **ALTROUTED** or **DEROUTED Ckt Status**. You can even create a new circuit in the **ALTROUTED Ckt Status**.
- You can only **ALTROUTE** a circuit once. Before altrouting a second time, you must first **DEACTIVATE** or **NORMALIZE** (return it to its primary route).
- An **ALTROUTED** circuit is not available for being preempted (bumped from a channel assignment) until it has been deactivated or normalized.
- An **ALTROUTED** circuit can only be deactivated, normalized, or deleted. It can be activated in `local only` mode, but any circuit that it preempted will be deactivated.

For high-rate circuits:

- When you `ALTRROUTE` an EFT in a multichannel circuit, all the channels on that side of the circuit get altrouted, possibly requiring the preempting of multiple circuits (see the section "Preempting" later in this chapter).
- Random circuits cannot be altrouted.

For multipoint circuits:

- Only the EFTs can be altrouted; the virtual node of a broadcast circuit or the DMB channel of a symmetric voice circuit or of a polling data circuit cannot be. Multipoint altrouting means that you change the EFTs of the legs, but not the branch point.

For BCON circuits:

- BCON circuits cannot be altrouted.

Most altrouting occurs when you use the I-2000 to route a circuit that is connected in the DACS (`ACTIVE Ckt Status`) through another DACS channel. This is a "real" `ALTRROUTE Action`.

However, an `ALTRROUTE` in which all channel ends are altrouted to themselves is called a "pseudo-"`ALTRROUTE`. The pseudo-`ALTRROUTE` allows you to put up a temporary circuit, in `ALTRROUTE Ckt Status`, that becomes deactivated on normalization, without special action to deactivate it.

### **Procedure: Specifying a "real" Altroute**

---

To specify a **real** altroute using the `ALTRROUTE` screen, follow these steps:

1. Obtain the `CIRCUIT PROVISIONING` form, as shown in Figure 8-1.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- CIRCUIT PROVISIONING -----
Site Name:DACS00                               Ckt Status:ACTIVE
Action:ALTRROUTE                               Ckt Class:FDX
Ckt ID:circl                                   Bandwidth Type:A

      Hier      Ext      NPC ID      Ch
FROM: 01101    0001    firstnpc  001
TO:   01102    0002    secondnpc 001

Bandwidth:1      Options:

TC:0011,0011    IW:TRB   SC:      Framing:
Loc A:          Loc Z:
Customer Name:  Service Date:DD MMM YY  Ckt Priority:00
Rmks:

Enter the site name.
    
```

HELP [ ] NEXTPAGE QUIT RECNCILE TOP MENU PRINT EXECUTE

**Figure 8-1. CIRCUIT PROVISIONING Form**

2. Enter the **Site Name**, an **Action** of ALTRROUTE and the **Ckt ID**.

You must press **Enter** after entering the Ckt ID.

3. Press **NEXTPAGE**.

The ALTRROUTE screen is available only in this way. It enables you to perform alternate channel connections and informs you what the PREEMPTED circuit(s) will be.

**⇒ NOTE:**  
A pseudo-ALTRROUTE is entered on the CIRCUIT PROVISIONING form only.

The ALTRROUTE screen is displayed, as shown in Figure 8-2.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- CIRCUIT PROVISIONING -----
Site Name:DACS00           Altroute Date & Time:
Ckt ID:circl              Ckt Status:ACTIVE
Ckt Priority:00 Bandwidth:1 Bandwidth Type:A   Ckt Class:FDX
Rmks:

NORMAL      Hier  Ext           NPC ID           Ch
          FROM: 01101 0001 firstnpc           007
          TO:  01101 0001 firstnpc           008
ALTRROUTE
          FROM:
          TO:

Preempted
Ckt ID:              Status:           CP:

-- Enter the FROM Side NPC Number (Hierarchical format) --
HELP  [ ]  NEXTPAGE  QUIT  RECNCILE  TOP MENU  PRINT  EXECUTE

```

**Figure 8-2. ALTRROUTE Screen**

The ALTRROUTE screen contains the following sections of information:

- **CIRCUIT PROVISIONING**—The fields on the top half of the screen are the essential fields from the first page of the CIRCUIT PROVISIONING form, which concern the circuit being altrouted. When the altrouting operation is complete, the **Ckt Status** field is ALTRROUTED and the **Altroute Date & Time** field indicates the date and time the ALTRROUTE took effect.
- **NORMAL**—The fields under **NORMAL** display the primary channel assignment of the ALTRROUTED circuit, carried over from the first page.
- **ALTRROUTE**—The fields under **ALTRROUTE** specify the channel assignment to which you are going to ALTRROUTE the circuit.
- **Preempted**—The fields under **Preempted** identify information concerning circuits that are being preempted by this ALTRROUTE.

The following constraints apply to the use of the ALTRROUTE screen:

- If you enter an altrouted channel connection and press **EXECUTE**, the I-2000 verifies whether the channel you picked is spare.
- If you enter a **NPC ID** without a channel number, the I-2000 picks a spare channel from that NPC, if one is available. If one is not available, you must enter a channel.

- If the channel entered in any case is not spare, the I-2000 prompts you for preemption confirmation. Note that if you do not answer YES to all confirmation prompts, the entire altroute is terminated and you must start again from the beginning.
- If the ALTRROUTE is successful, the **Altroute Date & Time** indicates when these circuits were altrouted.
- When any circuit is in the ALTRROUTED **Ckt Status**, you can call up the I-2000 database record for the circuit via the CIRCUIT PROVISIONING screen and observe the ALTRROUTE screen to see the routing destination, the time of altrouting and the circuit(s) preempted by the altrouting.
- The Preempted fields indicate the **Ckt ID**, **Ckt Status**, and **CP** fields of the PREEMPTED circuit. Use **NEXT** to scroll through the PREEMPTED circuits (if there are more than one).

The following table summarizes the fields of the ALTRROUTE screen and their values. For full descriptions, refer to Chapter 6 "Circuit Provisioning."

### Field Descriptions

Field descriptions for the ALTRROUTE screen are described in Table 8-1.

**Table 8-1. ALTRROUTE Field Descriptions**

Name	Field Size	Values
Site Name	24	Established on the FRAME ADMINISTRATION form
Altroute Date & Time	19	DD MMM YY HH:MM:SS
Ckt ID	41	All printable characters except *, ?, \, [, ], ^, ", %,
Ckt Status	11	ACTIVE, DEACTIVATED, ALTRROUTED, PREEMPTED, PENDING, NULL
Ckt Priority	2	a-z, A-Z, 0-9
Bandwidth	2	1-24 NAS, 1-31 CEPT
Bandwidth Type	1	A or C
Ckt Class	3	FDX, HDX, BBL, BRD, DMB
Rmks	77	All printable characters except *, ?, \, [, ], ^, ", %,
Hier	5	xxyzz, xx is 01-16, y is 1-8, zz is 01-40
Ext	4	0001-256H
NPC ID	41	All printable characters except *, ?, \, [, ], ^, ", %,
Ch	3	0-31 CEPT or 0-24 NAS

**Table 8-1. ALTRROUTE Field Descriptions (Contd)**

Name	Field Size	Values
Preempted Ckt ID	41	All printable characters except *, ?, \, [, ], ^, ", %,
Ckt Status	11	ACTIVE, PREEMPTED
CP	2	a-z, A-Z, 0-9

### Procedure: Completing a "real" Altroute

To complete a real Altroute, follow these steps:

1. Fill in the **FROM** line under ALTRROUTE:
  - **NPC ID:** facility01
  - **Ch:** 001
2. Fill in the **TO** line:
  - **NPC ID:** facility01
  - **Ch:** 002
3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** changes according to your circuit setup; and an ALTROUTED is displayed.

In addition, a completion message is displayed.

### Preempting

A circuit can be altrouted to a spare, unused channel (which is preferable but may be unavailable), or to a channel already in use by other circuits. In this latter case, the other circuits are preempted; that is, they are temporarily bumped off their channel assignment.

- Preempted circuits stay in the PREEMPTED **Ckt Status** until they are normalized or you manually change them to another **Ckt Status**.
- Once you manually change the **Ckt Status** of a PREEMPTED circuit, it can no longer be automatically normalized to its primary channel assignment; you would have to do this via a CIRCUIT PROVISIONING **Action**.
- An NPC and channel cannot be preempted twice. A second attempt is denied.
- Some channels on a PREEMPTED circuit may not be required for the ALTROUTED circuit. They are still available for preemption by other circuits.
- Once any channels on a circuit are preempted, that circuit is in the PREEMPTED **Ckt Status** and cannot be activated to carry traffic until all pre-empted channels on the circuit are normalized.

- You can place a `PREEMPTED` circuit in service on other channels with an `ALTRROUTE Action`. This `Action` will remove it from the preemption list of its original preempting circuit. You can return it to its original path with a `NORMALIZE Action` when the original channels are available. If they are not, the normalization will leave the circuit in the `DEACTIVATED` status.
- If more than one circuit preempts the channels on a `PREEMPTED` circuit, the `PREEMPTED` circuit cannot be reactivated until all the preemption has been removed from its channels. The normalizing of the last preempted channel reactivates the `PREEMPTED` circuit.

For high-rate circuits:

- Random circuits can be preempted, although they cannot be altrouted.

For multipoint circuits:

- Any or all of the EFTs can be preempted. For DMB, the EFT of a leg can be preempted. For both virtual and DMB, the corresponding legs are then placed in `PREEMPTED Ckt Status`. However, the virtual node or DMB channel remains `ACTIVE`, meaning that additional legs can be attached to it at any time.

For BCON circuits:

- BCON circuits cannot be preempted.

When you specify an altrouting operation that preempts `ACTIVE` circuits, the I-2000 displays a pop-up insert prompting for a confirmation of the preemption, and you must enter `YES` to authorize the preemption. When you `ALTRROUTE` a multichannel circuit requiring the preemption of multiple circuits, you must authorize the preemption of each circuit. A new confirmation insert pops up for each preempted channel. If you select `NO` at any point, the entire `ALTRROUTE Action` is canceled.

## Normalizing

---

When you `NORMALIZE` an `ALTROUTED` circuit, the circuit is rerouted from its temporary channel to the original channel for which it was provisioned and is returned to its pre-`ALTROUTED` connection `Ckt Status`. Any `PREEMPTED` circuits are reactivated.

- When you `NORMALIZE` a real `ALTROUTED` circuit, the original circuit is restored to `ACTIVE Ckt Status`.
- When you `NORMALIZE` a pseudo-`ALTROUTED` circuit, the original circuit is restored to `DEACTIVATED Ckt Status`.
- `DEACTIVATE` also performs a `NORMALIZE` and leaves the original circuit in the `DEACTIVATED Ckt Status`, whether it was a real or a pseudo-`ALTRROUTE`.
- If another circuit was preempted by the `ALTROUTED` circuit, the I-2000 attempts to reactivate the `PREEMPTED` circuit, provided that the circuit just returned to `ACTIVE` was the only one preempting it.

- Circuits which cannot be reactivated for any reason are put in DEACTIVATED **Ckt Status** so that the user can work on them when conditions permit.
- If a conflict arises during a normalization, the preempted circuits are put into a DEACTIVATED **Ckt Status** to be worked on later by the user.

### **Procedure: Normalizing an Altrouted Circuit**

---

To normalize an Altrouted circuit, follow these steps:

1. From the CIRCUIT PROVISIONING form, call up the record for the ALTROUTED circuit you want to normalize. You can do this by entering the **Site Name** and **Ckt ID**.
2. Enter an **Action** of NORMALIZE.
3. Press **EXECUTE** and select IMMEDIATE. The ALTROUTED circuit is disconnected and reactivated on its primary channel assignments.

The screen is updated to reflect the new **Ckt Status** of the circuit.

### **Procedure: Normalizing an Out of Service NPC**

---

To normalize an NPC that was out of service, follow these steps:

1. Obtain the CIRCUIT PROVISIONING form.
2. Enter or select:
  - **Action:** MODIFY
  - **Options:** D

This option selects OOS.



**NOTE:**

You must also select the options previously in effect.

3. Press **EXECUTE** and confirm.
4. NORMALIZE as described in the previous procedure.

### **Altrouting and Normalizing Examples**

---

This section contains integrated examples of altrouting and normalizing. The model underlying these examples is described in Table 8-2.

In Figure 8-3, the following NPCs have been provisioned, as shown in Table 8-2:

**Table 8-2. Sample Provisioned NPCs**

NPC NO.	NPC ID	NPC TYPE	NPC NO.	NPC ID	NPC TYPE
001	dgrpA	DE210	004	dgrpF	DE210
002	dgrpD	DE210	121	dgrpB	PB144
003	dgrpG	DE210	122	dgrpC	PB144

Table 8-3 shows the circuits that have been provisioned:


**Table 8-3. Sample Provisioned Circuits**

CKT ID	CLASS	BW	BW TYPE	FROM		TO	
				NPC	CHAN	NPC	CHAN
MM01	FDX	3	C	dgrpA	06	dgrpB	02
MM02	FDX	4	C	dgrpC	12	dgrpB	12
MM03	HDX	2	A	dgrpA	18	dgrpA	21
MM04	HDX	1	-	dgrpA	19	dgrpA	20
MM05	FDX	1	-	dgrpD	15	dgrpG	17
MM06	HDX	1	-	dgrpF	05	dgrpG	09
MM07	HDX	1	-	dgrpG	08	dgrpF	04

### Single Channel Circuits

#### Example: Configuring a “Real” Altroute

Figure 8-3 shows an example of how to configure an `ALTROUTE` of a real, single-channel, two-point, full-duplex, NAS-only circuit. The `TO` side is changed to a spare channel. Circuit `MM05` currently goes from `dgrpD`, Channel 15, to `dgrpG`, Channel 17. The example altroutes `MM05` to `dgrpG`, Channel 1, which is spare, and is not shown. No preemptions are necessary.



**Figure 8-3. Example of Altrouting**

To configure a "real" Altroute, follow these steps:

1. Select **CIRCUIT** from the **PROVISIONING** menu.
2. Enter the following data, being sure to press **[Enter]**:
  - **Action:** ALTRROUTE
  - **Ckt ID:** MM05

The I-2000 confirms the existing circuit. The **Ckt Status** is **ACTIVE**.

3. Press **[NEXTPAGE]**.

4. Enter the following data under ALTRROUTE:
  - **TO NPC ID:** dgrpG
  - **TO Ch:** 1
5. Press **EXECUTE** and select IMMEDIATE. The results are:
  - The I-2000 sends commands to disconnect the original TO and connect the altrouted TO.
  - **Altroute Date & Time** is filled in.
  - The **Ckt Status** field changes to ALTROUTED.
  - A completion message from the I-2000 is displayed.

**Example: Normalizing a “real” Altroute**

To normalize the previous example, follow these steps:

1. After selecting CIRCUIT under PROVISIONING, enter:
  - **Action:** NORMALIZE
  - **Ckt ID:** MM05

The I-2000 confirms the existing circuit. The **Ckt Status** is ALTROUTED.

2. Press **EXECUTE** and select IMMEDIATE. The results are:
  - The I-2000 sends commands to the DACS to disconnect the altrouted TO and connect the original TO.
  - The **Ckt Status** field changes to ACTIVE.
  - A completion message from the I-2000 is displayed.

**Example: Performing a Pseudo-Altroute**

To perform a pseudo-ALTRROUTE on the same original circuit, as in the previous example (on MM05), follow these steps:

1. Select CIRCUIT under PROVISIONING.
2. Enter the following data:
  - **Action:** ALTRROUTE
  - **Ckt ID:** MM05

The I-2000 displays the information for the **Ckt ID**.

- **TO NPC ID:** dgrpG
  - **TO Ch:** 017
3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** field changes to ALTROUTED. In addition, a completion message is displayed.

### Example: Normalizing a Pseudo-Altroute

To normalize the previous example, follow these steps:

1. After selecting CIRCUIT under PROVISIONING, enter:

- **Action:** NORMALIZE
- **Ckt ID:** MM05

The I-2000 confirms an existing circuit. The **Ckt Status** is ALTROUTED.

2. Press **EXECUTE**, select IMMEDIATE. The **Ckt Status** field changes to DEACTIVATED. In addition, a completion message is displayed.

### Example: Altouting a Half-duplex Circuit to a Full-duplex Circuit

To perform a real ALTROUTE of a single-channel, half-duplex, NAS-only circuit, MM06. The FROM end is changed to one direction of an EFT, dgrpD, Channel 15, which is already in use for a full-duplex circuit, MM05. The result is its preemption

To perform an Altroute of a half-duplex circuit to part of a full-duplex circuit, follow these steps:

1. Enter the following data under CIRCUIT PROVISIONING:

- **Action:** ALTROUTE
- **Ckt ID:** MM06

The I-2000 confirms the existing circuit. The **Ckt Status** is ACTIVE.

2. Press **NEXTPAGE**, and then enter the following data under ALTROUTE:

- **FROM NPC ID:** dgrpD
- **FROM Ch:** 15

3. Press **EXECUTE** and select IMMEDIATE, and also answer YES when asked if it is OK to preempt circuit MM05.

The **Ckt Status** of the MM06 circuit changes to ALTROUTED.

4. Enter the following data:

- **Ckt ID:** MM05

The **Ckt Status** field now says PREEMPTED.

### Example: Normalizing an ALTROUTE of a Half-duplex Circuit to Part of a Full-duplex Circuit

To normalize the previous example, follow these steps:

1. Enter the following data in CIRCUIT PROVISIONING:

- **Action:** NORMALIZE
- **Ckt ID:** MM06

The I-2000 confirms the existing circuit. The **Ckt Status** is ALTROUTED.

2. Press **EXECUTE** and select IMMEDIATE; observe that the **Ckt Status** of MM06 changes to ACTIVE.
3. Enter the following data:
  - **Ckt ID:** MM05
  - The **Ckt Status** field now says ACTIVATED.

**Example: Altrouting a Half-duplex Circuit to an Unused Pre-empted Full-duplex Circuit**

To perform a real ALTRROUTE of a single-channel, half-duplex circuit, MM07. The TO side is changed to the unused side of a full-duplex circuit, MM05, that has already been preempted by another half-duplex circuit.

To perform an Altroute of a half-duplex circuit to the unused part of a pre-empted full-duplex circuit, follow these steps:

1. Enter the following data within CIRCUIT PROVISIONING:
  - **Action:** ALTRROUTE
  - **Ckt ID:** MM07

The I-2000 confirms the existing circuit. The **Ckt Status** is ACTIVE.
2. Enter the following data under ALTRROUTE:
  - **TO NPC ID:** dgrpD
  - **TO Ch:** 15
3. Press **EXECUTE**, select IMMEDIATE, and also reply YES when asked if it is OK to preempt circuit MM05. Soon, after the completion message appears, the **Ckt Status** field changes to ALTROUTED.

**Example: Normalizing an ALTRROUTE of a Half-duplex Circuit to a Full-duplex Circuit**

To normalize the previous circuit, follow these steps:

1. Enter on the CIRCUIT PROVISIONING form:
  - **Action:** NORMALIZE
  - **Ckt ID:** MM07

The I-2000 confirms the existing circuit. The **Ckt Status** is ALTROUTED.
2. Press **EXECUTE** and select IMMEDIATE. Then observe that the completion message appears and that the **Ckt Status** field changes to ACTIVE.
3. Enter **Ckt ID:** MM05 .

The **Ckt Status** field now says ALTROUTED.

## High-rate Circuits

---

### Example: Altrouting a Real, High-rate Circuit

To ALTROUTE a real, high-rate, two-point, full-duplex gateway circuit, MM01. Both ends (FROM and TO) are changed to EFTs already in use by other circuits: the initial FROM **Ch** is changed to dgrpA, Channel 19, and the corresponding TO **Ch** is changed to dgrpB, Channel 12. These ends are already in use by circuits MM04 and MM02, respectively, and dgrpA, Channel 21 is in use by Circuit MM03. The result is preemption of MM02, MM03 and MM04.

To perform an Altroute of a real high-rate circuit, follow these steps:

1. After selecting CIRCUIT PROVISIONING, enter the following data, being sure to press **Enter**:

- **Action:** ALTROUTE
- **Ckt ID:** MM01

The I-2000 confirms the existing circuit. The **Ckt Status** is ACTIVE.

2. Press **NEXTPAGE**, and then enter the following data under ALTROUTE:

- **FROM NPC ID:** dgrpA
- **FROM Ch:** 19
- **TO NPC ID:** dgrpB
- **TO Ch:** 12

3. Press **EXECUTE** and select IMMEDIATE.

4. Answer YES when prompted if it is OK to preempt circuits MM02, MM03, and MM04.

5. The following actions occur:

- The I-2000 sends a disconnect command for the MM01 circuit.
- The DACS sends a COMPLD message.
- The I-2000 sends a disconnect command for the MM02 circuit.
- The DACS sends a COMPLD message.
- The I-2000 sends two disconnect commands for the MM03 circuit.
- The DACS sends a COMPLD message.
- The I-2000 sends a disconnect command for the MM04 circuit:
- The DACS sends a COMPLD message.
- The I-2000 sends a connect command for the MM01 circuit on DGRPA/channel 19 and DGRP B/channel 12.
- The DACS sends a COMPLD message.
- The **Ckt Status** of MM01 circuit changes to ALTROUTED.
- The I-2000 displays a completion message.

6. Enter the following data: **Ckt ID:** MM02  
The **Ckt Status** field changes to PREEMPTED.
7. Enter the following data: **Ckt ID:** MM03  
The **Ckt Status** field changes to PREEMPTED.
8. Enter the following data: **Ckt ID:** MM04  
The **Ckt Status** field changes to PREEMPTED.

**Example: Normalizing an Altroute of a Real, High-rate Circuit**

To normalize the previous circuit, follow these steps:



**NOTE:**

In this example, multiple circuits are restored.

1. In CIRCUIT PROVISIONING, enter the following data:
  - **Action:** NORMALIZE
  - **Ckt ID:** MM01The I-2000 confirms the existing circuit. The **Ckt Status** is ALTROUTED.
2. Press **EXECUTE** and select IMMEDIATE. The result is
  - The I-2000 sends a disconnect command for the MM01 circuit on dgrpA/channel 19 and dgrpB/channel 12.
  - The DACS sends a COMPLD message.
  - The I-2000 sends a connect command for the MM01 circuit on dgrpA/channel 6 and dgrpB/channel 2.
  - The DACS sends a COMPLD message.
  - The I-2000 sends a connect command for the MM02 circuit.
  - The DACS sends a COMPLD message.
  - The I-2000 sends a connect command for the MM04 circuit:
  - The DACS sends a COMPLD message.
  - Finally, the **Ckt Status** of the MM01 circuit changes to ACTIVE.
3. Enter the following data: **Ckt ID:** MM02  
The **Ckt Status** field changes to ACTIVE.
4. Enter the following: **Ckt ID:** MM03  
The **Ckt Status** field changes to PREEMPTED.
5. Enter the following data: **Ckt ID:** MM04  
The **Ckt Status** field changes to ACTIVE.

### Example: Altrouting a Single-channel Circuit to a Pre-empted High-rate Circuit

To perform a real `ALTRROUTE` of a single-channel, full-duplex circuit, MM05. The FROM end is changed to an unused EFT of a high-rate circuit, MM03, that has already been preempted.

To perform an Altroute of a single-channel circuit to the unused part of a preempted high-rate circuit, follow these steps:

1. Enter the following data under `CIRCUIT PROVISIONING`:

- **Action:** `ALTRROUTE`

- **Ckt ID:** `MM05`

The I-2000 confirms the existing circuit. The **Ckt Status** is `PREEMPTED`.

2. Enter the following data under `ALTRROUTE CHANNEL CONNECTION`:

- **FROM NPC ID:** `dgrpA`

- **FROM Ch:** `23`

3. Press `EXECUTE`, select `IMMEDIATE`, and reply `YES` when asked if it is OK to preempt circuit MM03. After the completion message, the **Ckt Status** of the MM05 circuit changes to `ALTROUTED`.

4. Generate and print an `ALTROUTED CIRCUITS` data report:

- c. Press `TOP MENU`, select `REPORT OPERATIONS` from the `MAIN MENU`, and select `ALTROUTES/PREEMPTIONS` from the `REPORT OPERATIONS` menu.

- d. Select `ALTROUTED CIRCUITS`.

- e. Press `EXECUTE` and confirm to get a listing of all `ALTROUTED` circuits.

- f. Wait for the report to be generated, select `DISPLAY LAST GENERATED REPORT`, and then select `PRINTER`.

5. Observe that the report lists circuits MM01, MM05, MM06, and MM07.

6. Now print a `PREEMPTED CIRCUITS` report:

- a. Proceed as in Step 4 except select `PREEMPTED CIRCUITS` instead of `ALTROUTED CIRCUITS`.

- b. Press `EXECUTE` and confirm to get a listing of all `ALTROUTED` circuits.

- c. Wait for the report to be generated, select `DISPLAY LAST GENERATED REPORT`, then select `PRINTER`.

The report lists circuits MM02, MM03, and MM04.

### **Example: Normalizing an ALTROUTE of a Single-channel Circuit to a Preempted High-rate Circuit**

To normalize circuit MM05, follow these steps:

1. At CIRCUIT PROVISIONING enter the following data:

- **Action:** NORMALIZE
- **Ckt ID:** MM05

The I-2000 confirms the existing circuit. The **Ckt Status** is ALTROUTED.

2. Press **EXECUTE** and select IMMEDIATE. The results are:

- The I-2000 sends a disconnect command for the MM05 circuit on dgrpA/channel 23.
- The DACS sends a COMPLD message.
- The I-2000 sends a connect command for the MM05 circuit on dgrpD/channel 15.
- The DACS sends a COMPLD message.
- The I-2000 sends two connect commands for the MM03 circuit.
- The DACS sends a COMPLD message.
- The **Ckt Status** of the MM05 circuit changes to ACTIVE.
- The I-2000 sends a completion message.

3. Repeat the steps given earlier for printing an ALTROUTED CIRCUITS report. The report should NOT list circuits MM01, MM05, MM06, and MM07.

4. Then print a PREEMPTED CIRCUITS report. It should NOT list circuits MM02, MM03, and MM04.

### **Multipoint Circuits**

---

#### **Example: Altrouting a Leg in a Broadcast Circuit**

To move the source of the broadcast in the virtual multipoint example from Chapter 6, "Circuit Provisioning," from NPC 33JJ09, Channel 1, to a spare channel, NPC 33KK16, Channel 10.

To perform an Altroute of a leg in a broadcast circuit, follow these steps:

1. On the CIRCUIT PROVISIONING form, enter:

- **Action:** ALTRROUTE
- **Ckt ID:** MULTIN

The I-2000 confirms the existing circuit. The **Ckt Status** is ACTIVE.

2. Press **NEXTPAGE**, and then enter the following data under ALTROUTE:
  - **FROM NPC ID:** 33JJ09
  - **FROM Ch:** 001
3. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** of circuit MULTIN changes to ALTROUTED.

A completion message from the I-2000 is displayed.
4. Navigate to **FROM NPC ID** and use **NEXT** to scroll through the BRDs. Their **Ckt Statuses** remain ACTIVE.

The leg can be returned to service as it was, and any other leg can be restored by normalization.

## NPC ROLL

---

Using the NPC ROLL selection of the PROVISIONING menu, you may switch all circuit connections from one facility NPC to another. NPC types that can be rolled are DE, TE, PB, PC, DA, PA, and TA. The following constraints apply:

- The NPCs must be present on the DACS.
- Both NPCs must be in the I-2000 database.
- The **Roll To** NPC must have a **State** of IS.
- No channel in the **Roll To** NPC may be assigned to any circuit in the ACTIVE, ALTROUTED, PREEMPTED or DEROUTED **Ckt Status**.
- No channel in the **Current NPC** may be assigned to any substrate circuit.
- No channel in the Current NPC may be assigned to any BCON circuit.
- The NPCs must not be under test.

An NPC ROLL affects circuits in ACTIVE or ALTROUTED **Ckt Status** only. At the beginning of the roll, ACTIVE circuits are placed in DEACTIVATED **Ckt Status** and ALTROUTED circuits are placed in DEROUTED **Ckt Status**. If the system fails during the roll, they remain in those **Ckt Statuses**. At the end of the roll, they are returned to their original **Ckt Statuses**.

An NPC ROLL changes every reference to the NPC throughout the I-2000 system; for example, in all circuits referencing the NPC, regardless of status, in all RPs, ARPs and in stored data resulting from NPC PROVISIONING.

**⇒ NOTE:**  
DACS II has an NPC Roll feature that works differently than the I-2000 feature. The I-2000 does not process the echoed response of an NPC Roll using the DACS II command. The DACS II command is SW-ROLL-T1.

### NPC ROLL Form

---

To transfer circuit connections from one NPC to another, select NPC ROLL from the PROVISIONING menu.

The NPC ROLL form is displayed, as shown in Figure 8-4.

Figure 8-4. NPC ROLL Form

### Field Descriptions

Field descriptions for the NPC Roll form are described in Table 8-4.

Table 8-4. NPC ROLL Field Descriptions

<b>Site Name</b>	Mandatory. 1 through 24 characters from the set A-Z, a-z, 0-9, /, _, and -. All other characters are illegal. Blanks are not allowed within a name.  Enter the name of the DACS on which the <b>Current</b> and <b>Roll To</b> NPCs are provisioned.
<b>Current Hier, Ext, NPC ID</b>	Mandatory. The hierarchical number, extended number, or NPC ID of the NPC from which the circuits are to be rolled. Whichever field you select, the others will be filled in automatically.
<b>Current Type</b>	Display only. The <b>Type</b> of the <b>Current</b> NPC, from the NPC PROVISIONING form. The value of this field is determined by the DACS hardware supporting the NPC of this number.

**Table 8-4. NPC ROLL Field Descriptions (Contd)**

<b>Roll To Hier, Ext, NPC ID</b>	<p>Mandatory. The identifiers of the NPC to which the circuits are to be rolled. The <b>Current</b> and <b>Roll To</b> NPCs must match as follows, or you will not successfully complete a roll with these NPCs:</p> <ul style="list-style-type: none"> <li>— Any DE**x, TE**x, DC**x or DA**x will match any other DE**x, TE**x or DA**x respectively except where x is 9 (Clear DS1 types).</li> <li>— Any DE**9, TE**9, DC**9 or DA**9 will match any other DE**9, TE**9, DC**9 or DA**9 respectively.</li> <li>— Any PA***, PB*** or PC*** will match any other PA***, PB*** or PC*** respectively, so long as both are CAS type or NAS type.</li> </ul>
----------------------------------	--

**Example: Rolling NPC Circuits**

Circuits are to be rolled from 55US23 to 43TZ86. Both are IS NPCs of **Type** DE.

To roll these NPC circuits, follow these steps:

1. Select PROVISIONING from the MAIN MENU and NPC ROLL from the PROVISIONING menu.
2. Enter the following data, or use the displayed defaults:
  - **Site Name:** DACS00
  - **Current NPC ID:** 55US23
  - **Roll To NPC ID:** 43TZ86
3. Press **EXECUTE** and confirm. The task executes in the background only.

The I-2000 **Status** line displays an IN PROGRESS message.

All references to the current NPC in the I-2000 are replaced with **Roll To** NPC data.

A completion message is displayed in the I-2000 **Status** line.

A circuit failure during the roll is logged the same way as a failure at any other time. The roll continues.

To see the results of the roll, access the NPC ROLL Report (see Chapter 14, "Report Operations"). Only the results of the last NPC ROLL are available.

---

## Contents

<b>Introduction</b>	9-1
<b>Single Plans</b>	9-2
■ RECONFIGURATION PLAN PROVISIONING Form	9-2
■ Field Descriptions	9-3
<b>Reconfiguration Plan Examples</b>	9-9
■ Example: Creating a Reconfiguration Plan	9-9
■ Example: Inserting Activations and Deactivations	9-10
■ Example: Placing the Ckt ID in the Database	9-10
■ Example: Removing an Item from Reconfiguration Plan	9-11
■ Example: Inserting Altrouting	9-12
■ Example: Generating a Report	9-12
<b>Modification Plan Examples</b>	9-13
■ Example: Checking the Plan	9-13
■ Example: Changing the Plan	9-13
■ Example: Rechecking the Plan	9-14
■ Example: Executing Reconfiguration Plans	9-15
■ Example: Idling Reconfiguration Plans	9-15
<b>Automatic Plans</b>	9-16
■ AUTOMATIC RECONFIGURATION PROVISIONING Form Field Descriptions	9-16 9-17
<b>Automatic Reconfiguration Plan Examples</b>	9-19
■ Example: Creating an Automatic Reconfiguration Plan	9-20
■ Example: Inserting Reconfiguration Plans and Alarm List Items	9-20

### Introduction

A reconfiguration plan specifies a sequence of circuit-provisioning **Actions** to be executed automatically when you execute the plan. The number of **Actions** you can enter is virtually unlimited. These **Actions** reconfigure the **Ckt Status** of circuits already in the database.

If a circuit is not in the database, you may still provision it from RECONFIGURATION PLAN PROVISIONING. On you typing in a circuit ID the I-2000 cannot identify, it displays a pop-up menu asking: NEW CIRCUIT! PROVISION NOW? If you answer YES, you are placed in the CIRCUIT PROVISIONING form.

While in CIRCUIT PROVISIONING, you may utilize all of its capabilities: CREATE as many circuits as you wish, BROWSE any circuits, and so on. When you are ready for an automatic return to RECONFIGURATION PLAN PROVISIONING, press **QUIT**.

A plan is defined in two steps:

- First you CREATE the plan, which opens a blank plan in the I-2000 database associated with the **Site Name** you specify in the creation screen.
- Then you INSERT the items, which are the allowed circuit-provisioning **Actions**, into the plan one by one.

Each is assigned a sequence number.

When you EXECUTE the plan, the I-2000 simply goes down the list executing the items. The completion results of each step are logged. If some time has elapsed since the plan was created, some circuits may no longer exist on the I-2000. In that case, the I-2000 does not try to execute the item.

Ordinarily the I-2000 waits three minutes for a reply from the DACS before reporting a `timeout error` message in the COMMAND RESPONSE box. For a circuit reconfiguration **Action**, the I-2000 waits a default time of 30 minutes. Since the RP is being executed in the background, the I-2000 does not report a timeout on the screen. Instead, it places the `timeout error` message in the database, to be retrieved with an RP report.

An automatic reconfiguration plan (ARP) is a plan of plans. Just as a single plan lists a sequence of circuit-provisioning **Actions** to be executed, the automatic plan lists a sequence of plans to be executed. An ARP is defined in the same way as an RP, and typically whatever applies to the items of the RP also applies to the items of the ARP.

An ARP can be set to execute when triggered by the receipt of a major or critical alarm from a specified NPC. Within each ARP is a list of RPs and also a list of NPCs whose alarms will be triggers for that ARP. The items of an ARP can, therefore, be one of two types: an RP to be executed or an NPC to be added to (or removed from) the list.

## Single Plans

---

### RECONFIGURATION PLAN PROVISIONING Form

---

To obtain the RECONFIGURATION PLAN PROVISIONING form, select RECONFIGURATION PLAN from the PROVISIONING menu. The RECONFIGURATION PLAN PROVISIONING form is displayed, as shown in Figure 9-1.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- RECONFIGURATION PLAN PROVISIONING -----
Site Name:DACS00                                RP Status:
RP Action:INSERT                                RP ID:
                                                Sequence:
Ckt ID:                                          Action:ALTRROUTE
  Class:                                         CP:00:
  Bandwidth:1                                   Bandwidth Type:A
  Status:
NORMAL      Hier  Ext          NPC ID          Ch
  FROM:
  TO:
ALTRROUTE
  FROM:
  TO:
Preempted                                     Status:      CP:
Ckt ID:
----- Enter the FROM Side NPC Number (Hierarchical format) -----
HELP  [ ]  [ ]  QUIT  [ ]  TOP MENU  PRINT  EXECUTE
    
```

**Figure 9-1. RECONFIGURATION PLAN (RP) PROVISIONING Form**

If the **RP Action** is not INSERT, REMOVE, or CHANGE, then only **Site Name**, **RP Status**, **RP Action**, and **RP ID** appear. The **ALTRROUTE** and **Preempted Ckt ID** fields appear only if the circuit **Action** is ALTRROUTE.

**Field Descriptions**

Field descriptions for the Reconfiguration Plan Provisioning form are described in Table 9-1.

**Table 9-1. RECONFIGURATION PLAN PROVISIONING Field Descriptions**

<p><b>Site Name</b></p>	<p>Mandatory. 1 through 24 characters from the set A-Z, a-z, 0-9, /, _, and -. All other characters are illegal. Blanks are not allowed within a name.</p> <p>Enter the name of the DACS on which this circuit action (<b>Action</b>) is to be executed.</p>
-------------------------	--

**Table 9-1. RECONFIGURATION PLAN PROVISIONING Field Descriptions (Contd)**

<b>RP Status</b>	<p>Inaccessible through form. Indicates whether the plan has been EXECUTED or is IDLE: either never executed or executed and subsequently made IDLE by an <b>RP Action</b> of IDLE.</p> <p>Note that reconfiguration plans are executed in the background. The status displayed on the screen is the status retrieved from the database. Therefore, if you execute the plan, the <b>RP Status</b> may still indicate IDLE.</p> <p>You can update the screen at any time by entering the <b>RP ID</b>. The I-2000 retrieves the current <b>RP Status</b>.</p>
<b>RP Action</b>	<p>Mandatory. Reconfiguration plan action.</p> <p><b>CREATE</b> Applies to plans only. Creates a reconfiguration plan, uniquely identified by an <b>RP ID</b>.</p> <p><b>DESTROY</b> Applies to plans only. Deletes the RP. Once the DESTROY form has been filled in and executed, the RP is no longer in the I-2000. If the RP is listed in an ARP, the DESTROY is rejected.</p> <p><b>BOOT</b> Applies to plans only. Locates all ACTIVE and ALTROUTED circuits in the I-2000 database, and places an item for each one of them in a special RP having the <b>RP ID</b> of BootDacs. Each item will bring about the same circuit status in the DACS as exists in the I-2000. BOOT then performs an EXECUTE on this plan in the Site-only mode, thereby booting the DACS database. If every item completes successfully, the DACS database will record the same in-service circuits as does the I-2000 database. Unlike other <b>RP Actions</b>, which log both successes and failures, BOOT only logs the failures.</p> <p><b>INSERT</b> Applies to items only. Inserts an item into the plan in the position indicated by the <b>Sequence</b>. If the position is already occupied, the I-2000 places your item in front of the existing entry and adjusts the rest of the sequence numbers. If you specify a sequence number that is higher than any existing entries, the I-2000 inserts the item at the end of the plan and assigns it the last number in the sequence.</p>

**Table 9-1. RECONFIGURATION PLAN PROVISIONING Field Descriptions (Contd)**

<p><b>RP Action (Continued)</b></p>	<p>If the <b>Ckt ID</b> indicates the circuit does not exist, a pop-up window appears, allowing you to enter <b>CIRCUIT PROVISIONING</b>. When you have provisioned the circuit, you are returned to this form.</p> <p>A circuit can only be inserted in a plan once. However, the same circuit can be used in different plans.</p> <p><b>REMOVE</b> Applies to items only. Removes an item from the plan. The I-2000 automatically renumbers all subsequent entries in that plan.</p> <p><b>CHANGE</b> Applies to items only. Changes the information in an item. An exception is the <b>Sequence</b>. It identifies the items in the plan and, therefore, cannot be changed directly.</p> <p>To change the position (<b>Sequence</b>) of an item in the plan, you must <b>REMOVE</b> the item and <b>INSERT</b> it where you want it to be.</p> <p><b>EXECUTE</b> Applies to plans only. Executes the plan specified by <b>RP ID</b>. Execution consists of first performing a <b>CHECK</b>, then executing the <b>Actions</b> of all items not internally marked null, in order of <b>Sequence</b>. Nullified items are logged anyway.</p> <p><b>EXECUTE</b> does not affect circuits already in the desired circuit status.</p> <p>Upon completion, <b>EXECUTE</b> reports the number of circuit provisioning actions that were attempted and the number that were successfully completed. You can inspect these results by running the reconfiguration plan results report.</p> <p>The results of only the most recent <b>CHECK</b>, <b>EXECUTE</b>, or <b>IDLE</b> are saved in the results log for an RP.</p> <p>If a circuit provisioning action was unsuccessful, you can modify the plan or correct the condition that prevented execution and then execute the plan an many times as it takes to bring about all the desired circuit statuses.</p>
-------------------------------------	---

Table 9-1. RECONFIGURATION PLAN PROVISIONING Field Descriptions (Contd)

RP Action (Continued)	IDLE	<p>Applies to plans only. Reverses the provisioning accomplished by a previous execution of the plan specified in <b>RP ID</b>; i.e., changes each circuit status back to what it is presumed to have been before. We presume you will be starting from <b>ACTIVE</b>, <b>DEACTIVATED</b>, or <b>PENDING</b>.</p> <p>Exception: a circuit that had been in the <b>PENDING</b> status before the plan was executed is placed into the <b>DEACTIVATED</b> status by <b>IDLE</b>.</p> <p><b>IDLE</b> undoes the provisioning in the reverse order of the plan, starting with the last item and finishing with the first, regardless of the order in which the circuits actually were provisioned. If <b>IDLE</b> discovers an action that cannot be reversed, because the circuit does not exist, it internally marks the <b>Status</b> null.</p>
	CHECK	<p>Applies to plans only. Checks the circuits in the plan specified by <b>RP ID</b> against the circuits in the current I-2000 database, to determine which circuits have been deleted from the database. If an item specifies a circuit that does not now exist, the item is internally marked null.</p> <p>When <b>CHECK</b> completes, it displays an I-2000 status message listing how many items can be successfully completed. To find out which items cannot complete and why, run the reconfiguration plan results report (see Chapter 14). Then correct the problems and perform <b>CHECK</b> again.</p> <p><b>EXECUTE</b>, <b>IDLE</b>, and <b>CHECK</b> keep a results log for each RP. The reconfiguration plan results report is taken from the log. One use of one of these commands overwrites the data in the log from the previous use.</p>
	CLEAN	<p>Applies to plans only. Looks for every circuit referenced in the plan. If it does not find the circuit in the appropriate I-2000 frame database, <b>CLEAN</b> removes its reference from the plan.</p>
	ABORT	<p>Applies to plans only. Aborts the plan currently running as a background process. Background plans are started by <b>BOOT</b>, <b>IDLE</b>, <b>EXECUTE</b>, or <b>CHECK</b>. Once an <b>ABORT</b> is entered, the I-2000 finishes the current circuit and stops. Circuits already reconfigured remain reconfigured.</p>

**Table 9-1. RECONFIGURATION PLAN PROVISIONING Field Descriptions (Contd)**

<b>RP ID</b>	Mandatory, up to 12 characters. Identifies the reconfiguration plan that is to be affected by the <b>RP Action</b> .
<b>Sequence</b>	Up to 5 characters. Mandatory for <b>RP Actions</b> of INSERT, REMOVE, CHANGE; not accessible in other cases. Specifies the sequence number identifying the item in the plan.
<b>Ckt ID</b>	For items only. 1 through 41 characters. Identifies the circuit to which the <b>Action</b> of this item pertains. The circuit must already be in the database, but it can have any status there.
<b>Action</b>	<p>For items only. Specifies the operation to be performed when the plan is executed. The possible <b>Actions</b> are:</p> <p><b>ACTIVATE</b>      Changes the <b>Status</b> of an already existing I-2000 circuit from PENDING or DEACTIVATED to ACTIVE, and cross-connects it in the DACS, making it a traffic-carrying circuit. The I-2000 validates all fields before activating a circuit. If the circuit <b>Status</b> is ACTIVE, ALTROUTED, or PRE-EMPTED, this RP ACTIVATE will fail.</p> <p><b>DEACTIVATE</b>    Changes the specified circuit in the I-2000 database to DEACTIVATED and disconnects it in the DACS.</p> <p><b>ALTROUTE</b>      Changes the specified circuit to ALTROUTED. Altrouting may involve the preemption of other circuits. The operator will be informed of each preemption and will be required to confirm before this item can be successfully placed in the plan. A circuit can be altrouted only once, and an ALTROUTED circuit cannot be preempted. ALTROUTE is the default <b>Action</b>. Between the time when the ALTROUTE item is entered and the time when the RP is executed, the EFTs to which the circuit is to be altrouted may have changed status. The user will be notified in the preemption confirmation pop-up inserts of their new status, and may then alter the ALTROUTE.</p>

**Table 9-1. RECONFIGURATION PLAN PROVISIONING Field Descriptions (Contd)**

<b>Class</b>	<p>A display-only field indicating the <b>Ckt Class</b> (see Chapter 6, "Circuit Provisioning") of the circuit identified by <b>Ckt ID</b>.</p> <p>FDX Full-duplex, a two-way, two-point circuit.  HDX Half-duplex, a one-way, two-point circuit.  BBL Backbone leg, a one-way, backbone leg broadcast circuit.  BRD Branch leg, a one-way, branch leg broadcast circuit.  DMB Digital multipoint bridge, a two-way, multipoint circuit leg.</p>
<b>CP</b>	A display-only field indicating the <b>CP</b> (circuit priority).
<b>Status</b>	<p>A display-only field indicating the current operating status of the circuit, as follows:</p> <p>NULL The <b>Ckt ID</b> does not identify a circuit currently in the I-2000 or DACS databases. The <b>RP Action</b> will not be accepted, and, therefore, the circuit cannot be used in the plan.</p> <p>PENDING The circuit is in the I-2000 database, but is not cross-connected in the DACS. It is ready to be made <b>ACTIVE</b> on user request. To cross-connect the circuit, use the <b>ACTIVATE Action</b>, in the plan.</p> <p>DEACTIVATED The circuit is in the I-2000 database but is not cross-connected in the DACS. It was <b>ACTIVE</b>, but was disconnected with a <b>DEACTIVATE Action</b>. To cross-connect the circuit, use the <b>ACTIVATE Action</b>.</p> <p>ALTROUTED The circuit is present in the DACS and I-2000 databases, is cross-connected in the DACS, and is carrying transmission. However, it was temporarily rerouted over an alternate path with an <b>ALTROUTE Action</b>. If any part of the alternate path was in use by another circuit, that circuit was placed in <b>PREEMPTED Ckt Status</b>. An <b>IDLE RP Action</b> is required to return the <b>ALTROUTED</b> circuit to its original path.</p>

**Table 9-1. RECONFIGURATION PLAN PROVISIONING Field Descriptions (Contd)**

<b>Status (Continued)</b>	PREEMPTED	The circuit was ACTIVE in the DACS, but has been temporarily disconnected for use by an ALTROUTED circuit. The circuit is in the I-2000 database only and is not carrying transmission. One or more of its channels are being used by one or more ALTROUTED circuits. The IDLE <b>RP Action</b> that returns the ALTROUTED circuits to normal also returns the PREEMPTED circuits to normal.
	ACTIVE	The circuit is present in the DACS and I-2000 databases, is cross-connected in the DACS, and is carrying transmission.
<b>Bandwidth</b>	A display-only field indicating the circuit bandwidth, as described in Chapter 6 "Circuit Provisioning."	
<b>Bandwidth Type</b>	A display-only field indicating how bandwidth is allocated in an NPC, as described in Chapter 6 "Circuit Provisioning."	
<b>NORMAL fields</b>	Display-only fields indicating the initial TO and FROM identifying information of the circuit: the NPC number in both hierarchical and extended format, the <b>NPC ID</b> , and channel number ( <b>Ch</b> ).	
<b>ALTROUTE fields</b>	User-accessible fields specifying the altrouting information, if the <b>Action</b> is ALTROUTE. Fill in the FROM and TO NPC and channel identifiers for this ALTROUTE destination, just as you would on the ALTROUTE screen. Refer to Chapter 8 "Alternate Routing."	
<b>Preempted fields</b>	The circuit identifiers for circuits that are preempted by this ALTROUTE, as they would appear on the ALTROUTE screen. Refer to Chapter 8 "Alternate Routing."	

## Reconfiguration Plan Examples

The examples below describe how to create reconfiguration plans.

### Example: Creating a Reconfiguration Plan

To create a Reconfiguration Plan, follow these steps:

1. Select RECONFIGURATION PLAN from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS00
  - **RP Action:** CREATE
  - **RP ID:** testplan

3. Press **EXECUTE** and confirm. The **RP Status** says `IDLE`. In addition, a completion message from the I-2000 is displayed.
4. If the plan already exists, you are notified:  
The RP ID is already in use

### Example: Inserting Activations and Deactivations

In this example, `Ckt01` is in the I-2000 database with a **Ckt Status** of `PENDING`.

To insert activations and deactivations, follow these steps:

1. Enter the following data:
  - **Site Name:** `DACS01`
  - **RP Action:** `INSERT`The appropriate fields appear on the form.
  - **RP ID:** `testplan`The **RP Status** is filled in.
  - **Sequence:** `1`
  - **Ckt ID:** `Ckt01`The circuit information is filled in.
  - **Action:** `ACTIVATE`The appropriate fields appear on the form.
2. Press **EXECUTE** and confirm. All but the default information disappears.  
The **Sequence** increases by one. In addition, a completion message from the I-2000 is displayed.
3. Insert as many more **Ckt IDs** as needed.

### Example: Placing the Ckt ID in the Database

If `ckt01` was not in the database, You can place it there and return automatically to the reconfiguration plan as follows:

1. Enter the following data:
  - **Site Name:** `DACS01`
  - **RP Action:** `INSERT`The appropriate fields appear on the form.
  - **RP ID:** `testplan`The **RP Status** is filled in.

— **Sequence:** 1

— **Ckt ID:** Ckt01

A pop-up menu is displayed:

NEW CKT! PROVISION NOW?

2. Select YES.

The CIRCUIT PROVISIONING form is displayed.

3. Enter the following data:

— **Site Name:** DACS01

— **Action:** PEND

— **Ckt ID:** ckt01

4. Press **EXECUTE** and select IMMEDIATE. The **Ckt Status** field changes from NULL to PENDING. In addition, the command completed successfully message is displayed.

5. Press **QUIT**.

You are returned to the RECONFIGURATION PLAN PROVISIONING form.

6. Enter these data: **Action:** ACTIVATE

The appropriate fields appear on the form.

7. Press **EXECUTE** and confirm. All but the default information disappears and the **Sequence** increases by one.

In addition, a completion message from the I-2000 is displayed.

### **Example: Removing an Item from Reconfiguration Plan**

---

To remove an item from the reconfiguration plan, follow these steps:

1. Enter the following data:

— **Site name:** DACS01

— **RP Action:** REMOVE

— **RP ID:** testplan

— **Sequence:** 1

The information for that item is displayed on the form.

2. Press **EXECUTE** and confirm. The information on the form reverts to the previous item, if any. In addition, a completion message from the I-2000 is displayed.

### **Example: Inserting Altrouting**

---

To insert altrouting, follow these steps:

1. Enter the following data:
  - **Site name:** DACS01
  - **RP Action:** INSERT
  - **RP ID:** testplan
  - **Sequence:** 1
  - **Ckt ID:** Ckt01
  - **Action:** ALTROUTE
  - **ALTRROUTE, FROM, NPC ID:** msc217
  - **ALTRROUTE, FROM, Ch:** 010
  - **ALTRROUTE, TO, NPC ID:** msc212
  - **ALTRROUTE, TO, Ch:** 011
2. Press **EXECUTE** and confirm.
3. If any circuits will be preempted, their data appears in the **Preempted** fields successively. The I-2000 prompts you to approve each one as follows:

OK TO PREEMPT CIRCUIT?
4. Answer **YES** in each case, if you want to preempt a circuit. All but the default information disappears and the **Sequence** increases by one.

In addition, a completion message is displayed.

### **Example: Generating a Report**

---

This example displays a listing of an existing reconfiguration plan (`testplan`) for the DACS at **Site Name** `DACS00`.

To generate a report, follow these steps:

1. Select REPORT OPERATIONS from the MAIN MENU.
2. Select RECONFIGURATION PLAN RESULTS.
3. Select SEQUENCE SORTED to sort the items by **Sequence** for the report only, or select CP SORTED to sort the items by circuit priority for the report only.
4. On the RECONFIGURATION PLAN RESULTS SEARCH CRITERIA form.
5. Enter the following data:
  - **Site Name:** DACS00
  - **Reconfiguration ID:** testplan

6. Press **EXECUTE** and confirm.

The following message to is displayed on the I-2000 Status line. In addition, the REPORT OPERATIONS menu to is displayed.

```
report generation is completed
```

7. Select DISPLAY LAST GENERATED REPORT, and choose SCREEN from the ALLOWED CHOICES.

Wait for the report to appear on the screen and confirm the correctness of the plan's content.

## **Modification Plan Examples**

---

The examples below describe how to check and change a plan.

### **Example: Checking the Plan**

---

To check the reconfiguration plan, follow these steps:

1. Select RECONFIGURATION PLAN from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS01
  - **RP Action:** CHECK
  - **RP ID:** testplan
3. Press **EXECUTE** and confirm. You are notified that the plan will be executed in the background, and are required to confirm.

A message is displayed in the I-2000 status line, stating the number of items attempted and the number successful.

4. Display RECONFIGURATION PLAN RESULTS report, following the steps given under "Example: Generating a Report". The report should list all conflicts.
5. Some examples of conflicts are as follows:

```
Seq. no. 1: Circuit MM07 is already ACTIVE  
Seq. no. 2: Circuit MM03 is already ACTIVE  
Seq. no. 3: Circuit MM06 is already DEACTIVATED
```

### **Example: Changing the Plan**

---

Change the existing reconfiguration plan by inserting, removing, and changing operations. First an existing circuit is made DEACTIVATED to remove one of the conflicts found in checking the plan, then other conflicts are removed by changing the plan.

To change the reconfiguration plan, follow these steps:

1. In the CIRCUIT PROVISIONING form.
2. Enter the following data:
  - **Site Name:** DACS01
  - **Action:** DEACTIVATE
  - **Ckt ID:** MM07
3. Press **EXECUTE** and confirm.
4. Press **QUIT**. Return to the PROVISIONING menu.
5. Select RECONFIGURATION PLAN.
6. Enter the following data:
  - **Site Name:** DACS01
  - **RP Action:** CHANGE
  - **RP ID:** testplan
  - **Sequence:** 3
  - **Ckt ID:** MM06
  - **Action:** ACTIVATE.
7. Press **EXECUTE** and confirm.
8. Enter the following data:
  - **RP Action:** INSERT
  - **Ckt ID:** MM05
  - **Action:** DEACTIVATE
  - **Sequence:** 5
9. Press **EXECUTE** and confirm.

### **Example: Rechecking the Plan**

---

Repeat the steps under "Example: Generating a Report", and confirm that the report displays the changed plan data. Also repeat the steps under "Example: Checking the Plan", to do a check of the revised plan and display the results. See that there are now no execution conflicts.

### **Example: Executing Reconfiguration Plans**

---

To execute a reconfiguration plan, follow these steps:

1. Select RECONFIGURATION PLAN from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS01
  - **RP Action:** EXECUTE
  - **RP ID:** testplan
3. Press **EXECUTE** and confirm. The entire plan is now executed and the I-2000 sends the appropriate commands to the specified DACS.  
In addition, a completion message appears.
4. Display a RECONFIGURATION PLAN RESULTS report to determine if there were any execution conflicts.

### **Example: Idling Reconfiguration Plans**

---

To idle a reconfiguration plan, follow these steps:

1. Select RECONFIGURATION PLAN from the PROVISIONING menu.
2. Enter the following data:
  - **Site Name:** DACS01
  - **RP Action:** IDLE
  - **RP ID:** testplan
3. Press **EXECUTE** and confirm.
  - The entire plan is now idled. The appropriate commands are sent to the specified DACS
  - A completion message appears.
4. Display a RECONFIGURATION PLAN RESULTS report to determine if there were any execution conflicts.

## Automatic Plans

---

### AUTOMATIC RECONFIGURATION PROVISIONING Form

---

To obtain the AUTOMATIC RECONFIGURATION PLAN form, select AUTOMATIC RECONFIGURATIN PROVISIONING from the PROVISIONING menu.

The AUTOMATIC RECONFIGURATION PROVISIONING PLAN is displayed, as shown in Figure 9-2.

```
06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- AUTOMATIC RECONFIGURATION PLAN PROVISIONING -----
Action:                ARP ID:                ARP Status:
List Type:              Sequence:
Site Name:              RP ID:
Number (Hier):          (Ext):
NPC ID:
Enter the desired action:
HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE
```

**Figure 9-2. AUTOMATIC RECONFIGURATION PLAN PROVISIONING Form**

Initially only the first line appears. The fields that appear subsequently depend on the **Action** and **List Type**.

**Field Descriptions**

Field descriptions for the AUTOMATIC RECONFIGURATION PLAN are described in Table 9-2.

**Table 9-2. AUTOMATIC RECONFIGURATIN PLAN Field Descriptions**

<b>Action</b>	Mandatory. Valid actions are:
CREATE	Applies to ARPs only. Creates an automatic reconfiguration plan (ARP), uniquely identified by an <b>ARP ID</b> .
DESTROY	Applies to ARPs only. Deletes the ARP. Once the DESTROY form has been filled in and executed, the ARP is no longer in the I-2000.
INSERT	Applies to ARP items only. Inserts an item into the ARP in the position indicated by the <b>Sequence</b> . If the position is already occupied, the I-2000 places your item in front of the existing entry and adjusts the rest of the sequence numbers. If you specify a sequence number that is higher than any existing entries, the I-2000 inserts the item at the end of the plan and assigns it the last number in the sequence.
REMOVE	Applies to items only. Removes an item from the ARP. The I-2000 automatically renumbers all subsequent entries in the ARP.
CHANGE	Applies to items only. Changes the information in an item. An exception is the <b>Sequence</b> . It identifies the items in the ARP, and, therefore, cannot be changed directly. To change the position ( <b>Sequence</b> ) of an item in the plan, you must REMOVE the item and INSERT it where you want it to be.
EXECUTE	Applies to ARPs only. Sequentially executes the RPs in the plan specified by <b>ARP ID</b> . Once a provisioning command has been sent to the DACS specified by the RP's <b>Site Name</b> , the I-2000 does not wait for a reply, but goes on to the next item. The replies, when they arrive, are logged. Upon completion, EXECUTE reports the number of items for which it sent commands, and the number that succeeded. The results of the most recent CHECK, EXECUTE, or IDLE overwrite the previous results in the results log for an ARP.

Table 9-2. AUTOMATIC RECONFIGURATION PLAN Field Descriptions (Contd)

<b>Action (Continued)</b>	<p><b>IDLE</b> Applies to ARPs only. Idles the plan specified by <b>ARP ID</b>. Idling consists of parsing each RP in the plan sequentially from last to first, and from last item to first item within a plan, and taking immediate action on each item as it is encountered. Upon completion, <b>IDLE</b> reports the number of items for which it sent commands and the number that succeeded.</p> <p>The results of the most recent <b>CHECK</b>, <b>EXECUTE</b>, or <b>IDLE</b> overwrite the previous results in the results log for an ARP.</p>
	<p><b>CHECK</b> Applies to ARPs only. Checks the contents of each RP in the plan specified by <b>ARP ID</b> against the NPCs in the current I-2000 database to determine which NPCs have been deleted from the database. If an item specifies a NPC that does not now exist, the item is internally marked null.</p> <p>When <b>CHECK</b> completes, it displays an I-2000 status message listing how many items can be successfully completed. To find out which items cannot complete and why, run the reconfiguration plan results report (see Chapter 14). Then correct the problems and perform <b>CHECK</b> again.</p> <p><b>EXECUTE</b>, <b>IDLE</b> and <b>CHECK</b> keep a results log for each RP. The reconfiguration plan results report is taken from the log. One use of one of these <b>Actions</b> overwrites the data in the log from the previous use.</p>
	<p><b>CLEAN</b> Applies to items only. Looks for every RP referenced in the ARP. If it does not find the RP in the appropriate I-2000 frame database, <b>CLEAN</b> removes its reference from the ARP.</p> <p>If the ARP item is an <b>ALARM</b>, <b>CLEAN</b> determines whether the NPC is still provisioned. If it is not, <b>CLEAN</b> removes the <b>ALARM</b> from the list.</p>
	<p><b>ABORT</b> Applies to ARPs only. Aborts all the RPs that were started by this ARP. Background RPs are started by <b>BOOT</b>, <b>IDLE</b>, <b>EXECUTE</b>, or <b>CHECK</b>. Once an <b>ABORT</b> is entered, the I-2000 allows the current item to finish and stops.</p>
<b>ARP ID</b>	Mandatory. Up to 12 characters. Identifies the automatic reconfiguration plan that is to be affected by the <b>Action</b> .

**Table 9-2. AUTOMATIC RECONFIGURATIN PLAN Field Descriptions (Contd)**

<b>ARP Status</b>	Inaccessible through this form. Indicates whether the specified item has been EXECUTED or is IDLE. IDLE means either never been executed or executed and subsequently made IDLE. This field appears only if <b>List Type</b> is RP.
<b>List Type</b>	Specifies the type of item to which this <b>Action</b> applies: RP The item is an RP.  ALARM The item is an NPC to be placed on or removed from the alarm list. If an NPC is on the list, a critical or major alarm from it will trigger the ARP.
<b>Sequence</b>	Up to five characters. Specifies the sequence number identifying the entry, in the plan, that is to be affected by the <b>Action</b> .
<b>Site Name</b>	Mandatory. 1-24 alphanumeric characters. Identifies the site to which the items of the RP specified in <b>RP ID</b> are to apply, provided the <b>List Type</b> is RP. If the <b>List Type</b> is ALARM, <b>Site Name</b> identifies the site where the NPC to be placed on the alarm list is located.
<b>RP ID</b>	Up to 12 characters. Identifies the RP that is to execute.
<b>Number (Hier)</b>	Appears only for a <b>List Type</b> of ALARM. The NPC number in hierarchical format of the NPC whose alarm will trigger the ARP.
<b>(Ext)</b>	Appears only for a <b>List Type</b> of ALARM. The previous NPC number, but in extended format.
<b>NPC ID</b>	Appears only for a <b>List Type</b> of ALARM. 1-41 characters. The NPC ID of the NPC whose alarm will trigger the ARP. The NPC must be in the database; for example, must have been created under NPC PROVISIONING.

## **Automatic Reconfiguration Plan Examples**

---

The examples below describe how to create an Automatic Reconfiguration Plan, and how to insert Reconfiguration Plans and Alarm List items.

### **Example: Creating an Automatic Reconfiguration Plan**

---

To create an Automatic Reconfiguration Plan, follow these steps:

1. Select AUTOMATIC RECONFIGURATION PLAN from the PROVISIONING menu.
2. Enter the following data:
  - **Action:** CREATE
  - **ARP ID:** newplanThe I-2000 searches the database for a plan of that ID.
3. Press **EXECUTE** and select IMMEDIATE or YES. The **ARP Status** changes to IDLE. In addition, a completion message for the I-2000 is displayed.
4. If the plan already exists, you are notified:

New Automatic Reconfiguration Plan must have unique ID
5. You are required to acknowledge.

### **Example: Inserting Reconfiguration Plans and Alarm List Items**

---

To insert a Reconfiguration Plan and Alarm List Items, follow these steps:

1. Select AUTOMATIC RECONFIGURATION PLAN from the PROVISIONING menu.
2. Enter the following data:
  - **Action:** INSERTAdditional fields are displayed on the screen.
3. Enter the following data:
  - **ARP ID:** newplan
  - **List Type:** RP
4. The next sequence number is automatically displayed.
5. Enter the following data:
  - **Site Name:** DACS02
  - **RP ID:** testplan
6. Press **EXECUTE** and select IMMEDIATE or YES.

A completion message is displayed.

7. To add an NPC to the alarm list, navigate to **List Type** and enter:

- **List Type:** ALARM
- **Sequence:** automatically supplied.
- **Site Name:** DACS02
- **NPC ID:** dgrp01

8. Press **EXECUTE** and select IMMEDIATE or YES.

A completion message is displayed.

Reports are available for each ARP. The Reports list the RPs and NPCs whose alarms will trigger the ARP. Refer to Chapter 14 "Report Operations."

---

**Contents**

<b>Introduction</b>	10-1
<b>Database Administration Menu</b>	10-1
■ DATABASE AUDIT/SYNCHRONIZATION	10-2
Introduction to Database Audit	10-3
Introduction to Database Synchronization	10-6
Other Features and Constraints	10-12
■ DATABASE AUDIT/SYNCHRONIZATION Form	10-13
Field Descriptions	10-14
Bottom Screen Field Descriptions	10-18
■ Procedure: Scheduling an NPC Audit	10-19
■ Procedure: Printing an NPC Audit	10-20
■ Procedure: Performing a Channel Audit	10-21
■ Procedure: Performing a Synchronization	10-23
■ Procedure: Performing a Subrate Audit	10-23
■ Procedure: Performing a Subrate Sync	10-24
■ Procedure: Uploading the I-2000 Database	10-25
■ Procedure: Initiating an ABORT Action	10-25
<b>Backing Up and Restoring I-2000 Databases</b>	10-26
■ BACKUP/RESTORE Menu	10-26
■ Procedure: Backing Up Database to Tape	10-27
■ Procedure: Restoring a Database From Tape	10-29
■ Procedure: Backing Up The Alarm Log to Tape	10-31
■ Procedure: Restoring Alarm Log From Tape	10-32
■ Procedure: Backing Up An Alarm Log to Diskette	10-32
■ Procedure: Restoring An Alarm Log from Diskette	10-34
■ Procedure: Backing Up or Restoring Report Formats	10-35

---

## Contents

■ Procedure: Formatting a Diskette	10-35
<b>Entering and Retrieving Outage Data</b>	10-35
■ Procedure: Entering Outage Log Data	10-36
Field Descriptions	10-36
■ Procedure: Inserting a Record in the NPC Outage Log	10-38
■ Procedure: Retrieving Outage Data	10-38
Field Descriptions	10-39
<b>Moving a Database from One I-2000 to Another</b>	10-39

## Introduction

---



**NOTE:**

Database Administration is available *only* to the system administrator.


As a system administrator, you can perform the following database administration functions:

- Database Audit/Synchronization
- Backup/Restore
- Enter Outage Data

## Database Administration Menu

---

Select DATABASE ADMINISTRATION from the MAIN MENU. The DATABASE ADMINISTRATION menu is displayed, as shown in Figure 10-1.



**Figure 10-1. DATABASE ADMINISTRATION Menu**

## **DATABASE AUDIT/SYNCHRONIZATION**

DATABASE AUDIT/SYNCHRONIZATION consists of two capabilities: database audit and scheduled database synchronization. Ordinarily you schedule periodic audits for inspection purposes and do scheduled synchronization whenever the audits indicate that it is necessary.

The echoed response processing capabilities, which are described in Chapter 4 "NPC Provisioning" and Chapter 6 "Circuit Provisioning," also perform synchronization. That synchronization is automatic and is performed in the background on a continual basis if echoed response processing is enabled. Automatic synchronization insures that the data in the I-2000 and DACS databases are kept approximately the same.

The DATABASE AUDIT/SYNCHRONIZATION capabilities allow you to compare databases without synchronizing, to synchronize if a special need arises, and to upload frame provisioning data into the I-2000 databases all at once. Some examples of a special need are as follows. The link to the DACS can be down for a time, allowing a gap between the I-2000 and DACS databases to develop. Also, a SNIDER link can be choked by a long transmission when the I-2000 is very busy, so that the I-2000 loses characters, rendering one or more messages incomprehensible. Once again, a gap between databases is opened.

Only one DATABASE AUDIT/SYNCHRONIZATION action per DACS can be run at one time. In addition, an ALARM QUERY cannot be executed while a DATABASE AUDIT/SYNCHRONIZATION is running.

### **Introduction to Database Audit**

The local database is defined as the I-2000 database for a specified DACS. The facility or remote database is defined as the corresponding DACS database. A database audit compares the NPC or channel information in a facility database with the same information in its corresponding local database and records certain discrepancies between the two in the audit/synchronization log, which can be accessed through a report.

You can specify the range of NPCs or channels to be checked. A range of all facility NPCs causes every NPC to be checked. A range of all local NPCs causes only NPCs equipped in the I-2000 to be checked. In either case, it is possible to select one NPC or a range between and including specified NPCs. All channels can be selected for one NPC, or only one channel.

You can specify an NPC audit or a channel audit. In general, the former compares NPC provisioning in the two databases, while the latter compares circuit provisioning. More specifically, the audit of NPCs compares the values of the following fields in the local database with the same fields in the remote database for every NPC of the range. The comparison proceeds in the order in which the fields are listed. These fields appear on the I-2000 NPC provisioning form. An "X" means, "comparison supported."

Table 10-1 lists the NPC database parameters audited.

**Table 10-1. NPC Parameters Audited**

Type of NPC	DE/TE	PB/PC	DA/TA	PA	DC	Clear DE/TE	Clear DA/TA	Clear PA	SD
<b>Service State</b>	X	X	X	X	X	X	X	X	X
<b>Type</b>	X	X	X	X	X	X	X	X	X
<b>NPC number</b>	X	X	X	X	X	X	X	X	X
<b>Alarm State*</b>	X	X	X	X	X	X	X	X	X
<b>IW</b>	X	X	X	X	X				
<b>TS0</b>		X**		X					
<b>TS0M</b>		X**		X					
<b>AIS Alarm Level</b>	X	X	X	X		X	X	X	
<b>NFS†</b>				X					
<b>Performance thresholds</b>	X**	X**		X		X		X	

\* Only synchronized when the DACS is the master.

\*\*Applies only to DACS II.

† NFS (non-framing setting) is the NFW value of Framing on CIRCUIT PROVISIONING.

The allowed values of each field can be found under Chapter 4, "NPC Provisioning." If no difference in value between the same field in the same NPC record of each database is found, then no further action is taken.

If a difference is found, it is recorded in one of six possible records in the audit/synchronization log. One record notes discrepancies in the **Service State**, **Type**, or **IW** fields; another in the **TS0** or **TS0M** fields; another in the **performance threshold fields**; and still a fourth in the **Alarm State** field. A fifth records **NFS discrepancies**, and a sixth, **AIS Alarm Level**. Six discrepancy records per NPC are thus possible.

Each of the above fields of every NPC record of the range is checked and all discrepancies are logged.

If there is a Performance Thresholds discrepancy, the DACS value "10" will be represented by a "G" in the log.

An audit of channels cross-compares the values of the following fields for each circuit in which the channels are cross-connected, in the order listed.

Table 10-2 lists the circuit parameters audited.



**NOTE:**  
DCC, INCL, and OOS are not audited.

**Table 10-2. Circuit Parameters Audited**

Type of circuit	CEPT nxDS0	NAS nxDS0	Gateway nxDS0	DMB*	Clear DS1*	Clear E1*	Virtual multipoint*	Subrate	Estab. DS0
<b>Ckt Status</b>	X	X	X	X	X	X	X	X	X
<b>Ckt Class</b>	X	X	X	X	X	X	X	X	X
FROM NPC	X	X	X	X	X	X	X	X	X
FROM Ch	X	X	X	X			X	X	X
FROM CUST								X	
TO NPC	X	X	X	X	X	X	X	X	X
TO Ch	X	X	X	X			X	X	
TO CUST								X	
<b>DMB Mode</b>				X					
<b>NTR</b>				X					
<b>Bandwidth</b>	X	X	X	X			X		
<b>Bandwidth Type</b>	X	X	X	X			X		
<b>IW</b>	X	X	X	X			X		
TLA**	X	X	X	X	X	X	X		
NAM	X	X	X	X			X		
AIS	X	X	X	X					
RDL D	X	X	X	X	X	X	X		
<b>TC</b>	X	X	X	X			X		
<b>SC</b>			X						
<b>Framing</b>	X		X						
Transmission Rate								X	X†

Table 10-2. Circuit Parameters Audited (Contd)

Type of circuit	CEPT nxDS0	NAS nxDS0	Gateway nxDS0	DMB*	Clear DS1*	Clear E1*	Virtual multipoint*	Subrate	Estab. DS0
UMC, MUX, SIG, Framing								X	
Transmission Standard									X

\* DACS II ISX Release 1.0 does not support these circuit types.

\*\* Only synchronized when the DACS is the master and one end for one-way or two ends for two-way are terminated or unterminated.

† For Transmission Standard X.50 only.

The allowed values for each field can be found in Chapter 6, "Circuit Provisioning." If no difference in the value of a field between databases is found, no further action is taken. If a difference is found in one field, it is recorded in the audit/synchronization log. The remaining fields of the record are checked and remaining discrepancies are noted internally, but are not logged.

To display all differences, utilize the CHANNEL AUDIT **Action** in SINGLE CHAN **Mode**. All the differences are shown on the CIRCUIT PROVISIONING form(s), except for **Mode**, **NTR** and **Framing**.

### Introduction to Database Synchronization

Synchronization makes the data that is checked in an audit the same in both the local and facility databases, subject to certain constraints, which are detailed in this section. You select one database as the master. The other database is forced to conform to it.

An NPC synchronization first performs an NPC audit. Then it attempts to insure that the discrepancies noted in the audit/synchronization log as a result of that audit are removed:

- If the I-2000 is the master, then the NPC SYNC sends commands to the DACS to provision it in such a way as to change the values of the fields noted as inconsistent. The results of each command are then noted in additional records in the audit/synchronization log as success or failure, with the reason for the failure.
- If the DACS is the master, the NPC SYNC changes the existing field in the I-2000 database. If no corresponding NPC provisioning record exists, one is created.
  - New NPC IDs created by NPC synchronization are in the format: **NPCxxxxx**.
  - Frames provisioned with link hierarchical numbering are in the format: **NPCyyyy**.

For frames provisioned with link extended numbering,  
where:

`xxxxxx` is the hierarchical number for the NPC.

`yyyyy` is the extended number for the NPC.

If the identifier is already in use, a `.z` is suffixed to create a unique identifier, where `z` is an integer from 0 to 9.

A channel synchronization insures that the end-points and circuit characteristics noted as different in a channel audit are reconciled, subject to limitations.

- If the DACS is chosen as the master, then the circuit provisioning records of the local database are either updated, or are deleted and new records are created.
- If the I-2000 is the master, then circuit provisioning commands are sent to the DACS.

New circuit IDs have the following format:

- For circuit classes `FDX`, `HDX`, `BBL`, `BRD`, and `DMB`:  
**SYN** fromnpc-fromchan tonpc-tochan **BW/bw** class
- For subrate circuits:  
**SYN** fromnpc-fromchan-fromcust tonpc-tochan-tocust rate **SUB**  
**BW/bw** class
- For established DS0 circuits:  
**SYN** fromnpc-fromchan tonpc sectype **EST**
- For new BCON BKB circuits:  
**BYN** fromnpc-fromchan tonpc-tochan **BW/bw** class

where:

`fromnpc` is the FROM NPC number in hierarchical or extended format, depending on how the DACS was provisioned.

`fromchan` is the FROM channel number, or `DS1` or `E1`.

`from-cust` is the FROM customer number.

`tonpc` is the TO NPC number in hierarchical or extended format.

`tochan` is the TO channel number, or `DS1` or `E1`.

`tocust` is the To customer number.

bw	is the bandwidth, which is either 1 or the number of contiguous channels of a high-rate circuit.
rate	is the subrate transmission rate.
class	is the <b>Ckt Class</b> : FDX, HDX, BBL, BRD or DMB.
sech-type	is the type of SRM NPC.

If the identifier is already in use, a .z is suffixed to create a unique identifier, where z is an integer from 0 to 9.

**The limitations on the use of NPC synchronization are as follows:**


- When the I-2000 is the master:
  - If there are discrepancies of NPC **TYPE** that would require unequipping the NPC at the DACS, and there are circuits on these NPCs, the NPC sync will fail.
  - When auditing for a range of NPCs (ALL LOCAL NPCS or RANGE OF LOCAL NPCS), unequipped NPCs at the I-2000 are not processed. If the NPC is equipped at the DACS, the NPC will not be degrown (unequipped) at the DACS.
- When the DACS is the master:
  - If there are discrepancies of equipment state that would require unequipping the NPCs at the I-2000, and there are circuits on these NPCs at the I-2000, then the NPC sync will fail. If the NPC is deleted on the I-2000, the action will be logged.

**The limitations on the use of channel synchronization are as follows:**

- Channel synchronization does not automatically equip NPCs. If an NPC is missing from one database, the synchronization of channels within it is not performed. It is suggested, therefore, that you precede a channel synchronization with an NPC synchronization.
- Channels that are connected to a test port in either the I-2000 or the DACS are not audited or synchronized.
- DMB cascades are not audited or synchronized.
- Channels that are established for subrate cross-connection are not audited or synchronized. Their existence is logged.
- The BKB of a BCON circuit must be in the range of the NPC synchronization request for that BKB to be synchronized. This means that if a leg is encountered in the range of the request, and the BKB is not in the range of the request, the LEG will not be individually synchronized. The report for the audit/synchronization results will, however, identify this and will identify the BKB. Note, however, that if the BKB is in the range of the sync request then ALL LEGS associated with the BKB will be synchronized.

**In addition, when the I-2000 is the master:**

- There is no command to modify provisioning in the DACS. The I-2000 always disconnects and connects when it changes frame provisioning.
- If NPCs are equipped in the I-2000, but their channels are not cross-connected, the channel synchronization disconnects all circuits in the same NPCs of the DACS.
- Discrepancies of **Class**, **Status**, end points, **TC**, **SC**, **IW**, and **Options** result in disconnection in the DACS and connection of new circuits with the matching attributes.
- The Termination State (TLA or TLR, **Option G**) of a circuit is not changed in the DACS during synchronization, unless the circuit is being disconnected and reconnected because of another discrepancy.
- A number of limitations apply to virtual conference circuits when the I-2000 is the master, as shown in Figure 10-2.
  - If a BBL required by the synchronization of the circuit is already in use in the DACS, the synchronization does not change it in any way.
  - If the BBL is already in use in the DACS, the synchronization does not connect its BRDs unless the facility BBL is the same as the local BBL in every field of interest.
  - The synchronization does not connect a BRD unless its bandwidth is the same as that of the BBL.
  - The synchronization does not disconnect a virtual conference type if the bandwidth does not match.



---


**Figure 10-2. Virtual Multipoint Circuit****NOTE:**

The limitations on virtuals are designed to protect the DACS user who is not utilizing the I-2000. The I-2000 is not allowed to automatically interfere in existing DACS circuits by preempting control of a virtual node or of virtual conference circuits already in use by others.

**When the DACS is the master:**


- Channel synchronization and circuit echoed response processing delete records that cannot be corrected.
- Differences of end points, **Ckt Class**, **Ckt Status**, **DMB Mode**, or **Bandwidth** result in deletion of the circuit record containing them and activation of a new circuit record with matching attributes.
- Differences of **TC**, **IW**, **SC**, **NTR** (DMB), Termination State, or **Options** result in modification of the existing circuit record.
- The termination state can only be fully synchronized if both ends of the connection in the DACS are the same, either TLA or TLR. If they are not the same you can use the **TERMINATE Action** with the **Direction** field in **TEST ACCESS** to reset the termination state of one side.
- Circuits that use the end points but that do not match are deleted.
- If the bandwidths do not match in corresponding virtual conference circuits, the entire circuit in the I-2000 is deleted.
- The DACS provisions I-2000 high-rate circuits as individual channels. As a result:
  - If the I-2000 record no longer exists, a separate I-2000 record is created for each channel of a circuit that was originally high-rate in the I-2000.
  - If the I-2000 record is still present and the circuit corresponds in every way to the DACS circuit, no changes are made.
  - If the I-2000 record is still present, but some of the circuit characteristics have changed, they can be made to correspond to the DACS.
  - If there is a discrepancy that cannot be corrected globally, over the entire circuit; for example, the **TC** in the DACS is not the same as for all the I-2000 circuit's channels, then the I-2000 record is deleted and new records are written.
- If a channel was originally in the high-rate circuit but for some reason is not now the same as in the DACS, synchronization will delete the I-2000 high-rate record and will create individual records of single-channel BW for all remaining connections in the high-rate that still match.

NPC, channel, and subrate synchronizations are combined in the **UPLOAD Action**. An **UPLOAD** loads the NPC, channel, and C-Bit cross-connection information located in the remote DACS database into the local, or I-2000, database for the DACS. It does so in two stages, as shown in Figure 10-3 and 10-4.



**Figure 10-3. Stage 1 of the UPLOAD Action: NPC SYNC**

The result of the first stage, shown in Figure 10-4, is that the NPC provisioning in the local database conforms to the NPC provisioning in the remote database, subject to the limitations of an NPC SYNC .



**Figure 10-4. Stage 2 & 3 of the UPLOAD Action: CHANNEL SYNC/ SUBRATE SYNC**

An important point to remember is that **UPLOAD** does not first delete the existing information in the local database. The information is checked as in an audit. If matches are found in the values of the fields of interest, no action is taken, and the information remains. Otherwise, records are deleted, revised or created according to the rules for **NPC SYNC** , and or **CHANNEL SYNC** , and **SUBRATE SYNC** . You can execute an **UPLOAD** repeatedly to bring about a successively closer correspondence of the databases, without loss of data you may want to keep, such as the previous circuit attributes.

There may be some exceptions in the second stage according to the limitations on the use of **NPC SYNC** , **CHANNEL SYNC** , and **UPLOAD** (below).

For example, circuits for remote channels under test or used as test ports, or circuits that are not supported by the I-2000, are not recorded in the local database. Instead, an exception report is placed in the log.

Discrepancies in NPC, subrate, and channel data are tracked internally. Only failed synchronization attempts are logged, keeping the log size small and using less disk space.

**Other Features and Constraints**

Database audit/synchronization may take a long time—longer than four hours for a 320-NPC DACS with all channels connected in one-way circuits. Therefore, scheduling these activities for off-peak times is suggested. However, there are some constraints. A channel audit for a single channel runs in the foreground. Everything else, whether scheduled or not, runs in the background.

Some additional features of audit/synchronization are:

- Certain **Actions** are denied when others are in progress; such as, `ALARM QUERY (REPORT OPERATIONS)` is not allowed during an audit/synchronization.
- Audit synchronization applies to these DACS types only: DACS II Releases 4 and higher; and DACS II ISX Releases 1.0 and higher. A table of NPC types supported for each frame is shown in Table 10-3. In addition, Table 10-3 lists DSPP types supported for the X.50 and X.57 subrate provisioning.

**Table 10-3. DSPP Types supported for Subrate Provisioning**

	P B	P C	P A	D C	D E	T E	D A	T A	M B	S R	M J	Virtual	SD
<b>DACS II before Release 6.0</b>	X	X			X	X							
<b>DACS II Release 6.0 and after</b>	X	X	X		X	X	X	X					
<b>DACS II ISX Releases 1.0 and higher</b>			X*				X						X**

\* DACS II ISX Releases 1, 1.1 do not support the clear DS1/E1 versions of Types PA and DA

\*\* DACS II ISX Release 2.0 and higher

- Audit/synchronization cannot be performed when any user is in SNIDER passthrough mode, or doing a database restoral.
- Any user with the ADMIN user class can terminate an audit/synchronization from any terminal.

Scheduling relieves the administrator of some repetitive work; however, the administrator should be aware that some circumstances can inadvertently change

scheduled operations. Unintended change of a scheduled audit or synchronization will occur if the following is performed:

- The time schedule for the audit/synchronization is added, changed, or deleted.

When the database is restored, the schedule that existed before backup also is restored, and the new schedule that was entered after backup is lost. Therefore, it is recommended that whenever you restore the I-2000 database from floppy disk, you reenter any scheduled operations.

A log is kept during auditing of all mismatches and during synchronization of all connects and disconnects in a frame, or of all deactivations, deletions and activations in the I-2000. The log also records successes and failures of synchronization. The log is accessible to the user through an AUDIT/ SYNCHRONIZATION RESULTS report, refer to Chapter 14 "Report Operations."

The log contains records of activity related to NPCs. Data from each successive audit/synchronization overwrites the previous records. Data not overwritten remains. Thus, an ALL FACILITY NPCs **Mode** NPC SYNC would create records for every NPC, but a succeeding SINGLE NPC **Mode** NPC SYNC would overwrite the records for one NPC only.

The log may be large if this is the first audit or synchronization and the differences are great. A report of the audit/sync results which does not qualify the range of NPCs in the report may be quite large. Qualify the report by limiting the range of NPCs in the report.

### **DATABASE AUDIT/SYNCHRONIZATION Form**

Select DATABASE AUDIT/SYNCHRONIZATION from the DATABASE ADMINISTRATION menu. The DATABASE AUDIT/SYNCHRONIZATION form is displayed, as shown in Figure 10-5.

This example shows every possible field that can appear on this form. However, the fields that you see vary according to the values in the **Action** and the **Mode** fields.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- DATABASE AUDIT/SYNCHRONIZATION -----
Site Name:
Action:           Mode:           Master DB:
NPC ID:           Channel:
Hier:            Ext:
Last NPC ID:
Hier:            Ext:
                LOCAL INFO           DACS INFO
                Fr:           To:           Fr:           To:
NPC:
Ch:
IW:
Term:
Opts:
SC:
TC:
Enter site name
HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE
    
```

**Figure 10-5. DATABASE AUDIT/SYNCHRONIZATION Form**

**Field Descriptions**

The field descriptions for the DATABASE AUDIT/SYNCHRONIZATION form are described in Table 10-4.

**Table 10-4. DATABASE AUDIT/SYNCHRONIZATION Field Descriptions**

<p><b>Site Name</b></p>	<p>Mandatory. 1 through 24 characters from the set A-Z, a-z, 0-9, /, _, and -. All other characters are illegal. Blanks are not allowed within a name.</p> <p>The name of the DACS where the requested <b>Action</b> will take place. Pressing <b>CHOICES</b> displays WHICH DACS? with a list of the DACS names. These names were established during frame administration, described in Chapter 3 "System Administration."</p>
-------------------------	---

Table 10-4. DATABASE AUDIT/SYNCHRONIZATION Field Descriptions (Contd)

Action	
	Mandatory. Specifies the type of audit/synchronization to be executed. For full details, be sure to refer to the introduction to each <b>Action</b> , given previously in this chapter.
ALARM SYNC	Performs a synchronization of <b>Alarm State</b> only, on the same NPCs as would be specified by ALL LOCAL NPC Mode. This <b>Action</b> is a manual version of automatic alarm synchronization described in the <b>NPC Alarm Sync</b> field under DACS administration in Chapter 3 "System Administration."
CHANNEL AUDIT	Compares local and facility cross-connection databases and logs differences in parameters that are common to the two. The range of channels to be compared is specified by <b>Mode</b> and channel selection fields.
CHANNEL SYNC	Compares local and facility cross-connection databases, logs differences in parameters that are common to the two, and synchronized by eliminating those differences according to restrictions. The range of channels to be synchronized is specified by <b>Mode</b> and channel selection fields.
NPC AUDIT/SYNC	Compares local and facility NPC provisioning databases, logs differences in parameters that are common to the two, and synchronizes by eliminating those differences according to restrictions. The range of NPCs to be compared is specified by <b>Mode</b> or by <b>Mode</b> and NPC selection fields.
UPLOAD	Initiates an NPC SYNC in ALL FACILITY NPC Mode with DACS as <b>Master DB</b> , followed by a CHANNEL SYNC Action in ALL LOCAL NPC Mode, again with <b>Master DB</b> . You can use UPLOAD to load the I-2000 database initially with data taken from the DACS database. The UPLOAD Action only logs failures.
ABORT	Cancels the audit/synchronization currently executing in the background or on queue.


**Table 10-4. DATABASE AUDIT/SYNCHRONIZATION Field Descriptions (Contd)**

<b>Mode</b>	<p>Mandatory. Specifies the range of NPCs or channels to which the <b>Action</b> is to apply. A selection that is explicit about the NPCs, such as ALL FACILITY NPCS, also implies all the associated channels. The values are:</p> <p>ALL FACILITY NPCS      Selects all NPCs that can be equipped in the DACS.</p> <p>ALL LOCAL NPCS      Selects all NPCs that are currently equipped in the local database.</p> <p>RANGE OF LOCAL NPCS      Indicates that the range of local NPCs to be considered is bounded by the <b>NPC ID</b> field or its corresponding <b>Hier</b> or <b>Ext</b> fields and the <b>Last NPC ID</b> field.</p> <p>RANGE OF FACILITY NPCS      Indicates that the range of facility NPCs to be considered is bounded by the <b>NPC ID</b> field or its corresponding <b>Hier</b> or <b>Ext</b> fields and the <b>Last NPC ID</b> fields.</p> <p>SINGLE NPC      Selects the channels of the NPC specified by <b>NPC ID</b> or the associated hierarchical or extended number.</p> <p>SINGLE CHANNEL      Selects the channel specified by the <b>NPC ID</b> or its <b>Hier</b> or <b>Ext</b> equivalents and the <b>Channel</b>.</p>
<b>Master DB</b>	<p>Appears for SYNC <b>Action</b> values only. Selects the master database for a synchronization. The values are:</p> <p>DACS      Use the facility database as the master.</p> <p>LOCAL      Use the local database as the master.</p>

Table 10-4. DATABASE AUDIT/SYNCHRONIZATION Field Descriptions (Contd)

<b>NPC ID</b>	<p>Mandatory. 1 through 41 characters from the printable ASCII character set, excluding *, \, ?, [, ], ^, ", %,  . Blanks are allowed in the name, but leading and trailing blanks are ignored.</p> <p>An identifier, or name, associated with the specified <b>Number</b>. The <b>CREATE Action</b> associates the name and number.</p> <p>Only one <b>NPC ID</b> can be associated with a <b>Number</b> within a DACS, and also, an <b>NPC ID</b> can be associated with only one NPC. An <b>NPC ID</b> uniquely identifies an NPC.</p> <p>An identifier, or name, associated with the specified <b>Number</b>. The <b>CREATE Action</b> associates the name and number.</p> <p>Only one <b>NPC ID</b> can be associated with a <b>Number</b> within a DACS, and also, an <b>NPC ID</b> can be associated with only one NPC. An <b>NPC ID</b> uniquely identifies an NPC.</p>
<b>Channel</b>	Appears for <b>AUDIT</b> and <b>SYNC Actions</b> when the <b>Mode</b> is <b>SINGLE CHANNEL</b> . The channel number of the single channel to be audited or synchronized.
<b>Hier</b>	Appears with <b>NPC ID</b> . The NPC number in hierarchical format. Enter either this field or <b>NPC ID</b> or <b>Ext</b> .
<b>Ext</b>	Appears with <b>NPC ID</b> . The NPC number in extended format.
<b>Last NPC ID</b>	Appears for <b>AUDIT</b> and <b>SYNC Actions</b> when the <b>RANGE Mode</b> values are in effect. Specifies the last <b>NPC ID</b> of the range. Enter either it or the associated <b>Hier</b> or <b>Ext</b> .
<b>Hier</b>	Appears with <b>Last NPC ID</b> . The NPC number in hierarchical format.
<b>Ext</b>	Appears with <b>Last NPC ID</b> . The NPC number in extended format.


This discussion and the fields below apply to **SINGLE CHANNEL Mode** only, as shown in Figure 10-6.



**Figure 10-6. Two Two-point, One-way Circuits**

One channel has two directions. Figure 10-7 depicts two one-way, two-point circuits (**Class** of HDX) utilizing the same channel, Ch x, at the FROM side.

In the case of a two-way, two-point circuit (**Class** of FDX) Ch y and Ch z are the same channel, and both directions are used for channel operation.



**Figure 10-7. A Two-point, Two-way Circuit**

The FROM side **NPC ID** and **Channel** are stated in the upper screen. The fields in the bottom half of the screen, if they appear, state the TO side information. The **Fr NPC** states the hierarchical or extended number of the Tx side of Connection B; for example, at the TO side. In the FDX case, it is the same as the Rx side of Connection A.

**Bottom Screen Field Descriptions**

The field descriptions that appear at the bottom of the screen are described in the following table.

<b>LOCAL INFO Fr</b>	Display-only. The identifying information of the TO side Tx channel as that information appears in the local database. <b>NPC</b> is the hierarchical or extended number.
<b>LOCAL INFO To</b>	Display-only. The identifying information of the TO side Rx channel as that information appears in the local database.

<b>DACS INFO Fr</b>	Display-only. The identifying information of the TO side Tx channel as it appears in the DACS database.
<b>DACS INFO To</b>	Display-only. The identifying information of the TO side Rx channel as it appears in the DACS database.

**Procedure: Scheduling an NPC Audit**

---

This procedure schedules an NPC audit to run every day at 8:00 P.M.

To schedule an NPC Audit, follow these steps:

1. Select DATABASE ADMINISTRATION from the MAIN MENU and DATABASE AUDIT/SYNCHRONIZATION from the DATABASE ADMINISTRATION menu. The DATABASE AUDIT/SYNCHRONIZATION form is displayed, as shown in Figure 10-8.

**Figure 10-8. DATABASE AUDIT/SYNCHRONIZATION Form**

2. Enter these values in the following fields:

- **Site Name:** DACS01
- **Action:** NPC AUDIT
- **Mode:** ALL FACILITY NPC'S

3. Press **EXECUTE** and select SCHEDULE. Enter the following data:

- **Date:** 01 Dec 97

- **Time:** 20 00
- **Number of Times:** 00

 **NOTE:**  
00 indicates continuous.

- **Interval:** 01
- **Scale:** DAYS

4. Press **EXECUTE** again. The Command Completed Successfully message is displayed.

The audit is initiated at the scheduled time. You are notified of its completion status in the I-2000 **Status** field at the top of the screen.

### **Procedure: Printing an NPC Audit**

---

To print the results of the NPC audit, return to the MAIN MENU and follow these steps

1. Select REPORT OPERATIONS from the MAIN MENU and AUDIT/SYNCHRONIZATION RESULTS from the REPORT OPERATIONS menu. The AUDIT/SYNCHRONIZATION SEARCH CRITERIA form is displayed, as shown in Figure 10-9.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
_____ AUDIT/SYNCHRONIZATION SEARCH CRITERIA _____
Site Name:DACS01
Action: NPC AUDIT          Report Type: DETAILED
NPC ID:
Hier:           Ext:
Last NPC ID:
Hier:           Ext:
Date:           Time: : :
_____
Enter the Site name _____
HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE
    
```

**Figure 10-9. AUDIT/SYNCHRONIZATION SEARCH CRITERIA Form**

2. Enter the **Site Name** and **Action** NPC AUDIT. Then press **EXECUTE** and confirm. You are notified that the report request will be executed in the background. When the report is complete, the following status message is displayed:

Report Generation is completed.

The I-2000 **Status** message appears and the cursor moves to DISPLAY LAST GENERATED REPORT.

3. Press **Enter** to select DISPLAY LAST GENERATED REPORT.
4. Select SCREEN or PRINTER from the insert. The AUDIT/SYNCHRONIZATION RESULTS report is printed or displayed.

**Procedure: Performing a Channel Audit**


To perform a channel audit, follow these steps:

1. Select DATABASE ADMINISTRATION from the MAIN MENU and DATABASE AUDIT/SYNCHRONIZATION from the DATABASE ADMINISTRATION menu.

2. Enter the following data:

- **Site Name:** DACS01
- **Action:** CHANNEL AUDIT
- **Mode:** RANGE OF LOCAL NPCS

The NPC range fields are displayed, as shown in Figure 10-10.



---

**Figure 10-10. NPC Range Fields**

3. Enter the following data:

- **NPC ID:** firstnpc
- The **Hier** and **Ext** fields are automatically filled in. You could have entered one of them and the other two fields would have been filled in.
- **Last NPC ID:** lastnpc

The **Hier** and **Ext** fields are automatically filled in.

4. Press **EXECUTE** and select IMMEDIATE. The following events take place:

- A command response window appears notifying you that the job will be run in the background. Press **Enter**.
- The audit is placed on queue to be executed in the background.

- An IN PROGRESS message is displayed in the I-2000 **Status** line.
- When the job is complete, IN PROGRESS changes to NO LONGER IN PROGRESS.

### **Procedure: Performing a Synchronization**

---

This example illustrates how to schedule a one-time background synchronization at 6:00 A.M.

To perform a synchronization, follow these steps:

1. Obtain the DATABASE AUDIT/SYNCHRONIZATION form.
2. Enter the following data:
  - **Site Name:** DACS01
  - **Action:** NPC SYNC
  - The **Master DB** field appears.
3. Enter the following data:
  - **Mode:** ALL FACILITY NPCS
  - **Master DB:** DACS



**NOTE:**

The **Mode** must be compatible with the **Master DB**. If you enter LOCAL with ALL FACILITY NPCS, you get an error message on execution.

4. Press **EXECUTE** and select SCHEDULE.
5. Enter these values:
  - **Date:** 01 Dec 97
  - **Time:** 06 00
  - **Number of Times:** 01
6. Press **EXECUTE**. The Command Completed Successfully message is displayed. In addition, the synchronization is initiated at the scheduled time. You are notified of its completion status in the I-2000 **Status** field at the top of the screen.

### **Procedure: Performing a Subrate Audit**

---

To perform a subrate audit, follow these steps:

1. Select DATABASE ADMINISTRATION from the MAIN MENU and DATABASE AUDIT/SYNCHRONIZATION from the DATABASE ADMINISTRATION menu.

2. Enter the following data:

- **Site Name:** DACS01
- **Action:** SUBRATE AUDIT
- **Mode:** RANGE OF LOCAL NPCS

3. Enter the following data:

- **NPC ID:** firstnpc
- The **Hier** and **Ext** fields are automatically filled in. You could have entered one of them and the other two fields would have been filled in.
- **Last NPC ID:** lastnpc

The **Hier** and **Ext** fields are automatically filled in.

4. Press **EXECUTE** and select IMMEDIATE. The following events take place:

- A command response window appears notifying you that the job will be run in the background. Press **Enter**.
- The audit is placed on queue to be executed in the background.
- An IN PROGRESS message is displayed in the I-2000 **Status** line.
- When the job is complete, IN PROGRESS changes to NO LONGER IN PROGRESS.

### **Procedure: Performing a Subrate Sync**

---

To perform a subrate synchronization, follow these steps:

1. Obtain the DATABASE AUDIT/SYNCHRONIZATION form.

2. Enter the following data:

- **Site Name:** DACS01
- **Action:** SUBRATE SYNC
- The **Master DB** field appears.

3. Enter the following data:

- **Mode:** ALL FACILITY NPCS
- **Master DB:** DACS



**NOTE:**

The **Mode** must be compatible with the **Master DB**. If you enter LOCAL with ALL FACILITY NPCS, you get an error message on execution.

4. Press **EXECUTE** and select SCHEDULE.

5. Enter these values:

- **Date:** 01 Dec 97
- **Time:** 04 00
- **Number of Times:** 01

6. Press **EXECUTE**. The Command Completed Successfully message is displayed. In addition, the synchronization is initiated at the scheduled time. You are notified of its completion status in the I-2000 **Status** field at the top of the screen.

### **Procedure: Uploading the I-2000 Database**

This example illustrates how to upload the I-2000 database from a specified DACS.

To upload the database, follow these steps:

1. Obtain the DATABASE AUDIT/SYNCHRONIZATION form.
2. Enter the following data:
  - **Site Name:** DACS01
  - **Action:** UPLOAD
3. Press **EXECUTE** and select SCHEDULE.
4. Enter the follow data:
  - **Date:** 01 Dec 97
  - **Time:** 06 00
  - **Number of Times:** 01

The upload is initiated at the scheduled time. You are notified of its completion status in the I-2000 **Status** field at the top of the screen.

To obtain reports of the results of an **UPLOAD**, print **AUDIT/SYNCHRONIZATION RESULTS** reports, selecting **Actions** of **NPC SYNC** and **CHANNEL SYNC** on the **SEARCH CRITERIA** forms.

### **Procedure: Initiating an ABORT Action**

The **ABORT Action** causes the currently executing audit/synchronization task to terminate after receiving the response to the last query sent to the DACS. If the task queued, it is just removed from the queue.

To initiate an **ABORT** action, follow these steps:

1. Obtain the DATABASE AUDIT/SYNCHRONIZATION form.
2. Enter the following data:
  - **Site Name:** DACS01
  - **Action:** ABORT

The **Mode** field disappears from the screen.

3. Press **EXECUTE** and confirm. The Command Completed Successfully message is displayed.

## Backing Up and Restoring I-2000 Databases

---

The I-2000 maintains the following data:

- The I-2000 common database, named COMMON. It contains information common to all configured frames.
- The I-2000 report formats, named REPORT FORMATS.



**NOTE:**

The REPORT FORMATS are contained within the COMMON database. They are made available separately to allow easy transport of report formats. However, backing up COMMON also backs up REPORT FORMATS.

- One database for each DACS in the system, with names the same as the **Site Names**. Each database contains data specific to one DACS.
- Some I-2000 logs.

The DACS have their own databases, apart from the I-2000 system, which they utilize even if they are not connected to the I-2000. Backing up or restoring an I-2000 database, whether it is COMMON, REPORT FORMATS, or a database named with a site name, does not affect a DACS-installed database in any way.



**NOTE:**

When selecting a FULL backup/restore, you can abort the backup/restore by pressing the **DELETE** key twice. The action may not stop immediately, since the backup/restore may be working on a single database on the tape and cannot be interrupted. However, the command will stop the backup/restore process after the action on the current database is complete.




**NOTE:**

All backup actions to tape or diskette will overwrite the current contents of the media.

### BACKUP/RESTORE Menu

---

To obtain the BACKUP/RESTORE menu, select it from the DATABASE ADMINISTRATION menu. The BACKUP/RESTORE menu is displayed, as shown in Figure 10-11.



**Figure 10-11. BACKUP/RESTORE Menu**

Before restoring the COMMON database, REMOVE all frames from service (refer to “Frame Provisioning” in Chapter 3 “System Administration”).

A backup or a database restore may fail if one of the following conditions exist:

- FRAME PROVISIONING request is in progress, for example, adding or deleting a DACS, or changing the name of a DACS.
- A message log recovery is in progress on the DACS that is to be backed up.

A database restore may also fail or be denied:

- If an audit/sync is running on the DACS that is to be backed up.
- The database on the tape was not created from the same DACS release that is currently running on the I-2000.
- The language on the database is not consistent with the language of the I-2000.

In general, it is not possible to restore a database or log from tape or diskette that was created from an older release of I-2000 into the current (or newer) release of I-2000.

### **Procedure: Backing Up Database to Tape**

The tape backup feature offers capabilities to back up all databases (**Action** of FULL BACKUP) or selected databases (**Action** of SELECTIVE BACKUP). The following example demonstrates how to select databases.

To backup a database to tape, follow these steps:

1. Select DATABASE BACKUP/RESTORE (TAPE) from the BACKUP/RESTORE menu. The sample screens shown in Figure 10-12 display a FULL BACKUP and a FULL RESTORE for COMMON and 30 other databases.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS II
Status:
Alarms:
----- DATABASE BACKUP/RESTORE (TAPE) -----
Action: FULL BACKUP
COMMON
ISX
CEF
CEF2
CEF3
CEF4
CEF5
CEF6
CEF7
CEF8
CEF9
CEF10
CEF11
ISX1
ISX2
ISX3
ISX4
ISX5
ISX6
ISX7
ISX8
ISX9
ISX10
ISX11
ISX12
ISX13
ISX14
ISX15
ISX16
ISX17
ISX18
Enter desired action
HELP CHOICES QUIT TOP MENU PRINT EXECUTE
    
```

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS II
Status:
Alarms:
----- DATABASE BACKUP/RESTORE (TAPE) -----
Action: FULL RESTORE
COMMON
ISX
CEF
CEF2
CEF3
CEF4
CEF5
CEF6
CEF7
CEF8
CEF9
CEF10
CEF11
ISX1
ISX2
ISX3
ISX4
ISX5
ISX6
ISX7
ISX8
ISX9
ISX10
ISX11
ISX12
ISX13
ISX14
ISX15
ISX16
ISX17
ISX18
Enter desired action
HELP CHOICES QUIT TOP MENU PRINT EXECUTE
    
```

Figure 10-12. DATABASE BACKUP/RESTORE (TAPE) Form

2. Enter `SELECTIVE BACKUP` in the **Action** field or select it with the `CHOICES` key. An insert pops up asking WHICH DATABASES? and displaying the existing database names. This is a multiselect menu. The `SELECT` and `UNSELECT` keys are enabled.
3. Use the `SELECT` key to select as many databases as you want. Selected databases remain highlighted even though the cursor is not on them. When finished, press `Enter`. The selected databases are listed in the form.
4. Insert the tape cartridge into the drive.
5. Press `EXECUTE` and confirm.

The following messages are displayed in this order:

Unloading name database into files...

Copying name database files onto tape...

Messages similar to those above are repeated for as many databases as are selected.

6. When the I-2000 successfully completes the backup, the following message is displayed:

The Command Completed Successfully

7. If the command fails, an insert appears stating the reason. To try again, reselect the databases.

### **Procedure: Restoring a Database From Tape**

---

The tape restore feature offers capabilities to restore:

- All databases (**Action** of `FULL RESTORE`)
- Selected databases (**Action** of `SELECTIVE RESTORE`).



**NOTE:**

On successful completion of a `COMMON database RESTORE`, the I-2000 system restarts.

When selecting a `FULL backup/restore`, you can abort the backup/restore by pressing the `DELETE` key twice. The action may not stop immediately; however, the command will stop the backup/restore process after the action on the current database is complete.



**WARNING:**

*Restoral of the `COMMON database` where the current I-2000 hardware ports configuration is not identical to that of the backup I-2000 may cause the system to run in a degraded manner.*



**WARNING:**

*Before doing a full restore, or any restore that involves the COMMON database, it is recommended that all DACSs be removed from service. It is also recommended that all users be logged off before doing a full restore.*



**WARNING:**

*It is recommended that you not perform a partial restore that includes the COMMON database unless you are certain that the FRAME PROVISIONING information on the existing COMMON database and the one on tape is the same.*



**NOTE:**

A `SELECTIVE RESTORE` using a DACS database that does not already exist at the I-2000 will fail. To copy that database to the I-2000, first go to `FRAME PROVISIONING` and `CREATE` a DACS of the same name, then use `SELECTIVE RESTORE` to restore that database from tape into the newly created DACS.

The following procedure demonstrates how to restore selected databases.

To restore a database from tape, follow these steps:

1. Select `DATABASE BACKUP/RESTORE (TAPE)` from the `BACKUP/RESTORE` menu. The `DATABASE BACKUP/RESTORE (TAPE)` form.
2. Insert the tape cartridge into the drive.
3. Enter `SELECTIVE RESTORE` in the **Action** field or select it with the `CHOICES` key. The tape is read. An insert pops up asking `WHICH DATABASES?` and displaying the names of the databases on tape. This is a multiselect menu.
4. Use the `SELECT` key to select as many databases as you want.
5. When finished, press `Enter`. The databases selected along with the name of the I-2000 and time stamp on the tape are displayed. (See "Changing the I-2000 Name.")
6. Press `EXECUTE` and confirm. The following messages are displayed in the following order:  

```
Copying name database files from tape...
Loading name database files...
```

Messages similar to those above are repeated for as many databases as are selected.
7. When the I-2000 successfully completes the restore, the following message is displayed:  

```
The Command Completed Successfully
```
8. If the command fails, an insert appears stating the reason.

### **Procedure: Backing Up The Alarm Log to Tape**

The tape backup feature offers capabilities to back up the alarm log for all (**Action** of FULL BACKUP) or selected databases (**Action** of SELECTIVE BACKUP). The following example demonstrates how to select databases.

To backup the alarm log to tape, follow these steps:

1. Select LOG BACKUP/RESTORE (TAPE) from the BACKUP/RESTORE menu. The LOG BACKUP/RESTORE (TAPE) form is displayed, as shown in Figure 10-13, with **Type** fixed at ALARM.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS II
Status:
Alarms:
          LOG BACKUP/RESTORE (TAPE)
Action:          Type:ALARM          Database Name:
Enter desired action
HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE

```

**Figure 10-13. LOG BACKUP/RESTORE (TAPE) Form**

2. Enter SELECTIVE BACKUP in the **Action** field or select it with the **CHOICES** key. An insert pops up asking WHICH DATABASES? and displaying the existing database names. This is a multiselect menu. The **SELECT** and **UNSELECT** keys are enabled.
3. Use the **SELECT** key to select as many databases as you want. Selected databases remain highlighted even though the cursor is not on them. When finished, press **Enter**. The selected databases are listed in the form.
4. Insert the tape cartridge into the drive.
5. Press **EXECUTE** and confirm. The following messages are displayed in this order:

Unloading name database into files.

Copying name database files onto tape...

Messages similar to those above are repeated for as many sites as are selected.

6. When the I-2000 successfully completes the backup, the following message is displayed:

The Command Completed Successfully

If the command fails, an insert appears stating the reason. To try again, reselect the sites.

### **Procedure: Restoring Alarm Log From Tape**

---

The tape restore feature offers capabilities to restore:

- Alarm log for all databases (**Action** of FULL RESTORE)
- Alarm log for selected databases (**Action** of SELECTIVE RESTORE).

The following example demonstrates how to restore selected databases.

To restore an alarm log from tape, follow these steps:

1. Select LOG BACKUP/RESTORE (TAPE) from the BACKUP/RESTORE menu. The LOG BACKUP/RESTORE (TAPE) form is displayed, with **Type** set at ALARM.
2. Insert the tape cartridge into the drive.
3. Enter SELECTIVE RESTORE in the **Action** field or select it with the **CHOICES** key. The tape is read. An insert pops up asking WHICH DATABASES? and displaying the names of the databases on tape. This is a multiselect menu.
4. Use the **SELECT** key to select as many databases as you want.
5. When finished, press **Enter**. The databases selected along with the time stamp on the tape are displayed.
6. Press **EXECUTE** and confirm. The following messages appear in this order:  

```
Copying name database files from tape...  
Loading name database files...
```

Messages similar to those above are repeated for as many sites as are selected.
7. When the I-2000 successfully completes the restore, the following message is displayed:  

```
The Command Completed Successfully
```
8. If the command fails, an insert appears stating the reason.

### **Procedure: Backing Up An Alarm Log to Diskette**

---

To back up an alarm log to a diskette, follow these steps:

1. Select LOG BACKUP/RESTORE (DISKETTE). The LOG BACKUP/RESTORE (DISKETTE) form is displayed, as shown in Figure 10-14.


```
06:15 01 Nov 1997 I-2000 Controller Release-x.x for DACS II
Status:
Alarms:
----- LOG BACKUP/RESTORE (DISKETTE) -----
Action:BACKUP   Type:ALARM   Database Name:
-----
Enter desired action
HELP  CHOICES  [ ]  QUIT  [ ]  TOP MENU  PRINT  EXECUTE
```

---

**Figure 10-14. LOG BACKUP/RESTORE (DISKETTE) Form**

2. Enter **BACKUP** in the **Action** field.
3. Enter the name of the database in the **Database Name** field. The possibilities can be listed with **CHOICES**.
4. Press **EXECUTE** and confirm.

The named database is unloaded to an ASCII temporary file. The LOG BACKUP/RESTORE (DISKETTE) screen is displayed, as shown in Figure 10-15.



**Figure 10-15. Insert Disk Prompt**

5. Insert a diskette and press **Enter**. The I-2000 writes the log to diskette. When the backup is complete, The Command Completed Successfully message is displayed.



**NOTE:**

After the log is backed up, be sure to label it with number sequence and contents.

**Procedure: Restoring An Alarm Log from Diskette**

To restore an alarm log from diskette, follow these steps:

1. From the BACKUP/RESTORE menu, select LOG BACKUP/RESTORE (DISKETTE) and enter an **Action** of RESTORE.
2. Enter the name of the site in the **Database Name** field. Pressing **CHOICES** lists the names of the I-2000 sites.
3. Press **EXECUTE** and confirm.
4. You are prompted for the diskette. Insert the diskette into the drive. Press **Enter**.

### **Procedure: Backing Up or Restoring Report Formats**

To backup or restore the report formats of an I-2000 to a diskette, follow these steps:

1. Select REPORT FORMAT BACKUP/RESTORE (DISKETTE) from the BACKUP/RESTORE menu.
2. Following the prompt, insert the diskette into the drive.
3. Choose BACKUP or RESTORE from the **Action** field.
4. Press `EXECUTE`.

### **Procedure: Formatting a Diskette**

To format a diskette, follow these steps:

1. Select FORMAT DISKETTE from the BACKUP/RESTORE menu.
2. Following the prompt, insert the diskette into the drive. But first, make sure the write-protect notch is covered.
3. Press `Enter`. The diskette is formatted. The system will prompt you with the following message:

```
formatting
...
```

where the number of dots under the word `formatting` increases as the format progresses.

4. Press any key to continue. You return to the BACKUP/RESTORE menu.
5. Repeat the procedure for the remaining diskettes.

### **Entering and Retrieving Outage Data**

The ENTER OUTAGE DATA selection allows you to keep electronic notebooks, or logs, on NPC and circuit outages that have occurred on a DACS. You collect the data to be placed in a log. An advantage to keeping the log is that you can generate a report to obtain a formatted, hard-copy log.

Two logs are available:

- NPC outage log
- Circuit outage log

The logs allow you to record when an NPC or circuit, respectively, became nonfunctional, and when you restored service on them. You can store, change, or remove records for each log.

**Procedure: Entering Outage Log Data**

To obtain the OUTAGE LOG data, follow these steps:

1. Select DATABASE ADMINISTRATION from the MAIN MENU.
2. Select ENTER OUTAGE DATA from the DATABASE ADMINISTRATION menu. The OUTAGE LOG form is displayed, as shown in Figure 10-16.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS II
Status:
Alarms:
----- OUTAGE LOG -----
Site Name:DACS00

Outage Type:NPC           Action:INSERT           Record No:

Outage ID:

Date Out:                 Time Out:      :      :

Date In:                  Time In:       :      :

Enter site name
HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE
    
```

**Figure 10-16. OUTAGE LOG Form**

**Field Descriptions**

The field descriptions for the OUTAGE LOG form are described in Table 10-5.

**Table 10-5. Outage Log Field Descriptions**

<b>Site Name</b>	<p>Mandatory. 1 through 24 characters from the set A-Z, a-z, 0-9, /, _, and -. All other characters are illegal. Blanks are not allowed within a name.</p> <p>The name of the DACS where the requested <b>Action</b> will take place. Pressing <b>CHOICES</b> displays WHICH DACS? with a list of the DACS names. These names were established during frame administration, described in Chapter 3 "System Administration."</p>
------------------	---

**Table 10-5. Outage Log Field Descriptions (Contd)**

<b>Outage Type</b>	Mandatory. The log to be affected by the <b>Action</b> .  NPC           Selects the outage log for an NPC. CIRCUIT      Selects the outage log for a circuit.
<b>Action</b>	Mandatory. The type of record handling to be performed  INSERT       Places the record in the log. CHANGE       Modifies the record. DELETE       Removes the record from the log. DESTROY      Removes all records from the log.
<b>Record No.</b>	A sequence number, 1 through 9999, that is automatically assigned during an <b>INSERT Action</b> , and can be entered in other <b>Actions</b> . Each circuit or NPC can have up to 9999 outage records. The default is the next highest value for the set of entries for a circuit or NPC. After a deletion, the records in the sequence are renumbered automatically.
<b>Outage ID</b>	Mandatory. 1 through 41 characters. The ID of the NPC or circuit for which the outage is being recorded. IDs that are not provisioned are not accepted.
<b>Date Out</b>	Three fields stating the date on which the outage began, in the format:  dd mmm yy  If you do not enter a <b>Date Out</b> when inserting an outage record, the default is the current date.  where dd can be one or two digits, mmm is the first three letters of the month in either upper or lower case, and yy is the last two digits of the current year. 90-38 are valid entries.
<b>Time Out</b>	Three fields stating the time on which the outage began, in the format:  hh:mm:ss  where hh is 0 through 24 hours (00:01 follows 24:00), mm is 0 through 59 minutes, and ss is 0 through 59 seconds. The default is the current time.
<b>Date In</b>	The date the outage was cleared. If you do not enter a <b>Date In</b> when inserting an outage record, the default is the current date.
<b>Time In</b>	The time the outage was cleared. The default is the current time.

### **Procedure: Inserting a Record in the NPC Outage Log**

---

To insert a record in the NPC outage log, follow these steps:

1. On the OUTAGE LOG form, enter the following data:
  - **Site Name:** DACS01
  - **Outage Type:** NPC
  - **Action:** INSERT
  - **Record No:** 0001
  - **Outage ID:** NPC01101
  - **Date Out:** 01 Nov 97
  - **Time Out:** 01:34:26
  - **Date In:** 01 Dec 97
  - **Time In:** 06 15 22
2. Press **EXECUTE** and confirm. The I-2000 completion message is displayed.



**NOTE:**

If you get a COMMAND DENIAL WINDOW with a message CANNOT INSERT OR CHANGE OUTAGE LOG WHEN OUTAGE ID NOT IN SYSTEM, then your NPC has not been provisioned when the **Outage Type** is NPC or your circuit has not been provisioned when the **Outage Type** is CIRCUIT.

### **Procedure: Retrieving Outage Data**

---

To obtain a report on the data from an OUTAGE DATA LOG, follow these steps:

1. Select REPORT OPERATIONS from the MAIN MENU.
2. Select OUTAGES from the REPORT OPERATIONS menu.
3. On the OUTAGE SEARCH CRITERIA form, only the **Site Name** and **Outage Type** are required. Enter them. **Outage Type** selects the log.
4. The ID field that appears on the screen depends on the **Outage Type** that you entered. Not entering an ID selects all NPCs or circuits in the log.

Another method of selecting is to enter a **Record Number** expression, if you know or can guess the record sequence numbers of the log. The **Record Number** field description is described in Table 10-6.

## Field Descriptions

Field descriptions for the record number are listed in Table 10-6.

**Table 10-6. Record Number Field Descriptions**

<b>Record Number</b>	Two fields specifying a range of record numbers:  <number specifies all numbers less than number.  >number specifies all numbers greater than number.  number specifies only the number. The default of blanks in both fields selects all numbers, except as qualified by the additional fields.
----------------------	---

5. When you have entered the selection criteria, press **EXECUTE** and confirm. The screen temporarily displays the following message:

SENDING REPORT GENERATION REQUEST. WAITING FOR REPLY.  
COMMAND WILL BE EXECUTED IN BACKGROUND.

6. Press **Enter** to acknowledge the command response.
7. The REPORT OPERATIONS screen is displayed with DISPLAY LAST GENERATION REPORT selected. Press **Enter**.
8. Select SCREEN or PRINTER. The report is printed or displayed.

## Moving a Database from One I-2000 to Another

---

You can use DATABASE BACKUP/RESTORE to move a DACS to another I-2000. First, do a **SELECTIVE BACKUP** of the DACS' database on tape. Take the tape to the other I-2000, provision a DACS at this I-2000 with the same **Site Name** and do a **SELECTIVE RESTORE**. Finally, delete the DACS at the old site.



**WARNING:**

*The same version of I-2000 software must be running at both sites.*

---

**Contents**

<b>Introduction</b>	11-1
<b>TASK ADMINISTRATION Menu</b>	11-2
■ TASK MANAGEMENT Form	11-3
Field Descriptions	11-3
■ Procedure: Listing Scheduled Tasks	11-4
Field Descriptions	11-5
■ Procedure: Deleting a Task	11-6
■ PRINTER QUEUE STATUS Form	11-6
Field Descriptions	11-7
■ Procedure: Displaying Printer Queue Status	11-7
■ Procedure: Removing a Printer Job From the Queue	11-9

---

## **Task Administration**

# **11**

---

### **Introduction**


---

The TASK ADMINISTRATION selection of the MAIN MENU allows you to list or delete scheduled tasks. These tasks were scheduled by the user with the TASK SCHEDULING insert (refer to "Using the Execute Key" in Chapter 2 "Getting Started"). Once they have been deleted, you will have to reschedule to run them again.

## **TASK ADMINISTRATION Menu**

---

To obtain the TASK ADMINISTRATION menu, select TASK ADMINISTRATION from the MAIN MENU. The TASK ADMINISTRATION menu is displayed, as shown in Figure 11-1.



---

**Figure 11-1. TASK ADMINISTRATION Menu**

**TASK MANAGEMENT Form**

To view the queue of tasks, or to delete a task, select TASK MANAGEMENT. The TASK ADMINISTRATION Form is displayed, as shown in Figure 11-2.

**Figure 11-2. TASK ADMINISTRATION Form**

**Field Descriptions**

The fields that appear on the screen depend on the value of **Type**. Field descriptions are described in Table 11-1.

**Table 11-1. Task Administration Field Descriptions**

<b>Action</b>	<p>Mandatory. The selections for this field are:</p> <p>LIST            Lists the scheduled tasks that you have specified in <b>Type</b>.</p> <p>DELETE        Deletes the scheduled tasks that you have specified in <b>Type</b>. You can delete any of your own tasks. Only the system administrator can delete tasks scheduled by other users.</p>
---------------	---

**Table 11-1. Task Administration Field Descriptions (Contd)**

<b>Type</b>	Mandatory. Specifies which scheduled tasks you wish to list or delete. The selections are:  TASK            All tasks for a specified <b>Site Name</b> and <b>User ID</b> . SITE            All tasks for a specified <b>Site Name</b> . USER            All tasks for a specified <b>User ID</b> . ALL             All scheduled tasks.
<b>Site Name</b>	Enter the name of the DACS where the requested <b>Action</b> will take place. Pressing <b>CHOICES</b> displays WHICH DACS? with a list of the DACS names. These names were established during frame administration.
<b>User ID</b>	Mandatory for <b>TASK</b> and <b>USER</b> <b>Types</b> only. Enter the I-2000 login name for the user whose task schedules you wish to <b>LIST</b> or <b>DELETE</b> .

Before you delete specified tasks, it is a good idea to take a look at them by selecting the **LIST** from the **Action** field. A **DELETE Action** does not automatically list tasks.

### **Procedure: Listing Scheduled Tasks**

To list scheduled tasks, follow these steps:

1. Select **TASK ADMINISTRATION** from the **MAIN MENU** and **TASK MANAGEMENT** from the **TASK ADMINISTRATION** menu.
  - Enter the following data.
  - **Action:** LIST
  - **Type:** SITE
  - **Site Name:** testsite
2. Press **EXECUTE**. The **TASK SELECTION** insert pops up, describing the first task. Use **NEXT** and **PREVIOUS** to display descriptions of the other tasks on the list. An example of a displayed task is shown in Figure 11-3.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- TASK ADMINISTRATION -----
Action:          Type:          Site Name:      User ID:
----- TASK SELECTION -----
User ID:ems      Site:testsite   Task:NPC Provisioning
Next Run:29Dec97 12:15:00  Last Run:      Interval:ONCE
Desc:CREATE NPC 01101 PB144
Enter desired action
HELP  PREVIOUS  NEXT  QUIT  TOP MENU  EXECUTE
    
```

Figure 11-3. A Displayed Task

**Field Descriptions**

Table 11-2 describes the fields for a displayed task in the TASK ADMINISTRATION form.

**Table 11-2. TASK ADMINISTRATION Field Descriptions**

<b>User ID</b>	The login ID of the user who created the task.
<b>Site</b>	The <b>Site Name</b> of the DACS on which the task is scheduled to be implemented.
<b>Task</b>	The name of the form on which the task was created.
<b>Next Run</b>	The time when next execution of the task is scheduled to begin.
<b>Last Run</b>	The time when last execution of the task is scheduled to begin, if this is a task that runs more than once.
<b>Interval</b>	The interval, in minutes, hours or days, at which the task is scheduled to run.
<b>Desc</b>	A brief description of the task to be implemented.

### Procedure: Deleting a Task

---

To delete a task, follow these steps:

1. Press **QUIT** and navigate to **Action**.
2. Enter **DELETE**.
3. Move to the **Type** field and enter the type of task to delete, for example, **ALL**.
4. Press **EXECUTE** and confirm. The **command completed successfully** message is displayed.

### PRINTER QUEUE STATUS Form

---

To display and delete print requests in the print queue, select **PRINTER QUEUE STATUS**. The **PRINTER QUEUE STATUS Form** is displayed, as shown in Figure 11-4.

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II  
Status:  
Alarms:

PRINTER QUEUE STATUS

Action: Printer Name:CONSOLE PRINTER  
Printer Status:ENABLED

HELP CHOICES QUIT TOP MENU PRINT EXECUTE

---

**Figure 11-4. PRINTER QUEUE STATUS Form**

**Field Descriptions**

The field descriptions for the PRINTER QUEUE STATUS form are described in Table 11-3.

**Table 11-3. PRINTER QUEUE STATUS Descriptions**

<b>Action</b>	Mandatory. Enter the action to be performed with regard to the printer job.  LIST            Select LIST to display the printer queue.  CANCEL        Select CANCEL to cancel any printer job already ENABLED.
<b>Printer Name</b>	Name of the printer. Press CHOICES for a list of valid printer names.
<b>Printer Status</b>	The printer status.

**Procedure: Displaying Printer Queue Status**

---

To display the printer queue status, follow these steps:

1. Select PRINTER QUEUE STATUS. The PRINTER QUEUE STATUS form is displayed, as shown in Figure 11-5.



```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- PRINTER QUEUE STATUS -----
Action:LIST                               Printer Name:CONSOLE PRINTER
----- Printer Queue -----
Job no.   User      Size      Time
-----
16        root      5         Nov 1 14:33 on printer
17        rootadm  6         Nov 1 14:33 on printer
-----
Page x of y   Display Page:n
Enter the page number:

```

HELP    NEXTPAGE    PREVPAGE    QUIT    TOP MENU    PRINT

**Figure 11-6. Sample Print-job Status**

**⇒ NOTE:**  
The Time column does not appear for Sun systems.

### **Procedure: Removing a Printer Job From the Queue**

To remove a job from the queue, follow these steps:

1. Obtain the PRINTER QUEUE STATUS form.
2. Select an **Action** of CANCEL from the **CHOICES** menu.
3. Select a **Printer Name** from the **CHOICES** menu.
4. Press **EXECUTE**. The jobs are listed as for the **LIST Action**. However, an additional field, **Cancel**, appears before **Job No.**
5. Using **Enter**, move the cursor to the beginning of the line for the job you want to cancel and type an **x** or **X**.
6. Press **CANCEL**.

**⇒ NOTE:**  
If the cursor remains on **Display Page**, you are in **LIST** rather than in **CANCEL**. Press **QUIT** and enter **CANCEL** as an **Action**.

---

**Contents**

<b>Introduction</b>	12-1
<b>Constraints</b>	12-2
<b>USER ADMINISTRATION Menu</b>	12-2
■ USER MANAGEMENT Form	12-3
Field Descriptions	12-4
■ Procedure: Adding a User Login	12-5
■ CHANGE PASSWORD	12-6
■ Procedure: Changing Password as an Operator	12-6
■ Procedure: Changing Password as a System Administrator	12-7
■ Procedure: Entering the System on Loss of Password	12-8

### Introduction

The I-2000 supports a total of 64 logins: **dacsadm**, **cscan**, **ems**, and 61 others. The **dacsadm** login is a system administrator and cannot be deleted. The others can be system administrators or operators. After setup and configuration of ports and links, a system administrator adds logins and can **ADD**, **CHANGE**, or **DELETE** them thereafter. A **CHANGE** or **DELETE** on an active login is delayed until the login becomes inactive (logs off).

System administrators and operators are distinguished from each other by the I-2000 functions they are permitted to use. System administrators always have unrestricted access to the I-2000; operators are restricted from certain selections. For example, all of the **SYSTEM ADMINISTRATION** and **DATABASE ADMINISTRATION** selections are reserved for the administrator. An operator can change his own user information and login, but only a system administrator can change any login's information. User access is defined by the **User Class** field on the **USER MANAGEMENT** form.

The I-2000 supports up to 16 simultaneous login sessions. Some of them may be reserved for controllers. Users may log in after stating their **Login Name** and **Password**, provided a session is available. If it is not, login is denied. Controllers log in automatically.

## Constraints

---

The following constraints apply to passwords and logins:


- The login name must contain from two through eight alphanumeric characters with at least one lower case letter.
- Passwords must contain at least six characters with at least two alphabetic and at least one numeric or special character. Refer to the restrictions stated under "CHANGE PASSWORD", in this chapter.

The term alphabetic refers to all uppercase and lowercase letters. UNIX will disable upper/lower case password sensitivity whenever a login name is entered with all uppercase letters.

## USER ADMINISTRATION Menu

---

To obtain the USER ADMINISTRATION menu, select USER ADMINISTRATION from the MAIN MENU. The USER ADMINISTRATION menu is displayed, as shown in Figure 12-1.



**Figure 12-1. USER ADMINISTRATION Menu**

### USER MANAGEMENT Form

---

To access the USER MANAGEMENT form, select USER MANAGEMENT from the USER ADMINISTRATION menu. The USER MANAGEMENT form is displayed, as shown in Figure 12-2.

```
06:15 01 Nov 1997  I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- USER MANAGEMENT -----
Action:                               Login Name:
User Class:                           Password:
User Name:
Phone:                                 Printer Name:CONSOLE PRINTER
Address:                               City:
Alarms Audible:                       UI Idle Option:OFF

Enter desired action -----
HELP  CHOICES  QUIT  TOP MENU  PRINT  EXECUTE
```

---

**Figure 12-2. USER MANAGEMENT Form**

## Field Descriptions

Table 12-1 describes the fields used in the USER MANAGEMENT form.

**Table 12-1. USER MANAGEMENT Field Descriptions**

<b>Action</b>	<p>Mandatory.</p> <p>ADD            Adds a user login to the I-2000.</p> <p>CHANGE        Changes USER MANAGEMENT fields other than the <b>Login Name</b> and <b>Password</b>. To change the <b>Login Name</b>, DELETE and ADD the login. To change the password, use the CHANGE PASSWORD selection.</p> <p>DELETE        Deletes a user login from the I-2000.</p>
<b>Login Name</b>	<p>Mandatory. The login name by which the user will be known to the I-2000, and which will be required on login. Two through eight alphanumeric characters from the printable ASCII character set. One lower-case letter is required. Login Name may only contain alphanumeric characters (0-9, A-Z, and a-z). It may not contain control characters, punctuation marks, or spaces.</p>
<b>User Class</b>	<p>The type of login:</p> <p>OPERATOR    The login is for an operator.</p> <p>ADMIN        The login is for an administrator.</p> <p>CONTROLLER Not available.</p>
<b>Password</b>	<p>Mandatory. Appears only for an <b>Action</b> of ADD. The password, which will authorize entry to the I-2000 system with the <b>User Class</b> field value in effect, and will be required on login.</p>
<b>User Name</b>	<p>Up to 40 alphanumeric characters including numbers, letters, dash, open parenthesis, closed parenthesis, period, comma, and space. The name of the person owning the login specified in <b>Login Name</b>.</p>
<b>Phone</b>	<p>Up to 13 alphanumeric characters, including 0-9, -, (, ), comma, and space. The telephone number of the person cited in <b>User Name</b>.</p>
<b>Printer Name</b>	<p>Mandatory. The name of the printer to be in effect for this login. Use the [CHOICES] menu to select the name. The default, CONSOLE PRINTER, appears in every [CHOICES] menu. Names of remote printers installed in the <b>printcap</b> file of Sun systems also will appear. For more information, refer to Remote Printer Administration in Chapter 2 "Getting Started."</p> <p>To reset the <b>Printer Name</b>, use a CHANGE <b>Action</b>.</p>

**Table 12-1. USER MANAGEMENT Field Descriptions (Contd)**

<b>Address</b>	Up to 20 alphanumeric characters. The address of the person cited in <b>User Name</b> .
<b>City</b>	Up to 20 alphanumeric characters. The city of the person cited in <b>User Name</b> .
<b>Alarms Audible</b>	A switch:  ON An audible signal should sound at the terminal where the user is logged in when an alarm occurs.  OFF An audible signal should not sound.
<b>UI Idle Option</b>	Set a threshold value for terminal idle time:  ON Log off automatically after IDLE_THRESHOLD minutes of idle time. See the description of the userenv file in Chapter 2.  OFF Remain logged on until the user logs off.  The <b>UI IDLE Option</b> is accessible to the OPERATOR class. It is not accessible for the ADMIN and CONTROLLER user classes.

**Procedure: Adding a User Login**

To add a user login, follow these steps:

1. On the USER MANAGEMENT form, enter the following data:

- **Action:** ADD
- **Login Name:** NANCY
- **User Class:** OPERATOR
- **User Name:** Nancy Smith
- **Phone:** (908)555-0000
- **Address:** 101 Crawfords Corner Road
- **City:** Holmdel, New Jersey
- **Alarm Audible:** OFF
- **UI Idle Option:** OFF

2. Navigate to the **Password** field and enter the password. The letters you type do not appear on the screen.

3. Press **[Enter]**. The PASSWORD VERIFY FORM appears with the following message:

Reenter the password  
Reenter the password and type VERIFY key

The label of the F8 key becomes **[VERIFY]**.

4. Retype the password and press **[VERIFY]**. The cursor goes to **User name**. The password is never displayed.
5. Press **[EXECUTE]** and confirm. The command completed successfully message is displayed.

## **CHANGE PASSWORD**

---

The following restrictions apply to changing the password.

- The password can be changed only for the current user.
- Passwords must be at least six characters.
- Passwords must contain at least two letters and one nonletter, meaning one number or special character.
- #, @, -, **[Backspace]**, **[Delete]**, and other functional keystrokes are excluded.

### **Procedure: Changing Password as an Operator**

---

To change the password as an operator, follow these steps:

1. Select CHANGE PASSWORD from the USER ADMINISTRATION menu. The following message is displayed:

Changing password for login name

2. You are prompted to enter

Old password:

Enter the old password. What you type does not appear on the screen. If you decide to abort the procedure, simply press **[Delete]** without typing a password. The message:

Sorry. Incorrect password.

is displayed, and you are returned to the USER ADMINISTRATION menu.

3. You are prompted to enter a new password:

New password:

Enter a new password and press **[Enter]**. If you decide to abort the procedure, press **[Delete]** to return to the USER ADMINISTRATION menu.

4. You are prompted to reenter the password:

Reenter new password:

Reenter the new one and press **Enter**. It is accepted only if it matches the new password just entered letter for letter, including case. At the bottom of the screen the following message is displayed:

Password successfully changed.

### Procedure: Changing Password as a System Administrator

---

To change the password as a system administrator, follow these steps:

1. Select CHANGE PASSWORD from the USER ADMINISTRATION menu. The PASSWORD CHANGE FORM is displayed, as shown in Figure 12-3.

The screenshot shows a terminal window with the following content:

```
06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- PASSWORD CHANGE FORM -----
Login Name:                               New Password:
-----
Enter desired login name -----
HELP  [ ]  [ ]  QUIT  [ ]  TOP MENU  PRINT  EXECUTE
```

**Figure 12-3. PASSWORD CHANGE Form**

2. Enter the **Login Name** of the user whose password you want to change.
3. Enter the **New Password** and press **Enter**. The PASSWORD VERIFY FORM is displayed, with the prompt:

Re-enter the password

The message at the bottom of the screen is

Re-enter the password and press VERIFY key.

The 8th function key changes to **VERIFY**.

4. Re-enter the password and press **VERIFY**. The cursor returns to **Login Name**.

## Procedure: Entering the System on Loss of Password

---

If you forget the password, then you will have to rely on the **root** password. Use the following procedure to gain access with the **root** password.



**NOTE:**

This procedure can only be followed by the system administrator at the console. If you are at a remote site, call the console site.

To enter the system with out a password, follow these steps:

1. At the login prompt, enter the word **root**:

```
login: root  
and press .
```

2. Enter the **root** password that was established at software installation:

```
password:
```



**NOTE:**

It is extremely important to enter and to remember a root password, both to prevent unauthorized access from the root login, and for purposes of recovery.

3. At the # prompt, type a command in the format

```
# passwd {user}
```

For example, if the password is to be entered for a user of **ems**, type

```
# passwd ems
```

4. The system asks for a new password. Enter it, and be sure not to forget it.
5. Re-enter the same new password on request.
6. At the # prompt, type **exit**:

```
# exit
```

```
and press .
```

7. Log in under **ems** with the new password.

---

**Contents**

<b>Introduction</b>	13-1
■ Prerequisites	13-1
<b>Passthrough</b>	13-2
■ Passthrough through X.25	13-2
■ Passthrough through SNIDER	13-2
<b>Multiplexed Passthrough</b>	13-2
■ Procedure: Entering a Multiplexed Passthrough	13-3
<b>Full Passthrough</b>	13-7
■ Procedure: Entering a Full Passthrough	13-8
<b>Using Passthrough Selections</b>	13-8
■ Passthrough Control Keys	13-9
■ Procedure: Terminating Passthrough	13-10
<b>Frame Command Script</b>	13-11
■ FRAME COMMAND SCRIPT Form	13-12
Field Descriptions	13-14
■ Procedure: Creating a Script File	13-15
■ Procedure: Writing a File to DOS Diskette	13-16
■ Procedure: Reading a File From DOS Diskette	13-18
■ Procedure: Executing a File	13-18

## Introduction

---

The PASSTHROUGH selection of the MAIN MENU sets up direct communication with a DACS, bypassing the I-2000. This transparent mode is for DACS maintenance and administrative operations.

Two types of passthrough are supported:

- MULTIPLEXED PASSTHROUGH
- and PASSTHROUGH, also called *full passthrough*.

## Prerequisites

---

Both types of passthrough are available for DACS II and DACS II ISX. Before you can establish either type of passthrough to a DACS, you must:

1. `CREATE` the DACS under FRAME ADMINISTRATION, described in Chapter 3, "System Administration."
2. For multiplexed passthrough, `RESTORE` the DACS. The DACS must be in service and communicating with the I-2000 for a multiplexed passthrough session to be established.
3. For full passthrough:
  - On a SNIDER connection, `RESTORE` the DACS. The DACS must be in service and communicating with the I-2000.
  - With an X.25 link, the DACS may be in service or out of service.

## **Passthrough**

---

### **Passthrough through X.25**

---

When you `RESTORE` a DACS with an X.25 link, a SVC connection is established from the I-2000 to the DACS. A successful `RESTORE` results in a **Site Status** of `IS P`.

For Multiplexed Passthrough, the passthrough session shares the same SVC used by the I-2000 for communicating to the DACS. The DACS must be in service and communicating with the I-2000. The Multiplexed Passthrough session may be used to observe messages being received from the DACS and processed by the I-2000.

For Full Passthrough, the passthrough session sets up a new SVC connection to the DACS, which is separate from that being used for I-2000 communications. If no more SVC connections are available, a request to open a full passthrough session to the DACS is denied.

The DACS may be in service or out of service when you start a full passthrough session.

### **Passthrough through SNIDER**

---

Multiplexed Passthrough and Full Passthrough are also supported on a SNIDER-based connection.

For Multiplexed Passthrough, the DACS must be in service and communicating with the I-2000. The passthrough session and the I-2000 user share the same SNIDER connection to the DACS. The Multiplexed Passthrough session may be used to observe messages being received from the DACS and processed by the I-2000.

For a Full Passthrough session to be established through an asynchronous SNIDER connection, the DACS must be in service and communicating to the I-2000. The Full Passthrough session will take over the link to the DACS and no other commands from the I-2000 user interface will be allowed. However, echoed responses and alarms will continue to be processed.

## **Multiplexed Passthrough**

---

This type of passthrough lets you communicate directly with the DACS in a multiplexed mode, sharing the link with others. It allows simultaneous access by all operators to a DACS over either a SNIDER link or a single X.25 SVC.

The I-2000 supports these MULTIPLEXED PASSTHROUGH functions:

- Simultaneous passthrough sessions for each logged-in user on any DACS that is in service
- Command processing via the forms interface simultaneously with any active passthrough sessions
- Automatic termination of idle passthrough sessions

- Multiplexing of passthrough sessions onto a single communications circuit (SVC for X.25 or link for SNIDER) with the forms command processing interface for any DACS
- Aborting a session.

The MULTIPLEXED PASSTHROUGH capability does not use an entire communication link with a DACS just for the passthrough functions. Moreover, as far as is possible, it provides the same kinds of functionality as does full PASSTHROUGH.

The following constraints apply to MULTIPLEXED PASSTHROUGH:

- Do not use the ? help mode on the DACS.
- Do not use interactive commands to the DACS; for example, commands to log on to the DACS, or to edit macros and maps. If you inadvertently enter an interactive command, access to the DACS is temporarily suspended, until the DACS times out.
- You cannot enter a multiplexed passthrough session if a full passthrough session is active.




**NOTE:**

The link to the DACS must be set for MML.

**Procedure: Entering a Multiplexed Passthrough**


To enter a multiplexed passthrough, follow these steps:

1. Select PASSTHROUGH from the MAIN MENU. The PASSTHROUGH Choices pop-up menu is displayed, as shown in Figure 13-1.




**Figure 13-1. PASSTHROUGH Choices Menu**

2. Select MULTIPLEXED PASSTHROUGH. The WHICH DACS? pop-up menu is displayed.
3. Select the DACS. The Output Choices? menu appears. These selections describe the types of output messages that are displayed on the PASSTHROUGH screen, as shown in Figure 13-2.



**Figure 13-2. Output Choices Menu for MULTIPLEXED PASSTHROUGH**

4. Select the desired choice of output. The MULTIPLEXED PASSTHROUGH form is displayed, as shown in Figure 13-3.



**Figure 13-3. MULTIPLEXED PASSTHROUGH Screen**

5. To leave MULTIPLEXED PASSTHROUGH, press **EXIT**. You are immediately returned to the main menu.

The I-2000 returns control of the terminal to you if it waits longer than a default of **COMMAND\_TIMEOUT** seconds for the response to a command. **COMMAND\_TIMEOUT** defaults to 60 seconds. The I-2000 ends the multiplexed passthrough session autonomously and returns you to the previous menu if the session remains idle for more than **SESSION\_TIMEOUT** hours. **SESSION\_TIMEOUT** defaults to eight hours. (See Chapter 2 for the procedure to update the **COMMAND\_TIMEOUT** and **SESSION\_TIMEOUT** environment variables.)

## Full Passthrough

---

This type of passthrough lets you communicate directly with the DACS, but does not allow other users to share the link. Select this type when you must enter interactive commands to the DACS; for example, commands that require DACS login.

Constraints on the use of full PASSTHROUGH are stated more fully as follows. Note that they apply only to this type of PASSTHROUGH.

- If the DACS was connected to the I-2000 in a direct configuration during installation, and a **Protocol** of `SNIDER` was specified during frame administration, entry of full PASSTHROUGH by one user restricts I-2000 access to the DACS: no other I-2000 users can send commands to it. An attempt to do so results in a message:

PASS THROUGH IS IN PROGRESS

- If a DACS is connected to the I-2000, whether the link protocol is `SNIDER` or `X.25`, you cannot start both a multiplexed passthrough session and a full passthrough session to the same DACS.
- The system administrator has priority for PASSTHROUGH. If an operator is in the passthrough mode, the system administrator can terminate that relationship instantly with the PASSTHROUGH ABORT selection from the MAIN MENU. A pop-up box prompts `WHICH USERS?` Select the user(s) from the list given. A successful PASSTHROUGH ABORT results in the message:

PASS THROUGH IS AVAILABLE

Then the system administrator may enter PASSTHROUGH and, once in, cannot be displaced by I-2000 terminal operators. However, more than one system administrator can be logged in, and any of those can terminate the passthrough session of any other with PASSTHROUGH ABORT.


- Full PASSTHROUGH sessions time out after 15 minutes of idle time.
- If the DACS was connected to the I-2000 as a node on a Packet Data Network (PDN) and a **Protocol** of `X.25` was specified during frame administration, a maximum of six PASSTHROUGH sessions are supported. They require the availability of one Switched Virtual Circuit (SVC) per session.
- If the **Protocol** is `SNIDER`, but you change the link in PASSTHROUGH to communicate in `PDS`, the I-2000 does not automatically reset the DACS to `MML`. Unless you do it manually before leaving PASSTHROUGH, the I-2000 will not be able to communicate with the DACS at all after you leave PASSTHROUGH.
- If during a `SNIDER FULL PASSTHROUGH` session, an alarm triggers an Automatic Reconfiguration Plan, the `SNIDER FULL PASSTHROUGH` session will be aborted and the automatic reconfiguration plan will be executed.

### Procedure: Entering a Full Passthrough

---

To enter full passthrough, follow these steps:

1. Select PASSTHROUGH from the PASSTHROUGH Choices menu. The WHICH DACS? pop-up menu is displayed.
2. Select the DACS. The PASSTHROUGH screen is displayed, as shown in Figure 13-4.



**Figure 13-4. Passthrough Screen**

3. To leave full PASSTHROUGH, press **EXIT**. You are immediately returned to the MAIN MENU.

**NOTE:**  
The **Del** key also exits full PASSTHROUGH, and is quicker when alarm responses are scrolling.

### Using Passthrough Selections

---

In PASSTHROUGH, the I-2000 temporarily stores the last 120 lines of screen display in a special area called a screen buffer. The display includes both the commands you type and the DACS' responses to them. The screen displays 18 of those lines at any time.

In MULTIPLEXED PASSTHROUGH, the command remains on the screen. The I-2000 saves the last 120 lines of DACS responses also. The screen displays 14 lines at a time.

The 14 or 18 lines are, therefore, a “window” to the 120 screen buffer lines. You may move, or scroll, the window up and down through the buffer by means of the function keys. However, a different set of function keys is valid for each type of passthrough.

### Passthrough Control Keys

Table 13-1 describes the control keys used for full passthrough and Table 13-2 describes the control keys for multiplexed passthrough.

**Table 13-1. Full PASSTROUGH Control Keys**

<p>(F1)                      LINE UP                      Ctrl (u)</p>	<p>Scroll up (backward) one line.</p>
<p>(F2)                      LINE DOWN                      Ctrl (d)</p>	<p>Scroll down (forward) one line.</p>
<p>(F3)                      PAGE UP                      Ctrl (b)</p>	<p>Scroll up (backward) a full page.</p>
<p>(F4)                      PAGE DOWN                      Ctrl (f)</p>	<p>Scroll down (forward) a full page.</p>
<p>(F5)                      TOP                      Ctrl (t)</p>	<p>Go to top of first page.</p>
<p>(F6)                      BOTTOM                      Ctrl (l)</p>	<p>Go to top of last page.</p>
<p>(F7)                      HOME                      Ctrl (I)</p>	<p>Go back to last-displayed line.</p>
<p>(F8)                      EXIT                      Ctrl (e)</p>	<p>Exit.</p>

**Table 13-2. MULTIPLEXED PASSTHROUGH Control Keys**

LINE UP	Scroll up (backward) one line.
LINE DOWN	Scroll down (forward) one line.
PAGE UP	Scroll up (backward) a full page.
PAGE DOWN	Scroll down (forward) a full page.
TOP	Go to top of first page.
BOTTOM	Go to top of last page.
EXIT	Exit
EXECUTE	Send command to DACS.

If a printer is attached to the I-2000 console monitor, typing **Ctrl** **O** prints the contents of the screen. If no printer is attached, or if an error is encountered during the screen dump, the screen flashes and the terminal beeps once.


### **Procedure: Terminating Passthrough**

---

To terminate the passthrough session of another user, you must be logged in as a system administrator.

To terminate a passthrough, follow these steps:

1. Select PASSTHROUGH ABORT from the MAIN MENU. A window is displayed, as shown in Figure 13-5, showing the names of the DACSs used in passthrough and the terminals using them.



**Figure 13-5. Passthrough Form**

2. Use **SELECT** to select the sessions to be terminated.
3. Press **ENTER**. The selected passthrough sessions are cancelled.

## **Frame Command Script**

---

The FRAME COMMAND SCRIPT Option allows you to create a script file of MML commands in the I-2000 COMMON database for the DACS. You may execute the script in the background, write it on DOS diskette, edit it, delete it, or read it from DOS diskette. The maximum number of script files per I-2000 is 100.

Database backup and restore include the script files with the other COMMON files. Manual execution of an RP and a script are mutually exclusive.

The last executed script log remains and can be viewed under REPORT OPERATIONS.

Some rules governing script content and allowed characters are as follows.

- The script language must be MML.
- Lines beginning with the # character are comment lines. They will not be sent to the DACS or logged in the log file.
- Only printable characters, except “|” are allowed.
- Command lines in the script may not contain the characters ? or !, or have any data following the command termination character ;
- Empty lines are not allowed.
- The maximum length of a script line is 120 characters; the maximum file size, 150 lines.
- The login DAX command,

```
LGN-USER : : : : DAX
```

is the only multi-line command supported by the FRAME COMMAND SCRIPT option.



**NOTE:**

You must have changed the DAX user login to MML before executing the script containing the login DAX command.

### **FRAME COMMAND SCRIPT Form**

---

To obtain the FRAME COMMAND SCRIPT option, select PASSTHROUGH from the MAIN MENU and then FRAME COMMAND SCRIPT from the PASSTHROUGH Choices insert. The FRAME COMMAND SCRIPT form is displayed, as shown in Figure 13-6.

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II  
Status:  
Alarms:

————— FRAME COMMAND SCRIPT —————

Action:                    Script Name:                    Site Name:  
                                  DAX Login Password:  
  
Line:

HELP CHOICES    QUIT    TOP MENU UNSELECT SELECT

---

**Figure 13-6. FRAME COMMAND SCRIPT Form**

The specific fields that appear on the form depend on the **Action**. For an **Action** of `EDIT`, **Mode** replaces **Site Name**.

## Field Descriptions

Table 13-3 describes the field values for the FRAME COMMAND SCRIPT form.

**Table 13-3. FRAME COMMAND SCRIPT Field Descriptions**

<b>Action</b>	<p>The FRAME COMMAND SCRIPT actions are:</p> <p><b>EDIT</b> Opens the file of the given <b>Script Name</b> and displays 13 screen lines. You may specify the type of edit with the <b>Mode</b> field, and the line to be edited with the <b>Line</b> field.</p> <p><b>DELETE</b> Displays the first 13 screen lines of the <b>Script Name</b> file. On your pressing <input type="button" value="EXECUTE"/>, the I-2000 deletes the file.</p> <p><b>DOSREAD</b> Reads a DOS diskette on which you have previously stored script files in the root directory. The I-2000 has automatically supplied a suffix of SCR.</p> <p><b>DOSWRITE</b> Writes selected script files to DOS diskette.</p> <p><b>EXECUTE</b> Executes the specified script.</p> <p><b>ABORT</b> Terminates executing a script for a site.</p>
<b>Script Name</b>	1-8 alphanumeric characters. The name of the script file to which the <b>Action</b> is to apply. The I-2000 converts lower to upper case.
<b>Site Name</b>	The name of the site where the script file is to be executed or aborted.
<b>Mode</b>	<p>Appears for an <b>Action</b> of <b>EDIT</b> only.</p> <p><b>Insert</b> On <input type="button" value="EXECUTE"/> of this <b>EDIT</b>, insert the <b>Line</b> into the <b>Script Name</b> file. You are presumed to have finished typing the line.</p> <p><b>Change</b> On <input type="button" value="EXECUTE"/> of this <b>EDIT</b>, replace the <b>Line</b> with the one displayed. You are presumed to have finished changing it.</p> <p>To delete a line, simply <b>Change</b> its contents to no value.</p>
<b>DAX Login Password</b>	<p>Appears only after an <b>Action</b> of <b>EXECUTE</b> when the <b>Script Name</b> file contains the command:</p> <p>LGN-USER::::DAX</p> <p>The password necessary to gain admission to the DACS referenced by <b>Site Name</b>.</p>

**Table 13-3. FRAME COMMAND SCRIPT Field Descriptions (Contd)**

<b>Line</b>	Appears only for an <b>Action</b> of <code>EDIT</code> . The line number being referenced of the <b>Script Name</b> file.
-------------	---

**Procedure: Creating a Script File**

To create a script file, follow these steps:

1. Enter the following fields:

- **Action**: `EDIT`  
Additional fields appear.
- **Script Name**: name
- **Mode**: `INSERT`
- **Line**: 001

The cursor moves to a highlighted area, where the line is to be typed.

2. Type the line. Note that the entire space is reserved only for the line specified by **Line**. When you have finished, press `ENTER` twice. The line you have typed appear on the screen below. The cursor returns to **Action**. The **Line** is incremented by 1.

**NOTE:**

Instead of hitting `ENTER` twice, you may want to use `Ctrl` `P` to terminate a line and place the cursor at the **Line** field.

3. Move the cursor to the highlighted area for typing the next line, type the line, and press `ENTER` twice. Repeat this procedure for as many lines as you care to enter.

Some line editing rules are as follows:

- The space bar and any other character push the text to the right.
- `BACKSPACE` moves the cursor to the left, erasing what was there.
- `←` moves the cursor to the left over the text that was there, leaving it intact.
- There is room for two screen lines in the highlighted region. However, they are only one script line. One `ENTER` move the cursor to the start of the second screen line. The only way back to the first screen line is by backspacing.
- To correct a line, change the **Mode** to `CHANGE` and specify the **Line** to be changed. The line is displayed and can be accessed in the highlighted area.
- To delete a line, `CHANGE` it to all blanks.

- To insert a line, change **Mode** to `INSERT` and enter the **Line** that the new line will have when it will have been inserted. The current line of that number appears in the highlighted area. Blank it out first, and then retype. Blanking out in this case has no effect on the line. On your pressing `ENTER` twice, the typed line will be inserted at the specified location and subsequent lines, including the line formerly at **Line**, will be incremented by 1.
4. When you are ready to accept the file, press `EXECUTE` and confirm.
- The I-2000 adds the terminating `;` character, and the minimum required number of `:` characters, where needed. The I-2000 overrides the control tag sequence number field:
- ```
:ww
```
- in order to track the command line. The I-2000 adds the logout DAX command:

```
LGT-USER: : : :DAX
```

at the end of the script file, if the script would end with login DAX in effect. When the script has been stored in the I-2000's database, the message is displayed:

  - `The command completed successfully`


5. You can recall the script by entering and `EDIT` **Action** and the **Script Name**. To delete the script, use an **Action** of `DELETE`.

### **Procedure: Writing a File to DOS Diskette**

---

To write a file on DOS diskette, follow these steps:

1. Insert the diskette into the disk drive.
2. Enter the following fields:
  - **Action**: `DOSWRITE` A screen similar to Figure 13-7 is displayed.



**Figure 13-7. FRAME COMMAND SCRIPT Screen**

- Using the arrow keys, position the cursor at the name you wish to select and press **SELECT**. Repeat this step as often as is necessary to select the files to be written on the DOS diskette. As you select each, a dash appears before it. Use **UNSELECT** to change your mind, and **SEL\_ALL** to select all.
- When you have finished, press **ENTER**. The cursor returns to the original FRAME COMMAND SCRIPT screen.



**NOTE:**

Press **ENTER** only once, and wait. The system may be a little slow, depending on the level of activity. If you continue to press **ENTER**, you will miss some screens.

- When you are ready, press **EXECUTE** and confirm. The I-2000 displays a message, working on: name, while it writes the file, and The command is finished when all the files have been written.



**NOTE:**

The file names displayed before you selected them were compiled from both the I-2000 and the DOS diskette. Names in both places are marked with a suffixed \*. When you **EXECUTE** a write, if you have selected a \*-name, the file on diskette is overwritten by the file on the I-2000.

### **Procedure: Reading a File From DOS Diskette**

---

To read a file from DOS diskette follow, these steps:

1. Enter the following fields: **Action** : DOSREAD

A screen similar to the one for a DOSWRITE appears.

2. Using the arrow keys, position the cursor at the name you wish to select and press **SELECT**. Repeat this step as often as is necessary to select the files to be read to the I-2000. As you select each, a dash appears before it. Use **UNSELECT** to change your mind, and **SEL\_ALL** to select all.
3. When you have finished, press **ENTER**. The cursor returns to the original FRAME COMMAND SCRIPT screen.



**NOTE:**

Press **ENTER** only once, and wait. The system may be a little slow, depending on the level of activity. If you continue to press **ENTER**, you will miss some screens.

4. When you are ready, press **EXECUTE** and confirm. The I-2000 displays a message, *working on: name*, while it reads the file, and *The command is finished* when all the files have been read.



**NOTE:**

The file names displayed before you selected them were compiled from both the I-2000 and the DOS diskette. Names in both places are marked with a suffixed \*. When you **EXECUTE** a read, if you have selected a \*-name, the file in the I-2000 is overwritten by the file on the DOS diskette.

### **Procedure: Executing a File**

---

To execute a file, follow these steps:

1. Enter the following fields:

— **Action** : EXECUTE

— **Script Name**: name

The contents of name are displayed.

— **Site Name**: the site where the script is to run.

2. Press **EXECUTE** and confirm. A COMMAND RESPONSE window notifies you that The command will be executed in background.

3. Acknowledge the notification.

The password for the login DAX command is interactive only. The execution of a script file with the login DAX command causes the **DAX Login Password** field to appear.

4. Fill in the password. If the login succeeds, the script goes on executing. If the login fails, the script aborts.

When the I-2000 has finished running the script, it displays a **Status** message:

```
Script name name is completed for site site.
```

---

**Contents**

|                                                   |       |
|---------------------------------------------------|-------|
| <b>Introduction</b>                               | 14-1  |
| <b>REPORT OPERATIONS Menu</b>                     | 14-2  |
| ■ Procedure: Generating Reports                   | 14-2  |
| ■ Procedure: Displaying and Printing Reports      | 14-4  |
| ■ Procedure: Transferring Reports To DOS Diskette | 14-4  |
| Field Descriptions                                | 14-5  |
| <b>Report Categories</b>                          | 14-6  |
| ■ CIRCUITS                                        | 14-6  |
| ■ NPCS                                            | 14-7  |
| ■ CHANNELS                                        | 14-7  |
| ■ OUTAGES                                         | 14-7  |
| ■ ALTROUTES/PREEMPTIONS                           | 14-8  |
| ■ TEST PORT                                       | 14-8  |
| ■ TEST ACCESS                                     | 14-8  |
| ■ FRAMES/LINKS                                    | 14-9  |
| ■ USER ADMINISTRATION                             | 14-9  |
| ■ NPC ALARMS                                      | 14-9  |
| ■ CIRCUIT ALARMS                                  | 14-9  |
| ■ ALARM LOG                                       | 14-10 |
| ■ AUDIT/SYNCHRONIZATION RESULTS                   | 14-10 |
| ■ NPC ROLL RESULTS                                | 14-10 |
| ■ ECHOED RESPONSE PROCESSING                      | 14-10 |
| ■ TASK SCHEDULE LIST                              | 14-10 |
| ■ TASK SCHEDULE RESULTS                           | 14-10 |
| ■ LOST RESPONSE LOG                               | 14-11 |
| ■ HISTORY LOG                                     | 14-11 |

---

## Contents

|                                               |       |
|-----------------------------------------------|-------|
| ■ SCRIPT LOG                                  | 14-11 |
| ■ RECONFIGURATION SUB-MENU                    | 14-11 |
| RECONFIGURATION PLANS                         | 14-12 |
| RECONFIGURATION PLAN ALTROUTE                 | 14-12 |
| RECONFIGURATION PLAN RESULTS                  | 14-13 |
| AUTOMATIC RECONFIGURATION PLAN RESULTS        | 14-13 |
| ■ AUTOMATIC RECONFIGURATION PLANS             | 14-13 |
| ■ COMMON EQUIPMENT ALARMS                     | 14-13 |
| ■ 24-HOUR PERFORMANCE STATISTICS              | 14-13 |
| ■ 24-HOUR PM Log                              | 14-14 |
| ■ ESTABLISHED DS0 CHANNELS                    | 14-14 |
| ■ SUBRATE CIRCUITS                            | 14-14 |
| <b>Custom Report Formats</b>                  | 14-14 |
| ■ Edit Screen and Fields                      | 14-14 |
| Field Descriptions                            | 14-16 |
| ■ Procedure: Creating a New Report Format     | 14-17 |
| ■ Procedure: Modifying a Report Format        | 14-19 |
| ■ Procedure: Renaming a Report Format         | 14-19 |
| ■ Procedure: Deleting a Report Format         | 14-19 |
| ■ Alarm Query                                 | 14-20 |
| ■ Procedure: Generating an Alarm Query Report | 14-21 |

### Introduction

The REPORT OPERATIONS MENU allows you to generate reports containing data from the I-2000 database. The reports can be displayed on screen, printed or written to a DOS diskette. The DOS diskette option presumes you will access the diskette from a DOS system. No provision is made for recovering the report from the diskette in the I-2000.

When you generate a report, the I-2000 extracts data from the database and prepares it to be displayed or printed. The generated data is saved in a file. One such file is maintained for each I-2000 user. It contains the data for the report most recently generated.

When generating a report, you are allowed to specify search criteria for the records that are to be extracted from the I-2000 database. The search criteria restrict the report to records that have certain values in certain fields.

You may also create and edit custom formats. A custom format allows you to specify which data items will be shown in the report and the way in which those items will be arranged. Several pre-defined formats are supplied with the I-2000. You may select any of them or create formats of your own, which then appear as format selections. Several fixed formats are also supplied that cannot be customized, for example, it is not possible to modify or customize the AUDIT/ SYNCHRONIZATION RESULTS report.

It is also possible to backup the customized report formats to a diskette (see Chapter 8) and to restore customized reports from a diskette.

All reports can be displayed on the user-terminal screen, printed on the I-2000 printer, or written to a DOS diskette. Displayed reports are paged (divided into screen-sized segments).

You can move through the report using **TOPPAGE**, **LASTPAGE**, **NEXTPAGE**, and **PREVPAGE**, or by entering the page number in the **Display Page** field. Reports sent to the printer are also paged, but with a different page size than is used on the screen.

## REPORT OPERATIONS Menu

Select REPORT OPERATIONS from the MAIN MENU. The REPORT OPERATIONS MENU is displayed, as shown in Figure 14-1.

```

06:15 01 Nov 1997  I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- REPORT OPERATIONS MENU -----
-CIRCUITS                TASK SCHEDULE LIST
NPCS                     TASK SCHEDULE RESULTS
CHANNELS                 LOST RESPONSE LOG
ALTROUTES/PREEMPTIONS   HISTORY LOG
OUTAGES                  SCRIPT LOG
TEST PORT                DISPLAY LAST GENERATED REPORT
TEST ACCESS              EDIT CUSTOM REPORT FORMAT
FRAMES/LINKS             ALARM QUERY
USER ADMINISTRATION     DISPLAY ALARM QUERY
NPC ALARMS               RECONFIGURATION SUB-MENU
CIRCUIT ALARMS          ESTABLISHED DSO CHANNELS
ALARM LOG                SUBRATE CIRCUITS
AUDIT/SYNCHRONIZATION RESULTS COMMON EQUIPMENT ALARMS
NPC ROLL RESULTS         24-HOUR PERFORMANCE
ECHOED RESPONSE PROCESSING 24-HOUR PM LOG

Press ENTER to specify report search criteria

HELP  [ ] [ ] [ ] QUIT [ ] TOP MENU PRINT [ ]

```

Figure 14-1. REPORT OPERATIONS MENU

### Procedure: Generating Reports

To generate a report, follow these steps:

1. Select the data category on the REPORT OPERATIONS MENU.
2. If the selected category has more than one available format menu, a pop-up window is displayed listing the format names. Select the format.
3. For all categories except the HISTORY LOG, a SEARCH CRITERIA form appears displaying the fields for the selected category. Enter values into these fields to find the records that match. If you leave all fields blank, all records in the database are reported.

For example, in a CHANNEL USAGE report (under CHANNELS) to limit for a single NPC, enter a specific **NPC ID**, or a hierarchical or extended number. If you want a report of the NPCs and channels involved in a particular circuit, enter the circuit name in the **Used by Circuit ID** field.

To list all spare or unused channels, enter the value **NULL** in the **Status** field. If you want a report of all channel usage data for the specified **Site Name**, leave all fields blank. Refer to Figure 14-2.



**NOTE:**

Reports are identified and unique to a user login name. If there is more than one login session on the system with the same login name, one session may view the reports of the other session, and one session may overwrite the reports of the other login session.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- CHANNEL USAGE SEARCH CRITERIA -----
Site Name:DACS00

      Hier      Ext      NPC ID      Ch
NPC:
Status:
Used by Circuit ID:
      TC:      IW:      Termination State:      Class:
      Hier      Ext      NPC ID      Ch
TO NPC:

Enter site name _____
    
```

HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE

**Figure 14-2. CHANNEL USAGE SEARCH CRITERIA Form**

Use wild-card abbreviations (metacharacters) as follows:

- \* stands for any number of any alphanumeric characters (including none) at that position in the string.
- ? stands for a single occurrence of any single character at that position in the string.

For example, AB5\* finds AB544, AB54, AB5, AB55D, etc. ABC?5 finds ABC45, ABCD5, etc., but not ABC or ABC5.

In numeric fields you can enter:

- > number All numbers greater than number.
- < number All numbers less than number.

In a time/date field these values translate to: before (<) or after (>) the time/date given.



**NOTE:**

Search criteria on date/time is taken separately. For example a date of:

> 01 June 1997

and a time of:

> 06:15

may provide unexpected results. Only matches for days after 01 Jun 1997 and times after 06:15 on each day. For example, 03 July 1997 at 01:15 will not match.

4. When you have entered the selection criteria, press **EXECUTE** and answer YES to ARE YOU SURE? A command response window notifies you that the COMMAND WILL BE EXECUTED IN BACKGROUND.
5. Press **Enter** to acknowledge the command response. The REPORT OPERATIONS MENU is displayed, with the cursor at DISPLAY LAST GENERATED REPORT. Report generation will not be complete until a

REPORT IS COMPLETED

message is displayed. You may wait for the completion message and display or print the report (see following section), or proceed to any other I-2000 operation.



**NOTE:**

With large databases, report generation can several minutes.

### **Procedure: Displaying and Printing Reports**

To display or print the most recently generated report, follow these steps:

1. Select DISPLAY LAST GENERATED REPORT or DISPLAY ALARM QUERY from the REPORT OPERATIONS MENU. A pop-up window appears listing the output medium choices. Select SCREEN or PRINTER.
2. If you select SCREEN, the last generated report appears on your terminal screen. Use **NEXTPAGE**, **PREVPAGE**, **TOPPAGE**, and **LASTPAGE** to page through the report or specify a page in the **Display Page** field.

### **Procedure: Transferring Reports To DOS Diskette**

The ALLOWED CHOICES pop-up menu will list DOS DISKETTE as an option when you select the following choices from the REPORT OPERATIONS menu:

- HISTORY LOG
- DISPLAY LAST GENERATED REPORT
- DACS COMMAND SCRIPT LOG
- DISPLAY ALARM QUERY

You can then transfer the report, log or query results to DOS diskette by selecting the DOS DISKETTE option. The REPORT TO DOS DISKETTE form is displayed, as shown in Figure 14-3.

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II  
 Status:  
 Alarms:

REPORT TO DOS DISKETTE

File Name:

Enter the DOS File name

HELP    QUIT    TOP MENU    PRINT    EXECUTE

**Figure 14-3. REPORT TO DOS DISKETTE Form**

**Field Descriptions**

Field descriptions for the REPORT TO DOS DISKETTE form as describes in Table 14-1.

**Table 14-1. REPORT TO DOS DISKETTE Field Descriptions**

|                  |                                                                                                                                                                                                                                            |
|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>File Name</b> | User defined. Mandatory, 1-8 alphanumeric characters, capital letters only. The I-2000 will append the suffix, .Rxx, where xx is the diskette number, starting at 01 and incrementing if multiple diskettes are required to save the file. |
|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## Report Categories

---

This section describes the report categories that are available with the I-2000 system.

### CIRCUITS

---

CIRCUITS provides reports on circuit records. Four default formats are provided. Each concentrates on a different aspect of the information that has been created about the circuit. The data is from information that was entered in the CIRCUIT PROVISIONING form, or placed in the database through ERP or by audit/synchronization.

The SEARCH CRITERIA form is similar to the CIRCUIT PROVISIONING form. You can search for circuits of a given **Status** and other fields given on the form in addition to the ones that will appear in the report.

The four default circuit reports are:

- **CIRCUIT AVAILABILITY**—Concentrates on the availability of the circuits. The service date, circuit priority and status are listed for each Circuit ID, as well as the user informational location A and location Z.
- **CIRCUIT INFORMATION**—Concentrates on the circuit characteristics for each Circuit ID. The report includes trunk conditioning and insertion word.
- **CIRCUIT OPTIONS**—Concentrates on the circuit characteristics specified in options.
- **CIRCUIT CONNECTIONS**—Identifies circuit and end points by Circuit ID. For each cross-connection, the NPC and channel number of the NPC in which it occurs is stated for both the FROM and the TO sides. High-rate and multipoint circuits are presented as multiple cross-connections.

The report includes circuit priority, status, class, bandwidth and bandwidth type.

## **NPCS**

---

NPCS provides reports on NPC records. Two default formats are provided. Each contains similar information, but the records are sorted on different fields. The data was entered in the NPC PROVISIONING form, or placed in the database through ERP or audit/synchronization.

The SEARCH CRITERIA form is similar to the NPC PROVISIONING forms. You can specify search criteria for fields that do not appear on the report. Moreover, you can use search criteria in the status fields, which are not accessible on the NPC PROVISIONING form.

The two default NPC reports are:

- **NPC NUMBERS**—Contains records that are sorted by hierarchical NPC number. Alarm and service state information is included. The entries are sorted by NPC ID.
- **NPC IDS**—Contains a record of NPCs that are in the database. The NPC ID and various information, such as the type and status are included. The report lines are sorted by NPC ID

## **CHANNELS**

---

CHANNELS provides reports on channel usage data. One default format is provided for channel usage.

- **CHANNEL USAGE**—This format lists the use of each channel within each facility NPC that has been equipped.

The information in this report is taken from both NPC and circuit data. On the SEARCH CRITERIA form, you can select by NPC, circuit or connecting NPC.



**NOTE:**

Entering NULL in the **Status** field of the SELECTION CRITERIA form for this category selects channels which are not in use.



**NOTE:**

A full CHANNELS report takes some time to generate, since the I-2000 must check every channel of every NPC. It is suggested you limit the search to one or a few NPCs.

## **OUTAGES**

---

OUTAGES provides reports on outage data records. One default format is provided. The SEARCH CRITERIA form permits searching of log entries by type, record, number, NPC or circuit ID, and time or date in or out.

- **OUTAGE INFORMATION**—This report is a printed version of the OUTAGE LOG.

## **ALTROUTES/PREEMPTIONS**

---

ALTROUTES/PREEMPTIONS provides reports on ALTROUTED and/or PREEMPTED circuits. Two default formats are provided. The fields that appear in the reports contain information that was entered in the CIRCUIT PROVISIONING form, and its second page, the ALTROUTE form (Chapter 7).

The SEARCH CRITERIA form allows you to select by circuit ID of the ALTROUTED circuits, circuit characteristics, end point NPC and channel number, and PREEMPTED circuit identifiers.

- **ALTROUTED CIRCUITS**—Identifies circuits in ALTROUTED **Status**. One line lists the ALTROUTED circuit ID and identifies one end point of the ALTROUTED circuit. The normal hierarchical number and channel is listed along with the ALTROUTED hierarchical number and channel.

One two-point circuit is thus identified by two report lines, one for each point. A multipoint circuit results in more than two report lines. Note that NPC and its channel will not be different from the altrouted NPC and its channel if that point was not changed.

- **PREEMPTED CIRCUITS**—Identifies the PREEMPTED circuits and the ALTROUTED end points that caused their preemption.

## **TEST PORT**

---

TEST PORT reports on test port and test port group status. Two default formats are provided. The fields that appear in the reports contain information that was entered in the TEST PORT PROVISIONING form (Chapter 5) and in the TEST ACCESS form (Chapter 15).

The SEARCH CRITERIA form permits search by test port or test circuit connection data and characteristics.

- **TEST PORT STATUS**—Lists Test Port and test circuit identifying and status information. The test port number, hierarchical number of its NPC, ID of the circuit under test and type of test connection is stated.
- **TEST PORT PROVISIONING**—Provides identifying information on the test ports and lists conditioning information to be applied to the circuits under test.

## **TEST ACCESS**

---

TEST ACCESS reports on test access status. One default format is provide that lists identifying information for circuits that are under test through either test ports or test groups. The fields that appear in the report contain information that was entered in the TEST ACCESS form.

## **FRAMES/LINKS**

---

FRAMES/LINKS provides reports on information entered during provisioning of frames and also on the links through which communication to the frames is effected. Four default formats are provided. The fields that appear in the reports contain information that was entered in the FRAME ADMINISTRATION and X.25 LINK ADMINISTRATION forms (Chapter 3).

SEARCH CRITERIA form allows you to search by both frame and link characteristics.

- **FRAME CONTROL**—States the values of various control fields from the FRAME PROVISIONING form.
- **LINK CONNECTIVITY**—Lists information for primary and backup links that have been connected to a given DACS. If the backup line data is not present, the backup line has not been provisioned.
- **PROVISIONING**—Lists identifying information for the frames that have been provisioned.

## **USER ADMINISTRATION**

---

USER ADMINISTRATION reports user login information. One format is provided for user logins that allows selection on every USER ADMINISTRATION form field. The fields that appear in the report contain information that was entered in the USER ADMINISTRATION form (Chapter 11).

- **USER LOGINS** —Lists **Login name, User Name, Phone, and User Class** for each login.
- **USER CONNECTIVITY**—Lists **Login name, User Name, Type, and User Class** for each login.

## **NPC ALARMS**

---

This report states the values of various fields for NPC alarms. The fields appear mainly on the NPC PROVISIONING form. One format is provided for ALARMS that identifies the NPC and lists **Service State, Alarm State and Alarm Aging** information.

## **CIRCUIT ALARMS**

---

This report states the values of various fields for circuits that have as an end point an NPC in alarm. The fields appear mainly on the CIRCUIT PROVISIONING form. One format is provided for alarms that identifies the NPC and channel information of the circuit in alarm.

## ALARM LOG

---

This is a custom report. The ALARM LOG reports all alarms received by the I-2000. The selection criterion is by **Site Name**. For an example and explanation of the report, refer to Chapter 3 "System Administration."



**NOTE:**

[Ctrl] + [a] provides access from any screen to the Alarm Log and customized alarm reports.

## AUDIT/SYNCHRONIZATION RESULTS

---

This report lists discrepancies found between the I-2000 and DACS databases during the most recent database audit/synchronization operation. The selection criteria comprise **Site Name, Action, NPC Hier, Ext, ID, Date, and Time**.

Use of the SEARCH CRITERIA form parallels use of the DATABASE AUDIT/SYNCHRONIZATION form. You need to enter the same **Action** and range in the SEARCH CRITERIA form as you did on the AUDIT/SYNCHRONIZATION form in order to obtain only the data of interest.

## NPC ROLL RESULTS

---

This report lists the results of NPC rolls. The circuit IDs of rolled circuits, as well as their statuses, are included. The selection criteria are the NPC identifiers.

## ECHOED RESPONSE PROCESSING

---

The ECHOED RESPONSE PROCESSING Report lists messages that are received by the I-2000, and were initiated by a DACS independently; for example, they report changes in provisioning that were not in response to user requests through the I-2000.

The SEARCH CRITERIA form allows you to search by type of message, date and time. The DACS is a mandatory entry.

## TASK SCHEDULE LIST

---

The TASK SCHEDULE LIST is a list of all I-2000 tasks scheduled to be executed. Selection criteria are **Site Name** and **User ID**.

## TASK SCHEDULE RESULTS

---

The TASK SCHEDULE RESULTS report is a list of all scheduled tasks that were executed, along with the results of the execution.

## **LOST RESPONSE LOG**

---

Although listed as a REPORT OPERATIONS MENU option on every system, the lost response log only contains data if your I-2000 system interfaces to the Event Management System. The lost responses that get logged originate with the I-2000 in reply to network traffic. However, for some reason they cannot now be returned to the upstream network controller.

The Request field on the report represents the originator of the request, and can be FRAME, NPC or CIRCUIT. The Reason field is truncated to 31 characters, due to space considerations.

## **HISTORY LOG**

---

The HISTORY LOG does not have to be generated each time it is displayed or printed. It lists messages exactly as they were sent to the I-2000 from the DACS, in chronological order. The only selection criterion is **Site Name**.

In general, RTRV type messages that are the response to audit/sync operations are not logged in the HISTORY LOG. Exceptions are commands executed in MULTIPLEX PASSTHROUGH, FULL PASSTHROUGH, or those executed on a SNIDER link.

## **SCRIPT LOG**

---

A frame command SCRIPT LOG lists the contents of one user script file of DACS commands.

## **RECONFIGURATION SUB-MENU**

---

The RECONFIGURATION SUB-MENU provides access to reports for Reconfiguration plans and Altroute plans.

Choose RECONFIGURATION SUB-MENU from the REPORT OPERATION MENU. The RECONFIGURATION SUB-MENU is displayed, as shown in Figure 14-4.




Figure 14-4. RECONFIGURATION SUB-MENU

## RECONFIGURATION PLANS

RECONFIGURATION PLANS reports on the contents of reconfiguration plans. One default format is provided. The fields that appear in the report contain information that was entered in the RECONFIGURATION PLAN PROVISIONING screen (Chapter 8).

SEARCH CRITERIA form allows you to select by circuit state as well as by the fields listed on the report.

- **PLAN CONTENTS**—Lists the circuits and actions for the items of a reconfiguration plan.

## RECONFIGURATION PLAN ALTROUTE

RECONFIGURATION PLAN ALTROUTE provides reports on the altroutes and preemptions contained in a reconfiguration plan. Two default formats are provided. The fields that appear in the reports contain information that was entered in the RECONFIGURATION PLAN PROVISIONING form (Chapter 8).

The SEARCH CRITERIA form permits you to select by RP identifying data, or by ALTROUTED or PREEMPTED circuit identifiers.

- **PLAN ALTROUTED CIRCUITS**—Lists the ALTROUTED circuit ID for ALTROUTE action items in a reconfiguration plan. One line is reported for each end point.

- **PLAN PREEMPTED CIRCUITS**—Lists the `PREEMPTED` circuit ID for circuits preempted by the `ALTRROUTE` action items in a reconfiguration plan. One line is reported for each end point.

### **RECONFIGURATION PLAN RESULTS**

This fixed format report gives the results of the latest execution of a reconfiguration plan (**RP Action** of `ACTIVATE`, `CHECK`, or `IDLE`). It includes one entry for each step in the plan showing either successful completion or what type of conflict occurred, and an indication of what the last plan action was. Selection criteria include plan name and sorting field.

The plan is available sorted by sequence number (`Seq`) or by circuit priority (`CP`).

### **AUTOMATIC RECONFIGURATION PLAN RESULTS**

This report gives the results of the latest execution of an ARP. It includes one entry for each RP in the plan. The RP status indicates whether an RP was executed. The plan is available sorted by sequence number (`Seq`) or by reconfiguration plan ID (`RP_ID`).

### **AUTOMATIC RECONFIGURATION PLANS**

---

**AUTOMATIC RECONFIGURATION PLANS** reports the contents of the two list types, **RP LISTS** and **NPC LISTS**. The fields that appear in the reports were entered in the **AUTOMATIC RECONFIGURATION PROVISIONING** form (Chapter 8).

The **SEARCH CRITERIA** form allows searching by site, plan, ARP Status, date and time.

- **RP LISTS**—Reports the RPs listed in the ARP. The execution status of the ARP and the location at which the RP will execute are stated
- **NPC LISTS**—Reports the NPCs whose alarm will trigger the ARP. The same information as in **RP LISTS** is reported, except the site identification and hierarchical number of the NPC is substituted for the RP site and identifier.

### **COMMON EQUIPMENT ALARMS**

---

The **COMMON EQUIPMENT ALARMS** is the log of all equipment alarms received at the I-2000 from the DACS.

### **24-HOUR PERFORMANCE STATISTICS**

---

This report allows you to display the 24-Hour Performance Statistics report for all NPCs or a set of NPCs.

## **24-HOUR PM Log**

---

The 24-Hour PM LOG contains information on discrepancies encountered during the processing of the daily 24-Hour PM reports from the DACS II or DACS II ISX.

## **ESTABLISHED DS0 CHANNELS**

---

This report allows you to search for established circuit records.

The SEARCH CRITERIA form allows searching by Circuit ID, Status, From NPC, To NPC, Channel, Type, Standard, Rate and Frame.

## **SUBRATE CIRCUITS**

---

This report allows you to search for subrate circuit records.

The SEARCH CRITERIA form allows searching by Circuit ID, From NPC, From channel, From customer, To NPC, To channel, To customer, Rate and Status.

## **Custom Report Formats**


---

The formats listed in Appendix A are provided with the I-2000 system and will supply most needs, but the user may customize or add to these using the procedures which follow. Once a custom format has been created or modified, it will be listed in the format selection pop-up window, which appears during report generation.

## **Edit Screen and Fields**

---

Choose the EDIT CUSTOM REPORT FORMAT selection on the REPORT OPERATIONS MENU. You are then asked to choose a report format category. The first several categories are shown in Figure 14-5. For a complete list of categories and fields, refer to Appendix A.



**Figure 14-5. Selection of Report Format Category**

After you have chosen, the initial screen is the same in every case, except for the available fields and the title, as shown in Figure 14-6.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:

Action:MODIFY      Report Name:CIRCUIT REMARKS

-----site name-----CIRCUITS-----
Remarks          Circuit_ID

          COLUMN NAME          DATA WIDTH
SELECT  ORDER  SORT  DEFAULT  OPTIONAL  DEF  OPT  COL
X       1      1      Remarks  72      36   72  TOTAL
          Ckt_Status  11      11      WIDTH
X       2      1      Circuit_ID  41      36   78
          Class        3       5
          Customer_Name  12      13
          Location_A    24      24
          Location_Z    24      24
          F_NPC_Hier    5       5

_Enter the desired action_

HELP  SCROLLDN  SCROLLUP  QUIT  TOP MENU  PRINT  EXECUTE
    
```

**Figure 14-6. Sample Edit Custom Report Format Form**

To customize a new report, first **CREATE** it with a **Report Name**, then **MODIFY** the report of that name. You will be adding or removing fields from the report. The range of possible fields will be listed under **COLUMN NAME**. You have simply to select the desired field with an **X**.

**Field Descriptions**

Table 14-2 lists the Report Format field descriptions for creating a custom report format.

**Table 14-2. Edit Custom Report Format Field Descriptions**

|                    |                                                                                                                                                                                                                                   |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Action</b>      | Mandatory. The valid actions are:<br><br>CREATE    Creates an initial report format.<br>DELETE   Deletes an existing format by name.<br>MODIFY   Displays an existing format for editing.<br>RENAME   Renames an existing format. |
| <b>Report Name</b> | Mandatory. 1 through 30 alphanumeric characters. Enter the name of the report you wish to create or otherwise access with the <b>Action</b> .                                                                                     |
| <b>SELECT</b>      | Accessible in <b>MODIFY</b> only, as are the remaining fields of this screen. You can select or deselect display items by inserting or deleting an <b>X</b> in this field.                                                        |

**Table 14-2. Edit Custom Report Format Field Descriptions (Contd)**

|                             |                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ORDER</b>                | Numeric, 1 through the number of Xs marked in the <b>SELECT</b> column. The order in which the item is to appear across the report, from left to right. As you edit this format, a line is displayed across the upper portion of the screen with each column name given in the specified order.                                                                                                    |
| <b>SORT</b>                 | Numeric. The sort order priority of the item. For example, to sort report records first by <b>Circuit ID</b> , and then by <b>Circuit Type</b> , enter a 1 on the line at which <b>Circuit ID</b> is named and a 2 on the line at which <b>Circuit Type</b> is named. You can specify sorting priority down to the eighth level. You must enter Priority 1 first, Priority 2 second, etc.          |
| <b>DEFAULT COLUMN NAME</b>  | 1 through 18 alphanumeric characters. The item names appear as the column names unless you enter an alternative name as the OPTIONAL COLUMN NAME. Use <b>PREVIOUS</b> and <b>NEXT</b> to scroll through the whole listing.                                                                                                                                                                         |
| <b>OPTIONAL COLUMN NAME</b> | 1 through 18 alphanumeric characters. Column names of your own choosing. They replace the default names.                                                                                                                                                                                                                                                                                           |
| <b>DEF DATA WIDTH</b>       | Numeric. The widths of the database items selected. The default is used unless you enter an alternative value under OPTIONAL DATA WIDTH.                                                                                                                                                                                                                                                           |
| <b>OPT DATA WIDTH</b>       | Numeric. Column widths of your own choosing. The data is truncated to these widths, if necessary.                                                                                                                                                                                                                                                                                                  |
| <b>COL DATA WIDTH</b>       | Numeric. The width of the column to be displayed as defined by the user actions. If the data exceeds the width of a column, it will appear truncated on the report. The entire entry appears in the database.                                                                                                                                                                                      |
| <b>TOTAL WIDTH</b>          | Numeric. The sum of the column widths with single spacing between columns. This sum automatically changes as you select or deselect data items, or modify the OPTIONAL COLUMN NAME or OPTIONAL DATA WIDTH fields. The maximum width of the report display is 78 characters. If the data exceeds the total width, it will appear truncated on the report. The entire entry appears in the database. |

**Procedure: Creating a New Report Format**

To create a new report format, follow these steps:


1. Select EDIT CUSTOM REPORT FORMAT from the REPORT OPERATIONS MENU. The pop-up menu REPORT FORMAT CATEGORIES is displayed.
2. Select the category for which you want to create a format. A new screen appears with mandatory fields **Action** and **Report Name** highlighted.
3. Enter **CREATE** in the **Action** field.
4. Enter a **Report Name** for the format you are creating.

⇒ **NOTE:**  
 If the sum of the site name, report format category name and report name would exceed 78 characters, which is the width of the screen, then the report format category name is truncated.

5. Press **EXECUTE** and confirm. When the database has been updated, the following message is displayed:

REPORT FORMAT HAS BEEN CREATED

⇒ **NOTE:**  
 If you exit at this point, you have created a default report format with database items taken in the order they appear in the database (for this category) and as many as can fit across the page (78 columns). You can modify this basic format to suit your own needs.



**Figure 14-7. Sample Report Format**

### **Procedure: Modifying a Report Format**

---

To modify an existing report format, follow these steps:

1. Select EDIT CUSTOM REPORT FORMAT from the REPORT OPERATIONS MENU.
2. Select the category for which the format was created. A new screen appears with mandatory fields **Action** and **Report Name** highlighted.
3. Enter `MODIFY` in the **Action** field.
4. Enter the **Report Name**. The screen flashes in the upper right corner:  
`SEARCHING`
5. The lower fields on the screen become active and are filled in with values representing the current state of the format. Change the values in these fields to redesign your format.
6. Press `EXECUTE` and confirm. When the database has been updated, the following message appears:

`REPORT FORMAT HAS BEEN MODIFIED`

### **Procedure: Renaming a Report Format**

---

To rename a report format, follow these steps:

1. Select EDIT CUSTOM REPORT FORMAT from the REPORT OPERATIONS MENU.
2. Select the category for which the format was created. A new screen appears with mandatory fields **Action** and **Report Name** highlighted.
3. Enter `RENAME` in the **Action** field.
4. Enter the **Report Name**.
5. A new field appears, **New Name**. Enter the new report name.
6. Press `EXECUTE` and confirm. When the database has been updated, the following message appears:

`REPORT FORMAT HAS BEEN RENAMED`

### **Procedure: Deleting a Report Format**

---

To delete a report format, follow these steps:

1. Select EDIT CUSTOM REPORT FORMAT from the REPORT OPERATIONS MENU.
2. Select the category for which the format was created. A new screen appears with mandatory fields **Action** and **Report Name** highlighted.
3. Enter `DELETE` in the **Action** field.

4. Enter the **Report Name**.
5. Press **EXECUTE** and confirm. When the database has been updated, the following message is displayed:

REPORT FORMAT HAS BEEN DELETED

## **Alarm Query**

---

This is a fixed-format report, but the format depends on the content. It provides you with an alarm profile for a given DACS. The report contains two classes of information:

- Statistics: totals and subtotals of alarms by category.
- Alarm information specific to objects within the DACS.

The categories of alarms are

- Frame summary alarms, resulting from malfunction of some hardware object within the DACS.
- DS3 facility alarms, reporting on DS3 termination conditions.
- DS3 FTU alarms, reporting on termination conditions of NPCs within the DS3 shelf.
- FTU alarms, reporting on termination conditions of NPCs provided by DDCs and DPCs.
- DSPU alarms, reporting on termination conditions of DSPU NPCs (such as DMB).

Alarm information specific to objects within the DACS are frame summary alarms. The hardware objects that cause frame summary alarms when they malfunction are:

- **DACS II And DACS II ISX Entities**

- Main Controller
- Main Processor
- Communications Interface
- Secondary Service Controller
- Disk
- Tape
- Administrative Links
- Cross-connect Networks
- Clock and Control Interfaces
- Time and Date
- Tape Backup
- Power Converters
- Synchronizers
- Clock Reference Oscillator

Timing Link Interfaces  
Time Slot Interchangers  
Memory Cards  
Timing References

■ **FTU Equipment**

Unit Controller  
FTU Module Interfaces  
Format Converters  
Cross-connect Buffers

■ **DSPU Equipment**

Unit Controller  
Cross-connect Buffers  
DSPU Interface

■ **DS3 Equipment**

Unit Controller  
Formatters  
Facility Line Interface  
Protection Facility Line Interface  
Multiplexers  
Protection Multiplexers  
Multiple Interface Units  
Protection Multiple Interface Unit

**Procedure: Generating an Alarm Query Report**

---

To generate an Alarm Query report, follow these steps:

1. Select it from the REPORT OPERATIONS MENU.
2. Enter the **Site Name** on the ALARM QUERY SEARCH CRITERIA form.
3. Press **EXECUTE** and confirm. Wait for the completion message.
4. To access the report, select DISPLAY ALARM QUERY from the REPORT OPERATIONS MENU.



**NOTE:**

This is the only report not accessed via DISPLAY LAST GENERATED REPORT.

An instance of a ALARM QUERY REPORT follows:

pnfstst-----ALARM QUERY REPORT-----

Alarm Conditions Outstanding:

pnfstst is alarming

Summary of alarm totals for pnfstst:

pnfstst has 1 major alarm(s).

pnfstst has 2 autonomously removed component(s).

Subtotals of frame summary alarms:

1 Major alarms(s).

DACS II Entities:

Cross Connect Network (XC) 1 is in major alarm.

Subtotals for FTU Network Processing Circuit (NPC) Alarm(s):

1 Autonomously removed component(s).

Facility Terminating Unit (FTU) NPC Alarm(s):

Unit 01 module 3 npc 39 (0119) has been autonomously removed.

Unit 01 module 3 npc 40 (0120) has been autonomously removed.

---

**Contents**

|                                                    |       |
|----------------------------------------------------|-------|
| <b>Introduction</b>                                | 15-1  |
| ■ Monitor Test Access                              | 15-2  |
| ■ Monitor Test Access                              | 15-4  |
| ■ The HUB Action                                   | 15-7  |
| ■ The LOOP Action                                  | 15-8  |
| <b>TEST ACCESS Form</b>                            | 15-8  |
| ■ Field Descriptions                               | 15-9  |
| ■ Procedure: Reading the Test State Sequences      | 15-13 |
| <b>Test Access Examples</b>                        | 15-14 |
| ■ Example: Placing a Circuit in MONITOR State      | 15-14 |
| ■ Example: MONITOR of Unmapped Channels            | 15-14 |
| ■ Example: Terminating a Circuit                   | 15-15 |
| ■ Example: Modifying the Status to a SPLIT State   | 15-15 |
| ■ Example: Unterminating a Circuit                 | 15-15 |
| ■ Example: Placing a Test Object into a LOOP State | 15-15 |

### Introduction

---

Test Access provides a capability to connect a test object to an object under test. An object under test is a circuit or an unmapped channel.

Test access is of two types:

- **Test Port (TP)**—The object under test must be a circuit of bandwidth 1 or an unmapped channel. You must provision the test ports and the test port group through the TEST PORT PROVISIONING form, as is discussed in Chapter 5 “Test Port Provisioning.”
- **Test Group (TG)**—The object under test is a circuit of bandwidth  $n \times DS0$ , regardless of whether  $n$  is 1 or more than 1. You also may test unmapped channel(s) using a test group.

In either TP or TG access, you must have connected test equipment to one or more NPCs, which can then become either one or more test port groups or test group NPCs.

In TG access, you identify the NPCs to be used by the test group and supply the number of the first channel to be used in each NPC.

The I-2000 checks the bandwidth of the object under test, provisions the specified NPC(s) as a single test group, and connects the appropriate number of channels to the object under test. When you **RELEASE** the test group, the I-2000 deletes it.

The constraints on TG access are as follows:

- Deletion of the test group after use is automatic; however, if the access is interrupted by a failure, the TG might be left provisioned.
- The test group is created with bandwidth equal to the bandwidth of the object under test.

Typically you enter TEST ACCESS when a transmission problem is discovered in an existing circuit. The **Action** field on the TEST ACCESS form allows you to determine the type of test connection to the problem circuit.

Test access to the following circuits is **not** supported:

- Subrate.
- Clear DS1/E1
- A node in a real or virtual multipoint circuit. However, the EFTs can be tested.

Test Port access to the following circuit is **not** supported:

- BCON

A brief summary of the test connections supported is stated below. More complete descriptions are to be found in the DACS II manuals, such as the *DACS II Reference manual*.

The logical diagrams shown in this section apply to two-way circuits. You can derive the equivalent diagrams for one-way circuits by eliminating the second direction (Rx to Tx) and all the connections to it.



**NOTE:**


The diagrams shown in this section are from an internal point of view. An Rx from an external point of view; for example, a receiving point for line transmission, becomes the Tx for cross-connection within the DACS. This same convention is used consistently throughout this manual.

Figures 15-1 and 15-2 presume a bandwidth of 1. For their  $n \times DS0$  equivalents, imagine that each channel and its connection becomes  $n$  channels and connections.

## **Monitor Test Access**

---

The most common type of access is MONITOR. It allows test equipment to “listen” to an existing circuit without interrupting transmission on the circuit. Signals from the FROM and the TO sides are communicated along their intended route, but are also received at the test object.




**Figure 15-1. Illustration Of Monitor Test Access**

In Figure 15-1, the normal circuit, which is in this case duplex, sends data from the FROM side Tx to the TO side Rx, and from the TO side Tx to the FROM side Rx.

A test connection in **MONITOR Status** joins Channel(s) A and Channel(s) B Rx of the test object to the circuit connection. Normal transmission on the circuit is received at both the TO side Rx and a test object Rx, and at both the FROM side Rx and a test object Rx. If the circuit were half-duplex, only the TO side Rx and the test object Rx would receive.


If *Terminate and leave* is applied to the TO side, the TO Rx receives only the IW signal; for example, traffic is replaced by an insertion word on that side. However, the test object Rx continues to monitor normal traffic on that side.

If you have not entered an **IW** in either the NPC or circuit provisioning forms, the DACS uses its own default; typically, the UMC. An **IW** entered in NPC provisioning takes precedence over the DACS default, and an **IW** entered in circuit provisioning takes precedence over either of those.




**Figure 15-2. Illustration Of Monitor Test Access, TLA Applied in T Direction**

The same may be said of FROM side TLA.



**Figure 15-3. Illustration Of Monitor Test Access, TLA Applied in F Direction**


If TLA is applied to both sides, then no normal traffic is received over the circuit being tested, but the traffic is received at the test object.



**Figure 15-4. Illustration Of Monitor Test Access, TLA Applied in B(oth) Directions**

### Monitor Test Access

In **SPLIT** access, transmission through the object under test is broken and the test signal is inserted at the break.




**Figure 15-5. Illustration Of Split Test Access**

The connection is completed through Channel(s) A by connecting Channel(s) A Tx to the FROM side Rx, and through Channel(s) B by connecting Channel(s) B Tx to the TO side Rx. Moreover, transmission from FROM Tx to TO Rx and from TO Tx to FROM Rx are broken. Although the old circuit still nominally exists, the TO side and the FROM side are both connected to the test object. The TO and FROM sides can transmit to each other only if the test object passes on the transmission externally to the DACS.


The test object both sends and receives. User test equipment can send signals to both the FROM and the TO sides of the object under test simultaneously and independently, simulating the old circuit if such simulation is desired.

If TLA is applied to the TO side, the traffic from the channel(s) B Tx to the TO side Rx is replaced with the IW.




**Figure 15-6. Illustration Of Split Test Access, TLA Applied in T Direction**

If TLA is applied to the FROM side of a circuit being tested in *SPLIT Status*, the return traffic from Channel(s) A Tx to the FROM side Rx is replaced by the IW.



**Figure 15-7. Illustration Of Split Test Access, TLA Applied in F Direction**

If TLA is applied to both sides, there is still traffic from the FROM side Tx to Channel(s) A and from the TO side Tx to Channel(s) B.




**Figure 15-8. Illustration of Split Test Access, TLA Applied in B(oth) Directions**

A test object can connect to channels that are not mapped in a circuit. This use of the TEST ACCESS capability can test channels before they are placed in service on any circuit.

### The HUB Action

---

The **HUB Action** provides a two-way cross-connection between some test object channels and other channels. With this capability, a remote test system in a hub office can have test access to a DACS located in other offices via the hub DACS. The **HUB Action** is, in fact, a way of displacing test objects to remote DACSs.



**Figure 15-9. Illustration Of Hub Test Access**

In Figure 15-9, channels for Test Objects 1 through 4 at the Hub DACS have been connected to a monitoring test system. In the Hub DACS, these channels have been provisioned as test objects and then have been cross-connected with a **HUB Action** to other EFTs, which lead to remote DACSs.

At a remote DACS, the far ends have been provisioned as test objects and may now be cross-connected to objects under test with a **MONITOR Action**. The monitoring is displaced to the test equipment at the hub.

### The LOOP Action

The **LOOP Action** cross-connects a test object to itself. The test system can monitor and test the health of the test object. The channels of the test object are looped to themselves. The NPC and channels are test objects only for the duration of the loop and the test object cannot be used for a **MONITOR** or **SPLIT** while in the **LOOP** state.

### TEST ACCESS Form

Select **TEST ACCESS** from the **MAIN MENU**. The **TEST ACCESS** form is displayed, as shown in Figure 15-10.

```

06:15 01 Nov 1997 I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- TEST ACCESS -----
Site Name:
Action:      Direction:      OOS:      Test State:
Test Object
  Object Type:  Number:  Bandwidth:  TC:  IW:  AtoMU:
                Hier  Ext          NPC ID          Ch
FROM:
TO:
Object Under Test
  Ckt ID:      Termination State:
Channel Connection
  Hier  Ext          NPC ID          Ch
FROM:
TO:
Enter site name (at least 5 characters) _____
HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE
    
```

**Figure 15-10. TEST ACCESS Form**

The **Direction** field only appears for an **Action** of **TERMINATE** or **UNTERMINATE**. The **OOS** field only appears for an **Action** of **RELEASE**. For an **Action** of **LOOP**, the **Object Under Test** information does not appear.

**Field Descriptions**

The field descriptions for the TEST ACCESS form are described in Table 15-1.

**Table 15-1. Test Access Field Descriptions**

|                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Site Name</b> | <p>Mandatory. 1 through 24 characters from the set A-Z, a-z, 0-9, /, _, and -. All other characters are illegal. Blanks are not allowed within a name.</p> <p>The name of the DACS where the requested <b>Action</b> will take place. Pressing [CHOICES] displays WHICH DACS? with a list of the DACS names. These names were established during frame administration, described in Chapter 3 "System Administration."</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Action</b>    | <p>Mandatory. Specifies the TEST ACCESS operation. The valid actions are:</p> <p>MONITOR      Connects an object under test, and any ACTIVE or ALTRouted circuit containing the object under test, to a test object. The test object will receive data from the object under test without disrupting traffic. The <b>Test State</b> field must be RELEASED or SPLIT.</p> <p>SPLIT           Connects both transmit and receive FROM and TO sides of an existing two-way circuit to the test object. The FROM and TO sides can then be tested simultaneously and independently.</p> <p>HUB             Connects a circuit to a test object in such a way that the local DACS is used as a test access concentrator, with the local test object connected to a remote test object on another DACS.</p> <p>TERMINATE    For a test object testing a circuit in the MONITOR or SPLIT mode, replaces the normal signal with the IW signal. The <b>Direction</b> field appears and you must enter a direction, when the <b>Action</b> is TERMINATE or UNTERMINATE .</p> <p>The extent of the replacement depends on the direction selected. You can select a replacement of the signal in the TO direction of the object under test, in the FROM direction or in BOTH directions for a two-way circuit or on all branch LEGS toward facilities for a multi-point circuit. See also under the <b>Direction</b> field.</p> <p>UNTERMINATE   Resumes the normal signal(s) when a TERMINATE has been in effect. As in the case of TERMINATE, the part of the circuit to be affected is specified by the <b>Direction</b> field.</p> |

**Table 15-1. Test Access Field Descriptions (Contd)**

|                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Action (Continued)</b> | <p>RELEASE      Disconnects a test object from an object under test and makes the test object available for reuse. With the OOS option, the test object may be released even if it is out of service.</p> <p>LOOP            Loops channels of a test object so that they can be tested.</p>                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Direction</b>          | <p>The circuit ends for which IW is to be substituted for the normal signal when the <b>TERMINATE Action</b> is requested, or the circuit ends for which normal transmission is to resume when the <b>UNTERMINATE Action</b> is requested. This field only appears when you request a <b>TERMINATE</b> or <b>UNTERMINATE Action</b>. The <b>CHOICES</b> are:</p> <p>F      Replace the signal to the FROM channel with IW.<br/> T      Replace the signal to the TO channel with IW.<br/> B      Replace the signals to the FROM and TO channels with IW.<br/> L      Replace the signals on all branch LEGS toward facilities for a multipoint circuit with IW.</p> |
| <b>OOS</b>                | <p>This field appears for the <b>RELEASE Action</b> only. The values are:</p> <p>Y      Requests DACS to allow the release request to succeed when the test group or test port group NPC or an NPC of the object under test is out of service.<br/> N      Default. Allows DACS to deny the release request if the NPC is out of service.</p>                                                                                                                                                                                                                                                                                                                        |
| <b>Test State</b>         | <p>A display-only field indicating the operating status of the test object connections, as follows:</p> <p>RELEASED    is displayed when the test object is not in use.<br/> MONITOR     is displayed when MONITOR access is in effect.<br/> SPLIT        is displayed when SPLIT access is in effect.<br/> HUB          is displayed when HUB access is in effect.<br/> LOOP         is displayed when LOOP access is in effect.</p> <p>The <b>Test State</b> field reflects the last successful <b>Action</b>.</p>                                                                                                                                                 |
| <b>Object Type</b>        | <p>The type of test object. The valid types of objects are:</p> <p>TP      The object is a test port, and therefore user test port provisioning is required (Chapter 5 Test Port Provisioning).<br/> TG      The object is a test group, which will be automatically provisioned as required for test access.</p>                                                                                                                                                                                                                                                                                                                                                    |

**Table 15-1. Test Access Field Descriptions (Contd)**

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Number</b></p>    | <p>The number of the test object to be used for performing tests. If <b>Object Type</b> is TP, enter the test port number. If <b>Object Type</b> is TG, the I-2000 selects the number by default; however, you may enter a test group number. If the test group was provisioned, the fields corresponding to this number test group are filled in.</p> <p>Test Port The range is 1 through 48 with DACS II generics prior to 6.0 and 1 through 96 with DACS II Generic 6.0 and later and DACS II ISX.</p> <p>Test Group DACS II generics prior to 6.0 and DACS II ISX prior to 1.1 do not support this feature. The range is 1 through 400 with DACS II Generic 6.0 and later, and 1 through 100 for DACS II ISX.</p> |
| <p><b>Bandwidth</b></p> | <p>The bandwidth of the test object. Values are as follows.</p> <p>Test Port Only a value of 1 is allowed. The default is 1.</p> <p>Test Group If the object under test is a mapped circuit, enter nothing. Regardless of what you enter, the bandwidth will be taken from the object under test. If the object under test is an unmapped circuit, enter the desired bandwidth. For valid bandwidths, refer to the <b>Bandwidth</b> field description under CIRCUIT PROVISIONING.</p>                                                                                                                                                                                                                                 |
| <p><b>TC</b></p>        | <p>This field appears for the LOOP, MONITOR, SPLIT and HUB <b>Actions</b> only. Enter the Trunk Conditioning Code that is to apply to the test connection. For valid TC codes, refer to the <b>TC</b> field description under CIRCUIT PROVISIONING.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <p><b>IW</b></p>        | <p>This field complements <b>TC</b>. For valid IW codes, refer to the <b>IW</b> field description under CIRCUIT PROVISIONING.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <p><b>AtoMU</b></p>     | <p>This field appears for the MONITOR, SPLIT and HUB <b>Actions</b> only. The values are:</p> <p>Y Specifies A-law to Mu-law (also called x-law) conversion on a CEPT-type NPC in a Gateway type of test connection; this conversion can apply to the signal coming from either the object under test or from the test object itself.</p> <p>N Default. Disables the A-law to Mu-law conversion.</p>                                                                                                                                                                                                                                                                                                                  |

**Table 15-1. Test Access Field Descriptions (Contd)**

|                                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Test Object FROM Hier</b>                | <p>This and the following three fields are the identifying information of the test object. Their values depend on the test object.</p> <p><b>Test Port</b> Filled in automatically. A blank value means you have not provisioned the test port (Chapter 5 Test Port Provisioning).</p> <p><b>Test Group</b> The hierarchical NPC number of the NPC to be used as the FROM side of the test object. Alternatively, you may enter the extended number or the <b>NPC ID</b>. Whichever you enter, the other two fields are filled in. The NPCs must be in service.</p> |
| <b>Test Object FROM Ext</b>                 | <p>The value depends on the test object type.</p> <p><b>Test Port</b> Filled in automatically.</p> <p><b>Test Group</b> The extended NPC number of the NPC to be used as the FROM side of the test object.</p>                                                                                                                                                                                                                                                                                                                                                      |
| <b>Test Object FROM NPC ID</b>              | <p>The value depends on the test object type.</p> <p><b>Test Port</b> Filled in automatically.</p> <p><b>Test Group</b> The ID of the NPC to be used as the FROM side of the test object.</p>                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Test Object FROM Ch</b>                  | <p>The value depends on the test object type.</p> <p><b>Test Port</b> Filled in automatically.</p> <p><b>Test Group</b> The first channel to be used as the FROM side of the test object. The allocation of channels depends on the <b>Bandwidth</b> and the <b>Bandwidth Type</b> of the object under test. You must insure that the test group has sufficient available channels.</p>                                                                                                                                                                             |
| <b>Test Object TO Hier, Ext, NPC ID, Ch</b> | <p>The same information as for the Test Object FROM side, but referring to the TO side. FROM and TO NPCs may be the same, if the test connection calls for only one; for example, if FROM and TO are only different channels in the same NPC.</p>                                                                                                                                                                                                                                                                                                                   |
| <b>Object Under Test Ckt ID</b>             | <p>The <b>Ckt ID</b> of the circuit to be made an object under test, if you are going to test a circuit. For unmapped channels, leave blank.</p>                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Termination State</b>                    | <p>Information concerning the termination of the object under test.</p> <p>F Terminated in FROM direction.<br/> T Terminated in TO direction.<br/> B Terminated in both directions.<br/> blanks Unterminated in both directions.</p>                                                                                                                                                                                                                                                                                                                                |

**Table 15-1. Test Access Field Descriptions (Contd)**

|                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Channel Connection</b> fields | Identify the object under test. Their values depend on the <b>Object Type</b> and the <b>Action</b> . For the <code>LOOP Action</code> , in which there is no object under test, the fields do not appear. If the object to be tested has been mapped, you can identify it by filling in either the <b>Ckt ID</b> or the lowest numbered FROM or TO channel along with its NPC. The remaining information is automatically filled in. If the object to be tested is an unmapped channel, you must specify the lowest-numbered channel to be tested. |
|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

With the exception of `TERMINATE` and `UNTERMINATE`, a **TEST ACCESS Action** requests a change in the **Test State**. **Test State** values can succeed each other only in a certain order; for example, certain **Actions** succeed only when requested from certain **Test States**. The **Test State** sequences are shown in Table 15-2.

**Procedure: Reading the Test State Sequences**

To read the Test State Sequences table, follow these steps:

1. Look up the row of the current **Test State** down the left-hand column of the table.
2. Look up the column of the desired **Test State** across the top of the table.
3. Read the **Action** at the intersection of the row and column. A dash means that the **Action** is not allowed. **X** means the **Action** is allowed.

**Table 15-2. Allowed Test State Sequences**

| Current Test State | Desired Test State |       |     |      |          |
|--------------------|--------------------|-------|-----|------|----------|
|                    | MONITOR            | SPLIT | HUB | LOOP | RELEASED |
| MONITOR            | -                  | X     | -   | -    | X        |
| SPLIT              | X                  | -     | -   | -    | X        |
| HUB                | -                  | -     | -   | -    | X        |
| LOOP               | -                  | -     | -   | -    | X        |
| RELEASED           | X                  | -     | X   | X    | -        |

An attempt to enter an **Action** that is not allowed for the **Test State** results in the appropriate denial message.

## Test Access Examples

---

Examples of Test Access are given in the following sections. Assume that communication between the I-2000 and the DACS has been established, and the following facility NPCs have been created and restored.

### Example: Placing a Circuit in MONITOR State

---

To place a circuit in MONITOR state, follow these steps:

1. Select TEST ACCESS from the MAIN MENU.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** MONITOR
  - **Object Type:** TG
  - **TC:**
  - **IW:**
  - **Test Object FROM NPC ID:** NPC0001
  - Observe that the test object identification fields are filled in.
  - **Test Object FROM Ch:** 001
  - **Test Object TO NPC:** NPC0001
  - **Test Object TO Ch:** 002
  - **Ckt ID:** NPC0005
  - Observe that the object under test identification fields are filled in.
3. Press **EXECUTE** and confirm. The I-2000 prints a completion message at the bottom of the screen and updates fields in the form.

### Example: MONITOR of Unmapped Channels

---

To MONITOR unmapped channels, follow these steps:

1. Select TEST ACCESS from the MAIN MENU.
2. Enter the following data:
  - **Site Name:** DACS00
  - **Action:** MONITOR
  - **Object Type:** TG
  - **TC:** 0011, 0011
  - **IW:** FF
  - **Test Object FROM NPC ID:** NPC0001

Observe that the test object identification fields are filled in.

- **Test Object FROM Ch:** 001
  - **Test Object TO NPC:** NPC0001
  - **Test Object TO Ch:** 002
  - **Object Under Test TO NPC:** NPC0001
  - **Object Under Test TO Ch:** 004
3. Press **EXECUTE** and confirm. The I-2000 prints a completion message at the bottom of the screen and updates fields in the form.

### **Example: Terminating a Circuit**

---

To apply TLA in the **T** direction, follow these steps:

1. Enter the following data:
  - **Action:** TERMINATE
  - **Direction:** T
2. Press **EXECUTE** and confirm. The I-2000 prints a completion message at the bottom of the screen.

### **Example: Modifying the Status to a SPLIT State**

---

To modify a status to a SPLIT state, follow these steps:

1. Enter **Action:** SPLIT
2. Press **EXECUTE** and confirm. The I-2000 prints a completion message at the bottom of the screen and updates the fields in the form.

### **Example: Unterminating a Circuit**

---

To remove TLA in the **T** direction, follow these steps:

1. Enter the following data:
  - **Action:** UNTERMINATE
  - **Direction:** T
2. Press **EXECUTE** and confirm. The I-2000 prints a completion message at the bottom of the screen.

### **Example: Placing a Test Object into a LOOP State**

---

To place a test object in a LOOP state, follow these steps:

1. Select TEST ACCESS and enter the following data:
  - **Site Name:** DACS00

- **Action:** LOOP
- **Bandwidth:** 03
- **TO NPC ID:** NPC0006
- **TO Ch:** 05
- **FROM NPC ID:** NPC0006
- **FROM Ch:** 05

2. Press **EXECUTE** and confirm. The I-2000 prints a completion message and updates the fields in the form.



**NOTE:**

Do not enter an Object Type (TG) or a TG Number. Only identify the NPC and channels.

---

**Contents**

|                                   |      |
|-----------------------------------|------|
| <b>Introduction</b>               | 16-1 |
| <b>Alarm Notification Feature</b> | 16-1 |
| ■ Retrieving Alarms               | 16-2 |
| ■ Alarm Log                       | 16-3 |
| Power Fail Messages               | 16-9 |

### Introduction

---

This chapter describes the Alarm notification feature of the I-2000. This feature allows you to monitor the alarm status of the DACSs being controlled by the I-2000 on a real time basis. In addition to notification, the feature also provides a mechanism to view the contents of the DACS Alarm Log. Details of the various field values in the Alarm Log reports are also provided in this chapter.



**NOTE:**

When an alarm set message is received by the I-2000, the alarm set message is stored in the I-2000 database and logged to the Alarm Log *if* the alarm *is not* already active in the I-2000 database.

In addition, when an alarm clear message is received by the I-2000, the alarm clear message is stored in the I-2000 database and logged to the Alarm Log *if* the alarm *is* currently active in the I-2000 database.

Therefore, an alarm set is logged to the Alarm Log *only if* that alarm does not currently exist in the I-2000 database. Likewise, an alarm clear is logged to the Alarm Log *only if* that alarm currently does exist in the I-2000 database.

### Alarm Notification Feature

---

The I-2000 alarm status line, labeled `Alarms`, displays equipment alarms. When this line is clear, no unacknowledged alarms are pending.

- **DACS Alarms** are indicated when the appropriate site name appears on the alarm status line. Equipment alarms are displayed from as many DACSs as will fit on the line.

Frame names where critical alarms arise are displayed in red (color terminal), in reverse video (monochrome terminal), or blinking (VT100 only, not the SUN console). Frame names where Minor or major alarms arise are displayed in red (color terminal) or in reverse video (monochrome terminal). Frame names where information alarms arise are not displayed.

When a critical alarm occurs, the site name will flash until you acknowledge by pressing **Ctrl** + **a**.

## Retrieving Alarms

---

To retrieve and acknowledge an alarm, perform these steps:

1. Press **Ctrl** + **a**. A pop-up window will display the available alarm reports including **EQUIPMENT** alarms and any customized alarm reports that have been created.
2. Select the type of alarm. Then, you are prompted for **WHICH DACS?** and a list of **Site Names** is displayed.
3. Select the site name that is in the alarm state. The I-2000 displays a report listing the alarms in the alarm log, one page at a time. The acknowledged site name indicator disappears from the status line until a new alarm is received.
4. Page through the report using the function keys that are noted at the bottom of the screen, as shown in the sample alarm report.

Exiting an alarm report returns you to the previous screen.



**NOTE:**

While you are reviewing the report, new alarms can be added to the log, and new alarm notifications are displayed, but no new alarms are added to the report being displayed.

You also can obtain this report by selecting **REPORT OPERATIONS** from the **MAIN MENU** and **EQUIPMENT ALARMS** from the **REPORT OPERATIONS** menu. However, obtaining a report in this way does not serve to acknowledge the alarm.

**Alarm Log**

Figure 16-1 shows an example of an Alarm Log report.

```

11:42 25 Nov 1997      I-2000 Controller Release x.x for DACS-II
Status:report generation is completed
Alarms:
-----CEF-----ALARM LOG-----ALARMS-----
Date Time      Sev Summary      NPC   Type  Threshold Un S Sub Fld1 Fld2
25Nov 11:07:14 MAJ OOS:  FC                02 0 2
25Nov 11:06:26 MIN OOS:  TLI                04 0
25Nov 11:06:26 MIN OOS:  TLI                01 0
24Nov 15:00:36 MAJ LINK DOWN
24Nov 14:54:32 CLR THRES IDLE 02207      15MIN
24Nov 14:45:48 CLR LINK UP

25 Nov 97                                Page 1 of 1      Display Page:1
HELP  NEXTPAGE  PREVPAGE  QUIT  TOPPAGE  TOP MENU  PRINT  LASTPAGE
    
```

**Figure 16-1. Sample Alarm Report**

Tables 16-1 through 16-8 describe DACS II alarm message elements. These field values help you identify the type of alarm. Explanations of each message element follow each table. The column headings in the report and their values are explained in Table 16-1.

**Table 16-1. Explanation of DACS II and DACS II ISX Alarm Message Elements**

|                   |                                                                                                                  |
|-------------------|------------------------------------------------------------------------------------------------------------------|
| <b>Date, Time</b> | The date and time when the alarm was received. Dates are in order from most recent to least recent.              |
| <b>Sev</b>        | The severity of the alarm: CR (critical), MAJ (major), MIN (minor), CLR (clear) for Idle, and INF (information). |

**Table 16-1. Explanation of DACS II and DACS II ISX Alarm Message Elements (Contd)**

| Summary                                                 | The type of alarm message.                                                                                                                                                                                   |
|---------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| BMTR ALARM                                              | Backup memory transfer alarm.                                                                                                                                                                                |
| BMTR IDLE                                               | Backup memory transfer alarm retired.                                                                                                                                                                        |
| BOOT FAILED                                             | Reports that a system boot has failed during a RST::MC or RST::MC,TAPE command.                                                                                                                              |
| CCB ALARM                                               | Cross-connect buffer alarm.                                                                                                                                                                                  |
| CCB IDLE                                                | Cross-connect buffer alarm retired.                                                                                                                                                                          |
| CCI ALARM                                               | Clock and control interface alarm.                                                                                                                                                                           |
| CCI IDLE                                                | Clock and control interface alarm retired.                                                                                                                                                                   |
| CCNI ALARM                                              | Cross-connect network interface alarm.                                                                                                                                                                       |
| CCNI IDLE                                               | Cross-connect network interface alarm retired.                                                                                                                                                               |
| CGA                                                     | Carrier group alarm for NAS NPCs. This message reports facility alarms.                                                                                                                                      |
| The type of facility alarm is reported in the F column. |                                                                                                                                                                                                              |
| CCN IDLE                                                | Cross-connect network alarm retired.                                                                                                                                                                         |
| CGA IDLE                                                | The message is informationally the same as for CGA. It means that the CGA has been retired.                                                                                                                  |
| CI RESET                                                | Communications interface reset. A DACS II outputs this type of message immediately after a hardware reset. The MAJ severity notifies remote systems of the reset.                                            |
| DATE RESET                                              | Reports that a DACS II's date and/or time have been reset.                                                                                                                                                   |
| DSG                                                     | Jitter suppressor.                                                                                                                                                                                           |
| DSPI ALARM                                              | Digital signal processing interface alarm.                                                                                                                                                                   |
| DSPI IDLE                                               | Digital signal processing interface alarm retired.                                                                                                                                                           |
| DSPU ALARM                                              | Error recovery for the DSPU NPC.                                                                                                                                                                             |
| ECCN IDLE                                               | Expanded cross-connect network side (ECCN) alarm retired.                                                                                                                                                    |
| ETSI ALARM                                              | Expanded time slot interchanger alarm.                                                                                                                                                                       |
| ETSI IDLE                                               | Expanded time slot interchanger alarm retired.                                                                                                                                                               |
| EER                                                     | Excessive Error Rate                                                                                                                                                                                         |
| ERR:SXC                                                 | This autonomous message reports that the synchronizer on the specified synchronizer/cross-connect (SXC) CP has switched to a new phase locked loop operating mode or has switched to a new source of timing. |
| ERR:TREF                                                | Synchronization timing reference error.                                                                                                                                                                      |
| FC ALARM                                                | Format converter alarm.                                                                                                                                                                                      |
| FC IDLE                                                 | Format converter alarm retired.                                                                                                                                                                              |
| FMT ALARM                                               | Formatter alarm.                                                                                                                                                                                             |
| FMT IDLE                                                | Formatter alarm retired.                                                                                                                                                                                     |
| FTMI ALARM                                              | Facility terminating module interface alarm.                                                                                                                                                                 |
| FTMI IDLE                                               | Facility terminating module interface alarm retired.                                                                                                                                                         |

**Table 16-1. Explanation of DACS II and DACS II ISX Alarm Message Elements (Contd)**

|                             |                   |                                                                                                                                                                               |
|-----------------------------|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Summary</b><br>Continued | FTU ALARM         | Error recovery for the FTU NPC. Refers to error condition code.                                                                                                               |
|                             | IDLE : SXC        | The SXC has returned to in-service state.                                                                                                                                     |
|                             | LES               | Loss of External Synchronization                                                                                                                                              |
|                             | LES + AIS         | Loss of External Synchronization and Alarm Indication Signal.                                                                                                                 |
|                             | LES + EER         | Loss of External Synchronization and Excessive Error Rate.                                                                                                                    |
|                             | LES +<br>LOFA/LOS | Loss of External Synchronization and Loss of Frame Alignment or Loss of Signal.                                                                                               |
|                             | LOFA/LOS          | Loss of Frame Alignment or Loss of Signal.                                                                                                                                    |
|                             | LOS               | Loss of signal (LOS) alarm on a DA type NPC.                                                                                                                                  |
|                             | LOS IDLE          | LOS alarm retired.                                                                                                                                                            |
|                             | MC ALARM          | Main controller alarm.                                                                                                                                                        |
|                             | MC IDLE           | Main controller alarm retired.                                                                                                                                                |
|                             | MC IN MCOND       | Maintenance condition (MCOND) in main controller. Reports that the MC has been restored to service in the maintenance condition.                                              |
|                             | MC REMOVED        | Main controller removed. Reports that the MC was removed from service.                                                                                                        |
|                             | OOS : CCB         | Cross-connect buffer out of service.                                                                                                                                          |
|                             | OOS : CCI         | Clock and control interface (CCI) out of service.                                                                                                                             |
|                             | OOS : CCN         | CCN out of service.                                                                                                                                                           |
|                             | OOS : CCNI        | Cross-connect network interface (CCNI) out of service.                                                                                                                        |
|                             | OOS : DSPI        | Digital signal processor interface (DSPI) out of service.                                                                                                                     |
|                             | OOS : ECCN        | Expanded cross-connect network side (ECCN) out of service.                                                                                                                    |
|                             | OOS : ETSI        | Expanded time slot interchanger (ETSI) out of service.                                                                                                                        |
|                             | OOS : FC          | Format converter of a facility terminating unit (FTU) out of service.                                                                                                         |
|                             | OOS : FLI         | Facility line interface out of service .                                                                                                                                      |
|                             | OOS : FMT         | Formatter in a DS3 unit is out of service.                                                                                                                                    |
|                             | OOS : FTMI        | Facility terminating module interface out of service.                                                                                                                         |
|                             | OOS : LINK        | Link out of service.                                                                                                                                                          |
|                             | OOS : MMFG        | Multiplexer-multiplexer interface unit functional group (MMFG) of a DS3 unit out of service.                                                                                  |
|                             | OOS : MEMA        | Memory card A out of service.                                                                                                                                                 |
|                             | OOS : MEMB        | Memory card B out of service.                                                                                                                                                 |
|                             | OOS : PMEM        | Primary memory card out of service.                                                                                                                                           |
|                             | OOS : SMEM        | Secondary memory card out of service.                                                                                                                                         |
|                             | OOS : NPC         | NPC out of service.                                                                                                                                                           |
|                             | OOS : SYNC        | Synchronizer out of service. Reports that the timing extractor circuit, the phase-locked loop, the clock generator unit, or the service and reply circuit are out of service. |

**Table 16-1. Explanation of DACS II and DACS II ISX Alarm Message Elements (Contd)**

|                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|--------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Summary</b><br>Continued... | <p>OOS:SYNC-TB Synchronizer time base out of service. Reports that the synchronizer time base has been removed as a clock reference oscillator (CRO).</p> <p>OOS:SYNC-TLI Synchronizer time link interface out of service.</p> <p>OOS:SXC One of the SXC CPs has gone out of service as a result of either a failure and a protection switch to the duplicated side, or a manual removal of the SXC.</p> <p>OOS:TSI Time slot interchange out of service.</p> <p>OOS:TREF Synchronization timing reference out of service.</p> <p>OOS:UC Unit controller out of service.</p> <p>PBA Primary block alarm (PBA) for CEPT NPCs.</p> <p>PBA IDLE The PBA has been retired.</p> <p>POWER ALARM Power supply alarm.</p> <p>POWER FAIL Reports that error recovery was instigated by a DACS II because of a frame power failure.</p> <p>The F1d1 and F1d2 columns of the report contain field1 and field2 reported in the DACS II error status register. Refer to the description immediately following this table.</p> <p>POWER IDLE Power supply alarm retired.</p> <p>SSP ALARM Synchronizer sync port alarm.</p> <p>SSP IDLE Synchronizer sync port alarm retired.</p> <p>SYNC ALARM Synchronizer alarm.</p> <p>SYNC IDLE Synchronizer alarm retired.</p> <p>THRES ALARM Threshold alarm. This message reports that the 15-minute or 24-hour threshold exception alarm for a particular NPC has been equaled or exceeded for the facility performance parameter designated under <i>Threshold</i>.</p> <p>THRESH IDLE This threshold alarm has been retired.</p> <p>TS0 BOVF TS0 monitor buffer overflow.</p> <p>TS0 IDLE TS0 monitor buffer clear.</p> <p>TSI ALARM Time slot interchanger alarm.</p> <p>TSI ALARM Time slot interchanger alarm.</p> <p>TSI IDLE Time slot interchanger alarm retired.</p> <p>UC ALARM Unit controller alarm.</p> <p>UC IDLE Unit controller alarm retired.</p> |
|--------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Table 16-1. Explanation of DACS II and DACS II ISX Alarm Message Elements (Contd)**

|                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Type</b>      | <p>Facility Alarm Type. For CEPT NPCs; for example, the Summary is PBA:</p> <p>A Primary AIS; for example, Alarm indication signal received in all 32 time slots.</p> <p>B BER: bit error rate detected in received signal.</p> <p>C LCMA: Loss of CRC4 multiframe alignment in TS0.</p> <p>E RBER: remote bit error rate detected in Bit 4 of TS0.</p> <p>F LOF PBF: Loss of frame primary block failure.</p> <p>G FLCMA;</p> <p>I RAIS: remote AIS detected in Bit 4 of TS0.</p> <p>L LMA: Loss of multiframe alignment in CAS Time Slot 16.</p> <p>M R16: RAI received in Bit 6 of Frame 0 of TS16.</p> <p>P PFOOF:</p> <p>R LOS PBF: Loss of signal type primary block failure, or primary block alarm (PBA).</p> <p>S SFI: synchronization failure indication in Bit 5 of TS0.</p> <p>V A16: AIS received in CAS time slot 16.</p> <p>X EER: excessive error rate.</p> <p>Y RAI: Remote alarm indication received in Bit 3 of NFW of TS0.</p> |
| <b>NPC</b>       | <p>The NPC Number of the NPC that is the subject of the message. The NPC number is displayed in hierarchical format if the DACS is provisioned for hierarchical and displayed as 4-digit extended if provisioned for extended 3 or extended 4. (NPCs on a DACS II ISX are always displayed as 4-digit extended.) See Chapter 2, "Frame Administration."</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Threshold</b> | <p>See Table 16-2.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Unit</b>      | <p>The unit number of the alarming facility.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Side</b>      | <p>The side number of the alarming facility.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Sub</b>       | <p>The subunit number of the alarming facility.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>FLD1,FLD2</b> | <p>See Table 16-3 and Table 16-4.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

**Table 16-2. Alarm Thresholds**

| <b>Threshold</b> | <b>Description</b>                       |
|------------------|------------------------------------------|
| BER              | Bit error rate.                          |
| COFA             | Change of frame alignment error.         |
| CRC15MIN         | 15-minute CRC block errors.              |
| CRCDAILY         | Daily CRC block errors.                  |
| CSS15MIN         | 15-minute controlled slip seconds.       |
| CSSDAILY         | Daily controlled slip seconds.           |
| CV15MIN          | 15-minute coding violations.             |
| CVDAILY          | Daily coding violations.                 |
| DM1H             | Degraded minutes after 1 hour.           |
| DM24H            | Degraded minutes after 24 hours.         |
| ERS15M           | Errored seconds after 15 minutes.        |
| ERS24H           | Errored seconds after 24 hours.          |
| ES15MIN          | 15-minute errored seconds.               |
| ESDAILY          | Daily errored seconds                    |
| FEBE15MIN        | 15-minute far -end block errors.         |
| FEBEDAILY        | Daily far-end block errors               |
| FES15MIN         | 15-minute far-end seconds.               |
| FESDAILY         | Daily far-end errored seconds.           |
| FRER15MIN        | 15-minute framing errors.                |
| FRERDAILY        | Daily frame errors.                      |
| FSESDAILY        | Daily far-end severely errored seconds.  |
| FUAS15MIN        | 15-minute far-end unavailable seconds.   |
| FUASDAILY        | Daily far-end unavailable seconds.       |
| IDLE SIG         | Idle signal.                             |
| LOS              | Loss of signal.                          |
| MER15MIN         | 15-minute multiframe errors.             |
| MERDAILY         | Daily multiframe errors.                 |
| OFS15MIN         | 15-minute out of frame seconds.          |
| OFSDAILY         | Daily out of frame seconds.              |
| OOF              | Out of frame.                            |
| SAFE             | Shelf alarm far end.                     |
| SANE             | Shelf alarm near end.                    |
| SERS15M          | Severe errored seconds after 15 minutes. |
| SERS24H          | Severe errored seconds after 24 hours.   |
| SES15MIN         | 15-minute severely errored seconds.      |
| SESDAILY         | Daily severe errored seconds.            |
| SLIP             | Slip count.                              |
| SLIPS15M         | Slip count after 15 minutes.             |
| SLIPS24H         | Slip count after 24 hours.               |
| UAS15MIN         | 15-minute unavailable seconds.           |
| UASDAILY         | Daily unavailable seconds.               |
| UATC15MIN        | 15-minute unavailable time count.        |
| UATCDAILY        | Daily unavailable time count.            |
| US15M            | Unavailable seconds after 15 minutes.    |
| US24H            | Unavailable seconds after 24 hours.      |

**Power Fail Messages**

For a `POWER FAIL` message, `F1d1` and `F1d2` contain field1 and field2 reported in the error status register. These fields are described in the *DACS II Command and Message Manual* of the appropriate release, for message number 0.01301.

Each field consists of four hexadecimal digits that are 16-bit masks. A bit set to 1 indicates a power error and the source of the error. The maps of bit position into power source are repeated here from that manual.

For field1 (`Unit`):

**Table 16-3. Error Status Register *field1* Bit Mask**

| Bit   | Failed Power Supply               | Bit | Failed Power Supply    |
|-------|-----------------------------------|-----|------------------------|
| 15-08 | Not used                          | 03  | CCN/ECCN 1 PWR failure |
| 07    | MC 1, 484GA                       | 02  | CCN/ECCN 0 PWR failure |
| 06    | MC 0, SM565                       | 01  | SYNC 1 PWR failure     |
| 05    | MC 1, 484GA power converter in MC | 00  | SYNC 0 PWR failure     |
| 04    | MC 0, SM565 power converter in MC |     |                        |

For field2:

**Table 16-4. Error Status Register *field2* Bit Mask**

| Bit | Failed Power Supply | Bit | Failed Power Supply |
|-----|---------------------|-----|---------------------|
| 15  | Unit 16             | 07  | Unit 8              |
| 14  | Unit 15             | 06  | Unit 7              |
| 13  | Unit 14             | 05  | Unit 6              |
| 12  | Unit 13             | 04  | Unit 5              |
| 11  | Unit 12             | 03  | Unit 4              |
| 10  | Unit 11             | 02  | Unit 3              |
| 09  | Unit 10             | 01  | Unit 2              |
| 08  | Unit 9              | 00  | Unit 1              |

For an `ISX_PWR FAIL` message, `F1d1` and `F1d2` contain field1 and field2 reported in the error status register. Each field consists of two hexadecimal digits. Expand the two hex digits to 8 bits before comparing to the table below.

A bit set to 1 indicates a power error or a unit not installed. For example, if field1 contains C0, then the 8-bit expansion is 11000000, indicating that main shelf PU3 and PU2 are not installed.

The maps of bit position into units are as follows.

For field1:

**Table 16-5. Error Status Register *field1* Bit Mask**

| Bit   | Unit                          |
|-------|-------------------------------|
| 07-03 | Reserved.                     |
| 02    | Main shelf PU3 not installed. |
| 01    | Main shelf PU2 not installed. |
| 00    | Main shelf PU1 not installed. |

For field2:

**Table 16-6. Error Status Register *field2* Bit Mask**

| Bit | Unit                                                    |
|-----|---------------------------------------------------------|
| 07  | Expansion shelf PU4 not installed.                      |
| 06  | Expansion shelf PU5 not installed.                      |
| 05  | Main shelf feeder A or fuse failure to PU1, PU2 or PU3. |
| 04  | Main shelf feeder B or fuse failure to PU1, PU2 or PU3. |
| 03  | Main shelf +5 V output failure on PU1, PU2 or PU3.      |
| 02  | Expansion shelf feeder A or fuse failure to PU4 or PU5. |
| 01  | Expansion shelf feeder B or fuse failure to PU4 or PU5. |
| 00  | Expansion shelf +5 V output failure on PU4 or PU5.      |

---

**Contents**

|                                                             |       |
|-------------------------------------------------------------|-------|
| <b>Introduction</b>                                         | 17-1  |
| ■ Performance Parameters                                    | 17-2  |
| Performance Parameters for PB/PC type NPCs                  | 17-2  |
| Performance Parameters for PA type NPCs                     | 17-2  |
| <b>Scheduling Performance Monitoring Reports</b>            | 17-4  |
| ■ Scheduling Performance Monitoring Reports for DACS II ISX | 17-4  |
| ■ Scheduling Performance Monitoring Reports for DACS II     | 17-4  |
| ■ When Performance Monitoring Reports are Expected          | 17-5  |
| <b>24-HOUR PERFORMANCE Form</b>                             | 17-5  |
| ■ Field Descriptions                                        | 17-7  |
| <b>24-Hour Performance Monitoring Examples</b>              | 17-9  |
| ■ Example: Browsing 24-Hour Performance Data                | 17-9  |
| ■ Example: Resetting 24-Hour Performance Data               | 17-10 |

---

## 24-Hour Performance Monitoring

# 17

---

### Introduction

---

The I-2000 provides you with the ability to control and report performance monitoring parameters for CEPT type NPCs.

⇒ **NOTE:**  
In order to use the 24-hour performance monitoring feature, set the environment variable `PM24HR_NONFT` to **YES** in *userenv*.

The performance monitoring parameters are those reported in the daily 24-hour performance data reports sent by the DACS II. The I-2000 database is updated based on the output of the daily report.

There are three daily counters also maintained by the I-2000 for each NPC:

- **Days Data Collected**—The number of days for which performance data has been successfully collected.
- **Errored Days**—The number of days for which the performance data has not been successfully collected.
- **Days Since Reset**—The number of days since the performance data has been reset.

⇒ **NOTE:**  
**Days Since Reset = Days Data Collected + Errored Days**

## **Performance Parameters**

---

Performance parameters for PA type NPCs and PB/PC type NPCs are listed below. The following data is kept for each performance parameter:

- The performance data for the last 24 hours
- The average for the performance data based on the number of days data was collected successfully.

### **Performance Parameters for PB/PC type NPCs**

- Loss of Frame Alignment
- Slips
- Cyclic Redundancy Check
- Degraded Minutes
- Unavailable Seconds
- Errored Seconds
- Severely Errored Seconds
- Multiframe Errors
- Framing Errors

### **Performance Parameters for PA type NPCs**

- CRC Block Errors
- Errored Seconds
- Severely Errored Seconds
- Unavailable Seconds
- Framing Errors
- Out-of-Frame Seconds
- Controlled Slip Seconds
- Coding Violations
- Unavailable Time Count
- Multiframe Errors
- Far-end Block Errors
- Far-end Errored Seconds
- Far-end Severely Errored Seconds
- Far-end Unavailable Seconds

Not all PA performance parameters apply to all PA type NPCs. The following tables highlight the inapplicable parameters based on the x and y values in the PAxyz NPC type.

**Table 17-1. Invalid PA Parameters (Based on x value in PAxyz NPC Type)**

| <i>x</i> value parameter | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
|--------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| CRC                      |   |   |   |   |   |   |   |   |   |   | X | X |   | X | X | X |
| MER                      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| FRER                     |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| OFS                      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| ES                       |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| SES                      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| CSS                      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| CV                       |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| UAS                      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| UATC                     |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| FEBE                     | X |   | X |   | X |   | X |   |   |   | X | X |   |   | X | X |
| FES                      | X |   | X |   | X |   | X |   |   |   | X | X |   |   | X | X |
| FSES                     | X |   | X |   | X |   | X |   |   |   | X | X |   |   | X | X |
| FUAS                     | X |   | X |   | X |   | X |   |   |   | X | X |   |   | X | X |

**Table 17-2. Invalid PA Parameters (Based on y value in PAxyz NPC Type)**

| <i>y</i> value parameter | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
|--------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| CRC                      |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |
| MER                      |   |   |   |   |   |   |   |   | X | X |   |   | X | X |   |   |
| FRER                     |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |
| OFS                      |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |
| ES                       |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |
| SES                      |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |
| CSS                      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| CV                       |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| UAS                      |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |
| UATC                     |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |
| FEBE                     |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |
| FES                      |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |
| FSES                     |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |
| FUAS                     |   |   |   |   |   |   |   |   |   |   |   |   |   | X |   |   |

## Scheduling Performance Monitoring Reports

---

The 24-hour performance monitoring statistics processing feature requires that you schedule reports on each DACS II ISX and DACS II that the I-2000 manages. The following sections describe how to schedule the 24-hour PM Statistics Report on the DACS II ISX and DACS II.



**NOTE:**

Do not schedule performance monitoring reports to be executed at midnight.

### Scheduling Performance Monitoring Reports for DACS II ISX

---

To schedule the 24-Hour Performance Monitoring Statistics Report for DACS II ISX, enter the following two commands on each DACS II ISX:

```
SCHED-PMREPT-ALL::: , PRIM-X-FBFF  
SCHED-PMREPT-ALL::: :HH-MM-SS , MONDAT
```

The report should be scheduled on a 15-minute boundary, such as 10:00, 10:15, 10:30, or 10:45.

### Scheduling Performance Monitoring Reports for DACS II

---

To schedule the 24-Hour Performance Monitoring Statistics Report for DACS II, you enter two commands on each DACS II. The first command schedules the report time for PB type NPCS. The second command schedules the report time for PA type NPCs. Both of the scheduled times should be the same. The second report will be expected from the DACS II within 3 minutes of the completion of the first one. If the second report does not start within 3 minutes after the first one, the day will be treated as a day for which no PM reports were received.

The report should be scheduled on a 15-minute boundary, such as 10:00, 10:15, 10:30, or 10:45.

For a gateway DACS II, enter these two commands:

```
SCHED-PMREPT-ALL::: :HH-MM-SS , FAC-X-0002b5 , , PRIM-x-FBFF  
SCHED-PMREPT-ALL::: :HH-MM-SS , MONDAT
```


For a non-gateway CEPT DACS II, enter these two commands:

```
SCHED-PMREPT-ALL::: :HH-MM-SS , PRIM-X-FBFF  
SCHED-PMREPT-ALL::: :HH-MM-SS , MONDAT
```

### When Performance Monitoring Reports are Expected

---

After you create the DACS on the I-2000 and schedule performance monitoring reports on the DACS, the I-2000 will expect the first report from the DACS in the period starting 12:00 midnight and ending 24 hours later. If you scheduled the report to run before 12:00 midnight, any data received before the first midnight will be discarded. This will also be true following an I-2000 restart for DACS that already exist in the I-2000 database and following DACS removals or restorations. The following figure illustrates when the I-2000 expects reports from the DACS.



---

Figure 17-1. Intervals when Performance Monitoring Reports are Expected

### 24-Hour Performance Form

---

Select 24-HOUR PERFORMANCE from the PROVISIONING menu. The PROVISIONING menu is shown in Figure 17-2. The 24-HOUR PERFORMANCE form is displayed, as shown in Figure 17-3.

```
13:37 24 Nov 1997      I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- PROVISIONING -----
CIRCUIT
TEST PORT
NPC
RECONFIGURATION PLAN
AUTOMATIC RECONFIGURATION PLAN
NPC ROLL
ESTABLISH DS0 CHANNEL
SUBRATE CROSS CONNECT
- 24-HOUR PERFORMANCE *

Press ENTER to 24-HOUR Performance.

HELP  [ ] [ ] QUIT  [ ] TOP MENU PRINT  [ ]
```

Figure 17-2. PROVISIONING Menu

```
13:38 24 Nov 1997      I-2000 Controller Release x.x for DACS-II
Status:
Alarms:
----- 24-HOUR PERFORMANCE -----
Site Name: ISX                      Service State:
Action:                               NPC ID:
Type:                                Number (Hier):      (Ext):

Enter the desired action.

HELP CHOICES [ ] QUIT  [ ] TOP MENU PRINT EXECUTE
```

Figure 17-3. 24-HOUR PERFORMANCE Form

\* To display the 24-HOUR PERFORMANCE option on the PROVISIONING menu, set the environment variable PM24HR\_NONFT to **YES**.

There are two actions available on the 24-Hour Performance form:

- **RESET**—Allows you to reset the performance statistics for a single NPC or all NPCs on the I-2000.
- **BROWSE**—Allows you to browse performance statistics for the I-2000 based on the specified search criteria.

### Field Descriptions

Table 17-3 describes the fields used on the 24-Hour Performance form.

**Table 17-3. 24-HOUR PERFORMANCE Field Descriptions**

|                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Site Name</b>     | <p>Mandatory. The name of the frame where the requested <b>Action</b> will take place. Pressing [CHOICES] displays WHICH DACS? with a list of the frame names. These names were established during DACS administration, described in Chapter 3 “System Administration.”</p> <p>The default length of the Site Name field is 17 characters. The length of the Site Name field can be set between 17 to 24 characters in length, if specified by the SITENAME_SIZE environment variable.</p> <p>All alphanumeric characters are valid entries in this field. In addition, the following characters are allowed:</p> <ul style="list-style-type: none"> <li>_ underscore</li> <li>- dash</li> <li>/ slash</li> </ul> <p>All other characters are not allowed.</p> |
| <b>Service State</b> | <p>The status of the NPC. This field cannot be changed by the user except as the result of an <b>Action</b>. Possible values are:</p> <ul style="list-style-type: none"> <li>UEQD Unequipped. The NPC referenced by the <b>NPC ID</b> is not currently recorded in the I-2000 and/or DACS databases (equipped).</li> <li>OOS Out of service. The NPC is currently equipped, but is not operable.</li> <li>IS In service. The NPC is equipped and operable.</li> </ul>                                                                                                                                                                                                                                                                                          |

**Table 17-3. 24-HOUR PERFORMANCE Field Descriptions (Contd)**

|                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Action</b>        | <p>The provisioning actions are:</p> <p><b>RESET</b>      The RESET command resets the average performance statistics in the I-2000 database for one NPC or all NPCs. The following daily counters will also be reset to zero:</p> <p style="text-align: center;"><b>Days Data Collected</b><br/><b>Days Since Reset</b><br/><b>Errored Days</b></p> <p>This command does not erase the last daily 24-hour performance counts.</p> <p><b>BROWSE</b>      The BROWSE command allows you read-only access to the performance statistics database.</p> |
| <b>NPC ID</b>        | <p>Mandatory. The NPC ID is a user-defined string of characters that uniquely identify an NPC on a frame. An NPC ID can be from 1 to 41 characters in length. Most printable characters are allowed.</p> <p>To reset the average performance statistics in the I-2000 database for all NPCs, enter a * in this field and choose the RESET action.</p>                                                                                                                                                                                               |
| <b>Type</b>          | <p>The type of NPC. The format is ABxyz where AB identifies the type of hardware and xyz sets certain provisioning parameters such as frame and signaling format.</p>                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Number (Hier)</b> | <p>The number of the NPC in hierarchical (hier) numbering.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Ext</b>           | <p>The number of the NPC in extended numbering.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

## 24-Hour Performance Monitoring Examples

### Example: Browsing 24-Hour Performance Data

The BROWSE selection retrieves 24-hour performance statistics for each NPC in a specified range.

To browse the 24-hour performance statistics, follow these steps:

1. Select PROVISIONING from the MAIN MENU and 24-HOUR PERFORMANCE from the PROVISIONING menu.
2. Navigate to **Action** and select BROWSE.
3. Fill out the desired search criteria.
4. Press **EXECUTE**.

A search is conducted for the specified NPCs. Also, the data for the first NPC is displayed.

5. To display the data for the next NPC, press **NEXT**.
6. To stop the BROWSE, press RETURN.
7. To exit the form, press **QUIT**.

Figure 17-4 shows a sample BROWSE through the 24-Hour Performance.

```

13:17 24 Nov 1997          I-2000 Controller Release x.x for DACS-II
Status:
Alarms:

----- 24-HOUR PERFORMANCE -----
Site Name:ISX                      Service State:IS
Action:BROWSE                      NPC ID:rlm1
Type:PA100                          Number (Hier):01101          (Ext):0001
NEAR END- LAST 24Hr  AVERAGE  FAR END - LAST 24 Hr  AVERAGE
CRC Block Errors           600      450.2           104      36.3
Errored Seconds
Sev Errored Seconds
Unavailable Seconds
Framing Errors
Out-of-Frame Seconds
Controlled Slip Seconds
Coding Violations
Unavailable Time Count
Multiframe Errors
No of Days Collected: 10 No of Days Since Reset: 12 No of Errored Days: 2
Item 1 of 3. Use NEXT/PREVIOUS keys to scroll.
Enter the NPC Identifier.
HELP  NEXT  PREVIOUS  QUIT  TOP MENU  PRINT  EXECUTE

```

Figure 17-4. 24-HOUR PERFORMANCE Browse Screen

### Example: Resetting 24-Hour Performance Data

The **RESET** selection resets the average performance statistics for an NPC or NPCs associated with a selected DACS.

To reset the 24-hour performance statistics, follow these steps:

1. Select **PROVISIONING** from the **MAIN MENU** and **24-HOUR PERFORMANCE** from the **PROVISIONING** menu.
2. Navigate to **Action** and select **RESET**.
3. Select the NPC using one of the following fields:
  - **NPC ID**
  - **Number (Hier)**: If you fill this in, **(Ext)** is automatically supplied.
  - **Number (Ext)**: If you fill this in, **(Hier)** is automatically supplied.
4. Press **EXECUTE**.

Figure 17-5 shows a sample Reset screen.

```

13:17 24 Nov 1997          I-2000 Controller Release x.x for DACS-II
Status:
Alarms:


----- 24-HOUR PERFORMANCE -----
Site Name:ISX                      Service State:IS
Action:RESET                        NPC ID:rlm1
Type:PA100                          Number (Hier):01101          (Ext):0002
NEAR END- LAST 24Hr AVERAGE        FAR END - LAST 24 Hr AVERAGE
CRC Block Errors                    600                          104
Errored Seconds
Sev Errored Seconds
Unavailable Seconds
Framing Errors
Out-of-Frame Seconds
Controlled Slip Seconds
Coding Violations
Unavailable Time Count
Multiframe Errors
No of Days Collected:000 No of Days Since Reset:000 No of Errored Days:000

Enter the site name.
HELP CHOICES [ ] QUIT [ ] TOP MENU PRINT EXECUTE
  
```

Figure 17-5. 24-HOUR PERFORMANCE Reset Screen

---

# Summary of Fields for Customized Reports



---

## Contents

|                                                          |      |
|----------------------------------------------------------|------|
| <b>Introduction</b>                                      | A-1  |
| <b>CIRCUITS Reports</b>                                  | A-2  |
| <b>NPCS Reports</b>                                      | A-4  |
| <b>CHANNELS Reports</b>                                  | A-9  |
| <b>ALTROUTES/PREEMPTIONS</b>                             | A-10 |
| <b>RECONFIGURATION PLANS Reports</b>                     | A-11 |
| <b>RECONFIGURATION PLAN ALTROUTE Reports</b>             | A-11 |
| <b>AUTO RECONFIGURATION PLANS Reports</b>                | A-13 |
| <b>OUTAGES Reports</b>                                   | A-14 |
| <b>ALARM LOG Reports</b>                                 | A-14 |
| <b>TEST PORT Reports</b>                                 | A-16 |
| <b>TEST ACCESS Reports</b>                               | A-17 |
| <b>FRAMES/LINKS Reports</b>                              | A-19 |
| <b>USER ADMINISTRATION Reports</b>                       | A-20 |
| <b>NPC ALARMS Reports</b>                                | A-21 |
| <b>CIRCUIT ALARMS Reports</b>                            | A-21 |
| <b>LOST RESPONSE LOG Reports</b>                         | A-23 |
| <b>24-HOUR PERFORMANCE MONITORING STATISTICS Reports</b> | A-24 |
| <b>COMMON EQUIPMENT ALARM Reports</b>                    | A-27 |

---

## Summary of Fields for Customized Reports



---

### Introduction

---

The EDIT CUSTOM REPORT FORMAT feature allows you to design a report in one of a number of categories, which are based on type of information. Each category makes available a range of fields, from which you may select for inclusion on your report.

To find out how to create and maintain reports, refer to "Custom Report Formats" in Chapter 14 "Report Operations." This appendix states the full range of fields available, by category, and gives a brief description of each, with its report default size in characters, and its form of origination. In some instances, there is no form of origination, but the data was generated by the system. In that case, the field is the only way to access that data. All data comes from the database.

## CIRCUITS Reports

**Table A-1. CIRCUITS Reports Fields**

| Name          | Form of Origination                                 | Description                                                       |
|---------------|-----------------------------------------------------|-------------------------------------------------------------------|
| Remarks       | <b>Rmks</b> field,<br>CIRCUIT PROVISIONING          | User-defined information concerning the circuit.                  |
| Ckt_Status    | <b>Ckt Status</b> field,<br>CIRCUIT PROVISIONING    | The operating status of the circuit.                              |
| Circuit_ID    | <b>Ckt ID</b> field,<br>CIRCUIT PROVISIONING        | User-assigned circuit name.                                       |
| Class         | <b>Ckt Class</b> field,<br>CIRCUIT PROVISIONING     | The type of circuit: FDX, HDX, BBL, BRD, DMB.                     |
| Customer_Name | <b>Customer Name</b> field,<br>CIRCUIT PROVISIONING | User-defined name of the customer owning the circuit.             |
| Location_A    | <b>Loc A</b> field,<br>CIRCUIT PROVISIONING         | User-defined station ID of the FROM side of the circuit.          |
| Location_Z    | <b>Loc Z</b> field,<br>CIRCUIT PROVISIONING         | User-defined station ID of the TO side of the circuit.            |
| F_NPC_Hier    | <b>FROM Hier</b> field,<br>CIRCUIT PROVISIONING     | Hierarchical number of the circuit's FROM side NPC.               |
| T_NPC_Hier    | <b>TO Hier</b> field,<br>CIRCUIT PROVISIONING       | Hierarchical number of the circuit's TO side NPC.                 |
| F_NPC_Ext     | <b>FROM Ext</b> field,<br>CIRCUIT PROVISIONING      | Extended number of the circuit's FROM side NPC.                   |
| T_NPC_Ext     | <b>TO Ext</b> field,<br>CIRCUIT PROVISIONING        | Extended number of the circuit's TO side NPC.                     |
| F_NPC_ID      | <b>FROM NPC ID</b> field,<br>CIRCUIT PROVISIONING   | NPC ID of the circuit's FROM side NPC.                            |
| T_NPC_ID      | <b>TO NPC ID</b> field,<br>CIRCUIT PROVISIONING     | NPC ID of the circuit's TO side NPC.                              |
| F_Ch          | <b>FROM Ch</b> field,<br>CIRCUIT PROVISIONING       | The circuit's FROM side channel number.                           |
| T_Ch          | <b>TO Ch</b> field,<br>CIRCUIT PROVISIONING         | The circuit's TO side channel number.                             |
| F_Mode        | <b>FROM Mode</b> field,<br>CIRCUIT PROVISIONING     | The use of the FROM channel in a DMB circuit: SYM, BRD, BBL, LEG. |
| T_Mode        | <b>TO Mode</b> field,<br>CIRCUIT PROVISIONING       | The use of the TO channel in a DMB circuit: SYM, BRD, BBL, LEG    |

**Table A-1. CIRCUITS Reports Fields (Contd)**

| Name              | Form of Origination                                      | Description                                                                                     |
|-------------------|----------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| TC                | <b>TC</b> field,<br>CIRCUIT PROVISIONING                 | Trunk conditioning. Specifies whether A/B-robbet-bit signaling will signal circuit failure.     |
| IW                | <b>IW</b> field,<br>CIRCUIT PROVISIONING                 | Insertion word. Specifies the OOS signal of mapped channels.                                    |
| SC                | <b>SC</b> field,<br>CIRCUIT PROVISIONING                 | Signaling conversion. Specifies the CAS channel values for CEPT and GATEWAY.                    |
| Bandwidth         | <b>Bandwidth</b> field,<br>CIRCUIT PROVISIONING          | The number of channels in a high-rate circuit.                                                  |
| Bandwidth_Type    | <b>Bandwidth Type</b> field,<br>CIRCUIT PROVISIONING     | The placement of channels in a high-rate circuit: contiguous (C), alternating (A), random (R).  |
| Service_Date      | <b>Service Date</b> field,<br>CIRCUIT PROVISIONING       | User-defined date when the circuit was first placed in service.                                 |
| Options_NAM       | <b>Options</b> field value,<br>CIRCUIT PROVISIONING      | The value NAM, for no a-to-mu law conversion, if <b>Options</b> is set to A; otherwise, blanks. |
| Options_AIS       | <b>Options</b> field value,<br>CIRCUIT PROVISIONING      | The value AIS, for transmit Alarm Indication Signal, if <b>Options</b> is set to B.             |
| Options_RDLD      | <b>Options</b> field value,<br>CIRCUIT PROVISIONING      | The value RDLD, for disconnect red-lined circuits, if <b>Options</b> is set to C.               |
| Options_OOS       | <b>Options</b> field value,<br>CIRCUIT PROVISIONING      | The value OOS, for disconnect on channel going OOS, if <b>Options</b> is set to D.              |
| Options_INCL      | <b>Options</b> field value,<br>CIRCUIT PROVISIONING      | The value INCL, for authorize disconnect of red-lined circuits, if <b>Options</b> is set to E.  |
| Options_DCC       | <b>Options</b> field value,<br>CIRCUIT PROVISIONING      | The value DCC, for assert IW as disconnect code, if <b>Options</b> is set to F.                 |
| Termination_State | <b>Options</b> field value,<br>CIRCUIT PROVISIONING      | The value TLA, for terminate normal traffic, if <b>Options</b> is set to G.                     |
| NTR               | <b>NTR</b> field value,<br>CIRCUIT PROVISIONING          | No transmit. Specifies that a direction of a DMB leg will not carry traffic: T or F.            |
| CP                | <b>Ckt Priority</b> field value,<br>CIRCUIT PROVISIONING | Determines the importance of a circuit for restoral actions.                                    |
| Framing           | <b>Framing</b> field value,<br>CIRCUIT PROVISIONING      | The value of the framing bits in CEPT Channel 0 cross-connection.                               |

## NPCS Reports

**Table A-2. NPCS Reports Fields**

| Name            | Form of Origination                                                       | Description                                                                                         |
|-----------------|---------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| NPC_Hier        | <b>Number (Hier)</b> field,<br>NPC PROVISIONING                           | The hierarchical number of the NPC.                                                                 |
| NPC_Ext         | <b>(Ext)</b> field,<br>NPC PROVISIONING                                   | The extended number of the NPC.                                                                     |
| NPC_ID          | <b>NPC ID</b> field,<br>NPC PROVISIONING                                  | User-assigned NPC name.                                                                             |
| Type            | <b>Type</b> field,<br>NPC PROVISIONING                                    | The I-2000 type of NPC, which is based on the hardware module providing it.                         |
| FE_Site         | <b>FE Site</b> field,<br>NPC PROVISIONING                                 | User-defined name of the DACS at the other end of the DS1 line terminating at the NPC.              |
| Service_State   | <b>Service State</b> field,<br>NPC PROVISIONING                           | The operating status of the NPC.                                                                    |
| Alarm_State     | <b>Alarm State</b> field,<br>NPC PROVISIONING                             | The status of an alarm currently being received or asserted by this NPC.                            |
| Alarm_Aging     | <b>Alarm Aging</b> field,<br>NPC PROVISIONING                             | The number of seconds after an alarm is received before the I-2000 takes action.                    |
| Insertion_Word  | <b>IW</b> field,<br>NPC PROVISIONING                                      | The value transmitted by an IS NPC on unassigned channels.                                          |
| AIS             | <b>AIS</b> field, Alarm Indica-<br>tion Signal.                           | Specifies AIS alarm level for this NPC. Values are MJ (Major), MN (Minor), MI (Informa-<br>tional). |
| NFS             | <b>NFS</b> field,<br>NPC PROVISIONING                                     | Non-frame word setting. Specifies how the spare bits of time slot 0 are to be handled.              |
| TS0             | <b>TS0</b> field,<br>NPC PROVISIONING                                     | Describes how to process bits for transmis-<br>sion in a CEPT time slot 0.                          |
| TS0M            | <b>TS0M</b> field,<br>NPC PROVISIONING                                    | Describes what CEPT time slot 0 bits are to<br>be monitored by the frame.                           |
| Min_Slips       | <b>Minor Alarm Option/<br/>Slips</b> field,<br>NPC PROVISIONING           | Specifies the threshold of a minor alarm on a<br>slips error in an NAS NPC.                         |
| Min_BER         | <b>Minor Alarm Option/<br/>Bit Error Rate</b> field,<br>NPC PROVISIONING  | Specifies the threshold of a minor alarm on a<br>bit error rate in an NAS NPC.                      |
| Min_Frame_Align | <b>Minor Alarm Option/<br/>Frame Alignment</b> field,<br>NPC PROVISIONING | Specifies the threshold of a minor alarm on a<br>frame alignment error in an NAS NPC.               |

**Table A-2. NPCS Reports Fields (Contd)**

| Name               | Form of Origination                                                       | Description                                                                                    |
|--------------------|---------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|
| Maj_Slips          | <b>Major Alarm Option/ Slips</b> field,<br>NPC PROVISIONING               | Specifies the threshold of a major alarm on a slips error in an NAS NPC.                       |
| Maj_BER            | <b>Major Alarm Option Bit Error Rate</b> field,<br>NPC PROVISIONING       | Specifies the threshold of a major alarm on a bit error rate in an NAS NPC.                    |
| Maj_Frame_Align    | <b>Major Alarm Option Frame Alignment</b> field,<br>NPC PROVISIONING      | Specifies the threshold of a major alarm on a frame alignment error in an NAS NPC.             |
| Maj_Err_Sec        | <b>Major Alarm Option Errored Seconds</b> field,<br>NPC PROVISIONING      | Specifies the threshold of a major alarm on errored seconds in an NAS NPC.                     |
| Maj_Sev_Err_Sec    | <b>Major Alarm Option Severe Errored Seconds</b><br>NPC PROVISIONING      | Specifies the threshold of a major alarm on severe errored seconds in an NAS NPC.              |
| Short_Slips        | <b>Short Interval Options Slips</b> field,<br>NPC PROVISIONING            | Specifies the short-interval threshold of a slips alarm in a CEPT non-PA NPC.                  |
| Short_Degraded_Min | <b>Short Interval Options Degraded Minutes</b> field,<br>NPC PROVISIONING | Specifies the short-interval threshold of a degraded minutes alarm in a CEPT non-PA NPC.       |
| Short_Unavail_Sec  | <b>Short Interval Options Unavailable Seconds</b><br>NPC PROVISIONING     | Specifies the short-interval threshold of an unavailable seconds alarm in a CEPT non-PA NPC.   |
| Short_Err_Sec      | <b>Short Interval Options Errored Seconds</b> field<br>NPC PROVISIONING   | Specifies the short-interval threshold of an errored seconds alarm in a CEPT non-PA NPC.       |
| Short_Sev_Err_Sec  | <b>Short Interval Options Severe Errored Seconds</b><br>NPC PROVISIONING  | Specifies the short-interval threshold of a severe errored seconds alarm in a CEPT non-PA NPC. |
| Long_Slips         | <b>Long Interval Options Slips</b> field value,<br>NPC PROVISIONING       | Specifies the long-interval threshold of a slips alarm in a CEPT non-PA NPC.                   |
| Long_Degraded_Min  | <b>Long Interval Options Degraded Minutes</b> ,<br>NPC PROVISIONING       | Specifies the long-interval threshold of a degraded minutes alarm in a CEPT non-PA NPC.        |
| Long_Unavail_Sec   | <b>Long Interval Options Unavailable Seconds</b> ,<br>NPC PROVISIONING    | Specifies the long-interval threshold of an unavailable errors alarm in a CEPT non-PA NPC.     |

**Table A-2. NPCS Reports Fields (Contd)**

| <b>Name</b>        | <b>Form of Origination</b>                                               | <b>Description</b>                                                                            |
|--------------------|--------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
| Long_Err_Sec       | <b>Long Interval Options Errored Seconds,</b><br>NPC PROVISIONING        | Specifies the long-interval threshold of an errored seconds alarm in a CEPT non-PA NPC.       |
| Long_Sev_Err_Sec   | <b>Long Interval Options Severe Errored Seconds,</b><br>NPC PROVISIONING | Specifies the long-interval threshold of a severe errored seconds alarm in a CEPT non-PA NPC. |
| NE_Daily_CRC_Err   | <b>Daily NE CRC Block Errors</b> field,<br>NPC PROVISIONING              | Specifies the daily near end CRC block errors for a CEPT PA NPC.                              |
| NE_Daily_Err_Sec   | <b>Daily NE Errored Seconds</b> field,<br>NPC PROVISIONING               | Specifies the daily near end errored seconds for a CEPT PA NPC.                               |
| NE_Daily_S_Err_Sec | <b>Daily NE Severe Errored Seconds</b><br>NPC PROVISIONING               | Specifies the daily near end severe errored seconds for a CEPT PA NPC.                        |
| NE_Daily_Unavl_Sec | <b>Daily NE Unavailable Seconds</b><br>NPC PROVISIONING                  | Specifies the daily near end unavailable seconds for a CEPT PA NPC.                           |
| NE_Daily_Frame_Err | <b>Daily NE Framing Errors</b><br>NPC PROVISIONING                       | Specifies the daily near end framing errors for a CEPT PA NPC.                                |
| NE_Daily_OOF_Sec   | <b>Daily NE Out-of-Frame Seconds</b><br>NPC PROVISIONING                 | Specifies the daily near end out-of-frame seconds for a CEPT PA NPC.                          |
| NE_Daily_Slip_Sec  | <b>Daily NE Controlled Slip Seconds</b><br>NPC PROVISIONING              | Specifies the daily near end controlled slip seconds for a CEPT PA NPC.                       |
| NE_Daily_Code_Vltn | <b>Daily NE Coding Violations</b><br>NPC PROVISIONING                    | Specifies the daily near end coding violations for a CEPT PA NPC.                             |
| NE_Daily_Unavl_Cnt | <b>Daily NE Unavailable Time Count</b><br>NPC PROVISIONING               | Specifies the daily near end unavailable time count for a CEPT PA NPC.                        |
| NE_Daily_Mfram_Err | <b>Daily NE Multiframe Errors</b><br>NPC PROVISIONING                    | Specifies the daily near end multiframe errors for a CEPT PA NPC.                             |
| FE_Daily_CRC_Err   | <b>Daily FE CRC Block Errors</b><br>NPC PROVISIONING                     | Specifies the daily far end CRC block errors for a CEPT PA NPC.                               |

**Table A-2. NPCS Reports Fields (Contd)**

| <b>Name</b>        | <b>Form of Origination</b>                                   | <b>Description</b>                                                          |
|--------------------|--------------------------------------------------------------|-----------------------------------------------------------------------------|
| FE_Daily_Err_Sec   | <b>Daily FE Errored Seconds</b><br>NPC PROVISIONING          | Specifies the daily far end errored seconds for a CEPT PA NPC.              |
| FE_Daily_S_Err_Sec | <b>Daily FE Severe Errored Seconds</b><br>NPC PROVISIONING   | Specifies the daily far end severe errored seconds for a CEPT PA NPC.       |
| FE_Daily_Unavl_Sec | <b>Daily FE Unavailable Seconds</b><br>NPC PROVISIONING      | Specifies the daily far end unavailable seconds for a CEPT PA NPC.          |
| NE_15M_CRC_Err     | <b>15-Min NE CRC Block Errors</b><br>NPC PROVISIONING        | Specifies the 15-minute near end CRC block errors for a CEPT PA NPC.        |
| NE_15M_Err_Sec     | <b>15-Min NE Errored Seconds</b><br>NPC PROVISIONING         | Specifies the 15-minute near end errored seconds for a CEPT PA NPC.         |
| NE_15M_S_Err_Sec   | <b>15-Min NE Severe Errored Seconds</b><br>NPC PROVISIONING  | Specifies the 15-minute near end severe errored seconds for a CEPT PA NPC.  |
| NE_15M_Unavl_Sec   | <b>15-Min NE Unavailable Seconds</b><br>NPC PROVISIONING     | Specifies the 15-minute near end unavailable seconds for a CEPT PA NPC.     |
| NE_15M_Frame_Err   | <b>15-Min NE Framing Errors</b><br>NPC PROVISIONING          | Specifies the 15-minute near end framing errors for a CEPT PA NPC.          |
| NE_15M_OOF_Sec     | <b>15-Min NE Out-of-Frame Seconds</b><br>NPC PROVISIONING    | Specifies the 15-minute near end out-of frame seconds for a CEPT PA NPC.    |
| NE_15M_Slip_Sec    | <b>15-Min NE Controlled Slip Seconds</b><br>NPC PROVISIONING | Specifies the 15-minute near end controlled slip seconds for a CEPT PA NPC. |
| NE_15M_Code_Vltn   | <b>15-Min NE Coding Violations</b><br>NPC PROVISIONING       | Specifies the 15-minute near end coding violations for a CEPT PA NPC.       |
| NE_15M_Unavl_Cnt   | <b>15-Min NE Unavailable Time Count</b><br>NPC PROVISIONING  | Specifies the 15-minute near end unavailable time count for a CEPT PA NPC.  |
| NE_15M_Mfram_Err   | <b>15-Min NE Multiframe Errors</b><br>NPC PROVISIONING       | Specifies the 15-minute near end multiframe errors for a CEPT PA NPC.       |

**Table A-2. NPCS Reports Fields (Contd)**

| Name             | Form of Origination                                             | Description                                                                                                                                                                                                                                                                                                              |
|------------------|-----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FE_15M_CRC_Err   | <b>15-Min FE<br/>CRC Block Errors</b><br>NPC PROVISIONING       | Specifies the 15-minute far end CRC block errors for a CEPT PA NPC.                                                                                                                                                                                                                                                      |
| FE_15M_Err_Sec   | <b>15-Min FE<br/>Errored Seconds</b><br>NPC PROVISIONING        | Specifies the 15-minute far end errored seconds for a CEPT PA NPC.                                                                                                                                                                                                                                                       |
| FE_15M_S_Err_Sec | <b>15-Min FE<br/>Severe Errored Seconds</b><br>NPC PROVISIONING | Specifies the 15-minute far end severe errored seconds for a CEPT PA NPC.                                                                                                                                                                                                                                                |
| FE_15M_Unavl_Sec | <b>15-Min FE<br/>Unavailable Seconds</b><br>NPC PROVISIONING    | Specifies the 15-minute far end unavailable seconds for a CEPT PA NPC.                                                                                                                                                                                                                                                   |
| Trans            | <b>Lpbk Trans</b> field,<br>NPC PROVISIONING                    | The transmission parameter of a loopback state. Values are:<br>A - loop the signal, send AIS, turn off PM and alarms<br>B - loop the signal, send AIS, perform PM and alarm processing<br>C - Loop the signal, turn off PM, freeze alarms<br>T - Loop the signal, perform PM and process alarms<br>N - No loopback is up |
| Dir              | <b>Dir</b> field,<br>NPC PROVISIONING                           | The Direction parameter of a loopback state. Values are:<br>F - Facility, back to the facility<br>E - Equipment, back to the DACS II<br>N - No loopback                                                                                                                                                                  |

## CHANNELS Reports

**Table A-3. CHANNELS Reports Fields**

| Name        | Form of Origination                                           | Description                                                                                                                                   |
|-------------|---------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| NPC_Hier    | <b>FROM Hier</b> field,<br>CIRCUIT PROVISIONING               | The hierarchical number of the NPC. This NPC is to be understood as the FROM NPC.                                                             |
| NPC_Ext     | <b>FROM Ext</b> field,<br>CIRCUIT PROVISIONING                | The extended number of the NPC.                                                                                                               |
| NPC_ID      | <b>FROM NPC ID</b> field,<br>CIRCUIT PROVISIONING             | User-assigned NPC name.                                                                                                                       |
| Ch          | <b>FROM Ch</b> field,<br>CIRCUIT PROVISIONING                 | The number of the channel under consideration, within the specified NPC.                                                                      |
| Status      | <b>Ckt Status</b> field,<br>CIRCUIT PROVISIONING              | The status of the circuit in which the channel appears.                                                                                       |
| Circuit_ID  | <b>Ckt ID</b> field,<br>CIRCUIT PROVISIONING                  | The ID of the circuit in which the channel appears.                                                                                           |
| Class       | <b>Ckt Class</b> field,<br>CIRCUIT PROVISIONING               | The type of circuit: FDX, HDX, BBL, BRD, DMB, BKB, LEG.                                                                                       |
| TC          | <b>TC</b> field,<br>CIRCUIT PROVISIONING                      | Trunk conditioning. Specifies whether A/B-robbed-bit signaling will signal circuit failure.                                                   |
| IW          | <b>IW</b> field,<br>CIRCUIT PROVISIONING                      | Insertion word. Specifies the OOS signal of mapped channels.                                                                                  |
| To_NPC_Hier | <b>TO Hier</b> field,<br>CIRCUIT PROVISIONING                 | The hierarchical number of the TO NPC.                                                                                                        |
| To_NPC_Ext  | <b>TO Ext</b> field,<br>CIRCUIT PROVISIONING                  | The extended number of the TO NPC.                                                                                                            |
| To_NPC_ID   | <b>TO NPC ID</b> field,<br>CIRCUIT PROVISIONING               | User-assigned TO NPC name.                                                                                                                    |
| To_Ch       | <b>TO Ch</b> field,<br>CIRCUIT PROVISIONING                   | Specifies the TO channel.                                                                                                                     |
| TS          | None. This information is reported only in this report field. | Reports the termination state of the EFT represented by the channel, as it was when the report was generated. Values are TLA, TLR, or blanks. |

## ALTROUTES/PREEMPTIONS

**Table A-4. ALTROUTES/PREEMPTIONS Reports Fields**

| Name          | Form of Origination                                       | Description                                                                                         |
|---------------|-----------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| Circuit_ID    | <b>Ckt ID</b> field,<br>CIRCUIT PROVISIONING              | The circuit ID of the altrouted circuit.                                                            |
| CP            | <b>Ckt Priority</b> field,<br>CIRCUIT PROVISIONING        | The circuit priority of the altrouted circuit. The CP partly determines its order of normalization. |
| TC            | <b>TC</b> field,<br>CIRCUIT PROVISIONING                  | Trunk conditioning of the altrouted circuit.                                                        |
| IW            | <b>IW</b> field,<br>CIRCUIT PROVISIONING                  | Insertion word of the altrouted circuit.                                                            |
| Alt_Date      | <b>Altroute Date &amp; Time</b> ,<br>CIRCUIT PROVISIONING | The date the circuit was altrouted.                                                                 |
| Alt_Time      | <b>Altroute Date &amp; Time</b> ,<br>CIRCUIT PROVISIONING | The time the circuit was altrouted.                                                                 |
| NPC_Hier      | <b>NORMAL Hier</b> ,<br>CIRCUIT PROVISIONING              | The hierarchical NPC number of the EFT that was changed in altrouting.                              |
| NPC_Ext       | <b>NORMAL Ext</b> field,<br>CIRCUIT PROVISIONING          | The extended NPC number of the EFT that was changed in altrouting.                                  |
| NPC_ID        | <b>NORMAL NPC ID</b> field,<br>CIRCUIT PROVISIONING       | The NPC ID of the EFT that was changed in altrouting.                                               |
| Ch            | <b>NORMAL Ch</b> field,<br>CIRCUIT PROVISIONING           | The channel that was changed in altrouting.                                                         |
| Alt_NPC_Hier  | <b>ALTROUTE Hier</b> field,<br>CIRCUIT PROVISIONING       | The hierarchical number of the NPC to which the NORMAL NPC was changed.                             |
| Alt_NPC_Ext   | <b>ALTROUTE Ext</b> field,<br>CIRCUIT PROVISIONING        | The extended number of the NPC to which the NORMAL NPC was changed.                                 |
| Alt_NPC_ID    | <b>ALTROUTE NPC ID</b> field,<br>CIRCUIT PROVISIONING     | The NPC number to which the NORMAL NPC was changed.                                                 |
| Alt_Ch        | <b>ALTROUTE Ch</b> field,<br>CIRCUIT PROVISIONING         | The channel to which the NORMAL channel was changed.                                                |
| Preemp_Ckt_ID | <b>Preempted Ckt ID</b> field,<br>CIRCUIT PROVISIONING    | The NPC ID of the first circuit that was preempted by this altroute, if any.                        |
| Preemp_CP     | <b>Preempted CP</b> field,<br>CIRCUIT PROVISIONING        | The circuit priority of the preempted circuit, if any.                                              |

## RECONFIGURATION PLANS Reports

Table A-5. RECONFIGURATION PLANS Reports Fields

| Name               | Form of Origination                                      | Description                                                                          |
|--------------------|----------------------------------------------------------|--------------------------------------------------------------------------------------|
| Reconfiguration_ID | <b>RP ID</b> field, RECONFIGURATION PLAN PROVISIONING    | The user-defined name of this plan.                                                  |
| Circuit_ID         | <b>Ckt ID</b> field, RECONFIGURATION PLAN PROVISIONING   | The circuit ID of the circuit on which this item of the plan operates.               |
| Status             | <b>Status</b> field, RECONFIGURATION PLAN PROVISIONING   | The current operating status of the circuit on which this item of the plan operates. |
| Circuit_Action     | <b>Action</b> field, RECONFIGURATION PLAN PROVISIONING   | The <b>Action</b> to be performed on the circuit of this item.                       |
| Sequence           | <b>Sequence</b> field, RECONFIGURATION PLAN PROVISIONING | The sequence number of this item in the plan.                                        |

## RECONFIGURATION PLAN ALTRROUTE Reports

Table A-6. RECONFIGURATION PLAN ALTRROUTE Reports Fields

| Name               | Form of Origination                                      | Description                                                                                         |
|--------------------|----------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| Reconfiguration_ID | <b>RP ID</b> field, RECONFIGURATION PLAN PROVISIONING    | The user-defined name of this plan.                                                                 |
| Sequence           | <b>Sequence</b> field, RECONFIGURATION PLAN PROVISIONING | The sequence number of this item in the plan.                                                       |
| Side               | <b>SIDE</b> field, NPC PROVISIONING                      | Specifies the side for an altroute of types MR, MJ and SR.                                          |
| Circuit_ID         | <b>Ckt ID</b> field, RECONFIGURATION PLAN PROVISIONING   | The circuit ID of the circuit on which this item of the plan operates.                              |
| CP                 | <b>Ckt Priority</b> field, CIRCUIT PROVISIONING          | The circuit priority of the altrouted circuit. The CP partly determines its order of normalization. |

**Table A-6. RECONFIGURATION PLAN ALTRROUTE Reports Fields (Contd)**

| <b>Name</b>     | <b>Form of Origination</b>                             | <b>Description</b>                                                                       |
|-----------------|--------------------------------------------------------|------------------------------------------------------------------------------------------|
| NPC_Hier        | <b>FROM Hier</b> field,<br>CIRCUIT PROVISIONING        | The hierarchical number of the NPC. This NPC is to be understood as the FROM NPC.        |
| NPC_Ext         | <b>FROM Ext</b> field,<br>CIRCUIT PROVISIONING         | The extended number of the NPC.                                                          |
| NPC_ID          | <b>FROM NPC ID</b> field,<br>CIRCUIT PROVISIONING      | User-assigned NPC name.                                                                  |
| Ch              | <b>FROM Ch</b> field,<br>CIRCUIT PROVISIONING          | The number of the channel under consideration, within the specified NPC.                 |
| Alt_NPC_Hier    | <b>ALTRROUTE Hier</b> field,<br>CIRCUIT PROVISIONING   | The hierarchical number of the NPC to which the NORMAL NPC was changed.                  |
| Alt_NPC_Ext     | <b>ALTRROUTE Ext</b> field,<br>CIRCUIT PROVISIONING    | The extended number of the NPC to which the NORMAL NPC was changed.                      |
| Alt_NPC_ID      | <b>ALTRROUTE NPC ID</b> field,<br>CIRCUIT PROVISIONING | The NPC number to which the NORMAL NPC was changed.                                      |
| Alt_Ch          | <b>ALTRROUTE Ch</b> field,<br>CIRCUIT PROVISIONING     | The channel to which the NORMAL channel was changed.                                     |
| F_Preemp_Ckt_ID | <b>Preempted Ckt ID</b> field,<br>CIRCUIT PROVISIONING | A circuit preempted by the FROM side of an altrouted circuit, if any.                    |
| F_Preemp_CP     | <b>Preempted CP</b> field,<br>CIRCUIT PROVISIONING     | The circuit priority of the circuit preempted by the FROM side of the altrouted circuit. |
| T_Preemp_Ckt_ID | <b>Preempted Ckt ID</b> field,<br>CIRCUIT PROVISIONING | A circuit preempted by the TO side of an altrouted circuit, if any.                      |
| T_Preemp_CP     | <b>Preempted CP</b> field,<br>CIRCUIT PROVISIONING     | The circuit priority of the circuit preempted by the TO side of the altrouted circuit.   |

## AUTO RECONFIGURATION PLANS Reports

**Table A-7. AUTO RECONFIGURATION PLAN Reports Fields**

| Name         | Form of Origination                                                     | Description                                                        |
|--------------|-------------------------------------------------------------------------|--------------------------------------------------------------------|
| ARP_ID       | <b>ARP ID</b> field, AUTOMATIC RECONFIGURATION PLAN PROVISIONING        | The user-defined name of this ARP.                                 |
| ARP_Status   | <b>ARP Status</b> field, AUTOMATIC RECONFIGURATION PLAN PROVISIONING    | The execution status of the ARP.                                   |
| RP_Sequence  | <b>Sequence</b> field, AUTOMATIC RECONFIGURATION PLAN PROVISIONING      | The sequence number of the RP listed in the ARP.                   |
| RP_Status    | <b>RP Status</b> field, RECONFIGURATION PLAN PROVISIONING               | The execution status of an RP on the ARP.                          |
| RP_Site      | <b>Site Name</b> field, RP and ARP forms.                               | The name of the site where the RP was or is to be executed.        |
| RP_ID        | <b>RP ID</b> field, RP and ARP forms.                                   | The ID of the RP that was or is to be executed.                    |
| RP_Date      | None.                                                                   | The date when the RP was executed.                                 |
| RP_Time      | None                                                                    | The time when the RP was executed.                                 |
| NPC_Sequence | <b>Sequence</b> field, AUTOMATIC RECONFIGURATION PLAN PROVISIONING      | The sequence number of an item placing an NPC on the alarm list.   |
| NPC_Site     | <b>Site Name</b> field, AUTOMATIC RECONFIGURATION PLAN PROVISIONING     | The site of the NPC being placed on the alarm list.                |
| NPC_Hier     | <b>Number (Hier)</b> field, AUTOMATIC RECONFIGURATION PLAN PROVISIONING | The hierarchical number of the NPC being placed on the alarm list. |
| NPC_Ext      | <b>(Ext)</b> field, AUTOMATIC RECONFIGURATION PLAN PROVISIONING         | The extended number of the NPC being placed on the alarm list.     |
| NPC_Date     | None.                                                                   | The date on which the NPC issued an alarm, triggering the RP.      |

**Table A-7. AUTO RECONFIGURATION PLAN Reports Fields (Contd)**

| Name     | Form of Origination | Description                                |
|----------|---------------------|--------------------------------------------|
| NPC_Time | None.               | The time at which the NPC issued an alarm. |

## OUTAGES Reports

**Table A-8. OUTAGES Reports Fields**

| Name          | Form of Origination                                | Description                                                            |
|---------------|----------------------------------------------------|------------------------------------------------------------------------|
| Outage_Type   | <b>Outage Type</b> field,<br>OUTAGE LOG            | The type of log: NPC or CIRCUIT.                                       |
| Record_Number | <b>Record No.</b> field,<br>OUTAGE LOG             | The sequence number of the record in the log.                          |
| Outage_ID     | <b>Outage ID</b> field,<br>OUTAGE LOG              | The ID of this outage record. It is in fact an NPC ID or a circuit ID. |
| CP            | <b>Ckt Priority</b> field,<br>CIRCUIT PROVISIONING | The priority of the circuit referenced by the <b>Outage ID</b> .       |
| Date_Out      | <b>Date Out</b> field,<br>OUTAGE LOG               | Three fields stating the date on which the outage began.               |
| Time_Out      | <b>Time Out</b> field,<br>OUTAGE LOG               | Three fields stating the time on which the outage began.               |
| Date_In       | <b>Date In</b> field,<br>OUTAGE LOG                | The date when the outage was cleared.                                  |
| Time_In       | <b>Time In</b> field,<br>OUTAGE LOG                | The time the outage was cleared.                                       |

## ALARM LOG Reports

**Table A-9. ALARM LOG Report Fields**

| Name     | Form of Origination                             | Description                                                                                     |
|----------|-------------------------------------------------|-------------------------------------------------------------------------------------------------|
| Alm_Date | None.                                           | The date on which the NPC issued the alarm.                                                     |
| Alm_Time | None.                                           | The time at which the NPC issued the alarm.                                                     |
| NPC_Hier | <b>Number (Hier)</b> field, NPC<br>PROVISIONING | The hierarchical number of the NPC in alarm.                                                    |
| NPC_Ext  | <b>(Ext)</b> field, NPC PROVI-<br>SIONING       | The extended number of the NPC in alarm.                                                        |
| NPC_ID   | <b>NPC ID</b> field, NPC PRO-<br>VISIONING      | The NPC ID of the NPC in alarm.                                                                 |
| FE_Site  | <b>FE Site</b> field,<br>NPC PROVISIONING       | User-defined name of the DACS at the other end of the DS1 line terminating at the NPC in alarm. |
| Severity | None.                                           | The severity of the alarm: Cr, Maj, Min, Clr.                                                   |

**Table A-9. ALARM LOG Report Fields (Contd)**

| <b>Name</b> | <b>Form of Origination</b>                                  | <b>Description</b>                                             |
|-------------|-------------------------------------------------------------|----------------------------------------------------------------|
| Alm_Summary | None.                                                       | The reason for the alarm.                                      |
| Threshold   | None.                                                       | The name of the threshold stored in the frame.                 |
| Fac_A_Type  | None.                                                       | The type of facility alarm in a message <b>Summary</b> of CGA. |
| Side        | None                                                        | The side number of the alarming facility.                      |
| Unit        | None.                                                       | The unit number of the alarming facility.                      |
| S_Unit      | None.                                                       | The subunit of the alarming facility.                          |
| Field1      | None.                                                       | Field1 of the Error Status Register, for a power fail message. |
| Field2      | None                                                        | Field2 of the Error Status Register, for a power fail message. |
| NPC_Num     | <b>NPC (Hier)</b> or <b>(Ext)</b> field, FRAME Provisioning | The format of the NPC number, either hierarchical or extended. |

## TEST PORT Reports

**Table A-10. TEST PORT Reports Fields**

| Name            | Form of Origination                                | Description                                                             |
|-----------------|----------------------------------------------------|-------------------------------------------------------------------------|
| Test_Port       | <b>Test Port No.</b> field,<br>TP PROVISIONING     | The test port number.                                                   |
| Test_Port_Group | <b>Test Port Group</b> field,<br>TP PROVISIONING   | The test port group.                                                    |
| Test_Port_State | Test State field,<br>TEST ACCESS                   | The operating status of the test port.                                  |
| TP_NPC_Hier     | <b>NPC Number (Hier)</b> field,<br>TP PROVISIONING | The hierarchical number of the NPC being used for this test port group. |
| TP_NPC_Ext      | <b>(Ext)</b> field,<br>TP PROVISIONING             | The extended number of the NPC being used for this test port group.     |
| TP_NPC_ID       | <b>NPC ID</b> field,<br>TP PROVISIONING            | The NPC ID of the NPC being used for this test port group.              |
| Static_TC       | <b>TC</b> field,<br>TP PROVISIONING                | The test port trunk conditioning, if the TC is static for this port.    |
| Static_IW       | <b>IW</b> field,<br>TP PROVISIONING                | The test port insertion word, if the IW is static for this port.        |
| F_NPC_Hier      | <b>FROM Hier</b> field,<br>TEST ACCESS form        | The hierarchical number of the FROM NPC of the object under test.       |
| F_NPC_Ext       | <b>FROM Ext</b> field,<br>TEST ACCESS form         | The extended number of the FROM NPC of the circuit under test.          |
| F_NPC_ID        | <b>FROM NPC ID</b> field,<br>TEST ACCESS form      | The ID of the FROM NPC of the circuit under test.                       |
| F_Ch            | <b>FROM Ch</b> field,<br>TEST ACCESS form          | The FROM channel number of the circuit under test.                      |
| T_NPC_Hier      | <b>TO Hier</b> field,<br>TEST ACCESS form          | The hierarchical number of the TO NPC of the circuit under test.        |
| T_NPC_Ext       | <b>TO Ext</b> field,<br>TEST ACCESS form           | The extended number of the TO NPC of the circuit under test.            |
| T_NPC_ID        | <b>TO NPC ID</b> field,<br>TEST ACCESS form        | The ID of the TO NPC of the circuit under test.                         |
| T_Ch            | <b>TO Ch</b> field,<br>TEST ACCESS form            | The TO channel number of the circuit under test.                        |
| Circuit_ID      | <b>Ckt ID</b> ,<br>TEST ACCESS form                | The circuit ID of the object under test.                                |

**Table A-10. TEST PORT Reports Fields (Contd)**

| Name       | Form of Origination                                 | Description                                            |
|------------|-----------------------------------------------------|--------------------------------------------------------|
| Term_State | <b>Termination State</b> field<br>TEST ACCESS form. | The actual termination state of the object under test. |
| Ckt_Status | <b>Ckt Status</b> field,<br>CIRCUIT PROVISIONING    | The operational status of the circuit under test.      |

## TEST ACCESS Reports

**Table A-11. TEST ACCESS Reports Fields**

| Name                | Form of Origination                             | Description                                                                               |
|---------------------|-------------------------------------------------|-------------------------------------------------------------------------------------------|
| Test_Object_Number  | <b>Test Object Number</b><br>field, TEST ACCESS | The test object number.                                                                   |
| IW                  | <b>IW</b> field,<br>TEST ACCESS                 | The IW of the test object.                                                                |
| F_Test_Obj_NPC_ID   | <b>Test Object F NPC ID</b> ,<br>TEST ACCESS    | The FROM NPC ID of the test object.                                                       |
| T_Test_Obj_NPC_ID   | <b>Test Object T NPC ID</b> ,<br>TEST ACCESS    | The TO NPC ID of the test object.                                                         |
| FIRST_F_Test_Ch     | <b>Test Object FROM Ch</b><br>TEST ACCESS       | The channel number of the first channel of the band, of the FROM side of the test object. |
| Test_Object_Type    | <b>Object Type</b> field,<br>TEST ACCESS        | The type of test object, TP or TG.                                                        |
| TC                  | <b>TC</b> field,<br>TEST ACCESS                 | The trunk conditioning of the object under test, if the TC is static for this port.       |
| F_Test_Obj_NPC_Ext  | <b>Test Object FROM Ext</b> ,<br>TEST ACCESS    | The extended number of the test object FROM NPC.                                          |
| T_Test_Obj_NPC_Ext  | <b>Test Object TO Ext</b> ,<br>TEST ACCESS      | The extended number of the test object TO NPC.                                            |
| FIRST_T_Test_Ch     | <b>Test Object TO Ch</b> ,<br>TEST ACCESS       | The channel number of the first channel of the band, of the TO side of the test object.   |
| Test State          | <b>Test State</b> field,<br>TEST ACCESS         | The operating status of the test access connections: RELEASED, MONITOR, etc.              |
| AtoMU               | <b>AtoMU</b> field,<br>TEST ACCESS              | A-law to Mu-law conversion in effect, Y or N.                                             |
| F_Test_Obj_NPC_Hier | <b>Test Object F Hier</b> ,<br>TEST ACCESS      | The hierarchical number of the of the test object FROM NPC.                               |

**Table A-11. TEST ACCESS Reports Fields (Contd)**

| <b>Name</b>         | <b>Form of Origination</b>                       | <b>Description</b>                                                 |
|---------------------|--------------------------------------------------|--------------------------------------------------------------------|
| T_Test_Obj_NPC_Hier | <b>Test Object T Hier,</b><br>TEST ACCESS        | The hierarchical number of the test object TO NPC.                 |
| BW                  | <b>Bandwidth</b> field,<br>TEST ACCESS           | The bandwidth of the test object.                                  |
| Circuit_ID          | <b>Object Under Test Ckt ID,</b><br>TEST ACCESS  | The circuit ID of the circuit being tested.                        |
| F_NPC_ID            | <b>Obj. Under Test F NPC ID,</b><br>TEST ACCESS  | The FROM NPC ID of the circuit under test.                         |
| T_NPC_ID            | <b>Obj. Under Test T NPC ID,</b><br>TEST ACCESS  | The TO NPC ID of the circuit under test.                           |
| F_Ch                | <b>Obj. Under Test F Ch,</b><br>TEST ACCESS      | The first FROM channel of the object under test.                   |
| Ckt_Status          | <b>Ckt Status</b> field,<br>CIRCUIT PROVISIONING | The circuit status of the circuit under test.                      |
| F_NPC_Ext           | <b>Obj. Under Test F Ext,</b><br>TEST ACCESS     | The extended number of the FROM NPC in the circuit under test.     |
| T_NPC_Ext           | <b>Obj. Under Test T Ext,</b><br>TEST ACCESS     | The extended number of the TO NPC in the circuit under test.       |
| T_Ch                | <b>Obj. Under Test T Ch,</b><br>TEST ACCESS      | The first TO channel of the object under test.                     |
| F_NPC_Hier          | <b>Obj. Under Test F Hier,</b><br>TEST ACCESS    | The hierarchical number of the FROM NPC in the circuit under test. |
| T_NPC_Hier          | <b>Obj. Under Test T Hier,</b><br>TEST ACCESS    | The hierarchical number of the TO NPC in the circuit under test.   |
| Termination_State   | <b>Termination State</b> field,<br>TEST ACCESS   | The termination state of the circuit under test.                   |

## FRAMES/LINKS Reports

**Table A-12. FRAMES/LINKS Reports Fields**

| Name               | Form of Origination                               | Description                                                                                  |
|--------------------|---------------------------------------------------|----------------------------------------------------------------------------------------------|
| Site_Name          | <b>Site Name</b> field, FRAME ADMINISTRATION      | The user-assigned name of the frame being provisioned.                                       |
| Site_Status        | <b>Site Status</b> field, FRAME ADMINISTRATION    | The status of the frame.                                                                     |
| Protocol           | <b>Protocol</b> field, FRAME ADMINISTRATION       | The protocol in effect over the path between the I-2000 and the frame: SNIDER or X.25.       |
| Location           | <b>Location</b> field, FRAME ADMINISTRATION       | User-defined value stating the physical location of the frame.                               |
| Generic            | <b>Generic</b> field, FRAME ADMINISTRATION        | States the software release of the frame software.                                           |
| NPC_Addressing     | <b>NPC Addr</b> field, FRAME ADMINISTRATION       | The type of NPC addressing used in frame commands generated by the I-2000: HIER, EXT3, EXT4. |
| Language           | <b>Language</b> field, FRAME ADMINISTRATION       | The command language used for frame commands generated by the I-2000: MML, PDS.              |
| Frame_Type         | <b>Type</b> field, FRAME ADMINISTRATION           | The type of frame: DACS II, D II ISX.                                                        |
| Alarm_Sync         | <b>NPC Alarm Sync</b> , FRAME ADMINISTRATION      | The selection or non-selection of NPC alarm synchronization for this frame.                  |
| Speed              | <b>Speed</b> field, FRAME ADMINISTRATION          | The baud rate for the SNIDER port.                                                           |
| Primary_Line       | <b>Primary Line</b> , FRAME ADMINISTRATION        | The number of the line between the I-2000 and the network or the frame.                      |
| Primary_Conn_Type  | <b>Connection Type</b> , X.25 LINK ADMINISTRATION | The connection type of the primary line: PDN or DIRECT.                                      |
| Primary_Netwk_Addr | <b>Network Address</b> , FRAME ADMINISTRATION     | The network address of the primary line.                                                     |
| Primary_Link_Stat  | <b>Status</b> field, FRAME ADMINISTRATION         | The operational status of the primary line.                                                  |
| Backup_Line        | <b>Backup Line</b> , FRAME ADMINISTRATION         | The number of the backup line.                                                               |
| Backup_Conn_Type   | <b>Connection Type</b> , X.25 LINK ADMINISTRATION | The connection type of the backup line: PDN or DIRECT.                                       |

**Table A-12. FRAMES/LINKS Reports Fields (Contd)**

| Name              | Form of Origination                                   | Description                                                                                                                     |
|-------------------|-------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| Backup_Netwk_Addr | <b>Network Address</b> ,<br>FRAME ADMINISTRA-<br>TION | The network address of the backup line.                                                                                         |
| Backup_Link_Stat  | <b>Status</b> field, FRAME<br>ADMINISTRATION          | The operational status of the backup line.                                                                                      |
| ERP_Control       | <b>ERP Control</b> , FRAME<br>ADMINISTRATION          | The selection or non-selection of conditional<br>echoed response processing for this frame.                                     |
| Comm_Status       | None.                                                 | Whether or not the I-2000 received a<br>response after it sent out a command to the<br>frame. A * means communication occurred. |

## USER ADMINISTRATION Reports

**Table A-13. USER ADMINISTRATION Reports Fields**

| Name         | Form of Origination                          | Description                                                                                             |
|--------------|----------------------------------------------|---------------------------------------------------------------------------------------------------------|
| Login        | <b>Login Name</b> field, USER MANAGEMENT     | The login name by which the user is known to the I-2000 system.                                         |
| Class        | <b>User Class</b> field, USER MANAGEMENT     | The type of login: OPERATOR, ADMIN, CONTROLLER.                                                         |
| User_Name    | <b>User Name</b> field, USER MANAGEMENT      | The name of the person owning the login.                                                                |
| Phone        | <b>Phone</b> field, USER MANAGEMENT          | User-defined value stating the user's telephone number.                                                 |
| Address      | <b>Address</b> field, USER MANAGEMENT        | User-defined value stating the user's address.                                                          |
| City         | <b>City</b> field, USER MANAGEMENT           | User-defined value stating the user's city.                                                             |
| Alarm        | <b>Alarms Audible</b> field, USER MANAGEMENT | Whether or not an audible alarm should sound at the user terminal when a frame alarm occurs: ON or OFF. |
| Idle         | <b>UI Idle Option</b> field, USER MANAGEMENT | The logoff threshold in seconds of terminal idle time.                                                  |
| Printer_Name | <b>Printer Name</b> field, USER MANAGEMENT   | Printer Name                                                                                            |
| Type         | <b>Type</b> field, USER MANAGEMENT           | ASync, X25, LOCAL                                                                                       |

## NPC ALARMS Reports

**Table A-14. NPC ALARMS Reports Fields**

| Name          | Form of Origination                          | Description                                  |
|---------------|----------------------------------------------|----------------------------------------------|
| NPC_Hier      | <b>Number (Hier)</b> field, NPC PROVISIONING | The hierarchical number of the NPC in alarm. |
| NPC_Ext       | <b>(Ext)</b> field, NPC PROVISIONING         | The extended number of the NPC in alarm.     |
| NPC_ID        | <b>NPC ID</b> field, NPC PROVISIONING        | The NPC ID of the NPC in alarm.              |
| Service_State | <b>Service State</b> field, NPC PROVISIONING | The operational status of the NPC in alarm.  |

**Table A-14. NPC ALARMS Reports Fields (Contd)**

| Name           | Form of Origination                        | Description                                                                                   |
|----------------|--------------------------------------------|-----------------------------------------------------------------------------------------------|
| Alarm_State    | <b>Alarm State</b> field, NPC PROVISIONING | The status of the alarm.                                                                      |
| Alarm_Aging    | <b>Alarm Aging</b> field, NPC PROVISIONING | The threshold in seconds before the I-2000 takes action on the alarm.                         |
| Severity       | Sev field, Alarm Report                    | The severity of the alarm.                                                                    |
| Type           | <b>Type</b> field, NPC PROVISIONING        | The type of the NPC in alarm.                                                                 |
| FE_Site        | <b>FE Site</b> field, NPC PROVISIONING     | The user-defined name of the DACS at the far end of the line terminating at the alarming NPC. |
| Insertion_Word | <b>IW</b> field, NPC PROVISIONING          | The insertion word of the NPC in alarm.                                                       |
| NFS            | <b>NFS</b> field, NPC PROVISIONING         | The treatment of the non-framing bits in Channel 0 to non-Channel 0 connections.              |

## CIRCUIT ALARMS Reports

**Table A-15. CIRCUIT ALARMS Reports Fields**

| Name          | Form of Origination                               | Description                                                                                                          |
|---------------|---------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|
| NPC_Hier      | <b>Number (Hier) field</b> , NPC PROVISIONING     | The hierarchical number of the NPC in alarm.                                                                         |
| NPC_Ext       | <b>(Ext) field</b> , NPC PROVISIONING             | The extended number of the NPC in alarm.                                                                             |
| NPC_ID        | <b>NPC ID field</b> , NPC PROVISIONING            | The NPC ID of the NPC in alarm.                                                                                      |
| Service_State | <b>Service State field</b> , NPC PROVISIONING     | The operational status of the NPC in alarm.                                                                          |
| Ch            | <b>Ch field</b> , NPC PROVISIONING                | The channel, of the NPC in alarm, that is connected in the circuit.                                                  |
| Alarm_State   | <b>Alarm State field</b> , NPC PROVISIONING       | The status of the alarm.                                                                                             |
| Term_State    | None.                                             | The actual termination state of the EFT in the alarming NPC. The EFT can acquire this state by a variety of methods. |
| Circuit_ID    | <b>Ckt ID field</b> , CIRCUIT PROVISIONING        | The circuit ID of the circuit containing the NPC in alarm.                                                           |
| Ckt_Status    | <b>Ckt Status field</b> , CIRCUIT PROVISIONING    | The operating status of the circuit containing the EFT of the NPC in alarm.                                          |
| Class         | <b>Ckt Class field</b> , CIRCUIT PROVISIONING     | The class of the circuit containing the EFT of the NPC in alarm: FDX, HDX, etc.                                      |
| Customer_Name | <b>Customer Name field</b> , CIRCUIT PROVISIONING | The user-defined name of the customer owning the circuit containing the alarming NPC.                                |
| TC            | <b>TC field</b> , CIRCUIT PROVISIONING            | Trunk conditioning of the circuit containing the NPC in alarm.                                                       |
| IW            | <b>IW field</b> , CIRCUIT PROVISIONING            | Insertion word of the circuit containing the NPC in alarm.                                                           |
| T_NPC_Hier    | <b>TO Hier field</b> , CIRCUIT PROVISIONING       | The hierarchical number of the NPC at the other side of the circuit containing the alarming NPC.                     |
| T_NPC_Ext     | <b>TO Ext field</b> , CIRCUIT PROVISIONING        | The extended number of the NPC at the other side of the circuit containing the alarming NPC.                         |
| T_NPC_ID      | <b>TO NPC ID field</b> , CIRCUIT PROVISIONING     | The ID of the NPC at the other side of the circuit containing the alarming NPC.                                      |

**Table A-15. CIRCUIT ALARMS Reports Fields (Contd)**

| Name            | Form of Origination                                 | Description                                                                                                                                                   |
|-----------------|-----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| T_Service_State | <b>Service State</b> field,<br>NPC PROVISIONING     | The service status of the NPC at the other side of the circuit containing the alarming NPC.                                                                   |
| T_Ch            | <b>TO Ch</b> field, CIRCUIT PROVISIONING            | The EFT at the other side of the circuit containing the alarming NPC.                                                                                         |
| T_Alarm_State   | <b>Alarm State</b> field,<br>CIRCUIT PROVISIONING   | The alarm status of the NPC at the other side of the circuit containing the alarming NPC.                                                                     |
| T_Term_State    | None.                                               | The actual termination state of the NPC at the other side of the circuit containing the alarming NPC. The EFT can acquire this state by a variety of methods. |
| Ckt_Priority    | <b>Ckt Priority</b> field,<br>CIRCUIT PROVISIONING  | The priority of the circuit containing the alarming NPC.                                                                                                      |
| Bandwidth       | <b>Bandwidth</b> field,<br>CIRCUIT PROVISIONING     | The bandwidth of the circuit containing the alarming NPC.                                                                                                     |
| SC              | <b>SC</b> field,<br>CIRCUIT PROVISIONING            | The signalling conversion specification of the circuit containing the alarming NPC.                                                                           |
| Framing         | <b>Framing</b> field,<br>CIRCUIT PROVISIONING       | The new values of the framing bits in Channel 0 to non-Channel 0 connections in a circuit containing the alarming NPC.                                        |
| Options_AIS     | <b>Options</b> field value,<br>CIRCUIT PROVISIONING | The value AIS, for transmit Alarm Indication Signal, if <b>Options</b> is set to B for the circuit in which the alarming NPC appear.                          |
| Location_A      | <b>Loc A</b> field,<br>CIRCUIT PROVISIONING         | A user-defined field stating the station ID of the FROM side of the circuit containing the alarming NPC.                                                      |
| Location_Z      | <b>Loc Z</b> field,<br>CIRCUIT PROVISIONING         | A user-defined field stating the station ID of the TO side of the circuit containing the alarming NPC.                                                        |

## LOST RESPONSE LOG Reports

**Table A-16. LOST RESPONSE LOG Report Fields**

| Name           | Form of Origination | Description                                       |
|----------------|---------------------|---------------------------------------------------|
| L_Date         | None.               | The date on which the I-2000 issued the response. |
| L_Time         | None.               | The time at which the I-2000 issued the response. |
| Request_Type   | None                | FRAME, NPC or CIRCUIT.                            |
| Status         | None                | S (Success) or F (Failure).                       |
| Message_No     | None                | The message number.                               |
| Denial_Message |                     | The reason for denial.                            |

## 24-HOUR PERFORMANCE MONITORING STATISTICS Reports

**Table A-17. 24-HOUR PERFORMANCE MONITORING Report Fields**

| Name     | Form of Origination                             | Description                              |
|----------|-------------------------------------------------|------------------------------------------|
| NPC_ID   | <b>NPC ID</b> field,<br>NPC PROVISIONING.       | The NPC ID.                              |
| NPC_Type | <b>NPC Type</b> field,<br>NPC PROVISIONING.     | The NPC Type.                            |
| NPC_Hier | <b>Number (Hier)</b> field,<br>NPC PROVISIONING | The hierarchical number of the NPC.      |
| NPC_Ext  | <b>Number (EXT)</b> field,<br>NPC PROVISIONING  | The extended number of the NPC.          |
| CRC_Avg  | <b>CRC_AVG</b> field, 24-<br>HOUR PERFORMANCE   | Average Cyclic Redundancy Check counts.  |
| ES_Avg   | <b>ES_AVG</b> field, 24-HOUR<br>PERFORMANCE     | Average Errored Seconds counts.          |
| SES_Avg  | <b>SES_AVG</b> field, 24-<br>HOUR PERFORMANCE   | Average Errored Severely Seconds counts. |
| UAS_Avg  | <b>UAS_AVG</b> field, 24-<br>HOUR PERFORMANCE   | Average Unavailable Seconds counts.      |
| FRER_Avg | <b>FRER_AVG</b> field, 24-<br>HOUR PERFORMANCE  | Average Framing Errors counts.           |

**Table A-17. 24-HOUR PERFORMANCE MONITORING Report Fields (Contd)**

| <b>Name</b> | <b>Form of Origination</b>                              | <b>Description</b>                               |
|-------------|---------------------------------------------------------|--------------------------------------------------|
| OFS_Avg     | <b>OFS_AVG</b> field, 24-HOUR PERFORMANCE               | Average Out of Frame Seconds counts.             |
| CSS_Avg     | <b>CSS_AVG</b> field, 24-HOUR PERFORMANCE               | Average Control Slips Seconds counts.            |
| CV_Avg      | <b>CV_AVG</b> field, 24-HOUR PERFORMANCE                | Average Coding Violations counts.                |
| UATC_Avg    | <b>UATC_AVG</b> field, 24-HOUR PERFORMANCE              | Average Unavailable Time Count counts.           |
| MER_Avg     | <b>MER_AVG</b> field, 24-HOUR PERFORMANCE               | Average Multiframe Error counts.                 |
| FEBE_Avg    | <b>FEBE_AVG</b> field, 24-HOUR PERFORMANCE              | Average Far End Bit Error counts.                |
| FSES_Avg    | <b>FSES_AVG</b> field, 24-HOUR PERFORMANCE              | Average Far End Severely Errored Seconds counts. |
| FES_Avg     | <b>FES_AVG</b> field, 24-HOUR PERFORMANCE               | Average Far End Errored Seconds counts.          |
| FUAS_Avg    | <b>FUAS_AVG</b> field, 24-HOUR PERFORMANCE              | Average Far End Unavailable Second counts.       |
| LOFA_Avg    | <b>LOFA_AVG</b> field, 24-HOUR PERFORMANCE              | Average Loss of Frame Alignment counts.          |
| ERS_Avg     | <b>ERS_AVG</b> field, 24-HOUR PERFORMANCE               | Average Errored Seconds counts.                  |
| SLIP_Avg    | <b>SLIP_AVG</b> field, 24-HOUR PERFORMANCE              | Average SLIP counts.                             |
| US_Avg      | <b>US_AVG</b> field, 24-HOUR PERFORMANCE                | Average Unavailable Second counts.               |
| DM_Avg      | <b>DM_AVG</b> field, 24-HOUR PERFORMANCE                | Average Degraded Minutes counts.                 |
| SERS_Avg    | <b>SERS_AVG</b> field, 24-HOUR PERFORMANCE              | Average Severely Errored Seconds counts.         |
| Collected   | <b>No. of Days Collected</b> field, 24-HOUR PERFORMANCE | Number of days collected.                        |
| Reset       | <b>Reset</b> field, 24-HOUR PERFORMANCE                 | Number of days since data was reset.             |
| Error       | <b>Error</b> field, 24-HOUR PERFORMANCE                 | Number of days data not collected.               |

**Table A-17. 24-HOUR PERFORMANCE MONITORING Report Fields (Contd)**

| <b>Name</b> | <b>Form of Origination</b>                  | <b>Description</b>                       |
|-------------|---------------------------------------------|------------------------------------------|
| CRC_24hr    | <b>CRC_24hr</b> field, 24-HOUR PERFORMANCE  | Cyclic Redundancy Check counts.          |
| ES_24hr     | <b>ES_24hr</b> field, 24-HOUR PERFORMANCE   | Errored Seconds counts.                  |
| SES_24hr    | <b>SES_24hr</b> field, 24-HOUR PERFORMANCE  | Errored Severely Seconds counts.         |
| UAS_24hr    | <b>UAS_24hr</b> field, 24-HOUR PERFORMANCE  | Unavailable Seconds counts.              |
| FRER_24hr   | <b>FRER_24hr</b> field, 24-HOUR PERFORMANCE | Framing Errors counts.                   |
| OFS_24hr    | <b>OFS_24hr</b> field, 24-HOUR PERFORMANCE  | Out of Frame Seconds counts.             |
| CSS_24hr    | <b>CSS_24hr</b> field, 24-HOUR PERFORMANCE  | Control Slips Seconds counts.            |
| CV_24hr     | <b>CV_24hr</b> field, 24-HOUR PERFORMANCE   | Coding Violations counts.                |
| UATC_24hr   | <b>UATC_24hr</b> field, 24-HOUR PERFORMANCE | Unavailable Time Count counts.           |
| MER_24hr    | <b>MER_24hr</b> field, 24-HOUR PERFORMANCE  | Multiframe Error counts.                 |
| FEBE_24hr   | <b>FEBE_24hr</b> field, 24-HOUR PERFORMANCE | Far End Bit Error counts.                |
| FSES_24hr   | <b>FSES_24hr</b> field, 24-HOUR PERFORMANCE | Far End Severely Errored Seconds counts. |
| FES_24hr    | <b>FES_24hr</b> field, 24-HOUR PERFORMANCE  | Far End Errored Seconds counts.          |
| FUAS_24hr   | <b>FUAS_24hr</b> field, 24-HOUR PERFORMANCE | Far End Unavailable Second counts.       |
| LOFA_24hr   | <b>LOFA_24hr</b> field, 24-HOUR PERFORMANCE | Loss of Frame Alignment counts.          |
| ERS_24hr    | <b>ERS_24hr</b> field, 24-HOUR PERFORMANCE  | Errored Seconds counts.                  |
| SLIP_24hr   | <b>SLIP_24hr</b> field, 24-HOUR PERFORMANCE | SLIP counts.                             |
| US_24hr     | <b>US_24hr</b> field, 24-HOUR PERFORMANCE   | Unavailable Second counts.               |

**Table A-17. 24-HOUR PERFORMANCE MONITORING Report Fields (Contd)**

| Name        | Form of Origination                           | Description                      |
|-------------|-----------------------------------------------|----------------------------------|
| DM_24hr     | <b>DM_24hr</b> field, 24-HOUR PERFORMANCE     | Degraded Minutes counts.         |
| SERS_24hr   | <b>SERS_24hr</b> field, 24-HOUR PERFORMANCE   | Severely Errored Seconds counts. |
| Alarm_State | <b>Alarm_State</b> field, 24-HOUR PERFORMANCE | Current alarm state on the NPC.  |

## COMMON EQUIPMENT ALARM Reports

---

**Table A-18. COMMON EQUIPMENT ALARM Report Fields**

| <b>Name</b> | <b>Form of Origination</b> | <b>Description</b>                               |
|-------------|----------------------------|--------------------------------------------------|
| EqpDate     | None.                      | The date on which the I-2000 received the alarm. |
| EqpTime     | None.                      | The time at which the I-2000 received the alarm. |
| Status      | None.                      | The severity of the alarm.                       |
| Device      | None.                      | The device name under alarm.                     |
| Sub_Device  | None.                      | The sub-device name under alarm.                 |
| Side        | None.                      | The side under alarm.                            |
| Unit        | None.                      | The unit under alarm.                            |
| Sub_Unit    | None.                      | The subunit under alarm.                         |

---

## **Error Messages**

# **B**

---

## **Contents**

|                              |      |
|------------------------------|------|
| <b>Introduction</b>          | B-1  |
| <b>Status Error Messages</b> | B-1  |
| <b>Troubleshooting</b>       | B-8  |
| ■ Resource Problems          | B-8  |
| ■ Software Failure           | B-9  |
| ■ Error Log                  | B-10 |

---

# Error Messages

# B

---

## Introduction

A number of messages may be displayed on the I-2000 status line. Most of these are self explanatory except for those messages that indicate unusual internal conditions. When the I-2000 software detects an unusual or invalid condition, it signal this through a STATUS message and also supplies trace information in an internal INFORMIX table setup specifically to record error messages.

---

## Status Error Messages

**Table B-1. STATUS Error Messages**

---

| Error Code | Number | Error Message                                                                | Description                                                                                                                                                                                                                                                                                      |
|------------|--------|------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ABORT_SYNC | 4539   | "Audit/synchronization autonomously aborted."                                | An audit sync that is in progress has stopped itself due to an internal verification error (software error).                                                                                                                                                                                     |
| ALLOC_ERR  | 1021   | "Memory allocation failed."                                                  | A process was unable to allocate memory from the system memory pool, typically because it is exhausted.                                                                                                                                                                                          |
| ALT_CKTID  | 4505   | "Too many ERP created circuits for the same points. Cleanup database now!!." | The system is running out of internally generated circuit names for these end points in response to echoed responses from the DACS. The circuits created through echoed response should be modified and given proper names. This error will occur for the creation of multi-point circuits only. |

**Table B-1. STATUS Error Messages (Contd)**

| <b>Error Code</b> | <b>Number</b> | <b>Error Message</b>                     | <b>Description</b>                                                                                                                                                                                                                                                                                                                                                                                                           |
|-------------------|---------------|------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B_T_X25_OUTSVC_L  | 5079          | "No more SVC available locally"          | Currently for the FT feature, the selected link is established directly by the X.25 software, if no more SVCs on any link can be found locally, then this message is output.                                                                                                                                                                                                                                                 |
| BAD_ACTION_ST     | 1044          | "The circuit action is invalid"          | A circuit has an invalid status and cannot be normalized (un-altroute).                                                                                                                                                                                                                                                                                                                                                      |
| BAD_BW            | 1045          | "The circuit bandwidth is invalid."      | An invalid bandwidth was received by circuit provisioning, it was less than 1 or greater than 32 channels in width. Typically accompanied by a circuit provisioning failure.                                                                                                                                                                                                                                                 |
| BAD_BWTYPE        | 1046          | "The circuit bandwidth type is invalid." | Internal circuit provisioning checking has received a bad bandwidth type.                                                                                                                                                                                                                                                                                                                                                    |
| BAD_MSG           | 1051          | "The message type is invalid."           | A message was received a software process, but one or more of its internal contents fail consistency checking or some other validation of the parameters. This error message implies an internal software error and should be reported to Technical Support.                                                                                                                                                                 |
| BAD_OPERATION     | 1052          | "The circuit class is invalid."          | Typically accompanied by a circuit provisioning failure, this indicates that the software has received an invalid circuit class (e.g. FDX, HDX....LEG). The circuit class received is not a member of the known circuit classes. This can possibly happen due to database corruption, a software error or an improperly parsed DACS message, all of which imply software defect and should be reported to technical support. |
| BAD_PPR_LST       | 1503          | "The reconfiguration LIST is invalid."   | An error was found in a pre-planned routing list, the list appears to be out of order, the sequence of the list can be altered with the CHECK action.                                                                                                                                                                                                                                                                        |
| BAD_SENDER        | 1517          | "The calling function is invalid."       | A message was received by a process, but from an unknown sender.                                                                                                                                                                                                                                                                                                                                                             |
| BAD_VEFT          | 1056          | "The virtual NPC/channel is invalid."    | The virtual (site only) provisioning command could not be executed because the circuit was not found in the database and no virtual NPC was specified.                                                                                                                                                                                                                                                                       |

**Table B-1. STATUS Error Messages (Contd)**

| <b>Error Code</b> | <b>Number</b> | <b>Error Message</b>                            | <b>Description</b>                                                                                                                                                                                                                                                                                                                                                                        |
|-------------------|---------------|-------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| BBL_NOT_LAST      | 1058          | "The backbone leg must be the last leg."        | When setting up a multipoint circuit (virtual, dmb), the backbone leg must be the last to be deleted. This typically accompanies a circuit provisioning denial.                                                                                                                                                                                                                           |
| CH_SZERR          | 1063          | "The circuit channel is invalid."               | A request was made to operate on a channel that failed validation (e.g. greater than 32), for example an echoed response was received from the DACS that was incorrect.                                                                                                                                                                                                                   |
| DACS_FORK_FAILED  | 1009          | "UNIX system error (cannot fork)."              | An attempt to spawn another process has failed, possibly because of system resources, possibly because the executable for the process cannot be found.                                                                                                                                                                                                                                    |
| DACS_PORT_ERROR   | 1001          | "A site port error occurred."                   | A serial SNIDER port was unable to be opened or configured for unknown reasons, possibly because it is being it is not free for use.                                                                                                                                                                                                                                                      |
| DACSNAME_ERR      | 4517          | "Unable to get site name for system."           | Verification of the DACS "name" has failed, the process has received a message but the associated DACS information is incorrect and is not present in the common database.                                                                                                                                                                                                                |
| DACSNAME_SZERR    | 4529          | "Size error: site name."                        | Similar to DACSNAME_ERR, except the size of the DACS name, as received, fails verification.                                                                                                                                                                                                                                                                                               |
| DB_ERR            | 1023,         | "A database error prevented command completion" | An error was detected reading, writing, opening or closing a database table. In some cases this may be a logical error (i.e. an expected/unexpected record was not found/expected) or it may be a physical error (e.g. the table does not exist).                                                                                                                                         |
| DB_ERROR          | 1096          | "A database error occurred."                    | Redundant with DB_ERR                                                                                                                                                                                                                                                                                                                                                                     |
| DBA_DIE           | 1106          | "The DBA process died"                          | The lock monitor process controls single user access to the database. The lock monitor process has been restarted and the application processes have been notified, all in progress actions are aborted. The lock monitor process will exit if it has encountered an internal software defect, or more likely it is unable to allocation more memory to maintain its lock request queues. |

**Table B-1. STATUS Error Messages (Contd)**

| <b>Error Code</b>  | <b>Number</b> | <b>Error Message</b>                                  | <b>Description</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--------------------|---------------|-------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DBNAME_SZERR       | 4513          | "Size error: input database name."                    | Similar to DACSNAME_ERR, except the associated database to the DACS has failed verification.                                                                                                                                                                                                                                                                                                                                                                                                                             |
| DUPL_PPRID         | 1507          | "The new reconfiguration plan must have a unique ID." | Typically accompanies deny of an ARP request to CREATE a pre-planned route, the ID has already been used.                                                                                                                                                                                                                                                                                                                                                                                                                |
| ERPIDLINE_SZERR    | 4514          | "Size error: echo response ID line."                  | The construction of a line in the ERP log has created a string greater than the maximum size that can be stored in the log. The string has been truncated prior to insertion in the log.                                                                                                                                                                                                                                                                                                                                 |
| HISTORY_FILE_ERROR | 1006          | "A history file error occurred."                      | The process which maintains the DACS message log (history file) was unable to open, close or otherwise set the history file.                                                                                                                                                                                                                                                                                                                                                                                             |
| INCONSISTENT_NPC   | 1070          | "The NPC specification is inconsistent."              | Circuit provisioning detected and internal problem with the NPC number in the provisioning request.                                                                                                                                                                                                                                                                                                                                                                                                                      |
| INV_PARM_ERR       | 1031          | "An invalid parameters error occurred."               | Typically the default of a c language switch statement, and this indicates that an unexpected condition/definition was passed to a software routine. Similar to SOFT_ERR.                                                                                                                                                                                                                                                                                                                                                |
| IPC_FAILURE        | 1005          | "A message failure occurred"                          | This is an error in using the Interprocessor communication facility of UNIX. A variety of failures may account for this, most commonly it is because the receiving process does not exist. This can commonly happen (i.e. normal operations) when a DACS link failure occurs. That is, a message was being sent to the process which handles DACS communications, and the DACS link went down. This was very common in R4.0 and earlier releases. In R4.1.2 and later releases, this is no longer treated as an "error." |
| LP_PIPE_ERROR      | 1008          | "A printer error occurred."                           | As part of printer operations, when printer logging is enabled, the process (e.g. history process to log dacs commands) was unable to open a UNIX communication pipe to the UNIX line printer software.                                                                                                                                                                                                                                                                                                                  |

**Table B-1. STATUS Error Messages (Contd)**

| <b>Error Code</b> | <b>Number</b> | <b>Error Message</b>                                 | <b>Description</b>                                                                                                                                                                                                                                                                          |
|-------------------|---------------|------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MISMATCH_CKT_SQN  | 1508          | "Reconfiguration sequence mismatch."                 | May accompany an Automatic Replan request, when deleting a circuit from the plan, there is a mismatch in the sequencing of the circuit plan.                                                                                                                                                |
| MISMATCH_PPR      | 1509          | "Reconfiguration ID mismatch."                       | The reconfiguration plan ID does not match the ID of the database.                                                                                                                                                                                                                          |
| MISMATCH_VCKT     | 1075          | "The virtual circuit specification is inconsistent." | There is a mismatch between internal virtual circuit number and the internal circuit number.                                                                                                                                                                                                |
| MSG_ERR           | 1012          | "A message processing error occurred."               | A process has received an unexpected message. Each message is keyed with a message type, the processed received a message type it is not coded to handle.                                                                                                                                   |
| MSG_SEQ_ERR       | 5099          | "Message log sequencing error. Details in error log" | During a message log recovery, the DACS, when a link is restored, the message log sequencing is examined, if an out of sequence message is detected, a message is output.                                                                                                                   |
| NO_CKT            | 4533          | "The circuit does not exist."                        | An operation was attempted on a circuit, but that circuit did not exist, i.e. an echoed response was received from a DACS, which operated on a circuit that the I-2000 has no record of, or a pre-planned route operation was requested on a circuit which does not exist.                  |
| NO_PPRCKT         | 1511          | "No such reconfiguration circuit."                   | May accompany an Automatic Replan request. There are no records associated with the requested routing plan.                                                                                                                                                                                 |
| OAM_BAD_PROC_ID   | 3075          | "Bad process ID."                                    | A reference was made to a process which is not identified in the I-2000 system.                                                                                                                                                                                                             |
| OAM_EXEC_FAILED   | 3082          | "UNIX system error (cannot exec process)."           | Similar to OAM_FORK_FAILED.                                                                                                                                                                                                                                                                 |
| OAM_FORK_FAILED   | 3083          | "UNIX system error (cannot fork process)."           | Similar to DACS_FORK_FAILED but applied to the OAM process which is the parent process for all I-2000 processes. OAM was not able to start or restart a process, possibly due to system resources, or due to the fact that the executable does not exist (i.e. program installation error). |

**Table B-1. STATUS Error Messages (Contd)**

| <b>Error Code</b>   | <b>Number</b> | <b>Error Message</b>                                | <b>Description</b>                                                                                                                                                                     |
|---------------------|---------------|-----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| OAM_MSGQ_GONE       | 3085          | "UNIX system error (message queues are gone)."      | A process' message queue has inexplicably been removed from global shared memory.                                                                                                      |
| OAM_NO_USER         | 3098          | "No users."                                         | An error has occurred in trying to read the password file for a user, the user does not exist.                                                                                         |
| OPEN_FILE_ERR       | 1022          | "Failed to open a file."                            | Many processes open and write to files for many different reasons. This signifies that an open, close, read or write of an ordinary UNIX file failed.                                  |
| OVER_MAX_LEG        | 1078          | "There are no more spare legs."                     | The BCON circuit already has the maximum of 99 legs, or the virtual circuit has the maximum of 20 legs.                                                                                |
| PASSTHRU_FAIL       | 2000          | "Passthrough request failed."                       | An error was detected when the user attempted to exit a passthrough session, may be accompanied by other system error output. Typically this was in inability to release resources.    |
| PIPE_FAIL           | 2001          | "Passthrough pipe failed."                          | Similar LP_PIPE_ERROR, but applied to other operations that require UNIX pipes, such as passthrough and other printer actions.                                                         |
| RECEIVE_ERROR       | 1010          | "A receive message error occurred."                 | Interchangeable with IPC_FAILURE when receiving messages.                                                                                                                              |
| SEND_ERR            | 1011          | "A send message error occurred."                    | Interchangeable with IPC_FAILURE when sending messages.                                                                                                                                |
| SHMAT_ERR           | 1020          | "I-2000 failed to attach to shared memory segment." | Shared memory is used to store global information between process. An attempt to attach to the shared memory has failed.                                                               |
| SOFT_ERR            | 1030          | "A software error occurred"                         | A piece of software has encountered a condition it is not prepared to handle. Typically this are indicative of software deficiencies, or unexpected error handling has not been coded. |
| STRING_TOO_LONG     | 1000          | "The message length is bad"                         | The maximum length string that can be passed through a "passthrough" session, or through a "passthrough script" is 140 characters, this has been exceeded.                             |
| TMP_HIST_FILE_ERROR | 1007          | "A temporary history file error occurred."          | Similar to HISTORY_FILE_ERROR                                                                                                                                                          |

**Table B-1. STATUS Error Messages (Contd)**

| <b>Error Code</b>  | <b>Number</b> | <b>Error Message</b>                             | <b>Description</b>                                                                                                                                                                                                       |
|--------------------|---------------|--------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| UI_FORK_FAIL       | 2002          | "Passthrough fork failed."                       | Similar to OAM_FORK_FAILED, except applied to the User Interface process when attempting to start a Passthrough session.                                                                                                 |
| UNEXP_RSP          | 1084          | "An unexpected response was received."           | While waiting for a response to a command sent to the DACS, an unexpected response was received (e.g. not a time-out, or a reply). Typically, indicative of a software defect. The command in progress has been aborted. |
| UNEXPECTED_SIGNAL  | 1004          | "An unexpected signal was received."             | Processes set themselves up to receive and do certain processes upon receiving certain UNIX signals (e.g. alarm clock signal). A process has received a signal it did not expect or set itself up to handle.             |
| X25_OUTSVC_L_B     | 5021          | "No more SVC available locally on Backup link"   | Similar to X25_OUTSVC_L_P, except for the backup link.                                                                                                                                                                   |
| X25_OUTSVC_L_P     | 5020          | "No more SVC available locally on Primary link"  | Similar to B_T_X25_OUTSVC_L, except that for non-FT customers, the link is specified at frame provisioning time. The SVCs on the primary link are exhausted.                                                             |
| X25_OUTSVC_R_B     | 5023          | "No more SVC available remotely on Backup link"  | Similar to X25_OUTSVC_R_P except this occurs on the backup link.                                                                                                                                                         |
| X25_OUTSVC_R_P     | 5022          | "No more SVC available remotely on Primary link" | Similar to X25_OUTSVC_L_P, except the problem is on the remote side of the connection.                                                                                                                                   |
| X25_PROTOCOL_ERROR | 5001          | None.                                            | No longer used.                                                                                                                                                                                                          |

## Troubleshooting

---

There are only two classifications of error, those that indicate system problems and those that indicate an internal software problem (bug).

System problems are listed below and are typically resource issues. Hardware problems usually manifest in more severe ways, such as CPU panic messages, erratic screen or keyboard behavior, or UNIX messages that appear on the system console. Resource problems may also be evident on the system console as well.

### Resource Problems

---

The following errors may indicate resource problems on the I-2000:

- ALLOC\_ERR
- B\_T\_X25\_OUTSVC\_L
- DACS\_FORK\_FAILES
- DACS\_PORT\_ERROR
- DB\_ERR
- DB\_ERROR
- DBA\_DIE
- HISTORY\_FILE\_ERROR
- IPC\_FAILURE
- LP\_PIPE\_ERROR
- OAM\_FORK\_FAILED
- OAM\_EXEC\_FAILED
- OPEN\_FILE\_ERR
- PIPE\_FAIL
- RECEIVE\_ERROR
- SEND\_ERR
- SHMAT\_ERR
- SOFT\_ERR
- TMP\_HIST\_FILE\_ERROR
- UI\_FORK\_FAIL
- X25\_OUTSVC\_L\_P
- X25\_OUTSVC\_L\_B
- X25\_OUTSVC\_R\_P
- X25\_OUTSVC\_R\_B

When one of the errors listed above occurs, take the following actions:

1. Installation problems may cause some of the abnormal behaviors. The user should insure that:
  - Proper amount of RAM has been installed
  - X.25 package has been installed
  - X.25 network is operating properly
  - There are no other software applications using memory, disk and TTY resources.
2. If installation error are not suspect, then typically resource problems occur because of DACS activities. Significant activity on a single DACS or on multiple DACS may exceed the capacity of the workstation. Wait for the activity to diminish.
3. Isolate the offending DACS by observing DACS activity in MUX PASS-THROUGH for each DACS to identify busy DACS and then modify the DACS behavior.
4. If improper behavior is still apparent, the administrator can remove the DACS from service.
5. If this fails, SHUTDOWN the I-2000 and reboot the workstation.

### **Software Failure**

---

All of the above errors that do not appear to be resource problems based on the descriptions above, may indicate a software failure. Typically these occur during some command activity or some autonomous activity as a result of a message from the DACS. Then these occur and cause a command or action to not successfully complete, take the following actions:

1. Write down the STATUS message that appears on the STATUS line.
2. Identify and note the command or action that cause the abnormal STATUS message.
3. Write down the state of the system at the time of the error, including the following information:
  - Which form was being filled out
  - What fields were filled in
4. If the error is associated with some DACS messages (for example, circuit provisioning action, NPC provisioning, or ERP) use REPORTS to display the HISTORY LOG for that DACS and print the last 3 or 4 pages in the log.
5. Perform a backup of the COMMON database to tape.
6. If it is clear that the error was associated with a particular DACS, also backup that particular DACS to another tape.
7. Send all of the above information to your next level of support, identifying this as a possible software problem.

## Error Log

---

The error messages described in Table C-1 also cause an entry in a COMMON database table, called the Error Log. Internally, this is known as the LGSER table and is part of the EMS database. It is possible for field support personnel to obtain this information and insert this information into a CAROD or MR report.

Use the following procedure to obtain the error log and write it to a floppy disk:

1. Log in as **dacsadm**.
2. To obtain the LGSER table entries inserted into the database "today", type the following command:

```
echo "unload to lgser_log select * from lgser  
where erdate=today;" | isql ems
```

3. To obtain all LGSER table entries type the following command:

```
echo "unload to lgser_log select * from lgser" | isql ems
```

4. Write the file to a floppy disk:

```
tar cf /dev/rfd0 lgser_log; eject
```

Write this command on the floppy disk to facilitate retrieval.

---

# Glossary

---

## A

### **Action**

An operation specified to the I-2000 by entry of a predefined value into the **Action** field of many I-2000 forms. The **Action** value is the command verb of the I-2000 user interface. It may generate one or more MML command verbs to the DACS, or it may designate an operation that is strictly local to the I-2000 computer.

### **Activate**

Place in service as a transmission-carrying circuit.

### **Aging**

With reference to alarms, delaying action on the alarm after its receipt.

### **Alarm**

A message sent by an NPC indicating that transmission is impaired. Alarms are classified by cause as Circuit Pack Failure, Carrier Failure (see CGA) and Facility Performance. They are also classified by severity for purposes of response or notification.

### **Alarm Indication Signal (AIS)**

See Blue Alarm.

### **Alarm Monitor Port**

An RS232C asynchronous port of the I-2000 computer. On the port are placed all alarm messages sent to the I-2000 from a DACS. This port was formerly called the alarm broadcast port.

### **A-law**

A set of companding rules used for CEPT transmission. See Compander, Gateway.

### **Alternate Bandwidth**

Channels that are allocated alternately to a high-rate circuit; e.g., 3, 5, 7.

### **Altroute -ed -ing**

Alternate routing of transmissions paths. See also Real Altroute and Pseudo-Altroute.

### **Asynchronous Transmission**

A method of transmitting digital signals in which the bits are sent when they are initiated, rather than in synchronization with a timing signal; for example, keystrokes. Communication between the I-2000 computer and its terminals is asynchronous.

### **Audit**

An I-2000 **Action** under DATABASE ADMINISTRATION by which differences between the I-2000 database and a frame database are tracked and logged.

### **Automatic Reconfiguration Plan (ARP)**

A file containing a sequence of references to Reconfiguration Plans to be executed when the ARP is executed. See also Reconfiguration Plan.

## **B**

### **Backbone Leg**

In a Broadcast Circuit, the transmission source: the one-way circuit from the FROM side to the virtual branch point. In a Polling Data Circuit, it is the branch between the Rx of the transmission EFT and the DMB channel, along with the corresponding Tx side of the same EFT, which branches to the other EFTs without going through the DMB. In the latter case, the Tx branch point is in the CCN only, while the Rx branch point is the DMB channel.

### **Backup Line**

In the I-2000, the SVC designated as a backup line in the FRAME ADMINISTRATION form. It will be the path to the DACS to which the I-2000 automatically reverts when the primary line is not operable.

### **Bandwidth**

The number of channels used for a high-rate circuit.

### **Baud Rate**

The number of bauds per second. One baud, named after J.M.E. Baudot, is one signaling element. For example, in an 8-state code system, one baud is one code representing one state of the 8. If such a code were represented by bits, one baud would be three bits. In a two-state system, one baud is one bit, and the baud rate is identical to the bit rate; however, the term baud rate is preferred when it refers to the speed at which terminals communicate. Here, "baud rate" is used of the terminal line speed and "bit rate" is used of channel transmission speed.

### **Bit Error Rate**

A DACS concept referring to the rate at which wrong bits are received. The number of wrong bits over an interval is calculated from a checksum.

### **Bit Rate**

The speed at which binary digital signals are transmitted, usually expressed in bits per second (bps).

### **Blue Alarm**

Also known as an Alarm Indication Signal (AIS). An all 1s pattern asserted at an intermediary point in a facility when loss of transmission is detected. A yellow alarm is sent in the direction of the loss and a blue alarm is sent downstream. See also Alarm.

### **Boot**

In general, to load and start the operating system of a computer. In the I-2000, boot means to load an I-2000 database with data reflecting the provisioning present in a specified DACS, or to provision the DACS so that it matches provisioning data stated in the I-2000 database.

### **Branch Legs**

In a virtual broadcast circuit, the one-way circuits from the virtual branch point to the broadcast points. In a Polling Data Circuit, a DMB channel takes the place of the virtual branch point on the Rx side. On the Tx side, the branch is in the CCN. See also Backbone Leg.

### **Broadcast Circuit or Cross-connection**

A virtual multipoint circuit, connecting a channel on one side with multiple channels on the other. The cross-connection is one-way, and can be high-rate. Connection is through a virtual node, which is a logical, or software, entity performing the signal switching. The circuit on the FROM side is the Backbone Leg and the circuits on the TO side are the Branch Legs.

---

## C

### **Capacity Expansion Frame (CEF)**

An expanded DACS II frame able to configure up to 2560 NPCs.

### **Carrier Group Alarm (CGA)**

Also called a Carrier Failure Alarm. One of three classes of DACS-II alarms (see Alarm). An alarm asserted by an NAS NPC to indicate loss of an incoming signal or receipt of a remote alarm signal from the other side of the line. The loss of an incoming signal is reported in an output message as a Red Alarm, and an alarm from the other end is reported as a Yellow Alarm. A variety of other types of CGA alarms can be generated. The equivalent type of alarm for CEPT NPCs is a PBA.

### **Cascade**

There are many kinds of cascade in the electronics industry and in the communications business. In general, it signifies a circuit in which one configuration branches to another of its kind indefinitely. With reference to DMB multipoint circuits, a cascade of conferences is achieved when a leg of one conference is simultaneously the leg of another; i.e., two DMB channels are connected. Additional DMB channels can be connected also, leading to a longer cascade of conferences.

### **CEPT Facility**

An NPC terminating DS1 signals that were multiplexed according to the CEPT standard.

### **Channel**

A continuous stream of coded output signals. The channel may be carried by a variety of media, and may be broken into segments for discontinuous transmission. In the I-2000, a channel is a DS0 signal provided by an NPC.

### **Channelized**

Said primarily of DS1 to distinguish it from Clear DS1.

### **Circuit**

A cross-connection between channels. A two-point circuit connects two channels; a multipoint circuit connects more than two. A circuit may be a one-way circuit, where one transmission direction is used for each channel or a circuit may be a two-way circuit, where both transmission directions are used for each channel. Thus, the same channel can be in two active one-way circuits.

### **Circuit Pack**

A hardware module that can be easily installed or removed from a DACS. Units such as power supplies, CCNs and DDCs are implemented as CPs.

### **Clear DS1 Signal**

A nonchannelized, 193-bit DS1 signal on an NAS NPC. The 24 8-bit DS0 channels and one framing bit are cross-connected as one DS1 signal, 193 bits wide.

### **Clear E1 Signal**

A nonchannelized, 256-bit DS1 signal on a CEPT NPC. The 32 8-bit DS0 channels are cross-connected as one DS1 signal, 256 bits wide.

### **Channel**

A DS0-level signal that can be cross-connected in a circuit. Channels are provided by NPCs. An NPC makes available two directions per channel.

### **Channel Associated Signaling (CAS)**

A signaling format in which the signal bits for all channels in an NPC are placed in a signaling channel, separate from the message channels. In CEPT facilities the signaling channel is Channel 31.

**Command**

In the I-2000, a command is, strictly speaking, an MML command generated by an I-2000 **Action**; however, a command may also be, by analogy, any I-2000 **Action**, whether it generates one or more, or no, commands to the DACS.

**Compander**

Compressor-expander, a device used to protect low-level voice volumes from noise by increasing them for transmission; i.e., compressing the range of volumes and expanding the range again at the other end of the transmission. See also A-law and Mu-law.

**Conference**

A multipoint circuit. The Symmetric Voice Circuit most closely fits the English meaning of *conference*, although the term is used of any multipoint circuit. In DMB multipoint circuits, *conference* also means the DMB channel number.

**Conference Number**

The channel number of the DMB side of a leg in a circuit of **Class** DMB. Since one conference includes only one DMB channel, which is used as one side of every leg, this channel number uniquely identifies the conference. For an exception, see under Cascade.

**Conference European Postale et Telephonique (CEPT)**

The standard of DS1 level telephone transmission used predominantly outside the United States. CEPT NPCs consist of 32 channels containing 64 Kilobits per second each. Numbering is from 0 to 31, but not all 32 are ordinarily available to the user: 0 and 31 are not available. Channel 0 is available as a special case in DACS II release 6, as an option under CIRCUIT PROVISIONING.

**Constant Width (CW)**

A typewriter-style typeface used for emphasis; in the I-2000 manuals, primarily to mark field values that you type or that appear on the screen. Displayed messages also are quoted in CW.

**Contiguous Bandwidth**

Channels that are allocated contiguously to a high-rate circuit.

**Contiguous Cross-connections**

Multiple cross-connections such that the channels on the FROM side and the TO side are each consecutively numbered channels in a single NPC.

**Controller**

A device that takes the initiative in sequencing operations, and which uses feedback to make decisions. In the I-2000's case, switching of multiplexed telephone communications is controlled.

**Create**

An I-2000 **Action** used in a number of forms to register an object in the I-2000 database. Some objects that can be created are a DACS and an NPC.

**Cross-connect -ion -ing**

A circuit between two or more channels. The DACS interchanges channels from a time slot in one NPC to another time slot in the same or in a different NPC, as designated by the I-2000. The hardware module that accomplishes cross-connection is the Cross-connect Network (CCN).

**Cross-connect Frame**

Same as Distribution Frame.

**Cross-connect Module (CCM)**

A DACS I hardware unit contained within a CCU and containing up to eight NPCs.

**Cross-connect Network (CCN)**

A hardware module that is used to implement cross-connection. It contains Time Slot Interchangers (TSIs).

**Cross-connect Unit (CCU)**

A DACS I hardware unit containing a maximum of four CCMs.

**Custom Report**

A report for which the format can be changed by use of the Edit Custom Report Format form. A fixed-format report may not be changed in format. Some custom report formats are predesigned and are furnished with the I-2000. These can be selected like fixed-format reports; nevertheless, they can be changed and are custom formats.

---

**D**

**DACS**

Used without further qualification, DACS means any supported, configured cross-connect frame.

**DACS Database**

The I-2000 database that is named with a frame Site Name and stores I-2000 information concerning that frame. This database is distinct from the frame's own database, here termed the *remote* or *facility* database, which is installed on the frame itself.

**DACS I, DACS II**

A Lucent Technologies product that terminates DS3- or DS1-level multiplexed signals and has the capability of separating them into DS0 signals for purposes of cross-connecting them. The I-2000 provides a user-friendly interface to generate the commands that instruct the DACS to perform the appropriate cross-connections.

**Database**

A collection of logically united data. Here, the term does not imply any specific structure of code or organization of data on disk or in memory. The data might be tracked in various ways and be stored at disparate locations. A screen, for example, is not necessarily a record in a file, as it would be in COBOL or PL-1.

**Data Circuit-terminating Equipment (DCE)**

A type of equipment recognized by standards organizations such as the EIA, the CCITT and the ISO. A data circuit is a network equipment configuration that provides data services. The DACS is DCE.

**Dataset**

In DACS II, a stored set of Facility Performance Parameters.

**Data Terminal Equipment (DTE)**

A type of equipment recognized by standards organizations such as the EIA, the CCITT and the ISO. A data terminal is a remote device used with a computer for data input and output: teletypewriters, CRTs and host computers. Each I-2000 terminal is DTE

**Default Disconnect Code (DDC)**

The DDC is a disconnect channel code asserted by an equipped NPC on all of its unmapped channels, unless it is replaced by a value entered into the **IW** field on the NPC PROVISIONING form.

**Delete**

An I-2000 **Action** used in a number of forms to delete an object from the I-2000 database. Some objects that can be deleted are a DACS and an NPC.

**De-grow**

A DACS II term meaning to delete from the frame database perhaps with a DGRTH (de-growth) command in MML. In the I-2000, the DELETE Action takes its place. The DELETE functionality is a superset of DGRTH functionality.

**Digital Multipoint Bridge (DMB)**

A physical module containing the electronic circuits that can establish two types of two-way multipoint circuits, beginning with Release 2.0: the Symmetric Voice Circuit and the Polling Data Circuit. The DMB makes available DMB NPCs and channels, from which the user may select one as the branch point. This DMB channel number is used as the conference number.

**Digital Signal Processing Unit (DSPU)**

A type of DACS unit containing the ICs used to create specialized circuits, such as DMB or subrate. These units contain more specialized TSIs than a CCN.

**Digroup**

For NAS transmission, a digroup is 24 (two groups of 12) DS0-level signals. It is a specific kind of NPC, provided by a DDC.

**Digroup Roll**

The former name of the NPC Roll feature.

**Direct Configuration.**

See Point-to-point.

**Disconnect Channel Code**

A signal, a digital word, that is sent on the unmapped (unassigned) channels of an equipped NPC. If it is not supplied by the operator as an **IW** field value on the NPC PROVISIONING form, the Default Disconnect Code is used.

**Display**

In the I-2000, to display always means to show on the screen.

**Distributing Frame**

A mechanical chassis on which multiple transmission lines are terminated to allow cross-connections of transmission signals. In early equipment, the cross-connections were made by jumpers. Today's frames provide an electronic cross-connection capability.

See DACS II.

**Domestic**

A term in use in earlier DACS documentation and I-2000 manuals to mean North American Standard; however, strictly speaking, it only applies to within the U.S.

**DS0**

A level in the TDM hierarchy, at which one channel is sampled and the digital transmission rate is 64 kilobits per second.

**DS1**

A level in the TDM hierarchy. For NAS transmission, 24 channels are sampled and the transmission rate is 1.544 Mbps. For CEPT transmission, 32 channels are sampled and the transmission rate is 2.048 Mbps.

**DS3**

A level in the TDM hierarchy. For NAS transmission, 672 channels are sampled and the transmission rate is 44.736 Mbps.

**DS3 Unit**

A DACS II hardware module containing a maximum of six DS3 terminations.

**Dual Digroup Card (DDC)**

A DACS II card containing two NPCs for NAS transmission.

**Dual Primary Circuit (DPC)**

A DACS II card containing two NPCs for CEPT transmission.

**Dumb**

Used of terminals; incapable of doing any preprocessing.

---

**E**

**Echoed Response Processing (ERP)**

An Echoed Response Message is a message from a DACS to the I-2000 that is not in response to an I-2000 process waiting for it. Echoed Response Messages often indicate that provisioning has been performed in the DACS but is not matched by provisioning in the I-2000. Echoed Response Processing is I-2000-only NPC or circuit provisioning automatically performed for the purpose of making the I-2000 provisioning match the frame provisioning indicated by the message.

**Encoding**

Representing by 8-bit binary numbers the numbers resulting from quantizing a PAM Signal. See Pulse Code Modulation.

**Enhanced Small Device Interface (ESDI)**

A standard interface, which achieves faster throughput than standard fixed-disk controllers by shifting functionality to the Hard Disk Unit (HDU). It also defines a disk format.

**Environmental Variable**

A shell variable, which can be set by a variety of methods. The I-2000 uses an environmental variable file, .dnrcr, which stores the default values.

**Equipment Provisioning**

Prior to I-2000 Release 3.2, the term used for NPC provisioning in I-2000 forms.

**Equipped**

In the DACS II, "to equip" is to grow with a CRTE command in MML. In the I-2000, the `CREATE Action` performs this function, sending commands to the DACS when necessary. An NPC that has been created can, therefore, be said to have been equipped. "Equipped" is thus a status that is NOT unequipped (UEQD); i.e., a **Service Status** value referencing an object that is described in the I-2000 database. However, no explicit "equipped" **Service Status** is used; instead, IS or OOS is used to mean "equipped" by implication.

**Errored Seconds**

The number of seconds a transmission facility was not working properly over an interval.

**Execute**

In general, to set a software procedure in motion. In the I-2000, "to execute" implies to use the `EXECUTE` special function key to set an I-2000 or DACS procedure in motion; however, sometimes it is used in the general sense.

**Extended Numbering or Addressing**

A system of numbers used to address NPCs in I-2000 forms and DACS commands. Extended numbering maps a whole number from 1 through 2564 to an NPC.

**External Facility Termination (EFT)**

A channel that is coming from outside the DACS and terminates in a DACS II DDC or DPC, or in a DACS I NPC. A node in a multipoint circuit is NOT an EFT.

## **F**

### **Facility**

In the telephone vocabulary, a device for transmitting telephone signals. With reference to a DACS, "facility" is typically used to mean NPC.

### **Facility Performance Alarm Parameters**

One of the categories of DACS alarms (see Alarms). A line status error alarm resulting when errors on a monitored line exceed a stored threshold value for a defined parameter. Microprocessor circuits in the line interface circuits detect and count various types of line error conditions for each NPC. The parameters monitored are the Bit Error Rate, Frame Alignment Errors, Errored Seconds, Severely Errored Seconds, Slips, Degraded Minutes and Unavailable Seconds.

### **Facility Terminating Module (FTM)**

A DACS II hardware module contained in an FTU. The FTM contains up to 20 NPC Cards, supporting 40 digroups, or NPCs.

### **Facility Terminating Unit (FTU)**

A DACS II hardware module mounted on a DACS II. It contains up to 4 FTMs.

### **Far End**

With regard to a cross-connection, the far end is the NPC at the other end of a line terminating in one of the sides of the circuit. Thus, a two-point, single-channel cross-connection has two far ends.

### **Field**

A named and delineated space on the screen, where data entry is expected; also, the logical entity associated with the name. Fields are not necessarily mapped into any scheme of I-2000 data records, C language structures or shell variables; however, all of these devices are utilized to store fields.

### **Form, Screen**

A terminal display showing field names into which you enter data.

### **Form Control Keystroke**

A keystroke that positions the cursor among the fields within a form.

### **Frame**

See Time Frame, Distributing Frame. In this manual, frame is used most often to mean any distributing frame that becomes an object in the I-2000 system through provisioning.

### **Frame Alignment Error**

A concept referring to errors detected in framing bits received. The errors must be severe enough to require the receiver to be resynchronized with the transmitter.

### **Framing, Framing Bits, Framing Word**

The process of marking the beginning of a time frame or two time frames in a PCM stream. The NAS standard uses one bit, the framing bit, making a total of 193 bits per frame. The CEPT standard uses an 8-bit pattern, the framing word, in alternate time slots. The other alternate contains the non-framing word.

**FROM Side**

One side in a cross-connection. For one-way circuits (two-point or multipoint), the FROM side is the channel that sends the transmission (Tx) and the TO side is the channel that receives the transmission (Rx). The name derives from the fact that the DACS II command that establishes the cross-connection identifies the channel number of this point with a FROM qualifier.

For two-way circuits, the second direction of the FROM and TO channels is used. It also has Tx and Rx sides. Thus, the FROM side and the TO side each have a Tx and Rx direction.

**Front End**

Hardware or software that preprocesses data before it is massaged by the main hardware or software under consideration. The I-2000 is a front end to the frame, because it generates frame switching commands.

**Full Duplex Circuit**

A two-way cross-connection.

**Function Key**

One of the keys across the top row of the keyboard. Many of them are assigned special functions in the I-2000. These functions are labeled pictorially in a display line at the bottom of the screen, for functions that are valid with that screen.

---

**G**

**Gateway**

A cross-connection between a channel in an NAS NPC and a channel in a CEPT NPC. For transmission of digitized voice signals, the difference in companding rules must be taken into consideration; i.e., an A-to-Mu Law Conversion may be necessary. This conversion is not necessary for transmission of data signals.

**Generate a Report**

To instruct the I-2000 to create a report in an electronic file. Printing or displaying the file is a separate step.

**Generic**

Formerly the release number of the software and, therefore, the "type" of software. One generic is not necessarily compatible with another. Currently the use of generic has been dropped and "release" is being used instead.

**Grow**

A DACS II term meaning to record an NPC in the frame database with a CRTE command in MML. In the I-2000, the CREATE Action takes its place, and is a superset of it.

---

**H**

**Half Duplex Circuit**

A one-way cross-connection.

**Hierarchical Numbering or Addressing**

A system of numbers used to address NPCs in I-2000 forms and DACS commands. Hierarchical numbering maps, to each NPC, a number consisting of the shelf or unit number followed by the module number followed by the NPC within the module.

**High-rate Circuit**

A single circuit defined to be multiple one-way or two-way two-point cross-connections. The number of cross-connections, which is the same as the number of channels on a side, is the bandwidth. Bandwidth is allocated on channels numbered contiguously or alternately.

**History File**

A file storing I-2000/DACS communications just as they were generated or received, in circumstances for which a history file has been defined.

**Hub Test Configuration, Hub DACS**

A test circuit configuration in which any number of signals to be tested are brought from remote DACSs to a hub DACS and there are routed to test equipment.

---

**I**

**Idle**

A concept based on the IDLE **Action** of Reconfiguration Plan Provisioning. To idle a plan means to restore all circuits acted upon by actions in the plan to their previous status.

**In Service (IS)**

A value that can be had by a status field, indicating that the object referenced by the form is fully operable. For example, if the object is an NPC, an NPC that is IS has been created and restored. Only in-service NPCs can provide transmission.

**INSERT Mode**

A typing mode in which the typed character pushes other characters to the right.

**Insertion Word (IW)**

In general, an insertion word is a signal, an 8-bit data word, that is inserted into a DS0 channel for some reason. The I-2000 defines two types of insertion words:

NPC Provisioning. The *unassigned* insertion word. Entered into the **IW** field of the NPC PROVISIONING form, this word replaces the DDC as a standard disconnect code to be sent on all unmapped (unassigned) channels on an equipped NPC.

Circuit Provisioning. Entered into the **IW** field of the CIRCUIT PROVISIONING form, this word is sent on mapped channels of an NPC after it has gone out of service (carrier or NPC failure).

**Integral Shelf Cross-connect (ISX)**

A member of the DACS II family of products that combines the capacity expanded DACS with the single bay DACS. Offering a subset of DACS II capabilities, it is positioned for smaller applications. Both NAS and CEPT DS0 cross-connects are supported.

**Interval**

In the I-2000, the number of scale units between successive executions of scheduled tasks.

**Italics**

A slanted typeface used for emphasis; in the I-2000 manuals, in quotations and for variable names.

**I-2000 Controller for DACS II**

A controller that offers a user-friendly interface between operators at terminals and multiple DACSs stationed on a Packet Data Network or in a point-to-point configuration.

---

**K**

**Keystroke**

The signal resulting from pressing a key once. Be sure to do so sharply, since more than one keystroke may result from holding the key down.

---

**L**

**Leg**

In a multipoint circuit, the connection from an EFT to the branch point. The branch point can be a virtual node if the circuit is one-way (Broadcast Circuit) or a DMB channel if the circuit is two-way (Symmetric Voice Circuit or Polling Data Circuit).

**Line**

A connection between a computer and a peripheral, such as a terminal. In general, however, a line can be any stream of transmission or facility for carrying it.

**Link**

A connection to a network.

**Link Protection**

The presence of an additional link for every link from the I-2000 to the PDN or from the PDN to the DACS. If the primary link is disconnected, the backup link becomes functional. You can acquire link protection by backing up the port or by merely backing up the link within the port.

**Local Database**

The I-2000 database, named after a DACS Site Name, that stores information concerning the DACS.

**Local-only Mode**

A mode of the EXECUTE function, selected from the WHICH DATABASE? menu. Local-only specifies that the Action implemented by the EXECUTE is to apply to the I-2000 database only.

**Log**

A file containing records of predefined events resulting from various defined circumstances. Some logs are automatically generated by the I-2000; others can be electronically kept by the user in the I-2000.

**Log-in Port**

An asynchronous connection to the I-2000 computer, to which a user terminal is attached.

**Loop Circuit**

A cross-connect in which the Tx direction is connected to the Rx direction of the same channel.

---

## M

### **Man-Machine Language**

A software command language that is used in the human interface to the DACS.

### **Master**

In database audit/synchronization, the database designated as the standard to which other databases are made to conform.

### **Menu**

A list of selections on the screen. Make your selection by pressing  or  when the cursor is opposite the selection.

### **Menu Control Keystroke**

A keystroke that positions the cursor relative to the selections within a menu.

### **Modem**

Modulator-demodulator, a device that converts signals from data processing into signals suitable for transmission over telephone lines (modulation) and vice versa (demodulation). A modem is required to transmit the synchronous signals to and from the PDN.

### **Monitor Test Circuit**

A test circuit configuration in which the Tx and Rx signals in a cross-connection also are received at test ports. The circuit being tested is not interrupted.

### **Multiplexing**

Multiplexing is the combining of a number of signals into one transmission stream. Demultiplexing is the separation of a multiplexed stream into consistent signals. See Time Division Multiplexing.

### **Multipoint Circuit**

A cross-connection in which a signal can be sent from a single source to a number of destinations. A virtual multipoint is one-way and features a virtual node as a branch point. The virtual node is a software entity. A true DACS multipoint is two-way and features a DMB channel as a branch point. See also Broadcast Circuit.

### **Mu-law**

A set of companding rules used for NAS transmission. See Compander, Gateway.

---

## N

### **NAS Facility**

An NPC terminating DS1 signals that were multiplexed according to the Time-Division Multiplexing (TDM) hierarchy in use in the North American Standard (NAS).

### **Near End**

With regard to a cross-connection, the near end is the cross-connected NPC in the DACS on which you are working in the I-2000 system.

### **Network**

A set of communication pathways. Networks consist of nodes connected by links.

**Network Address**

In the FRAME PROVISIONING form, the address of the synchronous link between the PDN and the DACS. This link must already be operable. The "address" is in the form of the link's telephone number.

**Network Processing Circuit (NPC)**

As used in this manual, an NPC is any IC that provides terminations for cross-connection. FTU NPCs in the DACS II and CCU NPCs in the DACS I provide EFTs, but other types of NPC, such as DMB and Subrate, provide other types of terminations. In the DACS I, an NPC is implemented as one CP, but in the DACS II, the NPC is one digroup on a DDC or DPC, which is implemented as a CP.

**Non-framing Word (NFW)**

The 8 bits of time slot 0 in alternate DACSs of a CEPT transmission. The other alternates contain the framing word.

**Normalize**

Return an ALTROUTED circuit to its original path or a PREEMPTED circuit to ACTIVE.

**North American Standard (NAS)**

A standard of transmission in use in the United States and elsewhere. Within the US it is termed domestic.

**NPC Provisioning**

The process of growing NPCs through use of the NPC PROVISIONING form. Prior to release 3.2, this was called the EQUIPMENT PROVISIONING form.

**NPC Roll**

The transfer of all the circuits connected to an NPC to another NPC. Only certain kinds of NPC can be rolled.

**NULL Status**

A value returned to a status field, after you press , when no record of the object described by the form exists in the I-2000 database. An example of an object that can have a NULL status is a login port.

---

**O**

**One-way Cross-connect or Circuit**

A cross-connect that utilizes only one transmission direction.

**Operator**

As used in the I-2000, a person who has logged on with a login and password assigned by the system administrator. An operator does not have access to the selections listed on the SYSTEM ADMINISTRATION menu.

**Outage Log**

A DATABASE ADMINISTRATION feature by which the system administrator is allowed to keep electronic logs of NPC or circuit outages, and can print a log at any time.

**Out of Service (OOS)**

A value that can be had by a status field indicating that the object referenced by the form exists in the database but is not yet operable. For example, an NPC that is OOS is equipped but is not placed in active service. An out-of-service NPC cannot be expected to transmit data.

**OVERLAY Mode**

A typing mode in which the typed character replaces the character on which it is typed.

---

**P**

**Packet Data Network (PDN)**

A network on which data is transmitted by breaking it up into packets. Commonly, the X.25 protocol is used in a PDN. Connection to a customer X.25 PDN by the I-2000 is through the X.25 Interface Board. See also Switched Virtual Circuit, X.25.

**Passthrough**

A special mode of the I-2000, which allows an operator at an I-2000 terminal to communicate directly to a DACS as though the terminal were a DACS terminal.

**Passthrough Control Keystroke**

A keystroke that positions the cursor in passthrough mode.

**Pattern Matching Buffer**

The logical entity that stores keystrokes as you type them.

**Pending**

Said of circuits that exist in the I-2000 only and are marked with a `PENDING` **Ckt Status**. They are waiting to be activated.

**Performance Alarm**

See Facility Performance Alarm.

**Permanent Virtual Circuit (PVC)**

A virtual circuit set up for longer than the duration of a call on an X.25 Packet Data Network; i.e., across calls.

**Point-to-point**

Used of a connection between pieces of hardware (nodes) where a network does not intervene.

**Polling Data Circuit**

A type of multipoint circuit in which the backbone leg broadcasts information (polling) to the branch, or tributary legs, and they return the replies through a DMB to the backbone leg.

**Port**

A physical and logical connection to a computing system. The I-2000 features asynchronous, RS232C ports for its operator terminals and also for the Alarm Broadcast Port. These ports are provided by the IPC-900 and IPC-1600 Boards. Synchronous ports, for connection to the PDN, are provided by GPSC-AT/E Boards.

**Preempt -ing, -ed, -ion**

Deactivate a circuit and place it in `PREEMPTED` **Ckt Status** so that one or more of its channels can be used by another circuit.

**Primary Block Alarm (PBA)**

An alarm asserted by a CEPT NPC. A variety of PBA alarms can be generated. The equivalent type of alarm for NAS NPCs is a CGA.

**Primary Line**

In the I-2000, the SVC designated as primary in the FRAME ADMINISTRATION form. It will be the path over which the I-2000 will communicate with the DACS, so long as that SVC is operable.

**Print**

In the I-2000, to print is always to place on the printer; i.e., you never "print" to screen.

**Protocol**

A conventional format and set of rules for initiating, maintaining and terminating data communications. The I-2000 utilizes one of two for communication with each DACS: SNIDER or X.25.

**Provisioning**

The process of making available various communications resources. In the I-2000, the resources are mainly NPCs and circuits.

**Pseudo-Altroute**

An altroute in which each channel end is altouted to itself. Note that a pseudo-altroute does not merely reroute to the same circuit: an altroute in which the channel ends are reversed is a real altroute, even though the circuit is the same. See also Real Altroute.

**Pulse Amplitude Modulation (PAM) Signal**

A stream of pulses resulting from Pulse Code Modulation of an analog signal. See Time Division Multiplexing.

**Pulse Code Modulation (PCM)**

Digital transmission of an analog voice signal by converting it into a digital signal.

---

**Q**

**Quantizing**

Assigning numbers to the amplitudes of the pulses in a PAM Signal. See Pulse Code Modulation.

---

**R**

**Real Altroute**

Alternate routing of circuits to different end points. See also Pseudo-Altroute.

**Reconcile**

In the I-2000, making the I-2000 databases and the frame databases contain the same or nearly the same NPC and circuit configuration data. Alarm data also can be reconciled. "To reconcile" can be to use the **RECNCILE** key or to perform a database synchronization.

**Reconfiguration**

In the I-2000, the alteration of a circuit in any way, whether by changing its **Ckt Status** or its terminations.

**Reconfiguration Plan (RP)**

A defined collection of circuit provisioning actions.

**Red Alarm**

A CGA alarm signaled by an NPC when it detects loss of transmission. See also Alarm.

**Red-lined**

Selected out for some purpose. In the I-2000, circuits can be red-lined via the RDL D **Option** for purposes of not being allowed to be disconnected without additional authorization.

**Released**

See Terminate and Leave Activated, Released.

**Remote Database**

The frame-installed database utilized by the DACS to record provisioning information. The DACS contains this database of its own even if it is not connected to an I-2000.

**Remove**

As used in the I-2000, to take an object out of service. Some objects that can be removed are an asynchronous port, a synchronous link, a DACS and an NPC.

**Reset**

A restart of a computer's executive software. Turning the power switch off and on accomplishes a reset, but there is typically a reset button. Reset of the I-2000 is not recommended; instead, shut it down, if possible.

**Restore**

As used in the I-2000, to place an object in service. Some objects that can be restored are an asynchronous port, a synchronous link, a DACS and an NPC. The term is also applied to retrieving a database from backup.

**Robbed-Bit Signaling**

A signaling format in which the signal bits associated with a DS0 channel overwrite some of the message bits in that channel.

**Root**

The highest-level directory of any UNIX system. In the I-2000 system, root is the initial login of the system and also grants full access to it. The root password is the password associated with root.

---

## S

**Scale**

In the I-2000, the unit in which time frequency is measured: MINUTES, HOURS, DAYS.

**Schedule**

In the I-2000, to place an `EXECUTE` on queue, to be executed at the time and frequency specified in the scheduling insert.

**Screen, Form**

A terminal display showing named fields into which you enter data.

**Search Criteria**

In the I-2000, a field value or range of values, specified on a SEARCH CRITERIA form, that restrict the scope of the report data to be found by keying in on that field.

**Severely Errored Seconds**

A concept referring to the number of seconds transmission was severely impaired on a facility.

**Severity**

The importance of an alarm message. Three severities are recognized: Major (MAJ), Minor (MIN) and Informational (Inf).

**Side**

One of two duplicate NPCs with the same address provided by a DMB circuit pack. They are identified as Side 0 and Side 1.

**Signaling**

A method of sending network-level signals bits, which can be used in the transmission network to determine the treatment of DS0 channels at the receiving side of the transmission. Channel Associated Signaling and Robbed-Bit Signaling are two commonly used signaling formats.

**Slip Error**

A transmission concept referring to a difference in the number of bits received on a facility over an interval relative to the number expected.

**Small Computer Systems Interface**

An interface established to support mass storage for microcomputers and minicomputers. Published in ANSI Standard X3.131, it defines a standard for attaching intelligent peripherals to computers. In the case of HDUs, SCSI defines a disk format also.

**SNIDER**

The Asynchronous Data Link Protocol, an EIA RS-449 based AT&T handshaking routine used to handle input transactions to a DACS and output messages from it.

**Speed**

The baud rate over an asynchronous line. The I-2000 offers baud rates of 1200, 2400, 4800, or 9600.

**Split Test Circuit**

A test circuit configuration in which the circuit being tested is broken and its traffic is rerouted to test ports.

**Stand-alone**

Hardware or software that function without the assistance of other hardware or software. A DACS can be used as a stand-alone device, without either the I-2000 or the DACScan-2000 Controller C-Module.

**Status or Service Status**

In the I-2000, one of a number of fields not accessible to the user, which display the current pre-defined mode of activity of an object. Some of the objects that have a status are a login port, a synchronous link, an NPC and a circuit. Sometimes state is used as a synonym. Some of the major status values are IS (In Service), OOS (Out of Service), UEQD (Unequipped), NULL.

**Subchannel**

A facility provided by the DS0-B format.

**Subrate**

A facility consisting of less than the full bit rate available on a DS0 channel. Subrate facilities are available at 2.4 Kbps, 4.8 Kbps, 9.6 Kbps, and 56 Kbps. Two formats are available, DS0-A and DS0-B.

**Subrate Multiplexer**

The hardware module that provides two-point subrate circuits.

**Subrate Multipoint Junction Unit**

The hardware module that provides multipoint circuits between sub-channels.

**Switched Virtual Circuit (SVC)**

A virtual circuit set up for the duration of a call on an X.25 Packet Data Network. An X.25 card provides 20 SVCs. Each installed DACS reserves one for its primary link and possibly another for backup.

### **Symmetric Voice Circuit**

A type of circuit in which all (possibly more than two) the terminations are on-line all the time; i.e., all the legs are two-way circuits. Symmetric voice circuits provide customers with the ability to carry on round table discussions. This is one type of DMB circuit.

### **Synchronize, Synchronization**

To make predefined logical objects contain the same or similar data in parallel. An example of parallel objects are the time and date in both the I-2000 and a DACS. Synchronization is also an I-2000 **Action** under DATABASE ADMINISTRATION by which differences between the I-2000 database and the frame database for a given DACS are reconciled, subject to certain restrictions. This is termed "scheduled" synchronization. Echoed Response Processing also performs some automatic synchronization. Synchronization of alarm information can be turned on or off in I-2000 CIRCUIT PROVISIONING.

### **Synchronous Modem Eliminator (SME)**

A line device for simulating a network connection by providing synchronous timing signals. In I-2000, SMEs can be used to establish a direct connection with an X.25 interface, which normally connects to a PDN.

### **Synchronous Transmission**

A method of transmitting digital signals in which the bits are moved in synchronization with a cyclical timing signal.

### **System Administrator**

As used in the I-2000, a person who has logged on as dacsadm with the root password. The system administrator has access to the selections listed on the SYSTEM ADMINISTRATION menu.

---

## **T**

### **Task**

As used in the I-2000, a set of commands or an I-2000-only operation that has been initiated on the I-2000 system with the **EXECUTE** key. It may or may not be identical with one or more UNIX tasks. An I-2000 task may be executed in the background or foreground, or may be placed on queue for scheduled execution.

### **TDM Hierarchy**

A set of digital levels determining the number of channels that will be sampled during one time frame in Pulse Code Modulation transmission. Since the time frame is fixed at 1/8000 sec., a number of channels implies a digital transmission rate. For example, at the DS0 level, 1 channel is sampled and the rate is 0.064 Mbps. At the DS1 level for the NAS, 24 channels are sampled and the rate is 1.544 Mbps. The higher rate comes from the greater number of words per frame. For the CEPT standard, 32 channels are sampled and the transmission rate is 2.048 Mbps. See Time Division Multiplexing.

### **Test Access**

Cross-connecting test ports in test circuits.

### **Terminate And Leave Activated, Released**

A term that is somewhat ambiguous in English, but is to be construed as follows. "Terminate" means "end normal traffic on this circuit". "Terminate And Leave" makes the inhibition of normal traffic a condition that can be switched on or off. "Terminate And Leave Activated" (TLA) activates the condition, ending the traffic. "Terminate And Leave Released" (TLR) releases the condition, restoring the traffic.

**Test Port**

Two contiguous channels that have been designated as a test port through TEST PORT PROVISIONING. They must be located in an NPC that has been designated as a Test Port Group.

**Test Port Group**

An equipped NPC that has been further designated as a collection of test ports through TEST PORT PROVISIONING.

**TG80**

A hardware module that makes available Clear DS1 in the DACS II.

**Threshold**

An error rate below which no alarm is generated for a Facility Performance Parameter. A DACS II stores sets of Facility Performance Parameter Thresholds for each performance parameters.

**Time Division Multiplexing (TDM)**

The multiplexing of a number of channels for transmission purposes by taking samples of the signal on each channel at time intervals.

Sampling occurs once every time frame, where the time frames are contiguous. Since the sampling rate is 8000 samples per sec., a time frame is 1/8000 sec.

The number of channels sampled depends on the level in the TDM hierarchy at which multiplexing has been designed to operate. See TDM hierarchy. A DACS II assumes multiplexing is at the DS1 or DS3 levels.

One sample of one channel obtains a number representing the amplitude of the signal on that channel. The resulting stream of numbers is termed a Pulse Amplitude Modulation (PAM) Signal.

The PAM outputs from each channel for one frame are switched sequentially into a common encoder, which represents each one by an 8-bit word. The frame can then be sent as a stream of 8-bit words. The conversion of pulses into words is called Pulse Code Modulation (PCM).

In the transmission phase, the frame of words is transmitted via a single line. At the far end of the line, the PCM signal is converted back to analog signal in demultiplexing.

**Time Frame**

A 1/8000 sec. time interval within which analog signals are sampled for digitization and transmission. See Pulse Code Modulation, Time Division Multiplexing.

**Timeout**

A time to wait after the onset of some condition before the software takes action concerning it.

**Time Slot**

A timed position in a formatted stream of 8-bit words resulting from TDM. An NAS NPC provides time frames of 193 bits divided into 24 channels plus one framing bit. The first 8 data bits are time slot 0, channel 1, the second 8 are time slot 1, channel 2, etc.

A CEPT NPC provides time frames of 256 bits divided into 32 channels. The first 8 bits are time slot 0, channel 0, the second 8 are time slot 1, channel 1, etc. Time slot 0 in alternate frames contains a framing word. The other frame contains signalling information in those bits, called the non-framing word.

**Time Slot Interchanger (TSI)**

One of many circuits within a CCN that accomplish cross-connection by routing output from a time slot in one NPC to a time slot in another (or the same) NPC.

**Time Zone (TZ)**

A region whose conventional clocks are set at the same displacement from Greenwich Mean Time (GMT). UNIX treats daylight savings time as an alternate time zone (ATZ). It has a different displacement from GMT, even though its displacement applies to the same region as does the TZ. UNIX is programmed to change between the TZ and the ATZ twice a year. Since the day of one change varies from year to year, the UNIX administrator must set the days of change once a year in the TZ command. The I-2000 provides an interface to enter a TZ command.

**TO Side**

One side in a two-point cross-connection. In one-way circuits, the TO side is the receiving side (Rx). Its name is derived from the fact that the frame command that establishes the cross-connection identifies the channel number of this point with a TO qualifier. In two-way circuits, the second direction also has a Tx side and Rx side. Thus, if two channels are connected in a two-way circuit, the FROM side and the TO side each have a Tx and Rx side.

**Transparent**

For the object of which it is predicated, not exhibiting any of its distinguishing characteristics. To the DACScan-2000 Controller C-Module operator, the I-2000 is transparent.

**Tributary Leg**

Same as branch leg.

**Trunk Conditioning Code**

A code associated with cross-connected channels or a provisioned test port. The code tells the DACS what signals to place on each channel if the facility fails. It indicates signaling bits to be sent in each direction on the circuit for the first 2.5 seconds after transmission is lost and another set to be sent thereafter.

**Two-point Circuit or Cross-connection**

A cross-connection between two DS0 channels.

**Two-way Cross-connection**

A two-point cross-connection that connects the channels in both transmission directions.

**Type**

The kind of NPC, where "type" gets its significance from the **Type** field of the NPC PROVISIONING form. Different types of NPC are provided by different hardware modules.

---

**U**

**UB**

A DACS II power unit.

**Unassigned Multiplexer Channel Code**

A value of Hex 18, or 00011000. A code that is sent as the disconnect channel code on unmapped channels of a provisioned NPC when the DS1 lines terminate at the far end on DDS second stage multiplexers.

**Unequipped (UEQD)**

A value returned to a status field, after you press , when no record of the object described by the form exists in the I-2000 database. The major objects referenced by this status are an NPC or a DACS.

**Unprovision**

A term used in this manual to mean to remove from the I-2000 database, after having taken out of service.

**Upload**

An I-2000 **Action** under DATABASE ADMINISTRATION, by which the current provisioning of a DACS is recorded in the I-2000 database, subject to certain restrictions.

**Upper NPC**

The higher-addressed NPC of the two contiguously numbered DMB NPCs that must be grown at a time.

---

**V**

**Virtual**

Apparent, simulating some function or other entity, but not actually it. "Virtual memory", for example, is not really electronic memory, but is disk storage space.

**Virtual Multipoint Circuit**

A Broadcast Circuit. It is called virtual because the connection is not provided by a DMB, as it is in a true multipoint circuit. Instead, it is a software emulation.

**Virtual Node**

The branch point in a Virtual Multipoint Circuit. It is not a channel of a DMB NPC, as it is in DMB multipoint, but is a software emulation. Ordinarily the virtual node is system-selected from the 0 through 500 range.

---

**W**

**White Space**

Characters, such as blanks, that have no meaning to the system and are treated as blanks.

**Wild-card Character**

More technically called a metacharacter, it is a character that can stand for a defined range of other characters in a name, just as a joker can stand for any other card when jokers are wild. The major I-2000 metacharacters are \*, which can replace any number of characters, and ?, which can replace one character.

**Window**

A delineated work region on the screen. In the Sun systems, more than one window can be in use. The background is termed the root window. In other systems, you get only the root window. There is no continuity between windows.

---

## X

### X.25

An AT&T implementation of CCITT Recommendation X.25, a packet-switching protocol defining standards of communication between DTE and DCE; i.e., the DTE/DCE interface. The recommendation defines the physical, data link, and network layers of the Reference Model For Open Systems Interconnection, an international convention for data communication.

---

## Y

### Yellow Alarm

A CGA alarm sent by an NPC in the direction of transmission when it detects loss of signal. At the same time, the card signals a red alarm to its own DACS. If the line is down, the yellow alarm will not be received, and both sending and transmitting frames will signal red alarm. See also Alarm.

---

## Abbreviations and Acronyms

---

**4GL**  
Fourth-generation language

---

### A

**A**  
Alarm indication signal

**ac**  
Alternating current

**Ac**  
Alternating current

**adm**  
Administrat-or, -ive

**admn**  
Administrat-or, -ive

**AIS**  
Alarm Insertion Signal

**Alm**  
Alarm

**ALM**  
Alarm

**ALMS**  
Alarms

**alt**  
Altroute

**ATZ**  
Alternate Time Zone

**ANSI**  
American National Standards Institute

**arp**  
Automatic Reconfiguration Plan

**ARP**  
Automatic Reconfiguration Plan

**ASCII**  
American Standard Code for Information Interchange

**AT&T**  
American Telephone and Telegraph

---

### B

**b**  
Bits

**B**  
Bytes

**B**  
Both red and yellow alarms

**BBL**  
Backbone leg

**BCD**  
Business Communications Device

**Bd**  
Baud

**BER**  
Bit-error rate

**bf**  
Boldface

**BF**  
Boldface

**BMTR**  
Backup Memory Transfer Alarm

**bps**  
bits per second

**BPSS**  
Basic Packet-Switching Service

**BRD**  
Broadcast

---

### C

**CAS**  
Channel Associated Signaling

|                                                                                   |                                                |
|-----------------------------------------------------------------------------------|------------------------------------------------|
| <b>CCB</b><br>Cross-connect Buffer                                                | <b>CLR</b><br>Clear                            |
| <b>CCI</b><br>Clock and control interface                                         | <b>cmd</b><br>Command                          |
| <b>CCITT</b><br>Comite Consultatif International<br>Telegraphique et Telephonique | <b>CNC</b><br>Customer Network Controller      |
| <b>CCM</b><br>Cross-connect Module                                                | <b>COFA</b><br>Change of Frame Alignment Error |
| <b>CCN</b><br>Cross-connect Network                                               | <b>COMCODE</b><br>Component Code               |
| <b>CCNI</b><br>CCN interface                                                      | <b>cond</b><br>Condition                       |
| <b>CCU</b><br>Cross-connect Unit                                                  | <b>CP</b><br>Circuit Pack                      |
| <b>cd</b><br>Change Directory                                                     | <b>CPU</b><br>Central Processing Unit          |
| <b>CEF</b><br>Capacity Expanded Frame                                             | <b>CR</b><br>Critical                          |
| <b>CEPT</b><br>Conference European Postale et Telepho-<br>nique                   | <b>CRC</b><br>Cyclic Redundancy Check          |
| <b>CGA</b><br>Carrier-group alarm (carrier group = digroup)                       | <b>CRIT</b><br>Critical                        |
| <b>Ch</b><br>Channel                                                              | <b>CRO</b><br>Clock Reference Oscillator       |
| <b>CH</b><br>Channel                                                              | <b>CRT</b><br>Cathode Ray Tube                 |
| <b>Chan</b><br>Channel                                                            | <b>CRTE</b><br>Create                          |
| <b>CHAN</b><br>Channel                                                            | <b>CSS</b><br>Controlled slip seconds          |
| <b>CHG</b><br>Change                                                              | <b>Ctrl</b><br>Control                         |
| <b>CI</b><br>Communications interface                                             | <b>CTS</b><br>Clear to Send                    |
| <b>Ckt</b><br>Circuit                                                             | <b>CUS</b><br>Customer                         |
| <b>CKT</b><br>Circuit                                                             | <b>CV</b><br>Coding violation                  |
| <b>ckts</b><br>Circuits                                                           | <b>cw</b><br>Constant Width                    |

## Abbreviations and Acronyms

---

**CW**  
Constant Width

---

### D

**DACS**  
Digital Access and Cross-connect System

**dacsadm**  
DACS administrator

**DB**  
Database

**dc**  
Direct current

**DCC**  
Disconnect-channel code

**DCD**  
Data Carrier Detect

**DCE**  
Data Circuit-terminating Equipment

**DCON**  
Disconnect

**dd**  
Day (2 chars.)

**DD**  
Day (2 chars.)

**DDC**  
Default Disconnect Code

**DDC**  
Dual-digroup card

**DDS**  
Digital Data System

**DE**  
Digroup-enhanced

**DEV**  
Device

**DEX**  
Digital Electronic Cross-connect System

**DGRTH**  
De-growth

**DISC**  
Disconnect

**DM**  
Degraded Minutes

**DM**  
Dual multiplexer

**DMA**  
Deferred Maintenance Alarm

**DMB**  
Digital Multipoint Bridge

**DPC**  
Dual primary circuit

**DSPU**  
Digital Signal Processing Unit

**DSR**  
Data Set Ready

**DSX**  
Digital Signal Cross-Connect

**DS0**  
Digital signal level 0

**DS1**  
Digital signal level 1

**DS3**  
Digital signal level 3

**DS3U**  
DS3 Unit

**DSPI**  
Digital Signal Processing Interface

**DTE**  
Data Terminal Equipment

**DTR**  
Data Terminal Ready

---

### E

**E**  
Extended

**ECCN**  
Extended or Expanded cross-connect network

**ECEF**  
Extended Capacity Expanded Frame

**EDDC**  
Enhanced Dual Digroup Circuit

**EDPC**  
Enhanced Dual Primary Circuit

**EER**  
Excessive error rate

**EFT**  
External Facility Termination

**EIA**  
Electronic Industries Association

**EISA**  
Extended Industry Standard Architecture

**eq**  
Equipment

**EQD**  
Equipped

**EQL**  
Embedded Query Language

**EQPT**  
Equipment

**ERM**  
Echoed Response Message(s)

**ERM**  
Errored Minutes

**ERP**  
Echoed Response Processing

**ERS**  
Errored Seconds

**ES**  
Errored seconds

**Esc**  
Escape

**ESD**  
Electrostatic discharge

**ESDI**  
Enhanced Small Device Interface

**ESQL**  
Embedded Structured Query Language

**EST**  
Eastern Standard Time

**ETSI**  
Extended time slot interchange

**Ext**  
Extended

**Extd**  
Extended

---

## **F**

**F**  
Female

**FACE**  
Framed Access Command Environment

**FAX**  
Facsimile

**FC**  
Format converter

**FDD**  
Floppy Disk Drive

**FDX**  
Full duplex

**FE**  
Far end

**FEBE**  
Far end block error

**FFER**  
Frame Format Error rate

**FLI**  
Facility Line Interface

**FMLI**  
Form and Menu Language Interpreter

**FMT**  
Format

**Fr**  
From

**FR**  
From

## Abbreviations and Acronyms

---

**FRER**

Framing errors

**FTM**

Facility Terminating Module

**FTMI**

Facility Terminating Module Interface

**FTU**

Facility Terminating Unit

**FUAS**

Far end unavailable seconds

**FW**

Framing Word

---

**G****GMT**

Greenwich Mean Time

**GPSC**

General Purpose Synchronous Controller

**GRP**

Group

**GRTH**

Growth

---

**H****H**

Hierarchical

**HDU**

Hard Disk Unit

**HDX**

Half duplex

---

**I****IC**

Integrated Circuit

**ID**

Identifier or identification

**IDL**

Idled

**IF**

Interface

**IMX**

Informix

**INCL**

Inclusive

**INFO**

Informational

**ipc**

Interprocess communications

**IP**

Internet Protocol

**IPC**

Intelligent Ports Card

**IRQ**

Interrupt request

**IS**

In service

**ISA**

Industry Standard Architecture

**ISO**

International Organization For Standardization

**ISX**

Integral Shelf Cross-connect

**IW**

Insertion Word

---

**K****k**

Kilo or x 1000

**kb**

Kilobits

**kB**

kilobytes

**KB**  
kilobytes

**kbd**  
Keyboard

**KBD**  
Keyboard

**Kbps**  
Kilo-bits per second

---

**L**

**L**  
Local multiframe alarm

**LAN**  
Local Area Network

**LED**  
Light Emitting Diode

**LFER**  
Line Format Error rate

**lgn**  
Login

**LMA**  
Local Multiframe Alarm

**LMA**  
Loss of Multiframe Alignment

**Loc**  
Location

**LOFA**  
Loss of Frame Alignment

**LOS**  
Loss of Signal

**LP**  
Logging Printer

---

**M**

**M**  
Male

**M**  
Remote multiframe alarm

**M**  
Mega or x 1,000,000

**Maj**  
Major

**MAJ**  
Major

**MAX**  
Maximum

**Mb**  
Megabits

**MB**  
Megabytes

**MB**  
Multipoint Bridge

**Mbps**  
Megabits per second

**MC**  
Main Controller

**MCOND**  
Maintenance Condition

**MEM**  
Memory

**MER**  
Multiframe errors

**MI**  
Minor

**MI**  
Maintenance information

**MIN**  
Minor

**Mj**  
Major alarm

**MJ**  
Major alarm

**MJ**  
Multipoint Junction Unit

**MJU**  
Multipoint Junction Unit

**MMFG**  
Multiplexer-Multiplexer Interface Unit Functional Group

## Abbreviations and Acronyms

---

**mml**  
Man Machine Language

**MML**  
Man Machine Language

**mmm**  
Month (3 chars.)

**MMM**  
Month (3 chars.)

**MN**  
Minor Alarm

**MP**  
Multipoint

**msg**  
Message

**mux**  
Multiplex, -ed, -ing, -or

**MUX**  
Multiplex, -ed, -ing, -or

**MIX**  
DS1 to DSX Multiplexer

---

## N

**NAM**  
No a-to-mu-law conversion

**NAS**  
North American Standard

**NAU**  
Network-access unit

**NE**  
Near end

**net**  
Network

**NFS**  
Non-framing Word Setting

**NFW**  
Non-framing Word

**NI**  
Network Interface

**NMS**  
Network Management System

**NPC**  
Network Processing Circuit

**NPCTP**  
NPC Test Port

**NTR**  
No Transmit

**Num**  
Number

---

## O

**OCON**  
One-way cross-connect

**OFS**  
Out-of-frame seconds

**OOF**  
Out of Frame

**OOS**  
Out of service

**O&M**  
Operation and Maintenance

**openwin**  
OpenWindows

---

## P

**PAM**  
Pulse Amplitude Modulation

**PARAM**  
Parameter

**passwd**  
password

**PB**  
Primary block

**PBA**  
Primary Block Alarm

**PBF**  
Primary block failure

**PC**  
Personal computer

**PCM**  
Pulse Code Modulation

**PDN**  
Packet Data Network

**PDS**  
Product Documentation Standard

**PEC**  
Price Element Code

**PII**  
Peripheral Interrupt Interface.

**PMA**  
Prompt Maintenance Alarm

**PU**  
Power Unit

**PVC**  
Permanent Virtual Circuit

**PWR**  
Power

**RCNCILE**  
Reconcile

**RDL**  
Red-lined

**rlogin**  
Remote login.

**RMA**  
Remote Multiframe Alarm

**Rmks**  
Remarks

**RMV**  
Remove

**RP**  
Restoration or restoral priority

**RP**  
Reconfiguration Plan

**RST**  
Restore

**RTS**  
Request to Send

**Rx**  
Receive

---

## Q

**QIC**  
Quarter-Inch Cartridge

---

## S

**s**  
Second(s)

**SAFE**  
Shelf Alarm Far End

**SANE**  
Shelf Alarm Near End

**SC**  
Signal(ing) Conversion

**SCSI**  
Small Computer Systems Interface

**SE**  
Standard Engine

**Seq**  
Sequence

**SERS**  
Severe errored seconds

---

## R

**R**  
Red alarm

**RAI**  
Remote Alarm Indicat-or -ion

**RAIS**  
Remote AIS

**RAM**  
Random Access Memory

**RBER**  
Remote bit error rate

## Abbreviations and Acronyms

---

**SES**

Severe errored seconds

**SEV, sev**

Severity

**SFI**

Synchroniz-er -ation Failure Indicat-or -ion

**SHMEM**

Shared memory

**SIMM**

Single In-Line Memory Module

**SME**

Synchronous Modem Eliminator

**SQL**

Structured Query Language

**SR**

Subrate (multiplexer)

**SRD**

Software Release Description

**SRM**

Subrate Multiplexer

**SSP**

Synchronizer Sync Port

**Str**

String

**stty**

Set tty

**Sub**

Subunit

**SV**

System V

**SVC**

Switched Virtual Circuit

**SW**

Software; switch

**SXC**

Synchronizer cross-connect

**SYNC**

Synchronizer, Synchronization

---

**T****TB**

Time Base

**TC**

Trunk conditioning

**TCP**

Transport Control Protocol

**TCS**

T-Carrier Cross-Connect System

**TDM**

Time Division Multiplexing

**TE**

Timing Extractor

**Telco**

Telephone Company

**terminfo**

Terminal information

**tid**

Terminal ID

**TID**

Terminal ID

**TLA**

Terminate and Leave Activated

**TLI**

Time link interface

**TLR**

Terminate and Leave Released

**TP**

Test port

**TPG**

Test Port Group

**TRB**

Trouble word

**TREF**

Timing reference

**TRSP**

Transparent signaling

**TSI**

Time Slot Interchanger

**TS0**

Time slot zero

---

**W**

**TS0M**

Time Slot 0 Monitor

**WGS**

Work-Group Station

**tty**

Teletype

**Tx**

Transmit

---

**Y**

**TZ**

Time Zone

**Y**

Yellow alarm

---

**U**

**yy**

Year (2 chars.)

**UAS**

Unavailable seconds

**YY**

Year (2 chars.)

**UATC**

Unavailable time count

**UC**

Unit Controller

**UCR**

Unit Controller

**UEQD**

Unequipped

**UI**

User interface

**UMC**

Unassigned Multiplexer Channel Code

**US**

Unavailable Seconds

---

**V**

**VDC**

Video Display Console

**VGA**

Video Graphics Analog

---

# Index

---

## A

### A

- Bandwidth Type field value, 6-15
- Options field value, 6-17
- A/B signaling
  - and IW field, 6-19
  - and TC field, 6-18
  - and TRSP field, 6-19
- ABORT
  - RP Action field value, 9-6
- Accessing alarm reports, 14-10
- Action field
  - Circuit Provisioning, 3-26, 6-8, 7-12, 7-19, 11-7
  - Edit Custom Report Format form, 14-16
  - Frame Administration, 3-14
  - Login Port Administration, 3-4
  - on 24-Hour Performance form, 17-8
  - on DATABASE AUDIT/SYNCHRONIZATION form, 10-15
  - on TEST ACCESS form, 15-9
  - Printer Management, 3-27
  - RP, 9-7
  - Task Administration, 11-3
  - test port provisioning, 5-3
  - User Management, 12-4
- ACTIVATE
  - Circuit Provisioning Action field value, 6-8
  - Failure of CIRCUIT PROVISIONING Action, 6-3
  - Reconfiguration Plan Action field value, 9-7
  - usage, 6-3, 6-4, 6-24
- ACTIVE Status
  - and ACTIVATE, 6-24
  - and ACTIVATE in RP, 9-7
  - and NORMALIZE, 8-7
  - and NPC Roll, 8-18
  - and preempting, 8-7
  - and TLR, 6-18
  - circuit, 6-3, 6-12
  - on RP, 9-9
- ADD
  - user login Action, 12-4
- Address field
  - USER MANAGEMENT form, 12-5
- Addressing system
  - setting an I-2000 frame for, 3-16
  - setting the DACS for, 2-3
- ADMIN
  - User Class field value, 12-4
- Aging of an alarm, 4-19
- AIS, 16-7
  - Circuit Provisioning Options field selection, 6-17
- ALARM
  - List Type field value, 9-19
- Alarm
  - critical, 9-2, 16-3
  - date, 16-3
  - in ARP, 9-19
  - logging, 3-30
  - major, 9-2, 16-3
  - minor, 16-3
  - reported, 14-20
  - severity, 16-3
  - threshold, 4-23
  - time, 16-3
  - type, 16-4
- Alarm Aging field
  - on NPC PROVISIONING form, 4-19
- Alarm indication signal, 16-7
  - and AIS Option, 6-17
- Alarm Monitor Port
  - baud rate, 2-5
  - definition, 1-10
  - device name, 2-5
- Alarm notification, 16-1
- Alarm Query report
  - illustration, 14-22
- Alarm reports hot key, 14-10
- Alarm State field
  - on NPC PROVISIONING form, 4-15
- Alarm status line
  - reported on top of screen, 2-40
  - usage, 16-1
- ALARM\_DEV
  - description, 2-5
- ALARM\_DEV\_SPEED
  - description, 2-5
- alarm\_state, 2-13
- Alarms Audible field
  - USER MANAGEMENT form, 12-5
- alarmtype, 2-13
- ALL
  - Type field value, 11-4
- ALL FACILITY NPCS
  - Mode field value, 10-16
- ALL LOCAL NPCS
  - Mode field value, 10-16
- Alternate routing, 8-1
- Alternating bandwidth
  - definition, 6-15
- ALTRROUTE
  - definition, 8-1
  - real and pseudo-, 8-2
  - Reconfiguration Plan Action field value, 9-7
  - usage, 8-1
- Altroute
  - performing an altroute fro half-duplex to unused part of a preempted full-duplex circuit, 8-13
- Altroute Date & Time field
  - on ALTROUTING form, 8-5
- ALTRROUTE fields
  - on RECONFIGURATION PLAN PROVISIONING form, 9-9

ALTROUTED CIRCUITS report  
illustration and description, 14-8

ALTROUTED Status  
and ACTIVATE in RP, 9-7  
and NORMALIZE, 8-7  
and NPC Roll, 8-18  
and TLR, 6-18  
circuit, 6-12  
constraints associated with, 8-1  
in RP, 9-8

ALTROUTES/PREEMPTIONS reports  
types available, 14-8

Altrouting  
completing a "real" altroute, 8-6  
configuring a "real" altroute, 8-9  
normalizing, 8-7  
normalizing a "real" altroute, 8-11  
normalizing a pseudo altroute, 8-12  
normalizing an altroute from half-duplex to full-duplex,  
8-12  
normalizing an altroute from half-duplex to part of a  
full-duplex, 8-13  
normalizing an altroute of a real high-rate circuit, 8-15  
normalizing an altroute of a single-channel to unused part  
of a high-rate circuit, 8-17  
normalizing an altrouted circuit, 8-8  
normalizing an out of service NPC, 8-8  
performing a pseudo altroute, 8-11  
preempting, 8-6  
specifying a "real" altroute, 8-2

Altrouting and normalizing examples, 8-8

ARE YOU SURE  
use of this prompt, 2-38

ARP  
definition, 9-2

ARP ID field  
on AUTOMATIC RECONFIGURATION PLAN PROVI-  
SIONING form, 9-18

ARP RESULTS report  
description and illustration, 14-13

ARP Status field  
on AUTOMATIC RECONFIGURATION PLAN PROVI-  
SIONING form, 9-19

Arrow keys  
use in menu selection, 2-27

Asynchronous lines  
number of, 3-5

Asynchronous ports  
and number of users, 2-26  
definition, 3-2  
number of, 3-5

A-to-mu law  
and NAM Option, 6-3, 6-17

Audit  
definition, 10-3

Automatic plans, 9-16  
Automatic Reconfiguration Plan  
definition, 9-2  
report types available, 14-13  
Automatic reconfiguration plan

creating an automatic reconfiguration plan, 9-20  
inserting reconfiguration plans and alarm list items, 9-20  
Automatic reconfiguration plan examples, 9-19  
AUTOMATIC RECONFIGURATION PROVISIONING form,  
9-16

Autonomous features  
alarm monitoring, 1-10  
echoed response processing, 1-11

---

## B

B  
Circuit Provisioning Options field value, 6-17  
Direction field value, 15-10  
Backbone leg  
of broadcast circuit, 6-13, 6-33  
Background  
Audit/Sync running in, 10-12  
Backup  
and Database Audit/Sync, 10-12  
of synchronous lines, 1-6, 3-11, 3-14  
on tape, 10-27, 10-31  
Backup Line field  
on FRAME ADMINISTRATION form, 3-18  
BACKUP/RESTORE menu, 10-26  
Bandwidth  
definition, 6-16  
maximum, 6-2  
Bandwidth field  
on RECONFIGURATION PLAN PROVISIONING form,  
9-9  
usage for broadcast circuit, 6-33  
use to determine circuit type, 6-3  
Bandwidth Type field  
on CIRCUIT PROVISIONING form, 6-15  
on RECONFIGURATION PLAN PROVISIONING form,  
9-9  
value for broadcast circuit, 6-33  
Baud rate  
of asynchronous link (SNIDER), 3-18  
of asynchronous port, 3-5  
setting in DACS, 2-2  
BBL  
and CHANNEL SYNC, 10-9  
Ckt Class field value, 6-13, 9-8  
Mode field value, 6-16  
usage in broadcast circuit, 6-33  
BCON Circuits, 6-43  
BER, 16-7, 16-8  
BER alarm  
and minor alarm options, 4-25  
BF  
IW field value, 6-20  
Bit error rate  
and threshold settings, 4-25  
reported in alarm message, 16-8  
BMTR ALARM, 16-4

BMTR IDLE, 16-4  
 BOOT  
   RP Action field value, 9-4  
 BOOT FAILED, 16-4  
 BootDacs  
   special RP ID, 9-4  
 BOTTOM  
   use in passthrough, 13-9  
 Branch leg  
   of broadcast circuit, 6-13  
 BRD  
   and CHANNEL SYNC, 10-9  
   Ckt Class field value, 6-13, 9-8  
   Mode field value, 6-16  
   number allowed, 6-13  
   usage in broadcast circuit, 6-33  
 BRESTORE  
   frame, 3-14  
 Broadcast circuit  
   and ALTRROUTE, 8-2  
   and CHANNEL SYNC, 10-9  
   bandwidth, 6-2  
   illustration, 10-9  
 Broadcast leg  
   in broadcast circuit, 6-33  
 BROWSE  
   circuit, 6-10, 7-12, 7-20  
   NPC, 4-17  
 BROWSE\_TIMEOUT  
   description, 2-5  
 BTLP  
   description, 2-6  
 BTLP\_ALARM\_STATE  
   description, 2-6  
 BTLP\_DATE\_FORMAT  
   description, 2-6  
 BTLP\_EXCLUDE  
   description, 2-6  
 BTLP\_FMT\_STRING  
   description, 2-6  
 BTMI  
   description, 2-5  
 Buffer  
   pattern matching, 2-30  
   printer, 3-30

---

## C

**C**  
 Bandwidth Type field value, 6-15  
 Options field value, 6-17  
 C2000  
   automatically supplied value of Customer Name field,  
   6-21  
   Circuit deleted when deactivated, 6-53  
   Deletion of circuit on deactivation, 6-53  
 Capacity Expansion Frame

  description, 1-3  
 Carrier group alarm, 16-4  
   in Alarm State field, 4-15  
 CAS signaling  
   and SC field, 6-20  
 Cascaded multipoint circuit  
   and Audit/Sync, 10-8  
   definition, 6-40  
   polling data circuit, 6-42  
 CCB, 16-5  
 CCB ALARM, 16-4  
 CCB IDLE, 16-4  
 CCI, 16-5  
 CCI ALARM, 16-4  
 CCI IDLE, 16-4  
 CCITT  
   use in the I-2000, 1-6  
 CCN, 16-5  
   definition, 1-3  
 CCNI, 16-5  
 CCNI ALARM, 16-4  
 CCNI IDLE, 16-4  
 CEF frame  
   and 4-digit extended numbers, 4-6  
 CEPT  
   and Type PA, 4-17  
   creating a CEPT NPC, 4-26  
   default dataset, 4-23  
   number of channels in NPC, 1-3  
 CGA, 16-4  
   Alarm State field value, 4-15  
   and AIS Option, 6-17  
   and Alarm Aging field, 4-19  
 CGA IDLE, 16-4  
 Ch field  
   on CIRCUIT PROVISIONING form, 6-16, 7-21  
 CHANGE  
   ARP Action field value, 9-17  
   Outage Data Log, 10-37  
   user login Action, 12-4  
 Change of frame alignment error, 16-8  
 Channel  
   definition, 4-1  
   number, 4-2, 6-16, 7-21  
   selection for Altrouting purposes, 8-4  
   virtual channel number, 6-16, 7-13, 7-21  
 Channel 0  
   use, 6-4  
 Channel A  
   definition, 5-2  
 CHANNEL AUDIT  
   Database Audit/Sync Action field value, 10-15  
   example, 10-21  
   fields checked during, 10-4  
   running in foreground, 10-12  
 Channel B  
   definition, 5-2  
 Channel field  
   on DATABASE AUDIT/SYNCHRONIZATION form,  
   10-17

- CHANNEL SYNC
  - definition, 10-7
- Channel-counting sequence
  - and Type DE, 4-18
- CHANNELS report
  - type available, 14-7
- CHECK
  - ARP Action field value, 9-18
  - RP Action field value, 9-6
- CHGSITE
  - Frame Administration Action, 3-14
- CHOICES
  - use to list choices, 2-34
- CI RESET, 16-4
- CIRCUIT
  - Outage Type field value, 10-37
- CIRCUIT AVAILABILITY report
  - illustration and description, 14-6
- CIRCUIT CONNECTIONS report
  - illustration and description, 14-6
- CIRCUIT INFORMATION report
  - illustration and description, 14-6
- CIRCUIT OPTIONS report
  - illustration and description, 14-6
- Circuit pack
  - definition, 1-3
- Circuit Priority
  - and CP field, 6-21, 9-8
- Circuit Provisioning
  - BCON circuit examples, 6-43
- Circuit provisioning
  - and ALTROUTES/PREEMPTIONS reports, 14-8
  - and CIRCUITS reports, 14-6
  - cascaded multipoint, 6-40
  - clear DS1 full duplex, 6-26
  - definition, 1-4, 6-1
  - DMB multipoint, 6-35
  - ERP, 6-51
  - full duplex circuit, 6-25
  - half-duplex circuit, 6-27
  - high-rate for multiple circuits, 6-32
  - loopback, 6-28
  - number of RP Actions allowed, 9-1
  - polling data, 6-38
  - TSO to Non-TSO circuits, 6-50
- Circuit provisioning examples, 6-24
- CIRCUIT PROVISIONING forms, 6-5
- Circuits
  - cascaded multipoint, 6-40
- CIRCUITS report
  - descriptions, 14-6
- City field
  - USER MANAGEMENT form, 12-5
- Ckt Class field
  - on CIRCUIT PROVISIONING form, 7-13, 7-21
  - on RECONFIGURATION PLAN PROVISIONING form, 9-8
  - usage, 6-3
- Ckt ID field
  - and broadcast circuit, 6-33
  - automatically assigned by circuit ERP, 6-53
  - on RECONFIGURATION PLAN PROVISIONING form, 9-7
- Ckt Status
  - and circuit ERP action results, 6-54
  - on CIRCUIT PROVISIONING form, 7-13, 7-20
- ckts, 2-13
- CLEAN
  - ARP Action field value, 9-18
  - RP Action field value, 9-6
- Clear DS1
  - and Ch field, 6-16
  - and test access, 15-2
  - and TG80 Card, 1-4, 6-2
  - and Type DE, 4-18
  - and Type TE, 4-18
- Clear E1
  - and TG192 Card, 6-2
  - and Type PA, 4-17
- Clearing a field
  - how to, 2-27
- Clock, 2-20
- cmd-tool window, 2-20
- COFA, 16-8
- COFA alarm
  - and minor alarm options, 4-25
- COMBINE
  - CIRCUIT PROVISIONING Action, 6-10
- COMMAND\_TIMEOUT
  - description, 2-6
- COMMON
  - database name, 10-26
- Communications interface reset, 16-4
- condtype, 2-12
- Configuration
  - philosophy of, 1-6
- Connect
  - of EFTs, 6-4
- Console
  - and PASSTHROUGH, 13-7
  - does not need a login port, 3-3
- Contiguous Bandwidth
  - and broadcast circuit, 6-33
  - definition, 6-15
- CONTROLLER
  - User Class field value, 12-4
- Conversion specification, 2-12
- CP field
  - on CIRCUIT PROVISIONING form, 6-21
  - on RECONFIGURATION PLAN PROVISIONING form, 9-8
- CRC Block Errors
  - Type PA performance parameter, 4-24, 17-2
- CRC15MIN, 16-8
- CRC15MIN alarm
  - and Type PA performance parameters, 4-24
- CRCDAILY, 16-8
- CRCDAILY alarm
  - and Type PA performance parameters, 4-24
- CREATE

- ARP, 9-20
    - ARP Action field value, 9-17
    - definition and philosophy of, 4-2
    - done by ERP, 4-35
    - format, 14-17
    - NPC, 4-26, 4-27, 4-29
    - report format, 14-16
    - RP, 9-9
    - RP Action field value, 9-4
    - TEST PORT, 5-3, 5-6
    - TP DIGROUP, 5-3, 5-5
  - CREATE frame, 3-14
  - Critical alarm
    - and ARP, 9-2
    - in alarm message, 16-3
  - Cross-connect Network
    - definition, 1-3
  - Cross-connection
    - and CHANNEL SYNC, 10-9
  - CRTE command
    - What it does, 4-2
  - CSS15MIN, 16-8
  - CSS15MIN alarm
    - and Type PA performance parameters, 4-24
  - CSSDAILY, 16-8
  - CSSDAILY alarm
    - and Type PA performance parameters, 4-24
  - Ctrl
    - use in passthrough, 13-9
  - Ctrl a
    - hot key for customized alarm reports, 14-10
    - use to get an alarm report, 2-29, 2-30, 2-32
  - Ctrl b
    - use to request next page, 2-30
    - use to scroll back a page, 2-32, 13-9
    - use to scroll forward a page, 2-29
  - Ctrl c
    - use to return to MAIN MENU or log off, 2-29
  - Ctrl d
    - use in passthrough, 13-9
    - use to move down a line, 2-29
    - use to scroll forward a line, 2-32
  - Ctrl e
    - use to exit from passthrough, 2-32, 13-9
  - Ctrl f
    - use to request next page, 2-30
    - use to scroll backward a page, 2-29
    - use to scroll forward a page, 2-33, 13-9
  - Ctrl h
    - use to backspace and erase character, 2-29, 2-31, 2-33
  - Ctrl i
    - use to move down a line, 2-29
  - Ctrl j
    - use to select an item from a menu, 2-29
  - Ctrl k
    - use to clear to end of field, 2-31
  - Ctrl l
    - use to move to last page, 2-33, 13-9
  - Ctrl m
    - use for field entry, 2-30
    - use to select an item from a menu, 2-29
  - Ctrl n
    - use to move down a line, 2-29
  - Ctrl o
    - use to output screen to printer, 2-29, 2-31, 2-33
  - Ctrl p
    - use to move up one line, 2-30
  - Ctrl t
    - use to move to top, 2-33, 13-9
  - Ctrl u
    - use to move up a field, 2-31
    - use to scroll back a line, 2-33
  - Ctrl v
    - use to delete a character, 2-32
  - Ctrl w
    - use to refresh the screen, 2-30, 2-32
  - Ctrl x
    - use to clear field, 2-27, 2-32
    - use to clear the pattern matching buffer, 2-30
  - Ctrl z
    - use to find the next pattern, 2-30
    - use to request previous choice, 2-32
  - Current field
    - on NPC ROLL form, 8-19
  - Cursor
    - position in typing, 2-28
  - Custom format
    - definition, 14-1
  - Custom Report formats, 14-14
  - Customer Name field
    - of CIRCUIT PROVISIONING form, 6-21
  - Customized Reports, A-1
  - CV15MIN, 16-8
  - CV15MIN alarm
    - and Type PA performance parameters, 4-25
  - CVDAILY, 16-8
  - CVDAILY alarm
    - and Type PA performance parameters, 4-25
- 
- ## D
- D
    - CEPT default dataset, 4-23
    - Options field value, 6-17
    - threshold setting, 4-23
  - DA
    - support for, 4-4
  - DACS
    - databases, 10-26
    - definition, 1-2
    - Master DB field value, 10-16
  - DACS ALARM LOG
    - purpose, 14-10
  - DACS ALARM QUERY report
    - illustration, 14-22
  - DACS and Local
    - how to obtain, 2-42

- DACS HISTORY LOG
  - illustration and description, 14-11
  - number of entries in, 2-7
- DACS I
  - description, 1-3
- DACS II
  - description, 1-3
  - login, 2-1
  - NPC types supported, 4-4
  - number of allowed test ports, 5-2
  - Type field value, 3-15
- DACS II ISX
  - login, 2-1
  - NPC types supported, 4-4
  - number of allowed test ports, 5-2
  - Type field marker, 3-15
- DACS INFO fields
  - on DATABASE AUDIT/SYNCHRONIZATION form, 10-19
- DACS Only
  - how to obtain, 2-41
- DACS\_HIST\_SIZE
  - description, 2-7
- DACS\_TIMEOUT
  - description, 2-7
- dacsadm
  - system administrator login, 2-20
- DACScan
  - and network, 1-6
  - TP provisioning not available, 5-2
- DACSCAN\_STRING
  - description, 2-7
- dacsmsgno, 2-13
- Database
  - COMMON, 10-26
  - DACS, 10-26
  - description of types, 10-26
  - facility, 10-3
  - how to select different databases, 2-39
  - local, 10-3
  - logs, 10-26
  - reports format, 10-26
  - updating, 2-41
- Database administration, 10-1
  - backing up alarm log to diskette, 10-32
  - backing up alarm log to tape, 10-31
  - backing up database to tape, 10-27
  - formatting diskette, 10-35
  - initiating an ABORT, 10-25
  - moving frame, 10-39
  - performing a channel audit, 10-21
  - performing a substrate audit, 10-23
  - performing a substrate sync, 10-24
  - performing a synchronization, 10-23
  - printing an NPC audit, 10-20
  - restoring alarm log from diskette, 10-34
  - restoring alarm log from tape, 10-32
  - restoring database from tape, 10-29
  - scheduling an NPC audit, 10-19
  - uploading the I-2000 database, 10-25
- DATABASE ADMINISTRATION menu, 10-1
- Database audit, 10-3
  - definition, 10-3
- DATABASE AUDIT/SYNCHRONIZATION, 10-2
- DATABASE AUDIT/SYNCHRONIZATION form, 10-13
- DATABASE BACKUP/RESTORE (TAPE) form
  - illustration, 10-28
- DATABASE BACKUP/RESTORE menu
  - illustration, 10-27
- Database synchronization, 10-6
  - definition, 10-6
- Datasets
  - and threshold settings, 4-25
  - definition, 4-23
- Date
  - %D, 2-14
  - default on reports, 2-7
  - in TASK SCHEDULING pop-up, 2-39
  - on DACS, 3-36
  - resetting I-2000 Computer, 3-34
  - Service, 6-21
- DATE and TIME, 3-34
  - setting, 3-34
- Date field
  - on SEARCH CRITERIA form, 14-4
- Date in field
  - on OUTAGE LOG form, 10-37
- Date Out field
  - on OUTAGE LOG form, 10-37
- DATE RESET, 16-4
- DATE\_FORMAT
  - description, 2-7
- Day field
  - in TASK SCHEDULING pop-up, 2-39
  - on OUTAGE LOG form, 10-37
  - part of Service Date field, 6-21
  - TIME AND DATE ADMINISTRATION form, 3-35
- Day of week, 2-13
- Days Data Collected, 17-1
- Days Since Reset, 17-1
- DC
  - support for, 4-4
- DCC
  - Options field selection, 6-17
- DDC
  - usage, 4-2, 6-2
- DE
  - in NPC Roll, 8-20
  - support for, 4-4
  - Type field value, 4-18
- DEACTIVATE
  - and ALTRROUTE, 8-1
  - and NORMALIZE, 8-7
  - Circuit Provisioning Action field value, 7-12, 7-20
  - Reconfiguration Plan Action field value, 9-7
- DEACTIVATED Status
  - and broadcast circuit, 6-33
  - and IDLE, 9-6
  - circuit, 6-11, 7-13, 7-21
  - on RP, 9-8

- DECserver 700
  - login to, 2-21
  - use, 2-22
- DEFAULT COLUMN NAME field
  - on Edit Custom Report Format form, 14-17
- DEFAULT DATA WIDTH field
  - on Edit Custom Report Format form, 14-17
- Degraded minutes, 16-8
  - and threshold settings, 4-24
- De-growing an NPC
  - definition, 4-2
- DELETE
  - circuit, 6-3
  - Circuit Provisioning Action field value, 6-9, 7-12, 7-20
  - definition and philosophy of, 4-2
  - done by ERP, 4-35
  - frame, 3-14
  - Outage Data Log, 10-37
  - report format, 14-16
  - scheduled tasks, 11-3
  - TEST PORT, 5-3, 5-6
  - TP DIGROUP, 5-3, 5-7
  - user login Action, 12-4
- DEROUTED Status
  - circuit, 6-12
  - usage, 8-18
- Desc field
  - on TASK SELECTION insert, 11-5
- DESTROY
  - ARP Action field value, 9-17
  - Outage Data Log, 10-37
  - RP Action field value, 9-4
- DGRTH command
  - what it does, 4-2
- Digital multipoint bridge
  - DMB value of Ckt Class field, 6-14
- Digroup
  - circuit, 1-3
  - definition, 1-3
- Direct access
  - changing root password, 2-18
- Direct configuration
  - and Protocol field, 3-15
  - illustration of, 1-7
- Direction field
  - on TEST ACCESS form, 15-10
  - usage, 10-10
- DISABLE
  - Printer Management Action, 3-28
- DISC command
  - what it does, 4-2
- Disconnect
  - and CHANNEL SYNC, 10-9
  - and the INCL Option, 6-17
  - and the OOS Option, 6-17
- Disconnect channel code
  - and DCC Option, 6-17
  - when asserted, 4-15
- Diskette
  - backup on, 10-32
- DISPLAY LAST GENERATED REPORT Option
  - description, 14-4
- Display Page field
  - usage, 14-1
- DM1H alarm
  - and short interval option, 4-24
- DM24H, 16-8
- DM24H alarm
  - and long interval option, 4-24
- DMB
  - and Bandwidth field, 6-16
  - and multipoint circuit, 6-35
  - and preempting, 8-7
  - circuits available, 6-2
  - Ckt Class field value, 6-14, 9-8
  - creating a DMB NPC, 4-29
- DMB card
  - and Type MB, 4-18
  - usage, 4-3
- DPC
  - usage, 4-2, 6-2
- DS0
  - and CCN, 1-3
  - and DS3 circuit pack, 4-2
  - transmission speed, 4-1
- DS0 channel examples, 7-14
- DS0 channel provisioning, 7-7
- DS0 two-point cross connections, 1-3
- DS1
  - as Ch field value, 6-16
  - transmission speed, 4-1
- DS1 multiplexed signals, 1-3
- DS3
  - alarm, 14-20
  - circuit packs, 4-2
  - circuits available, 6-2
  - Unit, 1-3
- DSP shelf
  - and DMB card, 4-3
  - and virtual multipoint, 1-4
- DSPI, 16-5
- DSPI ALARM, 16-4
- DSPI IDLE, 16-4
- DSPU
  - alarm, 14-20
  - definition, 1-4
- Dual digroup card
  - and Type DE, 4-18
  - definition, 1-3
  - usage, 4-2
- Dual primary circuit
  - usage, 4-2
- Dynamic conditioning
  - specified on TEST PORT PROVISIONING form, 5-4

**E**

- E
  - Options field value, 6-17
- E4
  - standard DACS II trouble code, 6-20
- ECCN, 16-5
- ECCN IDLE, 16-4
- Echoed response processing
  - and link screening level, 2-3
  - as synchronization, 10-2
  - circuit, 6-51
  - definition, 1-11
- ECHOED RESPONSE PROCESSING report
  - illustration and description, 14-10
- EFT
  - and ALTRROUTE, 8-2
  - and preempting, 8-7
  - definition, 6-1
  - determines the type of circuit, 6-3
  - how specified in multipoint circuit, 6-16
- ENABLE
  - Printer Management Action, 3-28
- End
  - use to move to the last menu item, 2-29
- Enhanced Dual Primary Circuit
  - and Type PA, 4-17
- Enter
  - and validation of field data, 2-28
  - use for field entry, 2-27, 2-30
  - use to acknowledge message, 2-36
  - use to display branch leg data, 6-33
  - use to select an item from a menu, 2-29
- Environment variables, 2-5
- Environmental variables
  - table of, 2-5
- eqid, 2-12
- eqtype, 2-12
- ERP
  - automatically supplied value of Circuit ID field, 6-53, 6-54
  - automatically supplied value of Customer Name field, 6-21
  - circuit provisioning, 6-51
  - definition, 1-11
  - Deletion of circuit on deactivation, 6-53
  - disablement, 6-54
  - disabling echoed response, 4-37
  - disabling ERP, 6-54
  - output messages, 6-52
- ERP Control Field
  - and circuit ERP, 6-52
- ERP Control field
  - and NPC ERP, 4-35
  - on FRAME ADMINISTRATION form, 3-16
- ERP format for NPC ID, 4-36
- ERP report
  - illustration and description, 14-10
- Error message
  - NEW AUTOMATIC RECONFIGURATION PLAN MUST HAVE UNIQUE ID, 9-20
  - Non-clear DS1 can not connect to Clear DS1 NPC, 6-16
  - NPC type is inconsistent with FTMI type, 4-18
  - PASS THROUGH IS IN PROGRESS, 13-7
  - rejecting a command, 2-36
  - Sorry. Incorrect Password, 12-6
  - Unimplemented Function Key, 2-35
- Error Messages, B-1
- Error status register
  - and POWER FAIL message, 16-9
- Errored Days, 17-1
- Errored seconds, 16-8
  - and threshold settings, 4-24, 4-25
  - Type PA performance parameter, 4-24, 17-2
- ERS15M, 16-8
- ERS15M alarm
  - and short interval options, 4-24
- ERS24H, 16-8
- ERS24H alarm
  - and long interval options, 4-24
- ES15MIN, 16-8
- ES15MIN alarm
  - and Type PA performance parameters, 4-24
- Esc
  - use to change keystroke mode, 2-28
- ESDAILY, 16-8
- ESDAILY alarm
  - and Type PA performance parameters, 4-24
- ESTABLISH DS0 CHANNEL form, 7-8
- ethers, 2-25
- ETSI, 16-5
- ETSI ALARM, 16-4
- ETSI IDLE, 16-4
- Examples
  - NPC provisioning, 4-25
- EXECUTE
  - ARP Action field value, 9-17
  - ARP Status field value, 9-19
  - description of use, 2-35
  - how to execute RP, 9-15
  - RP Status field value, 9-4
- EXECUTE key
  - using, 2-35
- EXIT
  - use to leave passthrough, 13-9
- Ext field
  - of CIRCUIT PROVISIONING form, 6-15, 7-13, 7-21
  - on DATABASE AUDIT/SYNCHRONIZATION form, 10-17
- EXT3
  - NPC Addr field value, 3-16
- Extended numbering, 2-3
  - and (Ext) field on 24-Hour Performance form, 17-8
  - and (Ext) field on ARP form, 9-19
  - and (Ext) field on NPC PROVISIONING form, 4-18
  - and Circuit Provisioning Ext field, 6-15, 7-13, 7-21
  - setting the DACS for, 2-3
  - setting the I-2000 frame for, 3-16

External facility termination  
definition, 1-4, 6-1

## F

### F

- Direction field value, 15-10
- NTR field value, 6-18
- Options field value, 6-17
- F1 through F8
  - use of, 13-9
- Facility database
  - definition, 10-3
- Facility ID field
  - on AUTOMATIC RECONFIGURATION PLAN PROVISIONING form, 9-19
- Facility performance alarm message
  - and alarm thresholds, 4-23
- Facility Terminating Module
  - relation to FTU, 1-3
- Far End
  - definition, 1-2
- Far End Site
  - and FE Site field, 4-19
- FC, 16-5
- FC ALARM, 16-4
- FC IDLE, 16-4
- FDX
  - and SC field value, 6-20
  - Ckt Class field value, 9-8
- FE Site field
  - on NPC PROVISIONING form, 4-19
- FE15MIN alarm
  - and Type PA performance alarms, 4-24
- FEBE15MIN alarm
  - and Type PA performance parameters, 4-24
- FEBEDAILY, 16-8
- FEBEDAILY alarm
  - and Type PA performance parameter, 4-24
- FES15MIN, 16-8
- FESDAILY, 16-8
- FESDAILY alarm
  - and Type PA performance parameters, 4-24
- FF
  - IW field value, 6-20
- FFER, 16-7
- Field
  - mandatory, 2-28
- Field Descriptions
  - RECONFIGURATION PLAN PROVISIONING, 9-3
- Field descriptions
  - ALTRROUTE screen, 8-5
  - AUTOMATIC RECONFIGURATION PLAN, 9-17
  - bottom screen, 10-18
  - C-BIT provisioning, 17-7
  - DATABASE AUDIT/SYNCHRONIZATION, 10-14
  - edit custom report format, 14-16
  - ESTABLISH DS0 CHANNEL, 7-11
  - FRAME ADMINISTRATION, 3-14
  - FRAME COMMAND SCRIPT form, 13-14
  - LOGIN PORT ADMINISTRATION, 3-4
  - NPC PROVISIONING, 4-14
  - NPC ROLL, 8-19
  - OUTAGE LOG form, 10-36
  - outage record, 10-39
  - REPORT TO DOS DISKETTE form, 14-5
  - SUBRATE CROSS CONNECT, 7-19
  - TASK ADMINISTRATION, 11-3, 11-7
  - TASK ADMINISTRATION form, 11-5
  - task scheduling, 2-39
  - TEST ACCESS, 15-9
  - TEST PORT PROVISIONING, 5-3
  - USER MANAGEMENT form, 12-4
  - X.25 LINK ADMINISTRATION, 3-7
- Figure
  - sample clear DS1 full-duplex circuit, 6-26
- Figure
  - 24-Hour Performance Browse screen, 17-9
  - ALTRROUTE screen, 8-4
  - AUDIT/SYNCHRONIZATION SEARCH CRITERIA form, 10-21
  - AUTOMATIC RECONFIGURATION PLAN PROVISIONING form, 9-16
  - backup of I-2000 link, 3-11
  - backup of link to frame, 3-11
  - BBL-to-BBL cascaded polling data circuit, 6-42
  - cascaded symmetric voice circuit, 6-41
  - change site name, 3-21
  - CHANNEL USAGE SEARCH CRITERIA form, 14-3
  - circuit provisioning example (two sequential time frames), 6-5
  - CIRCUIT PROVISIONING form, 6-6, 8-3
  - CIRCUIT PROVISIONING SEARCH CRITERIA form, 6-7
  - clear DS1 NAS NPC provisioning form (DE type), 4-13
  - clear DS1-DS3 NAS NPC provisioning form (TE type), 4-13
  - command response pop-up window, 2-36
  - confirmation window, 2-37
  - creating a frame (SNIDER), 3-22
  - creating a frame (X.25), 3-19
  - cross-connection architecture, 7-2
  - DATABASE ADMINISTRATION Menu, 10-2
  - DATABASE AUDIT/SYNCHRONIZATION Form, 10-14
  - DATABASE AUDIT/SYNCHRONIZATION form, 10-19
  - DATABASE BACKUP/RESTORE (TAPE) form, 10-28
  - database selection window, 2-41
  - displayed task, 11-5
  - DMB NPC provisioning form (MB type), 4-14
  - enhanced NPC provisioning form (PA type), 4-11
  - ESTABLISH DS0 CHANNEL form, 7-10
  - example of altrouting, 8-10
  - FRAME ADMINISTRATION form, 3-13
  - FRAME COMMAND SCRIPT form, 13-13
  - FRAME COMMAND SCRIPT screen, 13-17
  - fully backed-up DACS II ISX configuration, 3-10
  - I-2000 configuration example, 1-2
  - ideal broadcast circuit, 6-32

- illustration of hub test access, 15-7
- illustration of monitor test access, 15-3
- illustration of split test access, 15-5
- insert disk prompt, 10-34
- inter-NPC bus architecture for DSPP circuit pack, 7-3
- LOG BACKUP/RESTORE (DISKETTE) form, 10-33
- LOG BACKUP/RESTORE (TAPE) form, 10-31
- LOGIN PORT ADMINISTRATION form, 3-4
- main menu, 2-27
- MULTIPLEXED PASSTHROUGH screen, 13-6
- NPC Browse screen, 4-35
- NPC provisioning form (DA/TA type), 4-12
- NPC provisioning form (DE/TE type), 4-12
- NPC PROVISIONING form (PB/PC types), 4-9
- NPC QUERY form, 4-34
- NPC QUERY form (non PA), 4-31
- NPC QUERY form (PA first page), 4-32
- NPC QUERY form (PA second page), 4-33
- NPC range fields, 10-22
- NPC ROLL form, 8-19
- OUTAGE LOG form, 10-36
- output choices menu, 13-5
- PASSTHROUGH choices menu, 13-4
- passthrough form, 13-11
- passthrough screen, 13-8
- PASSWORD CHANGE form, 12-7
- PDN X.25 configuration, 1-6
- Point-to-point SNIDER configuration, 1-8
- Point-to-point X.25 configuration, 1-7
- PRINTER MANAGEMENT form, 3-27
- PRINTER QUEUE STATUS form, 11-6, 11-8
- PROVISIONING menu, 4-8, 7-9
- RECONFIGURATION PLAN PROVISIONING form, 9-3
- RECONFIGURATION PLAN SUB-MENU, 14-12
- REPORT OPERATIONS MENU, 14-2
- REPORT TO DOS DISKETTE form, 14-5
- sample alarm report, 16-3
- sample broadcast circuit, 6-34
- sample edit custom report format form, 14-16
- sample half-duplex circuit, 6-27
- sample loopback circuit, 6-28
- sample polling data, 6-38
- sample print-job status, 3-29, 11-9
- sample report format, 14-18
- sample symmetric voice, 6-36
- select schedule or confirm window, 2-37
- selection of report format category, 14-15
- SHUTDOWN TIME pop-up menu, 3-32
- single polling data circuit, 6-41
- stage 1 of UPLOAD (NPC SYNC), 10-11
- stage 2 of UPLOAD action (CHANNEL SYNC), 10-11
- SUBRATE CROSS CONNECT form, 7-18
- SYSTEM ADMINISTRATION menu, 3-2
- TASK ADMINISTRATION form, 11-3
- TASK ADMINISTRATION menu, 11-2
- task scheduling window, 2-38
- TEST ACCESS form, 15-8
- TEST PORT PROVISIONING form, 5-2
- TIME and DATE ADMINISTRATION form, 3-35
- two point two-way circuit, 10-18
- two two-point one-way circuits, 10-18
- USER ADMINISTRATION menu, 12-2
- USER MANAGEMENT form, 12-3
- virtual multipoint circuit, 10-9
- X.25 LINK ADMINISTRATION form, 3-7
- X.50 customer circuit cross-connection diagram, 7-4
- X.50 to X.57 customer circuit cross-connection diagram, 7-6
- File manager, 2-20
- FIRST
  - use to move to first list item, 2-34
- F-keys
  - description, 2-33
- FLI, 16-5
- FMT, 16-5
- Foreground
  - CHANNEL AUDIT running in, 10-12
- Format of report
  - definition, 14-1
- Four-state signaling
  - and TC field, 6-19
- Fr NPC field
  - on DATABASE AUDIT/SYNCHRONIZATION form, 10-18
- Frame
  - alarm, 14-20
  - configuring, 2-1
  - configuring for DACS II & DACS II ISX, 2-1
  - configuring using SNIDER, 2-2
  - configuring using X.25, 2-3
  - definition, 3-9
  - moving one, 10-39
  - number allowed in I-2000, 1-9
  - synchronize date and time, 3-36
- Frame administration, 3-9
  - changing site name, 3-21
  - creating and restoring a frame (SNIDER), 3-22
  - creating and restoring a frame (X.25), 3-18
  - synchronizing date and time, 3-36
  - unprovisioning a frame (X.25 or SNIDER), 3-23
- FRAME ADMINISTRATION form, 3-13
  - illustration, 3-13
  - reported, 14-9
- Frame alignment error
  - and threshold settings, 4-25
- Frame command script, 13-11
  - creating script file, 13-15
  - executing file, 13-18
  - reading file from DOS diskette, 13-18
  - writing file to DOS diskette, 13-16
- FRAME COMMAND SCRIPT form, 13-12
- Frame format
  - and Type DE, 4-18
- Frames
  - administering, 2-25
- FRAMES/LINKS reports
  - types available, 14-9
- Framing errors
  - Type PA performance parameter, 4-24, 17-2
- Framing field

use, 6-4  
Framing word  
  and NFS field, 4-21  
  definition, 6-4  
FRER15MIN, 16-8  
FRER15MIN alarm  
  and Type PA performance parameters, 4-24  
FRERDAILY, 16-8  
FRERDAILY alarm  
  and Type PA performance parameters, 4-24  
FROM  
  and multipoint circuit, 6-35  
  and NTR field, 6-18  
  and SC field value, 6-20  
  definition, 6-4  
  in broadcast circuit, 6-33  
  in high-rate circuit, 6-15  
  in Test Access, 15-2  
  of a BRD, 6-13  
  on DATABASE AUDIT/SYNCHRONIZATION form,  
    10-18  
FSER15MIN alarm  
  and Type PA performance alarms, 4-24  
FSESDAILY, 16-8  
FSESDAILY alarm  
  and Type PA performance alarms, 4-24  
FTMI, 16-5  
FTMI ALARM, 16-4  
FTMI IDLE, 16-4  
FTU  
  alarm, 14-20  
FUAS15MIN, 16-8  
FUAS15MIN alarm  
  and Type PA performance parameters, 4-24  
FUASDAILY, 16-8  
FUASDAILY alarm  
  and Type PA performance parameters, 4-24  
Full passthrough, 13-7  
Function keys  
  description, 2-33  
  identification on screen, 2-40  
  using, 2-33

---

## G

G  
  Options field value, 6-17  
G2\_ALARM\_STATE  
  description, 2-7  
G2\_DATE\_FORMAT  
  description, 2-8  
G2\_EXCLUDE  
  description, 2-8  
G2\_FMT\_STRING  
  description, 2-8  
Gateway  
  and NAM Option, 6-17

  in Test Access, 15-11  
  types of circuits used in, 6-2  
Generic field  
  on FRAME ADMINISTRATION form, 3-16  
Growing an NPC  
  definition, 4-2

---

## H

H  
  abbreviation for HDX, 6-13  
Half duplex  
  illustration, 6-13  
HDX  
  and SC field value, 6-20  
  Ckt Class field value, 6-13, 9-8  
HELP  
  use to display help message, 2-34  
HIER  
  NPC Addr field value, 3-16  
Hier field  
  on CIRCUIT PROVISIONING form, 6-15, 7-13, 7-21  
  on DATABASE AUDIT/SYNCHRONIZATION form,  
    10-17  
Hierarchical numbering  
  and circuit provisioning Hier field, 6-15, 7-13, 7-21  
  and Number (Hier) field on ARP form, 9-19  
  and Number (Hier) field on NPC PROV. form, 4-18  
  definition, 4-6  
  setting the DACS for, 2-3  
  setting the I-2000 frame for, 3-16  
High-rate circuit  
  and ALTRROUTE, 8-2  
  and Bandwidth field, 6-16  
  and CHANNEL SYNC, 10-10  
  ERP deactivation of, 6-53  
High-rate circuits, 8-14  
High-rate cross-connection  
  types of circuits used in, 6-2  
Home  
  use in passthrough, 13-9  
  use to go to previously typed line, 13-9  
  use to position cursor at input line, 2-32  
Hot key for alarm reports, 14-10  
Hour, 2-13  
Hour field  
  in TASK SCHEDULING pop-up, 2-39  
  on OUTAGE LOG form, 10-37  
  TIME AND DATE ADMINISTRATION form, 3-35  
HUB  
  illustration and description, 15-7  
  Test Access Action field value, 15-9  
HUB Status  
  description, 15-10  
HuMan-Machine Language  
  specified in Language field, 3-16

## I

### I-2000

- autonomous features, 1-10
- backing up and restoring databases, 10-26
- features, 1-8
- features under menu control, 1-9
- logging in as an operator, 2-18
- logging in as I-2000 administrator, 2-20
- logging in from DECserver 700, 2-21
- logging in using another host, 2-22
- logging in using I-2000, 2-22
- logging into, 2-18
- main menu, 2-27
- navigating between menus and fields, 2-27
- possible configurations, 1-6
- product description, 1-1
- supported NPC addressing schemes, 4-6
- system features, 1-8

### I-2000 REBOOT

- on SHUTDOWN TYPE menu, 3-33

### I-2000 UPDATE

- on SHUTDOWN TYPE menu, 3-33

### IDLE

- ARP Action field value, 9-18
- ARP Status field value, 9-19
- how to idle an RP, 9-15
- RP Action field value, 9-5, 9-6
- RP Status value, 9-4

### IDLE SIG, 16-8

### In Service

- definition and philosophy of, 4-2

### INCL

- Circuit Provisioning Options field selection, 6-17
- usage, 4-17, 6-4

### INCL field

- on NPC PROVISIONING form, 4-21

### Inf

- threshold setting, 4-23

### INFO\_ALARMS

- description, 2-9

### Informational alarm

- and threshold setting, 4-23

### INSERT

- ARP Action field value, 9-17
- ARP item, 9-20
- in Outage Data Log, 10-37
- into RP, 9-10

### INSERT mode

- description and use, 2-28

### Insertion Word

- and TLR, 6-18
- definition, 4-19, 6-20

### Interval field

- on TASK SELECTION insert, 2-39, 11-5

### INUSE Status

- of login port, 3-5

### IS B Status

- Site Status field value, 3-15

### IS P Status

- Site Status field value, 3-15

### IS Status

- and broadcast circuit, 6-33
- and NPC Roll, 8-18
- login port, 3-5
- Service State field value, 4-15, 17-7
- Site Status field value, 3-15

### IW

- used instead of Disconnect Channel Code, 4-15

### IW field

- and A/B signaling, 6-19
- description, 5-4
- on CIRCUIT PROVISIONING form, 6-20
- on NPC PROVISIONING form, 4-19
- on TEST ACCESS form, 15-11

---

## K

### KCR1 Multiplexer

- and DS3, 4-2

### KCR5/6

- and Type TA, 4-18

### Keystroke

- menu control, 2-29

### kill\_I, 2-15

---

## L

### L

- Direction field value, 15-10

### LAN, 2-22

### Language field

- on FRAME ADMINISTRATION form, 3-16

### LAST

- use to move to last list item, 2-34

### Last NPC ID field

- on DATABASE AUDIT/SYNCHRONIZATION form, 10-17

### Last Run field

- on TASK SELECTION insert, 11-5

### LASTPAGE

- use to move through report, 14-1

### LCMA, 16-7

### LEG

- Mode field value, 6-16

### LINE DOWN

- use in passthrough, 13-9

### LINE UP

- use in passthrough, 13-9

### LINES\_PER\_PAGE

- description, 2-9

### LINK, 16-5

- LINK CONNECTIVITY REPORT
    - illustration and description, 14-9
  - Link protection
    - illustrations, 1-6
  - Link screening level, 2-3
  - Link screening options, 6-54
    - how to change, 4-37
  - LIST
    - Printer Management Action, 3-28
    - scheduled tasks, 11-3
  - List Type field
    - on AUTOMATIC RECONFIGURATION PLAN PROVISIONING form, 9-19
  - LMA, 16-7
  - Loc A field
    - of a CIRCUIT PROVISIONING form, 6-21
  - Loc Z field
    - on CIRCUIT PROVISIONING form, 6-21
  - LOCAL
    - Master DB field value, 10-16
  - Local database
    - definition, 10-3
  - LOCAL INFO fields
    - on DATABASE AUDIT/SYNCHRONIZATION form, 10-19
  - Local Only
    - how to obtain, 2-41
  - Location field
    - on FRAME ADMINISTRATION form, 3-16
  - LOF PBF, 16-7
  - Log
    - backup, 10-33
    - restoring report format, 10-34
  - LOG BACKUP/RESTORE (TAPE) form
    - illustration, 10-31
  - LOGALARMS
    - Printer Management Action, 3-30
  - LOGALL
    - Printer Management Action, 3-30
  - Logging
    - alarms and DACS putput, 3-30
    - and CHANNEL SYNC, 10-12
    - ARP Results, 9-18
    - Audit/Synchronization Results, 10-13
    - circuit outage, 10-35
    - NPC outage, 10-35
    - Reconfiguration Plan results, 9-6
    - results of NPC AUDIT, 10-4, 10-6
    - results of NPC SYNC, 10-6
  - Login
    - number allowed, 1-9, 2-20, 12-1
    - number of sessions allowed, 1-9, 12-1
  - Login Name field
    - on USER LOGINS report, 14-9
    - USER MANAGEMENT form, 12-4
  - Login port
    - administration form, 3-4
    - setting the speed of, 3-6
  - Login ports, 3-2
    - configuring, 2-26
    - definition, 2-26
    - restoring, 3-2, 3-3
  - Logoff
    - automatic, 2-19, 2-20
    - options, 2-19
  - Logs
    - definition, 10-26
  - Long Interval Options
    - and threshold settings, 4-24
  - LOOP
    - description, 15-8
    - Test Access Action field value, 15-10
  - LOOP Status
    - description, 15-10
  - LOS, 16-5, 16-8
    - Alarm State field value, 4-15
  - LOS IDLE, 16-5
  - LOS PBF, 16-7
  - Loss of multiframe alignment, 16-7
- 
- ## M
- MAIN MENU
    - illustration, 2-27
  - MAJ
    - Alarm State field value, 4-15
  - Maj
    - threshold setting, 4-23
  - Major alarm
    - and ARP, 9-2
    - and threshold setting, 4-23
    - in alarm message, 16-3
  - Major Alarm Options
    - and threshold settings, 4-25
  - Mandatory field
    - definition, 2-28
  - Master database
    - definition, 10-6
  - Master DB field
    - on DATABASE AUDIT/SYNCHRONIZATION form, 10-16
  - MAX\_ALM\_LOGS
    - description, 2-9
  - MB
    - NPC number equivalents, 4-7
    - NPC Type field value, 4-18
    - support for, 4-4
  - MC ALARM, 16-5
  - MC IDLE, 16-5
  - MC IN MCOND, 16-5
  - MC REMOVED, 16-5
  - Menu
    - definition, 2-27
    - selecting from, 2-27
  - Menu control keystrokes
    - table of, 2-29
  - Menus and forms

- summary, 2-42
- MER15MIN, 16-8
- MER15MIN alarm
  - and Type PA performance parameters, 4-25
- MERDAILY, 16-8
- MERDAILY alarm
  - and Type PA performance parameters, 4-25
- MI
  - AIS field value, 4-19
- Min
  - threshold setting, 4-23
- Minor alarm
  - and threshold setting, 4-23
  - in alarm message, 16-3
  - not defined for errored and severe errored seconds, 4-25
- Minor Alarm Options
  - and threshold settings, 4-25
- MINR
  - Alarm State field value, 4-15
- Minute, 2-13
- Minute field
  - in TASK SCHEDULING pop-up, 2-39
  - on OUTAGE LOG form, 10-37
  - TIME AND DATE ADMINISTRATION form, 3-35
- MJ
  - AIS field value, 4-19
  - support for, 4-4
- mknod, 2-24
- MMFG, 16-5
- MML
  - Language field value, 3-16
  - line displayed for incorrect TC value, 6-19
  - setting the DACS for, 2-3
  - used in circuit provisioning, 6-2
- MN
  - AIS field value, 4-19
- Mode field
  - on CIRCUIT PROVISIONING form, 6-16
  - on DATABASE AUDIT/SYNCHRONIZATION form, 10-16
  - use, 6-14
- MODIFY
  - and NEW ID field, 6-14
  - and normalization, 8-8
  - Circuit Provisioning Action field value, 6-8, 7-20
  - frame, 3-14
  - NPC, 4-16
  - report format, 14-16
- Module number
  - in hierarchical number, 4-18
- MONITOR
  - illustration and description, 15-2
  - Test Access Action field value, 15-9
- MONITOR Status
  - description, 15-10
- Month field
  - in TASK SCHEDULING pop-up, 2-39
  - on OUTAGE LOG form, 10-37
  - part of Service Date field, 6-21
  - TIME AND DATE ADMINISTRATION form, 3-35

- Month name, 2-13
- Multichannel circuit
  - and ALTRROUTE, 8-2
- Multiplexed passthrough, 13-2
- Multipoint circuit
  - and ALTRROUTE, 8-2
  - and Ckt Class DMB, 6-14
  - and preempting, 8-7
  - cascaded circuits, 6-40
- Multipoint circuits, 8-17
- Multipoint cross-connections, 1-4
- Multiselect menu
  - how to use, 6-17
- MUX
  - Circuit Provisioning IW field value description, 6-20

---

## N

- N
  - OOS field value, 15-10
- NAM
  - Circuit Provisioning Options, 6-17
  - usage, 6-3
- NAS
  - creating an NAS NPC, 4-27
  - default dataset, 4-23
  - number of channels in NPC, 1-3
- Navigation
  - description, 2-27
- Network Address field
  - on FRAME ADMINISTRATION form, 3-18
- Network Processing Circuit
  - definition, 1-3
- NEW ID field
  - of a CIRCUIT PROVISIONING form, 6-14
- New Name field
  - FRAME ADMINISTRATION form, 3-21
- Newline, 2-12
- NEXT
  - use to find branch leg, 6-33
  - use to move to next list item, 2-34
- Next Run field
  - on TASK SELECTION insert, 11-5
- NEXTPAGE
  - use to move through report, 14-1
  - use to obtain ALTRROUTE form, 8-3
- NFS field
  - on NPC PROVISIONING form, 4-21
- NO
  - INCL field value, 4-21
  - on SHUTDOWN TYPE menu, 3-33
  - OOS field value, 4-21
- NONE
  - Alarm State field value, 4-15
- Non-framing word
  - and NFS field, 4-21
  - definition, 6-4

- NORMAL fields
    - on RECONFIGURATION PLAN PROVISIONING form, 9-9
  - NORMALIZE
    - and ALTRROUTE, 8-1
    - Circuit Provisioning Action field value, 6-9
    - definition, 8-7
    - how to, 8-8
  - NPC, 16-5
    - addresses for different types, 4-6
    - addressing system, 3-16
    - alarm triggering ARP, 9-2
    - browsing NPCs, 4-34
    - creating an NPC as subrate, 4-28
    - creating an NPC for CEPT, 4-26
    - creating an NPC using DMB multipoint, 4-29
    - creating and placing in service, 4-26
    - definition, 1-3, 4-2
    - deleting an NPC, 4-30
    - DMB, 4-3, 6-35
    - echoed response processing, 4-35
    - logical provisioning, 4-1
    - number of channels, 1-3
    - OOS and normalization, 8-8
    - Outage Type field value, 10-37
    - physical provisioning, 4-1
    - provisioning, 4-8
    - provisioning examples, 4-25
    - querying an NPC, 4-30
    - removing an NPC, 4-29
    - types of, 4-2
  - NPC Addr field
    - on FRAME ADMINISTRATION form, 3-16
  - NPC Alarm Sync field
    - on FRAME ADMINISTRATION form, 3-17
  - NPC AUDIT
    - fields checked during, 10-3
  - NPC ID
    - ERP format, 4-36
  - NPC ID field
    - on CIRCUIT PROVISIONING form, 6-15, 7-13
    - on DATABASE AUDIT/SYNCHRONIZATION form, 10-17
    - on NPC PROVISIONING form, 4-17, 4-20, 6-12, 6-13, 6-14, 7-12, 7-20, 7-21, 10-17
    - on TEST PORT PROVISIONING form, 5-4
    - value assigned by NPC ERP, 4-36
  - NPC LISTS report
    - illustration and description, 14-13
  - NPC Number (Ext) field
    - description, 5-4
  - NPC provisioning
    - definition, 1-4, 4-1
    - ERP, 4-35
  - NPC PROVISIONING form
    - and NPC report, 14-7
  - NPC report
    - description of types, 14-7
  - NPC Roll
    - differences in I-2000 and DACS II commands, 8-18
    - rolling NPC circuits, 8-20
  - NPC roll, 8-18
  - NPC ROLL form, 8-18
  - NPC SYNC
    - definition, 10-6
  - npc\_id, 2-13
  - NPCS report
    - illustration and description, 14-7
  - NTR field
    - on CIRCUIT PROVISIONING form, 6-18
    - usage, 6-2
  - NULL
    - in Ckt ID field, 6-25, 6-50
    - Status field value on RP, 9-8
    - Used By Circuit ID field value, 14-7
  - NULL Status
    - circuit, 6-3, 6-11, 7-13, 7-20
    - login port, 3-5
  - Number (Hier) field
    - on AUTOMATIC RECONFIGURATION PLAN PROVISIONING form, 9-19
    - on NPC PROVISIONING form, 4-18
  - Number of times field
    - on TASK SCHEDULING pop-up, 2-39
- 
- ## O
- OFF
    - Alarms Audible field value, 12-5
    - ERP Control field value, 3-16
    - UI Idle Option field value, 12-5
  - OFS15MIN, 16-8
  - OFS15MIN alarm
    - and Type PA performance parameters, 4-24
  - OFSDAILY, 16-8
  - OFSDAILY alarm
    - and Type PA performance parameters, 4-24
  - Old Name field
    - FRAME ADMINISTRATION form, 3-21
  - ON
    - Alarms Audible field value, 12-5
    - ERP Control field value, 3-16
    - UI Idle Option field value, 12-5
  - One-way cross-connection
    - and NTR field, 6-18
    - described and illustrated, 6-13, 10-18
    - types of circuits used in, 6-2
  - OOF, 16-8
  - OOS
    - Alarm State field value, 4-15
    - and broadcast circuit, 6-33
    - and Insertion Word, 6-20
  - CCB, 16-5
  - CCI, 16-5
  - CCN, 16-5
  - CCNI, 16-5
  - DSPI, 16-5

- ECCN, 16-5
- ETSI, 16-5
- FC, 16-5
- FLI, 16-5
- FMT, 16-5
- FTMI, 16-5
- LINK, 16-5
- login port status, 3-5
- MMFG, 16-5
- NPC, 16-5
- Options field selection, 6-17
- Service State field value, 4-15, 17-7
- Site Status field value, 3-15
- SYNC, 16-5
- SYNC-TB, 16-6
- SYNC-TLI, 16-6
- TSI, 16-6
- OOS field
  - on EQUIPMENT PROVISIONING form, 4-21
  - on TEST ACCESS form, 15-10
- openwin, 2-20
- OpenWindows, 2-18
- OPERATOR
  - User Class field value, 12-4
- Operator
  - permissions, 12-1
- OPTIONAL COLUMN NAME field
  - on Edit Custom Report Format form, 14-17
- OPTIONAL DATA WIDTH field
  - on Edit Custom Report Format form, 14-17
- Options field
  - on CIRCUIT PROVISIONING form, 6-17
  - usage, 6-3
- ORDER field
  - on Edit Custom Report Format form, 14-17
- Out of frame seconds
  - Type PA performance parameter, 4-24, 17-2
- Out of Service
  - definition and philosophy of, 4-2
- Outage data
  - entering and retrieving, 10-35
  - entering outage log data, 10-36
  - inserting record in NPC outage log, 10-38
  - retrieving outage data, 10-38
- Outage Data Logs
  - description, 10-35
- Outage ID field
  - on OUTAGE LOG form, 10-37
- Outage Type field
  - on OUTAGE LOG form, 10-37
- Out-of-sync code
  - value, 6-20
- OVERLAY mode
  - description and use, 2-28

---

## P

- P
  - in SC field value, 6-20
  - NFS field value, 4-21
  - TS0 field value, 4-20
- PA
  - support for, 4-4
  - Type field value, 4-17
- Packet Data Network
  - address, 3-18
  - and Protocol field, 3-15
- Page Down
  - use to scroll forward a page, 13-9
- Page Up
  - use to scroll backward a page, 13-9
- Pagination
  - of report, 14-1
- PASSTHROUGH
  - and Database Audit/Sync, 10-12
  - definition, 1-5, 13-1
  - usage, 13-1
- Passthrough, 13-1
  - control keys, 13-9
  - entering multiplexed passthrough, 13-3
  - entering full passthrough, 13-8
  - full, 13-7
  - multiplexed, 13-2
  - selections, 13-8
  - terminating, 13-10
- passwd
  - use to enter root password, 2-18
- PASSWORD, 12-6
- Password
  - rules for forming, 12-6
- Password field
  - USER MANAGEMENT form, 12-4
- Passwords
  - changing, 2-26
- Pattern matching buffer
  - definition, 2-30
- PB
  - in NPC Roll, 8-20
  - NPC provisioning form, 4-9
  - support for, 4-4
- PBA
  - Alarm State field value, 4-15
  - and Alarm Aging field, 4-19
- PBA IDLE, 16-6
- PC
  - in NPC Roll, 8-20
  - NPC provisioning form, 4-9
  - support for, 4-4
- PDN
  - address, 3-18
  - and Protocol field, 3-15
- PEND

- usage, 6-3
- PENDING
  - Status field value on RP, 9-8
- PENDING Status
  - and IDLE, 9-6
  - circuit, 6-3, 6-11
- PERF
  - Alarm State field value, 4-15
- Performance Alarm
  - in Alarm State field, 4-15
- Performance Monitoring Reports
  - scheduling on DACS, 17-4
- Performance parameters
  - and threshold settings, 4-23
- Permissions
  - operator/system administrator, 12-1
- Pg Dn
  - use to request next page, 2-30
  - use to scroll forward a page, 2-29
- Pg Up
  - use to request next page, 2-30
  - use to scroll backward a page, 2-29
- Phone field
  - on USER LOGINS report, 14-9
  - USER MANAGEMENT form, 12-4
- PLAN ALTROUTED CIRCUITS report
  - illustration and description, 14-12
- PLAN CONTENTS report
  - illustration and description, 14-12
- PLAN PREEMPTED CIRCUITS report
  - illustration and description, 14-13
- Point-to-point configuration
  - illustration of, 1-7
- Polling data circuit
  - and ALTROUTE, 8-2
  - available with DMB, 6-2
  - how specified, 6-16
- Port
  - definition of login ports, 2-26
  - number of asynchronous, 3-2, 3-5
- Port field
  - on LOGIN PORT ADMINISTRATION form, 3-5
- POWER ALARM, 16-6
- POWER FAIL, 16-6
- POWER FAIL message
  - special parameters, 16-9
- POWER IDLE, 16-6
- PPPPPPPP
  - NFS field value, 4-21
- Preempt
  - authorization, 8-7
  - definition, 8-6
  - initiated by reconfiguration plan ALTROUTE, 9-7
- PREEMPTED CIRCUITS report
  - illustration and description, 14-8
- Preempted Ckt field
  - on ALTROUTED form, 8-4
- Preempted fields
  - on RECONFIGURATION PLAN PROVISIONING form, 9-9
- PREEMPTED Status
  - and ACTIVATE in RP, 9-7
  - and NORMALIZE, 8-7
  - and NPC Roll, 8-18
  - circuit, 6-12
  - on RP, 9-9
  - usage, 8-6
- PREVIOUS
  - use to move to previous list item, 2-34
- PREVPAGE
  - use to move through report, 14-1
- Primary block alarm, 16-6, 16-7
  - in Alarm State field, 4-15
- Primary Line field
  - on FRAME ADMINISTRATION form, 3-17
- PRINT
  - use to print the screen, 2-34, 3-26
- printcap, 2-23
- Printer
  - buffer, 3-30
  - disable, 3-26, 3-28
  - enable, 3-26, 3-28
  - in passthrough, 13-10
  - queue, 3-26
  - what can be printed, 3-26
- PRINTER ADMINISTRATION, 3-26
- Printer administration
  - disabling printer, 3-28
  - displaying print queue, 3-28
  - enabling printer, 3-28
  - removing print jobs, 3-29
  - stop/start printing output and frame alarms, 3-30
  - viewing printer management, 3-27
- PRINTER MANAGEMENT form
  - illustration, 3-27
- Printers
  - administering remote, 2-23
  - remote, 2-22
- Priority
  - circuit, 9-8
- Protocol
  - setting in DACS, 2-2
- Protocol field
  - on FRAME ADMINISTRATION form, 3-15
- protocols, 2-25
- Provisioning
  - and Database Audit/Sync, 10-12
  - circuit, 6-1
  - definition, 1-4
  - NPC, 4-1, 4-8
  - test port, 5-1
- Provisioning forms, 4-8
- PROVISIONING report
  - frame, 14-9
- Provisioning types
  - circuit, 1-4
  - NPC, 1-4
  - test port, 1-4
- Pseudo-ALTROUTE
  - and NORMALIZE, 8-7

definition, 8-2  
PVC  
number for which the DACS is set, 2-3

---

## Q

QUERY  
NPC, 4-16, 4-30  
Queue  
printer, 3-26  
QUIT  
on SHUTDOWN TYPE menu, 3-33  
use to get out of field, 2-28  
use to return to the previous menu, 2-34

---

## R

R16, 16-7  
RAIS, 16-7  
RANGE OF FACILITY NPCS  
Mode field value, 10-16  
RANGE OF LOCAL NPCS  
Mode field value, 10-16  
RBER, 16-7  
RDLD  
Options field selection, 6-17  
usage, 6-4  
Real ALTRROUTE  
and NORMALIZE, 8-7  
definition, 8-2  
REBOOT  
on SHUTDOWN TYPE menu, 3-33  
RECNCILE  
description of usage, 2-39  
RECNCILE key  
using, 2-39  
Reconfiguration Plan  
definition, 1-4, 9-1  
how to generate, 9-1  
Reconfiguration plan  
changing the plan, 9-13  
checking the plan, 9-13  
creating a reconfiguration plan, 9-9  
executing reconfiguration plans, 9-15  
generating a report, 9-12  
idling reconfiguration plans, 9-15  
inserting activation and deactivations, 9-10  
inserting altrouting, 9-12  
modifying plans examples, 9-13  
placing the Ckt ID in database, 9-10  
rechecking the plan, 9-14  
removing item from reconfiguration plan, 9-11  
RECONFIGURATION PLAN ALTRROUTE reports  
types available, 14-12  
Reconfiguration plan examples, 9-9

RECONFIGURATION PLAN PROVISIONING form, 9-2  
and reports, 14-12  
RECONFIGURATION PLAN report  
type available, 14-12  
RECONFIGURATION PLAN RESULTS Report  
how to obtain, 9-13  
usage, 9-6  
Reconfiguration plans, 9-1  
single plans, 9-2  
Record No. field  
on OUTAGE LOG form, 10-37  
Record Number field  
on OUTAGE SEARCH CRITERIA form, 10-39  
Red-lined  
and RDLD Option, 6-17  
removal of circuits, 4-17  
RELEASE  
Test Access Action field value, 15-10  
Release number  
location on screen, 2-40  
RELEASED Status  
description, 15-10  
Remarks  
and Rmks field, 6-21  
Remote alarm indication, 16-7  
Remote bit error rate  
in alarm message, 16-7  
Remote printers, 2-22  
REMOVE  
and Database BACKUP/RESTORE, 10-27  
ARP Action field value, 9-17  
definition and philosophy of, 4-2  
done by ERP, 4-35  
frame, 3-14  
from RP, 9-11  
login port, 3-4  
NPC, 4-17, 4-29  
RP Action field value, 9-4, 9-5  
RENAME  
format, 14-19  
report format, 14-16  
Report  
displaying or printing, 14-4  
header, 2-7  
predefined, 14-1  
Report categories, 14-6  
alarm log, 14-10  
alarm query, 14-20  
altroutes/preemptions, 14-8  
audit/synchronization results, 14-10  
automatic reconfiguration plan results, 14-13  
automatic reconfiguration plans, 14-13  
channels, 14-7  
circuit alarms, 14-9  
circuits, 14-6  
custom report formats, 14-14  
echoed response processing, 14-10  
establish DS0 channel, 14-14  
frames/links, 14-9  
history log, 14-11

- lost response log, 14-11
- NPC alarms, 14-9
- NPCs, 14-7
  - reconfiguration plan altroute, 14-12
  - reconfiguration plan results, 14-13
  - reconfiguration plans, 14-12
  - reconfiguration sub-menu, 14-11
- script log, 14-11
- subrate circuits, 14-14
- task schedule list, 14-10
- task schedule results, 14-10
- test access, 14-8
- test port, 14-8
- user administration, 14-9
- Report format
  - deleting, 14-19
  - modifying, 14-19
  - renaming, 14-19
- Report formats
  - creating new, 14-17
  - edit screens and fields, 14-14
- Report formats database
  - definition, 10-26
- Report Name field
  - on Edit Custom Report Format form, 14-16
- Report Operations, 14-1
- Report operations
  - NPC roll results, 14-10
- REPORT OPERATIONS MENU, 14-2
- Reports
  - displaying and printing, 14-4
  - generating, 14-2
  - generating alarm query report, 14-21
  - transferring reports to DOS diskette, 14-4
- Reset
  - communications interface, 16-4
- RESTORE
  - and Database Audit/Sync, 10-12
  - definition and philosophy of, 4-2
  - done by ERP, 4-35
  - frame, 3-14
  - from tape, 10-29, 10-32
  - login port, 3-4
  - NPC, 4-16, 4-28
- Return, 2-12
- Rmks field
  - on CIRCUIT PROVISIONING form, 6-21
- RMV command
  - what it does, 4-2
- Roll To field
  - on NPC ROLL form, 8-20
- Root password
  - definition, 2-18
  - procedure to use, 12-8
- Root window, 2-18
- RP
  - definition, 9-1
  - List Type field value, 9-19
- RP ID field
  - on AUTOMATIC RECONFIGURATION PLAN PROVI-

- SIONING form, 9-19
- on RECONFIGURATION PLAN PROVISIONING form, 9-7

RP LISTS report

- illustration and description, 14-13

RP Status field

- on RECONFIGURATION PLAN PROVISIONING form, 9-4

RP\_DACS\_TIMEOUT

- description, 2-10

RST command

- what it does, 4-2

Rx

- in test circuits, 15-3

---

## S

- SAFE, 16-8
- Sample full-duplex circuit
  - illustration, 6-25
- Sample polling data circuit
  - illustration, 6-38
- Sample symmetric voice circuit
  - illustration, 6-36
- SANE, 16-8
- SAVE\_ALMS
  - description, 2-10
- SC field
  - on NPC PROVISIONING form, 6-20
- Scale field
  - on TASK SELECTION pop-up, 2-39
- Scheduling
  - and Database Audit/Sync, 10-12
  - and deletion of tasks, 11-1
  - example, 10-19
  - of Database Audit/Sync, 10-12
  - overview, 2-38
- Screen contents, 2-40
- Screening level
  - and ERP, 4-36
- Search criteria
  - definition, 14-1
- SEARCH CRITERIA form
  - for CIRCUIT CONNECTIONS report, 14-6
- Second field
  - on OUTAGE LOG form, 10-37
- Seconds, 2-13
- SELECT
  - use in multiselect menu, 6-17
  - use to select databases, 10-29
  - use to select sites for alarm logs, 10-31
- SELECT field
  - on Edit Custom Report Format field, 14-16
- SELECTIVE BACKUP
  - Action on LOG BACKUP/RESTORE (TAPE) form, 10-31
  - Action on TAPE BACKUP/RESTORE form, 10-29
- SEND\_ALARM\_EVENTS

- description, 2-10
- SEND\_NON\_NPC\_ALARMS
  - description, 2-10
- Sequence field
  - on AUTOMATIC RECONFIGURATION PLAN PROVISIONING form, 9-19
  - on RECONFIGURATION PLAN PROVISIONING form, 9-7
- Sequential numbering
  - definition, 4-6
  - in ARP, 9-19
  - in Outage Data Log, 10-37
  - of NPC record in ERP, 4-36
  - of RP items, 9-7
- SERS15M, 16-8
- SERS15M alarm
  - and short interval options, 4-24
- SERS24H, 16-8
- SERS24H alarm
  - and long interval options, 4-24
- Service Date field
  - on CIRCUIT PROVISIONING form, 6-21
- Service State field
  - on 24-Hour Performance form, 17-7
  - on NPC PROVISIONING form, 4-15
- Service-affecting fields, 6-8
- services, 2-25
- SES, 16-8
- SES15MIN, 16-8
- SES15MIN alarm
  - and Type PA performance alarms, 4-24
- SESDAILY, 16-8
- SESDAILY alarm
  - and Type PA performance alarms, 4-24
- Session
  - number allowed, 12-1
- SESSION\_TIMEOUT
  - description, 2-11
- Severe errored seconds, 16-8
  - and threshold settings, 4-24, 4-25
  - Type PA performance parameter, 4-24, 17-2
- Shelf alarm far end
  - reported in alarm message, 16-8
- Shelf alarm near end
  - reported in alarm message, 16-8
- Shelf number
  - in hierarchical number, 4-18
- Short Interval Options
  - and threshold settings, 4-24
- SHUTDOWN, 3-31
  - on SHUTDOWN TYPE menu, 3-33
- SHUTDOWN TYPE Menu
  - illustration, 3-33
- Side 0
  - and Service State field, 4-15
  - in a DMB NPC, 4-3
- Side 1
  - and Service State field, 4-15
  - in a DMB NPC, 4-3
- SIDE field
  - and DMB NPC, 4-3
  - on NPC PROVISIONING form, 4-18
- Signaling
  - and SC field, 6-20
  - and TC field, 6-18
  - and Type DE, 4-18
- SINGLE CHANNEL
  - Mode field value, 10-16
- Single channel circuits, 8-9
- SINGLE NPC
  - Mode field value, 10-16
- SITE
  - Type field value, 11-4
- Site field
  - on TASK SELECTION insert, 11-5
- Site Name field
  - on 24-Hour Performance form, 17-7
  - on AUTOMATIC RECONFIGURATION PLAN PROVISIONING form, 9-19
  - on CIRCUIT PROVISIONING form, 6-8, 7-11, 7-19
  - on DATABASE AUDIT/SYNCHRONIZATION form, 10-14
  - on NPC PROVISIONING form, 4-14
  - on NPC ROLL form, 8-19
  - on RECONFIGURATION PLAN PROVISIONING form, 9-3
  - on TASK ADMINISTRATION form, 11-4
  - on TEST ACCESS form, 15-9
- Site Status field
  - on FRAME ADMINISTRATION form, 3-15
- SITENAME\_SIZE
  - description, 2-11
- Sixteen-state signaling
  - and TC field, 6-19
- SLIP, 16-8
- SLIP alarm
  - and minor alarm options, 4-25
- Slip count, 16-8
- SLIP15M alarm
  - and short interval option, 4-24
- SLIP24H alarm
  - and long interval option, 4-24
- Slips
  - and threshold settings, 4-24, 4-25, 17-2
- SLIPS15MIN, 16-8
- SLIPS24H, 16-8
- SME
  - and direct configuration, 3-15
  - definition, 1-7
- SNIDER
  - and asynchronous lines, 3-2
  - and PASSTHROUGH, 13-7
  - illustration of configuration, 1-8
  - link status, 3-15
  - Protocol field value, 3-15
  - use in direct configuration, 1-8
- SORT KEY field
  - on Edit Custom Report Format form, 14-17
- Spare bits
  - definition, 6-5

Spare channel  
  selection in altrouting, 8-5

Special function keys  
  description, 2-33

Speed  
  baud rate of asynchronous port, 3-5

Speed field  
  of FRAME ADMINISTRATION form, 3-18  
  of LOGIN PORT ADMINISTRATION form, 3-5

SPLIT  
  description, 15-10  
  illustration and description, 15-4  
  Test Access Action field value, 15-9

SR  
  support for, 4-4

SSP ALARM, 16-6

SSP IDLE, 16-6

Static conditioning  
  specified on the TEST PORT PROVISIONING form, 5-4

Station ID  
  in Loc A field, 6-21  
  in Loc Z field, 6-21

Status  
  circuit, 6-3  
  description of I-2000 Status Line, 2-40  
  of a synchronous link, 3-18  
  on LOGIN PORT ADMINISTRATION form, 3-5  
  on RP form, 9-8  
  Site, 3-15

STOPLOGGING  
  Printer Management Action, 3-30

Subrate  
  and NPC Roll, 8-18  
  and test access, 15-2

Subrate circuits  
  cross connection architecture, 7-2

Subrate cross connect examples, 7-22

SUBRATE CROSS CONNECT form, 7-17

Subrate cross-connection provisioning, 7-17

Subrate provisioning, 7-1, 7-7  
  creating an NPC as subrate, 7-8  
  deactivating a DS0 channel, 7-14  
  deactivating a subrate cross connect, 7-22  
  deleting a DS0 channel, 7-15  
  deleting a subrate cross connect, 7-23  
  establishing a DS0 channel, 7-10  
  establishing subrate cross-connection, 7-18  
  modifying a DS0 channel, 7-15  
  modifying a subrate cross connect, 7-23  
  relevant architecture elements (DSPP circuit pack), 7-3  
  X.50 customer circuit cross-connections, 7-4  
  X.50 to X.57 customer circuit cross-connections, 7-6

Summary  
  menus and forms, 2-42

summary, 2-13

SVC  
  number for which the DACS is set, 2-3

SYM  
  Mode field value description, 6-16

Symmetric voice circuit

  and ALTRROUTE, 8-2  
  available with DMB, 6-2  
  cascaded, 6-41  
  how specified, 6-16

SYN  
  automatically supplied value of Circuit ID field, 10-7  
  Deletion of circuit on deactivation, 6-53

SYNC, 16-5

SYNC ALARM, 16-6

SYNC IDLE, 16-6

SYNC\_DEACTIVATE\_CKTS  
  description, 2-12

Synchronization  
  database, 10-6  
  types, 1-5

Synchronization failure indication, 16-7

Synchronization Results report  
  description, 14-10

Synchronizing  
  time and date, 3-36

Synchronous Modem Eliminator  
  and direct configuration, 3-15  
  definition, 1-7

SYNC-TB, 16-6

SYNC-TLI, 16-6

System administration menu, 3-1

System administrator  
  permissions, 12-1

---

## T

T  
  Direction field value, 15-10  
  NTR field value, 6-18

TA  
  NPC provisioning form, 4-12  
  NPC Type field value, 4-18  
  support for, 4-4

Tab, 2-12  
  use to move between fields, 2-28

Table  
  alarms for NPC performance parameters, 4-25  
  alarms for NPC performance parameters (other than PA type), 4-24  
  alarms for NPC performance parameters (PA type), 4-24  
  allowed test state sequences, 15-13  
  AUTOMATIC RECONFIGURATION PLAN field descriptions, 9-17  
  CIRCUIT PROVISIONING field values, 6-22  
  DATABASE AUDIT/SYNCHRONIZATION field descriptions, 10-14  
  DSPP types supported for subrate provisioning, 10-12  
  edit custom report format field descriptions, 14-16  
  environment variables, 2-5  
  error status register field1 bit mask, 16-9, 16-10  
  error status register field2 bit mask, 16-9, 16-10  
  ESTABLISH DS0 CHANNEL field descriptions, 7-11

- explanation of DACS II alarm message elements, 16-3
- form control keys, 2-30
- FRAME ADMINISTRATION field descriptions, 3-14
- FRAME COMMAND SCRIPT field descriptions, 13-14
- FULL PASSTHROUGH control keys, 13-9
- G2\_DATE\_FORMAT and BTLP\_DATE\_FORMAT conversion specifications, 2-13
- G2\_FMT\_STRING & BLLP\_FMT\_STRING characters, 2-12
- G2\_FMT\_STRING and BTLP\_FMT\_STRING conversion specifications, 2-12
- LOGIN PORT ADMINISTRATION field descriptions, 3-4
- menu control keys, 2-29
- MULTIPLEXED PASSTHROUGH control keys, 13-10
- NPC number equivalents (TE/TA NPC types), 4-8
- NPC number equivalents (DE/PB NPCs), 4-7
- NPC number equivalents (SR/MB/MJ NPC types), 4-7
- NPC parameters audited, 10-4
- NPC PROVISIONING field descriptions, 4-14
- NPC provisioning types, 4-4
- NPC ROLL field descriptions, 8-19
- OUTAGE LOG field descriptions, 10-36
- outage record field descriptions, 10-39
- passthrough control keys, 2-32
- preprogrammed function keys, 2-34
- RECONFIGURATION PLAN PROVISIONING field descriptions, 9-3
- REPORT TO DOS DISKETTE field descriptions, 14-5
- sample provisioned circuits, 8-9
- sample provisioned NPCs, 8-9
- screen contents, 2-40
- SUBRATE CROSS CONNECT field descriptions, 7-19
- summary of menus and forms, 2-43
- TASK ADMINISTRATION field descriptions, 11-3
- Task scheduling field descriptions, 2-39
- TEST ACCESS field descriptions, 15-9
- test port groups supported by frame, 5-2
- TEST PORT PROVISIONING field descriptions, 5-3
- USER MANAGEMENT field descriptions, 12-4
- valid NPC types for MODIFY, 4-5
- X.25 LINK ADMINISTRATION field descriptions, 3-7, 3-8
- Tape
  - backup on, 10-27, 10-31
- TASK
  - Type field value, 11-4
- Task administration, 11-1
  - deleting task, 11-6
  - displaying printer queue status, 11-7
  - listing scheduled tasks, 11-4
  - removing print-job from queue, 11-9
- TASK ADMINISTRATION menu, 11-2
- Task field
  - on TASK SELECTION insert, 11-5
- TASK MANAGEMENT form, 11-3
- TASK SCHEDULE LIST
  - report
    - illustration and description, 14-10
- TASK SCHEDULE RESULTS report
  - illustration and description, 14-10
- TASK SELECTION insert
  - illustration, 11-4
- TC field
  - description, 5-4
  - on CIRCUIT PROVISIONING form, 6-18
  - on TEST ACCESS form, 15-11
- TCP/IP, 2-22
- TE
  - in NPC Roll, 8-20
  - NPC provisioning form, 4-12
  - NPC Type field value, 4-18
  - support for, 4-4
- telnet, 2-21
- TERMINATE
  - Test Access Action field value, 15-9
  - usage, 10-10
- Terminate and Leave Activated and CHANNEL SYNC, 10-9
  - and TLA Option, 6-17
  - definition, 6-4
- Terminate and Leave Released and CHANNEL SYNC, 10-9
  - and TLA Option, 6-17
  - definition, 6-4
- Test access, 15-1
  - modifying status to SPLIT state, 15-15
  - placing channel in multipoint cross-connect, 15-15
  - placing circuit in MONITOR state for test group, 15-14
  - reading test state sequences, 15-13
- Test access examples, 15-14
- TEST ACCESS form, 15-8
  - reported, 14-8
- TEST ACCESS report
  - type available, 14-8
- Test Port
  - creating a test port group, 5-4
- Test port
  - and CHANNEL SYNC, 10-8
  - creating a, 5-6
  - definition, 5-1, 5-2
  - deleting a, 5-6
  - deleting a test port group, 5-7
  - number possible, 5-1
- Test port group
  - definition, 5-1
  - number possible, 5-1
- Test Port Group field
  - description, 5-3
- Test Port No. field
  - description, 5-3
- Test port provisioning
  - definition, 1-4, 5-1
- TEST PORT PROVISIONING form, 5-2
- TEST PORT STATUS report
  - illustration and description, 14-8
- TG192 Card
  - supports Type PA, 4-17
- TG80 Card
  - and Type DE, 4-18
  - Circuit available with, 6-2
  - purpose, 1-4

- THRES ALARM, 16-6
  - THRESH IDLE, 16-6
  - Threshold alarm, 16-6
    - and facility performance alarm message, 4-23
  - tid, 2-12
  - Time
    - %T, 2-13
    - %T, %R, 2-14
    - on DACS, 3-36
    - resetting I-2000 Computer, 3-34
  - Time field
    - in TASK SCHEDULING pop-up, 2-39
    - on SEARCH CRITERIA form, 14-4
  - Time In field
    - on OUTAGE LOG form, 10-37
  - Time Out field
    - on OUTAGE LOG form, 10-37
  - Time zone, 2-16
    - setting, 2-17
  - Timeout
    - DACS frame commands, 2-7
    - for frame command in MP passthrough, 2-6
    - of MP passthrough sessions, 2-11
    - of RP plan command, 2-10
  - timezone, 2-17
  - TLA
    - definition, 6-18
    - in monitor test circuits, 15-3
    - in split test circuits, 15-5
    - Options field selection, 6-17
    - usage, 6-4
  - TLR
    - and TLA Option, 6-17
    - definition, 6-4, 6-18
    - usage, 6-18
  - TO
    - and multipoint circuit, 6-35
    - and NTR field, 6-18
    - and SC field value, 6-20
    - definition, 6-4
    - in broadcast circuit, 6-33
    - in high-rate circuit, 6-15
    - in Test Access, 15-2
    - on DATABASE AUDIT/SYNCHRONIZATION form, 10-18
  - TOP
    - use in passthrough, 13-9
  - TOP MENU
    - use to return to the MAIN MENU, 2-34
  - TOPPAGE
    - use to move through report, 14-1
  - TOTAL WIDTH field
    - on Edit Custom Report Format form, 14-17
  - Traffic-bearing
    - definition, 6-3
  - Transparent
    - denoted by TRSP in TC field, 6-19
  - TRB
    - IW field value, 6-20
  - Trouble code
    - definition, 6-20
  - Troubleshooting, B-8
  - TRSP
    - TC field value, 6-19
  - Trunk conditioning
    - and TC field, 6-18
    - as field on TP PROVISIONING form, 5-4
  - TS0 cross-connect feature
    - description, 6-4
  - TS0 field
    - on NPC PROVISIONING field, 4-20
  - TS0 to Non-TS0 circuits, 6-50
  - TS0M field
    - on NPC PROVISIONING form, 4-20
  - TSI ALARM, 16-6
  - TSI IDLE, 16-6
  - tty Port Number
    - and primary line, 3-17
  - Two-point cross-connection
    - types of circuits used in, 6-2
  - Two-way cross-connection
    - described and illustrated, 10-18
    - types of circuits used in, 6-2
  - Tx
    - in test circuits, 15-3
  - Type field
    - on FRAME ADMINISTRATION form, 3-15
    - on TASK ADMINISTRATION form, 11-4
    - restrictions on changing, 4-16
    - usage, 4-18
  - Type of alarm
    - in alarm messages, 16-4
- 
- ## U
- UAS, 16-8
  - UAS15MIN, 16-8
  - UAS15MIN alarm
    - and Type PA performance parameters, 4-24
  - UASDAILY, 16-8
  - UASDAILY alarm
    - and Type PA performance parameters, 4-24
  - UAT, 16-8
  - UATC, 16-8
  - UATC15MIN, 16-8
  - UATC15MIN alarm
    - and Type PA performance parameters, 4-25
  - UATCDAILY, 16-8
  - UATCDAILY alarm
    - and Type PA performance parameters, 4-25
  - UC, 16-6
  - UC ALARM, 16-6
  - UC IDLE, 16-6
  - UEQD
    - and broadcast circuit, 6-33
    - Service State field value, 4-15, 17-7
    - Site Status field value, 3-15

UI Idle Option field  
  USER MANAGEMENT form, 12-5

UI number, xxx

ui\_dval files, 2-15

Unavailable seconds, 16-8  
  and threshold settings, 4-24  
  Type PA performance parameter, 4-24, 17-2

Unit number  
  in hierarchical number, 4-18

unix  
  escape to, 2-20

UNSELECT  
  use in multiselect menu, 6-17

UNTERMINATE  
  Test Access Action field value, 15-9

Upper NPC  
  and DMB NPC, 4-3

Upper NPC No field  
  on NPC PROVISIONING form, 4-20

US15M alarm  
  and short interval options, 4-24

US24H alarm  
  and long interval options, 4-24

USER  
  Type field value, 11-4

User administration, 12-1  
  constraints, 12-2

USER ADMINISTRATION menu, 12-2

USER ADMINISTRATION report  
  type available, 14-9

User Class field  
  on USER LOGINS report, 14-9  
  usage, 12-1  
  USER MANAGEMENT form, 12-4

User ID field  
  on TASK ADMINISTRATION form, 11-4  
  on TASK SELECTION insert, 11-5

User Interface window, 2-19

User management  
  adding user login, 12-5  
  changing password (operator), 12-6  
  changing password (system administrator), 12-7  
  entering system on loss of password, 12-8

User Name field  
  on USER LOGINS report, 14-9  
  USER MANAGEMENT form, 12-4

---

## V

V  
  in SC field value, 6-20  
  NFS field value, 4-21  
  TS0 field value, 4-20

VERIFY  
  usage, 12-7

Virtual channel number  
  and Ch field, 6-16

  number, 6-16, 7-13

Virtual circuit  
  support for, 4-4

Virtual Multipoint Circuit  
  and DSP Shelf, 1-4

Virtual multipoint circuit  
  and test access, 15-2  
  bandwidth, 6-2

Virtual node  
  and ALTROUTE, 8-2  
  and FROM side of BRD, 6-13  
  and preempting, 8-7  
  definition, 6-33  
  how numbered, 6-33

Virtual NPC  
  definition and number, 4-3

VIRTUALx  
  NPC ID of virtual node, 4-3

---

## W

Wastebasket, 2-20

Wild-card characters  
  and NPC BROWSE, 4-17, 4-34  
  and SEARCH CRITERIA form, 14-3

Window manipulation, 2-19

---

## X

X.25  
  and PASSTHROUGH, 13-7  
  interface, 1-6  
  link status, 3-15  
  placing a line in service, 3-8  
  Protocol field value, 3-15  
  removing a line from service, 3-9

X.25 administration, 3-6

X.25 ADMINISTRATION form, 3-6

X.25 LINK ADMINISTRATION form  
  reported, 14-9

X.25 links  
  administering, 2-25

---

## Y

Y  
  OOS field value, 15-10

Year, 2-13

Year field  
  in TASK SCHEDULING pop-up, 2-39  
  on OUTAGE LOG form, 10-37  
  part of Service Date field, 6-21

TIME AND DATE ADMINISTRATION form, 3-35  
YES  
INCL field value, 4-21  
OOS field value, 4-21