

**FT-2000 OC-48 Lightwave System Quick Reference Guide 365-575-101 -
Issue 7.2**

This electronic document is protected by the copyright laws of the United States and other countries. The complete document may not be reproduced, distributed, or altered in any fashion. Selected sections may be copied or printed with the utilities provided by the viewer software as set forth in the contract between the copyright owner and the licensee to facilitate use by the licensee, but further distribution of the data is prohibited.

Copyright(c) 1996 Lucent Technologies
All Rights Reserved

1. Caution

Caution: Use a static ground wrist strap whenever handling circuit packs or working on an FT-2000 network element to prevent electrostatic discharge damage to sensitive components.

2. Reports

Retrieve-Alarm (and Status) retrieves local active alarm and status information.

Retrieve-Equipment retrieves the equipage and version information.

Retrieve-History retrieves maintenance history information up to 500 events.

Retrieve-Network Alarms retrieves active alarm and status information for the network.

Retrieve-State retrieves the slot, port, and protection switching state information.

Retrieve-Crossconnection-STS3 (or STS1) retrieves the STS3 (or STS1) cross-connect map of the node.

3. Clear Local Trouble When `USE CIT' LED Is Off

Overview: This procedure is used to replace a circuit pack with a lighted **FAULT** LED at the local FT-2000 network element. Alternatively, the craft interface terminal (CIT) can be used to clear the trouble following the procedure in **TAP-102** of AT&T 365-575-102, *FT-2000 OC-48 Lightwave System User/Service Manual*.

1.

Caution: Do not remove the **SYSC**TL circuit pack even if its **FAULT LED** is lighted because the provisioning data (current values) could be lost. Current values were provisioned with the **Set** command.

Are you using the CIT to clear trouble?

If **NO**, then continue with Step 2.

If **YES**, then go to **TAP-102** in the FT-2000 User/Service Manual.

2. Momentarily depress and release the **ACO/LOCTR** pushbutton on the user panel to silence any audible alarms.

3. Does the **LINE LOCTR** display in the user panel show a line (1 or P) or a shelf (H or L)?

If **LINE (1 or P)**, then continue with Step 4.

If **SHELF (H or L)**, then continue with Step 5.

4. Depress and hold the **ACO/LOCTR** pushbutton. The **LINE LOCTR** display will indicate the shelf with the failed circuit pack. The shelf is associated with an OC-48 line, and its direction is visually indicated by a lighted **E** (East) or **W** (West) LED.

5.

Note: An H indicates a High Speed Shelf or Enhanced High Speed Shelf at the bottom of the bay.
An L indicates a Low Speed Shelf - System Controller or Low Speed Shelf - Complementary in the middle of the bay.

Remove the cover on the shelf just identified.

Reference: **DLP-511** in the FT-2000 User/Service Manual.

6. Is one and only one **FAULT** LED continuously lighted?

If **YES**, then continue with Step 7.

If **NO**, then go to **TAP-108** in the FT-2000 User/Service Manual.

7. Is the **FAULT** LED lighted on either the SYSCTL or SYSTEMEM circuit pack?
If **YES**, then go to **TAP-102** in the FT-2000 User/Service Manual.
If **NO**, then continue with Step 8.
8.

Note: A series number **S1:2** is the same series number as **S1:4**. The 2 and 4 refer to minor changes within series 1.

Obtain a replacement circuit pack with the same or a higher series number and install it in place of the circuit pack with the lighted **FAULT** LED. As required, make the appropriate optical connections on the OC-3, IS-3, OC-12, RCVR, TRMTR, or REGENR circuit pack(s).
Reference: **DLP-514** in the FT-2000 User/Service Manual.
9. Wait for the time indicated in Table A.
10. Is the **FAULT** LED off on the circuit pack just replaced?
If **YES**, then continue with Step 11.
If **NO**, then go to **TAP-116** in the FT-2000 User/Service Manual.
11. Replace the shelf cover.
Reference: **DLP-511** in the FT-2000 User/Service Manual.
12. Are all LEDs off at the user panel except the **PWR ON** LED?
If **YES**, then **STOP! YOU HAVE COMPLETED THIS PROCEDURE**.
If **NO**, then go to **Trouble Clearing: IXL-001** in the FT-2000 User/Service Manual.

List of Tables

Table A: Mini Reset Waiting Times

CP Inserted	Waiting Time
LNCTL *	10 minutes
OHCTL	5 minutes
TG3 **	5 minutes
TOHCTL	5 minutes
All Others	35 seconds

* Inserting an LNCTL circuit pack starts a mini reset that can take up to 10 minutes to complete. During this time, LEDs on other circuit packs will be lighted due to software provisioning.

** When a TG3 circuit pack is first inserted, it will be switched out of service until it warms up. This can take as long as 5 minutes.

Glossary: Acronyms

Glossary: Terms and Definitions

adfasdfasdf — afadsfadfasdfasfafas