


# 46010

## MULTIPLE ALARM TRANSMITTER (MAT)



### Table of Contents

Ordering Information .....	2
General Description .....	2
Application Information .....	3
Circuit Description .....	6
Installation .....	7
Checkout .....	15
Operation .....	15
Technical Specifications .....	16
Warranty .....	18

#### About this Practice:

This practice has been reissued to:

- Move the **Application Information** section forward and renumber all Figs. appropriately.

**Reissued Practices:** Updated and new content can be identified by a banner in the right margin.

**Issue date: July 1998**

UPDATED

### CAUTION

- Install or remove modules from the shelf only when the power is off. If you install a module in the shelf with the power on, the internal circuitry may suffer damage and the product warranty will be void.
- Remove and install circuit boards only in a static-safe environment (use antistatic wrist straps, smocks, footwear, etc.).
- Keep circuit boards in their antistatic bags when they are not in use.
- Do not ship or store circuit boards near strong electrostatic, electromagnetic, magnetic, or radioactive fields.
- For more complete information on electrostatic discharge safety precautions, refer to Bellcore™ Technical Reference # TR-NWT-000870.

# ORDERING INFORMATION

**NOTE:** This section lists the different options available for this product. To order any of the available options, contact Dantel Inside Sales through our toll-free number, **1-800-432-6835**.

OPTION NUMBER	FEATURES
B11-46010-00	Multiple Alarm Transmitter; no display; one alarm relay output
B11-46010-02	Multiple Alarm Transmitter; one alarm relay output
B11-46010-03	Multiple Alarm Transmitter; four alarm relay outputs
B11-46010-12	Multiple Alarm Transmitter; one alarm relay output; TTL alarm inputs
B11-46010-13	Multiple Alarm Transmitter; four alarm relay outputs; TTL alarm inputs
A17-46010-02	Special Application MAT utilizing no parity

## GENERAL DESCRIPTION

The 46010 Multiple Alarm Transmitter (MAT) is part of Dantel's 460 Alarm and Control System. It does the following:

- ◆ Reports the alarm status for 16 independent discrete alarm inputs.
- ◆ Reports the alarms to a 46020 Multiple Alarm Processor (MAP), which sends data to an alarm center.
- ◆ Reports alarms locally through 1-4 relays to audible or visual devices.
- ◆ Provides alarm acknowledgment.

The 46010 MAT has a regulated power supply that uses -21 to -56 VDC input power. It is available in five different options:

OPTION NUMBER	FEATURES
*-00	A basic unit with no LED display and a one-alarm relay output.
-02	An LED display and a single-level relay output bus.
-03	An LED display and four alarm-level relay output buses.
-12	An LED display and a single-level relay output bus and TTL alarm inputs.
-13	An LED display, four alarm-level relay output buses, and TTL alarm inputs.

**NOTE:** In these instructions, any mention of LED displays (other than DATA XMT) refers only to the -02, -03, -12, and -13 options. The -00 option does not have these LEDs.

# GENERAL DESCRIPTION

---

## On all options:

A green LED on the front panel (labeled DATA XMT) lights up to show that the unit is sending data.

---

## On options -02, -03, -12, -13:

There are 20 red LEDs on the upper half of the front panel, arranged in a vertical row. The first 16 are numbered 1-16 starting at the top, and the last four are numbered A-D. The first 16 LEDs show the alarm status of each point. The last four (A-D) show the level of alarm. These LEDs operate in different modes, depending on how you set the switches S3-1, S3-2, S4-3, and S5-1. Table A explains how to set these switches for the type of operation you want.

If a second alarm occurs at the same level as an existing alarm, the level LED pulses once. The output relays follow the level LEDs.

---

## A17-46010-02 Special Application MAT

The A17-46010-02 MAT communicates using no parity, 1 stop bit and 8 data bits. (The standard 46010 MAT communicates using even parity, 1 stop bit and 8 data bits.)

# APPLICATION INFORMATION

**M**ultiple Alarm Transmitter applications include interrogated alarm status reporting, and alarm and control. All sixteen alarm inputs are bipolar. Two connections are made for each input. You can bus all negative or positive (ground) input leads together.

The 46010 MAT accepts plug-in subassemblies. These subassemblies provide additional functions, and you can order subassemblies factory installed or you can install them in the field. You can only mount one subassembly at a time. Fig. 1 shows the maximum allowable cable lengths for data transmission.

Fig. 2 shows an interrogated alarm application. The processing center interrogates (polls for data) multiple MATs with a 46022-20 Multiple Alarm Combiner (MAC) equipped with a data communications subassembly. The MATs and the MAC are in the same shelf and exchange data via TTL. You can set the polling address for each MAT with on-board switches.

---

**NOTE:** *Two MATs cannot share the same address. If they do, the combined output is garbled.*

---

# APPLICATION INFORMATION

FIG. 1 - MAXIMUM RECOMMENDED CABLE LENGTHS






FIG. 2 - EXAMPLE APPLICATION; MULTIPLE MATS IN SAME SHELF (ALARM ONLY)



# APPLICATION INFORMATION

Fig. 3 shows an alarm and control application. A MAT is connected to a 46030 Control Point Module (CPM). This provides alarm status reporting and remote control points at the same location and within the same shelf. A common data communications subassembly on the CPM sends data to and from the MAC and 46020 Multiple Alarm Processor (MAP).

FIG. 3 - EXAMPLE APPLICATION; DUAL SHELF APPLICATION



MATs and CPMs use Dantel DCM protocol to communicate with other system components. You can download alarm level assignments from the MAC and MAP no matter what the switch settings are. Refer to the MAP Firmware manual for information.

You can configure Dantel 460 Alarm Control Systems with custom software for special applications. Contact a Dantel Custom Service Engineer for more information.

FIG. 4 - EXAMPLE APPLICATION; MAT/CPM MODE




Fig. 4 shows a MAT/CPM mode application. Useful for transmitting alarm points from a remote location back to a central alarm center:

- ◆ Data transmission is one direction only
- ◆ Any communications subassembly may be used, but must match at both ends.
- ◆ The MAT and CPM must have the same address.
- ◆ Only one MAT may be used.

CONTINUED . . .


# APPLICATION INFORMATION

- ◆ The MAT is locked into transmit mode and is never polled.
- The CPM is locked into receive mode and constantly monitors the MAT's transmission. Any alarm point (1-16) triggered on the MAT is duplicated by the CPM's relay output (1-16).
- Point 16 of the CPM can be used to monitor the MAT and energize (or release) if the MAT fails.
- The CPM outputs can then be used to drive another MAT in that same office.

# CIRCUIT DESCRIPTION

Fig. 5 shows the 46010 MAT Functional Schematic.

FIG. 5 - FUNCTIONAL SCHEMATIC, 46010 MAT



# INSTALLATION

The 46010 MAT can operate in a number of different modes, depending on your needs. Study the tables carefully and make the proper switch settings for the mode of operation you choose.

---

## 1. Set switches.

Set the switches described in Tables A, B, C, and D, and Fig. 6 for the type of operation you want.

---

## 2. Mount a subassembly, if necessary.

The module comes equipped with a subassembly. To install a different subassembly, follow these steps:

- ◆ If there is a hole plug in the front panel of the MAT, remove the plug.
- ◆ Remove the three screws from the subassembly standoffs (see Fig. 6).
- ◆ Take the subassembly off the board.
- ◆ Place the new subassembly on the board.
- ◆ Insert P4 into J4 and P5 into J5.
- ◆ Make sure each connector pin goes straight into the socket.
- ◆ Make sure the subassembly fits closely on the standoffs.
- ◆ The panel should be straight in the opening.

---

## 3. Install the module in the proper slot of the equipment shelf.

Wire as necessary. Refer to Fig. 7.

# INSTALLATION

TABLE A - MODES OF OPERATION

OPTION	SWITCH NUMBER	SETTING
<b>NORMAL MODE</b>		
When an alarm occurs, that alarm's LED goes on but the level LED does not. When the alarm goes away, the alarm LED goes off. The ACK button does not function. The output relays remain inoperative.	S3-1	OFF
	S3-2	OFF
	S4-3	OFF
	S5-1	OFF
<b>LATCHING MODE</b>		
When an alarm occurs, both the alarm LED and the level LED go on. Press the ACK button. The level LED goes off. When the alarm goes away, the level LED goes back on. Press the ACK button. Both LEDs go off.	S3-1	OFF
	S3-2	ON
	S4-3	OFF
	S5-1	OFF
<b>ANNUNCIATOR MODE</b>		
When an alarm occurs, the alarm LED flashes. The level LED goes on. Press the ACK button. The level LED goes off and the alarm LED does not flash but stays on. When the alarm goes away, the level LED goes back on and the alarm LED flashes again. Press the ACK button. Both LEDs go off.	S3-1	ON
	S3-2	ON
	S4-3	OFF
	S5-1	OFF
<b>ALARM WITH LEVELS MODE</b>		
When an alarm occurs, that alarm's LED and the level LED go on. Press the ACK button. The level LED goes off. When the alarm goes away, both LEDs go off.	S3-1	ON
	S3-2	OFF
	S4-3	OFF
	S5-1	OFF
<b>TRANSMIT RESPOND DELAY (46010-12/13 OPTIONS ONLY)</b>		
When ON, the MAT's response to its poll is delayed by 1/25 second (40mS).	S3-3	ON
<b>TRANSMIT CONTINUOUS</b>		
ONLY FOR MAT/CPM MODE APPLICATIONS. Serial data is transmitted continuously. No external command is required to start data transmission.	S3-6	ON
<b>REVERSED INPUTS</b>		
Reverses the normal alarm status current from (A) Current Flow (TTL High) = Alarm Status, to (B) No Current Flow (TTL Low) = Alarm Status. The number of inputs reversible are 4, 8, 16, or none.	S4-1	Refer to Table B
	S4-2	
<b>LATCHING INPUTS</b>		
Holds and alarm point in the alarm status, even if the alarm is very brief. Reports the alarm data during the next transmission cycle. To restore the alarm point to normal, press the RST button.	S4-3	ON
<b>DELAYED INPUTS</b>		
Adds a short delay (1/2 second) to the alarm detection function. Brief signals caused by non-alarm conditions are not reported as alarms.	S4-4	ON
<b>AUTO LATCH RELEASE</b>		
Applies automatic reset to all latching inputs. The inputs are released as soon as the MAT transmits its status. The RST button is inactive.	S5-1	ON
	S4-3	ON
<b>MANUAL RELEASE</b>		
After an alarm is reported, the RST button must be pressed to return the alarm point to normal.	S5-1	OFF
	S4-3	ON
<b>ADDRESS</b>		
Sets the address of the MAT.	S5-2 thru S5-8	Refer to Table C.

# INSTALLATION

**TABLE B - SWITCH SETTINGS**

OPTION	SWITCH SETTINGS							
	S3-1	S3-2	S3-3	S3-4	S3-5	S3-6	S3-7	S3-8
Display Function Normal Latching Annunciator Alarm with Levels	OFF OFF ON ON	OFF ON ON OFF						
Transmit Respond Delay (-1X only)			ON					
Not Used				OFF	OFF		OFF	OFF
Transmit Continuous MAT/CPM Mode Only All other applications						ON OFF		
	S4-1	S4-2	S4-3	S4-4	S4-5	S4-6	S4-7	S4-8
Input Reversal Normal (current flow generates an alarm) Points 1-4 Reversed (no current flow generates an alarm) Points 1-8 All Points Reversed	OFF OFF ON ON	OFF ON OFF ON						
Latching Input			ON					
Delayed Input (500 m.s.)				ON				
Data Rate 50 Baud 75 Baud 110 Baud 135 Baud 150 Baud 300 Baud 600 Baud 1200 Baud 1800 Baud 2400 Baud 3600 Baud 4800 Baud 7200 Baud 9600 Baud					OFF OFF OFF OFF OFF OFF ON ON ON ON ON ON ON ON ON	OFF OFF OFF ON ON ON OFF OFF OFF OFF OFF OFF ON ON ON	OFF ON ON OFF ON ON OFF OFF ON ON OFF OFF OFF ON ON	ON OFF ON OFF ON ON OFF OFF ON OFF ON OFF OFF ON OFF
	S5-1	S5-2	S5-3	S5-4	S5-5	S5-6	S5-7	S5-8
Latch Release (When S4-3 is ON) Automatic Release (On Poll) Manual Release (Use RST button)	ON OFF							
Address	See Table C							

# INSTALLATION

**TABLE C - ADDRESS SELECTION (S5-8 IS NOT PART OF THE ADDRESSING)**

1  12345678	14 OFF ↓ ON  12345678	27  12345678	40  12345678	53  12345678	66  12345678	79  12345678	92  12345678	105  12345678	118  12345678
2  12345678	15  12345678	28  12345678	41  12345678	54  12345678	67  12345678	80  12345678	93  12345678	106  12345678	119  12345678
3  12345678	16  12345678	29  12345678	42  12345678	55  12345678	68  12345678	81  12345678	94  12345678	107  12345678	120  12345678
4  12345678	17  12345678	30  12345678	43  12345678	56  12345678	69  12345678	82  12345678	95  12345678	108  12345678	121  12345678
5  12345678	18  12345678	31  12345678	44  12345678	57  12345678	70  12345678	83  12345678	96  12345678	109  12345678	122  12345678
6  12345678	19  12345678	32  12345678	45  12345678	58  12345678	71  12345678	84  12345678	97  12345678	110  12345678	123  12345678
7  12345678	20  12345678	33  12345678	46  12345678	59  12345678	72  12345678	85  12345678	98  12345678	111  12345678	124  12345678
8  12345678	21  12345678	34  12345678	47  12345678	60  12345678	73  12345678	86  12345678	99  12345678	112  12345678	125  12345678
9  12345678	22  12345678	35  12345678	48  12345678	61  12345678	74  12345678	87  12345678	100  12345678	113  12345678	126  12345678
10  12345678	23  12345678	36  12345678	49  12345678	62  12345678	75  12345678	88  12345678	101  12345678	114  12345678	127  12345678
11  12345678	24  12345678	37  12345678	50  12345678	63  12345678	76  12345678	89  12345678	102  12345678	115  12345678	128  12345678
12  12345678	25  12345678	38  12345678	51  12345678	64  12345678	77  12345678	90  12345678	103  12345678	116  12345678	
13  12345678	26  12345678	39  12345678	52  12345678	65  12345678	78  12345678	91  12345678	104  12345678	117  12345678	

# INSTALLATION

**TABLE D - ALARM LEVEL SELECTION (POINTS 1-8)**

ALARM INPUT NUMBER	ALARM LEVEL	SWITCH NUMBER & SETTING	
1	A	<b>S101-1</b> ON	<b>S103-1</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
2	A	<b>S101-2</b> ON	<b>S103-2</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
3	A	<b>S101-3</b> ON	<b>S103-3</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
4	A	<b>S101-4</b> ON	<b>S103-4</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
5	A	<b>S101-5</b> ON	<b>S103-5</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
6	A	<b>S101-6</b> ON	<b>S103-6</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
7	A	<b>S101-7</b> ON	<b>S103-7</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
8	A	<b>S101-8</b> ON	<b>S103-8</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF


# INSTALLATION

TABLE D - ALARM LEVEL SELECTION (POINTS 9-16)

ALARM INPUT NUMBER	ALARM LEVEL	SWITCH NUMBER & SETTING	
9	A	<b>S102-1</b> ON	<b>S104-1</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
10	A	<b>S102-2</b> ON	<b>S104-2</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
11	A	<b>S102-3</b> ON	<b>S104-3</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
12	A	<b>S102-4</b> ON	<b>S104-4</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
13	A	<b>S102-5</b> ON	<b>S104-5</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
14	A	<b>S102-6</b> ON	<b>S104-6</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
15	A	<b>S102-7</b> ON	<b>S104-7</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF
16	A	<b>S102-8</b> ON	<b>S104-8</b> ON
	B	ON	OFF
	C	OFF	ON
	D	OFF	OFF


# INSTALLATION

FIG. 6 - SWITCH LOCATIONS, 46010



# INSTALLATION

FIG. 7 - PIN DESIGNATIONS, 46010



# CHECKOUT

Verify the 46010 MAT is functioning properly by following these steps:

1. Operate each of the devices connected to each of the MAT's alarm points one at a time.
2. Look at the front panel LEDs and the computer (or dumb terminal) that is being used with the system. The lighted LEDs and the messages on the computer screen should be correct for each device.

Table E describes some other ways to test the performance of the 46010 MAT.

TABLE E - CHECKOUT PROCEDURES, 46010 MAT

PROCEDURE	RESULT
1. Turn on power to the shelf.	When the MAT's address is polled, the green LED labeled DATA XMT flashes. This indicates that the MAT is sending data to the processing center.
2. Press the ACK and RST buttons at the same time. Hold them for a few seconds.	All LEDs except the DATA XMT light up and remain on until the buttons are released.

# OPERATION

Once the 46010 MAT is installed, simply observe the front panel and press the RST and ACK buttons to reset and acknowledge alarms according to the mode you have chosen. (Refer to Tables A and B, in the *Installation* section for switch settings.)

# TECHNICAL SPECIFICATIONS

DESCRIPTION	VALUE
Input Voltage	-21 to -56 VDC
Input Current (Maximum; @ -56VDC)	
-00 Option	35 mA
-02 & -12 Options	75 mA
-03 & -13 Options	105 mA
Heat Dissipation (maximum; @ -56VDC)	
-00 Option	6.7 Btu/Hr
-02 & -12 Options	14.3 Btu/Hr
-03 & -13 Options	20.0 Btu/Hr
Alarm Inputs	
-00 thru -03 Options	
Voltage Range	-21 to -56 VDC
Current Range	600uA to 2.0 mA
Resistance	33K Ohms + 1 diode (0.6 volts)
-12 & -13 Options (TTL)	0 to 0.9 VDC = Low Level 2.6 to 5.25 VDC = High Level
Outputs (Alarm Level Relays)	
Contact Type	Single Form-C Dry Contact
Contact Ratings (maximum)	1 Amp @ 28 VDC; 0.5 Amp @ 120 VAC
Data Port (with Bypass Card - no subassembly)	Standard TTL
Data Rates	50 through 9600 baud
Weight (excluding subassemblies)	
-00 Option	10 ounces
-02 & -12 Options	12 ounces
-03 & -13 Options	14 ounces
Physical Dimensions	1.4"W x 6"D x 5.6"H
Operating Temperature Range	0° to 55° C.

# NOTES

# WARRANTY

## LIMITED WARRANTY

The Seller warrants that the standard hardware products sold will be free from defects in material and workmanship and perform to the Seller's applicable published specifications for a period of 18 months for hardware, and 3 months for software, from the date of the original invoice. The liability of the Seller hereunder shall be limited to replacing or repairing, at its option, any defective products which are returned F.O.B. to the Seller's plant, (or, at the Seller's option, refunding the purchase price of such products). In no case are products to be returned without first obtaining permission and a customer return authorization number from the Seller. In no event shall the Seller be liable for any consequential or incidental damages.

Equipment or parts which have been subject to abuse, misuse, accident, alteration, neglect, unauthorized repair or installation are not covered by warranty. The Seller shall make the final determination as to the existence and cause of any alleged defect. No warranty is made with respect to custom equipment or products produced to the Buyer's specifications except as specifically stated in writing by the Seller in the contract for such custom equipment.

This warranty is the only warranty made by the Seller with respect to the goods delivered hereunder, and may be modified or amended only by a written instrument signed by a duly authorized officer of the Seller and accepted by the Buyer.

Warranty and remedies on products not manufactured by the Seller are in accordance with warranty of the respective manufacturer. THE SELLER MAKES NO OTHER WARRANTY OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED; AND ALL IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE WHICH EXCEEDS THE AFORESAID OBLIGATIONS IS HEREBY DISCLAIMED BY THE SELLER.

## IN CASE OF DIFFICULTY

If you experience difficulty with this equipment, check the following, as appropriate:

1. Switch settings
2. Signal levels
3. Software configuration
4. Connections between Dantel's equipment and your equipment.

If there is still a problem, substitute equipment that is known to be good. For additional assistance, call Dantel's Technical Field Service Department weekdays, 6 A.M. to 5 P.M. pacific time:

**1-800-4DANTEL (1-800-432-6835).**

If a thorough checkout shows a piece of equipment has malfunctioned, you may return it to the factory. For repairs and emergency replacements, obtain a Return Material Authorization (RMA) number from the Customer Service Representative at **1-800-4DANTEL (1-800-432-6835)**.

To ensure expedient processing of your order, provide a purchase order number and shipping and billing information when requesting an RMA number. Also, when the units are returned to Dantel, include a description of the failure symptoms for each unit returned. Send defective equipment to:

**Dantel, Inc. • 2991 North Argyle Avenue • Fresno, California 93727-1388**

