



PARTNER® Plus /II Release 3.1

Communications System and

PARTNER MAIL VS™


Voice Messaging System



Quick Reference

518-322-103

Copyright © 1994 AT&T





Help!

If you have problems with your phone, contact your System Manager. If the problem is not solved, in the continental U.S. please call our toll-free Helpline, available 24 hours a day, at 1 800 628-2888.

Outside the continental U.S., contact your local AT&T Authorized Dealer.



PARTNER MAIL VS is a trademark and MLS-34D, MLS-18D, MLS-12D, MLS-12, MLS-6, and PARTNER are registered trademarks of AT&T.






Table Of Contents

Telephone Buttons and Indicators	2
Using the Phone	4
Ringing Patterns	4
Lights	4
System Lines	4
Programming	5
System Features	6
Making a Call	8
Entering a Password	8
Entering an Account Code	8
Answering a Call	9
Transferring a Call	9
Making a Conference Call	10
Joining a Call	10
Making a Call to a Calling Group	10
Loudspeaker Paging	10
Putting a Call on Hold	11
Answering a Call Ringing at Another Extension	11
Forwarding a Call	11
Using the PARTNER MAIL VS System	12
Helpful Hints	12
Logging In to the Voice Messaging System	13
Listening to Messages	13
Recording Your Personal Greeting	14
Changing Your Password	14
Using the Tutor Service	15
Programming a Voice Mail Messages Button	15
Personal Speed Dial Numbers	16
System Extensions	16





Telephone Buttons and Indicators



Intercom Buttons. Press either button to place an inside (intercom) call to another extension.

Volume Control Buttons. Press to decrease (▼) or increase (▲) the volume of the ringer, speaker, and handset:

- To adjust ringer volume, while phone is idle and handset is on the phone, press ▼ or ▲.
- To adjust speaker volume, press ▼ or ▲ while listening through the speaker.
- To adjust handset earpiece volume, while listening on a call lift the handset and press ▼ or ▲.
- To adjust background music volume, press ▼ or ▲ while listening to music through the phone's speakers.

To adjust the display brightness on an MLS-18D phone, when the phone is idle and the handset is on the phone: press (⊗); then press ▼ to decrease brightness, or ▲ to increase brightness.

Message Indicator. Lights when someone signals you using Message Light On (see page 7) or if you have a message in your mailbox. To turn off, dial *Feature* 1 0 and your extension number, or call PARTNER MAIL VS to retrieve then delete your messages.



1 Display

[MLS-34D,[®] MLS-18D,[®] and MLS-12D[®] only] When dialing, shows the number dialed, duration of call, and feature messages. When receiving an intercom call, shows the number (and name if programmed) of the extension calling. When in programming mode, displays programming messages. When not using the phone, displays today's date and time or Caller ID information (if available—on PARTNER II systems only). (You can adjust the display contrast on the MLS-18D; see "Volume Control Buttons" on page 2.)

2 Line/Programmable Buttons

A line can be assigned on any button with status lights. (The MLS-34D and MLS-18D have status lights for all of these buttons; the MLS-12D and MLS-12[®] are identical to the MLS-18D, except that they do not have lights for the 6 buttons shown above the white line on the left.) When an outside line is assigned, press the button to make and receive calls. You may have to enter an account code to get an outside line (see page 6). When no line is assigned to a button, you can program the button with one-touch dialing features (no status lights are required for most features). Dial-code features are listed on pages 6 and 7; programming instructions are on page 5. Once programmed, press the button to dial the number or use the feature.

NOTE: The MLS-6[®] phone has 4 line/programmable buttons. When 4 lines are assigned, it has no programmable buttons; with 2 lines assigned, it has 2 programmable buttons.

3 Speakerphone Operation

[MLS-34D, MLS-18D, MLS-12D, and MLS-12]

Press **(Spkr)** to dial and speak on your phone without lifting the handset. When you press **(Spkr)**, both the speaker and the microphone come on (indicated by the lights next to the **(Spkr)** and **(Mic)** buttons). When the party on the other end answers, you can speak without lifting the handset. (On the MLS-6, press to dial without lifting the handset; when the party you are calling answers, lift the handset to speak.)

Mic (Microphone) Button. [MLS-34D, MLS-18D, MLS-12D, and MLS-12 only] Press **(Mic)** to turn your microphone on and off. When the green light next to **(Mic)** is on, the microphone is on. To answer calls without lifting the handset, leave the microphone on (see "HFAI" below). On a speakerphone call, press **(Mic)** to mute your voice.

HFAI (Hands-Free Answer on Intercom). For more convenient speakerphone operation, leave the microphone on all the time (press **(Mic)** if the light next to the button is off). When you receive a voice-signal call (you hear a beep), the person calling can talk to you over your phone's speaker; simply begin speaking to have a hands-free, two-way conversation.

Feature Button. Press to program (page 5) or to use dial-code features (pages 6 and 7).

Conf (Conference) Button. Press to conference (add) other parties to your call (page 10).

Transfer Button. Press to transfer a call to another extension (page 9).

Hold Button. Press to put a call on hold for later pickup (page 11).





Using the Phone

Ringling Patterns

You can tell the type of call coming in by the way the phone rings:

Ring...Ring...Ring...Ring...Ring...Ring... Outside Call

Ring-BEEP...Ring-BEEP...Ring-BEEP... Inside Call

Ring-BEEP-BEEP...Ring-BEEP-BEEP... Transferred Call

Lights

Red (top) light shows activity at **another** extension.

Green (bottom) light shows activity at **your** extension.

Steady on: Line is busy.

Off (off continuously): Line is idle, available for use.

Flash (long on, long off): Call is ringing on the line.

Alternating Red/Green Flash: (red on, green on, red on, green on): Appears at all extensions in a conference or joined call.

Wink (long on, short off): Call is on hold (anyone with line can pick up).

Flutter (short on, short off): Call is on exclusive hold (only extension that put call on hold can pick up) or a transferred call is returning to you, or on PARTNER II systems only Caller ID Inspect feature button is on or you are being manually signaled by an extneison.

Broken flutter (short on and off followed by long off): Fax trouble.

System Lines

Line No.	Phone No. or Description	Line No.	Phone No. or Description
01		13	
02		14	
03		15	
04		16	
05		17	
06		18	
07		19	
08		20	
09		21	
10		22	
11		23	
12		24	

* Shading indicates lines that apply only to the PARTNER II system.





Programming

To Program Buttons

Use programming to store dialing sequences on programmable buttons (see diagram, pages 2–3). Then simply touch the button to dial automatically.

1. Press **(Feature)** **(0)** **(0)** to enter programming mode.
2. Press a programmable button.
3. Press the buttons you normally press to dial another extension, to dial an outside telephone number, or to use a system feature (see examples below).

NOTE: To store **(Intercom)** on a button, press the left **(Intercom)** button.

To program more buttons, or to change the programming, repeat Steps 2 and 3.

4. Press **(Feature)** **(0)** **(0)** to exit programming mode.

Examples:

Autodial another extension number

To ring extension 11 with one touch, program **(Intercom)** **(1)** **(1)**; to voice signal extension 11, program **(Intercom)** **(*)** **(1)** **(1)**.

You can also use this button to:

- Transfer calls with one touch.
- See when the extension is busy (*red steady light*) or calling you (*green flashing light*), or when a transferred call is returning to you or (on PARTNER II systems only) when you are being manually signaled by the extension (*green fluttering light*).

Autodial an outside telephone number

To dial 555-5678 with one touch, program **(5)** **(5)** **(5)** **(5)** **(6)** **(7)** **(8)**.

Any dial-code feature on page 6 or 7

Program the dial code on a button. For example, to use Do Not Disturb with one touch, program **(Feature)** **(0)** **(1)** on a button with lights. For some features, you can also program an extension number or group number on the button, as indicated in the descriptions on pages 6 and 7. For example, to use Call Pickup for calls ringing at extension 12, program **(Intercom)** **(6)** **(1)** **(2)** on a button.

To Program Personal Speed Dial Numbers

1. Press **(Feature)** **(0)** **(0)** to enter programming mode.
2. Press **(Feature)**, then the two-digit Dial Code (80–99) for the phone number.
3. Enter the outside phone number (up to 20 digits).
To add more Speed Dial numbers, repeat Steps 2 and 3.
4. Press **(Feature)** **(0)** **(0)** to exit programming mode.

To change a number, follow Steps 1–4 but enter the new number in Step 3.

Special Dialing Functions

You can enter the following special functions in Speed Dial or Auto Dial numbers:

Function	Button	Display	Description
Pause	(Hold)	P	1.5-second pause
Recall	(Spkr)	R	Timed switchhook flash
Stop	(Mic)	S	Stops dialing sequence until button is pressed or code is dialed again
Touch-Tone Enable	(Transfer)	T	Sends touch tones over a rotary line





System Features

Feature	Manual	Button
Account Code Entry Enters a code of up to 16 digits for an incoming or outgoing call. You may have to enter an account code to access an outside line.	Dial <i>Feature</i> (1) (2), the account code, then <i>Feature</i> (1) (2) again	Press the button*, dial the account code, then press the button again
Background Music Plays Music On Hold through the speaker on your idle system phone (except MLC-6).	Dial <i>Feature</i> (1) (9) to turn on and off	Press the button* to turn on and off
Call Forwarding/Call Follow-Me Forwards calls (to cancel, enter your extension as destination). Unless Do Not Disturb is on, phone beeps when a call is forwarded. On PARTNER II, extension numbers are optional on a button (must be entered manually if not stored).	Dial <i>Feature</i> (1) (1) + Your Ext. No. + Destination Ext. No.	Press the button* + Your Ext. No. (if not stored) + Destination Ext. No. (if not stored)
Call Pickup Picks up a call ringing at an extension. On a programmed button, include extension number.	Dial <i>Intercom</i> (6) + Ext. No.	Press the button
Caller ID—Inspect (PARTNER II only) Shows information for another line (without disconnecting a current call or putting it on hold). To use, program <i>Feature</i> (1) (7) on a button with lights (button light flutters when feature is on).	Not available	Press the button, then press a line button; press the button again to turn off
Caller ID—Name Display (PARTNER II only) Switches between caller's phone number and name (if available). To use, program <i>Feature</i> (1) (6) on a button with lights.	Not available	Press the button* to turn on and off
Conference Drop Drops the last outside party added to a conference call.	Dial <i>Feature</i> (0) (6)	Press the button
Direct Line Pickup—Active Line Accesses a ringing, held, or active call on a line that is not assigned to your phone.	Dial <i>Intercom</i> (6) (8) + Line Number	Press the button + Line Number
Direct Line Pickup—Idle Line Accesses an idle line that is not assigned to your phone.	Dial <i>Intercom</i> (8) + Line Number	Press the button + Line Number
Do Not Disturb Prevents your incoming calls from ringing (use only if someone covers your calls). To use, program <i>Feature</i> (0) (1) on a button with lights.	Not available	Press the button* to turn on and off
Exclusive Hold Places a call on hold so other extensions cannot pick it up.	Dial <i>Feature</i> (0) (2)	Press the button
Group Calling—Ring/Page Simultaneously rings or pages all extensions in a Calling Group [†] , or (on PARTNER II systems only) transfers a call to a Calling Group. You are connected to the first group extension that answers.	Ring: Dial <i>Intercom</i> (7) + Group Number (1-4) Page: Dial <i>Intercom</i> (x) (7) + Group Number (1-4) Transfer: Dial <i>Transfer</i> (7) + Group Number (1-4)	Press the button

- ★ On a button with lights, light is on when feature is on.
- † If programmed on a button, include the group number (see your System Manager for group assignments).
- Feature must be programmed onto a button with lights (see page 4).
- Button with lights recommended (not required).





Feature	Manual	Button
Group Hunting—Ring/Voice Signal Rings, voice signals, or (for PARTNER II systems only) transfers a call to the next available extension in a Hunt Group.†	Ring: Dial (Intercom) 7 7 + Group Number (1-7) Voice: Dial (Intercom) * 7 7 + Group Number (1-6) Transfer: Dial (Transfer) 7 7 + Group Number (1-7)	Press the button
Group Pickup Picks up a call ringing at any extension in a Pickup Group.†	Dial (Intercom) 6 6 + Group Number (1-4)	Press the button
Last Number Redial Redials the last outside number you dialed.	Dial (Feature) 0 5	Press the button
Loudspeaker Paging Connects you to the loudspeaker system.	Dial (Intercom) 7 0	Press the button
Manual Signaling—Ring/Voice Signal (PARTNER II systems only) When on-hook or on an outside line, beeps an extension; when on intercom, rings or voice signals. Program (Feature) 1 3 and the extension on a button to ring, or (Feature) 1 3 * and the extension to voice signal. On a button with lights, lights show calling activity.	Not available	* To beep: Press the button To ring or voice signal: Press (Intercom), then press the button
Message Light On/Off Turns a phone's message light on or off. On PARTNER II, an extension number is optional on a button (must be entered manually if not stored).	On: (Feature) 0 9 + Ext. No. Off: (Feature) 1 0 + Ext. No.	Press the button + Ext. No. (if not stored)
Privacy Prevents others from joining your calls. To use, program (Feature) 0 7 on a button with lights.	Not available	Press the button* to turn on and off
Recall "Recalls" dial tone when you are on a call, to access a PBX or Central Office service.	Dial (Feature) 0 3	Press the button
Save Number Redial Saves the last outside number you dialed into memory (but not a System Speed Dial number). Save a number before you hang up; the number stays in memory until a new one is saved.	Dial (Feature) 0 4 before hanging up To redial later, dial (Feature) 0 4 again	Press the button before hanging up To redial later, press the button again
Touch-Tone Enable Sets to touch-tone dialing for the rest of a call.	Dial (Feature) 0 8	Press the button
VMS Cover Turns voice mail coverage on and off. To use, program (Feature) 1 5 on a button with lights.	Not available	Press the button* to turn on and off
Voice Interrupt on Busy Talk-Back Lets you respond to a voice interrupt on busy call. To use, program (Feature) 1 8 on a button with lights.	Not available	Press the button* to turn on and off
Voice Mail Messages Dials PARTNER MAIL VS to check messages.	Dial (Intercom) 7 7 7	Press the button
Voice Mailbox Transfer Transfers a call directly to a subscriber's voice mailbox, so a caller can leave a message.	Dial (Feature) 1 4 + Ext. No.	Press the button + Ext. No.

- * On a button with lights, light is on when feature is on.
- † If programmed on a button, include the group number (see your System Manager for group assignments).
- Feature must be programmed onto a button with lights (see page 4).
- Button with lights recommended (not required).





Making a Call

To call an outside party:

Outside:
 (Line) + Phone Number
 or
 (Intercom) (8) +
 Line Number +
 Phone Number

If a password is needed, enter it before Step 1. Also, to get outside dial tone, you may have to enter an account code before Step 2. If this applies to your phone, contact your System Manager for instructions.

1. Lift handset.
2. Press an idle (not lit) line button. To dial on a line not assigned to your phone, press (Intercom) (8) followed by the line number.
3. Dial telephone number.

To call an inside party (another extension):

Inside—Ringing:
 (Intercom) +
 Extension Number

You can lift the handset or press (Spkr) before dialing.

1. Press an idle (Intercom) button.

Inside—Voice-Signaled:
 (Intercom) + (*) +
 Extension Number

You hear intercom dial tone, and the light next to the (Intercom) button is steady green.

2. To ring the extension, dial the two-digit extension number.

To voice-signal a system phone at the extension, press (*) plus the two-digit extension number:

- If you hear *one beep*, you have reached an idle system phone. You can speak after the beep.
Your voice is heard through the other extension's speaker. If the recipient is present, he or she can reply.
- If you hear *two beeps*, you have reached a busy system phone with Voice Interrupt On Busy Assigned. You can speak after the beeps. Be aware that the third party to whom the recipient is speaking will probably also hear the two beeps and the faint sound of your voice.
If the recipient has a Voice Interrupt On Busy Talk-Back button, wait for a response.



Entering a Password

(Hold) + Password

1. Press (Hold) and enter the four-digit password.

Entering an Account Code

(Feature) (1) (2) +
 Account Code +
 (Feature) (1) (2)

1. While off-hook, dial (Feature) (1) (2).
2. Enter an account code of up to 16 digits (manually or using an Auto Dial button or Speed Dial number). See your System Manager for a list of account codes.
3. Dial (Feature) (1) (2).





Answering a Call

You can answer a call on any line that is ringing, or select a specific line if more than one is ringing:

- When the telephone is ringing, lift the handset.
- To answer a call on a specific line, press the line button for the line you want to answer, then lift the handset.

If you are already on a call:

- Press **Hold** to put the first call on hold.
- Press the flashing line button to pick up the new call.

To answer a voice-sigaled call (your phone beeps):

- If the microphone is on, begin speaking (if not, press **Mic** or lift handset).

To respond to a voice interrupt on busy call (your phone beeps twice):

- Press the Voice Interrupt On Busy Talk-Back button, then begin speaking.

At Your Extension:

Line

Hold Line

Transferring a Call

To pass a call to another extension:

- While active on the call, press **Transfer**.
The call is put on hold and you hear intercom dial tone.
- Dial the extension number, **7 7** and a Hunt Group number (1-7), or (for PARTNER II systems only) **7** and a Calling Group number (1-4)*.
- When someone answers, announce the call, then hang up.

If no one answers or the call is refused, to reconnect to the caller, press the line button next to the winking green light.

To make a voice-sigaled transfer:

- While active on the call, press **Transfer**.
The call is put on hold and you hear intercom dial tone.
- Dial ***x** and the two-digit extension number.
 - If you hear *one beep*, you have reached an idle system phone. You can speak after the beep.
Your voice is heard through the other extension's speaker. If the call is accepted, hang up. If no one answers or the call is refused, press the line button next to the winking green light to reconnect to the caller.
 - If you hear *two beeps*, you have reached a busy system phone with Voice Interrupt On Busy Assigned. You can speak after the beeps. Be aware that the third party to whom the recipient is speaking will probably also hear the two beeps and the faint sound of your voice.
Your voice is heard through the recipient's handset or speaker. If the recipient has a Voice Interrupt On Busy Talk-Back button, wait for a response. To complete the transfer, hang up—the call rings at the recipient's extension. If the call is refused, press the line button next to the winking green light to reconnect to the caller.

Transfer +
Extension Number,
7 7 + Hunt Group
Number (1-7),
or
7 + Calling Group
Number (1-4)

Transfer + ***x** +
Extension Number

* See your System Manager for Calling Group, Pickup Group, and Hunt Group assignments.





Making a Conference Call

To add parties to a call (max. 4 parties plus you):

Telephone or
Extension Number +
(Conf) +
Telephone or
Extension Number +
(Conf)

1. Call the first party (can use Speed Dial or Auto Dial buttons).
2. After the first party answers, press (Conf).
3. Press an idle line button and call the second party (or press (Intercom) and extension number to add an inside party).
4. After the second party answers, press (Conf) again; you are connected with both parties.

The lights at all extensions in the conference flash red and green.

5. To add others, repeat Steps 2–4.

To Drop:

(Feature) 0 6

To drop the last outside party added to the call:

1. Press (Feature) 0 6.

NOTE: You cannot add more than 2 outside parties, transfer a conference call, or join a conference call.

Joining a Call

To connect yourself to an outside call being conducted at another extension:

(Line)

or

(Intercom) 6 8 +
Line Number

1. Press the line button (steady red light) or dial (Intercom) 6 8 and the two-digit line number.
2. Lift handset.

NOTE: You cannot join an inside call, a conference call, or a call at an extension with Privacy turned on.

Making a Call to a Calling Group

To call everyone in a Calling Group* :

Ringing Call:
(Intercom) 7 +
Group Number (1–4)

Paging Call:
(Intercom) * 7 +
Group Number (1–4)

1. Press (Intercom).
2. Lift handset.
3. Dial 7 and a group number (1–4) to ring the group, or dial (* 7) plus a group number to page those in the group who have idle MLS-model phones with speakers.

You are connected to the first extension to answer.

Loudspeaker Paging

To make an announcement over the loudspeaker paging system (if one is connected to your system):

(Intercom) 7 0

1. Press (Intercom).
2. Lift handset.
3. Dial 7 0, then follow the instructions for your paging system to make your announcement.

* See your System Manager for Calling Group, Pickup Group, and Hunt Group assignments.





Putting a Call on Hold

Hold:

(Hold)

Exclusive Hold:

(Feature) 0 2

To Pick Up:

(Line)

To hold so anyone with the line can pick it up:

1. Press (Hold).

To hold so only you can pick it up (Exclusive Hold):

1. Press (Feature) 0 2.

To pick up a held call:

1. Press the line button next to the winking green light.
2. Lift handset.

Answering a Call Ringing at Another Extension

At a specific extension:

(Intercom) 6 +

Extension Number

or

At any extension:

(Intercom) 6 8 +

Line Number

At any extension in the

Pickup Group:

(Intercom) 6 6 +

Group Number (1-4)

To answer a call ringing at any other extension:

1. Press (Intercom).
2. Lift handset.
3. Dial 6 plus the number of the ringing extension (or if you know which line is ringing—but not the specific extension—dial 6 8 plus the two-digit line number).

To answer a call ringing at any extension in a Pickup Group:*

1. Press (Intercom).
2. Lift handset.
3. Dial 6 6 plus the group number (1-4).

NOTE: On PARTNER II systems, you can answer an outside, intercom, or transferred call ringing at any extension in a Pickup Group. On a PARTNER Plus system, you can answer only outside calls.

Forwarding a Call

(Feature) 1 1 +

Source Extension

Number +

Destination Extension

Number

To forward intercom, outside, and transferred calls:

1. Press (Feature) 1 1.
2. Dial your extension number.
3. Dial the destination extension number. (To cancel Call Forwarding, enter your own extension number as the destination.)

Your system phone beeps once each time a call is forwarded from your extension.

* See your System Manager for Calling Group, Pickup Group, and Hunt Group assignments.





Using the PARTNER MAIL VS System

The voice messaging system serves as your personal answering machine. Callers from inside and outside your company can hear your personal greeting and leave messages in your mailbox, which you can listen to, save, or discard. A password you create keeps messages private.

Helpful Hints

- While using Voice Mail Service, you can:
 - Dial the next step of any procedure without waiting for a greeting or prompt to finish.
 - Press **(*) #** to go back to the previous menu.
 - Use the following key sequences:
 - (*) D** or **(*) 3** to *delete* a message
 - (*) H** or **(*) 4** to access *help*
 - (*) R** or **(*) 7** to *restart*
 - (*) T** or **(*) 8** to *transfer*

Additionally, you can press **(*) (*) X** or **(*) (*) 9** to exit Voice Mail Service and make other calls without having to hang up the handset. (This is useful when you are calling from a pay phone or making credit card calls.)
- The PARTNER MAIL VS system turns on the message light on your system phone when a message is sent to your mailbox, and turns off the message light after you delete all of your messages.
- Your mailbox accommodates up to 10 minutes of stored messages (or 40 messages). The receptionist's mailbox at extension 10 accommodates up to 30 minutes of stored messages (or 120 messages).
- When your mailbox is 80% full, you will hear the "Mailbox is 80% Full" warning when you first log in to Voice Mail Service. If your mailbox is 100% full, you will hear the "Mailbox is Full" warning.
- You can transfer to another extension:
 - While logged in to Voice Mail Service,
 - After hearing someone's personal greeting,
 - From a system extension or a remote telephone,

To transfer:

 1. Press **(*) T** to transfer to another extension.
The prompt says, "Please enter extension number."
 2. Enter the extension number to which you want to be connected.
To transfer to the receptionist's extension, press **0**.
- Intercom and transferred calls to covered extensions ring 4 times at the extension before Call Answer Service plays your personal greeting. If you want intercom and transferred calls to go immediately to the PARTNER MAIL VS system, you can use the Do Not Disturb feature in conjunction with voice mail coverage. The green light next to the Do Not Disturb button is lit when this feature is on.





Logging In to the Voice Messaging System

- If you are calling from:
 - Outside your company:
 - Call in on a line answered by the PARTNER MAIL VS system.
 - Press **(*) (R)** to access your mailbox when you hear either the Automated Attendant Service greeting or a subscriber's personal greeting.

If someone answers the call, ask them to transfer you to the PARTNER MAIL VS system by dialing **(Transfer) (7) (7) (7)** (or pressing a programmed button).
 - Inside your company:
 - Press a programmed button to log in to the PARTNER MAIL VS system or:
 - From a system phone**, press **(Intercom) (7) (7) (7)**.
 - From a standard phone**, press **(7) (7) (7)** after you hear intercom dial tone.
- Enter your extension number followed by **(#)**.
NOTE: When dialing from your extension, just press **(#)**.
- Enter your password followed by **(#)**.
NOTE: Until you change it, the password is 1 2 3 4.
The system announces the number of messages in your mailbox.
- Select an option from the Voice Mail Menu:
Press **(2)** to get messages.
(3) to change your personal greeting.
(5) to change your password.
(*) (7) to transfer to another extension.
(0) to transfer to the receptionist at extension 10.



Listening to Messages

- Log in to the PARTNER MAIL VS system.
The Voice Mail Menu plays.
- Press **(2)** to get messages.
The message header plays.
- Press **(0)** to play the message.
The message plays.
- After the message plays:
 - Press **(2) (3)** to replay the current message header. Go back to Step 3.
 - Press **(0)** to replay the current message.
 - Press **(#)** to save the message and skip to the next message header. Go back to Step 3.
 - Press **(*) (0)** to delete the message.
The prompt says "Deleted" and the next message header plays. Go back to Step 3.





Recording Your Personal Greeting

Before you record, note that callers who hear your personal greeting can enter **(*) 7** to transfer to another extension, or they can enter **0** to reach the receptionist before or after your message plays. You may want to prompt the caller to press **(*) 7** or **0** in your personal greeting.

Note: If your mailbox is full, callers hear your personal greeting and then the message "Sorry Mailbox is Full." To leave a message, they must either transfer to the receptionist's extension or to another subscriber's extension.

1. Log in to PARTNER MAIL VS.
The Voice Mail Menu plays.
2. Press **(3)** to change your personal greeting.
The Greeting Menu plays.
3. If you would like to listen to the current greeting before you change it, press **0**. If not, go to Step 4.
4. Lift the handset and press **7** to change your greeting.
The prompt says, "After recording, press 1. Record at the tone."
5. After you hear the tone, record your personal greeting (two minutes maximum).
Example: "This is Joe Conlin. I'm in the office today but away from my desk. If you would like to talk to the receptionist, press **0**. Otherwise, please leave your name, phone number, and a brief message at the sound of the tone."
6. Press **7** after recording.
7. Choose an option or go to Step 8:
 - Press **(2) (3)** to play back the greeting.
 - Press **(2) (7)** to re-record the greeting. Go to step 5.
 - Press **(*) (0)** to delete the greeting. The old greeting remains in effect.
8. Press **(*) (#)** to approve the greeting.

Changing Your Password

To prevent unauthorized use, select a password composed of random, non-sequential digits.

1. Log in to the PARTNER MAIL VS system.
The Voice Mail Menu plays.
2. Press **(5)** to change your password.
The prompt says, "Enter new password and # sign."
3. Enter up to four digits for the new password followed by **(#)**. You should use random, non-sequential digits.
The prompt says "Re-enter password."
4. Enter the new password again followed by **(#)**.





Using the Tutor Service

The TUTOR Service is a help feature that allows you to access and listen to information about commonly-used phone system features.

To access the TUTOR Service menu:

1. Dial (Intercom) 7 7 7.
2. Press (*) 4 after you hear the "Please enter extension number" prompt.
Voice prompts request you to enter the topic and subtopic numbers.
3. At any time during the voice prompts, enter a topic and subtopic number:

1 Autodial Features

- 1 Last Number Redial
- 2 Save Number Redial
- 3 Personal Speed Dial
- 4 Intercom Auto Dial
- 5 Outside Auto Dial

2 Internal Calls

- 1 Hands Free Answer on Intercom
- 2 Voice Interrupt On Busy
- 3 Group Page

3 Fixed Features

- 1 Transfer
- 2 Conference

4 About Your Phone

- 1 Buttons and Lights
- 2 Display
- 3 Speakerphone
- 4 Volume
- 5 Ring Patterns

One beep after an information segment means there is more information about the subtopic. Two beeps indicate the end of the information.

At one beep:

- Press (*) 4 to replay the previous segment.
or
- Press # to play the next segment.

At two beeps:

- Press (*) 4 to replay the previous segment.
or
- Press # to return to the main menu.



Programming a Voice Mail Messages Button

To program an Auto Dial button on your system phone for one-touch dialing into the PARTNER MAIL VS system:

- Press (Feature) 0 0.
- Press a programmable button.
- Press left (Intercom) 7 7 7.





Personal Speed Dial Numbers

To dial a Personal Speed Dial number: Press **(Feature)** followed by the two-digit Dial Code.
 See page 5 for programming instructions. Your system may also be programmed with System Speed Dial numbers (Dial Codes 20-79), which are similar to Personal Speed Dial numbers except anyone on the system can dial them. If programmed, a list is available from your System Manager.

Record your Personal Speed Dial numbers below, in pencil.

DIAL CODE	NAME	DIAL CODE	NAME
80		90	
81		91	
82		92	
83		93	
84		94	
85		95	
86		96	
87		97	
88		98	
89		99	

To call the receptionist at extension 10: Dial **(Intercom) 0** or **(Intercom) 1 0**.

System Extensions

EXT	NAME	EXT	NAME	EXT	NAME
10		26		42	
11		27		43	
12		28		44	
13		29		45	
14		30		46	
15		31		47	
16		32		48	
17		33		49	
18		34		50	
19		35		51	
20		36		52	
21		37		53	
22		38		54	
23		39		55	
24		40		56	
25		41		57	

* Shading indicates extensions that apply only to the PARTNER II system.

